

09/14/82

CYCLE 7 HELPFUL HINTS

This paper describes helpful hints on how to use Cycle 7 of NOS/VE. It is intended to supplement, rather than to replace, the standard NOS/VE documentation. If you have any questions or suggestions, please see Tom McGee or Bonnie Swierzbin. Appendix D lists background documents and how to obtain them.

To obtain additional copies of this document while running on SN101 at Arden Hills, please type:

```
SES,INT1.LISTHINTS C=<number of copies>
```

To obtain a copy with revision bars against the Helpful Hints of the previous build, one can type:

```
SES,INT1.LISTHINTS REVB C=<number of copies>
```

The C parameter is optional and defaults to one.

Update History

Date	Changes
12/22/80	Revisions for NOS/VE Phase C
2/12/81	Additional Revisions for NOS/VE Phase C
6/09/81	Revisions for NOS/VE Build N
6/19/81	Additional Revisions for NOS/VE Build N
8/28/81	Revisions for NOS/VE Build D
11/06/81	Revisions for NOS/VE Build P
3/01/82	Revisions for NOS/VE Build Q
4/15/82	Revisions for NOS/VE Cycle 2
5/01/82	Revisions for NOS/VE Cycle 3
6/30/82	Revisions for NOS/VE Cycle 5
7/29/82	Revisions for NOS/VE Cycle 7

1.0 MAJOR CHARACTERISTICS OF THIS BUILD

1.0 MAJOR_CHARACTERISTICS_OF_THIS_BUILD

- o Cycle 6 and subsequent cycles of NOS/VE are built to run with a NOS 6.1 base system and the DSD displays and commands have changed considerably from the NOS 5.3 base system used with Cycle 5. This hints document has been updated to reflect these changes where they affect NOS/VE, for instance, using the command NVEnnnn to bring up NOS/VE instead of cp.NVEnnnn. For more information on the NOS commands see BJ Swierzbis's memo of July 23 titled 'NOS 6.1 Notes', the NOS reference manuals listed in Appendix A, or the NOS R6 Software Release Bulletin.
- o To access NOS/VE interactively, the user must login to the application named VEIAF. For example: ,DAH,DAHX,VEIAF The previous application name was TAF.
- o With Cycle 7, the operator of the NOS/VE dual state system can simulate terminal breaks. She/he may issue at any time a *BREAK at the K display for the NVE job. This will start the terminal break, which works just like the interactive break. The broken command may be continued by issuing the resume_command (resc) or may be terminated by issuing the terminate_command (terc). If the command get_file is broken into, the command will be terminated by the Remote Host. After the DS proc has been executed, a terminal break at the command level will cause the SCL task to terminate. The job monitor task will restart the SCL task after a brief delay (up to 20 seconds).
- o Miscellaneous SCL Changes:
 - A RING parameter has been added to the TASK/TASKEND command. This parameter may be used to switch to a new ring of execution within the user's validated minimum_ring and nominal_ring.
 - A \$RING function has been added. It has no arguments and returns the current ring of execution.
 - Commands from user jobs are no longer written to the system log by default. This function is controlled by the new operator commands ACTIVATE_SYSTEM_LOGGING and DEACTIVATE_SYSTEM_LOGGING.

09/14/82

 1.0 MAJOR CHARACTERISTICS OF THIS BUILD

The abbreviation for the SKIP_TAPE command has been corrected to SKIT from SKIPT.

A new internal interface, CLP\$VALIDATE_NAME has been added. This is an INLINE procedure that should be used instead of the high overhead CLP\$CONVERT_STRING_TO_NAME. (See common deck CLXVN for interface details.)

o DISPLAY_FILE leaves the source file with an attribute of RT=U. This can be corrected by setting the RT attribute back to the correct value after the DISPLAY value: SETFA file RT=V

o COPY_FILE will not copy at EOI if it had been specified on the COPF command. The following sequence will accomplish copying at EOI:

```
SETFA dest_file OP=$EOI
COPF source_file dest_file
SETFA dest_file OP=$BOI
```

o The permanent file system has been modified to make files invisible when all cycles have been purged even if one or more of those cycles are still attached. This results in references to the file emitting an unknown file message as expected, rather than an unknown cycle message containing an invalid cycle number. It also prevents display catalog commands from showing the file as having zero cycles.

o The administer utility has been updated to correspond to Rev. 9 of the NOS/VE Command Interface ERS. Old command and parameter names are no longer supported.

o The TAFNVE operator command (TAF control point) is no longer required or available. The capabilities that were provided by it have been packaged within the NVE subsystem control point. The impact of this change is as follows:

- The K display is assigned to the same control point during both deadstart and normal system operation.
- Output from the system core debugger will no longer appear at the NVE control point K-display. All system core debugger communication is via the MDD terminal.
- The K.*BYEVE. command is no longer available.
- The OFFSW,jsn,6. command before doing a STOP,jsn. is not required to bring NVE down.

NOS/VE Cycle 7 Helpful Hints

09/14/82

1.0 MAJOR CHARACTERISTICS OF THIS BUILD

- All capabilities are available via the NVExxxx. ;
command. The NVE subsystem may be placed at any control ;
point (like NAM is).
- o Cycle 5 (actually Cycle 4) of NOS/VE no longer supports the
"old" command names for system commands. Both "old" and "new"
names have been supported since Build Q. See DAP ARH4776 for
details. As part of this change the abbreviations for the
COPY_FILE and PRINT_FILE commands have been corrected to COPF
and PRIF (from COPYF and PRINTF).
- o The EXPLAIN command was implemented in Cycle 4 of NOS/VE.
Don't get too excited about this, however, because as yet
there are no "explain level" message templates for any of the
system conditions. EXPLAIN will simply regurgitate the
regular message.

While implementing the EXPLAIN command it was discovered that
the specification of the command (i.e. that it have an
optional "condition" parameter) was not nearly as useful as
having the first parameter be a "status" value. So the
implementation deviates from the ERS in that the first
parameter to EXPLAIN is MESSAGE_STATUS or MS and is of kind
STATUS. The \$STATUS function can be used to transform a
"condition" into a "status". A DAP is being written to make
this change official.

- o NOS/VE multiple mass storage volumes have been implemented in
Cycle 5. For more information see the section 'Configuration
Management'.
- o The implicit attach process has been modified to choose share
mode to be the following function of access mode. If access
mode includes shorten, append or modify then share mode is
none, otherwise share mode is read and execute. This results
in allowing sharing of implicitly attached files that are not
being written but inhibiting sharing of implicitly attached
files that are being written.

The implicit attach process formerly chose share mode to be
the share requirements established by the permit mechanism.
The owner of files typically has no share requirements and
hence would implicitly attach the files for exclusive access.
This created a severe usability problem for code or command
files that were to be executed by multiple jobs.

- o An EDI problem exists with respect to a file shared between
jobs. An existing file is opened with an access mode of

09/14/82

1.0 MAJOR CHARACTERISTICS OF THIS BUILD

append by job A. The same file is opened with an access mode of read by job B. Job A extends the file and either explicitly closes the file or terminates. Job B explicitly closes the file or terminates. In this case, since the job accessing the file in read mode terminated after the job which extended the file, EDI on the file will be reset to the original position and the result of the extend will be lost.

- o The Interstate Communication Facility, which is described in Section 9 of the NOS/VE ERS - Program Interface (Rev. 8), has been implemented. The callable subroutines described in section 9.3 reside in User Library LINKLIB in the Integration catalogs INT1, DEV1, REL1, etc. NOS libraries SYSLIB and SRVLIB are also required to complete the loading process. LDSET loader commands must be used to select these libraries.
- o Interactive Usage Restrictions:
 - When logging in to NOS/VE (i.e. HELLO,VEIAF etc.) do not enter a terminate break (CTRL t) or a pause break (CTRL p) before the 'welcome message' appears at the terminal. A pause or terminate break entered before the interactive NOS/VE job has completed it's initialization may crash the system.
 - A REQUEST_TERMINAL command in a batch job will crash the system. This can happen accidentally through a REQUEST_TERMINAL command in a user prolog when the user runs a batch job since the prolog is executed for both interactive and batch jobs. The problem can be avoided by making the REQUEST_TERMINAL command in the prolog conditional on the job type as follows:

```
IF $JOB(MODE) <> 'BATCH' THEN
  REQUEST_TERMINAL
IFEND
```

- o Any product or utility that is placed in the \$SYSTEM catalog (or any frequently loaded program) should be bound using the CREATE_MODULE subcommand of the CREATE_OBJECT_LIBRARY utility. This will minimize overhead associated with loading the product or utility.
- o Debug responds to terminal breaks when a program is being debugged. However, entering a pause or terminate break when debug is active (i.e. the DB/ prompt has appeared and the user has not issued the RUN command) will cause the task to terminate.

09/14/82

1.0 MAJOR CHARACTERISTICS OF THIS BUILD

- o When sharing executable files via permanent files (i.e. compilers, libraries, etc.) you should make the file an object library via the CREATE_OBJECT_LIBRARY utility. By sharing object libraries instead of object files, the code is actually shared among all tasks using the library; the library is not copied to another segment but is executed directly.

1.1 NOS/VE_USAGE_EXAMPLES

1.1.1 EXECUTING PROGRAMS

PROCESS

Create an object text file by compiling a program on NOS. Then perform the following steps on NOS/VE:

- Acquire any necessary libraries (which are not quoted in text embedded directives) by either:
 - o Attaching them from the system catalog, either explicitly or via prolog
 - or
 - o Creating the library file via the object library generator
 - or
 - o Staging the library file from NOS to NOS/VE using the GET_OBJECT_LIBRARY command.
- Get the file from NOS and convert the object text file from the CI data mapping to II data mapping by executing the CONVERT_OBJECT_FILE command.
- Load and execute the program via the EXECUTE_TASK command, specifying the necessary libraries with the LIBRARY parameter; alternatively SET_PROGRAM_ATTRIBUTES may be used to include the libraries in all subsequent EXECUTE_TASK commands.
- Stage the loadmap from NOS/VE to NOS for printing by using either:
 - o The REPLACE_FILE command with A6 conversion mode specified if running on the simulator.
 - or
 - o The PRINT_FILE command if running on the hardware.

EXAMPLES

NDS/VE Cycle 7 Helpful Hints

09/14/82

1.0 MAJOR CHARACTERISTICS OF THIS BUILD

1.1.1 EXECUTING PROGRAMS

The following is an example command sequence for executing a program not requiring any libraries for loading:

Assumptions: all modules to be loaded are contained on the NDS permanent file 'citxtrs'.

```
CONVERT_OBJECT_FILE CITXTRS
EXECUTE_TASK CITXTRS PARAMETER='program parameters'
PRINT_FILE LOADMAP
```

The following is an example command sequence for executing a program requiring libraries for loading:

Assumptions: the NDS permanent file 'citxtrs' contains object text generated by the CYBIL CI compiler. The compiler modules reference procedures contained on the library 'mylib' and the CYBIL run-time library. These libraries have been generated on NDS/VE and saved on NDS.

```
GET_OBJECT_LIBRARY MYLIB
SET_PROGRAM_ATTRIBUTES LOAD_MAP_OPTIONS=(BLOCK,ENTRY_POINT,SEGMENT
CONVERT_OBJECT_FILE CITXTRS
EXECUTE_TASK CITXTRS 'program parameters' LIBRARY=MYLIB
PRINT_FILE LOADMAP
```

1.1.2 CREATE OBJECT LIBRARY ON NDS/VE AND SAVE IT ON NDS

Notes:

- o CLG0170 is NDS permanent file name for file containing CI object text for modules to be included in the library.
- o IITEXT180 is NDS/VE local file name for file containing II object text for modules to be included in the library.
- o LIBRARY180 is NDS/VE local file name for the library being created.
- o ILIB170 is NDS permanent file name for file containing the library.

NDS/VE Job Commands

```
CONVERT_OBJECT_FILE IITEXT180 CLG0170
CREATE_OBJECT_LIBRARY
ADD_MODULE LIBRARY=IITEXT180
```

NOS/VE Cycle 7 Helpful Hints

09/14/82

1.0 MAJOR CHARACTERISTICS OF THIS BUILD

1.1.2 CREATE OBJECT LIBRARY ON NOS/VE AND SAVE IT ON NOS

```

GENERATE_LIBRARY LIBRARY=LIBRARY180
QUIT
REPLACE_FILE LIBRARY180 ILIB170 DC=B56

```

1.1.3 MODIFY A PREVIOUSLY SAVED OBJECT LIBRARY

Notes:

- o ILIB170 is NOS permanent file name for file containing the old library
- o LIBRARY180 is NOS/VE local file name for file containing the old library
- o CMOD170 is NOS permanent file name for file containing CI object text for the new module
- o NEWIIMODULE is NOS/VE local file name for file containing II object text for the new module
- o NEWLIBRARY is NOS/VE local file name for the library being created
- o NLIB170 is NOS local file name for new library

NOS/VE Job Commands

```

GET_OBJECT_LIBRARY LIBRARY180 ILIB170
CONVERT_OBJECT_FILE NEWIIMODULE CMOD170
CREATE_OBJECT_LIBRARY
ADD_MODULE LIBRARY=LIBRARY180
REPLACE_MODULE LIBRARY=NEWIIMODULE
GENERATE_LIBRARY LIBRARY=NEWLIBRARY
QUIT
REPLACE_FILE NEWLIBRARY NLIB170 DC=B56

```

1.1.4 ROUTE AN INPUT FILE FROM NOS TO NOS/VE

Running from an interactive terminal, enter:

```

GET,filename.
ROUTE,filename,DC=LP,FC=RH.

```

The input file which is sent to NOS/VE must be in 6/12 ASCII (or display code subset). The job file must be a single

NOS/VE Cycle 7 Helpful Hints

09/14/82

1.0 MAJOR CHARACTERISTICS OF THIS BUILD

1.1.4 ROUTE AN INPUT FILE FROM NOS TO NOS/VE

partition NOS record containing NOS/VE commands. The first statement must be a valid LOGIN command with user, password and family name specified. Multi partition input files are not supported by NOS/VE so NOS data files used by the program must be obtained through the GET_FILE command.

1.1.5 PRINT A NOS/VE FILE

At NOS/VE job termination the job log will be automatically returned to NOS. The job log will be appended to the NOS/VE output file OUTPUT. NOS/VE print files must be written by BAM as 8/8 ASCII RT=V. Print files will be converted from 8/8 ASCII RT=V to NOS 8/12 ASCII when they are sent to NOS and will be printed in upper/lower case.

All NOS/VE output files will appear in the NOS output queue (NOS H,0 display) with the name IRHFxxx as a banner. In order to print a NOS/VE file, the following command must be issued within your job or be entered from the system console via the operator facility:

PRINT_FILE filename

2.0 COMMAND INTERFACE STATUS

2.0 COMMAND_INTERFACE_STATUS

2.1 ACCESS_TO_NOS/VE_IN_DUAL_STATE

2.1.1 LOGIN TO NOS/VE

To initially login to NOS/VE via VEIAF, you must cause the first login attempt to fail. This can be done by responding to the "FAMILY:" login prompt with something like: ",,,". This must be done because the system will try to connect the terminal to IAF on the first login attempt no matter what is typed. To access VEIAF do the following on the second "FAMILY:" prompt:

,user,password,VEIAF

You can access VEIAF from IAF by doing "HELLO,VEIAF" or by answering VEIAF to the system prompt "APPLICATION:".

2.1.2 TERMINAL USAGE

- 1) The slant (/) is the prompt to enter a NOS/VE command. Any normal NOS/VE command can now be entered (continuation lines are prompted with ../). The full ASCII character set, lower or upper case and all special characters, can be used.
- 2) A LOGOUT command will cause the NOS/VE Interactive Job to terminate. A new NOS/VE Interactive Job can then be started by responding to the 'APPLICATION:' prompt with VEIAF.
- 3) Terminal breaks (control-t and control-p) can be used to terminate a task or command and suspend a task and enter a new task to process SCL commands. Control-t causes a terminate break and control-p causes a pause break. Terminate break will terminate a command or the most recently executed task. A pause break will suspend execution and allow commands to be entered. When a

09/14/82

 2.0 COMMAND INTERFACE STATUS

2.1.2 TERMINAL USAGE

terminal is in pause break state, two additional commands are available:

RESUME_COMMAND - resume execution at the point of interruption.

TERMINATE_COMMAND - cause a terminate break condition as a terminate break had been entered.

Both terminate break and pause break are available to programs as conditions via the program management condition mechanism.

2.1.3 NDS/VE PROGRAM ACCESS TO THE TERMINAL

- 1) Interactive NDS/VE jobs are able to obtain terminal input through the AMP\$GET_NEXT or AMP\$GET_PARTIAL program interface which can be used by both task services and user ring programs. Interactive programs which use this interface should be able to handle both upper and lower case input in order to make them more convenient to use in both 64 and 96 character set modes.

2.2 COMMAND_AND_PARAMETER_NAMES

During the next few months a command supported by the system may not be in sync with your command interface document. The parameter descriptor table gives an accurate, concise description of the command interface as currently supported.

PDI_Reader's_Guide

The definition of a command's parameter list is enclosed in parenthesis with a parameter description per line. Each description has the general form:

PARAMETER NAME: ALLOWED PARAMETER VALUES = PARAMETER DEFAULT VALUE

Parameter Names - describes the parameter name and any abbreviations.

ALLOWED PARAMETER VALUES - describes the kind of value allowed and whether a list of values is possible. The value kind can be

09/14/82

2.0 COMMAND INTERFACE STATUS

2.2 COMMAND AND PARAMETER NAMES

further qualified. In some cases, the actual values allowed are described using the KEY notation. The value kinds include INTEGER, STRING, NAME, FILE, STATUS.

PARAMETER DEFAULT VALUES - describes the defaulting rules and/or values for the parameter. \$REQUIRED and \$OPTIONAL are obvious. Other values in this position will be treated as if they were entered by the user on command invocation.

See the PROC command in the Command Interface ERS for more details.

The PDTs for the commands currently in the system can be displayed using the DISPLAY_COMMAND_INFORMATION command. This is documented in the nonstandard command section of this document.

2.3 COMMAND_FUNCTIONS

Function	Status
\$MOD	unchanged
\$CHAR	unchanged
\$CLOCK	unchanged
\$DATE	unchanged
\$FILE	unchanged
\$FNAME	unchanged
\$INTEGER	unchanged
\$NAME	unchanged
\$ORD	unchanged
\$REAL	unchanged
\$STRING	unchanged
\$STRLEN	unchanged
\$STRREP	unchanged
\$SUBSTR	unchanged
\$UNIQUE	unchanged
\$TIME	unchanged
\$VAR	unchanged
\$SPECIFIED	unchanged
\$SET_COUNT	unchanged
\$VALUE_COUNT	unchanged
\$RANGE	unchanged
\$PARAMETER_LIST	unchanged
\$PARAMETER	unchanged
\$STATUS	unchanged
\$CONDITION	unchanged
\$SEVERITY	unchanged
\$PROCESSOR	unchanged

NOS/VE Cycle 7 Helpful Hints

09/14/82

2.0 COMMAND INTERFACE STATUS

2.3 COMMAND FUNCTIONS

\$JOB	unchanged
\$PROGRAM	unchanged

2.4 SYSTEM_ACCESS_COMMANDS

Commands	Status
SET_LINK_ATTRIBUTES	unchanged
LOGIN	unchanged - *1
LOGOUT	unchanged
SET_PASSWORD	unchanged

- *1 The family name of the job doing the submit will be used as the default family name on batch jobs. The default for jobs submitted from NOS will be family \$SYSTEM. This effectively means that whenever NOS/VE jobs are submitted from NOS the family parameter is required.

2.5 RESOURCE_MANAGEMENT

Command	Status
REQUEST_TERMINAL	unchanged

2.6 FILE_MANAGEMENT

Command	Status
SET_FILE_ATTRIBUTES	unchanged
COPY_FILE	unchanged
DISPLAY_FILE	unchanged
COMPARE_FILE	unchanged
DISPLAY_FILE_ATTRIBUTES	unchanged
SKIP_TAPE	unchanged

2.7 PERMANENT_FILE_MANAGEMENT

Command	Status
GET_FILE	unchanged
REPLACE_FILE	unchanged
CREATE_FILE	unchanged

09/14/82

2.0 COMMAND INTERFACE STATUS

2.7 PERMANENT FILE MANAGEMENT

ATTACH_FILE	unchanged
DELETE_FILE	unchanged
CHANGE_CATALOG_ENTRY	unchanged
CREATE_FILE_PERMIT	unchanged
DELETE_FILE_PERMIT	unchanged
CREATE_CATALOG	unchanged
DELETE_CATALOG	unchanged
DELETE_CATALOG_PERMIT	unchanged
CREATE_PERMIT_CATALOG	unchanged
DISPLAY_CATALOG	unchanged
DISPLAY_CATALOG_ENTRY	unchanged
SET_WORKING_CATALOG	unchanged

2.8 SQL STATEMENTS AND PROCEDURES

Command	Status
PROC/PROCEND	unchanged
SET_COMMAND_LIST	unchanged
DISPLAY_COMMAND_LIST	unchanged
REPEAT/UNTIL	unchanged
WHILE/WHILEND	unchanged
CREATE_VARIABLE	unchanged
DELETE_VARIABLE	unchanged
BLOCK/BLOCKEND	unchanged
LOOP/LOOPEND	unchanged
FOR/FOREND	unchanged
IF/ELSEIF/ELSE/IFEND	unchanged
CYCLE	unchanged
EXIT	unchanged
WHEN/WHENEND	unchanged
CONTINUE	unchanged
CANCEL	unchanged
INCLUDE_FILE	unchanged
COLLECT_TEXT	unchanged
DISPLAY_VALUE	unchanged
EXIT_PROC	unchanged
ACCEPT_LINE	unchanged
INCLUDE_LINE	unchanged
CREATE_FILE_CONNECTION	unchanged
DELETE_FILE_CONNECTION	unchanged
DISPLAY_FILE_CONNECTION	unchanged
change HCS variable	unchanged
display HCS variable	unchanged

09/14/82

2.0 COMMAND INTERFACE STATUS

2.9 INTERACTIVE COMMANDS

2.9 INTERACTIVE_COMMANDS

Command	Status
RESUME_COMMAND	unchanged
TERMINATE_COMMAND	unchanged
SET_TERMINAL_ATTRIBUTES	unchanged
DISPLAY_TERMINAL_ATTRIBUTES	unchanged
esc-e	new - 1*
esc-l	new - 1*
esc-j	new - 1*
esc-t	new - 1*
esc-x	new - 1*

*1 These commands are entered with the 3-key sequence: escape_key, character, carriage_return. The characters have the following meanings:

e	perform "display_job_status" command
l	perform "display_log 10" command
j	perform "display_job_status all" command
t	discard all unprocessed, typed-ahead input
x	terminate job, but do not disconnect

2.10 OBJECT_CODE_MAINTENANCE

Command	Status
CREATE_OBJECT_LIBRARY	unchanged
DISPLAY_NEW_LIBRARY	unchanged
SELECT_DISPLAY_OPTION	unchanged
ADD_MODULE	unchanged
REPLACE_MODULE	unchanged
COMBINE_MODULE	unchanged
CREATE_MODULE	unchanged
BIND_MODULE	unchanged
CREATE_PROGRAM_DESCRIPTION	unchanged
DELETE_MODULE	unchanged
CHANGE_MODULE_ATTRIBUTE	unchanged
SATISFY_EXTERNAL_REFERENCES	unchanged
REORDER_MODULE	unchanged
GENERATE_LIBRARY	unchanged
DISPLAY_OBJECT_LIBRARY	unchanged
COMPARE_OBJECT_LIBRARY	unchanged
QUIT	unchanged
CI to II Conversion	unchanged

09/14/82

2.0 COMMAND INTERFACE STATUS

2.11 USER SERVICES

2.11 USER_SERVICES

Command	Status
DISPLAY_LOG	unchanged
DISPLAY_MESSAGE	unchanged

2.12 FILE_ROUTING

Command	Status
HCS JMROUTE	removed

2.13 PROGRAM_EXECUTION

Command	Status
SET_PROGRAM_ATTRIBUTES	unchanged
DISPLAY_PROGRAM	unchanged
EXECUTE	unchanged
"name call"	unchanged - *1
TASK/TASKEND	unchanged
TERMINATE_TASK	unchanged
WAIT	unchanged
SET_DEBUG_RING	unchanged
DISPLAY_ACTIVE_TASKS	unchanged

*1 Warning - "name call" works only for SCL procedures unless a SETFA command has been issued to specify that the FILE_CONTENTS are OBJECT and the FILE_ORGANIZATION is DATA or LIBRARY. The SETFA command must be reissued every time the file is brought over from NOS. The CONVERT_OBJECT_FILE, GET_OBJECT_FILE, and GET_OBJECT_LIBRARY nonstandard commands issue the appropriate SET_FILE_ATTRIBUTES command and are therefore recommended.

2.14 JOB_MANAGEMENT

Command	Status
SUBMIT_JOB	unchanged
DISPLAY_JOB_STATUS	unchanged
TERMINATE_JOB	unchanged
PRINT_FILE	unchanged
TERMINATE_PRINT	unchanged
DISPLAY_PRINT_STATUS	unchanged

09/14/82

.....

2.0 COMMAND INTERFACE STATUS

2.15 NON STANDARD COMMANDS

.....

2.15 NON_STANDARD_COMMANDS

The following commands provide a nonstandard means of performing various frequently performed functions. They may be superceded in subsequent builds by standard commands and capabilities.

2.15.1 DELETE_CATALOG_CONTENTS ; DELCC

The purpose of this command is to delete all entries from the specified catalog. This includes subcatalogs and the files they contain.

```
delete_catalog_contents [catalog=<catalog>]
                        [status=<status variable>]
```

catalogic: This parameter specifies from which catalog all files are to be deleted. Omission will cause the current working catalog to be used.

status: See ERROR HANDLING.

2.15.2 DISPLAY_ACTIVE_TASK ; DISAT

The purpose of this command is to display task statistics for all currently active tasks in a job. The following information is displayed.

```
task name
execution time use
number of page faults
```

```
display_active_task [output=<file>]
                    [status=<status variable>]
```

outputio: This parameter specifies the file to which the task statistics is displayed. Omission will cause \$OUTPUT to be used.

09/14/82

2.0 COMMAND INTERFACE STATUS

2.15.3 DISPLAY_SYSTEM_DATA : DISSD

2.15.3 DISPLAY_SYSTEM_DATA : DISSD

The purpose of this command is to display system page fault statistics and system monitor request statistics.

```
display_system_data [display_option=page_faults:pf
                    ;monitor_requests:mr:all
                    [display_format=incremental:ii:total:it]
                    [output=<file>]
                    [status=<status variable>]
```

display_option:do: This parameter specifies which statistics are to be displayed. The following options are allowed :

page_faults - display the page fault statistics.

monitor_requests - display the system monitor request statistics.

Omission will cause ALL to be used.

display_format:df: This parameter specifies whether a display of the all statistics recorded so far (total) or only those statistics recorded since the last `display_system_data` command (incremental) should be displayed. Omission will cause incremental to be used.

output:io: This parameter specifies the file to which the system data will be displayed. Omission will cause \$OUTPUT to be used.

status: See ERROR HANDLING.

2.15.4 DISPLAY_JOB_DATA : DISJD

The purpose of this command is to display the following job related statistics:

09/14/82

2.0 COMMAND INTERFACE STATUS

2.15.4 DISPLAY_JOB_DATA ; DISJD

```

time in job mode
time in monitor mode
count of page in operations
reclaimed pages
new pages assigned
working set size
count of ready tasks

```

```

display_job_data [display_option=job_data]
                  [display_format=incremental|total]
                  [output=<file>]
                  [status=<status variable>]

```

display_option!do: This parameter specifies which statistics are to be displayed. The following options are allowed:

job_data - display job related data.

Omission will cause job_data to be used.

display_format!df: This parameter specifies whether a display of the all statistics recorded so far (total) or only those statistics recorded since the last display_job_data command (incremental) should be displayed. Omission will cause incremental to be used.

output!o: This parameter specifies the file to which the job data will be displayed. Omission will cause \$OUTPUT to be used.

status: See ERROR HANDLING.

2.15.5 DISPLAY_COMMAND_INFORMATION ; DISCI

The purpose of this command is to display current information about a NDS/VE command. The parameter names, abbreviations, allowed values and known problems for a command, as supported in the current system, can be determined. This is a nonstandard command and will be replaced by the help utility sometime in the future.

```

display_command_information command_name=<name>!all
                            [utility_name=create_object_library]

```

09/14/82

2.0 COMMAND INTERFACE STATUS

2.15.5 DISPLAY_COMMAND_INFORMATION : DISCI

```

                col:source_code_utility!scu!system]
[display_option=parameter_description_table!
                pdt!notes!names!help]
[output=<file reference>]
[status=<status variable>]

```

- command_name!cn:** This parameter specifies the name of the command about which information is to be displayed.
- utility_name!un:** This parameter specifies which utility the command belongs to. Omission will cause SYSTEM to be used.
- display_option!do:** This parameter specifies the type of display being requested. The options are:
- parameter_description_table!pdt - selects a display of the parameter description table used by the command when executed.
- notes - selects a display of any known problems with the command.
- names - selects a display of the command names for a utility.
- help - selects a display of the command interface description of the command.
- Omission will cause PDT to be used.
- output!o:** This parameter specifies the file to which information will be displayed. Omission will cause \$OUTPUT to be used.
- status:** See ERROR HANDLING.

2.15.6 CONVERT_OBJECT_FILE : CONOF

The purpose of this command is to get a NOS/VE object file produced on NOS and to convert it to an object file suitable for processing by the NOS/VE loader or object code maintenance commands.

```
convert_object_file to=<file reference>
```

09/14/82

2.0 COMMAND INTERFACE STATUS
 2.15.6 CONVERT_OBJECT_FILE ! CONOF

```
[from=<name>]
[user=<name>]
[status=<status variable>]
```

- to!f:** This parameter specifies the NOS/VE file name on which the converted object file is to be written.
- from!f:** This parameter specifies the name of the NOS file to be converted. This is the permanent file name as defined in the NOS file system and can be up to seven characters in length.
- Omission will cause the permanent file name of the TO parameter to be used.
- user!u:** This parameter specifies the NOS user identification of the owner of the file. This parameter is only necessary if the file is in a catalog other than the user who was specified by the most recently issued SET_LINK_ATTRIBUTES command.
- status:** See ERROR HANDLING.

2.15.7 GET_OBJECT_FILE ! GETOF

The purpose of this command is to get a previously converted NOS/VE object file from the NOS side and sets the appropriate file attributes that will allow the object file to be used by NOS/VE.

```
get_object_file to=<file reference>
                [from=<name>]
                [user=<name>]
                [status=<status variable>]
```

- to!f:** This parameter specifies the NOS/VE file name of the object file.
- from!f:** This parameter specifies the NOS file name of the object file. This is the permanent file name as defined in NOS and can be up to seven characters in length.
- Omission will cause the permanent file name of the TO parameter to be used.
- user!u:** This parameter specifies the NOS user identification

09/14/82

 2.0 COMMAND INTERFACE STATUS

2.15.7 GET_OBJECT_FILE : GETOF

of the owner of the file. This parameter is only necessary if the file is in a catalog other than the user who was specified by the most recently issued SET_LINK_ATTRIBUTES command.

status: See ERROR HANDLING.

2.15.8 GET_OBJECT_LIBRARY : GETOL

The purpose of this command is to get a previously created NOS/VE object library from the NOS side and set the appropriate file attributes that will allow the object library to be used on NOS/VE.

```
get_object_library to=<file reference>
                    [from=<name>]
                    [user=<name>]
                    [status=<status variable>]
```

to:t: This parameter specifies the NOS/VE file name of the object library.

from:f: This parameter specifies the NOS file name of the object file. This is the permanent file name as defined in NOS and can be up to seven characters in length.

Omission will cause the permanent file name of the TO parameter to be used.

user!u: This parameter specifies the NOS user identification of the owner of the file. This parameter is only necessary if the file is in a catalog other than the user who was specified on the most recently issued SET_LINK_ATTRIBUTES command.

status: See ERROR HANDLING.

2.15.9 DISPLAY_OBJECT_TEXT : DISOT

The purpose of this command is to produce a formatted display of the object text contained in an object file or object library produced on NOS/VE.

```
display_object_text file=<file>
```

09/14/82

 2.0 COMMAND INTERFACE STATUS

2.15.9 DISPLAY_OBJECT_TEXT ; DISOT

[output=<file reference>]
 [status=<status variable>]

file:f: This parameter specifies the object file or object library containing the object text to be listed.

output:o: This parameter specifies the file to which the display is to be written.

Omission will cause the file \$OUTPUT to be used.

status: See ERROR HANDLING.

2.15.10 GET_SOURCE_LIBRARY ; GETSL

The purpose of this command is to get a previously created SCU source library from the NOS side and set the appropriate file attributes that will allow the source library to be used on NOS/VE.

get_source_library to=<file reference>
 [from=<name>]
 [user=<name>]
 [status=<status variable>]

to:t: This parameter specifies the NOS/VE file name of the source library.

from:f: This parameter specifies the NOS file name of the source library. This is the permanent file name as defined in NOS and can be up to seven characters in length.

Omission will cause the permanent file name of the TO parameter to be used.

user:u: This parameter specifies the NOS user identification of the owner of the file. This parameter is only necessary if the file is in a catalog other than the user who was specified on the most recently issued SET_LINK_ATTRIBUTES command.

status: See ERROR HANDLING.

NDS/VE Cycle 7 Helpful Hints

09/14/82

2.0 COMMAND INTERFACE STATUS

2.15.11 EDIT_FILE : EDIF

2.15.11 EDIT_FILE : EDIF

The purpose of EDIT_FILE is to initiate the execution of the SCU editor on a text file. (For details see ARH3883.)

edit_file : edif - edit lines on a source file. (procedure file not necessarily in its final form)

parameters	defaults
file=file(source)	\$REQUIRED
[result=file(source)]	\$VALUE(FILE)
[input=file reference]	\$COMMAND
[output=file reference]	\$OUTPUT
[status]	--

2.15.12 JEDIT

The purpose of this command is to initiate execution of the JEDIT editor built by Jack Bohnhoff. Anyone wanting information about the editor should contact Jack.

jedit from=<file>
[status=<status variable>]

from!f: This parameter specifies the file to be edited. This file is rewritten after the editor terminates.

status: See ERROR HANDLING in the NOS/VE Command Interface.

2.15.13 DEBUG

The prototype R1 NOS/VE debugger is now available. Details on how to use the debugger can be found in the "CYBER 180 INTERACTIVE DEBUG External Reference Specification and User's Guide", Sunnyvale DCS number S4028.

NOS/VE Cycle 7 Helpful Hints

09/14/82

2.0 COMMAND INTERFACE STATUS

2.15.14 SET_LINK_ATTRIBUTES : SETLA

2.15.14 SET_LINK_ATTRIBUTES : SETLA

The SET_LINK_ATTRIBUTES command is the same as documented in the NOS/VE command interface with the exception that the CHARGE and PROJECT parameters are optional (and in fact not useful in the current environment since we disable that feature on the NOS side).

09/14/82

 3.0 PROGRAM INTERFACE STATUS

3.0 PROGRAM_INTERFACE_STATUS

The 'status' column indicates whether the procedure is unchanged from the previous build, modified from the previous build or not available in this build. Footnotes are numbered within each section.

3.1 COMMAND_PROCESSING

<u>Procedure</u>	<u>Status</u>
CLP\$SCAN_PARAM_LIST	unchanged
CLP\$TEST_PARAMETER	unchanged
CLP\$GET_KEYWORD	unchanged
CLP\$GET_SET_COUNT	unchanged
CLP\$GET_VALUE_COUNT	unchanged
CLP\$TEST_RANGE	unchanged
CLP\$GET_VALUE	unchanged
CLP\$CREATE_VARIABLE	unchanged
CLP\$DELETE_VARIABLE	unchanged
CLP\$READ_VARIABLE	unchanged
CLP\$WRITE_VARIABLE	unchanged
CLP\$SCAN_COMMAND_FILE	unchanged
CLP\$END_SCAN_COMMAND_FILE	unchanged
CLP\$SCAN_COMMAND_LINE	unchanged
CLP\$CREATE_FILE_CONNECTION	unchanged
CLP\$DELETE_FILE_CONNECTION	unchanged
CLP\$PUSH/POP_UTILITY	unchanged
CLP\$GET_COMMAND_ORIGIN	unchanged
CLP\$GET_DATA_LINE	unchanged
CLP\$SCAN_PRODC_DECLARATION	unchanged

;
;
;
;

3.2 MESSAGE_GENERATOR

<u>Procedure</u>	<u>Status</u>
OSP\$FORMAT_MESSAGE	unchanged
OSP\$SET_STATUS_ABNORMAL	unchanged
OSP\$APPEND_STATUS_PARAMETER	unchanged
OSP\$APPEND_STATUS_INTEGER	unchanged

09/14/82

3.0 PROGRAM INTERFACE STATUS

3.3 RESOURCE MANAGEMENT

3.3 RESOURCE_MANAGEMENT

<u>Procedure</u>	<u>Status</u>
RMP\$REQUEST_MASS_STORAGE	unchanged
RMP\$REQUEST_TERMINAL	unchanged

All terminal attributes can be specified on the RMP\$REQUEST_TERMINAL call but only the following are operational:

- o auto_input
- o transparent_mode
- o prompt_file
- o prompt_string

Files assigned to a terminal device can be accessed via the following BAM requests:

- o AMP\$OPEN
- o AMP\$GET_NEXT
- o AMP\$GET_DIRECT
- o AMP\$GET_PARTIAL
- o AMP\$PUT_NEXT
- o AMP\$PUT_DIRECT
- o AMP\$PUT_PARTIAL
- o AMP\$CLOSE
- o AMP\$REWIND
- o AMP\$SKIP
- o AMP\$SEEK_DIRECT

3.4 PROGRAM_EXECUTION

<u>Procedure</u>	<u>Status</u>
PMP\$EXIT	unchanged
PMP\$EXECUTE	unchanged
PMP\$TERMINATE	unchanged
PMP\$AWAIT_TASK_TERMINATION	unchanged
PMP\$MODULE_TABLE_ADDRESS	unchanged
PMP\$ENTRY_POINT_TABLE_ADDRESS	unchanged
PMP\$PUSH_TASK_DEBUG_MODE	unchanged
PMP\$SET_TASK_DEBUG_MODE	unchanged
PMP\$TASK_DEBUG_MODE_ON	unchanged
PMP\$SET_DEBUG_RING	unchanged
PMP\$DEBUG_RING	unchanged
PMP\$CHANGE_DEBUG_LIBRARY_LIST	unchanged
PMP\$PDP_TASK_DEBUG_MODE	unchanged

09/14/82

3.0 PROGRAM INTERFACE STATUS

3.5 PROGRAM COMMUNICATION

3.5 PROGRAM COMMUNICATION

<u>Procedure</u>	<u>Status</u>
OSP\$AWAIT_ACTIVITY_COMPLETION	unchanged
PMP\$DEFINE_QUEUE	unchanged
PMP\$REMOVE_QUEUE	unchanged
PMP\$CONNECT_QUEUE	unchanged
PMP\$DISCONNECT_QUEUE	unchanged
PMP\$SEND_TO_QUEUE	unchanged
PMP\$RECEIVE_FROM_QUEUE	unchanged
PMP\$STATUS_QUEUE	unchanged
PMP\$STATUS_QUEUES_DEFINED	unchanged
PMP\$GET_QUEUE_LIMITS	unchanged

3.6 CONDITION PROCESSING

<u>Procedure</u>	<u>Status</u>
PMP\$ESTABLISH_CONDITION_HANDLER	Added support of detected uncorrected error
PMP\$DISESTABLISH_COND_HANDLER	unchanged
PMP\$CAUSE_CONDITION	unchanged
PMP\$CONTINUE_TO_CAUSE	unchanged
PMP\$TEST_CONDITION_HANDLER	unchanged
PMP\$VALIDATE_PREVIOUS_SAVE_AREA	unchanged
PMP\$ESTABLISH_DEBUG_OFF	unchanged
OSP\$SET_STATUS_FROM_CONDITION	unchanged

3.7 PROGRAM SERVICES

<u>Procedure</u>	<u>Status</u>
PMP\$GENERATE_UNIQUE_NAME	unchanged
PMP\$GET_TIME	unchanged
PMP\$GET_MICROSECOND_CLOCK	unchanged
PMP\$GET_TASK_CP_TIME	unchanged
PMP\$GET_DATE	unchanged
PMP\$GET_USER_IDENTIFICATION	unchanged
PMP\$GET_ACCOUNT_PROJECT	unchanged
PMP\$GET_JOB_NAMES	unchanged
PMP\$GET_JOB_ID	unchanged
PMP\$GET_JOB_MODE	unchanged
PMP\$GET_PROGRAM	unchanged
PMP\$GET_TASK_ID	unchanged
PMP\$MANAGE_SENSE_SWITCHES	unchanged
PMP\$GET_OS_VERSION	unchanged

NDS/VE Cycle 7 Helpful Hints

09/14/82

3.0 PROGRAM INTERFACE STATUS

3.7 PROGRAM SERVICES

```

PMP$GET_PROCESSOR_ATTRIBUTES      unchanged
PMP$DEFINE_DEBUG_ENTRY            unchanged
PMP$GET_DEBUG_ENTRY               unchanged
PMP$MODIFY_DEBUG_ENTRY            unchanged
PMP$REMOVE_DEBUG_ENTRY            unchanged

```

3.8 LOGGING

Procedure	Status
PMP\$LOG	unchanged
PMP\$LLOG_ASCII	unchanged

3.9 FILE_MANAGEMENT

Procedure	Status
Sequential Access	unchanged
Byte_Addressable Access	unchanged
Record Access	unchanged
Segment Access	unchanged - #1
V_System Specified	unchanged
V_User Specified	unchanged
U_System Specified	unchanged
U_User Specified	unchanged
F_System Specified	unchanged
F_User Specified	unchanged
AMP\$DESCRIBE_NEW_FILE	deleted
AMP\$FILE	unchanged
AMP\$GET_FILE_ATTRIBUTES	unchanged
AMP\$FETCH	unchanged
AMP\$STORE	unchanged
AMP\$COPY_FILE	unchanged
AMP\$RENAME	unchanged
AMP\$RETURN_FILE	new name
AMP\$OPEN	unchanged
AMP\$CLOSE	unchanged
AMP\$FETCH_ACCESS_INFORMATION	unchanged
AMP\$SKIP	unchanged
AMP\$REWIND	#2
AMP\$WRITE_END_PARTITION	unchanged
AMP\$GET_NEXT	unchanged
AMP\$GET_DIRECT	unchanged
AMP\$GET_PARTIAL	unchanged
AMP\$PUT_NEXT	unchanged
AMP\$PUT_DIRECT	unchanged
AMP\$PUT_PARTIAL	unchanged - #3

NDS/VE Cycle 7 Helpful Hints

09/14/82

3.0 PROGRAM INTERFACE STATUS

3.9 FILE MANAGEMENT

```

AMP$SEEK_DIRECT                unchanged
AMP$GET_SEGMENT_POINTER        unchanged
AMP$SET_SEGMENT_EOI           unchanged
AMP$SET_SEGMENT_POSITION      unchanged
AMP$SET_LOCAL_NAME_ABNORMAL   unchanged
AMP$SET_FILE_INSTANCE_ABNORMAL unchanged
AMP$ACCESS_METHOD             unchanged
AMP$FETCH_FAP_POINTER         unchanged
AMP$STORE_FAP_POINTER         unchanged

```

- *1 Segment access If a segment access file is written and an AMP\$SET_SEGMENT_EOI is not issued to record the EOI, EOI remains zero. The highest page referenced is not yet used as the default EOI. This particularly affects those who wish to make heaps permanent because EOI is always zero for a heap.
- *2 AMP\$REWIND The WAIT parameter on the procedure call is not supported.
- *3 AMP\$PUT_PARTIAL PUT_PARTIAL with the TERM_OPTION = AMC\$TERMINATE does not act as a put_next if a preceding START was not issued.

3.10 PERMANENT_FILE_MANAGEMENT

Procedure	Status
PFP\$DEFINE	unchanged
PFP\$ATTACH	unchanged
PFP\$PURGE	unchanged
PFP\$CHANGE	unchanged
PFP\$PERMIT	unchanged
PFP\$DELETE_PERMIT	unchanged
PFP\$DEFINE_CATALOG	unchanged
PFP\$PURGE_CATALOG	unchanged
PFP\$PERMIT_CATALOG	unchanged
PFP\$DELETE_CATALOG_PERMIT	unchanged

3.11 MEMORY_MANAGEMENT

MMP\$ADVISE_IN	unchanged
MMP\$ADVISE_OUT	unchanged
MMP\$ADVISE_OUT_IN	unchanged
MMP\$WRITE_MODIFIED_PAGES	unchanged
MMP\$CREATE_SEGMENT	unchanged
MMP\$DELETE_SEGMENT	unchanged
MMP\$STORE_SEGMENT_ATTRIBUTES	unchanged
MMP\$FETCH_SEGMENT_ATTRIBUTES	unchanged

NOS/VE Cycle 7 Helpful Hints

09/14/82

3.0 PROGRAM INTERFACE STATUS

3.11 MEMORY MANAGEMENT

MMP\$VERIFY_ACCESS	unchanged
MMP\$FREE	unchanged
MMP\$LOCK_PAGES	number of locked pages per
MMP\$UNLOCK_PAGES	segment restricted to 32
MMP\$FETCH_PVA_UNWRITTEN_PAGES	unchanged

3.12 STATISTICS FACILITY

SFP\$ESTABLISH_STATISTIC	unchanged
SFP\$ENABLE_STATISTIC	unchanged
SFP\$DISABLE_STATISTIC	unchanged
SFP\$DISESTABLISH_STATISTIC	unchanged
SFP\$EMIT_STATISTIC	unchanged
SFP\$EMIT_SYSTEM_STATISTIC	unchanged

3.13 INTERACTIVE FACILITY

IFP\$TERMINAL	unchanged
IFP\$FETCH_TERMINAL	unchanged
IFP\$STORE_TERMINAL	unchanged
IFP\$GET_DEFLT_TERMINAL_ATTRIBUTES	unchanged
IFP\$GET_TERMINAL_ATTRIBUTES	unchanged
IFP\$ADVANCE	new - *1

*1 Only the option IFC\$ADVANCE_ALL_QUEUED_OUTPUT is supported.

3.14 NOS/VE EXCEPTIONS

The following summarizes the exception code ranges currently assigned to NOS/VE. These code ranges represent a finer breakdown than the one specified in the SIS for internal NOS/VE development purposes. However, it is important to remember that only the product identifiers documented in the SIS may appear in error messages.

Common Modules	9,000 - 9,999
Common Code Generator	8,000 - 8,999

NOS/VE Cycle 7 Helpful Hints

09/14/82

3.0 PROGRAM INTERFACE STATUS

3.14 NOS/VE EXCEPTIONS

Exception Code	Product Identifier	Product Name
1 - 158,999	Reserved	
159,000 - 159,999	SY	System Core
160,000 - 169,999	AM	Basic Access Methods
160,000 - 163,999	BA	Basic Access
164,000 - 164,999	LN	Local Name Mgr
165,000 - 165,999	JF	Job File Mgr
166,000 - 166,999	SR	Conversion Services
167,000 - 167,999	CM	Configuration Mgmt
170,000 - 179,999	CL	Command Language
180,000 - 189,999	JM	Job Management
190,000 - 199,999	LL	Loader
200,000 - 209,999	MM	Memory Management
200,000 - 204,999	MM	Monitor Level
205,000 - 205,999	MM	Task Level
210,000 - 219,999	OS	Operating System
210,000 - 210,999	OS	OS
211,000 - 211,999	MT	EXEC
212,000 - 212,999	IO	MS I/O
213,000 - 213,999	IO	Tape I/O
214,000 - 214,999	DM	Device Management
215,000 - 215,999	ML	Memory Link
216,000 - 216,999	IF	Interactive
217,000 - 217,999	TM	TM Monitor
218,000 - 218,999	TM	TM Task
219,000 - 219,999	JS	Job Swappers
220,000 - 229,999	PF	Permanent File Management
221,000 - 221,999	ST	Set Management
222,000 - 222,999	PU	Permanent File Utilities
230,000 - 239,999	PM	Program Management
240,000 - 249,999	RM	Resource Management
250,000 - 259,999	OF	Operator Facility
260,000 - 269,999	AV	User Administrator
270,000 - 279,999	IC	Interstate Communication
280,000 - 289,999	RH	Remote Host Facility
290,000 - 299,999	OC	Object Code Utilities
300,000 - 309,999	DB	Deadstart/Recovery
310,000 - 319,999	MS	Maintenance Services
320,000 - 329,999	Reserved	
340,000 - 349,999	SF	Statistics Fac.
330,000 - 339,999	US	User Errors
500,000 - 509,999	AA	Advanced Access Method
510,000 - 519,999	AG	ALGOL
520,000 - 529,999	AL	Assembly Language
530,000 - 539,999	AP	APL
540,000 - 549,999	BA	BASIC

NOS/VE Cycle 7 Helpful Hints

09/14/82

3.0 PROGRAM INTERFACE STATUS

3.14 NOS/VE EXCEPTIONS

550,000 - 559,999	CA	Conversion Aids System
560,000 - 569,999	CB	COBOL
570,000 - 579,999	CY	CYBIL
580,000 - 589,999	FT	FORTRAN
590,000 - 599,999	PA	PASCAL (Wirth)
600,000 - 609,999	PI	PL/1
610,000 - 619,999	SM	Sort Merge
620,000 - 629,999	SC	Source Code Utility
640,000 - 649,999	DB	Debug

4.0 DUAL STATE DEADSTART AND OPERATION

4.0 DUAL STATE DEADSTART AND OPERATION

4.1 CURRENT DUAL STATE CONFIGURATION

The Arden Hills S2 development systems are configured to run with three FMD units.

o FMD Unit 43

This unit contains NOS permanent files.

o FMD Unit 41

This unit contains the following:

- Files required to deadstart dual state Cycle 5; A170 NOS (5.3 plus changes necessary for Cycle 5), CTI, MSL, EI binaries, and NOS Deadstart files.
- It is also used as a temp device.

o FMD Unit 42

This unit contains NOS permanent files.

o FMD Unit 44

This is another NOS PF device.

o FMD Unit 45

This is another NOS temp device.

4.2 USER NAMES AND PERMANENT FILES

1) The convention used for creating user names on NOS/VE is as follows:

- o Your user name will be your initials.
- o Your password will be these 3 letters followed by the

09/14/82

 4.0 DUAL STATE DEADSTART AND OPERATION

4.2 USER NAMES AND PERMANENT FILES

letter 'x'.

- o You must see COMSOURCE (R.K. Cooper - x3092) to be assigned a user index

2) PF dumping and loading

You may use "SES.DUMPPF" on SN/101 to dump your permanent files to tape, and then load them onto your user name on A170 NOS using "SES.LOADPF". Documentation on how to use these SES procedures and what their parameters are is included in the SES User's Guide, or they can be obtained by typing:

SES,HELP.DUMPPF and SES,HELP.LOADPF.

4.3 ID_RELOAD_CONTROLWARE_FOR_THE_NOS/VE_DISK_DRIVER

At deadstart time NOS will automatically load 7155-1x disk controlware on one channel with controller type=FM (LBC CMRdeck entry), and will automatically load 7155-4x disk controlware on any channel with controller type=HT (LBC CMRdeck entry). NOS/VE supports both of those types of controllers. NOTE: It is not possible to use 844 half-track controlware in this environment.

4.4 A170_NOS_DEADSTART

4.4.1 CTI AND CHECKING CENTRAL MEMORY

Deadstarting A170 NOS assumes some knowledge of CTI. CTI stands for Common Test and Initialization. It is software that places an 800 series machine in a state such that it is possible to deadstart an operating system. CTI is used somewhat ambiguously in the software community to imply CTI and MSL (Maintenance Software Library). The MSL is a collection of programs and data that includes such things as a subset of CMSE (Cyber Maintenance Software Executive) that enables one to load controlware to controllers, look at CYBER 180 maintenance registers, look at microcode, etc. The MSL also contains microcode that can be loaded by CTI. The MSL is actually an operating system that runs independently of NOS. An important element of CTI/MSL is HIVS (Hardware Verification Sequence), which is a program that loads microcode, clears and checks central memory and tests all 170 opcodes. If you are not sure what the machine was used for (particularly the first hands on

NOS/VE Cycle 7 Helpful Hints

09/14/82

4.0 DUAL STATE DEADSTART AND OPERATION4.4.1 CTI AND CHECKING CENTRAL MEMORY

user each morning) then the HIVS program should be run. This is accomplished by:

- 1) deadstart to NOS/VE (unit 40 for S3, unit 41 for S2)
- 2) Enter 0 (operator intervention)
- 3) Enter P (deadstart panel, make sure level 0 deadstart)
- 4) <BKSP>
- 5) Enter H (assure yourself that CS=YES to reload microcode)
- 6) <BKSP>
- 7) Enter V (verification sequence)
- 8) Hit <CR> at 'parameter display' to test CM & CP

When you see text that tells you that verification is complete and a deadstart is required, you are now ready to deadstart NOS.

4.4.2 NOS DEADSTART

See Section 3.3 of the Integration Procedures Notebook for important NOS CMRDECK changes.

- o Set the D/S panel to deadstart from the primary system disk. ;
- This is Unit 41 for all Cycle 5 systems. ;
- o Push D/S button
- o Enter (CR)
- o Enter date/time

Wait for deadstart to complete.

Note: The deadstart tape DUAL5 (which is currently installed on ;
unit 41) is found in the area in the northeast corner of the S2 ;
lab where the tape cabinet is found. ;

4.5 NOS/VE_DEADSTART_AND_INSTALLATION

- o Enter DOWN,CH2. so NOS/VE can use the channel.
- o Enter DOWN,CH32. so NOS/VE can use the channel.

09/14/82

.....

4.0 DUAL STATE DEADSTART AND OPERATION

4.5 NOS/VE DEADSTART AND INSTALLATION

.....

- o The following file must be available in your catalog on the S2:

TPXXXK contains a NOS/VE deadstart image. This must be a copy of the dual state deadstart images available from the link procedures.

- o If you've never deadstarted NOS/VE from the user number from which you want to run or if you wish to change the current parameter settings for your particular user number, then do a SETVE. SETVE assumes the file TPXXXK is in your user number; you do not have to do another SETVE if TPXXXK has changed since the last time you ran. The general form of SETVE is:

X.SETVE(PN=ffff,UN=un,C=6)

where ffff is an identifier of up to 4 characters and un is the user number to search first for files. 6 is the number of the system core command deck for the Arden Hills S2 configuration. Warning: Specifying C=6 on the Arden Hills S3 will destroy the closed shop permanent file base. In general ffff and un will be the same, e.g. X.SETVE(DAH,UN=DAH,C=6)

Only ONE SETVE should be done for each user number and a SETVE should NOT be done for ANY Integration user number except by the Integration project.

SEE SECTION 5.1 FOR MORE DETAILS.

- o Bring up dual state:

NVEffff.

where ffff is the identifier specified in SETVE, e.g. NVEINT1.

- o Bring up the Operator Facility

Enter K,NVE.

NOS/VE is currently generated and initialized on both NOS and NOS/VE. All source and object libraries that make up the NOS/VE system are produced on NOS and therefore must be converted from their CI to II counterparts. Other parts of installing and initializing the system (e.g. building the \$SYSTEM catalog) are performed by command language procedures on NOS/VE. Since the same system will many times in a closed shop environment, it is advantageous to only perform the conversion from CI to II a single time; save the results in

09/14/82

 4.0 DUAL STATE DEADSTART AND OPERATION

4.5 NOS/VE DEADSTART AND INSTALLATION

the NOS file system and then simply bring the files back during deadstart.

The actual files that get installed and loaded on each deadstart are determined by a command language procedure (the system profile) interpreted on NOS/VE. This procedure can be modified by each site to initialize their NOS/VE environment in the most suitable fashion. The process of building the system profile and of performing the CI to II conversions is referred to as an installation deadstart and the process of executing the system profile and of fetching previously converted files from NOS and making them available in the NOS/VE file system is referred to as a deadstart. A single command is available to perform both an installation deadstart and a deadstart.

4.5.1 THE DS PROCEDURE

The purpose of this command is to perform an installation, normal or recovery deadstart of NOS/VE. The defaults for parameters are those most convenient for "closed shop" deadstarts.

The procedure "brings up" the job log display on the left screen where the progress of the procedure may be watched, and the control point display on the right screen. Just before the procedure completes it changes the left screen to display the system log and writes to that log the message:

```
'---- Deadstart Completed ----'
```

at which point the operator may enter commands.

```
ds [kind=install ; normal ; recover]
   [get_source_libraries=<boolean>]
   [get_products=<boolean>]
   [echo=<boolean>]
   [alternate_user=<NOS_user_name>]
   [save_install_files=<boolean>]
   [validate_users=<boolean>]
   [quick_validate=list of <name>]
   [debug=<boolean>]
   [help=<file reference>]
   [status=<status variable>]
```

kind : k: This parameter specifies what kind of deadstart is

09/14/82

 4.0 DUAL STATE DEADSTART AND OPERATION

4.5.1 THE DS PROCEDURE

to be performed. Valid specifications are:

install ; i - installation deadstart to be performed.
 The system libraries are built from CI object files.

normal ; n - normal deadstart to be performed. The system libraries are obtained from the results of a previous installation deadstart.

recover ; r - recovery deadstart. Just initiates system tasks. Permanent files are "recovered" from a previous run of the system.

Omission will cause a recovery deadstart to be performed.

get_source_libraries ; gsl: This parameter specifies whether SCU libraries are to be installed. Valid specifications are:

true ; yes ; on - libraries are to be installed

false ; no ; off - libraries are not to be installed

On the Arden Hills closed shop S2 system, the SCU libraries to be installed are:

OSFPIL -> OSF\$PROGRAM_INTERFACE_LIBRARY: operating system program interface

OSFSL -> OSF\$SOURCE_LIBRARY: subset of operating system source library

Omission will cause SCU libraries to be installed.

get_products ; gp: This parameter specifies whether the object libraries defining the current product set are to be installed. Valid specifications are:

true ; yes ; on - the products are to be installed

false ; no ; off - the products are not to be installed

On the Arden Hills closed shop S2 system, the product set to be installed consists of:

CYFIIC -> CYF\$COMPILER: cybil II compiler

09/14/82

 4.0 DUAL STATE DEADSTART AND OPERATION

4.5.1 THE DS PROCEDURE

CCFRTL -> CCF\$RUN_TIME_LIBRARY: common compiler modules
 run time library

MLFRTL -> MLF\$RUN_TIME_LIBRARY: math run time library

DBFDL -> DBF\$DEBUG_LIBRARY: symbolic debug library

SCFOL -> SCF\$OBJECT_LIBRARY: source code utility

SCFCL -> SCF\$COMMAND_LIBRARY: source code utility
 "stand-alone" command library

IFFEDIT -> IFF\$EDITOR: Jack Bohnhoff's editor (JEDIT)

Omission will cause the product set to be installed.

echo ; e: This parameter specifies whether the commands should
 be echoed to the console during execution. Valid
 specifications are:

true ; yes ; on - echo commands

false ; no ; off - do not echo commands

Omission will cause commands not to be echoed.

alternate_user ; au: This parameter specifies what NOS user to
 check if the default NVE user does not have the needed
 file. Any NOS user name is allowed.

Omission will cause INT1 to be used.

save_install_files ; sif: This parameter specifies whether to
 save the system libraries created by an installation
 deadstart. This parameter is ignored for a normal or
 recovery deadstart. Valid specifications are:

true ; yes ; on - save the installed system libraries

false ; no ; off - do not save the installed system
 libraries

Omission will cause the files not to be saved.

validate_users ; vu: This parameter specifies whether to run
 the job that validates NOS/VE users. This parameter is
 ignored for a recovery deadstart. Valid specifications
 are:

09/14/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.5.1 THE DS PROCEDURE

true ; yes ; on - run the validation job

false ; no ; off - do not run the validation job

Omission will cause the validation job to be run.

quick_validate ; qv: This parameter determines which users will be validated by the validation job if it is run. When specified, this parameter gives a list of user names to be validated in addition to the users: INT1, INT2, DEV1, DEV2, REL1, EVAL and RKC.

Omission will cause all users to be validated.

debug ; d: This parameter specifies whether the procedure should abort if an error condition is detected. Valid specifications are:

true ; yes ; on - do not abort on an error. The user will be prompted for commands in the event of an error at which time entering "continue" will cause processing to resume.

false ; no ; off - abort on an error

Omission will cause the procedure to abort when an error is encountered.

help ; h: This parameter specifies whether help information is to be written. If this parameter is specified, the help information will be written to the specified file and the procedure will terminate.

Omission will cause the procedure to execute and the help information not to be written.

status: See ERROR HANDLING in the NOS/VE ERS.

If you change any of the following decks you MUST use the installation deadstart from your own catalog (with files :
CYBILGO, XLJOCM, XLJDSL and XLJLIB), or you must use the :
alternate_user parameter to specify a NOS catalog containing :
the files (e.g. DEV1).

AVMUTIL CLMDP DMMDISA ICMCLOS ICMFAI ICMFAPC ICMFLSH ICMGET
ICMOPEN ICMPUT ICMWEOP IFMEXEC IIMA72H IIMDC2S IIMRLE
IIMRSE IIMRUM IIMRUSM IIMTDEL OCMADD OCMBIM OCMBIM OCMCOL
OCMCOM OCMCPY OCMCRM OCMDEF OCMDEL OCMDLB OCMDNL

NOS/VE Cycle 7 Helpful Hints

09/14/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.5.1 THE DS PROCEDURE

```

OCMDOL  OCMEND  OCMGEN  OCMLCH  OCMLMG  OCMLP   OCMMUR
OCMNP   OCMOBJ  OCMOFH  OCMOMS  OCMRCH  OCMRED  OCMREP  OCMRMB
OCMSAT  OCMSOL  OCMVEL  OCMVLU  OCMVOL  PFMDC   PFMTALL
PUMBCAT PUMBCYC PUMBFIL PUMBFO  PUMBLST PUMBPFF PUMBSET
PUMCOMN PUMCRAK PUMPURG PUMCRAK PUMIOBF PUMLIST PUMMISC
PUMPURG PUMRALL PUMRCAT PUMREC  PUMREF  PUMRFIL PUMRPF
PUMSTUB RHMLML  RHMQAT  RHMQOP  RHMORE  RHMSFM  USORT   UTMDUR
UTMPC1  UTMPC2  UTMPC3  UTMPC4  UTMPC5  UTMTSA  UUSER1

```

4.5.2 EXAMPLE OF NOS/VE INSTALLATION DEADSTART

Type

```

K,NVE.
K.SETLA (your_un,NVE) your_password
K.GETF DS U=scat
K.DS INSTALL GSL=NO GP=NO AU=scat

```

4.5.3 EXAMPLE OF NOS/VE "NORMAL" DEADSTART

The Integration system has had the installation deadstart run on it. Also the files produced by the installation deadstart have been made semi-private and are found on the catalog used in the NVExxxx call.

Type (where DEV1 is the same as the xxxx in the NVExxxx call):

```

K,NVE.
K.SETLA (DEV1,NVE) DEV1X
K.GETF DS
K.DS NORMAL

```

4.5.4 EXAMPLE OF NOS/VE RECOVERY DEADSTART

This is the kind of deadstart that should most frequently be done in a "closed shop" environment and consequently is the one for which all the parameter defaults are oriented. It presupposes that permanent file recovery has been successful.

Type (where DEV1 is the same as the xxxx in the NVExxxx call):

```

K,NVE.
K.SETLA (DEV1,NVE) DEV1X
K.GETF DS

```

NOS/VE Cycle 7 Helpful Hints

09/14/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.5.4 EXAMPLE OF NOS/VE RECOVERY DEADSTART

K.DS

4.5.5 EXAMPLE OF MINIMAL NOS/VE DEADSTART

The minimal deadstart shown below may be useful to OS developers who need to get the system up quickly and do not need the product set or all validated users.

Type

```
K,NVE.
K.SETLA (your_un,NVE) your_password
K.GETF DS U=scat
K.DS NORMAL GSL=NO GP=NO QV=your_un AU=scat
```

4.5.6 USE OF THE QUICK_DEADSTART COMMAND

This command is intended as a development tool to facilitate 'fast' deadstarts where recovery is not needed; indeed, if this command is entered recovery_will_not_be_performed when the system is brought down for whatever reason. Specifying this command will cause an installation deadstart to take place. If the INITDD command is not specified then a default value of 'VSN001' is used for the system deadstart device. Use of INITDD will allow setting the deadstart devices identifier to any value. THIS COMMAND WILL NOT BE ACCEPTED FROM A DEADSTART COMMAND FILE, SO 'D=T' MUST BE SPECIFIED ON THE SETVE PROCEDURE TO PERMIT ENTRY OF THE QUICKDS COMMAND.

Format: QUICKDS or QUICK_DEADSTART

Values: The default is false. Executing this command causes this initial value to be toggled, thus executing this command twice will cause the final value to be false.

Note: QUICK_TEMPLATE_LOAD does not exist now.

4.6 NOS/VE_INTERACTIVE_FACILITY_OPERATION

4.6.1 OPERATOR INITIATION

To bring up the NOS/VE interactive facility do the following:

1) Bring up NOS/VE.

NOS/VE Cycle 7 Helpful Hints

09/14/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.6.1 OPERATOR INITIATION

2) Bring up NAM

At the system console enter:

FCN,5,7700.
NAMV2. for S2 and S3

3) If IAF is not up at control point 1, enter:

IAFV2.

4.6.2 OPERATOR TERMINATION

To terminate NOS/VE interactive any of the following may be done:

- CFO,NAM,DI,AP=VEIAF.

This is the preferred method. To bring NOS/VE interactive back up, you must first do a CFO,NAM,EN,AP=VEIAF.

- CFO,NAM,DI,NE.

This terminates the entire network including IAF,RBF, etc.

4.6.3 OTHER OPERATOR CAPABILITIES

- To logically turn the printer on, under DSD enter:

ON,33.
FORM,33,TM,.

- To send a "shutdown warning" to all terminals logged on to VEIAF do:

CFO,NAM,ID,AP=VEIAF.

- To send a message to all terminals do:

CFO,NAM,MSG,ALL,message.

- PASSON has the ability to record various types of diagnostic information. This capability is controlled via the sense switches at the PASSON control point. To turn a sense switch on (off) at job jsn do:

4.0 DUAL STATE DEADSTART AND OPERATION

4.6.3 OTHER OPERATOR CAPABILITIES

ONSW,jsn,x. (OFFSW,jsn,x.)

where x is the desired sense switch (1 to 6). The PASSON default is all sense switches off. It will take a short period of time before PASSON detects a change in a sense switch and reacts to it. The sense switches currently used by PASSON are:

switch_#	use
1	Network Trace
2	PASSON Logic Trace To Dayfile
3	Memory Link Trace To Dayfile

4.7 NOS/VE_OPERATOR_FACILITY_AND_OPERATOR_COMMANDS

With the release of the Operator Facility Phase 1 several changes to the NOS/VE Operating System will occur that will effect the users of the NOS/VE Operators Console. The Operator Facility runs as part of the NVE control point. When the request for K display appears on the NOS B Display, assign the K Display to the NVE control point. The Operator Facility is capable of displaying both a left and a right screen area at the same time. If the operator wants both screens then type in KK. The contents of these displays are determined by the commands entered by the operator.

The left screen is divided into four different areas. The top most area is the system header which contains the current date and time, memory statistics, and an operator action message if one is posted. The operator action will include the job sequence number of the owner of the message and 'message cancelled' if the message is cancelled because the task has terminated. The next line contains the first 64 characters of the operator action message (60 characters in stand alone).

The next area of the screen is the main output area. This area has the file name of OUTPUT. Any display command can have its output directed to this area as well as any system command.

The third area is towards the bottom of the screen. This area is two lines long and contains the response area. This will contain error messages from system commands. The area is

09/14/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.7 NOS/VE OPERATOR FACILITY AND OPERATOR COMMANDS

cleared when the next operator typein is entered at the operator's console and received by NOS/VE.

The fourth area is the prompt area. This will contain the status of the keyboard. If NOS/VE is processing a command, then the keyboard is locked and all typeins will be ignored. When the keyboard is locked, the message 'data received by 180 - keyboard locked' will appear at the screen's bottom. When the keyboard is unlocked then any data in the keyboard buffer will be sent to NOS/VE. The bottom line is the last line that was processed by Operator Facility.

The right K Display has the file name OUTPUT_RIGHT. There is only one area on the right screen therefore the main display area is 10 lines longer than the left screen area. If a dayfile display or CP display is shown on the right screen you will get more lines of information than on the left screen.

There are no default displays that come up automatically on either output display area. It is up to the operator to decide the display the operator wishes to see. The only parts of the display that come up automatically is the system header display and the prompt area for keyboard status.

The page width of the screen is 60 characters for standalone and 64 characters for dual state. The character set translation code is the same as that for the current NVE Subsystem control point. The escape code sequence for the special characters to be typed has not changed. There are a few differences in the processing of data by the Operator Facility and NVE Subsystem.

- 1) Do NOT end commands with a period. Periods are sent to NOS/VE.
- 2) The NVE subsystem commands that begin with an asterisk will not be supported from the Operator Facility control point. If these commands are entered from the Operator facility they will be passed on to SCL where an illegal command will be issued.
- 3) Routing of console job data to a specific job by the 'n=command' protocol will not be supported in dual state. This feature should work in standalone but will not be

NOS/VE Cycle 7 Helpful Hints

09/14/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.7 NOS/VE OPERATOR FACILITY AND OPERATOR COMMANDS

supported.

- 4) No type ahead - commands cannot be entered until the prompt area shows that they are requested.

There is one new command to replace the current display commands. The entry points for Zdis, Zdisb, and Sdis have been deleted. The new command is VEDISPLAY and has two parameters. The options are listed below. The values in paranthesis are the abbreviations. Note that this command does not begin with an asterisk (*). This command will be processed by SCL and create a new system control point task to display it's data. The user can have the same display type on each of the display areas, if the user so desires.

Command Name	Display Type	Screen Area
	Parameter Name	Parameter Name
	DISPLAY_OPTIONS	OUTPUT (O)
	DISPLAY_OPTION (DO)	
	Parameter Values	Parameter Values
VEDISPLAY (VED)	DISPLAY_SYSTEM_LOG	OUTPUT
	JOB_LOG (JL)	OUTPUT_RIGHT (OR)
	CONTROL_POINT (CP)	

The default file name for all displays is OUTPUT.

The following is a brief list of commands to bring up NOSVE with the Operator Facility installed.

NVEffff. to bring up NOS/VE. (See Section 5) ;

K,NVE. ;

KK. to bring up the K display on both screens.

K.VED JL to bring up the job log.

or

K.VED DISPLAY_OPTIONS=JL OUTPUT=OUTPUT

 to bring up the job log using key word

09/14/82

 4.0 DUAL STATE DEADSTART AND OPERATION

4.7.2 REBUILD_INPUT_QUEUE ; REBIQ

4.7.2 REBUILD_INPUT_QUEUE ; REBIQ

The purpose of this command is to rebuild an entry in the Known Job List (KJL) from information in the System Label of the file representing the job being processed. This command is to be used during the process of recovering the input queues during recovery deadstart.

```
rebuild_input_queue [name=<name>]
                   [status=<status variable>]
```

name ; n: This parameter specifies the file name of the file representing the job. An attempt is made to process the specified file within the catalog where job input queues are known to reside.

status: See ERROR HANDLING.

4.7.3 REBUILD_OUTPUT_QUEUE ; REBOQ

The purpose of this command is to rebuild an entry in the Known Output List (KOL) from information retained in the System Label of the file representing the output being processed. This command is to be used during the process of recovering the output queues during a recovery deadstart.

```
rebuild_output_queue [name=<name>]
                    [status=<status variable>]
```

name: This parameter specifies the file name of the file representing the output. An attempt is made to process the specified file within the catalog path of where job output queues are known to reside.

status: See ERROR HANDLING.

4.8 ROUTE_AN_INPUT_FILE_FROM_C17Q_TO_C18Q

Through the system console, enter:

Type

X.DIS.
 USER,A,B.

09/14/82

4.0 DUAL STATE DEADSTART AND OPERATION
 4.8 ROUTE AN INPUT FILE FROM C170 TO C180

```
GET,filename.
where filename identifies the input file to be routed.
ROUTE,filename,DC=LP,FC=RH.
```

4.9 CONFIGURATION MANAGEMENT

In order to run NOS/VE in a dual state environment, certain hardware configuration rules must be in effect. All storage devices and channels that NOS/VE will request must be in a 'down' state in the NOS EST. For more information on the NOS EST, see the NOS Version 1 Operator's Guide, 60435600, Section 4. Refer to the E display.

To run S2 S/N 104 in the standard configuration, channels 2 and 32 must be downed as shown below.

```
DOWN,CH2.
DOWN,CH32.
```

4.9.1 SYSTEM CORE COMMANDS

Configuration Management (CM) system core commands define the system mass storage device. The commands are described in detail in the NOS/VE Installation Command Interface ERS, Section 3. The CM system core commands define the hardware configuration of the system device and the controller accessing the system device. An example for S2 S/N 104 is shown here.

```
SETDCT $7155_1
SETDD $885_11 40(8)
```

4.9.2 JOB TEMPLATE COMMANDS

During an installation deadstart, the Physical Configuration Utility (PCU) and the Logical Configuration Utility (LCU) must be run. The PCU is run to describe the physical configuration that NOS/VE may access. The LCU will logically install all or part of the physical configuration and allow NOS/VE to access the equipment. Commands for both utilities are described in the NOS/VE Installation Command

NDS/VE Cycle 7 Helpful Hints

09/14/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.9.2 JOB TEMPLATE COMMANDS

Interface ERS, Section 2.

The system device which was defined by the system core commands must be defined via the PCU, using the same controller and channel number. Additional devices may be defined as long as the device is in a down state, and all channels defined are also down. An example is listed here.

```
EXECUTE_TASK SP=MANAGE_PHYSICAL_CONFIGURATION
  SET_MAINFRAME_DEFINITION MAINFRAME=S2
  SET_DATA_CHANNEL_DEFINITION CHANNEL_NUMBER=2
  SET_DATA_CHANNEL_DEFINITION CHANNEL_NUMBER=18
  SET_CONTROLLER_DEFINITION ELEMENT=CT1 ..
    PRODUCT_IDENTIFICATION=$7155_1 ..
    SERIAL_NUMBER=2 CHANNEL_CONNECTION=CHANNEL2
  SET_CONTROLLER_DEFINITION ELEMENT=CT2 ..
    PRODUCT_IDENTIFICATION=$7155_1 ..
    SERIAL_NUMBER=3 CHANNEL_CONNECTION=CHANNEL18
  SET_STORAGE_DEVICE_DEFINITION ELEMENT=FMD40_A ..
    PRODUCT_IDENTIFICATION=$885_11 SERIAL_NUMBER=1234 ..
    UNIT_NUMBER=40(8) CONTROLLER_CONNECTION=CT1
  SET_STORAGE_DEVICE_DEFINITION ELEMENT=FMD40_B ..
    PRODUCT_IDENTIFICATION=$855_11 SERIAL_NUMBER=3456 ..
    UNIT_NUMBER=40(8) CONTROLLER_CONNECTION=CT2
  INSTALL_PHYSICAL_CONFIGURATION MAINFRAME=S2
QUIT

EXECUTE_TASK SP=MANAGE_LOGICAL_CONFIGURATION
  INSTALL_LOGICAL_CONFIGURATION INCLUDE=ALL
QUIT
```

4.9.3 MULTIPLE VOLUME CONSIDERATIONS

If a configuration is used defining multiple mass storage volumes, the execution of the PCU and LCU will only permit access to the system device. In order to bring additional volumes online, the LCU must be run again. The user may want to initialize a fresh volume. To do this, use the LCU subcommand INITMV. To add a volume to the NDS/VE set, i.e. to allow NDS/VE use of the volume, use the LCU subcommand ADDMTS. An example is shown here.

```
EXECUTE_TASK TP=MANAGE_LOGICAL_CONFIGURATION
  INITIALIZE_MS_VOLUME ELEMENT=FMD40_B RECORDED_VSN='VSN002'
  ADD_MEMBER_TO_SET MEMBER_VSN='VSN002'
QUIT
```

09/14/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.9.3 MULTIPLE VOLUME CONSIDERATIONS

During a noninstallation deadstart, an attempt will be made to bring all logically configured volumes online and reactivate them. This means the above sequence need only occur when a new volume is being brought online the first time.

Reference has been made to the NOS/VE Installation Command Interface ERS. To get a copy of this document on S/N 101, enter SES,MAD.LISTNIH.

4.10 K_DISPLAY_ASCII

Support of 6-12 ASCII from the console (K display) causes the following changes:

INPUT	TRANSLATED_ID	INPUT	TRANSLATED_ID
/1		/([
/2 "		/)]
/3 #		/+	>
/4 \$		/-	<
/5 (reversed /)		/=	.
/6 ;		/*	' (single quote)
/7 ?		//	/
/8 {		/,	:
/9 }		/A to /Z	a - z (lower case)
/0 _ (underscore)			

4.11 EDD_AND_DSDI_INFORMATION

Most of the steps listed here are used to gather information for recovery problems, etc. If you do not wish to do this, execute steps D and E only (EDD dump and NOS level 3 deadstart).

- A. Enter DR I at the MDD display.
- B. Enter HP at the MDD display.
- C. If IOU.FS1 NOT = 0 OR IOU.FS2 NOT = 0 THEN do NOT enter DU at the MDD display ELSE do enter DU at the MDD display.

NOS/VE Cycle 7 Helpful Hints

09/14/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.11 EDD AND DSDI INFORMATION

D. Press deadstart button and perform EDD: :

1) Mount scratch tape (ring in) on a 9-track drive. :

2) Push D/S button. :

3) Select U (utilities) display. :

4) Select E (EDD) display. :

5) Set channel (S2=13). :

6) Set ECUU (S2=01uu) :

E = equipment :

C = 1 for 67X drives, 2 for 66X drives :

uu = unit number of the tape drive to be used. :

7) Answer "dump number" with a CR. :

8) Answer "non zero inhibits rewind" with a CR. :

9) Answer "channel controlware" with a CR. Warning: :
if this step is omitted, DSDI cannot process the :
dump tape. :

E. Perform a level 3 NOS deadstart (See Section 4.13). :

F. If you are running on the S3, enter the following at the :
console: :

```
X.DIS.
USER,INT1,INT1X.
GET,DMPDFS/UN=JLG.
BEGIN,,DMPDFS.
.
.
DROP.
```

This is a procedure to dump several dayfiles associated :
with the NVExxxx job and are needed along with the EDD tape to :
adequately debug a NOS/VE hang. :

Some of the crashes that NOS/VE encounters will cause :
NOS/VE to terminate such that the operator will notice the :
K-display which requests that a K.*RUN. be entered. Before a :

09/14/82

 4.0 DUAL STATE DEADSTART AND OPERATION

4.11 EDD AND DSDI INFORMATION

K.*RUN. is entered the EDD should be performed. :

To create a listing of the EDD tape, type SES,INT1.DSDI See :
 the procedure's HELP documentation for parameter :
 descriptions. :

C170 DSDI information can be found in Chapter 10 of the NOS
 SYSTEM MAINTENANCE Manual.

A170 DSDI info can be found in document ARH3060 -- GID for
 A170 NOS/S2.

4.12 NOS/VE_TERMINATION

o Bringing down dual state:

K,NVE. :

K.TERMINATE_SYSTEM :

o If not a normal termination

K,NVE. :

K.*RUN.

K.*ENDLST.

K.*ENDRUN.

4.13 A170_NOS_SHUTDOWN

Before leaving the machine, it is necessary to bring NOS
 down. If NOS has crashed, a level 3 deadstart must be
 attempted even if the only reason is to bring NOS down. To do
 a level 3 deadstart:

- 1) Push D/S button
- 2) Select "D" display
- 3) Select "P" display
- 4) Enter I=3
- 5) Enter (CR)

09/14/82

4.0 DUAL STATE DEADSTART AND OPERATION

4.13 A170 NOS SHUTDOWN

6) Enter date/time

If a dump is desired but a crash has not occurred STEP. should always be entered before pushing the deadstart button. After the dump has been taken a level 3 deadstart should be performed.

To bring NOS down, do the following:

1) Enter:

CHE

The screen will display:

CHECKPOINT SYSTEM.

Enter: carriage return

2) Make sure no mass storage device has a checkpoint requested. To do this, enter: E,M. If the display shows there are no "C"s in the status field, then all devices are checkpointed and you may continue.

3) Enter:

STEP.

4) Push deadstart button.

09/14/82

 5.0 RECOVERY OF NOS/VE PERMANENT FILES

5.0 RECOVERY_OF_NOS/VE_PERMANENT_FILES

5.1 SETVE_EQRMAI

The general format of the SETVE command is

X.SETVE(PN=ffff,UN=un,VSN=vsN,D=d,P=p,B=b,C=c,CH=ch)

ffff is a string of no more than four characters. SETVE appends ffff to 'NVE' to construct the name of a procedure file which, when invoked, will deadstart NOS/VE. The default is TST.

un specifies the user number from which TPXXXK is attached. Un is the first catalog searched for other files used in deadstarting and terminating NOS/VE. The default is INT1.

c specifies the deadstart command deck to be used when deadstarting NOS/VE. The function served by the deadstart command deck is analogous to the function served by the CMRDECK of NOS. Currently supported values for c and their respective uses are:

1	Arden Hills S3 S/N 02 open shop/hands-on time
3	Arden Hills S3 S/N 02 closed shop
6	Arden Hills S2 S/N 104 open shop/hands-on time
10	Sunnyvale S2 closed shop installation
40	Sunnyvale S2 closed shop continuation

The default is set in the file CMDS1. Currently the default is 6. Warning: Specifying C=6 on the Arden_Hills_S3 will destroy the NOS/VE permanent file base.

b specifies an alternate catalog to be searched for the various files used in deadstarting and terminating NOS/VE. The default is INT1.

d is used to indicate that the system core command processor should accept commands from the console. Specifying D=T in the SETVE command allows the

09/14/82

5.0 RECOVERY OF NOS/VE PERMANENT FILES

5.1 SETVE FORMAT

operator to enter commands from the console after processing the deadstart command deck. If the operator wishes to initialize the system device and/or install a new version of NOS/VE, D=T must be specified. The default is set in the file CMDS1. Currently the default is D=F.

- p specifies the password for the catalog indicated by the un parameter. If this parameter is omitted the password will be generated by appending an 'X' to the UN parameter.
- ch specifies the octal channel to be used for NOS/VE disk I/O. The default is set in the file CMDS1. Currently the default is 2.
- vsn specifies the vsn of a deadstart tape. If this parameter is used then NOS/VE will be deadstarted from the tape specified. If it is omitted, then NOS/VE will be deadstarted from the permanent file TPXXXK.

5.2 SETVE_USAGE

Earlier versions of NOS/VE required that two SETVE commands be issued if the system was to be installed and subsequently recovered. The current system does not require this. The only reason for issuing two SETVE commands is to provide a deadstart procedure that does not require/permit operator intervention.

It should be noted that once the SETVE command has been issued, it need not be issued again unless...

- 1) There is a need to change one or more of the parameters specified in SETVE.
- 2) The command file, NVEffff, generated by the SETVE command is purged from the system.

Two examples of SETVE usage and subsequent NOS/VE deadstart are given below. The first example shows a "hands on" user working with recovery. The second illustrates these concepts for a typical NOS/VE closed shop. This writer hopes that the reader will find both examples useful and illuminating.

I. A "hands on" user

NOS/VE Cycle 7 Helpful Hints

09/14/82

5.0 RECOVERY OF NOS/VE PERMANENT FILES5.2 SETVE USAGE

The command file NVERSD is built and installed in NOS by typing

```
X.SETVE(RSD,UN=RSD,VSN=TAPE,B=DEV1,C=6,D=T)
```

Several of the choices of parameters are worth noting.

- 1) By specifying the VSN parameter the user has built a command file that will deadstart the system directly from the tape produced by NVE SYS.
- 2) The user in this example has specified deadstart command deck 6 (C parameter) and has allowed the NOS/VE disk I/O channel (ch parameter) to default to 2. One concludes that the user is running on the Arden Hills S2.
- 3) The user has specified D=T. This is important. The deadstart command which triggers installation of a recoverable system cannot be read from a deadstart command deck. It must be entered from the console at deadstart time. Specifying D=T allows the operator to enter commands from the console.

NOS/VE is deadstarted by typing

```
NVERSD.
```

at the console.

The user brings up the K display by typing

```
K,NVE.
```

Presently, the deadstart command deck is displayed and the user is prompted for input. The deadstart command deck used in this example looks like this:

```
USECP      S2CFIG
USEIP      EMPTY
SETDCT     $7155_1
SETDD      $885_12 32
```

The user types

```
K.INITDD VSN001.
```

09/14/82

5.0 RECOVERY OF NOS/VE PERMANENT FILES5.2 SETVE USAGE

K.GO.

The system accepts the commands and installs and deadstarts NOS/VE.

After the system comes down, via either controlled termination or a crash, the system can be recovered (if necessary) and redeadstarted by typing

NVERSD.

When the deadstart command deck is displayed, the user types

GO.

This will cause NOS/VE to be deadstarted without initializing the system device.

II. A typical "closed shop"

Two command files, NVECLSH and NVEINST, are created by typing

```
X.SETVE(CLSH,UN=CLSH,B=DEV1,C=40,CH=1)
X.SETVE(INST,UN=CLSH,B=DEV1,C=10,CH=1,D=T)
```

One notes that

- 1) Closed shop is deadstarted from a TPXXXK file in the CLSH catalog.
- 2) Specifying D=T, for NVEINST, causes deadstart to pause for operator intervention.
- 3) Using DCF deck 40 for continuation suppresses redundant (and possibly damaging) reexecution of the configuration prolog.

A normal deadstart is used when bringing up NOS/VE at the beginning of closed shop or following a system failure. The operator, in this example, types

NVECLSH.

NOS/VE will recover (if necessary) and deadstart. When recovery runs, the operator must respond to a request for input from the MANLC utility. See note 4 at the end of this section for more information.

09/14/82

5.0 RECOVERY OF NOS/VE PERMANENT FILES

5.2 SETVE USAGE

If it is necessary to reinitialize the system device, or if the installation is upgrading to a new version of NOS/VE, the operator keys

NVEINST.

This causes deadstart to pause and wait for operator input when deadstart commands are being processed. There are two cases requiring discussion here. The first is the case of upgrading to a new and compatible version of NOS/VE. The second case is used only when it is necessary to reinitialize the system device.

The first case involves the installation of a new version of NOS/VE. In order to install a new version of the system, the old system must have been idled in an orderly way. A new system cannot be installed if, following a crash, the system being superceded was not recovered. Assuming everything in the old system is tidy, and the file systems are compatible, the operator keys

K.USECP EMPTY.

K.SETSA INSTALL_JOB_TEMPLATES 1.

K.GO.

when the system displays the deadstart command deck and prompts for input. The new system is installed, the file system is preserved, and deadstart proceeds.

The second case amounts to an installation deadstart. This should be used only with full knowledge that any files which may have existed on mass storage prior to this deadstart, will be blasted into oblivion by it.

An installation deadstart will be required if

- 1) This is the initial installation of a recoverable version of NOS/VE.
- 2) If the file systems of the system being installed and the system being superceded are not compatible.
- 3) If the file system has been damaged beyond the possibility of recovery.

An installation deadstart is effected by typing

09/14/82

5.0 RECOVERY OF NOS/VE PERMANENT FILES

5.2 SETVE USAGE

K.INITDD VSN001.

K.GO.

when the deadstart command deck is displayed and the operator is prompted for input.

NOTES:

1. The CMDS1 file used to deadstart NOS/VE must have the DEBUG2 flag set to TRUE. When NOS/VE is deadstarted, the catalog specified by the UN parameter is first in the search order for CMDS1, followed by the catalog specified by the B parameter.
2. See Section 3.3 of the Integration Procedures Notebook for other information about the CMDS1 file.
3. If NOS/VE crashes and a dump is desired (in the context of our second example)
 - i. Type du at the MDD console. The message "WRITING IMAGE FILE" should appear immediately. The message "IMAGE FILE COMPLETE" should appear a few moments later.
 - ii. Push the deadstart button.
 - iii. Take the EDD dump.
 - iv. Do a level 3 NOS deadstart.

Alternatively the operator can skip step i if she/he is sure to redeadstart NOS/VE after step iv. In this event the system will detect that the image file was never created, will create one, and will recover from it.

4. A recovery deadstart which is under the control of a SETVE command in which D=T was specified will pause in the recovery system with the message "OPERATOR INTERVENTION BEFORE RECOVERY BEGINS". The system is executing the logical configuration utility at this point. In order to exit this utility and allow recovery to proceed the operator types K.QUIT (no period). For more details on the use of the LCU see Section 4.9 of this document :

NDS/VE Cycle 7 Helpful Hints

09/14/82

5.0 RECOVERY OF NDS/VE PERMANENT FILES

5.2 SETVE USAGE

and the NDS/VE Installation Command Interface :
ERS. :

09/14/82

6.0 SYSTEM CORE DEBUGGER

6.0 SYSTEM_CORE_DEBUGGER

The System Core debugger provides a set of capabilities intended to assist in debugging the operating system. Services provided by the debugger are task oriented: selection of the tasks to be debugged must be made via debugger subcommands. No tasks will be under control of the debugger unless they are selected. The selection capability allows any number of tasks to be debugged simultaneously; from one task to all tasks in the system. Obviously a capability this powerful must be used with some care. The System Core debugger uses the debug hardware to provide these capabilities.

6.1 SYSDEBUG

The purpose of this command is to initiate execution of the system core debugger. This command can be issued from the deadstart command file or as a command in any job.

```
sysdebug
```

This command has no parameters; all information the debugger requires is provided via subcommands.

The system core debugger can also be invoked from the MDD console. The format of the command is:

```
DD n.sysdebug
```

where n is the job ordinal of the desired job. The debugger is brought up in the job monitor task of the job. All system core debugger subcommands are available, but must be prefixed by the MDD command DD.

The system core debugger can also be brought up (from the MDD console) by specifying a global task id. The format of the command is:

```
DD n.tdebug gggggg
```

The value of n is ignored, and the value gggggg specifies the

09/14/82

6.0 SYSTEM CORE DEBUGGER

6.1 SYSDEBUG

NOS/VE global task id (3 hex bytes) of the task to bring the debugger up in. If the task id is invalid, then the command will be ignored.

6.2 SUBCOMMAND_PARAMETER_DEFINITIONS

<name> ::= 1-8 character breakpoint name
 <condition> ::= READ!WRITE!RNI!BRANCH!CALL!DIVFLT!ARLOS!
 AROVFL!EXOVFL!EXUNFL!FPLOS!FPINDEF!INVBDP
 <base> ::= process virtual address
 <offset> ::= integer
 <length> ::= integer
 <frame> ::= 1..100
 <count> ::= 1..10000
 <regid> ::= X!A!P
 <regno> ::= 0..15!0..OF(16)
 <value> ::= integer
 <time> ::= 1..(2*31)-1
 <vstring> ::= 'charstring'
 <datatype> ::= HEX!ASCII!ASC!DEC
 <change_count> ::= 1..8
 <selector> ::= FULL!AUTO!SAVE

6.3 SYSTEM_CORE_DEBUGGER_SUBCOMMANDS

Within the descriptions which follow, optional parameters are enclosed in brackets. Default values for optional parameters are also defined.

6.3.1 SELECT

The purpose of this subcommand is to select the tasks in which the system core debugger is to be active. When the debugger is first called, it is not active in any task. To use the debugger therefore, it is necessary to select the tasks in which it is to be active.

```
select <selection option> [<ring number> ! <active job list
ordinal>]
```

selection_option: This parameter specifies one of a series of selection options used to control the tasks in which the debugger will be active and some

09/14/82

6.0 SYSTEM CORE DEBUGGER

6.3.1 SELECT

other debug options. The selections are remain in effect until they are explicitly changed with subsequent SELECT subcommands. Valid selection options are:

<right:left> - This selects the screen for the debug display. The display stays active when the screen is switched.

<jobmonitor:nojobmonitor> - This selects whether or not to debug job monitor tasks.

<user:nouser> - This selects whether or not to debug user tasks (i.e. those that are not job monitors).

<highring> - This specifies the highest ring in which debug traps will be recognized. Traps occurring in rings above this selection will be ignored.

<job:nojob> - This enables or disables debugging for the job at the specified active job list ordinal. The system job has an active job list ordinal of zero.

<alljobs:nojobs> - This activates or deactivates debugging in all jobs.

The initial selections are: RIGHT, NOSTEP, NOJOBMONITOR, NOUSER, HIGHRING=3, NOJOBS.

6.3.2 BREAKPOINT : B

The purpose of this subcommand is to select a program interrupt which is to take place upon occurrence of a specified condition within a specified virtual address range.

breakpoint <name> <condition> [<base>] [<offset>] [<length>]

The <name> is any user supplied name for identifying the breakpoint. A maximum of thirty two breakpoints can be selected. When a trap occurs, the <name> of the breakpoint which caused the trap is displayed.

The base parameter is required when specifying a new breakpoint name; offset and length specifications are optional

09/14/82

 6.0 SYSTEM CORE DEBUGGER

6.3.2 BREAKPOINT ! B

in this case. When adding a new condition selection to an existing breakpoint, base, offset, and length parameters may not be specified.

Base, offset, and length parameters define the desired virtual address range: $\langle \text{base} \rangle + \langle \text{offset} \rangle$ yields a first-byte-address; $\text{first-byte-address} + \langle \text{length} \rangle - 1$ yields a last byte address.

Default parameter values:

$\langle \text{offset} \rangle$: 0
 $\langle \text{length} \rangle$: 1

6.3.3 REMOVE_BREAKPOINT ! RB

The purpose of this subcommand is to deselect a previously selected program inte

`remove_breakpoint <name> [<condition>]`

If only the name parameter is specified, all conditions associated with the breakpoint are deselected and all evidence of the breakpoint is removed. If the condition parameter is specified, only that condition is deselected; however, if the specified condition is the only condition selected, all evidence of the named breakpoint is removed.

6.3.4 LIST_BREAKPOINT ! LB

The purpose of this subcommand is to provide a list of currently selected breakp and associated conditions.

`list_breakpoint [<name>]`

If the name parameter is specified, information is displayed for the named breakpoint only. If the name parameter is not specified, information is displayed for all currently defined breakpoints.

09/14/82

6.0 SYSTEM CORE DEBUGGER

6.3.5 CHANGE_BREAKPOINT : CB

6.3.5 CHANGE_BREAKPOINT : CB

The purpose of this subcommand is to change the virtual address range of a previously specified breakpoint.

change_breakpoint <name> <base> [<offset>] [<length>]

Base, offset, and length parameters define the desired virtual address range: <base> + <offset> yields a first-byte-address; first-byte-address + <length> -1 yields a last byte address.

Default parameter values:

<offset>: 0
<length>: 1

6.3.6 TRACE_BACK : TB

The purpose of this subcommand is to provide information relevant to stack frame associated with an interrupted procedure and its predecessor procedures. Validation of PVA's is now performed.

Information displayed for each selected stack frame consists of:

- Stack frame number;
- Current P-address of the associated procedure;
- Virtual address of the start of the stack frame;
- Virtual address of the stack frame save area.

trace_back [<frame>] [<count>] [FULL;SHORT]

The frame parameter specifies the number of the first stack frame for which information is to be displayed. Stack frame number one is associated with the interrupted procedure, stack frame two is associated with the interrupted procedure's predecessor, etc.

The module name provided on the traceback is usually correct but not guaranteed.

The count parameter specifies the total number of stack frames for which information is to be displayed.

09/14/82

6.0 SYSTEM CORE DEBUGGER

6.3.6 TRACE_BACK ! TB

Default parameter values:

<frame>: 1
<count>: 1

6.3.7 DISPLAY_STACK_FRAME ! DSF

The purpose of this subcommand is to display selected information from a specific stack frame.

display_stack_frame [<frame>] [<selector>]

The frame parameter specifies the number of the stack frame for which information is to be displayed. (Stack frame number one is associated with the interrupted procedure, stack frame two is associated with the interrupted procedure's predecessor, etc.)

The selector parameter identifies a region of the specified stack frame:

AUTO: Causes the automatic region of the stack frame to be displayed.

SAVE: Causes the save area of the stack frame to be displayed.

FULL: Causes both the automatic and save areas of the stack frame to be displayed.

Default parameter values:

<frame>: 1
<selector>: FULL

6.3.8 DISPLAY_REGISTER ! DR

The purpose of this subcommand is to display the contents of a specified register interrupted procedure.

display_register <regid> [<regno>] [<datatype>]

Default parameter values:

<regno>: 0

09/14/82

6.0 SYSTEM CORE DEBUGGER

6.3.8 DISPLAY_REGISTER : DR

<datatype>: HEX

6.3.9 DISPLAY_MEMORY : DM

The purpose of this subcommand is to display the contents of a specified area of virtual memory. Validation of PVA's is now performed.

display_memory <base> [<length>]

Default parameter values:

<length>: 8

6.3.10 CHANGE_MEMORY : CM

The purpose of this subcommand is to set a specified value into a specified loca of virtual memory for a specified number of bytes. Validation of PVA's is now performed.

change_memory <base> <value> <change_count>

Default parameter values:

<change_count>: 1

6.3.11 RUN

The purpose of this subcommand is to invoke program execution after a selected p interrupt has occurred.

run

6.3.12 SUPER_CHANGE_MEMORY : SCM

The purpose of this subcommand is the same as the change memory subcommand, that is, to change the contents of virtual memory. It differs from change memory, however, in that it will change the attributes of the segment to allow memory to be written, and then change the attributes back to their original values.

09/14/82

6.0 SYSTEM CORE DEBUGGER

6.3.12 SUPER_CHANGE_MEMORY ; SCM

The command format is the same as the change memory subcommand.

6.3.13 FORMAT ; FMT

The purpose of this subcommand is to set the system core debugger into a mode where all subcommand output is sent to a permanent file. This is done by having the task running the debugger communicate with another task running in the system job. It is this other task that actually creates and writes the permanent file. The entry point of this task is OSP\$BROKEN_JOB_DUMP_TASK. It will normally be initiated by the DS procedure. If it is not running, a diagnostic will be issued. This task will create successive cycles of the permanent file 'DUMP' in the \$SYSTEM catalog. These files contain ASCII text data written in BAM variable records. The parameter to this command is a string which will be output as the first line of the file.

format string

6.3.14 UNFORMAT ; UNFMT

The purpose of this subcommand is to leave the output mode established by the FORMAT command. Output will again be sent to the operator console. At this point the permanent file will be flushed to mass storage.

unformat

6.3.15 DISPLAY_MONITOR_FAULT ; DISMF

The purpose of this subcommand is to display any monitor faults present in this task. See the section titled 'NOS/VE Processing of Job Mode Software Errors' for more information.

All monitor fault buffers are displayed in the hope they will show some task history. If a given fault buffer is invalid the message "following fault is not present" is displayed.

display_monitor_fault

09/14/82

6.0 SYSTEM CORE DEBUGGER

6.3.16 DISPLAY_XCB ; DISXCB

6.3.16 DISPLAY_XCB ; DISXCB

The purpose of this subcommand is to display all of the fields of the current task's (i.e., the task running the debugger) execution control block.

6.3.17 DISPLAY_TASK_ENVIRONMENT ; DISTE

The purpose of this subcommand is to display the XCB of all tasks running within the current job (i.e., the job with the task running the debugger). If the command is entered while the debugger is in format mode, then a full XCB is displayed, otherwise just the task name, XCB address and global task id are displayed.

09/14/82

7.0 NOS/VE PROCESSING OF JOB MODE SOFTWARE ERRORS

7.0 NOS/VE_PROCESSING_OF_JOB_MODE_SOFTWARE_ERRORS

7.1 INTRODUCTION

Tasks running in job mode will occasionally cause an error which is detected either by the hardware or NOS/VE monitor. The action taken when an error like this occurs is controlled by various system attributes. The purpose of this section is to discuss the types of errors and the effect a given system attribute will have upon the handling of the error.

7.2 TYPES_OF_ERRORS

- 1) **BROKEN TASK:** A broken task is a task in which the trap mechanism is not able to function correctly. NOS/VE monitor will attempt to repair the trap mechanism and send a broken task fault to the task. The specific cases of a broken task are:

system error	job mode software has declared the task to be broken. (This is a special case of broken task.)
monitor fault buffer full	job mode errors are occurring but are not being processed by job mode.
traps disabled	a job mode error has occurred while traps were disabled.
Invalid A0	the task's A0 register was invalid.
UCR/MCR traps disabled	UCR/MCR error occurred with traps disabled.

- 2) **MCR FAULT:** This error signifies that job mode caused a hardware detected MCR fault. This may be caused by

09/14/82

7.0 NOS/VE PROCESSING OF JOB MODE SOFTWARE ERRORS

7.2 TYPES OF ERRORS

software or hardware detected uncorrectable error.

- 3) UNKNOWN SYSTEM REQUEST: This error signifies that job mode issued a monitor request that is either invalid or cannot be issued from the ring it was issued from.
- 4) SEGMENT ACCESS FAULTS: These errors signify that job mode encountered or caused one of the following errors:
 - page fault for an address greater than EDI on a read-only file (segment)
 - disk read error

These errors either originate in NOS/VE monitor or cause the hardware to exchange to monitor. Depending on the values of certain system attributes, monitor will halt or reflect the error back to job mode as a monitor default.

It is at this point that the system core debugger can be activated. (See the definition of SYSTEM_DEBUG_RING in the next section.)

The normal job mode OS actions for these faults are:

broken task	exit
MCR fault	cause condition
invalid system request	exit
segment access	cause condition

7.3 SYSTEM_ATTRIBUTES_FOR_ERROR_PROCESSING

The following system attributes can be set or displayed by the SETSA and DISSA commands.

7.3.1 HALTRING

If a broken task or MCR fault occurs at or below the value of HALTRING (P register ring number), NOS/VE monitor will halt the system. Broken tasks occurring above HALTRING will cause a monitor fault to be sent back to job mode.

09/14/82

 7.0 NOS/VE PROCESSING OF JOB MODE SOFTWARE ERRORS

7.3.2 SYSTEM_ERROR_HANG_COUNT

7.3.2 SYSTEM_ERROR_HANG_COUNT

This is the number of broken task errors allowed to occur in any given task before that task is considered a hung task.

7.3.3 HALT_ON_HUNG_TASK

If this attribute is true, then an occurrence of a hung task will cause NOS/VE monitor to halt the system. If the attribute is false, the task will be sent a signal to 'hang' itself, i.e. to go into an infinite wait doing nothing. Jobs with hung tasks will have a *H in the status field on the operator CP display.

A hung task will also occur if any error happens in job mode ring 1.

7.3.4 SYSTEM_DEBUG_RING

If an error (broken task, MCR fault, unknown system request, or segment access fault) occurs at or below the value of this attribute (P register ring number), the system core debugger will be invoked within the task. At that point in time the task environment can be examined by using system core debugger commands.

If the RUN command is issued to the debugger, the system will take its normal action for the specific fault.

7.3.5 DUMP_WHEN_DEBUG

When the system core debugger is invoked by a fault at or below SYSTEM_DEBUG_RING and the DUMP_WHEN_DEBUG attribute is true, the debugger will automatically create a dump of the task (see system core debugger command FORMAT). When the dump is complete, normal fault action will take place. The following system core debugger commands are executed during an automatic dump:

```

FORMAT automatic dump data
TB 1 1000
DISMF
```

NDS/VE Cycle 7 Helpful Hints

09/14/82

7.0 NDS/VE PROCESSING OF JOB MODE SOFTWARE ERRORS

7.3.5 DUMP_WHEN_DEBUG

DISXCB
DM 00300000000 10000(16)
DM 00400000000 10000(16)
DM 00500000000 10000(16)
DM 00600000000 10000(16)
DM 00F00000000 10000(16)
DM 01000000000 10000(16)
DM 01100000000 10000(16)
DISTR
UNFORMAT

09/14/82

8.0 STAND ALONE DEADSTART

8.0 STAND_ALONE_DEADSTART

A standalone deadstart tape is a 9-track, unlabeled, I format, 1600 BPI density tape (produced by the NVE SYS procedure). To deadstart in standalone mode, perform the following steps:

- 1) Set the deadstart panel for standard disk deadstart.
- 2) Perform an alternate deadstart to the NVE deadstart tape using CTI. The CTI parameters on the 'P' display should be set as follows
 - L = 0
 - C = '<'C' parameter of the SETVE procedure>
 - D = '<'D' parameter of the SETVE procedure
 - D = Y when display is true
 - D = N when no display>
 - W14 = '<'CH' parameter of the SETVE procedure>
- 3) The tape should move and eventually the message "PROCEED" will appear on the lower left on the console.
- 4) Enter CR,Mx,BR=0000000000000000 (Editor's note: 16 zeros!)
 - where Mx is M1 for S1
 - M2 for S2
 - M3 for S3

This clears the memory bounds register which is set by the deadstart.
- 5) Enter DR,P2 This displays the CPU registers. The SIT should be changing; if not, give up.
- 6) At this point the system core is loaded and can be patched. The commands to display and change memory are documented in IPNDOC.
- 7) To start the system enter SS The CPU registers should spin; if they ever stop the CPU has halted.
- 8) Enter DD to display the system dayfile on the right screen.

8.0 STAND ALONE DEADSTART

9) Enter NVE deadstart commands when the system requests them. ('D = Y' must be specified on the 'P' display for this to happen.)

Note: Standalone deadstart is always a 'quick' deadstart, so no recovery of permanent files is possible. 'QUICKDS' mode is set internally and need not be specified.

10) Enter DJ to display the system job dayfile when the system requests it. The 'DJ' display is on the left screen.

11) Now the system is operational and commands can be entered.

09/14/82

 9.0 INTERACTIVE PROJECT DUMP ANALYSIS PROCEDURES

9.0 INTERACTIVE_PROJECT_DUMP_ANALYSIS_PROCEDURES

The following procedures were developed by the interactive project to assist them in interpreting dumps. They guarantee the procedures work if your user name is IFP; otherwise caveat emptor. For more information about these procedures, contact Fred Bischke.

The following dump analysis procedures are available in the IFP catalog:

9.1

EDDSIM

This is a CCL procedure which brings an EDD dump tape on a specified

VSN into the simulator. The procedure can be accessed from the IFP

catalog as follows:

```
get,eddsim/un=ifp
```

```
begin,,eddsim,vsn ( vsn is the vsn of the EDD dump tape )
```

9.2

ANALEXC

This is a Simulator INCLUDE file which does a preliminary analysis of

the current simulator exchange package (when the system crashes in task

NOS/VE Cycle 7 Helpful Hints

09/14/82

9.0 INTERACTIVE PROJECT DUMP ANALYSIS PROCEDURES9.2

services, this will normally be JPS). A qr exc=mon or qr exc=rma can be

used to get into another exchange package before doing the include.

The include file is ANALEXC/UN=IFP. It can be called from the simulator

as follows:

```
'get,analex/ un=ifp' ; include analex
```

(carriage return) a lone carriage return must be entered after an INCLUDE in order to start it up

9.3

SEG_DUMP

This is a CCL procedure which calls DSDIV to dump a specified segment to a list file which can then be examined with an editor or printed.

The procedure can be accessed from within the Simulator as follows:

```
'get,segdump/ un=ifp' ; 'begin,,segdump,seg,len,file,exc,cpf' <*
```

The segdump parameters are:

seg - segment number in hex (default is 1)

length - number of bytes to dump in hex (default is 10000)

list - name of the list file (default is LIST)

exc - reference exchange package (default is JPS)

cpf - name of checkpoint file (default is CPF)

NOS/VE Cycle 7 Helpful Hints

09/14/82

9.0 INTERACTIVE PROJECT DUMP ANALYSIS PROCEDURES

9.3

In most cases of task services debugging, only the seg parameter is

needed.

9.4

ANALJOB

This is a CCL procedure which uses DSDIV, XEDIT and the Simulator to

perform an analysis of all tasks in a specified job. The procedure can

be accessed from within the simulator as follows:

```
'get,analjob/un=ifp' ; 'begin,,analjob,seg,cpf'
```

The analjob parameters are:

seg - the monitor segment which contains the exchange packages of the job (14 is the system job, 15 is job 1 etc.) (default is 14)

cpf - the name of the simulator file (default is CPF)

After the procedure has completed, a list of the RMA's of the

job's exchange packages can be obtained by doing the following:

```
include tplist
```

```
(carriage return)
```

A traceback of all tasks in the job can be obtained by doing the

NOS/VE Cycle 7 Helpful Hints

09/14/82

9.0 INTERACTIVE PROJECT DUMP ANALYSIS PROCEDURES

9.4

following:

include tblast

(carriage return)

include tbrun

(carriage return)

!

09/14/82

1.0 Hardware Overview

- 1.1 An introduction to CYBER 180
- 1.2 C180 Instant
- 1.3 Model Independent General Design Specification - ARH1700

2.0 NOS Reference Manuals

- 2.1 XEDIT V3.0 - 60455730
- 2.2 IAF V1.0 User's Guide - 60455260
- 2.3 NOS Version 2 Reference Set - Vol 3, 60459680 - Vol 4, 60459690 ;
- 2.4 NOS Systems Programmer's Instant - 60459370 ;
- 2.5 NOS Version 2 Operator/Analyst Handbook - 60459310 ;
- 2.6 NOS Version 2 Diagnostic Index - 60459390 ;
- 2.7 NOS A170 ERS
- 2.8 NOS A170 GID - ARH3060

3.0 NOS/VE Reference Documents

- 3.1 Program Interface ERS - ARH3610 - obtained from Karen Rubey (482-3966) or via SES.TOOLDOC
- 3.2 Command Interface ERS - ARH3609 - obtained from Karen Rubey (482-3966) or via SES.TOOLDOC
- 3.3 NOS/VE Procedures and Conventions - SESD010 - obtained by SES.TOOLDOC
- 3.4 Listing of all NOS/VE Modules - obtained by SES,DEV1.LISTNVE. See Integration Procedures Notebook for details.
- 3.5 NOS/VE Internal Interface Maintenance Procedures Memo available from S.C. Wood.
- 3.6 Integration Procedures Notebook Obtained by: Acquire,IPNDOC/UN=DEV1. SES.PRINT,IPNDOC.

09/14/82

4.0 Tools Reference Documents

- 4.1 CYBIL Interactive Debugger - ARH3142
- 4.2 SES User's Guide - ARH1833
- 4.3 CYBIL Specification - ARH2298
- 4.4 C180 Assembler ERS - ARH1693
- 4.5 Simulator ERS - ARH1729
- 4.6 VEGEN ERS - ARH2591
- 4.7 VELINK ERS - ARH2816
- 4.8 Simulated I/O ERS - ARH3125
- 4.9 Object Code Utilities ERS - ARH2922
- 4.10 CYBIL Implementation Dependent Handbook - ARH3078
- 4.11 CYBER 180 INTERACTIVE DEBUG External Reference
Specification and Users Guide - S4028
- 4.12 CYBER 180 II Assembler ERS - ARH3945
- 4.13 ERS for Source Code Utility - ARH3883

Table of Contents

1.0 MAJOR CHARACTERISTICS OF THIS BUILD	1-1
1.1 NOS/VE USAGE EXAMPLES	1-5
1.1.1 EXECUTING PROGRAMS	1-5
1.1.2 CREATE OBJECT LIBRARY ON NOS/VE AND SAVE IT ON NOS	1-6
1.1.3 MODIFY A PREVIOUSLY SAVED OBJECT LIBRARY	1-7
1.1.4 ROUTE AN INPUT FILE FROM NOS TO NOS/VE	1-7
1.1.5 PRINT A NOS/VE FILE	1-8
2.0 COMMAND INTERFACE STATUS	2-1
2.1 ACCESS TO NOS/VE IN DUAL STATE	2-1
2.1.1 LOGIN TO NOS/VE	2-1
2.1.2 TERMINAL USAGE	2-1
2.1.3 NOS/VE PROGRAM ACCESS TO THE TERMINAL	2-2
2.2 COMMAND AND PARAMETER NAMES	2-2
2.3 COMMAND FUNCTIONS	2-3
2.4 SYSTEM ACCESS COMMANDS	2-4
2.5 RESOURCE MANAGEMENT	2-4
2.6 FILE MANAGEMENT	2-4
2.7 PERMANENT FILE MANAGEMENT	2-4
2.8 SCL STATEMENTS AND PROCEDURES	2-5
2.9 INTERACTIVE COMMANDS	2-6
2.10 OBJECT CODE MAINTENANCE	2-6
2.11 USER SERVICES	2-7
2.12 FILE ROUTING	2-7
2.13 PROGRAM EXECUTION	2-7
2.14 JOB MANAGEMENT	2-7
2.15 NON STANDARD COMMANDS	2-8
2.15.1 DELETE_CATALOG_CONTENTS ; DELCC	2-8
2.15.2 DISPLAY_ACTIVE_TASK ; DISAT	2-8
2.15.3 DISPLAY_SYSTEM_DATA ; DISSD	2-9
2.15.4 DISPLAY_JOB_DATA ; DISJD	2-9
2.15.5 DISPLAY_COMMAND_INFORMATION ; DISCI	2-10
2.15.6 CONVERT_OBJECT_FILE ; CONOF	2-11
2.15.7 GET_OBJECT_FILE ; GETOF	2-12
2.15.8 GET_OBJECT_LIBRARY ; GETOL	2-13
2.15.9 DISPLAY_OBJECT_TEXT ; DISOT	2-13
2.15.10 GET_SOURCE_LIBRARY ; GETSL	2-14
2.15.11 EDIT_FILE ; EDIF	2-15
2.15.12 JEDIT	2-15
2.15.13 DEBUG	2-15
2.15.14 SET_LINK_ATTRIBUTES ; SETLA	2-16
3.0 PROGRAM INTERFACE STATUS	3-1
3.1 COMMAND PROCESSING	3-1
3.2 MESSAGE GENERATOR	3-1
3.3 RESOURCE MANAGEMENT	3-2
3.4 PROGRAM EXECUTION	3-2
3.5 PROGRAM COMMUNICATION	3-3
3.6 CONDITION PROCESSING	3-3

3.7 PROGRAM SERVICES	3-3
3.8 LOGGING	3-4
3.9 FILE MANAGEMENT	3-4
3.10 PERMANENT FILE MANAGEMENT	3-5
3.11 MEMDRY MANAGEMENT	3-5
3.12 STATISTICS FACILITY	3-6
3.13 INTERACTIVE FACILITY	3-6
3.14 NOS/VE EXCEPTIONS	3-6
4.0 DUAL STATE DEADSTART AND OPERATION	4-1
4.1 CURRENT DUAL STATE CONFIGURATION	4-1
4.2 USER NAMES AND PERMANENT FILES	4-1
4.3 TO RELOAD CONTROLWARE FOR THE NOS/VE DISK DRIVER	4-2
4.4 A170 NOS DEADSTART	4-2
4.4.1 CTI AND CHECKING CENTRAL MEMORY	4-2
4.4.2 NOS DEADSTART	4-3
4.5 NOS/VE DEADSTART AND INSTALLATION	4-3
4.5.1 THE DS PROCEDURE	4-5
4.5.2 EXAMPLE OF NOS/VE INSTALLATION DEADSTART	4-9
4.5.3 EXAMPLE OF NOS/VE "NORMAL" DEADSTART	4-9
4.5.4 EXAMPLE OF NOS/VE RECOVERY DEADSTART	4-9
4.5.5 EXAMPLE OF MINIMAL NOS/VE DEADSTART	4-10
4.5.6 USE OF THE QUICK_DEADSTART COMMAND	4-10
4.6 NOS/VE INTERACTIVE FACILITY OPERATION	4-10
4.6.1 OPERATOR INITIATION	4-10
4.6.2 OPERATOR TERMINATION	4-11
4.6.3 OTHER OPERATOR CAPABILITIES	4-11
4.7 NOS/VE OPERATOR FACILITY AND OPERATOR COMMANDS	4-12
4.7.1 DELETE_JOB_QUEUE ; DELETE_JOB_QUEUES ; DELJQ	4-15
4.7.2 REBUILD_INPUT_QUEUE ; REBIO	4-16
4.7.3 REBUILD_OUTPUT_QUEUE ; REBQQ	4-16
4.8 ROUTE AN INPUT FILE FROM C170 TO C180	4-16
4.9 CONFIGURATION MANAGEMENT	4-17
4.9.1 SYSTEM CORE COMMANDS	4-17
4.9.2 JOB TEMPLATE COMMANDS	4-17
4.9.3 MULTIPLE VOLUME CONSIDERATIONS	4-18
4.10 K DISPLAY ASCII	4-19
4.11 EDD AND DSDI INFORMATION	4-19
4.12 NOS/VE TERMINATION	4-21
4.13 A170 NOS SHUTDOWN	4-21
5.0 RECOVERY OF NOS/VE PERMANENT FILES	5-1
5.1 SETVE FORMAT	5-1
5.2 SETVE USAGE	5-2
6.0 SYSTEM CORE DEBUGGER	6-1
6.1 SYSDEBUG	6-1
6.2 SUBCOMMAND PARAMETER DEFINITIONS	6-2
6.3 SYSTEM CORE DEBUGGER SUBCOMMANDS	6-2
6.3.1 SELECT	6-2
6.3.2 BREAKPOINT ; B	6-3
6.3.3 REMOVE_BREAKPOINT ; RB	6-4
6.3.4 LIST_BREAKPOINT ; LB	6-4
6.3.5 CHANGE_BREAKPOINT ; CB	6-5

6.3.6	TRACE_BACK ; TB	6-5
6.3.7	DISPLAY_STACK_FRAME ; DSF	6-6
6.3.8	DISPLAY_REGISTER ; DR	6-6
6.3.9	DISPLAY_MEMORY ; DM	6-7
6.3.10	CHANGE_MEMORY ; CM	6-7
6.3.11	RUN	6-7
6.3.12	SUPER_CHANGE_MEMORY ; SCM	6-7
6.3.13	FORMAT ; FMT	6-8
6.3.14	UNFORMAT ; UNFMT	6-8
6.3.15	DISPLAY_MONITOR_FAULT ; DISMF	6-8
6.3.16	DISPLAY_XCB ; DISXCB	6-9
6.3.17	DISPLAY_TASK_ENVIRONMENT ; DISTE	6-9
7.0	NOS/VE PROCESSING OF JOB MODE SOFTWARE ERRORS	7-1
7.1	INTRODUCTION	7-1
7.2	TYPES OF ERRORS	7-1
7.3	SYSTEM ATTRIBUTES FOR ERROR PROCESSING	7-2
7.3.1	HALTRING	7-2
7.3.2	SYSTEM_ERROR_HANG_COUNT	7-3
7.3.3	HALT_ON_HUNG_TASK	7-3
7.3.4	SYSTEM_DEBUG_RING	7-3
7.3.5	DUMP_WHEN_DEBUG	7-3
8.0	STAND ALONE DEADSTART	8-1
9.0	INTERACTIVE PROJECT DUMP ANALYSIS PROCEDURES	9-1
9.1		9-1
9.2		9-1
9.3		9-2
9.4		9-3
	APPENDIX A NOS/VE BACKGROUND DOCUMENTS	A1