

SERIES 200

TAPE SORT A AND COLLATE A ADDENDUM #1

GENERAL SYSTEM:

SERIES 200 BASIC PROGRAMMING SYSTEM

SUBJECT:

Loading of Collate A (formerly Collate 1) via
the Type 224-2 Card Reader/Punch

SPECIAL INSTRUCTIONS:

In the Honeywell Information Bulletin Sort 1
and Collate 1, DSI-247B, dated June 15, 1965,
insert the attached paragraph below Figure 5-2
on page 5-10.

DATE: June 10, 1966

DSI-247B

8984
5666

Printed in U. S. A.

If the Type 223 or 227 Card Reader or the Type 214-2 Card Reader/Punch is used for loading , proceed as described in the following paragraphs. If the Type 224-2 Card Reader/Punch is used for loading, reverse the positions of the Bootstrap card and the parameter card shown in Figure 5-2; load the Bootstrap card (i. e., the first card in the COLPAR deck) into location 1, and then bootstrap the parameter card into location 121_8 as usual. Set the sequence counter to location 1. Press the RUN button.