

**PUBLICATIONS
RELEASE**

UTS 700 Universal Terminal System

Summary of
Current Documentation

January 1979

UP-8497

This SPERRY UNIVAC® UTS 700 Universal Terminal System Library Memo announces the release and availability of "SPERRY UNIVAC UTS 700 Universal Terminal System Summary of Current Documentation," UP-8497. This is a Standard Library Item (SLI).

This summary includes all current items released through the month of January 1979 will be updated and released on a bimonthly basis unless there have been no additions or deletions to the document.

Destruction Notice: UP-8497, January 1979 supersedes and replaces "SPERRY UNIVAC UTS 700 Universal Terminal System Summary of Current Documentation October 1978. Please destroy all copies of UP-8497 dated October 1978.

NOTE: When ordering items for SPERRY UNIVAC UTS 700 Universal Terminal System, please refer to this summary for the most current information.

Additional copies may be ordered by your local Sperry Univac Representative.

LIBRARY MEMO ONLY	LIBRARY MEMO AND ATTACHMENTS	THIS SHEET IS:
Mailing Lists BZ, CZ (less HA) and MZ	Mailing Lists 1, 2 and HA (Cover and 4 pages)	Library Memo for UP-8497 RELEASE DATE: January 1979

SPERRY UNIVAC
UTS 700 Universal Terminal System
Summary of
Current
Documentation
January 1979

This document contains the latest information available at the time of preparation. Therefore, it may contain descriptions of functions not implemented at manual distribution time. To ensure that you have the latest information regarding levels of implementation and functional availability, please contact your local Sperry Univac representative.

Sperry Univac reserves the right to modify or revise the content of this document. No contractual obligation by Sperry Univac regarding level, scope, or timing of functional implementation is either expressed or implied in this document. It is further understood that in consideration of the receipt or purchase of this document, the recipient or purchaser agrees not to reproduce or copy it by any means whatsoever, nor to permit such action by others, for any purpose without prior written permission from Sperry Univac.

Sperry Univac is a division of the Sperry Rand Corporation.

FASTRAND, SPERRY UNIVAC, UNISCOPE, UNISERVO, and UNIVAC are registered trademarks of the Sperry Rand Corporation. AccuScan, ESCORT, PAGEWRITER, PIXIE, and UNIS are additional trademarks of the Sperry Rand Corporation.

This document was prepared by Systems Publications using the SPERRY UNIVAC UTS 400 Text Editor. It was printed and distributed by the Customer Information Distribution Center (CIDC), 555 Henderson Rd., King of Prussia, Pa., 19406.

SUBJECT: SOFTWARE

UP-8497

JAN-79

PAGE: 001

DOCUMENT NUMBER	SYSTEM	TYPE	T I T L E	A N D / O R	D E S C R I P T I O N	#PP	STATUS
UD1-1780	UTS700	RD	SYSTEM USER GUIDE FORM				C
UP-8371 R2	UTS700	SLI	REPORT PROGRAM GENERATOR II (RPGII) USER GUIDE			404	C
			UPDATE PACKAGE A, TO UP-8371 R2			63	
UP-8401	UTS700	RD	PL/M PROG REF			119	C
UP-8407 R3	UTS700	SLI	COMMUNICATIONS USER GUIDE			300	C
UP-8528	UTS700	RD	INTRODUCTION TO SYSTEM CONTROL LANGUAGE			32	C
UP-8530	UTS700	RD	INTRODUCTION TO RPG II			38	C
UP-8535	UTS700	RD	INTRODUCTION TO ESCORT			22	C
UP-8563 R1	UTS700	RD	ESCORT USER GUIDE			221	C
UP-8610.1	UTS700	SLI	BULLETIN #1			7	C
UP-8610.2	UTS700	SLI	UTS700 BULLETIN #2			22	C

ABBREVIATIONS

C=CURRENT OPR=OPERATOR PROG=PROGRAMMER R=REVISION RD=RESTRICTED DISTRIBUTION REF=REFERENCE
SLI=STANDARD LIBRARY ITEM S/R=SLI INTERNAL-RD CUSTOMER S/S=SUBSYSTEM SU=SLI SPERRY UNIVAC ONLY

DOCUMENT NUMBER	SYSTEM	TYPE	T I T L E A N D / O R	D E S C R I P T I O N	#PP	STATUS
UP-8205	UTS700	RD	UNISERVO 10 AND 14 MAGNETIC TAPE SUBSYSTEMS	SUBSYSTEM REF	76	C
UP-8206	UTS700	RD	UNISERVO 10 AND 14 MAGNETIC TAPE SUBSYSTEMS	GEN DESC	43	C
UP-8207	UTS700	RD	UNISERVO 10 AND 14 MAGNETIC TAPE SUBSYSTEMS	OPER REF	35	C
UP-8208 R1	UTS700	RD	UNISERVO MAGNETIC TAPE SUBSYSTEMS	MEDIA	34	C
UP-8234	UTS700	RD	0608 CARD PUNCH SUBSYSTEM	SUBSYSTEM REF	34	C
UP-8378	UTS700	RD	0719 CARD READER SUBSYSTEM	GENERAL DESCRIPTION	11	C
UP-8380	UTS700	RD	0608 CARD PUNCH SUBSYSTEM	GENERAL DESCRIPTION	22	C
UP-8386	UTS700	RD	0608 CARD PUNCH SUBSYSTEM	OPERATOR REF	32	C
UP-8388	UTS700	RD	0608 CARD PUNCH SUBSYSTEM	MEDIA AND EXPENDABLE SUPPLIES	12	C
UP-8390	UTS700	RD	0719 CARD READER SUBSYSTEM	MEDIA AND EXPENDABLE SUPPLIES	12	C
UP-8394	UTS700	RD	0784 PRINTER SUBSYSTEM	OPERATOR REF	45	C
UP-8410	UTS700	RD	0784 PRINTER SUBSYSTEM	GENERAL DESCRIPTION	44	C
UP-8429	UTS700	RD	0719 CARD READER SUBSYSTEM	OPERATOR REF	21	C
UP-8431	UTS700	RD	0719 CARD READER SUBSYSTEM	SUBSYSTEM REFERENCE	26	C
UP-8432	UTS700	RD	0784 PRINTER SUBSYSTEM	SUBSYSTEM REFERENCE	55	C
UP-8433	UTS700	RD	0784 PRINTER SUBSYSTEM	MEDIA AND EXPENDABLE SUPPLIES	21	C
			UPDATE A, TO UP-8433-A		7	
UP-8495	UTS700	RD	0786 PRINTER SUBSYSTEM	GENERAL DESCRIPTION	23	C
UP-8496	UTS700	RD	0786 PRINTER SUBSYSTEM	OPERATOR'S GUIDE	26	C
UP-8554	UTS700	RD	UNIVERSAL DATA LINK CONTROL	GENERAL DESCRIPTION	43	C
UP-8574	UTS700	RD	0781 PRINTER SUBSYSTEM	GENERAL DESCRIPTION	23	C
UP-8575	UTS700	RD	0781 PRINTER SUBSYSTEM	OPERATOR REFERENCE	31	C
UP-8576	UTS700	RD	0781 PRINTER SUBSYSTEM	SUBSYSTEM REFERENCE	38	C
UP-8577	UTS700	RD	0781 PRINTER SUBSYSTEM	EXPENDABLE SUPPLIES	19	C
UP-8620	UTS700	RD	0871 MAGNETIC TAPE SUBSYSTEM	GENERAL DESCRIPTION	16	C
UP-8621	UTS700	RD	0871 MAGNETIC TAPE SUBSYSTEM	SUBSYSTEM REFERENCE	22	C

ABBREVIATIONS

C=CURRENT OPR=OPERATOR PRDG=PROGRAMMER R=REVISION RD=RESTRICTED DISTRIBUTION REF=REFERENCE
 SLI=STANDARD LIBRARY ITEM S/R=SLI INTERNAL-RD CUSTOMER S/S=SUBSYSTEM SU=SLI SPERRY UNIVAC ONLY

DOCUMENT NUMBER	SYSTEM	TYPE	T I T L E	A N D / O R	D E S C R I P T I O N	#PP	STATUS
UP-8260 R3	UTS700	SLI	REMOTE BATCH TERMINAL SYSTEM USER GUIDE			334	C
UP-8261 R3	UTS700	SLI	UTS 700 UNIVERSAL TERMINAL SYSTEM OPERATIONS HANDBOOK OPERATOR REFERENCE			423	C
UP-8406 R2	UTS700	SLI	UNIVERSAL TERMINAL SYSTEM SYSTEM DESCRIPTION			49	C
UP-8497	UTS700	SLI	UTS 700 SUMMARY OF CURRENT DOCUMENTATION JAN-79			6	C
UP-8529	UTS700	RD	INTRODUCTION TO DATA STORAGE			18	C
UP-8531	UTS700	RD	INTRODUCTION TO DATA COMMUNICATIONS			36	C
UP-8532	UTS700	RD	INTRODUCTION TO COMPUTERS			36	C
UP-6533	UTS700	RD	INTRODUCTION TO PROGRAMMING			31	C
UP-8534	UTS700	RD	GLOSSARY OF COMPUTER TERMS			51	C
UP-8564 R2	UTS700	SLI	REPORT PROGRAM GENERATOR II (RPG II) REFERENCE CARD			17	C
UP-8609	UTS700	RD	0871 MAGNETIC TAPE SUBSYSTEM OPERATOR REFERENCE			27	C
UP-8617	UTS700	RD	0719 CARD READER SUBSYSTEM OPERATOR REFERENCE			21	C
UP-8896	UTS700	RD	0608 CARD PUNCH SUBSYSTEM OPERATOR REFERENCE			32	C

ABBREVIATIONS

C=CURRENT OPR=OPERATOR PROG=PROGRAMMER R=REVISION RD=RESTRICTED DISTRIBUTION REF=REFERENCE
 SLI=STANDARD LIBRARY ITEM S/R=SLI INTERNAL-RD CUSTOMER S/S=SUBSYSTEM SU=SLI SPERRY UNIVAC ONLY

DOCUMENT NUMBER	SYSTEM	TITLE AND/OR DESCRIPTION	MAILING LISTS	
			1	2
UP-8260 R3	UTS700	REMOTE BATCH TERMINAL SYSTEM USER GUIDE	X	X
UP-8261 R3	UTS700	UTS 700 UNIVERSAL TERMINAL SYSTEM OPERATIONS HANDBOOK OPERATOR REFERENCE	X	X
UP-8371 R2 (A)	UTS700	REPORT PROGRAM GENERATOR II (RPGII) USER GUIDE	X	X
UP-8406 R2	UTS700	UNIVERSAL TERMINAL SYSTEM SYSTEM DESCRIPTION	X	X
UP-8407 R3	UTS700	COMMUNICATIONS USER GUIDE	X	X
UP-8497	UTS700	UTS 700 SUMMARY OF CURRENT DOCUMENTATION JAN-79	X	X
UP-8564 R2	UTS700	REPORT PROGRAM GENERATOR II (RPG II) REFERENCE CARD	X	X
UP-8610.1	UTS700	BULLETIN #1	X	X
UP-8610.2	UTS700	UTS700 BULLETIN #2	X	X