

.REM _

IDENTIFICATION

PRODUCT CODE: AC-E848D-MC
PRODUCT NAME: CXAAADO AA11/VT01-A MODULE
PRODUCT DATE: SEPTEMBER 1978
MAINTAINER: DEC/X11 SUPPORT GROUP

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITALS COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1973,1978 DIGITAL EQUIPMENT CORPORATION

1. ABSTRACT:

AAA IS A IOMOD THAT EXERCISES THE AA11 SCOPE CONTROLLER. A CONFIDENCE LOGIC TEST IS EXECUTED ON THE CONTROL/STATUS, X POSITION AND Y POSITION REGISTERS. ALL LOGIC ERRORS ARE REPORTED TO THE CONSOLE TELETYPE. THE MAJOR PORTION OF THIS MODULE IS DEFERRED TO LEVEL 0 SERVICE. A SIX LETTER MESSAGE (PDP-11) WILL BE PLOTTED ON THE SCREEN DURING EXECUTION. THIS ROUTIN IS INTERRUPT DRIVEN & FLICKERS MAY RESULT IF OTHER DEVICES ARE BEING TESTED

2. REQUIREMENTS:

HARDWARE: AA11 INTERFACE WITH A VT01-A (DIGITAL MODIFIED TEXTRONICS X-611 DISPLAY)

STORAGE:: AAA REQUIRES:
1. DECIMAL WORDS: 288
2. OCTAL WORDS: 0440
3. OCTAL BYTES: 1100

3. PASS DEFINITION:

ONE PASS OF THE XAAAB MODULE CONSISTS OF DISPLAYING 55,296 POINTS ON THE SCREEN. THIS MEANS THAT 55,296 DATA TRANSFERS OCCURED ON THE UNIBUS.

4. EXECUTION TIME:

VARIABLES WITH SCOPE DELAY BUT SHOULD TAKE AN AVERAGE OF -----
----- TO COMPLETE ONE PASS. WHEN RUNNING ALONE.

5. CONFIGURATION PARAMETERS:

DEFAULT PARAMETERS:

DVA: 176756, VCT: 140, BR1: 4

REQUIRED PARAMETERS: NONE

6. DEVICE OPTION SETUP:

A. TURN ON SCOPE POWER.

7. MODULE OPERATION:

7.1 TEST SEQUENCE:

- A. START: USING THE DEVICE ADDRESS, THIS SECTION OF CODE, DETERMINES THE CONTROL, X AND Y POSITION ADDRESSES, AND VECTORS.
- B. PRIMF: IN THIS SECTION, THE X AXIS, Y AXIS AND CONTROL REGISTERS ARE LOADED. THE SCOPE IS ENABLED AND AN "EXIT" RETURN TO THE MONITOR.
- C. AASVC: UPON A SCOPE INTERRUPT, THE PROGRAM WILL RETURN TO THIS CODE. ENTER DEFERRED SERVICE MODE AND TEST FOR A MODE FLAG. IF NO MODE FLAG, REPORT IT AS AN ERROR.

- D. AASVCA: THRU CHAR13: THIS SECTION SELECTS THE PROPER POINTS TO BE INTENSIFIED ON THE SCREEN.
- E. CHAR11: IN THIS CODE, THE COLOR AND CHANNEL BITS ARE ALTERNATED TO DISPLAY EACH CHANNEL AND COLOR IF A 611/613 SCOPE IS CONNECTED ALTERNATING CHARACTERS WILL HAVE ALTERNATING INTENSITY LEVELS.
- F. CHAR20: IN THIS SECTION, THE PASS COUNT IS DECREMENTED AND TESTED. IF IT DID NOT BECOME ZERO, THEN SELECT ANOTHER CLOCK RATE AND RESUME COUNTING. UPON A ZERO PASS COUNT THE CONTROL AND PRESET REGISTER ARE CLEARED AND "ENDPAS" IS REPORTED.

8. OPERATOR OPTIONS:

NONE

9. NON-STANDARD PRINTOUTS:

NONE: ALL PRINTOUTS HAVE THE STANDARD FORMATS DESCRIBED IN THE DEC/X11 DOCUMENT MAINDEC-11-DXQAAA

JAA-11 DEC/X11 EXERCISER MODULE

```

000000" IOMOD <AAAD > 176756 140 4 100 43
000000" MODULE 140000 AAAD 176756 140 4 100 43
; TITLE AAAD DEC/X11 SYSTEM EXERCISER MODULE
; DDXCUM VERSION 6 23-MAY-78
;*****LIST BIN*****
000000" BEGIN:
000000" 040501 042101 040 MODNAM: -ASCII /AAAD /MODULE NAME.
000005" 000 XFLAG: -BYTE OPEN ;USED TO KEEP TRACK OF WBUFF USAGE
000006" 176756 ADDR: 176756+0 ;1ST DEVICE ADDR.
000010" 000140 VECTOR: 140+0 ;1ST DEVICE VECTOR.
000012" 200 BR1: -BYTE PRTY4+0 ;1ST BR LEVEL.
000013" 000 BR2: -BYTE PRTY+0 ;2ND BR LEVEL.
000014" 000001 DVID1: +1 ;DEVICE INDICATOR 1.
000016" 000000 SR1: OPEN ;SWITCH REGISTER 1.
000020" 000000 SR2: OPEN ;SWITCH REGISTER 2.
000022" 000000 SR3: OPEN ;SWITCH REGISTER 3.
000024" 000000 SR4: OPEN ;SWITCH REGISTER 4.
;*****
000026" 140000 STAT: 140000 ;STATUS WORD.
000030" 000332 INIT: START ;MODULE START ADDR.
000032" 000224 SPOTNT: MODSP ;MODULE STACK POINTER.
000034" 000000 PASCNT: 0 ;PASS COUNTER.
000036" 000144 ICONT: 100. ;# OF ITERATIONS PER PASS=100.
000040" 000000 ICONT: 0 ;LOC TO COUNT ITERATIONS
000042" 000000 SOFCNT: 0 ;LOC TO SAVE TOTAL SOFT ERRORS
000044" 000000 HRDCNT: 0 ;LOC TO SAVE TOTAL HARD ERRORS
000046" 000000 SOFPAS: 0 ;LOC TO SAVE SOFT ERRORS PER PASS
000050" 000000 HRDPAS: 0 ;LOC TO SAVE HARD ERRORS PER PASS
000052" 000000 SYSCNT: 0 ;# OF SYS ERRORS ACCUMULATED
000054" 000000 RANWU: 0 ;HOLDS RANDW # WHEN RAND MACRO IS CALLED
000056" 000000 COMPIC: 0 ;RESERVED FOR MONITOR USE
000056" 000000 RES1: 0 ;RESERVED FOR MONITOR USE
000060" 000000 RES2: 0 ;RESERVED FOR MONITOR USE
000062" 000000 SVR0: OPEN ;LOC TO SAVE R0.
000064" 000000 SVR1: OPEN ;LOC TO SAVE R1.
000066" 000000 SVR2: OPEN ;LOC TO SAVE R2.
000070" 000000 SVR3: OPEN ;LOC TO SAVE R3.
000072" 000000 SVR4: OPEN ;LOC TO SAVE R4.
000074" 000000 SVR5: OPEN ;LOC TO SAVE R5.
000076" 000000 SVR6: OPEN ;LOC TO SAVE R6.
000100" 000000 CSRA: OPEN ;ADDR OF CURRENT CSR.
000102" 000000 SADR: OPEN ;ADDR OF GOOD DATA, OR
000104" 000000 ACSR: OPEN ;CONTENTS OF CSR.
000104" 000000 ASTAT: OPEN ;ADDR OF BAD DATA, OR
000106" 000000 ERTVFP: OPEN ;STATUS REG CONTENTS.
000110" 000000 ASB: OPEN ;TYPE OF ERROR.
000110" 000000 AWAS: OPEN ;EXPECTED DATA.
000112" 000254 RSTRT: RSTRT ;ACTUAL DATA.
000116" 000000 WDFR: OPEN ;RSTRT ADDRESS AFTER END OF PASS
;WORDS TO MEMORY PER ITERATION
;WORDS FROM MEMORY PER ITERATION

```

```

000120" 000000 INTR: OPEN ;# OF INTERRUPTS PER ITERATION
000122" 000043 IDNUM: 43 ;MODULE IDENTIFICATION NUMBER=43
;*****LIST BIN*****
000224" MODSP:
;*****
;REGISTER ADDRESS DEFINITIONS
000224" 000000 SCSR: OPEN
000226" 000000 DACO: OPEN
000230" 000000 DACI: OPEN
000232" 012767 000322 177656 START: MOV #210,WDFR
000240" 012767 000322 177652 MOV #210,INTR
000246" 012767 000011 177644 MOV #11,INTR
000254" 016705 177526 RSTRT: MOV ADDR,R5 ;GET 1ST ADDRESS
000260" 010567 177740 MOV R5,SCSR ;BUILD REG. ADDRESSES
000264" 010567 177734 MOV R5,DACO
000272" 005725 MOV R5,DACI
000274" 018700 177730 TST R5
000300" 018700 177504 MOV R5,DACI
000304" 012720 000342 MOV VECTOR,R0 ;GET VECTOR ADDRESS
000310" 016720 177476 MOV #A11(0)+ ;SET UP INTR. RETURN
000314" 016767 177704 MOV BR1(0)+ ;SET UP PRIORITY
000322" 012767 000144 177556 MOV SCSR,CSRA ;PUT CSR ADDRESS IN CSRA
000330" 012777 000100 177666 MOV #100,COUNT ;DO IT 100 TIMES PER PASS
000336" 104400 000000 WDFR: MOV #100,SCSR ;TURN ON THE INTERRUPT
EXITS,BEGIN ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
;*****
;INTERRUPT SERVICE ROUTINES TO DISPLAY "PDP-11" ON SCOPE
A111:
000342" 000004 000000 000352 PIRQS,BEGIN,A11A ; QUEUE UP TO CONTINUE AT A11A AND RTI
;*****
000350" 000352 177646 A11A: TSTR @SCSR A11A ;IS DONE SET
000356" 104413 177646 BNL A11B ;BR IF DONE IS SET
000360" 017767 177640 177514 MOV @SCSR,ACSR ;SAVE CONTENTS OF THE CSR IN ACSR
000366" 042777 000100 177630 BIC #100,@SCSR ;TURN OFF INTERRUPT
;*****
000374" 104405 000000 000000 A11B: HDRS,BEGIN,NULL ;DONE DID NOT SET
ENDS,BEGIN ;
000402" 104410 000000 000452 A118: MOV #0,XPOS ;SHOULD WORK FOR ALL SCOPES
000408" 012767 000000 CLR YPOS
000414" 005067 000444 MOV #6,CNTR ;# CHARACTER COUNT
000420" 012767 000006 000446 MOV #TEXT,PNTNTR ;TEXT="PDP-11"
000426" 012767 001014 000436 MOV #CHARS,@VECTOR ;POINT NEXT INTR TO CHARS
000434" 012777 000540 177346

```

```

276 000442 017767 000424 000410 TTT1: MOV @PNTR, AAR2
277 ;PLOT CHARACTER
278 000450 016767 000410 000412 CHAR: MOV YPOS, YPT ;INIT ENTER WITH SCOPE INTERRUPT
279 000456 052777 000024 177520 BIC #24, @SCSR ;ENABLE INTENSIFY OF LOADING Y
280 000464 017767 177773 000352 MOV #9, AAR0 ;MATRIX COUNT (ROW)
281 000472 017767 177771 000356 CHAR1: MOV #9, AAR1 ;MATRIX COUNT (COLUMN)
282 000500 117767 000354 000354 MOV @AAR2, AAR3 ;GET CHARACTER
283 000506 052767 000346 INC AAR3 ;
284 000512 105167 000346 CHAR2: MOV AAR3 ;INTENSIFY POINT?
285 000516 100026 BPL CHAR13 ;NO
286 000520 016777 000342 177500 MOV XPOS, @DAC0 ;LOAD X
287 000526 016777 000342 177474 MOV YPOS, @DAC1 ;LOAD Y AND INTENSIFY
288 000534 104400 000000 EXITS, BEGIN ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
289
290 000540 CHAR3:
291 ;-----
292 000540 000004 000000 000546 PIRQS, BEGIN, AS ; QUEUE UP TO CONTINUE AT AS AND RTI
293 ;-----
294 AS: ; IS DOWN SET
295 000546 105777 177452 ; BR IF DONE SET
296 000552 100410 ; SAVE CONTENTS OF CSR
297 000554 017767 177444 177320 MOV @SCSR, ACSR
298 ;*****
299 000562 104405 000000 000000 HDRRS, BEGIN, NULL ; DONE DID NOT SET
300 ;*****
301 000570 104410 000000 ENDS, BEGIN ;
302 000574 062767 000070 000262 CHAR13: ADD #70, YPOS ;NEXT POINT
303 000602 052767 000250 INC AAR2 ;DONE ALL POINTS IN A COLUMN?
304 000606 016767 000254 000246 MOV YPT, YPOS ;NO
305 000610 016767 000254 000246 MOV YPT, YPOS ;NEXT COLUMN
306 000616 062767 000070 000242 ADD #70, XPOS ;ADD SCALE
307 000624 052767 000224 INC AAR0 ;DONE ALL COLUMNS?
308 000630 013320 BNE CHAR1 ;NO
309 000632 062767 000070 000226 ADD #70, XPOS ;YES, POSITION FOR NEXT CHARACTER
310 000640 062767 000002 000224 ADD #2, PNTR ;NEXT CHARACTER
311 000646 052767 177144 TST SRI ;TWO COLOR SCOPE ??
312 000654 017777 001000 177342 BNE CHAR4 ;BR IF NOT
313 000662 011010 SET #1000, @SCSR ;GREEN BIT SET ??
314 000664 052777 001000 177332 BNE #5 ;BR IF SET
315 000672 012777 000714 177110 MOV #CHAR4, @VECTOR ;NO SET FOR GREEN
316 000700 104400 000000 3S: EXITS, BEGIN ;POINT NEXT INTR TO CHAR4
317 000704 042777 001000 177312 BIC #1000, @SCSR ;EXIT TO MONITOR. MODULE WAIT FOR INTERRUPT.
318 000712 000767 BR 3S ;CLEAR GREEN BIT
319 ;GO EXIT
320 CHAR4:
321 ;-----
322 000714 000004 000000 000722 PIRQS, BEGIN, 1S ; QUEUE UP TO CONTINUE AT 1S AND RTI
323 ;-----
324 1S: ; WAS THE DONE BIT SET??
325 000726 100410 ; BR IF YES
326 000730 017767 177270 177144 MOV @SCSR, ACSR ;SAVE CONTENTS OF THE CSR
327 ;*****
328 000736 104405 000000 000000 HDRRS, BEGIN, NULL ; DONE NOT SET
329 ;*****
330 000744 104410 000000 ENDS, BEGIN ;
331 000750 012777 000540 177032 MOV #CHAR3, @VECTOR ;RESET VECTOR

```

```

332 000756 005367 000112 CH4A: DEC CNTR ;DONE ALL?
333 000762 001777 177232 BNE TTT1 ;NO
334 000764 042777 000002 177110 BIC #2, @SCSR ;INIT AND ERASE
335 000772 005367 000100 DEC COUNT ;COUNT IT
336 000776 001002 177220 BNE 1S ;BR IF 100. TIMES
337 001000 005077 CLR @SCSR
338 001004 104413 000000 1S: ENDIRS, BEGIN ;SIGNAL END OF ITERATION.
339 001010 000167 177372 ;MONITOR SHALL TEST END OF PASS
340 ;GO DO IT AGAIN
341 ;TEXT FOR A111 DAC WITH SCOPE OPTION
342 ;TEXT = "PDP11"
343 ;TEXT:
344 001014 001030 P
345 001016 001042 XD
346 001018 001050 DASH
347 001022 001035 NI
348 001024 001047 NI
349 001026 001047 NI
350 001030 177 011 P: .BYTE 177, 11, 11, 11, 6
351 001033 011 006 010 DASH: .BYTE 0, 10, 10, 10, 0
352 001035 000 010 101 XD: .BYTE 177, 101, 101, 101, 76
353 001040 010 000 177 N1: .BYTE 0, 102, 177, 100, 0
354 001042 177 011 076
355 001046 101 102
356 001047 000 102
357 001052 100 000 .EVEN
358
359 AARO: OPEN ;A111 (ROW)
360 AAR1: OPEN ;A111 (COLUMN)
361 AAR2: OPEN ;CHARACTER POINTER
362 AAR3: OPEN ;HOLDS CHARACTER
363 YPOS: OPEN
364 YPT: OPEN
365 XPOS: OPEN
366 PNTR: OPEN
367 CNTR: OPEN
368 COUNT: OPEN ;KEEPS TRACK OF SWIPES PER PASS
369
370
371 000001 .END

```


SPSIZ =	000040	1#	222				
SR1	000016R	183#	311				
SR2	000020R	183#					
SR3	000022R	184#					
SR4	000023R	185#					
START	000232R	185#	238#				
STAT	000026R	187#					
SVR0	000062R	202#					
SVR1	000064R	203#					
SVR2	000066R	204#					
SVR3	000070R	205#					
SVR4	000072R	206#					
SVR5	000074R	207#					
SVR6	000076R	208#					
SYSCMT	000052R	197#					
TEXT	001014R	274#	344#				
TRPDFD=	000022	274#					
TX1	000442R	274#	333				
VECTOR	000010R	178#	248	275*	316*	331*	
WASADR	000104R	212#					
WDFR	000116R	213#	238*				
WDT0	00014R	213#					
XD	001042R	345#	354#				
XFLAG	000005R	176#					
XPOS	001066R	271#	286	306*	309*	365#	
YPOS	001064R	272#	298	307*	302*	305*	364#
YPT	001070R	278*	305	366#			

- ABS. 000000 000
 001100 001

ERRORS DETECTED: 0
 DEFAULT GLOBALS GENERATED: 0
 XAAAD0,XAAAD0/SOL/CRP:SYN=DDXCON,XAAAD0
 RUN-TIME: 1 1 3 SECONDS
 RUN-TIME RATIO: 11/3=3.6
 CORE USED: 7K (13 PAGES)