

CBIOS4.PRN

```

*****
*
* CBIOS FOR CP/M VER 2.2 FOR DISK JOCKEY 2D CONTROLLER (ALL
* REVS). HANDLES DISKETTES WITH SECTOR SIZES OF 128 BYTES
* SINGLE DENSITY, 256, 512, 1024 BYTES DOUBLE DENSITY.
*
* WRITTEN BY BOBBY DALE GIFFORD.
* 9/1/79
*
* CUSTOMIZED BY JAY O'BRIEN.
* 4/12/81
*
* MODIFIED FOR ADDITIONAL PRINTER ON PORT 0 WITH PRINTER BUSY
* ON PORT 5 BIT 1
* 11/9/81
*
* DISK MAP OF SECTORS USED BY COLD BOOT, WARM BOOT, FIRMWARE,
* AND CP/M:
*
* TRK 0 SEC 1 = FIRST SECTOR OF COLD BOOT.          E700H
*           2 = COLD BOOT 256.                      80H
*           3 = COLD BOOT 512.                      80H
*           4 = COLD BOOT 1024.                     80H
*           5 = WARM BOOT 256.                      80H
*           6 = WARM BOOT 512.                      80H
*           7 = WARM BOOT 1024.                     80H
*           8 = COLD/WARM BOOT.                     3200H
*           9 = FIRMWARE.                           E400H
*           10 = FIRMWARE+80H.                      E480H
*           11 = FIRMWARE+100H.                    E500H
*           12 = FIRMWARE+180H.                   E580H
*           13 = FIRMWARE+200H.                   E600H
*           14 = FIRMWARE+280H.                   E680H
*           15 = FIRMWARE+300H.                   E700H
*           16 = FIRMWARE+380H.                   E780H
*           17 = CCP.                               2D00H
*           18 = CCP+80H.                          2D80H
*           19 = CCP+100H.                         2E00H
*           20 = CCP+180H.                         2E80H
*           21 = CCP+200H.                         2F00H
*           22 = CCP+280H.                         2F80H
*           23 = CCP+300H.                         3000H
*           24 = CCP+380H.                         3080H
*           25 = CCP+400H.                         3100H
*           26 = CCP+480H.                         3180H
*           1 = REST OF CP/M.                      3200H-4FFFH
*
*****

```

*The BIOS IN THE  
MOV CP/M ROM  
WORKS FINE.*

TITLE '\*\*\* Cbios For CP/M Ver. 2.2 \*\*\*'

```

*****
*
* THE FOLLOWING REVISION NUMBER IS IN REFERENCE TO THE CP/M
* 2.0 CBIOS.
*
*****

```

001E = REVNUM EQU 30 ;CBIOS REVISION NUMBER
0016 = CPMREV EQU 22 ;CP/M REVISION NUMBER

\*\*\*\*\*
\*
\* THE FOLLOWING EQUATES RELATE THE THINKER TOYS 2D CONTROLLER.
\* IF THE CONTROLLER IS NON STANDARD (0E000H) ONLY THE ORIGIN
\* EQUATE NEED BE CHANGED. THIS VERSION OF THE CBIOS WILL WORK
\* WITH 2D CONTROLLER BOARDS REV 0, 1, 3, 3.1, 4.
\*

E000 = ORIGIN EQU 0E000H
E400 = DJRAM EQU ORIGIN+400H ;DISK JOCKEY 2D RAM ADDRESS
E403 = DJCIN EQU DJRAM+3H ;DISK JOCKEY 2D CHARACTER INPUT ROUTINE
E406 = DJCOUT EQU DJRAM+6H ;DISK JOCKEY 2D CHARACTER OUTPUT ROUTINE
E409 = DJHOME EQU DJRAM+9H ;DISK JOCKEY 2D TRACK ZERO SEEK
E40C = DJTRK EQU DJRAM+0CH ;DISK JOCKEY 2D TRACK SEEK ROUTINE
E40F = DJSEC EQU DJRAM+0FH ;DISK JOCKEY 2D SET SECTOR ROUTINE
E412 = DJDMA EQU DJRAM+012H ;DISK JOCKEY 2D SET DMA ADDRESS
E415 = DJREAD EQU DJRAM+15H ;DISK JOCKEY 2D READ ROUTINE
E418 = DJWRITE EQU DJRAM+18H ;DISK JOCKEY 2D WRITE ROUTINE
E41B = DJSEL EQU DJRAM+1BH ;DISK JOCKEY 2D SELECT DRIVE ROUTINE
E421 = DJTSTAT EQU DJRAM+21H ;DISK JOCKEY 2D TERMINAL STATUS ROUTINE
E427 = DJSTAT EQU DJRAM+27H ;DISK JOCKEY 2D STATUS ROUTINE
E42A = DJERR EQU DJRAM+2AH ;DISK JOCKEY 2D ERROR, FLASH LED
E42D = DJDEN EQU DJRAM+2DH ;DISK JOCKEY 2D SET DENSITY ROUTINE
E430 = DJSIDE EQU DJRAM+30H ;DISK JOCKEY 2D SET SIDE ROUTINE

\*\*\*\*\*
\*
\* EQUATES FOR MY SYSTEM. J.J. O'BRIEN
\*

E800 = MSDV EQU 0E800H ;VIDEO DRIVER FOR MSDV

\*\*\*\*\*
\*
\* CP/M SYSTEM EQUATES. IF RECONFIGURATION OF THE CP/M SYSTEM
\* IS BEING DONE, THE CHANGES CAN BE MADE TO THE FOLLOWING
\* EQUATES.
\*

0038 = MSIZE EQU 56 ;MEMORY SIZE OF TARGET CP/M
9000 = BIAS EQU (MSIZE-20)\*1024 ;MEMORY OFFSET FROM 20K SYSTEM
BD00 = CCP EQU 2D00H+BIAS ;CONSOLE COMMAND PROCESSOR
C500 = BDOS EQU CCP+800H ;BDOS ADDRESS
D300 = BIOS EQU CCP+1600H ;CBIOS ADDRESS
0004 = CDISK EQU 4 ;ADDRESS OF LAST LOGGED DISK
0080 = BUFF EQU 80H ;DEFAULT BUFFER ADDRESS
0100 = TPA EQU 100H ;TRANSIENT MEMORY
00C0 = INTIOBY EQU 192 ;INITIAL IOBYTE

64 = 40
01000000

192 C 0
11000000

```

0003 = IOBYTE EQU 3 ;IOBYTE LOCATION
0000 = WBOT EQU 0 ;WARM BOOT JUMP ADDRESS
0005 = ENTRY EQU 5 ;BDOS ENTRY JUMP ADDRESS

```

= 11000011  
195 = C3

```

*****
*
* THE FOLLOWING ARE INTERNAL CBIOS EQUATES. MOST ARE MISC.
* CONSTANTS.
*
*****

```

```

000A = RETRIES EQU 10 ;MAX RETRIES ON DISK I/O BEFORE ERROR
000D = ACR EQU 0DH ;A CARRIAGE RETURN
000A = ALF EQU 0AH ;A LINE FEED
0003 = AETX EQU 3 ;A ETX CHAR
0006 = AACK EQU 6 ;A ACK CHAR
0019 = CLEAR EQU 19H ;CLEAR SCREEN FOR MSDV
0004 = MAXDISK EQU 4 ;MAXIMUM # OF DISK DRIVES
0008 = DBLSID EQU 8 ;SIDE BIT FROM CONTROLLER

```

```

*****
*
* THE JUMP TABLE BELOW MUST REMAIN IN THE SAME ORDER, THE
* ROUTINES MAY BE CHANGED, BUT THE FUNCTION EXECUTED MUST BE
* THE SAME.
*
*****

```

```

D300          ORG      BIOS          ;CBIOS STARTING ADDRESS

D300 C3A0D3    JMP      CBOOT         ;COLD BOOT ENTRY POINT
D303 C3FCD3    WBOOTE  JMP      WBOOT         ;WARM BOOT ENTRY POINT
D306 C340D6    JMP      CONST         ;CONSOLE STATUS ROUTINE
D309 C34CD6    JMP      CONIN          ;CONSOLE INPUT
D30C C361D6    COUT   JMP      CONOUT         ;CONSOLE OUTPUT
D30F C381D6    JMP      LIST           ;LIST DEVICE OUTPUT
D312 C376D6    JMP      PUNCH          ;PUNCH DEVICE OUTPUT
D315 C36CD6    JMP      READER         ;READER DEVICE INPUT
D318 C390D4    JMP      HOME           ;HOME DRIVE
D31B C3C6D4    JMP      SETDRV          ;SELECT DISK
D31E C392D4    JMP      SETTRK         ;SET TRACK
D321 C385D4    JMP      SETSEC         ;SET SECTOR
D324 C38AD4    JMP      SETDMA         ;SET DMA ADDRESS
D327 C369D5    JMP      READ            ;READ THE DISK
D32A C362D5    JMP      WRITE           ;WRITE THE DISK
D32D C38CD6    JMP      LISTST         ;LIST DEVICE STATUS
D330 C397D4    JMP      SECTAN         ;SECTOR TRANSLATION
D333 C31BE4    DJDRV   JMP      DJSEL          ;HOOK FOR SINGLE.COM PROGRAM

```

```

*****
*
* SIGNON MESSAGE OUTPUT DURING COLD BOOT.
*
*****

```

```

D336 0D0A0A  PROMPT  DB      ACR,ALF,ALF

```

```

D339 35 DB '0'+MSIZE/10 ;CP/M MEMORY SIZE
D33A 36 DB '0'+(MSIZE MOD 10)
D33B 4B2043502F DB 'K CP/M Vers. ' ;CP/M VERSION NUMBER
D348 32 DB CPMREV/10+'0'
D349 2E DB '.'
D34A 32 DB (CPMREV MOD 10)+'0'
D34B 2C20436269 DB ', Cbios rev '
D357 332E DB REVNUM/10+'0', '.' ;CBIOS REVISION NUMBER
D359 30 DB REVNUM MOD 10+'0'
D35A 0D0A DB ACR,ALF
D35C 466F722054 DB 'For Thinker Toys Disk Jockey 2D Controller '
D387 402030 DB '@ 0'

```

```

D38A 45 IF ORIGIN/4096 > 10 ;CONTROLLER ORIGIN (HEX)
DB ORIGIN/4096+'A'-10
ELSE
DB ORIGIN/4096+'0'
ENDIF

```

```

D38B 30 IF (ORIGIN/256 AND 0FH) > 10
DB (ORIGIN/256 AND 0FH)+'A'-10
ELSE
DB (ORIGIN/256 AND 0FH)+'0'
ENDIF
D38C 3030482E DB '00H.'
D390 0D0A00 DB ACR,ALF,0

```

```

*****
*
* UTILITY ROUTINE TO OUTPUT THE MESSAGE POINTED AT BY H&L,
* TERMINATED WITH A NULL.
*
*****

```

```

D393 7E MESSAGE MOV A,M ;GET A CHARACTER OF THE MESSAGE
D394 23 INX H ;BUMP TEXT POINTER
D395 A7 ANA A ;TEST FOR END
D396 C8 RZ ;RETURN IF DONE
D397 E5 PUSH H ;SAVE POINTER TO TEXT
D398 4F MOV C,A ;OUTPUT CHARACTER IN C
D399 CD0CD3 CALL COUT ;OUTPUT THE CHARACTER
D39C E1 POP H ;RESTORE THE POINTER
D39D C393D3 JMP MESSAGE ;CONTINUE UNTIL NULL REACHED

```

```

*****
*
* CBOOT IS THE COLD BOOT LOADER. ALL OF CP/M HAS BEEN LOADED IN
* WHEN CONTROL IS PASSED HERE.
*
*****

```

```

D3A0 310001 CBOOT LXI SP,TPA ;SET UP STACK
D3A3 CD3AD7 CALL TINIT ;INITIALIZE THE TERMINAL
D3A6 2136D3 LXI H,PROMPT ;PREP FOR SENDING SIGNON MESSAGE
D3A9 CD93D3 CALL MESSAGE ;SEND THE PROMPT
D3AC AF XRA A ;SELECT DISK A

```

D3AD 32E9D8 STA CPMDRV  
 D3B0 320400 STA CDISK

\*\*\*\*\*  
 \*  
 \* GOCPM IS THE ENTRY POINT FROM COLD BOOTS, AND WARM BOOTS. IT \*  
 \* INITIALIZES SOME OF THE LOCATIONS IN PAGE 0, AND SETS UP THE \*  
 \* INITIAL DMA ADDRESS (80H). \*  
 \*  
 \*\*\*\*\*

D3B3 218000 GOCPM LXI H,BUFF ;SET UP INITIAL DMA ADDRESS  
 D3B6 CD8AD4 CALL SETDMA  
 D3B9 3EC3 MVI A,(JMP) ;INITIALIZE JUMP TO WARM BOOT  
 D3BB 320000 STA WBOT  
 D3BE 320500 STA ENTRY ;INITIALIZE JUMP TO BDOS  
 D3C1 2103D3 LXI H,WBOOTE ;ADDRESS IN WARM BOOT JUMP  
 D3C4 220100 SHLD WBOT+1  
 D3C7 2106C5 LXI H,BDOS+6 ;ADDRESS IN BDOS JUMP  
 D3CA 220600 SHLD ENTRY+1  
 D3CD AF XRA A ;A <- 0  
 D3CE 32EED8 STA BUFSEC ;DISK JOCKEY BUFFER EMPTY  
 D3D1 32D5D5 STA BUFWRN ;SET BUFFER NOT DIRTY FLAG  
 D3D4 3A0400 LDA CDISK ;JUMP TO CP/M WITH CURRENTLY SELECTED DISK IN C  
 D3D7 4F MOV C,A  
 D3D8 11FBD3 LXI D,CMNDBEG ;BEGINNING OF INITIAL COMMAND  
 D3DB 2108BD LXI H,CCP+8 ;COMMAND BUFFER  
 D3DE 3E01 MVI A,CMNDEND-CMNDBEG+1 ;LENGTH OF COMMAND  
 D3E0 3207BD STA CCP+7  
 D3E3 47 MOV B,A  
 D3E4 CD37D6 CALL MOVLOP  
 D3E7 3AF9D3 LDA CWFLG  
 D3EA A7 ANA A  
 D3EB 3AFAD3 LDA AUTOFLG  
 D3EE CAF2D3 JZ CLDBOT  
 D3F1 1F RAR  
 D3F2 1F CLDBOT RAR  
 D3F3 DA00BD JC CCP  
 D3F6 C303BD JMP CCP+3 ;ENTER CP/M  
  
 D3F9 00 CWFLG DB 0 ;COLD/WARM BOOT FLAG

\*\*\*\*\*  
 \*  
 \* THE FOLLOWING BYTE DETERMINES IF AN INITIAL COMMAND IS TO BE \*  
 \* GIVEN TO CP/M ON WARM OR COLD BOOTS. THE VALUE OF THE BYTE IS \*  
 \* USED TO GIVE THE COMMAND TO CP/M: \*  
 \*  
 \* 0 = NEVER GIVE COMMAND. \*  
 \* 1 = GIVE COMMAND ON COLD BOOTS ONLY. \*  
 \* 2 = GIVE THE COMMAND ON WARM BOOTS ONLY. \*  
 \* 3 = GIVE THE COMMAND ON WARM AND COLD BOOTS. \*  
 \*  
 \*\*\*\*\*

D3FA 01 AUTOFLG DB 1 ;AUTO COMMAND FEATURE

```

*****
*
* IF THERE IS A COMMAND INSERTED HERE, IT WILL BE GIVEN IF THE
* AUTO FEATURE IS ENABLED.
*   FOR EXAMPLE:
*
*   CMNDBEG DB      'MBASIC MYPROG'
*   CMNDEND DB      0
*
* WILL EXECUTE MICROSOFT BASIC, AND MBASIC WILL EXECUTE THE
* "MYPROG" BASIC PROGRAM.
*
*****

```

```

D3FB 00 CMNDBEG DB      ''           ;INITIAL COMMAND GOES HERE
        CMNDEND DB      0

```

```

*****
*
* WBOOT LOADS IN ALL OF CP/M EXCEPT THE CBIOS, THEN INITIALIZES
* SYSTEM PARAMETERS AS IN COLD BOOT. SEE THE COLD BOOT LOADER
* LISTING FOR EXACTLY WHAT HAPPENS DURING WARM AND COLD BOOTS.
*
*****

```

```

D3FC 310001 WBOOT   LXI     SP,TPA           ;SET UP STACK POINTER
D3FF 3E01    MVI     A,1
D400 =      WFLG   EQU     $-1             ;TEST IF BEGINNING OR
D401 A7     ANA     A                     ;   ENDING A WARM BOOT
D402 3E01    MVI     A,1
D404 3200D4 STA     WFLG
D407 32F9D3 STA     CWFLG           ;SET COLD/WARM BOOT FLAG
D40A CAB3D3 JZ      GOCPM
D40D AF     XRA     A
D40E 3200D4 STA     WFLG
D411 4F     MOV     C,A
D412 CD33D3 CALL    DJDRV           ;SELECT DRIVE A
D415 0E00    MVI     C,0             ;SELECT SINGLE DENSITY
D417 CD2DE4 CALL    DJDEN
D41A 0E00    MVI     C,0             ;SELECT SIDE 0
D41C CD30E4 CALL    DJSIDE
D41F 3E0F    MVI     A,15           ;INITIALIZE THE SECTOR TO READ
D421 323FD4 STA     NEWSEC
D424 2100BC LXI     H,CCP-100H         ;AND THE DMA ADDRESS
D427 225ED4 SHLD   NEWDMA
D42A CD3ED4 CALL    WARMLOD        ;READ IN CP/M
D42D 0100C2 LXI     B,CCP+500H       ;LOAD ADDRESS FOR REST OF WARM BOOT
D430 CD12E4 CALL    DJDMA
D433 0E08    MVI     C,8
D435 CD0FE4 CALL    DJSEC
D438 CD72D4 CALL    WARMRD
D43B C303C2 JMP     CCP+503H

D43E 3E0F    WARMLOD MVI     A,15           ;PREVIOUS SECTOR
D43F =      NEWSEC EQU     $-1

```

```

D440 3C          INR      A          ;UPDATE THE PREVIOUS SECTOR
D441 3C          INR      A
D442 FE1B       CPI      27         ;WAS IT THE LAST ?
D444 DA56D4     JC       NOWRAP
D447 D609       SUI      9          ;YES
D449 FE13       CPI      19
D44B C8         RZ
D44C 2A5ED4     LHL D    NEWDMA
D44F 1180FB     LXI      D,-480H
D452 19         DAD      D
D453 225ED4     SHLD   NEWDMA
D456 323FD4     NOWRAP STA    NEWSEC          ;SAVE THE NEW SECTOR TO READ
D459 4F         MOV     C,A
D45A CD0FE4     CALL   DJSEC
D45D 2100BC     LXI    H,CCP-100H          ;GET THE PREVIOUS DMA ADDRESS
D45E =          NEWDMA EQU    $-2
D460 110001     LXI    D,100H             ;UPDATE THE DMA ADDRESS
D463 19         DAD      D
D464 225ED4     SHLD   NEWDMA          ;SAVE THE DMA ADDRESS
D467 44         MOV     B,H
D468 4D         MOV     C,L
D469 CD12E4     CALL   DJDMA            ;SET THE DMA ADDRESS
D46C CD72D4     CALL   WARMRD
D46F C33ED4     JMP    WARMLOD
    
```

```

D472 01000A     WARMRD LXI    B,RETRIES*100H+0;MAXIMUM # OF ERRORS
D475 C5         WRMREAD PUSH   B
D476 CD0CE4     CALL   DJTRK            ;SET THE TRACK
D479 CD15E4     CALL   DJREAD           ;READ THE SECTOR
D47C C1         POP    B
D47D D0         RNC                    ;CONTINUE IF SUCCESSFUL
D47E 05         DCR    B
D47F C275D4     JNZ    WRMREAD          ;KEEP TRYING
D482 C32AE4     JMP    DJERR
    
```

```

*****
*
* SETSEC JUST SAVES THE DESIRED SECTOR TO SEEK TO UNTIL AN
* ACTUAL READ OR WRITE IS ATTEMPTED.
*
*****
    
```

```

D485 79         SETSEC MOV     A,C          ;SAVE THE SECTOR NUMBER
D486 32E8D8     STA    CPMSEC          ;CP/M SECTOR #
D489 C9         RET
    
```

```

*****
*
* SETDMA SAVES THE DMA ADDRESS FOR THE DATA TRANSFER.
*
*****
    
```

```

D48A 60         SETDMA MOV     H,B          ;HL <- BC
D48B 69         MOV     L,C
D48C 22B5D5     SHLD   CPMDMA          ;CP/M DMA ADDRESS
D48F C9         RET
    
```

```
*****
*
* HOME IS TRANSLATED INTO A SEEK TO TRACK ZERO.
*
*****
```

```
D490 0E00 HOME MVI C,0 ;TRACK TO SEEK TO
```

```
*****
*
* SETTRK SAVES THE TRACK # TO SEEK TO. NOTHING IS DONE AT THIS
* POINT, EVERYTHING IS DEFERRED UNTIL A READ OR WRITE.
*
*****
```

```
D492 79 SETTRK MOV A,C ;A <- TRACK #
D493 32EAD8 STA CPMTRK ;CP/M TRACK #
D496 C9 RET
```

```
*****
*
* SECTRAN TRANSLATES A LOGICAL SECTOR # INTO A PHYSICAL SECTOR
* #.
*
*****
```

```
D497 03 SECTRAN INX B
D498 D5 PUSH D ;SAVE TABLE ADDRESS
D499 C5 PUSH B ;SAVE SECTOR #
D49A CD41D5 CALL GETDPB ;GET DPB ADDRESS INTO HL
D49D 7E MOV A,M ;GET # OF CP/M SECTORS/TRACK
D49E B7 ORA A ;CLEAR CARY
D49F 1F RAR ;DIVIDE BY TWO
D4A0 91 SUB C
D4A1 F5 PUSH PSW ;SAVE ADJUSTED SECTOR
D4A2 FAAED4 JM SIDETWO
D4A5 F1 SIDEA POP PSW ;DISCARD ADJUSTED SECTOR
D4A6 C1 POP B ;RESTORE SECTOR REQUESTED
D4A7 D1 POP D ;RESTOR ADDRESS OF XLT TABLE
D4A8 EB SIDEONE XCHG ;HL <- &(TRANSLATION TABLE)
D4A9 09 DAD B ;BC = OFFSET INTO TABLE
D4AA 6E MOV L,M ;HL <- PHYSICAL SECTOR
D4AB 2600 MVI H,0
D4AD C9 RET

D4AE 010F00 SIDETWO LXI B,15 ;OFFSET TO SIDE BIT
D4B1 09 DAD B
D4B2 7E MOV A,M
D4B3 E608 ANI 8 ;TEST FOR DOUBLE SIDED
D4B5 CAA5D4 JZ SIDEA ;MEDIA IS ONLY SINGLE SIDED
D4B8 F1 POP PSW ;RETRIEVE ADJUSTED SECTOR
D4B9 C1 POP B
D4BA 2F CMA ;MAKE SECTOR REQUEST POSITIVE
D4BB 3C INR A
D4BC 4F MOV C,A ;MAKE NEW SECTOR THE REQUESTED SECTOR
```



```

D4BD D1      POP      D
D4BE CDA8D4  CALL     SIDEONE
D4C1 3E80    MVI     A,80H      ;SIDE TWO BIT
D4C3 B5      ORA     L          ;      AND SECTOR
D4C4 6F      MOV     L,A
D4C5 C9      RET
    
```

```

*****
*
* SETDRV SELECTS THE NEXT DRIVE TO BE USED IN READ/WRITE
* OPERATIONS. IF THE DRIVE HAS NEVER BEEN SELECTED BEFORE, A
* PARAMETER TABLE IS CREATED WHICH CORRECTLY DESCRIBES THE
* DISKETTE CURRENTLY IN THE DRIVE. DISKETTES CAN BE OF FOUR
* DIFFERENT SECTOR SIZES:
*   1) 128 BYTES SINGLE DENSITY.
*   2) 256 BYTES DOUBLE DENSITY.
*   3) 512 BYTES DOUBLE DENSITY.
*   4) 1024 BYTES DOUBLE DENSITY.
*
*****
    
```

```

D4C6 79      SETDRV  MOV     A,C          ;SAVE THE DRIVE #
D4C7 32E9D8  STA     CPMDRV
D4CA FE04    CPI     MAXDISK      ;CHECK FOR A VALID DRIVE #
D4CC D23DD5  JNC     ZRET                ;ILLEGAL DRIVE #
D4CF 7B      MOV     A,E          ;TEST IF DRIVE EVER LOGGED IN BEFORE
D4D0 E601    ANI     1
D4D2 C224D5  JNZ     SETDRV1            ;BIT 0 OF E = 0 -> NEVER SELECTED BEFORE
D4D5 3E01    MVI     A,1                ;SELECT SECTOR 1 OF TRACK 1
D4D7 32EBD8  STA     TRUESEC
D4DA 32EAD8  STA     CPMTRK
D4DD CD20D6  CALL    FILL                ;FLUSH BUFFER AND REFILL
D4E0 DA3DD5  JC      ZRET                ;TEST FOR ERROR RETURN
D4E3 CD27E4  CALL    DJSTAT             ;GET STATUS ON CURRENT DRIVE
D4E6 E60C    ANI     0CH                ;STRIP OFF UNWANTED BITS
D4E8 F5      PUSH    PSW                ;USED TO SELECT A DPB
D4E9 1F      RAR
D4EA 215AD5  LXI     H,XLTS            ;TABLE OF XLT ADDRESSES
D4ED 5F      MOV     E,A
D4EE 1600    MVI     D,0
D4F0 19      DAD     D
D4F1 E5      PUSH    H                ;SAVE POINTER TO PROPER XLT
D4F2 CD41D5  CALL    GETDPB             ;GET DPH POINTER INTO DE
D4F5 EB      XCHG
D4F6 D1      POP     D
D4F7 0602    MVI     B,2                ;NUMBER OF BYTES TO MOVE
D4F9 CD37D6  CALL    MOVLOP            ;MOVE THE ADDRESS OF XLT
D4FC 110800  LXI     D,8                ;OFFSET TO DPB POINTER
D4FF 19      DAD     D                ;HL <- &DPH.DPB
D500 E5      PUSH    H
D501 2A07E0  LHLD   ORIGIN+7           ;GET ADDRESS OF DJ TERMINAL OUT ROUTINE
D504 23      INX     H                ;BUMP TO LOOK AT ADDRESS OF
;          UART STATUS LOCATION
D505 7E      MOV     A,M
D506 EE03    XRI     3                ;ADJUST FOR PROPER REV DJ
D508 6F      MOV     L,A
    
```

```

D509 26E3      MVI      H,(ORIGIN+300H)/100H
D50B 7E        MOV      A,M
D50C E608      ANI      DBLSID      ;CHECK DOUBLE SIDED BIT
D50E 1116D8    LXI      D,DPB128S ;BASE FOR SINGLE SIDED DPB'S
D511 C217D5    JNZ      SIDEOK
D514 1156D8    LXI      D,DPB128D ;BASE OF DOUBLE SIDED DPB'S
D517 EB        SIDEOK  XCHG      ;HL <- DBP BASE, DE <- &DPH.DPB
D518 D1        POP      D      ;RESTORE DE (POINTER INTO DPH)
D519 F1        POP      PSW     ;OFFSET TO CORRECT DPB
D51A 17        RAL
D51B 17        RAL
D51C 4F        MOV      C,A
D51D 0600      MVI      B,0
D51F 09        DAD      B
D520 EB        XCHG      ;PUT DPB ADDRESS IN DPH
D521 73        MOV      M,E
D522 23        INX      H
D523 72        MOV      M,D
D524 CD41D5    SETDRV1 CALL    GETDPB   ;GET ADDRESS OF DPB IN HL
D527 010F00    LXI      B,15      ;OFFSET TO SECTOR SIZE
D52A 09        DAD      B
D52B 7E        MOV      A,M      ;GET SECTOR SIZE
D52C E607      ANI      7H
D52E 326ED5    STA      SECSIZ
D531 7E        MOV      A,M
D532 1F        RAR
D533 1F        RAR
D534 1F        RAR
D535 1F        RAR
D536 E60F      ANI      0FH
D538 32A4D5    STA      SECPSEC
D53B EB        XCHG      ;HL <- DPH
D53C C9        RET

D53D 210000    ZRET     LXI      H,0      ;SELDRV ERROR EXIT
D540 C9        RET

```

```

*****
*
* GETDPB RETURNS HL POINTING TO THE DPB OF THE CURRENTLY
* SELECTED DRIVE, DE POINTING TO DPH.
*
*****

```

```

D541 3AE9D8    GETDPB  LDA      CPMDRV   ;GET DRIVE #
D544 6F        MOV      L,A      ;FORM OFFSET
D545 2600      MVI      H,0
D547 29        DAD      H
D548 29        DAD      H
D549 29        DAD      H
D54A 29        DAD      H
D54B 1196D8    LXI      D,DPZERO  ;BASE OF DPH'S
D54E 19        DAD      D
D54F E5        PUSH     H      ;SAVE ADDRESS OF DPH
D550 110A00    LXI      D,10     ;OFFSET TO DPB
D553 19        DAD      D

```

```

D554 7E      MOV      A,M          ;GET LOW BYTE OF DPB ADDRESS
D555 23      INX      H
D556 66      MOV      H,M          ;GET LOW BYTE OF DPB
D557 6F      MOV      L,A
D558 D1      POP      D
D559 C9      RET

```

```

*****
*
* XLTS IS A TABLE OF ADDRESS THAT POINT TO EACH OF THE XLT
* TABLES FOR EACH SECTOR SIZE.
*
*****

```

```

D55A 48D7   XLTS    DW      XLT128      ;XLT FOR 128 BYTE SECTORS
D55C 63D7   DW      XLT256      ;XLT FOR 256 BYTE SECTORS
D55E 98D7   DW      XLT512      ;XLT FOR 512 BYTE SECTORS
D560 D5D7   DW      XLT124      ;XLT FOR 1024 BYTE SECTORS

```

```

*****
*
* WRITE ROUTINE MOVES DATA FROM MEMORY INTO THE BUFFER. IF THE
* DESIRED CP/M SECTOR IS NOT CONTAINED IN THE DISK BUFFER, THE
* BUFFER IS FIRST FLUSHED TO THE DISK IF IT HAS EVER BEEN
* WRITTEN INTO, THEN A READ IS PERFORMED INTO THE BUFFER TO GET
* THE DESIRED SECTOR. ONCE THE CORRECT SECTOR IS IN MEMORY, THE
* BUFFER WRITTEN INDICATOR IS SET, SO THE BUFFER WILL BE
* FLUSHED, THEN THE DATA IS TRANSFERRED INTO THE BUFFER.
*
*****

```

```

D562 79      WRITE   MOV      A,C          ;SAVE WRITE COMMAND TYPE
D563 32CCD5  STA      WRITTYP
D566 3E01    MVI      A,1          ;SET WRITE COMMAND
D568 06      DB      (MVI) OR (B*8) ;THIS "MVI B" INSTRUCTION CAUSES
;          THE FOLLOWING "XRA A" TO
;          BE SKIPPED OVER.

```

```

*****
*
* READ ROUTINE TO BUFFER DATA FROM THE DISK. IF THE SECTOR
* REQUESTED FROM CP/M IS IN THE BUFFER, THEN THE DATA IS SIMPLY
* TRANSFERRED FROM THE BUFFER TO THE DESIRED DMA ADDRESS. IF
* THE BUFFER DOES NOT CONTAIN THE DESIRED SECTOR, THE BUFFER IS
* FLUSHED TO THE DISK IF IT HAS EVER BEEN WRITTEN INTO, THEN
* FILLED WITH THE SECTOR FROM THE DISK THAT CONTAINS THE
* DESIRED CP/M SECTOR.
*
*****

```

```

D569 AF      READ    XRA      A          ;SET THE COMMAND TYPE TO READ
D56A 32B8D5  STA      RDWR        ;SAVE COMMAND TYPE

```

```

*****
*
* REDWRT CALCULATES THE PHYSICAL SECTOR ON THE DISK THAT
*
*****

```

```

* CONTAINS THE DESIRED CP/M SECTOR, THEN CHECKS IF IT IS THE *
* SECTOR CURRENTLY IN THE BUFFER. IF NO MATCH IS MADE, THE *
* BUFFER IS FLUSHED IF NECESSARY AND THE CORRECT SECTOR READ *
* FROM THE DISK. *
* *
*****

```

```

D56D 0600 REDWRT MVI B,0 ;THE 0 IS MODIFIED TO CONTAIN THE LOG2
D56E = SECSIZ EQU $-1 ; OF THE PHYSICAL SECTOR SIZE/128
; ON THE CURRENTLY SELECTED DISK.
D56F 3AE8D8 LDA CPMSEC ;GET THE DESIRED CP/M SECTOR #
D572 F5 PUSH PSW ;TEMPORARY SAVE
D573 E680 ANI 80H ;SAVE ONLY THE SIDE BIT
D575 4F MOV C,A ;REMEMBER THE SIDE
D576 F1 POP PSW ;GET THE SECTOR BACK
D577 E67F ANI 7FH ;FORGET THE SIDE BIT
D579 3D DCR A ;TEMPORARY ADJUSTMENT
D57A 05 DIVLOOP DCR B ;UPDATE REPEAT COUNT
D57B CA83D5 JZ DIVDONE
D57E B7 ORA A ;CLEAR THE CARY FLAG
D57F 1F RAR ;DIVIDE THE CP/M SECTOR # BY THE SIZE
; OF THE PHYSICAL SECTORS
;

```

```

D580 C37AD5 JMP DIVLOOP
D583 3C DIVDONE INR A
D584 B1 ORA C ;RESTORE THE SIDE BIT
D585 32EBD8 STA TRUESEC ;SAVE THE PHYSICAL SECTOR NUMBER
D588 21E9D8 LXI H,CPMDRV ;POINTER TO DESIRED DRIVE,TRACK, AND SECTOR
D58B 11ECD8 LXI D,BUFDRV ;POINTER TO BUFFER DRIVE,TRACK, AND SECTOR
D58E 0604 MVI B,4 ;COUNT LOOP
D590 05 DTSLOP DCR B ;TEST IF DONE WITH COMPARE
D591 CA9FD5 JZ MOVE ;YES, MATCH. GO MOVE THE DATA
D594 1A LDAX D ;GET A BYTE TO COMPARE
D595 BE CMP M ;TEST FOR MATCH
D596 23 INX H ;BUMP POINTERS TO NEXT DATA ITEM
D597 13 INX D
D598 CA90D5 JZ DTSLOP ;MATCH, CONTINUE TESTING

```

```

*****
*
* DRIVE, TRACK, AND SECTOR DON'T MATCH, FLUSH THE BUFFER IF *
* NECESSARY AND THEN REFILL. *
* *
*****

```

```

D59B CD20D6 CALL FILL ;FILL THE BUFFER WITH CORRECT PHYSICAL SECTOR
D59E D8 RC ;NO GOOD, RETURN WITH ERROR INDICATION

```

```

*****
*
* MOVE HAS BEEN MODIFIED TO CAUSE EITHER A TRANSFER INTO OR OUT *
* THE BUFFER. *
* *
*****

```

```

D59F 3AE8D8 MOVE LDA CPMSEC ;GET THE CP/M SECTOR TO TRANSFER
D5A2 3D DCR A ;ADJUST TO PROPER SECTOR IN BUFFER

```

```

D5A3 E600      ANI      0      ;STRIP OFF HIGH ORDERED BITS
D5A4 =         SECPSEC EQU    $-1 ;THE 0 IS MODIFIED TO REPRESENT THE # OF
                                ; CP/M SECTORS PER PHYSICAL SECTORS
D5A5 6F        MOV      L,A    ;PUT INTO HL
D5A6 2600      MVI      H,0
D5A8 29        DAD      H      ;FORM OFFSET INTO BUFFER
D5A9 29        DAD      H
D5AA 29        DAD      H
D5AB 29        DAD      H
D5AC 29        DAD      H
D5AD 29        DAD      H
D5AE 29        DAD      H
D5AF 11EFD8    LXI      D,BUFFER ;BEGINNING ADDRESS OF BUFFER
D5B2 19        DAD      D      ;FORM BEGINNING ADDRESS OF SECTOR TO TRANSFER
D5B3 EB        XCHG     ;DE = ADDRESS IN BUFFER
D5B4 210000    LXI      H,0    ;GET DMA ADDRESS, THE 0 IS MODIFIED TO
                                ; CONTAIN THE DMA ADDRESS
D5B5 =         CPMDMA EQU    $-2
D5B7 3E00      MVI      A,0    ;THE ZERO GETS MODIFIED TO CONTAIN
                                ; A ZERO IF A READ, OR A 1 IF WRITE
D5B8 =         RDWR    EQU    $-1
D5B9 A7        ANA      A      ;TEST WHICH KIND OF OPERATION
D5BA C2C2D5    JNZ      INTO    ;TRANSFER DATA INTO THE BUFFER
D5BD CD35D6    OUTOF   CALL    MOVER
D5C0 AF        XRA      A
D5C1 C9        RET
D5C2 EB        INTO    XCHG     ;
D5C3 CD35D6    CALL    MOVER   ;MOVE THE DATA, HL = DESTINATION
                                ; DE = SOURCE
D5C6 3E01      MVI      A,1
D5C8 32D5D5    STA      BUFWRN  ;SET BUFFER WRITTEN INTO FLAG
D5CB 3E00      MVI      A,0    ;CHECK FOR DIRECTORY WRITE
D5CC =         WRITTYP EQU    $-1
D5CD 3D        DCR      A
D5CE 3E00      MVI      A,0
D5D0 32CCD5    STA      WRITTYP ;SET NO DIRECTORY WRITE
D5D3 C0        RNZ

```

```

*****
*
* FLUSH WRITES THE CONTENTS OF THE BUFFER OUT TO THE DISK IF
* IT HAS EVER BEEN WRITTEN INTO.
*
*****

```

```

D5D4 3E00      FLUSH   MVI      A,0    ;THE 0 IS MODIFIED TO REFLECT IF
                                ; THE BUFFER HAS BEEN WRITTEN INTO
D5D5 =         BUFWRN EQU    $-1
D5D6 A7        ANA      A      ;TEST IF WRITTEN INTO
D5D7 C8        RZ
D5D8 2118E4    LXI      H,DJWRITE ;WRITE OPERATION

```

```

*****
*
* PREP PREPARES TO READ/WRITE THE DISK. RETRIES ARE ATTEMPTED.
*

```

\* UPON ENTRY, H&L MUST CONTAIN THE READ OR WRITE OPERATION \*  
 \* ADDRESS. \*  
 \* \*  
 \*\*\*\*\*

```

D5DB AF      PREP   XRA      A          ;RESET BUFFER WRITTEN FLAG
D5DC 32D5D5      STA      BUFWRN
D5DF 2212D6      SHLD     RETRYOP   ;SET UP THE READ/WRITE OPERATION
D5E2 060A      MVI      B,RETRIES ;MAXIMUM NUMBER OF RETRIES TO ATTEMPT
D5E4 C5      RETRYLP  PUSH     B          ;SAVE THE RETRY COUNT
D5E5 3AEC8      LDA      BUFDRV   ;GET DRIVE NUMBER INVOLVED IN THE OPERATION
D5E8 4F      MOV      C,A
D5E9 CD33D3      CALL     DJDRV    ;SELECT THE DRIVE
D5EC 3AEDD8      LDA      BUFTRK
D5EF A7      ANA      A          ;TEST FOR TRACK ZERO
D5F0 4F      MOV      C,A
D5F1 C5      PUSH     B
D5F2 CC09E4      CZ      DJHOME   ;HOME THE DRIVE IF TRACK 0
D5F5 C1      POP      B          ;RESTORE TRACK #
D5F6 CD0CE4      CALL     DJTRK   ;SEEK TO PROPER TRACK
D5F9 3AEED8      LDA      BUFSEC   ;GET SECTOR INVOLVED IN OPERATION
D5FC F5      PUSH     PSW    ;SAVE THE SECTOR #
D5FD 07      RLC      ;BIT 0 OF A EQUALS SIDE #
D5FE E601      ANI      1        ;STRIP OFF UNNECESSARY BITS
D600 4F      MOV      C,A      ;C <- SIDE #
D601 CD30E4      CALL     DJSIDE  ;SELECT THE SIDE
D604 F1      POP      PSW    ;A <- SECTOR #
D605 E67F      ANI      7FH     ;STRIP OFF SIDE BIT
D607 4F      MOV      C,A      ;C <- SECTOR #
D608 CD0FE4      CALL     DJSEC   ;SET THE SECTOR TO TRANSFER
D60B 01EFD8      LXI     B,BUFFER ;SET THE DMA ADDRESS
D60E CD12E4      CALL     DJDMA
D611 CD15E4      CALL     DJREAD  ;THE READ OPERATION IS MODIFIED TO WRITE
D612 =      RETRYOP  EQU     $-2
D614 C1      POP      B          ;RESTORE THE RETRY COUNTER
D615 3E00      MVI     A,0      ;NO ERROR EXIT STATUS
D617 D0      RNC      ;RETURN NO ERROR
D618 05      DCR     B          ;UPDATE THE RETRY COUNTER
D619 37      STC      ;ASSUME RETRY COUNT EXPIRED
D61A 3EFF      MVI     A,0FFH  ;ERROR RETURN
D61C C8      RZ
D61D C3E4D5      JMP     RETRYLP  ;TRY AGAIN
    
```

\*\*\*\*\*  
 \* \*  
 \* FILL FILLS THE BUFFER WITH A NEW SECTOR FROM THE DISK. \*  
 \* \*  
 \*\*\*\*\*

```

D620 CDD4D5      FILL   CALL     FLUSH   ;FLUSH BUFFER FIRST
D623 D3      RC      ;CHECK FOR ERROR
D624 11E9D8      LXI     D,CPMDRV ;UPDATE THE DRIVE, TRACK, AND SECTOR
D627 21ECD8      LXI     H,BUFDRV
D62A 0603      MVI     B,3      ;NUMBER OF BYTES TO MOVE
D62C CD37D6      CALL     MOVLOP   ;COPY THE DATA
D62F 2115E4      LXI     H,DJREAD
    
```

```
D632 C3DBD5      JMP      PREP          ;SELECT DRIVE, TRACK, AND SECTOR.
                  ;          THEN READ THE BUFFER
```

```
*****
*
* MOVER MOVES 128 BYTES OF DATA. SOURCE POINTER IN DE, DEST
* POINTER IN HL.
*
```

```
D635 0680      MOVER  MVI      B,128      ;LENGTH OF TRANSFER
D637 1A        MOVLOP LDAX   D          ;GET A BTE OF SOURCE
D638 77        MOV     MOV     M,A      ;MOVE IT
D639 13        INX    INX    D          ;BUMP POINTERS
D63A 23        INX    INX    H
D63B 05        DCR    DCR    B          ;UPDATE COUNTER
D63C C237D6    JNZ     JNZ     MOVLOP     ;CONTINUE MOVING UNTIL DONE
D63F C9        RET
```

```
*****
*
* TERMINAL DRIVER ROUTINES. IOBYTE IS INITIALIZED BY THE COLD
* BOOT ROUTINE, TO MODIFY, CHANGE THE "INTIOBY" EQUATE. THE
* I/O ROUTINES THAT FOLLOW ALL WORK EXACTLY THE SAME WAY. USING
* IOBYTE, THEY OBTAIN THE ADDRESS TO JUMP TO IN ORDER TO EXECUTE
* THE DESIRED FUNCTION. THERE IS A TABLE WITH FOUR ENTRIES FOR
* EACH OF THE POSSIBLE ASSIGNMENTS FOR EACH DEVICE. TO MODIFY
* THE I/O ROUTINES FOR A DIFFERENT I/O CONFIGURATION, JUST
* CHANGE THE ENTRIES IN THE TABLES.
*
```

TERMINAL DRIVERS

```
E403 =          CITYY  EQU      DJCIN      ;INPUT FROM THE DISK JOCKEY 2D
E406 =          COTTY  EQU      DJCOUT     ;OUTPUT TO THE DISK JOCKEY 2D
```

```
*****
*
* CONST: GET THE STATUS FOR THE CURRENTLY ASSIGNED CONSOLE
* DEVICE. THE CONSOLE DEVICE CAN BE GOTTEN FROM IOBYTE,
* THEN A JUMP TO THE CORRECT CONSOLE STATUS ROUTINE IS
* PERFORMED.
*
```

```
D640 21BAD6    CONST  LXI      H,CSTBLE     ;BEGINNING OF JUMP TABLE
D643 C352D6    JMP     JMP     CONINI      ;SELECT CORRECT JUMP
```

```
*****
*
* CSREADER: IF THE CONSOLE IS ASSIGNED TO THE READER THEN A
* JUMP WILL BE MADE HERE, WHERE ANOTHER JUMP WILL
* OCCUR TO THE CORRECT READER STATUS.
*
```

```
D646 21C2D6    CSREADR LXI      H,CSRTBLE     ;BEGINNING OF READER STATUS TABLE
```

D649 C36FD6 JMP READERA

\*\*\*\*\*
\*
\* CONIN: TAKE THE CORRECT JUMP FOR THE CONSOLE INPUT ROUTINE.
\* THE JUMP IS BASED ON THE TWO LEAST SIGNIFICANT BITS OF
\* IOBYTE.
\*
\*\*\*\*\*

D64C CDD4D5 CONIN CALL FLUSH ;FLUSH THE DISK BUFFER
D64F 2192D6 LXI H,CITBLE ;BEGINNING OF CHARACTER INPUT TABLE

\*
\* ENTRY AT CONIN1 WILL DECODE THE TWO LEAST SIGNIFICANT BITS
\* OF IOBYTE. THIS IS USED BY CONIN,CONOUT, AND CONST.
\*

D652 3A0300 CONIN1 LDA IOBYTE
D655 17 RAL

\*
\* ENTRY AT SELDEV WILL FORM AN OFFSET INTO THE TABLE POINTED
\* TO BY H&L AND THEN PICK UP THE ADDRESS AND JUMP THERE.
\*

D656 E606 SELDEV ANI 6H ;STRIP OFF UNWANTED BITS
D658 1600 MVI D,0 ;FORM OFFSET
D65A 5F MOV E,A
D65B 19 DAD D ;ADD OFFSET
D65C 7E MOV A,M ;PICK UP HIGH BYTE
D65D 23 INX H
D65E 66 MOV H,M ;PICK UP LOW BYTE
D65F 6F MOV L,A ;FORM ADDRESS
D660 E9 PCHL ;GO THERE !

\*\*\*\*\*
\*
\* CONOUT: TAKE THE PROPER BRANCH ADDRESS BASED ON THE TWO LEAST
\* SIGNIFICANT BITS OF IOBYTE.
\*
\*\*\*\*\*

D661 C5 CONOUT PUSH B ;SAVE THE CHARACTER
D662 CDD4D5 CALL FLUSH ;FLUSH THE DISK BUFFER
D665 C1 POP B ;RESTORE THE CHARACTER
D666 219AD6 LXI H,COTBLE ;BEGINNING OF THE CHARACTER OUT TABLE
D669 C352D6 JMP CONIN1 ;DO THE DECODE

\*\*\*\*\*
\*
\* READER: SELECT THE CORRECT READER DEVICE FOR INPUT. THE
\* READER IS SELECTED FROM BITS 2 AND 3 OF IOBYTE.
\*
\*\*\*\*\*



D66C 21B2D6 READER LXI H,RTBLE ;BEGINNING OF READER INPUT TABLE

\*
\* ENTRY AT READERA WILL DECODE BITS 2 & 3 OF IOBYTE, USED
\* BY CSREADER.
\*

D66F 3A0300 READERA LDA IOBYTE

\*
\* ENTRY AT READER1 WILL SHIFT THE BITS INTO POSITION, USED
\* BY LIST AND PUNCH.
\*

D672 1F READR1 RAR
D673 C356D6 JMP SELDEV

\*\*\*\*\*
\*
\* PUNCH: SELECT THE CORRECT PUNCH DEVICE. THE SELECTION COMES
\* FROM BITS 4&5 OF IOBYTE.
\*
\*\*\*\*\*

D676 21AAD6 PUNCH LXI H,PTBLE ;BEGINNING OF PUNCH TABLE
D679 3A0300 LDA IOBYTE

\*
\* ENTRY AT PNCH1 ROTATES BITS A LITTLE MORE IN PREP FOR
\* SELDEV, USED BY LIST.
\*

D67C 1F PNCH1 RAR
D67D 1F RAR
D67E C372D6 JMP READR1

\*\*\*\*\*
\*
\* LIST: SELECT A LIST DEVICE BASED ON BITS 6&7 OF IOBYTE
\*
\*\*\*\*\*

D681 21A2D6 LIST LXI H,LTBLE ;BEGINNING OF THE LIST DEVICE ROUTINES
D684 3A0300 LIST1 LDA IOBYTE
D687 1F RAR
D688 1F RAR
D689 C37CD6 JMP PNCH1

\*\*\*\*\*
\*
\* LISTST: GET THE STATUS OF THE CURRENTLY ASSIGNED LIST DEVICE
\*
\*\*\*\*\*

D68C 21CAD6 LISTST LXI H,LSTBLE ;BEGINNING OF THE LIST DEVICE STATUS
D68F C384D6 JMP LIST1

\*\*\*\*\*  
 \*  
 \* IF CUSTOMIZING I/O ROUTINES IS BEING PERFORMED, THE TABLE \*  
 \* BELOW SHOULD BE MODIFIED TO REFLECT THE CHANGES. ALL I/O \*  
 \* DEVICES ARE DECODED OUT OF IOBYTE AND THE JUMP IS TAKEN FROM \*  
 \* THE FOLLOWING TABLES. \*  
 \*  
 \*\*\*\*\*

\*  
 \* CONSOLE INPUT TABLE  
 \*

D692 00D7	CITBLE DW	CIUC1	<u>Value</u> 0	;INPUT FROM USER CONSOLE 1 (CURRENTLY ; SWBD PARALLEL PORT 4)	KYBD
D694 15D7	DW	CICRT	1	;INPUT FROM CRT (CURRENTLY SWITCHBOARD ; SERIAL PORT 1)	DIABLO
D696 6CD6	DW	READER	2	;INPUT FROM READER (DEPENDS ON READER ; SELECTION)	
D698 03E4	DW	CITTY	3	;INPUT FROM TTY (CURRENTLY INPUT FROM ; DISK JOCKEY 2D)	

\*  
 \* CONSOLE OUTPUT TABLE  
 \*

D69A D2D6	COTBLE DW	COCRT	0	;OUTPUT TO CRT (MSDV)	CRT
D69C D2D6	DW	COCRT	1	;OUTPUT TO CRT (MSDV)	CRT
D69E 81D6	DW	LIST	2	;OUTPUT TO LIST DEVICE (DEPENDS ON ; BITS 6&7 OF IOBYTE)	LIST
D6A0 06E4	DW	COTTY	3	;OUTPUT TO TTY (CURRENTLY OUTPUT TO ; DISK JOCKEY 2D)	DJ

\*  
 \* LIST DEVICE TABLE  
 \*

D6A2 06E4	LTBLE DW	COTTY	0	;OUTPUT TO TTY (CURRENTLY ASSIGNED ; BY INTIOBY,OUTPUT TO 2D)	
D6A4 D6D8	DW	COPTR	1	;OUTPUT TO PRINTER	
D6A6 D6D6	DW	COLPT	2	;OUTPUT TO LINE PRINTER (CURRENTLY ; SWITCHBOARD SERIAL PORT 1)	
D6A8 E1D6	DW	COUL1	3	;OUTPUT TO USER LINE PRINTER 1 (CURRENTLY ; SWITCHBOARD SERIAL PORT 1)	

\*  
 \* PUNCH DEVICE TABLE  
 \*

D6AA 06E4	PTBLE DW	COTTY		;OUTPUT TO THE TTY (CURRENTLY ASSIGNED ; BY INTIOBY,OUTPUT TO 2D)	
D6AC D6D8	DW	COPTR		;OUTPUT TO PRINTER	

D6AE D6D6 DW COUP1 ;OUTPUT TO USER PUNCH 1 (CURRENTLY  
; SWITCHBOARD SERIAL PORT 1)  
D6B0 D6D6 DW COUP2 ;OUTPUT TO USER PUNCH 2 (CURRNTLLY  
; SWITCHBOARD SERIAL PORT 1)

\*  
\* READER DEVICE INPUT TABLE  
\*

D6B2 03E4 RTBLE DW CITY ;INPUT FROM TTY (CURRENTLY ASSIGNED  
; BY INTIOBY, INPUT FROM 2D)  
D6B4 15D7 DW CIPTR ;INPUT FROM PAPER TAPE READER (CURRENTLY  
; SWITCHBOARD SERIAL PORT 1)  
D6B6 15D7 DW CIUR1 ;INPUT FROM USER READER 1 (CURRENTLY  
; SWITCHBOARD SERIAL PORT 1)  
D6B8 15D7 DW CIUR2 ;INPUT FROM USER READER 2 (CURRENTLY  
; SWITCHBOARD SERIAL PORT 1)

\*  
\* CONSOLE STATUS TABLE  
\*

D6BA 0CD7 CSTBLE DW CSUC1 ;STATUS FROM SWBD PARALLEL PORT 4, AS  
; READ FROM ATTN BIT 0)  
D6BC 29D7 DW CSCRT ;STATUS FROM CRT (CURRENTLY SWITCHBOARD  
; SERIAL PORT 1)  
D6BE 46D6 DW CSREADR ;STATUS FROM READER (DEPENDS ON READER DEVICE )  
; D6C0 21D7 DW CSTTY ;STATUS OF TTY (CURRENTLY STSTUS FROM  
; DISK JOCKEY 2D)

\*  
\* STATUS FROM READER DEVICE  
\*

D6C2 21D7 CSRTBLE DW CSTTY ;STATUS FROM TTY (CURRENTLY ASSIGNED  
; BY INTIOBY, STATUS OF 2D)  
D6C4 29D7 DW CSPTR ;STATUS FROM PAPER TAPE READER (CURRENTLY  
; SWITCHBOARD SERIAL PORT 1)  
D6C6 29D7 DW CSUR1 ;STATUS FROM USER READER 1 (CURRENTLY  
; SWITCHBOARD SERIAL PORT 1)  
D6C8 29D7 DW CSUR2 ;STATUS OF USER READER 2 (CURRENTLY  
; SWITCHBOARD SERIAL PORT 1)

\*  
\* STATUS FROM LIST DEVICE  
\*

D6CA 37D7 LSTBLE DW READY ;CONSOLE ALWAYS READY  
D6CC 37D7 DW READY ;GET LIST STATUS  
D6CE 32D7 DW LSLPT  
D6D0 32D7 DW LSLPT

\*\*\*\*\*  
\*  
\* ROUTINES FOR MY SYSTEM. J. J. O'BRIEN \*  
\*

\*\*\*\*\*

\*  
\* MSDV VIDEO DRIVER  
\*

```
D6D2 79      COCRT  MOV    A,C      ;MSDV WANTS DATA IN A
D6D3 C300E8  JMP    MSDV    ;GO THERE
```

\*\*\*\*\*

\* THE FOLLOWING EQUATES SET OUTPUT DEVICE TO OUTPUT TO THE  
\* SWITCHBOARD SERIAL PORT 1.  
\*



```
D6D6 =      COPTP  EQU    $      ;OUTPUT FROM PAPER TAPE PUNCH
D6D6 =      COUP1  EQU    $      ;OUTPUT FROM USER PUNCH 1
D6D6 =      COUP2  EQU    $      ;OUTPUT FROM USER PUNCH 2
D6D6 DB02   COLPT  IN     2      ;OUTPUT FROM LINE PRINTER,GET STATUS
D6D8 E680   ANI    80H        ;WAIT UNTIL OK TO SEND
D6DA CAD6D6 JZ     COLPT
D6DD 79     MOV    A,C      ;OUTPUT THE CHARACTER
D6DE D301   OUT    1
D6E0 C9     RET
```

\*\*\*\*\*  
\* CUSTOM I/O PRINTER DRIVER FOR DIABLO PRINTER WITH 1200 BAUD  
\* ETX/ACK HANDSHAKE.  
\*  
\*\*\*\*\*

```
D6E1 CDD6D6 COUL1  CALL   COLPT    ;OUTPUT THE CHARACTER
D6E4 3AFFD6 LDA    COUNT
D6E7 3D     DCR    A
D6E8 32FFD6 STA    COUNT
D6EB C0     RNZ
D6EC 3E4E   MVI    A,78
D6EE 32FFD6 STA    COUNT
D6F1 0E03   MVI    C,AETX
D6F3 CDD6D6 CALL   COLPT
D6F6 CD15D7 PWAIT  CALL   CIPTR
D6F9 FE06   CPI    AACK
D6FB C2F6D6 JNZ    PWAIT
D6FE C9     RET
```

```
D6FF 32     COUNT  DB     50
```

\*\*\*\*\*  
\* THE FOLLOWING EQUATES SET THE INPUT TO COME FROM THE SWBD  
\* PARALLEL PORT 4, WITH STATUS ON ATTENTION PORT BIT 0.  
\*



\*\*\*\*\*

```
D700 DB03      CIUC1  IN      3      ;GET ATTENTION BYTE
D702 E601      ANI      1      ;GET BIT 0 ONLY
D704 CA00D7    JZ       CIUC1    ;WAIT FOR CHARACTER
D707 DB04      IN      4      ;GET CHARACTER
D709 E67F      ANI      7FH    ;STRIP OFF THE PARITY
D70B C9        RET
```

```
D70C DB03      CSUC1  IN      3      ;GET ATTENTION BYTE
D70E E601      ANI      1      ;GET BIT 0 ONLY
D710 EE01      XRI      1      ;CHANGE POLARITY
D712 C324D7    JMP      STAT    ;RETURN PROPER INDICATION
```

\*\*\*\*\*

```
*
* THE FOLLOWING EQUATES SET THE INPUT FROM THE DEVICES TO COME *
* FROM THE SWITCHBOARD SERIAL PORT 1. *
*
```

\*\*\*\*\*

```
D715 =         CICRT  EQU      $      ;INPUT FROM CRT
D715 =         CIUR1  EQU      $      ;INPUT FROM USER READER 1
D715 =         CIUR2  EQU      $      ;INPUT FROM USER READER 2
D715 DB02      CIPTR  IN      2      ;INPUT FROM PAPER TAPE READER, GET STATUS
D717 E640      ANI      40H    ;WAIT FOR CHARACTER
D719 CA15D7    JZ       CIPTR    ;
D71C DB01      IN      1      ;
D71E E67F      ANI      7FH    ;STRIP OFF THE PARITY
D720 C9        RET
```

\*\*\*\*\*

```
*
* CONSOLE STATUS ROUTINES, TEST IF A CHARACTER HAS ARRIVED. *
*
```

\*\*\*\*\*

```
D721 CD21E4    CSTTY  CALL    DJTSTAT    ;STATUS FROM DISK JOCKEY 2D
D724 3E00      STAT   MVI     A,0      ;PREP FOR ZERO RETURN
D726 C0        RNZ                    ;NOTHING FOUND
D727 3D        DCR     A          ;RETURN WITH 0FFH
D728 C9        RET
```

\*\*\*\*\*

```
*
* THE FOLLOWING EQUATES CAUSE THE DEVICES TO GET STATUS FROM *
* THE SWITCHBOARD SERIAL PORT 1. *
*
```

\*\*\*\*\*

```
D729 =         CSUR1  EQU      $      ;STATUS OF USER READER 1
D729 =         CSUR2  EQU      $      ;STATUS OF USER READER 2
D729 =         CSPTR  EQU      $      ;STATUS OF PAPER TAPE READER
D729 DB02      CSCRT  IN      2      ;STATUS FROM CRT, GET STATUS
D72B E640      ANI      40H    ;STRIP OF DATA READY BIT
D72D EE40      XRI      40H    ;MAKE CORRECT POLARITY
```

D72F C324D7 JMP STAT ;RETURN PROPER INDICATION

\*\*\*\*\*
\*
\* LIST DEVICE STATUS ROUTINES.
\*
\*\*\*\*\*

D732 DB02 LSLPT IN 2 ;ALL OTHER DEVICES WAIT
D734 E680 ANI 80H
D736 C8 RZ
D737 3EFF READY MVI A,0FFH
D739 C9 RET

\*\*\*\*\*
\*
\* THIS INITIALIZING ROUTINE SAMPLES BIT 0 OF SWBD PORT 7 TO
\* DETERMINE IF THE KEYBOARD IS PLUGGED IN. IF THE KEYBOARD IS
\* PLUGGED IN, THE LSB RETURNS A 0. OTHERWISE, IT IS A 1.
\* THIS 1 IS ADDED TO IOBYTE TO CHANGE THE CONSOLE INPUT FROM
\* THE SWBD PARALLEL PORT 4 (THE KEYBOARD) TO THE SWBD SERIAL
\* PORT THAT RECEIVES RS232 DATA FROM THE RS232 TERMINAL.
\*
\*\*\*\*\*

D73A 0E19 TINIT MVI C,CLEAR ;INITIALIZE THE TERMINAL ROUTINE
D73C DB07 IN 7 ;GET KEYBOARD INTERLOCK BYTE
D73E E601 ANI 1 ;GET BIT 1 ONLY
D740 C6C0 ADI INTIOBY ;ADD INTIOBY TO KEYBOARD BIT
D742 320300 STA IOBYTE ;INITIALIZE IOBYTE
D745 C30CD3 JMP COUT

\*\*\*\*\*
\*
\* XLT TABLES (SECTOR SKEW TABLES) FOR CP/M 2.0. THESE TABLES
\* DEFINE THE SECTOR TRANSLATION THAT OCCURS WHEN MAPPING CP/M
\* SECTORS TO PHYSICAL SECTORS ON THE DISK. THERE IS ONE SKEW
\* TABLE FOR EACH OF THE POSSIBLE SECTOR SIZES. CURRENTLY THE
\* TABLES ARE LOCATED ON TRACK 0 SECTORS 6 AND 8. THEY ARE
\* LOADED INTO MEMORY IN THE CBIOS RAM BY THE COLD BOOT ROUTINE.
\*
\*\*\*\*\*

D748 00 XLT128 DB 0
D749 01070D1319 DB 1,7,13,19,25
D74E 050B1117 DB 5,11,17,23
D752 03090F15 DB 3,9,15,21
D756 02080E141A DB 2,8,14,20,26
D75B 060C1218 DB 6,12,18,24
D75F 040A1016 DB 4,10,16,22
D763 00 XLT256 DB 0
D764 0102131425 DB 1,2,19,20,37,38
D76A 0304151627 DB 3,4,21,22,39,40
D770 0506171829 DB 5,6,23,24,41,42
D776 0708191A2B DB 7,8,25,26,43,44

EXCEPT
CONTROL at 58DB
END OF TERMINAL DRIVERS

TINIT MVI C, '

D77C 090A1B1C2D DB 9,10,27,28,45,46  
 D782 0B0C1D1E2F DB 11,12,29,30,47,48  
 D788 0D0E1F2031 DB 13,14,31,32,49,50  
 D78E 0F10212233 DB 15,16,33,34,51,52  
 D794 11122324 DB 17,18,35,36

D798 00 XLT512 DB 0  
 D799 0102030411 DB 1,2,3,4,17,18,19,20  
 D7A1 2122232431 DB 33,34,35,36,49,50,51,52  
 D7A9 0506070815 DB 5,6,7,8,21,22,23,24  
 D7B1 2526272835 DB 37,38,39,40,53,54,55,56  
 D7B9 090A0B0C19 DB 9,10,11,12,25,26,27,28  
 D7C1 292A2B2C39 DB 41,42,43,44,57,58,59,60  
 D7C9 0D0E0F101D DB 13,14,15,16,29,30,31,32  
 D7D1 2D2E2F30 DB 45,46,47,48

D7D5 00 XLT124 DB 0  
 D7D6 0102030405 DB 1,2,3,4,5,6,7,8  
 D7DE 191A1B1C1D DB 25,26,27,28,29,30,31,32  
 D7E6 3132333435 DB 49,50,51,52,53,54,55,56  
 D7EE 090A0B0C0D DB 9,10,11,12,13,14,15,16  
 D7F6 2122232425 DB 33,34,35,36,37,38,39,40  
 D7FE 393A3B3C3D DB 57,58,59,60,61,62,63,64  
 D806 1112131415 DB 17,18,19,20,21,22,23,24  
 D80E 292A2B2C2D DB 41,42,43,44,45,46,47,48

\*\*\*\*\*  
 \*  
 \* EACH OF THE FOLLOWING TABLES DESCRIBES A DISKETTE WITH THE \*  
 \* SPECIFIED CHARACTERISTICS. THE TABLES ARE CURRENTLY STORED \*  
 \* ON TRACK 0 SECTOR 13. THEY ARE READ INTO MEMORY BY THE GOCPM \*  
 \* ROUTINE IN THE CBIOS FOR CP/M VER 2.0. \*  
 \*  
 \*\*\*\*\*

\*\*\*\*\*  
 \*  
 \* THE FOLLOWING DPB DEFINES A DISKETTE FOR 128 BYTE SECTORS, \*  
 \* SINGLE DENSITY, AND SINGLE SIDED. \*  
 \*  
 \*\*\*\*\*

D816 1A00 DPB128S DW 26 ;CP/M SECTORS/TRACK  
 D818 03 DB 3 ;BSH  
 D819 07 DB 7 ;BLM  
 D81A 00 DB 0 ;EXM  
 D81B F200 DW 242 ;DSM  
 D81D 3F00 DW 63 ;DRM  
 D81F C0 DB 0C0H ;AL0  
 D820 00 DB 0 ;AL1  
 D821 1000 DW 16 ;CKS  
 D823 0200 DW 2 ;OFF  
 D825 01 DB 1H ;16\*((#CPM SECTORS/PHYSICAL SECTOR) -1) +  
 ;LOG2(#BYTES PER SECTOR/128) + 1 +  
 ;8 IF DOUBLE SIDED.

\*\*\*\*\*  
\*  
\* THE FOLLOWING DPB DEFINES A DISKETTE FOR 256 BYTE SECTORS,  
\* DOUBLE DENSITY, AND SINGLE SIDED.  
\*  
\*\*\*\*\*

```
D826 3400 DPB256S DW 52 ;CP/M SECTORS/TRACK
D828 04 DB 4 ;BSH
D829 0F DB 15 ;BLM
D82A 00 DB 0 ;EXM
D82B F200 DW 242 ;DSM
D82D 7F00 DW 127 ;DRM
D82F C0 DB 0C0H ;AL0
D830 00 DB 0 ;AL1
D831 2000 DW 32 ;CKS
D833 0200 DW 2 ;OFF
D835 12 DB 12H ;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) +
;LOG2(#BYTES PER SECTOR/128) + 1 +
;8 IF DOUBLE SIDED.
```

\*\*\*\*\*  
\*  
\* THE FOLLOWING DPB DEFINES A DISKETTE AS 512 BYTE SECTORS,  
\* DOUBLE DENSITY, AND SINGLE SIDED.  
\*  
\*\*\*\*\*

```
D836 3C00 DPB512S DW 60 ;CP/M SECTORS/TRACK
D838 04 DB 4 ;BSH
D839 0F DB 15 ;BLM
D83A 00 DB 0 ;EXM
D83B 1801 DW 280 ;DSM
D83D 7F00 DW 127 ;DRM
D83F C0 DB 0C0H ;AL0
D840 00 DB 0 ;AL1
D841 2000 DW 32 ;CKS
D843 0200 DW 2 ;OFF
D845 33 DB 33H ;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) +
;LOG2(#BYTES PER SECTOR/128) + 1 +
;8 IF DOUBLE SIDED.
```

\*\*\*\*\*  
\*  
\* THE FOLLOWING DPB DEFINES A DISKETTE AS 1024 BYTE SECTORS,  
\* DOUBLE DENSITY, AND SINGLE SIDED.  
\*  
\*\*\*\*\*

```
D846 4000 DP1024S DW 64 ;CP/M SECTORS/TRACK
D848 04 DB 4 ;BSH
D849 0F DB 15 ;BLM
D84A 00 DB 0 ;EXM
D84B 2B01 DW 299 ;DSM
D84D 7F00 DW 127 ;DRM
```



```

D84F C0      DB      0C0H      ;AL0
D850 00      DB      0        ;AL1
D851 2000    DW      32        ;CKS
D853 0200    DW      2        ;OFF
D855 74      DB      74H      ;16*((#CPM SECTORS/PHYSICAL SECTOR) -1) +
                        ;LOG2(#BYTES PER SECTOR/128) + 1 +
                        ;8 IF DOUBLE SIDED.

```

```

*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE FOR 128 BYTE SECTORS,
* SINGLE DENSITY, AND DOUBLE SIDED.
*
*****

```

```

D856 3400    DPB128D DW      52      ;CP/M SECTORS/TRACK
D858 04      DB      4        ;BSH
D859 0F      DB      15       ;BLM
D85A 01      DB      1        ;EXM
D85B F200    DW      242      ;DSM
D85D 7F00    DW      127      ;DRM
D85F C0      DB      0C0H     ;AL0
D860 00      DB      0        ;AL1
D861 2000    DW      32        ;CKS
D863 0200    DW      2        ;OFF
D865 09      DB      9H

```

```

*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE AS 256 BYTE SECTORS,
* DOUBLE DENSITY, AND DOUBLE SIDED.
*
*****

```

```

D866 6800    DPB256D DW      104     ;CP/M SECTORS/TRACK
D868 04      DB      4        ;BSH
D869 0F      DB      15       ;BLM
D86A 00      DB      0        ;EXM
D86B E601    DW      486      ;DSM
D86D FF00    DW      255      ;DRM
D86F F0      DB      0F0H     ;AL0
D870 00      DB      0        ;AL1
D871 4000    DW      64        ;CKS
D873 0200    DW      2        ;OFF
D875 1A      DB      1AH

```

```

*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE AS 512 BYTE SECTORS,
* DOUBLE DENSITY, AND DOUBLE SIDED.
*
*****

```

```

D876 7800    DPB512D DW      120     ;CP/M SECTORS/TRACK
D878 04      DB      4        ;BSH
D879 0F      DB      15       ;BLM

```

```

D87A 00      DB      0      ;EXM
D87B 3102    DW      561     ;DSM
D87D FF00    DW      255     ;DRM
D87F F0      DB      0F0H   ;AL0
D880 00      DB      0      ;AL1
D881 4000    DW      64      ;CKS
D883 0200    DW      2       ;OFF
D885 3B      DB      3BH
    
```

```

*****
*
* THE FOLLOWING DPB DEFINES A DISKETTE AS 1024 BYTE SECTORS,
* DOUBLE DENSITY, AND DOUBLE SIDED.
*
*****
    
```

```

D886 8000    DP1024D DW      128      ;CP/M SECTORS/TRACK
D888 04      DB      4         ;BSH
D889 0F      DB      15        ;BLM
D88A 00      DB      0         ;EXM
D88B 5702    DW      599       ;DSM
D88D FF00    DW      255       ;DRM
D88F F0      DB      0F0H     ;AL0
D890 00      DB      0         ;AL1
D891 4000    DW      64        ;CKS
D893 0200    DW      2         ;OFF
D895 7C      DB      7CH
    
```

```

*****
*
* CP/M DISK PARAMETER HEADERS, UNITIALIZED.
*
*****
    
```

```

D896 0000    DPZERO  DW      0      ;ADDRESS OF TRANSLATION TABLE (FILLED
;          IN BY SETDRV)
D898 0000000000 DW      0,0,0     ;USED BY BDOS
D89E 1BDF    DW      DIRBUF     ;ADDRESS OF DIRECTORY BUFFER
D8A0 0000    DW      0          ;ADDRESS OF DPB (FILLED IN BY SETDRV)
D8A2 1BDE    DW      CSV0       ;DIRECTORY CHECK VECTOR
D8A4 EFDC    DW      ALV0       ;ALLOCATION VECTOR

D8A6 0000    DPONE   DW      0
D8A8 0000000000 DW      0,0,0
D8AE 1BDF    DW      DIRBUF
D8B0 0000    DW      0
D8B2 5BDE    DW      CSV1
D8B4 3ADD    DW      ALV1

D8B6 0000    DPTWO   DW      0
D8B8 0000000000 DW      0,0,0
D8BE 1BDF    DW      DIRBUF
D8C0 0000    DW      0
D8C2 9BDE    DW      CSV2
D8C4 85DD    DW      ALV2
    
```

```

D8C6 0000 DPTHRE DW 0
D8C8 00000000 DW 0,0,0
D8CE 1BDF DW DIRBUF
D8D0 0000 DW 0
D8D2 DBDE DW CSV3
D8D4 D0DD DW ALV3

```

```

*****
*
* ROUTINE FOR OKIDATA PRINTER
*
*****

```

*TEORM DRIVER*

```

D8D6 DB02 COPTR IN 2 ;INPUT FROM PORT 2
D8D8 E608 ANI 8 ;WAIT UNTIL OK TO SEND
D8DA CAD6D8 JZ COPTR
D8DD DB05 COPTR1 IN 5 ;BUFFER FULL?
D8DF E601 ANI 1
D8E1 CADDD8 JZ COPTR1 ;WAIT UNTIL PRINTER READY
D8E4 79 MOV A,C ;OUTPUT THE CHARACTER
D8E5 D300 OUT 0
D8E7 C9 RET

```

```

*****
*
* CBIOS RAM LOCATIONS THAT DON'T NEED INITIALIZATION.
*
*****

```

```

D8E8 00 CPMSEC DB 0 ;CP/M SECTOR #
D8E9 00 CPMDRV DB 0 ;CP/M DRIVE #
D8EA 00 CPMTRK DB 0 ;CP/M TRACK #
D8EB 00 TRUESEC DB 0 ;DISK JOCKEY SECTOR THAT CONTAINS CP/M SECTOR
D8EC 00 BUFDRV DB 0 ;DRIVE THAT BUFFER BELONGS TO
D8ED 00 BUFTRK DB 0 ;TRACK THAT BUFFER BELONGS TO
D8EE 00 BUFSEC DB 0 ;SECTOR THAT BUFFER BELONGS TO
D8EF BUFFER DS 1024 ;MAXIMUM SIZE BUFFER FOR 1K SECTORS

```

```

DCEF ALV0 DS 75 ;ALLOCATION VECTOR FOR DRIVE A
DD3A ALV1 DS 75 ;ALLOCATION VECTOR FOR DRIVE B
DD85 ALV2 DS 75 ;ALLOCATION VECTOR FOR DRIVE C
DDD0 ALV3 DS 75 ;ALLOCATION VECTOR FOR DRIVE D
DE1B CSV0 DS 64 ;DIRECTORY CHECK VECTOR FOR DRIVE A
DE5B CSV1 DS 64 ;DIRECTORY CHECK VECTOR FOR DRIVE B
DE9B CSV2 DS 64 ;DIRECTORY CHECK VECTOR FOR DRIVE C
DEDB CSV3 DS 64 ;DIRECTORY CHECK VECTOR FOR DRIVE D
DF1B DIRBUF DS 128 ;DIRECTORY BUFFER

```

DF9B END

0006 AACK	000D ACR	0003 AETX	000A ALF	DCEF ALV0
DD3A ALV1	DD85 ALV2	DDD0 ALV3	D3FA AUTOFLG	C500 BDOS
9000 BIAS	D300 BIOS	D8EC BUFDRV	0080 BUFF	D8EF BUFFER
D8EE BUFSEC	D8ED BUFTRK	D5D5 BUFWRN	D3A0 CBOOT	BD00 CCP
0004 CDISK	D715 CICRT	D715 CIPTR	D692 CITBLE	E403 CTTY
D700 CIUCL	D715 CIUR1	D715 CIUR2	D3F2 CLDBOT	0019 CLEAR
D3FB CMNDBEG	D3FB CMNDEND	D6D2 COCRT	D6D6 COLPT	D64C CONIN
D652 CONIN1	D661 CONOUT	D640 CONST	D6D6 COPTP	D8D6 COPTR
D8DD COPTR1	D69A COTBLE	E406 COTTY	D6E1 COUL1	D6FF COUNT
D6D6 COUPL	D6D6 COUP2	D30C COUT	D5B5 CPMDMA	D8E9 CPMDRV
0016 CPMREV	D8E8 CPMSEC	D8EA CPMTRK	D729 CSCRT	D729 CSPTR
D646 CSREADR	D6C2 CSRTBLE	D6BA CSTBLE	D721 CSTTY	D70C CSUC1
D729 CSUR1	D729 CSUR2	DE1B CSV0	DE5B CSV1	DE9B CSV2
DEDB CSV3	D3F9 CWFLG	0008 DBLSID	DF1B DIRBUF	D583 DIVDONE
D57A DIVLOOP	E403 DJCIN	E406 DJCOUT	E42D DJDEN	E412 DJDMA
D333 DJDRV	E42A DJERR	E409 DJHOME	E400 DJRAM	E415 DJREAD
E40F DJSEC	E41B DJSEL	E430 DJSIDE	E427 DJSTAT	E40C DJTRK
E421 DJTSTAT	E418 DJWRITE	D886 DP1024D	D846 DP1024S	D856 DPB128D
D816 DPB128S	D866 DPB256D	D826 DPB256S	D876 DPB512D	D836 DPB512S
D8A6 DPONE	D8C6 DPTHRE	D8B6 DPTWO	D896 DPZERO	D590 DTSLOP
0005 ENTRY	D620 FILL	D5D4 FLUSH	D541 GETDPB	D3B3 GOCPM
D490 HOME	00C0 INTIOBY	D5C2 INTO	0003 IOBYTE	D681 LIST
D684 LIST1	D63C LISTST	D732 LSLPT	D6CA LSTBLE	D6A2 LTBLE
0004 MAXDISK	D393 MESSAGE	D59F MOVE	D635 MOVER	D637 MOVLOP
E800 MSDV	0038 MSIZE	D45E NEWDMA	D43F NEWSEC	D456 NOWRAP
E000 ORIGIN	D5BD OUTOF	D67C PNCH1	D5DB PREP	D336 PROMPT
D6AA PTBLE	D676 PUNCH	D6F6 PWAIT	D5B8 RDWR	D66C READER
D569 READ	D66F READERA	D672 READR1	D737 READY	D56D REDWRT
000A RETRIES	D5E4 RETRYLP	D612 RETRYOP	001E REVNUM	D6B2 RTBLE
D5A4 SECPSEC	D56E SECSIZ	D497 SECTAN	D656 SELDEV	D48A SETDMA
D4C6 SETDRV	D524 SETDRV1	D485 SETSEC	D492 SETTRK	D4A5 SIDEA
D517 SIDEOK	D4A8 SIDEONE	D4AE SIDETWO	D724 STAT	D73A TINIT
0100 TPA	D8EB TRUESEC	D43E WARMLOD	D472 WARMRD	D303 WBOOTE
D3FC WBOOT	0000 WBOT	D400 WFLG	D562 WRITE	D5CC WRITYP
D475 WRMREAD	D7D5 XLT124	D748 XLT128	D763 XLT256	D793 XLT512
D55A XLTS	D53D ZRET			