

IDENTIFICATION
.....

PRODUCT CODE: MAINDEC-11-JZKMC-C-D
PRODUCT NAME: KW11M LOGIC TEST
DATE CREATED: .SEPTEMBER 1, 1974
MAINTAINER: IPG CUSTOM SYSTEMS
AUTHOR: RAYMOND BALDWIN
COPYRIGHT: DIGITAL EQUIPMENT CORP, 1973 1974

AH

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

MEMORY STORAGE - 80000 - 312000 OCTAL

LOADING PROCEDURE - (PAPER TAPE SUPPLIED) LOADED USING NORMAL
BINARY PROCEDURE.

STARTING PROCEDURE:

STARTING ADDRESS 2001

FOR NON-STANDARD VECTORS, DEVICE ADDRESSES & PRIORITY INTERRUPT
LEVELS, THE PROGRAM WILL ASK THE FOLLOWING QUESTIONS TO WHICH
THE OPERATOR MUST RESPOND:

FIRST DEVICE ADDRESS - (6 CHARACTERS)
FIRST INT. VECTOR - (3 CHARACTERS)
PRIORITY INT. LEVEL - (INPUT INT. LEVEL OF DEVICE 4-7)
PDP-11 (A)=09,10,20 (B)=39,40 (C)=45,50

IF AN ERROR IS ENCOUNTERED WHILE INPUTTING THE DEVICE ADDRESS
OR INT. VECTOR, THE OPERATOR MAY TYPE A RUB OUT AND REPEAT
ENTIRE LINE INPUTTING, WHEN LINE IS COMPLETE OR IF NO CHANGES
(FROM STANDARD DEVICE) THE OPERATOR MUST TERMINATE THE LINE
WITH A CARRIAGE RETURN.

STARTING ADDRESS 10001

DIRECT STARTING OR RESTARTING OF LOGIC TEST.

STARTING ADDRESS 2201

DIRECT STARTING OR RESTARTING OF DELAY ADJUSTMENT TEST.

STARTING ADDRESS 2401

DIRECT STARTING OR RESTARTING OF DYNAMIC SYSTEM TEST.

LOGIC TEST OPERATING PROCEDURE AND DESCRIPTION

THE LOGIC TEST CONSISTS OF 44 SUB TESTS EACH CONTAINING AN ERROR ROUTINE. LOGIC TEST SHOULD BE STARTED WITH ALL CONSOLE (PDP-11) SWITCHES DOWN. IF AN ERROR IS ENCOUNTERED, THE TELETYPE WILL REPORT WITH FAILING TEST AND HALT. TO LOOP ON A FAILURE CONSOLE SWITCH REGISTER, BIT 14 IS RAISED AND THE TEST IS LOOPED BY DEPRESSING THE CONTINUE KEY. TO INHIBIT THE ERROR TYPING RAISE SWITCH REGISTER BIT 13.

LOGIC TEST REQUIREMENTS:

TO RUN THE LOGIC TEST, THE SUPPLIED TEST PLUG MUST BE CONNECTED TO THE MODULE CONNECTOR. THE T3 DELAY MUST EXCEED T2 BY 50 MICRO-SECONDS. THE ADJUSTMENT OF T1 MUST BE SET AT A MINIMUM.

LOGIC TEST ERROR REPORTS.

TEST	FAILURE
T1	STATUS AND CONTROL REG, NOT CLEAR UPON INITIALIZE.
T2	INT, ENABLE BIT 6 OF CSR NOT SET.
T3	INT, ENABLE BIT 6 OF CSR NOT CLEAR.
T4	AN ILLEGAL INT, IS PRESENT FROM THE MODULE.
T5	AN ILLEGAL INT, IS PRESENT AFTER A DELAY TIME OUT.
T6	STATUS REGISTER NOT CLEAR AFTER DELAY TIME OUT.
T7	STATUS REGISTER WAS AFFECTED BY A CLEAR FLAGS INSTRUCTION.
T8	FAILED TO MONITOR A T2 FLAG.
T9	ALARM RECEIVED BIT 14 OF CSR SET WITHOUT AN EXT. ENABLE.
T10	ALARM RECIEVE FLAG FAILED TO SET AFTER ENABLING THE EXTERNAL WORLD.
T11	T2 FLAG FAILED TO CLEAR.
T12	RECIEVE FLAG FAILED TO CLEAR.
T13	SHORT LOOP (T1) FAILED TO CLEAR.
T14	T2 FLAG SET SHOULD HAVE BEEN TERMINATED BY THE LOCK FLOP UPON THE SHORT LOOP GENERATED IN T13.
T15	RECEIVE FLAG WAS SET UPON A SHORT LOOP WITHOUT THE EXTERNAL ENABLE.
T16	LOCK FLOP FAILED TO CLEAR JPON ENABLING THE EXTERNAL WORLD AND WAITING 5M,SEC, FOR CLEAR ERROR.
T17	NO ERROR CHECKING, CONDITIONING FOR T18, T19, AND T23.
T18	T1 FLAG FAILED TO CLEAR.
T19	T2 FLAG FAILED TO CLEAR.
T20	RECEIVE FLAG FAILED TO CLEAR.
T21	RECEIVE FLAG FAILED TO SET UPON A TIME OUT OF T3.
T22	ALARM REC, FLAG FAILED TO CLEAR.
T23	ENABLE FLOP NOT CLEARED AN ALARM OUT.
T24	A T2 FLAG FAILED TO RAISE AN INT, AT VECTOR 358.
T25	SHORT LOOP FLAG FAILED TO RAISE AN INT, AT VECTOR 358.

T26 ALARM REC. FLAG FAILED TO RAISE AN INT. AT VECTOR 353.
T27 SHORT LOOP "LOCK" FAILED TO TERMINATE T3.
T28 SHORT LOOP "LOCK" FAILED TO TERMINATE T2.
T29 THE CLEARING OF "LOCK" DIDNOT RELEASE T2 TO THE
BUS (REFER TO T26,T27, &T28).
T30 SHORT LOOP " LOCK"FAILED TO LOCK PULSING OF TIMER.
T31 INITIALIZE FAILED TO CLEAR SHORT LOOP FLAG.
T32 INITIALIZE FAILED TO CLEAR RECEIVE FLAG.
T33 INITIALIZE FAILED TO CLEAR THE LOCK FLOP.
T34 INITIALIZE FAILED TO TERMINATE T3.
T35 INITIALIZE FAILED TO TERMINATE T2.
T36 INCORRECT STATUS IN EXTERNAL STATUS REG.
T37 STATUS OF ECSR CHANGED UPON A RESEY INSTRUCTION.
T38 SWITCH BUS INSTRUCTION FAILED TO CHANGE THE EXTERNAL
STATUS REGISTER.
T39 THE LATCH FAILED TO PREVENT A 2ND BUS SWITCHING
(REFER TO T38).
T40 BUS FAILED TO SWITCH TO 2ND LATCH.
T41 TERMINATION OF T3 FAILED TO RELEASE THE LATCH.
T42 A SWITCH BUS COMMAND FAILED TO CHANGE THE BUS STATUS.
T43 A RESEY INSTRUCTION FAILED TO CLEAR THE LATCH.
T44 MANUAL ENABLE INPUT FAILED.
.....
T385 TEST FOLLOWED BY AN "S" DENOTES SUBTEST.
T408 WHICH IS A FAILURE OF THE EXTERNAL STATUS
T418 REGISTER (STATUS READ IS INCORRECT).
T438

ALL TESTS MUST BE SUCCESSFULLY COMPLETED BEFORE THE NEXT TEST MAY
BE EXECUTED.

UPON SUCCESSFUL COMPLETION OF THE LOGIC TEST, THE TELETYPE WILL
PRINT "PASS".

FOR SCOPING ERRORS, SWITCH REGISTER BIT 7 MAY BE RAISED TO INCREASE
THE TEST REPEATABILITY RATE.

DELAY ADJUSTMENT TESTS,

THE OPERATOR MUST RESPOND TO THE QUESTION, "(1) WATCHDOG, (2) WARNING & SHORT LOOP" BY TYPING A 1 OR A 2 FOR DESIRED ADJUSTMENT LOOP TO BE RUN.

DYNAMIC SYSTEM TEST,

THIS TEST IS INTENDED AS AN EXERCISE WHICH SHOULD BE RUN ONLY AFTER COMPLETING THE LOGIC TEST.

THE TEST EXERCISES THE INTERRUPT LOGIC, EXTERNAL STATUS AND DELAYS.

THE TIMER IS PRIMED BY PULSING THE DELAYS AND ENABLING THE INTERRUPT. THE ONLY LEGAL INTERRUPTS ARE THOSE FROM THE T2 DELAY. AFTER EACH LEGAL INTERRUPT, THE EXTERNAL STATUS IS SWITCHED AND TESTED FOR A CORRECT STATUS READING.

A "PASS" IS PRINTED AFTER 100 SUCCESSFUL INTERRUPTS. POSSIBLE ERRORS REPORTED ARE:

1. SHORT LOOP FLAG SET
2. EXTERNAL STATUS BAD
3. ILLEGAL INTERRUPT

TO EXIT ANY TEST, RAISE CONSOLE SWITCH REGISTER, BIT 00, THE PROGRAM WILL THEN OUTPUT THE HEADER, MAKE SURE THAT THE SWITCH IS LOWERED BEFORE ENTERING A NEW TEST.

END

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54

.TITLE WATCH DOG TIMER
.ENABL ANA A35

;
;
;LOGIC TEST FOR WATCH DOG TIMER (HARDWARE MONITOR)
;FOR PDP-11 SYSTEMS,
;THE WATCH DOG TIMER MUST BE PULSED FROM THE
;COMPUTER PROGRAM WITHIN A SPECIFIED TIME TO
;INHIBIT THE TIMER FROM TIMING OUT. UPON A TIME
;OUT CONDITION THE WATCH DOG WILL POST AN
;INTERRUPT ALLOWING THE PROCESSOR A CHANCE TO
;RECOVER BEFORE A SECOND TIME OUT CONDITION
;OCCURS ISSUING AN "ALARM OUT" TO THE EXTERNAL
;WORLD. THE WARNING INTERRUPT IS SENSED AT
;BIT 07 OF THE CONTROL AND STATUS REGISTER.
;THE TIMER ALSO HAS A "SHORT LOOP" PROTECTION WHICH
;GUARDS AGAINST A PROGRAM FAILURE THAT MAYBE PULSING THE
;TIMER BEFORE A SPECIFIED INTERVAL. THE SHORT LOOP WILL
;POST AN INTERRUPT ALSO AT VECTOR (XXX) WHENEVER PULSED
;TWICE WITHIN A SPECIFIED TIME INTERVAL. THE SHORT LOOP
;INTERRUPT IS SENSED IN THE STATUS REGISTER BY BIT 14,
;THE RECEIVE CIRCUIT ALLOWS FOR AN INTERRUPT (VECTOR XXX) TO BE
;POSTED WHEN AN "ALARM SIGNAL" IS RECEIVED FROM THE
;EXTERNAL WORLD. THE RECEIVE INTERRUPT IS SENSED AT
;BIT 7 OF THE STATUS REGISTER.

;
;FOR TEST PURPOSES THE "ALARM OUT" SIGNAL IS
;JUMPED TO THE ALARM RECEIVE WITH A SUPPLIED
;TEST PATCH.

;
;
;DIGITAL EQUIPMENT CORP.
;INDUSTRIAL PRODUCTS GROUP
;WATCH DOG TIMER LOGIC TEST
;MAINDEC-11-DZKMC-C
;AUTHOR: RAY, BALDWIN
;MAINTAINER: IPGICUSTOM SYSTEMS
;COPYRIGHT: DIGITAL 1973

177776
177562
177568
177566
177564
172400
172402
172404
172406
177578
184888
000248

PS=177776
TKB=177562
TKS=177568
TYDB=177566
TYSR=177564
CSR=172400
CINT=172402
ECBR=172404
SWBU=172406
SR=177578
NULL=184888
NOP=248
;TELETYPE READER BUFFER
;TELETYPE READER STATUS
;TELETYPE PRINTER BUFFER
;TELETYPE PRINTER STATUS
;CONTROL AND STATUS-WATCHDOG
;INTERRUPT CLR INSTRUCTION
;EXTERNAL CSR
;SWITCH BUS
;SWITCH REGISTER

61

55	000000	HLT=0	
56	000000	R0=X0	
57	000001	R1=X1	
58	000002	R2=X2	
59	000003	R3=X3	
60	000004	R4=X4	
61	000005	R5=X5	
62	000006	SP=X6	
63	000007	PC=X7	
64			

;SUBROUTINE RETAIN
;TELETYPE ROUTINE RETAIN
;TIME CONTROL ROUTINES
;ERROR PRINT & SCOPE MODE
;LOAD TRAP CATCHER


```

66
67      200020
68
69
70
71
72
73      200004
74      000004 207466
75      000006 000340
76      200030
77      000030 010430
78      000032 000340
79
80
81
82      000350
83      000350 007362
84      000352 000340
85      000354 007372
86      000356 000340
87
88
89
90
91      000500 172400
92      000502 172402
93      000504 172404
94      000506 172406
95      000510 000300
96
97
98
99      000600 000000
100     000600 000200
101     000200 012706 000600
102     000204 004937 007910
103     000210 000137 007060
104
105     000220
106     000220 012706 000600
107     000224 000137 006220
108
109     000240
110     000240 012706 000600
111     000244 000137 006436
112
113     001000
114     001000 012706 000600
115     001004 104000
116     001006 000005
117     001010 104000
118     001012 000137 001016
119

```

```

      .=8
      .REPT 100
      .+2
      HLT
      .ENDR
      ;
      .=4
      TOBE
      340
      .=30
      NULPRY
      340
      ;
      ;
      ;
      .=350
      WAOC
      340
      RECF
      340
      ;
      ;
      .=500
      XCSR: CSR
      XCINT: CINT
      XECSR: ECSR
      XSWBU: SWBU
      PRIVI
      300
      ;
      .=600
      STACK: 0
      .=200
      MOV #STACK,SP
      JSR R5,ADDMO
      JMP -HEADER
      ;
      .=220
      MOV #STACK,SP
      JMP DELAY
      ;
      .=240
      MOV #STACK,SP
      JMP DYMAN
      ;
      .=1000
      LOGIC: MOV #STACK,SP
      NULL
      RESET
      NULL
      JMP TEST
      ;

```

```

;TRAPPED TO PREVIOUS VECTOR
;TIME OUT BUSS ERROR
;PROCESSOR STATUS
;WATCH DOG INTERRUPT
;SET PROCESSOR STATUS BACK TO 7
;RECEIVE FLAG VECTOR
;PRIORITY LEVEL
;STACK LOCATOR
;ASK FOR VECTORS AND ADDRESSES
;PRINT HEADER AND TAKE COMMANDS
;DIRECT ENTRY TO DELAY TEST
;DIRECT ENTRY TO DYNAMIC TEST
;INITIALIZE STACK

```

11

```

120
121
122
123
124 001016 012737 010017 007334 TEST: MOV    #LT,YES      ;SET REGISTER 3 FOR OUTCODE
125 001024 004337 007210 JSR    R3,PRINT      ;PRINT "LOGIC TEST"
126
127
128
129
130
131 001030 004137 007402 T1: JSR    R1,CHECK
132 001034 012737 000340 MOV    #340,PS
133 001042 012737 001030 MOV    #T1,LOOP
134 001050 032777 177777 BIT    #177777,0XCSR ;TEST ALL BITS OF STATUS REG
135 001056 001414 BEQ    T2
136 001060 004537 010520 JSR    R5,ERROR
137 001064 012737 010034 MOV    #EE1,YES 007334
138 001072 004337 007210 JSR    R3,PRINT
139 001076 004537 010536 JSR    R5,SCOPE
140 001102 000000 HLT
141 001104 000137 001030 JMP    T1 ;STATUS REG NOT CLEAR
142
143
144
145
146 001110 004137 007402 T2: JSR    R1,CHECK
147 001114 012737 001110 MOV    #T2,LOOP 010570
148 001122 012777 000100 MOV    #100,0XCSR 177350
149 001130 032777 000100 BIT    #100,0XCSR ;TEST THAT INT,EN, IS SET IN THE CSR
150 001136 001014 BNE    T3
151 001140 004537 010520 JSR    R5,ERROR
152 001144 012737 010040 MOV    #EE2,YES 007334
153 001152 004337 007210 JSR    R3,PRINT
154 001156 004537 010536 JSR    R5,SCOPE
155 001162 000000 HLT
156 001164 000137 001110 JMP    T2 ;INT, EN, BIT FAILED TO SET
157
158
159
160 001170 004137 007402 T3: JSR    R1,CHECK
161 001174 012737 001170 MOV    #T3,LOOP 010570
162 001202 005077 177272 CLR    0XCSR
163 001206 032777 000100 BIT    #100,0XCSR ;CHECK THAT INT ENABLE CLEARED
164 001214 001414 BEQ    T4
165 001216 004537 010520 JSR    R5,ERROR
166 001222 012737 010044 MOV    #EE3,YES 007334
167 001230 004337 007210 JSR    R3,PRINT
168 001234 004537 010536 JSR    R5,SCOPE
169 001240 000000 HLT
170 001242 000137 001170 JMP    T3 ;INT.ENABLE FAILED TO CLEAR
171
172
173
    JEX
    ;ENABLE PROCESSOR INTERRUPT AND CHECK FOR ILLEGAL
    
```

51

```

174                                     ;INTERRUPTS OF WATCH DOG TIMER
175                                     ;
176 001246 004137 007482 T4i JSR R1,CHECK
177 001252 012737 001246 013570 MOV #T4,LOOP
178 001260 012704 001322 MOV #AA1,R4 ;SET UP INT RETURN
179 001264 012705 001322 MOV #AA1,R5
180 001270 052777 000100 177202 BIS #100,OXCSR ;ENABLE INT
181 001276 013737 000510 177776 MOV PRIV,PS ;SET PROCESSOR STATUS TO PRIV
182 001304 000240 NOP
183 001306 000240 NOP ;WAIT FOR INTERRUPT
184 001310 012737 000340 177776 MOV #340,PS ;NO INTERRUPT SO GO
185 001316 000137 001352 JMP T5
186 001322 004537 010520 AA1i JSR R5,ERROR ;CHECK FOR ERROR PRINTOUT
187 001326 012737 010650 007334 MOV #EE4,MES ;PRINT ERROR MESSAGE
    
```

```

189
190 001334 004337 007210 JSR R3,PRINT ;PRINT ERROR 1
191 001340 004537 010536 JSR R5,SCOPE ;CHECK FOR SCOPE LOOP
192 001344 000000 HLT ;STAY HERE
193 001346 000137 001246 JMP T4 ;RUN TEST OVER ON KEY "COUNT"
194
195
196 ;WAIT FOR POSSIBLE TIME OUT OF DELAYS AND CHECK AGAIN
197 ;FOR ILLEGAL WATCHDOG INTERRUPTS
198
199 001352 004137 007482 JSR R1,CHECK
200 001356 012737 000340 177776 T5i MOV #340,PS ;SET PROCESSOR STATUS TO 7
201 001364 004237 010350 JSR R2,TOUT ;WAIT FOR TIME OUTS
202 001370 012704 001432 MOV #AA2,R4 ;SET INT RETURN
203 001374 012709 001432 MOV #AA2,R5
204 001400 013737 000510 177776 MOV PRIV,PS ;P.S. TO PRIV
205 001406 000240 NOP ;WAIT FOR INT
206 001410 000240 NOP
207 001412 012737 000340 177776 MOV #340,PS ;SET STATUS TO 7
208 001420 042777 000100 177052 BIC #100,0XCSR
209 001426 000137 001462 JMP T6 ;GO ON
210 001432 004537 010520 AA2i JSR R5,ERROR ;CHECK FOR ERROR PRINT
211 001436 012737 010654 007324 MOV #EE5,MES ;PRINT ERROR MESSAGE
212 001444 004337 007210 JSR R3,PRINT ;PRINT ERROR 1A
213 001450 004537 010536 JSR R5,SCOPE
214 001454 000000 HLT ;ILLEGAL INT AFTER TIME OUT
215 001456 000137 001352 JMP T5
216
217
218 ;READ THE STATUS WORD TO CHECK THAT ALL BITS ARE
219 ;CLEAR AT THIS TIME.
220
221 001462 004137 007482 T6i JSR R1,CHECK
222 001466 012737 001462 010570 MOV #T6,LOOP ;SET FOR SCOPE LOOP RUN
223 001474 032777 177777 176776 BIT #177777,0XCSR ;CHECK STATUS REGISTER
224 001502 001414 BEO T7 ;IF 0 GO TO TEST 7
225 001504 004537 010520 JSR R5,ERROR
226 001510 012737 010660 007324 MOV #EE6,MES
227 001516 004337 007210 JSR R3,PRINT ;PRINT ERROR2
228 001522 004537 010536 JSR R5,SCOPE ;CHECK FOR SCOPE LOOP
229 001526 000000 HLT ;STAY HERE
230 001530 000137 001462 JMP T6 ;RECYCLE
231
232
233 ;GENERATE A CLEAR COMMAND AND CHECK
234 ;THAT STATUS WAS UNAFFECTED
235
236 001534 004137 007482 T7i JSR R1,CHECK
237 001540 012737 001534 010570 MOV #T7,LOOP ;SET UP FOR SCOPE LOOP RUN
238 001546 005777 176730 TST 0XCINT ;CLR TO FLAGS SHORT LOOP,SECOND CHANCE
239 001552 004237 010350 JSR R2,TOUT
240 001556 032777 177777 176714 BIT #177777,0XCSR
241 001564 001414 BEO T8 ;ALL CLEAR GO TO TEST 8
242 001566 004537 010520 JSR R5,ERROR

```

```

243 001572 212737 010004 007384      MOV      @EE7,MES      ;PRINT ERROR 3
244 001600 004337 007210      JSR      R3,PRINT
245 001604 004537 010536      JSR      R5,SCOPE      ;CHECK FOR SCOPE LOOP
246 001610 000000      HLT
247 001612 000137 001534      JMP      T7            ;RECYCLE TEST
248
249
250
251
252
253
254 001616 004137 007402      Y8i      JSR      R1,CHECK
255 001622 212737 001616 013570      MOV      @T0,LOOP
256 001630 012737 000340 177776      MOV      @340,PS
257 001636 012777 000001 176634      MOV      @1,@XCSR      ;PULSE TIMER
258 001644 004237 010350      JSR      R2,TOUT
259 001650 109777 176624      TSTB    @XCSR          ;TEST THAT T2 TIMED OUT
260 001654 100414      BMI     T9
261 001656 004537 010520      JSR      R5,ERROR
262 001662 212737 010670 007384      MOV      @EE0,MES
263 001670 004337 007210      JSR      R3,PRINT
264 001674 004537 010536      JSR      R5,SCOPE
265 001700 000000      HLT
266 001702 000137 001616      JMP      T8            ;T2 FAILED TO TIME OUT
267
268
269
270
271 001706 004137 007402      Y9i      JSR      R1,CHECK
272 001712 032777 040000 176568      BIT     @040000,@XCSR
273 001720 001414      BEQ     T10
274 001722 004537 010520      JSR      R5,ERROR
275 001726 012737 010674 007384      MOV      @EE9,MES
276 001734 004337 007210      JSR      R3,PRINT
277 001740 004537 010536      JSR      R5,SCOPE
278 001744 000000      HLT
279 001746 000137 001706      JMP      T9            ;REC.SET WITHOUT ENABLE
280
281
282
283
284
285
286
287 001752 004137 007402      Y10i     JSR      R1,CHECK
288 001756 012737 001616 013570      MOV      @T0,LOOP
289 001764 012777 000002 176586      MOV      @2,@XCSR
290 001772 004237 007342      JSR      R2,WAITX
291 001776 032777 040000 176474      BIT     @040000,@XCSR      ;TEST BIT 14
292 002004 001014      BNE     T11
293 002006 004537 010520      JSR      R5,ERROR
294 002012 012737 010700 007384      MOV      @EE13,MES
295 002020 004337 007210      JSR      R3,PRINT
296 002024 004537 010536      JSR      R5,SCOPE
    
```

M1

```

297 002030 000000          HLT
298 002032 000137 001016    JMP      TB          ;RECEIVE FLAG FAILED TO
                               ;SET,CHECK THAT T3 TIMED OUT
299
300
301                          ;TEST THAT T2 FLAG IS CLEARED BY (164002)CINT
302
303 002036 004137 007402    T11:   JSR      R1,CHECK
304 002042 012737 002036 010570    MOV      @T11,LOOP
305 002050 005777 176426    TST      @XCSR
306 002054 105777 176420    TSTB    @XCSR
307 002060 100014          BPL      T12
308 002062 004537 010520    JSR      R5,ERROR
309 002066 012737 010705 007304    MOV      @EE11,MES
310 002074 004337 007210    JSR      R3,PRINT
311 002100 004537 010536    JSR      R5,SCOPE
312 002104 000000          HLT
313 002106 000137 002036    JMP      T11          ;T2 NOT CLEARED BY CINT(164002)
314
315                          ;CHECK THAT RECIEVE FLAG WAS CLEARED BY CLEAR REC FLAG (BIT 8 OF CSR)
316
317 002112 004137 007402    T12:   JSR      R1,CHECK
318 002116 012737 002036 010570    MOV      @T11,LOOP
319 002124 012777 000400 176346    MOV      @000400,@XCSR          ;CLEAR RECIEVE FLAG
320 002132 032777 040000 176340    BIT      @040000,@XCSR          ;TEST RECIEVE FLAG
321 002140 001414          BEQ      T13
322 002142 004537 010520    JSR      R5,ERROR
323 002146 012737 010712 007304    MOV      @EE12,MES
324 002154 004337 007210    JSR      R3,PRINT
325 002160 004537 010536    JSR      R5,SCOPE
326 002164 000000          HLT
327 002166 000137 002112    JMP      T12          ;RECEIVE FLG FAILED TO CLR
328
329
330                          ;ISSUE TWO SUCCESSIVE PULSES TO THE TIMER AND MONITOR BIT 15
331                          ;OF THE CSR FOR A SHORT LOOP FLAG
332 002172 004137 007402    T13:   JSR      R1,CHECK
333 002176 012737 000340 177776    MOV      @340,PS          ;SET STATUS TO SEVEN
334 002204 012737 002474 010570    MOV      @TWH,LOOP        ;SET FOR SCOPE LOOP
335 002212 005277 176262    INC      @XCSR          ;HIT TIMER TWICE
336 002216 005277 176256    INC      @XCSR
337 002222 005777 176252    TST      @XCSR          ;BIT 15 SHOULD BE SET

```

```

339
340 002226 100004          BPL      .+12
341 002230 004237 010350    JSR      R2,TOUT          ;GO WAIT FOR TIMEOUT BEFORE PROCEEDING
342 002234 000137 002270    JMP      T14
343 002240 004537 010520    JSR      R5,ERROR        ;CHECK FOR ERROR PRINT
344 002244 012737 010717 007304    MOV      #EE13,MES       ;PRINT ERROR 13
345 002252 004337 007210    JSR      R3,PRINT
346 002256 004537 010536    JSR      R5,SCOPE
347 002262 000000          HLT
348 002264 000137 002474    JMP      THW             ;SHORT LOOP FLAG FAILED TO SET
349
350
351
352
353
354 002270 004137 007402          T14:    JSR      R1,CHECK
355 002274 105777 176200          TS#B    #XCSR            ;TEST BIT 7
356 002300 100014          BPL      T15             ;CONTINUE TO TEST
357 002302 004537 010520    JSR      R5,ERROR
358 002306 012737 010724 007304    MOV      #EE14,MES
359 002314 004337 007210    JSR      R3,PRINT
360 002320 004537 010536    JSR      R5,SCOPE
361 002324 000000          HLT
362 002326 000137 002474    JMP      THW             ;T2 (2ND CHANCE) FLAG SET,CHECK LOCK FLOP
363
364
365
366
367
368 002332 004137 007402          T15:    JSR      R1,CHECK
369 002336 012737 000340 177776    MOV      #340,PS
370 002344 004237 007342          JSR      R2,WAITX        ;WAIT FOR POSSIBLE TIME OUT OF T4
371 002350 032777 040000 176122    BIT     #040000,#XCSR    ;TEST THAT REC.DIDNT SET
372 002356 001414          BEO     T16
373 002360 004537 010520    JSR      R5,ERROR
374 002364 012737 010731 007304    MOV      #EE15,MES
375 002372 004337 007210    JSR      R3,PRINT
376 002376 004537 010536    JSR      R5,SCOPE
377 002402 000000          HLT
378 002404 000137 002474    JMP      THW             ;REC. FLAG SET WITHOUT AN ENABLE
379
380
381
382
383
384
385
386 002410 004137 007402          T16:    JSR      R1,CHECK
387 002414 012777 000002 176056    MOV      #2,#XCSR        ;ENABLE THE EXTERNAL WORLD
388 002422 004237 007342          JSR      R2,WAITX        ;WAIT FOR CLEAR ERROR
389 002426 005277 176046          INC     #XCSR            ;SET T2 FLAG AGAIN
390 002432 004237 010350    JSR      R2,TOUT        ;TIME OUT DELAYS
391 002436 105777 176036          TS#B    #XCSR
392 002442 100431          BMT     T17             ;RE CLR AND PROCEED
    
```

B-

393	002444	004537	210520			JSR	R5,ERROR	
394	002450	012737	010736	007304		MOV	#EE16,MES	
395	002456	004337	007210			JSR	R3,PRINT	
396	002462	004537	010536			JSR	R5,SCOPE	
397	002466	000000				HLT		;LOCK FLOP NOT CLEARED BY
398	002470	000137	002474			JMP	THW	;CLEAR ERROR
399	002474	012777	000002	175776	THW:	MOV	#2,#XCSR	;CLEAR LOCK FOR RECYCLE
400	002502	004237	007342			JSR	R2,WAITX	
401	002506	005777	175770			TSY	#XCINT	;CLEAR FLAGS SHORT LOOP,SECOND CHANCE
402	002512	012777	000400	175760		MOV	0000400,#XCSR	;CLEAR RECIEVE FLAG
403	002520	000005				RESET		
404	002522	000137	002172			JMP	T13	
405						;		
406						;		
407								;WITH RECEIVE AND SHORT LOOP FLAG SET PULSE TIMER
408								;AND WAIT FOR TIME OUT OF T2 THEN ISSUE AN CLEAR INSTRUCTION
409								;AND CHECK THAT ALL FLAGS ARE CLEARED.


```

411      |
412 002526 004137 007402      | T19: JSR    R1,CHECK
413 002532 012737 000340 177776 | MOV    #340,PS
414 002540 012737 002526 010570 | MOV    #T17,LOOP      ;LOOP TESTS
415 002546 005777 175730      | TST    #XCINT          ;CLEAR INTERRUPT FLAGS, SHORT LOOP,SECOND CHANCE
416 002552 012777 000400 175720 | MOV    #000400,#XCSR  ;CLEAR RECEIVE FLAG
417      | ;TEST SHORT LOOP INTERRUPT FLAG FOR BEING CLEARED
418      |
419 002560 004137 007402      | T10: JSR    R1,CHECK
420 002564 005777 175710      | TST    #XCSR          ;TEST BIT 15 OF CSR
421 002570 100014      | BPL    T10            ;OK GO ON
422 002572 004537 010520      | JSR    R5,ERROR       ;CHECK FOR REPORT OF ERROR
423 002576 012737 010750 007304 | MOV    #EE10,MES      ;SET ERROR PRINT
424 002604 004337 007210      | JSR    R3,PRINT
425 002610 004537 010536      | JSR    R5,SCOPE
426 002614 000000      | HLT                    ;SHORT LOOP FLAG FAILED TO CLEAR
427 002616 000137 002526      | JMP    T17            ;LOOP TO TEST 17 ON KEY "CONT"
428      |
429      | ;TEST WARNING FLAG (BIT 7) FOR BEING CLEAR
430      |
431 002622 004137 007402      | T19: JSR    R1,CHECK
432 002626 105777 175646      | TSTB   #XCSR          ;TEST BIT 07 OF CSR
433 002632 100014      | BPL    T20
434 002634 004537 010520      | JSR    R5,ERROR       ;CHECK FOR ERROR REPORT
435 002640 012737 010755 007304 | MOV    #EE10,MES      ;SET ERROR PRINT
436 002646 004337 007210      | JSR    R3,PRINT
437 002652 004537 010536      | JSR    R5,SCOPE
438 002656 000000      | HLT
439 002660 000137 002526      | JMP    T17            ;LOOP TO TEST 17 ON KEY "CONT"
440      |
441      | ;TEST ALARM RECEIVE (BIT 14) FOR BEING CLEAR
442      |
443 002664 004137 007402      | T20: JSR    R1,CHECK
444 002670 032777 040000 175602 | BIT    #040000,#XCSR  ;TEST BIT 14 OF CSR
445 002676 001414      | BEQ    T21
446 002700 004537 010520      | JSR    R5,ERROR       ;CHECK FOR ERROR REPORT
447 002704 012737 010762 007304 | MOV    #EE20,MES      ;SET PRINT ERROR T20
448 002712 004337 007210      | JSR    R3,PRINT
449 002716 004537 010536      | JSR    R5,SCOPE
450 002722 000000      | HLT                    ;BIT 14 OF CSR FAILED TO A CLR
451 002724 000137 000017      | JMP    17             ;LOOP TO TEST 17 ON CONT
452      |
453      | ;ENABLE ALARM OUT SIGNAL (PROGRAM CONTROL) AND TEST
454      | ;THAT TIME OUT OF T3 WILL SET ALARM RECEIVE FLOP (BIT 14)
455      | ;THE ALARM RECEIVE SIGNAL MUST BE CONNECTED TO THE ALARM OUT
456      | ;AND THE PROGRAM CONTROLLED "RESET" STRAP MUST BE CONNECTED
457      |
458 002730 004137 007402      | T21: JSR    R1,CHECK
459 002734 012737 002730 010570 | MOV    #T21,LOOP
460 002742 012737 000340 177776 | MOV    #340,PS
461 002750 012777 000003 175522 | MOV    #3,#XCSR
462 002756 004237 010350      | JSR    R2,TOUT        ;START TIMER AND ENABLE "ALARM OUT"
463 002762 032777 040000 175510 | BIT    #040000,#XCSR  ;TIME OUT DELAYS
464 002770 001402      | BEQ    #0             ;CHECK BIT 14 FOR BEING SET

```

465	002772	000137	003026		JMP	T22	
466	002776	004537	010520		JSR	R5,ERROR	
467	003002	012737	010767	007304	MOV	#EE21,MES	;SET ERROR PRINTOUT
468	003010	004337	007210		JSR	R3,PRINT	
469	003014	004537	010536		JSR	R5,SCOPE	
470	003020	000000			HLT		;RECEIVE ALARM FLOP FAILED TO SET
471	003022	000137	002730		JMP	T21	;LOOP ON TEST 21
472							
473							
474							
475							
476							
477	003026	004137	007402	T22:	JSR	R1,CHECK	
478	003032	012777	000340	175440	MOV	#340,0XCSR	
479	003040	012737	003026	010570	MOV	#T22,LOOP	;SET SCOPE RETURN
480	003046	012777	000400	175424	MOV	0000400,0XCSR	;CLEAR ALARM RECEIVE FLAG
481	003054	032777	040000	175416	BIT	0040000,0XCSR	;TEST BIT 14 FOR BEING CLEAR
482	003062	001414			BEO	T23	;FLAG CLEAR GO ON

```

484
485 003064 004537 010520 JSR R5,ERROR
486 003070 012737 010774 007304 MOV #EE22,MES
487 003076 004337 007210 JSR R3,PRINT
488 003102 004537 010536 JSR R5,SCOPE
489 003106 000000 HLT ;BIT 14 OF CSR FAILED TO CLEAR
490 003110 000137 003026 JMP T22
491
492 ;CHECK "LOCKOUT" FEATURE OF "ALARM OUT" AFTER AN ALARM
493 ;OUT SIGNAL HAS BEEN GENERATED.
494
495 003114 004137 007402 T23: JSR R1,CHECK
496 003120 012737 000340 177776 MOV #340,PS
497 003126 012737 003114 010570 MOV #T23,LOOP
498 003134 012777 000001 175336 MOV #1,0XCSR ;START TIMING
499 003142 004237 010350 JSR R2,TOUT ;TIME OUT DELAYS
500 003146 004237 007342 JSR R2,WAITX ;WAIT FOR REC TO =SET
501 003152 032777 040000 175320 BIT #04000,0XCSR ;TEST THAT LOCK OUT PREVENTED
502 003160 001414 T24 MOV #14,PS ;BIT 14 FROM BEING SET
503 003162 004537 010520 JSR R5,ERROR
504 003166 012737 011001 007304 MOV #EE23,MES
505 003174 004337 007210 JSR R3,PRINT
506 003200 004537 010536 JSR R5,SCOPE
507 003204 000000 HLT ;CLEAR ERROR FAILED TO ENABLE FLOP
508 003206 000137 003114 JMP T23 ;ALARM OUT SIGNAL
509
510 ;DROP PROCESSOR STATUS TO 6 AND CHECK THAT WARNING FLAG WILL GIVE AN
511 ;INTERRUPT AT VECTOR 170
512
513 003212 005777 175264 T24: TST 0XC1VT ;CLEAR SHORT LOOP, SECOND CHANCE
514 003216 012777 000400 175254 MOV #000400,0XCSR ;CLEAR RECEIVE FLAG
515 003224 004137 007402 JSR R1,CHECK
516 003230 012704 003330 MOV #T25,R4 ;SET INTERRUPT RETURN
517 003234 012705 007440 MOV #WRNG,R5 ;SET FOR INTERRUPT AT WRONG VECTOR
518 003240 012737 003212 010570 MOV #T24,LOOP
519 003246 012777 000101 175224 MOV #101,0XCSR
520 003254 004237 010350 JSR R2,TOUT
521 003260 013737 000510 177776 MOV PRIV,PS ;SET STATUS TO PRIV
522 003266 000240 NOP ;WAIT FOR INTERRUPT
523 003270 000240 NOP ;
524 003272 012737 000340 177776 MOV #340,PS ;SHOULD HAVE INTERRUPTED
525 003300 004537 010520 JSR R5,ERROR ;SET STATUS BACK TO SEVEN
526 003304 012737 011000 007304 MOV #EE24,MES
527 003312 004337 007210 JSR R3,PRINT
528 003316 004137 010536 JSR R5,SCOPE
529 003322 000000 HLT ;WARNING FLAG (BIT 07) FAILED
530 003324 000137 003212 JMP T24 ;TO PRODUCE AN INTERRUPT
531
532 ;CLEAR FLAGS AND SET THE SHORT LOOP
533 ;FLAG TO CHECK FOR AN INTERRUPT
534
535

```

```

537
538 003330 004137 007402          T251 JSR      R1,CHECK
539 003334 000000                RESET
540 003336 005777 175140                TST      @XCINT          ;CLEAR INTERRUPTS
541 003342 012704 003446                MOV      @AA4,R4        ;SET INTERRUPT RETURN
542 003346 012705 007440                MOV      @WRNG,R5      ;SETFOR WRONG VECTOR
543 003352 012737 003330 013570                MOV      @T25,LOOP    ;SET SCOPE MODE
544 003360 013737 000510 177776                MOV      PRIV,PS      ;GET STATUS DOWN TO PRIV
545 003366 052777 000102 175104                BIS      @102,@XCSR   ;INT.EN +EXT.EN
546 003374 005277 175100                INC      @XCSR        ;SET SHORT LOOP
547 003400 005277 175074                INC      @XCSR
548 003404 000240                NOP
549 003406 000240                NOP
550 003410 012737 000340 177776                MOV      @340,PS      ;NO INT.GET STATUS BACK UP
551 003416 004537 010520                JSR      R5,ERROR
552 003422 012737 011013 007304                MOV      @EE25,MES    ;SET ERROR PRINT
553 003430 004337 007210                JSR      R3,PRINT
554 003434 004537 010536                JSR      R5,SCOPE
555 003440 000000                HLT
556 003442 000137 003330                JMP      T25          ;SHORT LOOP FLAG FAILED TO RAISE A
557 003446 004237 007342          AA41 JSR      R2,WAITX      ;WAIT FOR TIME OUT CLR ERROR
558 003452 005777 175024                TST      @XCINT       ;CLEAR FLAGS SHORT LOOP, SECOND CHANCE
559 003456 012777 000400 175014                MOV      @000400,@XCSR ;CLEAR RECEIVE FLAG
560 003464 000137 003470                JMP      T26
561
562 ;CHECK FOR ALARM RECEIVE FLAG TO GENERATE AN INTERRUPT
563 ;BY CLEARING THE WARNING FLAG BEFORE THE RECEIVE
564 ;FLAG IS SET, T3>T2 BY AT LEAST 90 MICO. SEC.
565
566 003470 004137 007402          T261 JSR      R1,CHECK
567 003474 012737 000340 177776                MOV      @340,PS      ;SET PROCESSOR STATUS TO 7
568 003502 012705 003626                MOV      @AA5,R5      ;SET INTERRUPT RETURN
569 003506 012704 007440                MOV      @WRNG,R4      ;SET FOR WRONG VECTOR
570 003512 012737 003446 010570                MOV      @AA4,LOOP    ;SET SCOPE
571 003520 012777 000003 174752                MOV      @3,@XCSR     ;START TIMING, ENABLE ALARM OUT
572 003526 105777 174746                TSTB    @XCSR         ;WAIT FOR WARNING
573 003532 100375                BPL     ,=4
574 003534 005777 174742                TST      @XCINT       ;CLEAR BIT 7 OF CSR
575 003540 032777 040000 174732                BIT     @040000,@XCSR ;WAIT FOR ALARM RECEIVE FLAG
576 003546 001774                BEQ     ,=6
577 003550 052777 000100 174722                BIS      @100,@XCSR   ;ENABLE INT.-2L
578 003556 013737 000510 177776                MOV      PRIV,PS      ;SET STATUS TO PRIV
579 003564 000240                NOP
580 003566 000240                NOP
581 003570 012737 000340 177776                MOV      @340,PS      ;FAILED TO INT. SET STATUS TO 7
582 003576 004537 010520                JSR      R5,ERROR      ;CHECK FOR ERROR REPORT
583 003602 012737 011020 007304                MOV      @EE25,MES
584 003610 004337 007210                JSR      R3,PRINT
585 003614 004537 010536                JSR      R5,SCOPE     ;CHECK FOR SCOPE ROUTINE
586 003620 000000                HLT
587 003622 000137 003446                JMP      AA4
588 003626 004237 010350          AA51 JSR      R2,TOUT
589 003632 012777 000400 174640                MOV      @000400,@XCSR ;CLEAR POSSIBILITY OF SHORT LOOP
590 003640 000137 003644                JMP      T27          ;CLEAR RECEIVE FLAG
                    IT 27

```

62

```

591
592
593
594
595
596
597 003644 004137 007402          T29: JSR    R1,CHECK
598 003650 012737 003626 010570 MOV    @AAS,LOOP
599 003656 012737 000340 177776 MOV    @J40,PS
600 003664 005777 174612          TST    @XCINT
601 003670 005077 174604          CLR    @XCSR
602 003674 012777 000003 174576 MOV    @J,@XCSR      ;SET SHORT LOOP
603 003702 005277 174572          INC    @XCSR
604 003706 004237 007342          JSR    R2,WAITX     ;5,MILLI.SEC,CLEAR LOCK AND ENABLE
605 003712 032777 040000 174560 BIT    @040000,@XCSR
606 003720 001014          BNE    T20
607 003722 004537 010520          JSR    R5,ERROR
608 003726 012737 011025 007304 MOV    @EE27,MES
609 003734 004337 007210          JSR    R3,PRINT
610 003740 004537 010536          JSR    R5,SCOPE
611 003744 000000          HLT
612 003746 000137 003626          JMP    AAS          ;SHORT LOOP LOCK FAILED TO TERMINATE T3
613
614
615
616
617 003752 004137 007402          T20: JSR    R1,CHECK
618 003756 012737 003752 010570 MOV    @T20,LOOP
619 003764 004237 010350          JSR    R2,TOUT
620 003770 012777 000400 174502 MOV    @000400,@XCSR ;CLEAR RECEIVE FLAG
621 003776 005777 174500          TST    @XCINT      ;CLR FLAGS SHORT LOOP, SECOND CHANCE
622 004002 012777 000003 174470 MOV    @J,@XCSR     ;EXT EN, SET S.LOOP
623 004010 005277 174464          INC    @XCSR
624 004014 105777 174460          TSTB   @XCSR      ;TEST BIT 9
625 004020 100014          BPL    T20
626 004022 004537 010520          JSR    R5,ERROR
627 004026 012737 011032 007304 MOV    @EE20,MES
628 004034 004337 007210          JSR    R3,PRINT
629 004040 004337 010536          JSR    R3,SCOPE
630 004044 000000          HLT          ;LOCK FAILED TO TERMINATE T2
631 004046 000137 003752          JMP    T20       ;LOOP ONTEST 20
632
633
634
635
636
637
638 004052 004137 007402          T29: JSR    R1,CHECK
639 004056 004237 007342          JSR    R2,WAITX
640 004062 105777 174412          TSTB   @XCSR
641 004066 100414          BMI   T30
642 004070 004537 010520          JSR    R5,ERROR
643 004074 012737 011037 007304 MOV    @EE29,MES
644 004102 004337 007210          JSR    R3,PRINT
    
```

```

645 004106 004537 010536 JSR R5,SCOPE
646 004112 000000 MLT ;LOCK DIDNT RELEASE T2 TO BUS
647 004114 000137 003792 JMP T28 ;LOOP ON TEST 28
648
649
650
651 ;CHECK THAT LOCK FROM SHORT LOOP FLAG
652 ;LOCKS PULSE INC OF TIMER BY ATTEMPTING TO SET SHORT
653 ;LOOP FLAG AFTER A PREVIOUS SHORT LOOP
654
655 004120 004137 007402 T30: JSR R1,CHECK
656 004124 012737 000340 177776 MOV #340,PS
657 004132 012737 004120 010570 MOV #T30,LOOP
658 004140 005777 174336 TST @XCINT ;CLEAR FLAGS SHORT LOOP,SECOND CHANCE
659 004144 005277 174330 INC @XCSR
660 004150 005277 174324 INC @XCSR
661 004154 005777 174322 TST @XCINT ;CLR FLAGS SHORT LOOP,SECOND CHANCE
662 004160 005277 174314 INC @XCSR
663 004164 005277 174310 INC @XCSR
664 004170 005777 174304 TST @XCSR
665 004174 100014 BPL PTR
666 004176 004537 010520 JSR R5,ERROR
667 004202 012737 011044 007304 MOV #EE33,MES
668 004210 004337 007210 JSR R3,PRINT
669 004214 004537 010536 JSR R5,SCOPE
670 004220 000000 MLT ;SHORT LOOP LOCK FAILED TO LOCK TIMER
671 004222 000137 004120 JMP T30 ;LOOP ON TEST 30
672
673 004226 012777 000002 174244 PTR: MOV #2,@XCSR
674 004234 004237 007342 JSR R2,WAITX ;CLR ERROR
675 004240 005777 174236 TST @XCINT ;CLEAR FLAGS SHORT LOOP,SECOND CHANCE
676
677
678 ;GENERATE A SHORT LOOP COMMAND AND CHECK THAT INITIALIZE
679 ;WILL CLEAR THE SHORT LOOP FLAG,
680
681
682 004244 004137 007402 T31: JSR R1,CHECK
683 004250 012737 004244 010570 MOV #T31,LOOP
684 004256 005277 174216 INC @XCSR ;SET A SHORT LOOP
685 004262 005277 174212 INC @XCSR
686 004266 000000 RESET
687 004270 005777 174204 TST @XCSR ;TEST SHORT LOOP FLAG FOR CLEAR
688 004274 100014 BPL T32
689 004276 004537 010520 JSR R5,ERROR
690 004302 012737 011051 007304 MOV #EE31,MES
691 004310 004337 007210 JSR R3,PRINT
692 004314 004537 010536 JSR R5,SCOPE
693 004320 000000 MLT ;INITIALIZE FAILED TO CLEAR SHORT
694 004322 000137 004244 JMP T31 ;LOOP FLAG
695
696 ;ENABLE THE EXTERNAL WORLD AND ALLOW THE RECIEVE
697 ;FLAG TO SET THEN CHECK THAT THE INITIALIZE
698 ;CLEARED RECEIVE FLAG.
    
```

```

699
700 004326 004137 007402          T32: JSR    R1,CHECK
701 004332 012737 004326 010570  MOV    #T32,LOOP
702 004340 012777 000002 174132  MOV    #2,0XCSR
703 004346 004237 007342          JSR    R2,WAITX      ;5.MILLI SEC SET REC
704 004352 000005          RESET
705 004354 032777 040000 174116  BIT    #040000,0XCSR  ;TEST RECIEVE FLAG
706 004362 001414          BEO    T33
707 004364 004537 010520          JSR    R9,ERROR
708 004370 012737 011056 007304  MOV    #EE32,MES
709 004376 004337 007210          JSR    R3,PRINT
710 004402 004537 010536          JSR    R5,SCOPE
711 004406 000000          HLT
712 004410 000137 004326          JMP    T32           ;INITIALIZE PAILED TO CLEAR REC
713
714
715
716
717
718
719
720
721
722 004414 004137 007402          T33: JSR    R1,CHECK
723 004420 012737 004414 010570  MOV    #T33,LOOP
724 004426 005277 174046          INC    0XCSR
725 004432 005277 174042          INC    0XCSR
726 004436 000005          RESET      ;ATTEMPT TO CLEAR SHORT LOOP
727 004440 005277 174034          INC    0XCSR
728 004444 005277 174030          INC    0XCSR
729 004450 005777 174024          TST    0XCSR      ;TEST SHOT LOOP
730 004454 100414          BHI    PTX1
731 004456 004537 010520          JSR    R9,ERROR
732 004462 012737 011063 007304  MOV    #EE33,MES
733 004470 004337 007210          JSR    R3,PRINT
734 004474 004537 010536          JSR    R5,SCOPE
735 004500 000000          HLT      ;INITIALIZE PAILED TO CLEAR LOCK
736 004502 000137 004414          JMP    T33
737 004506 012777 000002 173704  PTX1: MOV    #2,0XCSR
738 004514 004237 007342          JSR    R2,WAITX      ;WAIT 5.M.S. FOR ERROR TO CLR
739
740
741
742
743
744 004520 004137 007462          T34: JSR    R1,CHECK
745 004524 012737 004520 010570  MOV    #T34,LOOP
746 004532 012777 000001 173740  MOV    #1,0XCSR      ;PULSE TIMER & EX. EN SET
747 004540 000005          RESET
748 004542 012777 000002 173730  MOV    #2,0XCSR
749 004550 004237 007342          JSR    R2,WAITX      ;WAIT 5, MILLI SEC FOR T4
750 004554 032777 040000 173716  BIT    #040000,0XCSR  ;TEST RECEIVE FLAG
751 004562 001020          BNE    PTX2
752 004564 004237 010350          JSR    R2,TOUT

```

```

753 004570 005777 173700          TST      0XCINT
754 004574 004537 010520          JSR      R5,ERROR
755 004600 012737 011070 007304      MOV      #EE34,MES
756 004606 004337 007210          JSR      R3,PRINT
757 004612 004537 010536          JSR      R5,SCOPE
758 004616 000000                      HLT                      ;INITIALIZE FAILED TO TERMINATE
759 004620 000137 004520          JMP      T34              ;T3
760 004624 004237 010350          PTX21  JSR      R2,TOUT
761 004630 005777 173646          TST      0XCINT          ;CLEAR SHORT LOOP,SECOND CHANCE
762 004634 012777 000400 173636      MOV      #000400,0XCSCR ;CLEAR RECEIVE FLAG
763
764
765
766
767
768
769 004642 004137 007402          T351  JSR      R1,CHECK
770 004646 012737 004642 010570      MOV      #T35,LOOP
771 004654 012777 000003 173616      MOV      #3,0XCSCR
772 004662 000005                      RESET
773 004664 004237 010350          JSR      R2,TOUT          ;WAIT FOR DELAYS TO TIME OUT
774 004670 105777 173604          TSTB     0XCSCR          ;TEST BIT 9
775 004674 100016          BPL      PTX3
776 004676 005777 173600          TST      0XCINT          ;CLEAR FLAGS
777 004702 004537 010520          JSR      R5,ERROR
778 004706 012737 011075 007304      MOV      #EE35,MES
779 004714 004337 007210          JSR      R3,PRINT
780 004720 004537 010536          JSR      R5,SCOPE
781 004724 000000                      HLT                      ;INITIALIZE FAILED TO TERMINATE T2
782 004726 000137 004642          JMP      T35
783 004732 005777 173544          PTX31  TST      0XCINT          ;CLEAR FLAGS SHORT LOOP, SECOND CHANCE
784 004736 012777 000400 173534      MOV      #000400,0XCSCR ;CLEAR RECEIVE FLAG
785
786
787
788
789 004744 004137 007402          T361  JSR      R1,CHECK
790 004750 000005                      RESET
791 004752 012737 000340 177776      MOV      #340,PS
792 004760 012737 004744 010570      MOV      #T36,LOOP
793 004766 005777 173512          TST      0XCSCR          ;CHECK BIT 15 OF ECSR
794 004772 100005          BPL      TILT
795 004774 105777 173504          TSTB     0XCSCR          ;CHECK BIT 7 OF EXT CSR 15=1
796 005000 100402          BMI      TILT            ;REPORT ERROR BOTH SAME
797 005002 000137 005040          JMP      T37              ;OK 15=1 9=0
798 005006 000240          TILT1 NOP
799 005010 004537 010520          JSR      R5,ERROR
000 005014 012737 011102 007304      MOV      #EE36,MES
001 005022 004337 007210          JSR      R3,PRINT
002 005026 004537 010536          JSR      R5,SCOPE
003 005032 000000                      HLT                      ;INCORRECT STATUS IN EXT. CSR
004 005034 000137 004744          JMP      T36
005
006

```

R2


```

007
008
009 005040 004137 007402 T39: JSR R1,CHECK
010 005044 017737 173434 005724 MOV @XECRS,PPL ;SAVE EXT STATUS
011 005052 012737 005040 010570 MOV @T37,LOOP
012 005060 000005 RESET
013 005062 004237 007342 JSR R2,WAITX ;WAIT FO RELAY
014 005066 067737 173412 005724 ADD @XECRS,PPL ;TEST FOR STATUS CHANGE
015 005074 100014 BPL T30
016 005076 004537 010520 JSR R5,ERROR
017 005102 012737 011107 007304 MOV @EE37,MES
018 005110 004337 007210 JSR R3,PRINT
019 005114 004537 010536 JSR R5,SCOPE
020 005120 000000 HLT ;RESET INSTRUCTION CHANGED STATUS
021 005122 000137 005040 JMP T37 ;OF EXT CSR
022
023
024 ;WITH LATCH IN NEUTRAL POSITION SWITCH BUSS AND
025 ;CHECK FOR CHANGE OF STATUS IN EXT. CSR
026
027 005126 004137 007402 T30: JSR R1,CHECK
028 005132 000005 RESET
029 005134 012737 005126 010570 MOV @T30,LOOP
030 005142 012737 011197 007304 MOV @EE30,MES
031 005150 017737 173330 005724 MOV @XECRS,PPL ;SAVE EXT. STATUS
032 005156 005277 173324 INC @XSWBU ;SWITCH BUSS
033 005162 004237 007342 JSR R2,WAITX
034 005166 004337 006100 JSR R3,OPP ;CHECK THAT BITS ARE OF OPPOSITE
035 005172 067737 173306 005724 ADD @XECRS,PPL ;POLARITY
036 005200 100414 BHI T39
037 005202 004537 010520 JSR R5,ERROR
038 005206 012737 011114 007304 MOV @EE30,MES
039 005214 004337 007210 JSR R3,PRINT
040 005220 004537 010536 JSR R5,SCOPE
041 005224 000000 HLT ;SWITCHING BUSS FAILED
042 005226 000137 005126 JMP T30
043
044
045 ;WITH BUS SWITCH'D CHECK THAT LATCH WILL DE-ENERGISE RELAY ON
046 ;A SECOND SWITCHING OF THE BUS
047 ;TEST THAT STATUS CHANGED (NEUTRAL POSITION)
048
049
050 005232 004137 007402 T39: JSR R1,CHECK
051 005236 012737 005232 010570 MOV @T39,LOOP
052 005244 017737 173234 005724 MOV @XECRS,PPL ;SAVE EXT STATUS
053 005252 005277 173230 INC @XSWBU ;ATTEMPT TO SWITCH BUSS
054 005256 004237 007342 JSR R2,WAITX ;WAIT FOR RELAY
055 005262 067737 173216 005724 ADD @XECRS,PPL ;HAS BUSS STATUS CHANGED
056 005270 100414 BHI T40
057 005272 004537 010520 JSR R5,ERROR
058 005276 012737 011121 007304 MOV @EE39,MES
059 005304 004337 007210 JSR R3,PRINT
060 005310 004537 010536 JSR R5,SCOPE

```

```

061 005314 000000
062 005316 200137 005232
063
064
065
066
067
068 005322 004137 007402 T401 JSR R1,CHECK
069 005326 012737 005322 013570 MOV @T40,LOOP
070 005334 017737 173144 005724 MOV @XCSR,PPL
071 005342 005277 173140 INC @XSNBU ;SWITCH BUS
072 005346 004237 007342 JSR R2,WAITX ;5 MILLI SEC FOR RELAY
073 005352 012737 011165 007304 MOV @EE40,MES
074 005360 004337 006100 JSR R3,OPP ;TEST FOR POL.CHANGE
075 005364 067737 173114 005724 ADD @XCSR,PPL ;TEST THAT STATUS CHANGED
076 005372 100414 BH T41
077 005374 004537 010520 JSR R5,ERROR
078 005400 012737 011126 007304 MOV @EE40,MES
079 005406 004337 007210 JSR R3,PRINT
080 005412 004537 010536 JSR R5,SCOPE
081 005416 000000 HLT ;BUS FAILED TO SWITCH TO 2ND LATCH
082 005420 000137 005322 JMP T40
083
084
085
086
087
088
089
090 005424 004137 007402 T411 JSR R1,CHECK
091 005430 012737 005322 013570 MOV @T40,LOOP
092 005436 017737 173042 005724 MOV @XCSR,PPL ;SAVE STATUS AND
093 005444 012777 000003 173026 MOV @3,@XCSR ;ALLOW FOR CLEAR ERROR
094 005452 004237 010350 JSR R2,TSUT ;TIME OUT ALLDELAYS
095 005456 004237 007342 JSR R2,WAITX ;5 MILLI,SEC FOR RELAYS
096 005462 012737 011173 007304 MOV @EE41,MES ;SET SUBTEST PRINT
097 005470 004337 006100 JSR R3,OPP ;SUBTEST
098 005474 067737 173004 005724 ADD @XCSR,PPL
099 005502 100414 BH T42 ;IF STATUS CHANGED GO ON
100 005504 004537 010520 JSR R5,ERROR
101 005510 012737 011133 007304 MOV @EE41,MES
102 005516 004337 007210 JSR R3,PRINT
103 005522 004537 010536 JSR R5,SCOPE
104 005526 000000 HLT ;BUSS FAILED TO SWITCH TO SECOND LATCH
105 005530 000137 005424 JMP T41
106
107
108
109
110
111
112 005534 004137 007402 T421 JSR R1,CHECK
113 005540 012737 005334 013570 MOV @T42,LOOP
114 005546 017737 172732 005724 MOV @XCSR,PPL

```

MZ

```

915 005554 005277 172720      INC      0XSW3U      ;ATTEMPT TO SWITCH BUSS
916 005560 004237 007342      JSR      R2,WAITX  ;5 MILLI SEC FOR RELAY
917 005564 067737 172714 005724  ADD      0XCSR,PPL ;DID STATUS CHANGE
918 005572 100414                BMI      T43       ;IF MINUS STATUS CHANGED
919 005574 004537 010520      JSR      R5,ERROR
920 005600 012737 011140 007304  MOV      0EE42,MES
921 005606 004337 007210      JSR      R3,PRINT
922 005612 004537 010536      JSR      R5,SCOPE
923 005616 000000                HLT
924 005620 000137 005534      JMP      T42       ;LATCH FAILED TO PREVENT BUSS FROM
;SWITCHING
925
926
927
928
929
930 005624 004137 007402      T43:    JSR      R1,C4ECK
931 005630 012737 005624 010570      MOV      #T43,LOOP
932 005636 017737 172642 005724  MOV      0XCSR,PPL      ;SAVE STATUS
933 005644 012737 011201 007304  MOV      0EE43S,MES     ;SET SUBTEST PRINT
934 005652 000000                RESET          ;CLEAR LATCH
935 005654 004237 007342      JSR      R2,WAITX     ;WAIT FOR RELAY
936 005660 004337 006100      JSR      R3,OPP
937 005664 067737 172614 005724  ADD      0XCSR,PPL     ;TEST FOR STATUS CHANGE
938 005672 100415                BMI      T44       ;IF MINUS STATUS CHANGED
939 005674 004537 010520      JSR      R5,ERROR
940 005700 012737 011145 007304  MOV      0EE43,MES
941 005706 004337 007210      JSR      R3,PRINT
942 005712 004537 010536      JSR      R5,SCOPE
943 005716 000000                HLT
944 005720 000137 005624      JMP      T43       ;RESET FAILED TO RELEASE LATCH
945
946
947
948 005724 000000      PPL:    B
949
950
951
952
953
954
955 005726 004137 007402      T44:    JSR      R1,C4ECK
956 005732 012737 005726 010570      MOV      #T44,LOOP
957 005740 012777 000003 172532  MOV      #3,0XCSR
958 005746 004237 010350      JSR      R2,TOUT     ;CLEAR ANY ERROR CONDITIONS
959 005752 005777 172524      TST      0XCINT      ;CLEAR FLAGS SHORT LOOP,SECOND CHANCE
960 005756 012777 000400 172514  MOV      000400,0XCSR ;CLEAR RECEIVE FLAG
961 005764 005277 172516      INC      0XSW3U
962 005770 004237 007342      JSR      R2,WAITX     ;SWITCH BUSS WAIT FOR RELAY
963 005774 005277 172500      INC      0XCSR       ;GENERATE A SHORT LOOP ERROR,RECEIVE FLAG SHOULD
964 006000 005277 172474      INC      0XCSR       ;GET SET WITH EXTERNAL ENABLE SET BY SWITCH BUS COMMAND
965 006004 004237 007342      JSR      R2,WAITX
966 006010 032777 040000 172462  BIT      040000,0XCSR
967 006016 001014                BNE      INIT
968 006020 004537 010520      JSR      R5,ERROR

```

A3

```

969 006024 012737 211152 007304 MOV 0EE44,MES
970 006032 004337 007210 JSR R3,PRINT
971 006036 004537 010536 JSR R5,SCOPE
972 006042 000000 HLT
973 006044 000137 005726 JMP T44 ;MANUAL ENABLE INPUT CIRCUITRY FAILED
974
975
976
977
978
979 ;INITIALIZE THE WORLD AND PRINT PASS FOR EACH
980 ;PASS OF TEST CHECK TELETYPE FOR COMMAND INSTRUCTIONS
981 006050 000005 INIT: RESET ;INITIALIZE WORLD
982 006052 012737 011233 007304 MOV 0PASS,MES ;SET PASS PRINT
983 006060 004337 007210 JSR R3,PRINT
984 006064 004137 007402 JSR R1,CHECK ;CHECK FOR TELTYPE COMMANDS
985 006070 012706 000600 MOV 0STACK,SP
986 006074 000137 001030 JMP T1
987
988
989 ;SUBROUTINE TO TEST THAT STATUS A&B ARE OF ADJACENT
990 ;POLARITY, THIS ROUTINE IS USED AS A SUBTEST.
991
992 006100 005777 172400 OPP: TST 0XEC5H ;TEST BIT 15 OF ESCR
993 006104 100004 BPL ,+12
994 006106 105777 172372 TSTB 0XEC5H ;BIT 15=1 TEST BIT 7
995 006112 100405 BHJ ,+14 ;REPORT A&B SAME
996 006114 000203 RTS R3
997 006116 105777 172362 TSTB 0XEC5H ;15=1 7=0
998 006122 100001 BPL ,+4 ;REPORT BOTH SAME
999 006124 000203 RTS R3
1000 006126 004537 010520 JSR R5,ERROR
1001 006132 000240 NOP
1002 006134 000240 NOP
1003 006136 000240 NOP
1004 006140 004337 007210 JSR R3,PRINT
1005 006144 004537 010536 JSR R5,SCOPE
1006 006150 000000 HLT
1007 006152 000177 002412 JMP 0LOOP ;LOOP ON FAILING TEST
1008 006156 000203 RTS R3 ;OK 15=1 7=0
1009 006160 105777 172320 TSTB 0XEC5H ;15=0 TEST 7
1010 006164 100001 BPL ,+4 ;REPORT BOTH SAME
1011 006166 000203 RTS R3 ;OK 15=0 7=1
1012 006170 004537 010520 JSR R5,ERROR ;CHECK FOR ERROR REPORT
1013 006174 000240 NOP
1014 006176 000240 NOP
1015 006200 000240 NOP
1016 006202 004237 007210 JSR R2,PRINT
1017 006206 004537 010536 JSR R5,SCOPE
1018 006212 000000 HLT
1019 006214 000177 002350 JMP 0LOOP ;LOOP ON FAILING TEST
1020
1021
1022

```

```

1024
1025
1026
1027
1028
1029
1030 006220 012737 000340 177776 DELAY: MOV #340,PS ;KEEP STATUS AT 7 FOR ENTIRE TEST
1031 006226 104000 NULL
1032 006230 000005 RESET
1033 006232 104000 NULL
1034 006234 012737 011277 007384 MOV #DELYST,MES ;PRINT "DELAY ADJUST TEST"
1035 006242 004337 007210 JSR R3,PRINT
1036 006246 012737 011327 007384 LREP: MOV #ASK,MES ;ASK FOR DELAY 1, 2
1037 006254 004337 007210 JSR R3,PRINT
1038 006260 004137 007306 JSR R1,REC ;RECIEVE ONE CHARACTER FROM TELE
1039 006264 004337 007172 JSR R3,ECHO ;ECHO CHARACTER
1040 006270 023727 007170 000261 CMP #LD,#261
1041 006276 001413 BEQ D1 ;RUN DELAY 1 (RECEIVE) TIMING TEST
1042 006300 023727 007170 000262 CMP #LD,#262
1043 006306 001432 BEQ D2 ;RUN DELAY 2 (WARNING & S.L.) TIMING TEST
1044 006310 012737 011402 007384 MOV #DU,MES ;PRINT A ?
1045 006316 004337 007210 JSR R3,PRINT
1046 006322 000137 006246 JMP LREP ;REPEAT LINE
1047
1048
1049 006326 012737 000340 177776 D1: MOV #340,PS
1050 006334 012777 000400 172136 MOV #000400,0XCSR ;CLEAR RECEIVE FLAG
1051 006342 012777 000003 172130 MOV #3,0XCSR ;PULSE WARNING FLAG DELAY
1052 006350 032777 040000 172122 BIT #040000,0XCSR ;MONITOR BIT 14
1053 006356 001774 BEQ #6
1054 006360 004237 010350 JSR R2,TDUT ;WAIT APPROX 10.-6 SEC
1055 006364 004137 007402 JSR R1,CHECK
1056 006370 000137 006326 JMP D1
1057 ;RUN WARNING FLAG & SHORT LOOP DELAY TIMING TESTS
1058
1059 006374 012737 000340 177776 D2: MOV #340,PS
1060 006402 005777 172074 TST 0XCIVT ;CLEAR FLAG
1061 006406 012777 000001 172004 MOV #1,0XCSR ;PULSE ALARM DELAY
1062 006414 105777 172060 TSTB 0XCSR ;TEST BIT ?
1063 006420 100375 BPL #4
1064 006422 004237 007342 JSR R2,WAITX
1065 006426 004137 007402 JSR R1,CHECK ;CHECK FOR TELETYPE COMMANDS
1066 006432 000137 006374 JMP D2 ;RECYCLE
1067
1068

```

```

1070
1071
1072
1073
1074
1075
1076
1077 006436 012737 011463 007334 DYNAMI MOV 0DYTST,MES
1078 006444 004337 007210 JSR R3,PRINT
1079 006450 104000 NULL
1080 006452 000005 RESET
1081 006454 004137 007402 DYN1 JSR R1,CHECK
1082 006460 017737 172020 007056 MOV 0XCSR,SIRE ;SAVE STATUS
1083 006466 012737 000340 177776 MOV 0340,PS ;SET STATUS
1084 006474 012704 006562 MOV 0HORV,R4 ;SET INT. RETURN
1085 006500 012705 006562 MOV 0HORV,R5
1086 006504 012737 000120 007054 MOV 0120,COUNT ;SET COUNTER FOR 100 PASSES
1087 006512 012777 000103 171700 PT1 MOV 0103,0XCSR ;START TIMING, ENABLE ALARM OUT
1088 006520 013737 000510 177776 MOV 0PRIV,PS ;STATUS=6
1089 006526 000240 NOP
1090 006530 000137 006526 JMP ;STAY HERE WAIT FOR INTERRUPT
1091 006534 012737 011502 007334 HERE1 MOV 0SLF,MES ;SHORT LOOP FLAG SET
1092 006542 004337 007210 JSR R3,PRINT
1093 006546 004237 010350 JSR R2,TOUT ;TIME OUT DELAYS
1094 006552 005777 171724 TST 0XCINT ;CLEAR FLAGS
1095 006556 000137 006512 JMP PT ;RECYCLE TEST
1096 006562 005777 171712 HORN1 TST 0XCSR ;FIND WHO GAVE INTERRUPT
1097 006566 100762 BMT HERE
1098 006570 105777 171704 TSTB 0XCSR ;CHECK BIT 7
1099 006574 100407 BMT OKK ;ALL RIGHT GO
1100 006576 032777 040000 171674 BIT 0040000,0XCSR ;NOT BIT 7 SO TRY 14
1101 006604 001505 BEQ ERR ;ILLEGAL INT.
1102 006606 105777 171666 TSTB 0XCSR
1103 006612 100375 BPL ;=4
1104 006614 032777 040000 171656 OKK1 BIT 040000,0XCSR ;BIT 7=1 WAIT FOR 14
1105 006622 001774 BEQ ;=6
1106 006624 005777 171652 TST 0XCINT ;CLEAR FLAGS SHORT LOOP, SECOND CHANCE
1107 006630 012777 000400 171642 MOV 0000400,0XCSR ;CLEAR RECEIVE FLAG
1108 006636 005277 171644 INC 0XSWBU ;SWITCH BUS
1109 006642 004237 007342 JSR R2,WAITX
1110 006646 067737 171632 007056 ADD 0XCSR,SIRE
1111 006654 100410 BMT CLST ;BR IF STATUS CHANGED
1112 006656 104000 NULL
1113 006660 012737 011552 007334 MOV 0000,MES ;REPORT EXT. STATUS BAD
1114 006666 004337 007210 JSR R3,PRINT
1115 006672 000137 006454 JMP DYN
1116 006676 017737 171602 007056 CLST1 MOV 0XCSR,SIRE
1117 006704 000005 RESET ;CLEAR LATCH
1118 006706 004237 007342 JSR R2,WAITX
1119 006712 067737 171566 007056 ADD 0XCSR,SIRE
1120 006720 100410 BMT TIME
1121 006722 104000 NULL
1122 006724 012737 011552 007334 MOV 0000,MES
1123 006732 004337 007210 JSR R3,PRINT
  
```

59

```

1124 006736 000137 006454          JMP      JYX
1125 006742 005337 007054          TIMEI  DEC      COJNT
1126 006746 001404          BEQ      ,+12          ;BRANCH WHEN DONE
1127 006750 004137 007402          JSR      R1,CHECK
1128 006754 000137 006512          JMP      PT
1129 006760 012737 000340 177776          MOV      #340,PS
1130 006766 104000          NULL
1131 006770 012737 011233 007304          MOV      #PASS,MES
1132 006776 004337 007210          JSR      R3,PRINT
1133 007002 104000          NULL
1134 007004 004237 010350          JSR      R2,TJUT
1135 007010 004237 010350          JSR      R2,TJUT
1136 007014 000137 006454          JMP      JYX
1137 007020 012737 011527 007304  ERRI  MOV      #IINT,MES
1138 007026 004337 007210          JSR      R3,PRINT
1139 007032 004237 010350          JSR      R2,TJUT
1140 007036 005777 171440          TST     #XCINT          ;CLEAR SHORT LOOP,SECOND CHANCE
1141 007042 012777 000400 171430          MOV      #000400,#XCSR ;CLEAR RECEIVE FLAG
1142 007050 000137 006512          JMP      PT
1143 007054 000000          COUNT: 0
1144 007056 000000          SIRE:  0
1145          I
1146          I
1147          I
1148          ;PRINT HEADER ROUTINE AND RECIEVE TELETYPE COMMANDS
1149          ;TO SPECIFY DESIRED TESTS
1150          I
1151 007060 005037 177562          HEADER: CLR      TKB          ;CLEAR DONE OF READER STATUS
1152 007064 012737 011405 007304          MOV      #HEAD,MES
1153 007072 004337 007210          JSR      R3,PRINT
1154 007076 004137 007306          JSR      R1,REC
1155 007102 004337 007172          JSR      R3,ECHO
1156 007106 023727 007170 000261          CMP      #LD,#261
1157 007114 001417          BEQ      TA
1158 007116 023727 007170 000262          CMP      #LD,#262
1159 007124 001415          BEQ      TB
1160 007126 023727 007170 000263          CMP      #LD,#263
1161 007134 001413          BEQ      TC
1162 007136 012737 011402 007304          MOV      #QU,MES
1163 007144 004337 007210          JSR      R3,PRINT
1164 007150 000137 007060          JMP      JYX          ;ILLEGAL CHARACTER TRY AGAIN
1165 007154 000137 001000          TA:   JMP      LOGIC      ;LOGIC TEST
1166 007160 000137 006220          TB:   JMP      DELAY     ;DELAY TIME LOOP
1167 007164 000137 006436          TC:   JMP      DYNAM       ;DYNAMIC TEST
1168 007170 000000          HD:   0              ;HOLD TEST DESIRED
  
```

```

1170
1171
1172 007172 013737 177562 177566 ECHO:  J
MOV     TK0,TYDB      ;READER BUFFER TO PRINTER BUFFER
TSTB   TYSR          ;TEST PRINTER STATUS
BPL    ,=4
RTS    R3
1174 007204 100375
1175 007206 000203
1176
1177
1178 007210 104000 PRINT: J
NULL
1179 007212 013704 007304 MOV     YES,R4
1180 007216 112437 007302 MOVB   (R4)+,DBUF
1181 007222 122737 000100 007302 CMPB   #100,DBUF
1182 007230 001422 BEQ    DONE
1183 007232 122737 000045 007302 CMPB   #45,DBUF
1184 007240 001004 BNE    OUT
1185 007242 004237 010466 JSR    R2,LPCR
1186 007246 000137 007216 JMP    PRINT+6
1187 007252 004537 007260 OUT:   JSR    R5,PRY
1188 007256 000757 BR     PRINT+6
1189
1190 007260 113737 007302 177566 PRY:   J
MOVB   DBUF,TYDB
1191 007266 105737 177564 TSTB   TYSR
1192 007272 100375 BPL    ,=4
1193 007274 000205 RTS    R5
1194 007276 104000 DDVEI: NULL
1195 007300 000203 RTS    R3
1196 007302 000000 DBUF:  0
1197 007304 000000 MESI:  0
1198
1199
1200
1201
1202
1203 007306 105737 177560 RECI:  J
TSTB   TKS          ;WAIT FOR KEYBOARD
1204 007312 100375 BPL    ,=4
1205 007314 013737 177562 007170 MOV    TKS,HL0     ;MOV DATA TO LOC. HLD
1206 007322 000201 RTS    R1
1207
1208
1209
1210
1211 007324 012737 001750 010426 WAIT:  J
MOV     #1750,TIMI
1212 007332 005337 010426 DEC    TIMI
1213 007336 001375 BNE    ,=4
1214 007340 000202 RTS    R2
1215
1216
1217
1218 007342 013737 007360 010426 WAITX: J
MOV     SPEED,TIMI ;LOAD FOR 5 MILLISEC
1219 007350 005337 010426 DEC    TIMI
1220 007354 001375 BNE    ,=4
1221 007356 000202 RTS    R2
1222 007360 177777 SPEED: 177777 ;5 MILLI SEC CONSTY
1223
    
```



```

1224
1225
1226
1227 007362 012706 000000 MAOCI MOV #STACK,SP ;FORCE INTERRUPT RETURN OF SHORTLOOP & WARNING
1228 007366 010407 MOV R4,PC
1229 007370 000000 MLT ;SHOULD NEVER GET HERE
1230
1231
1232 007372 012706 000000 RECFI MOV #STACK,SP ;RETURN FROM RECIEVE FLAG INTERRUPTS
1233 007376 010507 MOV R5,PC ;FORCE INT RET OF REC
1234 007400 000000 MLT
1235
1236
1237
1238
1239
1240 ;CHECK FOR COMMANDS TO MONITOR
1241 ;TEST REQUIRED
1242
1243
1244 007402 032737 000001 177570 CHECKI BIT #1,SR
1245 007410 001001 BNE ,+4
1246 007412 000201 RTS R1
1247 007414 012777 000003 171096 MOV #3,0XCSR
1248 007422 004237 010410 JSR R2,TCUT1
1249 007426 000005 RESET
1250 007430 005777 171046 TST 0XCINT ;CLEAR FLAGS
1251 007434 000137 007060 JMP HEADER
1252
1253
1254
1255
1256 ;WHEN VECTORS 170 & 174 ARE INCORRECTLY ASSERTED
1257 ;ENTER ROUTINE, REPORT ERROR AND RETURN TO FAILING TEST
1258
1259
1260 007440 012737 011241 007304 WRNGI MOV #WRONG,MES
1261 007446 004337 007210 JSR R3,PRINT
1262 007452 005726 TST (SP)+
1263 007454 012776 000340 000000 MOV #340,0(SP) ;SET RETURN STATUS TO 7
1264 007462 005746 TST -(SP)
1265 007464 000002 RTI ;RETURN TO FAILING TEST
1266
1267 ;BUSS TIME-OUT ERROR SUBROUTINE
1268
1269
1270 007466 004537 010520 TOBEI JSR R5,ERROR
1271 007472 012737 011207 007304 MOV #TOER,MES ;REPORT TIME OUT ERROR
1272 007500 004337 007210 JSR R3,PRINT
1273 007504 000240 NOP
1274 007506 000002 RTI
1275
1276
1277 ;SUBROUTINE FOR INPUTTING ADDRESSES AND VECTORS
    
```

```

1270
1279
1280 007510 012737 011576 007304 ADDMOI MOV #ASK1,MES ;ASK FOR "FIRST DEVICE ADD"
1281 007516 004337 007210 JSR R3,PRINT
1282 007522 005037 010334 CLR ADDRES
1283 007526 004137 007306 MODI JSR R1,REC ;REC A CHARACTER
1284 007532 004337 007172 JSR R3,ECHO
1285 007536 022737 000215 007170 CMP #219,HLD ;TEST FOR A C.R.
1286 007544 001416 BEQ SET
1287 007546 006337 010334 ASL ADDRES
1288 007552 006337 010334 ASL ADDRES
1289 007556 006337 010334 ASL ADDRES
1290 007562 042737 177770 007170 BIC #177770,HLD
1291 007570 063737 007170 010334 ADD HLD,ADDRES
1292 007576 000137 007526 JMP #00
1293 007602 005737 010334 SEPI TST ADDRES
1294 007606 001425 BEQ STRB
1295 007610 013737 010334 002500 MOV ADDRES,XCSR ;SET DEVICE ADDRESS
1296 007616 062737 000002 010334 ADD #2,ADDRES
1297 007624 013737 010334 002502 MOV ADDRES,XCINT
1298 007632 062737 000002 010334 ADD #2,ADDRES
1299 007640 013737 010334 002504 MOV ADDRES,XECSR
1300 007646 062737 000002 010334 ADD #2,ADDRES
1301 007654 013737 010334 002506 MOVB ADDRES,XSWBU
1302 007662 000240 STRBI NOP
1303 007664 012737 011625 007304 MOV #ASK2,MES ;ASK FIRST INT. VECTOR
1304 007672 004337 007210 JSR R3,PRINT
1305 007676 005037 010336 CLR VADDR ;CLR VECTOR ADDRESS
1306 007702 004137 007306 MODAI JSR R1,REC
1307 007706 004337 007172 JSR R3,ECHO
1308 007712 022737 000215 007170 CMP #219,HLD ;TEST FOR C.R.
1309 007720 001416 BEQ SETA
1310 007722 006337 010336 ASL VADDR
1311 007726 006337 010336 ASL VADDR
1312 007732 006337 010336 ASL VADDR
1313 007736 042737 177770 007170 BIC #177770,HLD
1314 007744 063737 007170 010336 ADD HLD,VADDR
1315 007752 000137 007702 JMP #00A
1316 007756 005737 010336 SEPAI TST VADDR
1317 007762 001430 BEQ STRBA
1318 007764 042737 177800 010336 BIC #177800,VADDR
1319 007772 012777 007362 002336 MOV #0A05,0VADDR
1320 010000 062737 000002 010336 ADD #2,VADDR
1321 010006 012777 000340 002322 MOV #340,0VADDR
1322 010014 062737 000002 010336 ADD #2,VADDR
1323 010022 012777 007372 002306 MOV #RECF,0VADDR
1324 010030 062737 000002 010336 ADD #2,VADDR
1325 010036 012777 000340 002272 MOV #340,0VADDR
1326 010044 012737 011651 007304 STRBAI MOV #ASK3,MES ;ASK FOR VECTOR LEVEL
1327 010052 004337 007210 JSR R3,PRINT
1328 010056 004137 007306 JSR R1,REC ;REC ONE CHARACTERS
1329 010062 004337 007172 JSR R3,ECHO
1330 010066 022737 000215 007170 CMP #219,HLD
1331 010074 001407 BEQ .+20
  
```

#3

1332	010076	022737	000264	007170	CMP	0264, HLD	:CHECK FOR A 4
1333	010104	001004			BNE	,+12	
1334	010106	012737	000140	000510	MOV	0140, PRIV	:SET PRIORITY AT 3
1335	010114	000437			BR	PROTIM	
1336	010116	022737	000265	007170	CMP	0265, HLD	
1337	010124	001004			BNE	,+12	
1338	010126	012737	000200	000510	MOV	0200, PRIV	
1339	010134	000427			BR	PROTIM	
1340	010136	022737	000266	007170	CMP	0266, HLD	
1341	010144	001004			BNE	,+12	
1342	010146	012737	000240	000510	MOV	0240, PRIV	
1343	010154	000417			BR	PROTIM	
1344	010156	022737	000267	007170	CMP	0267, HLD	
1345	010164	001004			BNE	,+12	
1346	010166	012737	000300	000510	MOV	0300, PRIV	
1347	010174	000407			BR	PROTIM	
1348	010176	012737	011402	007304	MOV	00U, YES	
1349	010204	004337	007210		JSR	R3, PRINT	
1350	010210	000137	010044		JMP	STRBA	:TRY AGAIN
1351	010214	012737	011677	007304	PROTIM: MOV	0ASK4, MES	
1352	010222	004337	007210		JSR	R3, PRINT	
1353	010226	004137	007306		JSR	R1, REC	
1354	010232	004337	007172		JSR	R3, ECHO	
1355	010236	022737	000301	007170	CMP	0301, HLD	
1356	010244	001004			BNE	,+12	
1357	010246	012737	001500	007360	MOV	01500, SPEED	
1358	010254	000417			BR	KA	
1359	010256	022737	000302	007170	CMP	0302, HLD	
1360	010264	001004			BNE	,+12	
1361	010266	012737	003000	007360	MOV	03000, SPEED	
1362	010274	000407			BR	KA	
1363	010276	022737	000303	007170	CMP	0303, HLD	
1364	010304	001004			BNE	,+12	
1365	010306	012737	006000	007360	MOV	06000, SPEED	
1366	010314	000205			RTS	R5	
1367	010316	012737	011402	007304	MOV	00J, YES	
1368	010324	004337	007210		JSR	R3, PRINT	
1369	010330	000137	010214		JMP	PROTIM	
1370							
1371							
1372	010334	000000			ADDRES: 0		
1373	010336	000000			VADDR: 0		

```

1375
1376 010340 012706 000600          TIMEXI  MOV      #STACK,SP      ;REINITIALIZE THE STACK
1377 010344 011407          MOV      (R4),PC        ;FORCE RETURN FROM INTERRUPT
1378 010346 000000          HLT
1379
1380
1381          ;RUN DELAY TIME OUTS, TOTAL TIME AS PER
1382          ;PROCESSOR TIME 05=4SEC, 40=3 SEC
1383
1384 010350 105737 177570          TOUTI   TSTB      SR
1385 010354 000415          BR       TOJY1          ;CHANGE TO BPL TO RUN A FAST MODE FOR
1386 010356 012737 000012 013424      MOV      #12,CNTIM      ;T1,T2,T3<90 MILLI=SEC
1387 010364 013737 007360 013426      RAI      MOV      SPEED,TIMI ;50 MILLI SEC. WORTH
1388 010372 005337 010426          DEC      TIMI
1389 010376 001375          BNE     ,=4
1390 010400 005337 010424          DEC     CNTIM
1391 010404 001367          BNE     RA
1392 010406 000202          RTS     R2              ;GO WHEN DONE
1393          ;RUN LONG TIME OUT FOR ALL DELAYS HERE
1394 010410 012737 000005 013426      TOUTI1  MOV      #5,TIMI        ;SET COUNT TIME
1395 010416 004437 010572          JSR     R4,TIME
1396 010422 000202          RTS     R2
1397 010424 000000          CNTIMI  0
1398 010426 000000          TIMI1   0
1399
1400
1401          NULPRTI  NOP
1402 010430 000240          TSTB    TYSR
1403 010432 105737 177564          BPL     ,=4
1404 010440 005037 177566          CLR     TYDB
1405 010444 105737 177564          TSTB    TYSR
1406 010450 100375          BPL     ,=4
1407 010452 005037 177566          CLR     TYDB
1408 010456 105737 177564          TSTB    TYSR
1409 010462 100375          BPL     ,=4
1410 010464 000002          RTI
1411
1412
1413 010466 012737 000215 177566      LFCRI   MOV      #215,TYDB      ;CARRIAGE RET.
1414 010474 105737 177564          TSTB    TYSR
1415 010500 100375          BPL     ,=4
1416 010502 012737 000212 177566      MOV      #212,TYDB
1417 010510 105737 177564          TSTB    TYSR
1418 010514 100375          BPL     ,=4
1419 010516 000202          RTS     R2
1420
1421
1422
1423          ;CHECK FOR ERROR PRINT OUT (BIT 13 OF SWITCH REG.)
1424 010520 032737 020000 177570      ERRORI  BIT      #28000,SR
1425 010526 001402          BEQ     ,=0              ;IF BIT 13=0 PRINT ERROR
1426 010530 062709 000012          ADD     #12,R5           ;ADD VALUE TO OMIT ERROR PRINT
1427 010534 000205          RTS     R5
1428

```

53

```

1429
1430 010536 013737 177570 010566 SCOPE1 ICHECK FOR SCOPE LOOP (BIT 14 OF SWITCH REG.)
1431 010544 032737 040000 010566 MOV SR,ESTAT
1432 010552 001404 BEQ ,=12 ;TEST BIT 14 OF SWITCH REGISTER
1433 010554 012706 000600 MOV @STACK,SP ;IF BIT 14=1 RUN SCOPE
1434 010560 013707 010570 MOV LOOP,PC ;FORCE RETURN TO TEST
1435 010564 000205 RTS R5 ;RETURN AND WLT
1436 010566 000000 ESTAT1 0
1437 010570 000000 LOOP1 0
1438
1439 ;
1440 010572 005037 010614 TIME1 CLR XE5 ;RUN TIME INCREMENTS IN VALUES STORED IN TIME
1441 010576 005237 010614 INC XE5 ;COUNT LOOP
1442 010602 001375 ONE ,=4 ;
1443 010604 005337 010426 DEC TIME1 ;NUMBER OF COUNT LOOPS
1444 010610 001372 ONE ,=12
1445 010612 000204 RTS R4
1446 010614 000000 XE51 0
1447 ;
1448 010616 000 ;MESSAGES
1449 010617 045 047514 044537 LTI ,BYTE
010624 020103 042524 052123 ;ASCII /XLOGIC TESTX0/
010632 040045
1450 010634 030524 040045 EE11 ,ASCII /T1X0/
1451
1452 010640 031124 040045 EE21 ,ASCII /T2X0/
1453
1454 010644 031524 040045 EE31 ,ASCII /T3X0/
1455
1456 010650 032124 040045 EE41 ,ASCII /T4X0/
1457
1458 010654 032524 040045 EE51 ,ASCII /T5X0/
1459
1460 010660 033124 040045 EE61 ,ASCII /T6X0/
1461
1462 010664 033524 040045 EE71 ,ASCII /T7X0/
1463
1464 010670 034124 040045 EE81 ,ASCII /T8X0/
1465
1466 010674 034524 040045 EE91 ,ASCII /T9X0/
1467
1468 010700 030524 022460 100 EE101 ,ASCII /T10X0/
1469
1470 010705 124 030461 040045 EE111 ,ASCII /T11X0/
1471
1472 010712 030524 022462 100 EE121 ,ASCII /T12X0/
1473
1474 010717 124 031461 040045 EE131 ,ASCII /T13X0/
1475
1476 010724 030524 022464 100 EE141 ,ASCII /T14X0/
1477
1478 010731 124 032461 040045 EE151 ,ASCII /T15X0/
1479
1480 010736 030524 022466 100 EE161 ,ASCII /T16X0/
    
```

1481							
1482	010743	124	033461	040045	EE171	.ASCII	/T17X0/
1483							
1484	010750	030524	022470	100	EE181	.ASCII	/T18X0/
1485							
1486	010755	124	034461	040045	EE191	.ASCII	/T19X0/
1487							
1488	010762	031124	022460	100	EE201	.ASCII	/T20X0/
1489							
1490	010767	124	030462	040045	EE211	.ASCII	/T21X0/
1491							
1492	010774	031124	022462	100	EE221	.ASCII	/T22X0/
1493							
1494	011001	124	031462	040045	EE231	.ASCII	/T23X0/
1495							
1496	011006	031124	022464	100	EE241	.ASCII	/T24X0/
1497							
1498	011013	124	032462	040045	EE251	.ASCII	/T25X0/
1499							
1500	011020	031124	022466	100	EE261	.ASCII	/T26X0/
1501							
1502	011025	124	033462	040045	EE271	.ASCII	/T27X0/
1503							
1504	011032	031124	022470	100	EE281	.ASCII	/T28X0/
1505							
1506	011037	124	034462	040045	EE291	.ASCII	/T29X0/
1507							
1508	011044	031524	022460	100	EE301	.ASCII	/T30X0/
1509							
1510	011051	124	030463	040045	EE311	.ASCII	/T31X0/
1511							
1512	011056	031524	022462	100	EE321	.ASCII	/T32X0/
1513							
1514	011063	124	031463	040045	EE331	.ASCII	/T33X0/
1515							
1516	011070	031524	022464	100	EE341	.ASCII	/T34X0/
1517							
1518	011075	124	032463	040045	EE351	.ASCII	/T35X0/
1519							
1520	011102	031524	022466	100	EE361	.ASCII	/T36X0/
1521							
1522	011107	124	033463	040045	EE371	.ASCII	/T37X0/
1523							
1524	011114	031524	022470	100	EE381	.ASCII	/T38X0/
1525							
1526	011121	124	034463	040045	EE391	.ASCII	/T39X0/
1527							
1528	011126	032124	022460	100	EE401	.ASCII	/T40X0/
1529							
1530	011133	124	030464	040045	EE411	.ASCII	/T41X0/
1531							
1532	011140	032124	022462	100	EE421	.ASCII	/T42X0/
1533							
1534	011145	124	031464	040045	EE431	.ASCII	/T43X0/

```

1535
1536 011152 032124 022464 100 EE441 .ASCII /T44X0/
1537
1538 011157 124 034063 022523 EE3051 .ASCII /T305X0/
011164 100
1539
1540 011165 124 030064 022523 EE4051 .ASCII /T405X0/
011172 100
1541
1542 011173 124 030464 022523 EE4151 .ASCII /T415X0/
011200 100
1543
1544 011201 124 030464 022523 EE4351 .ASCII /T415X0/
011206 100
1545
1546 011207 102 051525 042440 TOER1 .ASCII /BUS ERROR TIME-OUTX0/
011214 051122 051117 052040
011222 046511 026505 052517
011230 022524 100
1547
1548 011233 120 051501 022523 PASS1 .ASCII /PASSX0/
011240 100
1549
1550 011241 124 040522 053120 WRONG1 .ASCII /TRAPPED TO WRONG INT. VECTORX0/
011246 042105 052040 023117
011254 051127 047117 023107
011262 047111 027124 053040
011270 041505 047524 022522
011276 100
1551
1552 011277 045 042504 043514 DELTST1 .ASCII /XDELAY ADJUSTMENT TESTX0/
011304 020131 042101 052512
011312 052123 042515 053116
011320 052040 051505 022524
011326 100
1553
1554 011327 104 046105 054501 ASR1 .ASCII /DELAY:(1)WATCHDOG.(2)WARNING & SHORT LOOPX0/
011334 024072 024461 043527
011342 041524 042110 043517
011350 024056 024462 043527
011356 047122 047111 023107
011364 020046 044123 051117
011372 020124 047514 053117
011400 040048
1555
1556 011402 022477 100 QUI .ASCII /TX0/
1557
1558 011405 045 047514 044507 HEAD1 .ASCII /XLOGIC TEST(1),DELAY TEST(2),DYNAMIC TEST(3)X0/
011412 020103 042524 052123
011420 030490 020051 042504
011426 040514 020131 042524
011434 052123 031050 026051
011442 054504 040516 044515
011450 020103 042524 052123
  
```

	011456	031458	722451	100		
1559						
1560	011463	045	054524	040516	DYFST:	.ASCII /XDYNAMIC TESTX0/
	011470	244515	220183	042524		
	011476	052123	040045			
1561						
1562	011502	044123	051117	020124	SLP:	.ASCII /SHORT LOOP FLAG SETX0/
	011510	047514	050117	043040		
	011516	040514	020107	042523		
	011524	022524	100			
1563						
1564	011527	111	046114	043505	IINT:	.ASCII /ILLEGAL INTERRUPTX0/
	011534	046101	044440	052116		
	011542	051105	052522	052120		
	011550	040045				
1565						
1566	011552	054105	027124	052502	BBG:	.ASCII /EXT,BUS STATUS BADX0/
	011560	020123	052123	052101		
	011566	051525	041040	042101		
	011574	040045				
1567						
1568	011576	043045	051111	052123	ASK1:	.ASCII /XFIRST DEVICE ADDRESS=0/
	011604	042040	053105	041511		
	011612	020105	042101	051104		
	011620	051505	036523	100		
1569						
1570	011625	045	044506	051522	ASK2:	.ASCII /XFIRST INT. VECTOR=0/
	011632	020124	047111	027124		
	011640	053040	041505	047524		
	011646	036522	100			
1571						
1572	011651	045	051120	047511	ASK3:	.ASCII /XPRIORITY INT. LEVEL=0/
	011656	044522	054524	044440		
	011664	052116	020056	042514		
	011672	042526	036514	100		
1573	011677	045	042120	020520	ASK4:	.ASCII /XPDP=11 (A)=05,10,20 (B)=35,40 (C)=45,50 0/
	011704	030461	024040	024501		
	011712	030075	026065	030061		
	011720	031054	020060	041050		
	011726	036451	032463	032054		
	011734	020060	041450	036451		
	011742	032464	032454	020060		
	011750	100				
1574						
1575		011752				.EVEN
1576		000001				.END

AA1	001322	AA2	001432	AA4	003446	AA5	003626
ADDMO	007510	ADDRES	010334	ASK	011327	ASK1	011576
ASK2	011625	ASK3	011651	ASK4	011677	BBS	011552
CHECK	007402	CJMT	= 172402	CLST	006676	CNTIM	010424
COUNT	007054	CSR	= 172400	DBUF	007382	DELAY	006220
DELSTY	011277	DONE	007276	DYMAN	006436	DYSTY	011463
DYX	006454	D1	006326	D2	006374	ECHO	007192
ECOR	= 172404	EE1	010634	EE10	010700	EE11	010705
EE12	010712	EE13	010717	EE14	010724	EE15	010731
EE16	010736	EE17	010743	EE18	010750	EE19	010755
EE2	010640	EE20	010762	EE21	010767	EE22	010774
EF23	011001	EE24	011006	EE25	011013	EE26	011020
EE27	011025	EE28	011032	EE29	011037	EE3	010644
EE30	011044	EE31	011051	EE32	011056	EE33	011063
EE34	011070	EE35	011075	EE36	011102	EE37	011107
EE38	011114	EE38S	011117	EE39	011121	EE4	010650
EE40	011126	EE40S	011165	EE41	011133	EE41S	011173
EE42	011140	EE43	011145	EE43S	011201	EE44	011152
EE5	010654	EE6	010660	EE7	010664	EE8	010670
EE9	010674	ERR	007020	ERROR	010520	ESTAT	010566
HEAD	011405	HEADER	007000	HERE	006534	HLD	007170
HL7	= 000000	HORN	006562	IINT	011527	INIT	006050
KA	010314	LFGR	010466	LOGIC	001000	LOOP	010570
LREP	006246	LY	010617	MES	007384	MOD	007526
MODA	007702	NOP	= 000240	NULL	= 104000	NULPRT	010430
OKK	006614	OPP	006130	OUT	007252	PASS	011233
PC	=X000007	PPL	005724	PRINT	007210	PRIV	000510
PROTIM	010214	PRT	007260	PS	= 177776	PT	006512
PTR	004226	PTX1	004536	PTX2	004624	PTX3	004732
QU	011402	RA	010304	REC	007306	RECF	007372
R0	=X000000	R1	=X000001	R2	=X000002	R3	=X000003
R4	=X000004	R5	=X000005	SCOPE	010536	SET	007602
SEYA	007756	SIRE	007056	SLP	011502	SP	=X000006
SPELD	007360	SR	= 177570	STACK	000600	STR0	007662
STRBA	010044	SWBU	= 172406	TA	007154	TB	007160
TC	007164	TEST	001016	THW	002474	TIKE	006742
TILT	005006	TIME	010572	TIMEX	010340	TIMI	010426
TK0	= 177562	TKS	= 177560	TOOE	007466	TOER	011207
TOUT	010350	TOUT1	010410	TY00	= 177566	TYSR	= 177564
T1	001030	T10	001752	T11	002036	T12	002112
T13	002172	T14	002270	T15	002332	T16	002410
T17	002526	T18	002560	T19	002622	T2	001110
T20	002664	T21	002730	T22	003026	T23	003114
T24	003212	T25	003330	T26	003470	T27	003644
T28	003752	T29	004052	T3	001170	T30	004120
T31	004244	T32	004326	T33	004414	T34	004520
T35	004642	T36	004744	T37	005040	T38	005126
T39	005232	T4	001246	T40	005322	T41	005424
T42	005534	T43	005624	T44	005726	T5	001352
T6	001462	T7	001534	T8	001610	T9	001706
VADDR	010336	WAIT	007324	WA!TX	007342	WADG	007362
WRNG	007440	WRONG	011241	XCINT	000502	XCSR	000500
XCSR	000504	XES	010614	XSWBU	000506	.	= 011752

134

WATCH DOG TIMER MACY11 27(655) 12-SEP-74 13143 PAGE 11-6
WATCH.SRC SYMBOL TABLE

ERRORS DETECTED: 0

*WATCH, WATCH=WATCH.SRC
RUN-TIME: 4 9 0 SECONDS
CORE USED: 4K

C4