

.REM .

IDENTIFICATION

PRODUCT CODE: AC-8050C-MC
PRODUCT NAME: CFKGTGCO 11/34 MEM MGMT
PRODUCT DATE: 26 MAR 79
MAINTAINER: DIAGNOSTIC ENGINEERING

COPYRIGHT (C) DIGITAL EQUIPMENT CORPORATION
1974, 1979

THE MATERIAL IN THIS DOCUMENT IS FOR INFORMATION
PURPOSES ONLY AND IS SUBJECT TO CHANGE WITHOUT NOTICE.
DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY
FOR THE USE OF SOFTWARE ON EQUIPMENT WHICH IS NOT
SUPPLIED BY IT.
DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY
FOR ANY ERRORS WHICH MAY APPEAR IN THE DOCUMENT.

ABSTRACT

C 1

THIS PROGRAM IS AN INTERACTIVE EXERCISER FOR THE MEMORY MANAGEMENT PORTION OF A PDP 11/34. IT PERFORMS A TEST OF INSTRUCTIONS AND CONCURRENT OPERATIONS OF I/O EQUIPMENT WHILE RELOCATING THRU MEMORY. IT PROVIDES NUMEROUS MODES OF TESTING, FROM 4K EXECUTION WITH THE MEMORY MANAGEMENT TURNED OFF AND ONLY KERNEL MODE IN USE, TO 128K EXECUTION WITH EACH USER PAGE MAPPED SEQUENTIALLY TO EVERY 4K BANK OF MEMORY.

THIS PROGRAM IS NOT TO BE CONSIDERED A TOTAL CHECK OF THE SYSTEM. IF AN ERROR IS DETECTED IN AN I/O DEVICE, IT WILL PROBABLY BE NECESSARY TO CORRECT THE MALFUNCTION WITH THE RESPECTIVE DIAGNOSTIC FOR THAT DEVICE.

2.0 REQUIREMENTS

2.1 EQUIPMENT

PDP-11/34 STANDARD COMPUTER
TELETYPE OR EQUIVALENT

2.1.1 OPTIONAL HARDWARE THAT THE PROGRAM WILL EXERCISE

MEMORY UP TO 124 KW OF MEMORY-DOES NOT HAVE TO BE CONTIGUOUS,
BUT BLOCKS OF LESS THAN 4KW WILL NOT BE USED
RF11 DISK
RK11 DISK
TC11 DECTAPE-TRANSPORT ONE(1)
KW11-L LINE CLOCK
KL11 ASR33 OR ASR35 TELEPRINTER
LP11 LINE PRINTER

2.2 STORAGE

THIS PROGRAM USES MEMORY FROM 00000 TO 17760.

3.0 LOADING PROCEDURE

PROCEDURE FOR NORMAL ABSOLUTE TAPES SHOULD BE FOLLOWED.

4.0 STARTING PROCEDURE AND SWITCH SETTINGS

4.1 NORMAL STARTING PROCEDURE

SET DESIRED MEMORY MANAGEMENT OPTION SWITCHES
(IN LOC. 174, MMOPT) (SEE SECTION 4.2)
ALL ZERO FOR WORST CASE TESTING
SET DESIRED SWITCH REGISTER BITS.
(USE LOC. 176 FOR SOFTWARE SWITCH REGISTER
IF NECESSARY). (SEE SECTION 4.3 AND 5.1.2)
LOAD ADDRESS 200 AND START.

4.1 NORMAL STARTING PROCEDURE (CONTINUED)

THE PROGRAM WILL RING THE BELL (UNLESS THE TTY OUTPUT IS INHIBITED) AT THE END OF EACH BANK. IF SWITCHES 0,1 AND 2 WERE ALL DOWN WHEN START WAS PRESSED (SELECTING THE USE OF 4K PHYSICAL ADDRESS SPACE AS 32K VIRTUAL ADDRESS SPACE-SEE 5.3.1) AN ASTERISK WILL BE TYPED AT THE END OF A FULL PASS THRU ALL MEMORY (UNLESS THE TTY OUTPUT IS INHIBITED).

4.2 MEMORY MANAGEMENT SELECTION SWITCHES (INITIAL SWITCH REGISTER SETTINGS).

THE SWITCHES SET BEFORE STARTUP DETERMINE THE WAY IN

WHICH MEMORY IS MAPPED AND EXERCISED: (USE LOC 174 FOR SETTING SWITCHES)

MMOPT BIT0=1---INHIBIT MEMORY MGMT. (SRO<0> WILL NOT BE SET AT ALL)

MMOPT BIT1=1---INHIBIT USE OF USER MODE.

(ALSO INHIBITS 4K AS 32K)

MMOPT BIT2=1---INHIBIT 4K AS 32 K (ALSO INHIBITED IF EITHER SW0
OR SW1 IS SET)-SEE SECTION 5.3.1 FOR EXPLANATION

MMOPT BIT5=1---INHIBIT VARIABLE CORE EXPANSION

=0 OR DOWN-CORE EXPAND UNLESS SW0, 1 AND 2 ARE ALL DOWN
(IN WHICH CASE 4K AS 32K IS RUN INSTEAD)

4.3 DEVICE SELECTION SWITCHES

THE DEVICE SELECTION SWITCHES ARE SET IN THE SWITCH REGISTER
(USE LOC. 176 FOR SOFTWARE SW. REG. IF NECESSARY) ALSO SEE
SEC. 5.1.2. EACH SWITCH INHIBITS A SINGLE I/O DEVICE FROM
BEING EXERCISED.

SW0=1 OR UP---INHIBIT TTY OUTPUT

SW3=0 OR DOWN---INHIBIT RK11 DISK

SW4=0 OR DOWN---INHIBIT LINE CLOCK

SW5=0 OR DOWN---INHIBIT RF11 DISK

SW6=0 OR DOWN---INHIBIT TC11 DECTAPE

SW7=0 OR DOWN---INHIBIT LINE PRINTER (USE SA310 IF LP11 IS SELECTED)

4.4 RESTART PROCEDURE

USING RESTART ADDRESS 310 THE SWITCH REGISTER SETTINGS
GIVEN PREVIOUSLY ARE USED (FOR BOTH MEMORY MANAGEMENT
SELECTION AND DEVICE SELECTION).

5. OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

5.1.1 BASIC SWITCH SETTINGS-STARTUP

SEE SECTIONS 4.2 AND 4.3 FOR THE BASIC SWITCH SETTINGS USED AT STARTUP.
THOSE SWITCHES ARE NOT RECHECKED AFTER THEY ARE INITIALLY STORED.

5.1.2 DYNAMIC SWITCH SETTINGS

NOTE: IF NO HARDWARE SWITCH REGISTER IS AVAILABLE, THE PROGRAM
----- WILL AUTOMATICALLY USE THE CONTENTS OF LOC. 176 AS THE SOFTWARE
SWITCH REG. THE USER SHOULD SET THIS LOCATION BEFORE STARTING
THE PROGRAM.

THE FOLLOWING SWITCHES ARE RECHECKED PERIODICALLY DURING PROGRAM
EXECUTION:

SW15=1 OR UP---HALT ON ERROR

SW14=1 OR UP---SCOPE LOOP

SW13=1 OR UP---INHIBIT PRINT OUT

SW12=1 OR UP---INHIBIT TRACE TRAPPING

SW11=1 OR UP---INHIBIT SUB-PROGRAM ITERATION AND INHIBIT TESTS WHICH USE ALL COMBINATIONS OF NUMBERS
SW10=i OR UP---INHIBIT PROCESSOR TEST (ONCE SET, PROCESSOR TEST IS PERMANENTLY INHIBITED)

5.2 SUBROUTINE ABSTRACTS

5.2.1 SCOPE

THIS SUBROUTINE CALL IS PLACED BETWEEN EACH SUBTEST. IT RECORDS THE STARTING ADDRESS OF EACH SUBTEST AS IT IS BEING ENTERED. IF A SCOPE LOOP IS REQUESTED, IT WILL JUMP TO THE START OF THE SUBTEST THAT THE SCOPE LOOP IS REQUESTED FOR. IF A SCOPE LOOP IS NOT REQUESTED, THERE WILL BE 256 ITERATIONS ON THAT SUBTEST BEFORE THE NEXT SUBTEST IS ENTERED. SWITCH 11 ON A 1 INHIBITS ITERATION OF SUBTESTS.

5.2.2 MLT

THIS EMT CALLS THE SUBROUTINE PRINT, WHICH PRINTS OUT THE LOCATION COUNTER AT THE TIME OF FAILURE, THE CONTENTS OF THE PROCESSOR STATUS REGISTER, AND THE CONTENTS OF THE CURRENT BANK COUNTER. NOTE THAT THE LOCATION COUNTER WILL BE THE VIRTUAL ADDRESS OF THE MLT PLUS TWO.

5.2.3 TRAPCATCHER

THIS IS A SERIES OF INSTRUCTIONS STARTING AT LOCATION 0 DESIGNED TO DETECT AND ISOLATE UNEXPECTED TRAPS AND INTERRUPTS TO THE TRAP AND INTERRUPT VECTOR AREA OF MEMORY.

EACH VECTOR ENTRANCE ADDRESS IS LOADED WITH THE ADDRESS OF THE NEXT LOCATION. THE NEXT LOCATION IS LOADED WITH A HALT (00000). THUS AN ILLEGAL TRAP OR INTERRUPT WILL CAUSE A HALT AT THE TRAP LOCATION PLUS TWO.

IF A HALT OCCURS IN THE TRAP OR INTERRUPT AREA EXAMINE KERNEL REGISTER SIX. IT WILL CONTAIN THE CURRENT STACK ADDRESS. THE CONTENTS OF THE CURRENT STACK ADDRESS IS THE VIRTUAL PC AT THE TIME THE TRAP OR INTERRUPT OCCURRED.

5.2.4 EMTSRV (EMT HANDLER)

THIS ROUTINE DECODES THE EMT CALLS AND PASSES CONTROL TO THE CORRECT SERVICE ROUTINE. THE ROUTINES HANDLED BY EMT CALLS ARE PRINT (MLT CALL) AND EOBSRV (EOB CALL).

5.2.6 EOBSRV (END OF BANK SERVICE)

THE VARIOUS EXECUTION OPTIONS FOR THIS EXERCISER REQUIRE SPECIAL HANDLING WHEN THE END OF THE PROCESSOR TESTS IS REACHED IN A BANK. THIS SERVICE ROUTINE PERFORMS THE VARIOUS MAPPING FUNCTIONS, DEPENDING UPON THE INITIAL SWITCH REGISTER SETTINGS.

5.2.7 BEGINX (CORE EXPANSION SPECIAL HANDLER)

WHEN CORE EXPANSION IS UTILIZED, A NUMBER OF SPECIAL ACTIONS MUST BE TAKEN AT THE BEGINNING OF EACH BANK. THE SCOPE ROUTINE VECTOR IS LOADED TO POINT TO THE NEW BANK, AND IF TC11 AND RF11 CODE AND BUFFER RELOCATION IS ALLOWED.

5.2.9 PFAIL (POWER FAIL)

IN THIS VERSION THE POWER FAIL ROUTINE IS NOT OPERABLE.

5.2.11 TYOUT (TTY OUTPUT)

THIS ROUTINE OUTPUTS A COUNT PATTERN IN THE INTERRUPT MODE TO THE TELEPRINTER.

5.2.12 RFSTART (RF11 DISK)

THIS ROUTINE PERFORMS A WRITE AND A WRITE CHECK OF THE DISK. THE DATA THAT IS WRITTEN ON THE DISK IS A PART OF THE TEST PROGRAM CODE THAT IS NEVER MODIFIED. THIS SEGMENT OF CORE IS WRITTEN IN CONTIGUOUS BLOCKS THRU THE DISK MEMORY. AFTER THE TOTAL DISK(S) HAS BEEN WRITTEN, A WRITE CHECK IS USED TO VERIFY THAT THE DATA HAS BEEN WRITTEN CORRECTLY ON THE DISK. NOTE THAT NO "DATA" ARE USED IN EXERCISING THE DISK (DATA IS NOT TRANSFERRED INTO MEMORY). THERE IS A LOCATION IN THE PROGRAM THAT IF MODIFIED WILL ALLOW EXERCISING UP TO EIGHT DISKS.

5.2.13 ENDZ (TC11 END ZONE HANDLER)

THIS ROUTINE IS PART OF THE TC11 SERVICE CODE. IT DRIVES THE DECTAPE INTO THE FORWARD OR REVERSE END ZONE, THEN REVERSES IT. IT ALSO DOES THE NECESSARY SETUP TO BEGIN READING OR WRITING THE TAPE.

5.2.14 REGEN (TC11 WRITE BUFFER REGENERATE ROUTINE)

THE TC11 CODE WRITES THE ENTIRE DECTAPE GOING FORWARD, THEN READS IT IN REVERSE. THE BUFFER IS REGENERATED BEFORE WRITING THE TAPE, AND IS CLEARED OUT ONCE THE ENTIRE TAPE HAS BEEN WRITTEN. THIS ROUTINE REGENERATES THE WRITE BUFFER.

5.2.15 RBN (TC11 READ BLOCK NUMBER SERVICE ROUTINE)

AT THE END OF EACH "BLOCK NUMBER FOUND" INTERRUPT, THIS ROUTINE IS ENTERED (UNLESS END ZONE IS BEING SEARCHED FOR). IT CHECKS FOR THE CORRECT SEQUENCE OF BLOCK NUMBERS, THEN SETS UP THE TC11 TO WRITE A BLOCK IF THE TAPE IS TRAVELLING FORWARD. IF IT IS GOING IN REVERSE, THE ROUTINE CHECKS TO SEE IF DATA IS STILL BEING CHECKED FROM A PREVIOUS READ. IF IT'S NOT, THE ROUTINE SETS UP TO READ A BLOCK. IF DATA IS STILL BEING CHECKED FROM BEFORE, IT SIMPLY DOES ANOTHER READ BLOCK NUMBER.

5.2.16 NRTBLK (TC11 READ BLOCK AND WRITE BLOCK SERVICE ROUTINE)

WHEN A READ BLOCK OR A WRITE BLOCK OPERATION IS COMPLETED, THIS ROUTINE IS ENTERED. IT CHECKS THE ERROR BIT, THEN SETS UP A CALL TO CHECK DATA IF DATA WAS JUST READ IN. THE ROUTINE ALSO SETS UP A READ BLOCK NUMBER OPERATION.

5.2.17 TCCK (TC11 CHECK DATA ROUTINE)

WHEN A READ BLOCK OPERATION HAS BEEN COMPLETED, THIS ROUTINE IS CALLED VIA A PRIORITY INTERRUPT REQUEST AT LEVEL 3. THE ENTIRE BUFFER IS CHECKED, AND THE CONTENTS OF THE BUFFER IS ALTERED AS THE CHECK PROGRESSES. THUS, IF A READ BLOCK OPERATION DOES NOT ACTUALLY READ IN ANY DATA, THE DATA CHECK ROUTINE WILL FIND BAD DATA INSTEAD OF SEEING GOOD DATA FROM AN EARLIER READ.

5.2.18 LCLK (LINE CLOCK)

THIS TEST OF THE LINE CLOCK IS IN THE INTERRUPT MODE. IF OPERATING CORRECTLY THE SYSTEM I/O WILL RUN AT FULL SPEED FOR 55 SECONDS. AND THEN ALL I/O AT LEVEL FOUR OR LESS (AND THE PROCESSOR TESTS) WILL STALL FOR 5 SECONDS. TIMES GIVEN ARE BASED ON 60 CYCLES AS THE LINE FREQUENCY.

5.2.19 LPI (LINE PRINTER)

THIS ROUTINE OUTPUTS TO THE LINE PRINTER IN THE FLAG MODE WHILE FILLING THE BUFFER, AND IN THE INTERRUPT MODE WHILE THE BUFFER IS BEING PRINTED.

5.2.20 RKSTART (RK-11 DISK)

THIS ROUTINE PERFORMS A WRITE AND WRITE CHECK OF THE DISK. THE DATA THAT IS WRITTEN ON THE DISK IS PART OF THE TEST PROGRAM CODE THAT IS NEVER MODIFIED. THIS SEGMENT OF CORE IS WRITTEN IN CONTIGUOUS BLOCKS THRU THE DISK MEMORY. AFTER THE TOTAL DISK HAS BEEN WRITTEN, A WRITE CHECK IS USED TO VERIFY THAT DATA HAS BEEN WRITTEN CORRECTLY ON THE DISK.

5.2.22 CORE EXPANSION (DET1)

THIS ROUTINE IS CONTROLLED BY SWITCH 5. IF CALLED, THE PROCESSOR MAINLINE CODE WILL EXPAND TO THE MAXIMUM MEMORY THAT IS AVAILABLE (UP TO 28K). THE ROUTINE DETERMINES THE MAXIMUM MEMORY SIZE BY DOING A "DATO" TO A LOCATION IN EACH BANK. IF THE BANK DOES NOT EXIST, A TIMEOUT WILL OCCUR. AN IMAGE OF BANK 0 IS THEN TRANSFERRED TO EACH EXISTING BANK. THE CODE IN EACH BANK EXCEPT THE LAST IS MODIFIED TO CHANGE THE END OF BANK CALL TO A JUMP TO BEGINX (CORE EXPANSION SPECIAL HANDLER) IN THE NEXT BANK.

THE LISTING SHOWS ONLY THE CODE FOR BANK ZERO. WHEN AN ERROR OCCURS THAT IS NOT IN BANK ZERO, IGNORE THE BANK BITS OF THE PRINT OUT AND USE THE LISTING FOR BANK ZERO.

5.3 PROGRAM AND/OR OPERATOR ACTION

5.3.1 PROCESSOR TEST EXECUTION - 4K AS 32K

IF MMOPT BITS 0, 1, AND 2 ARE ALL ZERO (=0) AT STARTUP, THE PROCESSOR TEST WILL BE EXECUTED TREATING EACH 4K BANK AS 32K OF VIRTUAL ADDRESS SPACE. THE FOLLOWING DETAILS THIS MODE OF OPERATION.

USER PAGE 0 IS FIRST MAPPED RW, BANK 0, AND ALL OTHER USER PAGES ARE MAPPED NON-RESIDENT. THE PROCESSOR TESTS ARE EXECUTED IN USER THRU USER PAGE 0. WHEN DONE, USER PAGE 0 IS CHANGED TO NON-RESIDENT, AND USER PAGE 1 IS MAPPED RW, BANK 0. THE PC IS CHANGED TO ADDRESS THE START OF THE PROCESSOR TESTS THRU PAGE 1, AND ANOTHER PASS THRU THE PROCESSOR TESTS IS EXECUTED. AT THE END OF THIS PASS, USER PAGE 2 IS MAPPED RW, BANK 0, AND USER PAGE 1 IS MADE NON-RESIDENT. THE PC IS AGAIN CHANGED. THIS TIME TO ACCESS USER PAGE 2, AND THE PROCESSOR TESTS ARE EXECUTED THRU USER PAGE 2. THIS CYCLE IS REPEATED FOR THE REMAINING USER PAGES, MAPPING EACH IN TURN TO BANK 0 AND CHANGING THE PC TO EXECUTE THRU THE ONE CURRENTLY MAPPED. WHEN THE PASS USING USER PAGE 7 IS COMPLETED, A SEARCH IS MADE FOR THE NEXT 4K BANK OF MEMORY. WHEN A BANK IS FOUND, THE PROGRAM IS COPIED INTO THAT BANK FROM BANK 0. USER PAGE 0 IS MAPPED TO THE NEW BANK, AND THE PC IS CHANGED TO EXECUTE THRU USER PAGE 0. THE PREVIOUS CYCLE IS REPEATED, BUT THIS TIME EACH USER PAGE IS MAPPED IN TURN TO THE NEW BANK. ONCE EXECUTION THRU USER PAGE 7 IS COMPLETED, A SEARCH IS MADE FOR THE NEXT BANK. THE PREVIOUS BANK IS CLEARED (EXCEPT FOR THE LOADER), AND THE PROGRAM IS COPIED FROM BANK 0 INTO THE CURRENT BANK. THE CYCLE REPEATS UNTIL THE EXTERNAL BANK IS REACHED, AT WHICH POINT USER 0 IS MAPPED BACK TO BANK 0 AND THE PROCESS STARTS AGAIN.

5.3.2 PROCESSOR TEST EXECUTION - CORE EXPANSION

IF MMOPT BITS 0, 1, OR 2 IS UP AND SW5 IS ZERO AT STARTUP, THE PROCESSOR TESTS WILL BE CORE EXPANDED THRU ALL AVAILABLE MEMORY UP TO 28K. THE ROUTINE DET1 DOES THIS CORE EXPANSION, COPYING BANK 0 INTO EACH OF THE OTHER BANKS. THE EMT CALL AT THE END OF EACH BANK (EOB) WHICH CALLS THE END OF BANK SERVICE ROUTINE IS CHANGED TO A JUMP TO BEGINX IN THE NEXT BANK. THE EOB CALL IN THE LAST BANK IS LEFT ALONE. IF MMOPT BITS 0 AND 1 WERE BOTH ZERO AT STARTUP, USER PAGES 0 THRU 6 ARE MAPPED SO THAT THE PHYSICAL AND VIRTUAL ADDRESSES CORRESPOND, AND THE PROCESSOR TESTS ARE THEN RUN IN USER. IF BIT0 WAS ZERO BUT BIT1 WAS ONE, KERNEL PAGES 0-6 ARE MAPPED SO THAT THE PHYSICAL AND VIRTUAL ADDRESSES ARE THE SAME, AND THE PROCESSOR TESTS ARE THEN RUN IN KERNEL MODE. IF BIT0 WAS ONE, ORDINARY CORE EXPANSION IS RUN WITH NO SPECIAL MAPPING REQUIRED (MEMORY MGMT. IS TURNED OFF).

5.3.3 PROCESSOR TEST EXECUTION - BANK 0 ONLY

IF BITS 0, 1 OR 2 IS UP AND BIT5 IS UP AT STARTUP, ONLY BANK 0 IS UTILIZED, IN THIS CASE, IF BIT0 AND BIT1 WERE ZERO THE PROCESSOR TESTS ARE EXECUTED IN USER, WITH USER PAGE 0

MAPPED TO BANK 0. IF BIT0 WAS ZERO AND BIT1 WAS ONE, THE PROCESSOR TESTS ARE EXECUTED IN KERNEL, WITH KERNEL PAGE 0 MAPPED TO BANK 0. IF BIT0 WAS ONE, THE MEMORY MGMT. IS TURNED OFF AND THE PROCESSOR TESTS ARE EXECUTED IN KERNEL MODE OR USER MODE (DEPENDING ON BIT1) IN BANK 0 ONLY.

6.0 ERRORS

6.1 ERROR PRINTOUT

PRINTOUTS ARE IN AN EXTENDED VERSION OF THE STANDARD FORMAT, USING THREE WORDS. THE FIRST WORD IS THE OCTAL VALUE OF THE VIRTUAL PC+2 OF THE DETECTED ERROR. THE SECOND WORD IS THE CONTENTS OF THE PROCESSOR STATUS REGISTER WHEN THE ERROR WAS DETECTED. THE THIRD IS THE TOP 12 BITS OF THE 18-BIT ADDRESS OF THE BANK BEING CURRENTLY USED FOR EXECUTION OF THE PROCESSOR TEST. THE FOURTH IS RETURN WHICH IS THE RETURN ADDRESS IN THE CURRENT BANK OF MEMORY. TO GET THE STARTING ADDRESS OF THE CURRENT BANK SIMPLY APPEND TWO ZEROS TO THE END OF THE OCTAL VALUE PRINTED OUT (I.E. 007400 INDICATES THE BANK BEGINNING AT PHYSICAL ADDRESS 740000).

6.2 ERROR RECOVERY

IN GENERAL, TEST FAILURES WILL PRINTOUT AN ERROR MESSAGE AND CONTINUE. IF THE "HALT ON ERROR" SWITCH IS SET, HITTING CONTINUE WILL RECOVER. IF THE PROGRAM HANGS UP IN A LOOP, THE ERROR IS LIKELY TO BE A SIGNAL WHICH WAS NEVER RECEIVED. IF A HALT OCCURS IN THE TRAP AND VECTOR AREA THE PROGRAM MUST BE RESTARTED. IF THE PROGRAM HALTS IN THE MAIN FLOW, CONSULT THE LISTING IF NO MESSAGE IS TYPED OUT. FOR TTY READER AND HSR, TAPE MUST BE REPOSITIONED TO LEADER BEFORE RESTARTING THE TEST.

6.3 FINDING WHICH PROCESSOR TEST WAS BEING EXECUTED WHEN AN ERROR OCCURRED

SOME ERRORS ARE DEPENDENT ON THE PROCESSOR TEST BEING RUN (SUCH AS LATENCY ERRORS WHICH ONLY SHOW UP IN WORST-CASE PROCESSOR TIMING). THE SCOPE ROUTINE CONTAINS A LOCATION CALLED "RETURN" WHICH STORES THE STARTING ADDRESS OF THE PROCESSOR TEST CURRENTLY BEING EXECUTED. NOTE THAT THE SCOPE ROUTINE IS EXECUTED IN USER MODE IF SW1 IS DOWN AT STARTUP, AND IS THEREFORE RELOCATED WITH THE PROCESSOR TESTS. THUS, TO DETERMINE WHICH PROCESSOR TEST WAS BEING EXECUTED WHEN A FAILURE OCCURRED, FIRST CHECK THE CONTENTS OF CURBNK IN BANK 0. THIS LOCATION CONTAINS THE ADDRESS OF THE CURRENT PHYSICAL BANK, SHIFTED RIGHT 6 PLACES. BY APPENDING 2 ZEROES TO IT, YOU HAVE THE 18-BIT ADDRESS OF THE CURRENT BANK OF MEMORY. ADD TO THIS THE ADDRESS OF RETURN IN

BANK 0 AND YOU HAVE THE ADDRESS OF RETURN IN THE CURRENT BANK OF MEMORY. THE CONTENTS OF RETURN IN THE CURRENT BANK OF MEMORY IS THE VIRTUAL ADDRESS OF THE START OF THE CURRENT PROCESSOR TEST.

7.0 RESTRICTIONS

PROGRAM MUST BE LOADED INTO LOWER 4K OF MEMORY.

THE INHIBIT SWITCHES MUST ONLY BE SET FOR ALL DEVICES THAT ARE PART OF THE SYSTEM BUT WHICH YOU DO NOT WISH TO RUN.

IF THE LINE PRINTER IS USED, STARTING ADDRESS 310 MUST BE USED.

8.0 MISCELLANEOUS

8.1 EXECUTION TIME

EXECUTION TIME VARIES WITH THE AMOUNT OF MEMORY, THE TYPES OF MEMORY, AND THE OPTIONAL MODES OF EXECUTION USED.

A PASS RUN WITH CORE EXPANSION AND 4K AS 32K RELOCATION BOTH INHIBITED TAKES LESS THAN 10 SECONDS (RUNNING NO I/O).

A PASS RUN WITH 4K AS 32K, IN CORE MEMORY WITH NO I/O, TAKES ABOUT 5 MINUTES PER 4K BANK. (AN ASTERIK IS PRINTED AT THE END OF A FULL PASS, AND THE BELL IS RUNG AT THE END OF EACH 4K BANK.

ACT11 WITH OPTIONS SET AS DESCRIBED IN SECTION 8.3:

1ST PASS ABOUT 3 SECONDS.
2ND PASS ABOUT 60 SECONDS (TRACE MODE ON).
3RD PASS ABOUT 30 SECONDS (TRACE MODE OFF).

XXDP WITH OPTIONS SET AS DESCRIBED IN SECTION 8.3:

1ST PASS 1 TO 2 SECONDS.
2ND PASS ABOUT 24 SECONDS (TRACE MODE ON).
3RD PASS ABOUT 12 SECONDS (TRACE MODE OFF).

8.2 STACK POINTERS

THE KERNEL STACK POINTER IS INITIALIZED TO 17760.

THE USER STACK POINTER IS INITIALIZED TO 400. IT IS RELOCATED THRU ALL USER PAGES AND TO EVERY 4K BANK IF THE 4K AS 32K MODE OF EXECUTION IS RUN.

8.3 ACT11/XXDP OPERATION

FOUR LOCATIONS ARE USED AS SOFTWARE SWITCHES TO CONTROL PROGRAM OPERATION DURING ACT11 OR XXDP CHAIN MODE OPERATION. THE SOFTWARE SWITCHES CONTENTS ARE USED TO SET SOFTWARE SWITCHES MMOPT AND SREG2, WHICH ARE THE LOCATIONS THAT ARE ROUTINELY CHECKED BY THE PROGRAM TO CONTROL ITS OPERATION.

THE ACT11/XXDP SOFTWARE SWITCHES ARE:

ACTSW1: 40 ;NO CORE EXPANSION.
ACTSW2: 201 ;INHIBIT LPT AND TTY DURING ACT11.

XDPSW1: 46 ;INHIBIT KT11D, NO CORE EXPANSION,NO 4K AS 32
XDPSW2: 1 ;INHIBIT TTY WHILE IN XXDP CHAIN MODE.

SWITCH XDPSW1 MUST ALWAYS BE LEFT WITH THE VALUE 46, AS IF CHANGED, THE PROGRAM WILL NOT FUNCTION UNDER CHAIN MODE.

ALL OTHER SWITCHES MAY BE CHANGED FREELY, ESPECIALLY THE DEVICE SELECTION SWITCHES XDPSW2 AND ACTSW2.

THE LOAD MEDIUM IS NOT EXERCISED BY THE PROGRAM WHEN LOADED V'A TCDP OR RKDP (THAT IS DECTAPE OR RK11 WILL NOT BE EXERCISED THEN).

9.0

PROGRAM DESCRIPTION

THIS MEMORY MANAGEMENT EXERCISER IS DESIGNED TO RUN BACKGROUND PROCESSOR TESTS AND FOREGROUND CONCURRENT I/O WITH MEMORY MANAGEMENT UTILIZED IN ANY OF SEVERAL DIFFERENT MODES. THE VARIOUS MODES AVAILABLE FOR UTILIZING MEMORY MANAGEMENT ARE INCLUDED TO AID IN FAULT ISOLATION BY PROVIDING A SERIES OF STEPS FROM SIMPLE TO COMPLEX. MEMORY MANAGEMENT CAN BE LEFT TURNED OFF AND THE PROCESSOR TESTS CAN STILL BE RUN IN 4K ONLY OR CORE EXPANDED UP TO 28K. WITH MEMORY MANAGEMENT ON, THE PROGRAM CAN BE RUN USING ONLY 4K, WITH EVERYTHING MAPPED IN KERNEL SPACE OR WITH USER AND KERNEL BOTH USED. AT THE NEXT LEVEL OF COMPLEXITY, CORE EXPANSION CAN BE RUN WITH MEMORY MANAGEMENT ON, USING KERNEL ONLY OR USING BOTH MODES AS DESIRED. FINALLY, ALL AVAILABLE MEMORY (IN 4K PIECES) CAN BE UTILIZED BY RUNNING 4K AS 32K. THERE IS NO MONITOR IN THE CONVENTIONAL SENSE. EACH DEVICE THAT IS TO BE EXERCISED HAS ITS OWN STAND ALONE ROUTINE THAT OPERATES IN THE INTERRUPT MODE. THESE ROUTINES NEED NO SUPERVISION OR MONITORING AFTER THEY ARE INITIATED. THERE IS A PRIMER AREA THAT CHECKS THE SWITCH REGISTER TO SEE WHAT DEVICES ARE TO BE INITIATED. IT SETS THE INTERRUPT ENABLE BIT IN THE DEVICE STATUS REGISTER, INITIALIZES THE DATA PATTERN, AND INITIATES AN OPERATION TO RAISE DATA FLAGS ON DEVICES THAT CAN NOT INITIATE THEM THEMSELVES. THE PRIMER CODE THEN ENTERS THE MEMORY MANAGEMENT SETUP CODE. THE RF11 AND TC11 PRIMER CODE IS IN WITH THE MEMORY MANAGEMENT SETUP CODE SINCE THEY REQUIRE CERTAIN PARTS OF THE MEMORY MANAGEMENT CODE TO BE RUN FIRST. AFTER MEMORY MANAGEMENT IS TURNED ON, EXECUTION OF THE BACKGROUND PROCESSOR TESTS BEGINS, AND THE I/O DEVICES ARE SERVICED WHEN THEY INTERRUPT.

```
561 .NLIST MC,CND,MD,TOC
562 .TITLE CFKTC 11/34 MEM MGMT
563 .ABS
564 .DSABL ERFZ
565
566
567 ;THIS PROGRAM IS A MODIFICATION OF THE 11/40 DIAGNOSTIC, DBKTG.
568 ;THIS TEST HAS BEEN MODIFIED TO PROVIDE SOFTWARE SWITCH CAPABILITY
569 ;AND TO ACCOUNT FOR ANY 11/34-11/40 DIFFERENCES.
570 ;THIS PROGRAM IS INTENDED FOR USE ON ONLY 11/34 PROCESSORS
571 ;*****
572 ;SBITL OPERATING INSTRUCTIONS
573 ;*****
574 ;PDP11/34 SYSTEM EXERCISER, WITH MEMORY MGMT. --- TTY,PC11,KW11-L
575 ;LP11,RF11,TC11
576 ;TEST SIMULTANEOUS RUNNING OF I/O, WITH PROCESSOR INSTRUCTION TEST AND
577 ;WITH TRACE BIT ENABLED TO BE CONSIDERED MAINLINE CODE
578
579 ;I/O RUNS IN KERNEL MODE
580 ;CPU TESTS RUN IN USER MODE UNLESS INHIBITED BY SR SETTINGS
581 ;MEMORY MANAGEMENT IS UTILIZED
582
583 ;(R6) IS THE STACK POINTER
584 ;((R6)) IS THE PC+2 OF LOCATION WHERE THE TRAP ORIGINATED
585 ;FOR NORMAL OPERATION RUN WITH ALL SWITCHES DOWN
586 ;SA - 200
587 ;RESTART - 310 (SR SETTINGS PREVIOUSLY MADE ARE USED)
588
589 ;AT STARTUP, MMOPT (LOC. 174) SETTINGS ARE:
590 ;MMOPT BIT 0=1 OR UP --- RUN WITHOUT MEMORY MGMT.
591 ;MMOPT BIT 1=1 OR UP --- RUN ALL IN KERNEL MODE (INHIBITS RUNNING 4K AS 32K)
592 ;MMOPT BIT 2=1 OR UP --- INHIBIT RUNNING 28K USER MEMORY MGMT. FROM EVERY 4K
593 ;BANK (ALLOW NORMAL CORE EXPANSION)
594 ;MMOPT BIT 5=1 OR UP---INHIBIT VARIABLE CORE EXPANSION
595
596 ;SR (USE LOC. 176 IF NECESSARY), BIT SETTINGS ARE:
597 ;SR 15=1 OR UP---HALT ON ERROR
598 ;SR 14=1 OR UP---SCOPE LOOP
599 ;SR 13=1 OR UP---INHIBIT PRINT OUT
600 ;SR 12=1 OR UP---INHIBIT TRACE TRAPPING
601 ;SR 11=1 OR UP---INHIBIT SUB-PROGRAM ITERATION AND INHIBIT TESTS WHICH
602 ;USE ALL COMBINATIONS OF NUMBERS
603 ;SR 10=1 OR UP---INHIBIT PROCESSOR TEST
604
605 ;SPECIAL DELETE SWITCHES-SET RESPECTIVE SWITCH TO INHIBIT
606 ;INITIATION OF DEVICE
607 ;SW 0=1 INHIBIT TTY OUTPUT
608 ;SW 3=0 INHIBIT RK11 DISK
609 ;SW 4=0 INHIBIT LINE CLOCK
610 ;SW 5=0 INHIBIT RF11 DISK
611 ;SW 6=0 INHIBIT TC11 DECTAPE
612 ;SW 7=0 INHIBIT LINE PRINTER
613
614
```

REVISION HISTORY

- 615
 - 616
 - 617
 - 618
 - 619
 - 620
 - 621
 - 622
 - 623
 - 624
 - 625
-
1. TITLE CHANGED FROM DFKTGB TO CFKTC
 2. LOCATION CHGC6 INSTRUCTION CHANGED FROM (BIT SR,#20000) TO (BIT @SR,#20000) TEST FOR INHIBIT PRINTOUT. LOOKS AT SWITCH REGISTER SETTINGS.
 3. LOCATION CHGC7 INSTRUCTION CHANGED FROM (TST SR) TO (TST @SR) TEST FOR HALT ON ERROR. LOOKS AT SWITCH REGISTER SETTINGS.
 4. LOCATIONS CHGC1 THRU CHGC5 CHANGED FROM BNE TO BEQ INSTRUCTION.
 5. INSTRUCTIONS ON SETTING SR CHANGED FROM 1 TO 0 ON BITS 3,4,5,6,7 TO INHIBIT OPERATION OF THE DEVICE EACH BIT CONTROLS.
-

626 000000 001440
 627 000002 001526
 628 000004 001572
 629 000006 001670
 630 000010 001730
 631 000012 015706
 632 000014 016036

CHGC1
 CHGC2
 CHGC3
 CHGC4
 CHGC5
 CHGC6
 CHGC7

.....
 :SBTTL DEFINITIONS
 :.....

633
 634
 635
 636
 637 000240
 638 104400
 639 000410
 640 000412
 641 177776
 642 104006
 643 104010
 644 000000
 645 000001
 646 000002
 647 000003
 648 000004
 649 000005
 650 000006
 651 000006
 652 000007
 653

NOP=240 ;SYSTEM NULL OPERATION
 SCOPE=TRAP ;TRAP USED SCOPE LOOP AND ITERATION
 TCSR=TTCSR
 TDBR=TTDBR
 PSR=177776
 HLT=104006 ;ERROR PRINTOUT CALL
 EOB=104010 ;END OF BANK CALL
 R0=%0
 R1=%1
 R2=%2
 R3=%3
 R4=%4
 R5=%5
 SP=%6
 R6=SP
 PC=%7

Address	Value	Label	Description
654			
655		SBTTL	TRAP CATCHER
656			
657	000000	.	0
658	000000	.+2	TRAP ENTRANCE
659	000002	HALT	TRAPPED TO PREVIOUS LOCATION
660	000004	.+2	TRAP ENTRANCE
661	000006	HALT	TRAPPED TO PREVIOUS LOCATION
662	000010	.+2	TRAP ENTRANCE
663	000012	HALT	TRAPPED TO PREVIOUS LOCATION
664	000014	.+2	TRAP ENTRANCE
665	000016	HALT	TRAPPED TO PREVIOUS LOCATION
666	000020	.+2	TRAP ENTRANCE
667	000022	HALT	TRAPPED TO PREVIOUS LOCATION
668	000024	.+2	TRAP ENTRANCE
669	000026	HALT	TRAPPED TO PREVIOUS LOCATION
670	000030	.+2	TRAP ENTRANCE
671	000032	HALT	TRAPPED TO PREVIOUS LOCATION
672	000034	.+2	TRAP ENTRANCE
673	000036	HALT	TRAPPED TO PREVIOUS LOCATION
674	000040	.+2	TRAP ENTRANCE
675	000042	HALT	TRAPPED TO PREVIOUS LOCATION
676	000044	.+2	TRAP ENTRANCE
677	000046	HALT	TRAPPED TO PREVIOUS LOCATION
678	000050	.+2	TRAP ENTRANCE
679	000052	HALT	TRAPPED TO PREVIOUS LOCATION
680	000054	.+2	TRAP ENTRANCE
681	000056	HALT	TRAPPED TO PREVIOUS LOCATION
682	000060	.+2	TRAP ENTRANCE
683	000062	HALT	TRAPPED TO PREVIOUS LOCATION
684	000064	.+2	TRAP ENTRANCE
685	000066	HALT	TRAPPED TO PREVIOUS LOCATION
686	000070	.+2	TRAP ENTRANCE
687	000072	HALT	TRAPPED TO PREVIOUS LOCATION
688	000074	.+2	TRAP ENTRANCE
689	000076	HALT	TRAPPED TO PREVIOUS LOCATION
690	000100	.+2	TRAP ENTRANCE
691	000102	HALT	TRAPPED TO PREVIOUS LOCATION
692	000104	.+2	TRAP ENTRANCE
693	000106	HALT	TRAPPED TO PREVIOUS LOCATION
694	000110	.+2	TRAP ENTRANCE
695	000112	HALT	TRAPPED TO PREVIOUS LOCATION
696	000114	.+2	TRAP ENTRANCE
697	000116	HALT	TRAPPED TO PREVIOUS LOCATION
698	000120	.+2	TRAP ENTRANCE
699	000122	HALT	TRAPPED TO PREVIOUS LOCATION
700	000124	.+2	TRAP ENTRANCE
701	000126	HALT	TRAPPED TO PREVIOUS LOCATION
702	000130	.+2	TRAP ENTRANCE
703	000132	HALT	TRAPPED TO PREVIOUS LOCATION
704	000134	.+2	TRAP ENTRANCE
705	000136	HALT	TRAPPED TO PREVIOUS LOCATION
706	000140	.+2	TRAP ENTRANCE
707	000142	HALT	TRAPPED TO PREVIOUS LOCATION
708	000144	.+2	TRAP ENTRANCE
709	000146	HALT	TRAPPED TO PREVIOUS LOCATION

710	000150	000152	.+2	:TRAP ENTRANCE
711	000152	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
712	000154	000156	.+2	:TRAP ENTRANCE
713	000156	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
714	000160	000162	.+2	:TRAP ENTRANCE
715	000162	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
716	000164	000166	.+2	:TRAP ENTRANCE
717	000166	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
718	000170	000172	.+2	:TRAP ENTRANCE
719	000172	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
720	000174	000176	.+2	:TRAP ENTRANCE
721	000176	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
722	000200	000202	.+2	:TRAP ENTRANCE
723	000202	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
724	000204	000206	.+2	:TRAP ENTRANCE
725	000206	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
726	000210	000212	.+2	:TRAP ENTRANCE
727	000212	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
728	000214	000216	.+2	:TRAP ENTRANCE
729	000216	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
730	000220	000222	.+2	:TRAP ENTRANCE
731	000222	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
732	000224	000226	.+2	:TRAP ENTRANCE
733	000226	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
734	000230	000232	.+2	:TRAP ENTRANCE
735	000232	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
736	000234	000236	.+2	:TRAP ENTRANCE
737	000236	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
738	000240	000242	.+2	:TRAP ENTRANCE
739	000242	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
740	000244	000246	.+2	:TRAP ENTRANCE
741	000246	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
742	000250	000252	.+2	:TRAP ENTRANCE
743	000252	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
744	000254	000256	.+2	:TRAP ENTRANCE
745	000256	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
746	000260	000262	.+2	:TRAP ENTRANCE
747	000262	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
748	000264	000266	.+2	:TRAP ENTRANCE
749	000266	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
750	000270	000272	.+2	:TRAP ENTRANCE
751	000272	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
752	000274	000276	.+2	:TRAP ENTRANCE
753	000276	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
754	000300	000302	.+2	:TRAP ENTRANCE
755	000302	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
756	000304	000306	.+2	:TRAP ENTRANCE
757	000306	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
758	000310	000312	.+2	:TRAP ENTRANCE
759	000312	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
760	000314	000316	.+2	:TRAP ENTRANCE
761	000316	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
762	000320	000322	.+2	:TRAP ENTRANCE
763	000322	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
764	000324	000326	.+2	:TRAP ENTRANCE
765	000326	000000	HALT	:TRAPPED TO PREVIOUS LOCATION

766	000330	000332	.+2	:TRAP ENTRANCE
767	000332	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
768	000334	000336	.+2	:TRAP ENTRANCE
769	000336	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
770	000340	000342	.+2	:TRAP ENTRANCE
771	000342	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
772	000344	000346	.+2	:TRAP ENTRANCE
773	000346	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
774	000350	000352	.+2	:TRAP ENTRANCE
775	000352	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
776	000354	000356	.+2	:TRAP ENTRANCE
777	000356	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
778	000360	000362	.+2	:TRAP ENTRANCE
779	000362	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
780	000364	000366	.+2	:TRAP ENTRANCE
781	000366	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
782	000370	000372	.+2	:TRAP ENTRANCE
783	000372	000000	HALT	:TRAPPED TO PREVIOUS LOCATION
784	000374	000376	.+2	:TRAP ENTRANCE
785	000376	000000	HALT	:TRAPPED TO PREVIOUS LOCATION

.....
 :SBTTL LOAD VECTOR AREA
 :.....

790		000C24	.=24	
791	000024	016370	PFAIL	:POWER FAIL TRAP
792	000026	000340	340	
793		000030	.=30	
794	000030	015072	EMTSRV	:EMT CALLS
795	000032	000340	340	:HIGHEST PRIORITY
796		000034	.=34	
797	000034	014570	SCOPEC	:USER TRAP
798	000036	000000	0	
799		000040	.=40	:LOAD MEDIUM INDICATOR.
800	000040	000000	0	:LOADS AS 0.
801		000042	.=42	:AUTOMATIC MODE INDICATOR.(ACT11/XXDP).
802	000042	000000	0	:ZERO AT LOAD TIME.
803		000046	.=46	:POINTER TO LOGICAL END.
804	000046	015640	\$ENDAD	
805		000052	.=52	:PROGRAM ATTRIBUTES WORD.
806	000052	040000	40000	
807		000174	.=174	
808	000174	000000	MMOPT: 0	:MEMORY MANAGEMENT OPTION SEL.
809	000176	000000	SWREG: 0	:SOFTWARE SWITCH REG.
810		000176	SREG2=SWREG	

.....
 :SBTTL LOAD STARTING AREA
 :.....

816		000200	.=200	
817	000200	000137	JMP @#START	000664
818		000300	.=300	
819	000300	000137	JMP @#START	000664
820		000310	.=310	
821	000310	000137	JMP @#RSTRT	000634


```

822
823
824
825
826      000400      000400
827      000400      000000      UBUFF: 0
828      000406      000406      =400
829      000406      177560      TRCSR: 177560      ;BUFFER FOR USER SP
830      000410      177564      TTCSR: 177564      ;FOR STACK OVERRUN
831      000412      177566      TTDBR: 177566      ;TTY READER STATUS REGISTER
832      000414      000064      TTPVC: 64
833      000416      000066      TTPST: 66
834      000420      000000      TTSAV: 0
835      000422      000100      KWLVC: 100
836      000424      000102      KWLST: 102
837      000426      177546      LKCSR: 177546
838      000430      177514      LPCSR: 177514
839      000432      177516      LPDBR: 177516
840      000434      000200      LPVC: 200
841      000436      000202      LPST: 202
842      000440      177470      RFDAR: 177470      ;DISK ADDRESS AND ERROR
843      000442      177466      RFDAR: 177466      ;DISK ADDRESS REGISTER
844      000444      177462      RFWC: 177462      ;WORD COUNT REGISTER
845      000446      177464      RFCAR: 177464      ;CURRENT ADDRESS REGISTER
846      000450      177460      RFCSR: 177460      ;STATUS REGISTER
847      000452      177461      RFCSRH: 177461      ;HIGH BYTE ADDRESS OF CSR
848      000454      000204      RFVC: 204
849      000456      000206      RFST: 206
850      000460      177413      RKDAH: 177413      ;HIGH BYTE DISK ADR
851      000462      177412      RKDAE: 177412      ;DISK ADDRESS REGISTER
852      000464      177406      RKWC: 177406      ;WORD COUNT REGISTER
853      000466      177410      RKBAR: 177410      ;CURRENT ADDRESS REGISTER
854      000470      177404      RKCSR: 177404      ;STATUS REGISTER
855      000472      177405      RKCSRH: 177405      ;HIGH BYTE OF CSR
856      000474      000220      KKVC: 220
857      000476      000222      RKST: 222
858      000500      177572      SR0: 177572      ;MEMORY MANAGEMENT REGISTER
859      000502      177600      UPDR0: 177600
860      000504      177602      UPDR1: 177602
861      000506      177616      UPDR7: 177616
862      000510      177640      UPAR0: 177640
863      000512      177642      UPAR1: 177642
864      000514      177656      UPAR7: 177656
865      000516      172300      KPDR0: 172300
866      000520      172302      KPDR1: 172302
867      000522      172304      KPDR2: 172304
868      000524      172316      KPDR7: 172316
869      000526      172340      KPAR0: 172340
870      000530      172342      KPAR1: 172342
871      000532      172344      KPAR2: 172344
872      000534      172356      KPAR7: 172356
873
874      000536      177600      IPDRTAB: 177600
875      000540      177640      177640
876      000542      172300      172300
877      000544      172340      IPDREND: 172340
    
```

878	000546	177570	SR:	177570	:SWITCH REGISTER POINTER
879	000550	177571	SRH:	177571	:HIGH BYTE OF SW. REG. POINTER
880	000552	177342	TCCM:	177342	:CONTROL AND FUNCTION
881	000554	177340	TCST:	177340	:GENERAL STATUS
882	000556	177350	TCDT:	177350	:DATA
883	000560	177344	TCWC:	177344	:WORD COUNT
884	000562	177346	TCBA:	177346	:BUS ADDRESS
885	000564	000214	TCIV:	214	:DECTAPE INTERRUPT VECTOR
886	000566	000216	TCSTA:	216	
887	000570	000000	CURBNK:	0	:SAF TO POINT TO CURRENT BANK
888	000572	000000	OLDBNK:	0	
889	000574	000000	CURPAR:	0	:ADDRESS OF CURRENT ISAR
890	000576	000000	CURPDR:	0	
891	000600	000000	BNKSTR:	0	: PC TO POINT TO BEGIN THRU CURRENT SEGMENT
892	000602	000000	TRPB:	0	
893			:THE NEXT TWO WORDS ARE THE MEMORY MAP. THE FIRST WORD REPRESENTS		
894			:0-64K WITH ONE BIT REPRESENTING A 4K CONTIGUOUS BLOCK. IF THE		
895			:BIT=1 THAT 4K BLOCK IS PRESENT. THE LSB REPRESENTS 0-4K, THE NEXT		
896			:SIGNIFICANT BIT REPRESENTS 4-8K ANS SO ON.		
897	000604	177777	MEMO:	177777	:0-64K
898	000606	077777	MEM1:	77777	:64-124K
899	000610	000001	COREPT:	1	
900	000612	000604	MEMUT:	MEMO	
901	000614	000000	TBANK:	0	
902	000616	000000	REFF:	0	
903	000620	000000	TEST:	0	

```

:.....
:SBTTL FILLCT, ACT11, XSDP SOFTWARE SWITCHES
:.....
FILLCT: 14           :CONSOLE FILL COUNT.
ACTSW1: 40          :NO CORE EXPANSION.
ACTSW2: 201        :NO LP, NO TTY.
XSDPSW1: 46         :NO CORE EXPANSION, NO 4 AS 32, ETC.
XSDPSW2: 1          :NO TTY.

```

```

:.....
:SBTTL RESTART ADD USING INITIAL SR SETTINGS
:.....
RSTRT:  MOV    #KSTACK,R6
        MOV    #PFAIL,@#24
        TST   @#42           :IN AUTO MODE? (ACT11/XSDP)
        BNE   START2        :BR IF YES.
        MOVB  @SRH,@#SREG2+1 :UPDATE DYNAMIC SWITCH SETTINGS.
        BR    START2

```

```

:.....
:SBTTL START UP FOR MINI MONITOR - NORMAL START FROM LOC 00020C
:.....
START:  MOV    #KSTACK,R6   :SET UP STACK
        MOV    #137,@#200   :RESTORE 200 IF START AT 300
        MOV    #START,@#20?
        CLR   TRPB          :NO TRACE IN FIRST PASS.
        CLR   PASCNT        :CLEAR THE PASS COUNTER.
        MOV   @#4,-(SP)     :SAVE ERROR VECTOR

```

```

934 000720 013746 000006      MOV      @#6,-(SP)
935 000724 012767 000740 177052  MOV      #15,4          ;SET UP TIME OUT VECTOR
936 000732 005777 177610      TST      @SR           ;TRY TO REFERENCE HARDWARE SW. REG.
937 000736 000404          BR       2$           ;BRANCH IF NO TIMEOUT TRAP OCCURS
938 000740 012767 000176 177600 1$:  MOV      #SWREG,SR     ;POINT TO SOFTWARE SW. REG.
939 000746 022626          CMP      (SP)+,(SP)+  ;RESTORE STACK
940 000750 016767 177572 177572 2$:  MOV      SR,SRH
941 000756 005267 177566          INC      SRH
942 000762 012637 000006          MOV      (SP)+,@#6     ;RESTORE ERROR VECTOR
943 000766 012637 000004          MOV      (SP)+,@#4
944 000772 005737 000042          TST      @#42         ;IN AUTOMATIC TEST MODE?
945 000776 001422          BEQ     STARTX       ;BR IF NOT IN AUTOMATIC MODE.
946 001000 023727 000042 015640  CMP      @#42,#SENDAD ;IN ACT11 MODE?
947 001006 001007          BNE     3$           ;BR IF NOT.
948 001010 016737 177610 000174  MOV      ACTSW1,@MMOPT ;YES. SET MMOPT FROM ACTSW1.
949 001016 016737 177604 000176  MOV      ACTSW2,@SREG2 ;SET SREG2 FROM ACTSW2.
950 001024 000412          BR      START1
951 001026 016737 177576 000174 3$:  MOV      XDPSW1,@MMOPT ;XDP MODE. SET MMOPT FROM XDPSW1.
952 001034 016737 177572 000176  MOV      XDPSW2,@SREG2 ;SET SREG2 FROM XDPSW2.
953 001042 000403          BR      START1
954 001044          STARTX:
955 001044 017737 177476 000176  MOV      @SR,@SREG2
956 001052          START1:
957 001052 004767 013752          START2: JSR      %7,NRALL
958 001056 012777 077406 177432  MOV      #77406,@KPDR0
959 001064 012777 007600 177442  MOV      #7600,@KPAR7   ;MAP PAGE 7 TO EXT BANK
960 001072 012777 077406 177424  MOV      #77406,@KPDR7
961 001100 005067 177510          CLR     TBANK
962 001104 012767 177777 177472  MOV      #177777,MEMO   ;SET UP CORE MAPS
963 001112 012767 077777 177466  MOV      #77777,MEM1
964 001120 012767 000001 177462  MOV      #1,COREPT      ;SET UP 4K POINTER
965 001126 012767 000604 177456  MOV      #MEMO,MEMUT
966 001134 012777 077406 177360  MOV      #77406,@KPDR2 ;BEING CHECKED FOR
967 001142 012737 001212 000004  MOV      #TMEMEX,@#4   ;SET UP FOR TIME OUTS
968 001150 005037 000006          CLR     @#6
969 001154 052777 000001 177316  BIS     #1,@SRO
970 001162 016777 177426 177342  MAP1:  MOV      TBANK,@KPAR2  ;MAP KERNEL PAGE 2 TO BANK
971 001170 005737 041000          TST     @#41000       ;1ST K PRESENT
972 001174 005737 045000          TST     @#45000       ;2ND K PRESENT
973 001200 005737 051000          TST     @#51000       ;3RD K PRESENT
974 001204 005737 055000          TST     @#55000       ;4TH K PRESENT
975 001210 000404          BR      MOVEPT       ;OK. FULL 4K BLOCK PRESENT
976 001212 046777 177372 177372  TMEMEX: BIC     COREPT,@MEMUT ;NO. BLOCK NOT PRESENT
977 001220 022626          CMP     (SP)+,(SP)+  ;ADJUST STACK POINTER
978 001222 062767 000200 177364  MOVEPT: ADD     #200,TBANK ;UPDATE BANK POINTER
979 001230 006367 177354          ASL     COREPT
980 001234 103006          BCC     MAP2         ;THIS 1ST MEM WORD DONE
981 001236 012767 000001 177344  MOV      #1,COREPT
982 001244 012767 000606 177340  MOV      #MEM1,MEMU1
983 001252 022767 007600 177334  MAP2:  CMP     #7600,TBANK  ;EXTERNAL BANK YET
984 001260 001340          BNE     MAP1         ;NO,NOT YET?
985 001262 012767 000001 177320  MOV      #1,COREPT     ;RE-INIT
986 001270 012767 000604 177314  MOV      #MEMO,MEMUT
987 001276 042777 000001 177174  BIC     #1,@SRO
988 001304 012737 014570 000034  MOV      #SCOPEC,@#34
989 001312 005037 000036          CLR     @#36          ;INITIALIZE SCOPE CALL TO KERNEL
  
```

```

990 001316 012737 015072 000030      MOV    #EMTSRV,@#30
991 001324 012737 000340 000032      MOV    #340,@#32
992 001332 012737 005542 014704      MOV    #BEGIN,@RETURN
993 001340 012737 000340 177776      MOV    #340,@#PSR          ;LOCK OUT INTERRUPTS
994 001346 005037 016060          CLR    @#PRTON             ;PRINT ROUTINE BUSY FLAG
995 001352 000005          RESET
996 001354 012737 002404 000004      MOV    #NODEV,@#4         ;RETURN FOR NO DEVICE
997 001362 005037 000006          CLR    @#6
998
999
1000
1001 001366 005067 001464          CLR    DATA2             ;BASE DATA FOR TTY TELEPRINTER
1002 001372 033727 000176 000001      BIT    @#SREG2,#1         ;INHIBIT TTY OUTPUT?
1003 001400 001006          BNE    ST3                ;YES, GO CHECK NEXT.
1004 001402 012777 003070 177004      MOV    #TYOUTR,@TTPVC     ;NO, SETUP INTERRUPT VECTOR
1005 001410 052777 000100 176772      BIS    #100,@TTCR        ;START TTY OUTPUT
1006
1007
1008
1009 001416 012700 000010      ST3:  MOV    #10,RO
1010 001422 122737 000002 000041      CMPB   #2,@#41           ;LOAD MEDIUM RK11?
1011 001430 001432          BEQ    ST4                ;BR IF YES, DON'T USE RK11 THEN.
1012 001432 032737 000010 000176      BIT    #10,@#SREG2       ;INHIBIT RK DISK
1013
1014 001440 001426          CHGC1: BEQ    ST4           ;YES, SKIP OVER
1015
1016 001442 005777 177022          TST    @RKCSR            ;PRESENT
1017 001446 012777 003466 177020      MOV    #1RK,@RKVC        ;SETUP VECTOR RETURNS
1018 001454 012777 000240 177014      MOV    #240,@RKST        ;PRIORITY 5 SERVICE.
1019 001462 012767 043503 002040      MOV    #43503,RKFUNCT
1020 001470 005077 176766          CLR    @RKDAE            ;INIT
1021 001474 016777 002170 176764      MOV    LLIMIT,@RKBAR     ;CORE BASE
1022 001502 016777 002164 176754      MOV    WORDCT,@RKWC      ;TRANSFER LENGTH
1023 001510 116777 002014 176752      MOVB   RKFUNCT,@RKCSR
1024
1025
1026
1027 001516 006300          ST4:  ASL    RO
1028 001520 033727 000176 000020      BIT    @#SREG2,#20       ;INHIBIT LINE CLOCK?
1029
1030 001526 001415          CHGC2: BEQ    ST5         ;YES, GO CK NEXT
1031
1032 001530 005777 176672          TST    @LKCSR            ;PRESENT
1033 001534 012777 003146 176660      MOV    #LK3,@KWLVC
1034 001542 012777 000300 176654      MOV    #300,@KWLST
1035 001550 005067 001466          CLR    TIME              ;NO, INITIALIZE COUNT
1036 001554 052777 000100 176644      BIS    #100,@LKCSR       ;START LINE CLOCK
1037
1038
1039
1040 001562 006300          ST5:  ASL    RO
1041 001564 033727 000176 000040      BIT    @#SREG2,#40       ;TEST FOR INHIBITING RF11 DISK
1042
1043 001572 001426          CHGC3: BEQ    ST6         ;SKIP IF SET
1044
1045 001574 005777 176650          TST    @RFCSR            ;PRESENT?
    
```

```

1046 001600 012777 003562 176646      MOV    #1RF,@RFVC          ;SET UP TRAP RETURN
1047 001606 012777 000240 176642      MOV    #240,@RFST
1048 001614 012767 043503 002044      MOV    #43503,RFFUNCT     ;WRITE CHECK/WRITE
1049 001622 105277 176624              INCB   @RFCSR             ;INITIALIZE DISK-DAR,DAE
1050 001626 016777 002040 176610      MOV    WORDCT,@RFWC       ;LENGTH OF TRANSFER
1051 001634 016777 002030 176604      MOV    LLIMIT,@RFCAR      ;CORE ADDRESS OF START OF TRANSFER
1052 001642 116777 002020 176600      MOVB   RFFUNCT,@RFCSR     ;START RFI1 READ OR WRITE
1053                                     ;.....
1054      .SBTTL TC11 INIT
1055                                     ;.....
1056 001650 006300                      ST6:   ASL    R0
1057 001652 122737 000001 000041      CMPB   #1,@#41           ;LOAD MEDIUM DECTAPE?
1058 001660 001417                      BEQ    ST7               ;BR IF YES. DON'T USE IT THEN.
1059 001662 033727 000176 000100      BIT    @#SREG2,#100     ;CHECK FOR INHIBITING TC11 DECTAPE
1060                                     ;.....
1061 001670 001413                      CHGC4: BEQ    ST7         ;SKIP IF SET
1062                                     ;.....
1063 001672 005777 176656              TST    @TCST             ;PRESENT?
1064 001676 012777 003702 176660      MOV    #FENDZ,@TCIV      ;GO TO END ZONE ON INTERRUPT
1065 001704 012777 000300 176654      MOV    #300,@TCSTA
1066 001712 012777 004503 176632      MOV    #R+IE+RB+DO,@TCM  ;START REVERSE READ BLOCK NUMBER
1067                                     ;.....
1068      .SBTTL LINE PRINTER INIT
1069                                     ;.....
1070 001720 006300                      ST7:   ASL    R0
1071 001722 033727 000176 000200      BIT    @#SREG2,#200     ;INHIBIT LINE PRINTER?
1072                                     ;.....
1073 001730 001432                      CHGC5: BEQ    ST8         ;YES, GO CK NEXT
1074                                     ;.....
1075 001732 005777 176472              TST    @LPCSR            ;PRESENT?
1076 001736 012737 002016 000004      MOV    #ST8,@#4         ;DON'T CHANGE 200 IF NO SUCH DEVICE
1077 001744 012767 000137 001274      MOV    #137,SOLPAT       ;RESET FOR START OF LINE PATTERN
1078 001752 012767 000117 001360      MOV    #79,CLINCT        ;LINE COUNT
1079 001760 012767 000137 001262      MOV    #137,CURPAT
1080 001766 012777 000014 176436      MOV    #14,@LPDBR        ;LINE FEED TO POSITION BUFFER
1081 001774 012777 003270 176432      MOV    #LPINTR,@LPVC     ;INTERRUPT ENABLE
1082 002002 012777 000200 176426      MOV    #200,@LPST        ;PROCESSOR LEVEL 4
1083 002010 012777 000100 176412      MOV    #100,@LPCSR       ;INTERRUPT ENABLE
1084                                     ;.....
1085      .SBTTL PRE-PASS SETUP
1086                                     ;.....
1087 002016 005037 000006                      ST8:   CLR    @#6         ;CHANGE ADDRESS ERROR VECTOR TO CAUSE
1088 002022 012737 000006 000004      MOV    #6,@#4           ;HALT ON A TRAP TO 4
1089 002030 004767 000370                      JSR    #7,DETI          ;CHECK FOR CORE EXPANSION
1090 002034 032737 000001 000174      BIT    #1,@#MMOPT       ;INHIBIT MEMORY MGMT?
1091 002042 001106                      BNE    MODE             ;YES - GO SETUP USER
1092 002044 004767 012760                      JSR    #7,NRALL         ;NO - MAKE ALL SEGMENTS INITIALLY NON-RESIDENT
1093 002050 012777 077406 176446      MOV    #77406,@KPCR7
1094 002056 012777 007600 176450      MOV    #7600,@KPAR7
1095 002064 032737 000006 000174      BIT    #6,@#MMOPT       ;INHIBIT USER/KERNEL OR 4K AS 32K?
1096 002072 001415                      BEQ    SEGM1            ;NO - BRANCH
1097 002074 012701 000007                      MOV    #7,R1            ;YES - MAP KERNEL ASR'S 0-6 TO PA
1098 002100 016702 176422                      MOV    <PAR0,R2
1099 002104 005003                      CLR    R3
1100 002106 010312                      SETEX: MOV   R3,@R2
1101 002110 012762 077406 177740      MOV    #77406,-40(R2)
    
```

```

1102 002116 005722          TST      (R2)+
1103 002120 062703 000200  ADD      #200,R3
1104 002124 077110          SOB      R1,SETEX
1105 002126 012777 077406 176362 SEGMI:  MOV      #77406,@KPDRO ;MAP KERNEL 0 TO BANK 0, RW
1106 002134 032737 000004 000174  BIT      #4,@MMOPI ;INHIBIT RUNNING 4K AS 32K?
1107 002142 001416          BEQ      USEALL ;NO, SETUP FOR RUNNING 4K AS 32K
1108 002144 012701 000010  MOV      #10,R1 ;YES, MAP ALL USER ASR'S TO PA
1109 002150 016702 176334  MOV      UPARO,R2
1110 002154 005003          CLR      R3
1111 002156 010312          SETUSE: MOV      R3,(R2)
1112 002160 062703 000200  ADD      #200,R3
1113 002164 012762 077406 177740  MOV      #77406,-40(R2)
1114 002172 005722          TST      (R2)+
1115 002174 077110          SOB      R1,SETUSE
1116 002176 000425          BR       SETSEG
1117 002200 012777 077406 176274 USEALL: MOV      #77406,@UPDRO ;MAP USER ASRO TO BANK 0, RW
1118 002206 012737 000000 000570  MOV      #0,@CURBNK ;CURRENT SAR CONTENTS
1119 002214 012767 000001 176366  MOV      #1,COREPT ;INIT MAP POINTERS
1120 002222 012767 000604 176362  MOV      #MEMO,MEMUT
1121 002230 016767 176254 176336  MOV      UPARO,CURPAR ;CURRENT SEGMENT REGISTER ADDRESSES
1122 002236 016767 176240 176332  MOV      UPDRO,CURPDR
1123 002244 012767 005542 176326  MOV      #BEGIN,BNKSTR ;CURRENT STARTING PC
1124 002252 052777 000001 176220 SETSEG: BIS      #1,@SRO ;SET MEM MGMT ENABLE BIT
1125 002260 005767 176316  MODE:  TST      TRPB ;USE TRACE MODE?
1126 002264 001406          BEQ      1$ ;BR IF NOT.
1127 002266 012737 015662 000014  MOV      #TRRP,@#14 ;SET UP TRACE TRAP VECTOR.
1128 002274 012746 000020          MOV      #20,-(SP) ;ALLOW TRACE MODE.
1129 002300 000406          BR       2$
1130 002302 012737 000016 000014 1$:  MOV      #16,@#14 ;NO TRACE MODE . RESET THE VECTOR.
1131 002310 005037 000016          CLR      @#16
1132 002314 005046          CLR      -(SP) ;INSURE NO TRACE WILL BE ENABLED.
1133 002316 012746 002324 2$:  MOV      #3$,-(SP) ;CONTINUE AT 3$.
1134 002322 000002          RTI     ;DO IT NOW.
1135 002324 032737 000002 000174 3$:  BIT      #2,@MMOPI ;INHIBIT USER/KERNEL?
1136 002332 001016          BNE     MAIN+2 ;YES - SKIP OVER
1137 002334 052737 140000 000036  BIS      #140000,@#36 ;SET USER BIT IN SCOPE STATUS
1138 002342 012746 000400          MOV      #UBUFF,-(R6)
1139 002346 052737 030000 177776  BIS      #30000,@PSR
1140 002354 006606          MTP1    SP ;SET UP USER STACK
1141 002356 012737 140000 177776  MOV      #140000,@PSR ;CHANGE TO USER
1142 002364 000401          BR      .+4
1143 002366 000001          MAIN:  WAIT
1144 002370 033727 000176 002000  BIT      @#SREG2,#2000 ;INHIBIT PROCESSOR TEST
1145 002376 001373          BNE     MAIN
1146 002400 000167 003136          JMP     BEGIN
1147
1148 ;.....
1149 ;SBTTL NON-EXISTING DEVICE SERVICE
1150 ;.....
1151 002404 050037 000176          NODEV: BIS      R0,@#SREG2 ;SET INHIBIT BIT
1152 002410 162716 000006          SUB      #6,(SP) ;ALTER PC RETURN
1153 002414 042766 000017 000002  BIC      #17,2(SP) ;CLEAR Z BIT ON STACK
1154 002422 000002          RTI
1155
1156 ;.....
1157 ;SBTTL PDP-11 MEMORY DETERMINATION AND SETUP
    
```

```

1158 ;*****
1159 ;USE WITH VARIABLE CORE QUANTITY SYSTEMS/
1160 002424 012767 104610 012074 DET1: MOV #EOB,DONE ;RESTORE INITIAL CODE
1161 002432 032737 000007 000174 BIT #7,@#MMOPT ;INHIBIT RUNNING 4K AS 32K USER?
1162 ;OR INHIBIT SEGMENTATION?
1163 002440 001001 BNE .+4 ;YES - ALLOW CORE EXPANSION
1164 002442 000207 RTS #7 ;NO - INHIBIT CORE EXPANSION
1165 002444 032737 000040 000174 BIT #40,@#MMOPT ;CHECK VARIABLE CORE SWITCH
1166 002452 001401 BEQ DET4 ;USE VARIABLE CORE ROUTINE
1167 002454 000207 RTS #7 ;4K ONLY (SWITCH SET)
1168 002456 012737 002542 000004 DET4: MOV #DE12,@#4 ;TRAP VECTOR SETUP
1169 002464 012737 000340 000006 MOV #340,@#6 ;TRAP STATUS SETUP
1170 002472 000241 CLC
1171 002474 005537 037770 EIGHT: ADC @#37770 ;CHECK FOR 8K
1172 002500 000240 NOP
1173 002502 005537 057770 ADC @#57770 ;CHECK FOR 12K
1174 002506 000240 NOP
1175 002510 005537 077770 ADC @#077770 ;CHECK FOR 16K
1176 002514 000240 NOP
1177 002516 005537 117770 ADC @#117770 ;CHECK FOR 20K
1178 002522 000240 NOP
1179 002524 005537 137770 ADC @#137770 ;CHECK FOR 24K
1180 002530 000240 NOP
1181 002532 005537 157770 ADC @#157770 ;CHECK FOR 28K
1182 002536 000240 NOP
1183 002540 000437 BR STRT28
1184 002542 012602 DET12: MOV (6)+,%2 ;RETRIEVE TRAP PC
1185 002544 005726 TST (6)+ ;DISCARD TRAP STATUS WORD
1186 002546 062702 000074 ADD #STRT4-EIGHT-4,%2
1187 002552 000112 JMP @R2
1188
1189 002554 005000 MOVE: CLR %0 ;SET UP MAIN CORE POINTER
1190 002556 010102 MOV %1,%2
1191 002560 062702 015030 ADD #0+2,%2 ;SET UP MAX CORE MOVE
1192 002564 012021 MOV (0)+,(1)+ ;MOVE WORD
1193 002566 020201 CMP %2,%1 ;MOVE COMPLETE?
1194 002570 001375 BNE .-4 ;MOVE ANOTHER WORD
1195 002572 000207 RTS #7 ;MOVE COMPLETE
1196 002574 000521 STRT4: BR DET3
1197 002576 000240 NOP
1198 002600 000240 NOP
1199 002602 004767 000110 JSR %7,XFER8 ;START 8K TRANSFER
1200 002606 000506 BP MOD4 ;START 4K MODIFY
1201 002610 004767 000072 JSR %7,XFER12 ;START 12K TRANSFER
1202 002614 000475 BR MOD8 ;START 8K MODIFY
1203 002616 004767 000054 JSR %7,XFER16 ;START 16K TRANSFER
1204 002622 000464 BR MOD12 ;START 12K MODIFY
1205 002624 004767 000036 JSR %7,XFER20 ;START 20K TRANSFER
1206 002630 000453 BR MOD16 ;START 16K MODIFY
1207 002632 004767 000020 JSR %7,XFER24 ;START 24K TRANSFER
1208 002636 000442 BR MOD20 ;START 20K MODIFY
1209 002640 004767 000002 STRT28: JSR %7,XFER28 ;START 28K TRANSFER
1210 002644 000431 BR MOD24 ;START 24K MODIFY
1211 002646 012701 140000 XFER28: MOV #140000,%1 ;SET UP MOVE START LOCATION
1212 002652 004767 177676 JSR %7,MOVE ;GO TO MOVE SUBROUTINE
1213 002656 012701 120000 XFER24: MOV #120000,%1
    
```

```

1214 002662 004767 177666      JSR      Z7,MOVE
1215 002666 012701 100000      XFER20: MOV      #100000,Z1
1216 002672 004767 177656      JSR      Z7,MOVE
1217 002676 012701 060000      XFER16: MOV      #60000,Z1
1218 002702 004767 177646      JSR      Z7,MOVE
1219 002706 012701 040000      XFER12: MOV      #40000,Z1
1220 002712 004767 177636      JSR      Z7,MOVE
1221 002716 012701 020000      XFER8:  MOV      #20000,Z1
1222 002722 004767 177626      JSR      Z7,MOVE
1223 002726 000207                RTS      Z7 ;RETURN FROM TRANSFERS
1224 002730 012767 000137 131570 MOD24:  MOV      #137,DONE+120000
1225 002736 012767 145510 131564      MOV      #BEGINX+140000,DONE+120002
1226 002744 012767 000137 111554 MOD20:  MOV      #137,DONE+100000
1227 002752 012767 125510 111550      MOV      #BEGINX+120000,DONE+100002
1228 002760 012767 000137 071540 MOD16:  MOV      #137,DONE+60000
1229 002766 012767 105510 071534      MOV      #BEGINX+100000,DONE+60002
1230 002774 012767 000137 051524 MOD12:  MOV      #137,DONE+40000
1231 003002 012767 065510 051520      MOV      #BEGINX+60000,DONE+40002
1232 003010 012767 000137 031510 MOD8:   MOV      #137,DONE+20000
1233 003016 012767 045510 031504      MOV      #BEGINX+40000,DONE+20002
1234 003024 012767 000137 011474 MOD4:   MOV      #137,DONE
1235 003032 012767 025510 011470      MOV      #BEGINX+20000,DONE+2
1236 003040 005037 000006      DET3:   CLR      #6
1237 003044 012737 000006 000004      MOV      #6,#4
1238 003052 000207                RTS      Z7
1239
1240 ;.....
1241 ;SBTTL TTY TRANSMITTER PRINT VALUES 0 TO 377
1242 ;.....
1243 003054 005027 000000      TYOUT:  CLR      #0 ;INITAL DATA
1244 003056                DATA2=-2
1245 003060 016777 177772 175324 TYOUT1:  MOV      DATA2,@TTDBR ;OUTPUT TO DEVICE
1246 003066 000002                RTI ;RETURN TO MAINLINE**
1247 003070 017767 175314 175322 TYOUTR:  MOV      @TTCSR,TTSV
1248 003076 105767 175316                TSTB    TTSV ;TEST FOR DONE
1249 003102 100401                BMI     .+4 ;BRANCH IF FLAG FOUND
1250 003104 104006                HLT ;FALSE INTERRUPT RETURN
1251 003106 005267 177744                INC     DATA2 ;INCREMENT DATA
1252 003112 022767 000400 177736      CMP     #400,DATA2 ;TEST DATA FOR UPPER LIMIT
1253 003120 001755                BEQ     TYOUT ;AT UPPER LIMIT START OVER
1254 003122 000756                BR      TYOUT1 ;FINISH REST OF DATA
1255
1256 ;.....
1257 ;SBTTL TEST OF LINE CLOCK, INTERRUPT FOR 55 SECONDS THEN STALL FOR 5 SECONDS.
1258 ;.....
1259 003124 005037 003242      LK1:   CLR      @#TIME ;CLEAR LINE CLOCK TIMER
1260 003130 052777 000100 175270      BIS     #100,@LKCSR
1261 003136 052737 000100 177776      BIS     #100,@#PSR
1262 003144 000002                LK2:   RTI
1263 003146 105777 175254      LK3:   TSTB    @LKCSR
1264 003152 100401                BMI     .+4
1265 003154 104006                HLT ;FALSE INTERRUPT
1266 003156 042777 000200 175242      BIC     #200,@LKCSR
1267 003164 005237 003242      LK4:   INC     @#TIME ;HERE ON INTERRUPTS
1268 003170 022737 006344 003242      CMP     #3300.,@#TIME ;55 SEC YET.
1269 003176 103362                BHS    LK2 ;BR IF NOT
    
```



```

1270 003200 042777 000100 175220 BIC #100,@LKCSR
1271 003206 042737 000100 177776 BIC #100,@PSR ;LOWER PRIORITY
1272 003214 022737 007020 003242 CMP #3600.,@TIME ;ONE MINUTE YET
1273 003222 001740 BEQ LK1 ;YES RESET TIMER
1274 003224 105777 175176 TSTB @LKCSR ;NO, SKIP TILL MINUTE UP
1275 003230 100375 BPL .-4
1276 003232 042777 000200 175166 BIC #200,@LKCSR ;CLEAR FLAG
1277 003240 000751 BR LK4
1278 003242 000000 TIME: 0
1279
1280 ;.....
1281 ;SBTTL LINE PRINTER SERVICE
1282 ;.....
1283 ;LINE PRINTER SHOULD RAISE PROCESSOR PRIORITY TO LEVEL OF LINE PRINTER/
1284 ;INTERRUPT VECTOR IS 200/
1285 003244 012727 000000 000000 LP1: MOV #0,#0 ;START OF LINE TO CURRENT
1286 003250 CURPAT=-2 ;CHARACTER BEING PRINTED
1287 003246 SOLPAT=-4 ;START OF LINE CHARACTER
1288 003252 016777 177772 175152 LP2: MOV CURPAT,@LPDDBR ;CURRENT PATTERN TO LINE PRINTER
1289 003260 105777 175144 TSTB @LPCSR
1290 003264 100420 BMI LP6
1291 003266 000002 RTI ;RETURN TO MAIN LINE
1292 003270 105777 175134 LPINTR: TSTB @LPCSR ;TEST FOR FLAG
1293 003274 100414 BMI LP6
1294 003276 005737 000042 TST @#42 ;MONITOR LOAD
1295 003302 001410 BEQ LP7 ;NO, ERROR
1296 003304 032777 100000 175116 BIT #100000,@LPCSR ;YES, IS ERROR SET
1297 003312 001404 BEQ LP7 ;NO, ERROR
1298 003314 042777 000100 175106 BIC #100,@LPCSR ;DIS ABLE INTERRUPT
1299 003322 000002 RTI
1300 003324 104006 LP7: HLT ;FALSE RETURN FROM MAIN LINE
1301 003326 026727 000006 000117 LP6: CMP CLINCT,#79. ;TEST FOR END OF LINE
1302 003334 001415 BEQ LP4 ;GO GENERATE CR/LF
1303 003336 005227 000000 INC #0 ;INCREMENT LINE POSITION COUNT
1304 003340 CLINCT=-2 ;POSITION OF LINE
1305 003342 026727 177702 000137 CMP CURPAT,#137 ;TEST FOR MAXIMUM PATTERN
1306 003350 001403 BEQ LP3 ;YES - GO TO LP3 AND RESET
1307 003352 005267 177672 INC CURPAT ;NO - INCREMENT TO NEXT PATTERN
1308 003356 000735 BR LP2 ;GO SEND IT TO LINE PRINTER
1309 003360 012767 000040 177662 LP3: MOV #40,CURPAT ;RESET PATTERN AND SEND TO PRINTER
1310 003366 000731 BR LP2 ;SENT TO LINE PRINTER
1311 003370 005067 177744 LP4: CLR CLINCT ;RESET LINE COUNT
1312 003374 012777 000012 175030 MOV #12,@LPDDBR ;LINE FEED
1313 003402 105777 175022 TSTB @LPCSR
1314 003406 100375 BPL .-4
1315 003410 026727 177632 000137 CMP SOLPAT,#137 ;START OF LINE PATTERN
1316 003416 001403 BEQ LP5
1317 003420 005267 177622 INC SOLPAT ;INCREMENT START OF LINE
1318 003424 000707 BR LP1
1319 003426 012767 000040 177612 LP5: MOV #40,SOLPAT ;RESET START OF LINE
1320 003434 000703 BR LP1 ;PRINT
1321
1322 ;.....
1323 ;SBTTL RK11 SERVICE
1324 ;.....
1325 ;RK11 DISK TEST INTERRUPT LEVEL 5, 2000 WORD TRANSFERS
    
```

```

1326 003436 005077 175020 RKSTART: CLR @RKDAE ;INIT
1327 003442 013777 003670 175016 RK1: MOV @LLIMIT,@RKBAR ;CORE BASE
1328 003450 013777 003672 175006 MOV @WORDCT,@RKC ;TRANSFER LENGTH
1329 003456 113777 003530 175004 MOV @RKFUNCT,@RKC ;WRITE OR WRITE CK TO DSK
1330 003464 000002 RTI ;RETURN TO MAINLINE
1331 003466 032777 100200 174774 IRK: BIT #100200,@RKC ;INTERRUPT RETURN
1332 003474 0030G2 BGT .+6
1333 003476 104006 HLT
1334 003500 000756 BR RKSTART
1335 003502 032777 000037 174752 BIT #37,@RKDAE ;DISK AT UPPER LIMIT?
1336 003510 001354 BNE RK1
1337 003512 122777 000031 174740 CMPB #31,@RKDAH
1338 003520 001350 BNE RK1
1339 003522 000337 003530 SWAB @RKFUNCT ;CHANGE COMMAND
1340 003526 000743 BR RKSTART ;RESTART NEW TRANSFER OF DISK
1341 003530 000000 RKFUNCT: 0
1342
1343 :*****
1344 SBTTL RF11 DISK
1345 :*****
1346 003532 105277 174714 RFSTART: INCB @RFCSR ;INITIALIZE DISK - DAR-DAE
1347 003536 013777 003670 174702 RFI: MOV @LLIMIT,@RFCAR ;CORE BASE
1348 003544 013777 003672 174672 MOV @WORDCT,@RFC ;LENGTH OF TRANSFER
1349 003552 113777 003666 174670 MOV @RFFUNCT,@RFC ;WRITE OR WRITE CHECK TO DISK
1350 003560 000002 RTI ;RETURN TO MAINLINE CODE
1351 003562 105777 174662 IRF: TSTB @RFCR ;INTERRUPT VECTOR POINTS HERE
1352 003566 100402 BMI .+6
1353 003570 104006 HLT ;RF11 READY NOT UP
1354 003572 000757 BR RFSTART
1355 003574 005777 174650 TST @RFCR ;ERROR SET?
1356 003600 100012 BPL ERROK ;BRANCH IF NOT
1357 003602 032777 020000 174640 BIT #20000,@RFCR ;YES-WRITE CHECK ERROR?
1358 003610 001404 BEQ ERRSET ;NO-BRANCH
1359 003612 104006 HLT ;YES-RF11 WRITE CHECK ERROR
1360 003614 000337 003666 SWAB @RFFUNCT ;CHANGE COMMAND TO DO WRITE
1361 003620 000744 BR RFSTART
1362 003622 104006 ERRSET: HLT ;RF11 ERROR SET-NOT WRITE CHECK
1363 003624 000742 BR RFSTART
1364 003626 005777 174612 ERROK: TST @RFC ;
1365 003632 100002 BPL .+6
1366 003634 104006 HLT ;RF-11 WORD COUNT NOT ZERO
1367 003636 000735 BR RFSTART
1368 003640 122777 000003 174572 CMPB #3,@RFD ;DISK AT UPPER LIMIT? 7=2, 17=4, 37 8
1369 003646 001333 BNE RFI ;NO
1370 003650 027727 174566 174000 CMP @RFDAR,#174000 ;AS FAR ON DISK AS WE CAN GO
1371 003656 101727 BLOS RFI ;NO
1372 003660 000337 003666 SWAB @RFFUNCT ;CHANGE COMMAND
1373 003664 000722 BR RFSTART ;RESTART NEW TRANSFER OF DISK
1374 003666 000000 RFFUNCT: 0 ;DISK COMMAND
1375 003670 005542 LLIMIT: BEGIN ;FIRST CORE ADDRESS OF TRANSFER
1376 003672 176000 WORDCT: -2000 ;LENGTH OF TRANSFER
1377
1378 :*****
1379 SBTTL TC11 DIAGNOSTIC ROUTINE
1380 :*****
1381 ;DECTAPE DIAGNOSTIC ROUTINE. THE TAPE IS FIRST DRIVEN TO THE FORWARD
    
```

```

1382 ;END ZONE. THE DESIRED DATA IS THEN GENERATED IN THE DECTAPE BUFFER AREA
1383 ;AND DATA IS WRITTEN ONTO ALL BLOCKS FROM THE BLOCK NUMBER IN TCFRST
1384 ;THRU THE BLOCK NUMBER IN TCLAST. BLOCK NUMBERS ARE ALSO CHECKED FOR
1385 ;BEING IN ORDER. AFTER THE BLOCK NUMBER IN TCLAST IS WRITTEN, TAPE IS
1386 ;DRIVEN INTO THE REVERSE END ZONE.
1387 ;THE TAPE IS THEN STARTED IN REVERSE, AND WHEN THE CLOSEST BLOCK THAT
1388 ;WAS WRITTEN (TCLAST) IS FOUND, IT IS READ INTO THE DECTAPE BUFFER AREA.
1389 ;THE PROGRAM INTERRUPT REQUEST FACILITY IS THEN USED TO BOOK A REQUEST
1390 ;FOR CHECKING THE DATA AT LEVEL 3, AND NO FURTHER DATA IS READ IN
1391 ;UNTIL THAT DATA HAS BEEN CHECKED. AFTER IT IS CHECKED, THE DATA IS
1392 ;SCRAMBLED TO GUARANTEE THAT NEW DATA IS REALLY READ IN NEXT TIME. WHILE
1393 ;THIS IS GOING ON, BLOCK NUMBERS ARE CHECKED FOR BEING IN ORDER AS THE
1394 ;TAPE TRAVELS TOWARD THE FORWARD END ZONE. ONCE THE DATA IS FULLY CHECKED
1395 ;THE NEXT BLOCK THAT COMES UP IS READ IN AND THE PROCESS REPEATED. ONCE
1396 ;THE BLOCK WHOSE NUMBER IS IN TCFRST HAS BEEN READ, THE TAPE IS DRIVEN
1397 ;INTO THE FORWARD END ZONE AND THE WHOLE SEQUENCE IS REPEATED.
1398
1399 ;FUNCTION VALUES IN CSR
1400 ;DT11 DEC TAPE
1401 RD-4 ;READ DATA
1402 WD-14 ;WRITE DATA
1403 RB-2
1404 IE-500 ;INTERRUPT ENABLE+UNIT 1
1405 DO-1 ;DO - THE FUNCTION
1406 R=4000 ;REVERSE
1407
1408 TCFRST: 0 ;FIRST BLOCK TO BE SEARCHED FOR
1409 TCLAST: 577. ;LAST BLOCK TO BE SEARCHED FOR
1410 TCXPE: 0 ;THE BLOCK THAT IS EXPECTED
1411
1412 ;GO TO FORWARD END ZONE
1413 FENDZ: MOV #FENDZ,@TCIV ;END ZONE VECTOR SETUP
1414 TST @TCST ;TEST FOR END ZONE
1415 BMI FEND1 ;AT END ZONE?
1416 INCB @TCCM ;SET DO - NO DELAY
1417 RTI ;NO - WAIT SOME MORE
1418 FEND1: MOV #TCF1,@TCIV ;YES - NEW VECTOR
1419 BIC #104000,@TCCM ;SEARCH BLOCK FOWARD
1420 MOV TCFRST,TCXPE ;COUNT WHEN THIS BLOCK IS FOUND
1421 TCF1A: INCB @TCCM ;SET DO
1422 RTI ;RETURN ON NEXT BLOCK
1423 TCF1: BIT #100200,@TCCM ;ANY ERROR ON READ?
1424 BPL .+4
1425 HLT ;TC ERROR SET - FORWARD READ BLOCK
1426 BNE .+4 ;DONE FLAG UP?
1427 HLT ;FALSE INTERRUPT
1428 CMP @TCDT,TCXPE ;IS THIS OUR BLOCK FOR SYNC
1429 BLT TCF1A ;NO-READ SOME MORE BLOCKS
1430 BEQ TCF2 ;YES
1431 HLT ;WE PASSED THE BLOCK
1432
1433 TCF2: MOV #TCF3,@TCIV ;VECTOR FOR SEQUENTIAL READS
1434 INCB @TCCM ;SET DO
1435 RTI ;RETURN AND TEST SEQUENTIAL BLOCKS
1436
1437 ;FIND SEQUENTIAL BLOCK AT FOWARD DIRECTION

```

```

1438 004022 032777 100200 174522 TCF3: BIT #100200,@TCCM ;TEST ERROR AND READY
1439 004030 100001 BPL .+4
1440 004032 104006 HLT ;FOWARD READ ERROR TC-11
1441 004034 001001 BNE .+4
1442 004036 104006 HLT ;FALSE INTERRUPT ON TC-11
1443 004040 027767 174512 177630 CMP @TCDT,TCCLAS ;HAVE WE TESTED ALL BLOCKS
1444 004046 001414 BFO RENDZ ;YES DRIVE UNIT IN END ZONE TO START OVER
1445 004050 005267 177624 INC TCXPE ;NO-INCREMENT EXPECTED COUNT
1446 004054 027767 174476 177616 CMP @TCDT,TCXPE ;IS CURRENT BLOCK CORRECT
1447 004062 001401 BEO .+4
1448 004064 104006 HLT ;FAILED IN FOWARD READ TO FIND NEXT BLOCK
1449 004066 000427 BR TCWBK ;THIS ROUTINE WRITES A BLOCK
1450 004070 105277 174456 TCF4: INCB @TCCM ;SET DO
1451 004074 000002 RTI
1452 004076 000701 XFENDZ: BR FENDZ ;INDIRECT LINK
1453
1454 ;MOVE TAPE TO REVERSE END ZONE
1455 004100 012777 004100 174456 RENDZ: MOV #RENDZ,@TCIV ;END ZONE VECTOR SETUP
1456 004106 016767 177564 177564 MOV TCLAST,TCXPE ;SET UP FOR REVERSE SEARCH
1457 004114 005777 174434 TST @TCST ;IN END ZONE
1458 004120 100403 BMI REND1 ;YES - START TO TURN UNIT AROUND
1459 004122 105277 174424 INCB @TCCM ;SET DO
1460 004126 000002 RTI ;NO - WAIT TILL WE ARE
1461 004130 012777 004503 174414 REND1: MOV #R+IE+RB+DO,@TCCM ;FUNCTION = READ BLOCK, REVERSE AND GO
1462 004136 012777 004226 174420 MOV #TCR1,@TCIV ;SET UP NEW INTERRUPT VECTOR
1463 004144 000002 RTI
1464 ;WRITE FORWARD ALL BLOCKS EXCEPT 0
1465
1466 004146 012777 004200 174410 TCWBK: MOV #TCWB1,@TCIV ;INTERRUPT VECTOR FOR WRITE
1467 004154 012777 177400 174376 MOV #-400,@TCWC ;ONE BLOCK
1468 004162 012777 004510 174372 MOV #TCWBUF,@TCBA ;THE WRITE BUFFER ADDRESS
1469 004170 112777 000515 174354 MOVB #IE+WD+DO,@TCCM ;WRITE THE BLOCK
1470 004176 000002 RTI ;RETURN WHEN BLOCK IS WRITTEN
1471 004200 005777 174346 TCWB1: TST @TCCM ;ANY ERRORS
1472 004204 100001 BPL .+4
1473 004206 104006 HLT
1474 004210 012777 004022 174346 MOV #TCF3,@TCIV ;SEARCH BLOCK VECTOR
1475 004216 112777 000502 174326 MOVB #IE+RB,@TCCM ;READ BLOCK
1476 004224 000721 BR TCF4 ;FIND THE NEXT BLOCK
1477
1478 004226 032777 100200 174316 TCR1: BIT #100200,@TCCM ;TEST FOR ERROR AND READY
1479 004234 100001 BPL .+4
1480 004236 104006 HLT ;DECTAPE ERROR ON READ BLOCK REVERSE
1481 004240 001001 BNE .+4
1482 004242 104006 HLT ;FALSE INTERRUPT FROM DECTAPE
1483 004244 027767 174306 177426 CMP @TCDT,TCXPE ;IS IT OUR FIRST BLOCK
1484 004252 001406 BEO TCR2 ;YES - GO TEST THE REST
1485 004254 002002 BGE TCR1A ;NO - HAVE WE PASSED THE BLOCK
1486 004256 104006 HLT ;WE PASS OUR BLOCK
1487 004260 000707 BR RENDZ ;GO TO END ZONE AND TRY AGAIN
1488 004262 105277 174264 TCR1A: INCB @TCCM ;SET DO
1489 004266 000002 RTI ;WE FOUND OUR FIRST BLOCK
1490 004270 012777 004304 174266 TCR2: MOV #TCR3,@TCIV ;SET UP INTERRUPT TO TEST ALL BLOCKS
1491 004276 105277 174250 INCB @TCCM ;SET DO
1492 004302 000002 RTI ;WAIT FOR NEXT BLOCK TO INTERRUPT
1493
  
```

```

1494          :FIND SEQUENTIAL BLOCK IN REVERSE DIRECTION
1495 004304 032777 100200 174240 TCR3: BIT #100200,@TCCM ;TEST FOR READ AND ERROR
1496 004312 100001          BPL .+4
1497 004314 104006          HLT          ;ERROR READING SEQUENTIAL BLOCK IN REVERSE
1498 004316 001001          BNE .+4
1499 004320 104006          HLT          ;FALSE DECTAPE INTERRUPT
1500 004322 026777 177346 174226 CMP TCFIRST,@TCDT ;DID WE DO ALL THE BLOCKS
1501 004330 001662          BEQ XFENDZ ;YES - GO TO END ZONE TO RESTART
1502 004332 005367 177342          DEC TCXPE ;NO - DECREMENT BLOCK NUMBER
1503 004336 027767 174214 177334 CMP @TCDT,TCXPE ;TEST SEQUENTIAL BLOCK IN REVERSE
1504 004344 001401          BEQ .+4
1505 004346 104006          HLT          ;TEST SEQUENTIAL READ BLOCK IN REVERSE FAILED
1506 004350 000403          BR TCRBK ;THIS ROUTINE READ A BLOCK
1507 004352 105277 174174 TCR4: INCB @TCCM ;SET DO
1508 004356 000002          RTI ;LETS TRY A NEW BLOCK
1509
1510          :READ REVERSE ALL BLOCK EXCEPT BLOCK 1101
1511 004360 012777 004416 174176 TCRBK: MOV #TCRBK,@TCIV ;SET UP INTERRUPT VECTOR
1512 004366 012777 177400 174164 MOV #-400,@TCWC ;READ ONE BLOCK
1513 004374 012777 004510 174160 MOV #TCRBUF,@TCBA ;WHERE BUFFER IS
1514 004402 112777 000505 174142 MOVB #1E+RD+DO,@TCCM ;READ THE BLOCK
1515 004410 004767 000030          JSR %7,TC1 ;CHECK DATA BUFFER
1516 004414 000002          RTI ;EXIT - RETURN WHEN BLOCK IS READ
1517 004416 005777 174130 TCRBK: TST @TCCM ;AND ERRORS
1518 004422 100001          BPL .+4
1519 004424 104006          HLT          ;DECTAPE ERROR
1520 004426 012777 004304 174130 MOV #TCR3,@TCIV ;NEW VECTOR FOR BLOCK SEARCH
1521 004434 112777 000502 174110 MOVB #1E+RB,@TCCM ;READ BLOCK FUNCTION
1522 004442 000743          BR TCR4 ;RETURN TO BLOCK SEARCH
1523
1524          :THIS ROUTINE CHECKS THE READ DATA BUFFER TC11
1525          :BY DOING A CHECK SUM ON THE DATA
1526 004444 010146          TC1: MOV %1,-(6) ;SAVE THESE ON THE STACK
1527 004446 010246          MOV %2,-(6)
1528 004450 010346          MOV %3,-(6)
1529 004452 005003          CLR %3 ;SUM OF DATA
1530 004454 012701 004510          MOV #TCRBUF,%1 ;ADDRESS OF READ BUFFER
1531 004460 012702 005510          MOV #TCRBUF+1000,%2 ;END OF READ BUFFER
1532 004464 062103          TC2: ADD (1)+,%3 ;EVEN ADD
1533 004466 062103          ADD (1)+,%3 ;ODD ADD -2'S COMPLIMENT
1534 004470 001401          BEQ .+4
1535 004472 104006          HLT          ;DATA ERROR TC-11
1536 004474 020102          CMP %1,%2 ;AT END OF BUFFER?
1537 004476 001372          BNE TC2 ;NO - SUM THE REST
1538 004500 012603          MOV (6)+,%3 ;RESTORE THE REGISTERS
1539 004502 012602          MOV (6)+,%2
1540 004504 012601          MOV (6)+,%1
1541 004506 000207          RTS %7 ;EXIT
1542
1543          :THIS WRITE BUFFER LOOK THE SAME FORWARD OR REVERSE
1544 004510          TCWBUF:
1545 004510          TCRBUF:
1546          N=1
1547 004510 000001          N ;DECTAPE WRITE BUFFER
1548 004512 177777          -N
1549          000002          N-N+1
  
```

1550	004514	000002	N	;DECTAPE WRITE BUFFER
1551	004516	177776	-N	
1552		000003	N=N+1	
1553	004520	000003	N	;DECTAPE WRITE BUFFER
1554	004522	177775	-N	
1555		000004	N=N+1	
1556	004524	000004	N	;DECTAPE WRITE BUFFER
1557	004526	177774	-N	
1558		000005	N=N+1	
1559	004530	000005	N	;DECTAPE WRITE BUFFER
1560	004532	177773	-N	
1561		000006	N=N+1	
1562	004534	000006	N	;DECTAPE WRITE BUFFER
1563	004536	177772	-N	
1564		000007	N=N+1	
1565	004540	000007	N	;DECTAPE WRITE BUFFER
1566	004542	177771	-N	
1567		000010	N=N+1	
1568	004544	000010	N	;DECTAPE WRITE BUFFER
1569	004546	177770	-N	
1570		000011	N=N+1	
1571	004550	000011	N	;DECTAPE WRITE BUFFER
1572	004552	177767	-N	
1573		000012	N=N+1	
1574	004554	000012	N	;DECTAPE WRITE BUFFER
1575	004556	177766	-N	
1576		000013	N=N+1	
1577	004560	000013	N	;DECTAPE WRITE BUFFER
1578	004562	177765	-N	
1579		000014	N=N+1	
1580	004564	000014	N	;DECTAPE WRITE BUFFER
1581	004566	177764	-N	
1582		000015	N=N+1	
1583	004570	000015	N	;DECTAPE WRITE BUFFER
1584	004572	177763	-N	
1585		000016	N=N+1	
1586	004574	000016	N	;DECTAPE WRITE BUFFER
1587	004576	177762	-N	
1588		000017	N=N+1	
1589	004600	000017	N	;DECTAPE WRITE BUFFER
1590	004602	177761	-N	
1591		000020	N=N+1	
1592	004604	000020	N	;DECTAPE WRITE BUFFER
1593	004606	177760	-N	
1594		000021	N=N+1	
1595	004610	000021	N	;DECTAPE WRITE BUFFER
1596	004612	177757	-N	
1597		000022	N=N+1	
1598	004614	000022	N	;DECTAPE WRITE BUFFER
1599	004616	177756	-N	
1600		000023	N=N+1	
1601	004620	000023	N	;DECTAPE WRITE BUFFER
1602	004622	177755	-N	
1603		000024	N=N+1	
1604	004624	000024	N	;DECTAPE WRITE BUFFER
1605	004626	177754	-N	

1606		000025	N=N+1	
1607	004630	000025	N	;DECTAPE WRITE BUFFER
1608	004632	177753	-N	
1609		000026	N=N+1	
1610	004634	000026	N	;DECTAPE WRITE BUFFER
1611	004636	177752	-N	
1612		000027	N=N+1	
1613	004640	000027	N	;DECTAPE WRITE BUFFER
1614	004642	177751	-N	
1615		000030	N=N+1	
1616	004644	000030	N	;DECTAPE WRITE BUFFER
1617	004646	177750	-N	
1618		000031	N=N+1	
1619	004650	000031	N	;DECTAPE WRITE BUFFER
1620	004652	177747	-N	
1621		000032	N=N+1	
1622	004654	000032	N	;DECTAPE WRITE BUFFER
1623	004656	177746	-N	
1624		000033	N=N+1	
1625	004660	000033	N	;DECTAPE WRITE BUFFER
1626	004662	177745	-N	
1627		000034	N=N+1	
1628	004664	000034	N	;DECTAPE WRITE BUFFER
1629	004666	177744	-N	
1630		000035	N=N+1	
1631	004670	000035	N	;DECTAPE WRITE BUFFER
1632	004672	177743	-N	
1633		000036	N=N+1	
1634	004674	000036	N	;DECTAPE WRITE BUFFER
1635	004676	177742	-N	
1636		000037	N=N+1	
1637	004700	000037	N	;DECTAPE WRITE BUFFER
1638	004702	177741	-N	
1639		000040	N=N+1	
1640	004704	000040	N	;DECTAPE WRITE BUFFER
1641	004706	177740	-N	
1642		000041	N=N+1	
1643	004710	000041	N	;DECTAPE WRITE BUFFER
1644	004712	177737	-N	
1645		000042	N=N+1	
1646	004714	000042	N	;DECTAPE WRITE BUFFER
1647	004716	177736	-N	
1648		000043	N=N+1	
1649	004720	000043	N	;DECTAPE WRITE BUFFER
1650	004722	177735	-N	
1651		000044	N=N+1	
1652	004724	000044	N	;DECTAPE WRITE BUFFER
1653	004726	177734	-N	
1654		000045	N=N+1	
1655	004730	000045	N	;DECTAPE WRITE BUFFER
1656	004732	177733	-N	
1657		000046	N=N+1	
1658	004734	000046	N	;DECTAPE WRITE BUFFER
1659	004736	177732	-N	
1660		000047	N=N+1	
1661	004740	000047	N	;DECTAPE WRITE BUFFER

1662	004742	177731	-N	
1663		000050	N N+1	
1664	004744	000050	N	;DECTAPE WRITE BUFFER
1665	004746	177730	-N	
1666		000051	N-N+1	
1667	004750	000051	N	;DECTAPE WRITE BUFFER
1668	004752	177727	-N	
1669		000052	N N+1	
1670	004754	000052	N	;DECTAPE WRITE BUFFER
1671	004756	177726	-N	
1672		000053	N-N+1	
1673	004760	000053	N	;DECTAPE WRITE BUFFER
1674	004762	177725	-N	
1675		000054	N=N+1	
1676	004764	000054	N	;DECTAPE WRITE BUFFER
1677	004766	177724	-N	
1678		000055	N-N+1	
1679	004770	000055	N	;DECTAPE WRITE BUFFER
1680	004772	177723	-N	
1681		000056	N=N+1	
1682	004774	000056	N	;DECTAPE WRITE BUFFER
1683	004776	177722	-N	
1684		000057	N=N+1	
1685	005000	000057	N	;DECTAPE WRITE BUFFER
1686	005002	177721	-N	
1687		000060	N-N+1	
1688	005004	000060	N	;DECTAPE WRITE BUFFER
1689	005006	177720	-N	
1690		000061	N N+1	
1691	005010	000061	N	;DECTAPE WRITE BUFFER
1692	005012	177717	-N	
1693		000062	N=N+1	
1694	005014	000062	N	;DECTAPE WRITE BUFFER
1695	005016	177716	-N	
1696		000063	N=N+1	
1697	005020	000063	N	;DECTAPE WRITE BUFFER
1698	005022	177715	-N	
1699		000064	N=N+1	
1700	005024	000064	N	;DECTAPE WRITE BUFFER
1701	005026	177714	-N	
1702		000065	N-N+1	
1703	005030	000065	N	;DECTAPE WRITE BUFFER
1704	005032	177713	-N	
1705		000066	N=N+1	
1706	005034	000066	N	;DECTAPE WRITE BUFFER
1707	005036	177712	-N	
1708		000067	N N+1	
1709	005040	000067	N	;DECTAPE WRITE BUFFER
1710	005042	177711	-N	
1711		000070	N-N+1	
1712	005044	000070	N	;DECTAPE WRITE BUFFER
1713	005046	177710	-N	
1714		000071	N-N+1	
1715	005050	000071	N	;DECTAPE WRITE BUFFER
1716	005052	177707	-N	
1717		000072	N N+1	

1718	005054	000072	N	:DECTAPE WRITE BUFFER
1719	005056	177706	-N	
1720		000073	N-N+1	
1721	005060	000073	N	:DECTAPE WRITE BUFFER
1722	005062	177705	-N	
1723		000074	N N+1	
1724	005064	000074	N	:DECTAPE WRITE BUFFER
1725	005066	177704	-N	
1726		000075	N N+1	
1727	005070	000075	N	:DECTAPE WRITE BUFFER
1728	005072	177703	-N	
1729		000076	N=N+1	
1730	005074	000076	N	:DECTAPE WRITE BUFFER
1731	005076	177702	-N	
1732		000077	N N+1	
1733	005100	000077	N	:DECTAPE WRITE BUFFER
1734	005102	177701	-N	
1735		000100	N-N+1	
1736	005104	000100	N	:DECTAPE WRITE BUFFER
1737	005106	177700	-N	
1738		000101	N=N+1	
1739		000100	N=N-1	
1740	005110	177700	-N	
1741	005112	000100	N	:DEC TAPE WRITE BUFFER
1742		000077	N=N-1	
1743	005114	177701	-N	
1744	005116	000077	N	:DEC TAPE WRITE BUFFER
1745		000076	N=N-1	
1746	005120	177702	-N	
1747	005122	000076	N	:DEC TAPE WRITE BUFFER
1748		000075	N=N-1	
1749	005124	177703	-N	
1750	005126	000075	N	:DEC TAPE WRITE BUFFER
1751		000074	N=N-1	
1752	005130	177704	-N	
1753	005132	000074	N	:DEC TAPE WRITE BUFFER
1754		000073	N=N-1	
1755	005134	177705	-N	
1756	005136	000073	N	:DEC TAPE WRITE BUFFER
1757		000072	N=N-1	
1758	005140	177706	-N	
1759	005142	000072	N	:DEC TAPE WRITE BUFFER
1760		000071	N=N-1	
1761	005144	177707	-N	
1762	005146	000071	N	:DEC TAPE WRITE BUFFER
1763		000070	N=N-1	
1764	005150	177710	-N	
1765	005152	000070	N	:DEC TAPE WRITE BUFFER
1766		000067	N=N-1	
1767	005154	177711	-N	
1768	005156	000067	N	:DEC TAPE WRITE BUFFER
1769		000066	N=N-1	
1770	005160	177712	-N	
1771	005162	000066	N	:DEC TAPE WRITE BUFFER
1772		000065	N=N-1	
1773	005164	177713	-N	

1774	005166	000065	N	:DEC TAPE WRITE BUFFER
1775		000064	N=N-1	
1776	005170	177714	-N	
1777	005172	000064	N	:DEC TAPE WRITE BUFFER
1778		000063	N=N-1	
1779	005174	177715	-N	
1780	005176	000063	N	:DEC TAPE WRITE BUFFER
1781		000062	N=N-1	
1782	005200	177716	-N	
1783	005202	000062	N	:DEC TAPE WRITE BUFFER
1784		000061	N=N-1	
1785	005204	177717	-N	
1786	005206	000061	N	:DEC TAPE WRITE BUFFER
1787		000060	N=N-1	
1788	005210	177720	-N	
1789	005212	000060	N	:DEC TAPE WRITE BUFFER
1790		000057	N=N-1	
1791	005214	177721	-N	
1792	005216	000057	N	:DEC TAPE WRITE BUFFER
1793		000056	N=N-1	
1794	005220	177722	-N	
1795	005222	000056	N	:DEC TAPE WRITE BUFFER
1796		000055	N=N-1	
1797	005224	177723	-N	
1798	005226	000055	N	:DEC TAPE WRITE BUFFER
1799		000054	N=N-1	
1800	005230	177724	-N	
1801	005232	000054	N	:DEC TAPE WRITE BUFFER
1802		000053	N=N-1	
1803	005234	177725	-N	
1804	005236	000053	N	:DEC TAPE WRITE BUFFER
1805		000052	N=N-1	
1806	005240	177726	-N	
1807	005242	000052	N	:DEC TAPE WRITE BUFFER
1808		000051	N=N-1	
1809	005244	177727	-N	
1810	005246	000051	N	:DEC TAPE WRITE BUFFER
1811		000050	N=N-1	
1812	005250	177730	-N	
1813	005252	000050	N	:DEC TAPE WRITE BUFFER
1814		000047	N=N-1	
1815	005254	177731	-N	
1816	005256	000047	N	:DEC TAPE WRITE BUFFER
1817		000046	N=N-1	
1818	005260	177732	-N	
1819	005262	000046	N	:DEC TAPE WRITE BUFFER
1820		000045	N=N-1	
1821	005264	177733	-N	
1822	005266	000045	N	:DEC TAPE WRITE BUFFER
1823		000044	N=N-1	
1824	005270	177734	-N	
1825	005272	000044	N	:DEC TAPE WRITE BUFFER
1826		000043	N=N-1	
1827	005274	177735	-N	
1828	005276	000043	N	:DEC TAPE WRITE BUFFER
1829		000042	N=N-1	

1830	005300	177736	-N	
1831	005302	000042	N	;DEC TAPE WRITE BUFFER
1832		000041	N=N-1	
1833	005304	177737	-N	
1834	005306	000041	N	;DEC TAPE WRITE BUFFER
1835		000040	N=N-1	
1836	005310	177740	-N	
1837	005312	000040	N	;DEC TAPE WRITE BUFFER
1838		000037	N=N-1	
1839	005314	177741	-N	
1840	005316	000037	N	;DEC TAPE WRITE BUFFER
1841		000036	N=N-1	
1842	005320	177742	-N	
1843	005322	000036	N	;DEC TAPE WRITE BUFFER
1844		000035	N=N-1	
1845	005324	177743	-N	
1846	005326	000035	N	;DEC TAPE WRITE BUFFER
1847		000034	N=N-1	
1848	005330	177744	-N	
1849	005332	000034	N	;DEC TAPE WRITE BUFFER
1850		000033	N=N-1	
1851	005334	177745	-N	
1852	005336	000033	N	;DEC TAPE WRITE BUFFER
1853		000032	N=N-1	
1854	005340	177746	-N	
1855	005342	000032	N	;DEC TAPE WRITE BUFFER
1856		000031	N=N-1	
1857	005344	177747	-N	
1858	005346	000031	N	;DEC TAPE WRITE BUFFER
1859		000030	N=N-1	
1860	005350	177750	-N	
1861	005352	000030	N	;DEC TAPE WRITE BUFFER
1862		000027	N=N-1	
1863	005354	177751	-N	
1864	005356	000027	N	;DEC TAPE WRITE BUFFER
1865		000026	N=N-1	
1866	005360	177752	-N	
1867	005362	000026	N	;DEC TAPE WRITE BUFFER
1868		000025	N=N-1	
1869	005364	177753	-N	
1870	005366	000025	N	;DEC TAPE WRITE BUFFER
1871		000024	N=N-1	
1872	005370	177754	-N	
1873	005372	000024	N	;DEC TAPE WRITE BUFFER
1874		000023	N=N-1	
1875	005374	177755	-N	
1876	005376	000023	N	;DEC TAPE WRITE BUFFER
1877		000022	N=N-1	
1878	005400	177756	-N	
1879	005402	000022	N	;DEC TAPE WRITE BUFFER
1880		000021	N=N-1	
1881	005404	177757	-N	
1882	005406	000021	N	;DEC TAPE WRITE BUFFER
1883		000020	N=N-1	
1884	005410	177760	-N	
1885	005412	000020	N	;DEC TAPE WRITE BUFFER

1886		000017	N=N-1	
1887	005414	177761	-N	
1888	005416	000017	N	;DEC TAPE WRITE BUFFER
1889		000016	N=N-1	
1890	005420	177762	-N	
1891	005422	000016	N	;DEC TAPE WRITE BUFFER
1892		000015	N=N-1	
1893	005424	177763	-N	
1894	005426	000015	N	;DEC TAPE WRITE BUFFER
1895		000014	N=N-1	
1896	005430	177764	-N	
1897	005432	000014	N	;DEC TAPE WRITE BUFFER
1898		000013	N=N-1	
1899	005434	177765	-N	
1900	005436	000013	N	;DEC TAPE WRITE BUFFER
1901		000012	N=N-1	
1902	005440	177766	-N	
1903	005442	000012	N	;DEC TAPE WRITE BUFFER
1904		000011	N=N-1	
1905	005444	177767	-N	
1906	005446	000011	N	;DEC TAPE WRITE BUFFER
1907		000010	N=N-1	
1908	005450	177770	-N	
1909	005452	000010	N	;DEC TAPE WRITE BUFFER
1910		000007	N=N-1	
1911	005454	177771	-N	
1912	005456	000007	N	;DEC TAPE WRITE BUFFER
1913		000006	N=N-1	
1914	005460	177772	-N	
1915	005462	000006	N	;DEC TAPE WRITE BUFFER
1916		000005	N=N-1	
1917	005464	177773	-N	
1918	005466	000005	N	;DEC TAPE WRITE BUFFER
1919		000004	N=N-1	
1920	005470	177774	-N	
1921	005472	000004	N	;DEC TAPE WRITE BUFFER
1922		000003	N=N-1	
1923	005474	177775	-N	
1924	005476	000003	N	;DEC TAPE WRITE BUFFER
1925		000002	N=N-1	
1926	005500	177776	-N	
1927	005502	000002	N	;DEC TAPE WRITE BUFFER
1928		000001	N=N-1	
1929	005504	177777	-N	
1930	005506	000001	N	;DEC TAPE WRITE BUFFER
1931				

1932
 1933
 1934
 1935 005510 010701
 1936 005512 042701 017777
 1937 005516 042737 160000 000034
 1938 005524 050137 000034
 1939 005530 000301
 1940 005532 006201
 1941 005534 006201
 1942 005536 010137 000570
 1943
 1944
 1945
 1946 005542
 1947 005542 005000
 1948 005544 066700 007210
 1949 005550 066700 007206
 1950 005554 001006
 1951 005556 012767 001233 007174
 1952 005564 012767 007622 007170
 1953 005572 005067 007104
 1954 005576 010767 007102
 1955 005602 062767 000042 007074
 1956 005610 016767 007064 007060
 1957 005616 005737 000042
 1958 005622 001407
 1959 005624 023737 000042 000046
 1960 005632 001403
 1961 005634 016767 007050 007034
 1962 005642
 1963
 1964
 1965
 1966 005642 012700 177770
 1967 005646 026027 014774 125252
 1968 005654 001401
 1969 005656 104006
 1970 005660 104400
 1971
 1972 005662 012700 000010
 1973 005666 022760 052525 014774
 1974 005674 001401
 1975 005676 104006
 1976 005700 104400
 1977
 1978 005702 012700 177770
 1979 005706 026060 014774 014774
 1980 005714 001401
 1981 005716 104006
 1982 005720 104400
 1983
 1984 005722 012700 000010
 1985 005726 026060 014774 014774
 1986 005734 001401
 1987 005736 104006

```

:.....
.SBTTL MAIN ROUTINE: CPU BACKGROUND TESTS
:.....
BEGINX: MOV PC,R1 ;SET UP R1 TO SELECT CURBNK
        BIC #17777,R1
        BIC #160000,@#34 ;SET SCOPE RET TO CURRENT BANK
        BIS R1,@#34
        SWAB R1
        ASR R1
        ASR R1
        MOV R1,@#CURBNK

: BINARY INSTRUCTIONS
: INDEX, AND INDIRECT TEST OF PDP-11
BEGIN:  CLR R0 ;CHECK RANDOM NUMBER GENERATOR SEEDS.
        ADD RP1,R0 ;AND RESTORE IF ZEROED.
        ADD RP2,R0
        BNE 1$ ;BR IF NOT ZEROED.
        MOV #1233,RP1 ;RESTORE RP1 SEED.
        MOV #7622,RP2 ;RESTORE RP2 SEED.
1$:     CLR SCOPEF
        MOV PC,RETURN ;FOR SCOPING - SETUP ADDRESS OF BEGIN1 IN
        ADD #42,RETURN ;THIS BANK THRU CURRENT ASR
        MOV $ICNT,ICOUNT ;ITERATION COUNT
        TST @#42 ;AUTO MODE?
        BEQ 2$ ;BR IF NOT.
        CMP @#42,@#46 ;XXDP CHAIN MODE?
        BEQ 2$ ;BR IF NOT.
        MOV XDPcnt,ICOUNT ;USE XXDP CHAIN ITERATION COUNT.
2$:

:.....
.SBTTL TEST COMPARE INSTRUCTION INDEXED
:.....
        MOV #-10,%0 ;MINUS 10 TO REG 0
        CMP A(0),#125252 ;(A INDEX BY MINUS 10) TO #125252
        BEQ .+4
        HLT ;COMPARE WITH INDEX FAILED
        SCOPE

        MOV #10,%0
        CMP #052525,A(0)
        BEQ .+4
        HLT
        SCOPE

        MOV #-10,%0
        CMP A(0),A(0)
        BEQ .+4
        HLT
        SCOPE

        MOV #+10,%0
        CMP A(0),A(0)
        BEQ .+4
        HLT
    
```

1988	005740	104400			SCOPE
1989					
1990	005742	012700	177774		MOV #-4,X0
1991	005746	012701	000010		MOV #+10,X1
1992	005752	026061	014774	014774	CMP A(0),A(1)
1993	005760	001401			BEQ .+4
1994	005762	104006			HLT
1995	005764	104400			SCOPE
1996					
1997	005766	012700	177774		MOV #-4,X0
1998	005772	012701	000010		MOV #10,X1
1999	005776	026160	014774	014774	CMP A(1),A(0)
2000	006004	001401			BEQ .+4
2001	006006	104006			HLT
2002	006010	104400			SCOPE
2003					
2004				
2005					.SBTTL TEST MOVE INSTRUCTION FOR INDEX
2006				
2007					
2008	006012	012700	177770		MOV #-10,X0
2009	006016	016067	014774	006772	MOV A(0),TEMP
2010	006024	026727	006766	125252	CMP TEMP,#125252
2011	006032	001401			BEQ .+4
2012	006034	104006			HLT
2013	006036	104400			SCOPE
2014					
2015	006040	012700	177770		MOV #-10,X0
2016	006044	012760	125252	015016	MOV #125252,TEMP(0)
2017	006052	023727	015006	125252	CMP @#C,#125252
2018	006060	001401			BEQ .+4
2019	006062	104006			HLT
2020	006064	104400			SCOPE
2021					
2022				
2023					.SBTTL TEST BIC INSTRUCTION FOR INDEXING
2024				
2025	006066	012767	177777	006722	MOV #-1,TEMP
2026	006074	012700	177770		MOV #-10,X0
2027	006100	046067	014774	006710	BIC A(0),TEMP
2028	006106	026727	006704	052525	CMP TEMP,#052525
2029	006114	001401			BEQ .+4
2030	006116	104006			HLT
2031	006120	104400			SCOPE
2032					
2033	006122	012700	177770		MOV #-10,X0
2034	006126	012767	1777	006652	MOV #-1,TEMP-10
2035	006134	042767	052525	006644	BIC #052525,TEMP-10
2036	006142	026727	006640	125252	CMP TEMP-10,#125252
2037	006150	001401			BEQ .+4
2038	006152	104006			HLT
2039	006154	104400			SCOPE
2040					
2041	006156	012737	125252	015016	MOV #125252,@#TEMP
2042	006164	012700	177770		MOV #-10,X0
2043	006170	166760	006570	015026	SUB B,TEMP+10(0)

2044	006176	001401			BEQ	.+4
2045	006200	104006			HLT	
2046	006202	104400			SCOPE	
2047						
2048	006204	012737	052525	015016	MOV	#052525,@#TEMP
2049	006212	012700	000010		MOV	#10,%0
2050	006216	166760	006562	015006	SUB	A+10,C(0)
2051	006224	001401			BEQ	.+4
2052	006226	104006			HLT	
2053	006230	104400			SCOPE	

 :SBTTL TEST UNARYS INDEXED

2058						
2059	006232	012737	177777	015016	MOV	#-1,@#TEMP
2060	006240	012700	000010		MOV	#+10,%0
2061	006244	005060	015006		CLR	C(0)
2062	006250	005737	015016		TST	@#TEMP
2063	006254	001401			BEQ	.+4
2064	006256	104006			HLT	
2065	006260	104400			SCOPE	
2066						
2067	006262	012737	177777	015016	MOV	#-1,@#TEMP
2068	006270	012700	000010		MOV	#10,%0
2069	006274	005160	015006		COM	C(0)
2070	006300	005737	015016		TST	@#TEMP
2071	006304	001401			BEQ	.+4
2072	006306	104006			HLT	
2073	006310	104400			SCOPE	
2074						
2075	006312	012737	177777	015016	MOV	#-1,@#TEMP
2076	006320	012700	177770		MOV	#-10,%0
2077	006324	005260	015026		INC	D(0)
2078	006330	005737	015016		TST	@#TEMP
2079	006334	001401			BEQ	.+4
2080	006336	104006			HLT	
2081	006340	104400			SCOPE	
2082						
2083	006342	012737	000001	015016	MOV	#1,@#TEMP
2084	006350	012700	177770		MOV	#-10,%0
2085	006354	005360	015026		DEC	D(0)
2086	006360	005737	015016		TST	@#TEMP
2087	006364	001401			BEQ	.+4
2088	006366	104006			HLT	
2089	006370	104400			SCOPE	
2090						
2091	006372	012737	000001	015016	MOV	#1,@#TEMP
2092	006400	012700	000010		MOV	#10,%0
2093	006404	005360	015006		DEC	C(0)
2094	006410	005737	015016		TST	@#TEMP
2095	006414	001401			BEQ	.+4
2096	006416	104006			HLT	
2097	006420	104400			SCOPE	
2098						
2099	006422	012737	000001	015016	MOV	#1,@#TEMP

2100	006430	012700	177770		MOV	#-10,%0
2101	006434	005460	015026		NEG	D(0)
2102	006440	022737	177777	0150'6	CMP	#-1,@#TEMP
2103	006446	001401			BEQ	+.4
2104	006450	104006			HLT	
2105	006452	104400			SCOPE	
2106						
2107	006454	012737	000001	015016	MOV	#1,@#TEMP
2108	006462	012700	000010		MOV	#+10,%0
2109	006466	005460	015006		NEG	(0)
2110	006472	022737	177777	015016	CMP	#-1,@#TEMP
2111	006500	001401			BEQ	+.4
2112	006502	104006			HLT	
2113	006504	104400			SCOPE	
2114						
2115	006506	012737	177777	015016	MOV	#-1,@#TEMP
2116	006514	012700	177770		MOV	#-10,%0
2117	006520	000261			SEC	
2118	006522	005560	015026		ADC	D(0)
2119	006526	005737	015016		TST	@#TEMP
2120	006532	001401			BEQ	+.4
2121	006534	104006			HLT	
2122	006536	104400			SCOPE	
2123						
2124	006540	012737	177777	015016	MOV	#-1,@#TEMP
2125	006546	012700	000010		MOV	#+10,%0
2126	006552	000261			SEC	
2127	006554	005560	015006		ADC	(0)
2128	006560	005737	015016		TST	@#TEMP
2129	006564	001401			BEQ	+.4
2130	006566	104006			HLT	
2131	006570	104400			SCOPE	
2132						
2133	006572	012737	000001	015016	MOV	#1,@#TEMP
2134	006600	012700	177770		MOV	#-10,%0
2135	006604	000261			SEC	
2136	006606	005660	015026		SBC	D(0)
2137	006612	005737	015016		TST	@#TEMP
2138	006616	001401			BEQ	+.4
2139	006620	104006			HLT	
2140	006622	104400			SCOPE	
2141						
2142	006624	012737	000001	015016	MOV	#1,@#TEMP
2143	006632	012700	000010		MOV	#+10,%0
2144	006636	000261			SEC	
2145	006640	005660	015006		SBC	(0)
2146	006644	005737	015016		TST	@#TEMP
2147	006650	001401			BEQ	+.4
2148	006652	104006			HLT	
2149	006654	104400			SCOPE	

.....
 ;SBTTL TEST JMP INDIRECT
 ;.....

2154	006656	010700			MOV	%7,%0
2155	006660	062700	000010		ADD	#10,%0


```

2156 006664 000110          JMP      @%0
2157 006666 104006          HLT
2158 006670 000240          NOP
2159 006672 104400          SCOPE
2160
2161 006674 010700          MOV      %7,%0
2162 006676 0627C3 000010        ADD      #10,%0
2163 006702 000110          JMP      @%0
2164 006704 104006          HLT
2165 006706 000240          NOP
2166 006710 104400          SCOPE
2167
2168
2169 :.....
2170 :SBTTL TEST INDIRECT ADDRESSINGTEST COMPARE INSTRUCTION
2171 :.....
2171 006712 023727 014764 125252        CMP      @#B,#125252
2172 006720 001401          BEQ      .+4
2173 006722 104006          HLT
2174 006724 104400          SCOPE
2175
2176 006726 022737 125252 014764        CMP      #125252,@#B
2177 006734 001401          BEQ      .+4
2178 006736 104006          HLT
2179 006740 104400          SCOPE
2180
2181 006742 023737 014764 014764        CMP      @#B,@#B
2182 006750 001401          BEQ      .+4
2183 006752 104006          HLT
2184 006754 104400          SCOPE
2185
2186 :.....
2187 :SBTTL TEST MOVE INSTRUCTIONS
2188 :.....
2189 006756 013700 014764          MOV      @#B,%0
2190 006762 022700 125252        CMP      #125252,%0
2191 006766 001401          BEQ      .+4
2192 006770 104006          HLT
2193 006772 104400          SCOPE
2194
2195 006774 012737 125252 015016        MOV      #125252,@#TEMP
2196 007002 023737 014764 015016        CMP      @#B,@#TEMP
2197 007010 001401          BEQ      .+4
2198 007012 104006          HLT
2199 007014 104400          SCOPE
2200
2201 007016 013737 014764 015006        MOV      @#B,@#C
2202 007024 023737 014764 015006        CMP      @#B,@#C
2203 007032 001401          BEQ      .+4
2204 007034 104006          HLT
2205 007036 104400          SCOPE
2206
2207 :.....
2208 :SBTTL TEST BIC INSTRUCTION INDIRECT
2209 :.....
2210 007040 012700 177777        MOV      #-1,%0
2211 007044 043700 014764        BIC      @#B,%0
    
```

```

2212 007050 020027 052525      CMP      %0,#052525
2213 007054 001401              BEQ      .+4
2214 007056 104006              HLT
2215 007060 104400              SCOPE
2216
2217 007062 012737 177777 015016      MOV      #-1,@#TEMP
2218 007070 042737 125252 015016      BIC      #125252,@#TEMP
2219 007076 022737 052525 015016      CMP      #052525,@#TEMP
2220 007104 001401              BEQ      .+4
2221 007106 104006              HLT
2222 007110 104400              SCOPE
2223
2224 007112 012737 177777 015006      MOV      #-1,@#C
2225 007120 043737 014764 015006      BIC      @#B,@#C
2226 007126 023727 015006 052525      CMP      @#C,#52525
2227 007134 001401              BEQ      .+4
2228 007136 104006              HLT
2229 007140 104400              SCOPE
2230
2231
2232
2233

```

.....
 :SBTTL TEST SUBTRACT INSTRUCTION
 :.....

```

2234 007142 012700 125252      MOV      #125252,%0
2235 007146 163700 014764      SUB      @#B,%0
2236 007152 020027 000000      CMP      %0,#0
2237 007156 001401              BEQ      .+4
2238 007160 104006              HLT
2239 007162 104400              SCOPE
2240
2241 007164 012737 125252 015016      MOV      #125252,@#TEMP
2242 007172 166737 005566 015016      SUB      B,@#TEMP
2243 007200 001401              BEQ      .+4
2244 007202 104006              HLT
2245 007204 104400              SCOPE
2246
2247 007206 012767 125252 005602      MOV      #125252,TEMP
2248 007214 163767 014764 005574      SUB      @#B,TEMP
2249 007222 005767 005570      TST     TEMP
2250 007226 001401              BEQ      .+4
2251 007230 104006              HLT
2252 007232 104400              SCOPE
2253
2254
2255
2256

```

.....
 :SBTTL TEST ADD INDIRECT
 :.....

```

2257 007234 005000              CLR      %0
2258 007236 063700 014764      ADD      @#B,%0
2259 007242 022700 125252      CMP      #125252,%0
2260 007246 001401              BEQ      .+4
2261 007250 104006              HLT
2262 007252 104400              SCOPE
2263
2264 007254 005037 015016      CLR      @#TEMP
2265 007260 062737 125252 015016      ADD      #125252,@#TEMP
2266 007266 022737 125252 015016      CMP      #125252,@#TEMP
2267 007274 001401              BEQ      .+4

```

```

2268 C07276 104006          HLT
2269 007300 104400          SCOPE
2270
2271 007302 012737 125252 015016  MOV    #125252,@#TEMP
2272 007310 067737 005466 015016  ADD    @A+6,@#TEMP
2273 007316 023727 015016 177777  CMP    @#TEMP,#-1
2274 007324 001401          BEQ    .+4
2275 007326 104006          HLT
2276 007330 104400          SCOPE
2277
2278 .....
2279 :SBTTL TEST UNARYS INDIRECT
2280 :.....
2281 007332 012737 177777 015016  MOV    #-1,@#TEMP
2282 007340 005037 015016          CLR    @#TEMP
2283 007344 005737 015016          TST    @#TEMP
2284 007350 001401          BEQ    .+4
2285 007352 104006          HLT
2286 007354 104400          SCOPE
2287
2288 007356 012737 125252 015016  MOV    #125252,@#TEMP
2289 007364 005137 015016          COM    @#TEMP
2290 007370 022737 052525 015016  CMP    #052525,@#TEMP
2291 007376 001401          BEQ    .+4
2292 007400 104006          HLT
2293 007402 104400          SCOPE
2294
2295 007404 005037 015016          CLR    @#TEMP
2296 007410 005237 015016          INC    @#TEMP
2297 007414 022737 000001 015016  CMP    #1,@#TEMP
2298 007422 001401          BEQ    .+4
2299 007424 104006          HLT
2300 007426 104400          SCOPE
2301
2302 007430 005037 015016          CLR    @#TEMP
2303 007434 005377 005360          DEC    @TEMP+2
2304 007440 023727 015016 177777  CMP    @#TEMP,#-1
2305 007446 001401          BEQ    .+4
2306 007450 104006          HLT
2307 007452 104400          SCOPE
2308
2309 007454 012737 000001 015016  MOV    #1,@#TEMP
2310 007462 005437 015016          NEG    @#TEMP
2311 007466 022737 177777 015016  CMP    #-1,@#TEMP
2312 007474 001401          BEQ    .+4
2313 007476 104006          HLT
2314 007500 104400          SCOPE
2315
2316 .....
2317 :SBTTL TEST INDIRECT ADDRESSING WITH INDEXING, TEST COMPARE INSTRUCTION
2318 :.....
2319 007502 027727 005260 125252  CMP    @B+2,#125252
2320 007510 001401          BEQ    .+4
2321 007512 104006          HLT
2322 007514 104400          SCOPE
2323
    
```

2324	007516	022777	125252	005242	CMP	#125252,@B+2
2325	007524	001401			BEQ	+.4
2326	007526	104006			HLT	
2327	007530	104400			SCOPE	
2328						
2329	007532	027777	00523C	005226	CMP	@B+2,@B+2
2330	007540	001401			BEQ	+.4
2331	007542	104006			HLT	
2332	007544	104400			SCOPE	
2333						
2334						
2335						
2336						
2337	007546	017700	005214		MOV	@B+2,%0
2338	007552	022700	125252		CMP	#125252,%0
2339	007556	001401			BEQ	+.4
2340	007560	104006			HLT	
2341	007562	104400			SCOPE	
2342						
2343	007564	012777	125252	005226	MOV	#125252,@TEMP+2
2344	007572	023737	014764	015016	CMP	@B,@TEMP
2345	007600	001401			BEQ	+.4
2346	007602	104006			HLT	
2347	007604	104400			SCOPE	
2348						
2349	007606	017777	005154	005174	MOV	@B+2,@C+2
2350	007614	023737	014764	015006	CMP	@B,@C
2351	007622	001401			BEQ	+.4
2352	007624	104006			HLT	
2353	007626	104400			SCOPE	
2354						
2355						
2356						
2357						
2358	007630	012700	177777		MOV	#-1,%0
2359	007634	047700	005126		BIC	@B+2,%0
2360	007640	020027	052525		CMP	%0,#52525
2361	007644	001401			BEQ	+.4
2362	007646	104006			HLT	
2363	007650	104400			SCOPE	
2364						
2365	007652	012737	177777	015016	MOV	#-1,@TEMP
2366	007660	042777	125252	005132	BIC	#125252,@TEMP+2
2367	007666	022737	052525	015016	CMP	#52525,@TEMP
2368	007674	001401			BEQ	+.4
2369	007676	104006			HLT	
2370	007700	104400			SCOPE	
2371						
2372	007702	012737	177777	015006	MOV	#-1,@C
2373	007710	047777	005052	005072	BIC	@B+2,@C+2
2374	007716	026737	005062	015006	CMP	A+10,@C
2375	007724	001401			BEQ	+.4
2376	007726	104006			HLT	
2377	007730	104400			SCOPE	
2378						
2379	007732	012700	125252		MOV	#125252,%0

.....
:SBTTL TEST MOVE INSTRUCTIONS
:.....

.....
:SBTTL TEST BIC INSTRUCTION INDIRECT WITH INDEXING
:.....

2380	007736	167700	005024		SUB	@B+2,X0
2381	007742	020027	000000		CMR	X0,#0
2382	007746	001401			BEQ	.+4
2383	007750	104006			HLT	
2384	007752	104400			SCOPE	
2385						
2386	007754	012737	125252	015016	MOV	#125252,@#TEMP
2387	007762	166777	004776	005030	SUB	B,@TEMP+2
2388	007770	001401			BEQ	.+4
2389	007772	104006			HLT	
2390	007774	104400			SCOPE	
2391						
2392	007776	012737	125252	015016	MOV	#125252,@#TEMP
2393	010004	167777	004756	005006	SUB	@B+2,@TEMP+2
2394	010012	005737	015016		TST	@#TEMP
2395	010016	001401			BEQ	.+4
2396	010020	104006			HLT	
2397	010022	104400			SCOPE	
2398						
2399						

.....
 :SBTTL TEST ADD INDIRECT WITH INDEXING
 :.....

2402	010024	005000			CLR	X0
2403	010026	067700	004734		ADD	@B+2,X0
2404	010032	022700	125252		CMR	#125252,X0
2405	010036	001401			BEQ	.+4
2406	010040	104006			HLT	
2407	010042	104400			SCOPE	
2408						
2409	010044	005037	015016		CLR	@#TEMP
2410	010050	062777	125252	004742	ADD	#125252,@TEMP+2
2411	010056	022737	125252	015016	CMR	#125252,@#TEMP
2412	010064	001401			BEQ	.+4
2413	010066	104006			HLT	
2414	010070	104400			SCOPE	
2415						
2416	010072	012737	125252	015016	MOV	#125252,@#TEMP
2417	010100	067777	004676	004712	ADD	@A+6,@TEMP+2
2418	010106	023727	015016	177777	CMR	@#TEMP,#-1
2419	010114	001401			BEQ	.+4
2420	010116	104006			HLT	
2421	010120	104400			SCOPE	
2422						

.....
 :SBTTL TEST UNARYS INDIRECT WITH INDEXING
 :.....

2426	010122	012737	177777	015016	MOV	#-1,@#TEMP
2427	010130	005077	004664		CLR	@TEMP+2
2428	010134	005737	015016		TST	@#TEMP
2429	010140	001401			BEQ	.+4
2430	010142	104006			HLT	
2431	010144	104400			SCOPE	
2432						
2433	010146	012737	125252	015016	MOV	#125252,@#TEMP
2434	010154	005177	004640		CMR	@TEMP+2
2435	010160	022737	052525	015016	CMR	#052525,@#TEMP

2436	010166	001401			BEQ	.+4
2437	010170	104006			HLT	
2438	010172	104400			SCOPE	
2439						
2440	010174	005037	015016		CLR	@#TEMP
2441	010200	005277	004614		INC	@TEMP+2
2442	010204	022737	000001	015016	CMP	#1,@#TEMP
2443	010212	001401			BEQ	.+4
2444	010214	104006			HLT	
2445	010216	104400			SCOPE	
2446						
2447	010220	005037	015016		CLR	@#TEMP
2448	010224	005377	004570		DEC	@TEMP+2
2449	010230	023727	015016	177777	CMP	@#TEMP,#-1
2450	010236	001401			BEQ	.+4
2451	010240	104006			HLT	
2452	010242	104400			SCOPE	
2453						
2454	010244	012737	000001	015016	MOV	#1,@#TEMP
2455	010252	005477	004542		NEG	@TEMP+2
2456	010256	022737	177777	015016	CMP	#-1,@#TEMP
2457	010264	001401			BEQ	.+4
2458	010266	104006			HLT	
2459	010270	104400			SCOPE	
2460						
2461	010272	012737	177777	015016	MOV	#-1,@#TEMP
2462	010300	000261			SEC	
2463	010302	005577	004512		ADC	@TEMP+2
2464	010306	005737	015016		TST	@#TEMP
2465	010312	001401			BEQ	.+4
2466	010314	104006			HLT	
2467	010316	104400			SCOPE	
2468						
2469	010320	012737	000001	015016	MOV	#1,@#TEMP
2470	010326	000261			SEC	
2471	010330	005677	004464		SBC	@TEMP+2
2472	010334	005737	015016		TST	@#TEMP
2473	010340	001401			BEQ	.+4
2474	010342	104006			HLT	
2475	010344	104400			SCOPE	
2476						
2477						
2478						
2479						
2480	010346	012700	177772		MOV	#-6,%0
2481	010352	027027	014774	125252	CMP	@A(0),#125252
2482	010360	001401			BEQ	.+4
2483	010362	104006			HLT	
2484	010364	104400			SCOPE	
2485						
2486	010366	012700	177772		MOV	#-6,%0
2487	010372	022770	125252	014774	CMP	#125252,@A(0)
2488	010400	001401			BEQ	.+4
2489	010402	104006			HLT	
2490	010404	104400			SCOPE	
2491						

.....
 :SBTIL TEST OF COMBINED INDEXING AND INDIRECT
 :.....

```

2492 010406 012700 177772      MOV      #-6,X0
2493 010412 012701 000002      MOV      #+2,X1
2494 010416 027071 014774 014774  CMP      @A(0),@A(1)
2495 010424 001401      BEQ      .+4
2496 010426 104006      HLT
2497 010430 104400      SCOPE
2498
2499
2500 :.....
2501 :SBTTL TEST BIC INSTRUCTION
2502 :.....
2502 010432 012700 000006      MOV      #+6,X0
2503 010436 012767 177777 004352      MOV      #-1,TEMP
2504 010444 047067 014774 004344      BIC      @A(0),TEMP
2505 010452 022767 125252 004336      CMP      #125252,TEMP
2506 010460 001401      BEQ      .+4
2507 010462 104006      HLT
2508 010464 104400      SCOPE
2509
2510 010466 012700 177772      MOV      #-6,X0
2511 010472 012737 177777 015006      MOV      #-1,@#C
2512 010500 042770 125252 015016      BIC      #125252,@TEMP(0)
2513 010506 023727 015006 052525      CMP      @#C,#052525
2514 010514 001401      BEQ      .+4
2515 010516 104006      HLT
2516 010520 104400      SCOPE
2517
2518 010522 012737 177777 015006      MOV      #-1,@#C
2519 010530 012700 177772      MOV      #-6,X0
2520 010534 012701 177772      MOV      #-6,X1
2521 010540 047071 014774 015016      BIC      @A(0),@TEMP(1)
2522 010546 022737 052525 015006      CMP      #052525,@#C
2523 010554 001401      BEQ      .+4
2524 010556 104006      HLT
2525 010560 104400      SCOPE
2526
2527 :BINARY INSTRUCTIONS
2528 :INDEX, AND INDIRECT TEST OF PDP-11
2529 :.....
2530 :SBTTL TEST COMPARE INSTRUCTION INDEXED
2531 :.....
2532 010562 012700 177770      MOV      #-10,X0      ;MINUS 10 TO REG 0
2533 010566 126027 014774 000252  CMPB     A(0),#000252  ;(A INDEX BY MINUS 10) TO #125252
2534 010574 001401      BEQ      .+4
2535 010576 104006      HLT      ;COMPARE WITH INDEX FAILED
2536 010600 104400      SCOPE
2537
2538 010602 012700 177770      MOV      #-10,X0      ;FOR INDEX
2539 010606 122760 000252 014774  CMPB     #000252,A(0)  ;A INDEXED
2540 010614 001401      BEQ      .+4
2541 010616 104006      HLT
2542 010620 104400      SCOPE
2543
2544 010622 012700 000010      MOV      #10,X0      ;INDEX
2545 010626 126027 014774 000125  CMPB     A(0),#000125
2546 010634 001401      BEQ      .+4
2547 010636 104006      HLT
    
```

2548	010640	104400			SCOPE	
2549						
2550	010642	012700	000010		MOV	#10,Z0
2551	010644	122760	000125	014774	CMPB	#000125,A(0)
2552	010654	001401			BEQ	.+4
2553	010656	104006			HLT	
2554	010660	104400			SCOPE	
2555						
2556	010662	012700	177770		MOV	#-10,Z0
2557	010666	126060	014774	014774	CMPB	A(0),A(0)
2558	010674	001401			BEQ	.+4
2559	010676	104006			HLT	
2560	010700	104400			SCOPE	
2561						
2562	010702	012700	000010		MOV	#+10,Z0
2563	010706	126060	014774	014774	CMPB	A(0),A(0)
2564	010714	001401			BEQ	.+4
2565	010716	104006			HLT	
2566	010720	104400			SCOPE	
2567						
2568	010722	012700	177770		MOV	#-10,Z0
2569	010726	012701	000004		MOV	#+4,Z1
2570	010732	126061	014774	014774	CMPB	A(0),A(1)
2571	010740	001401			BEQ	.+4
2572	010742	104006			HLT	
2573	010744	104400			SCOPE	
2574						
2575	010746	126160	014774	014774	CMPB	A(1),A(0)
2576	010754	001401			BEQ	.+4
2577	010756	104006			HLT	
2578	010760	104400			SCOPE	
2579						
2580	010762	012700	177774		MOV	#-4,Z0
2581	010766	012701	000010		MOV	#+10,Z1
2582	010772	126061	014774	014774	CMPB	A(0),A(1)
2583	011000	001401			BEQ	.+4
2584	011002	104006			HLT	
2585	011004	104400			SCOPE	
2586						
2587	011006	012700	177774		MOV	#-4,Z0
2588	011012	012701	000010		MOV	#10,Z1
2589	011016	126160	014774	014774	CMPB	A(1),A(0)
2590	011024	001401			BEQ	.+4
2591	011026	104006			HLT	
2592	011030	104400			SCOPE	
2593						
2594						
2595						
2596						
2597	011032	012700	177770		MOV	#-10,Z0
2598	011036	116067	014774	003752	MOVB	A(0),TEMP
2599	011044	126727	003746	000252	CMPB	TEMP,#000252
2600	011052	001401			BEQ	.+4
2601	011054	104006			HLT	
2602	011056	104400			SCOPE	
2603						

.....
 :SBTTL TEST MOVE INSTRUCTION FOR INDEX
 :.....

2604	011060	012700	000010		MOV	#+10,%0
2605	011064	116067	014774	003724	MOVB	A(0),TEMP
2606	011072	126727	003720	000125	CMPB	TEMP,#000125
2607	011100	001401			BEQ	+.4
2608	011102	104006			HLT	
2609	011104	104400			SCOPE	
2610						
2611	011106	012700	177770		MOV	#-10,%0
2612	011112	112760	125252	015016	MOVB	#125252,TEMP(0)
2613	011120	123727	015006	125252	CMPB	@#C,#125252
2614	011126	001401			BEQ	+.4
2615	011130	104006			HLT	
2616	011132	104400			SCOPE	
2617						
2618	011134	012700	000010		MOV	#+10,%0
2619	011140	112760	052525	015016	MOVB	#052525,TEMP(0)
2620	011146	123727	015026	052525	CMPB	@#TEMP+10,#052525
2621	011154	001401			BEQ	+.4
2622	011156	104006			HLT	
2623	011160	104400			SCOPE	
2624						
2625						
2626						
2627						
2628	011162	012767	177777	003626	MOV	#-1,TEMP
2629	011170	012700	177770		MOV	#-10,%0
2630	011174	146067	014774	003614	BICB	A(0),TEMP
2631	011202	126727	003610	177525	CMPB	TEMP,#177525
2632	011210	001401			BEQ	+.4
2633	011212	104006			HLT	
2634	011214	104400			SCOPE	
2635						
2636	011216	012767	177777	003572	MOV	#-1,TEMP
2637	011224	012700	000010		MOV	#10,%0
2638	011230	146067	014774	003560	BICB	A(0),TEMP
2639	011236	126727	003554	007652	CMPB	TEMP,#007652
2640	011244	001401			BEQ	+.4
2641	011246	104006			HLT	
2642	011250	104400			SCOPE	
2643						
2644	011252	012737	177777	015026	MOV	#-1,@#TEMP+10
2645	011260	012700	000010		MOV	#10,%0
2646	011264	142760	125252	015016	BICB	#125252,TEMP(0)
2647	011272	123727	015026	002525	CMPB	@#TEMP+10,#2525
2648	011300	001401			BEQ	+.4
2649	011302	104006			HLT	
2650	011304	104400			SCOPE	
2651						
2652	011306	012700	177770		MOV	#-10,%0
2653	011312	012767	177777	003466	MOV	#-1,TEMP-10
2654	011320	142767	052525	003460	BICB	#052525,TEMP-10
2655	011326	126727	003454	125252	CMPB	TEMP-10,#125252
2656	011334	001401			BEQ	+.4
2657	011336	104006			HLT	
2658	011340	104400			SCOPE	
2659						

.....
 :SBTTL TEST BIC INSTRUCTION FOR INDEXING
 :.....

Address	Op1	Op2	Op3	Op4	Instruction
2660				
2661					SBITL TEST UNARYS INDEXED
2662				
2663	011342	012737	177777	015016	MOV #-1,@TEMP
2664	011350	012700	177770		MOV #-10,%0
2665	011354	105060	015026		CLRB D(0)
2666	011360	105737	015016		TSTB @TEMP
2667	011364	001401			BEQ .+4
2668	011366	104006			HLT
2669	011370	104400			SCOPE
2670					
2671	011372	012737	177777	015016	MOV #-1,@TEMP
2672	011400	012700	177770		MOV #-10,%0
2673	011404	105060	015026		CLRB D(0)
2674	011410	023727	015016	177400	CMP @TEMP,#177400
2675	011416	001401			BEQ .+4
2676	011420	104006			HLT
2677	011422	104400			SCOPE
2678					
2679	011424	012737	177777	015016	MOV #-1,@TEMP
2680	011432	012700	177771		MOV #-7,%0
2681	011436	105060	015026		CLRB D(0)
2682	011442	023727	015016	000377	CMP @TEMP,#000377
2683	011450	001401			BEQ .+4
2684	011452	104006			HLT
2685	011454	104400			SCOPE
2686					
2687	011456	012737	177777	015016	MOV #-1,@TEMP
2688	011464	012700	000010		MOV #-10,%0
2689	011470	105060	015006		CLRB C(0)
2690	011474	105737	015016		TSTB @TEMP
2691	011500	001401			BEQ .+4
2692	011502	104006			HLT
2693	011504	104400			SCOPE
2694					
2695	011506	012737	177777	015016	MOV #-1,@TEMP
2696	011514	012700	177770		MOV #-10,%0
2697	011520	105160	015026		COMB D(0)
2698	011524	105737	015016		TSTB @TEMP
2699	011530	001401			BEQ .+4
2700	011532	104006			HLT
2701	011534	104400			SCOPE
2702					
2703	011536	012737	177777	015016	MOV #-1,@TEMP
2704	011544	012700	000010		MOV #-10,%0
2705	011550	105260	015006		INCB C(0)
2706	011554	105737	015016		TSTB @TEMP
2707	011560	001401			BEQ .+4
2708	011562	104006			HLT
2709	011564	104400			SCOPE
2710					
2711	011566	012737	000001	015016	MOV #1,@TEMP
2712	011574	012700	177770		MOV #-10,%0
2713	011600	105360	015026		DECB D(0)
2714	011604	105737	015016		TSTB @TEMP
2715	011610	001401			BEQ .+4

2716	011612	104006			HLT	
2717	011614	104400			SCOPE	
2718						
2719	011616	012737	000001	015016	MOV	#1,@TEMP
2720	011624	012700	000010		MOV	#+10,X0
2721	011630	105460	015006		NEGB	(0)
2722	011634	023727	015016	000377	CMF	@TEMP,#377
2723	011642	001401			BEQ	.+4
2724	011644	104006			HLT	
2725	011646	104400			SCOPE	
2726						
2727	011650	012737	177777	015016	MOV	#-1,@TEMP
2728	011656	012700	177770		MOV	#-10,X0
2729	011662	000261			SEC	
2730	011664	105560	015026		ADCB	D(0)
2731	011670	023727	015016	177400	CMF	@TEMP,#177400
2732	011676	001401			BEQ	.+4
2733	011700	104006			HLT	
2734	011702	104400			SCOPE	
2735						
2736	011704	012737	000001	015016	MOV	#1,@TEMP
2737	011712	012700	000010		MOV	#+10,X0
2738	011716	000261			SEC	
2739	011720	105660	015006		SBCB	(0)
2740	011724	005737	015016		TST	@TEMP
2741	011730	001401			BEQ	.+4
2742	011732	104006			HLT	
2743	011734	104400			SCOPE	
2744						
2745						
2746						
2747						
2748	011736	123727	014764	000252	CMFB	@B,#000252
2749	011744	001401			BEQ	.+4
2750	011746	104006			HLT	
2751	011750	104400			SCOPE	
2752						
2753	011752	122737	125252	014764	CMFB	#125252,@B
2754	011760	001401			BEQ	.+4
2755	011762	104006			HLT	
2756	011764	104400			SCOPE	
2757						
2758						
2759						
2760						
2761	011766	113700	014764		MOVB	@B,X0
2762	011772	122700	000252		CMFB	#000252,X0
2763	011776	001401			BEQ	.+4
2764	012000	104006			HLT	
2765	012002	104400			SCOPE	
2766						
2767	012004	112737	125252	015016	MOVB	#125252,@TEMP
2768	012012	126737	002746	015016	CMFB	B,@TEMP
2769	012020	001401			BEQ	.+4
2770	012022	104006			HLT	
2771	012024	104400			SCOPE	

.....
 :SBTTL TEST INDIRECT ADDRESSING, TEST COMPARE INSTRUCTION
 :.....

.....
 :SBTTL TEST MOVE INSTRUCTIONS
 :.....

```

2772
2773
2774
2775
2776 012026 012737 177777 015016
2777 012034 105037 015016
2778 012040 023727 015016 177400
2779 012046 001401
2780 012050 104006
2781 012052 104400
2782
2783 012054 012737 125252 015016
2784 012062 105137 015017
2785 012066 022737 052652 015016
2786 012074 001401
2787 012076 104006
2788 012100 104400
2789
2790 012102 005037 015016
2791 012106 105237 015017
2792 012112 022737 000400 015016
2793 012120 001401
2794 012122 104006
2795 012124 104400
2796
2797 012126 005037 015016
2798 012132 105377 002662
2799 012136 023727 015016 000377
2800 012144 001401
2801 012146 104006
2802 012150 104400
2803
2804 012152 005037 015016
2805 012156 112737 000001 015017
2806 012164 105437 015017
2807 012170 022737 177400 015016
2808 012176 001401
2809 012200 104006
2810 012202 104400
2811
2812
2813
2814
2815
2816 012204 122777 125252 002554
2817 012212 001401
2818 012214 104006
2819 012216 104400
2820
2821 012220 127777 002542 002540
2822 012226 001401
2823 012230 104006
2824 012232 104400
2825
2826
2827

```

.....
 .SBTTL TEST UNARYS INDIRECT

.....
 .SBTTL TEST INDIRECT ADDRESSING WITH INDEXING, TEST COMPARE INSTRUCTION

.....
 .SBTTL TEST MOVE INSTRUCTIONS

2828										
2829	012234	117700	002526			MOVB	@B+2,%0			
2830	012240	122700	125252			CMPB	#125252,%0			
2831	012244	001401				BEQ	.+4			
2832	012246	104006				HLT				
2833	012250	104400				SCOPE				
2834										
2835	012252	112777	125252	002540		MOVB	#125252,@TEMP+2			
2836	012260	126737	002500	015016		CMPB	B,@TEMP			
2837	012266	001401				BEQ	.+4			
2838	012270	104006				HLT				
2839	012272	104400				SCOPE				
2840										
2841	012274	117777	002466	002506		MOVB	@B+2,@C+2			
2842	012302	126737	002456	015006		CMPB	B,@C			
2843	012310	001401				BEQ	.+4			
2844	012312	104006				HLT				
2845	012314	104400				SCOPE				
2846										
2847										
2848										
2849										
2850	012316	012700	177777			MOV	#-1,%0			
2851	012322	147700	002440			BICB	@B+2,%0			
2852	012326	120027	052525			CMPB	%0,#52525			
2853	012332	001401				BEQ	.+4			
2854	012334	104006				HLT				
2855	012336	104400				SCOPE				
2856										
2857	012340	012737	177777	015016		MOV	#-1,@TEMP			
2858	012346	142777	125252	002444		BICB	#125252,@TEMP+2			
2859	012354	122737	052525	015016		CMPB	#52525,@TEMP			
2860	012362	001401				BEQ	.+4			
2861	012364	104006				HLT				
2862	012366	104400				SCOPE				
2863										
2864	012370	012737	177777	015006		MOV	#-1,@C			
2865	012376	147777	002364	002404		BICB	@B+2,@C+2			
2866	012404	126737	002374	015006		CMPB	A+10,@C			
2867	012412	001401				BEQ	.+4			
2868	012414	104006				HLT				
2869	012416	104400				SCOPE				
2870										
2871										
2872										
2873										
2874	012420	012737	177777	015016		MOV	#-1,@TEMP			
2875	012426	105077	002366			CLRB	@TEMP+2			
2876	012432	105737	015016			TSTB	@TEMP			
2877	012436	001401				BEQ	.+4			
2878	012440	104006				HLT				
2879	012442	104400				SCOPE				
2880										
2881	012444	005037	015016			CLR	@TEMP			
2882	012450	105277	002344			INCB	@TEMP+2			
2883	012454	122737	000001	015016		CMPB	#1,@TEMP			

2884	012462	001401			BEQ	.+4
2885	012464	104006			HLT	
2886	012466	104400			SCOPE	
2887						
2888	012470	005037	015016		CLR	@TEMP
2889	012474	105377	002320		DECB	@TEMP+2
2890	012500	123727	015016	177777	CMPB	@TEMP,#-1
2891	012506	001401			BEQ	.+4
2892	012510	104006			HLT	
2893	012512	104400			SCOPE	
2894						
2895	012514	012737	000001	015016	MOV	#1,@TEMP
2896	012522	105477	002272		NEGB	@TEMP+2
2897	012526	122737	177777	015016	CMPB	#-1,@TEMP
2898	012534	001401			BEQ	.+4
2899	012536	104006			HLT	
2900	012540	104400			SCOPE	
2901						
2902	012542	012737	177777	015016	MOV	#-1,@TEMP
2903	012550	000261			SEC	
2904	012552	105577	002242		ADCB	@TEMP+2
2905	012556	022737	177400	015016	CMF	#177400,@TEMP
2906	012564	001401			BEQ	.+4
2907	012566	104006			HLT	
2908	012570	105737	015016		TSTB	@TEMP
2909	012574	001401			BEQ	.+4
2910	012576	104006			HLT	
2911	012600	104400			SCOPE	
2912						
2913	012602	012737	000001	015016	MOV	#1,@TEMP
2914	012610	000261			SEC	
2915	012612	105377	002202		DECB	@TEMP+2
2916	012616	005737	015016		TST	@TEMP
2917	012622	001401			BEQ	.+4
2918	012624	104006			HLT	
2919	012626	104400			SCOPE	
2920						

```

:.....
:SBTTL TEST OF COMBINED INDEXING AND INDIRECT
:.....

```

2924	012630	012700	177772		MOV	#-6,X0
2925	012634	127027	014774	125252	CMPB	@A(0),#125252
2926	012642	001401			BEQ	.+4
2927	012644	104006			HLT	
2928	012646	104400			SCOPE	
2929						
2930	012650	012700	177772		MOV	#-6,X0
2931	012654	012701	000002		MOV	#+2,X1
2932	012660	127071	014774	014774	CMPB	@A(0),@A(1)
2933	012666	001401			BEQ	.+4
2934	012670	104006			HLT	
2935	012672	104400			SCOPE	
2936						

```

:.....
:SBTTL TEST BIC INSTRUCTION
:.....

```

2936
2937
2938
2939

```

2940 012674 012700 000006      MOV      #+6,Z0
2941 012700 012767 177777 002110      MOV      #-1,TEMP
2942 012706 147067 014774 002102      BICB    @A(0),TEMP
2943 012714 122767 125252 002074      CMPB    #125252,TEMP
2944 012722 001401              BEQ     .+4
2945 012724 104006              HLT
2946 012726 104400              SCOPE
2947
2948 012730 012700 177772      MOV      #-6,Z0
2949 012734 012737 177777 015006      MOV      #-1,@#C
2950 012742 142770 125252 015016      BICB    #125252,@TEMP(0)
2951 012750 123727 015006 000125      CMPB    @#C,#000125
2952 012756 001401              BEQ     .+4
2953 012760 104006              HLT
2954 012762 104400              SCOPE
2955
2956 012764 012700 014766      MOV      #B+2,Z0      ;ADDRESS OF ADDRESS OF B
2957 012770 023067 00177C      CMP      @-(0),B
2958 012774 001401              BEQ     .+4
2959 012776 104006              HLT
2960 013000 104400              SCOPE
2961
2962 013002 012700 014770      MOV      #B+4,Z0
2963 013006 025067 001752      CMP      @-(0),B
2964 013012 001401              BEQ     .+4
2965 013014 104006              HLT
2966 013016 104400              SCOPE
2967
2968 013020 012700 014770      MOV      #B+4,Z0
2969 013024 125067 001734      CMPB    @-(0),B
2970 013030 001401              BEQ     .+4
2971 013032 104006              HLT
2972 013034 104400              SCOPE
2973
2974 013036 012700 015012      MOV      #C+4,Z0
2975 013042 012737 177777 015006      MOV      #-1,@#C
2976 013050 105050              CLRB    @-(0)
2977 013052 023727 015006 177400      CMP      @#C,#177400
2978 013060 001401              BEQ     .+4
2979 013062 104006              HLT
2980 013064 104400              SCOPE
2981
2982 013066 012737 177777 015006      MOV      #-1,@#C
2983 013074 012700 177772      MOV      #-6,Z0
2984 013100 012701 177772      MOV      #-6,Z1
2985 013104 147071 014774 015016      BICB    @A(0),@TEMP(1)
2986 013112 022737 177525 015006      CMP      #177525,@#C
2987 013120 001401              BEQ     .+4
2988 013122 104006              HLT
2989 013124 104400              SCOPE
2990

```

```

2991 ;.....
2992 ;SBTTL SET UP TO TEST THAT R0 IS NOT DESTROYED BY FALSE SELECTION
2993 ;.....
2994 013126 012700 052525      MOV      #52525,Z0      ;THIS IS CHECKED LATER IN PROGRAM
2995

```

```

2996 :.....
2997 :SBTTL TEST JSR INSTRUCTION
2998 :.....
2999 013132 004767 000002          JSR      %7, TJSR2          ;PLACE PC ON STACK
3000 013136 000405          TJSR1: BR      TJSR3          ;RETURN HERE ON RTS %19
3001 013140 121627 013136          TJSR2: CMPB   @%6, #TJSR1     ;CHECK FOR CORRECT PC ON STACK
3002 013144 001401          BEQ      .+4
3003 013146 104006          HLT
3004 013150 000207          RTS      %7          ;INCORRECT PC ON STACK
3005 013152 104400          TJSR3: SCOPE          ;RETURN TO IMST AFTER JSR
3006
3007 013154 000257          CCC
3008 013156 004717          JSR      %7, @%7          ;INSTRUCTION UNDER TEST
3009 013160 121627 013160          CMPB   @%6, #TJSR3+6     ;TEST THE STACK
3010 013164 001401          BEQ      .+4
3011 013166 104006          HLT          ;PC OF JSR DID NOT GO TO STACK
3012 013170 005726          TST     (6)+          ;REPOSITION THE STACK
3013 013172 104400          SCOPE
3014
3015 :.....
3016 :SBTTL TEST NESTED SUBROUTINES
3017 :.....
3018 013174 000257          CCC          ;CLEAR CONDITION CODES
3019 013176 004767 001360          JSR      %7, SUBR6
3020 013202 100401          BMI     .+4
3021 013204 104006          HLT          ;JSR OR RTS FAILED
3022 013206 001401          BEQ     .+4
3023 013210 104006          HLT          ;JSR OR RTS FAILED
3024 013212 102401          BVS     .+4
3025 013214 104006          HLT          ;JSR OR RTS FAILED
3026 013216 103401          BCS     .+4
3027 013220 104006          HLT          ;JSR OR RTS FAILED
3028 013222 104400          SCOPE
3029
3030 :.....
3031 :SBTTL TEST ROTATE ODD BYTE
3032 :.....
3033 013224 104400          SCOPE
3034 013226 000257          CCC          ;CLEAR "C"
3035 013230 012767 123456 001560          MOV     #123456, TEMP
3036 013236 106067 001555          RORB   TEMP+1          ;ROTATE ODD BYTE
3037 013242 103401          BCS     .+4
3038 013244 104006          HLT          ;C NOT SET
3039 013246 102401          BVS     .+4
3040 013250 104006          HLT          ;V NOT SET
3041 013252 022767 051456 001536          CMP     #051456, TEMP
3042 013260 001401          BEQ     .+4
3043 013262 104006          HLT          ;ROTATE FAILED
3044 013264 104400          SCOPE
3045
3046 013266 000277          SCC          ;SET C
3047 013270 012767 123456 001520          MOV     #123456, TEMP
3048 013276 106067 001515          RORB   TEMP+1
3049 013302 103401          BCS     .+4
3050 013304 104006          HLT          ;C NOT SET
3051 013306 102001          BVC     .+4
    
```


3052	013310	104006			HLT				;V NOT CLEARED
3053	013312	022767	151456	001476	CMP	#151456,TEMP			
3054	013320	001401			BEQ	.+4			
3055	013322	104006			HLT				;ROTATE FAILED
3056	013324	104400			SCOPE				
3057									
3058	013326	000257			CCC				
3059	013330	012767	123456	001460	MOV	#123456,TEMP			
3060	013336	106167	001455		ROLB	TEMP+1			
3061	013342	103401			BCS	.+4			
3062	013344	104006			HLT				;C NOT SET
3063	013346	102401			BVS	.+4			
3064	013350	104006			HLT				;V NOT SET
3065	013352	022767	047056	001436	CMP	#047056,TEMP			
3066	013360	001401			BEQ	.+4			
3067	013362	104006			HLT				;ROTATE BYTE FAILED
3068	013364	104400			SCOPE				
3069									
3070	013366	000277			SCC				;SET C
3071	013370	012767	123456	001420	MOV	#123456,TEMP			
3072	013376	106167	001415		ROLB	TEMP+1			
3073	013402	103401			BCS	.+4			
3074	013404	104006			HLT				;C NOT SET
3075	013406	102401			BVS	.+4			
3076	013410	104006			HLT				;V NOT SET
3077	013412	022767	047456	001376	CMP	#047456,TEMP			
3078	013420	001401			BEQ	.+4			
3079	013422	104006			HLT				;ROTATE ODD BYTE FAILED
3080	013424	104400			SCOPE				
3081									
3082	013426	000257			CCC				;CLEAR C
3083	013430	012767	177777	001360	MOV	#-1,TEMP			
3084	013436	106267	001355		ASRB	TEMP+1			
3085	013442	103401			BCS	.+4			
3086	013444	104006			HLT				;C NOT SET
3087	013446	102001			BVC	.+4			
3088	013450	104006			HLT				;V NOT CLEARED
3089	013452	026727	001340	177777	CMP	TEMP,#-1			
3090	013460	001401			BEQ	.+4			
3091	013462	104006			HLT				;SHIFT FAILED
3092	013464	104400			SCOPE				
3093									
3094	013466	000277			SCC				
3095	013470	012767	177777	001320	MOV	#-1,TEMP			
3096	013476	106367	001315		ASLB	TEMP+1			
3097	013502	103401			BCS	.+4			
3098	013504	104006			HLT				;C NOT SET
3099	013506	102001			BVC	.+4			
3100	013510	104006			HLT				;V NOT CLEARED
3101	013512	026727	001300	177377	CMP	TEMP,#177377			
3102	013520	001401			BEQ	.+4			
3103	013522	104006			HLT				;SHIFT BYTE FAILED
3104	013524	104400			SCOPE				
3105									
3106									
3107									

.....

```

3108 .SBTTL TEST THAT RO WASN'T CLEARED BY FALSE SELECTION
3109 :.....
3110 013526 022700 052525          CMP      #52525,RO
3111 013532 001401                BEQ      .+4
3112 013534 104006                HL1
3113 013536 104400                SCOPE
3114
3115 :.....
3116 .SBTTL TEST COMBINATIONS OF NUMBERS WITH COMPARE INSTRUCTION
3117 :.....
3118 013540 004767 001146          JSR      PC,RNGEN          ;GET RANDOM NUMBER.
3119 013544 010001                MOV      RO,R1
3120 013546 020001          CMP1:  CMP      %0,%1          ;ARE THE EQUAL
3121 013550 001401                BEQ      .+4
3122 013552 104006                HL1          ;RO AND R1 DID NOT COMPARE
3123 013554 104400                SCOPE
3124
3125 :.....
3126 .SBTTL TEST ROTATING RANDOM NUMBERS
3127 :.....
3128 013556 004767 001130          JSR      PC,RNGEN          ;GET RANDOM NUMBER.
3129 013562 010067 165030          MOV      RO,REFF          ;PUT IN REFF WORD.
3130 013566 016767 165024          165024 ROTALL: MOV     REFF,TEST
3131 013574 006067 165020          ROR      TEST
3132 013600 006067 165014          ROR      TEST
3133 013604 006067 165010          ROR      TEST
3134 013610 006167 165004          ROL      TEST
3135 013614 006167 165000          ROL      TEST
3136 013620 006167 164774          ROL      TEST
3137 013624 100004                BPL      .+12
3138 013626 103007                BCC      .+20          ;Z=1
3139 013630 102013                BVC      .+30          ;Z=1, C=1
3140 013632 104006                HL1          ;Z=C, BUT V=1
3141 013634 006411                BR       .+24
3142 013636 103006                BCC      .+16          ;Z=0
3143 013640 102407                BVS      .+20          ;Z=0, C=1
3144 013642 104006                HL1          ;Z NOT EQUAL C, V=1
3145 013644 000405                BR       .+14
3146 013646 102404                BVS      .+12          ;Z=1, C=0
3147 013650 104006                HL1          ;Z NOT EQUAL C, V=1
3148 013652 000402                BR       .+6
3149 013654 102001                BVC      .+4          ;Z=0, C=0
3150 013656 104006                HL1          ;Z=C, BUT V=1
3151 013660 026767 164734 164730          CMP      TEST,REFF
3152 013666 001401                BEQ      .+4
3153 013670 104006                HL1          ;INITIAL NOT EQUAL TO FINAL
3154 013672 104400                SCOPE
3155
3156          000616          REF=REFF
3157
3158 :.....
3159 .SBTTL TEST ROTATING BYTE EVEN/ODD, RANDOM NUMBERS
3160 :.....
3161 013674 004767 001012          JSR      PC,RNGEN          ;GET RANDOM NUMBER.
3162 013700 010067 164712          MOV      RO,REFF          ;PUT IN REFF WORD.
3163 013704 004767 000006          JSR      %7,ROTBF
    
```

```

3164 013710 004767 000110 JSR 27,ROTBO
3165 013714 000503 BR ROTEN1
3166 013716 016767 164674 164674 ROTBE: MOV REFF,TEST
3167 013724 106067 164670 RORB TEST ;ROTATE BYTE EVEN
3168 013730 106067 164664 RORB TEST
3169 013734 106067 164660 RORB TEST
3170 013740 106167 164654 ROLB TEST
3171 013744 106167 164650 ROLB TEST
3172 013750 106167 164644 ROLB TEST
3173 013754 100004 BPL .+12
3174 013756 103007 BCC .+20 ;Z=1
3175 013760 102013 BVC .+30 ;Z=1, C=1
3176 013762 104006 HLT ;Z=C, BUT V-1
3177 013764 000411 BR .+24
3178 013766 103006 BCC .+16 ;Z=0
3179 013770 102407 BVS .+20 ;Z=0, C=1
3180 013772 104006 HLT ;Z NOT EQUAL C, V-1
3181 013774 000405 BR .+14
3182 013776 102404 BVS .+12 ;Z=1, C=0
3183 014000 104006 HLT ;Z NOT EQUAL C, V=1
3184 014002 000402 BR .+6
3185 014004 102001 BVC .+4 ;Z=0, C=0
3186 014006 104006 HLT ;Z=C, BUT V-1
3187 014010 026767 164604 164600 CMP TEST,REFF
3188 014016 001401 BEQ .+4
3189 014020 104006 HLT
3190 014022 000207 RTS 27
3191 014024 106067 164571 ROTBO: RORB TEST+1 ;ROTATE BYTE ODD
3192 014030 106067 164565 RORB TEST+1
3193 014034 106067 164561 RORB TEST+1
3194 014040 106167 164555 ROLB TEST+1
3195 014044 106167 164551 ROLB TEST+1
3196 014050 106167 164545 ROLB TEST+1
3197 014054 100004 BPL .+12
3198 014056 103007 BCC .+20 ;Z=1
3199 014060 102013 BVC .+30 ;Z=1, C=1
3200 014062 104006 HLT ;Z=C, BUT V=1
3201 014064 000411 BR .+24
3202 014066 103006 BCC .+16 ;Z=0
3203 014070 102407 BVS .+20 ;Z=0, C=1
3204 014072 104006 HLT ;Z NOT EQUAL C, V-1
3205 014074 000405 BR .+14
3206 014076 102404 BVS .+12 ;Z=1, C=0
3207 014100 104006 HLT ;Z NOT EQUAL C, V=1
3208 014102 000402 BR .+6
3209 014104 102001 BVC .+4 ;Z=0, C=0
3210 014106 104006 HLT ;Z=C, BUT V=1
3211 014110 026767 164504 164500 CMP TEST,REFF
3212 014116 001401 BEQ .+4
3213 014120 104006 HLT
3214 014122 000207 RTS 27
3215 014124 104400 ROTEN1: SCOPE

```

```

3216
3217 ;.....
3218 ;SBTLL ADD AND SUBTRACT RANDOM NUMBERS AGAINST FIXED NUMBERS
3219 ;.....

```

```

3220 ;A+B=C, C-A=B, BF SHOULD EQUAL BI
3221 014126 011667 000054 MOV @Z6,NUMA
3222 014132 004767 000554 JSR PC,RNGEN ;GET RANDOM NUMBER.
3223 014136 010067 164454 MOV RO,REFF ;PUT IN REF WORD.
3224 014142 004767 000002 JSR %7,ADSUB
3225 014146 000420 BR ARIEND
3226 014150 016767 164442 164442 ADSUB: MOV REFF,TEST
3227 014156 066767 000024 164434 ADD NUMA,TEST
3228 014164 166767 000016 164426 SUB NUMA,TEST
3229 014172 026767 164420 164420 CMP REFF,TEST
3230 014200 001401 BEQ .+4
3231 014202 104006 HLT
3232 014204 000207 RTS %7
3233 014206 000000 NUMA: 0
3234 014210 104400 ARIEND: SCOPE
3235
3236 :.....
3237 :SBTTL TEST COMPLEMENTING RANDOM NUMBERS
3238 :.....
3239 014212 004767 000474 JSR PC,RNGEN ;GET RANDOM NUMBER.
3240 014216 010067 164376 MOV RO,TEST ;PUT IN TEST.
3241 014222 012767 177777 164366 MOV #-1,REFF ;PREDETERMINE RESULT IN REFF.
3242 014230 160067 164362 SUB RO,REFF
3243 014234 005167 164360 COM TEST ;DO THE COMPLEMENT.
3244 014240 026767 164354 164350 CMP TEST,REFF ;EXPECTED RESULT?
3245 014246 001401 BEQ .+4 ;BR IF YES.
3246 014250 104006 HLT ;ERROR!! COMPLEMENT OF TEST DID NOT
3247 ;MATCH EXPCTED RESULTS AS IN REFF.
3248 014252 104400 SCOPE
3249
3250 :.....
3251 :SBTTL TEST COMB (EVEN BYTE) RANDOM NUMBERS.
3252 :.....
3253 014254 004767 000432 JSR PC,RNGEN ;GET RANDOM NUMBER.
3254 014260 010067 164334 MOV RO,TEST ;PUT IN TEST.
3255 014264 012767 177777 164324 MOV #-1,REFF ;PREDETERMINE THE RESULT.
3256 014272 160067 164320 SUB RO,REFF
3257 014276 105167 164316 COMB TEST ;DO COMPLEMENT EVEN BYTE.
3258 014302 126767 164312 164306 CMPB TEST,REFF ;EXPECTED RESULT?
3259 014310 001401 BEQ .+4 ;BR IF YES. OK.
3260 014312 104006 HLT ;ERROR!! RESULT IN TEST DOES NOT MATCH
3261 ;EXPECTED RESULT IN REFF.
3262 014314 104400 SCOPE
3263
3264 :.....
3265 :SBTTL TEST COMB (ODD BYTE) RANDOM NUMBERS
3266 :.....
3267 014316 004767 000370 JSR PC,RNGEN ;GET RANDOM NUMBER.
3268 014322 010067 164272 MOV RO,TEST ;PUT IN TEST.
3269 014326 012767 177777 164262 MOV #-1,REFF ;PREDETERMINE RESULT.
3270 014334 160067 164256 SUB RO,REFF
3271 014340 105167 164255 COMB TEST+1 ;DO ODD BYTE COMPLEMENT.
3272 014344 126767 164251 164245 CMPB TEST+1,REFF+1 ;EXPECTED RESULT?
3273 014352 001401 BEQ .+4 ;BR IF YES. OK.
3274 014354 104006 HLT ;ERROR!! RESULT IN TEST DOES NOT MATCH
3275 ;EXPECTED RESULT IN REFF.
    
```

```

3276 014356 104400          SCOPE
3277
3278
3279 :.....
3280 :SBTTL TEST COMPARE RANDOM VALUES EVEN BYTE WITH ODD
3281 :.....
3281 014360 004767 000326      JSR    PC,RNGEN      ;GET RANDOM NUMBER.
3282 014364 110067 000426      MOVB   RO,TEMP      ;PUT IN LOW BYTE OF TEMP.
3283 014370 110067 000423      MOVB   RO,TEMP+1    ;PUT IN HIGH BYTE.
3284 014374 126767 000416 000415  CMPB   TEMP,TEMP+1  ;DO THE COMPARE.
3285 014402 001401          BEQ    .+4           ;BR IF EQUAL. OK.
3286 014404 104006          HLT                    ;COMPARE FAILED.
3287 014406 002001          BGE    .+4
3288 014410 104006          HLT                    ;V IS NOT = TO N
3289 014412 003401          BLE    .+4
3290 014414 104006          HLT                    ;V IS SET
3291 014416 104400          SCOPE
3292
3293 :.....
3294 :SBTTL TEST SWAB
3295 :.....
3296 014420 012767 000200 164172  MOV    #0200,TEST
3297 014426 000367 164166      SWAB   TEST
3298 014432 100001          BPL    .+4
3299 014434 104006          HLT
3300 014436 001401          BEQ    .+4
3301 014440 104006          HLT
3302 014442 000367 164152      SWAB   TEST
3303 014446 100401          BMI    .+4
3304 014450 104006          HLT
3305 014452 001001          BNE    .+4
3306 014454 104006          HLT
3307 014456 104400          SCOPE
3308
3309 :.....
3310 :SBTTL TEST RANDOM COMBINATIONS OF SWAB
3311 :.....
3312 014460 004767 000226      JSR    PC,RNGEN      ;GET RANDOM NUMBER.
3313 014464 010067 164126      MOV    RO,REFF      ;PUT IN REF.
3314 014470 105067 164123      CLRB  REFF+1
3315 014474 116767 164116 164117  MOVB   REFF,TEST+1  ;PUT IN TEST HIGH BYTE.
3316 014502 105067 164112      CLRB  TEST          ;AND CLEAR THE LOW BYTE OF TEST.
3317 014506 000367 164106      SWAB   TEST          ;NOW DO THE SWAB!
3318 014512 026767 164102 164076  CMP    TEST,REFF    ;REFF AND TEST MUST BE SAME.
3319 014520 001401          BEQ    .+4           ;BR IF SAME. OK.
3320 014522 104006          HLT                    ;ERROR!. SWAB FAILURE.
3321 014524 104400          SCOPE
3322

```

```

3323 :.....
3324 :SBTTL END OF USER CODE IN BANK
3325 :.....
3326 :CALL KERNEL/
3327 :ALTERED IN CORE EXPANSION/
3328 014526 104010 DONE: EOB ;THIS EMT CALL GOES TO EOBSRV
3329 014530 000240 NOP ;TO ALLOW CORE EXPANSION TO PATCH IN JMP
3330 :.....
3331 :SBTTL GROUP OF NESTED SUBROUTINES/
3332 :.....
3333 :.....
3334 014532 000207 SUBR1: RTS %7 ;ONE INSTRUCTION
3335 014534 000277 SUBR2: SCC ;ONE DEEP
3336 014536 000207 RTS %7
3337 014540 004767 177770 SUBR3: JSR %7,SUBR2 ;TWO DEEP
3338 014544 000207 RTS %7
3339 014546 004767 177766 SUBR4: JSR %7,SUBR3 ;THREE DEEP
3340 014552 000207 RTS %7
3341 014554 004767 177766 SUBR5: JSR %7,SUBR4 ;FOUR DEEP
3342 014560 000207 RTS %7
3343 014562 004767 177766 SUBR6: JSR %7,SUBR5 ;FIVE DEEP
3344 014566 000207 RTS %7
3345 :.....
3346 :SBTTL SCOPE AND/OR ITERATION LOOP FOR EACH TEST TIMES/
3347 :.....
3348 :.....
3349 014570 005737 000042 SCOPEC: TST @#42 ;IN AUTOMATIC MODE?
3350 014574 001017 BNE 2$ ;BR IF YES.
3351 014576 032767 002000 163372 BIT #2000,SREG2 ;INHIBIT PROCESSOR TESTS?
3352 014604 001403 BEQ 1$ ;NO
3353 014606 022626 CMP (SP)+,(SP)+ ;CLEAN UP EMT CALL FROM STACK.
3354 014610 000167 165552 JMP MAIN ;YES
3355 014614 032767 040000 163354 1$: BIT #40000,SREG2 ;TEST SR FOR SCOPE
3356 014622 001015 BNE SCOPEB ;YES, SCOPE
3357 014624 032767 004000 163344 BIT #4000,SREG2 ;NO-TEST FOR ITERATION
3358 014632 001014 BNE SCOPEG ;INHIBIT ITERATION
3359 014634 005767 000046 2$: TST PASCNT ;IN FIRST PASS?
3360 014640 001411 BEQ SCOPEG ;BR IF YES. NO ITERATIONS ON 1ST PASS.
3361 014642 005267 000034 INC SCOPEF ;INCREMENT COUNT.
3362 014646 026767 000030 000022 CMP SCOPEF,ICOUNT ;COMPARE CURRENT COUNT TO MAX NUMBER
3363 014654 103003 BHIS SCOPEG ;EXIT-DONE
3364 014656 016716 000022 SCOPEB: MOV RETURN,@SP
3365 014662 000002 RTI
3366 014664 005067 000012 SCOPEG: CLR SCOPEF ;CLEAR COUNT
3367 014670 011667 000010 MOV @%6,RETURN ;SAVE SCOPE RETURN POINTER
3368 014674 000002 RTI ;RETURN INLINE-NEXT TEST
3369 014676 000000 ICOUNT: 0 ;ITERATION COUNT
3370 014700 000024 $ICNT: 20. ;STANDARD ITERATION COUNT.
3371 014702 000000 SCOPEF: 0 ;COUNT LOCATION FOR ITERATION LOOP
3372 014704 000000 RETURN: 0 ;ADDRESS OF LAST TEST
3373 014706 000000 PASCNT: 0 ;HOLDS PASS COUNT.
3374 014710 001750 XDPCNT: 1000. ;PASS COUNT TO USE WHEN IN XNDP (MAIN MODE).
3375 :.....
3376 :SBTTL ROUTINE RGEN
3377 :.....
3378 :.....
    
```

3379
 3380
 3381 014712 016700 000642
 3382 014716 006100
 3383 014720 006100
 3384 014722 066700 000034
 3385 014726 010067 000026
 3386 014732 006100
 3387 014734 006100
 3388 014736 066700 000020
 3389 014742 006100
 3390 014744 006100
 3391 014746 010067 000010
 3392 014752 016700 000002
 3393 014756 000207
 3394 014760 001233
 3395 014762 007622
 3396
 3397
 3398
 3399
 3400 014764 125252
 3401 014766 014764
 3402 014770 052525
 3403 014774 014774
 3404 014774 177777
 3405 014776 015000
 3406 014776 015000
 3407 015000 125252
 3408 015002 015004
 3409 015004 052525
 3410
 3411
 3412 015006 000000
 3413 015010 015006
 3414 015016 015016
 3415 015016 000000
 3416 015020 015016
 3417 015024 015024
 3418 015024 015026
 3419 015026 000000
 3420

```

:.....
:RANDOM NUMBER GENERATOR
RNGEN: MOV RP1,R0
      ROL R0
      ROL R0
      ADD RP2,R0
      MOV R0,RP1
      ROL R0
      ROL R0
      ADD RP2,R0
      ROL R0
      ROL R0
      MOV R0,RP2
      MOV RP1,R0
      RTS PC ;RETURN.
RP1: 1233
RP2: 7622
  
```

```

:.....
:SBTTL FIXED VALUES FOR USE IN TEST/
:.....
B: 125252 ;ADDRESS OF B
   B
   . = B*10
A: -1
   A+4
   . = A+4
   125252 ;ADDRESS OF A+10
   A+10
   052525

:FOR STORAGE
C: 0 ;ADDRESS OF C
   C
   . = C+10
TEMP: 0 ;ADDRESS OF TEMP
      TEMP
      . = TEMP+6
      TEMP+10 ;ADDRESS OF TEMP+10 OR "D"
D: 0
  
```

```

3421
3422
3423 :.....
3424 :SBTTL ROUTINE SUBROUTINE TO INITIALIZE ALL PAGES TO NR, BANK 0, 1 PAGE, UP/
3425 :.....
3425 015030 010146 NRALL: MOV R1,-(R6) ;SAVE REGISTERS
3426 015032 010246 MOV R2,-(R6)
3427 015034 010345 MOV R3,-(R6)
3428 015036 012701 000536 MOV #1PDRTAB,R1 ;R1 HOLDS ADDRESS OF CURRENT POSITION
3429 ;IN TABLE OF ADDRESSES
3430 015042 012703 000010 NRLOOP: MOV #8,R3 ;R3 USED AS COUNTER
3431 015046 012102 MOV (R1)+,R2 ;R2 CONTAINS ADDRESS OF PDR OR
3432 ;PAR TO BE CLEARED
3433 015050 005022 CLR (R2)+ ;CLEAR ALL ASR'S FOR THIS MODE
3434 015052 077302 SOB R3,-2
3435 015054 020127 000544 CMP R1,#1PDREND ;CHECK FOR DONE
3436 015060 003770 BLE NRLOOP ;CLEAR ALL IN NEXT MODE IF NOT DONE
3437 015062 012603 MOV (R6)+,R3
3438 015064 012602 MOV (R6)+,R2
3439 015066 012601 MOV (R6)+,R1
3440 015070 000207 RTS 27
3441
3442 :.....
3443 :SBTTL EMT HANDLER/
3444 :.....
3445 :FIRST 3 CALLS LEFT OPEN IN TABLE FOR EASY PATCHES/
3446 015072 162716 000002 EMTSRV: SUB #2,@SP ;GET CALL
3447 015076 006576 000000 MFPI @(SP)
3448 015102 012667 000022 MOV (SP)+,EPC
3449 015106 062716 000002 ADD #2,@SP
3450 015112 105067 000013 CLR EPC+1 ;SAVE OFFSET ONLY
3451 015116 062767 015132 000004 ADD #EMTAB,EPC ;POINT TO TABLE OF ADDRESSES
3452 015124 017707 000000 MOV @EPC,PC ;JUMP TO DESIRED ROUTINE
3453 015130 000000 EPC: 0
3454 000000 PATCH1=0
3455 000000 PATCH2=0
3456 000000 PATCH3=0
3457 015132 000000 EMTAB: PATCH1 ;PATCH IN ADDRESS OF ROUTINE
3458 015134 000000 PATCH2
3459 015136 000000 PATCH3
3460 015140 015664 PRINT ;ERROR PRINTOUT
3461 015142 015144 EOBSRV ;END OF BANK
3462
3463 :.....
3464 :SBTTL ROUTINE END OF BANK SERVICE
3465 :.....
3466
3467 015144 032767 000007 163022 EOBSRV: BIT #7,MMOPT ;MEM. MGMT./USER-KERNEL/4KAS 32 INHIBITED?
3468 015152 001406 BEQ EOB2 ;NO - CONTINUE
3469 015154 012716 015564 EOB1C: MOV #LOGIC,(SP) ;GO TO BEGIN
3470 015160 012766 000340 000002 MOV #340,2(SP) ;WILL ASSUME PRIORITY 7.
3471 015166 000002 RTI
3472 015170 042737 000340 177776 EOB2: BIC #340,@PSR
3473 015176 026767 163372 163310 CMP CURPAR,UPAR7 ;LAST USER ASR DONE?
3474 015204 001444 BEQ NXTBNK ;YES - GO FIND NEXT BANK
3475 015206 062737 020000 000034 ADD #20000,@#34 ;UPDATE SCOPE VECTOR ADDRESS IN BANK 0
3476 015214 062767 020000 163356 ADD #20000,BNKSTR ;UPDATE BANK START TO REFERENCE CURRENT ASR
    
```



```

3477 015222 016716 163352      MOV      BNKSTR,(SP)
3478 015226 026767 163256 163340      CMP      UPARO,CURPAR
3479 015234 001404                BEQ      NXTSEG
3480 015236 005077 163332      CLR      @CURPAR          ;SET PPREVIOUS ASR TO NR, BANK 0
3481 015242 005077 163330      CLR      @CURPDR
3482 015246 062767 000002 163320      NXTSEG: ADD     #2,CURPAR          ;UPDATE POINTERS TO NEXT SEGMENT
3483 015254 062767 000002 163314      ADD     #2,CURPDR
3484 015262 012777 077406 163306      MOV     #77406,@CURPDR    ;SET NEXT SEGMENT RW, 4K
3485 015270 016777 163274 163276      MOV     CURBNK,@CURPAR    ;MAP NEXT SEGMENT TO CURRENT BANK
3486 015276 052737 030000 177776      BIS     #30000,@PSR       ;SET PREVIOUS MODE TO USER
3487 015304 006506                MFPI    R6                ;PICK UP USER STACK POINTER
3488 015306 062716 020000                ADD     #20000,R6         ;MAP IT TO NEXT ASR
3489 015312 006606                MTPPI  R6                ;PUT IT BACK
3490 015314 000002                RTI                          ;GO BACK TO MAINLINE
3491 015316 012746 000400      NXTBNK: MOV     #UBUFF,-(SP)
3492 015322 052737 030000 177776      BIS     #30000,@PSR
3493 015330 006606                MTPPI  R6
3494 015332 013737 00057C 000572      MOV     @CURBNK,@OLDBNK    ;SAVE PREV BANK ADDRESS
3495 015340 062767 000200 163222      BNKTST: ADD     #200,CURBNK
3496 015346 006367 163236      ASL     COREPT
3497 015352 103006                BCC     1$
3498 015354 012767 000001 163226      MOV     #1,COREPT
3499 015362 012767 000606 163222      MOV     #MEM1,MEMUT
3500 015370 022767 007600 163172      1$:      CMP     #7600,CURRNK    ;CHECK FOR EXTERNAL BANK
3501 015376 001666                BEQ     EOB1C              ;BR IF YES TO START ANOTHER PASS.
3502 015400 016777 163164 163124      EOB3:  MOV     CURBNK,@KPAR2 ;MAP KERNEL SEGMENT 2 TO BANK BEING LOOKED FOR
3503 015406 012777 077406 163106      MOV     #77406,@KPAR2
3504 015414 036777 163170 163170      BIT     COREPT,@MEMUT
3505 015422 001746                BEQ     BNKTST
3506 015424 042737 160000 000034      BIC     #160000,@#34      ;INITIALIZE SCOPE VECTOR ADDRESS
3507 015432 005001                CLR     R1                ;R1 ADDRESSES BANK 0 THRU KERNEL ASR0
3508 015434 012702 040000                MOV     #40000,R2        ;R2 ADDRESSES NEW BANK THRU KERNEL ASR2
3509 015440 012703 015026                MOV     #D,R3
3510 015444 006203                ASR     R3
3511 015446 012122      CORMOV: MOV     (R1)+,(R2)+
3512 015450 077302                SOB     R3,CORMOV
3513 015452 016767 163032 163114      MOV     UPARO,CURPAR      ;FIRST ASR CHECKED IS USER ASR0
3514 015460 016767 163016 163110      MOV     UPDR0,CURPDR
3515 015466 016777 163076 163100      MOV     CURBNK,@CURPAR
3516 015474 012777 077406 163074      MOV     #77406,@CURPDR
3517 015502 005077 163006                CLR     @UPAR7
3518 015506 005077 162774                CLR     @UPDR7
3519 015512 026727 163054 000000      CMP     OLDBNK,#0        ;PREV BANK 0
3520 015520 001414                BEQ     EOB6              ;YES, DO NOT CLEAR
3521 015522 016777 163044 163002      MOV     OLDBNK,@KPAR2
3522 015530 012777 077406 162764      MOV     #77406,@KPAR2
3523 015536 012701 040000                MOV     #40000,R1
3524 015542 012703 007630                MOV     #7630,R3
3525 015546 005021      BNKLP: CLR     (R1)+
3526 015550 077302                SOB     R3,BNKLP
3527 015552 012716 005542      EOB6:  MOV     #BEGIN,(SP)
3528 015556 011667 163016                MOV     (SP),BNKSTR
3529 015562 000002                RTI

```

3530
 3531
 3532
 ;*****
 ;SBTTL END OF PASS CODE STARTS HERE

```

3533 ;.....
3534 015564 042777 00001 162706 LOGIC: BIC #1,@SRO ;TURN OFF MEMORY MANAGEMENT.
3535 015572 012737 00016 000014 MOV #16,@#14 ;RESET THE TRACE VECTOR.
3536 015600 005037 000016 CLR @#16
3537 015604 032737 000001 000176 BIT #1,@#SREG2 ;TTY OUT SELECTED
3538 015612 001404 BEQ 1$ ;YES, NO ASTERISK
3539 015614 004767 000444 JSR PC,BELL ;RING BELL TOO.
3540 015620 004767 000414 JSR PC,STAR ;TYPE ASTERISK.
3541 015624 005267 177056 1$: INC PASCNT ;INCREMENT PASS COUNT.
3542
3543 ;.....START OF "ACT11/XXDP EOP HOOKS".....
3544 015630 013701 000042 MOV @#42,R1
3545 015634 001405 BEQ HERE
3546 015636 000005 RESET
3547 015640 004711 SENDAD: JSR Z7,@R1
3548 015642 000240 NOP
3549 015644 000240 NOP
3550 015646 000240 NOP
3551 ;.....END OF "ACT11/XXDP EOP HOOKS".....
3552 015650 000005 HERE: RESET ;ISSUE RESET TO HALT I/O.
3553 015652 005167 162724 COM TRPB ;COMPLEMENT THE TRACE SWITCH.
3554 015656 000137 000634 JMP @#RSTR1 ;RESTART.
3555
  
```

```
3556 :.....  
3557 .SBTTL RTT EXECUTED WHEN TRACE IS ON/  
3558 :.....  
3559 015662 000005 TRTRP: RTT  
3560  
3561  
3562 :.....  
3563 .SBTTL ROUTINE PRINT  
3564 :.....  
3565 :ENTERED WITH SYSTEM TRAP CALL (HLT)  
3566 :PRINT OUT THE ERROR PC+2, STATUS REGISTER, AND LOCATION IN BACKGROUND  
3567 015664 005747 000170 PRINT: TST PRTON ;CHECK PRINT ON FLAG  
3568 015670 001401 BEQ .+4  
3569 015672 000002 RTI ;IF ANOTHER HALT IS BEING PRINTED, SKIP THIS ONE  
3570 015674 005267 000160 INC PRTON  
3571 015700 012767 000340 162070 MOV #340,PSR ;SET PRIORITY TO 7  
3572 :.....  
3573 015706 037727 162634 020000 CHGC6: BIT @SR,#20000 ;TEST FOR INHIBIT PRINT OUT  
3574 :.....  
3575 015714 001044 BNE CK ;BR TO INHIBIT PRINT.  
3576 015716 012667 000132 MOV (6)+,SAVPC ;PC OF FAILING ROUTINE  
3577 015722 012667 000130 MOV (6)+,SAVPSR ;PSR OF ERROR CONDITION  
3578 015726 024646 CMP -(6),-(6) ;RESTORE STACK  
3579 015730 012767 000200 162040 MOV #200,PSR  
3580 015736 004767 000342 JSR %7,CRLF ;OUTPUT CARRIAGE RETURN AND LINE FEED  
3581 015742 016767 000106 000264 MOV SAVPC,PTEMP1 ;LOAD WITH FAILING PC+2  
3582 015750 004767 000106 JSR %7,PROCT ;PRINT FAILING PC+2  
3583 015754 004767 000272 JSR %7,SPACE  
3584 015760 016767 000072 000246 MOV SAVPSR,PTEMP1 ;LOAD PROCESSOR STATUS  
3585 015766 004767 000070 JSR %7,PROCT ;PRINT PROCESSOR STATUS  
3586 015772 004767 000254 JSR %7,SPACE  
3587 015776 016767 162566 000230 MOV CURBNK,PTEMP1  
3588 016004 004767 000052 JSR %7,PROCT  
3589 016010 004767 000236 JSR %7,SPACE  
3590 016014 016767 176664 000212 MOV RETURN,PTEMP1  
3591 016022 004767 000034 JSR %7,PROCT  
3592 016026 023727 000042 015640 CK: CMP @#42,#SENDAD ;IN ACT11?  
3593 016034 001403 BEQ AB ;BR IF YES TO HALT  
3594 :.....  
3595 016036 005777 162504 CHGC7: TST @SR ;CHECK SR FOR HALT SWITCH  
3596 :.....  
3597 016042 100001 BPL .+4 ;BRANCH IF NOT SET  
3598 016044 000000 AB: HALT ;HALT ON ERROR UP  
3599 016046 005067 000006 CLR PRTON ;ROUTINE DONE - CLEAR FLAG  
3600 016052 000002 RTI ;RETURN TO MAIN LINE  
3601 SAVPC: 0  
3602 SAVPSR: 0  
3603 PRTON: 0  
3604  
3605  
3606 :.....  
3607 .SBTTL ROUTINE PROCT  
3608 :.....  
3609 :SUBROUTINE TO PRINT OUT OCTAL NUMBER/  
3610 016062 012727 000006 016066 PROCT: MOV #6,PTEMP3 ;CLEAR R4 FOR COUNTING CHARACTERS OUTPUT  
3611 016066 PTEMP3=-2
```

```

3612 016070 005067 000136          CLR      PRFLG      ;INITIALIZE CARRY FLAG FOR ROTATES
3613 016074 012767 000060 000134  MOV      #60,PTEMP2 ;SETUP R3
3614 016102 005767 000126          TST      PTEMP1    ;CHECK BIT 15 OF NUMBER
3615 016106 100002          BPL      .+6        ;BRANCH IF ZERO
3616 016110 005267 000122          INC      PTEMP2    ;INCREMENT R3 IF ONE
3617 016114 006167 000114          ROL      PTEMP1    ;ROTATE LEFT MOST OCTAL TO RIGHT END
3618 016120 006167 000110          ROL      PTEMP1
3619 016124 005567 000102          ADC      PRFLG     ;STORE CARRY
3620 016130 016746 000102          P.WAIT: MOV      PTEMP2,-(SP) ;OUTPUT THE CHARACTER
3621 016134 004767 000210          JSR      PC,CHROUT ;DO IT.
3622 016140 005367 177722          DEC      PTEMP3    ;COUNT
3623 016144 001001          BNE      P.CNT1   ;BRANCH IF NOT DONE
3624 016146 000207          RTS      %7        ;BRANCH IF NOT DONE
3625 016150 000241          P.CNT1: CLC      ;CLEAR CARRY
3626 016152 005767 000054          TST      PRFLG    ;CHECK FOR PREVIOUS CARRY
3627 016156 001403          BEQ      .+10     ;BRANCH IF PREVIOUSLY ZERO
3628 016160 005067 000046          CLR      PRFLG    ;INITIALIZE FLAG
3629 016164 000261          SEC      ;SET CARRY
3630 016166 006167 000042          ROL      PTEMP1   ;ROTATE NEXT CHARACTER INTO RIGHT END OF REGISTER
3631 016172 006167 000036          ROL      PTEMP1
3632 016176 006167 000032          ROL      PTEMP1
3633 016202 005567 000024          ADC      PRFLG    ;STORE CARRY
3634 016206 016767 000022 000022  MOV      PTEMP1,PTEMP2 ;LOAD DATA INTO R3
3635 016214 042767 177770 000014  BIC      #177770,PTEMP2 ;CLEAR ALL BUT LOWEST OCTAL DIGIT
3636 016222 052767 000060 000006  BIS      #60,PTEMP2 ;SET TO ASCII EQUIVALENT
3637 016230 000737          BR      P.WAIT    ;LOOP
3638 016232 000000          PRFLG: 0
3639 016234 000000          PTEMP1: 0 ;CONTAINS VALUE TO BE OUTPUT
3640 016236 000000          PTEMP2: 0 ;SCRATCH
    
```

3641
3642
3643
3644
3645
3646

```

:.....
.SBTTL ROUTINE STAR
:.....
;SUBROUTINE TO OUTPUT ASTERISK.
STAR: JSR      PC,CRLF ;OUTPUT CRLF.
      MOV      #52,-(SP) ;GO OUTPUT A *
      BR      BELL1
    
```

3647 016240 004767 000040
3648 016244 012746 000052
3649 016250 000407
3650
3651
3652

```

:.....
.SBTTL ROUTINE SPACE
:.....
;SUBROUTINE TO ISSUE SPACE/
SPACE: MOV      #40,-(SP) ;OUTPUT SPACE.
      JSR      PC,CHROUT ;DO IT.
      RTS      %7 ;RETURN
    
```

3653
3654
3655
3656 016252 012746 000040
3657 016256 004767 000066
3658 016262 000207
3659
3660

```

:.....
.SBTTL ROUTINE BELL
:.....
;BELL ON PASS COMPLETE
BELL: MOV      #7,-(SP) ;OUTPUT BELL.
BELL1: JSR      PC,CHROUT ;DO IT.
      DEC      #0 ;SLIGHT DELAY.
    
```

3661
3662
3663
3664
3665 016264 012746 000007
3666 016270 004767 000054
3667 016274 005327 000000

3668 016300 001375
 3669 016302 000207
 3670
 3671
 3672
 3673
 3674
 3675
 3676 016304 012746 000015
 3677 016310 004767 000034
 3678 016314 012746 000012
 3679 016320 004767 000024
 3680 016324 016746 162272
 3681 016330 001405
 3682 016332 005046
 3683 016334 004767 000010
 3684 016340 005316
 3685 016342 001373
 3686 016344 005726
 3687 016346 000207
 3688
 3689
 3690
 3691
 3692
 3693
 3694 016350 016677 000002 162034
 3695 016356 105777 162026
 3696 016362 100375
 3697 016364 012616
 3698 016366 000207
 3699
 3700
 3701 016370 013746 000024
 3702 016374 010667 000010
 3703 016400 012737 016412 000024
 3704 016406 000000
 3705 016410 000000
 3706 016412 016706 177772
 3707 016416 012637 000024
 3708 016422 022626
 3709 016424 104006
 3710 016426 000167 162202
 3711
 3712
 3713 016432 000207
 3714
 3715 017760 017760
 3716 017760 000000
 3717 000001

```

BELL2: BNE      -4
        RTS      %7

:.....
:SBTTL ROUTINE CRLF
:.....
:SUBROUTINE TO OUTPUT CARRIAGE RETURN AND LINEFEED/
CRLF:  MOV      #15,-(SP)      ;OUTPUT CR.
        JSR      PC,CHROUT    ;DO IT.
        MOV      #12,-(SP)    ;OUTPUT LF.
        JSR      PC,CHROUT    ;DO IT.
        MOV      FILLCT,-(SP) ;GET THE FILL COUNT.
        BEQ      2%          ;BR IF 0.
1$:    CLR      -(SP)        ;WILL OUTPUT NULLS FOR FILLERS.
        JSR      PC,CHROUT    ;DO IT.
        DEC      (SP)        ;DONE?
        BNE      1%          ;BR IF NOT.
2$:    TST      (SP)+        ;CLEAN UP STACK.
        RTS      PC          ;RETURN.

:.....
:SBTTL ROUTINE CHROUT
:.....
:SUBROUTINE TO OUTPUT CHARACTER TO CONSOLE TTY.
CHROUT:MOV      2(SP),@TOBR    ;LOAD THE CONSOLE BUFFER REG.
1$:    TSTB     @TCR          ;READY?
        BPL      1%          ;BR IF NOT. WAIT.
        MOV      (SP)+,(SP)   ;SET UP FOR EXIT.
        RTS      PC          ;RETURN.

:ENTER HERE ON POWER FAIL;
PFAIL:MOV      @#24,-(6)
        MOV      %6,SAVR6     ;STORE STACK POSITION
        MOV      #RESTR,@#24
        HALT
SAVR6: 0
RESTR:  MOV      SAVR6,%6
        MOV      (6)+,@#24
        CMP      (SP)+,(SP)+ ;RESTORE STACK
        HLT
        JMP      RSTR        ;POWER FAIL OCCURRED

:RETURN TO MAIN LINE

USER:   RTS      %7
        ;OVERLAY USER ROUTINE HERE IF 8kw
        ;USE BANK1 IF 8kw

KSTACK: 0
        ;=17760
        .END
    
```


LPINTR	003270	1081	1292#											
LPSY	000436	841#	1082#											
LPVC	000434	840#	1081#											
LP1	003244	1285#	1318	1320										
LP2	003252	1288#	1308	1310										
LP3	003360	1306	1309#											
LP4	003370	1302	1311#											
LP5	003426	1316	1319#											
LP6	003326	1290	1293	1301#										
LP7	003324	1295	1297	1300#										
MAIN	002366	1136	1143#	1145	3354									
MAP1	001162	970#	984											
MAP2	001252	980	983#											
MEMUT	000612	900#	965#	976#	982#	986#	1120#	3499#	3504					
MEMO	000604	897#	900	952#	965	986	1120							
MEM1	000606	898#	963#	982	3499									
MAGPT	000174	808#	948#	951#	1090	1095	1106	1135	1161	1165	3467			
MODE	002260	1091	1125#											
MOD12	002774	1204	1230#											
MOD16	002760	1206	1228#											
MOD20	002744	1208	1226#											
MOD24	002730	1210	1224#											
MOD4	003024	1200	1234#											
MOD8	003010	1202	1232#											
MOVE	002554	1189#	1212	1214	1216	1218	1220	1222						
MOVEPT	001222	975	978#											
N	= 000001	1546#	1547	1548	1549#	1550	1551	1552#	1553	1554	1555#	1556	1557	1558#
		1559	1560	1561#	1562	1563	1564#	1565	1566	1567#	1568	1569	1570#	1571
		1572	1573#	1574	1575	1576#	1577	1578	1579#	1580	1581	1582#	1583	1584
		1585#	1586	1587	1588#	1589	1590	1591#	1592	1593	1594#	1595	1596	1597#
		1598	1599	1600#	1601	1602	1603#	1604	1605	1606#	1607	1608	1609#	1610
		1611	1612#	1613	1614	1615#	1616	1617	1618#	1619	1620	1621#	1622	1623
		1624#	1625	1626	1627#	1628	1629	1630#	1631	1632	1633#	1634	1635	1636#
		1637	1638	1639#	1640	1641	1642#	1643	1644	1645#	1646	1647	1648#	1649
		1650	1651#	1652	1653	1654#	1655	1656	1657#	1658	1659	1660#	1661	1662
		1663#	1664	1665	1666#	1667	1668	1669#	1670	1671	1672#	1673	1674	1675#
		1676	1677	1678#	1679	1680	1681#	1682	1683	1684#	1685	1686	1687#	1688
		1689	1690#	1691	1692	1693#	1694	1695	1696#	1697	1698	1699#	1700	1701
		1702#	1703	1704	1705#	1706	1707	1708#	1709	1710	1711#	1712	1713	1714#
		1715	1716	1717#	1718	1719	1720#	1721	1722	1723#	1724	1725	1726#	1727
		1728	1729#	1730	1731	1732#	1733	1734	1735#	1736	1737	1738#	1739	1740
		1741	1742#	1743	1744	1745#	1746	1747	1748#	1749	1750	1751#	1752	1753
		1754#	1755	1756	1757#	1758	1759	1760#	1761	1762	1763#	1764	1765	1766#
		1767	1768	1769#	1770	1771	1772#	1773	1774	1775#	1776	1777	1778#	1779
		1780	1781#	1782	1783	1784#	1785	1786	1787#	1788	1789	1790#	1791	1792
		1793#	1794	1795	1796#	1797	1798	1799#	1800	1801	1802#	1803	1804	1805#
		1806	1807	1808#	1809	1810	1811#	1812	1813	1814#	1815	1816	1817#	1818
		1819	1820#	1821	1822	1823#	1824	1825	1826#	1827	1828	1829#	1830	1831
		1832#	1833	1834	1835#	1836	1837	1838#	1839	1840	1841#	1842	1843	1844#
		1845	1846	1847#	1848	1849	1850#	1851	1852	1853#	1854	1855	1856#	1857
		1858	1859#	1860	1861	1862#	1863	1864	1865#	1866	1867	1868#	1869	1870
		1871#	1872	1873	1874#	1875	1876	1877#	1878	1879	1880#	1881	1882	1883#
		1884	1885	1886#	1887	1888	1889#	1890	1891	1892#	1893	1894	1895#	1896
		1897	1898#	1899	1900	1901#	1902	1903	1904#	1905	1906	1907#	1908	1909
		1910#	1911	1912	1913#	1914	1915	1916#	1917	1918	1919#	1920	1921	1922#
		1923	1924	1925#	1926	1927	1928#	1929	1930					

3051	3054	3061	3063	3066	3073	3075	3078	3085	3087	3090	3097	3099
3102	3111	3121	3137	3138	3139	3141	3142	3143	3145	3146	3148	3149
3152	3173	3174	3175	3177	3178	3179	3181	3182	3184	3185	3188	3197
3198	3199	3201	3202	3203	3205	3206	3208	3209	3212	3230	3245	3259
3273	3285	3287	3289	3298	3300	3303	3305	3319	3403#	3406#	3414#	3417#
3434	3568	3597	3611	3615	3627	3668	3715#					

.SASTA 1#
.\$CATC 1#
.\$CMTA 1#
.\$DB2D 1#
.\$DB2D 1#
.\$DIV 1#
.\$EOP 1#
.\$ERRO 1#
.\$ERRT 1#
.\$MULT 1#
.\$POWE 1#
.\$RAND 1#
.\$RDDE 1#
.\$RDOC 1#
.\$READ 1#
.\$R2AZ 1#
.\$SAVE 1#
.\$SB2D 1#
.\$SB2D 1#
.\$SCOP 1#
.\$SIZE 1#
.\$SUPR 1#
.\$TRAP 1#
.\$TYPB 1#
.\$TYPD 1#
.\$TYPE 1#
.\$TYPO 1#
.\$4OCA 1#
.1170 1#

. ABS. 017762 000

ERRORS DETECTED: 0

CFKTC.BIN,CFKTC.LST/CRF/SOL/NL:TOC=CFKTC.SML,CFKTC.P11
RUN-TIME: 30 42 3 SECONDS
RUN-TIME RATIO: 171/77-2.2
CORE USED: 32K (63 PAGES)