

.REM

IDENTIFICATION

PRODUCT CODE: AC-8507G-MC
PRODUCT NAME: CZDJBGO DJ11 EXER & ONLNE
PROGRAM DATE: JUNE 1982
MAINTAINER: DIAGNOSTIC ENGINEERING

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1975, 1982 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

CONTENTS

1.	ABSTRACT
2.	REQUIREMENTS
2.1	EQUIPMENT
2.2	STORAGE
2.3	PRELIMINARY PROGRAMS
3.	LOADING PROCEDURE
4.	STARTING PROCEDURE
4.1	CONTROL SWITCH SETTINGS
4.2	STARTING ADDRESS
4.3	PROGRAM AND OPERATOR ACTION
5.	OPERATING PROCEDURE
5.1	OPERATIONAL SWITCH SETTINGS
5.2	SUBROUTINE ABSTRACTS
5.3	PROGRAM AND OPERATOR ACTION
6.	ERRORS
6.1	ERROR PRINTOUT
6.2	ERROR RECOVERY
6.3	ERROR COUNTER
7.	RESTRICTIONS
8.	MISCELLANEOUS
8.1	EXECUTION TIME
8.2	STACK POINTER
8.3	PASS COUNTER
8.4	POWER FAIL
9.	PROGRAM DESCRIPTION

HISTORY

JUNE 1982 REV F TO REV G

INSERTED THE LINE 'MOV #0,@MPS' IN THE ROUTINE 'BEGIN'
TO INSURE THAT INTERRUPTS WILL BE ALLOWED.



1. ABSTRACT

THIS PROGRAM CONSISTS OF THREE SUB-PROGRAMS WHICH EXERCISE THE DJ11 ASYNCHRONOUS MULTIPLEXER. PROGRAM 1 IS AN OFF-LINE EXERCISER. PROGRAM 2 IS AN ON-LINE EXERCISER WHICH CONTINUOUSLY TRANSMITS THE LAST CHARACTER RECEIVED. PROGRAM 3 IS AN ECHO TEST.

NOTE: PROGRAM 1 WILL RUN ANY SILO ALARM LEVEL SETTING.
(FOR PROGRAM 2 AND 3 SEE SECTION 9.)

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-11 STANDARD COMPUTER WITH CONSOLE TELETYPE
UP TO 16 DJ11 ASYNCHRONOUS MULTIPLEXERS.

2.2 STORAGE

THIS PROGRAM USES ALL OF 8K, EXCEPT ABSOLUTE LOADER.

2.3 PRELIMINARY PROGRAMS

CZDJA DJ11 LOGIC TESTS

3. LOADING PROCEDURE

USE STANDARD PROCEDURE FOR ABS TAPES.

4. STARTING PROCEDURE

4.1 CONTROL SWITCH SETTINGS

SEE 5.1 (ALL DOWN FOR WORST CASE TESTING)

4.2 STARTING ADDRESS

THE PROGRAM SHOULD ALWAYS BE STARTED AT 200. IT MAY BE
RESTARTED AT 1000 AFTER ALL PARAMETERS HAVE BEEN SELECTED.

4.3 PROGRAM AND OPERATOR ACTION

- 1) LOAD PROGRAM INTO MEMORY USING ABS LOADER.
- 2) LOAD ADDRESS 200.
- 3) IF HARDWARE SWITCH REGISTER IS AVAILABLE, SET SWITCHES (SEE SEC. 5.1), ALL DOWN FOR WORST CASE, PRESS START.
- 4) IF SWITCH-LESS PROCESSOR SIMPLY PRESS START.
- 5) ENTER THE PROGRAM NUMBER (1, 2, OR 3).
- 6) SELECT LINES IF SW<8> IS ON A 1.
- 7) PROGRAM 1 WILL LOOP AND BELL WILL RING ONCE EVERY PASS. 'ECF' IS ALSO PRINTED ON EACH PASS.

5. OPERATING PROCEDURE

5.1 OPERATIONAL SWITCH SETTINGS

AT SA 200, ALL SWITCHES DOWN IS WORST CASE TESTING. FOR PROGRAM 1 ONLY, THE BELL WILL RING AND EOP IS PRINTED UPON COMPLETION OF A PASS OF THE ENTIRE PROGRAM.

THE SWITCH SETTINGS ARE:

SW<15> = 1 HALT ON ERROR
SW<13> = 1 INHIBIT PRINTOUT
SW<12> = 1 PRINT SILO ALARM LEVEL (PROG1 ONLY)
SW<10> = 1 BELL ON ERROR
 0 BELL ON PASS COMPLETE (PROG1 ONLY)
SW<9> = 1 INHIBIT MAINTENANCE (PROG1 ON-LINE)
SW<8> = 1 SELECT LINES FOR TEST (SEE 5.3)
PROG1 ONLY:
SW<2:0>= 0 BINARY COUNT PATTERN
 1 "THE QUICK SILVER GRAY FOX ..."
 2 ALPHA-NUMERIC (40-177)
 3-7 ... NOT USED

THIS PROGRAM HAS BEEN MODIFIED TO RUN ON A PROCESSOR WITH OR WITHOUT A HARDWARE SWITCH REGISTER. WHEN FIRST EXECUTED THE PROGRAM TESTS THE EXISTENCE OF A HARDWARE SWITCH REGISTER. IF NOT FOUND A SOFTWARE SWITCH REGISTER LOCATION (SWREG=LOC. 176) IS DEFAULTED TO. IF THIS IS THE CASE, UPON EXECUTION THE CONTENTS OF THE SWREG ARE DUMPED IN OCTAL ON THE CONSOLE TTY AND ANY CHANGES ARE REQUESTED

(I.E.) SWR=XXXXXX NEW=

POSSIBLE RESPONSES ARE:

1. <CR> IF NO CHANGES ARE TO BE MADE.
2. 6 DIGITS 0-7 TO REPRESENT IN OCTAL THE NEW SWITCH REGISTER VALUE; LAST DIGIT FOLLOWED BY <CR>.
3. ^U TO ALLOW REENTERING VALUE IF ERROR IS COMMITTED KEYING IN SWREG VALUE.

BUILT INTO THE PROGRAM IS THE ABILITY TO DYNAMICALLY CHANGE THE CONTENTS OF SWREG DURING PROGRAM EXECUTION. BY STRIKING ^G (CNTRL G) ON CONSOLE TTY THE OPERATOR SETS A REQUEST FLAG TO CHANGE THE CONTENTS OF SWREG, WHICH IS PROCESSED IN KEY AREAS OF THE PROGRAM CODE (IE) ERROR ROUTINES, AFTER HALTS END OF PASS, AND OTHER APPLICABLE AREAS.

5.2 SUBROUTINE ABSTRACTS

5.2.1 HLT

THIS ROUTINE (CALLED BY AN EMT INSTRUCTION) PRINTS OUT AN ERROR MESSAGE (SEE 6.1). TO INHIBIT TYPEOUTS, PUT SW<13> ON A 1. TO RING THE BELL ON AN ERROR, PUT SW<10> ON A 1.

5.2.2 ALMCK (PROG1 ONLY)

IN THE NORMAL OPERATION THE "DONE" BIT IS SET AS EACH CHARACTER IS READ INTO THE FI/FO BUFFER(SILO). BUT THIS "DONE" CONDITION CAN BE DELAYED TO CAUSE DONE ON THE 5, 9, OR 17 CHARACTER. THIS IS DONE BY CUTTING ONE OF THE JUMPERS (W1,W2,W3) ON THE M7285 CONTROL BOARD. THE PROGRAM TESTS FOR THIS "SILO ALARM LEVEL" AND IF SW12 IS SET (1) IT WILL PRINT OUT THE LEVEL (IN OCTAL) AT WHICH EACH DJ11 IS WILL SET "DONE". THE SUBROUTINE ALSO ADJUSTS THE CHARACTER COUNTERS TO ENSURE THAT THE MAXIMUM NUMBER OF CHARACTERS TO BE TRANSFERED IS A MULTIPLE OF THE SILO ALARM LEVEL. THIS ENSURES THAT ALL DATA WILL BE READ OUT OF THE SILO. DONE WILL NOT SET IF THE NUMBER OF CHARACTERS IN THE FI/FO BUFFER IS LESS THAN THE SILO ALARM LEVEL. (NOTE CHARACTER PRESENT IS SET ON EACH CHARACTER IN THE BUFFER, REGARDLESS OF THE SILO ALARM LEVEL.)

5.2.3 TRAPCATCHER

A ".+2" - "HALT" SEQUENCE IS REPEATED FROM 0 - 56 TO DETECT ANY UNEXPECTED TRAPS AND A ".+2" - "IOT" SEQUENCE IS REPEATED FROM 60 - 776 TO DETECT ANY UNEXPECTED INTERRUPTS. THUS ANY UNEXPECTED TRAPS WILL HALT AT THE VECTOR + 2. ANY UNEXPECTED INTERRUPTS WILL RESULT IN AN ERROR MESSAGE AND "HALT" IN "IOTRAP".

5.3 PROGRAM AND OPERATOR ACTION

AFTER THE DEVICE PARAMETERS ARE REPORTED, THE PROGRAM TYPES 'PROGRAM #: ' AT WHICH TIME THE OPERATOR ENTERS '1', '2', OR '3' DEPENDING ON THE SUB-PROGRAM HE WISHES TO RUN.

IF SW<8> IS ON A 1, THE PROGRAM WILL TYPE OUT " N SELECT

LINES ='' THE OPERATOR RESPONDS BY TYPING IN AN OCTAL NUMBER REPRESENTING THE LINE(S) WHICH ARE TO BE TESTED FOR THAT DJ11.(INPUT A 1 FOR LINE 0,A 7 FOR LINES 0,1,AND 2, ETC. THE SAME AS IF YOU WERE DIRECTLY SETTING THE TCR OF THE DJ11.) IF MORE DJ11'S ARE ON THE SYSTEM THE N WILL INDICATE THE NEXT DJ11 AND THE PROMPT IS REISSUED. WHEN ALL LINES ARE SELECTED THE PROGRAM WILL RUN THE SELECTED SUBPROGRAM.

6. ERRORS

6.1 ERROR PRINTOUT

THE FORMAT IS AS FOLLOWS:

ADR (R1) (R2) (R3) (R4)

WHERE:

ADR = ADDRESS OF ERROR HLT
(RN) = CONTENTS OF GENERAL REGISTER 'N'. FROM NONE TO FOUR OF THESE MAY BE TYPED DEPENDING ON THE NUMBER FOLLOWING THE HLT; E.G., HLT+3 WOULD TYPE (R1) THRU (R3); HLT (BY ITSELF) WOULD STOP AFTER TYPING ADR AND DJADR.

TO FIND THE FAILING TEST, LOOK AT THE LISTING ABOVE THE ADDRESS TYPED. IN MOST CASES THE COMMENT BESIDE THE HLT TELLS WHAT WAS BEING CHECKED AND WHAT WAS EXPECTED.

6.2 ERROR RECOVERY

RESTART AT 200 OR 1000.

6.3 ERROR COUNTER

AN ERROR COUNT IS KEPT IN 'ERRORS'. IT CAN BE CLEARED FROM THE CONSOLE, BY RESTARTING AT 200, OR BY RELOADING THE PROGRAM.

7. RESTRICTIONS

THIS PROGRAM REQUIRES THAT THE DEVICE ADDRESSES FOLLOW THE FLOATING ADDRESS CONVENTION (DJ11'S WILL BE FIRST, STARTING AT 160010, THEN THE DJ11'S) AND THAT THE VECTOR ADDRESSES ALL BE CONTIGUOUS. IF THE FIRST DJ11 ADDRESS IS NONSTANDARD (OTHER THAN 160010) THEN LOC. 1270 MUST BE CHANGED TO CONTAIN THIS NONSTANDARD ADDRESS.

IF THIS PROGRAM IS RUN WITH A MONITOR, I.E. ACT11 OR DDP.

ONLY PROGRAM 1 IS RUN.

8. MISCELLANEOUS

8.1 EXECUTION TIME (PROG1 ONLY)

DUE TO THE VARIOUS BAUD RATES AVAILABLE AND THE ABILITY TO CHECK UP TO 16 DJ11'S AT ONCE, THE EXECUTION TIME CAN VARY ANYWHERE FROM 3 SECONDS TO NEARLY AN HOUR. THE FOLLOWING TYPICAL TIMES ARE FOR ONE DJ11 WITH ALL LINES AT THE SAME SPEED, 8 LEVEL CODE, 2 STOP BITS, AND NO PARITY ON A PDP-11/20. FOR MULTIPLE DJ11'S, MULTIPLY THESE TIMES BY THE NUMBER OF UNITS SELECTED FOR TEST.

APPROX
BAUD RUN TIME

75 00:10:00
110 00:07:00
134.5 00:05:40
150 00:05:00
300 00:02:30
600 00:01:15
1200 00:00:40
1800 00:00:30
2400 00:00:20
4800 00:00:10
9600 00:00:05

8.2 STACK POINTER

STACK IS INITIALLY SET TO 1200

8.3 PASS COUNT (PROG1 ONLY)

A 32 BIT (2 WORDS) PASS COUNT IS KEPT IN 'PCNT'. IT CAN BE CLEARED FROM THE CONSOLE, BY RESTARTING AT 200, OR BY RELOADING THE PROGRAM.

8.4 POWER FAIL

EACH PROGRAM CAN BE POWER FAILED WITH NO ERRORS. TO USE, START THE PROGRAM AS USUAL AND POWER DOWN THEN UP AT ANY TIME. THE ROUTINE SHOULD TYPE 'POWER' AND RESTART THE PROGRAM WITH NO OTHER ERROR TYPEOUTS.

9. PROGRAM DESCRIPTION

THIS PROGRAM CONSISTS OF THREE SUB-PROGRAMS WHICH EXERCISE THE LOGIC OF UP TO 16 DJ11 ASYNCHRONOUS DATA MULTIPLEXERS.

PROGRAM 1: EXERCISER (OFF-LINE)

THIS PROGRAM EXERCISES UP TO 256 LINES (16 DJ11'S) SIMULTANEOUSLY IN MAINTENANCE MODE. THREE DIFFERENT DATA PATTERNS MAY BE SELECTED FROM THE SWITCH REGISTER. THE DATA PATTERN IS REPEATED A MINIMUM OF 16 TIMES FOR EACH PASS. THE PROGRAM SHOULD BE RUN FOR AT LEAST 2 PASSES WITH ALL SWITCHES DOWN. SW<9> ON A ONE DISABLES THE MAINTENANCE MODE, REQUIRING TURN-AROUND CARDS AT THE TERMINATION OF EACH LINE BEING TESTED. (NOTE: THE RECIEVER AND TRANSMIT LINES MUST BE JUMPERED FOR THE SAME SPEED.)

PROGRAM 2: CONTINUOUS ECHO EXERCISER (ON-LINE)

THIS PROGRAM CONTINUOUSLY TRANSMITS THE LAST CHARACTER IT RECEIVED ON THE RESPECTIVE LINE. A NULL (000) WILL "ECHO" 72 TIMES AND THEN TURN OFF THE TRANSMITTER.

PROGRAM 3: ECHO TEST (ON-LINE)

THIS PROGRAM TRANSMITS A HEADIN: (*ECHO TEST*) ON EACH LINE AND THEN ECHOS EVERYTHING THAT IT RECEIVES.

CAUTION: IF CHARACTERS ARE RECEIVED FASTER THAN THEY CAN BE TRANSMITTED, THE SOFTWARE BUFFERS MAY OVERFLOW.

NOTE: THE ON-LINE EXERCISERS (PROG2 AND PROG3) ARE OPERATOR DEPENDENT, AND THEREFORE DO NOT LOOP. I.E. NO PASSES. ACT11 AND DDP MONITORS WILL ONLY RUN PROG1.

SWITCH	USE
SW15= 10000	:HALT ON ERROR
SW14= 40000	:NOT USED
SW13= 20000	:INHIBIT ERROR TYPEOUTS
SW12= 10000	:PRINT SILO ALARM LEVEL
SW11= 4000	:NOT USED
SW10= 2000	:0 - BELL ON PASS COMPLETE
	:1 - BELL ON ERROR
SW9= 1000	:ON-LINE (PROG1)
SW8= 400	:SELECT LINES (INITIALIZATION TIME ONLY)
:SW<0:2>	SELECT MESSAGE (PROG1 ONLY)
.REM!	

DJ11 REGISTER BIT ASSIGNMENTS:

CONTROL STATUS REGISTER (CSR) XXXXX0

BIT0 RECEIVER ENABLE (READ/WRITE)
BIT1 HALF DUPLEX SELECT (READ/WRITE)
BIT2 MAINTENANCE (READ/WRITE)
BIT3 CLEAR MOS (WRITE ONLY)
BIT4 CLEAR MOS FLAG (READ ONLY)
BIT5 NOT USED
BIT6 RECEIVER INTERRUPT ENABLE (READ/WRITE)
BIT7 DONE (READ ONLY)
BIT8 MASTER TRANSMITTER SCAN ENABLE (READ/WRITE)
BIT9 NOT USED
BIT10 READ/WRITE BREAK REGISTER (READ/WRITE)
BIT11 NOT USED
BIT12 STATUS ENABLE (READ/WRITE)
BIT13 FI/FO OVERRUN (READ ONLY)
BIT14 MASTER TRANSMITTER INTERRUPT ENABLE (READ/WRITE)
BIT15 TRANSMITTER READY (READ ONLY)

RECEIVER BUFFER REGISTER (RBUF) XXXXX2 (READ ONLY)

BIT0-7 RECEIVED CHARACTER
BIT8-11 LINE NUMBER
BIT12 PARITY ERROR
BIT13 FRAMING ERROR
BIT14 UART OVERRUN ERROR
BIT15 CHARACTER PRESENT

TRANSMITTER CONTROL REGISTER (TCR) XXXXX4 (READ/WRITE)

BIT0-15 STOP THE SCANNER ON CORRESPONDING LINE

TRANSMITTER BUFFER (TBUF) XXXXX6

BIT0-7 TRANSMITTED CHARACTER (WRITE ONLY)
BIT8-11 LINE NUMBER (READ ONLY)

BREAK CONTROL STATUS REGISTER (BCSR) XXXXX4 (BIT10 OF CSR SET) (READ/WRITE)

BIT0-15 TRANSMIT A BREAK ON CORRESPONDING LINE!

SCOPE= TRAP
 HLT= EMT
 TYPE= IOT
 PS= 177776
 R0= %0
 R1= %1
 R2= %2
 R3= %3
 R4= %4
 R5= %5
 TTY= %5
 SP= %6
 PC= %7
 BELL= 7
 BIT0= 1
 BIT1= 2
 BIT2= 4
 BIT3= 10
 BIT4= 20
 BIT5= 40
 BIT6= 100
 BIT7= 200
 BIT8= 400
 BIT9= 1000
 BIT10= 2000
 BIT11= 4000
 BIT12= 10000
 BIT13= 20000
 BIT14= 40000
 BIT15= 100000
 LEVEL7 = 340
 OPEN = 0
 STACK = 1200

491
 492 000000 000000 000000
 493
 494
 495
 496
 497
 498 000046 000046
 499 000046 014622
 500
 501 000174 000174
 502 000174 000000
 503 000176 000000
 504
 505 000200 000200
 506 000200 000137 006312
 507 001000 001000
 508 001000 000137 007316
 509
 510 001200

. = 0 :TRAP CATCHER IN LOCATIONS 0 THRU 776
 0,0 :LOCATIONS 0 AND 2 CONTAIN "HALT" INSTRUCTIONS
 :LOCATIONS 4 THRU 56 CONTAIN ".+2" AND "HALT" IN EVERY VECTOR
 :LOCATIONS 60 THRU 776 CONTAIN ".+2" AND "IOT" IN EVERY VECTOR

. = 46
 \$ENDAD

. = 174
 DISPREG: 0
 SWREG: 0

. = 200
 JMP BEGIN :200 ALWAYS IS THE STARTING ADDRESS
 . = 1000
 JMP RESTAR :RESTART ADDRESS

. = 1200

CZDJBG0 DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 12
DJ11 SPECIFICATIONS

511 001200 000000
512 001202 000000
513 001204 000000 000000
514
515 001210 177570
516 001212 177570
517
518 001214 000000
519 001216 000020
520 001220 000000
521 001222 000000
522 001224 000000
523 001226 000000
524 001230 000000
525 001232 000000
526 001234 000000
527 001236 000000
528 001240 000000
529 001242 000000
530 001244 000000
531 001246 000000
532 001250 000000
533 001252 000000
534 001254 000000
535 001256 000000
536 001260 000000
537 001262 000030
538 001264 000001
539 001266 160010
540 001270 000300
541 001272 000240
542 001274 000240
543 001276 000000
544 001300 000000
545 001302 000000
546 001304 000000
547 001306 000000
548 001310 000000

ICNT: 0
ERRORS: 0
PCNT: 0,0
SWR: 177570
DISPLAY:177570
SAVIT: 0
TIMES: 20
SVSW0: OPEN
SVSW1: OPEN
SVSW2: OPEN
SVSW3: OPEN
SVSW4: OPEN
SVSW5: OPEN
SVSW6: OPEN
SVSW7: OPEN
SVSW10: OPEN
SVSW11: OPEN
SVSW12: OPEN
SVSW13: OPEN
SVSW14: OPEN
SVSW15: OPEN
SVSW16: OPEN
SVSW17: OPEN
MARK: 0
BUFSIZ: 30
UNITS: 1
DEVADR: 160010
VECADR: 300
RCVLVL: 240
XMTLVL: 240
ISRFLG: 0
ALMFLG: 0
TIMERA: 0
TIMERB: 0
COUNT: 0
SUM: 0

: ITERATION COUNT-LH, TEST NO.-RH
: ERROR COUNT REGISTER
: PASS COUNT REGISTER
: MINIMUM NUMBER OF MESSAGES (PROG1)
: MAP OF LINES SELECTED, DJ11 #0
: MAP OF LINES SELECTED, DJ11 #1
: MAP OF LINES SELECTED, DJ11 #2
: MAP OF LINES SELECTED, DJ11 #3
: MAP OF LINES SELECTED, DJ11 #4
: MAP OF LINES SELECTED, DJ11 #5
: MAP OF LINES SELECTED, DJ11 #6
: MAP OF LINES SELECTED, DJ11 #7
: MAP OF LINES SELECTED, DJ11 #10
: MAP OF LINES SELECTED, DJ11 #11
: MAP OF LINES SELECTED, DJ11 #12
: MAP OF LINES SELECTED, DJ11 #13
: MAP OF LINES SELECTED, DJ11 #14
: MAP OF LINES SELECTED, DJ11 #15
: MAP OF LINES SELECTED, DJ11 #16
: MAP OF LINES SELECTED, DJ11 #17

: RECEIVE BUFFER SIZE (PROG3)
: NUMBER OF UNITS ON THE SYSTEM
: FIRST DEVICE ADDRESS
: FIRST VECTOR ADDRESS
: RECEIVER BR LEVEL = 5
: TRANSMITTER BR LEVEL = 5
: INTR SVC RTN FLAG
: SILO ALARM LEVEL FLAG
: TIME COUNTERS
: VALUE OF THE SILO ALARM LEVEL

::++F

549
550 :*****
551 : TABLES
552 :*****

553
554 001312 000400 XMTTAB: .BLKW 400 : TRANSMIT DATA POINTER TABLE
555
556 002312 000400 RCVTAB: .BLKW 400 : RECEIVE DATA POINTER TABLE (PROG1)
557 : RECEIVE DATA TABLE (PROG2 AND PROG3)
558
559 003312 000400 MAXTAB: .BLKW 400 : POINTER FOR XMIT/RCV BFRS.
560
561 004312 000400 XMTCNT: .BLKW 400 : TRANSMIT DATA COUNTER
562 004313 RVCNT=XMTCNT+1 : RECEIVE DATA COUNTER
563
564 005312 000400 MASK: .BLKW 400 : CHARACTER MASK TABLE
565 005313 CNTTAB=MASK+1 : ITERATION COUNT AND FLAGS

::++F

CZDJBG0 DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 13
SET UP AREA

```

566
567 006312 012706 001200 BEGIN: MOV #STACK, SP ;SET UP STACK POINTER
568 006316 012737 000000 177776 MOV #0,@#PS ;;ALLOW INTERUPTS VRG-060382
569 006324 004737 016236 JSR PC,SUSWRR
570 006330 012700 000020 MOV #20,R0
571 006334 012720 015720 MOV #IOTRAP,(R0)+ ;IOT VECTOR (20)
572 006340 012720 000340 MOV #340,(R0)+
573 006344 012720 015556 MOV #PDOWNS,(R0)+ ;POWER FAIL VECTOR (24)
574 006350 012720 000340 MOV #340,(R0)+
575 006354 012720 014636 MOV #EMTS,(R0)+ ;EMT VECTOR (30)
576 006360 012720 000340 MOV #340,(R0)+
577 006364 005037 001202 CLR ERRORS ;CLEAR ERROR COUNTER
578 006370 005037 001204 CLR PCNT ;CLEAR PASS COUNTER
579 006374 005037 001206 CLR PCNT+2
580 006400 012700 000300 MOV #300, R0 ;START OF FLOATING VECTOR AREA
581 006404 005720 2$: TST (R0)+ ;UPDATE POINTER
582 006406 010060 177776 MOV R0, -2(R0) ;PUT '+2' IN EACH VECTOR
583 006412 012720 000004 MOV #IOT, (R0)+ ;AND 'IOT'
584 006416 022700 001000 CMP #1000, R0 ;CHECK FOR END OF FLOATING VECTOR AREA
585 006422 003370 2$ BGT 2$ ;BRANCH IF MORE
586 006424 005037 001300 CLR ALMFLG ;CLEAR THE ALARM FLAG
587 006430 012737 000400 011240 MOV #256.,CNTNIT ;SET MAXIMUM SIZE VALUES
588 006436 012737 000106 011244 MOV #70.,CNTNIT+4 ;FOR PROG #1
589 006444 012737 000106 011250 MOV #70.,CNTNIT+10
590 006452 012737 000001 001216 MOV #1,TIMES ;SET FOR QV ON FIRST PASS
591
592 ;*****
593 ;ROUTINE TO MAP ALL THE DJ11'S ON THE SYSTEM
594 ;*****
595
596 006460 013700 001266 DJMAP: MOV DEVADR, R0 ;GET FIRST FLOATING ADDRESS
597 006464 012702 000001 MOV #1, R2 ;COUNTER FOR DJ11'S
598 006470 012737 000002 000006 MOV #RTI, @#6 ;RTI WHEN TIME-OUT
599 006476 005001 5$: CLR R1 ;SET UP COUNTER
600 006500 000261 1$: SEC ;SET CARRY
601 006502 005710 TST (R0) ;CHECK FOR A DEVICE
602 006504 103404 BCS 7$ ;BRANCH IF NONE
603 006506 062700 000010 6$: ADD #10, R0 ;GO TO NEXT DEVICE ADDRESS
604 006512 005201 INC R1 ;COUNT DJ11'S
605 006514 000771 BR 1$ ;LOOK FOR MORE
606
607 006516 005037 000006 7$: CLR @#6 ;RESTORE TIMEOUT VECTOR
608 006522 010137 001264 MOV R1, UNITS ;SAVE COUNT
609 006526 001005 BNE GETVEC
610 006530 000004 016632 TYPE, MSG01 ;TYPE 'NO DJ11'S!'
611 006534 000000 HALT ;FATAL ERROR
612 006536 000137 014550 JMP @#DONE ;RESTART
613
614 ;*****
615 ;ROUTINE TO DETERMINE VECTOR ADDRESSES OF DJ11'S
616 ;*****
617
618 006542 013746 000020 GETVEC: MOV @#20, -(SP) ;SAVE IOT VECTOR
619 006546 012737 006576 000020 MOV #1$, @#20 ;RESET IOT VECTOR
620 006554 013701 001266 MOV DEVADR, R1 ;FIRST DJ ADDRESS
621 006560 012711 040400 MOV #40400, (R1) ;SET CSR

```

CZDJBG DJ11 EXER & ONLINE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 14
DJ11 VECTOR MAPPING ROUTINE

```

622                                     ;BIT8= TRANS SCAN ENABLE
623                                     ;BIT14= TRANS INTERRUPT ENABLE
624 006564 012761 000001 000004      MOV    #1,    4(R1)      ;TCR, LINE 0
625 006572 000001                    WAIT                    ;WAIT FOR AN INTERRUPT
626 006574 000407                    BR     3$              ;CONTINUE AFTER INTERUPT
627
628 006576 011602                    1$:  MOV    (SP),    R2      ;SAVE VECTOR ADR. (+4)
629 006600 162716 000010              SUB    #10,    (SP)      ;REPOSITION ADR TO RCV. VEC.
630 006604 011637 001270              MOV    (SP),    VECADR   ;SAVE FIRST VECTOR
631 006610 022626                    CMP    (SP)+,    (SP)+   ;RESET STACK FROM IOT
632 006612 000002                    RTI                    ;RETURN FROM INITIAL INTERUPT
633
634 006614 012637 000020              3$:  MOV    (SP)+,    @#20  ;RESTORE IOT VECTOR
635 006620 005742                    TST    -(R2)           ;POINT TO XMT. VEC. +2
636 006622 013703 001264              MOV    UNITS,    R3     ;SET UP UNIT COUNTER
637
638                                     ;CHECK THAT VECTORS ARE CONTIGUOUS
639
640 006626 005061 000004              2$:  CLR    4(R1)         ;CLEAR TCR
641 006632 005011                    CLR    (R1)           ;CLEAR CSR
642 006634 012712 000004              MOV    #IOT,    (R2)   ;RESTORE IOT TO XMT. VEC.+2
643 006640 005303                    DEC    R3             ;CHECK FOR MORE DJ11'S
644 006642 001415                    BEQ    REPORT        ;BRANCH IF DONE
645 006644 062701 000010              ADD    #10,    R1     ;UPDATE DJ ADR. POINTER
646 006650 062702 000010              ADD    #10,    R2     ;UPDATE VECTOR POINTER
647 006654 012712 000002              MOV    #RTI,    (R2)   ;RTI ON INTERRUPT
648 006660 012711 040400              MOV    #40400,    (R1) ;SET CSR
649 006664 012761 000001 000004      MOV    #1,    4(R1)   ;TCR LINE 0
650 006672 000001                    WAIT                    ;WAIT FOR AN INTERRUPT
651 006674 000754                    BR     2$
652
653                                     ;REPORT CONFIGURATION
654
655 006676 032777 020000 172304      REPORT: BIT    #BIT13, @SWR ;CHECK FOR INHIBIT TYP0UT
656 006704 001026                    BNE    GETLEN        ;SKIP REPORT IF SET
657 006706 000004 016453              TYPE,  MSGMDN
658 006712 000004 016442              TYPE,  RETURN
659 006716 000004 016514              TYPE,  MSGADR
660 006722 013705 001266              MOV    DEVADR, TTY   ;TYPE DEVADR IN OCTAL
661 006726 004737 015374              JSR    PC, PRINTR   ;TYPE LEADING ZERO'S
662 006732 000004 016544              TYPE,  MSGVEC
663 006736 013705 001270              MOV    VECADR, TTY  ;TYPE VECADR IN OCTAL
664 006742 004737 015404              JSR    PC, PRINTS   ;AND SUPRESS LEADING ZERO'S
665 006746 000004 016570              TYPE,  MSGNUM
666 006752 013705 001264              MOV    UNITS, TTY   ;TYPE UNITS IN OCTAL
667 006756 004737 015404              JSR    PC, PRINTS   ;AND SUPRESS LEADING ZERO'S

```

668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717

000762 022737 000176 001210
006770 001002
006772 004737 016134
006776 013700 001264
007002 013701 001266
007006 012702 000001
007012 012711 000415
007016 032711 000020
007022 001375
007024 010261 000004
007030 005711
007032 100376
007034 012761 000377 000006
007042 006302
007044 006302
007046 006302
007050 006302
007052 103364
007054 005061 000004
007060 062701 000010
007064 005300
007066 001347
007070 013700 001264
007074 013701 001266
007100 012702 005312
007104 012703 000004
007110 016104 000002
007114 100375
007116 010405
007120 000305
007122 042705 177760
007126 006305
007130 060205
007132 105104
007134 042704 177400
007140 010425
007142 010425
007144 010425
007146 010425
007150 005303
007152 001356
007154 062701 000010
007160 062702 000040
007164 005300
007166 001346

:ROUTINE TO MAP CHARACTER LENGTHS

GETLEN: CMP #SWREG,SWR
BNE 6\$
JSR PC,CNTLU
6\$: MOV UNITS, R0 ;SET UP UNIT COUNTER
MOV DEVADR, R1 ;SET UP DEVICE ADDRESS POINTER
1\$: MOV #1, R2 ;SET UP LINE MARKER
MOV #415, (R1) ;RCV ENB, CMOS, MAINT., TRANS SCAN ENB
10\$: BIT #BIT4, (R1) ;WAIT FOR MOS TO CLEAR
BNE 10\$
2\$: MOV R2, 4(R1) ;TRANS CONTROL, ONE LINE AT A TIME
3\$: TST (R1) ;WAIT FOR TRANS READY
BPL 3\$
MOV #377, 6(R1) ;SEND A RUBOUT
ASL R2 ;SKIP 4 LINES
ASL R2
ASL R2
BCC 2\$;BRANCH BACK IF MORE LINES
CLR 4(R1) ;CLEAR TCR
ADD #10, R1 ;UPDATE POINTER TO NEXT UNIT
DEC R0 ;CHECK FOR MORE UNITS
BNE 1\$
MOV UNITS, R0 ;SET UP UNIT COUNTER
MOV DEVADR, R1 ;SET UP DEVICE ADDRESS POINTER
MOV #MASK, R2 ;SET UP CHAR LEN TABLE POINTER
4\$: MOV #4, R3 ;SET UP CHAR COUNTER
5\$: MOV 2(R1), R4 ;SAVE AND CHECK CHAR PRESENT
BPL 5\$
MOV R4, R5 ;DUP DATA
SWAB R5 ;LINE # IN LOW BYTE
BIC #177760,R5 ;CLEAR ALL BUT LINE #
ASL R5 ;*2
ADD R2, R5 ;MAKE POINTER TO CHAR TABLE
COMB R4 ;MAKE DATA INTO MASK
BIC #177400,R4 ;CLEAR UPPER BYTE
MOV R4, (R5)+ ;SAVE THE MASK
MOV R4, (R5)+ ;SAVE THE MASK
MOV R4, (R5)+ ;SAVE THE MASK
MOV R4, (R5)+ ;SAVE THE MASK
DEC R3 ;COUNT TO 4
BNE 5\$
ADD #10, R1 ;ADDRESS POINTER TO NEXT DJ
ADD #40, R2 ;CHAR LEN TABLE POINTER
DEC R0 ;COUNT UNITS
BNE 4\$;BRANCH BACK IF MORE

```
718  
719  
720 :*****  
721 :SELECT THE PROGRAM TO BE RUN  
722 :PROGRAM 1: OFF-LINE EXERCISER  
723 :PROGRAM 2: ON-LINE EXERCISER (TRANSMIT LAST CHARACTER RECEIVED)  
724 :PROGRAM 3: ON-LINE ECHO EXERCISER  
725 :*****  
726 007170 005737 000042 SELPRO: TST @#42 ;CHECK FOR AC1 11 OR DDP  
727 007174 001040 BNE ALL ;BRANCH IF MONITOR  
728 007176 000004 016613 TYPE, MSGPRG  
729 007202 004537 015030 JSR R5, READIN ;READ A NUMBER FROM THE CTY  
730 007206 007340 .WORD PROGNO  
731 007210 001367 BNE SELPRO  
732 007212 032777 000400 171770 BIT #BIT8, @SWR ;CHECK FOR SW<8>, SELECT LINES  
733 007220 001426 BEQ ALL ;BRANCH IF NOT  
734 007222 005000 CLR R0 ;SET UP UNIT COUNTER, DISPLAY  
735 007224 012701 001220 MOV #SVSW0,R1 ;SET UP SWITCH TABLE POINTER  
736 007230 000004 016442 SWITCH: TYPE, RETURN  
737 007234 000004 016417 TYPE, MNUM  
738 007240 010005 MOV R0,TTY ;PRINT THE NUMBER OF THE DR11C  
739 007242 004737 015404 JSR PC,PRINTS  
740 007246 000004 016422 TYPE, MSGSEL ;ASL FOR THE SELECTED LINES  
741 007252 004537 015030 JSR R5,READIN  
742 007256 001214 .WORD SAVIT  
743 007260 013721 001214 MOV SAVIT,(R1)+  
744 007264 005200 INC R0 ;COUNT UNITS  
745 007266 020037 001264 CMP R0, UNITS ;CHECK FOR MORE UNITS  
746 007272 001356 BNE SWITCH ;BRANCH IF MORE  
747 007274 000410 BR RESTAR ;GO DO IT  
748  
749 007276 013700 001264 ALL: MOV UNITS, R0 ;SET UP UNIT COUNTER  
750 007302 012701 001220 MOV #SVSW0,R1 ;SET UP SWITCH TABLE POINTER  
751 007306 012721 177777 1$: MOV #177777,(R1)+ ;SET ALL LINES  
752 007312 005300 R0 ;COUNT UNITS  
753 007314 001374 BNE 1$ ;BRANCH IF MORE  
754 .SBTTL RESTART POINT  
755  
756 007316 013700 007340 RESTAR: MOV PROGNO, R0  
757 007322 001722 BEQ SELPRO  
758 007324 022700 000003 CMP #3, R0  
759 007330 103717 BLO SELPRO  
760 007332 006300 ASL R0  
761 007334 000170 007340 JMP @PROGAD (R0)  
762  
763 007340 PROGNO: ;  
764 007340 000001 PROGAD: 1 ;DEFAULT TO PROGRAM 1  
765 007342 007350 PROG1  
766 007344 012012 PROG2  
767 007346 013216 PROG3
```

CZDJBG0 DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 17
PROG1: OFF-LINE EXERCISER

768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823

007350 000005
007352 005037 001276
007356 012706 001200
007362 052737 000340 177776
007370 012701 001312
007374 012702 C02000
007400 005021
007402 005302
007404 001375
007406 012702 000400
007412 005201
007414 105021
007416 005302
007420 001374

007422 005000
007424 013701 001266
007430 013702 001270
007434 012703 010400
007440 010322
007442 013722 001272
007446 022323
007450 010113
007452 062723 000002
007456 005723
007460 010322
007462 013722 001274
007466 022323
007470 010123
007472 005011
007474 052711 050510

007500 032711 000020
007504 001375
007506 005737 001300
007512 001002

```
*****  
:PROGRAM 1: TRANSMIT AND RECEIVE ALL LINES SIMULTANEOUSLY  
: OFF-LINE: SW<9> = 0  
: ON-LINE: SW<9> = 1  
: USES THE DATA TABLE SELECTED BY SW<2:0>  
: EACH LINE REPEATS THE PATTERN AT LEAST 16 TIMES  
: PER PASS.  
*****
```

```
PROG1: RESET ;CLEAR OUT THE WORLD  
CLR ISRFLG ;CLEAR INTR. SVC. RTN. FLAG. ;:++F  
MOV #STACK, SP ;RESET THE STACK POINTER  
BIS #340,#PS ;PROCESSOR TO LEVEL 7  
MOV #XMTTAB,R1 ;FIRST TABLE POINTER  
MOV #2000,R2 ;LENGTH OF TABLES (WORDS) ;:++F  
1$: CLR (R1)+ ;CLEAR THE TABLE  
DEC R2  
BNE 1$  
MOV #400,R2 ;LENGTH OF MASK/COUNT TABLE  
2$: INC R1 ;SKIP MASK  
CLRB (R1)+ ;CLEAR COUNT  
DEC R2  
BNE 2$
```

```
:ROUTINE TO INITIALIZE ALL DJ11'S AND THEIR ISR'S:  
:SET UP ALL INTERRUPT VECTORS  
:SET UP DEVICE ADDRESSES IN LINKER ROUTINES  
:SET CSR'S EVERYTHING ENABLED  
:SET TCR'S, ALL LINES ENABLED
```

```
PiINIT: CLR R0  
MOV DEVADR, R1  
MOV VECADR, R2  
MOV #RISR0, R3  
11$: MOV R3, (R2)+ ;SET UP RECEIVER INTERRUPT VECTOR  
MOV RCVLVL, (R2)+  
CMP (R3)+, (R3)+ ;ADD 4 TO R3  
MOV R1, (R3) ;ADDRESS OF CSR  
ADD #2, (R3)+ ;ADDRESS OF RBUF  
TST (R3)+  
MOV R3, (R2)+ ;SET UP TRANSMITTER INTERRUPT VECTOR  
MOV XMTLVL, (R2)+  
CMP (R3)+, (R3)+  
MOV R1, (R3)+ ;ADDRESS OF CSR  
CLR (R1) ;CLEAR CSR  
BIS #50510, (R1) ;SET UP CSR  
;BIT3 = CLEAR MOS  
;BIT6 = RECEIVER INTERRUPT ENABLE  
;BIT8 = TRANSMITTER SCAN ENABLE  
;BIT12 = STATUS ENABLE  
;BIT14 = TRANSMITTER INTERRUPT ENABLE  
13$: BIT #BIT4, (R1) ;CHECK FOR MOS TO CLEAR  
BNE 13$  
TST ALMFLG ;HAS THE SILO ALARM LEVEL BEEN CHECKED?  
BNE 10$ ;YES
```


CZDJBG0 DJ11 FXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 18
PROG1: OFF-LINE EXERCISER

```

824 007514 004737 010032      JSR      PC,ALMCK      ;NO,GO DO IT
825 007520 006300      ASL      RO            ;UNIT # * 2
826 007522 016061 001220 000004 10$:  MOV     SVSWO(RO),4(R1) ;SET TCR BITS (CSR + 4)
827 007530 006200      ASR      RO            ;RESTORE UNIT COUNTER
828 007532 012737 000001 001260  MOV     #1, MARK      ;SET UP MARKER
829 007540 017705 171444      MOV     @SWR, R5      ;GET SWITCH SETTINGS
830 007544 042705 177770      BIC     #177770,R5    ;MASK MESSAGE #
831 007550 006305      ASL      R5
832 007552 006305      ASL      R5
833 007554 012304      MOV     (R3)+, R4     ;SET UP OFFSET TO TABLES
834 007556 033761 001260 000004 14$:  BIT     MARK, 4(R1)   ;CHECK FOR LINE SELECTED IN TCR
835 007564 001414      BEQ     15$
836 007566 016564 011236 001312  MOV     ADRNIT(5),XMTTAB(4)
837 007574 016564 011236 002312  MOV     ADRNIT(5),RCVTAB(4)
838 007602 116564 011240 004312  MOVB   CNTNIT(5),XMTCNT(4)
839 007610 116564 011240 004313  MOVB   CNTNIT(5),RCVCNT(4)
840 007616 005724      TST     (R4)+         ;INC OFFSET TO NEXT LINE
841 007620 006337 001260      ASL     MARK
842 007624 103354      BCC     14$
843 007626 032777 001000 171354  BIT     #BIT9, @SWR   ;CHECK FOR ON-LINE
844 007634 001024      BNE     21$          ;BRANCH IF ON-LINE
845 007636 052711 000014      BIS     #14, (R1)    ;SET THE MAINTENANCE BIT AND CLR MOS
846 007642 032711 000020 20$:  BIT     #BIT4,(R1)   ;WAIT FOR MOS TO CLEAR
847 007646 001375      BNE     20$
848 007650 052711 000001      BIS     #1,(R1)     ;TURN ON RCV ENABLE
849 007654 062701 000010 12$:  ADD     #10,R1       ;POINT TO THE NEXT CSR
850 007660 005200      INC     RO
851 007662 020037 001264      CMP     RO, UNITS
852 007666 001264      BNE     11$
853 007670 012737 000001 001300  MOV     #1,ALMFLG    ;SET THE ALARM LEVEL FLAG
854 007676 042737 000140 177776  BIC     #140, @MPS   ;LOWER PROCESSOR PRIORITY
855 007704 000406      BR     FORGND       ;GO DO IT
856
857 007706 052711 000001 21$:  BIS     #1,(R1)     ;TURN ON RCV EN
858 007712 005761 000002 22$:  TST     2(R1)       ;CLEAR JUNK OUT OF THE RBUF
859 007716 100775      BMI     22$
860 007720 000755      BR     12$
861
862
863 *****
864 ;PROG1 BACKGROUND PROGRAM TO MONITOR TABLES
865 *****
866 ; NOTE - PROGRAM MAY HANG IN A LOOP.
867 ; IF THIS HAPPENS, RUN DZDJA.
868 007722 012701 004312  FORGND: MOV     #XMTCNT,R1
869 007726 012702 000400      MOV     #400,R2
870 007732 105711 21$:  TSTB   (R1)         ;CHECK FOR COUNT TABLE CLR
871 007734 001376      BNE     21$         ;BRANCH IF NOT
872 007736 062701 000002      ADD     #2,R1       ;GO TO NEXT LINE ENTRY
873 007742 005302      DEC     R2          ;COUNT LINES
874 007744 001372      BNE     21$         ;BRANCH IF MORE LINES
875 007746 012701 004313      MOV     #RCVCNT,R1
876 007752 012702 000400      MOV     #400,R2
877 007756 121137 001306 22$:  CMPB   (R1),COUNT  ;IS # OF CHAR LEFT IN RBUF LESS THAN
878                                     ;THE SILO ALARM LEVEL
879 007762 003375      BGT     22$         ;IF NO WAIT FOR THEM

```

```

880 007764 062701 000002 ADD #2,R1 ;IF YES IGNORE THEM
881 007770 005302 DEC R2 ;COUNT LINES
882 007772 001371 BNE 22$ ;BRANCH IF MORE LINES
883 007774 005337 001216 DEC TIMES ;DO THIS AGAIN?
884 010000 001402 BEQ 23$ ;NO, GET OUT
885 010002 000137 007350 'MP PROG1
886 010006 005737 001276 23$: ST ISRFLG ;SEE IF FLAG IS ZERO ;:++F
887 010012 001002 JNE 1$ ;IF NOT, BR ;:++F
888 010014 000004 016366 TYPE, TRNERR ;IF YES, RCV DATA ERROR ;:++F
889 010020 012737 000020 001216 1$: MOV #20,TIMES ;DO IT 16 TIMES THE NEXT TIME
890 010026 000137 014550 JMP @#DONE ;SKIP ISR'S
891 010032 012761 000001 000004 ALMCK: MOV #1,4(R1) ;SET LINE 0 IN THE TCR
892 010040 052711 000004 BIS #BIT2,(R1) ;SET THE MAINT BIT
893 010044 052711 000001 BIS #1,(R1) ;SET RCV EN AFTER MAINTENANCE BIT
894 010050 005037 001306 CLR COUNT
895 010054 005037 001310 CLR SUM
896 010060 005037 001302 CLR 1:;MERA
897 010064 012737 000200 001304 2$: MOV #200,TIMERB ;SET UP TIME CONSTANTS
898 010072 005711 TST (R1) ;WAIT FOR TRANSFER READY BIT
899 010074 100373 BPL 2$
900 010076 112761 000377 000006 MOVB #377,6(R1) ;OUTPUT A CHAR TO TBUF
901 010104 005237 001306 INC COUNT ;COUNT EACH CHAR
902 010110 105711 1$: TSTB (R1) ;CHECK FOR DONE IN THE CSR
903 010112 100405 BMI 3$ ;IF SET GET OUT OF THE LOOP
904 010114 004537 010344 JSR R5,TIME ;GIVE DONE TIME TO SET
905 010120 000773 BR 1$ ;RETURN TO TEST FOR DONE AGAIN
906 010122 000760 BR 2$ ;RETURN TO OUTPUT ANOTHER CHAR
907 010124 000742 BR ALMCK ;ERROR RETURN TRY AGAIN
908 010126 042711 000001 3$: BIC #BIT0,(R1) ;TURN OFF RCV ENABLE
909 010132 052711 000010 BIS #BIT3,(R1) ;CLEAR MOS
910 010136 022737 000001 001306 CMP #1,COUNT ;IF SILO LEVEL SET FOR 1 THEN GET OUT
911 010144 001437 BEQ 4$
912 010146 063737 001306 001310 5$: ADD COUNT,SUM ;GET THE LARGEST MULTIPLE OF THE
913 010154 023727 001310 000106 CMP SUM,#70. ;SILO ALARM LEVEL AND USE IT IN THE
914 010162 002771 BLT 5$ ;THREE SIZE LOCATIONS
915 010164 001403 BEQ 6$ ;IF EQUAL USE IT
916 010166 163737 001306 001310 SUB COUNT,SUM ;IF GREATER SUBTRACT ONE COUNT OFF
917 010174 013737 001310 011244 6$: MOV SUM,CNTNIT+4 ;AS CLOSE TO 70 AS POSSIBLE
918 010202 013737 001310 011250 MOV SUM,CNTNIT+10
919 010210 063737 001306 001310 7$: ADD COUNT,SUM ;CONTINUE TO A COUNT OF 256
920 010216 023727 001310 000377 CMP SUM,#377
921 010224 002771 BLT 7$
922 010226 163737 001306 001310 SUB COUNT,SUM
923 010234 013737 001310 011240 10$: MOV SUM,CNTNIT ;AS CLOSE TO 256 AS POSSIBLE
924 010242 000411 BR 11$ ;ALL SET GET OUT
925 010244 012737 000377 011240 4$: MOV #377,CNTNIT ;PUT SIZE TO MAX VALUE
926 010252 012737 000106 011244 MOV #70.,CNTNIT+4
927 010260 012737 000106 011250 MOV #70.,CNTNIT+10
928 010266 042711 000004 11$: BIC #BIT2,(R1) ;TURN OFF THE MAINT BIT
929 010272 032711 000020 12$: BIT #BIT4,(R1) ;WAIT FOR MOS TO CLEAR
930 010276 001375 BNE 12$
931 010300 004737 016316 JSR PC,KBDINT ;GET THE SWITCH REGISTER
932 010304 032777 010000 170676 BIT #SW12,@SWR ;PRINT ALARM LEVEL?
933 010312 001413 BEQ 13$ ;NO
934 010314 000004 016741 TYPE, MALARM
935 010320 010105 MOV R1,TTY ;YES, PRINT CSR FIRST

```

CZDJBG DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 20
BACKGROUND MONITOR

936 010322 004737 015374
937 010326 000004 016735
938 010332 013705 001306
939 010336 004737 015374
940 010342 000207

JSR PC,PRINTR
TYPE, MSGDAS
MOV COUNT,TTY ;PRINT ALARM LEVEL
JSR PC,PRINTR
13\$: RTS PC

941
942
943
944 010344 105237 001302
945 010350 001012
946 010352 005337 001304
947 010356 001007
948 010360 023727 001306 000022
949 010366 001002
950 010370 104001

TIME: INCB TIMERA ;INCREMENT THROUGH ONE WORD
BNE 1\$;GO TEST FOR DONE AGAIN
DEC TIMERB ;MAKE TIMERB LARGER IF FAST PROCESSOR
BNE 1\$
CMP COUNT,#22 ;HAVE OUTPUTTED 18 TIMES
BNE 2\$;NO, GO OUTPUT ANOTHER CHAR
HLT+1 ;YES, DONE DID NOT SET AFTER 18 OUTPUTS
;R1 = CSR
TST (R5)+ ;SET R5 FOR ERROR RETURN
2\$: TST (R5)+ ;SET R5 FOR NEXT OUTPUT RETURN
1\$: RTS R5 ;RETURN FROM ABOVE OR RETEST DONE

951
952 010372 005725
953 010374 005725
954 010376 000205
955
956
957
958
959

:PROG1 LINKERS TO DJ11 INTERRUPT SERVICE ROUTINES

960 010400 004037 011114
961 010404 160012 000000
962 010410 004037 011000
963 010414 160010 000000
964 010420 004037 011114
965 010424 160022 000040
966 010430 004037 011000
967 010434 160020 000040
968 010440 004037 011114
969 010444 160032 000100
970 010450 004037 011000
971 010454 160030 000100
972 010460 004037 011114
973 010464 160042 000140
974 010470 004037 011000
975 010474 160040 000140
976 010500 004037 011114
977 010504 160052 000200
978 010510 004037 011000
979 010514 160050 000200
980 010520 004037 011114
981 010524 160062 000240
982 010530 004037 011000
983 010534 160060 000240
984 010540 004037 011114
985 010544 160072 000300
986 010550 004037 011000
987 010554 160070 000300
988 010560 004037 011114
989 010564 160102 000340
990 010570 004037 011000
991 010574 160100 000340

RISR0: JSR R0,RCVISR
.WORD <160012+<0*10>>,<40*0>
XISR0: JSR R0,XMTISR
.WORD <160010+<0*10>>,<40*0>
RISR1: JSR R0,RCVISR
.WORD <160012+<1*10>>,<40*1>
XISR1: JSR R0,XMTISR
.WORD <160010+<1*10>>,<40*1>
RISR2: JSR R0,RCVISR
.WORD <160012+<2*10>>,<40*2>
XISR2: JSR R0,XMTISR
.WORD <160010+<2*10>>,<40*2>
RISR3: JSR R0,RCVISR
.WORD <160012+<3*10>>,<40*3>
XISR3: JSR R0,XMTISR
.WORD <160010+<3*10>>,<40*3>
RISR4: JSR R0,RCVISR
.WORD <160012+<4*10>>,<40*4>
XISR4: JSR R0,XMTISR
.WORD <160010+<4*10>>,<40*4>
RISR5: JSR R0,RCVISR
.WORD <160012+<5*10>>,<40*5>
XISR5: JSR R0,XMTISR
.WORD <160010+<5*10>>,<40*5>
RISR6: JSR R0,RCVISR
.WORD <160012+<6*10>>,<40*6>
XISR6: JSR R0,XMTISR
.WORD <160010+<6*10>>,<40*6>
RISR7: JSR R0,RCVISR
.WORD <160012+<7*10>>,<40*7>
XISR7: JSR R0,XMTISR
.WORD <160010+<7*10>>,<40*7>

CZDJBG DJ11 EXER & ONLINE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 21
ISR LINKERS

992 010600 004037 011114
 993 010604 160112 000400
 994 010610 004037 011000
 995 010614 160110 000400
 996 010620 004037 011114
 997 010624 160122 000440
 998 010630 004037 011000
 999 010634 160120 000440
 1000 010640 004037 011114
 1001 010644 160132 000500
 1002 010650 004037 011000
 1003 010654 160130 000500
 1004 010660 004037 011114
 1005 010664 160142 000540
 1006 010670 004037 011000
 1007 010674 160140 000540
 1008 010700 004037 011114
 1009 010704 160152 000600
 1010 010710 004037 011000
 1011 010714 160150 000600
 1012 010720 004037 011114
 1013 010724 160162 000640
 1014 010730 004037 011000
 1015 010734 160160 000640
 1016 010740 004037 011114
 1017 010744 160172 000700
 1018 010750 004037 011000
 1019 010754 160170 000700
 1020 010760 004037 011114
 1021 010764 160202 000740
 1022 010770 004037 011000
 1023 010774 160200 000740
 1024
 1025
 1026
 1027
 1028
 1029 011000
 1030 011000 010146
 1031 011002 010246
 1032 011004 012001
 1033 011006 005711
 1034 011010 100035
 1035 011012 116102 000007
 1036 011016 006302
 1037 011020 061002
 1038 011022 105762 004312
 1039 011026 001410
 1040 011030 117261 001312 000006
 1041 011036 105362 004312
 1042 011042 005262 001312
 1043 011046 000757
 1044 011050 010346
 1045 011052 005062 001312
 1046 011056 161002
 1047 011060 006202

RISR10: JSR R0,RCVISR
 .WORD <160012+<10*10>>,<40*10>
 XISR10: JSR R0,XMTISR
 .WORD <160010+<10*10>>,<40*10>
 RISR11: JSR R0,RCVISR
 .WORD <160012+<11*10>>,<40*11>
 XISR11: JSR R0,XMTISR
 .WORD <160010+<11*10>>,<40*11>
 RISR12: JSR R0,RCVISR
 .WORD <160012+<12*10>>,<40*12>
 XISR12: JSR R0,XMTISR
 .WORD <160010+<12*10>>,<40*12>
 RISR13: JSR R0,RCVISR
 .WORD <160012+<13*10>>,<40*13>
 XISR13: JSR R0,XMTISR
 .WORD <160010+<13*10>>,<40*13>
 RISR14: JSR R0,RCVISR
 .WORD <160012+<14*10>>,<40*14>
 XISR14: JSR R0,XMTISR
 .WORD <160010+<14*10>>,<40*14>
 RISR15: JSR R0,RCVISR
 .WORD <160012+<15*10>>,<40*15>
 XISR15: JSR R0,XMTISR
 .WORD <160010+<15*10>>,<40*15>
 RISR16: JSR R0,RCVISR
 .WORD <160012+<16*10>>,<40*16>
 XISR16: JSR R0,XMTISR
 .WORD <160010+<16*10>>,<40*16>
 RISR17: JSR R0,RCVISR
 .WORD <160012+<17*10>>,<40*17>
 XISR17: JSR R0,XMTISR
 .WORD <160010+<17*10>>,<40*17>

 :PROG1 TRANSMITTER INTERRUPT SERVICE ROUTINE

XMTISR:
 MOV R1,-(6) :PUSH R1 ON STACK
 MOV R2,-(6) :PUSH R2 ON STACK
 MOV (R0)+,R1
 1\$: TST (R1) :CHECK FOR TRANS READY
 BPL 4\$
 MOVB 7(R1),R2 :GET LINE NO.
 ASL R2
 ADD (R0),R2
 TSTB XMTCNT(2) :TST FOR ZERO
 BEQ 2\$
 MOVB @XMTTAB(2),6(1) :SEND A CHARACTER
 DECB XMTCNT(2) :COUNT CHARACTERS
 INC XMTTAB(2) :UPDATE TABLE POINTER
 BR 1\$
 2\$: MOV R3,-(SP)
 CLR XMTTAB(2) :CLEAR TABLE POINTER
 SUB (R0),R2
 ASL R2

CZDJBG0 DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 22
TRANSMITTER ISR

1048 011062 005003
1049 011064 000261
1050 011066 006103
1051 011070 005302
1052 011072 100375
1053 011074 040361 000004
1054 011100 012603
1055 011102 000741
1056 011104
1057 011104 012602
1058 011106 012601
1059 011110 012600
1060 011112 000002

CLR R3
SEC
3\$: ROL R3
DEC R2
BPL 3\$
BIC R3,4(R1) ;CLEAR TCR BIT FOR LINE
MOV (SP)+,R3 ;RESTORE R3
BR 1\$
4\$: MOV (6)+,R2 ;POP STACK INTO R2
MOV (6)+,R1 ;POP STACK INTO R1
MOV (6)+,R0 ;POP STACK INTO R0
RTI

1061
1062
1063
1064
1065

:PROG1 RECEIVER INTERRUPT SERVICE ROUTINE

1066 011114
1067 011114 010146
1068 011116 010246
1069 011120 010346
1070 011122 010446
1071 011124 012001
1072 011126 011102
1073 011130 100032
1074 011132 032702 070000
1075 011136 001403
1076 011140 104002

RCVISR:
MOV R1,-(6) ;PUSH R1 ON STACK
MOV R2,-(6) ;PUSH R2 ON STACK
MOV R3,-(6) ;PUSH R3 ON STACK
MOV R4,-(6) ;PUSH R4 ON STACK
MOV (R0)+,R1 ;GET RBUF ADDRESS
1\$: MOV (R1),R2 ;READ THE DATA
BPL 7\$;BRANCH IF NO CHAR PRESENT
BIT #70000,R2 ;CHECK FOR ERRORS
BEQ 2\$;BRANCH IF OK
HLT+2 ;RECEIVER ERROR
;R1=RBUF ADDRESS
;R2=CONTENTS OF RBUF
;BIT12=PARITY ERROR
;BIT13=FRAMING ERROR
;BIT14=UART OVERRUN

1077
1078
1079
1080
1081
1082 011142 042702 070000
1083 011146 010204
1084 011150 105004
1085 011152 000304
1086 011154 106304
1087 011156 061004
1088 011160 117403 002312
1089 011164 046403 005312
1090 011170 120302
1091 011172 001403
1092 011174 042703 177400
1093 011200 104003
1094
1095
1096

2\$: BIC #70000,R2 ;CLEAR ERROR BITS FOR SPEED
MOV R2,R4 ;DUP THE RBUF
CLRB R4 ;CLEAR THE DATA
SWAB R4 ;LINE # TO LOW BYTE
ASLB R4 ;LINE # * 2, ALSO CLR CHAR PRESENT
ADD (R0),R4 ;ADD OFFSET
MOVB @RCVTAB(R4),R3 ;GET EXPECTED DATA
BIC MASK(4),R3 ;MASK CHARACTER LENGTH
CMPB R3,R2
BEQ 3\$;BRANCH IF OK
BIC #177400,R3 ;MAKE SURE UPPER BYTE CLEAR
HLT+3 ;DATA ERROR
;R1=RBUF ADDRESS
;R2=CONTENTS OF RBUF (DATA)
;R3=EXPECTED DATA

1097 011202 105364 004313
1098 011206 001403
1099 011210 005264 002312
1100 011214 000744
1101 011216
1102 011216 012604
1103 011220 012603

3\$: DECB RCVcnt(4)
BEQ 7\$
INC RCVTAB(4) ;UPDATE TABLE POINTER
BR 1\$;CONTINUE
7\$: MOV (6)+,R4 ;POP STACK INTO R4
MOV (6)+,R3 ;POP STACK INTO R3

CZDJBG DJ11 EXER & ONLINE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 23
RECEIVER ISR

1104	011222	012602		MOV	(6)+,R2	:POP STACK INTO R2	
1105	011224	012601		MOV	(6)+,R1	:POP STACK INTO R1	
1106	011226	012600		MOV	(6)+,R0	:POP STACK INTO R0	
1107	011230	005237	001276	INC	ISRFLG	:STEP INT SVC RTN FLAG	::++F
1108	011234	000002		RTI			

```

1109
1110
1111 :*****
1112 :PROG1 DATA TABLES
1113 :*****

```

1114	011236	011302		ADRNIT:	BINARY	:SW<2:0>=0 BINARY COUNT PATTERN	
1115	011240	000377		CNTNIT:	377	:SIZE=256.	
1116	011242	011702			PHRASE	:SW<2:0>=1 "THE QUICK SILVER GRAY FOX..."	
1117	011244	000106			70.	:SIZE=70.	
1118	011246	011274			SIXBIT	:SW<2:0>=2 040 THRU 137	
1119	011250	000106			70.	:SIZE=70.	

```

1120 011252 016776
1121 011254 000001
1122 011256 017376
1123 011260 000001
1124 011262 017776
1125 011264 000001
1126 011266 020376
1127 011270 000001
1128 011272 020776

```

```

1129 011274 005015 177777 177777 SIXBIT: .ASCII <15><12><377><377><377><377> ;CR-LF, FILLERS

```

```

1130 011302 040
1131 011303 041
1132 011304 042
1133 011305 043
1134 011306 044
1135 011307 045
1136 011310 046
1137 011311 047
1138 011312 050
1139 011313 051
1140 011314 052
1141 011315 053
1142 011316 054
1143 011317 055
1144 011320 056
1145 011321 057
1146 011322 060
1147 011323 061
1148 011324 062
1149 011325 063
1150 011326 064
1151 011327 065
1152 011330 066
1153 011331 067
1154 011332 070
1155 011333 071
1156 011334 072
1157 011335 073
1158 011336 074
1159 011337 075

```

C7DJBG0 DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32MACY11 30A(1052) 07-JUN-82
DATA TABLES

16.36 PAGE 24

1160	011340	076	.BYTE	76
1161	011341	077	.BYTE	77
1162	011342	100	.BYTE	100
1163	011343	101	.BYTE	101
1164	011344	102	.BYTE	102
1165	011345	103	.BYTE	103
1166	011346	104	.BYTE	104
1167	011347	105	.BYTE	105
1168	011350	106	.BYTE	106
1169	011351	107	.BYTE	107
1170	011352	110	.BYTE	110
1171	011353	111	.BYTE	111
1172	011354	112	.BYTE	112
1173	011355	113	.BYTE	113
1174	011356	114	.BYTE	114
1175	011357	115	.BYTE	115
1176	011360	116	.BYTE	116
1177	011361	117	.BYTE	117
1178	011362	120	.BYTE	120
1179	011363	121	.BYTE	121
1180	011364	122	.BYTE	122
1181	011365	123	.BYTE	123
1182	011366	124	.BYTE	124
1183	011367	125	.BYTE	125
1184	011370	126	.BYTE	126
1185	011371	127	.BYTE	127
1186	011372	130	.BYTE	130
1187	011373	131	.BYTE	131
1188	011374	132	.BYTE	132
1189	011375	133	.BYTE	133
1190	011376	134	.BYTE	134
1191	011377	135	.BYTE	135
1192	011400	136	.BYTE	136
1193	011401	137	.BYTE	137
1194	011402	140	.BYTE	140
1195	011403	141	.BYTE	141
1196	011404	142	.BYTE	142
1197	011405	143	.BYTE	143
1198	011406	144	.BYTE	144
1199	011407	145	.BYTE	145
1200	011410	146	.BYTE	146
1201	011411	147	.BYTE	147
1202	011412	150	.BYTE	150
1203	011413	151	.BYTE	151
1204	011414	152	.BYTE	152
1205	011415	153	.BYTE	153
1206	011416	154	.BYTE	154
1207	011417	155	.BYTE	155
1208	011420	156	.BYTE	156
1209	011421	157	.BYTE	157
1210	011422	160	.BYTE	160
1211	011423	161	.BYTE	161
1212	011424	162	.BYTE	162
1213	011425	163	.BYTE	163
1214	011426	164	.BYTE	164
1215	011427	165	.BYTE	165

CZDJBG DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32MACY11 30A(1052) 07-JUN-82 16:36 PAGE 25
DATA TABLES

1216	011430	166	.BYTE	166
1217	011431	167	.BYTE	167
1218	011432	170	.BYTE	170
1219	011433	171	.BYTE	171
1220	011434	172	.BYTE	172
1221	011435	173	.BYTE	173
1222	011436	174	.BYTE	174
1223	011437	175	.BYTE	175
1224	011440	176	.BYTE	176
1225	011441	177	.BYTE	177
1226	011442	200	.BYTE	200
1227	011443	201	.BYTE	201
1228	011444	202	.BYTE	202
1229	011445	203	.BYTE	203
1230	011446	204	.BYTE	204
1231	011447	205	.BYTE	205
1232	011450	206	.BYTE	206
1233	011451	207	.BYTE	207
1234	011452	210	.BYTE	210
1235	011453	211	.BYTE	211
1236	011454	212	.BYTE	212
1237	011455	213	.BYTE	213
1238	011456	214	.BYTE	214
1239	011457	215	.BYTE	215
1240	011460	216	.BYTE	216
1241	011461	217	.BYTE	217
1242	011462	220	.BYTE	220
1243	011463	221	.BYTE	221
1244	011464	222	.BYTE	222
1245	011465	223	.BYTE	223
1246	011466	224	.BYTE	224
1247	011467	225	.BYTE	225
1248	011470	226	.BYTE	226
1249	011471	227	.BYTE	227
1250	011472	230	.BYTE	230
1251	011473	231	.BYTE	231
1252	011474	232	.BYTE	232
1253	011475	233	.BYTE	233
1254	011476	234	.BYTE	234
1255	011477	235	.BYTE	235
1256	011500	236	.BYTE	236
1257	011501	237	.BYTE	237
1258	011502	240	.BYTE	240
1259	011503	241	.BYTE	241
1260	011504	242	.BYTE	242
1261	011505	243	.BYTE	243
1262	011506	244	.BYTE	244
1263	011507	245	.BYTE	245
1264	011510	246	.BYTE	246
1265	011511	247	.BYTE	247
1266	011512	250	.BYTE	250
1267	011513	251	.BYTE	251
1268	011514	252	.BYTE	252
1269	011515	253	.BYTE	253
1270	011516	254	.BYTE	254
1271	011517	255	.BYTE	255

CZDJBG DJ11 EXFR & ONLINE
CZDJBG.P11 07-JUN-82 16:32MACY11 30A(1052) 07-JUN-82 16:36 PAGE 26
DATA TABLES

1272	011520	256	.BYTE	256
1273	011521	257	.BYTE	257
1274	011522	260	.BYTE	260
1275	011523	261	.BYTE	261
1276	011524	262	.BYTE	262
1277	011525	263	.BYTE	263
1278	011526	264	.BYTE	264
1279	011527	265	.BYTE	265
1280	011530	266	.BYTE	266
1281	011531	267	.BYTE	267
1282	011532	270	.BYTE	270
1283	011533	271	.BYTE	271
1284	011534	272	.BYTE	272
1285	011535	273	.BYTE	273
1286	011536	274	.BYTE	274
1287	011537	275	.BYTE	275
1288	011540	276	.BYTE	276
1289	011541	277	.BYTE	277
1290	011542	300	.BYTE	300
1291	011543	301	.BYTE	301
1292	011544	302	.BYTE	302
1293	011545	303	.BYTE	303
1294	011546	304	.BYTE	304
1295	011547	305	.BYTE	305
1296	011550	306	.BYTE	306
1297	011551	307	.BYTE	307
1298	011552	310	.BYTE	310
1299	011553	311	.BYTE	311
1300	011554	312	.BYTE	312
1301	011555	313	.BYTE	313
1302	011556	314	.BYTE	314
1303	011557	315	.BYTE	315
1304	011560	316	.BYTE	316
1305	011561	317	.BYTE	317
1306	011562	320	.BYTE	320
1307	011563	321	.BYTE	321
1308	011564	322	.BYTE	322
1309	011565	323	.BYTE	323
1310	011566	324	.BYTE	324
1311	011567	325	.BYTE	325
1312	011570	326	.BYTE	326
1313	011571	327	.BYTE	327
1314	011572	330	.BYTE	330
1315	011573	331	.BYTE	331
1316	011574	332	.BYTE	332
1317	011575	333	.BYTE	333
1318	011576	334	.BYTE	334
1319	011577	335	.BYTE	335
1320	011600	336	.BYTE	336
1321	011601	337	.BYTE	337
1322	011602	340	.BYTE	340
1323	011603	341	.BYTE	341
1324	011604	342	.BYTE	342
1325	011605	343	.BYTE	343
1326	011606	344	.BYTE	344
1327	011607	345	.BYTE	345

CZDJBG0 DJ11 EXER & ONLINE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 27
DATA TABLES

1328	011610	346	.BYTE	346
1329	011611	347	.BYTE	347
1330	011612	350	.BYTE	350
1331	011613	351	.BYTE	351
1332	011614	352	.BYTE	352
1333	011615	353	.BYTE	353
1334	011616	354	.BYTE	354
1335	011617	355	.BYTE	355
1336	011620	356	.BYTE	356
1337	011621	357	.BYTE	357
1338	011622	360	.BYTE	360
1339	011623	361	.BYTE	361
1340	011624	362	.BYTE	362
1341	011625	363	.BYTE	363
1342	011626	364	.BYTE	364
1343	011627	365	.BYTE	365
1344	011630	366	.BYTE	366
1345	011631	367	.BYTE	367
1346	011632	370	.BYTE	370
1347	011633	371	.BYTE	371
1348	011634	372	.BYTE	372
1349	011635	373	.BYTE	373
1350	011636	374	.BYTE	374
1351	011637	375	.BYTE	375
1352	011640	376	.BYTE	376
1353	011641	377	.BYTE	377
1354	011642	000	.BYTE	0
1355	011643	001	.BYTE	1
1356	011644	002	.BYTE	2
1357	011645	003	.BYTE	3
1358	011646	004	.BYTE	4
1359	011647	005	.BYTE	5
1360	011650	006	.BYTE	6
1361	011651	007	.BYTE	7
1362	011652	010	.BYTE	10
1363	011653	011	.BYTE	11
1364	011654	012	.BYTE	12
1365	011655	013	.BYTE	13
1366	011656	014	.BYTE	14
1367	011657	015	.BYTE	15
1368	011660	016	.BYTE	16
1369	011661	017	.BYTE	17
1370	011662	020	.BYTE	20
1371	011663	021	.BYTE	21
1372	011664	022	.BYTE	22
1373	011665	023	.BYTE	23
1374	011666	024	.BYTE	24
1375	011667	025	.BYTE	25
1376	011670	026	.BYTE	26
1377	011671	027	.BYTE	27
1378	011672	030	.BYTE	30
1379	011673	031	.BYTE	31
1380	011674	032	.BYTE	32
1381	011675	033	.BYTE	33
1382	011676	034	.BYTE	34
1383	011677	035	.BYTE	35

CZDJBG DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 28
DATA TABLES

1384	011700	036		
1385	011701	037		
1386				
1387	011702	005015	177777	177777
1388	011710	044124	020105	052521
1389	011716	041511	020113	044523
1390	011724	053114	051105	043440
1391	011732	040522	020131	047506
1392	011740	020130	052512	050115
1393	011746	042105	047440	042526
1394	011754	020122	026071	033470
1395	011762	026066	032065	026063
1396	011770	030462	027060	020060
1397	011776	040514	054532	042040
1398	012004	043517	020523	000
1399		012012		

.BYTE 36
.BYTE 37

PHRASE: .ASCII <15><12><377><377><377><377>
.ASCIZ "THE QUICK SILVER GRAY FOX JUMPED OVER 9,876,543,210.0 LAZY DOGS!"

.EVEN

CZDJBG0 DJ11 EXER & ONLINE
CZDJ9G P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 29
PROG2: ON-LINE EXERCISER (TRANSMIT LAST CHARACTER RECEIVED)

```

1400
1401
1402 :*****
1403 :PROGRAM 2: ON-LINE MULTI-ECHO EXERCISER
1404 : TRANSMITS THE LAST CHARACTER RECEIVED ON ITS RESPECTIVE
1405 : LINE. A CARRIAGE RETURN AND LINE FEED ARE INSERTED
1406 : EVERY 72 CHARACTERS.
1407 :*****
1408 PROG2: RESET ;CLEAR OUT THE WORLD
1409 012012 000005 MOV #STACK, SP ;RESET THE STACK POINTER
1410 012014 012706 001200 BIS #340, @#PS ;PROCESSOR TO LEVEL 7
1411 012020 052737 000340 177776 MOV #XMTTAB,R1 ;FIRST TABLE POINTER
1412 012026 012701 001312 MOV #2000, R2 ;LENGTH OF TABLES (WORDS) ;:++F
1413 012032 012702 002000 1$: CLR (R1)+ ;CLEAR THE TABLE
1414 012036 005021 DEC R2
1415 012040 005302 BNE 1$
1416 012042 001375 MOV #400,R2 ;LENGTH OF MASK/COUNT TABLE
1417 012044 012702 000400 2$: INC R1 ;SKIP MASK
1418 012050 005201 CLR (R1)+ ;CLEAR COUNT
1419 012052 105021 DEC R2
1420 012054 005302 BNE 2$
1421
1422 :ROUTINE TO INITIALIZE ALL DJ11'S AND THEIR ISR'S:
1423 :SET UP ALL INTERRUPT VECTORS
1424 :SET UP DEVICE ADDRESSES IN LINKER ROUTINES
1425 :SET CSR'S EVERYTHING ENABLED
1426 :SET TCR'S, ALL LINES ENABLED
1427
1428 P2INIT: CLR R0
1429 012060 005000 MOV DEVADR, R1
1430 012062 013701 001266 MOV VECADR, R2
1431 012066 013702 001270 MOV #R2SR0,R3 ;SET UP POINTER TO LINKERS
1432 012072 012703 012250 1$: MOV R3, (R2)+ ;SET UP RECEIVER INTERRUPT VECTOR
1433 012100 013722 001272 MOV RCVLVL, (R2)+
1434 012104 022323 CMP (R3)+, (R3)+ ;ADD 4 TO R3
1435 012106 010113 MOV R1, (R3) ;ADDRESS OF CSR
1436 012110 062723 000002 ADD #2, (R3)+ ;ADDRESS OF RBUF
1437 012114 005723 TST (R3)+
1438 012116 010322 MOV R3, (R2)+ ;SET UP TRANSMITTER INTERRUPT VECTOR
1439 012120 013722 001274 MOV XMTLVL, (R2)+
1440 012124 022323 CMP (R3)+, (R3)+
1441 012126 010123 MOV R1, (R3)+ ;ADDRESS OF CSR
1442 012130 012721 050501 MOV #50501, (R1)+ ;SET UP CSR
1443 ;BIT0 = RECEIVER ENABLE
1444 ;BIT6 = RECEIVER INTERRUPT ENABLE
1445 ;BIT8 = TRANSMITTER SCAN ENABLE
1446 ;BIT12 = STATUS ENABLE
1447 ;BIT14 = TRANSMITTER INTERRUPT ENABLE
1448 012134 005721 TST (R1)+
1449 012136 006300 RO ;UNIT # * 2
1450 012140 016011 001220 MOV SVSWO(R0), (R1) ;SET TCR BITS FOR SELECTED LINES
1451 012144 006200 ASR RO ;RESET UNIT COUNTER
1452 012146 012737 000001 001260 MOV #1, MARK ;SET UP MARKER
1453 012154 012304 MOV (R3)+, R4 ;SET UP OFFSET TO TABLES
1454 012156 033711 001260 4$: BIT MARK, (R1) ;CHECK FOR LINE SELECTED
1455 012162 001406 BEQ 5$

```

CZDJBG0 DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 30
PROG2: ON-LINE EXERCISER (TRANSMIT LAST CHARACTER RECEIVED)

1456	012164	012764	016647	001312
1457	012172	012764	000045	004312
1458	012200	005724		
1459	012202	006337	001260	
1460	012206	103363		
1461	012210	022121		
1462	012212	005200		
1463	012214	020037	001264	
1464	012220	001326		
1465	012222	042737	000140	177776
1466				
1467				
1468				
1469				
1470				
1471	012230	012700	020000	
1472	012234	000241		
1473	012236	005540		
1474	012240	001376		
1475	012242	005700		
1476	012244	001374		
1477	012246	000770		
1478				
1479				
1480				
1481				
1482				
1483	012250	004037	013042	
1484	012254	160012	000000	
1485	012260	004037	012650	
1486	012264	160020	000000	
1487	012270	004037	013042	
1488	012274	160022	000040	
1489	012300	004037	012650	
1490	012304	160030	000040	
1491	012310	004037	013042	
1492	012314	160032	000100	
1493	012320	004037	012650	
1494	012324	160040	000100	
1495	012330	004037	013042	
1496	012334	160042	000140	
1497	012340	004037	012650	
1498	012344	160050	000140	
1499	012350	004037	013042	
1500	012354	160052	000200	
1501	012360	004037	012650	
1502	012364	160060	000200	
1503	012370	004037	013042	
1504	012374	160062	000240	
1505	012400	004037	012650	
1506	012404	160070	000240	
1507	012410	004037	013042	
1508	012414	160072	000300	
1509	012420	004037	012650	
1510	012424	160100	000300	
1511	012430	004037	013042	

```

MOV #MGP2, XMTTAB(4) ;SET UP XMTR TABLE
MOV #45, XMTCNT(4) ;SET UP COUNT
5$: TST (R4)+ ;INC OFFSET TO NEXT LINE
    ASL MARK
    BCC 4$
    CMP (R1)+, (R1)+ ;ADD 4
    INC R0
    CMP R0, UNITS
    BNE 1$
    BIC #140, @MPS ;LOWER PROCESSOR PRIORITY

```

```

*****
:PROG2 FOREGROUND PROGRAM TO READ/WRITE MEMORY
*****

```

```

FORP2: MOV #20000,R0 ;TOP OF 4K BANK OF MEMORY
        CLC
1$: ADC -(R0) ;FAST READ/WRITE TO MEMORY
    BNE 1$ ;RAPID REPEAT
    TST R0 ;CHECK FOR LOC 0
    BNE 1$ ;BRANCH IF MORE MEMORY
    BR FORP2 ;LOOP FOR EVER!

```

```

*****
:PROG2 LINKERS TO DJ11 INTERRUPT SERVICE ROUTINES
*****

```

```

R2SR0: JSR R0,P2RISR
        .WORD <160012+<0*10>>,<0*40>
λ2SR0: JSR R0,P2XISR
        .WORD <160020+<0*10>>,<0*40>
R2SR1: JSR R0,P2RISR
        .WORD <160012+<1*10>>,<1*40>
X2SR1: JSR R0,P2XISR
        .WORD <160020+<1*10>>,<1*40>
R2SR2: JSR R0,P2RISR
        .WORD <160012+<2*10>>,<2*40>
X2SR2: JSR R0,P2XISR
        .WORD <160020+<2*10>>,<2*40>
R2SR3: JSR R0,P2RISR
        .WORD <160012+<3*10>>,<3*40>
X2SR3: JSR R0,P2XISR
        .WORD <160020+<3*10>>,<3*40>
R2SR4: JSR R0,P2RISR
        .WORD <160012+<4*10>>,<4*40>
X2SR4: JSR R0,P2XISR
        .WORD <160020+<4*10>>,<4*40>
R2SR5: JSR R0,P2RISR
        .WORD <160012+<5*10>>,<5*40>
X2SR5: JSR R0,P2XISR
        .WORD <160020+<5*10>>,<5*40>
R2SR6: JSR R0,P2RISR
        .WORD <160012+<6*10>>,<6*40>
X2SR6: JSR R0,P2XISR
        .WORD <160020+<6*10>>,<6*40>
R2SR7: JSR R0,P2RISR

```

CZDJBG0 DJ11 EXER & ONLINE
CZDJBG.P11 07-JUN-82 16.32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 31
ISR LINKERS

1512 012434 160102 000340
1513 012440 004037 012650
1514 012444 160110 000340
1515 012450 004037 013042
1516 012454 160112 000400
1517 012460 004037 012650
1518 012464 160120 000400
1519 012470 004037 013042
1520 012474 160122 000440
1521 012500 004037 012650
1522 012504 160130 000440
1523 012510 004037 013042
1524 012514 160132 000500
1525 012520 004037 012650
1526 012524 160140 000500
1527 012530 004037 013042
1528 012534 160142 000540
1529 012540 004037 012650
1530 012544 160150 000540
1531 012550 004037 013042
1532 012554 160152 000600
1533 012560 004037 012650
1534 012564 160160 000600
1535 012570 004037 013042
1536 012574 160162 000640
1537 012600 004037 012650
1538 012604 160170 000640
1539 012610 004037 013042
1540 012614 160172 000700
1541 012620 004037 012650
1542 012624 160200 000700
1543 012630 004037 013042
1544 012634 160202 000740
1545 012640 004037 012650
1546 012644 160210 000740
1547
1548
1549
1550
1551
1552 012650
1553 012650 010146
1554 012652 010246
1555 012654 012001
1556 012656 005711
1557 012660 100064
1558 012662 116102 000007
1559 012666 006302
1560 012670 061002
1561 012672 105762 004312
1562 012676 001413
1563 012700 117261 001312 000006
1564 012706 105362 004312
1565 012712 105762 005313
1566 012716 001357
1567 012720 005262 001312

```

        .WORD    <160012+<7*10>>,<7*40>
X2SR7: JSR      RO,P2XISR
        .WORD    <160020+<7*10>>,<7*40>
R2SR10: JSR     RO,P2RISR
        .WORD    <160012+<10*10>>,<10*40>
X2SR10: JSR     RO,P2XISR
        .WORD    <160020+<10*10>>,<10*40>
R2SR11: JSR     RO,P2RISR
        .WORD    <160012+<11*10>>,<11*40>
X2SR11: JSR     RO,P2XISR
        .WORD    <160020+<11*10>>,<11*40>
R2SR12: JSR     RO,P2RISR
        .WORD    <160012+<12*10>>,<12*40>
X2SR12: JSR     RO,P2XISR
        .WORD    <160020+<12*10>>,<12*40>
R2SR13: JSR     RO,P2RISR
        .WORD    <160012+<13*10>>,<13*40>
X2SR13: JSR     RO,P2XISR
        .WORD    <160020+<13*10>>,<13*40>
R2SR14: JSR     RO,P2RISR
        .WORD    <160012+<14*10>>,<14*40>
X2SR14: JSR     RO,P2XISR
        .WORD    <160020+<14*10>>,<14*40>
R2SR15: JSR     RO,P2RISR
        .WORD    <160012+<15*10>>,<15*40>
X2SR15: JSR     RO,P2XISR
        .WORD    <160020+<15*10>>,<15*40>
R2SR16: JSR     RO,P2RISR
        .WORD    <160012+<16*10>>,<16*40>
X2SR16: JSR     RO,P2XISR
        .WORD    <160020+<16*10>>,<16*40>
R2SR17: JSR     RO,P2RISR
        .WORD    <160012+<17*10>>,<17*40>
X2SR17: JSR     RO,P2XISR
        .WORD    <160020+<17*10>>,<17*40>

```

```

;*****
;PROG2 TRANSMITTER INTERRUPT SERVICE ROUTINE
;*****

```

```

P2XISR:
        MOV      R1,-(6)           ;PUSH R1 ON STACK
        MOV      R2,-(6)           ;PUSH R2 ON STACK
        MOV      (R0)+,R1
1$:     TST      (R1)               ;CHECK FOR TRANS READY
        BPL      4$
        MOVB     7(R1),R2          ;GET LINE NO.
        ASL      R2
        ADD      (R0),R2
        TSTB     XMTCNT(2)        ;TST FOR ZERO
        BEQ     2$                 ;GET OUT
        MOVB     @XMTTAB(2),6(R1) ;SEND A CHARACTER
        DECB     XMTCNT(2)        ;COUNT CHARACTERS
        TSTB     CNTTAB(2)        ;CHECK FOR MESSAGE OR DATA
        BNE     1$                 ;BRANCH IF DATA
        INC      XMTTAB(2)        ;UPDATE TABLE POINTER

```

CZDJBG DJ11 EXER & ONLINE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 32
TRANSMITTER ISR

```

1568 012724 000754
1569 012726 105162 005313
1570 012732 001430
1571 012734 012762 002312 001312
1572 012742 060262 001312
1573 012746 112762 000110 004312
1574 012754 105762 002312
1575 012760 001336
1576 012762 161002
1577 012764 006202
1578 012766 005037 001260
1579 012772 000261
1580 012774 006137 001260
1581 013000 005302
1582 013002 100374
1583 013004 043761 001260 000004
1584 013012 000721
1585 013014 012762 016442 001312
1586 013022 112762 000002 004312
1587 013030 000712
1588 013032
1589 013032 012602
1590 013034 012601
1591 013036 012600
1592 013040 000002
1593
1594
1595
1596
1597
1598 013042
1599 013042 010146
1600 013044 010246
1601 013046 010346
1602 013050 012001
1603 013052 011102
1604 013054 100053
1605 013056 032702 070000
1606 013062 001402
1607 013064 104302
1608
1609
1610
1611
1612
1613 013066 000771
1614
1615 013070 010203
1616 013072 105003
1617 013074 000303
1618 013076 106303
1619 013100 061003
1620 013102 136302 005312
1621 013106 001401
1622 013110 104002
1623

```

```

2$: BR 1$
COMB CNTTAB(2) ;CHANGE FLAG
BEQ 3$ ;BRANCH IF WAS DATA
MOV #RCVTAB,XMTTAB(2) ;SET UP POINTER TO RECEIVER TABLE
ADD R2,XMTTAB(2) ;ADD OFFSET
MOVB #72,XMTCNT(2) ;COUNT 72. CHARACTERS TO THE LINE
TSTB RCVTAB(2) ;CHECK FOR A BREAK
BNE 1$ ;BRANCH IF REAL DATA
SUB (R0),R2 ;RECOVER LINE NUMBER
ASR R2
CLR MARK ;SET UP MARKER
SEC
ROL MARK ;MOVE MARKER
DEC R2 ;COUNT LINES
BPL 5$ ;BRANCH IF MORE
BIC MARK,4(R1) ;CLEAR TCR BIT
BR 1$ ;CONTINUE
3$: MOV #RETURN,XMTTAB(2) ;TYPE CARRIAGE RETURN, LINE FEED
MOVB #2,XMTCNT(2) ;COUNTER OF 2 CHARACTERS
BR 1$
4$: MOV (6)+,R2 ;POP STACK INTO R2
MOV (6)+,R1 ;POP STACK INTO R1
MOV (6)+,R0 ;POP STACK INTO R0
RTI

```

```

:*****
:PROG2 RECEIVER INTERRUPT SERVICE ROUTINE
:*****

```

```

P2RISR:
MOV R1,-(6) ;PUSH R1 ON STACK
MOV R2,-(6) ;PUSH R2 ON STACK
MOV R3,-(6) ;PUSH R3 ON STACK
MOV (R0)+,R1 ;GET RBUF ADDRESS
1$: MOV (R1),R2 ;READ THE DATA
BPL 7$ ;BRANCH IF NO CHAR PRESENT
BIT #70000,R2 ;CHECK FOR ERRORS
BEQ 2$ ;BRANCH IF OK
HLT+2 ;RECEIVER ERROR
;R1=RBUF ADDRESS
;R2=CONTENTS OF RBUF
;BIT12=PARITY ERROR
;BIT13=FRAMING ERROR
;BIT14=UART OVERRUN
;FORGET THE DATA
BR 1$
2$: MOV R2,R3 ;DUP THE RBUF
CLRB R3 ;CLEAR THE DATA
SWAB R3 ;LINE # TO LOW BYTE
ASLB R3 ;LINE # + 2, ALSO CLR CHAR PRESENT
ADD (R0),R3 ;ADD OFFSET
BITB MASK(3),R2 ;CHECK CHARACTER LENGTH
BEQ 3$ ;BRANCH IF OK
HLT+2 ;CHARACTER LENGTH ERROR
;R1=RBUF ADDRESS

```

CZDJBG DJ11 EXER & ONLINE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 33
RECEIVER ISR

```

1624                                     ;R2=CONTENTS OF RBUF(DATA)
1625 013112 105763 002312      3$:  TSTB  RCVTAB(3)      ;CHECK FOR BREAK
1626 013116 001017                                     ;BRANCH IF REAL DATA
1627 013120 110263 002312      MOVB  R2,   RCVTAB(3) ;SAVE THE DATA
1628 013124 161003      SUB   (R0), R3      ;RECOVER LINE NUMBER
1629 013126 006203      ASR   R3
1630 013130 005037 001260      CLR  MARK          ;SET UP MARKER
1631 013134 000261      SEC
1632 013136 006137 001260      4$:  ROL  MARK          ;UPDATE MARKER
1633 013142 005303      DEC  R3           ;COUNT LINES
1634 013144 100374      BPL  4$          ;BRANCH IF MORE
1635 013146 053761 001260 000002  BIS  MARK, 2(M1)  ;SET TCR BIT
1636 013154 000736      BR   1$          ;CONTINUE
1637
1638 013156 110263 002312      5$:  MOVB  R2,   RCVTAB(3) ;SAVE THE DATA
1639 013162 105163 005313      COMB CNTTAB(3)    ;SET MESSAGE FLAG
1640 013166 012763 016442 001312  MOV  #RETURN,XMTTAB(3) ;TYPE CARRIAGE RETURN, LINE FEED
1641 013174 112763 000002 004312  MOVB #2,   XMTCNT(3) ;MESSAGE LENGTH
1642 013202 000723      BR   1$
1643 013204                                     7$:
1644 013204 012603      MOV  (6)+,R3      ;POP STACK INTO R3
1645 013206 012602      MOV  (6)+,R2      ;POP STACK INTO R2
1646 013210 012601      MOV  (6)+,R1      ;POP STACK INTO R1
1647 013212 012600      MOV  (6)+,R0      ;POP STACK INTO R0
1648 013214 000002      RTI

```


CZDJRGO DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 34
PROG3: ECHO EXERCISER

1649
1650
1651
1652
1653
1654 013216 000005
1655 013220 012706 001200
1656 013224 052737 000340
1657 013232 012701 001312
1658 013236 012702 002000
1659 013242 005021
1660 013244 005302
1661 013246 001375
1662 013250 012702 000400
1663 013254 005201
1664 013256 105021
1665 013260 005302
1666 013262 001374
1667 013264 012705 016776
1668
1669
1670
1671
1672
1673
1674
1675 013270 005000
1676 013272 013701 001266
1677 013276 013702 001270
1678 013302 012703 013570
1679 013306 010322
1680 013310 013722 001272
1681 013314 022323
1682 013316 010113
1683 013320 062723 000002
1684 013324 005723
1685 013326 010322
1686 013330 013722 001274
1687 013334 022323
1688 013336 010123
1689 013340 012721 050400
1690
1691
1692
1693 013344 005721
1694 013346 006300
1695 013350 016011 001220
1696 013354 006200
1697 013356 012737 000001 001260
1698 013364 012304
1699 013366 010246
1700 013370 010346
1701 013372 033711 001260
1702 013376 001420
1703 013400 010564 001312
1704 013404 010564 002312

```

:*****
:PROGRAM 3:      ECHO EXERCISER
:*****
PROG3:  RESET          ;CLEAR OUT THE WORLD
        MOV   #STACK, SP ;RESET THE STACK POINTER
        BIS   #340, @#PS ;PROCESSOR TO LEVEL 7
        MOV   #XMTTAB,R1 ;FIRST TABLE POINTER
        MOV   #2000, R2  ;LENGTH OF TABLES (WORDS)
1$:     CLR   (R1)+      ;CLEAR THE TABLE
        DEC   R2
        BNE   1$
        MOV   #400,R2   ;LENGTH OF MASK/COUNT TABLE
2$:     INC   R1         ;SKIP MASK
        CLRB  (R1)+     ;CLEAR COUNT
        DEC   R2
        BNE   2$
        MOV   #END, R5  ;SET UP BUFFER POINTER
:ROUTINE TO INITIALIZE ALL DJ11'S AND THEIR ISR'S:
:SET UP ALL INTERRUPT VECTORS
:SET UP DEVICE ADDRESSES IN LINKER ROUTINES
:SET CSR'S EVERYTHING ENABLED
:SET TCR'S, ALL LINES ENABLED
P3INIT: CLR   R0
        MOV   DEVADR, R1
        MOV   VECADR, R2
        MOV   #R3SR0,R3 ;SET UP POINTER TO LINKERS
1$:     MOV   R3, (R2)+  ;SET UP RECEIVER INTERRUPT VECTOR
        MOV   RCVLVL, (R2)+
        CMP   (R3)+, (R3)+ ;ADD 4 TO R3
        MOV   R1, (R3)  ;ADDRESS OF CSR
        ADD   #2, (R3)+ ;ADDRESS OF RBUF
        TST   (R3)+
        MOV   R3, (R2)+ ;SET UP TRANSMITTER INTERRUPT VECTOR
        MOV   XMTLVL, (R2)+
        CMP   (R3)+, (R3)+
        MOV   R1, (R3)+ ;ADDRESS OF CSR
        MOV   #50400, (R1)+ ;SET UP CSR, TRANSMITTER ONLY
:BIT8 = TRANSMITTER SCAN ENABLE
:BIT12 = STATUS ENABLE
:BIT14 = TRANSMITTER INTERRUPT ENABLE
        TST   (R1)+
        ASL   R0
        MOV   SVSW0(R0), (R1) ;UNIT # * 2
        MOV   R0 ;SET TCR BITS FOR SELECTED LINES
        ASR   R0 ;RESET UNIT COUNTER
        MOV   #1, MARK ;SET UP MARKER
        MOV   (R3)+, R4 ;SET UP OFFSET TO TABLES
        MOV   R2, -(6) ;PUSH R2 ON STACK
        MOV   R3, -(6) ;PUSH R3 ON STACK
2$:     BIT   MARK, (R1) ;CHECK FOR LINE SELECTED
        BEQ   6$
        MOV   R5, XMTTAB(4) ;SET UP HEADER MESSAGE
        MOV   R5, RCVTAB(4) ;SET UP RECEIVER TABLE

```

::**f

CZDJBG DJ11 EXER & ONLINE
CZDJBG.P11 07-JUN-82 16:32

MACY:1 30A(1052) 07-JUN-82 16:36 PAGE 35
PROG3: ECHO EXERCISER

```

1705 013410 013702 001262      MOV      BUFSIZ, R2      ;SET UP COUNTER
1706 013414 012703 016715      MOV      #MSGP3, R3     ;SET UP MESSAGE POINTER
1707 013420 112325      3$:     MOVVB     (R3)+, (R5)+ ;MOVE MESSAGE INTO BUFFER
1708 013422 001404      BEQ      5$             ;BRANCH IF END OF MESSAGE
1709 013424 005302      DEC      R2             ;COUNT BUFFER SIZE
1710 013426 001374      BNE      3$            ;BRANCH IF MORE
1711 013430 000403      BR       6$            ;BRANCH IF DONE
1712 013432 105025      4$:     CLRB     (R5)+     ;CLEAR REST OF BUFFER
1713 013434 005302      5$:     DEC      R2             ;COUNT BUFFER SIZE
1714 013436 001375      BNE      4$            ;BRANCH IF MORE
1715 013440 010564 003312      6$:     MOV      R5,MAXTAB(4) ;SETUP BFR POINTER TABLE.      ;:++F
1716 013444 005724      TST     (R4)+          ;INC OFFSET TO NEXT LINE
1717 013446 006337 001260      ASL     MARK
1718 013452 103347      BCC     2$
1719 013454 012603      MOV     (6)+,R3        ;POP STACK INTO R3
1720 013456 012602      MOV     (6)+,R2        ;POP STACK INTO R2
1721 013460 022121      CMP     (R1)+, (R1)+   ;ADD 4
1722 013462 005200      INC     R0
1723 013464 020037 001264      CMP     R0, UNITS
1724 013470 001306      BNE     1$
1725 013472 042737 000140 177776      BIC     #140, @#PS     ;LOWER PROCESSOR PRIORITY
1726
1727      ;*****
1728      ;PROG3 FOREGROUND PROGRAM TO START RECEIVERS, THEN EXERCISE MEMORY.
1729      ;*****
1730
1731 013500 012701 001312      FORP3:  MOV     #XMTTAB,R1
1732 013504 012702 000400      MOV     #400,R2
1733 013510 005711      1$:     TST     (R1)          ;CHECK FOR XMTR TABLE CLR
1734 013512 001376      BNE     1$             ;BRANCH IF NOT
1735 013514 062701 000002      ADD     #2,R1          ;GO TO NEXT LINE ENTRY
1736 013520 005302      DEC     R2             ;COUNT LINES
1737 013522 001372      BNE     1$             ;BRANCH IF MORE LINES
1738 013524 013700 001264      MOV     UNITS, R0      ;SET UP UNIT COUNTER
1739 013530 013701 001266      MOV     DEVADR, R1     ;AND DEVICE ADDRESS POINTER
1740 013534 052711 000101      2$:     BIS     #101, (R1)   ;SET RECEIVER ENABLES OF CSR
1741      ;BIT0 = RECEIVER ENABLE
1742      ;BIT6 = RCV INTERRUPT ENABLE
1743 013540 062701 000010      ADD     #10, R1        ;UPDATE TO NEXT DJ11
1744 013544 005300      DEC     R0             ;COUNT DJ11'S
1745 013546 001372      BNE     2$
1746 013550 012700 020000      MEMX3:  MOV     #20000,R0 ;TOP OF 4K BANK OF MEMORY
1747 013554 000241      CLC
1748 013556 005540      1$:     ADC     -(R0)        ;FAST READ/WRITE TO MEMORY
1749 013560 001376      BNE     1$             ;RAPID REPEAT
1750 013562 005700      TST     R0             ;CHECK FOR LOC 0
1751 013564 001374      BNE     1$             ;BRANCH IF MORE MEMORY
1752 013566 000770      BR      MEMX3         ;LOOP FOR EVER!
1753
1754      ;*****
1755      ;PROG3 LINKERS TO DJ11 INTERRUPT SERVICE ROUTINES
1756      ;*****
1757
1758 013570 004037 014320      R3SR0:  JSR     R0,P3RISR
1759 013574 160012 000000      .WORD  <160012+<0*10>>,<0*40>
1760 013600 004037 014170      X3SR0:  JSR     R0,P3XISR

```

CZDJBG0 DJ11 EXER & ONLINE
CZDJBG.P11 07-JUN-82 16:32

MALY11 30A(1052) 07-JUN-82 16:36 PAGE 36
ISR LINKERS

1761	013604	160020	000000		.WORD	<160020+<0*10>>,<0*40>
1762	013610	004037	014320	R3SR1:	JSR	RO,P3RISR
1763	013614	160022	000040		.WORD	<160012+<1*10>>,<1*40>
1764	013620	004037	014170	X3SR1:	JSR	RO,P3XISR
1765	013624	160030	000040		.WORD	<160020+<1*10>>,<1*40>
1766	013630	004037	014320	R3SR2:	JSR	RO,P3RISR
1767	013634	160032	000100		.WORD	<160012+<2*10>>,<2*40>
1768	013640	004037	014170	X3SR2:	JSR	RO,P3XISR
1769	013644	160040	000100		.WORD	<160020+<2*10>>,<2*40>
1770	013650	004037	014320	R3SR3:	JSR	RO,P3RISR
1771	013654	160042	000140		.WORD	<160012+<3*10>>,<3*40>
1772	013660	004037	014170	X3SR3:	JSR	RO,P3XISR
1773	013664	160050	000140		.WORD	<160020+<3*10>>,<3*40>
1774	013670	004037	014320	R3SR4:	JSR	RO,P3RISR
1775	013674	160052	000200		.WORD	<160012+<4*10>>,<4*40>
1776	013700	004037	014170	X3SR4:	JSR	RO,P3XISR
1777	013704	160060	000200		.WORD	<160020+<4*10>>,<4*40>
1778	013710	004037	014320	R3SR5:	JSR	RO,P3RISR
1779	013714	160062	000240		.WORD	<160012+<5*10>>,<5*40>
1780	013720	004037	014170	X3SR5:	JSR	RO,P3XISR
1781	013724	160070	000240		.WORD	<160020+<5*10>>,<5*40>
1782	013730	004037	014320	R3SR6:	JSR	RO,P3RISR
1783	013734	160072	000300		.WORD	<160012+<6*10>>,<6*40>
1784	013740	004037	014170	X3SR6:	JSR	RO,P3XISR
1785	013744	160100	000300		.WORD	<160020+<6*10>>,<6*40>
1786	013750	004037	014320	R3SR7:	JSR	RO,P3RISR
1787	013754	160102	000340		.WORD	<160012+<7*10>>,<7*40>
1788	013760	004037	014170	X3SR7:	JSR	RO,P3XISR
1789	013764	160110	000340		.WORD	<160020+<7*10>>,<7*40>
1790	013770	004037	014320	R3SR10:	JSR	RO,P3RISR
1791	013774	160112	000400		.WORD	<160012+<10*10>>,<10*40>
1792	014000	004037	014170	X3SR10:	JSR	RO,P3XISR
1793	014004	160120	000400		.WORD	<160020+<10*10>>,<10*40>
1794	014010	004037	014320	R3SR11:	JSR	RO,P3RISR
1795	014014	160122	000440		.WORD	<160012+<11*10>>,<11*40>
1796	014020	004037	014170	X3SR11:	JSR	RO,P3XISR
1797	014024	160130	000440		.WORD	<160020+<11*10>>,<11*40>
1798	014030	004037	014320	R3SR12:	JSR	RO,P3RISR
1799	014034	160132	000500		.WORD	<160012+<12*10>>,<12*40>
1800	014040	004037	014170	X3SR12:	JSR	RO,P3XISR
1801	014044	160140	000500		.WORD	<160020+<12*10>>,<12*40>
1802	014050	004037	014320	R3SR13:	JSR	RO,P3RISR
1803	014054	160142	000540		.WORD	<160012+<13*10>>,<13*40>
1804	014060	004037	014170	X3SR13:	JSR	RO,P3XISR
1805	014064	160150	000540		.WORD	<160020+<13*10>>,<13*40>
1806	014070	004037	014320	R3SR14:	JSR	RO,P3RISR
1807	014074	160152	000600		.WORD	<160012+<14*10>>,<14*40>
1808	014100	004037	014170	X3SR14:	JSR	RO,P3XISR
1809	014104	160160	000600		.WORD	<160020+<14*10>>,<14*40>
1810	014110	004037	014320	R3SR15:	JSR	RO,P3RISR
1811	014114	160162	000640		.WORD	<160012+<15*10>>,<15*40>
1812	014120	004037	014170	X3SR15:	JSR	RO,P3XISR
1813	014124	160170	000640		.WORD	<160020+<15*10>>,<15*40>
1814	014130	004037	014320	R3SR16:	JSR	RO,P3RISR
1815	014134	160172	000700		.WORD	<160012+<16*10>>,<16*40>
1816	014140	004037	014170	X3SR16:	JSR	RO,P3XISR

CZDJBG DJ11 EXER & ONLINE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 37
ISR LINKERS

1817 014144 160200 000700
1818 014150 004037 014320
1819 014154 160202 000740
1820 014160 004037 014170
1821 014164 160210 000740

R3SR17: .WORD <160020+<16*10>>,<16*40>
R0,P3RISR
.WORD <160012+<17*10>>,<17*40>
X3SR17: JSR R0,P3XISR
.WORD <160020+<17*10>>,<17*40>

1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865

:*****
:PROG3 TRANSMITTER INTERRUPT SERVICE ROUTINE
:*****

P3XISR:
MOV R1,-(6) ;PUSH R1 ON STACK
MOV R2,-(6) ;PUSH R2 ON STACK
MOV (R0)+,R1
1\$: TST (R1) ;CHECK FOR TRANS READY
BPL 4\$
MOVB 7(R1),R2 ;GET LINE NO.
ASL R2
ADD (R0),R2
MOVB @XMTTAB(2),6(R1);SEND A CHARACTER
CLRB @XMTTAB(2) ;CLR TABLE AFTER USE
INC XMTTAB(2) ;UPDATE TABLE POINTER
CMP MAXTAB(2),XMTTAB(2) ;CHECK FOR END OF BUFFER ;:++F
BNE 5\$;BRANCH IF NOT
SUB BUFSIZ,XMTTAB(2) ;RESET BUFFER POINTER ;:++F
5\$: TSTB @XMTTAB(2)
BNE 1\$;CHECK NEXT CHARACTER
;BRANCH IF MORE DATA
2\$: MOV R3,-(SP)
CLR XMTTAB(2) ;CLEAR TABLE POINTER
SUB (R0),R2
ASL R2
CLR R3
3\$: ROL R3
DEC R2
BPL 3\$
BIC R3,4(R1) ;CLEAR TCR BIT FOR LINE
MOV (SP)+,R3 ;RESTORE R3
BR 1\$
4\$: MOV (6)+,R2 ;POP STACK INTO R2
MOV (6)+,R1 ;POP STACK INTO R1
MOV (6)+,R0 ;POP STACK INTO R0
RTI

014170
014170 010146
014172 010246
014174 012001
014176 005711
014200 100043
014202 116102 000007
014206 006302
014210 061002
014212 117261 001312 000006
014220 105072 001312
014224 005262 001312
014230 026262 003312 001312
014236 001003
014240 163762 001262 001312
014246 105772 001312
014252 001351
014254 010346
014256 005062 001312
014262 161002
014264 006202
014266 005003
014270 000261
014272 006103
014274 005302
014276 100375
014300 040361 000004
014304 012603
014306 000733
014310
014310 012602
014312 012601
014314 012600
014316 000002

:*****
:PROG3 RECEIVER INTERRUPT SERVICE ROUTINE
:*****

P3RISR:
MOV R1,-(6) ;PUSH R1 ON STACK
MOV R2,-(6) ;PUSH R2 ON STACK
MOV R3,-(6) ;PUSH R3 ON STACK
MOV R4,-(6) ;PUSH R4 ON STACK
MOV (R0)+,R1 ;GET RBUF ADDRESS
1\$: MOV (R1),R2 ;READ THE DATA

014320
014320 010146
014322 010246
014324 010346
014326 010446
014330 012001
014332 011102

CZDJHGO DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:32 PAGE 38
RECEIVER ISR

```

1873 014334 100077          BPL      8$          ;BRANCH IF NO CHAR PRESENT
1874 014336 032702 070000  BIT      #70000,R2   ;CHECK FOR ERRORS
1875 014342 001402          BEQ      2$          ;BRANCH IF OK
1876 014344 104002          HLT+2          ;RECEIVER ERROR
1877                          ;R1=RBUF ADDRESS
1878                          ;R2=CONTENTS OF RBUF
1879                          ;BIT12=PARITY ERROR
1880                          ;BIT13=FRAMING ERROR
1881                          ;BIT14=UART OVERRUN
1882 014346 000771          BR       1$          ;SKIP BAD DATA
1883 014350 010204          2$:  MOV    R2,      R4   ;DUP THE RBUF
1884 014352 105004          CLR     R4          ;CLEAR THE DATA
1885 014354 000304          SWAB   R4          ;LINE # TO LOW BYTE
1886 014356 106304          ASLB   R4          ;LINE # * 2, ALSO CLR CHAR PRESENT
1887 014360 061004          ADD    (R0),R4     ;ADD OFFSET
1888 014362 136402 005312  BITB   MASK(4),R2   ;CHECK CHARACTER LENGTH
1889 014366 001401          BEQ    3$          ;BRANCH IF OK
1890 014370 104002          HLT+2          ;CHARACTER LENGTH ERROR
1891                          ;R1=RBUF ADDRESS
1892                          ;R2=CONTENTS OF RBUF(DATA)
1893 014372 005764 002312  3$:  TST    RCVTAB(4)  ;CHECK FOR UNSELECTED LINE
1894 014376 001002          BNE    4$          ;BRANCH IF OK
1895 014400 104002          HLT+2          ;RECEIVED DATA ON UNSELECTED LINE
1896                          ;R1 = RBUF ADDRESS
1897                          ;R2 = CONTENTS OF RBUF
1898 014402 000753          BR     1$          ;IGNORE THE DATA
1899 014404 105774 002312  4$:  TSTB  @RCVTAB(4)  ;CHECK FOR DATA BUFFER FULL
1900 014410 001403          BEQ    5$          ;BRANCH IF OK
1901 014412 104002          HLT+2          ;SOFTWARE DATA BUFFER OVERFLOW
1902                          ;POSSIBLE TRANSMITTER PROBLEM
1903                          ;R1 = RBUF ADDRESS
1904                          ;R2 = CONTENTS OF RBUF
1905          ;NOTE: IF THE ABOVE ERROR WAS DUE TO OVERLOAD, INCREASING THE CONTENTS
1906          ; OF 'BUFSIZ' MAY RECTIFY THE PROBLEM.
1907          ; 'BUFSIZ' MUST BE A MULTIPLE OF 2.
1908          ; INCREASING IT MAY CAUSE THE BUFFERS TO OVERFLOW 4K.
1909 014414 000137 013216  JMP     PROG3      ;RESTART ON THIS TYPE ERROR
1910
1911 014420 005764 001312  5$:  TST    XMTTAB(4)   ;CHECK FOR TRANSMITTER ACTIVE
1912 014424 001414          BEQ    6$          ;BRANCH IF INACTIVE
1913 014426 110274 002312  MOVB   R2, @RCVTAB(4) ;PUT THE DATA IN THE BUFFER
1914 014432 005264 002312  INC    RCVTAB(4)    ;UPDATE POINTER TO NEXT SPACE
1915 014436 026464 003312 002312  CMP    MAXTAB(4),RCVTAB(4) ;CHECK FOR END OF BUFFER      ;:++F
1916 014444 001332          BNE    1$          ;BRANCH IF NOT
1917 014446 163764 001262 002312  SUB    BUFSIZ,RCVTAB(4) ;RESET BUFFER POINTER      ;:++F
1918 014454 000726          BR     1$
1919 014456 016464 003312 002312 6$:  MOV    MAXTAB(4),RCVTAB(4) ;RESET TABLE POINTER      ;:++F
1920 014464 163764 001262 002312  SUB    BUFSIZ,RCVTAB(4)   ;RESET BUFFER      ;:++F
1921 014472 016464 002312 001312  MOV    RCVTAB(4),XMTTAB(4)
1922 014500 110274 002312          MOVB   R2, @RCVTAB(4)
1923 014504 005264 002312          INC    RCVTAB(4)      ;UPDATE POINTER TO NEXT SPACE
1924 014510 161004          SUB    (R0),R4
1925 014512 006204          ASR    R4
1926 014514 005003          CLR   R3
1927 014516 000261          SEC
1928 014520 006103          7$:  ROL    R3

```


CZDJBG0 DJ11 EXER & ONLNE
CZDJBG.F11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 40
BELL AND SCOPE ROUTINE

```

1959
1960
1961
1962
1963
1964
1965
1966
1967
1968 014636 004737 016316
1969 014642 032777 002000 164340
1970 014650 001402
1971 014652 000004 000007
1972 014656 005237 001202
1973 014662 032777 020000 164320
1974 014670 001026
1975 014672 000004 014676
1976 014702 011637 014766
1977 014706 162737 000002 014766
1978 014714 117737 000046 014764
1979 014722 013705 014766
1980 014726 004737 015374
1981 014732 000004 014736
1982 014742 004737 014770
1983 014746 005777 164236
1984 014752 100001
1985 014754 000000
1986 014756 004737 016316
1987 014762 000002
1988
1989 014764 000000
1990 014766 000000
1991
1992 014770 042737 007700 015012
1993 014776 105337 014764
1994 015002 100411
1995 015004 062737 000100 015012
1996 015012 010005
1997 015014 004737 015374
1998 015020 000004 016450
1999 015024 000764
2000 015026 000207

;          $HLT          ERROR TYPEOUT HANDLER

;THIS ROUTINE PRINTS OUT ERROR MESSAGES STARTING WITH THE
;ADDRESS OF THE 'HLT'. IT ALSO COUNTS THE NUMBER OF ERRORS
;AND HAS THE CAPABILITY OF LOOPING ON ERROR, BELL ON ERROR,
; 'HALT' ON ERROR, AND INHIBIT TYPEOUTS. AN OPTIONAL ARGUEMENT
; (HLT+3) WILL BE PLACED IN 'HLTCTS:' FOR ADITIONAL TYPEOUTS.

EMTS:  JSR      PC,      KBDINT
        BIT      #SW10,@SWR      ;BELL ON ERROR?
        BEQ      1$              ;NO - SKIP
        TYPE     ,BELL            ;RING BELL
        INC      ERRORS          ;COUNT THE NUMBER OF ERRORS
1$:     BIT      #SW13,@SWR      ;SKIP TYPEOUT IF SET
        BNE      2$              ;SKIP TYPEOUTS
        TYPE     ..+2            ;.ASCIZ <15><12>
        MOV      (6),HLTADR      ;PUT ADDRESS OF INSTRUCTION ON STACK
        SUB      #2,HLTADR      ;FUDGE ADDRESS
        MOV      @HLTADR,HLTCTS  ;GET HLT ARGUEMENT
        JSR      HLTADR,TTY      ;TYPE HLTADR IN OCTAL
        TYPE     PC,PRINTR      ;TYPE LEADING ZERO'S
        TYPE     ..+2            ;.ASCIZ " "
        JSR      PC,ERRORS      ;GO TO USER ERROR ROUTINE
2$:     TST      @SWR            ;HALT ON ERROR
        BPL      .+4            ;SKIP IF CONTINUE
        HALT     ;HALT ON ERROR!
        JSR      PC,KBDINT
        RTI                       ;RETURN

HLTCTS: 0
HLTADR: 0

;HLT ARGUEMENT
;LAST HLT INSTRUCTION EXECUTED

ERRORS: BIT      #7700,PC
1$:     DF CB      HLTCTS
        E,AI      3$
        ADD      #100,2$
2$:     MCV      X0,TTY
        JSR      X7,PRINTR
        TYPE     SPACE
        BR       1$
3$:     RTS      PC

;TYPE REGISTER X IN OCTAL

```

CZDJBG DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 41
OCTAL NUMBER INPUT ROUTINE

```

2001
2002 ;SUBROUTINE TO SAVE INPUT AS OCTAL NUMBER
2003
2004 015030 012737 000001 015322 READIN: MOV #1,INHRE
2005 015036 004737 015176 JSR PC, READS ;GO READ TTY UNTIL CR
2006 015042 005037 015322 CLR INHRE
2007 015046 010146 MOV R1,-(6) ;PUSH R1 ON STACK
2008 015050 010246 MOV R2,-(6) ;PUSH R2 ON STACK
2009 015052 010346 MOV R3,-(6) ;PUSH R3 ON STACK
2010 015054 012501 MOV (R5)+, R1
2011 015056 012737 000020 016214 MOV #20,CNT
2012 015064 012702 015324 MOV #INPUT,R2
2013 015070 122712 000120 CMPB #120,(R2) ;CHECK FOR 'P'
2014 015074 001425 BEQ 3$
2015 015076 005011 CLR (R1)
2016 015100 112203 1$: MOVB (R2)+,R3
2017 015102 120327 000015 CMPB R3,#15
2018 015106 001420 BEQ 3$ ;BRANCH WHEN DONE
2019 015110 162703 000060 SUB #60,R3
2020 015114 032703 177770 BIT #177770,R3
2021 015120 001013 BNE 3$ ;BRANCH IF BAD DATA
2022 015122 006311 ASL (R1)
2023 015124 103410 BCS 2$
2024 015126 006311 ASL (R1)
2025 015130 103406 BCS 2$
2026 015132 006311 ASL (R1)
2027 015134 103404 BCS 2$
2028 015136 050311 BIS R3,(R1)
2029 015140 005337 016214 DEC CNT
2030 015144 000755 BR 1$
2031 015146 000244 2$: CLZ
2032 015150 013737 177776 015174 3$: MOV @#PS, PSTEMP ;MAKE SURE Z-BIT IS CLR
2033 015156 012603 MOV (6)+,R3 ;SAVE CONDITION CODES
2034 015160 012602 MOV (6)+,R2 ;POP STACK INTO R3
2035 015162 012601 MOV (6)+,R1 ;POP STACK INTO R2
2036 015164 013737 015174 177776 MOV PSTEMP, @#PS ;POP STACK INTO R1
2037 015172 000205 RTS R5 ;RESTORE CONDITION CODES
2038
2039 015174 000000 PSTEMP: 0 ;TEMPORARY STORAGE FOR PS
2040
2041 015176 010346 READS: MOV R3,-(6) ;SAVE R3
2042 015200 012703 015324 1$: MOV #INPUT,R3 ;GET ADDRESS
2043 015204 022703 015344 2$: CMP #INPUT+20,R3 ;BUFFER FULL?
2044 015210 001415 BEQ 4$ ;YES - TYPE '?'
2045 015212 105737 177560 TSTB @#177560 ;WAIT FOR
2046 015216 100375 BPL #-4 ;A CHARACTER
2047 015220 113713 177562 MOVB @#177562,(3) ;GET CHARACTER
2048 015224 142713 000200 BICB #200,(3) ;GET RID OF JUNK
2049 015230 122713 000177 CMPB #177,(3) ;IS IT A RUBOUT
2050 015234 001403 BEQ 4$ ;SKIP IF NOT
2051 015236 122713 000025 CMPB #25,(3)
2052 015242 001006 BNE 3$
2053 4$: TYPE
2054 015244 000004 015250 BR 1$ ;.ASCIZ '?'<15><12>'= ''
2055 015256 000750 3$: BR 1$ ;ZAP THE BUFFER AND LOOP
2056 015260 111337 016132 MOVB (3),.TYPE ;SET UP FOR TYPING

```


CZDJBGO DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 42
TTY INPUT ROUTINE

```

2057 015264 000004 016132          TYPE      .TYPE      ;ECHO IT
2058 015270 122723 000015          CMPB      #15,(3)+   ;CHECK FOR RETURN
2059 015274 001343          BNE       2$      ;LOOP IF NOT RETURN
2060 015276 005737 015322          TST      INHRE
2061 015302 001401          BEQ      5$
2062 015304 000402          BR       6$
2063 015306 105063 177777          5$: CLRB   -1(3)      ;ZAP RETURN (THE 15)
2064 015312 000004 000012          6$: TYPE   ,12      ;TYPE A LINE FEED
2065 015316 012603          MOV      (6)+,R3   ;RESTORE R3
2066 015320 000207          RTS      PC        ;RETURN
2067
2068 015322 000000          INHRE:    0
2069 015324 000020          INPUT:   .BLKW   20      ;TTY INPUT AREA
2070          ;          $OCTAL          OCTAL TYPEOUT ROUTINE
2071
2072          ;THIS ROUTINE IS USED TO TYPE AN OCTAL NUMBER ON THE TTY. IT WILL TYPE
2073          ;ALL 6 CHARACTERS, SUPPRESS LEADING ZEROES, TYPE AN 18 BIT ADDRESS, OR TYPE
2074          ;THE 16 BITS. IT IS CALLED VIA THE DUMP. SCUMP, DUMP18, OR BITYPE MACRO'S.
2075
2076 015364 012737 170101 015532 BITYPS: MOV   #170101,.PR ;SET BIT FLAG ANS 16. CHARACTER COUNT
2077 015372 000411          BR       .PTIT      ;NOW TYPE IT IN BIT FORM
2078 015374 112737 000001 015532 PRINTR: MOVB  #1,.PR   ;SET ZERO FILL SWITCH
2079 015402 000402          BR       .+6        ;SKIP
2080 015404 005037 015532          PRINTS: CLR   .PR   ;SUPPRESS LEADING ZERO'S
2081 015410 112737 177772 015533          MOVB     #-6,.PR+1 ;SET COUNT
2082 015416 010446          .PTIT:  MOV   R4,-(6) ;SAVE R4
2083 015420 012704 015534          MOV      #.PR+2,R4 ;SET POINTER TO FIRST ASCII CHAR.
2084 015424 105014          CLRB    (4)        ;CLEAR FIRST BYTE
2085 015426 000411          BR      .PRF       ;ROTATE FIRST BIT
2086 015430 105014          .PRL:   CLRB   (4)  ;CLEAR BYTE OF CHARACTER
2087 015432 032737 000100 015532          BIT     #100,.PR   ;BIT TYPING MODE?
2088 015440 001004          BNE     .PRF       ;YES - SKIP 2 ROTATES
2089 015442 006105          ROL     TTY       ;ROTATE BIT INTO C
2090 015444 106114          ROLB   (4)        ;PACK IT
2091 015446 006105          ROL     TTY       ;ROTATE BIT INTO C
2092 015450 106114          ROLB   (4)        ;PACK IT
2093 015452 006105          .PRF:   ROL     TTY ;ROTATE BIT INTO C
2094 015454 106114          ROLB   (4)        ;PACK IT
2095 015456 105714          TSTB   (4)        ;IS IT ZERO?
2096 015460 001402          BEQ     .+6        ;SKIP INC
2097 015462 105237 015532          INCB   .PR        ;SET FILL SWITCH
2098 015466 105737 015532          TSTB   .PR        ;CHECK FILL SWITCH
2099 015472 001402          BEQ     .+6        ;SKIP BITSET
2100 015474 152724 000060          BLSB   #'0,(4)+   ;MAKE INTO ASCII CHAR
2101 015500 105237 015533          INCB   .PR+1      ;INC COUNT
2102 015504 001351          BNE     .PRL       ;REPEAT
2103 015506 022704 015534          CMP    #.PR+2,R4  ;EMPTY BUFFER?
2104 015512 001002          BNE     .+6        ;SKIP IF NOT
2105 015514 112724 000060          MOVB   #'0,(4)+   ;LOAD 1 ZERO
2106 015520 105014          CLRB   (4)        ;NULL TERMINATOR
2107 015522 000004 015534          TYPE   .,PR+2     ;TYPE IT
2108 015526 012604          MOV    (6)+,R4    ;RESTORE R4
2109 015530 000207          RTS    PC         ;RETURN
2110 015532 000012          .PR:   .BLKW   12  ;COUNT, SWITCH, AND OUTPUT BUFFER

```

CZDJBG0 DJ11 EXER & ONLNE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 43
POWER DOWN AND UP ROUTINES

```

2111 015556 012777 015704 000126 PDOWN$: MOV #ILLUP,@PUVECS :SET FOR FAST UP
2112 015564 012777 000340 000122 MOV #340,@PUVECS+2 :PRIO:7
2113 015572 010046 MOV R0,-(6) :PUSH R0 ON STACK
2114 015574 010146 MOV R1,-(6) :PUSH R1 ON STACK
2115 015576 010246 MOV R2,-(6) :PUSH R2 ON STACK
2116 015600 010346 MOV R3,-(6) :PUSH R3 ON STACK
2117 015602 010446 MOV R4,-(6) :PUSH R4 ON STACK
2118 015604 010546 MOV R5,-(6) :PUSH R5 ON STACK
2119 015606 010637 015710 MOV SP,.SAVR6 :SAVE SP
2120 015612 012777 015622 000072 MOV #PUPS,@PUVECS :SET UP VECTOR
2121 015620 000000 HALT :WAIT FOR PF
2122
2123 015622 013706 015710 PUPS: MOV .SAVR6,SP :GET SP
2124 015626 005001 CLR R1 :WAIT LOOP FOR THE TTY
2125 015630 005201 1$: INC R1 :WAIT FOR THE INC
2126 015632 001376 BNE 1$ :OF WORD
2127 015634 012605 MOV (6)+,R5 :POP STACK INTO R5
2128 015636 012604 MOV (6)+,R4 :POP STACK INTO R4
2129 015640 012603 MOV (6)+,R3 :POP STACK INTO R3
2130 015642 012602 MOV (6)+,R2 :POP STACK INTO R2
2131 015644 012601 MOV (6)+,R1 :POP STACK INTO R1
2132 015646 012600 MOV (6)+,R0 :POP STACK INTO R0
2133 015650 012737 015556 000024 MOV #PDOWN$,@#24 :SET UP THE POWER DOWN VECTOR
2134 015656 012737 000340 000026 MOV #340,@#26 :PRIO:7
2135 015664 000004 015670 TYPE :.ASCIZ <15><12>'POWER'
2136 015700 000137 007316 JMP RESTAR :JMP TO USER ADDRESS
2137
2138 015704 000000 ILLUP: HALT :THE POWER UP SEQUENCE WAS STARTED
2139 015706 009776 BR -2 : BEFORE THE POWER DOWN WAS COMPLETE
2140
2141 015710 000000 .SAVR6: 0 :PUT THE SP HERE
2142 015712 000024 000026 PUVECS: 24,26 :POWER UP VECTOR
2143
2144
2145 015716 0C0002 YESRT: RTI :RETURN FROM TRACE TRAP

```

CZDJBG DJ11 EXER & ONLINE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 44
IOT HANDLER

2146
2147
2148
2149
2150
2151
2152 015720 022716 001000
2153 015724 002440
2154 015726 152716 000004
2155 015732 000004 015736
2156 015736 005015 047125 054105
2157 015744 042520 052103 042105
2158 015752 044440 052116 051105
2159 015760 050125 020124 047524
2160 015766 000040
2161 015770 012605
2162 015772 004737 015404
2163 015776 005726
2164 016000 000004 016004
2165 016004 043040 047522 020115
2166 016012 000
2167 016014 016014
2168 016014 011605
2169 016016 004737 015404
2170 016022 000000
2171 016024 000002
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181 016026 010546
2182 016030 017605 000002
2183 016034 032705 177400
2184 016040 001004
2185 016042 019537 016132
2186 016046 012705 016132
2187 016052 105715
2188 016054 001406
2189 016056 112537 177566
2190 016062 105737 177564
2191 016066 100375
2192 016070 000770
2193 016072 017646 000002
2194 016076 062766 000002 000004
2195 016104 022666 000002
2196 016110 001006
2197 016112 062705 000002
2198 016116 042705 000001
2199 016122 010566 000002
2200 016126 012605
2201 016130 000002

```

:*****
:IOT HANDLER - REENTERENT ROUTINE TO INDICATE A FALSE
:          INTERRUPT OR TRAP, OR TO TYPE A MESSAGE
:*****

```

```

IOTRAP: CMP      #1000, (SP)      ;CHECK RETURN ADDRESS
        BLT      IOTS          ;BRANCH IF TYPE COMMAND
        SUB      #4, (SP)       ;GET VECTOR ADDRESS
        TYPE,    .+2           ;TYPE MESSAGE
        .ASCIIZ  <15><12>'UNEXPECTED INTERUPT TO '

        MOV      (SP)+,TTY      ;TYPE (SP)+ IN OCTAL
        JSR      PC,PRINTS     ;AND SUPPRESS LEADING ZERO'S
        TST      (SP)+         ;POP STACK
        TYPE,    .+2           ;TYPE MESSAGE
        .ASCIIZ  ' FROM '

        .EVEN
        MOV      (SP),TTY      ;TYPE (SP) IN OCTAL
        JSR      PC,PRINTS     ;AND SUPPRESS LEADING ZERO'S
        HALT
        RTI                    ;CONTINUE IF DESIRED

```

```

:      $TYPE      MESSAGE TYPEOUT ROUTINE

:THIS ROUTINE IS USE TO TYPE ASCII MESSAGES ON THE TTY. THE
:CALL CAN BE IN ONE OF 3 FORMS: 1) 'TYPE ,ADR' - TYPES THE
:MESSAGE STARTING IN LOCATION 'ADR:' 2) 'TYPE ,CHAR' - TYPES
:THE ASCII 'CHAR', AND 3) 'PRINT <<15><12>'MESSAGE'> - TYPES
:THE MESSAGE WHICH IS INLINE ASCII.

```

```

IOTS:  MOV      TTY,-(6)        ;SAVE TTY
        MOV      @2(6),TTY      ;GET ADDRESS TO BE TYPED
        BIT      #177400,TTY    ;IS IT A TYPEN?
        BNE     1$             ;NO
        MOV      TTY,.TYPE      ;GET THE CHARACTER
        MOV      #.TYPE,TTY     ;FUDGE THE ADDRESS
1$:    TSTB     (TTY)           ;TERMINATOR?
        BEQ     2$             ;GET OUT IF SO
        MOVB    (TTY)+,@#177566 ;LOAD AND TYPE THE CHARACTER
        TSTB    @#177564       ;IS THE PRINTER READY
        BPL     .-4            ;WAIT UNTIL IT IS
        BR      1$             ;GET THE NEXT CHARACTER
2$:    MOV      @2(6),-(6)      ;GET ADDRESS TO BE TYPED
        ADD     #2,4(6)         ;ADD 2 TO THE ADDRESS
        CMP     (6)+,2(6)       ;IS IT .+2?
        BNE     3$             ;NO
        ADD     #2,TTY          ;ADD 2 TO THE ADDRESS
        BIC     #1,TTY          ;BACK UP TO AN EVEN BYTE
3$:    MOV      TTY,2(6)       ;RESTORE ADDRESS
        MOV      (6)+,TTY      ;RESTORE TTY
        RTI                    ;RETURN

```


CZDJBG DJ11 EXER & ONLINE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 46
TYPE ROUTINE

2258	016416	000			
2259	016417	043	000040		MNUM: .ASCIZ '# ''
2260	016422	051440	046105	041505	MSGSEL: .ASCIZ '' SELECT LINE = ''
2261	016430	020124	044514	042516	
2262	016436	036440	000040		
2263	016442	005015	177777	000377	RETURN: .ASCIZ <15><12><377><377><377>
2264	016450	020040	000		SPACE: .ASCIZ '' ''
2265	016453	015	177412	055103	MSGMDN: .ASCIZ <15><12><377>'CZDJBG-G-0 DJ11 EXER & ONLINE''
2266	016460	045104	026502	026507	
2267	016465	020060	020040	045104	
2268	016474	030461	042440	042530	
2269	016502	020122	020046	047117	
2270	016510	047114	000105		
2271	016514	005015	044506	051522	MSGADR: .ASCIZ <15><12>'FIRST DJ11 ADDRESS: ''
2272	016522	020124	045104	030461	
2273	016530	040440	042104	042522	
2274	016536	051523	020072	000040	
2275	016544	005015	042526	052103	MSGVEC: .ASCIZ <15><12>'VECTOR ADDRESS: ''
2276	016552	051117	040440	042104	
2277	016560	042522	051523	020072	
2278	016566	000040			
2279	016570	005015	047516	020056	MSGNUM: .ASCIZ <15><12>'NO. OF DJ11'S: ''
2280	016576	043117	042040	030512	
2281	016604	023461	035123	020040	
2282	016612	000			
2283	016613	015	050012	047522	MSGPRG: .ASCIZ <15><12>'PROGRAM #: ''
2284	016620	051107	046501	021440	
2285	016626	020072	000040		
2286	016632	005015	047516	042040	MSG01: .ASCIZ <15><12>'NO DJ11'S!''
2287	016640	030512	023461	020523	
2288	016646	000			
2289	016647	015	050012	047522	MSGP2: .ASCIZ <15><12>'PROG2: CONTINUOUS ECHO EXERCISER'<15><12>
2290	016654	031107	020072	041440	
2291	016662	047117	044524	052516	
2292	016670	052517	020123	041505	
2293	016676	047510	042440	042530	
2294	016704	041522	051511	051105	
2295	016712	005015	000		
2296	016715	015	025012	041505	MSGP3: .ASCIZ <15><12>'ECHO TEST'<15><12>
2297	016722	047510	052040	051505	
2298	016730	025124	005015	000	
2299	016735	040	020055	000	MSGDAS: .ASCIZ '' - ''
2300	016741	015	051412	046111	MALARM: .ASCIZ <15><12>'SILO ALARM LEVEL FOR CSR'<15><12>
2301	016746	020117	046101	051101	
2302	016754	020115	042514	042526	
2303	016762	020114	047506	020122	
2304	016770	051503	006522	000012	
2305					.EVEN
2306	016776	000000			END: 0
2307		000001			.END

CZDJBG DJ11 EXER & ONLINE
CZDJBG.P11 07-JUN-82 16:32

MACY11 30A(1052) 07-JUN-82 16:36 PAGE 56
CROSS REFERENCE TABLE -- MACRO NAMES

\$SWRDF	1#	514
\$SWRRR	1#	2225
\$TRAP	1#	
\$TYPE	1#	2173
\$URAT	1#	
.SCOP	1#	
.SCOPE	1#	

. ABS. 017000 000

ERRORS DETECTED: 0

CZDJBG,CZDJBG/SOL/CRF/NL:TOC=CZDJBG.MAC,CZDJBG.P11
RUN-TIME: 57.7 SECONDS
RUN-TIME RATIO: 38/14=2.7
CORE USED: 20K (39 PAGES)