

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42

.REM \$

IDENTIFICATION

PRODUCT CODE: AC-A910B-MC
PRODUCT NAME: CZKCEB0 DDCMP MD L UNIT TSTS
DATE: AUGUST 1980
MAINTAINER: DIAGNOSTICS-MERRIMACK

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1977, 1980 BY DIGITAL EQUIPMENT CORPORATION

43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89

1. ABSTRACT

THE FUNCTION OF THE KMC11 DIAGNOSTICS IS TO VERIFY THAT THE OPTION OPERATES ACCORDING TO SPECIFICATIONS. THE DIAGNOSTICS VERIFY THAT THERE ARE NO MALFUNCTIONS AND THE ALL OPERATIONS OF THE KMC11 ARE CORRECT IN ITS ENVIRONMENT.

PARAMETERS MUST BE SET UP TO ALERT THE DIAGNOSTICS TO THE KMC11 CONFIGURATION. THESE PARAMETERS ARE CONTAINED IN THE STATUS TABLE AND ARE GENERATED IN TWO WAYS: 1) MANUAL INPUT - THE OPERATOR ANSWERS QUESTIONS. 2) AUTOSIZING - THE PROGRAM DETERMINES THE PARAMETERS AUTOMATICALLY.

DZKCE TESTS THE KMC-11 LINE UNIT (M8201 OR M8202). IT PERFORMS WRITE/READ TESTS ON THE KMC LINE UNIT REGISTERS. IT CHECKS FOR PROPER TRANSMITTER, RECEIVER, AND BCC OPERATION IN DDCMP MODE. THE MODEM SIGNALS ARE ALSO CHECKED. DZKCE REQUIRES A KMC MICRO-PROCESSOR (M8204) TO RUN. FOR BEST DIAGNOSIS A TURN-AROUND CONNECTOR SHOULD BE INSTALLED, HOWEVER THE DIAGNOSTIC WILL RUN WITHOUT IT (SOME TESTS ARE SKIPPED).

CURRENTLY THERE ARE FOUR OFF LINE DIAGNOSTICS THAT ARE TO BE RUN IN SEQUENCE TO INSURE THAT IF AN ERROR SHOULD OCCUR IT WILL BE DETECTED AT AN EARLY STAGE.

NOTE: ADDITIONAL DIAGNOSTICS MAY BE ADDED IN THE FUTURE.

THE FOUR DIAGNOSTICS ARE:

1. DZKCC [REV] BASIC W/R AND MICRO-PROCESSOR TESTS
2. DZKCD [REV] JUMP AND MAIN MEMORY TESTS
3. DZKCE [REV] DDCMP LINE UNIT TESTS
4. DZKCF [REV] BITSTUFF LINE UNIT TESTS
5. DZKCA [REV] KMC11 CPU MICRO-DIAGNOSTICS

NOTE: AS UPDATES OCCUR, THE NAMES OF THESE DIAGNOSTICS MAY VARIE.

2. REQUIREMENTS

2.1 EQUIPMENT

ANY PDP11 FAMILY CPU (EXCEPT AN LSI-11) WITH MINIMUM 8K MEMORY ASR 33 (OR EQUIVALENT)
KMC11-AN IOP (M8204)
KMC11-DA OR KMC11-MD OR KMC11-MA

90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132

2.2 STORAGE

PROGRAM WILL USE ALL 8K OF MEMORY EXCEPT WHERE ABL AND BOOTSTRAP LOADER RESIDE. LOCATIONS 2100 THRU 2300; CONTAIN THE "STATUS TABLE" INFORMATION WHICH IS GENERATED AT START OF DIAGNOSTICS BY MANUAL INPUT (QUESTIONS) OR AUTOMATICALLY (AUTO-SIZING). THIS AREA IS AN OVERLAY AREA AND SHOULD NOT BE ALTERED BY THE OPERATOR.

3. LOADING PROCEEDURE

3.1 METHOD

ALL PROGRAMS ARE IN ABSOLUTE FORMAT AND ARE LOADED USING THE ABSOLUTE LOADER. NOTE: IF THE DIAGNOSTICS ARE ON A MEDIA SUCH AS DISK ,MAGTAPE,DECTAPE, OR CASSETTE; FOLLOW INSTRUCTIONS FOR THE MONITOR WHICH HAS BEEN PROVIDED ON THAT SPECIFIC MEDIA.

ABSOLUTE LOADER STARTING ADDRESS *500

MEMORY * SIZE

4K	17
8K	37
12K	57
16K	77
20K	117
24K	137
28K	157

3.1.1 PLACE ADDRESS OF ABS LOADER INTO SWITCH REGISTER.
(ALSO PLACE 'HALT' SW UP)

3.1.2 DEPRESS 'LOAD ADDRESS' KEY ON CONSOLE AND RELEASE.

3.1.3 DEPRESS 'START KEY' ON CONSOLE AND RELEASE (PROGRAM SHOULD NOW BE LOADING INTO CPU)

133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186

4. STARTING PROCEEDURE

- A. SET SWITCH REGISTER TO 000200
- B. DEPRESS 'LOAD ADDRESS' KEY AND RELEASE
- C. SET SWR TO ZERO FOR 'AUTO SIZING' OR SWR BIT0=1 FOR MANUAL INPUT (QUESTIONS) OR SWR BIT7=1 TO USE EXISTING PARAMETERS SET UP BY A PREVIOUS START OR A PREVIOUSLY RUN KMC11 DIAGNOSTIC.
- D. DEPRESS 'START KEY' AND RELEASE. THE PROGRAM WILL TYPE MAINDEC NAME AND PROGRAM NAME (IF THIS WAS THE FIRST START UP OF THE PROGRAM) AND ALSO THE FOLLOWING:

MAP OF KMC11 STATUS

PC	CSR	STAT1	STAT2	STAT3
002100	160010	045310	177777	000000
002110	160020	045320	177777	000000

THE PROGRAM WILL TYPE 'R' AND PROCEED TO RUN THE DIAGNOSTIC. THE ABOVE IS ONLY AN EXAMPLE. THIS WOULD INDICATE THE STATUS TABLE STARTING AT ADD. 2100 IN THE PROGRAM. IN THIS EXAMPLE THE TABLE CONTAINS THE INFORMATION AND STATUS OF TWO KMC11'S. THE STATUS TABLE MUST BE VERIFIED BY THE USER IF AUTO SIZING IS DONE. FOR INFORMATION OF STATUS TABLE SEE SECTION 8.4 FOR HELP.

IF THE DIAGNOSTIC WAS STARTED WITH SW00=1 INDICATING MANUAL PARAMETER INPUT THEN THE FOLLOWING SHOWS AN EXAMPLE OF THE QUESTIONS ASKED AND SOME EXAMPLE ANSWERS:

HOW MANY KMC11'S TO BE TESTED?1
01
CSR ADDRESS?160010
VECTOR ADDRESS?310
BR PRIORITY LEVEL? (4,5,6,7)?5
WHICH LINE UNIT? IF NONE TYPE 'N', IF M8201 TYPE '1', IF M8202 TYPE '2'?1
IS THE LOOP BACK CONNECTOR ON?Y
(ONLY IF M8201 AND LOOP BACK)
WHICH MODEM TYPE, TYPE 'D' FOR KMC11-DA (RS232C), OR TYPE 'F' FOR KMC11-FA (V.35)? D
SWITCH PAC#1 (DDCMP LINE#)?377
SWITCH PAC#2 (BMB73 BOOT ADD)?377
FOLLOWING THE QUESTIONS THE STATUS MAP IS PRINTED OUT AS DESCRIBED ABOVE, THE INFORMATION IN THE MAP REFLECTS THE ANSWERS TO THE QUESTIONS. IF THE DIAGNOSTIC WAS STARTED WITH SW00=0 AND SW07=0 (AUTO-SIZING) THEN NO QUESTIONS ARE ASKED AND ONLY THE STATUS-MAP IS PRINTED OUT. IF AUTO-SIZING IS USED THE STATUS INFORMATION MUST BE VERIFIED TO BE CORRECT (MATCH THE HARDWARE). IF IT DOES NOT MATCH THE HARDWARE THE DIAGNOSTIC MUST BE RESTARTED WITH SW00=1 AND THE QUESTIONS ANSWERED.

187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214

4.1 CONTROL SWITCH SETTINGS

SW 15 SET: HALT ON ERROR
SW 14 SET: LOOP ON CURRENT TEST
SW 13 SET: INHIBIT ERROR PRINT OUT
SW 12 SET: INHIBIT TYPE OUT ABELL ON ERROR.
SW 11 SET: INHIBIT ITERATIONS. (QUICK PASS)
SW 10 SET: ESCAPE TO NEXT TEST ON ERROR
SW 09 SET: LOOP WITH CURRENT DATA
SW 08 SET: CATCH ERROR AND LOOP ON IT
SW 07 SET: USE PREVIOUS STATUS TABLE.
SW 06 SET: HALT IN ROMCLK ROUTINE BEFORE CLOCKING
MICRO-PROCESSOR
SW 05 SET: RESERVED
SW 04 SET: RESERVED
SW 03 SET: RESELECT KMC11'S DESIRED ACTIVE
SW 02 SET: LOCK ON SELECTED TEST
SW 01 SET: RESTART PROGRAM AT SELECTED TEST
SW 00 SET: BUILD NEW STATUS TABLE FROM QUESTIONS. (IF SW07=0
AND SW00=0 A NEW STATUS TABLE IS BUILT BY
AUTO-SIZING)

SWITCH 06 AND 08-15 ARE DYNAMIC AND CAN BE CHANGED AS NEEDED
WHILE THE DIAGNOSTIC IS RUNNING. SWITCHES 00-03 AND SWITCH 07
ARE STATIC, AND ARE USED ONLY ON STARTING OR RESTARTING THE
DIAGNOSTIC.

215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257

4.1.2 SWITCH REGISTER OPTIONS (AT START UP)

SW 01 RESTART PROGRAM AT SELECTED TEST. IT IS STRONGLY SUGGESTED THAT AT LEAST ONE PASS HAS BEEN MADE BEFORE TRYING TO SELECT A TEST, THE REASON BEING IS THAT THE PROGRAM HAS TO CLEAR AREAS AND SET UP PARAMETERS. WHEN THIS SWITCH IS USED THE DIAGNOSTIC WILL ASK TEST NO.? ANSWER BY TYPING THE NUMBER OF THE TEST DESIRED AND CARRIGE RETURN TO BEGIN EXECUTION AT THE SELECTED TEST.

SW 02 LOCK ON SELECTED TEST. THIS SWITCH WHEN USED WITH SW01 WILL CAUSE THE PROGRAM TO CONSTANTLY LOOP ON THE SELECTED TEST. HITTING ANY KEY ON THE CONSOLE WILL LET IT ADVANCE TO THE NEXT TEST AND LOOP UNTIL A KEY IS HIT AGAIN. IF SW02=0 WHEN SW01 IS USED. THE PROGRAM WILL BEGIN AT THE SELECTED TEST AND CONTINUE NORMAL OPERATIONS.

SW 03 RESELECT KMC11'S DESIRED ACTIVE. PLEASE NOTE THAT A MESSAGE IS TYPED OUT FOR SETTING THE SWITCH REGISTER EQUAL TO KMC11'S ACTIVE. THIS MEANS IF THE SYSTEM HAS FOUR KMC11S; BITS 00,01,02,03 WILL BE SET IN LOC 'KMACTV' FROM THE SWITCH REGISTER. USING THIS SWITCH(SW00) ALTERS THAT LOCATION; THEREFORE IF FOUR KMC11S ARE IN THE SYSTEM ***DO NOT*** SET SWITCHS GREATER THAN SW 03 IN THE UP POSITION. THIS WOULD BE A FATAL ERROR. DO NOT SELECT MORE ACTIVE KMC11S THAN THERE IS INFORMATION ON IN THE STATUS TABLE.

METHOD: A: LOAD ADDRESS 200
B: START WITH SW 00=1
C: PROGRAM WILL TYPE MESSAGE
D: SET A SWITCH FOR EACH KMC DESIRED ACTIVE.
EXAMPLE: IF YOU HAVE 4 KMC'S BUT ONLY WANT TO RUN THE FIRST AND THE LAST SET SWR BITS 0 AND 3 = 1. PRESS CONTINUE
E: NUMBER (IF VALID) WILL BE IN DATA LIGHTS (EXCLUDING 11/05)
F: SET WITH ANY OTHER SWITCH SETTINGS DESIRED. PRESS CONTINUE.

258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305

4.1.3 DYNAMIC SWITCHES

ERROR SWITCHES

1. SW 12 DELETE PRINT OUT/BELL ON ERROR.
2. SW 13 DELETE ERROR PRINTOUT.
3. SW 15 HALT ON THE ERROR.
4. SW 08 GOTO BEGINNING OF THE TEST(ON ERROR).
5. SW 10 GOTO NEXT TEST(ON ERROR).

SCOPE SWITCHES

1. SW06 HALT IN ROMCLK ROUTINE BEFORE CLOCKING MICRO-PROCESSOR INSTRUCTION. THIS ALLOWS THE OPERATOR TO SCOPE A MICRO-PROCESSOR INSTRUCTION IN THE STATIC STATE BEFORE IT IS CLOCKED. HIT CONTINUE TO RESUME RUNNING.
2. SW09 (IF ENABLED BY 'SCOPI') ON AN ERROR; IF AN '*' IS PRINTED IN FRONT OF THE TEST NO. (EX. *TEST NO. 10) SW09 IS INCORPORATED IN THAT TEST AND THEREFORE SW09 IS USUALLY THE BEST SWITCH FOR THE SCOPE LOOP (SW14=0, SW10=0, SW09=1, SW08=0). IF SW09 IS NOT ENABELED; AND THERE IS A HARD ERROR (CONSTANT); SW08 IS BEST. (SW14=1,0, SW10=0, SW09=0, SW08=1). FOR INTERMITTEMT ERRORS; SW14=1 WILL LOOP ON TEST REGARDLESS OF ERROR OR NOT ERROR. (SW14=1, SW10=0, SW09=0, SW08=1,0)
3. SW11 INHIBIT INTERATIONS.
4. SW14 LOOP ON CURRENT TEST.

4.2 STARTING ADDRESS

STARTING ADDRESS IS AT 000200 THERE ARE NO OTHER STARTING ADDRESSES FOR THE KMC11 DIAGNOSTICS. (SEE SECTION 4.0)

NOTE: IF ADDRESS 000042 IS NON-ZERO THE PROGRAM ASSUMES IT IS UNDER ACT11 OR XXDP CONTROL AND WILL ACT ACCORDINGLY AFTER ALL AVAILABLE KMC11'S ARE TESTED THE PROGRAM WILL RETURN TO 'XXDP' OR 'ACT-11'.

5. OPERATING PROCEDURE

WHEN PROGRAM IS INITIALLY STARTED MESSAGES AS DESCRIBED IN SECTION 4.0 WILL BE PRINTED, AND PROGRAM WILL BEGIN RUNNING THE DIAGNOSTIC

306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353

5.2 PROGRAM AND/OR OPERATOR ACTION

THE TYPICAL APPROACH SHOULD BE

1. HALT ON ERROR (VIA SW 15=1) WHEN EVER AN ERROR OCCURS.
2. CLEAR SW 15.
3. SET SW 14: (LOOP ON THIS TEST)
4. SET SW 13: (INHIBIT ERROR PRINT OUT)

THE TEST NUMBER AND PC WILL BE TYPED OUT AND POSSIBLY AN ERROR MESSAGE (THIS DEPENDS ON THE TEST) TO GIVE THE OPERATOR AN IDEA AS TO THE SOURCE OF THE PROBLEM. IF IT IS NECESSARY TO KNOW MORE INFORMATION CONCERNING THE ERROR REPORT; LOOK IN THE LISTING FOR THAT TEST NUMBER WHICH WAS TYPED OUT AND THEN NOTE THE PC OF THE ERROR REPORT THIS WAY THE EXACT FUNCTION OF THE TEST CAN BE DETERMINED.

6. ERRORS

AS DESCRIBED PREVIOUSLY THERE WILL ALWAYS BE A TEST NUMBER AND PC TYPED OUT AT THE TIME OF AN ERROR (PROVIDING SW 13=0 AND SW 12=0). IN MOST CASES ADDITIONAL INFORMATION WILL BE SUPPLIED IN THE THE ERROR MESSAGE TO GIVE THE OPERATOR AN INDICATION OF THE ERROR.

6.2 ERROR RECOVERY

IF FOR SOME REASON THE KMC11 SHOULD 'HANG THE BUS' (GAIN CONTROL OF BUS SO THAT CONSOLE MANUAL FUNCTIONS ARE INHIBITED) AN INIT OR POWER DOWN/UP IS NECESSARY FOR OPERATOR TO REGAIN CONTROL OF CPU. IF THIS SHOULD HAPPEN; LOOK IN LOCATION 'TSTNM' (ADDRESS 1202) FOR THE NUMBER OF THE TEST THAT WAS RUNNING AT THE TIME OF THE CATASTROPHIC ERROR. IN THIS WAY THE OPERATOR WILL HAVE AN IDEA AS TO WHAT THE KMC11 WAS DOING AT THE TIME OF THE ERROR.

7. RESTRICTIONS

7.1 STARTING RESTRICTIONS

SEE SECTION 4. (PLEASE)
STATUS TABLE SHOULD BE VERIFIED REGARDLESS OF HOW PROGRAM WAS STARTED. ALSO IT IS IMPORTANT TO USE THIS LISTING ALONG WITH THE INFORMATION PRINTED ON THE TTY TO COMPLETELY ISOLATE PROBLEMS.

354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406

7.2 OPERATING RESTRICTIONS

THE FIRST TIME A KMC11 DIAGNOSTIC IS LOADED INTO CORE AND RUN THE STATUS TABLE MUST BE SET UP. THIS IS DONE BY MANUAL INPUT (SW00=1) OR BY AUTOSIZING (SW00=0 AND SW07=0). THEREAFTER HOWEVER THE STATUS TABLE NEED NOT BE SETUP BY SUBSEQUENT RESTARTS OR EVEN LOADING THE NEXT KMC DIAGNOSTIC BECAUSE THE STATUS TABLE IS OVERLAYED. THE CURRENT PARAMETERS IN THE STATUS TABLE ARE USED WHEN SW07=1 ON START UP.

7.3 HARDWARE CONFIGURATION RESTRICTIONS

KMC11 IOP(M8204)- JUMPER W1 MUST BE IN.

LINE UNIT(M8201)- JUMPERS W1, W2, AND W4 MUST BE IN. JUMPERS W3, AND W5 MUST BE OUT. SW8 OF E26 MUST BE IN THE ON POSITION.

LINE UNIT (M8202)- JUMPER W1 MUST BE IN. SW8 OF E26 MUST BE IN THE OFF POSITION.

8. MISCELLANEOUS

8.1 EXECUTION TIME

ALL KMC11 DEVICE DIAGNOSTICS WILL GIVE AN 'END PASS' MESSAGE (PROVIDING NO ERRORS AND SW12=0) WITHIN 4 MINS. THIS IS ASSUMING SW11=1 (DELETE ITERATIONS) IS SET TO GIVE THE FASTEST POSSIBLE EXECUTION. THE ACTUAL EXECUTION TIME DEPENDS GREATLY ON THE PDP11 CPU CONFIGURATION AND THE AMOUNT OF MEMORY IN THE SYSTEM.

8.2 PASS COMPLETE

NOTE: EVERY TIME THE PROGRAM IS STARTED; THE TESTS WILL RUN AS IF SW11 (DELETE ITERATIONS) WAS UP (=1). THIS IS TO 'VERIFY NO HARD ERRORS' AS SOON AS POSSIBLE. THEREFORE THE FIRST PASS -EACH TIME PROGRAM IS STARTED- WILL BE A 'QUICK PASS' UNTIL ALL KMC11'S IN SYSTEM ARE TESTED. WHEN THE DIAGNOSTIC HAS COMPLETED A PASS THE FOLLOWING IS AN EXAMPLE OF THE PRINT OUT TO BE EXPECTED.

END PASS DZKCE CSR: 175000 VEC: 0300 PASSES: 000001
ERRORS: 000000

NOTE: THE PASS COUNT AND ERROR COUNTS ARE CUMMULITIVE FOR EACH KMC11 THAT IS RUNNING, AND ARE SET TO ZERO ONLY WHEN THE DIAGNOSTIC IS STARTED. THEREFORE AFTER AN OVERNIGHT RUN FOR EXAMPLE, THE TOTAL PASSES AND ERRORS FOR EACH KMC11 SINCE THE DIAGNOSTIC WAS STARTED ARE REFLECTED IN PASSES: AND ERRORS:.

407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462

8.4 KEY LOCATIONS

LPADR (1206) CONTAINS THE ADDRESS WHERE PROGRAM WILL RETURN WHEN ITERATION COUNT IS REACHED OR IF LOOP ON TEST IS ASSERTED.

NEXT (1442) CONTAINS THE ADDRESS OF THE NEXT TEST TO BE PERFORMED.

TSTNM (1202) CONTAINS THE NUMBER OF THE TEST NOW BEING PERFORMED.

RUN (1500) THE BIT IN 'RUN' ALWAYS POINTS TO THE KMC11 CURRENTLY BEING TESTED. EXAMPLE: (RUN) 1500/000000000100000 MEANS THAT KMC11 NO.06 IS THE KMC11 NOW RUNNING.

KMCR00-KMCR17
 KMST00-KMST17
 (2100)-(2300)

THESE LOCATIONS CONTAIN THE INFORMATION NEEDED TO TEST UP TO 16 (DECIMAL) KMC11S SEQUENTIALLY. THEY CONTAIN THE CSR, VECTOR AND STATUS CONCERNING THE CONFIGURATION OF EACH KMC11.

KMACTV (1470) EACH BIT SET IN THIS LOCATION INDICATES THAT THE ASSOCIATED KMC11 WILL BE TESTED IN TURN. EXAMPLE: (KMACTV) 1470/0000000000011111 MEANS THAT KMC11 NO. 00,01,02,03,04 WILL BE TESTED. EXAMPLE: (KMACTV) 1470/0000000000010001 MEANS THAT KMC11 NO. 00,04 WILL BE TESTED.

KMCSR (2066) CONTAINS THE CSR OF THE CURRENT KMC11 UNDER TEST.

8.4A 'STATUS TABLE' (2100-2300)

THE TABLE IS FILLED BY AUTO SIZING OR BY THE MANUAL PARAMETER INPUT (QUESTIONS) AS DESCRIBED PREVIOUSLY. ALSO IF DESIRED BY USER; THE LOCATIONS MAY BE ALTERED BY HAND (TOGGLED IN) TO SUIT THE SPECIFIC CONFIGURATION.

THE EXAMPLE STATUS MAP SHOWN BELOW CONTAINS INFORMATION FOR TWO KMC11'S. THE TABLE CAN CONTAIN UP TO 16 KMC11'S. FOLLOWING THE MAP IS A DESCRIPTION OF THE BITS FOR EACH MAP ENTRY

MAP OF KMC11 STATUS

PC	CSR	STAT1	STAT2	STAT3
002100	160010	045310	177777	000000
002110	160020	016320	000000	000000

463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488

EACH MAP ENTRY CONTAINS 4 WORDS WHICH CONTAIN THE STATUS INFORMATION FOR 1 KMC11. THE PC SHOWS WHERE IN CORE MEMORY THE FIRST OF THE 4 WORDS IS. IN THE EXAMPLE ABOVE THE FIRST KMC'S STATUS IS IN LOCATIONS, 2100, 2102, 2104, AND 2106. THE SECOND KMC STATUS IS LOCATED AT 2110, 2112, 2114, AND 2116. THE INFORMATION CONTAINED IN EACH 4 WORD ENTRY IS DEFINED AS FOLLOWS:

CSR: CONTAINS KMC11 CSR ADDRESS

STAT1: BITS 00-08 IS KMC11 VECTOR ADDRESS
BIT14=1 TURNAROUND CONNECTOR IS ON
BIT14=0 NO TURNAROUND CONNECTOR
BIT13=0 LINE UNIT IS AN M8201
BIT13=1 LINE UNIT IS AN M8202
BIT12=1 NO LINE UNIT
BITS 09-11 IS KMC11 BR PRIORITY LEVEL

STAT2: LOW BYTE IS SWITCH PAC#1 (DDCMP LINE NUMBER)
HIGH BYTE IS SWITCH PAC#2 (BM873 BOOI ADD)

STAT3: BIT 2=0 KMC11-DA
BIT 2=1 KMC11-FA

489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544

8.5 METHOD OF AUTO SIZING

8.5.1 FINDING THE CONTROL STATUS REGISTER.

THE AUTO-SIZING ROUTINE FINDS A KMC11 AS FOLLOWS: IT STARTS AT ADDRESS 160000 AND TESTS ALL ADDRESS IN INCREMENTS OF 10 UP TO AND INCLUDING ADDRESS 167760. IF THE ADDRESS DOES NOT TIME OUT, THE FOLLOWING IS DONE, THE FIRST CRAM ADDRESS IS WRITTEN TO A 125252 THEN IT IS READ BACK. IF IT CONTAINS A -1 OR 125252, IF NOT, THE ADDRESS IS UPDATED BY 10 AND THE SEARCH CONTINUES. A -1 INDICATES A KMC11 WITH NO CRAM, AND A 125252 INDICATES A KMC11 WITH CRAM. FURTHER TESTS ARE PERFORMED AT THIS POINT TO DETERMINE WHICH LINE UNIT, IF ANY, IS INSTALLED, IF A LOOP-BACK CONNECTOR IS INSTALLED AND VARIOUS SWITCH SETTINGS ON THE LINE UNIT. THIS IS WHY THE STATUS TABLE MUST BE VERIFIED BY THE USER AND IF ANY OF THE INFORMATION DOES NOT AGREE WITH THE HARDWARE THE DIAGNOSTIC MUST BE RESTARTED AND THE QUESTIONS MUST BE ANSWERED. ALL KMC11'S IN THE SYSTEM WILL BE FOUND BY THE AUTO-SIZER. IF IT DOES NOT FIND A KMC11 THE DIAGNOSTIC MUST BE RESTARTED AND THE QUESTIONS ANSWERED.

8.5.2 FINDING THE VECTOR AND BR LEVEL

THE VECTOR AREA (ADDRESS 300-776) IS FILLED WITH THE INSTRUCTION IOT AND '+2' (NEXT ADDRESS). THE PROCESSOR STATUS IS STARTED AT 7 AND THE KMC IS PROGRAMMED TO INTERRUPT. THE PS IS LOWERED BY 1 UNTIL THE KMC INTERRUPTS, A DELAY IS MADE AND IF NO INTERRUPT OCCURES AT PS LEVEL 3 (BECAUSE OF A BAD KMC11) THE PROGRAM ASSUMES VECTOR ADDRESS 300 AT BR LEVEL 5 AND THE PROBLEM SHOULD BE FIXED IN THE DIAGNOSTIC. ONCE THE PROBLEM IS FIXED; THE PROGRAM SHOULD BE RE-SETUP AGAIN TO GET CORRECT VECTOR. IF AN INTERRUPT OCCURED; THE ADDRESS TO WHICH THE KMC11 INTERRUPTED TO IS PICKED UP AND REPORTED AS THE VECTOR. NOTE: IF THE VECTOR REPORTED IS NOT THE VECTOR SET UP BY YOU; THERE IS A PROBLEM AND AUTO SIZING SHOULD NOT BE DONE.

8.6 SOFTWARE SWITCH REGISTER

IF THE DIAGNOSTIC IS RUN ON AN 11/04 OR OTHER CPU WITHOUT A SWITCH REGISTER THEN A SOFTWARE SWITCH REGISTER IS USED TO ALLOW USER THE SAME SWITCH OPTIONS AS DESCRIBED PREVIOUSLY. IF THE HARDWARE SWITCH REGISTER DOES NOT EXIST OR IF ONE DOES AND IT CONTAINS ALL ONES (177777) THIS SOFTWARE SWITCH REGISTER IS USED.

CONTROL:

TO OBTAIN CONTROL AT ANY ALLOWABLE TIME DURING EXECUTION OF THE DIAGNOSTIC THE OPERATOR TYPES A CTRL G ON THE CONSOLE TERMINAL KEYBOARD. AS SOON AS THE CTRL G IS RECOGNIZED, BY THE DIAGNOSTIC, THE FOLLOWING MESSAGE WILL BE DISPLAYED:

SWR=XXXXXX NEW?

545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587

WHERE XXXXXX IS THE CURRENT CONTENTS OF THE SOFTWARE SWITCH REGISTER IN OCTAL. THE SOFTWARE CONTROL ROUTINE WILL THEN AWAIT OPERATOR ACTION. AT WHICH TIME THE OPERATOR IS REQUIRED TO TYPE ONE OR MORE OF THE LEGAL CHARACTERS: 1) 0 - 7, 2) LINE FEED(<LF>), 3) CARRIAGE RETURN(<CR>), OR 4) CONTROL-U (CTRL U). NO CHECK IS MADE FOR LEGALITY. IF THE INPUT CHARACTER IS NOT A <LF>, <CR>, OR CTRL U IT IS ASSUMED TO BE AN OCTAL DIGIT.

TO CHANGE THE CONTENTS OF THE SSR THE OPERATOR SIMPLY TYPES THE NEW DESIRED VALUE IN OCTAL - LEADING ZEROS NEED NOT BE TYPED. AND TERMINATES THE INPUT STRING WITH A <CR> OR <LF> DEPENDING ON THE PROGRAM ACTION DESIRED AS DESCRIBED BELOW. THE INPUT VALUE WILL BE TRUNCATED TO THE LAST 6 DIGITS TYPED. AT LEAST ONE DIGIT MUST BE TYPED ON ANY GIVEN INPUT STRING PRIOR TO THE TERMINATOR BEFORE A CHANGE TO THE SSR WILL OCCUR.

WHEN THE INPUT STRING IS TERMINATED WITH A <CR> THE DIAGNOSTIC WILL CONTINUE EXECUTION FROM THE POINT AT WHICH IT WAS INTERRUPTED. IF A <CR> IS THE ONLY THING TYPED THE PROGRAM WILL CONTINUE WITHOUT CHANGING THE SSR. THE <LF> DIFFERS FROM THE <CR> BY RESTARTING THE PROGRAM AS IF IT WERE RESTARTED AT ADDRESS 200.

IF A CTRL U IS TYPED AT ANY POINT IN THE INPUT STRING PRIOR TO THE TERMINATOR THE INPUT VALUE WILL BE DISREGARDED AND THE PROMPT DISPLAYED (SWR = XXXXXX NEW?).

TO SET THE SSR FOR THE STARTING SWITCHES, FIRST LOAD THE DIAGNOSTIC, THEN HIT CTRL G, THEN START THE DIAGNOSTIC.

NOTE: FOR IPG'S LINE UNIT M8202-YE USERS.

CABLE DATA TEST:[TEST 56 TEST 57]

THESE TESTS WON'T RUN RELIABLY ON LINE UNITS WITHOUT TERMINATING RESISTENCE.

588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641

APT/ACT/XXDP/SLIDE

THIS DIAGNOSTIC IS APT/ACT/XXDP/SLIDE COMPATIBLE USER WOULD BE ABLE TO RUN IT UNDER APT/ACT/XXDP ENVIRONMENT.

NOTE: FOR MANUFACTURING PURPOSE ONLY ITS DESCRIBED HOW TO RUN UNDER APT ENVIRONMENT.

ETABLE SETTING FOR APT TO RUN UNDER APT

FIRST PASS TIME:

LONGEST TEST TIME:

ADDITIONAL TEST TIME:

ALL THE ABOVE PARAMETERS ARE DEPENDENT ON PARTICULAR DIAGNOSTICS AND SHOULD BE LOADED AT THE TIME OF SETTING ETABLE.THERE IS NO DEFAULT TIME SET UP.

SOFTWARE ENVIRONMENT:001 ENVIRONMENT MODE:200

SWITCH 1:-SHOULD BE USED AS NORMAL SWITCH REGISTER.

SWITCH 2:-NOT USED.

CPU OPTIONS:-NOT USED.

MEMORY TYPE 1:-BITS<2:4>:=BITS <12:14> OF STAT1 OF DEV:0.

MAXIMUM ADDRESS:-BITS<17:19>:=BITS<12:14> OF STAT1 OF DEV:1

 BITS<2:4>:=BITS <12:14> OF STAT1 OF DEV:2

 BITS<10:12>:=BITS<12:14> OF STAT1 OF DEV:3

IN THE SAME MANNER

MEMORY TYPE 2 MAXIMUM ADDRESS:-GETS STAT1<12:14> OF DEVICE 4,5,6,7.

MEMORY TYPE 3 MAXIMUM ADDRESS:-GETS STAT1<12:14> OF DEVICE 8,9,10,11.

MEMORY TYPE 4 MAXIMUM ADDRESS:-GETS STAT1<12:14> OF DEVICE 12,13,14,15.

INTERRUPT VECTOR 1:FIRST DEVICE RECEIVE VECTOR.

642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685

REST OF THE DEVICE(KMC'S) VECTOR SHOULD BE SET UP SEQUENTIALLY
IN INCREMENTS OF 10.

BUS PRIORITY:KMC'S PRIORITY(SHOULD BE SAME FOR ALL KMC'S UNDER
TEST).

INTERRUPT VECTOR 2:NOT USED.

BUS PRIORITY:NOT USED.

BASE ADDRESS:FIRST DEVICE CSR ADDRESS.

REST SHOULD FOLLOW SEQUENTIALLY
IN INCREMENTS OF 10.

DEVICE MAP:AS DESCRIBED IN APT MANUAL.

CONTROLLER SPECIFIC CODE 1:-NO. OF DEVICES UNDER TEST.

CONTROLLER SPECIFIC CODE 2:-NOT USED.

DEVICE DESCRIPTOR WORD 0:STAT2 OF FIRST DEVICE.

. .

. .

TO

. .

. .

DEVICE DESCRIPTOR WORD 15:STAT2 OF 16TH DEVICE.(KMC)

9.0 HISTORY

THIS DIAGNOSTIC WAS UPDATED TO DETECT FOR THE CONDITION OF V.35
AND MB201. IN THIS CONIFURATION, RING WILL NOT BE LOOPED BACK
AND SHOULD NOT BE TESTED FOR.

§

```

686 .TITLE CZKCE
687 :*COPYRIGHT (C) 1976
688 :*DIGITAL EQUIPMENT CORP.
689 :*MAYNARD, MASS. 01754
690 :*
691 :*PROGRAM BY DINESH GORADIA
692 :*
693 :*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
694 :*PACKAGE (MAINDEC-11-DZQAC-C3), JAN 19, 1977.
695 :*
696
697
698
699
700
701 :*CZKCE KMC11 DDCMP LINE UNIT TESTS
702 :*COPYRIGHT 1976, DIGITAL EQUIPMENT CORP., MAYNARD, MASS. 01754
703 :*-----
704
705 ;STARTING PROCEDURE
706 ;LOAD PROGRAM
707 ;LOAD ADDRESS 000200
708 ;SWR=0 AUTOSIZE KMC11
709 ;SW07=1 USE CURRENT KMC11 PARAMETERS
710 ;SW00=1 INPUT NEW KMC11 PARAMETERS
711 ;PRESS START
712 ;PROGRAM WILL TYPE "CZKCE KMC11 DDCMP LINE UNIT TESTS"
713 ;PROGRAM WILL TYPE STATUS MAP
714 ;PROGRAM WILL TYPE "R" TO INDICATE THAT TESTING HAS STARTED
715 ;AT THE END OF A PASS, PROGRAM WILL TYPE PASS COMPLETE MESSAGE
716 ;AND THEN RESUME TESTING
717 ;SUBSEQUENT RESTARTS WILL NOT TYPE PROGRAM TITLE
718
719 .SBTTL BASIC DEFINITIONS
720
721 :*INITIAL ADDRESS OF THE STACK POINTER *** 1200 ***
722 STACK= 1200
723 .EQUIV EMT,ERROR ;;BASIC DEFINITION OF ERROR CALL
724 .EQUIV IOT,SCOPE ;;BASIC DEFINITION OF SCOPE CALL
725
726 ;*MISCELLANEOUS DEFINITIONS
727 HT= 11 ;;CODE FOR HORIZONTAL TAB
728 LF= 12 ;;CODE FOR LINE FEED
729 CR= 15 ;;CODE FOR CARRIAGE RETURN
730 CRLF= 200 ;;CODE FOR CARRIAGE RETURN-LINE FEED
731 PS= 177776 ;;PROCESSOR STATUS WORD
732 .EQUIV PS,PSW
733 STKLMT= 177774 ;;STACK LIMIT REGISTER
734 PIRQ= 177772 ;;PROGRAM INTERRUPT REQUEST REGISTER
735 DSWR= 177570 ;;HARDWARE SWITCH REGISTER
736 DDISP= 177570 ;;HARDWARE DISPLAY REGISTER
737
738 ;*GENERAL PURPOSE REGISTER DEFINITIONS
739 R0= X0 ;;GENERAL REGISTER
740 R1= X1 ;;GENERAL REGISTER
741 R2= X2 ;;GENERAL REGISTER

```



```
742      000003      R3=    X3      ;;GENERAL REGISTER
743      000004      R4=    X4      ;;GENERAL REGISTER
744      000005      R5=    X5      ;;GENERAL REGISTER
745      000006      R6=    X6      ;;GENERAL REGISTER
746      000007      R7=    X7      ;;GENERAL REGISTER
747      000006      SP=    X6      ;;STACK POINTER
748      000007      PC=    X7      ;;PROGRAM COUNTER
749
750      ;*PRIORITY LEVEL DEFINITIONS
751      000000      PR0=    0      ;;PRIORITY LEVEL 0
752      000040      PR1=    40     ;;PRIORITY LEVEL 1
753      000100      PR2=   100     ;;PRIORITY LEVEL 2
754      000140      PR3=   140     ;;PRIORITY LEVEL 3
755      000200      PR4=   200     ;;PRIORITY LEVEL 4
756      000240      PR5=   240     ;;PRIORITY LEVEL 5
757      000300      PR6=   300     ;;PRIORITY LEVEL 6
758      000340      PR7=   340     ;;PRIORITY LEVEL 7
759
760      ;*'SWITCH REGISTER' SWITCH DEFINITIONS
761      100000      SW15= 100000
762      040000      SW14=  40000
763      020000      SW13=  20000
764      010000      SW12=  10000
765      004000      SW11=  4000
766      002000      SW10=  2000
767      001000      SW09=  1000
768      000400      SW08=   400
769      000200      SW07=   200
770      000100      SW06=   100
771      000040      SW05=   40
772      000020      SW04=   20
773      000010      SW03=   10
774      000004      SW02=    4
775      000002      SW01=    2
776      000001      SW00=    1
777      .EQUIV SW09,SW9
778      .EQUIV SW08,SW8
779      .EQUIV SW07,SW7
780      .EQUIV SW06,SW6
781      .EQUIV SW05,SW5
782      .EQUIV SW04,SW4
783      .EQUIV SW03,SW3
784      .EQUIV SW02,SW2
785      .EQUIV SW01,SW1
786      .EQUIV SW00,SW0
787
788      ;*DATA BIT DEFINITIONS (BIT00 TO BIT15)
789      100000      BIT15= 100000
790      040000      BIT14=  40000
791      020000      BIT13=  20000
792      010000      BIT12=  10000
793      004000      BIT11=  4000
794      002000      BIT10=  2000
795      001000      BIT09=  1000
796      000400      BIT08=   400
797      000200      BIT07=   200
```

CZKCE MACY11 30A(1052) 08-JUL-80 08:24 PAGE 19
 CZKCE.P11 08-JUL-80 08:24 BASIC DEFINITIONS

SEQ 0018

```

798          000100          BIT06= 100
799          000040          BIT05= 40
800          000020          BIT04= 20
801          000010          BIT03= 10
802          000004          BIT02= 4
803          000002          BIT01= 2
804          000001          BIT00= 1
805          .EQUIV BIT09,BIT9
806          .EQUIV BIT08,BIT8
807          .EQUIV BIT07,BIT7
808          .EQUIV BIT06,BIT6
809          .EQUIV BIT05,BIT5
810          .EQUIV BIT04,BIT4
811          .EQUIV BIT03,BIT3
812          .EQUIV BIT02,BIT2
813          .EQUIV BIT01,BIT1
814          .EQUIV BIT00,BIT0
815
816          ;*BASIC "CPU" TRAP VECTOR ADDRESSES
817          000004          ERRVEC= 4          ;;TIME OUT AND OTHER ERRORS
818          000010          RESVEC= 10         ;;RESERVED AND ILLEGAL INSTRUCTIONS
819          000014          TBITVEC=14        ;;"T" BIT
820          000014          TRTVEC= 14        ;;TRACE TRAP
821          000014          BPTVEC= 14        ;;BREAKPOINT TRAP (BPT)
822          000020          IOTVEC= 20        ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
823          000024          PWRVEC= 24        ;;POWER FAIL
824          000030          EMTVEC= 30        ;;EMULATOR TRAP (EMT) **ERROR**
825          000034          TRAPVEC=34        ;;"TRAP" TRAP
826          000060          TKVEC= 60         ;;TTY KEYBOARD VECTOR
827          000064          TPVEC= 64         ;;TTY PRINTER VECTOR
828          000240          PIRQVEC=240       ;;PROGRAM INTERRUPT REQUEST VECTOR
829
830
831
832
833          ;INSTRUCTION DEFINITIONS
834          ;-----
835
836          005746          PUSH1SP=5746       ;DECREMENT PROCESSOR STACK 1 WORD
837          005726          POP1SP=5726        ;INCREMENT PROCESSOR STACK 1 WORD
838          010046          PUSHRO=10046       ;SAVE R0 ON STACK
839          012600          POPRO=12600        ;RESTORE R0 FROM STACK
840          024646          PUSH2SP=24646     ;DECREMENT STACK TWICE
841          022626          POP2SP=22626     ;INCREMENT STACK TWICE
842          .EQUIV EMT,HLT ;BASIC DEFINITION OF ERROR CALL
843
844
845

```

```

846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892

```

```

;*****
;-----
;TRAPCATCAER FOR ILLEGAL INTERRUPTS
;THE STANDARD "TRAP CATCHER" IS PLACED
;BETWEEN ADDRESS 0 TO ADDRESS 776.
;IT LOOKS LIKE "PC+2 HALT".
;-----
;*****
.=0
0C0000 000000 000000
      .WORD 0,0
;STANDARD INTERRUPT VECTORS
;-----
.=20
      $SCOPE      ; SCOPE LOOP HANDLER.
      PR7         ; SERVICE AT LEVEL 7.
      $PWRDN      ; POWER FAIL HANDLER
      PR7         ; SERVICE AT LEVEL 7
      $ERROR      ; ERROR HANDLER
      PR7         ; SERVICE AT LEVEL 7
      $TRAP       ; GENERAL HANDLER DISPATCH SERVICE
      PR7         ; SERVICE AT LEVEL 7
.SBTTL ACT11 HOOKS
;*****
;HOOKS REQUIRED BY ACT11
      $SVPC=      ;SAVE PC
      .=46
      $ENDAD      ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
      .=52
      .WORD 0     ;;2)SET LOC.52 TO ZERO
      .=$SVPC    ;; RESTORE PC
.=174
DISPREG:0      ;SOFTWARE DISPLAY REGISTER
SWREG: 0      ;SOFTWARE SWITCH REGISTER
.=200
000200 000137 002402
      JMP .START ;GO TO START OF PROGRAM
.-1000
001000 005200 055103 041513
(2) 001010 046513 030503 020061
      MTITLE: .ASCII <200><12>/CZKCE/<200>
           .ASCIZ /KMC11 DDCMP LINE UNIT TESTS/<200>
DSWR = 177570
DDISP = 177570

```

```

893          .SBTTL COMMON TAGS
894
895          ::*****
896          ::THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
897          ::USED IN THE PROGRAM.
898
899          001200          .=1200
900          001200          SCMTAG:          ;;START OF COMMON TAGS
901          001200          000000          .WORD          0
902          001202          000          $STNM: .BYTE          0          ;;CONTAINS THE TEST NUMBER
903          001203          000          $ERFLG: .BYTE          0          ;;CONTAINS ERROR FLAG
904          001204          000000          $ICNT: .WORD          0          ;;CONTAINS SUBTEST ITERATION COUNT
905          001206          000000          $LPADR: .WORD          0          ;;CONTAINS SCOPE LOOP ADDRESS
906          001210          000000          $LPERR: .WORD          0          ;;CONTAINS SCOPE RETURN FOR ERRORS
907          001212          000000          $ERTTL: .WORD          0          ;;CONTAINS TOTAL ERRORS DETECTED
908          001214          000          $ITEMB: .BYTE          0          ;;CONTAINS ITEM CONTROL BYTE
909          001215          001          $ERMAX: .BYTE          1          ;;CONTAINS MAX. ERRORS PER TEST
910          001216          000000          $ERRPC: .WORD          0          ;;CONTAINS PC OF LAST ERROR INSTRUCTION
911          001220          000000          $GDADR: .WORD          0          ;;CONTAINS ADDRESS OF 'GOOD' DATA
912          001222          000000          $BDADR: .WORD          0          ;;CONTAINS ADDRESS OF 'BAD' DATA
913          001224          000000          $GDDAT: .WORD          0          ;;CONTAINS 'GOOD' DATA
914          001226          000000          $BDDAT: .WORD          0          ;;CONTAINS 'BAD' DATA
915          001230          000000          .WORD          0          ;;RESERVED--NOT TO BE USED
916          001232          000000          .WORD          0
917          001234          000          $AUTOB: .BYTE          0          ;;AUTOMATIC MODE INDICATOR
918          001235          000          $INTAG: .BYTE          0          ;;INTERRUPT MODE INDICATOR
919          001236          000000          .WORD          0
920          001240          177570          SWR: .WORD          DSWR          ;;ADDRESS OF SWITCH REGISTER
921          001242          177570          DISPLAY: .WORD          DDISP          ;;ADDRESS OF DISPLAY REGISTER
922          001244          177560          $TKS: 177560          ;;TTY KBD STATUS
923          001246          177562          $TKB: 177562          ;;TTY KBD BUFFER
924          001250          177564          $TPS: 177564          ;;TTY PRINTER STATUS REG. ADDRESS
925          001252          177566          $TPB: 177566          ;;TTY PRINTER BUFFER REG. ADDRESS
926          001254          000          $NULL: .BYTE          0          ;;CONTAINS NULL CHARACTER FOR FILLS
927          001255          002          $FILLS: .BYTE          2          ;;CONTAINS # OF FILLER CHARACTERS REQUIRED
928          001256          012          $FILLC: .BYTE          12          ;;INSERT FILL CHARS. AFTER A 'LINE FEED'
929          001257          000          $TPFLG: .BYTE          0          ;;'TERMINAL AVAILABLE' FLAG (BIT<07>=0=YES)
930          001260          000000          $REGAD: .WORD          0          ;;CONTAINS THE ADDRESS FROM
931          931          ;;WHICH ($REGO) WAS OBTAINED
932          001262          000000          $REG0: .WORD          0          ;;CONTAINS (($REGAD)+0)
933          001264          000000          $REG1: .WORD          0          ;;CONTAINS (($REGAD)+2)
934          001266          000000          $REG2: .WORD          0          ;;CONTAINS (($REGAD)+4)
935          001270          000000          $REG3: .WORD          0          ;;CONTAINS (($REGAD)+6)
936          001272          000000          $REG4: .WORD          0          ;;CONTAINS (($REGAD)+10)
937          001274          000000          $REG5: .WORD          0          ;;CONTAINS (($REGAD)+12)
938          001276          000000          $TMP0: .WORD          0          ;;USER DEFINED
939          001300          000000          $TMP1: .WORD          0          ;;USER DEFINED
940          001302          000000          $TMP2: .WORD          0          ;;USER DEFINED
941          001304          000000          $TMP3: .WORD          0          ;;USER DEFINED
942          001306          000000          $TMP4: .WORD          0          ;;USER DEFINED
943          001310          000000          $TIMES: 0          ;;MAX. NUMBER OF ITERATIONS
944          001312          077          $QUES: .ASCII          '??'          ;;QUESTION MARK
945          001313          015          $CRLF: .ASCII          '<15>'          ;;CARRIAGE RETURN
946          001314          000012          $LF: .ASCII          '<12>'          ;;LINE FEED
947          ::*****
948          .SBTTL APT MAILBOX-ETABLE
  
```

```

949
950 ::*****
951 .EVEN
952 001316 $MAIL: ::APT MAILBOX
953 001316 000000 $MSGTY: .WORD AMSGTY ::MESSAGE TYPE CODE
954 001320 000000 $FATAL: .WORD AFATAL ::FATAL ERROR NUMBER
955 001322 000000 $TESTN: .WORD ATESTN ::TEST NUMBER
956 001324 000000 $PASS: .WORD APASS ::PASS COUNT
957 001326 000000 $DEVCT: .WORD ADEVCT ::DEVICE COUNT
958 001330 000000 $UNIT: .WORD AUNIT ::I/O UNIT NUMBER
959 001332 000000 $MSGAD: .WORD AMSGAD ::MESSAGE ADDRESS
960 001334 000000 $MSGLG: .WORD AMSGLG ::MESSAGE LENGTH
961 001336 $ETABLE: ::APT ENVIRONMENT TABLE
962 001336 002 $ENV: .BYTE AENV ::ENVIRONMENT BYTE
963 001337 000 $ENVM: .BYTE AENVM ::ENVIRONMENT MODE BITS
964 001340 000000 $SWREG: .WORD ASWREG ::APT SWITCH REGISTER
965 001342 000000 $USWR: .WORD AUSWR ::USER SWITCHES
966 001344 000000 $CPUOP: .WORD ACPUOP ::CPU TYPE,OPTIONS
967 : *
968 : * BIT 15-11=CPU TYPE
969 : * 11/04=01,11/05=02,11/20=03,11/40=04,11/45=05
970 : * 11/70=06,PDQ=07,Q=10
971 : * BIT 10=REAL TIME CLOCK
972 : * BIT 9=FLOATING POINT PROCESSOR
973 001346 000 $MAMS1: .BYTE AMAMS1 ::HIGH ADDRESS,M.S. BYTE
974 001347 000 $MTYP1: .BYTE AMTYP1 ::MEM. TYPE,BLK#1
975 : * MEM. TYPE BYTE -- (HIGH BYTE)
976 : * 900 NSEC CORE=001
977 : * 300 NSEC BIPOLAR=002
978 : * 500 NSEC MOS=003
979 001350 000000 $MADR1: .WORD AMADR1 ::HIGH ADDRESS,BLK#1
980 : * MEM.LAST ADDR.=3 BYTES,THIS WORD AND LOW OF 'TYPE' ABOVE
981 001352 000 $MAMS2: .BYTE AMAMS2 ::HIGH ADDRESS,M.S. BYTE
982 001353 000 $MTYP2: .BYTE AMTYP2 ::MEM. TYPE,BLK#2
983 001354 000000 $MADR2: .WORD AMADR2 ::MEM.LAST ADDRESS,BLK#2
984 001356 000 $MAMS3: .BYTE AMAMS3 ::HIGH ADDRESS,M.S.BYTE
985 001357 000 $MTYP3: .BYTE AMTYP3 ::MEM. TYPE,BLK#3
986 001360 000000 $MADR3: .WORD AMADR3 ::MEM.LAST ADDRESS,BLK#3
987 001362 000 $MAMS4: .BYTE AMAMS4 ::HIGH ADDRESS,M.S.BYTE
988 001363 000 $MTYP4: .BYTE AMTYP4 ::MEM. TYPE,BLK#4
989 001364 000000 $MADR4: .WORD AMADR4 ::MEM.LAST ADDRESS,BLK#4
990 001366 000000 $VECT1: .WORD AVECT1 ::INTERRUPT VECTOR#1,BUS PRIORITY#1
991 001370 000000 $VECT2: .WORD AVECT2 ::INTERRUPT VECTOR#2BUS PRIORITY#2
992 001372 000000 $BASE: .WORD ABASE ::BASE ADDRESS OF EQUIPMENT UNDER TEST
993 001374 000000 $DEVN: .WORD ADEVN ::DEVICE MAP
994 001376 000000 $CDW1: .WORD ACDW1 ::CONTROLLER DESCRIPTION WORD#1
995 001400 000000 $CDW2: .WORD ACDW2 ::CONTROLLER DESCRIPTION WORD#2
996 001402 000000 $DDW0: .WORD ADDW0 ::DEVICE DESCRIPTOR WORD#0
997 001404 000000 $DDW1: .WORD ADDW1 ::DEVICE DESCRIPTOR WORD#1
998 001406 000000 $DDW2: .WORD ADDW2 ::DEVICE DESCRIPTOR WORD#2
999 001410 000000 $DDW3: .WORD ADDW3 ::DEVICE DESCRIPTOR WORD#3
1000 001412 000000 $DDW4: .WORD ADDW4 ::DEVICE DESCRIPTOR WORD#4
1001 001414 000000 $DDW5: .WORD ADDW5 ::DEVICE DESCRIPTOR WORD#5
1002 001416 000000 $DDW6: .WORD ADDW6 ::DEVICE DESCRIPTOR WORD#6
1003 001420 000000 $DDW7: .WORD ADDW7 ::DEVICE DESCRIPTOR WORD#7
1004 001422 000000 $DDW8: .WORD ADDW8 ::DEVICE DESCRIPTOR WORD#8

```

1005 001424 000000
 1006 001426 000000
 1007 001430 000000
 1008 001432 000000
 1009 001434 000000
 1010 001436 000000
 1011 001440 000000

SDDW9: .WORD ADDW9 ;;DEVICE DESCRIPTOR WORD#9
 SDDW10: .WORD ADDW10 ;;DEVICE DESCRIPTOR WORD#10
 SDDW11: .WORD ADDW11 ;;DEVICE DESCRIPTOR WORD#11
 SDDW12: .WORD ADDW12 ;;DEVICE DESCRIPTOR WORD#12
 SDDW13: .WORD ADDW13 ;;DEVICE DESCRIPTOR WORD#13
 SDDW14: .WORD ADDW14 ;;DEVICE DESCRIPTOR WORD#14
 SDDW15: .WORD ADDW15 ;;DEVICE DESCRIPTOR WORD#15

1012
 1013
 1014 001442

SETEND:

1015
 1016
 1017
 1018
 1019 001442 000000
 1020 001444 000000
 1021
 1022

PROGRAM CONTROL PARAMETERS

 NEXT: .WORD 0 ; ADDRSS OF NEXT TEST TO BE EXECUTED
 LOCK: .WORD 0 ; ADDRESS FOR LOCK CURRENT DATA

1023
 1024 001446 000000
 1025 001450 000000
 1026 001452 000000
 1027 001454 000000
 1028 001456 000000
 1029 001460 000000
 1030 001462 000000
 1031 001464 000001
 1032 001466 000000
 1033 001470 000001
 1034 001472 000001
 1035 001474 000001
 1036 001476 000001
 1037 001500 000000
 1038

PROGRAM VARIABLES

 STRTSW: .WORD 0 ; SWITCHES AT START OF PROGRAM
 STAT: .WORD 0 ; KM STATUS WORD STORAGE
 CLKX: .WORD 0 ;
 MASKX: .WORD 0 ;
 SAVSP: .WORD 0 ; STACK POINTER STORAGE
 SAVPC: .WORD 0 ; PROGRAM COUNTER STORAGE
 ZERO: .WORD 0 ;
 ONE: .WORD 1 ;
 MEMLIM: .WORD 0 ; HIGHEST LOCATION FOR NPR'S
 KMACTV: .BLKW 1 ; KMC11 SELECTED ACTIVE
 KMNUM: .BLKW 1 ; OCTAL NUMBER OF KMC11'S
 SAVACT: .BLKW 1 ; ORIGINAL ACTIVE DEVICES.
 SAVNUM: .BLKW 1 ; WORKABLE NUMBER.
 RUN: .WORD 0 ; POINTER TO RUNNING DEVICES

1039 001502 002072
 1040 001504 002276
 1041

CREAM: .WORD KM.MAP-6 ; TABLE POINTER
 MILK: .WORD CNT.MAP-4 ; TABLE POINTER

1042
 1043
 1044 001506 000
 1045 001510 000
 1046 001511 000
 1047
 1048
 1049

PROGRAM CONTROL FLAGS

 INIFLG: .BYTE 0 ; PROGRAM INITIALIZING FLAG
 .EVEN
 LOKFLG: .BYTE 0 ; LOCK ON CURRENT TEST FLAG
 QV.FLG: .BYTE 0 ; QUICK VERIFY FLAG
 ; ON FIRST PASS OF EACH KMC11 ITERATIONS WILL BE SUPPRES
 .EVEN

1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105

001512

001512 000000
001514 000000
001516 000000
001520 032062
001522 033225
001524 033542
001526 032120
001530 033225
001532 033542
001534 032163
001536 033225
001540 033542
001542 032227
001544 000000
001546 000000
001550 032271
001552 033225
001554 033542
001556 032271
001560 033263
001562 033560
001564 032321
001566 033204
001570 033530
001572 032340
001574 033204
001576 033530
001600 032365
001602 033204
001604 033530
001606 032550
001610 033361
001612 033604
001614 032577
001616 033361
001620 033604
001622 032550
001624 033321
001626 033572

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;;POINTS TO THE ERROR MESSAGE
;* DH ;;POINTS TO THE DATA HEADER
;* DT ;;POINTS TO THE DATA
;* DF ;;POINTS TO THE DATA FORMAT

\$ERRTB:

.EVEN
;* DF ;; DOES NOT APPLY IN THIS DIAGNOSTIC.
0
0
0
EM1 ; ERROR 1
DH2
DT2
EM2 ; ERROR 2
DH2
DT2
EM3 ; ERROR 3
DH2
DT2
EM4 ; ERROR 4
0
0
EM5 ; ERROR 5
DH2
DT2
EM5 ; ERROR 6
DH3
DT3
EM6 ; ERROR 7
DH1
DT1
EM7 ; ERROR 10
DH1
DT1
EM10 ; ERROR 11
DH1
DT1
EM11 ; ERROR 12
DH5
DT5
EM12 ; ERROR 13
DH5
DT5
EM11 ; ERROR 14
DH4
DT4

1106	001630	032623	EM13	
1107	001632	000000	0	: ERROR 15
1108	001634	000000	0	
1109	001636	032550	EM11	
1110	001640	033361	DH5	: ERROR 16
1111	001642	033622	DT6	
1112	001644	032577	EM12	
1113	001646	033361	DH5	: ERROR 17
1114	001650	033622	DT6	
1115	001652	032550	EM11	
1116	001654	033413	DH6	: ERROR 20
1117	001656	033640	DT7	
1118	001660	032550	EM11	
1119	001662	033413	DH6	: ERROR 21
1120	001664	033662	DT10	
1121	001666	032577	EM12	
1122	001670	033413	DH6	: ERROR 22
1123	001672	033640	DT7	
1124	001674	032577	EM12	
1125	001676	033413	DH6	: ERROR 23
1126	001700	033662	DT10	
1127	001702	032663	EM14	
1128	001704	000000	0	: ERROR 24
1129	001706	000000	0	
1130	001710	032733	EM15	
1131	001712	033204	DH1	: ERROR 25
1132	001714	033530	DT1	
1133	001716	032754	EM16	
1134	001720	033263	DH3	: ERROR 16
1135	001722	033704	DT11	
1136	001724	032577	EM12	
1137	001726	033204	DH1	: ERROR 27
1138	001730	033716	DT12	
1139	001732	032770	EM17	
1140	001734	000000	0	: ERROR 30
1141	001736	000000	0	
1142	001740	033034	EM20	
1143	001742	033204	DH1	: ERROR 31
1144	001744	033530	DT1	
1145	001746	033055	EM21	
1146	001750	033461	DH7	: ERROR 32
1147	001752	000000	0	
1148	001754	033055	EM21	
1149	001756	033263	DH3	: ERROR 33
1150	001760	033560	DT3	
1151	001762	033072	EM22	
1152	001764	033504	DH10	: ERROR 34
1153	001766	000000	0	
1154	001770	033115	EM23	
1155	001772	033225	DH2	: ERROR 35
1156	001774	033542	DT2	
1157	001776	033137	EM24	
1158	002000	000000	0	: ERROR 36
1159	002002	000000	0	
1160	002004	033162	EM25	
1161	002006	000000	0	: ERROR 37

1162 002010 000000
1163 002012 032321
1164 002014 033225
1165 002016 033542
1166 002020 032271
1167 002022 033361
1168 002024 033604
1169 002026 032623
1170 002030 033204
1171 002032 033530
1172 002034
1173
1174
1175
1176
1177
1178 002034
1179 000024 000024
1180 000024 000200
1181 000044 000044
1182 000044 002034
1183 002034 002034
1184
1185
1186
1187
1188 002034
1189 002034 000000
1190 002036 001316
1191 002040 000132
1192 002042 000137
1193 002044 000137
1194 002046 000052
1195

0
EM6
DH2 ; ERROR 40
DT2
EM5
DH5 ; ERROR 41
DT5
EM13
DH1 ; ERROR 42
DT1

.=2034
.SBTTL APT PARAMETER BLOCK

::*****
:SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
:*****
.\$X=. ;;SAVE CURRENT LOCATION
.=24 ;;SET POWER FAIL TO POINT TO START OF PROGRAM
200 ;;FOR APT START UP
.=44 ;;POINT TO APT INDIRECT ADDRESS PNTR.
\$APTHDR ;;POINT TO APT HEADER BLOCK
.=.\$X ;;RESET LOCATION COUNTER
:*****
:SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
:INTERFACE SPEC.

\$APTHD:
\$HIBTS: .WORD 0 ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
\$MBADR: .WORD \$MAIL ;;ADDRESS OF APT MAILBOX (BITS 0-15)
\$STIM: .WORD 90. ;;RUN TIM OF LONGEST TEST
\$PASTM: .WORD 95. ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
\$UNITM: .WORD 95. ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDITIONAL UNIT
.WORD \$ETEND-\$MAIL/2 ;;LENGTH MAILBOX-ETABLE(WORDS)

```

1196
1197 ;KMC11 CONTROL INDICATORS FOR CURRENT KMC11 UNDER TEST
1198 ;-----
1199
1200 002050 000000 STAT1: 0
1201 002052 000000 STAT2: 0
1202 002054 000000 STAT3: 0
1203
1204 ;KMC11 VECTOR AND REGISTER INDIRECT POINTERS
1205 ;-----
1206
1207 002056 000000 KMRVEC: 0 ;POINTER TO KMC11 RECEIVER INTERRUPT VECTOR
1208 002060 000000 KMRLVL: 0 ;POINTER TO KMC11 RECEIVER INTERRUPT SERVICE PS
1209 002062 000000 KMTVEC: 0 ;POINTER TO KMC11 TRANSMITTER INTERRUPT VECTOR
1210 002064 000000 KMTLVL: 0 ;POINTER TO KMC11 TRANSMITTER INTERRUPT SERVICE PS
1211 002066 000000 KMCSR: 0 ;POINTER TO KMC11 CONTROL STATUS REGISTER
1212 002070 000000 KMCSRH: 0 ;POINTER TO KMC11 CONTROL STATUS REGISTER HIGH BYTE.
1213 002072 000000 KMCTL: 0 ;POINTER TO KMC11 CONTROL OUT REGISTER
1214 002074 000000 KMPO4: 0 ;POINTER TO KMC11 PORT REGISTER(SEL 4)
1215 002076 000000 KMPO6: 0 ;POINTER TO KMC11 PORT REGISTER(SEL 6)
1216
1217 ;TEMP STORAGE
1218 ;-----
1219
1220 ;TEMP: 0
1221 ;.=.+40
1222
1223 ;KMC11 STATUS TABLE AND ADDRESS ASSIGNMENTS
1224 ;-----
1225
1226 .:=2100
1227 002100 KM.MAP:
1228 002100 000001 KMCR00: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 00
1229 002102 000001 KMS100: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 00
1230 002104 000001 KMS200: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 00
1231 002106 000001 KMS300: .BLKW 1 ;3RD STATUS WORD
1232
1233 002110 000001 KMCR01: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 01
1234 002112 000001 KMS101: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 01
1235 002114 000001 KMS201: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 01
1236 002116 000001 KMS301: .BLKW 1 ;3RD STATUS WORD
1237
1238 002120 000001 KMCR02: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 02
1239 002122 000001 KMS102: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 02
1240 002124 000001 KMS202: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 02
1241 002126 000001 KMS302: .BLKW 1 ;3RD STATUS WORD
1242
1243 002130 000001 KMCR03: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 03
1244 002132 000001 KMS103: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 03
1245 002134 000001 KMS203: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 03
1246 002136 000001 KMS303: .BLKW 1 ;3RD STATUS WORD
1247
1248 002140 000001 KMCR04: .BLKW 1 ;CONTROL STATUS REGISTER FOR KMC11 NUMBER 04
1249 002142 000001 KMS104: .BLKW 1 ;VECTOR FOR KMC11 NUMBER 04
1250 002144 000001 KMS204: .BLKW 1 ;DDCMP LINE# FOR KMC11 NUMBER 04
1251 002146 000001 KMS304: .BLKW 1 ;3RD STATUS WORD

```

CZKCE MACY11 30A(1052) 08-JUL-80 08:24 PAGE 28
 CZKCE.F11 08-JUL-80 08:24 APT PARAMETER BLOCK

SEQ 0027

1252					
1253	002150	000001	KMCR05: .BLKW	1	:CONTROL STATUS REGISTER FOR KMC11 NUMBER 05
1254	002152	000001	KMS105: .BLKW	1	:VECTOR FOR KMC11 NUMBER 05
1255	002154	000001	KMS205: .BLKW	1	:DDCMP LINE# FOR KMC11 NUMBER 05
1256	002156	000001	KMS305: .BLKW	1	:3RD STATUS WORD
1257					
1258	002160	000001	KMCR06: .BLKW	1	:CONTROL STATUS REGISTER FOR KMC11 NUMBER 06
1259	002162	000001	KMS106: .BLKW	1	:VECTOR FOR KMC11 NUMBER 06
1260	002164	000001	KMS206: .BLKW	1	:DDCMP LINE# FOR KMC11 NUMBER 06
1261	002166	000001	KMS306: .BLKW	1	:3RD STATUS WORD
1262					
1263	002170	000001	KMCR07: .BLKW	1	:CONTROL STATUS REGISTER FOR KMC11 NUMBER 07
1264	002172	000001	KMS107: .BLKW	1	:VECTOR FOR KMC11 NUMBER 07
1265	002174	000001	KMS207: .BLKW	1	:DDCMP LINE# FOR KMC11 NUMBER 07
1266	002176	000001	KMS307: .BLKW	1	:3RD STATUS WORD
1267					
1268	002200	000001	KMCR10: .BLKW	1	:CONTROL STATUS REGISTER FOR KMC11 NUMBER 10
1269	002202	000001	KMS110: .BLKW	1	:VECTOR FOR KMC11 NUMBER 10
1270	002204	000001	KMS210: .BLKW	1	:DDCMP LINE# FOR KMC11 NUMBER 10
1271	002206	000001	KMS310: .BLKW	1	:3RD STATUS WORD
1272					
1273	002210	000001	KMCR11: .BLKW	1	:CONTROL STATUS REGISTER FOR KMC11 NUMBER 11
1274	002212	000001	KMS111: .BLKW	1	:VECTOR FOR KMC11 NUMBER 11
1275	002214	000001	KMS211: .BLKW	1	:DDCMP LINE# FOR KMC11 NUMBER 11
1276	002216	000001	KMS311: .BLKW	1	:3RD STATUS WORD
1277					
1278	002220	000001	KMCR12: .BLKW	1	:CONTROL STATUS REGISTER FOR KMC 1 NUMBER 12
1279	002222	000001	KMS112: .BLKW	1	:VECTOR FOR KMC11 NUMBER 12
1280	002224	000001	KMS212: .BLKW	1	:DDCMP LINE# FOR KMC11 NUMBER 12
1281	002226	000001	KMS312: .BLKW	1	:3RD STATUS WORD
1282					
1283	002230	000001	KMCR13: .BLKW	1	:CONTROL STATUS REGISTER FOR KMC11 NUMBER 13
1284	002232	000001	KMS113: .BLKW	1	:VECTOR FOR KMC11 NUMBER 13
1285	002234	000001	KMS213: .BLKW	1	:DDCMP LINE# FOR KMC11 NUMBER 13
1286	002236	000001	KMS313: .BLKW	1	:3RD STATUS WORD
1287					
1288	002240	000001	KMCR14: .BLKW	1	:CONTROL STATUS REGISTER FOR KMC11 NUMBER 14
1289	002242	000001	KMS114: .BLKW	1	:VECTOR FOR KMC11 NUMBER 14
1290	002244	000001	KMS214: .BLKW	1	:DDCMP LINE# FOR KMC11 NUMBER 14
1291	002246	000001	KMS314: .BLKW	1	:3RD STATUS WORD
1292					
1293	002250	000001	KMCR15: .BLKW	1	:CONTROL STATUS REGISTER FOR KMC11 NUMBER 15
1294	002252	000001	KMS115: .BLKW	1	:VECTOR FOR KMC11 NUMBER 15
1295	002254	000001	KMS215: .BLKW	1	:DDCMP LINE# FOR KMC11 NUMBER 15
1296	002256	000001	KMS315: .BLKW	1	:3RD STATUS WORD
1297					
1298	002260	000001	KMCR16: .BLKW	1	:CONTROL STATUS REGISTER FOR KMC11 NUMBER 16
1299	002262	000001	KMS116: .BLKW	1	:VECTOR FOR KMC11 NUMBER 16
1300	002264	000001	KMS216: .BLKW	1	:DDCMP LINE# FOR KMC11 NUMBER 16
1301	002266	000001	KMS316: .BLKW	1	:3RD STATUS WORD
1302					
1303	002270	000001	KMCR17: .BLKW	1	:CONTROL STATUS REGISTER FOR KMC11 NUMBER 17
1304	002272	000001	KMS117: .BLKW	1	:VECTOR FOR KMC11 NUMBER 17
1305	002274	000001	KMS217: .BLKW	1	:DDCMP LINE# FOR KMC11 NUMBER 17
1306	002276	000001	KMS317: .BLKW	1	:3RD STATUS WORD
1307					

CZKCE MACY11 3GA(1052) 08-JUL-80 08:24 PAGE 29
CZKCE.P11 08-JUL-80 08:24 APT PARAMETER BLOCK

C 3

SEQ 0028

1308 002300 000000

KM.END: 000000

			;KMC11 PASS COUNT AND ERROR COUNT TABLE	

			CNT.MAP:	
1309				
1310				
1311				
1312				
1313	002302		PACT00: 0	;PASS COUNT FOR KMC11 NUMBER 00
1314	002302	000000	ERCT00: 0	;ERROR COUNT FOR KMC11 NUMBER 00
1315	002304	000000		
1316				
1317	002306	000000	PACT01: 0	;PASS COUNT FOR KMC11 NUMBER 01
1318	002310	000000	ERCT01: 0	;ERROR COUNT FOR KMC11 NUMBER 01
1319				
1320	002312	000000	FACT02: 0	;PASS COUNT FOR KMC11 NUMBER 02
1321	002314	000000	ERCT02: 0	;ERROR COUNT FOR KMC11 NUMBER 02
1322				
1323	002316	000000	PACT03: 0	;PASS COUNT FOR KMC11 NUMBER 03
1324	002320	000000	ERCT03: 0	;ERROR COUNT FOR KMC11 NUMBER 03
1325				
1326	002322	000000	PACT04: 0	;PASS COUNT FOR KMC11 NUMBER 04
1327	002324	000000	ERCT04: 0	;ERROR COUNT FOR KMC11 NUMBER 04
1328				
1329	002326	000000	PACT05: 0	;PASS COUNT FOR KMC11 NUMBER 05
1330	002330	000000	ERCT05: 0	;ERROR COUNT FOR KMC11 NUMBER 05
1331				
1332	002332	000000	PACT06: 0	;PASS COUNT FOR KMC11 NUMBER 06
1333	002334	000000	ERCT06: 0	;ERROR COUNT FOR KMC11 NUMBER 06
1334				
1335	002336	000000	PACT07: 0	;PASS COUNT FOR KMC11 NUMBER 07
1336	002340	000000	ERCT07: 0	;ERROR COUNT FOR KMC11 NUMBER 07
1337				
1338	002342	000000	PACT10: 0	;PASS COUNT FOR KMC11 NUMBER 10
1339	002344	000000	ERCT10: 0	;ERROR COUNT FOR KMC11 NUMBER 10
1340				
1341	002346	000000	PACT11: 0	;PASS COUNT FOR KMC11 NUMBER 11
1342	002350	000000	ERCT11: 0	;ERROR COUNT FOR KMC11 NUMBER 11
1343				
1344	002352	000000	PACT12: 0	;PASS COUNT FOR KMC11 NUMBER 12
1345	002354	000000	ERCT12: 0	;ERROR COUNT FOR KMC11 NUMBER 12
1346				
1347	002356	000000	PACT13: 0	;PASS COUNT FOR KMC11 NUMBER 13
1348	002360	000000	ERCT13: 0	;ERROR COUNT FOR KMC11 NUMBER 13
1349				
1350	002362	000000	PACT14: 0	;PASS COUNT FOR KMC11 NUMBER 14
1351	002364	000000	ERCT14: 0	;ERROR COUNT FOR KMC11 NUMBER 14
1352				
1353	002366	000000	PACT15: 0	;PASS COUNT FOR KMC11 NUMBER 15
1354	002370	000000	ERCT15: 0	;ERROR COUNT FOR KMC11 NUMBER 15
1355				
1356	002372	000000	PACT16: 0	;PASS COUNT FOR KMC11 NUMBER 16
1357	002374	000000	ERCT16: 0	;ERROR COUNT FOR KMC11 NUMBER 16
1358				
1359	002376	000000	PACT17: 0	;PASS COUNT FOR KMC11 NUMBER 17
1360	002400	000000	ERCT17: 0	;ERROR COUNT FOR KMC11 NUMBER 17
1361				

1362
1363
1364
1365
1366
1367

FORMAT OF STATUS TABLE

15	14	13	12	11	10	09	08	07	06	05	04	03	02	01	00	
I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	CSR
I	C	O	M	T	R	O	L		R	E	G	I	S	T	E	R
I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	
I	*	I	*	I	*	I	*	I	*	I	*	I	*	I	*	STAT1
I	I	I	I	I	I	I	I	I	I	V	E	C	T	O	R	
I	*	I	I	I	A	D	D	*	I	*	I	L	I	N	E	STAT2
I	I	B	M	I	I	I	I	I	I	I	I	I	I	I	#	
I	I	I	I	I	I	I	I	I	I	I	I	I	I	*	I	STAT3
I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	*	

DEFINITION OF FORMAT

- CSR: CONTAINS KMC11 CSR ADDRESS
- STAT1: BITS 00-08 IS KMC11 VECTOR ADDRESS
 BIT14=1 ??? TURNAROUND CONNECTOR IS ON
 BIT14=0 NO TURNAROUND CONNECTOR
 BIT13=0 LINE UNIT IS AN M8201
 BIT13=1 LINE UNIT IS AN M8202
 BIT12=1 NO LINE UNIT
 BITS 09-11 IS KMC11 BR PRIORITY LEVEL
- STAT2: LOW BYTE IS SWITCH PAC#1 (DDCMP LINE NUMBER)
 HIGH BYTE IS SWITCH PAC#2 (BM873 BOOT ADD)
- STAT3: BIT0=1 DO FREE RUNNING TESTS ON KMC
 (MUST BE SET TO A ONE MANUALLY [PROGRAMS G AND H ONLY])
 BIT2=0 DMC11-DA (RS232C)
 BIT2=1 DMC11-FA (V.35)

CZKCE MACY11 30A(1052) 08-JUL-80 08:24 PAGE 32
CZKCE.P11 08-JUL-80 08:24 APT PARAMETER BLOCK

SEQ 0031

S

```

1419
1420          :PROGRAM INITIALIZATION
1421          :LOCK OUT INTERRUPTS
1422          :SET UP PROCESSOR STACK
1423          :SET UP POWER FAIL VECTOR
1424          :CLEAR PROGRAM CONTROL FLAGS AND COUNTS
1425          :TYPE TITLE MESSAGE
1426
1427 002402 012737 000340 177776 .START: MOV      #340,PS      :LOCK OUT INTERRUPTS
1428 002410 012706 001200          MOV      #STACK,SP    :SET UP STACK
1429 002414 012737 007126 000024          MOV      #SPWRDN,@#24 :SET UP POWER FAIL VECTOR
1430 002422 013737 001472 001476          MOV      KMMNUM,SAVNUM :SAVE NUMBER OF DEVICES IN SYSTEM.
1431 002430 005037 011544          CLR      SWFLG        :CLEAR SOFT TYPEOUT FLAG
1432 002434 105037 001203          CLR      $ERFLG      :CLEAR ERROR FLAG
1433 002440 105037 001511          CLR      QV.FLG      :ZERO QUICK VERIFY FLAG
1434 002444 012737 002070 001502          MOV      #KM.MAP-10,CREAM:GET MAP POINTER.
1435 002452 012737 002276 001504          MOV      #CNT.MAP-4,MILK:GET PASS COUNT MAP POINTER
1436 002460 012737 100000 001500          MOV      #BIT15,RUN   :POINT POINTER TO FIRST DEVICE.
1437 002466 012700 002302          MOV      #CNT.MAP,RO  :PASS COUNT POINTER TO RO
1438 002472 005020          23$: CLR      (RO)+      :CLEAR TABLE
1439 002474 022700 002402          CMP      #CNT.MAP+100,RO:DONE YET?
1440 002500 001374          BNE      23$         :KEEP GOING
1441 002502 005037 001216          CLR      $ERRPC      :CLEAR LAST ERROR POINTER
1442 002506 012737 000001 001202          MGV      #1,$STSTM   :SET UP FOR TEST 1
1443 002514 012737 002402 001206          MOV      #.START,$LPADR:SET UP FOR POWER FAIL BEFORE
1444          :TESTING STARTS
1445 002522 132737 000001 001336          BITB     #1,$ENV      : IS IT RUNNING UNDER APT?
1446 002530 001404          3$: BEQ      3$         : IF NOT CHECK FOR TYPE OF SWITCH REGISTER.
1447 002532 013737 001340 000176          MOV      $SWREG,SWREG :LOAD SOFTWARE SWITCH REG.
1448 002540 000423          BR       6$+2        : GO SET UP SOFTWARE SWITCH REG.
1449 002542 013746 000006          3$: MOV      @#6,-(SP)   :SAVE CURRENT VECTORS
1450 002546 013746 000004          MOV      @#4,-(SP)   :
1451 002552 012737 002606 000004          MOV      #6$,@#4     :SET UP FOR TIMEOUT
1452 002560 012737 177570 001240          MOV      #177570,SWR  :SET SWR TO HARD SWR ADDRESS
1453 002566 012737 177570 001242          MOV      #177570,DISPLAY:SET DISPLAY TO HARD SWR ADDRESS
1454 002574 022777 177777 176436          CMP      #-1,@SWR    :REFERENCE HARDWARE SWITCH REGISTER
1455 002602 001402          BEQ      6$+2        :IF = -1 USE SOFT SWR ANYWAY
1456 002604 000407          BR       7$         :IF IT EXISTS AND NOT = -1 USE HARD SWR
1457 002606 022626          6$: CMP      (SP)+,(SP)+ :ADJUST STACK
1458 002610 012737 000176 001240          MOV      #SWREG,SWR   :POINTER TO SOFT SWR
1459 002616 012737 000174 001242          MOV      #DISPREG,DISPLAY:POINTER TO SOFT DISPLAY REG
1460 002624 012637 000004          7$: MOV      (SP)+,@#4   :RESTORE VECTORS
1461 002630 012637 000006          MOV      (SP)+,@#6   :
1462 002634 105737 001506          TSTB     INIFLG      :HAS INITIALIZATION BEEN PERFORMED
1463 002640 001006          BNE      20$        :BR IF YES
1464 002642 022737 004070 000042          CMP      #SENDAD,@#42 :IF ACT-11 AUTOMATIC MODE, DON'T TYPE ID
1465 002650 001402          BEQ      20$        :
1466 002652 104401 001000          TYPE     ,MTITLE     :TYPE TITLE MESSAGE
1467 002656 004737 011340          20$: JSR      PC,CKSWR   :CHECK FOR SOFT SWR
1468 002662 017737 176352 001446          MOV      @SWR,STRTSW :STORE STARTING SWITCHES
1469 002670 005737 000042          TST      @#42        :IS IT RUNNING IN AUTO MODE?
1470 002674 001402          BEQ      .+6         :BR IF NO
1471 002676 005037 001446          CLR      STRTSW     :IF YES, CLEAR SWITCHES
1472 002702 032737 000001 001446          BIT      #SW00,STRTSW:IF SW00=1, QUESTIONS ARE ASKED.
1473 002710 001012          BNE      17$        :BR IF SW00=1
1474 002712 105737 001446          TSTB     STRTSW     :BIT7=1??

```



```

1475 002716 100007          BPL      17$          ;BR IF SW07=0
1476 002720 005737 001470  TST      KMACTV     ;ARE ANY DEVICES SELECTED?
1477 002724 001027          BNE      16$          ;BR IF YES
1478 002726 104401 011057  TYPE,   NOACT        ;NO DEVICES SELECTED.
1479 002732 000000          HALT                     ;STOP THE SHOW
1480 002734 000776          BR       .-2           ;DISQUALIFY CONTINUE SWITCH
1481 002736 105737 001336  17$:    TSTB     $ENV      ; IS IT UNDER APT DUMP MODE?
1482 002742 001405          BEQ     27$          ; YES, CHECK IF APT SIZED IT?
1483 002744 132737 000001 001336  BITB    #1,$ENV     ; IS IT UNDER Q,V OR RUN MODE?
1484 002752 001012          BNE     30$          ; YES, NEEDS ONLY APT SIZING.
1485 002754 000406          BR      33$          ; NO, NEEDS REGULAR AUTO.SIZE.
1486 002756 105737 001337  27$:    TSTB     $ENVM    ; IS IT SIZED BY APT?
1487 002762 100406          BMI     30$          ; YES, NEEDS ONLY APT SIZING.
1488 002764 042737 000001 001446  BIC     #SW00,STRTSW ; SIZE ONLY IN AUTO MODE.
1489 002772 004737 012236  33$:    JSR     PC,AUTO.SIZE ; GO DO THE AUTO.SIZE.
1490 002776 000402          BR      16$          ; GO PRINT THE MAP.
1491 003000 004737 013716  30$:    JSR     PC,APT.SIZE ; GO DO THE APT SIZING.
1492 003004 105737 001506  16$:    TSTB     INIFLG    ;FIRST TIME?
1493 003010 001410          BEQ     21$          ;BR IF YES
1494 003012 105737 001446  TSTB     STRTSW     ;IF USING SAME PARAMETERS DONT TYPE MAP
1495 003016 100431          BMI     1$           ;
1496 003020 032737 000006 001446  BIT     #BIT1:BIT2,STRTSW ;IS TEST NO. OR LOCK SELECTED
1497 003026 001403          BEQ     24$          ;IF NO THEN TYPE STATUS
1498 003030 000424          BR      1$           ;IF YES DO NOT TYPE STATUS
1499 003032 105137 001506  21$:    COMB    INIFLG    ;SET FLAG
1500 003036 104401 010100  24$:    TYPE    ,XHEAD   ;TYPE HEADER
1501 003042 012704 002100          MOV     #KM.MAP,R4   ;SET POINTER
1502 003046 010437 001276  5$:    MOV     R4,$TMP0   ;SET ADDRESS
1503 003052 012437 001300          MOV     (R4)+,$TMP1  ;SET CSR
1504 003056 001411          BEQ     1$           ;ALL DONE IF ZERO
1505 003060 012437 001302          MOV     (R4)+,$TMP2  ;SET STAT1
1506 003064 012437 001304          MOV     (R4)+,$TMP3  ;SET STAT2
1507 003070 012437 001306          MOV     (R4)+,$TMP4  ;SET STAT3
1508 003074 104416          CONVRT ;TYPE OUT STATUS MAP
1509 003076 011206          XSTATQ ;
1510 003100 000762          BR      5$           ;
1511 003102 012700 002100  1$:    MOV     #KM.MAP,R0 ;R0 POINTS TO STATUS TABLE
1512
1513  ;*****
1514  ;*AUTO SIZE TEST
1515  ;*THIS TEST VERIFYS THAT THE KMC11S AND/OR KMC11S ARE AT THE CORRECT FLOATING
1516  ;*ADDRESSES FOR YOUR SYSTEM. IF THIS TEST FAILS, IT IS NOT A HARDWARE ERROR.
1517  ;*CHECK THE ADDRESSES OF ALL FLOATING DEVICES (DJ,DH,DQ,DU,DUP,LK,DMC,DZ,KMC).
1518  ;*IF THERE ARE NO OTHER FLOATING DEVICES BEFORE THE KMC11, THE FIRST
1519  ;* KMC11 IS 760110. NO DEVICE SHOULD EVER BE AT
1520  ;*ADDRESS 760000.
1521  ;*****
1522
1523 003106 013746 000004          MOV     @#4,-(SP)    ;SAVE LOC 4
1524 003112 013746 000006          MOV     @#6,-(SP)    ;SAVE LOC 6
1525 003116 005037 000006          CLR     @#6          ;CLEAR VEC+2
1526 003122 005037 001302          CLR     $TMP2        ;CLEAR FLAG
1527 003126 011037 002066  AUSTRT: MOV     (R0),KMC11 ;GET NEXT KMC CSR
1528 003132 001510          AUDONE ;BR IF DONE
1529 003134 012737 003240 000004  2$:    MOV     #NODEV,@#4 ;SET UP FOR TIMEOUT
1530 003142 012703 000010  3$:    MOV     #10,R3     ;R3 IS COUNT OF DEVICES BEFORE KMC

```

```

1531 003146 012702 003342 4$: MOV #DEVTAB,R2 ;R2 IS DEVICE TABLE PONTNER
1532 003152 012701 160010 MOV #160010,R1 ;START WITH ADDRESS 160010
1533 003156 005711 FLOAT: TST (R1) ;CHECK ADDRESS IN R1
1534 003160 111204 MOV (R2),R4 ;IF NO TIMEOUT, GET NEXT ADDRESS
1535 003162 060401 ADD R4,R1 ;IN R1
1536 003164 005201 INC R1 ;
1537 003166 040401 BIC R4,R1 ;
1538 003170 005703 TST R3 ;ANY MORE DEVICES TO CHECK FOR?
1539 003172 001371 BNE FLOAT ;BR IF YES
1540 003174 012737 003244 000004 MOV #ERR,@#4 ;OK ONLY KMC'S ARE LEFT, SET UP FOR TIMEOUT
1541 003202 005711 FY: TST (R1) ;CHECK KMC ADDRESS
1542 003204 020137 002066 CMP R1,KMCSR ;DOES IT MATCH
1543 003210 001403 BEQ OK ;BR IF YES
1544 003212 062701 000010 ADD #10,R1 ;GET NEXT KMC ADDRESS
1545 003216 000771 BR FY ;DO IT AGAIN
1546 003220 062700 000010 OK: ADD #10,R0 ;SKIP TO NEXT KMC CSR
1547 003224 062701 000010 ADD #10,R1 ; GET NEXT KMC ADDRESS
1548 003230 011037 002066 MOV (R0),KMCSR ; GET NEXT KMC CSR
1549 003234 001447 BEQ AUDONE ; BRANCH IF ALL DONE.
1550 003236 000761 BR FY ; DO IT AGAIN.
1551 003240 122243 NODEV: CMPB (R2)+,-(R3) ;ON TIMEOUT, INC R2, DEC R3
1552 003242 000002 RTI ;$LPADR
1553 003244 005737 001302 ERR: TST $TMP2 ;CHECK FLAG IF = 0 TYPE HEADER
1554 003250 001014 BNE 1$ ;SKIP HEADER
1555 003252 104401 TYPE ;TYPEOUT HEADER MESSAGE
1556 003254 011110 CONERR ;CONFIGURATION ERROR!!!!
1557 003256 012737 003244 001460 MOV #ERR,SAVPC ;SAVE PC FOR TYPEOUT
1558 003264 104417 CNVRT ;TYPE OUT ERROR PC
1559 003266 003322 ERRPC ;
1560 003270 104401 TYPE ;TYPE REST OF HEADER
1561 003272 011155 CNERR ;
1562 003274 012737 177777 001302 MOV #-1,$TMP2 ;SET FLAG SO IT ONLY GETS TYPED ONCE
1563 003302 010137 001264 1$: MOV R1,$REG1 ;SAVE R1 FOR TYPEOUT
1564 003306 104416 CNVRT ;
1565 003310 003330 CONTAB ;TYPE CSR VALUES
1566 003312 104401 3$: TYPE ;
1567 003314 011176 KMCM ;
1568 003316 022626 4$: CMP (SP)+,(SP)+ ;ADJUST STACK
1569 003320 000737 BR OK ;BR TO GET OUT
1570 003322 000001 ERRPC: 1 ;
1571 003324 006 002 .BYTE 6,2 ;
1572 003326 001460 SAVPC ;
1573 003330 000002 CONTAB: 2 ;
1574 003332 006 004 .BYTE 6,4 ;
1575 003334 001264 $REG1 ;
1576 003336 006 002 .BYTE 6,2 ;
1577 003340 002066 KMCSR ;
1578 003342 007 DEVTAB: .BYTE 7 ;DJ
1579 003343 017 .BYTE 17 ;DH
1580 003344 007 .BYTE 7 ;DQ
1581 003345 007 .BYTE 7 ;DU
1582 003346 007 .BYTE 7 ;DUP
1583 003347 007 .BYTE 7 ;LK
1584 003350 007 .BYTE 7 ;DMC
1585 003351 007 .BYTE 7 ;DZ
1586 003352 007 .BYTE 7 ;KMC

```

```

1587      003354      003354      .EVEN
1588      003354      012637      000006      AUDONE:
1589      003354      012637      000004      1$:  MOV      (SP)+,a#6      ;RESTORE LOC 6
1590      003360      012637      000004      MOV      (SP)+,a#4      ;RESTORE LOC 4
1591      003364      032737      000010      001446      BIT      #SW03,STRTSW    ;SELECT SPECIFIC DEVICES??
1592      003372      001422      BEQ      3$           ;BR IF NO.
1593      003374      104401      010020      TYPE    ,MNEW        ;TYPE THE MESSAGE.
1594      003400      005000      CLR      RO          ;ZERO DATA LIGHTS
1595      003402      000000      HALT    ;WAIT FOR USER TO TELL WHAT DEVICES TO RUN
1596      003404      027737      175630      001474      CMP      @SWR,SAVACT   ;IS THE NUMBER VALID?
1597      003412      101404      BLOS    2$           ;BR IF NUMBER IS OK.
1598      003414      104401      007673      TYPE    ,MERR3       ;TELL USER OF INVALID NUMBER.
1599      003420      000000      HALT    ;STOP EVERY THING.
1600      003422      000776      BR      -2           ;RESTART THE PROGRAM AGAIN.
1601      003424      017737      175610      001470      2$:  MOV      @SWR,KMACTV  ;GET NEW DEVICE PATTERN
1602      003432      013700      001470      MOV      KMACTV,RO    ;SHOW THE USER WHAT HE SELECTED.
1603      003436      000000      HALT    ;CONTINUE DYNAMIC SWITCHES.
1604      003440      012700      000300      3$:  MOV      #300,RO     ;PREPARE TO CLEAR THE FLOATING
1605      003444      012701      000302      MOV      #302,R1     ;VECTOR AREA. 300-776
1606      003450      010120      4$:  MOV      R1,(RO)+    ;START PUTTING 'PC+2 - HALT'
1607      003452      005027      CLR      (R1)+       ;IN VECTOR AREA.
1608      003454      022021      CMP      (RO)+,(R1)+ ;POP POINTERS
1609      003456      022700      001000      CMP      #1000,RO    ;ALL DONE??
1610      003462      001372      BNE     4$           ;BR IF NO.

```

```

1611
1612      ;TEST START AND RESTART
1613      ;-----
1614

```

```

1615      003464      012706      001200      .BEGIN: MOV      #STACK,SP      ;SET UP STACK
1616      003470      013746      000006      MOV      a#6,-(SP)    ;SAVE LOC 6
1617      003474      013746      000004      MOV      a#4,-(SP)    ;SAVE LOC 4
1618      003500      005000      CLR      RO          ;START AT 0
1619      003502      012737      003546      000004      MOV      #2$,a#4     ;SET UP FOR TIME OUT
1620      003510      005037      000006      CLR      a#6         ;TO AUTOSIZE MEMORY
1621      003514      005720      6$:  TST      (RO)+       ;CHECK ADDRESS IN RO
1622      003516      022700      157776      CMP      #157776,RO   ;IS IT AT LEAST 28K
1623      003522      001374      BNE     6$           ;BR IF NO
1624      003524      162700      007776      SUB      #7776,RO     ;SAVE 2K FOR MONITORS
1625      003530      010037      001466      7$:  MOV      RO,MEMLIM    ;STORE MEMORY LIMIT
1626      003534      012637      000004      MOV      (SP)+,a#4     ;RESTORE LOC 4
1627      003540      012637      000006      MOV      (SP)+,a#6     ;RESTORE LOC 6
1628      003544      000413      BR      10$         ;CONTINUE
1629      003546      022626      2$:  CMP      (SP)+,(SP)+  ;ADJUST STACK
1630      003550      162700      000004      SUB      #4,RO        ;GET LAST GOOD ADDRESS
1631      003554      162700      007776      SUB      #7776,RO     ;SAVE 2K FOR MONITORS
1632      003560      022700      030000      CMP      #30000,RO    ;IS IT 8K?
1633      003564      001361      BNE     7$           ;BR IF NO
1634      003566      012700      037400      MOV      #37400,RO    ;IF 8K DON'T SAVE 2K
1635      003572      000756      BR      7$           ;
1636      003574      012737      000340      177776      10$: MOV      #340,PS     ;LOCK OUT INTERRUPTS
1637      003602      032737      000004      001446      BIT      #BIT2,STRTSW ;CHECK FOR LOCK ON TES.
1638      003610      001406      BEQ     1$           ;BR IF NO LOCK DESIRED.
1639      003612      104401      007717      TYPE    ,MLOCK       ;TYPE LOCK SELECTED.
1640      003616      012737      000240      004146      MOV      #NOP,TTST    ;SET UP TO LOCK
1641      003624      000403      BR      3$           ;CONTINUE ALONG.
1642      003626      013737      004360      004146      1$:  MOV      BRW,TTST     ;PREPARE NORMAL SCOPE ROUTINE

```

CZKCE MACY11 30A(1052) 08-JUL-80 08:24 PAGE 37
CZKCE.P11 08-JUL-80 08:24

PROGRAM INITIALIZATION AND START UP.

SEQ 0036

1643	003634	012737	011606	001206	3\$:	MOV	#CYCLE,\$LPADR	:START AT "CYCLE" FIND WHICH DEVICE TO TEST
1644	003642	032737	000002	001446	4\$:	BIT	#SW01,STRTSW	:IS TEST NO. SELECTED?
1645	003650	001002				BNE	5\$:BR IF YES
1646	003652	104401	007643			TYPE	,MR	:TYPE R
1647	003656	000177	175324		5\$:	JMP	@\$LPADR	:START TESTING

```

1648 ;END OF PASS
1649 ;TYPE NAME OF TEST
1650 ;UPDATE PASS COUNT
1651 ;CHECK FOR EXIT TO ACT-11
1652 ;RESTART TEST
1653
1654
1655
1656
1657
1658
1659
1660
    
```

.SBTTL END OF PASS ROUTINE

```

;*****
;*INCREMENT THE PASS NUMBER ($PASS)
;*IF THERES A MONITOR GO TO IT
;*IF THERE ISN'T JUMP TO CYCLE
    
```

\$EOP:

1661	003662				RESET		
1662	003662	000005			INC	\$PASS	; INCREMENT THE PASS COUNT
1663	003664	005237	001324		CLRB	\$ERFLG	; CLEAR ERROR FLAG
1664	003670	105037	001203		TYPE	,MEPASS	; TYPE END PASS.
1665	003674	104401	007620		TYPE	,MCSR	; TYPE 'CSR'
1666	003700	104401	007746		CNVRT	,XCSR	; SHOW IT.
1667	003704	104417	004104		TYPE	,MVECX	; TYPE VECTOR.
1668	003710	104401	007754		CNVRT	,XVEC	; SHOW IT.
1669	003714	104417	004112		TYPE	,MPASSX	; TYPE " PASSES "
1670	003720	104401	007762		CNVRT	,XPASS	; SHOW IT.
1671	003724	104417	004120		TYPE	,MERRX	; TYPE " ERRORS "
1672	003730	104401	007773		CNVRT	,XERR	; SHOW IT.
1673	003734	104417	004126		MOV	MILK,RO	; SET POINTER TO PASSCNT.
1674	003740	013700	001304		MOV	\$PASS,(RO)+	; SAVE THE PASS COUNT.
1675	003744	013720	001324		MOV	\$ERTTL,(RO)+	; SAVE ERROR COUNT
1676	003750	013720	001212		MOV	KMRLVL,@KMRVEC	; RESTORE THE RECEIVER INTERRUPT VECTOR.
1677	003754	013777	002060	176074	CLR	@KMRLVL	; RESTORE RECEIVER LEVEL
1678	003762	005077	176072		MOV	KMTLVL,@KMTVEC	; RESTORE THE TRANSMIT INTERRUPT VECTOR.
1679	003766	013777	002064	176066	CLR	@KMTLVL	; RESTORE TRANSMITTER LEVEL
1680	003774	005077	176064		DEC	SAVNUM	; ALL DEVICE TESTED?
1681	004000	005337	001476		BNE	\$DOAGN	; BRANCH IF NO.
1682	004004	001035			MOVB	#377,QV.FLG	; SET QUICK VERIFY FLAG.
1683	004006	112737	000377	001511	MOV	KMNUM,SAVNUM	; RESTORE DEVICE COUNT.
1684	004014	013737	001472	001476	CLR	\$ERRPC	; CLEAR LAST ERROR PC
1685	004022	005037	001216		CLR	\$TIMES	; ZERO THE NUMBER OF ITERATIONS
1686	004026	005037	001310		INC	\$PASS	; INCREMENT THE PASS NUMBER
1687	004032	005237	001324		BIC	#100000,\$PASS	; DON'T ALLOW A NEG. NUMBER
1688	004036	042737	100000	001324	DEC	(PC)+	; LOOP?
1689	004044	005327			\$EOPCT:	.WORD 1	
1690	004046	000001			BGT	\$DOAGN	; YES
1691	004050	003013			MOV	(PC)+,@(PC)+	; RESTORE COUNTER
1692	004052	012737			\$ENDCT:	.WORD 1	
1693	004054	000001			\$EOPCT		
1694	004056	004046			\$GET42:	MOV @#42,RO	; GET MONITOR ADDRESS
1695	004060	013700	000042		BEQ	\$DOAGN	; BRANCH IF NO MONITOR
1696	004064	001405			RESET		; CLEAR THE WORLD
1697	004066	000005			\$ENDAD:	JSR PC,(RO)	; GO TO MONITOR
1698	004070	004710			NOP		; SAVE ROOM
1699	004072	000240			NOP		; FOR
1700	004074	000240			NOP		; ACT11
1701	004076	000240			\$DOAGN:		
1702	004100				JMP	@(PC)+	; RETURN
1703	004100	000137					

```

1704 004102 011606          SRTNAD: .WORD  CYCLE
1705 004104 000001          XCSR:   1
1706 004106 006           002 .BYTE  6,2
1707 004110 002066          KMCSR
1708 004112 000001          XVEC:   1
1709 004114 004           002 .BYTE  4,2
1710 004116 002056          KMRVEC
1711 004120 000001          XPASS:  1
1712 004122 006           002 .BYTE  6,2
1713 004124 001324          $PASS
1714 004126 000001          XERR:   1
1715 004130 006           002 .BYTE  6,2
1716 004132 001212          $ERTTL
1717
1718                          ;SCOPE LOOP AND INTERATION HANDLER
1719                          ;-----
1720
1721                          .SBTTL  SCOPE HANDLER ROUTINE
1722
1723                          ;:*****
1724                          ;*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
1725                          ;*AND LOAD THE TEST NUMBER($TSTNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
1726                          ;*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
1727                          ;*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
1728                          ;*SW14=1      LOOP ON TEST
1729                          ;*SW11=1      INHIBIT ITERATIONS
1730                          ;*CALL
1731                          ;*      SCOPE          ;;SCOPE=IOT
1732
1733                          $SCOPE:
1734                          CLR      $ERRPC          ; CLEAR LAST ERROR PC
1735                          CMP      TST1+2,(SP)     ; IS THIS TEST #1 ?
1736                          BEQ      $XTSTR          ; IF SO DON'T LOOP.
1737                          BR       1$
1738                          TSTB     @STKS           ; KEYBOARD DONE ?
1739                          BPL      $OVER          ; IF NO DONT WAIT.
1740                          MOV      @STKB,-2(SP)
1741                          1$:  BIT   #BIT14,@SWR   ;;LOOP ON PRESENT TEST?
1742                          BNE      $OVER          ;;YES IF SW14=1
1743                          ;*****START OF CODE FOR THE XOR TESTER*****
1744                          $XTSTR: BR      6$
1745
1746                          MOV      @ERRVEC,-(SP)   ;;IF RUNNING ON THE 'XOR' TESTER CHANGE
1747                          MOV      #5,@ERRVEC     ;;THIS INSTRUCTION TO A 'NOP' (NOP=240)
1748                          TST      @177060       ;;SAVE THE CONTENTS OF THE ERROR VECTOR
1749                          MOV      (SP)+,@ERRVEC  ;;SET FOR TIMEOUT
1750                          BR       $SVLAD        ;;TIME OUT ON XOR?
1751                          5$:  CMP      (SP)+,(SP)+ ;RESTORE THE ERROR VECTOR
1752                          MOV      (SP)+,@ERRVEC  ;;GO TO THE NEXT TEST
1753                          BR       $OVER          ;;CLEAR THE STACK AFTER A TIME OUT
1754                          6$:  ;*****END OF CODE FOR THE XOR TESTER*****
1755                          2$:  TSTB     $ERFLG     ;;HAS AN ERROR OCCURRED?
1756                          BEQ      3$           ;;BR IF NO
1757                          4$:  CLRB     $ERFLG     ;;ZERO THE ERROR FLAG
1758                          CLR      $TIMES        ;;CLEAR THE NUMBER OF ITERATIONS TO MAKE
1759                          3$:  BIT      #BIT11,@SWR ;;INHIBIT ITERATIONS?

```

```

1760 004256 001011          BNE      1$          ;;BR IF YES
1761 004260 005737 001324   TST      $PASS      ;;IF FIRST PASS OF PROGRAM
1762 004264 001406          BEQ      1$          ;;      INHIBIT ITERATIONS
1763 004266 005237 001204   INC      $ICNT      ;;INCREMENT ITERATION COUNT
1764 004272 023737 001310 001204  CMP      $TIMES,$ICNT ;;CHECK THE NUMBER OF ITERATIONS MADE
1765 004300 002015          BGE      $OVER      ;;BR IF MORE ITERATION REQUIRED
1766 004302 012737 000001 001204 1$:  MOV      #1,$ICNT    ;;REINITIALIZE THE ITERATION COUNTER
1767 004310 013737 004362 001310  MOV      $MXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
1768 004316 105237 001202   $SVLAD: INCB     $STNM    ;;COUNT TEST NUMBERS
1769 004322 113737 001202 001322  MOVVB   $STNM,$TESTN ;;SET TEST NUMBER IN APT MAILBOX
1770 004330 011637 001206          MOV      (SP),$LPADR ;;SAVE SCOPE LOOP ADDRESS
1771 004334 013777 001202 174700  $OVER: MOV      $STNM,@DISPLAY ;;DISPLAY TEST NUMBER
1772 004342 013716 001206          MOV      $LPADR,(SP) ;;FUDGE RETURN ADDRESS
1773 004346 005037 001444          CLR      LOCK      ; RESET LOCK ON DATA.
1774 004352 013701 002066          MOV      KMCSR,R1   ; R1 CONTAINS BASE KMC ADDRESS.
1775 004356 000002          RTI
1776 004360 000406          BRW:    .WORD     406
1777 004362 000020          $MXCNT: 20          ;;MAX. NUMBER OF ITERATIONS
1778
1779          ;CHECK FOR FREEZE ON CURRENT DATA
1780          ;-----
1781
1782 004364 004737 011340   .SCOPI: JSR      PC,CKSWR          ;CHECK FOR SOFT SWR
1783 004370 032777 001000 174642  BIT      #SW09,@SWR          ;IS SW09=1(SET)?
1784 004376 001405          BEQ      1$          ;BR IF NOT SET.
1785 004400 005737 001444          TST      LOCK
1786 004404 001402          BEQ      1$
1787 004406 013716 001444   1$:  MOV      LOCK,(SP)          ;GOTO THE ADDRESS IN LOCK.
1788 004412 000002          RTI          ;GO BACK.
1789
1790          ;TELETYPE OUTPUT ROUTINE
1791          ;-----
1792
1793          .SBTTL  TYPE ROUTINE
1794
1795          ;*****
1796          ;*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
1797          ;*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
1798          ;*NOTE1:      $NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
1799          ;*NOTE2:      $FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
1800          ;*NOTE3:      $FILLC CONTAINS THE CHARACTER TO FILL AFTER.
1801          ;*
1802          ;*CALL:
1803          ;*1) USING A TRAP INSTRUCTION
1804          ;*      TYPE      ,MESADR          ;;MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
1805          ;*OR
1806          ;*      TYPE
1807          ;*      MESADR
1808          ;*
1809
1810 004414 105737 001257   $TYPE: TSTB     $TPFLG          ;;IS THERE A TERMINAL?
1811 004420 100002          BPL      1$          ;;BR IF YES
1812 004422 000000          HALT                    ;;HALT HERE IF NO TERMINAL
1813 004424 000430          BR      3$          ;;LEAVE
1814 004426 010046   1$:  MOV      RO,-(SP)          ;;SAVE RO
1815 004430 017600 000002  MOV      @2(SP),RO      ;;GET ADDRESS OF ASCIZ STRING

```

```

1816 004434 122737 000001 001336      CMPB      #APTENV,$ENV      ;;RUNNING IN APT MODE
1817 004442 001011                      BNE       62$      ;;NO,GO CHECK FOR APT CONSOLE
1818 004444 132737 000100 001337      BITB     #APTSPOOL,$ENVM  ;;SPOOL MESSAGE TO APT
1819 004452 001405                      BEQ       62$      ;;NO,GO CHECK FOR CONSOLE
1820 004454 010037 004464                      MOV      RO,61$    ;;SETUP MESSAGE ADDRESS FOR APT
1821 004460 004737 004704                      JSR      PC,$ATY3  ;;SPOOL MESSAGE TO APT
1822 004464 000000                      .WORD    0         ;;MESSAGE ADDRESS
1823 004466 132737 000040 001337      61$:     BITB     #APTCSUP,$ENVM  ;;APT CONSOLE SUPPRESSED
1824 004474 001003                      62$:     BNE       60$      ;;YES,SKIP TYPE OUT
1825 004476 112046                      2$:     MOVVB   (RO)+,-(SP)  ;;PUSH CHARACTER TO BE TYPED ONTO STACK
1826 004500 001005                      BNE      4$       ;;BR IF IT ISN'T THE TERMINATOR
1827 004502 005726                      TST     (SP)+     ;;IF TERMINATOR POP IT OFF THE STACK
1828 004504 012600                      60$:     MOV      (SP)+,RO  ;;RESTORE RO
1829 004506 062716 000002                      3$:     ADD      #2,(SP)   ;;ADJUST RETURN PC
1830 004512 000002                      RTI                      ;;RETURN
1831 004514 122716 000011                      4$:     CMPB     #HT,(SP)   ;;BRANCH IF <HT>
1832 004520 001430                      BEQ      8$       ;;
1833 004522 122716 000200                      CMPB     #CRLF,(SP)  ;;BRANCH IF NOT <CRLF>
1834 004526 001006                      BNE      5$       ;;
1835 004530 005726                      TST     (SP)+     ;;POP <CR><LF> EQUIV
1836 004532 104401                      TYPE    ;;TYPE A CR AND LF
1837 004534 001313                      $CRLF
1838 004536 105037 004672                      CLRB    $CHARCNT  ;;CLEAR CHARACTER COUNT
1839 004542 000755                      BR      2$       ;;GET NEXT CHARACTER
1840 004544 004737 004626                      5$:     JSR      PC,$TYPEC  ;;GO TYPE THIS CHARACTER
1841 004550 123726 001256                      6$:     CMPB     $FILLC,(SP)+  ;;IS IT TIME FOR FILLER CHARS.?
1842 004554 001350                      BNE      2$       ;;IF NO GO GET NEXT CHAR.
1843 004556 013746 001254                      MOV      $NULL,-(SP)  ;;GET # OF FILLER CHARS. NEEDED
1844                                ;;AND THE NULL CHAR.
1845 004562 105366 000001                      7$:     DECB    1(SP)     ;;DOES A NULL NEED TO BE TYPED?
1846 004566 002770                      BLT     6$       ;;BR IF NO--GO POP THE NULL OFF OF STACK
1847 004570 004737 004626                      JSR      PC,$TYPEC  ;;GO TYPE A NULL
1848 004574 105337 004672                      DECB    $CHARCNT  ;;DO NOT COUNT AS A COUNT
1849 004600 000770                      BR      7$       ;;LOOP
1850
1851                                ;HORIZONTAL TAB PROCESSOR
1852
1853 004602 112716 000040                      8$:     MOVVB   #' ,(SP)   ;;REPLACE TAB WITH SPACE
1854 004606 004737 004626                      9$:     JSR      PC,$TYPEC  ;;TYPE A SPACE
1855 004612 132737 000007 004672      BITB     #7,$CHARCNT  ;;BRANCH IF NOT AT
1856 004620 001372                      BNE     9$       ;;TAB STOP
1857 004622 005726                      TST     (SP)+     ;;POP SPACE OFF STACK
1858 004624 000724                      BR      2$       ;;GET NEXT CHARACTER
1859 004626 105777 174416                      $TYPEC: TSTB    @STPS    ;;WAIT UNTIL PRINTER IS READY
1860 004632 100375                      BPL     $TYPEC
1861 004634 116677 000002 174410      MOVVB   2(SP),@STPB  ;;LOAD CHAR TO BE TYPED INTO DATA REG.
1862 004642 122766 000015 000002      CMPB     #CR,2(SP)  ;;IS CHARACTER A CARRIAGE RETURN?
1863 004650 001003                      BNE     1$       ;;BRANCH IF NO
1864 004652 105037 004672                      CLRB    $CHARCNT  ;;YES--CLEAR CHARACTER COUNT
1865 004656 000406                      BR      $TYPEX  ;;EXIT
1866 004660 122766 000012 000002      1$:     CMPB     #LF,2(SP)  ;;IS CHARACTER A LINE FEED?
1867 004666 001402                      BEQ     $TYPEX  ;;BRANCH IF YES
1868 004670 105227                      INCB    (PC)+     ;;COUNT THE CHARACTER
1869 004672 000000                      $CHARCNT: .WORD    0  ;;CHARACTER COUNT STORAGE
1870 004674 000207                      $TYPEX: RTS      PC
1871

```



```

1872 .SBTTL APT COMMUNICATIONS ROUTINE
1873
1874 *****
1875 004676 112737 000001 005142 $ATY1: MOVB #1,$FFLG ;;TO REPORT FATAL ERROR
1876 004704 112737 000001 005140 $ATY3: MOVB #1,$MFLG ;;TO TYPE A MESSAGE
1877 004712 000403 BR SATYC
1878 004714 112737 000001 005142 $ATY4: MOVB #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
1879 004722 SATYC:
1880 004722 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
1881 004724 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
1882 004726 105737 005140 TSTB $MFLG ;;SHOULD TYPE A MESSAGE?
1883 004732 001450 BEQ 5$ ;;IF NOT: BR
1884 004734 122737 000001 001336 CMPB #APTENV,$ENV ;;OPERATING UNDER APT?
1885 004742 001031 BNE 3$ ;;IF NOT: BR
1886 004744 132737 000100 001337 BITB #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
1887 004752 001425 BEQ 3$ ;;IF NOT: BR
1888 004754 017600 000004 MOV @4(SP),R0 ;;GET MESSAGE ADDR.
1889 004760 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
1890 004766 005737 001316 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
1891 004772 001375 BNE 1$ ;;IF NOT: WAIT
1892 004774 010037 001332 MOV R0,$MSGAD ;;PUT ADDR IN MAILBOX
1893 005000 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
1894 005002 001376 BNE 2$
1895 005004 163700 001332 SUB $MSGAD,R0 ;;SUB START OF MESSAGE
1896 005010 006200 ASR R0 ;;GET MESSAGE LGTH IN WORDS
1897 005012 010037 001334 MOV R0,$MSGLGTT ;;PUT LENGTH IN MAILBOX
1898 005016 012737 000004 001316 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
1899 005024 000413 BR 5$
1900 005026 017637 000004 005052 3$: MOV @4(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
1901 005034 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
1902 005042 013746 177776 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
1903 005046 004737 004414 JSR PC,$TYPE ;;CALL TYPE MACRO
1904 005052 000000 4$: .WORD 0
1905 005054 5$:
1906 005054 105737 005142 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
1907 005060 001416 BEQ 12$ ;;IF NOT: BR
1908 005062 005737 001336 TST $ENV ;;RUNNING UNDER APT?
1909 005066 001413 BEQ 12$ ;;IF NOT: BR
1910 005070 005737 001316 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
1911 005074 001375 BNE 11$ ;;IF NOT: WAIT
1912 005076 017637 000004 001320 MOV @4(SP),$FATAL ;;GET ERROR #
1913 005104 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
1914 005112 005237 001316 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
1915 005116 105037 005142 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
1916 005122 105037 005141 CLRB $LFLG ;;CLEAR LOG FLAG
1917 005126 105037 005140 CLRB $MFLG ;;CLEAR MESSAGE FLAG
1918 005132 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
1919 005134 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
1920 005136 000207 RTS PC ;;RETURN
1921 005140 000 $MFLG: .BYTE 0 ;;MESSG. FLAG
1922 005141 000 $LFLG: .BYTE 0 ;;LOG FLAG
1923 005142 000 $FFLG: .BYTE 0 ;;FATAL FLAG
1924 005144 .EVEN
1925 000200 APTSIZE=200
1926 000001 APTENV=001
1927 000100 APTSPOOL=100

```

1928 000040

APTC SUP=040
:-----

1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983

005144 011646
005146 016666 000004 000002
005154 105777 174064
005160 100375
005162 117766 174060 000004
005170 042766 177600 000004
005176 026627 000004 000023
005204 001013
005206 105777 174032
005212 100375
005214 117746 174026
005220 042716 177600
005224 022627 000021
005230 001366
005232 000750
005234 026627 000004 000140
005242 002407
005244 026627 000004 000175
005252 003003
005254 042766 000040 000004
005262 000002

010346
005046
012703 005520
022703 005527
101456
104402
112613
122713 000177
001022

.SBTTL TTY INPUT ROUTINE

::*****

.ENABL LSB

.DSABL LSB

::*****

*THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY

*CALL:

* RDCHR RETURN HERE :: INPUT A SINGLE CHARACTER FROM THE TTY
: CHARACTER IS ON THE STACK
: WITH PARITY BIT STRIPPED OFF

\$RDCHR: MOV (SP),-(SP) :: PUSH DOWN THE PC
MOV 4(SP),2(SP) :: SAVE THE PS
1\$: TSTB @STKS :: WAIT FOR
BPL 1\$:: A CHARACTER
MOVB @STKB,4(SP) :: READ THE TTY
BIC #^C<177>,4(SP) :: GET RID OF JUNK IF ANY
CMP 4(SP),#23 :: IS IT A CONTROL-S?
BNE 3\$:: BRANCH IF NO
2\$: TSTB @STKS :: WAIT FOR A CHARACTER
BPL 2\$:: LOOP UNTIL ITS THERE
MOVB @STKB,-(SP) :: GET CHARACTER
BIC #^C177,(SP) :: MAKE IT 7-BIT ASCII
CMP (SP)+,#21 :: IS IT A CONTROL-Q?
BNE 2\$:: IF NOT DISCARD IT
1\$ BR :: YES, RESUME
3\$: CMP 4(SP),#140 :: IS IT UPPER CASE?
BLT 4\$:: BRANCH IF YES
CMP 4(SP),#175 :: IS IT A SPECIAL CHAR?
BGT 4\$:: BRANCH IF YES
4\$: BIC #40,4(SP) :: MAKE IT UPPER CASE
RTI :: GO BACK TO USER

::*****

*THIS ROUTINE WILL INPUT A STRING FROM THE TTY

*CALL:

* RDLIN RETURN HERE :: INPUT A STRING FROM THE TTY
: ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
: TERMINATOR WILL BE A BYTE OF ALL 0'S

\$RDLIN: MOV R3,-(SP) :: SAVE R3
CLR -(SP) :: CLEAR THE RUBOUT KEY
1\$: MOV #TTYIN,R3 :: GET ADDRESS
2\$: CMP #TTYIN+7,R3 :: BUFFER FULL?
BLOS 4\$:: BR IF YES
RDCHR :: GO READ ONE CHARACTER FROM THE TTY
MOVB (SP)+,(R3) :: GET CHARACTER
10\$: CMPB #177,(R3) :: IS IT A RUBOUT
5\$ BNE 5\$:: BR IF NO

```

1984 005314 005716          TST      (SP)          ;; IS THIS THE FIRST RUBOUT?
1985 005316 001007          BNE      6$           ;; BR IF NO
1986 005320 112737 000134 005516  MOVB     #' \ ,9$     ;; TYPE A BACK SLASH
1987 005326 104401 005516          TYPE     ,9$
1988 005332 012716 177777          MOV      #-1,(SP)     ;; SET THE RUBOUT KEY
1989 005336 005303          6$: DEC      R3         ;; BACKUP BY ONE
1990 005340 020327 005520          CMP      R3,#$TTYIN  ;; STACK EMPTY?
1991 005344 103434          BLO      4$           ;; BR IF YES
1992 005346 111337 005516          MOVB     (R3),9$     ;; SETUP TO TYPEOUT THE DELETED CHAR.
1993 005352 104401 005516          TYPE     ,9$
1994 005356 000746          BR       2$           ;; GO TYPE
1995 005360 005716          5$: TST      (SP)     ;; GO READ ANOTHER CHAR.
1996 005362 001406          BEQ      7$           ;; RUBOUT KEY SET?
1997 005364 112737 000134 005516  MOVB     #' \ ,9$     ;; BR IF NO
1998 005372 104401 005516          TYPE     ,9$         ;; TYPE A BACK SLASH
1999 005376 005016          CLR      (SP)        ;; CLEAR THE RUBOUT KEY
2000 005400 122713 000025          7$: CMPB     #25,(R3)  ;; IS CHARACTER A CTRL U?
2001 005404 001003          BNE      8$           ;; BR IF NO
2002 005406 104401 005527          TYPE     ,SCNTLU     ;; TYPE A CONTROL 'U'
2003 005412 000726          BR       1$           ;; GO START OVER
2004 005414 122713 000022          8$: CMPB     #22,(R3)  ;; IS CHARACTER A 'R'?
2005 005420 001011          BNE      3$           ;; BRANCH IF NO
2006 005422 105013          CLRB     (R3)        ;; CLEAR THE CHARACTER
2007 005424 104401 001313          TYPE     ,SCRLF     ;; TYPE A 'CR' & 'LF'
2008 005430 104401 005520          TYPE     ,TTYIN     ;; TYPE THE INPUT STRING
2009 005434 000717          BR       2$           ;; GO PICKUP ANOTHER CHACTER
2010 005436 104401 001312          4$: TYPE     ,SQUES   ;; TYPE A '?'
2011 005442 000712          BR       1$           ;; CLEAR THE BUFFER AND LOOP
2012 005444 111337 005516          3$: MOVB     (R3),9$   ;; ECHO THE CHARACTER
2013 005450 104401 005516          TYPE     ,9$
2014 005454 122723 000015          CMPB     #15,(R3)+   ;; CHECK FOR RETURN
2015 005460 001305          BNE      2$           ;; LOOP IF NOT RETURN
2016 005462 105063 177777          CLRB     -1(R3)     ;; CLEAR RETURN (THE 15)
2017 005466 104401 001314          TYPE     ,LF        ;; TYPE A LINE FEED
2018 005472 005726          TST      (SP)+      ;; CLEAN RUBOUT KEY FROM THE STACK
2019 005474 012603          MOV      (SP)+,R3    ;; RESTORE R3
2020 005476 011646          MOV      (SP),-(SP)  ;; ADJUST THE STACK AND PUT ADDRESS OF THE
2021 005500 016666 000004 000002  MOV      4(SP),2(SP)  ;; FIRST ASCII CHARACTER ON IT
2022 005506 012766 005520 000004  MOV      #$TTYIN,4(SP)
2023 005514 000002          RTI
2024 005516 000          9$: .BYTE    0         ;; RETURN
2025 005517 000          .BYTE    0         ;; STORAGE FOR ASCII CHAR. TO TYPE
2026 005520 000007          $TTYIN: .BLKB    7   ;; TERMINATOR
2027 005527 136 006525 000012  $CNTLU: .ASCIZ  /^U/<15><12>  ;; RESERVE 7 BYTES FOR TTY INPUT
2028 005534 043536 005015 000          $CNTLG: .ASCIZ  /^G/<15><12>  ;; CONTROL 'U'
2029 005541 015 051412 051127  $MSWR:  .ASCIZ  <15><12>/SWR = /  ;; CONTROL 'G'
2030 005546 036440 000040          $MNEW:  .ASCIZ  / NEW = /
2031 005552 020040 042516 020127
2032 005560 020075 000
2033          .EVEN
2034          .SBTTL  READ AN OCTAL NUMBER FROM THE TTY
2035
2036          ;; *****
2037          ;; *THIS ROUTINE WILL READ AN OCTAL (ASCII) NUMBER FROM THE TTY AND
2038          ;; *CHANGE IT TO BINARY.
2039          ;; *THE INPUT CHARACTERS WILL BE CHECKED TO INSURED THEY ARE LEGAL

```

```

2040 ;*OCTAL DIGITS. IF AN ILLEGAL CHARACTER IS READ A "?" WILL BE TYPED
2041 ;*FOLLOWED BY A CARRIAGE RETURN-LINE FEED. THE COMPLETE NUMBER MUST
2042 ;*THEN BE RETYPED. THE INPUT IS TERMINATED BY TYPING A CARRIAGE RETURN.
2043 ;*CALL:
2044 ;*      RDOCT          ;;READ AN OCTAL NUMBER
2045 ;*      RETURN HERE   ;;LOW ORDER BITS ARE ON TOP OF THE STACK
2046 ;*                  ;;HIGH ORDER BITS ARE IN $HIOCT
2047
2048 005564 011646          $RDOCT: MOV      (SP),-(SP)      ;;PROVIDE SPACE FOR THE
2049 005566 016666 000004 000002 MOV      4(SP),2(SP)  ;;INPUT NUMBER
2050 005574 010046          MOV      RO,-(SP)      ;;PUSH R0 ON STACK
2051 005576 010146          MOV      R1,-(SP)      ;;PUSH R1 ON STACK
2052 005600 010246          MOV      R2,-(SP)      ;;PUSH R2 ON STACK
2053 005602 104403          1$:  RDLIN          ;;READ AN ASCII LINE
2054 005604 012600          MOV      (SP)+,R0      ;;GET ADDRESS OF 1ST CHARACTER
2055 005606 010037 005712 MOV      RO,5$      ;;AND SAVE IT
2056 005612 005001          CLR      R1          ;;CLEAR DATA WORD
2057 005614 005002          CLR      R2
2058 005616 112046          2$:  MOVB      (RO)+,-(SP)  ;;PICKUP THIS CHARACTER
2059 005620 001420          BEQ      3$          ;;IF ZERO GET OUT
2060 005622 122716 000060 CMPB      #'0,(SP)  ;;MAKE SURE THIS CHARACTER
2061 005626 003026          BGT      4$          ;;IS AN OCTAL DIGIT
2062 005630 122716 000067 CMPB      #'7,(SP)
2063 005634 002423          BLT      4$
2064 005636 006301          ASL      R1          ;;*2
2065 005640 006102          ROL      R2
2066 005642 006301          ASL      R1          ;;*4
2067 005644 006102          ROL      R2
2068 005646 006301          ASL      R1          ;;*8
2069 005650 006102          ROL      R2
2070 005652 042716 177770 BIC      #'C7,(SP)  ;;STRIP THE ASCII JUNK
2071 005656 062601          ADD      (SP)+,R1  ;;ADD IN THIS DIGIT
2072 005660 000756          BR       2$          ;;LOOP
2073 005662 005726          3$:  TST      (SP)+      ;;CLEAN TERMINATOR FROM STACK
2074 005664 010166 000012 MOV      R1,12(SP)  ;;SAVE THE RESULT
2075 005670 010237 005722 MOV      R2,$HIOCT
2076 005674 012602          MOV      (SP)+,R2  ;;POP STACK INTO R2
2077 005676 012601          MOV      (SP)+,R1  ;;POP STACK INTO R1
2078 005700 012600          MOV      (SP)+,R0  ;;POP STACK INTO R0
2079 005702 000002          RTI          ;;RETURN
2080 005704 005726          4$:  TST      (SP)+      ;;CLEAN PARTIAL FROM STACK
2081 005706 105010          CLRB      (RO)    ;;SET A TERMINATOR
2082 005710 104401          TYPE          ;;TYPE UP THRU THE BAD CHAR.
2083 005712 000000          5$:  .WORD      0
2084 005714 104401 001312 TYPE      ,$QUES  ;;'"?' 'CR' & 'LF'
2085 005720 000730          BR       1$          ;;TRY AGAIN
2086 005722 000000          $HIOCT: .WORD    0  ;;HIGH ORDER BITS GO HERE
2087
2088 ;
2089 ;-----
2090 ;
2091 005724 010546          $INPUT: MOV     R5,-(SP)  ;;SAVE REGISTER R5.
2092 005726 016605 000002 MOV     2(SP),R5      ;;GET FIRST PARAMETER ADDRESS.
2093 005732 012537 005770 MOV     (R5)+,WHAT   ;;GET MESSAGE ADDRESS.
2094 005736 012537 006050 MOV     (R5)+,LOLIM  ;;GET LOW LIMIT FOR THE #
2095 005742 012537 006052 MOV     (R5)+,HILIM  ;;GET HIGH LIMIT FOR THE #
  
```

```

2096 005746 012537 006054      MOV      (R5)+,WHERE      ; GET ADDRESS OF INBUFFER
2097 005752 112537 006056      MOVB     (R5)+,LOBITS     ; GET LOWMASK BITS.
2098 005756 112537 006057      MOVB     (R5)+,ADRCNT     ; GET # OF #'S TO BE GENERATED.
2099 005762 010566 000002      MOV      R5,2(SP)        ; SAVE THE RETURN ADDRESS.
2100 005766 104401                INLP1:  TYPE              ; TYPE THE MESSAGE.
2101 005770 000000                WHAT:   .WORD            0
2102 005772 104404                RDOCT   RDOCT            ; READ OCTAL # FROM KEYBOARD.
2103 005774 021637 006052      CMP      (SP),HILIM      ; IS IT IN HIGH LIMIT?
2104 006000 003003                BGT     2$               ; BRANCH IF NO.
2105 006002 021637 006050      CMP      (SP),LOLIM      ; IS IT MORE THAN LOW LIMIT.
2106 006006 002005                BGE     3$               ; BRANCH IF YES.
2107 006010 104401 001312      2$:     TYPE             , $QUES ; TYPE " ? "
2108 006014 104401 001313      TYPE             , $CRLF ; TYPE <CR>,<LF>
2109 006020 000762                BR      INLP1
2110 006022 013705 006054      3$:     MOV      WHERE,R5 ; GET BUFFER ADDRESS.
2111 006026 011625      4$:     MOV      (SP),(R5)+ ; SAVE THE # IN RIGHT PLACE.
2112 006030 062716 000002      ADD     #2,(SP)         ; NEXT SEQUENTIAL NUMBER.
2113 006034 105337 006057      DECB    ADRCNT          ; COUNT BY 1.
2114 006040 001372                BNE     4$              ; BRANCH IF NOT DONE.
2115 006042 005726                TST    (SP)+            ; POP THE STACK POINTER.
2116 006044 012605                MOV    (SP)+,R5        ; POP THE REG.5
2117 006046 000002                RTI
2118 006050 000000      LOLIM:  .WORD            0
2119 006052 000000      HILIM:  .WORD            0
2120 006054 000000      WHERE:  .WORD            0
2121 006056      000      LOBITS: .BYTE            0
2122 006057      000      ADRCNT: .BYTE            0
2123
2124                ; ADVANCE TO NEXT TEST HANDLER
2125                ;-----
2126                ;
2127 006060 013716 001442      .ADVANCE: MOV     NEXT,(SP) ; CRUNCH STACK WITH ADDRESS OF SCOPE CALL
2128 006064 005037 001444      CLR     LOCK            ; RESET TIGHT LOOP ADDRESS
2129 006070 000002                RTI                    ; CHECK TO SEE IF OLD TEST GETS REPEATED
2130
2131                ;SAVE PC OF TEST THAT FAILED AND R0-R5
2132                ;-----
2133
2134 006072 016637 000004 001460 .SAV05: MOV     4(SP),SAVPC ;SAVE R7 (PC)
2135
2136                ;SAVE R0-R5
2137
2138 006100 010537 001274      SV05:   MOV     R5,$REG5 ;SAVE R5
2139 006104 010437 001272      MOV     R4,$REG4 ;SAVE R4
2140 006110 010337 001270      MOV     R3,$REG3 ;SAVE R3
2141 006114 010237 001266      MOV     R2,$REG2 ;SAVE R2
2142 006120 010137 001264      MOV     R1,$REG1 ;SAVE R1
2143 006124 010037 001262      MOV     R0,$REG0 ;SAVE R0
2144 006130 000002                RTI                    ;LEAVE.
2145
2146                ;RESTORE R0-R5
2147
2148 006132 013700 001262      .RES05: MOV     $REG0,R0 ;RESTORE R0
2149 006136 013701 001264      MOV     $REG1,R1 ;RESTORE R1
2150 006142 013702 001266      MOV     $REG2,R2 ;RESTORE R2
2151 006146 013703 001270      MOV     $REG3,R3 ;RESTORE R3

```

2152	006152	013704	001272		MOV	\$REG4,R4	;RESTORE R4
2153	006156	013705	001274		MOV	\$REG5,R5	;RESTORE R5
2154	006162	000002			RTI		;LEAVE
2155							
2156					:	;CONVERT OCTAL NUMBER TO ASCII AND OUTPUT TO TELEPRINTER	
2157					:	-----	
2158					:		
2159	006164	104401	001313		.CONVR:	TYPE	,\$CRLF
2160	006170	010046			.CNVRT:	MOV	RO,-(SP)
2161	006172	010146				MOV	R1,-(SP)
2162	006174	010346				MOV	R3,-(SP)
2163	006176	010446				MOV	R4,-(SP)
2164	006200	010546				MOV	R5,-(SP)
2165	006202	017601	000012			MOV	@12(SP),R1
2166	006206	062766	000002	000012		ADD	#2,12(SP)
2167	006214	012137	006406			MOV	(R1)+,WRDCNT
2168	006220	112137	006410		1\$:	MOVB	(R1)+,CHRCNT
2169	006224	112137	006411			MOVB	(R1)+,SPACNT
2170	006230	013137	006412			MOV	@(R1)+,BINWRD
2171	006234	122737	000003	006410		CMPB	#3,CHRCNT
2172	006242	001003				BNE	2\$
2173	006244	042737	177400	006412		BIC	#177400,BINWRD
2174	006252	013704	006412		2\$:	MOV	BINWRD,R4
2175	006256	113705	006410			MOVB	CHRCNT,R5
2176	006262	012700	011234			MOV	#TEMP,R0
2177	006266	010403			3\$:	MOV	R4,R3
2178	006270	042703	177770			BIC	#177770,R3
2179	006274	062703	000060			ADD	#060,R3
2180	006300	110320				MOVB	R3,(R0)+
2181	006302	000241				CLC	
2182	006304	006004				ROR	R4
2183	006306	000241				CLC	
2184	006310	006004				ROR	R4
2185	006312	000241				CLC	
2186	006314	006004				ROR	R4
2187	006316	005305				DEC	R5
2188	006320	001362				BNE	3\$
2189	006322	012703	011276			MOV	#MDATA,R3
2190	006326	114023			4\$:	MOVB	-(R0),(R3)+
2191	006330	105337	006410			DECB	CHRCNT
2192	006334	001374				BNE	4\$
2193	006336	105737	006411			TSTB	SPACNT
2194	006342	001405				BEQ	6\$
2195	006344	112723	000040		5\$:	MOVB	#040,(R3)+
2196	006350	105337	006411			DECB	SPACNT
2197	006354	001373				BNE	5\$
2198	006356	105013			6\$:	CLRB	(R3)
2199	006360	104401	011276			TYPE	,MDATA
2200	006364	005337	006406			DEC	WRDCNT
2201	006370	001313				BNE	1\$
2202	006372	012605				MOV	(SP)+,R5
2203	006374	012604				MOV	(SP)+,R4
2204	006376	012603				MOV	(SP)+,R3
2205	006400	012601				MOV	(SP)+,R1
2206	006402	012600				MOV	(SP)+,R0
2207	006404	000002				RTI	

2208 006406 000000
 2209 006410 000000
 2210 006411 000000
 2211 006412 000000

WRDCNT: 0
 CHRCNT: 0
 SPACNT=CHRCNT+1
 BINWRD: 0

2212
 2213
 2214
 2215
 2216
 2217
 2218

;TRAP DISPATCH SERVICE
 ;ARGUMENT OF TRAP IS EXTRACTED
 ;AND USED AS OFFSET TO OBTAIN POINTER
 ;TO SELECTED SUBROUTINE

2219
 2220
 2221

.SBTTL TRAP DECODER

2222
 2223
 2224
 2225

;;*****
 ;*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE "TRAP" INSTRUCTION
 ;*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
 ;*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
 ;*GO TO THAT ROUTINE.

2226
 2227 006414 010046
 2228 006416 016600 000002
 2229 006422 005740
 2230 006424 111000
 2231 006426 006300
 2232 006430 016000 006450
 2233 006434 000200

\$TRAP: MOV RO,-(SP) ;;SAVE RO
 MOV 2(SP),RO ;;GET TRAP ADDRESS
 TST -(RO) ;;BACKUP BY 2
 MOVB (RO),RO ;;GET RIGHT BYTE OF TRAP
 ASL RO ;;POSITION FOR INDEXING
 MOV \$TRPAD(RO),RO ;;INDEX TO TABLE
 RTS RO ;;GO TO ROUTINE

2234
 2235
 2236

;;THIS IS USE TO HANDLE THE "GETPRI" MACRO

2237
 2238 006436 011646
 2239 006440 016666 000004 000002
 2240 006446 000002

\$TRAP2: MOV (SP),-(SP) ;;MOVE THE PC DOWN
 MOV 4(SP),2(SP) ;;MOVE THE PSW DOWN
 RTI ;;RESTORE THE PSW

2241
 2242
 2243

.SBTTL TRAP TABLE

2244
 2245
 2246

;*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
 ;*BY THE "TRAP" INSTRUCTION.

2247
 2248
 2249 006450 006436
 2250 006452 004414

; ROUTINE
 ;-----
 \$TRPAD: .WORD \$TRAP2
 \$TYPE ;;CALL=TYPE TRAP+1(104401) TTY TYPEOUT ROUTINE

2251
 2252
 2253 006454 005144
 2254 006456 005264
 2255 006460 005564
 2256 006462 004364
 2257 006464 006072
 2258 006466 006132
 2259 006470 007362
 2260 006472 007332
 2261 006474 007400
 2262 006476 007446
 2263 006500 007512

\$RDCHR ;;CALL=RDCHR TRAP+2(104402) TTY TYPEIN CHARACTER ROUTINE
 \$RDLIN ;;CALL=RDLIN TRAP+3(104403) TTY TYPEIN STRING ROUTINE
 \$RDOCT ;;CALL=RDOCT TRAP+4(104404) READ AN OCTAL NUMBER FROM TTY
 .SCOPI ;;CALL=SCOPI TRAP+5(104405) CALL TO LOOP ON CURRENT DATA HANDLER
 .SAVOS ;;CALL=SAVOS TRAP+6(104406) CALL TO REGISTER SAVE ROUTINE
 .RESOS ;;CALL=RESOS TRAP+7(104407) CALL TO REGISTER RESTORE ROUTINE
 .MSTCLR ;;CALL=MSTCLR TRAP+10(104410) CALL TO ISSUE A MASTER CLEAR
 .DELAY ;;CALL=DELAY TRAP+11(104411) CALL TO DELAY
 .ROMCLK ;;CALL=ROMCLK TRAP+12(104412) CALL TO CLOCK ROM ONCE
 .DATACLK ;;CALL=DATACLK TRAP+13(104413) CALL TO CLOCK DATA
 .TIMER ;;CALL=TIMER TRAP+14(104414) CALL TO DELAY A CLOCK TICK

```

2264 006502 005724 $INPUT ;;CALL=INPUT TRAP+15(104415) CALL TO OCTAL # INPUT ROUTINE
2265 006504 006164 .CONVRT ;;CALL=CONVRT TRAP+16(104416) CALL TO .....
2266 006506 006170 .CNVRT ;;CALL=CNVRT TRAP+17(104417) CALL TO .....
2267 006510 006060 .ADVANCE ;;CALL=ADVANCE TRAP+20(104420) CALL TO ADVANCE TO NEXT TEST
2268
2269
2270
2271
2272
2273
2274 006512 004737 011340 $ERROR: JSR PC,CKSWR ;CHECK FOR SOFT SWR
2275 006516 032777 010000 172514 BIT #SW12,@SWR ;BELL ON ERROR?
2276 006524 001406 BEQ XBX ;BR IF NO BELL
2277 006526 105777 172516 TSTB @STPS ;TTY READY.
2278 006532 100003 BPL XBX ;DON'T WAIT IF TTY NOT READY.
2279 006534 112777 000207 172510 MOVB #207,@STPB ;PUSH A BELL AT THE TTY.
2280 006542 032777 020000 172470 XBX: BIT #SW13,@SWR ;DELETE ERROR PRINT OUT?
2281 006550 001107 BNE HALTS ;BR IF NO PRINT OUT WANTED.
2282 006552 021637 001216 CMP (SP),$ERRPC ;WAS THIS ERROR FOUND LAST TIME?
2283 006556 001404 BEQ 1$ ;BR IF YES
2284 006560 011637 001216 MOV (SP),$ERRPC ;RECORD BEING HERE
2285 006564 105037 001203 CLRB $ERFLG ;PREPARE HEADER
2286 006570 104406 1$: SAVO5 ;SAVE ALL PROC REGISTERS
2287 006572 011605 MOV (SP),R5 ;GET THE PC OF ERROR
2288 006574 162705 000002 SUB #2,R5 ;GET ADDRESS OF TRAP CALL
2289 006600 011504 MOV (R5),R4 ;GET ERROR INSTRUCTION
2290 006602 110437 001214 MOVB R4,$ITEMB ; COPY ERROR # FOR APT HANDLING
2291 006606 006304 ASL R4 ;MULT BY TWO
2292 006610 061504 ADD (R5),R4 ;DOUBLE IT
2293 006612 006304 ASL R4 ;MULT AGAIN
2294 006614 042704 177001 BIC #177001,R4 ;CLEAR JUNK
2295 006620 062704 001512 ADD #$ERRTB,R4 ;GET POINTER
2296 006624 012437 006740 MOV (R4)+,$ERRMSG ;GET ERROR MESSAGE
2297 006630 012437 006752 MOV (R4)+,$DATAHD ;GET DATA HEADRER
2298 006634 011437 006764 MOV (R4),$DATABP ;GET DATA TABLE
2299 006640 105737 001203 TSTB $ERFLG ;TYPE HEADREER
2300 006644 001403 BEQ TYPMSG ;BR IF YES
2301 006646 005737 006764 TST DATABP ;DOES DATA TABLE EXIST?
2302 006652 001040 BNE TYPDAT ;BR IF YES.
2303 006654 104401 001313 TYPMSG: TYPE ,$CRLF
2304 006660 104401 001313 TYPE ,$CRLF
2305 006664 005737 001444 TST LOCK
2306 006670 001402 BEQ 1$
2307 006672 104401 010016 TYPE ,MASTEK
2308 006676 104401 010004 1$: TYPE ,MTSTN
2309 006702 104417 007120 CNVRT ,XTSTN ;SHOW IT
2310 006706 104401 010073 TYPE ,MERRPC ;TYPE PC.
2311 006712 104417 007112 CNVRT ,ERTABO ;SHOW IT
2312 006716 104401 001313 TYPE ,$CRLF ;GIVE A CR/LF
2313 006722 112737 177777 001203 MOVB #-1,$ERFLG ;NO MORE HEADER UNLESS NO DATA TABLE.
2314 006730 005737 006740 TST ERRMSG ;IS THERE AN ERROR MESSAGE?
2315 006734 001402 BEQ WRKO.FM ;BR IF NO.
2316 006736 104401 TYPE ;TYPE
2317 006740 000000 ERRMSG: 0 ; ERROR MESSAGE
2318 006742 WRKO.FM: ;
2319 006742 005737 006752 TST DATAHD ;DATA HEADER?
    
```



```

2320 006746 001402          BEQ      TYPDAT      ;BR IF NO
2321 006750 104401          TYPE          ;TYPE
2322 006752 000000          DATAHD: 0    ; DATA HEADER
2323 006754 005737 006764  TYPDAT: TST   DATABP   ;DATA TABLE?
2324 006760 001402          BEQ      RESREG     ;BR IF NO.
2325 006762 104416          CONVRT        ;SHOW
2326 006764 000000          DATABP: C     ; DATA TABLE
2327 006766 104407          RESREG: RESOS ;RESTORE PROC REGISTERS
2328 006770 122737 000001 001336 HALTS: CMPB   #APTENV,$ENV ; IS APT RUNNING ?
2329 006776 001007          BNE      3$      ; SKIP APT CALL IF NOT.
2330 007000 113737 001214 007012 MOVB     $ITEMB,6$ ; COPY ERROR #.
2331 007006 004737 004714 JSR      PC,$ATY4 ; CALL APT SERVICES.
2332 007012 000000          6$: .WORD    0    ; ERROR # GOES HERE.
2333 007014 000777          9$: BR       9$    ; LOCK HERE.
2334 007016 022737 004070 000042 3$: CMP     #$ENDAD,@#42 ;IF ACT-11 AUTOMATIC MODE, HALT!!
2335 007024 001403          BEQ      1$      ;
2336 007026 005777 172206 TST     @SWR      ;HALT ON ERROR?
2337 007032 100005          BPL     EXITER   ;BR IF NO HALT ON ERROR
2338 007034 010046          1$: PUSHRO ;SAVE RO
2339 007036 016600 000002 MOV     2(SP),RO ;SHOW ERROR PC IN DATA LIGHTS
2340 007042 000000          HALT        ;HALT
2341 007044 012600          POPRO       ;GET RO
2342 007046 005237 001212 EXITER: INC   $ERTTL  ;UPDATE ERROR COUNT
2343 007052 032777 000400 172160 BIT     #SW0B,@SWR  ;GOTO TOP OF TEST?
2344 007060 001007          BNE      1$      ;BR IF YES
2345 007062 032777 002000 172150 BIT     #SW10,@SWR ;GOTO NEXT TEST?
2346 007070 001407          BEQ     2$      ;BR IF NO
2347 007072 013737 001442 001206 MOV     NEXT,$LPADR ;SET FOR NEXT TEST
2348 007100 012706 001200 1$: MOV     #STACK,SP ;RESET SP
2349 007104 000177 172076 JMP     @SLPADR   ;GOTO SPECIFIED TEST
2350 007110 000002          2$: RTI       ;$LPADR
2351 007112 000001          ERTABO: 1
2352 007114          006      002 .BYTE   6,2
2353 007116          001460 SAVPC
2354 007120          000001 XTSTN: 1
2355 007122          003      002 .BYTE   3,2
2356 007124          001202 $TSTNM
2357          ;ENTER HERE ON POWER FAILURE
2358          ;-----
2359
2360          .SBTTL POWER DOWN AND UP ROUTINES
2361
2362          ;*****
2363          ;POWER DOWN ROUTINE
2364 007126 012737 007316 000024 $PWRDN: MOV   #$ILLUP,@#PWRVEC ;;SET FOR FAST UP
2365 007134 012737 000340 000026 MOV   #340,@#PWRVEC+2 ;;PRIO:7
2366 007142 010046          MOV   R0,-(SP) ;;PUSH R0 ON STACK
2367 007144 010146          MOV   R1,-(SP) ;;PUSH R1 ON STACK
2368 007146 010246          MOV   R2,-(SP) ;;PUSH R2 ON STACK
2369 007150 010346          MOV   R3,-(SP) ;;PUSH R3 ON STACK
2370 007152 010446          MOV   R4,-(SP) ;;PUSH R4 ON STACK
2371 007154 010546          MOV   R5,-(SP) ;;PUSH R5 ON STACK
2372 007156 017746 172056 MOV   @SWR,-(SP) ;;PUSH @SWR ON STACK
2373 007162 010637 007322 MOV   SP,$SAVR6 ;;SAVE SP
2374 007166 012737 007200 000024 MOV   #PWRUP,@#PWRVEC ;;SET UP VECTOR
2375 007174 000000          HALT

```

```

2376 007176 000776          BR      -2          ;;HANG UP
2377
2378
2379          ;;*****
          ;;POWER UP ROUTINE
2380 007200 012737 007316 000024 $PWRUP: MOV    #SILLUP,@PWRVEC ;;SET FOR FAST DOWN
2381 007206 013706 007322          MOV    $$SAVR6,SP      ;;GET SP
2382 007212 005037 007322          CLR    $$SAVR6          ;;WAIT LOOP FOR THE TTY
2383 007216 005237 007322          1$:  INC    $$SAVR6          ;;WAIT FOR THE INC
2384 007222 001375          BNE    1$              ;;OF WORD
2385 007224 104401 007562          TYPE  ,MPFAIL
2386 007230 104417 007324          CNVRT ,PFTAB
2387 007234 105037 001203          CLRB  $ERFLG          ;CLEAR ERROR FLAG.
2388 007240 005037 001216          CLR  $ERRPC          ; CLEAR LAST ERROR PC
2389 007244 013701 002066          MOV  KMCSR,R1        ; RESTORE DEVICE ADDRESS.
2390 007250 005011          CLR  (R1)           ; CLEAR THE CSR.
2391 007252 104410          MSTCLR
2392 007254 012677 171760          MOV  (SP)+,@SWR     ;;POP STACK INTO @SWR
2393 007260 012605          MOV  (SP)+,R5      ;;POP STACK INTO R5
2394 007262 012604          MOV  (SP)+,R4      ;;POP STACK INTO R4
2395 007264 012603          MOV  (SP)+,R3      ;;POP STACK INTO R3
2396 007266 012602          MOV  (SP)+,R2      ;;POP STACK INTO R2
2397 007270 012601          MOV  (SP)+,R1      ;;POP STACK INTO R1
2398 007272 012600          MOV  (SP)+,R0      ;;POP STACK INTO R0
2399 007274 012737 007126 000024  MOV  #SPWRDN,@PWRVEC ;;SET UP THE POWER DOWN VECTOR
2400 007302 012737 000340 000026  MOV  #340,@PWRVEC+2 ;;PRIO:7
2401 007310 104401          TYPE
2402 007312 007562          $PWRMG: .WORD  MPFAIL ;;REPORT THE POWER FAILURE
2403 007314 000002          RTI
2404 007316 000000          $ILLUP: HALT
2405 007320 000776          BR      -2          ;; THE POWER UP SEQUENCE WAS STARTED
2406 007322 000000          $$SAVR6: 0          ;; BEFORE THE POWER DOWN WAS COMPLETE
2407
2408 007324 000001          PFTAB: 1          ;;PUT THE SP HERE
2409 007326 003 002          .BYTE 3,2
2410 007330 001202          $TSTNM
2411
2412 007332          .DELAY:
2413 007332 012777 000020 172534  MOV  #20,@KMP04
2414 007340 104412          ROMCLK
2415 007342 121111          121111          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
2416 007344          1$:
2417 007344 104412          ROMCLK          ;POKE CLOCK DELAY BIT
2418 007346 121224          121224          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
2419 007350 032777 000020 172516  BIT  #BIT4,@KMP04  ;PORT4 IBUS+11
2420 007356 001772          BEQ  1$           ;IS CLOCK BIT SET?
2421 007360 000002          RTI             ;BR IF NO
2422
2423 007362          .MSTCLR:
2424 007362 152777 000100 172500  BISB #BIT6,@KMCSRH ;SET MASTER CLEAR
2425 007370 142777 000300 172472  BICB #BIT6:BIT7,@KMCSRH ;CLEAR MASTER CLEAR AND RUN
2426 007376 000002          RTI             ;RETURN
2427
2428 007400          .ROMCLK:
2429 007400 152777 000002 172462  BISB #BIT1,@KMCSRH ;SET ROMI
2430 007406 013677 172464          MOV  @(SP)+,@KMP06 ;LOAD INSTRUCTION IN SEL6
2431 007412 062746 000002          ADD  #2,-(SP)     ;ADJUST STACK

```

```

2432 007416 032777 000100 171614 BIT #SW06,@SWR ;HALT IF SW06 =1
2433 007424 001401 BEQ 1$ ;BR IF SW06 =0
2434 007426 000000 HALT ;HALT BEFORE CLOCKING INSTRUCTION
2435 007430 152777 000003 172432 1$: BISE #BIT1!BIT0,@KMC5RH ;CLOCK INSTRUCTION
2436 007436 142777 000007 172424 BICB #BIT2!BIT1!BIT0,@KMC5RH ;CLEAR ROMO, ROMI, STEP
2437 007444 000002 RTI

2438
2439 007446 .DATACLK:
2440 007446 013637 011234 MOV @ (SP)+,TEMP ;PUT TICK COUNT IN TEMP
2441 007452 062746 000002 ADD #2,-(SP) ;ADJUST STACK
2442 007456 152777 000020 172404 1$: BISE #BIT4,@KMC5RH ;SET STEP LU
2443 007464 027777 172376 172374 CMP @KMC5R,@KMC5R ;WASTE TIME
2444 007472 142777 000020 172370 BICB #BIT4,@KMC5RH ;CLEAR STEP LU
2445 007500 005337 011234 DEC TEMP ;DEC TICK COUNT
2446 007504 001364 BNE 1$ ;BR IF NOT DONE
2447 007506 000002 RTI ;RETURN
2448 007510 000001 3$: .BLKW 1

2449
2450 007512 .TIMER:
2451 007512 013637 011234 MOV @ (SP)+,TEMP ;MOVE COUNT TO TEMP
2452 007516 062746 000002 ADD #2,-(SP) ;ADJUST STACK
2453 007522 1$:
2454 007522 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
2455 007524 021364 021364 ;PORT4 IBUS* REG11
2456 007526 032777 000002 172340 BIT #2,@KMP04 ;IS PGM CLOCK BIT CLEAR?
2457 007534 001772 BEQ 1$ ;BR IF YES
2458 007536 2$:
2459 007536 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
2460 007540 021364 021364 ;PORT4 IBUS* REG11
2461 007542 032777 000002 172324 BIT #2,@KMP04 ;IS PGM CLOCK BIT SET?
2462 007550 001372 BNE 2$ ;BR IF YES
2463 007552 005337 011234 DEC TEMP ;DEC COUNT
2464 007556 001364 BNE 1$ ;BR IF NOT DONE
2465 007560 000002 RTI ;RETURN
2466
2467 007562 050200 051127 043040 MPFAIL: .ASCIZ <200>/PWR FAILED. RESTART AT TEST /
(2) 007620 042600 042116 050040 MEPASS: .ASCIZ <200>/END PASS CZCKEB /
(2) 007643 200 000122 MR: .ASCIZ <200>/R/
(2) 007646 047200 020117 042504 MERR2: .ASCIZ <200>/NO DEVICES PRESENT./
(2) 007673 200 047111 052523 MERR3: .ASCIZ <200>/INSUFFICIENT DATA!/
(2) 007717 200 047514 045503 MLOCK: .ASCIZ <200>/LOCK ON SELECTED TEST/
(2) 007746 051503 035122 000040 MCSRX: .ASCIZ /CSR: /
(2) 007754 042526 035103 000040 MVECX: .ASCIZ /VEC: /
(2) 007762 040520 051523 051505 MPASSX: .ASCIZ /PASSES: /
(2) 007773 105 051122 051117 MERRX: .ASCIZ /ERRORS: /
(2) 010004 042524 052123 047040 MTSTN: .ASCIZ /TEST NO: /
(2) 010016 000052 MASTEK: .ASCIZ /*/
(2) 010020 051600 052105 051440 MNEW: .ASCIZ <200>/SET SWITCH REG TO KMC11'S DESIRED ACTIVE./
(2) 010073 120 035103 000040 MERRPC: .ASCIZ /PC: /
(2) 010100 020200 020040 020040 XHEAD: .ASCII <200>/ MAP OF KMC11 STATUS/
(2) 010137 200 020040 020040 .ASCII <200>/-----/
(2) 010176 020200 050040 020103 .ASCII <200>/ PC CSR STAT1 STAT2 STAT3/
(2) 010250 026600 026455 026455 .ASCIZ <200>/-----/
(2) 010324 044200 053517 046440 NUM: .ASCIZ <200>/HOW MANY KMC11'S TO BE TESTED?/
(2) 010364 041600 051123 040440 CSR: .ASCIZ <200>/CSR ADDRESS?/
(2) 010402 053200 041505 047524 VEC: .ASCIZ <200>/VECTOR ADDRESS?/

```

```

(2) 010423 200 051102 050040 PRI0: .ASCIZ <200>/BR PRIORITY LEVEL? (4,5,6,7)?/
(2) 010462 053600 044510 044103 MODU: .ASCIZ <200>/WHICH LINE UNIT? IF NONE TYPE 'N', IF M8201 TYPE '1', IF M8202 TYP
(2) 010574 053600 044510 044103 MV35: .ASCII <200>/WHICH MODEM TYPE, TYPE 'D' FOR KMC11-DA (RS232C),OR/
(2) 010660 052200 050131 020105 .ASCIZ <200>/TYPE 'F' FOR KMC11-FA (V.35) ? /
(2)
(2) 010721 200 053523 052111 LINE: .ASCIZ <200>/SWITCH PAC#1 (DDCMP LINE #)?/
(2) 010757 200 053523 052111 BM: .ASCIZ <200>/SWITCH PAC#2 (BM873 BOOT ADD)?/
(2) 011017 200 051511 052040 CONN: .ASCIZ <200>/IS THE LOOP BACK CONNECTOR ON?/
(2) 011057 200 047516 042040 NOACT: .ASCIZ <200>/NO DEVICES ARE SELECTED/
(2) 011110 100200 046513 030503 CONERR: .ASCIZ <200><200>/KMC11 AT NONSTANDARD ADDRESS PC: /
(2) 011155 200 054105 042520 CNERR: .ASCIZ <200>/EXPECTED FOUND/
(2) 011176 024040 046513 024503 K9CM: .ASCIZ / (KMC) /
(2)
(2) 011206 000005 .EVEN
2468 011210 006 003 XSTATQ: 5
2469 011212 001276 .BYTE 6,3
2470 011214 006 003 $TMP0
2471 011216 001300 .BYTE 6,3
2472 011220 006 003 $TMP1
2473 011222 001302 .BYTE 6,3
2474 011224 006 003 $TMP2
2475 011226 001304 .BYTE 6,3
2476 011230 006 002 $TMP3
2477 011232 001306 .BYTE 6,2
2478 $TMP4
2479 .EVEN
2480 ;BUFFERS FOR INPUT-OUTPUT
2481
2482 011234 000000 TEMP: 0
2483 011276 .=.+40
2484 011276 000000 MDATA: 0
2485 011340 .=.+40
2486
2487
2488 ;ROUTINE USED TO CHANGE SOFTWARE SWITCH
2489 ;REGISTER USING THE CONSOLE TERMINAL
2490 ;-----
2491
2492 011340 022737 000176 001240 CKSWR: CMP #SWREG,SWR ;IS THE SOFT SWR BEING USED?
2493 011346 001075 BNE CKSWR5 ;BR IF NO
2494 011350 132737 000001 001336 BITB #1,$ENV ; IS IT RUNNING UNDER APT?
2495 011356 001071 BNE CKSWR5 ; EXIT IF YES.
2496 011360 022777 000007 167660 CMP #7,@$TKB ;WAS CTRL G TYPED? (7 BIT ASCII)
2497 011366 001404 BEQ 1$ ;BR IF YES
2498 011370 022777 000207 167650 CMP #207,@$TKB ;WAS CTRL G TYPED? (8 BIT ASCII)
2499 011376 001061 BNE CKSWR5 ;BR IF NO
2500 011400 010246 1$: MOV R2,-(SP) ;STORE R2
2501 011402 010346 MOV R3,-(SP) ;STORE R3
2502 011404 010446 MOV R4,-(SP) ;STORE R4
2503 011406 012737 177777 011544 MOV #-1,$WFLG ;SET SOFT TYPE OUT FLAG
2504 011414 005002 CKSWR1: CLR R2 ;CLEAR NEW SWR CONTENTS
2505 011416 012704 177777 MOV #-1,R4 ;SET FLAG TO ALL ONES
2506 011422 104401 005541 TYPE $MSWR ;TYPE 'SWR='
2507 011426 104417 CKSWR2: CNVRT ;TYPE OUT PRESENT CONTENTS
2508 011430 011600 SOFTSW ;OF SOFT SWITCH REGISTER
2509 011432 104401 005552 CKSWR3: TYPE $MNEW ;TYPE 'NEW?'
  
```

2510	011436	004737	011546	CKSWR4:	JSR	PC,INCHAR	:GET RESPONSE
2511	011442	022703	000015		CMP	#15,R3	:WAS IT A CR?
2512	011446	001424			BEQ	58	:BR IF YES
2513	011450	022703	000012		CMP	#12,R3	:WAS IT A LF?
2514	011454	001416			BEQ	48	:BR IF YES
2515	011456	022703	000025		CMP	#25,R3	:WAS IT CTRL U?
2516	011462	001754			BEQ	CKSWR1	:BR IF YES(START OVER)
2517	011464	022703	000007		CMP	#7,R3	:IF CNTL G GET NEXT CHAR
2518	011470	001762			BEQ	CKSWR4	
2519	011472	005004			CLR	R4	:IT MUST BE A DIGIT SO CLR FLAG
2520	011474	042703	177770		BIC	#177770,R3	:ONLY 0-7 ARE LEGAL SO MASK OFF BITS
2521	011500	006302			ASL	R2	:SHIFT R2 3 TIMES
2522	011502	006302			ASL	R2	
2523	011504	006302			ASL	R2	
2524	011506	050302			BIS	R3,R2	:ADD LAST DIGIT
2525	011510	000752			BR	CKSWR4	:GET NEXT CHARACTER
2526	011512	012766	002402 000006	4\$:	MOV	#.START,6(SP)	:LF WAS TYPED SO GO TO START
2527	011520	005704		5\$:	TST	R4	:IS FLAG CLEAR?
2528	011522	001002			BNE	6\$:IF NOT DON'T CHANGE SOFT SWR
2529	011524	010277	167510		MOV	R2,@SWR	:IF YES THEN WRITE NEW CONTENTS TO SOFT SWR
2530	011530	005037	011544	6\$:	CLR	SWFLG	:CLEAR TYPEOUT FLAG
2531	011534	012604			MOV	(SP)+,R4	:RESTORE R4
2532	011536	012603			MOV	(SP)+,R3	:RESTORE R3
2533	011540	012602			MOV	(SP)+,R2	:RESTORE R2
2534	011542	000207		CKSWR5:	RTS	PC	:RETURN
2535							
2536	011544	000000		SWFLG:		0	
2537							
2538	011546	105777	167472	INCHAR:	TSTB	@\$TKS	
2539	011552	100375			BPL	.-4	
2540	011554	017703	167466		MOV	@\$TKB,R3	
2541	011560	105777	167464		TSTB	@\$TPS	
2542	011564	100375			BPL	.-4	
2543	011566	010377	167460		MOV	R3,@\$TPB	
2544	011572	042703	000200		BIC	#BIT7,R3	
2545	011576	000207			RTS	PC	
2546							
2547	011600	000001		SOFTSW:		1	
2548	011602	006	002		.BYTE	6,2	
2549	011604	000176			SWREG		

```

2550
2551
2552
2553
2554
2555
2556
2557
2558
2559 011606 005737 001470 CYCLE: TST KMACTV ;ARE ANY KMC11'S TO BE TESTED?
2560 011612 001004 BNE 1$ ;BR IF OK.
2561 011614 104401 011057 TYPE ,NOACT ;NO KMC11'S SELECTED!!
2562 011620 000000 HALT ;STOP THE SHOW.
2563 011622 000776 BR -2 ;DISQUALIFY CONT. SW.
2564 011624 000241 1$: CLC ;CLEAR PROC. CARRY BIT.
2565 011626 006137 001500 ROL RUN ;UPDATE POINTER
2566 011632 005537 001500 ADC RUN ;CATCH CARRY FROM RUN
2567 011636 062737 000004 001504 ADD #4,MILK ;UPDATE POINTER
2568 011644 062737 000010 001502 ADD #10,CREAM ;UPDATE ADDRESS POINTER.
2569 011652 022737 002300 001502 CMP #KM.MAP+200,CREAM
2570 011660 001006 BNE 2$ ;KEEP GOING; NOT ALL TESTED FOR.
2571 011662 012737 002100 001502 MOV #KM.MAP,CREAM ;RESET ADDRESS POINTER.
2572 011670 012737 002302 001504 MOV #CNT.MAP,MILK ;RESET PASS COUNT POINTER
2573 011676 033737 001500 001470 2$: BIT RUN,KMACTV ;IS THIS ONE ACTIVE?
2574 011704 001747 BEQ 1$ ;BR IF NO
2575 011706 013700 001502 MOV CREAM,R0 ;GET ADDRESS POINTER
2576 011712 013702 001504 MOV MILK,R2 ;GET PASS COUNT POINTER
2577 011716 012037 002066 MOV (R0)+,KMCSR ;LOAD SYSTEM CTRL. REG
2578 011722 011037 002056 MOV (R0),KMRVEC ;LOAD VECTOR
2579 011726 042737 177000 002056 BIC #177000,KMRVEC ;CLEAR UNWANTED BITS
2580 011734 012037 002050 MOV (R0)+,STAT1 ;LOAD STAT1
2581 011740 012037 002052 MOV (R0)+,STAT2 ;LOAD STAT2
2582 011744 012037 002054 MOV (R0)+,STAT3 ;LOAD STAT3
2583 011750 012237 001324 MOV (R2)+,$PASS ;LOAD PASS COUNT
2584 011754 012237 001212 MOV (R2)+,$ERTTL ;LOAD ERROR COUNT
2585 011760 012700 000002 MOV #2,R0 ;SAVE CORE THIS WAY!
2586 011764 013737 002066 002070 MOV KMCSR,KMCSRH
2587 011772 005237 002070 INC KMCSRH
2588 011776 013737 002070 002072 MOV KMCSRH,KMCTL
2589 012004 005237 002072 INC KMCTL
2590 012010 013737 002072 002074 MOV KMCTL,KMPO4
2591 012016 060037 002074 ADD R0,KMPO4
2592 012022 013737 002074 002076 MOV KMPO4,KMPO6
2593 012030 060037 002076 ADD R0,KMPO6
2594
2595 012034 013737 002056 002060 MOV KMRVEC,KMRLVL ;PTY LVL
2596 012042 060037 002060 ADD R0,KMRLVL ;
2597 012046 013737 002060 002062 MOV KMRLVL,KMTVEC ;TX VEC
2598 012054 060037 002062 ADD R0,KMTVEC ;
2599 012060 013737 002062 002064 MOV KMTVEC,KMTLVL ;TX LVL
2600 012066 060037 002064 ADD R0,KMTLVL ;
2601
2602 012072 032737 000002 001446 BIT #SW01,STRTSW ;IS TEST NO. SELECTED
2603 012100 001447 BEQ 7$ ;BR IF NO
2604 012102
2605 012102 005737 000042 4$: TST @#42 ;RUNNING IN AUTO MODE?

```

```

2606 012106 001044          BNE      7$          ;BR IF YES
2607 012110 104401 001313  TYPE      , $CRLF
2608 012114 104415          INPUT
2609 012116 010004          MTSTN
2610 012120 000001          1
2611 012122 001000          1000
2612 012124 001202          $STNM
2613 012126 000          .BYTE 0
2614 012127 001          .BYTE 1
2615 012130 012700 014140  MOV      #TST1,R0
2616 012134 022710 5$:      CMP      (PC)+,(R0)      ;CMP FIRST WORD TO 12737
2617 012136 012737          MOV      (PC)+,@(PC)+
2618 012140 001020          BNE      6$          ;BR IF NOT SAME
2619 012142 023760 001202 000002  CMP      $STNM,2(R0)      ;DOES $STNM MATCH?
2620 012150 001014          BNE      6$          ;BR IF NO
2621 012152 022760 001202 000004  CMP      #$STNM,4(R0)      ;IS LAST WORD OK?
2622 012160 001010          BNE      6$          ;BR IF NO
2623 012162 010037 001206  MOV      R0,$LPADR      ;IT IS A LEGAL TEST SO DO IT
2624 012166 104401 007643  TYPE      ,MR
2625 012172 042737 000002 001446  BIC      #SW01,STRTSW
2626 012200 000412          BR      8$
2627 012202 005720 6$:      TST      (R0)+          ;POP R0
2628 012204 020027 027716  CMP      R0,#TLAST+10      ;AT END YET?
2629 012210 001351          BNE      5$          ;BR IF NO
2630 012212 104401 001312  TYPE      , $QUES      ;YES ILLEGAL TEST NO.
2631 012216 000731          BR      4$          ;TRY AGAIN
2632
2633 012220 012737 014140 001206 7$:      MOV      #TST1,$LPADR      ;PREPARE $LPADR ADDRESS
2634 012226 013701 002066 8$:      MOV      KMC11,R1          ;R1 = BASE KMC11 ADDRESS
2635 012232 000177 166750  JMP      @ $LPADR          ;GO START TESTING.
2636
2637
2638          ;ROUTINE USED TO "AUTO SIZE" THE KMC11
2639          ;CSR AND VECTOR.
2640          ;NOTE: THE CSR MAY BE ANY WHERE IN THE FLOATING
2641          ;      ADDRESS RANGE (160000:164000)
2642          ;      AND THE VECTOR MAY BE ANY WHERE IN THE
2643          ;      FLOATING VECTOR RANGE (300:770)
2644          ;
2645          ;
2646          AUTO.SIZE:
2647 012236 000005          RESET
2648 012240 012702 002100  CSRMAP: MOV      #KM.MAP,R2      ;INSURE A BUS INIT.
2649 012244 005022          CLR      (R2)+          ;LOAD MAP POINTER.
2650 012246 022702 002300  1$:      CMP      #KM.END,R2      ;ZERO ENTIRE MAP
2651 012252 001374          BNE      1$          ;ALL DONE?
2652 012254 005037 001472  CLR      KMMNUM          ;BR IF NO
2653 012260 012702 002100  MOV      #KM.MAP,R2      ;SET OCTAL NUMBER OF KMC11'S TO 0
2654 012264 005037 001470  CLR      KMACTV          ;R2 POINTS TO KMC MAP
2655 012270 032737 000001 001446  BIT      #SW00,STRTSW      ;CLEAR ACTIVE
2656 012276 001002          BNE      +6          ;QUESTIONS?
2657 012300 000137 012740  JMP      7$          ;BR IF YES
2658 012304 012737 000001 001306  MOV      #1,$TMP4          ;IF NO SKIP QUESTIONS
2659 012312 104415          INPUT
2660 012314 010324          NUM
2661 012316 000001          1
    
```

```

2662 012320 000020          16.
2663 012322 C01302          $TMP2
2664 012324 000           .BYTE 0
2665 012325 001           .BYTE 1
2666 012326 013737 001302 001472 MOV $TMP2,KMNUM ;KMNUM = HOW MANY
2667 012334 104401 001313 12$: TYPE .$CRLF
2668 012340 104416          CONVRT ;TYPE WHICH KMC IS BEING DONE
2669 012342 013372          WHICH ;$TMP4 IS WHICH KMC
2670 012344 005237 001306 INC $TMP4
2671 012350 104415          INPUT
2672 012352 010364          CSR
2673 012354 160000          160000
2674 012356 164000          164000
2675 012360 001304          $TMP3
2676 012362 000           .BYTE 0
2677 012363 001           .BYTE 1
2678 012364 013722 001304 MOV $TMP3,(R2)+ ;STORE CSR IN MAP
2679 012370 104415          INPUT
2680 012372 010402          VEC
2681 012374 000000          0
2682 012376 000776          776
2683 012400 001304          $TMP3
2684 012402 000           .BYTE 0
2685 012403 001           .BYTE 1
2686 012404 013712 001304 MOV $TMP3,(R2) ;STORE VECTOR IN MAP
2687 012410 104401          TYPE
2688 012412 010423          PRIO ;ASK WHAT BR LEVEL
2689 012414 004737 013664 JSR PC,INTTY ;GET RESPONSE
2690 012420 022703 000024 CMP #24,R3 ;
2691 012424 101014          BHI 50$ ;BR IF LESS THAN 4
2692 012426 022703 000027 CMP #27,R3 ;
2693 012432 103411          BLO 50$ ;BR IF GREATER THAN 7
2694 012434 012704 000011 MOV #11,R4 ;R4 = NUMBER OF SHIFTS
2695 012440 006303          ASL R3 ;SHIFT R3 LEFT
2696 012442 005304          DEC R4 ;DEC SHIFT COUNT
2697 012444 001375          BNE -4 ;BR IF NOT DONE
2698 012446 042703 170777 BIC #170777,R3 ;BIC UNWANTED BITS
2699 012452 050312          BIS R3,(R2) ;PUT BR LEVEL IN STATUS MAP
2700 012454 000403          BR 8$ ;CONTINUE
2701 012456 104401          TYPE
2702 012460 001312          $QUES
2703 012462 000752          BR 10$ ;RESPONSE IS OUT OF LIMITS
2704 012464          8$: ;TRY AGAIN
2705 012464          9$:
2706 012464          16$:
2707
2708 012464 104401          TYPE
2709 012466 010462          MODU
2710 012470 004737 013664 JSR PC,INTTY ;ASK WHICH LINE UNIT
2711 012474 022703 000021 CMP #21,R3 ;GET REPLY
2712 012500 001417          BEQ 30$ ;'1'
2713 012502 022703 000022 CMP #22,R3 ;'2'
2714 012506 001412          BEQ 31$
2715 012510 022703 000116 CMP #116,R3 ;'N'
2716 012514 001403          BEQ 32$
2717 012516 104401          TYPE

```



```

2718 012520 001312          $QUES          ;IF NOT A 1,2 OR N TYPE '?'
2719 012522 000760          BR          16$          ;TRY AGIAN
2720 012524 052722 010000 32$: BIS          #BIT12,(R2)+ ;SET BIT 12 IN STAT2 IF NO LU
2721 012530 022222          CMP          (R2)+,(R2)+ ;POP OVER STAT2 AND STA-3
2722 012532 000475          BR          33$
2723 012534 052712 020000 31$: BIS          #BIT13,(R2)  ;SET BIT 13 IN STAT2 IF M8202
2724 012540 104401          30$: TYPE
2725 012542 011017          CONN
2726 012544 004737 013664 JSR          PC,INTTY      ;ASK IF LOOP-BACK IS ON
2727 012550 022703 000131 CMP          #131,R3      ;GET REPLY
2728 012554 001406          BEQ          17$          ;Y
2729 012556 022703 000116 CMP          #116,R3      ;N
2730 012562 001436          BEQ          18$
2731 012564 104401          TYPE
2732 012566 001312          $QUES          ;IF NOT Y OR N TYPE '?'
2733 012570 000763          BR          30$          ;TRY AGAIN
2734 012572 052722 040000 17$: BIS          #BIT14,(R2)+ ;TURNAROUND IS CONNECTED
2735 012576 032762 020000 177776 BIT          #BIT13,-2(R2) ; M8202?
2736 012604 001027          BNE          19$
2737 012606          440$:
2738
2739 012606 104401          TYPE          ; ASK QUESTION
2740 012610 010574          MV35         ; ABOUT MODEM TTYPE
2741 012612 004737 013664 JSR          PC,INTTY      ; GET ANSWER.
2742 012616 122703 000104 CMPB         #'D,R3        ; IS IT DMC11-DA?
2743 012622 001004          BNE          442$        ; NO.
2744
2745 012624 042762 000004 000002 BIC          #BIT2,2(R2)  ; YES INDICATE IT IN STAT3
2746 012632 000411          BR          441$
2747
2748 012634 122703 000106 442$: CMPB         #'F,R3        ;IS IT A DMC11-FA (V.35)?
2749 012640 001403          BEQ          443$        ; YES-TAKE CARE OF IT.
2750
2751 012642 104401          TYPE          ; NO ASK OPERATER WHATS GOING ON.
2752 012644 001312          $QUES
2753 012646 000757          BR          440$        ; REASK QUESTION
2754
2755 012650 052767 000004 000002 443$: BIS          #BIT2,2(R2)  ; YES V.35, RECORD IN STAT3
2756
2757 012656          441$:          ; END DECISION POINT.
2758 012656 000402          BR          19$
2759 012660 042722 040000 18$: BIC          #BIT14,(R2)+ ;NO TURNAROUND
2760 012664          19$:
2761 012664 104415          INPUT
2762 012666 010721          LINE
2763 012670 000000          0
2764 012672 000377          377
2765 012674 001304          $TMP3
2766 012676 000          .BYTE 0
2767 012677 001          .BYTE 1
2768 012700 113722 001304 MOVB         $TMP3,(R2)+ ;STORE SWITCH PAC IN MAP
2769 012704 104415          INPUT
2770 012706 010757          BM
2771 012710 000000          0
2772 012712 000377          377
2773 012714 001304          $TMP3

```

CZKCE MACY11 30A(1052) 08-JUL-80 08:24 PAGE 59
 CZKCE.P11 08-JUL-80 08:24 POWER DOWN AND UP ROUTINES

SEQ 0058

```

2774 012716 000 .BYTE 0
2775 012717 001 .BYTE 1
2776 012720 113722 001304 MOVB $TMP3,(R2)+ ;STORE SWITCH PAC IN MAP
2777 012724 005722 TST (R2)+ ;POP OVER STAT3
2778 012726 005337 001302 33$: DEC $TMP2 ;DEC KMC COUNT
2779 012732 001200 BNE 12$ ;BR IF MORE TO DO
2780 012734 000137 013272 JMP 13$ ;CONTINUE
2781 012740 012701 160000 7$: MOV #160000,R1 ;SET FOR FIRST ADDRESS TO BE TESTED
2782 012744 012737 013364 000004 MOV #6$,R1 ;SET FOR NON-EXISTANT DEVICE TIME OUT
2783 012752 005011 2$: CLR (R1) ;CLEAR SEL0
2784 012754 005711 TST (R1) ;IF KMC11 KMC SR S/B 0
2785 012756 001135 BNE 3$ ;IF NO DEV ; TRAP TO 4. IF NO BIT 8 THEN NO KMC11
2786 012760 005061 000006 CLR 6(R1) ;CLEAR SEL6
2787 012764 005761 000006 TST 6(R1) ;IF KMC11 THEN KMRIC S/B =0!
2788 012770 001130 BNE 3$ ;BR IF NOT KMC11
2789 012772 012711 002000 MOV #BIT10,(R1) ;SET ROMO
2790 012776 005061 000004 CLR 4(R1) ;CLEAR SEL4
2791 013002 012761 125252 000006 MOV #125252,6(R1) ;WRITE THIS TO SEL6
2792 013010 052711 020000 BIS #BIT13,(R1) ;WRITE IT!
2793 013014 022761 125252 000004 CMP #125252,4(R1) ;WAS IT WRITTEN?
2794 013022 001113 BNE 3$ ;IF NO IT IS NOT CRAM
2795 ;AT THIS POINT IT IS ASSUMED THAT R1 HOLDS A KMC11 CSR ADDRESS.
2796 013024 21$:
2797 013024 010122 22$: MOV R1,(R2)+ ;STORE CSR IN CORE TABLE.
2798 013026 012711 001000 15$: MOV #BIT9,(R1) ;CLEAR LINE UNIT LOOP
2799 013032 005061 000004 CLR 4(R1) ;CLEAR PORT4
2800 013036 012761 122113 000006 MOV #122113,6(R1) ;LOAD INSTRUCTION (CLR DTR)
2801 013044 052711 000400 BIS #BIT8,(R1) ;CLOCK INSTRUCTION
2802 013050 012761 021264 000006 MOV #021264,6(R1) ;LOAD INSTRUCTION
2803 013056 052711 000400 BIS #BIT8,(R1) ;CLOCK INSTRUCTION
2804 013062 122761 000377 000004 CMPB #377,4(R1) ;IS IT ALL ONES?
2805 013070 001003 BNE .+10 ;BR IF NO
2806 013072 052712 010000 BIS #BIT12,(R2) ;IF YES, NO LINE UNIT, SET STATUS BIT
2807 013076 000436 BR 20$
2808 013100 032761 000002 000004 BIT #BIT1,4(R1) ;IS SWITCH A ONE?
2809 013106 001403 BEQ .+10 ;BR IF M8201
2810 013110 052712 060000 BIS #BIT13!BIT14,(R2) ;M8202 ASSUME CONNECTOR
2811 013114 000427 BR 20$ ;CONNECTOR ON)
2812 013116 032761 000010 000004 BIT #BIT3,4(R1) ;IS MRDY SET
2813 013124 001023 BNE 20$ ;BR IF M8201 NO CONNECTOR (ON LINE)
2814 013126 012761 000100 000004 MOV #BIT6,4(R1) ;LOAD PORT4
2815 013134 012761 122113 000006 MOV #122113,6(R1) ;LOAD INSTRUCTION
2816 013142 052711 000400 BIS #BIT8,(R1) ;CLOCK INSTRUCTION(SET DTR)
2817 013146 012761 021264 000006 MOV #021264,6(R1) ;LOAD INSTRUCTION
2818 013154 052711 000400 BIS #BIT8,(R1) ;CLOCK INSTRUCTION(READ MODEM REG)
2819 013160 032761 000010 000004 BIT #BIT3,4(R1) ;IS MRDY SET NOW?
2820 013166 001402 BEQ 20$ ;BR IF NO CONNECTOR
2821 013170 052712 040000 BIS #BIT14,(R2) ;SET STATUS BIT FOR CONNECTOR
2822 013174 005722 20$: TST (R2)+ ;POP POINTER
2823 013176 012761 021324 000006 MOV #021324,6(R1) ;PUT INSTRUCTION IN PORT6
2824 013204 012711 001400 MOV #BIT9!BIT8,(R1) ;PORT4 LU 15
2825 013210 156122 000004 BISB 4(R1),(R2)+ ;STORE DDCMP LINE # IN TABLE
2826 013214 012761 021344 000006 MOV #021344,6(R1) ;PORT6 INSTRUCTION
2827 013222 012711 001400 MOV #BIT8!BIT9,(R1) ;CLOCK INSTR.
2828 013226 156122 000004 BISB 4(R1),(R2)+ ;STORE BM873 ADD IN TABLE
2829 013232 005722 TST (R2)+ ;POP OVER STAT3

```

2830	013234	005011			CLR	(R1)	:CLEAR ROMI
2831	013236	005237	001472		INC	KMNUM	:UPDATE DEVICE COUNTER
2832	013242	022737	000020	001472	CMP	#20,KMNUM	:ARE MAX. NO. OF DEV FOUND?
2833	013250	001410			BEQ	13\$:YES DON'T LOOK FOR ANY MORE.
2834	013252	005011			3\$: CLR	(R1)	:CLEAR BIT 10
2835	013254	005061	000006		CLR	6(R1)	:CLEAR SEL 6
2836	013260	062701	000010		14\$: ADD	#10,R1	:UPDATE CSR POINTER ADDRESS
2837	013264	022701	164000		CMP	#164000,R1	
2838	013270	001230			BNE	2\$:BR IF MORE ADDRESS TO CHECK.
2839	013272	005037	001470		13\$: CLR	KMACTV	
2840	013276	005737	001472		TST	KMNUM	:WERE ANY KMC11'S FOUND AT ALL?
2841	013302	001423			BEQ	5\$:ERROR AUTO SIZER FOUND NO KMC11'S IN THIS SYS.
2842	013304	013701	001472		MOV	KMNUM,R1	
2843	013310	010137	001476		MOV	R1,SAVNUM	:SAVE NUMBER OF DEVICES
2844	013314	000241			4\$: CLC		
2845	013316	006137	001470		ROL	KMACTV	:GENERATE ACTIVE REGISTER OF DEVICES.
2846	013322	005237	001470		INC	KMACTV	:SET THE BIT
2847	013326	005301			DEC	R1	
2848	013330	001371			BNE	4\$:BR IF MORE TO GENERATE
2849	013332	012737	000006	000004	MOV	#6,@#4	:RESTORE TRAP VECTOR
2850	013340	013737	001470	001474	MOV	KMACTV,SAVACT	:SAVE ACTIVE REGISTER
2851	013346	000137	013400		JMP	VECMAP	:GO FIND THE VECTOR NOW.
2852	013352	104401	007646		5\$: TYPE	,MERR2	:NOTIFY OPR THAT NO KMC11'S FOUND.
2853	013356	005000			CLR	RO	:MAKE DATA LIGHTS ZERO
2854	013360	000000			HALT		:STOP THE SHOW
2855	013362	000776			BR	.-2	:DISABLE CONT. SW.
2856	013364	012716	013260		6\$: MOV	#14\$,(SP)	:ENTERED BY NON-EXISTANT TIME-OUT.
2857	013370	000002			RTI		:RETURN TO MAINSTREAM
2858							
2859	013372	000001			WHICH: 1		
2860	013374	002	002		.BYTE	2,2	
2861	013376	001306			\$TMP4		
2862							
2863	013400	032737	000001	001446	VECMAP: BIT	#SW00,STRTSW	
2864	013406	001114			BNE	5\$	
2865	013410	012737	000340	000022	MOV	#340,@#22	:SET IOT TRAP PRIO TO 7
2866	013416	012737	013572	000020	MOV	#4\$,@#20	:SET IOT TRAP VECTOR
2867	013424	012702	002100		MOV	#KM.MAP,R2	:SET SOFTWARE POINTER
2868	013430	012700	000300		MOV	#300,RO	:FLOATING VECTORS START HERE.
2869	013434	012701	000302		MOV	#302,R1	:PC OF IOT INSTR.
2870	013440	010120			1\$: MOV	R1,(R0)+	:START FILLING VECTOR AREA
2871	013442	012721	000004		MOV	#4,(R1)+	:WITH .+2: IOT
2872	013446	022021			CMP	(R0)+,(R1)+	:ADD 2 TO RO +R1
2873	013450	020127	001000		CMP	R1,#1000	
2874	013454	101771			BLOS	1\$:BR IF MORE TO FILL
2875	013456	013737	001470	001276	MOV	KMACTV,\$TMP0	:STORE TEMPORALLY
2876	013464	006037	001276		2\$: KOR	\$TMP0	:BRING OUT A BIT
2877	013470	103063			BCC	5\$:BR IF ALL DONE
2878	013472	012704	000012		MOV	#12,R4	:R4 IS INDEX REGISTER
2879	013476	016437	013650	177776	MOV	BRLVL(R4),PS	:SET PS TO 7
2880	013504	011201			MOV	(R2),R1	
2881	013506	012761	000200	000004	MOV	#200,4(R1)	
2882	013514	012711	001000		MOV	#BIT9,(R1)	:SET ROMI
2883	013520	012761	121111	000006	MOV	#121111,6(R1)	:PUT INSTRUCTION IN PORT6
2884	013526	012711	001400		MOV	#BIT9:BIT8,(R1)	:FORCE AN INTERRUPT
2885	013532	105200			7\$: INCB	RO	:STALL

```

2886 013534 001376          BNE      -2          ;FOR TIME TO INTERRUPT
2887 013536 162704 000002    SUB      #2,R4       ;GET NEXT LOWEST PS LEVEL
2888 013542 001404          BEQ      6$         ;BR IF R4 = 0
2889 013544 016437 013650 177776  MOV     BRLVL(R4),PS ;MOVE NEXT LOWER LEVEL IN PS
2890 013552 000767          BR       7$         ;BR TO DELAY
2891 013554 052762 005300 000002 6$:    BIS      #5300,2(R2) ;NO INTERRUPT ASSUME 300 AT LEVEL 5 AND FIX KMC11 LAYER
2892 013562 005011          3$:    CLR      (R1)       ;CLEAR ROMI
2893 013564 062702 000010    ADD     #10,R2      ;POP SOFTWARE POINTER
2894 013570 000735          BR       2$         ;KEEP GOING
2895 013572 051662 000002          4$:    BIS      (SP),2(R2) ;GET VECTOR ADDRESS
2896 013576 042762 000007 000002  BIC     #7,2(R2)    ;CLEAR JUNK
2897 013604 016405 013652    MOV     BRLVL+2(R4),R5 ;GET BR LEVEL OF KMC11
2898 013610 006305          ASL     R5          ;SHIFT LEVEL 4 PLACES
2899 013612 006305          ASL     R5          ;TO THE LEFT FOR THE
2900 013614 006305          ASL     R5          ;STATUS TABLE
2901 013616 006305          ASL     R5
2902 013620 042705 170777    BIC     #170777,R5  ;CLEAR UNWANTED BITS
2903 013624 050562 000002    BIS     R5,2(R2)    ;PUT BR LEVEL IN STATUS TABLE
2904 013630 022626          CMP     (SP)+,(SP)+ ;POP IOT JUNK OFF STACK
2905 013632 012716 013562    MOV     #3$, (SP)  ;SET FOR RETURN
2906 013636 000002          RTI
2907 013640 012737 004134 000020 5$:    MOV     #$$SCOPE,a#20 ; RESTORE SCOPE VECTOR
2908 013646 000207          RTS     PC         ;ALL DONE WITH 'AUTO SIZING'
2909
2910 013650 000000          BRLVL: PRO      ;LEVEL 0
2911 013652 000000          PRO      ;LEVEL 0
2912 013654 000200          PR4     ;LEVEL 4
2913 013656 000240          PR5     ;LEVEL 5
2914 013660 000300          PR6     ;LEVEL 6
2915 013662 000340          PR7     ;LEVEL 7
2916
2917
2918 013664 105777 165354    INTTY: TSTB     @$TKS ;WAIT FOR DONE
2919 013670 100375          BPL     -4
2920 013672 017703 165350    MOV     @$TKB,R3   ;PUT CHAR IN R3
2921 013676 105777 165346    TSTB   @$TPS      ;WAIT UNTIL PRINTER IS READY
2922 013702 100375          BPL     -4
2923 013704 010377 165342    MOV     R3,@$TPB  ;ECHO CHAR
2924 013710 042703 000240    BIC     #BIT7!BITS,R3 ;MASK OFF LOWER CASE
2925 013714 000207          RTS     PC         ;RETURN
2926
2927 013716          APT.SIZE:
2928 013716 000005          RESET
2929 013720 010046          MOV     R0,-(SP)   ;;PUSH R0 ON STACK
2930 013722 010146          MOV     R1,-(SP)   ;;PUSH R1 ON STACK
2931 013724 010246          MOV     R2,-(SP)   ;;PUSH R2 ON STACK
2932 013726 010346          MOV     R3,-(SP)   ;;PUSH R3 ON STACK
2933 013730 005037 014132    CLR     VECTR      ; CLEAR THE LOCAL VARIABLE
2934 013734 005037 014136    CLR     PRTY       ; CLEAN UP LOCAL VARIABLE
2935 013740 013700 001376    MOV     $CDW1,R0   ; GET THE DEVICE COUNT
2936 013744 010037 001476    MOV     R0,SAVNUM  ; SAVE THE NO. OF DEVICES
2937 013750 012701 001346    MOV     #MAMS1,R1  ; GET EXTRA INFO, BITS POINTER
2938 013754 013737 001372 014134    MOV     $BASE,BASE ; GET BASE CSR ADDRESS
2939 013762 113737 001366 014132    MOVB   $VECT1,VECTR ; GET THE VECTOR
2940 013770 113737 001367 014136    MOVB   $VECT1+1,PRTY ; GET THE PRIORITY
2941 013776 013737 001374 001470    MOV     $DEVN,KMACTV ; SAVE THE KMC'S SELECTED ACTIVE
    
```

```

2942 014004 013737 001470 001474      MOV      KMACTV,SAVACT      ; SAVE THE ACTIVE REGISTER
2943 014012 012702 001402              MOV      #SDDWO,R2         ; GET ADDRESS OF FIRST DEVICE DESCRIPTOR WORD
2944 014016 012703 002100              MOV      #KM.MAP,R3       ; GET POINTER TO DEVICE MAP
2945 014022 005023              CLR      (R3)+             ; CLEAR DEVICE MAP
2946 014024 022703 002300      3$:     CMP      #KM.END,R3     ; IS WHOLE DEV.MAP CLEARED?
2947 014030 003374              BGT      3$                ; NO, THEN GO ON.
2948 014032 012703 002100              MOV      #KM.MAP,R3       ; RESTORE DEV.MAP POINTER.
2949 014036 013723 014134      1$:     MOV      BASE,(R3)+      ; LOAD CSR ADDRESS
2950 014042 112163 000001      MOVVB   (R1)+,1(R3)       ; GET EXTRA INFO. BITS
2951 014046 006213              ASR      (R3)              ; SET IT IN RIGHT POSITION.
2952 014050 006213              ASR      (R3)              ; SET IT IN RIGHT POSITION.
2953 014052 053713 014136              BIS      PRIRTY,(R3)      ; GET PRIORITY IN STAT1
2954 014056 006313              ASL      (R3)              ; SET THEM IN RIGHT POSITION
2955 014060 006313              ASL      (R3)              ; .. .. .. .. ..
2956 014062 006313              ASL      (R3)              ; .. .. .. .. ..
2957 014064 006313              ASL      (R3)              ; .. .. .. .. ..
2958 014066 053723 014132              BIS      VECTR,(R3)+     ; GET THE VECTOR IN STAT1.
2959 014072 012223              MOV      (R2)+,(R3)+     ; GET THE STAT2 FROM DDWXX
2960 014074 005723              TST      (R3)+           ; SKIP OVER STAT3
2961 014076 005300              DEC      RO               ; COUNT BY 1
2962 014100 001407              BEQ      2$              ; ALL DONE?
2963 014102 062737 000010 014134      ADD      #10,BASE        ; INCREMENT BASE CSR ADDRESS BY 10
2964 014110 062737 000010 014132      ADD      #10,VECTR       ; INCREMENT VECTOR ADDRESS BY 10
2965 014116 000747              BR       1$              ; SET THE NEXT MAP ENTRY
2966 014120              2$:
2967 014120 012603              MOV      (SP)+,R3        ;: POP STACK INTO R3
2968 014122 012602              MOV      (SP)+,R2        ;: POP STACK INTO R2
2969 014124 012601              MOV      (SP)+,R1        ;: POP STACK INTO R1
2970 014126 012600              MOV      (SP)+,R0        ;: POP STACK INTO R0
2971 014130 000207              RTS      PC              ; RETURN
2972 014132 000000      VECTR:  .WORD  0
2973 014134 000000      BASE:   .WORD  0
2974 014136 000000      PRIRTY: .WORD  0
2975
2976
2977
2978      ;***** TEST 1 *****
2979      ;*OUT CONTROL REGISTER READ/ONLY TEST
2980      ;*DO A MASTER CLEAR, VERIFY THAT ALL READ/ONLY
2981      ;*BITS ARE IN THE CORRECT STATE
2982      ;*****
2983
2984      ; TEST 1
2985      ;-----
2986      ;*****
2987 014140 000004      TST1:   SCOPE
2988 014142 012737 000001 001202      MOV      #1,$TSTNM       ; LOAD THE NO. OF THIS TEST
2989 014150 012737 014214 001442      MOV      #TST2,NEXT     ; POINT TO THE START OF NEXT TEST.
2990
2991 014156 005077 165704              CLR      @KMCSR         ; R1 CONTAINS BASE KMC11 ADDRESS
2992 014162 012702 000011              MOV      #11,R2        ; CLEAR SEL0
2993 014166 104412              ROMCLK  021004!<20*11> ; SAVE R2 FOR TYPEOUT
2994 014170 021224              MOV      4(R1),R4       ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
2995 014172 016104 000004              BIC      #54,R4         ; PORT4 LINE UNIT REG 11
2996 014176 042704 000054              MOV      #4(R1),R4      ; PUT 'FOUND' IN R4
2997 014202 012705 000020              MOV      #20,R5        ; CLEAR UNKNOWN BITS
                          ; PUT 'EXPECTED' IN R5

```

```

2998 014206 120504          CMPB   R5,R4          ;IS OUT READY SET?
2999 014210 001401          BEQ    1$            ;BR IF YES
3000 014212 104002          ERROR  2            ;ERROR IN LU 11
3001 014214

```

1\$:

```

3002
3003
3004
3005
3006
3007
3008
3009

```

```

:***** TEST 2 *****
:*IN CONTROL REGISTER READ/ONLY TEST
:*DO A MASTER CLEAR, VERIFY THAT ALL READ/ONLY
:*BITS ARE IN THE CORRECT STATE
:*****

```

: TEST 2

```

3010
3011
3012

```

```

3013 014214 000004          TST2:  SCOPE
3014 014216 012737 000002 001202  MOV    #2,$STNM      ; LOAD THE NO. OF THIS TEST
3015 014224 012737 014262 001442  MOV    #TST3,NEXT    ; POINT TO THE START OF NEXT TEST.
3016
3017 014232 012702 000012          MOV    #12,R2        ;R1 CONTAINS BASE KMC11 ADDRESS
3018 014236 104412          ROMCLK                ;SAVE R2 FOR TYPEOUT
3019 014240 021244          021004!<20*12>      ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3020 014242 016104 000004          MOV    4(R1),R4      ;PORT4 LINE UNIT REG 12
3021 014246 042704 000017          BIC    #17,R4        ;PUT 'FOUND' IN R4
3022 014252 005005          CLR    R5            ;CLEAR UNKNOWN BITS
3023 014254 120504          CMPB   R5,R4        ;PUT 'EXPECTED' IN R5
3024 014256 001401          BEQ    1$            ;ARE ALL BITS CLEARED?
3025 014260 104002          ERROR  2            ;BR IF YES
3026 014262

```

1\$:

;ERROR IN LU 12

```

3027
3028

```

```

:***** TEST 3 *****
:*MODEM CONTROL REGISTER READ/ONLY TEST
:*DO A MASTER CLEAR, VERIFY THAT ALL READ/ONLY
:*BITS ARE IN THE CORRECT STATE
:*****

```

: TEST 3

```

3035
3036
3037

```

```

3038 014262 000004          TST3:  SCOPE
3039 014264 012737 000003 001202  MOV    #3,$STNM      ; LOAD THE NO. OF THIS TEST
3040 014272 012737 014334 001442  MOV    #TST4,NEXT    ; POINT TO THE START OF NEXT TEST.
3041
3042 014300 104410          MSTCLR                ;R1 CONTAINS BASE KMC11 ADDRESS
3043 014302 012702 000013          MOV    #13,R2        ;MASTER CLEAR KMC11
3044 014306 104412          ROMCLK                ;SAVE R2 FOR TYPEOUT
3045 014310 021264          021004!<20*13>      ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3046 014312 016104 000004          MOV    4(R1),R4      ;PORT4 LINE UNIT REG 13
3047 014316 042704 000213          BIC    #213,R4       ;PUT 'FOUND' IN R4
3048 014322 012705 000100          MOV    #100,R5       ;CLEAR UNKNOWN BITS
3049 014326 120504          CMPB   R5,R4        ;PUT 'EXPECTED' IN R5
3050 014330 001401          BEQ    1$            ;ARE RING, DTR, AND MODEM READY SET?
3051 014332 104002          ERROR  2            ;BR IF YES
3052 014334
3053

```

1\$:

;ERROR IN LU 13

```

3054
3055
3056
3057
3058
3059
3060
3061
3062
3063
3064 014334 000004
3065 014336 012737 000004 001202
3066 014344 012737 014426 001442
3067
3068 014352 104410
3069 014354 012702 000017
3070 014360 104412
3071 014362 021364
3072 014364 016104 000004
3073 014370 042704 000206
3074 014374 012705 000051
3075 014400 032737 020000 002050
3076 014406 001404
3077 014410 042704 000040
3078 014414 042705 000040
3079 014420 120504
3080 014422 001401
3081 014424 104002
3082 014426
3083
3084
3085
3086
3087
3088
3089
3090
3091
3092
3093
3094 014426 000004
3095 014430 012737 000005 001202
3096 014436 012737 014566 001442
3097 014444 012737 014460 001444
3098
3099 014452 104410
3100 014454 012702 000012
3101 014460 012761 000040 000004 1$:
3102 014466 104412
3103 014470 122112
3104 014472 104412
3105 014474 021245
3106 014476 012705 000040
3107 014502 116104 000005
3108 014506 042704 000337
3109 014512 120504

```

```

***** TEST 4 *****
*MAINTENANCE REGISTER READ/ONLY TEST
*DO A MASTER CLEAR, VERIFY THAT ALL READ/ONLY
*BITS ARE IN THE CORRECT STATE
*****

; TEST 4
-----
TST4: SCOPE
MOV #4,$STNM ; LOAD THE NO. OF THIS TEST
MOV #TST5,NEXT ; POINT TO THE START OF NEXT TEST.
;R1 CONTAINS BASE KMC11 ADDRESS
MSTCLR ;MASTER CLEAR KMC11
MOV #17,R2 ;SAVE R2 FOR TYPEOUT
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
021004!<20*17> ;PORT4 LINE UNIT REG 17
MOV 4(R1),R4 ;PUT 'FOUND' IN R4
BIC #206,R4 ;CLEAR UNKNOWN BITS
MOV #51,R5 ;PUT 'EXPECTED' IN R5
BIT #BIT13,STAT1 ;IS LU AN M8202 OR M8201?
BEQ .+12 ;BR IF M8201
BIC #40,R4 ;MASK OFF SI BIT IF M8202
BIC #BIT5,R5 ;SI BIT IS UNKNOWN ON AN M8202
CMPB R5,R4 ;ARE SI AND ICIR SET?
BEQ 1$ ;BR IF YES
ERROR 2 ;ERROR IN LU 17
1$:

```

```

***** TEST 5 *****
*LINE UNIT REGISTER WRITE/READ TEST
*SET BITS IN LU REGISTER 12, VERIFY IT IS SET
*CLEAR BITS IN LU REGISTER 12, VERIFY IT IS CLEAR
*****

; TEST 5
-----
TST5: SCOPE
MOV #5,$STNM ; LOAD THE NO. OF THIS TEST
MOV #TST6,NEXT ; POINT TO THE START OF NEXT TEST.
MOV #1$,LOCK ; ADDRESS FOR LOCK ON DATA.
;R1 CONTAINS BASE KMC11 ADDRESS
MSTCLR ;MASTER CLEAR KMC11
MOV #12,R2 ;SAVE REGISTER ADDRESS FOR TYPEOUT
MOV #40,4(R1) ;LOAD PORT4
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122112 ;SET BITS IN LU-12
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
021245 ;READ LU-12
MOV #40,R5 ;PUT 'EXPECTED' IN R5
MOV 5(R1),R4 ;PUT 'FOUND' IN R4
BIC #337,R4 ;CLEAR UNWANTED BITS
CMPB R5,R4 ;IS BITS SET?

```

```

3110 014514 001401 BEQ 2$ ;BR IF YES
3111 014516 104003 ERROR 3 ;ERROR, BIT 5 IS NOT SET
3112 014520 104405 2$: SCOPI ;SCOPE SUBTEST (SW09=1)
3113 014522 012737 014530 001444 MOV #3$,LOCK ;NEW SCOPI
3114 014530 005061 000004 3$: CLR 4(R1) ;LOAD PORT4
3115 014534 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3116 014536 122112 122112 ;CLEAR BIT 5 IN LU-12
3117 014540 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3118 014542 021245 021245 ;READ LU-12
3119 014544 005005 CLR R5 ;PUT 'EXPECTED' IN R5
3120 014546 116104 000005 MOVB 5(R1),R4 ;PUT 'FOUND' IN R4
3121 014552 042704 000337 BIC #337,R4 ;CLEAR UNWANTED BITS
3122 014556 120504 CMPB R5,R4 ;IS BITS CLEAR?
3123 014560 001401 BEQ 4$ ;BR IF YES
3124 014562 104003 ERROR 3 ;ERROR, BITS IS NOT CLEAR
3125 014564 104405 4$: SCOPI ;SCOPE SUBTEST (SW09=1)
3126
3127
3128 ;***** TEST 6 *****
3129 ;*LINE UNIT REGISTER WRITE/READ TEST
3130 ;*SET BIT1 IN LU REGISTER 17, VERIFY IT IS SET
3131 ;*CLEAR BIT1 IN LU REGISTER 17, VERIFY IT IS CLEAR
3132 ;*****
3133
3134 ; TEST 6
3135 -----
3136 ;*****
3137 014566 000004 TST6: SCOPE ;*****
3138 014570 012737 000006 001202 MOV #6,$TSTNM ; LOAD THE NO. OF THIS TEST
3139 014576 012737 014726 001442 MOV #TST7,NEXT ; POINT TO THE START OF NEXT TEST.
3140 014604 012737 014620 001444 MOV #1$,LOCK ; ADDRESS FOR LOCK ON DATA.
3141 ;R1 CONTAINS BASE KMC11 ADDRESS
3142 014612 104410 MSTCLR ;MASTER CLEAR KMC11
3143 014614 012702 000017 MOV #17,R2 ;SAVE REGISTER ADDRESS FOR TYPEOUT
3144 014620 012761 000001 000004 1$: MOV #1,4(R1) ;LOAD PORT4
3145 014626 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3146 014630 122117 122117 ;SET BIT1 IN LU-17
3147 014632 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3148 014634 021365 021365 ;READ LU-17
3149 014636 012705 000001 MOV #1,R5 ;PUT 'EXPECTED' IN R5
3150 014642 116104 000005 MOVB 5(R1),R4 ;PUT 'FOUND' IN R4
3151 014646 042704 000376 BIC #376,R4 ;CLEAR UNWANTED BITS
3152 014652 120504 CMPB R5,R4 ;IS BIT1 SET?
3153 014654 001401 BEQ 2$ ;BR IF YES
3154 014656 104003 ERROR 3 ;ERROR, BIT 1 IS NOT SET
3155 014660 104405 2$: SCOPI ;SCOPE SUBTEST (SW09=1)
3156 014662 012737 014670 001444 MOV #3$,LOCK ;NEW SCOPI
3157 014670 005061 000004 3$: CLR 4(R1) ;LOAD PORT4
3158 014674 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3159 014676 122117 122117 ;CLEAR BIT 1 IN LU-17
3160 014700 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3161 014702 021365 021365 ;READ LU-17
3162 014704 005005 CLR R5 ;PUT 'EXPECTED' IN R5
3163 014706 116104 000005 MOVB 5(R1),R4 ;PUT 'FOUND' IN R4
3164 014712 042704 000376 BIC #376,R4 ;CLEAR UNWANTED BITS
3165 014716 120504 CMPB R5,R4 ;IS BIT1 CLEAR?

```



```

3166 014720 001401          BEQ      48          ;BR IF YES
3167 014722 104003          ERROR    3          ;ERROR, BIT1 IS NOT CLEAR
3168 014724 104405          4$:      SCOPE1     ;SCOPE SUBTEST (SW09=1)
3169
3170
3171          ;***** TEST 7 *****
3172          ;*LINE UNIT REGISTER WRITE/READ TEST
3173          ;*FLOAT A 1 THROUGH LINE UNIT REGISTER 13
3174          ;*FLOAT A 0 THROUGH LINE UNIT REGISTER 13
3175          ;*****
3176
3177          ; TEST 7
3178          ;-----
3179          ;*****
3180 014726 000004          TST7:   SCOPE
3181 014730 012737          MOV      #7,$TSTNM      ; LOAD THE NO. OF THIS TEST
3182 014736 012737 000007 001202  MOV      #TST10,NEXT    ; POINT TO THE START OF NEXT TEST.
3183 014744 012737 014764 001442  MOV      #64$,LOCK      ; ADDRESS FOR LOCK ON DATA.
3184          ;R1 CONTAINS BASE KMC11 ADDRESS
3185 014752 104410          MSTCLR
3186 014754 012702 000013          MOV      #13,R2        ;MASTER CLEAR KMC11
3187 014760 012700 000001          MOV      #1,R0         ;SAVE REGISTER ADDRESS FOR TYPEOUT
3188 014764          64$:      ;START WITH BIT J
3189 014764 010061 000004          MOV      R0,4(R1)      ;PUT PATTERN INTO PORT4
3190 014770 042761 000257 000004  BIC      #257,4(R1)    ;CLEAR UNWANTED BITS
3191 014776 104412          ROMCLK  ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3192 015000 122113          122100!13 ;MOV DATA TO IBUS REGISTER 13
3193 015002 104412          ROMCLK  ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3194 015004 021265          21005!<13*20> ;READ FROM IBUS REGISTER 13
3195 015006 010005          MOV      R0,R5         ;PUT EXPECTED IN R5
3196 015010 042705 000257          BIC      #257,R5       ;CLEAR UNWANTED BITS
3197 015014 116104 000005          MOVB    5(R1),R4      ;PUT 'FOUND' INTO R4
3198 015020 042704 000257          BIC      #257,R4      ;CLEAR UNWANTED BITS
3199 015024 120504          CMPB    R5,R4         ;DATA CORRECT?
3200 015026 001401          BEQ     65$          ;BR IF YES
3201 015030 104003          ERROR    3          ;ERROR
3202 015032 104405          65$:      SCOPE1     ;SW09=1?
3203 015034 000241          CLC          ;CLEAR CARRY
3204 015036 106100          ROLB    R0          ;SHIFT BIT IN R0
3205 015040 001351          BNE     64$          ;IF R0=0 THEN DONE
3206 015042 012737 015056 001444  MOV      #67$,LOCK     ;NEW SCOPE1
3207 015050 012700 000001          MOV      #1,R0         ;START WITH BIT 0
3208 015054 005100          69$:      COM      R0   ;CHANGE TO FLOATING ZERO
3209 015056          67$:
3210 015056 010061 000004          MOV      R0,4(R1)      ;PUT PATTERN INTO PORT4
3211 01506? 042761 000257 000004  BIC      #257,4(R1)    ;CLEAR UNWANTED BITS
3212 015076 104412          ROMCLK  ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3213 015072 122113          122100!13 ;MOV DATA TO IBUS REGISTER 13
3214 015074 104412          ROMCLK  ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3215 015076 021265          21005!<13*20> ;READ FROM IBUS REGISTER 13
3216 015100 010005          MOV      R0,R5         ;PUT EXPECTED IN R5
3217 015102 042705 000257          BIC      #257,R5       ;CLEAR UNWANTED BITS
3218 015106 116104 000005          MOVB    5(R1),R4      ;PUT 'FOUND' INTO R4
3219 015112 042704 000257          BIC      #257,R4      ;CLEAR UNWANTED BITS
3220 015116 120504          CMPB    R5,R4         ;DATA CORRECT?
3221 015120 001401          BEQ     68$          ;BR IF YES

```

3222 015122 104003
 3223 015124 104405
 3224 015126 005100
 3225 015130 000241
 3226 015132 106100
 3227 015134 001347
 3228
 3229
 3230
 3231
 3232
 3233
 3234
 3235
 3236
 3237
 3238

68\$: ERROR 3 :ERROR
 SCOP1 :SW09=1?
 COM RO :CHANGE TO FLOATING 1
 CLC :CLEAR CARRY
 ROLB RO :SHIFT BIT IN RO
 BNE 67\$:IF RO=0 THEN DONE

***** TEST 10 *****
 :*LINE UNIT REGISTER WRITE/READ TEST
 :*FLOAT A 1 THROUGH LINE UNIT REGISTER 14
 :*FLOAT A 0 THROUGH LINE UNIT REGISTER 14
 :*****

: TEST 10
 :-----

3239 015136 000004
 3240 015140 012737 000010 001202
 3241 015146 012737 015312 001442
 3242 015154 012737 015174 001444
 3243
 3244 015162 104410
 3245 015164 012702 000014
 3246 015170 012700 000001
 3247 015174
 3248 015174 010061 000004
 3249 015200 104412
 3250 015202 122114
 3251 015204 104412
 3252 015206 021305
 3253 015210 010005
 3254 015212 116104 000005
 3255 015216 120504
 3256 015220 001401
 3257 015222 104003
 3258 015224 104405
 3259 015226 000241
 3260 015230 106100
 3261 015232 001360
 3262 015234 012737 015250 001444
 3263 015242 012700 000001
 3264 015246 005100
 3265 015250
 3266 015250 010061 000004
 3267 015254 104412
 3268 015256 122114
 3269 015260 104412
 3270 015262 021305
 3271 015264 010005
 3272 015266 116104 000005
 3273 015272 120504
 3274 015274 001401
 3275 015276 104003
 3276 015300 104405
 3277 015302 005100

 TST10: SCOPE :
 MOV #10,\$STNM ; LOAD THE NO. OF THIS TEST
 MOV #TST11,NEXT ; POINT TO THE START OF NEXT TEST.
 MOV #64\$,LOCK ; ADDRESS FOR LOCK ON DATA.
 ;R1 CONTAINS BASE KMC11 ADDRESS
 MSTCLR ;MASTER CLEAR KMC11
 MOV #14,R2 ;SAVE REGISTER ADDRESS FOR TYPEOUT
 MOV #1,RO ;START WITH BIT 0
 64\$: MOV RO,4(R1) ;PUT PATTERN INTO PORT4
 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
 122100!14 ;MOV DATA TO IBUS REGISTER 14
 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
 21005!<14*20> ;READ FROM IBUS REGISTER 14
 MOV RO,R5 ;PUT EXPECTED IN R5
 MOVB 5(R1),R4 ;PUT "FOUND" INTO R4
 CMPB R5,R4 ;DATA CORRECT?
 BEQ 65\$;BR IF YES
 ERROR 3 ;ERROR
 65\$: SCOP1 ;SW09=1?
 CLC ;CLEAR CARRY
 ROLB RO ;SHIFT BIT IN RO
 BNE 64\$;IF RO=0 THEN DONE
 MOV #67\$,LOCK ;NEW SCOPE
 MOV #1,RO ;START WITH BIT 0
 67\$: COM RO ;CHANGE TO FLOATING ZERO
 MOV RO,4(R1) ;PUT PATTERN INTO PORT4
 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
 122100!14 ;MOV DATA TO IBUS REGISTER 14
 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
 21005!<14*20> ;READ FROM IBUS REGISTER 14
 MOV RO,R5 ;PUT EXPECTED IN R5
 MOVB 5(R1),R4 ;PUT "FOUND" INTO R4
 CMPB R5,R4 ;DATA CORRECT?
 BEQ 68\$;BR IF YES
 ERROR 3 ;ERROR
 68\$: SCOP1 ;SW09=1?
 COM RO ;CHANGE TO FLOATING 1

3278 015304 000241 CLC ;CLEAR CARRY
3279 015306 106100 ROLB R0 ;SHIFT BIT IN R0
3280 015310 001356 BNE 69% ;IF R0=0 THEN DONE

3281
3282
3283 :***** TEST 11 *****
3284 :*SWITCH PAC TEST
3285 :*THIS TEST READS SWITCH PAC#1
3286 :*THIS SWITCH PAC CONTAINS THE DDCMP LINE #
3287 :*****

3288
3289 : TEST 11
3290 :-----
3291 :*****
3292 015312 000004 TST11: SCOPE ; LOAD THE NO. OF THIS TEST
3293 015314 012737 000011 001202 MOV #11,\$STNM ; POINT TO THE START OF NEXT TEST.
3294 015322 012737 015354 001442 MOV #TST12,NEXT ;R1 CONTAINS BASE KMC11 ADDRESS
3295 :*****
3296 015330 104410 MSTCLR ;MASTER CLEAR KMC11
3297 015332 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3298 015334 021324 021324 ;PORT4 LU15
3299 015336 016104 000004 MOV 4(R1),R4 ;PUT 'FOUND' IN R4
3300 015342 113705 002052 MOVB STAT2,R5 ;PUT 'EXPECTED' IN R5
3301 015346 120504 CMPB R5,R4 ;SW OK?
3302 015350 001401 BEQ 1% ;BR IF YES
3303 015352 104031 ERROR 31 ;ERROR, SWITCH PAC READ ERROR
3304 015354 1%
3305
3306

3307 :***** TEST 12 *****
3308 :*SWITCH PAC TEST
3309 :*THIS TEST READS SWITCH PAC#2
3310 :*THIS SWITCH PAC CONTAINS THE BM873 BOOT ADD
3311 :*****

3312 : TEST 12
3313 :-----
3314 :*****
3315 :*****
3316 015354 000004 TST12: SCOPE ; LOAD THE NO. OF THIS TEST
3317 015356 012737 000012 001202 MOV #12,\$STNM ; POINT TO THE START OF NEXT TEST.
3318 015364 012737 015416 001442 MOV #TST13,NEXT ;R1 CONTAINS BASE KMC11 ADDRESS
3319 :*****
3320 015372 104410 MSTCLR ;MASTER CLEAR KMC11
3321 015374 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3322 015376 021344 021344 ;PORT4 LU16
3323 015400 016104 000004 MOV 4(R1),R4 ;PUT 'FOUND' IN R4
3324 015404 113705 002053 MOVB STAT2+1,R5 ;PUT 'EXPECTED' IN R5
3325 015410 120504 CMPB R5,R4 ;SW OK?
3326 015412 001401 BEQ 1% ;BR IF YES
3327 015414 104031 ERROR 31 ;ERROR, SWITCH PAC READ ERROR
3328 015416 1%
3329
3330

3331 :***** TEST 13 *****
3332 :*LINE UNIT CLGCK TEST
3333 :*THIS TEST VERIFYS THAT THE LU INTERNAL CLOCK

```

3334 ;*(BIT 1 IN LU-17) IS WORKING
3335 ;*****
3336 ;
3337 ; TEST 13
3338 ;-----
3339 ;*****
3340 TST13: SCOPE
3341 015416 000004 MOV #13,$STNM ; LOAD THE NO. OF THIS TEST
3342 015420 012737 000013 001202 MOV #TST14,NEXT ; POINT TO THE START OF NEXT TEST.
3343 015426 012737 015516 001442 ;R1 CONTAINS BASE KMC11 ADDRESS
3344 015434 104410 MSTCLR ;MASTER CLEAR KMC11
3345 015436 005037 011234 CLR TEMP ;PREPARE FOR DELAY
3346 015442 1$. ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3347 015442 104412 021364 ;PORT4 LU-17
3348 015444 021364 BIT #2,4(R1) ;IS CLOCK BIT SET?
3349 015446 032761 000002 000004 BNE 2$ ;BR IF YES
3350 015454 001004 INC TEMP ;DELAY
3351 015456 005237 011234 BNE 1$ ;DELAY FINISHED?
3352 015462 001367 ERROR 4 ;ERROR BIT IS STUCK CLEAR
3353 015464 104004 2$: CLR TEMP ;PREPARE FOR DELAY
3354 015466 005037 011234 3$: ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3355 015472 021364 ;PORT4 LU-17
3356 015472 104412 BIT #2,4(R1) ;IS CLOCK BIT CLEAR?
3357 015474 021364 BEQ 4$ ;BR IF YES
3358 015476 032761 000002 000004 INC TEMP ;DELAY
3359 015504 001404 BNE 3$ ;BR IF DELAY NOT DONE
3360 015506 005237 011234 ERROR 4 ;ERROR BIT IS STUCK SET
3361 015512 001367 4$:
3362 015514 104004
3363 015516

```

```

3364
3365 ;***** TEST 14 *****
3366 ;*OUT DATA SILO TEST
3367 ;*SET SOM AND LOAD OUT DATA SILO
3368 ;*VERIFY THAT OCOR SET, INDICATING THAT THE
3369 ;*CHARACTER IS AT THE BOTTOM OF THE OUT SILO
3370 ;*****
3371

```

```

3372 ; TEST 14
3373 ;-----
3374 ;*****
3375 TST14: SCOPE
3376 015516 000004 MOV #14,$STNM ; LOAD THE NO. OF THIS TEST
3377 015520 012737 000014 001202 MOV #TST15,NEXT ; POINT TO THE START OF NEXT TEST.
3378 015526 012737 015616 001442 ;R1 CONTAINS BASE KMC11 ADDRESS
3379 015534 104410 MSTCLR ;MASTER CLEAR KMC11
3380 015536 012711 004000 MOV #BIT11,(R1) ;SET LINE UNIT LOOP
3381 015542 012761 000001 000004 MOV #1,4(R1) ;LOAD PORT4 WITH BIT0
3382 015550 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3383 015552 122111 ;SET SOM
3384 015554 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3385 015556 122110 ;LOAD OUT DATA SILO
3386 015560 104414 000002 TIMER, 2 ;WAIT FOR OCOR
3387 015564 012702 000017 MOV #17,R2 ;SAVE ADDRESS FOR TYPEOUT
3388 015570 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3389

```

```

3390 015572 021364          021364          :PORT4 LU 17
3391 015574 016104 000004  MOV      4(R1),R4      :PUT 'FOUND' IN R4
3392 015600 042704 000357  BIC      #357,R4      :CLEAR UNWANTED BITS
3393 015604 012705 000020  MOV      #20,R5       :PUT 'EXPECTED' IN R5
3394 015610 120504          CMPB     R5,R4        :IS OCOR SET?
3395 015612 001401          BEQ      1$           :BR IF YES
3396 015614 104005          ERROR    5
3397 015616

```

1\$:

```

3398
3399
3400 :***** TEST 15 *****
3401 :*DDCMP TEST OF RTS AND OUT ACTIVE
3402 :*SET SOM AND LOAD OUT DATA SILO
3403 :*SINGLE STEP 2 DATA CLOCKS, VERIFY
3404 :*THAT RTS AND ACTIVE ARE SET
3405 :*****
3406

```

3407 : TEST 15

3408 :-----

```

3409 :*****
3410 015616 000004          TST15: SCOPE
3411 015620 012737 000015 001202  MOV      #15,$TSTNM    ; LOAD THE NO. OF THIS TEST
3412 015626 012737 015754 001442  MOV      #TST16,NEXT   ; POINT TO THE START OF NEXT TEST.
3413 :R1 CONTAINS BASE KMC11 ADDRESS
3414 015634 104410          MSTCLR          ;MASTER CLEAR KMC11
3415 015636 012711 004000  MOV      #BIT11,(R1)   ;SET LINE UNIT LOOP
3416 015642 012761 000001 000004  MOV      #1,4(R1)      ;LOAD PORT4 WITH BIT0
3417 015650 104412          ROMCLK         ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3418 015652 122111          122111          ;SET SOM
3419 015654 104412          ROMCLK         ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3420 015656 122110          122110          ;LOAD OUT DATA SILO
3421 015660 004737 030260  JSR      PC,OCOR      ;WAIT FOR OCOR
3422 015664 104413 000002  DATACLK, 2          ;CLOCK DATA FOUR TIMES
3423 015670 012702 000011  MOV      #11,R2       ;SAVE ADDRESS FOR TYPEOUT
3424 015674 104412          ROMCLK         ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3425 015676 021224          021224          ;PORT4 LU 11
3426 015700 016104 000004  MOV      4(R1),R4      ;PUT 'FOUND' IN R4
3427 015704 042704 000257  BIC      #257,R4      ;CLEAR UNWANTED BITS
3428 015710 012705 000120  MOV      #120,R5      ;PUT 'EXPECTED' IN R5
3429 015714 120504          CMPB     R5,R4        ;IS ACTIVE SET?
3430 015716 001401          BEQ      1$           ;BR IF YES
3431 015720 104005          ERROR    5

```

1\$:

```

3432 015722
3433 015722 012702 000013  MOV      #13,R2       ;SAVE ADDRESS FOR TYPEOUT
3434 015726 104412          ROMCLK         ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3435 015730 021264          021264          ;PORT4 LU 13
3436 015732 016104 000004  MOV      4(R1),R4      ;PUT EXPECTED IN R4
3437 015736 042704 000337  BIC      #337,R4      ;CLEAR UNWANTED BITS
3438 015742 012705 000040  MOV      #BIT5,R5     ;PUT 'EXPECTED' IN R5, RTS SHOULD BE SET
3439 015746 120504          CMPB     R5,R4        ;IS RTS OK?
3440 015750 001401          BEQ      2$           ;BR IF YES
3441 015752 104005          ERROR    5           ;RTS ERROR

```

2\$:

```

3442 015754
3443
3444 :***** TEST 16 *****
3445

```

```

3446          : *TEST OF OUT CLEAR
3447          : *SET SOM AND LOAD OUT DATA SILO
3448          : *SINGLE STEP DATA CLOCK, SET OUT CLEAR
3449          : *VERIFY THAT OCOR, RTS, AND ACTIVE ARE CLEARED
3450          : :*****
3451          :
3452          :   TEST 16
3453          :   -----
3454          : :*****
3455 015754 000004          TST16: SCOPE
3456 015756 012737 000016 001202      MOV      #16,$TSTNM          ; LOAD THE NO. OF THIS TEST
3457 015764 012737 016152 001442      MOV      #TST17,NEXT        ; POINT TO THE START OF NEXT TEST.
3458          :R1 CONTAINS BASE KMC11 ADDRESS
3459 015772 104410          MSTCLR          ; MASTER CLEAR KMC11
3460 015774 012711 004000          MOV      #BIT11,(R1)        ; SET LINE UNIT LOOP
3461 016000 012761 000001 000004      MOV      #1,4(R1)          ; LOAD PORT4 WITH BIT0
3462 016006 104412          ROMCLK          ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3463 016010 122111          122111          ; SET SOM
3464 016012 104412          ROMCLK          ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3465 016014 122110          122110          ; LOAD OUT DATA SILO
3466 016016 004737 030260          JSR      PC,OCOR           ; WAIT FOR OCOR
3467 016022 104413 000002          DATACLK, 2          ; CLOCK DATA FOUR TIMES
3468 016026 012761 000200 000004      MOV      #BIT7,4(R1)        ; SET BIT 7 IN PORT4
3469 016034 104412          ROMCLK          ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3470 016036 122111          122111          ; SET OUT CLEAR
3471 016040 104413 000001          DATACLK, 1          ; GIVE A TICK TO CLEAR RTS
3472 016044 012702 000017          MOV      #17,R2            ; SAVE ADDRESS FOR TYPEOUT
3473 016050 104412          ROMCLK          ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3474 016052 021364          021364          ; PORT4 LU 17
3475 016054 016104 000004          MOV      4(R1),R4          ; PUT 'FOUND' IN R4
3476 016060 042704 000357          BIC      #357,R4           ; CLEAR UNWANTED BITS
3477 016064 005005          CLR      R5                ; PUT 'EXPECTED' IN R5
3478 016066 120504          CMPB    R5,R4              ; IS OCOR CLEARED?
3479 016070 001401          BEQ     1$                 ; BR IF YES
3480 016072 104005          ERROR   5
3481 016074          1$:
3482 016074 012702 000013          MOV      #13,R2            ; SAVE ADDRESS FOR TYPEOUT
3483 016100 104412          ROMCLK          ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3484 016102 021264          021264          ; PORT4 LU 13
3485 016104 016104 000004          MOV      4(R1),R4          ; PUT EXPECTED IN R4
3486 016110 042704 000337          BIC      #337,R4           ; CLEAR UNWANTED BITS
3487 016114 005005          CLR      R5                ; PUT 'EXPECTED' IN R5, RTS SHOULD BE CLEARED
3488 016116 120504          CMPB    R5,R4              ; IS RTS OK?
3489 016120 001401          BEQ     2$                 ; BR IF YES
3490 016122 104005          ERROR   5                  ; RTS ERROR
3491 016124          2$:
3492 016124 012702 000011          MOV      #11,R2            ; SAVE ADDRESS FOR TYPEOUT
3493 016130 104412          ROMCLK          ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3494 016132 021224          021224          ; PORT4 LU11
3495 016134 016104 000004          MOV      4(R1),R4          ; PUT 'FOUND' IN R4
3496 016140 012705 000020          MOV      #BIT4,R5          ; ONLY OUT READY SHOULD BE SFT
3497 016144 120504          CMPB    R5,R4              ; IS ACTIVE CLEAR?
3498 016146 001401          BEQ     3$                 ; BR IF YES
3499 016150 104005          ERROR   5                  ; ERROR ACTIVE NOT CLEARED
3500 016152          3$:
3501

```

```

3502
3503
3504
3505
3506
3507
3508
3509
3510
3511
3512
3513
3514 016152 000004
3515 016154 012737 000017 001202
3516 016162 012737 016334 001442
3517
3518 016170 104410
3519 016172 012711 004000
3520 016176 004737 030412
3521 016202 012761 000001 000004
3522 016210 104412
3523 016212 122111
3524 016214 012705 000000
3525 016220 004737 030412
3526 016224 010561 000004
3527 016230 104412
3528 016232 122110
3529 016234 004737 030260
3530 016240 005003
3531 016242 010502
3532 016244 104413 000002
3533 016250 104413 000001
3534 016254 106002
3535 016256 103005
3536 016260 004737 030226
3537 016264 103406
3538 016266 104006
3539 016270 000404
3540 016272 004737 030226
3541 016276 103001
3542 016300 104006
3543 016302
3544 016302 005203
3545 016304 022703 000010
3546 016310 001357
3547 016312 104413 000014
3548 016316 104412
3549 016320 021264
3550 016322 032761 000040 000004
3551 016330 001401
3552 016332 104034
3553 016334
3554
3555
3556
3557

```

```

***** TEST 17 *****
;DDCMP TRANSMITTER TEST
;SINGLE CLOCK THE CHARACTER 0
;VERIFY EACH BIT POSITION AS IT
;PASSES THE BIT WINDOW (SI BIT)
;ON AN ERROR, R3 CONTAINS BIT POSITION OF FAILURE
*****

: TEST 17
-----
*****
TST17: SCOPE
MOV #17,$TSTNM ; LOAD THE NO. OF THIS TEST
MOV #TST20,NEXT ; POINT TO THE START OF NEXT TEST.
;R1 CONTAINS BASE KMC11 ADDRESS
MSTCLR ;MASTER CLEAR KMC11
MOV #BIT11,(R1) ;SET LINE UNIT LOOP
JSR PC,OUTRDY ;WAIT FOR OUT-READY
MOV #1,4(R1) ;SET BIT0 IN PORT4
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122111 ;SET SOM!
MOV #0,R5 ;LOAD CHARACTER IN R5 FOR TYPEOUT
JSR PC,OUTRDY ;WAIT FOR OUT-READY
MOV R5,4(R1) ;LOAD PORT4 WITH CHARACTER
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122110 ;LOAD OUT DATA
JSR PC,OCOR ;WAIT FOR OCOR TO SET
CLR R3 ;CLEAR BIT COUNTER
MOV R5,R2 ;LOAD CHARACTER IN R2
DATACLK, 2 ;2 TICKS TO SET UP TRANSMITTER
DATACLK, 1 ;SHIFT NEXT BIT IN THE WINDOW (SI BIT)
RORB R2 ;SHIFT NEXT SOFTWARE BIT IN TO CARRY
BCC 2$ ;BR IF CARRY CLEAR
JSR PC,GETSI ;GET THE WINDOW
BCS 3$ ;BR IF BIT IS A MARK
ERROR 6 ;ERROR BIT WAS A SPACE
BR 3$ ;CONTINUE WITH TEST
2$: JSR PC,GETSI ;GET THE WINDOW
BCC 3$ ;BR IF BIT IS A SPACE
ERROR 6 ;ERROR BIT WAS A MARK
3$:
INC R3 ;NEXT BIT
CMP #10,R3 ;DONE YET?
BNE 1$ ;BR IF NO
DATACLK, 14 ;CLOCK TRANSMITTER 14 MORE TICKS
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
021264 ;PORT4 LU-13
BIT #BITS,4(R1) ;RTS SHOULD BE CLEAR NOW
BEQ 4$ ;BR IF YES
ERROR 34 ;ERROR, RTS NOT CLEAR
4$:
***** TEST 20 *****
;DDCMP TRANSMITTER TEST

```

```

3558      ;*SINGLE CLOCK THE CHARACTER 125
3559      ;*VERIFY EACH BIT POSITION AS IT
3560      ;*PASSES THE BIT WINDOW (SI BIT)
3561      ;*ON AN ERROR, R3 CONTAINS BIT POSITION OF FAILURE
3562      ;*****
3563
3564      ; TEST 20
3565      ;-----
3566      ;*****
3567      016334 000004          TST20: SCOPE
3568      016336 012737 000020 001202  MOV #20,$TSTNM          ; LOAD THE NO. OF THIS TEST
3569      016344 012737 016516 001442  MOV #TST21,NEXT        ; POINT TO THE START OF NEXT TEST.
3570
3571      016352 104410          MSTCLR          ;R1 CONTAINS BASE KMC11 ADDRESS
3572      016354 012711 004000          MOV #BIT11,(R1)      ;MASTER CLEAR KMC11
3573      016360 004737 030412          JSR PC,OUTRDY        ;SET LINE UNIT LOOP
3574      016364 012761 000001 000004  MOV #1,4(R1)         ;WAIT FOR OUT-READY
3575      016372 104412          ROMCLK          ;SET BIT0 IN PORT4
3576      016374 122111          122111          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3577      016376 012705 000125          MOV #125,R5 ;LOAD CHARACTER IN R5 FOR TYPEOUT
3578      016402 004737 030412          JSR PC,OUTRDY        ;SET SOM!
3579      016406 010561 000004          MOV #5,4(R1)         ;WAIT FOR OUT-READY
3580      016412 104412          ROMCLK          ;LOAD PORT4 WITH CHARACTER
3581      016414 122110          122110          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3582      016416 004737 030260          JSR PC,OCOR          ;LOAD OUT DATA
3583      016422 005003          CLR R3              ;WAIT FOR OCOR TO SET
3584      016424 010502          MOV R5,R2           ;CLEAR BIT COUNTER
3585      016426 104413 000002          DATACLK, 2         ;LOAD CHARACTER IN R2
3586      016432 104413 000001 1$: DATACLK, 1         ;2 TICKS TO SET UP TRANSMITTER
3587      016436 106002          RORB R2             ;SHIFT NEXT BIT IN THE WINDOW (SI BIT)
3588      016440 103005          BCC 2$              ;SHIFT NEXT SOFTWARE BIT IN TO CARRY
3589      016442 004737 030226          JSR PC,GETSI        ;BR IF CARRY CLEAR
3590      016446 103406          BCS 3$              ;GET THE WINDOW
3591      016450 104006          ERROR 6             ;BR IF BIT IS A MARK
3592      016452 000404          BR 3$               ;ERROR BIT WAS A SPACE
3593      016454 004737 030226 2$: JSR PC,GETSI        ;CONTINE WITH TEST
3594      016460 103001          BCC 3$              ;GET THE WINDOW
3595      016462 104006          ERROR 6             ;BR IF BIT IS A SPACE
3596      016464          3$:                ;ERROR BIT WAS A MARK
3597      016464 005203          INC R3              ;NEXT BIT
3598      016466 022703 000010          CMP #10,R3          ;DONE YET?
3599      016472 001357          BNE 1$              ;BR IF NO
3600      016474 104413 000014          DATACLK, 14        ;CLOCK TRANSMITTER 14 MORE TICKS
3601      016500 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3602      016502 021264          021264          ;PORT4 LU-13
3603      016504 032761 000040 000004  BIT #BITS,4(R1)      ;RTS SHOULD BE CLEAR NOW
3604      016512 001401          BEQ 4$              ;BR IF YES
3605      016514 104034          ERROR 34            ;ERROR, RTS NOT CLEAR
3606      016516          4$:
3607
3608
3609      ;***** TEST 21 *****
3610      ;*DDCMP TRANSMITTER TEST
3611      ;*SINGLE CLOCK THE CHARACTER 252
3612      ;*VERIFY EACH BIT POSITION AS IT
3613      ;*PASSES THE BIT WINDOW (SI BIT)

```


3614
3615
3616
3617
3618
3619
3620
3621
3622
3623
3624
3625
3626
3627
3628
3629
3630
3631
3632
3633
3634
3635
3636
3637
3638
3639
3640
3641
3642
3643
3644
3645
3646
3647
3648
3649
3650
3651
3652
3653
3654
3655
3656
3657
3658
3659
3660
3661
3662
3663
3664
3665
3666
3667
3668
3669

016516 000004
016520 012737 000021 001202
016526 012737 016700 001442

016534 104410
016536 012711 004000
016542 004737 030412
016546 012761 000001 000004
016554 104412
016556 122111
016560 012705 000252
016564 004737 030412
016570 010561 000004
016574 104412
016576 122110
016600 004737 030260
016604 005003
016606 010502
016610 104413 000002
016614 104413 000001
016620 106002
016622 103005
016624 004737 030226
016630 103406
016632 104006
016634 000404
016636 004737 030226
016642 103001
016644 104006
016646
016646 005203
016650 022703 000010
016654 001357
016656 104413 000014
016662 104412
016664 021264
016666 032761 000040 000004
016674 001401
016676 104034
016700

```

: *ON AN ERROR, R3 CONTAINS BIT POSITION OF FAILURE
: *****
: TEST 21
: -----
: *****
TST21: SCOPE
MOV #21,$STNM ; LOAD THE NO. OF THIS TEST
MOV #TST22,NEXT ; POINT TO THE START OF NEXT TEST.
; R1 CONTAINS BASE KMC11 ADDRESS
MSTCLR ; MASTER CLEAR KMC11
MOV #BIT11,(R1) ; SET LINE UNIT LOOP
JSR PC,OUTRDY ; WAIT FOR OUT-READY
MOV #1,4(R1) ; SET BIT0 IN PORT4
ROMCLK ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122111 ; SET SOM!
MOV #252,R5 ; LOAD CHARACTER IN R5 FOR TYPEOUT
JSR PC,OUTRDY ; WAIT FOR OUT-READY
MOV R5,4(R1) ; LOAD PORT4 WITH CHARACTER
ROMCLK ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122110 ; LOAD OUT DATA
JSR PC,OCOR ; WAIT FOR OCOR TO SET
CLR R3 ; CLEAR BIT COUNTER
MOV R5,R2 ; LOAD CHARACTER IN R2
DATACLK, 2 ; 2 TICKS TO SET UP TRANSMITTER
1$: DATACLK, 1 ; SHIFT NEXT BIT IN THE WINDOW (SI BIT)
RORB R2 ; SHIFT NEXT SOFTWARE BIT IN TO CARRY
BCC 2$ ; BR IF CARRY CLEAR
JSR PC,GETSI ; GET THE WINDOW
BCS 3$ ; BR IF BIT IS A MARK
ERROR 6 ; ERROR BIT WAS A SPACE
BR 3$ ; CONTINE WITH TEST
2$: JSR PC,GETSI ; GET THE WINDOW
BCC 3$ ; BR IF BIT IS A SPACE
ERROR 6 ; ERROR BIT WAS A MARK
3$: INC R3 ; NEXT BIT
CMP #10,R3 ; DONE YET?
BNE 1$ ; BR IF NO
DATACLK, 14 ; CLOCK TRANSMITTER 14 MORE TICKS
ROMCLK ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
021264 ; PORT4 LU-13
BIT #BITS,4(R1) ; RTS SHOULD BE CLEAR NOW
BEQ 4$ ; BR IF YES
ERROR 34 ; ERROR, RTS NOT CLEAR
4$:

```

```

: ***** TEST 22 *****
: *DDCMP TRANSMITTER TEST
: *SINGLE CLOCK THE CHARACTER 377
: *VERIFY EACH BIT POSITION AS IT
: *PASSES THE BIT WINDOW (SI BIT)
: *ON AN ERROR, R3 CONTAINS BIT POSITION OF FAILURE
: *****

```

```

3670          : TEST 22
3671          :-----
3672          :*****
3673 016700 000004          :TST22: SCOPE
3674 016702 012737 000022 001202      MOV #22,$TSTNM          ; LOAD THE NO. OF THIS TEST
3675 016710 012737 017062 001442      MOV #TST23,NEXT        ; POINT TO THE START OF NEXT TEST.
3676          :*****
3677 016716 104410          MSTCLR                ;R1 CONTAINS BASE KMC11 ADDRESS
3678 016720 012711 004000          MOV #BIT11,(R1)        ;MASTER CLEAR KMC11
3679 016724 004737 030412          JSR PC,OUTRDY          ;SET LINE UNIT LOOP
3680 016730 012761 000001 000004      MOV #1,4(R1)           ;WAIT FOR OUT-READY
3681 016736 104412          ROMCLK                ;SET BIT0 IN PORT4
3682 016740 122111          122111                ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3683 016742 012705 000377          MOV #377,R5           ;SET SOM!
3684 016746 004737 030412          JSR PC,OUTRDY          ;LOAD CHARACTER IN R5 FOR TYPEOUT
3685 016752 010561 000004          MOV R5,4(R1)          ;WAIT FOR OUT-READY
3686 016756 104412          ROMCLK                ;LOAD PORT4 WITH CHARACTER
3687 016760 122110          122110                ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3688 016762 004737 030260          JSR PC,OCOR            ;LOAD OUT DATA
3689 016766 005003          CLR R3                ;WAIT FOR OCOR TO SET
3690 016770 010502          MOV R5,R2             ;CLEAR BIT COUNTER
3691 016772 104413 000002          DATACLK, 2           ;LOAD CHARACTER IN R2
3692 016776 104413 000001          1$: DATACLK, 1        ;2 TICKS TO SET UP TRANSMITTER
3693 017002 106002          RORB R2               ;SHIFT NEXT BIT IN THE WINDOW (SI BIT)
3694 017004 103000          BCC 2$                ;SHIFT NEXT SOFTWARE BIT IN TO CARRY
3695 017006 004737 030226          JSR PC,GETSI          ;BR IF CARRY CLEAR
3696 017012 103406          BCS 3$                ;GET THE WINDOW
3697 017014 104006          ERROR 6               ;BR IF BIT IS A MARK
3698 017016 000404          BR 3$                 ;ERROR BIT WAS A SPACE
3699 017020 004737 030226          2$: JSR PC,GETSI          ;CONTINE WITH TEST
3700 017024 103001          BCC 3$                ;GET THE WINDOW
3701 017026 104006          ERROR 6               ;BR IF BIT IS A SPACE
3702          3$:          ;ERROR BIT WAS A MARK
3703 017030          INC R3                ;NEXT BIT
3704 017032 022703 000010          CMP #10,R3            ;DONE YET?
3705 017036 001357          BNE 1$                ;BR IF NO
3706 017040 104413 000014          DATACLK, 14          ;CLOCK TRANSMITTER 14 MORE T,CKS
3707 017044 104412          ROMCLK                ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3708 017046 021264          021264                ;PORT4 LU-13
3709 017050 032761 000040 000004      BIT #BITS,4(R1)        ;RTS SHOULD BE CLEAR NOW
3710 017056 001401          BEQ 4$                ;BR IF YES
3711 017060 104034          ERROR 34              ;ERROR, RTS NOT CLEAR
3712          4$:
3713
3714
3715          :***** TEST 23 *****
3716          :*DDCMP TRANSMITTER TEST
3717          :*SINGLE CLOCK A BINARY COUNT PATTERN
3718          :*VERIFY EACH BIT POSITION AS IT
3719          :*PASSES THE BIT WINDOW (SI BIT)
3720          :*ON AN ERROR, R3 CONTAINS BIT POSITION OF FAILURE
3721          :*AND R5 CONTAINS THE CHARACTER THAT FAILED
3722          :*****
3723
3724          : TEST 23
3725          :-----
    
```

```

3726 .....
3727 017062 000004 TST23: SCOPE
3728 017064 012737 000023 001202 MOV #23,$TSTNM ; LOAD THE NO. OF THIS TEST
3729 017072 012737 017270 001442 MOV #TST24,NEXT ; POINT TO THE START OF NEXT TEST.
3730 ;R1 CONTAINS BASE KMC11 ADDRESS
3731 017100 104410 MSTCLR ;MASTER CLEAR KMC11
3732 017102 012711 004000 MOV #BIT11,(R1) ;SET LINE UNIT LOOP
3733 017106 005003 CLR R3 ;R3 CONTAINS BIT COUNT
3734 017110 005004 CLR R4 ;R4 CONTAINS CHAR TO BE LOADED IN SILO
3735 017112 005005 CLR R5 ;R5 CONTAINS CHARACTER CURRENTLY BEING SHIFTED OUT
3736 017114 004737 030412 JSR PC,OUTRDY ;WAIT FOR OUT-READY
3737 017120 012761 000001 000004 MOV #1,4(R1) ;SET BIT0 IN PORT4
3738 017126 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3739 017130 122111 122111 ;SET SOM!
3740 017132 004737 030412 JSR PC,OUTRDY ;WAIT FOR OUT-READY
3741 017136 010461 000004 MOV R4,4(R1) ;LOAD PORT4 WITH CHARACTER
3742 017142 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3743 017144 122110 122110 ;LOAD OUT DATA
3744 017146 005204 INC R4 ;INCREMENT TO NEXT CHARACTER
3745 017150 004737 030412 JSR PC,OUTRDY ;WAIT FOR OUT-READY
3746 017154 010461 000004 MOV R4,4(R1) ;LOAD PORT4 WITH CHARACTER
3747 017160 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3748 017162 122110 122110 ;LOAD OUT DATA
3749 017164 004737 030260 JSR PC,OCOR ;WAIT FOR OCOR TO SET
3750 017170 104413 000002 DATACLK, 2 ;2 TICKS TO SET UP TRANSMITTER
3751 017174 005003 4$: CLR R3 ;CLEAR BIT COUNTER
3752 017176 010502 MOV R5,R2 ;LOAD CHARACTER IN R2
3753 017200 104413 000001 1$: DATACLK, 1 ;SHIFT NEXT BIT IN THE WINDOW (SI BIT)
3754 017204 106002 RORB R2 ;SHIFT NEXT SOFTWARE BIT IN TO CARRY
3755 017206 103005 BCC 2$ ;BR IF CARRY CLEAR
3756 017210 004737 030226 JSR PC,GETSI ;GET THE WINDOW
3757 017214 103406 BCS 3$ ;BR IF BIT IS A MARK
3758 017216 104006 ERROR 6 ;ERROR BIT WAS A SPACE
3759 017220 000404 BR 3$ ;CONTINUE WITH TEST
3760 017222 004737 030226 2$: JSR PC,GETSI ;GET THE WINDOW
3761 017226 103001 BCC 3$ ;BR IF BIT IS A SPACE
3762 017230 104006 ERROR 6 ;ERROR BIT WAS A MARK
3763 3$:
3764 017232 005203 INC R3 ;NEXT BIT
3765 017234 022703 000010 CMP #10,R3 ;DONE YET?
3766 017240 001357 BNE 1$ ;BR IF NO
3767 017242 005204 INC R4 ;NEXT CHARACTER
3768 017244 004737 030412 JSR PC,OUTRDY ;WAIT FOR OUT-READY
3769 017250 010461 000004 MOV R4,4(R1) ;LOAD PORT4 WITH CHARACTER
3770 017254 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3771 017256 122110 122110 ;LOAD OUT DATA
3772 017260 005205 INC R5 ;NEXT CHARACTER
3773 017262 022705 000400 CMP #400,R5 ;DONE YET?
3774 017266 001342 BNE 4$ ;BR IF NO
3775 5$:
3776
3777
3778
3779
3780
3781

```

```

***** TEST 24 *****
*DDCMP STRIP SYNC TEST
*SET LU LOOP, SINGLE STEP 5 SYNCs.
*VERIFY THAT IM ACTIVE DOES NOT SET

```

```
3782 ;*****  
3783 ;  
3784 ; TEST 24  
3785 ;-----  
3786 ;*****  
3787 017270 000004 TST24: SCOPE ;  
3788 017272 012737 000024 001202 MOV #24,$TSTNM ; LOAD THE NO. OF THIS TEST  
3789 017300 012737 017356 001442 MOV #TST25,NEXT ; POINT TO THE START OF NEXT TEST.  
3790 ;R1 CONTAINS BASE KMC11 ADDRESS  
3791 017306 104410 MSTCLR ;MASTER CLEAR KMC11  
3792 017310 012711 004000 MOV #BIT11,(R1) ;SET LU LOOP  
3793 017314 012702 000012 MOV #12,R2 ;SAVE LU REG FOR TYPEOUT  
3794 017320 004737 030276 JSR PC,SYNC ;SINGLE CLOCK 5 SYNC CHARACTERS  
3795 017324 000005 5  
3796 017326 104413 000054 DATACLK, 54 ;  
3797 017332 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
3798 017334 021244 021244 ;PORT4 LU12  
3799 017336 016104 000004 MOV 4(R1),R4 ;PUT 'FOUND' IN R4  
3800 017342 042704 000277 BIC #277,R4 ;CLEAR UNWANTED BITS  
3801 017346 005005 CLR R5 ;PUT 'EXPECTED' IN R5  
3802 017350 120504 CMPB R5,R4 ;IS ACTIVE CLEAR?  
3803 017352 001401 BEQ 1$ ;BR IF YES  
3804 017354 104040 ERROR 40 ;ERROR ACTIVE IS NOT CLEAR  
3805 1$:  
3806  
3807  
3808 ;***** TEST 25 *****  
3809 ;*DDCMP IN ACTIVE TEST  
3810 ;*SET LU LOOP, SINGLE STEP 5 SYNCs AND A NON-SYNC (301)  
3811 ;*VERIFY THAT IN ACTIVE IS SET  
3812 ;*****  
3813 ;  
3814 ; TEST 25  
3815 ;-----  
3816 ;*****  
3817 017356 000004 TST25: SCOPE ;  
3818 017360 012737 000025 001202 MOV #25,$TSTNM ; LOAD THE NO. OF THIS TEST  
3819 017366 012737 017446 001442 MOV #TST26,NEXT ; POINT TO THE START OF NEXT TEST.  
3820 ;R1 CONTAINS BASE KMC11 ADDRESS  
3821 017374 104410 MSTCLR ;MASTER CLEAR KMC11  
3822 017376 012711 004000 MOV #BIT11,(R1) ;SET LU LOOP  
3823 017402 012702 000012 MOV #12,R2 ;SAVE LU REG FOR TYPEOUT  
3824 017406 004737 030276 JSR PC,SYNC ;SINGLE CLOCK 5 SYNC CHARACTERS  
3825 017412 000005 5  
3826 017414 104413 000064 DATACLK, 64 ;  
3827 017420 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304  
3828 017422 021244 021244 ;PORT4 LU12  
3829 017424 016104 000004 MOV 4(R1),R4 ;PUT 'FOUND' IN R4  
3830 017430 042704 000277 BIC #277,R4 ;CLEAR UNWANTED BITS  
3831 017434 012705 000100 MOV #BIT6,R5 ;PUT 'EXPECTED' IN R5  
3832 017440 120504 CMPB R5,R4 ;IS ACTIVE SET?  
3833 017442 001401 BEQ 1$ ;BR IF YES  
3834 017444 104040 ERROR 40 ;ERROR ACTIVE IS NOT SET  
3835 1$:  
3836  
3837
```

```

3838 :***** TEST 26 *****
3839 :*DDCMP IN ACTIVE TEST
3840 :*SET LU LOOP, SINGLE STEP 1 SYNC AND A NON-SYNC (301)
3841 :*VERIFY THAT IN ACTIVE DOES NOT SET
3842 :*****
3843
3844 ; TEST 26
3845 :-----
3846 :*****

```

```

3847 017446 000004 TST26: SCOPE
3848 017450 012737 000026 001202 MOV #26,$STNM ; LOAD THE NO. OF THIS TEST
3849 017456 012737 017534 001442 MOV #TST27,NEXT ; POINT TO THE START OF NEXT TEST.
3850 ;R1 CONTAINS BASE KMC11 ADDRESS
3851 017464 104410 MSTCLR ;MASTER CLEAR KMC11
3852 017466 012711 004000 MOV #BIT11,(R1) ;SET LU LOOP
3853 017472 012702 000012 MOV #12,R2 ;SAVE LU REG FOR TYPEOUT
3854 017476 004737 030276 JSR PC,SYNC ;SINGLE CLOCK 1 SYNC CHARACTERS
3855 017502 000001 1
3856 017504 104413 000024 DATACLK, 24
3857 017510 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3858 017512 021244 021244 ;PORT4_LU12
3859 017514 016104 000004 MOV 4(R1),R4 ;PUT 'FOUND' IN R4
3860 017520 042704 000277 BIC #277,R4 ;CLEAR UNWANTED BITS
3861 017524 005005 CLR R5 ;PUT 'EXPECTED' IN R5
3862 017526 120504 CMPB R5,R4 ;IS ACTIVE CLEAR?
3863 017530 001401 BEQ 1$ ;BR IF YES
3864 017532 104040 ERROR 40 ;ERROR ACTIVE IS NOT CLEAR
3865 017534 1$

```

```

3866
3867
3868 :***** TEST 27 *****
3869 :*DDCMP IN ACTIVE TEST
3870 :*SET LU LOOP, SINGLE STEP 2 SYNC AND A NON-SYNC (301)
3871 :*VERIFY THAT IN ACTIVE IS SET
3872 :*****
3873
3874 ; TEST 27
3875 :-----
3876 :*****

```

```

3877 017534 000004 TST27: SCOPE
3878 017536 012737 000027 001202 MOV #27,$STNM ; LOAD THE NO. OF THIS TEST
3879 017544 012737 017624 001442 MOV #TST30,NEXT ; POINT TO THE START OF NEXT TEST.
3880 ;R1 CONTAINS BASE KMC11 ADDRESS
3881 017552 104410 MSTCLR ;MASTER CLEAR KMC11
3882 017554 012711 004000 MOV #BIT11,(R1) ;SET LU LOOP
3883 017560 012702 000012 MOV #12,R2 ;SAVE LU REG FOR TYPEOUT
3884 017564 004737 030276 JSR PC,SYNC ;SINGLE CLOCK 2 SYNC CHARACTERS
3885 017570 000002 2
3886 017572 104413 000034 DATACLK, 34
3887 017576 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3888 017600 021244 021244 ;PORT4_LU12
3889 017602 016104 000004 MOV 4(R1),R4 ;PUT 'FOUND' IN R4
3890 017606 042704 000277 BIC #277,R4 ;CLEAR UNWANTED BITS
3891 017612 012705 000100 MOV #BIT6,R5 ;PUT 'EXPECTED' IN R5
3892 017616 120504 CMPB R5,R4 ;IS ACTIVE SET?
3893 017620 001401 BEQ 1$ ;BR IF YES

```

3894 017622 104040 ERROR 40 :ERROR ACTIVE IS NOT SET
3895 017624 1\$:

3896
3897
3898 :***** TEST 30 *****
3899 :IN CLEAR TEST
3900 :SYNC UP RECEIVER AND TRANSMIT A CHARACTER
3901 :WAIT FOR IN RDY, THEN SET IN CLEAR
3902 :VERIFY THAT IN ACTIVE AND IN RDY ARE CLEARED
3903 :*****

3904
3905 : TEST 30
3906 :-----

3907 :*****
3908 017624 000004 TST30: SCOPE
3909 017626 012737 000030 001202 MOV #30,\$TSTNM : LOAD THE NO. OF THIS TEST
3910 017634 012737 017776 001442 MOV #TST31,NEXT : POINT TO THE START OF NEXT TEST.
3911 :R1 CONTAINS BASE KMC11 ADDRESS
3912 017642 104410 MSTCLR :MASTER CLEAR KMC11
3913 017644 012702 000012 MOV #12,R2 :SAVE REG ADDRESS IN R2 FOR TYPEOUT
3914 017650 012711 004000 MOV #BIT11,(R1) :SET LINE UNIT LOOP
3915 017654 004737 030444 JSR PC,CHAR :LOAD SILO WITH 3 SYNCs
3916 017660 000301 301 :AND A NON-SYNC (301)
3917 017662 104413 000053 DATACLK, 53 :SINGLE CLOCK THE DATA
3918 017666 104414 000002 TIMER, 2 :WAIT FOR INRDY
3919 017672 104412 ROMCLK :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3920 017674 021244 021244 :PORT4 LU 12
3921 017676 016104 000004 MOV 4(R1),R4 :PUT 'FOUND' IN R4
3922 017702 042704 000357 BIC #357,R4 :CLEAR UNWANTED BITS
3923 017706 012705 000020 MOV #BIT4,R5 :PUT 'EXPECTED' IN R5
3924 017712 120504 CMPB R5,R4 :IS INRDY SET?
3925 017714 001401 BEQ 1\$
3926 017716 104040 ERROR 40 :ERROR, INRDY IS NOT SET

3927 017720 1\$:
3928 017720 012761 000200 000004 MOV #BIT7,4(R1) :LOAD PORT4
3929 017726 104412 ROMCLK :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3930 017730 122112 122112 :SET IN CLEAR
3931 017732 104412 ROMCLK :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3932 017734 021244 021244 :PORT4 LU 12
3933 017736 016104 000004 MOV 4(R1),R4 :PUT 'FOUND' IN R4
3934 017742 042704 000277 BIC #277,R4 :CLEAR UNWANTED BITS
3935 017746 005005 CLR R5 :PUT 'EXPECTED' IN R5
3936 017750 120504 CMPB R5,R4 :IS IN ACTIVE CLEAR?
3937 017752 001401 BEQ 2\$
3938 017754 104040 ERROR 40 :ERROR, IN ACTIVE IS NOT CLEAR

3939 017756 2\$:
3940 017756 016104 000004 MOV 4(R1),R4 :PUT 'FOUND' IN R4
3941 017762 042704 000357 BIC #357,R4 :CLEAR UNWANTED BITS
3942 017766 005005 CLR R5 :PUT 'EXPECTED' IN R5
3943 017770 120504 CMPB R5,R4 :IS INRDY CLEARED?
3944 017772 001401 BEQ 3\$
3945 017774 104040 ERROR 40 :ERROR, INRDY IS NOT CLEARED

3946 017776 3\$:
3947
3948 :***** TEST 31 *****
3949

3950 : *DDCMP BASIC RECEIVER TEST
3951 : *SYNC UP RECEIVER AND SINGLE CLOCK THE CHARACTER 0
3952 : *VERIFY THAT IN RDY IS SET, AND THAT THE CHARACTER WAS RECEIVED
3953 : :
3954 :
3955 :
3956 :
3957 :

: TEST 31

3958	017776	000004			TST31: SCOPE	
3959	020000	012737	000031	001202	MOV #31,STSTNM	: LOAD THE NO. OF THIS TEST
3960	020006	012737	020112	001442	MOV #TST32,NEXT	: POINT TO THE START OF NEXT TEST.
3961						: R1 CONTAINS BASE KMC11 ADDRESS
3962	020014	104410			MSTCLR	: MASTER CLEAR KMC11
3963	020016	012702	000012		MOV #12,R2	: SAVE REG ADDRESS IN R2 FOR TYPEOUT
3964	020022	012711	004000		MOV #BIT11,(R1)	: SET LINE UNIT LOOP
3965	020026	004737	030444		JSR PC,CHAR	: LOAD SILO WITH 3 SYNC
3966	020032	000000			0	: AND THE CHARACTER 0
3967	020034	104413	000053		DATACLK, 53	: SINGLE CLOCK THE DATA
3968	020040	104414	000002		TIMER, 2	: WAIT FOR INRDY
3969	020044	104412			ROMCLK	: NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3970	020046	021244			021244	: PORT4 LU 12
3971	020050	016104	000004		MOV 4(R1),R4	: PUT 'FOUND' IN R4
3972	020054	042704	000357		BIC #357,R4	: CLEAR UNWANTED BITS
3973	020060	012705	000020		MOV #BIT4,R5	: PUT 'EXPECTED' IN R5
3974	020064	120504			CMPB R5,R4	: IS INRDY SET?
3975	020066	001401			BEQ 1\$	
3976	020070	104040			ERROR 40	: ERROR, INRDY IS NOT SET
3977	020072					
3978	020072	104412			1\$: ROMCLK	: NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
3979	020074	021204			021204	: PORT4 IN DATA
3980	020076	016104	000004		MOV 4(R1),R4	: PUT 'FOUND' IN R4
3981	020102	005005			CLR R5	: PUT 'EXPECTED' IN R5
3982	020104	120504			CMPB R5,R4	: WAS A 0 RECEIVED?
3983	020106	001401			BEQ 2\$	
3984	020110	104010			ERROR 10	: ERROR, RECEIVED DATA IS WRONG
3985	020112				2\$:	

: ***** TEST 32 *****

3988 : *DDCMP BASIC RECEIVER TEST
3989 : *SYNC UP RECEIVER AND SINGLE CLOCK THE CHARACTER 125
3990 : *VERIFY THAT IN RDY IS SET, AND THAT THE CHARACTER WAS RECEIVED
3991 : :
3992 :
3993 :
3994 :
3995 :

: TEST 32

3997	020112	000004			TST32: SCOPE	
3998	020114	012737	000032	001202	MOV #32,STSTNM	: LOAD THE NO. OF THIS TEST
3999	020122	012737	020230	001442	MOV #TST33,NEXT	: POINT TO THE START OF NEXT TEST.
4000						: R1 CONTAINS BASE KMC11 ADDRESS
4001	020130	104410			MSTCLR	: MASTER CLEAR KMC11
4002	020132	012702	000012		MOV #12,R2	: SAVE REG ADDRESS IN R2 FOR TYPEOUT
4003	020136	012711	004000		MOV #BIT11,(R1)	: SET LINE UNIT LOOP
4004	020142	004737	030444		JSR PC,CHAR	: LOAD SILO WITH 3 SYNC
4005	020146	000125			125	: AND THE CHARACTER 125

```

4006 020150 104413 000053          DATACLK,          53          :SINGLE CLOCK THE DATA
4007 020154 104414 000002          TIMER,           2          :WAIT FOR INRDY
4008 020160 104412                    ROMCLK           :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4009 020162 021244                    021244          :PORT4 LU 12
4010 020164 016104 000004          MOV              4(R1),R4    :PUT 'FOUND' IN R4
4011 020170 042704 000357          BIC              #357,R4    :CLEAR UNWANTED BITS
4012 020174 012705 000020          MOV              #BIT4,R5   :PUT 'EXPECTED' IN R5
4013 020200 120504                    CMPB             R5,R4       :IS INRDY SET?
4014 020202 001401                    BEQ              1$
4015 020204 104040                    ERROR           40          :ERROR, INRDY IS NOT SET
4016 020206                    1$:
4017 020206 104412                    ROMCLK           :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4018 020210 021204                    021204          :PORT4 IN DATA
4019 020212 016104 000004          MOV              4(R1),R4    :PUT 'FOUND' IN R4
4020 020216 012705 000125          MOV              #125,R5    :PUT 'EXPECTED' IN R5
4021 020222 120504                    CMPB             R5,R4       :WAS A 125 RECEIVED?
4022 020224 001401                    BEQ              2$
4023 020226 104010                    ERROR           10          :ERROR, RECEIVED DATA IS WRONG
4024 020230                    2$:
4025
4026
4027
4028
4029
4030
4031
4032
4033
4034
4035

```

```

:***** TEST 33 *****
:*DDCMP BASIC RECEICER TEST
:*SYNC UP RECEIVER AND SINGLE CLOCK THE CHARACTER 252
:*VERIFY THAT IN RDY IS SET, AND THAT THE CHARACTER WAS RECEIVED
:*****

```

: TEST 33

```

4036 020230 000004                    :*****
4037 020232 012737 000033 001202 1$T33: SCOPE
4038 020240 012737 020346 001442          MOV              #33,$TSTNM   : LOAD THE NO. OF THIS TEST
4039                    MOV              #TST34,NEXT    : POINT TO THE START OF NEXT TEST.
4040 020246 104410                    MSTCLR           :R1 CONTAINS BASE KMC11 ADDRESS
4041 020250 012702 000012          MOV              #12,R2      :MASTER CLEAR KMC11
4042 020254 012711 004000          MOV              #BIT11,(R1) :SAVE REG ADDRESS IN R2 FOR TYPEOUT
4043 020260 004737 030444          JSR              PC,CHAR     :SET LINE UNIT LOOP
4044 020264 000252                    252              :LOAD SILO WITH 3 SYNCs
4045 020266 104413 000053          DATACLK,          53          :AND THE CHARACTER 252
4046 020272 104414 000002          TIMER,           2          :SINGLE CLOCK THE DATA
4047 020276 104412                    ROMCLK           :WAIT FOR INRDY
4048 020300 021244                    021244          :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4049 020302 016104 000004          MOV              4(R1),R4    :PORT4 LU 12
4050 020306 042704 000357          BIC              #357,R4    :PUT 'FOUND' IN R4
4051 020312 012705 000020          MOV              #BIT4,R5   :CLEAR UNWANTED BITS
4052 020316 120504                    CMPB             R5,R4       :PUT 'EXPECTED' IN R5
4053 020320 001401                    BEQ              1$
4054 020322 104040                    ERROR           40          :IS INRDY SET?
4055 020324                    1$:
4056 020324 104412                    ROMCLK           :ERROR, INRDY IS NOT SET
4057 020326 021204                    021204          :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4058 020330 016104 000004          MOV              4(R1),R4    :PORT4 IN DATA
4059 020334 012705 000252          MOV              #252,R5    :PUT 'FOUND' IN R4
4060 020340 120504                    CMPB             R5,R4       :PUT 'EXPECTED' IN R5
4061 020342 001401                    BEQ              2$          :WAS A 252 RECEIVED?

```



```
4062 020344 104010          ERROR 10          ;ERROR, RECEIVED DATA IS WRONG
4063 020346          2$:
4064
4065
4066          ;***** TEST 34 *****
4067          ;*DDCMP BASIC RECEIVER TEST
4068          ;*SYNC UP RECEIVER AND SINGLE CLOCK THE CHARACTER 377
4069          ;*VERIFY THAT IN RDY IS SET, AND THAT THE CHARACTER WAS RECEIVED
4070          ;:*****
4071
4072          ; TEST 34
4073          ;-----
4074          ;:*****
4075 020346 000004          TST34: SCOPE
4076 020350 012737 000034 001202          MOV #34,$TSTNM          ; LOAD THE NO. OF THIS TEST
4077 020356 012737 020464 001442          MOV #TST35,NEXT          ; POINT TO THE START OF NEXT TEST.
4078          ;R1 CONTAINS BASE KMC11 ADDRESS
4079 020364 104410          MSTCLR          ;MASTER CLEAR KMC11
4080 020366 012702 000012          MOV #12,R2          ;SAVE REG ADDRESS IN R2 FOR TYPEOUT
4081 020372 012711 004000          MOV #BIT11,(R1)      ;SET LINE UNIT LOOP
4082 020376 004737 030444          JSR PC,CHAR          ;LOAD SILO WITH 3 SYNCs
4083 020402 000377          377          ;AND THE CHARACTER 377
4084 020404 104413 000053          DATACLK, 53          ;SINGLE CLOCK THE DATA
4085 020410 104414 000002          TIMER, 2          ;WAIT FOR INRDY
4086 020414 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4087 020416 021244          021244          ;PORT4 LU 12
4088 020420 016104 000004          MOV 4(R1),R4          ;PUT 'FOUND' IN R4
4089 020424 042704 000357          BIC #357,R4          ;CLEAR UNWANTED BITS
4090 020430 012705 000020          MOV #BIT4,R5          ;PUT 'EXPECTED' IN R5
4091 020434 120504          CMPB R5,R4          ;IS INRDY SET?
4092 020436 001401          BEQ 1$
4093 020440 104040          ERROR 40          ;ERROR, INRDY IS NOT SET
4094 020442          1$:
4095 020442 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4096 020444 021204          021204          ;PORT4 IN DATA
4097 020446 016104 000004          MOV 4(R1),R4          ;PUT 'FOUND' IN R4
4098 020452 012705 000377          MOV #377,R5          ;PUT 'EXPECTED' IN R5
4099 020456 120504          CMPB R5,R4          ;WAS A 377 RECEIVED?
4100 020460 001401          BEQ 2$
4101 020462 104010          ERROR 10          ;ERROR, RECEIVED DATA IS WRONG
4102 020464          2$:
4103
4104
4105          ;***** TEST 35 *****
4106          ;*DDCMP DATA TEST
4107          ;*THIS TEST SINGLE STEPS A BINARY COUNT PATTERN
4108          ;*CHECKING EACH CHARACTER AS IT IS RECEIVED
4109          ;:*****
4110
4111          ; TEST 35
4112          ;-----
4113          ;:*****
4114 020464 000004          TST35: SCOPE
4115 020466 012737 000035 001202          MOV #35,$TSTNM          ; LOAD THE NO. OF THIS TEST
4116 020474 012737 020514 001442          MOV #TST36,NEXT          ; POINT TO THE START OF NEXT TEST.
4117          ;R1 CONTAINS BASE KMC11 ADDRESS
```

4118	020502	104410		MSTCLR		:MASTER CLEAR KMC11
4119	020504	005037	031062	CLR	SCHAR	:START BINARY COUNT AT ZERO
4120	020510	005037	031064	CLR	STUFLG	:CLEAR BITSTUFF FLAG
4121	020514	005002		CLR	R2	:R2 IS 'EXPECTED' DATA
4122	020516	012703	000073	MOV	#73,R3	:R3 IS CHARACTER COUNT
4123	020522	012711	004000	MOV	#BIT11,(R1)	:SET LINE UNIT LOOP
4124	020526	004737	030622	JSR	PC,S:LOLD	:LOAD SILO WITH COUNT PATTERN
4125	020532	104413	000043	DATACLK,	43	:SYNC RECEIVER AND GET IT ACTIVE
4126	020536	104413	000730	1\$: DATACLK,	730	:CLOCK IN 73 CHARACTERS
4127	020542	004737	031066	4\$: JSR	PC,INRDY	:WAIT FOR INRDY
4128	020546	104412		ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4129	020550	021204		021204		:PORT4 IN DATA
4130	020552	016104	000004	MOV	4(R1),R4	:PUT 'FOUND' IN R4
4131	020556	010205		MOV	R2,R5	:PUT 'EXPECTED' IN R5
4132	020560	120504		CMQB	R5,R4	:IS DATA CORRECT?
4133	020562	001401		BEQ	2\$:BR IF YES
4134	020564	104010		ERROR	10	:DATA ERROR
4135	020566	005202		2\$: INC	R2	:NEXT CHARACTER
4136	020570	022702	000400	CMP	#400,R2	:ALL DONE?
4137	020574	001407		BEQ	3\$:BR IF YES
4138	020576	005303		DEC	R3	:DECREMENT CHARACTER COUNT
4139	020600	001360		BNE	4\$:BR IF SILO NOT EMPTY
4140	020602	004737	030622	JSR	PC,SILOLD	:LOAD SILO WITH MORE OF COUNT PATTERN
4141	020606	012703	000073	MOV	#73,R3	:RELOAD CHARACTER COUNT
4142	020612	000751		BR	1\$:CONTINUE
4143	020614			3\$:		

```

:***** TEST 36 *****
: *DDCMP DATA TEST
: *THIS TEST SINGLE STEPS A BINARY COUNT PATTERN
: *CHECKING EACH CHARACTER AS IT IS RECEIVED
: *THIS TEST IS EXACTLY THE SAME AS THE LAST TEST,
: *EXCEPT LINE UNIT LOOP IS SET IN LU REGISTER 12
:*****

```

: TEST 36

:-----

4156						:*****	
4157	020614	000004		TST36:	SCOPE	: LOAD THE NO. OF THIS TEST	
4158	020616	012737	000036	001202	MOV	#36,\$STNM	: POINT TO THE START OF NEXT TEST.
4159	020624	012737	020754	001442	MOV	#TST37,NEXT	
4160						:R1 CONTAINS BASE KMC11 ADDRESS	
4161	020632	104410		MSTCLR		:MASTER CLEAR KMC11	
4162	020634	005037	031062	CLR	SCHAR	:START BINARY COUNT AT ZERO	
4163	020640	005037	031064	CLR	STUFLG	:CLEAR BITSTUFF FLAG	
4164	020644	005002		CLR	R2	:R2 IS 'EXPECTED' DATA	
4165	020646	012703	000073	MOV	#73,R3	:R3 IS CHARACTER COUNT	
4166	020652	005011		CLR	(R1)	:CLEAR LU LOOP IN MAINT REG	
4167	020654	012761	000040	000004	MOV	#BITS,4(R1)	:LOAD PORT4
4168	020662	104412		ROMCLK		:NEXT WORD IS INSTRUCTION, ROMCLK PC=5304	
4169	020664	122112		122112		:SET LU LOOP IN LU REG 12	
4170	020666	004737	030622	JSR	PC,SILOLD	:LOAD SILO WITH COUNT PATTERN	
4171	020672	104413	000043	DATACLK,	43	:SYNC RECEIVER AND GET IT ACTIVE	
4172	020676	104413	000730	1\$: DATACLK,	730	:CLOCK IN 73 CHARACTERS	
4173	020702	004737	031066	4\$: JSR	PC,INRDY	:WAIT FOR INRDY	

```

4174 020706 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4175 020710 021204 ;PORT4 IN DATA
4176 020712 016104 000004 MOV 4(R1),R4 ;PUT 'FOUND' IN R4
4177 020716 010205 MOV R2,R5 ;PUT 'EXPECTED' IN R5
4178 020720 120504 CMPB R5,R4 ;IS DATA CORRECT?
4179 020722 001401 BEQ 2$ ;BR IF YES
4180 020724 104010 ERROR 10 ;DATA ERROR
4181 020726 005202 2$: INC R2 ;NEXT CHARACTER
4182 020730 022702 000400 CMP #400,R2 ;ALL DONE?
4183 020734 001407 BEQ 3$ ;BR IF YES
4184 020736 005303 DEC R3 ;DECREMENT CHARACTER COUNT
4185 020740 001360 BNE 4$ ;BR IF SILO NOT EMPTY
4186 020742 004737 030622 JSR PC,SILOLD ;LOAD SILO WITH MORE OF COUNT PATTERN
4187 020746 012703 000073 MOV #73,R3 ;RELOAD CHARACTER COUNT
4188 020752 000751 BR 1$ ;CONTINUE
4189 020754 3$:

```

```

4190
4191
4192 ;***** TEST 37 *****
4193 ;*TRANSMITTER MARK TEST
4194 ;*SINGLE CLOCK 3 SYNCs AND A 301 AND 20 EXTRA
4195 ;*CLOCK TICKS, VERIFY THAT A 301, A 377 AND A 377
4196 ;*WERE RECEIVED INDICATING THAT THE TRANSMITTER WENT
4197 ;*TO A MARK STATE FOR 16 BITS WHEN OUT SILO WAS EMPTY
4198 ;*****
4199

```

```

4200 ; TEST 37
4201 ;-----
4202 ;*****

```

```

4203 020754 000004 TST37: SCOPE
4204 020756 012737 000037 001202 MOV #37,$TSTNM ; LOAD THE NO. OF THIS TEST
4205 020764 012737 021114 001442 MOV #TST40,NEXT ; POINT TO THE START OF NEXT TEST.
4206 ;R1 CONTAINS BASE KMC11 ADDRESS
4207 020772 104410 MSTCLR ;MASTER CLEAR KMC11
4208 020774 012711 004000 MOV #BIT11,(R1) ;SET LINE UNIT LOOP
4209 021000 004737 030444 JSR PC,CHAR ;LOAD SILO WITH 3 SYNCs
4210 021004 000301 301 ;AND A 301
4211 021006 104413 000073 DATACLK, 73 ;CLOCK THE 301 IN AND 20 EXTRA TICKS
4212 021012 004737 031066 JSR PC,INRDY ;WAIT FOR INRDY
4213 021016 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4214 021020 021204 021204 ;PORT4 IN DATA
4215 021022 016104 000004 MOV 4(R1),R4 ;PUT 'FOUND' IN R4
4216 021026 012705 000301 MOV #301,R5 ;PUT 'EXPECTED' IN R5
4217 021032 120504 CMPB R5,R4 ;WAS A 301 RECEIVED?
4218 021034 001401 BEQ 1$
4219 021036 104010 ERROR 10 ;ERROR FIRST CHARACTER INCORRECT
4220 021040 004737 031066 1$: JSR PC,INRDY ;WAIT FOR INRDY
4221 021044 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4222 021046 021204 021204 ;PORT4 IN DATA
4223 021050 016104 000004 MOV 4(R1),R4 ;PUT 'FOUND' IN R4
4224 021054 012705 000377 MOV #377,R5 ;PUT 'EXPECTED' IN R5
4225 021060 120504 CMPB R5,R4 ;WAS A 377 RECEIVED?
4226 021062 001401 BEQ 2$
4227 021064 104010 ERROR 10 ;ERROR, 377 WAS NOT RECEIVED
4228 021066 004737 031066 2$: JSR PC,INRDY ;WAIT FOR INRDY
4229 021072 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304

```

4230 021074 021204
4231 021076 016104 000004
4232 021102 012705 000377
4233 021106 120504
4234 021110 001401
4235 021112 104010
4236 021114

3\$:

021204 ;PORT4 IN DATA
MOV 4(R1),R4 ;PUT 'FOUND' IN R4
MOV #377,R5 ;PUT 'EXPECTED' IN R5
CMPB R5,R4 ;WAS A 377 RECEIVED?
BEQ 3\$
ERROR 10 ;ERROR, 177 WAS NOT RECEIVED

***** TEST 40 *****
; *CABLE TURNAROUND TEST
; *CLEAR LINE UNIT LOOP, SET DTR
; *VERIFY THAT RING AND MODEM READY ARE SET
; *CLEAR DTR, VERIFY THAT RING AND MRDY ARE CLEARED
;*****

; TEST 40
;-----

4248
4249 021114 000004
4250 021116 012737 000040 001202
4251 021124 012737 021342 001442
4252
4253 021132 104410
4254 021134 032737 020000 002050
4255 021142 001004
4256 021144 032737 040000 002050
4257 021152 001473
4258 021154 005011
4259 021156 012761 000100 000004
4260 021164 104412
4261 021166 122113
4262 021170 104414 000002
4263 021174 104412
4264 021176 021264
4265 021200 016104 000004
4266 021204 042704 000023
4267 021210 012705 000310
4268 021214 032737 020000 002050
4269 021222 001402
4270 021224 042705 000200
4271
4272 021230 032737 000004 002054
4273 021236 001402
4274
4275 021240 042705 000200
4276 021244
4277 021244 020504
4278 021246 001401
4279
4280
4281 021250 104011
4282 021252 005061 000004
4283 021256 104412
4284 021260 122113
4285 021262 104414 000002

TST40:

SCOPE ; LOAD THE NO. OF THIS TEST
MOV #40,\$STNM ; POINT TO THE START OF NEXT TEST.
MOV #TST41,NEXT ; R1 CONTAINS BASE KMC11 ADDRESS
MSTCLR ; MASTER CLEAR KMC11
BIT #BIT13,STAT1 ; IS LINE UNIT M8202?
BNE .+12 ; BR IF YES (DO TEST EVEN IF NO LOOP-BACK CONN)
BIT #BIT14,STAT1 ; IS TURNAROUND CONNECTOR ON?
BEQ 2\$; SKIP TEST IF NO
CLR (R1) ; CLEAR LINE UNIT LOOP
MOV #100,4(R1) ; LOAD PORT4
ROMCLK ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122113 ; SET DTR
TIMER, 2 ; WAIT
ROMCLK ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
021264 ; PORT4 LU13
MOV 4(R1),R4 ; PUT FOUND IN R4 ++++NEW
BIC #23,R4 ; CLEAR JUNK
MOV #310,R5 ; GET EXPECTED.
BIT #BIT13,STAT1 ; IS LINE UNIT M8202?
BEQ .+6 ; NO RING ON M8202
BIC #BIT7,R5 ; NO RING ON M8202
BIT #BIT2,STAT3 ; IS THIS V.35 MODEM?
BEQ 3\$; NO THEN GO AHEAD.
BIC #BIT7,R5 ; YES-NO RING ON V.35 MODEM
3\$:
CMP R5,R4 ; ARE RING AND MODEM READY SET?
BEQ 1\$; WARNING! IF V.35 AND AUTO STARTED,
; YOU WILL GET THIS ERROR. YOU MUST
; MANUALL NASWER THE QUESTIONS FOR V.35.
1\$:
ERROR 11 ; ERROR, RING OR MRDY NOT SET
CLR 4(R1) ; CLEAR PORT4
ROMCLK ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122113 ; CLEAR DTR
TIMER, 2

```

4286 021266 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4287 021270 021264 ;PORT4 LU13
4288 021272 016104 000004 MOV 4(R1),R4 ;PUR FOUND IN R4 +++NEW
4289 021276 042704 000023 BIC #23,R4 ; STRIP JUNK
4290 021302 005005 CLR R5 ; SET EXPECTED.
4291 021304 032737 020000 002050 BIT #BIT13,STAT1 ; IS THIS A M8202?
4292 021312 001402 BEQ .+6
4293 021314 052705 000010 BIS #BIT3,R5 ; YES THEN EXPECT MRDY SET.
4294 021320 032737 000004 002054 BIT #BIT2,STAT3 ; IS THIS V.35?
4295 021326 001402 BEQ 4$
4296 021330 042704 000200 BIC #BIT7,R4
4297 021334 ;$:
4298 021334 120405 CMPB R4,R5 ; ARE RING AND MRDY CLEAR?
4299 021336 001401 BEQ 2$
4300 ; WARNING! YOU MAY GET THIS ERROR IF V.35
4301 ; AND AUTOSTART. YOU MUST MANNUALLY ANSWER
4302 ; ALL QUESTIONS IF V.35.
4303 021340 104011 ERROR 11 ;ERROR, RING OR MRDY NOT CLEAR
4304 021342 2$:
4305
4306 ;***** TEST 41 *****
4307 ;*CABLE TURNAROUND TEST
4308 ;*CLEAR LINE UNIT LOOP, LOAD OUT DATA SILO
4309 ;*VERIFY THAT ALL MODEM SIGNALS ARE SET
4310 ;:*****
4311
4312 ; TEST 41
4313 ;-----
4314 ;:*****
4315 ;*****
4316 021342 000004 TST41: SCOPE
4317 021344 012737 000041 001202 MOV #41,$STNM ; LOAD THE NO. OF THIS TEST
4318 021352 012737 021536 001442 MOV #TST42,NEXT ; POINT TO THE START OF NEXT TEST.
4319 ;R1 CONTAINS BASE KMC11 ADDRESS
4320 021360 104410 MSTCLR ;MASTER CLEAR KMC11
4321 021362 032737 020000 002050 BIT #BIT13,STAT1 ; IS LINE UNIT M8202?
4322 021370 001004 BNE .+12 ;BR IF YES (DO TEST EVEN IF NO LOOP-BACK CONN)
4323 021372 032737 040000 002050 BIT #BIT14,STAT1 ; IS TURNAROUND CONNECTOR ON?
4324 021400 001456 BEQ 1$ ;SKIP TEST IF NO
4325 021402 012711 004000 MOV #BIT11,(R1) ;SET LINE UNIT LOOP
4326 021406 012761 000100 000004 MOV #100, 4(R1) ;LOAD PORT4
4327 021414 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4328 021416 122113 122113 ;CLEAR ALL MODEM SIGNALS,EXCEPT DTR
4329 021420 104414 000002 TIMER, 2 ;WAIT
4330 021424 012761 000001 000004 MOV #1,4(R1) ;LOAD PORT4
4331 021432 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4332 021434 122111 122111 ;SET SOM
4333 021436 004537 031530 JSR R5,MESLD ;FILL OUT DATA SILO
4334 021442 032012 MESDAT ;WITH 64 CHARACTERS
4335 021444 000100 64.
4336 021446 012700 000050 MOV #50,R0 ;PREPARE FOR DELAY
4337 021452 005011 CLR (R1) ;CLEAR LINE UNIT LOOP
4338 021454 2$:
4339 021454 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4340 021456 021264 021264 ;PORT4 LU13
4341 021460 016104 000004 MOV 4(R1),R4 ;PUT 'FOUND' IN R4

```

```

4342 021464 042704 000023      BIC   #23,R4      ;CLEAR UNWANTED BITS
4343 021470 012705 000354      MOV   #354,R5     ;PUT 'EXPECTED' IN R5
4344
4345 021474 032737 000004 002054  BIT   #BIT2,STAT3 ; IS THIS V.35?
4346 021502 001402                BEQ   4$          ; NO
4347
4348 021504 042705 000200                BIC   #BIT7,R5   ; YES, GET RID OF RING
4349 021510                4$:
4350 021510 032737 020000 002050  BIT   #BIT13,STAT1 ; IS LINE UNIT M8202?
4351 021516 001402                BEQ   .+6        ;BR IF NO
4352 021520 042705 000200                BIC   #BIT7,R5   ;NO RING ON M8202
4353 021524 120504                CMPB  R5,R4      ;COMPARE EXPECTED AND FOUND
4354 021526 001403                BEQ   1$        ;BR IF OK
4355 021530 005300                DEC   R0         ;DEC DELAY COUNT
4356 021532 001350                BNE  2$        ;BR IF NOT ZERO
4357 021534 104011                ERROR 11        ;ERROR, ALL SIGNALS ARE NOT SET
4358                                ; WARNING IF V.35, YOU MUST ANSWER ALL QUESTIONS
4359                                ; MANUALLY.
4360 021536                1$:

```

```

4361
4362
4363 :***** TEST 42 *****
4364 :*TEST OF CRC OPERATION
4365 :*USING THE CRC16 POLYNOMIAL, SINGLE CLOCK THE CHARACTER
4366 :*0, VERIFY THE LSB OF THE BCC ON EACH SHIFT
4367 :*TEST TRANSMITTER FIRST THEN THE RECEIVER BCC
4368 :*****
4369

```

```

4370 : TEST 42
4371 :-----
4372 :*****

```

```

4373 021536 000004      TST42: SCOPE
4374 021540 012737 000042 001202  MOV   #42,$TSTNM ; LOAD THE NO. OF THIS TEST
4375 021546 012737 022052 001442  MOV   #TST43,NEXT ; POINT TO THE START OF NEXT TEST.
4376 021554 012737 021570 001444  MOV   #64$,LOCK   ; ADDRESS FOR LOCK ON DATA.
4377                                ;R1 CONTAINS BASE KMC11 ADDRESS
4378 021562 104410      MSTCLR ;MASTER CLEAR KMC11
4379 021564 012711 004000  MOV   #BIT11,(R1) ;SET LU LOOP
4380 021570 004737 031572  64$: JSR   PC,CLR10   ;CLEAR BCC REGISTERS
4381 021574 005000      CLR   R0         ;START SHIFT COUNTER AT ZERO
4382 021576 012737 120001 031226  MOV   #CRC16,XPOLY ;LOAD POLYNOMIAL FOR SOFTWARE BCC
4383 021604 012737 000000 021644  MOV   #0,66$     ;LOAD CHAR FOR SOFTWARE BCC
4384 021612 005037 021646      CLR   67$       ;CLEAR OLD SOFTWARE BCC
4385 021616 004737 031232  JSR   PC,BCCLD   ;LOAD OUT SILO WITH 2 SYNCS
4386 021622 000000      0           ;AND THE CHARACTER 0
4387 021624 104413 000021  DATACLK, 21    ;GET TRANSMITTER ACTIVE
4388 021630 104413 000001  65$: DATACLK, 1 ;SHIFT BCC ONCE
4389 021634 005200      INC   R0         ;BUMP SHIFT COUNT
4390 021636 004537 031122  JSR   R5,SIMBCC ;CALCULATE SOFTWARE BCC LSB
4391 021642 000001      1           ;ONE SHIFT
4392 021644 000000  66$: 0         ;DATA CHARACTER
4393 021646 000000  67$: 0         ;OLD BCC
4394 021650 103405      BCS   68$       ;BR IF SOFT BCC LSB IS SET
4395 021652 004737 031344  JSR   PC,GETQ0   ;GET HARDWARE TRANSMITTER BCC LSB
4396 021656 103006      BCC   69$       ;BR IF HARD BCC LSB IS CLEAR
4397 021660 104012      ERROR 12      ;ERROR, BCC LSB IS SET

```

```

4398 021662 000404          BR      69$          :CONTINUE
4399 021664 004737 031344 68$: JSR      PC,GETQD  :GET HARDWARE TRANSMITTER BCC LSB
4400 021670 103401          BCS     69$          :BR IF HARD BCC LSB IS SET
4401 021672 104016          ERROR   16          :ERROR, HARD BCC LSB IS CLEAR
4402 021674          69$:          :SHIFT SOFT DATA
4403 021674 006037 021644          ROR     66$          :LOAD OLD SOFT BCC
4404 021700 013737 031230 021646 MOV     CALBCC,67$   :DONE YET?
4405 021706 022700 000010 CMP     #10,RO      :BR IF NOT DONE
4406 021712 001346          BNE     65$          :SCOPE SUBTEST (SW09=1)
4407 021714 104405          SCOPE1          :NEW SCOPE1
4408 021716 012737 021724 001444 MOV     #71$,LOCK   :CLEAR BCC REGISTERS
4409 021724 004737 031572 71$: JSR     PC,CLRIO    :START SHIFT COUNTER AT ZERO
4410 021730 005000          CLR     RO          :LOAD POLYNOMIAL FOR SOFTWARE BCC
4411 021732 012737 120001 031226 MOV     #CRC16,XPOLY :LOAD CHAR FOR SOFTWARE BCC
4412 021740 012737 000000 022000 MOV     #0,73$     :CLEAR OLD SOFTWARE BCC
4413 021746 005037 022002 CLR     74$        :LOAD OUT SILO WITH 2 SYNCs
4414 021752 004737 031232 JSR     PC,BCCLD    :AND THE CHARACTER 0
4415 021756 000000          O          :GET RECEIVER ACTIVE
4416 021760 104413 000032 DATACLK, 32       :SHIFT BCC ONCE
4417 021764 104413 000001 72$: DATACLK, 1    :BUMP SHIFT COUNT
4418 021770 005200          INC     RO          :CALCULATE SOFTWARE BCC LSB
4419 021772 004537 031122 JSR     R5,SIMBCC  :ONE SHIFT
4420 021776 000001          1          :DATA CHARACTER
4421 022000 000000 73$: O          :OLD BCC
4422 022002 000000 74$: O          :BR IF SOFT BCC LSB IS SET
4423 022004 103405          BCS     75$          :GET HARDWARE RECEIVER BCC LSB
4424 022006 004737 031356 JSR     PC,GETQI   :BR IF HARD BCC LSB IS CLEAR
4425 022012 103006          BCC     76$          :ERROR, BCC LSB IS SET
4426 022014 104013          ERROR   13          :CONTINUE
4427 022016 000404          BR      76$          :GET HARDWARE RECEIVER BCC LSB
4428 022020 004737 031356 75$: JSR     PC,GETQI   :BR IF HARD BCC LSB IS SET
4429 022024 103401          BCS     76$          :ERROR, BCC LSB IS CLEAR
4430 022026 104017          ERROR   17          :SHIFT SOFT DATA
4431 022030          76$:          :LOAD OLD SOFT BCC
4432 022030 006037 022000          ROR     73$          :DONE YET?
4433 022034 013737 031230 022002 MOV     CALBCC,74$   :BR IF NOT DONE
4434 022042 022700 000010 CMP     #10,RO      :SCOPE SUBTEST (SW09=1)
4435 022046 001346          BNE     72$          :SCOPE SUBTEST (SW09=1)
4436 022050 104405          SCOPE1          :SCOPE SUBTEST (SW09=1)
4437 022052          77$:          :SCOPE SUBTEST (SW09=1)
4438
4439
4440
4441
4442
4443
4444
4445
4446
4447
4448
4449
4450 022052 000004          :***** TEST 43 *****
4451 022054 012737 000043 001202 :*TEST OF CRC OPERATION
4452 022062 012737 022366 001442 :*USING THE CRC16 POLYNOMIAL, SINGLE CLOCK THE CHARACTER
4453 022070 012737 022104 001444 :*377, VERIFY THE LSB OF THE BCC ON EACH SHIFT
:*****
: TEST 43
:-----
:*****
TST43: SCOPE          : LOAD THE NO. OF THIS TEST
MOV     #43,$TSTNM   : POINT TO THE START OF NEXT TEST.
MOV     #TST44,NEXT  : ADDRESS FOR LOCK ON DATA.
MOV     #64$,LOCK

```



```

4510 022350 013737 031230 022316      MOV    CALBCC,74$      ;LOAD OLD SOFT BCC
4511 022356 022700 000010                CMP    #10,RO         ;DONE YET?
4512 022362 001346                        BNE    72$           ;BR IF NOT DONE
4513 022364 104405                        SCOP1                ;SCOPE SUBTEST (SW09=1)
4514 022366                                77$:
4515
4516
4517                                ;***** TEST 44 *****
4518                                ;*TEST OF CRC OPERATION
4519                                ;*USING THE CRC16 POLYNOMIAL, SINGLE CLOCK THE CHARACTER
4520                                ;*125, VERIFY THE LSB OF THE BCC ON EACH SHIFT
4521                                ;*TEST TRANSMITTER FIRST THEN THE RECEIVER BCC
4522                                ;:*****
4523
4524                                : TEST 44
4525                                :-----
4526                                ;:*****
4527 022366 000004                                TST44: SCOPE
4528 022370 012737 000044 001202                MOV    #44,$TSTNM      ; LOAD THE NO. OF THIS TEST
4529 022376 012737 022702 001442                MOV    #TST45,NEXT     ; POINT TO THE START OF NEXT TEST.
4530 022404 012737 022420 001444                MOV    #64$,LOCK       ; ADDRESS FOR LOCK ON DATA.
4531                                ;R1 CONTAINS BASE KMC11 ADDRESS
4532 022412 104410                                MSTCLR                ;MASTER CLEAR KMC11
4533 022414 012711 004000                                MOV    #BIT11,(R1)     ;SET LU LOOP
4534 022420 004737 031572                                JSR    PC,CLRIO        ;CLEAR BCC REGISTERS
4535 022424 005000                                CLR    RO              ;START SHIFT COUNTER AT ZERO
4536 022426 012737 120001 031226                MOV    #CRC16,XPOLY    ;LOAD POLYNOMIAL FOR SOFTWARE BCC
4537 022434 012737 000125 022474                MOV    #125,66$;       ;LOAD CHAR FOR SOFTWARE BCC
4538 022442 005037 022476                                CLR    67$            ;CLEAR OLD SOFTWARE BCC
4539 022446 004737 031232                                JSR    PC,BCCLD        ;LOAD OUT SILO WITH 2 SYNCS
4540 022452 000125                                125                    ;AND THE CHARACTER 125
4541 022454 104413 000021                                DATACLK, 21           ;GET TRANSMITTER ACTIVE
4542 022460 104413 000001                                DATACLK, 1           ;SHIFT BCC ONCE
4543 022464 005200                                INC    RO              ;BUMP SHIFT COUNT
4544 022466 004537 031122                                JSR    R5,SIMBCC       ;CALCULATE SOFTWARE BCC LSB
4545 022472 000001                                1                       ;ONE SHIFT
4546 022474 000000                                66$: 0                ;DATA CHARACTER
4547 022476 000000                                67$: 0                ;OLD BCC
4548 022500 103405                                BCS    68$            ;BR IF SOFT BCC LSB IS SET
4549 022502 004737 031344                                JSR    PC,GETQO        ;GET HARDWARE TRANSMITTER BCC LSB
4550 022506 103006                                BCC    69$            ;BR IF HARD BCC LSB IS CLEAR
4551 022510 104012                                ERROR  12             ;ERROR, BCC LSB IS SET
4552 022512 000404                                BR     69$            ;CONTINUE
4553 022514 004737 031344                                68$: JSR    PC,GETQO    ;GET HARDWARE TRANSMITTER BCC LSB
4554 022520 103401                                BCS    69$            ;BR IF HARD BCC LSB IS SET
4555 022522 104016                                ERROR  16             ;ERROR, HARD BCC LSB IS CLEAR
4556 022524                                69$:
4557 022524 006037 022474                                ROR    66$            ;SHIFT SOFT DATA
4558 022530 013737 031230 022476                MOV    CALBCC,67$     ;LOAD OLD SOFT BCC
4559 022536 022700 000010                CMP    #10,RO         ;DONE YET?
4560 022542 001346                        BNE    65$           ;BR IF NOT DONE
4561 022544 104405                        SCOP1                ;SCOPE SUBTEST (SW09=1)
4562 022546 012737 022554 001444                MOV    #71$,LOCK      ;NEW SCOPE1
4563 022554 004737 031572                                71$: JSR    PC,CLRIO    ;CLEAR BCC REGISTERS
4564 022560 005000                                CLR    RO              ;START SHIFT COUNTER AT ZERO
4565 022562 012737 120001 031226                MOV    #CRC16,XPOLY    ;LOAD POLYNOMIAL FOR SOFTWARE BCC

```

BASIC RECEIVER TESTS

```
4566 022570 012737 000125 022630      MOV    #125,73$;      ;LOAD CHAR FOR SOFTWARE BCC
4567 022576 005037 022632      CLR    74$           ;CLEAR OLD SOFTWARE BCC
4568 022602 004737 031232      JSR    PC,BCCLD     ;LOAD OUT SILO WITH 2 SYNCs
4569 022606 000125          125           ;AND THE CHARACTER 125
4570 022610 104413 000032      DATACLK,          32 ;GET RECEIVER ACTIVE
4571 022614 104413 000001      72$: DATACLK,          1 ;SHIFT BCC ONCE
4572 022620 005200          INC    RO           ;BUMP SHIFT COUNT
4573 022622 004537 031122      JSR    R5,SIMBCC    ;CALCULATE SOFTWARE BCC LSB
4574 022626 000001          1           ;ONE SHIFT
4575 022630 000000      73$: 0           ;DATA CHARACTER
4576 022632 000000      74$: 0           ;OLD BCC
4577 022634 103405          BCS    75$         ;BR IF SOFT BCC LSB IS SET
4578 022636 004737 031356      JSR    PC,GETQI     ;GET HARDWARE RECEIVER BCC LSB
4579 022642 103006          BCC    76$         ;BR IF HARD BCC LSB IS CLEAR
4580 022644 104013          ERROR  13         ;ERROR, BCC LSB IS SET
4581 022646 000404          BR     76$         ;CONTINUE
4582 022650 004737 031356      75$: JSR    PC,GETQI     ;GET HARDWARE RECEIVER BCC LSB
4583 022654 103401          BCS    76$         ;BR IF HARD BCC LSB IS SET
4584 022656 104017          ERROR  17         ;ERROR, BCC LSB IS CLEAR
4585 022660          76$:          ;
4586 022660 006037 022630      ROR    73$         ;SHIFT SOFT DATA
4587 022664 013737 031230 022632      MOV    CALBCC,74$   ;LOAD OLD SOFT BCC
4588 022672 022700 000010      CMP    #10,RO       ;DONE YET?
4589 022676 001346          BNE    72$         ;BR IF NOT DONE
4590 022700 104405          SCOP1          ;SCOPE SUBTEST (SW09=1)
4591 022702          77$:          ;
```

```
4592
4593
4594 ;***** TEST 45 *****
4595 ;*TEST OF CRC OPERATION
4596 ;*USING THE CRC16 POLYNOMIAL, SINGLE CLOCK THE CHARACTER
4597 ;*252, VERIFY THE LSB OF THE BCC ON EACH SHIFT
4598 ;*TEST TRANSMITTER FIRST THEN THE RECEIVER BCC
4599 ;*****
```

```
4600
4601 ; TEST 45
4602 ;-----
```

```
4603 ;*****
4604 022702 000004      TST45: SCOPE
4605 022704 012737 000045 001202      MOV    #45,$STNM    ; LOAD THE NO. OF THIS TEST
4606 022712 012737 023216 001442      MOV    #TST46,NEXT  ; POINT TO THE START OF NEXT TEST.
4607 022720 012737 022734 001444      MOV    #64$,LOCK    ; ADDRESS FOR LOCK ON DATA.
4608          ;R1 CONTAINS BASE KMC11 ADDRESS
4609 022726 104410          MSTCLR          ;MASTER CLEAR KMC11
4610 022730 012711 004000          MOV    #BIT11,(R1) ;SET LU LOOP
4611 022734 004737 031572      64$: JSR    PC,CLRIO   ;CLEAR BCC REGISTERS
4612 022740 005000          CLR    RO           ;START SHIFT COUNTER AT ZERO
4613 022742 012737 120001 031226      MOV    #CRC16,XPOLY ;LOAD POLYNOMIAL FOR SOFTWARE BCC
4614 022750 012737 000252 023010      MOV    #252,66$;    ;LOAD CHAR FOR SOFTWARE BCC
4615 022756 005037 023012          CLR    67$         ;CLEAR OLD SOFTWARE BCC
4616 022762 004737 031232      JSR    PC,BCCLD     ;LOAD OUT SILO WITH 2 SYNCs
4617 022766 000252          252           ;AND THE CHARACTER 252
4618 022770 104413 000021          DATACLK,          21 ;GET TRANSMITTER ACTIVE
4619 022774 104413 000001      65$: DATACLK,          1 ;SHIFT BCC ONCE
4620 023000 005200          INC    RO           ;BUMP SHIFT COUNT
4621 023002 004537 031122      JSR    R5,SIMBCC    ;CALCULATE SOFTWARE BCC LSB
```

4622	023006	000001				1			:ONE SHIFT
4623	023010	000000			66\$:	0			:DATA CHARACTER
4624	023012	000000			67\$:	0			:OLD BCC
4625	023014	103405				BCC	68\$:BR IF SOFT BCC LSB IS SET
4626	023016	004737	031344			JSR	PC,GETQO		:GET HARDWARE TRANSMITTER BCC LSB
4627	023022	103006				BCC	69\$:BR IF HARD BCC LSB IS CLEAR
4628	023024	104012				ERROR	12		:ERROR, BCC LSB IS SET
4629	023026	000404				BR	69\$:CONTINUE
4630	023030	004737	031344		68\$:	JSR	PC,GETQO		:GET HARDWARE TRANSMITTER BCC LSB
4631	023034	103401				BCC	69\$:BR IF HARD BCC LSB IS SET
4632	023036	104016				ERROR	16		:ERROR, HARD BCC LSB IS CLEAR
4633	023040				69\$:				
4634	023040	006037	023010			ROR	66\$:SHIFT SOFT DATA
4635	023044	013737	031230	023012		MOV	CALBCC,67\$:LOAD OLD SOFT BCC
4636	023052	022700	000010			CMF	#10,R0		:DONE YET?
4637	023056	001346				BNE	65\$:BR IF NOT DONE
4638	023060	104405				SCOP1			:SCOPE SUBTEST (SW09=1)
4639	023062	012737	023070	001444		MOV	#71\$,LDCK		:NEW SCOPE1
4640	023070	004737	031572		71\$:	JSR	PC,CLRIO		:CLEAR BCC REGISTERS
4641	023074	005000				CLR	R0		:START SHIFT COUNTER AT ZERO
4642	023076	012737	120001	031226		MOV	#CRC16,XPOLY		:LOAD POLYNOMIAL FOR SOFTWARE BCC
4643	023104	012737	000252	023144		MOV	#252,73\$;		:LOAD CHAR FOR SOFTWARE BCC
4644	023112	005037	023146			CLR	74\$:CLEAR OLD SOFTWARE BCC
4645	023116	004737	031232			JSR	PC,BCCLD		:LOAD OUT SILO WITH 2 SYNC
4646	023122	000252				252			:AND THE CHARACTER 252
4647	023124	104413	000032			DATACLK,	32		:GET RECEIVER ACTIVE
4648	023130	104413	000001		72\$:	DATACLK,	1		:SHIFT BCC ONCE
4649	023134	005200				INC	R0		:BUMP SHIFT COUNT
4650	023136	004537	031122			JSR	R5,SIMBCC		:CALCULATE SOFTWARE BCC LSB
4651	023142	000001				1			:ONE SHIFT
4652	023144	000000			73\$:	0			:DATA CHARACTER
4653	023146	000000			74\$:	0			:OLD BCC
4654	023150	103405				BCC	75\$:BR IF SOFT BCC LSB IS SET
4655	023152	004737	031356			JSR	PC,GETQI		:GET HARDWARE RECEIVER BCC LSB
4656	023156	103006				BCC	76\$:BR IF HARD BCC LSB IS CLEAR
4657	023160	104013				ERROR	13		:ERROR, BCC LSB IS SET
4658	023162	000404				BR	76\$:CONTINUE
4659	023164	004737	031356		75\$:	JSR	PC,GETQI		:GET HARDWARE RECEIVER BCC LSB
4660	023170	103401				BCC	76\$:BR IF HARD BCC LSB IS SET
4661	023172	104017				ERROR	17		:ERROR, BCC LSB IS CLEAR
4662	023174				76\$:				
4663	023174	006037	023144			ROR	73\$:SHIFT SOFT DATA
4664	023200	013737	031230	023146		MOV	CALBCC,74\$:LOAD OLD SOFT BCC
4665	023206	022700	000010			CMF	#10,R0		:DONE YET?
4666	023212	001346				BNE	72\$:BR IF NOT DONE
4667	023214	104405				SCOP1			:SCOPE SUBTEST (SW09=1)
4668	023216				77\$:				

4669
4670
4671
4672
4673
4674
4675
4676
4677

```

:***** TEST 46 *****
:*TRANSMITTER CRC TEST
:*USING THE CRC16 POLYNOMIAL, SINGLE CLOCK A BINARY
:*COUNT PATTERN, VERIFY THE LSB OF THE TRANSMITTER BCC ON EACH SHIFT
:*****
: TEST 46
  
```

```

4678
4679
4680 023216 000004
4681 023220 012737 000046 001202
4682 023226 012737 023454 001442
4683
4684 023234 104410
4685 023236 012711 004000
4686 023242 005003
4687 023244 005004
4688 023246 005005
4689 023250 005037 023352
4690 023254 012737 120001 031226
4691 023262 004737 031374
4692 023266 010461 000004
4693 023272 104412
4694 023274 122110
4695 023276 005204
4696 023300 010461 000004
4697 023304 104412
4698 023306 122110
4699 023310 005204
4700 023312 010461 000004
4701 023316 104412
4702 023320 122110
4703 023322 004737 030260
4704 023326 104413 000021
4705 023332 010537 023350 1$:
4706 023336 104413 000001 2$:
4707 023342 004537 031122
4708 023346 000001
4709 023350 000000 3$:
4710 023352 000000 4$:
4711 023354 103405
4712 023356 004737 031344
4713 023362 103006
4714 023364 104020
4715 023366 000404
4716 023370 004737 031344 5$:
4717 023374 103401
4718 023376 104021
4719
4720 023400
4721 023400 006037 023350 6$:
4722 023404 013737 031230 023352
4723 023412 005203
4724 023414 022703 000010
4725 023420 001346
4726 023422 005003
4727 023424 005204
4728 023426 022704 000400
4729 023432 003404
4730 023434 010461 000004
4731 023440 104412
4732 023442 122110
4733 023444 005205 9$:
    
```

```

-----
:*****
TST46: SCOPE
MOV #46,$STSTM ; LOAD THE NO. OF THIS TEST
MOV #TST47,NEXT ; POINT TO THE START OF NEXT TEST.
;R1 CONTAINS BASE KMC11 ADDRESS
MSTCLR ;MASTER CLEAR KMC11
MOV #BIT11,(R1) ;SET LINE UNIT LOOP
CLR R3 ;ZERO BIT COUNT
CLR R4 ;R4 CONTAINS CHAR TO BE LOADED IN SILO
CLR R5 ;R5 CONTAINS CHAR CURRENTLY BEING SHIFTED OUT
CLR 4$ ;CLEAR SOFT BCC
MOV #CRC16,XPOLY ;LOAD POLYNOMIAL
JSR PC,SYNLD ;LOAD SILO WITH 2 SYNCS, SOM SET
MOV R4,4(R1) ;PORT4 CHAR
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122110 ;LOAD OUT DATA
INC R4 ;INCREMENT TO NEXT CHARACTER
MOV R4,4(R1) ;PORT4 CHAR
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122110 ;LOAD OUT DATA
INC R4 ;INCREMENT TO NEXT CHARACTER
MOV R4,4(R1) ;PORT4 CHAR
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122110 ;LOAD OUT DATA
JSR PC,OCOR ;WAIT FOR OCOR
DATACLK,21 ;CLOCK DATA
MOV R5,3$ ;LOAD CHAR FOR SOFT CRC
DATACLK,1 ;SHIFT BCC ONCE
JSR R5,SIMBCC ;CALCULATE SOFT BCC
1 ;SOFT SHIFT COUNT
0 ;SOFT CHARACTER
0 ;OLD SOFT BCC
BCS 5$ ;BR IF SOFT BCC LSB IS SET
JSR PC,GETQD ;GET HARDWARE TRANSMITTER BCC LSB
BCC 6$ ;BR IF OK (CLEARED)
ERROR 20 ;ERROR, BCC LSB WAS SET
BR 6$ ;CONTINUE WITH TEST
JSR PC,GETQD ;GET HARDWARE TRANSMITTER BCC LSB
BCS 6$ ;BR IF OK (SET)
ERROR 21 ;ERROR, BCC LSB WAS CLEAR

6$:
ROR 3$ ;SHIFT SOFT DATA
MOV CALBCC,4$ ;LOAD OLD SOFT BCC
INC R3 ;INCREMENT BIT COUNTER
CMP #10,R3 ;DONE A FULL CHARACTER YET?
BNE 2$ ;BR IF NO
CLR R3 ;RESTART BIT COUNTER
INC R4 ;INCREMENT DATA FOR SILO
CMP #400,R4 ;DONE BINARY COUNT YET?
BLE 9$ ;BR IF YES
MOV R4,4(R1) ;PORT4 DATA
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122110 ;LOAD OUT DATA
INC R5 ;INCREMENT DATA
    
```

```

4734 023446 022705 000400      CMP      #400,R5      :DONE BINARY PATTERN YET?
4735 023452 001327              BNE      1$          :BR IF NO
4736 023454                      7$:
4737
4738
4739
4740
4741
4742
4743
4744
4745
4746
4747
4748 023454 000004              ;***** TEST 47 *****
4749 023456 012737 000047 001202  ;*RECEIVER CRC TEST
4750 023464 012737 023712 001442  ;*USING THE CRC16 POLYNOMIAL, SINGLE CLOCK A BINARY
4751
4752 023472 104410              ;*COUNT PATTERN, VERIFY THE LSB OF THE RECEIVER BCC ON EACH SHIFT
4753 023474 012711 004000              ;*****
4754 023500 005003
4755 023502 005004
4756 023504 005005
4757 023506 005037 023610
4758 023512 012737 120001 031226  ; TEST 47
4759 023520 004737 031374
4760 023524 010461 000004
4761 023530 104412
4762 023532 122110
4763 023534 005204
4764 023536 010461 000004
4765 023542 104412
4766 023544 122110
4767 023546 005204
4768 023550 010461 000004
4769 023554 104412
4770 023556 122110
4771 023560 004737 030260
4772 023564 104413 000032
4773 023570 010537 023606
4774 023574 104413 000001
4775 023600 004537 031122
4776 023604 000001
4777 023606 000000
4778 023610 000000
4779 023612 103405
4780 023614 004737 031356
4781 023620 103006
4782 023622 104022
4783 023624 000404
4784 023626 004737 031356
4785 023632 103401
4786 023634 104023
4787
4788 023636
4789 023636 006037 023606

```

```

;***** TEST 47 *****
;*RECEIVER CRC TEST
;*USING THE CRC16 POLYNOMIAL, SINGLE CLOCK A BINARY
;*COUNT PATTERN, VERIFY THE LSB OF THE RECEIVER BCC ON EACH SHIFT
;*****
; TEST 47
-----
;*****
1$T47: SCOPE
MOV #47,$TSTNM ; LOAD THE NO. OF THIS TEST
MOV #TST50,NEXT ; POINT TO THE START OF NEXT TEST.
;R1 CONTAINS BASE KMC11 ADDRESS
MSTCLR ;MASTER CLEAR KMC11
MOV #BIT11,(R1) ;SET LINE UNIT LOOP
CLR R3 ;ZERO BIT COUNT
CLR R4 ;R4 CONTAINS CHAR TO BE LOADED IN SILO
CLR R5 ;R5 CONTAINS CHAR CURRENTLY BEING SHIFTED OUT
CLR 4$ ;CLEAR SOFT BCC
MOV #CRC16,XPOLY ;LOAD POLYNOMIAL
JSR PC,SYNLD ;LOAD SILO WITH 2 SYNCs, SOM SET
MOV R4,4(R1) ;PORT4 CHAR
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122110 ;LOAD OUT DATA
INC R4 ;INCREMENT TO NEXT CHARACTER
MOV R4,4(R1) ;PORT4 CHAR
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122110 ;LOAD OUT DATA
INC R4 ;INCREMENT TO NEXT CHARACTER
MOV R4,4(R1) ;PORT4 CHAR
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
122110 ;LOAD OUT DATA
JSR PC,OCOR ;WAIT FOR OCOR
DATACLK,32 ;CLOCK DATA
1$: MOV R5,3$ ;LOAD CHAR FOR SOFT CRC
2$: DATACLK,1 ;SHIFT BCC ONCE
JSR R5,SIMBCC ;CALCULATE SOFT BCC
1 ;SOFT SHIFT COUNT
3$: 0 ;SOFT CHARACTER
4$: 0 ;OLD SOFT BCC
BCS 5$ ;BR IF SOFT BCC LSB IS SET
JSR PC,GETQI ;GET HARDWARE RECEIVER BCC LSB
BCC 6$ ;BR IF OK (CLEARED)
ERROR 22 ;ERROR, BCC LSB WAS SET
BR 6$ ;CONTINUE WITH TEST
5$: JSR PC,GETQI ;GET HARDWARE RECEIVER BCC LSB
BCS 6$ ;BR IF OK (SET)
ERROR 23 ;ERROR, BCC LSB WAS CLEAR
6$: ROR 3$ ;SHIFT SOFT DATA

```

```

4790 023642 013737 031230 023610      MOV    CALBCC,48      ;LOAD OLD SOFT BCC
4791 023650 005203                      INC    R3              ;INCREMENT BIT COUNTER
4792 023652 022703 000010      CMP    #10,R3         ;DONE A FULL CHARACTER YET?
4793 023656 001346                      BNE   2$              ;BR IF NO
4794 023660 005003                      CLR   R3              ;RESTART BIT COUNTER
4795 023662 005204                      INC    R4              ;INCREMENT DATA FOR SILO
4796 023664 022704 000400      CMP    #400,R4        ;DONE BINARY COUNT YET?
4797 023670 003404                      BLE   9$              ;BR IF YES
4798 023672 010461 000004      MOV    R4,4(R1)       ;PORT4 DATA
4799 023676 104412                      ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4800 023700 122110                      122110 ;LOAD OUT DATA
4801 023702 005205                      9$: INC    R5              ;INCREMENT DATA
4802 023704 022705 000400      CMP    #400,R5        ;DONE BINARY PATTERN YET?
4803 023710 001327                      BNE   1$              ;BR IF NO
4804 023712                      7$:

```

```

4805
4806
4807      ;***** TEST 50 *****
4808      ;*TRANSMITTER DDCMP CRC TEST
4809      ;*THIS TEST TRANSMITS A FOUR CHARACTER MESSAGE WITH CRC
4810      ;*BOTH DATA AND THE BCC ARE VERIFIED IN THE BIT
4811      ;*WINDOW. THE FOUR CHARACTERS ARE 0,125,252,377
4812      ;*THE TRANSMITTER IS CHECKED FOR GOING TO A MARK STATE AFTER THE BCC
4813      ;*****

```

```

4814      ; TEST 50
4815      ;-----
4816
4817      ;*****

```

```

4818 023712 000004                      TST50: SCOPE
4819 023714 012737 000050 001202      MOV    #50,$STNM      ; LOAD THE NO. OF THIS TEST
4820 023722 012737 024244 001442      MOV    #TST51,NEXT    ; POINT TO THE START OF NEXT TEST.
4821
4822 023730 104410                      MSTCLR                ;R1 CONTAINS BASE KMC11 ADDRESS
4823
4824
4825
4826
4827
4828
4829
4830
4831
4832
4833
4834
4835
4836
4837
4838
4839
4840
4841
4842
4843
4844
4845

```

```

;*****
;-----
;*****

```

```

TST50: SCOPE
MOV    #50,$STNM      ; LOAD THE NO. OF THIS TEST
MOV    #TST51,NEXT    ; POINT TO THE START OF NEXT TEST.
;R1 CONTAINS BASE KMC11 ADDRESS
;MASTER CLEAR KMC11

```

```

;LOAD OUT DATA SILO

```

```

MOV    #BIT11,(R1)    ;SET LINE UNIT LOOP
MOV    #MESDAT,R4     ;LOAD POINTER TO DATA
CLR    10$            ;CLEAR SOFT BCC
MOV    #4,R0          ;LOAD CHARACTER COUNT
JSR    PC,SYNLD       ;LOAD 2 SYNCS IN OUT SILO
JSR    PC,OUTRDY      ;WAIT FOR OUTRDY
JSR    R5,MESLD       ;LOAD SILO WITH 4 CHAR MESS
MESDAT ;ADDRESS OF MESSAGE
4 ;NUMBER OF CHARACTERS
JSR    PC,EOM         ;LOAD GARBAGE CHARACTER, WITH EOM SET
JSR    PC,OCOR        ;WAIT FOR OCOR
CLR    R3             ;CLEAR BIT COUNTER
DATACLK,22           ;CLOCK DATA
12$: MOV    (R4)+,R5   ;LOAD R5 WITH CHAR
MOV    R5,R2          ;LOAD R2 WITH CHAR

```

```

;CHECK FIRST FOUR CHARACTER MESSAGE
;IN THE BIT WINDOW (0,125,252,377)

```

```

MOV    #CRC16,XPOLY  ;LOAD POLYNOMIAL

```

```

4846 024022 010537 024034      MOV      R5,67$      ;LOAD SOFT CHAR FOR BCC
4847 024026 004537 031122      JSR      R5,SIMBCC   ;CALCULATE SOFT BCC
4848 024032 000010                10          ;SHIFT COUNT
4849 024034 000000                0          ;CHARACTER
4850 024036 000000                10$       0          ;OLD BCC
4851 024040 013737 031230  C24036  MOV      CALBCC,10$  ;LOAD SOFT BCC FOR NEXT SHIFT
4852 024046 104413 000001                64$     DATACLK, 1      ;SHIFT DATA IN TO BIT WINDOW
4853 024052 106002                RORB      R2          ;SHIFT SOFT DATA
4854 024054 103005                BCC      65$         ;BR IF A SPACE
4855 024056 004737 030226      JSR      PC,GETSI    ;LOOK AT BIT WINDOW
4856 024062 103406                BCS      66$         ;BR IF OK (MARK)
4857 024064 104006                ERROR    6           ;ERROR, BIT WINDOW WAS A SPACE
4858 024066 00C404                BR       66$         ;CONTINUE
4859 024070 004737 030226      JSR      PC,GETSI    ;LOOK AT BIT WINDOW
4860 024074 103001                BCC      66$         ;BR IF OK (SPACE)
4861 024076 104006                ERROR    6           ;ERROR, BIT WINDOW WAS A MARK
4862 024100                66$:
4863 024100 005203                INC      R3           ;BUMP BIT COUNTER
4864 024102 022703 000010      CMP      #10,R3      ;DONE FULL 8 BITS YET
4865 024106 001357                BNE      64$         ;BR IF NO
4866 024110 005003                CLR      R3           ;CLEAR BIT COUNTER
4867 024112 005300                DEC      R0           ;DEC CHARACTER COUNT
4868 024114 001335                BNE      12$         ;BR IF NOT DONE YET
4869
4870                ;CHECK BCC FOR PRECEDING MESSAGE IN THE BIT WINDOW
4871
4872 024116 013700 031230      MOV      CALBCC,R0   ;PUT BCC IN R0
4873 024122 104413 000001      68$:  DATACLK,1          ;SHIFT HARDWARE BCC
4874 024126 006000                ROR      R0           ;SHIFT SOFT BCC
4875 024130 103005                BCC      69$         ;BR IF CARRY CLEAR
4876 024132 004737 030226      JSR      PC,GETSI    ;LOOK AT BIT WINDOW
4877 024136 103406                BCS      70$         ;BR IF OK (MARK)
4878 024140 104014                ERROR    14          ;ERROR, CRC WRONG (SPACE)
4879 024142 000404                BR       70$         ;CONTINUE
4880 024144 004737 030226      JSR      PC,GETSI    ;LOOK AT BIT WINDOW
4881 024150 103001                BCC      70$         ;BR IF OK (SPACE)
4882 024152 104014                ERROR    14          ;ERROR, CRC WRONG (MARK)
4883 024154                70$:
4884 024154 005203                INC      R3           ;BUMP BIT COUNTER
4885 024156 022703 000020      CMP      #20,R3      ;FINISHED BCC YET?
4886 024162 001357                BNE      68$         ;BR IF NO
4887 024164 005003                CLR      R3           ;CLEAR BIT COUNTER
4888
4889                ;CHECK TO SEE IF TRANSMITTER IS MARKING
4890
4891 024166 104413 000001      2$:  DATACLK, 1          ;CLOCK TRANSMITTER
4892 024172 004737 030226      JSR      PC,GETSI    ;LOOK AT WINDOW
4893 024176 103401                BCS      3$          ;IT SHOULD BE MARKING
4894 024200 104024                ERROR    24          ;ERROR, BIT WAS A SPACE
4895 024202 005203                3$:  INC      R3           ;BUMP BIT COUNTER
4896 024204 022703 000007      CMP      #7,R3       ;DONE YET
4897 024210 001366                BNE      2$          ;BR IF NO
4898 024212 104413 000010      DATACLK, 10         ;GIVE ENOUGH TICKS TO CLEAR OUT ACTIVE
4899 024216 005003                CLR      R3           ;CLEAR BIT COUNTER
4900 024220 104413 000001      4$:  DATACLK, 1          ;SHIFT OUT NEXT BIT
4901 024224 004737 030226      JSR      PC,GETSI    ;LOOK AT BIT WINDOW

```

4902 024230 103401
4903 024232 104024
4904 024234 005203
4905 024236 022703 000020
4906 024242 001366
4907 024244

BCS .+4
ERROR 24
INC R3
CMP #20,R3
BNE 4\$

:BR IF IT IS A MARK
:ERROR, TRANSMITTER IS NOT MARKING
:INC BIT COUNT
:DONE YET?
:BR IF NO

5\$:

***** TEST 51 *****
: *RECEIVER DDCMP CRC TEST
: *THIS TEST CLOCKS A FOUR CHARACTER MESSAGE WITH BCC
: *AND VERIFYS CORRECT DATA RECEPTION AND BCC MATCH
: *THE FOUR CHARACTER MESSAGE IS 0,125,252,377
: *****

: TEST 51
:-----

4908
4909
4910
4911
4912
4913
4914
4915
4916
4917
4918
4919
4920 024244 000004
4921 024246 012737 000051 001202
4922 024254 012737 024446 001442
4923
4924 024262 104410
4925 024264 012711 004000
4926 024270 012702 032012
4927 024274 012700 000004
4928 024300 004737 031374
4929 024304 004737 030412
4930 024310 004537 031530
4931 024314 032012
4932 024316 000004
4933 024320 004737 031504
4934 024324 004737 030260
4935 024330 104413 000114
4936 024334 004737 031066
4937 024340 104412
4938 024342 021204
4939 024344 016104 000004
4940 024350 112205
4941 024352 120504
4942 024354 001401
4943 024356 104010
4944 024360 005300
4945 024362 001364

TST51: SCOPE ; LOAD THE NO. OF THIS TEST
MOV #51,\$TSTNM ; POINT TO THE START OF NEXT TEST.
MOV #TST52,NEXT ; R1 CONTAINS BASE KMC11 ADDRESS
MSTCLR ; MASTER CLEAR KMC11
MOV #BIT11,(R1) ; SET LINE UNIT LOOP
MOV #MESDAT,R2 ; LOAD POINTER TO DATA
MOV #4,R0 ; LOAD CHARACTER COUNT
JSR PC,SYNLD ; LOAD 2 SYNCS IN OUT SILO
JSR PC,OUTRDY ; WAIT FOR OUTRDY
JSR R5,MESLD ; LOAD SILO WITH 4 CHAR MESS
MESDAT ; ADDRESS OF MESSAGE
4 ; NUMBER OF CHARACTERS
JSR PC,EOM ; LOAD GARBAGE CHARACTER, WITH EOM SET
JSR PC,OCOR ; WAIT FOR OCOR
DATACLK,114 ; CLOCK DATA
JSR PC,INRDY ; WAIT FOR INRDY
ROMCLK ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
021204 ; GET IN DATA
MOV 4(R1),R4 ; PUT "FOUND" IN R4
MOVB (R2)+,R5 ; PUT "EXPECTED" IN R5
CMPB R5,R4 ; COMPARE RECEIVED DATA
BEQ 1\$; BR IF OK
ERROR 10 ; DATA ERROR
DEC R0 ; DEC CHARACTER COUNT
BNE 3\$; BR IF NOT DONE YET

3\$:

1\$:

:CHECK TO SEE THAT IN BCC MATCH IS SET

4946
4947
4948
4949 024364 004737 031066
4950 024370 104412
4951 024372 021204
4952 024374 116137 000004 001302
4953 024402 042737 177400 001302
4954 024410 004737 031066
4955 024414 104412
4956 024416 021244
4957 024420 016104 000004

JSR PC,INRDY ; WAIT FOR INRDY
ROMCLK ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
021204 ; GET FIRST HALF OF CRC
MOVB 4(R1),\$TMP2 ; PUT IN \$TMP2
BIC #177400,\$TMP2 ; CLEAR HI BYTE
JSR PC,INRDY ; WAIT FOR INRDY
ROMCLK ; NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
021244
MOV 4(R1),R4 ; PUT "FOUND" IN R4

BASIC RECEIVER TESTS

SEQ 0097

```

4958 024424 042704 000376      BIC    #376,R4      ;CLEAR UNWANTED BITS
4959 024430 012705 000001      MOV    #1,R5        ;PUT "EXPECTED" IN R5
4960 024434 120504              CMPB   R5,R4        ;IS IN BCC MATCH SET?
4961 024436 001401              BEQ    25$          ;
4962 024440 104015              ERROR  15          ;IN BCC MATCH ERROR
4963 024442                    25$:
4964 024442 104412              ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
4965 024444 021204              021204 ;GET LAST HALF
4966 024446                    2$:

```

```

;***** TEST 52 *****
;DDCMP EOM FUNCTION TEST
;THIS TEST LOADS OUT SILO WITH: 2 SYNCS,4 CHAR MESSAGE,EOM
;4 CHARACTER MESS,EOM. THE DATA STREAM IS CHECKED TO BE
;4 CHAR,BCC,4 CHAR,BCC,MARKS. THIS TEST VERIFYS THAT
;THE CHARCTERS LOADED WITH EOM SET ARE LOST
;ALL DATA AND BCC'S ARE CHECKED IN THE BIT WINDOW
;THE FOUR CHARACTER MESSAGE IS 0,125,252,377
;RECEIVED DATA IS VERIFIED, AND IN BCC MATCH IS CHECKED
;*****

```

4980 ; TEST 52

```

4981 ;-----
4982 ;*****
4983 024446 000004      TST52: SCOPE
4984 024450 012737 000052 001202      MOV    #52,$STSNM      ; LOAD THE NO. OF THIS TEST
4985 024456 012737 025546 001442      MOV    #TST53,NEXT    ; POINT TO THE START OF NEXT TEST.
4986                                          ;R1 CONTAINS BASE KMC11 ADDRESS
4987 024464 104410      MSTCLR ;MASTER CLEAR KMC11
4988                                          ;LOAD OUT DATA SILO
4989
4990
4991 024466 012711 004000      MOV    #BIT11,(R1)    ;SET LINE UNIT LOOP
4992 024472 012704 032012      MOV    #MESDAT,R4    ;LOAD POINTER TO DATA
4993 024476 005037 024606      CLR    10$           ;CLEAR SOFT BCC
4994 024502 012700 000004      MOV    #4,R0         ;LOAD CHARACTER COUNT
4995 024506 004737 031374      JSR   PC,SYNLD       ;LOAD 2 SYNCS IN OUT SILO
4996 024512 004737 030412      JSR   PC,OUTRDY      ;WAIT FOR OUTRDY
4997 024516 004537 031530      JSR   R5,MESLD       ;LOAD SILO WITH 4 CHAR MESS
4998 024522 032012      MESDAT ;ADDRESS OF MESSAGE
4999 024524 000004      4 ;NUMBER OF CHARACTERS
5000 024526 004737 031504      JSR   PC,EOM         ;LOAD GARBAGE CHARACTER, WITH EOM SET
5001 024532 004537 031530      JSR   R5,MESLD       ;LOAD FOUR MORE CHARACTERS
5002 024536 032012      MESDAT ;ADDRESS OF MESSAGE
5003 024540 000004      4 ;NUMBER OF CHACTERS
5004 024542 004737 031504      JSR   PC,EOM         ;SET EOM
5005 024546 004737 030260      JSR   PC,OCOR        ;WAIT FOR OCOR
5006 024552 005003              CLR    R3            ;CLEAR BIT COUNTER
5007 024554 104413 000022      DATACLK,22 ;CLOCK DATA
5008 024560 112405 12$:      MOVB   (R4)+,R5     ;LOAD R5 WITH CHAR
5009 024562 010502              MOV    R5,R2        ;LOAD R2 WITH CHAR
5010
5011 ;CHECK FIRST FOUR CHARACTER MESSAGE
5012 ;IN THE BIT WINDOW (0,125,252,377)
5013

```

```

5014 024564 012737 120001 031226      MOV      #CRC16,XPOLY      ;LOAD POLYNOMIAL
5015 024572 010537 024604              MOV      R5,67$           ;LOAD SOFT CHAR FOR BCC
5016 024576 004537 031122              JSR      R5,SIMBCC        ;CALCULATE SOFT BCC
5017 024602 000010              10                    ;SHIFT COUNT
5018 024604 000000              67$: 0                  ;CHARACTER
5019 024606 000000              10$: 0                  ;OLD BCC
5020 024610 013737 031230 024606      MOV      CALBCC,10$      ;LOAD SOFT BCC FOR NEXT SHIFT
5021 024616 104413 000001      64$: DATACLK, 1        ;SHIFT DATA IN TO BIT WINDOW
5022 024622 106002              RORB     R2              ;SHIFT SOFT DATA
5023 024624 103005              BCC     65$             ;BR IF A SPACE
5024 024626 004737 030226              JSR     PC,GETSI        ;LOOK AT BIT WINDOW
5025 024632 103406              BCS    66$             ;BR IF OK (MARK)
5026 024634 104006              ERROR  6                ;ERROR, BIT WINDOW WAS A SPACE
5027 024636 000404              BR     66$             ;CONTINUE
5028 024640 004737 030226      65$: JSR     PC,GETSI        ;LOOK AT BIT WINDOW
5029 024644 103001              BCC    66$             ;BR IF OK (SPACE)
5030 024646 104006              ERROR  6                ;ERROR, BIT WINDOW WAS A MARK
5031 024650              66$:
5032 024650 005203              INC     R3              ;BUMP BIT COUNTER
5033 024652 022703 000010      CMP     #10,R3          ;DONE FULL 8 BITS YET
5034 024656 001357              BNE    64$             ;BR IF NO
5035 024660 005003              CLR    R3              ;CLEAR BIT COUNTER
5036 024662 005300              DEC    R0              ;DEC CHARACTER COUNT
5037 024664 001335              BNE    12$            ;BR IF NOT DONE YET
5038
5039
5040
5041 024666 013700 031230      MOV     CALBCC,R0       ;PUT BCC IN R0
5042 024672 104413 000001      68$: DATACLK,1        ;SHIFT HARDWARE BCC
5043 024676 006000              ROR    R0              ;SHIFT SOFT BCC
5044 024700 103005              BCC    69$             ;BR IF CARRY CLEAR
5045 024702 004737 030226              JSR    PC,GETSI        ;LOOK AT BIT WINDOW
5046 024706 103406              BCS    70$             ;BR IF OK (MARK)
5047 024710 104014              ERROR  14              ;ERROR, CRC WRONG (SPACE)
5048 024712 000404              BR     70$             ;CONTINUE
5049 024714 004737 030226      69$: JSR     PC,GETSI        ;LOOK AT BIT WINDOW
5050 024720 103001              BCC    70$             ;BR IF OK (SPACE)
5051 024722 104014              ERROR  14              ;ERROR, CRC WRONG (MARK)
5052 024724              70$:
5053 024724 005203              INC     R3              ;BUMP BIT COUNTER
5054 024726 022703 000020      CMP     #20,R3          ;FINISHED BCC YET?
5055 024732 001357              BNE    68$             ;BR IF NO
5056 024734 005003              CLR    R3              ;CLEAR BIT COUNTER
5057 024736 012700 000004      MOV     #4,R0           ;RESET CHARACTER COUNTER
5058 024742 012704 032012      MOV     #MESDAT,R4      ;LOAD MESSAGE POINTER
5059 024746 005037 025000              CLR    11$            ;CLR SOFT BCC
5060 024752 112405              13$: MOV     (R4)+,R5     ;LOAD CHAR IN R5
5061 024754 010502              MOV     R5,R2          ;LOAD CHAR IN R2
5062
5063
5064
5065 024756 012737 120001 031226      MOV     #CRC16,XPOLY    ;LOAD POLYNOMIAL
5066 024764 010537 024776              MOV     R5,76$         ;LOAD SOFT CHAR FOR BCC
5067 024770 004537 031122              JSR     R5,SIMBCC      ;CALCULATE SOFT BCC
5068 024774 000010              10                    ;SHIFT COUNT
5069 024776 000000              76$: 0                  ;CHARACTER

```

```

5070 025000 000000          11$: 0          :OLD BCC
5071 025002 013737 031230 025000 MOV CALBCC,11$ :LOAD SOFT BCC FOR NEXT SHIFT
5072 025010 104413 000001 73$: DATACLK, 1 :SHIFT DATA IN TO BIT WINDOW
5073 025014 106002          RORB R2 :SHIFT SOFT DATA
5074 025016 103005          BCC 74$ :BR IF A SPACE
5075 025020 004737 030226 JSR PC,GETSI :LOOK AT BIT WINDOW
5076 025024 103406          BCS 75$ :BR IF OK (MARK)
5077 025026 104006          ERROR 6 :ERROR, BIT WINDOW WAS A SPACE
5078 025030 000404          BR 75$ :CONTINUE
5079 025032 004737 030226 74$: JSR PC,GETSI :LOOK AT BIT WINDOW
5080 025036 103001          BCC 75$ :BR IF OK (SPACE)
5081 025040 104006          ERROR 6 :ERROR, BIT WINDOW WAS A MARK
5082 025042          75$:
5083 025042 005203          INC R3 :BUMP BIT COUNTER
5084 025044 022703 000010 CMP #10,R3 :DONT FULL 8 BITS YET
5085 025050 001357          BNE 73$ :BR IF NO
5086 025052 005003          CLR R3 :CLEAR BIT COUNTER
5087 025054 005300          DEC R0 :DEC CHARACTER COUNT
5088 025056 001335          BNE 13$ :BR IF NOT DONE YET
5089
5090 :CHECK BCC FOR PRECEDING MESSAGE IN THE BIT WINDOW
5091
5092 025060 013700 031230 MOV CALBCC,R0 :PUT BCC IN R0
5093 025064 104413 000001 77$: DATACLK,1 :SHIFT HARDWARE BCC
5094 025070 006000          ROR R0 :SHIFT SOFT BCC
5095 025072 103005          BCC 78$ :BR IF CARRY CLEAR
5096 025074 004737 030226 JSR PC,GETSI :LOOK AT BIT WINDOW
5097 025100 103406          BCS 79$ :BR IF OK (MARK)
5098 025102 104014          ERROR 14 :ERROR, CRC WRONG (SPACE)
5099 025104 000404          BR 79$ :CONTINUE
5100 025106 004737 030226 78$: JSR PC,GETSI :LOOK AT BIT WINDOW
5101 025112 103001          BCC 79$ :BR IF OK (SPACE)
5102 025114 104014          ERROR 14 :ERROR, CRC WRONG (MARK)
5103 025116          79$:
5104 025116 005203          INC R3 :BUMP BIT COUNTER
5105 025120 022703 000020 CMP #20,R3 :FINISHED BCC YET?
5106 025124 001357          BNE 77$ :BR IF NO
5107 025126 005003          CLR R3 :CLEAR BIT COUNTER
5108
5109 :CHECK TO SEE IF TRANSMITTER IS MARKING
5110
5111 025130 104413 000001 2$: DATACLK, 1 :CLOCK TRANSMITTER
5112 025134 004737 030226 JSR PC,GETSI :LOOK AT WINDOW
5113 025140 103401          BCS 3$ :IT SHOULD BE MARKING
5114 025142 104024          ERROR 24 :ERROR, BIT WAS A SPACE
5115 025144 005203          INC R3 :BUMP BIT COUNTER
5116 025146 022703 000007 3$: CMP #7,R3 :DONE YET
5117 025152 001366          BNE 2$ :BR IF NO
5118 025154 104413 000010 DATACLK, 10 :GIVE ENOUGH TICKS TO CLEAR OUT ACTIVE
5119 025160 005003          CLR R3 :CLEAR BIT COUNTER
5120 025162 104413 000001 4$: DATACLK, 1 :SHIFT OUT NEXT BIT
5121 025166 004737 030226 JSR PC,GETSI :LOOK AT BIT WINDOW
5122 025172 103401          BCS +4 :BR IF IT IS A MARK
5123 025174 104024          ERROR 24 :ERROR, TRANSMITTER IS NOT MARKING
5124 025176 005203          INC R3 :INC BIT COUNT
5125 025200 022703 000020 CMP #20,R3 :DONE YET?

```

```

5126 025204 001366          BNE      4$          ;BR IF NO
5127
5128                          ;CHECK TO SEE THAT FIRST FOUR CHARACTER MESSAGE
5129                          ;WAS RECEIVED CORRECTLY (0,125,252,377)
5130
5131 025206 104413 000001    DATACLK, 1          ;GET LAST BIT IN RECEIVER
5132 025212 012703 000004    MOV      #4,R3          ;R3=CHARACTER COUNT
5133 025216 012702 032012    MOV      #MESDAT,R2     ;LOAD MESSAGE POINTER IN R2
5134 025222 004737 031066    JSR      PC,INRDY       ;WAIT FOR INRDY
5135 025226 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5136 025230 021204          021204
5137 025232 016104 000004    MOV      4(R1),R4        ;PUT 'FOUND' IN R4
5138 025236 112205          MOVB     (R2)+,R5        ;PUT 'EXPECTED' IN R5
5139 025240 120504          CMPB    R5,R4           ;IS RECEIVED DATA CORRECT?
5140 025242 001401          BEQ     41$            ;BR IF YES
5141 025244 104010          ERROR   10            ;RECEIVE DATA ERROR
5142 025246 005303          41$: DEC     R3          ;DEC CHARACTER COUNT
5143 025250 001364          BNE     40$            ;BR IF NOT DONE YET
5144
5145                          ;CHECK TO SEE THAT IN BCC MATCH IS SET
5146                          ;AND THAT THE BCC WAS RECEIVED CORRECTLY
5147
5148 025252 004737 031066    JSR      PC,INRDY       ;WAIT FOR INRDY
5149 025256 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5150 025260 021204          021204            ;GET FIRST HALF OF CRC
5151 025262 116137 000004 001302  MOVB     4(R1),$TMP2     ;PUT IN $TMP2
5152 025270 042737 177400 001302  BIC     #177400,$TMP2   ;CLEAR HI BYTE
5153 025276 004737 031066    JSR      PC,INRDY       ;WAIT FOR INRDY
5154 025302 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5155 025304 021244          021244
5156 025306 016104 000004    MOV      4(R1),R4        ;PUT 'FOUND' IN R4
5157 025312 042704 000376    BIC     #376,R4         ;CLEAR UNWANTED BITS
5158 025316 012705 000001    MOV      #1,R5          ;PUT 'EXPECTED' IN R5
5159 025322 120504          CMPB    R5,R4           ;IS IN BCC MATCH SET?
5160 025324 001401          BEQ     50$            ;BR IF YES
5161 025326 104015          ERROR   15            ;IN BCC MATCH ERROR
5162 025330          50$:
5163 025330 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5164 025332 021204          021204            ;GET LAST HALF
5165 025334 116137 000004 001301  MOVB     4(R1),$TMP1+1   ;PUT IN $TMP1
5166 025342 042737 000377 001300  BIC     #377,$TMP1     ;CLEAR LO BYTE
5167 025350 053737 001300 001302  BIS     $TMP1,$TMP2     ;16 BIT BCC NOW IN $TMP2
5168 025356 023737 031230 001302  CMP     CALBCC,$TMP2    ;IS IT CORRECT?
5169 025364 001401          BEQ     42$            ;BR IF OK
5170 025366 104027          ERROR   27
5171
5172                          ;CHECK TO SEE THAT SECOND FOUR CHARACTER MESSAGE
5173                          ;WAS RECEIVED CORRECTLY (0,125,252,377)
5174
5175 025370 012703 000004          42$: MOV      #4,R3          ;R3=CHARACTER COUNT
5176 025374 012702 032012          MOV      #MESDAT,R2     ;LOAD MESSAGE POINTER IN R2
5177 025400 004737 031066          43$: JSR      PC,INRDY       ;WAIT FOR INRDY
5178 025404 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5179 025406 021204          021204
5180 025410 016104 000004    MOV      4(R1),R4        ;PUT 'FOUND' IN R4
5181 025414 112205          MOVB     (R2)+,R5        ;PUT 'EXPECTED' IN R5

```

```

5182 025416 120504          CMPB   R5,R4          ;IS RECEIVED DATA CORRECT?
5183 025420 001401          BEQ    44$           ;BR IF YES
5184 025422 104010          ERROR  10           ;RECEIVE DATA ERROR
5185 025424 005303          44$: DEC    R3       ;DEC CHARACTER COUNT
5186 025426 001364          BNE    43$           ;BR IF NOT DONE YET
5187
5188                          ;CHECK TO SEE THAT IN BCC MATCH IS SET
5189                          ;AND THAT THE BCC WAS RECEIVED CORRECTLY
5190
5191 025430 004737 031066     JSR    PC,INRDY      ;WAIT FOR INRDY
5192 025434 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5193 025436 021204          021204         ;GET FIRST HALF OF CRC
5194 025440 116137 000004 001302  MOVB   4(R1),STMP2  ;PUT IN STMP2
5195 025446 042737 177400 001302  BIC   #177400,STMP2 ;CLEAR HI BYTE
5196 025454 004737 031066     JSR    PC,INRDY      ;WAIT FOR INRDY
5197 025460 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5198 025462 021244          021244
5199 025464 016104 000004     MOV    4(R1),R4     ;PUT 'FOUND' IN R4
5200 025470 042704 000376     BIC   #376,R4      ;CLEAR UNWANTED BITS
5201 025474 012705 000001     MOV    #1,R5       ;PUT 'EXPECTED' IN R5
5202 025500 120504          CMPB   R5,R4       ;IS IN BCC MATCH SET?
5203 025502 001401          BEQ    51$         ;IN BCC MATCH ERROR
5204 025504 104015          ERROR  15
5205 025506
5206 025506 104412          51$: ROMCLK        ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5207 025510 021204          021204         ;GET LAST HALF
5208 025512 116137 000004 001301  MOVB   4(R1),STMP1+1 ;PUT IN STMP1
5209 025520 042737 000377 001300  BIC   #377,STMP1   ;CLEAR LO BYTE
5210 025526 053737 001300 001302  BIS   STMP1,STMP2  ;16 BIT BCC NOW IN STMP2
5211 025534 023737 031230 001302  CMP   CALBCC,STMP2 ;IS IT CORRECT?
5212 025542 001401          BEQ    5$         ;BR IF OK
5213 025544 104027          ERROR  27
5214 025546
5215
5216
5217
5218
5219
5220
5221
5222
5223
5224
5225
5226
5227
5228
5229
5230
5231
5232 025546 000004          5$:
5233 025550 012737 000053 001202  TST53: SCOPE
5234 025556 012737 026746 001442  MOV    #53,$STSTNM ; LOAD THE NO. OF THIS TEST
5235
5236 025564 104410          MOV    #TST54,$NEXT ; POINT TO THE START OF NEXT TEST.
5237

```

```

***** TEST 53 *****
;DDCMP EOM FUNCTION TEST
;THIS TEST LOADS OUT SILO WITH: 2 SYNC'S, 4 CHAR MESSAGE, EOM
;SOM, 4 CHAR MESS, EOM. THE DATA STREAM IS CHECKED TO BE
;*4 CHAR, BCC, 4 CHAR, BCC, MARKS. THIS TEST VERIFYS THAT
;THE CHARCTERS LOADED WITH EOM SET ARE LOST
;ALSO THAT THE CHAR LOADED WITH SOM IS NOT IN THE BCC
;ALL DATA AND BCC'S ARE CHECKED IN THE BIT WINDOW
;THE FOUR CHARACTER MESSAGE IS 0,125,252,377
;RECEIVED DATA IS VERIFIED, AND IN BCC MATCH IS CHECKED
*****

```

```

: TEST 53
:-----

```

```

*****
TST53:
MOV    #53,$STSTNM ; LOAD THE NO. OF THIS TEST
MOV    #TST54,$NEXT ; POINT TO THE START OF NEXT TEST.
;R1 CONTAINS BASE KMC11 ADDRESS
;MASTER CLEAR KMC11

```

```

5238                                     ;LOAD OUT DATA SILO
5239
5240 025566 012711 004000      MOV    #BIT11,(R1)      ;SET LINE UNIT LOOP
5241 025572 012704 032012      MOV    #MESDAT,R4      ;LOAD POINTER TO DATA
5242 025576 005037 025712      CLR    10$             ;CLEAR SOFT BCC
5243 025602 012700 000004      MOV    #4,R0           ;LOAD CHARACTER COUNT
5244 025606 004737 031374      JSR    PC,SYNLD        ;LOAD 2 SYNCs IN OUT SILO
5245 025612 004737 030412      JSR    PC,OUTRDY       ;WAIT FOR OUTRDY
5246 025616 004537 031530      JSR    R5,MESLD        ;LOAD SILO WITH 4 CHAR MESS
5247 025622 032012             MESDAT                 ;ADDRESS OF MESSAGE
5248 025624 000004             4                     ;NUMBER OF CHARACTERS
5249 025626 004737 031504      JSR    PC,EOM          ;LOAD GARBAGE CHARACTER, WITH EOM SET
5250 025632 004737 031454      JSR    PC,SOM          ;LOAD GARBAGE CHAR WITH SOM SET
5251 025636 004537 031530      JSR    R5,MESLD        ;LOAD FOUR MORE CHARACTERS
5252 025642 032012             MESDAT                 ;ADDRESS OF MESSAGE
5253 025644 000004             4                     ;NUMBER OF CHACTERS
5254 025646 004737 031504      JSR    PC,EOM          ;SET EOM
5255 025652 004737 030260      JSR    PC,OCOR         ;WAIT FOR OCOR
5256 025656 005003             CLR    R3              ;CLEAR BIT COUNTER
5257 025660 104413 000022      DATACLK,22           ;CLOCK DATA
5258 025664 112405             12$: MOVB (R4)+,R5        ;LOAD R5 WITH CHAR
5259 025666 010502             MOV    R5,R2           ;LOAD R2 WITH CHAR
5260
5261                                     ;CHECK FIRST FOUR CHARACTER MESSAGE
5262                                     ;IN THE BIT WINDOW (0,125,252,377)
5263
5264 025670 012737 120001 031226  MOV    #CRC16,XPOLY    ;LOAD POLYNOMIAL
5265 025676 010537 025710             MOV    R5,67$         ;LOAD SOFT CHAR FOR BCC
5266 025702 004537 031122      JSR    R5,SIMBCC       ;CALCULATE SOFT BCC
5267 025706 000010             10                    ;SHIFT COUNT
5268 025710 000000             67$: 0                ;CHARACTER
5269 025712 000000             10$: 0                ;OLD BCC
5270 025714 013737 031230 025712  MOV    CALBCC,10$     ;LOAD SOFT BCC FOR NEXT SHIFT
5271 025722 104413 000001             64$: DATACLK, 1      ;SHIFT DATA IN TO BIT WINDOW
5272 025726 106002             RORB R2               ;SHIFT SOFT DATA
5273 025730 103005             BCC 65$                ;BR IF A SPACE
5274 025732 004737 030226      JSR    PC,GETSI        ;LOOK AT BIT WINDOW
5275 025736 103406             BCS 66$                ;BR IF OK (MARK)
5276 025740 104006             ERROR 6                ;ERROR, BIT WINDOW WAS A SPACE
5277 025742 000404             BR 66$                 ;CONTINUE
5278 025744 004737 030226             65$: JSR PC,GETSI        ;LOOK AT BIT WINDOW
5279 025750 103001             BCC 66$                ;BR IF OK (SPACE)
5280 025752 104006             ERROR 6                ;ERROR, BIT WINDOW WAS A MARK
5281 025754             66$:
5282 025754 005203             INC R3                 ;BUMP BIT COUNTER
5283 025756 022703 000010             CMP #10,R3            ;DONE FULL 8 BITS YET
5284 025762 001357             BNE 64$                ;BR IF NO
5285 025764 005003             CLR R3                 ;CLEAR BIT COUNTER
5286 025766 005300             DEC R0                 ;DEC CHARACTER COUNT
5287 025770 001335             BNE 12$                ;BR IF NOT DONE YET
5288
5289                                     ;CHECK BCC FOR PRECEDING MESSAGE IN THE BIT WINDOW
5290
5291 025772 013700 031230             68$: MOV CALBCC,R0      ;PUT BCC IN R0
5292 025776 104413 000001             DATACLK,1           ;SHIFT HARDWARE BCC
5293 026002 006000             ROR R0                 ;SHIFT SOFT BCC

```

```

5294 026004 103005          BCC 69$          :BR IF CARRY CLEAR
5295 026006 004737 030226  JSR PC,GETSI    :LOOK AT BIT WINDOW
5296 026012 103406          BCS 70$          :BR IF OK (MARK)
5297 026014 104014          ERROR 14         :ERROR, CRC WRONG (SPACE)
5298 026016 000404          BR 70$          :CONTINUE
5299 026020 004737 030226  69$: JSR PC,GETSI    :LOOK AT BIT WINDOW
5300 026024 103001          BCC 70$          :BR IF OK (SPACE)
5301 026026 104014          ERROR 14         :ERROR, CRC WRONG (MARK)
5302 026030          70$:
5303 026030 005203          INC R3          :BUMP BIT COUNTER
5304 026032 022703 000020  CMP #20,R3      :FINISHED BCC YET?
5305 026036 001357          BNE 68$         :BR IF NO
5306 026040 005003          CLR R3          :CLEAR BIT COUNTER
5307
5308 ;CHECK CHARACTER LOADED WITH SOM (000), IN THE BIT WINDOW
5309
5310 026042 005005          CLR R5          :CHARACTER LOADED WITH SOM
5311 026044 010502          MOV R5,R2      :LOAD R2 WITH CHAR
5312 026046 104413 000001  32$: DATACL, 1    :CLOCK TRANSMITTER
5313 026052 106002          RORB R2        :SHIFT SOFT DATA
5314 026054 103005          BCC 30$        :BR IF SPACE
5315 026056 004737 030226  JSR PC,GETSI    :LOOK AT BIT WINDOW
5316 026062 103406          BCS 31$        :BR IF OK (MARK)
5317 026064 104006          ERROR 6        :ERROR,BIT WINDOW WAS A SPACE
5318 026066 000404          BR 31$        :CONTINUE
5319 026070 004737 030226  30$: JSR PC,GETSI    :LOOK AT BIT WINDOW
5320 026074 103001          BCC 31$        :BR IF OK (SPACE)
5321 026076 104006          ERROR 6        :ERROR,BIT WINDOW WAS A MARK
5322 026100 005203          31$: INC R3        :BUMP BIT COUNTER
5323 026102 022703 000010  CMP #10,R3     :DONE CHARACTER YET?
5324 026106 001357          BNE 32$        :BR IF NO
5325 026110 005003          CLR R3        :RESET BIT COUNTER
5326 026112 012700 000004  MOV #4,R0      :RESET CHARACTER COUNTER
5327 026116 012704 032012  MOV #MESDAT,R4 :LOAD MESSAGE POINTER
5328 026122 005037 026154  CLR 11$       :CLR SOFT BCC
5329 026126 112405          13$: MOVB (R4)+,R5   :LOAD CHAR IN R5
5330 026130 010502          MOV R5,R2     :LOAD CHAR IN R2
5331
5332 ;CHECK SECOND MESSAGE IN THE BIT WINDOW (0,125,252,377)
5333
5334 026132 012737 120001 031226  MOV #CRC16,XPOLY :LOAD POLYNOMIAL
5335 026140 010537 026152  MOV R5,76$     :LOAD SOFT CHAR FOR BCC
5336 026144 004537 031122  JSR R5,SIMBCC  :CALCULATE SOFT BCC
5337 026150 000010          10           :SHIFT COUNT
5338 026152 000000          76$: 0        :CHARACTER
5339 026154 000000          11$: 0        :OLD BCC
5340 026156 013737 031230 026154  MOV CALBCC,11$ :LOAD SOFT BCC FOR NEXT SHIFT
5341 026164 104413 000001  73$: DATACL, 1    :SHIFT DATA IN TO BIT WINDOW
5342 026170 106002          RORB R2        :SHIFT SOFT DATA
5343 026172 103005          BCC 74$        :BR IF A SPACE
5344 026174 004737 030226  JSR PC,GETSI    :LOOK AT BIT WINDOW
5345 026200 103406          BCS 75$        :BR IF OK (MARK)
5346 026202 104006          ERROR 6        :ERROR, BIT WINDOW WAS A SPACE
5347 026204 000404          BR 75$        :CONTINUE
5348 026206 004737 030226  74$: JSR PC,GETSI    :LOOK AT BIT WINDOW
5349 026212 103001          BCC 75$        :BR IF OK (SPACE)

```

```

5350 026214 104006
5351 026216
5352 026216 005203
5353 026220 022703 000010
5354 026224 001357
5355 026226 005003
5356 026230 005300
5357 026232 001335
5358
5359
5360
5361 026234 013700 031230
5362 026240 104413 000001
5363 026244 006000
5364 026246 103005
5365 026250 004737 030226
5366 026254 103406
5367 026256 104014
5368 026260 000404
5369 026262 004737 030226
5370 026266 103001
5371 026270 104014
5372 026272
5373 026272 005203
5374 026274 022703 000020
5375 026300 001357
5376 026302 005003
5377
5378
5379
5380 026304 104413 000001
5381 026310 004737 030226
5382 026314 103401
5383 026316 104024
5384 026320 005203
5385 026322 022703 000007
5386 026326 001366
5387 026330 104413 000010
5388 026334 005003
5389 026336 104413 000001
5390 026342 004737 030226
5391 026346 103401
5392 026350 104024
5393 026352 005203
5394 026354 022703 000020
5395 026360 001366
5396
5397
5398
5399
5400 026362 104413 000001
5401 026366 012703 000004
5402 026372 012702 032012
5403 026376 004737 031066
5404 026402 104412
5405 026404 021204

75%:
ERROR 6 ;ERROR, BIT WINDOW WAS A MARK
INC R3 ;BUMP BIT COUNTER
CMP #10,R3 ;DONE FULL 8 BITS YET
BNE 73% ;BR IF NO
CLR R3 ;CLEAR BIT COUNTER
DEC R0 ;DEC CHARACTER COUNT
BNE 13% ;BR IF NOT DONE YET

;CHECK BCC FOR PRECEDING MESSAGE IN THE BIT WINDOW

77%:
MOV CALBCC,R0 ;PUT BCC IN R0
DATACLK,1 ;SHIFT HARDWARE BCC
ROR R0 ;SHIFT SOFT BCC
BCC 78% ;BR IF CARRY CLEAR
JSR PC,GETSI ;LOOK AT BIT WINDOW
BCS 79% ;BR IF OK (MARK)
ERROR 14 ;ERROR, CRC WRONG (SPACE)
BR 79% ;CONTINUE

78%:
JSR PC,GETSI ;LOOK AT BIT WINDOW
BCC 79% ;BR IF OK (SPACE)
ERROR 14 ;ERROR, CRC WRONG (MARK)

79%:
INC R3 ;BUMP BIT COUNTER
CMP #20,R3 ;FINISHED BCC YET?
BNE 77% ;BR IF NO
CLR R3 ;CLEAR BIT COUNTER

;CHECK TO SEE IF TRANSMITTER IS MARKING

2%:
DATACLK, 1 ;CLOCK TRANSMITTER
JSR PC,GETSI ;LOOK AT WINDOW
BCS 3% ;IT SHOULD BE MARKING
ERROR 24 ;ERROR, BIT WAS A SPACE

3%:
INC R3 ;BUMP BIT COUNTER
CMP #7,R3 ;DONE YET
BNE 2% ;BR IF NO
DATACLK, 10 ;GIVE ENOUGH TICKS TO CLEAR OUT ACTIVE
CLR R3 ;CLEAR BIT COUNTER

4%:
DATACLK, 1 ;SHIFT OUT NEXT BIT
JSR PC,GETSI ;LOOK AT BIT WINDOW
BCS +4 ;BR IF IT IS A MARK
ERROR 24 ;ERROR, TRANSMITTER IS NOT MARKING
INC R3 ;INC BIT COUNT
CMP #20,R3 ;DONE YET?
BNE 4% ;BR IF NO

;CHECK TO SEE THAT FIRST FOUR CHARACTER MESSAGE
;WAS RECEIVED CORRECTLY (0,125,252,377)

40%:
DATACLK, 1 ;GET LAST BIT IN RECEIVER
MOV #4,R3 ;R3=CHARACTER COUNT
MOV #MESDAT,R2 ;LOAD MESSAGE POINTER IN R2
JSR PC,INRDY ;WAIT FOR INRDY
ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
021204

```



```

5406 026406 016104 000004      MOV      4(R1),R4      ;PUT 'FOUND' IN R4
5407 026412 112205              MOVVB   (R2)+,R5      ;PUT 'EXPECTED' IN R5
5408 026414 120504              CMPB   R5,R4         ;IS RECEIVED DATA CORRECT?
5409 026416 001401              BEQ    41$           ;BR IF YES
5410 026420 104010              ERROR  10           ;RECEIVE DATA ERROR
5411 026422 005303      41$:  DEC    R3           ;DEC CHARACTER COUNT
5412 026424 001364              BNE    40$           ;BR IF NOT DONE YET
5413
5414                          ;CHECK TO SEE THAT IN BCC MATCH IS SET
5415                          ;AND THAT THE BCC WAS RECEIVED CORRECTLY
5416
5417 026426 004737 031066      JSR    PC,INRDY      ;WAIT FOR INRDY
5418 026432 104412              ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5419 026434 021204              021204 ;GET FIRST HALF OF CRC
5420 026436 116137 000004 001302  MOVB   4(R1),$TMP2    ;PUT IN $TMP2
5421 026444 042737 177400 001302  BIC   #177400,$TMP2  ;CLEAR HI BYTE
5422 026452 004737 031066      JSR    PC,INRDY      ;WAIT FOR INRDY
5423 026456 104412              ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5424 026460 021244              021244
5425 026462 016104 000004      MOV    4(R1),R4      ;PUT 'FOUND' IN R4
5426 026466 042704 000376      BIC   #376,R4        ;CLEAR UNWANTED BITS
5427 026472 012705 000001      MOV    #1,R5         ;PUT 'EXPECTED' IN R5
5428 026476 120504              CMPB   R5,R4         ;IS IN BCC MATCH SET?
5429 026500 001401              BEQ    50$           ;IN BCC MATCH ERROR
5430 026502 104015              ERROR  15
5431 026504
5432 026504 104412              ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5433 026506 021204              021204 ;GET LAST HALF
5434 026510 116137 000004 001301  MOVVB  4(R1),$TMP1+1 ;PUT IN $TMP1
5435 026516 042737 000377 001300  BIC   #377,$TMP1    ;CLEAR LO BYTE
5436 026524 053737 001300 001302  BIS   $TMP1,$TMP2    ;16 BIT BCC NOW IN $TMP2
5437 026532 023737 031230 001302  CMP   CALBCC,$TMP2  ;IS IT CORRECT?
5438 026540 001401              BEQ    45$           ;BR IF OK
5439 026542 104027              ERROR  27
5440
5441                          ;CHECK THAT CHARACTER LOADED WITH SOM WAS RECEIVED (000)
5442
5443 026544 004737 031066      45$:  JSR    PC,INRDY      ;WAIT FOR INRDY
5444 026550 104412              ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5445 026552 021204              021204 ;GET RECEIVE DATA
5446 026554 016104 000004      MOV    4(R1),R4      ;PUT 'FOUND' IN R4
5447 026560 005005              CLR    R5            ;PUT 'EXPECTED' IN R5
5448 026562 120504              CMPB   R5,R4         ;IS RECEIVED DATA CORRECT?
5449 026564 001401              BEQ    42$           ;BR IF YES
5450 026566 104010              ERROR  10           ;RECEIVE DATA ERROR
5451
5452                          ;CHECK TO SEE THAT SECOND FOUR CHARACTER MESSAGE
5453                          ;WAS RECEIVED CORRECTLY (0,125,252,377)
5454
5455 026570 012703 000004      42$:  MOV    #4,R3         ;R3=CHARACTER COUNT
5456 026574 012702 032012      MOV    #MESDAT,R2    ;LOAD MESSAGE POINTER IN R2
5457 026600 004737 031066      43$:  JSR    PC,INRDY      ;WAIT FOR INRDY
5458 026604 104412              ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5459 026606 021204              021204
5460 026610 016104 000004      MOV    4(R1),R4      ;PUT 'FOUND' IN R4
5461 026614 112205              MOVVB  (R2)+,R5      ;PUT 'EXPECTED' IN R5
  
```

```

5462 026616 120504          CMPB   R5,R4          ;IS RECEIVED DATA CORRECT?
5463 026620 001401          BEQ    44$           ;BR IF YES
5464 026622 104010          ERROR  10           ;RECEIVE DATA ERROR
5465 026624 005303          44$: DEC   R3        ;DEC CHARACTER COUNT
5466 026626 001364          BNE    43$           ;BR IF NOT DONE YET
5467
5468                          ;CHECK TO SEE THAT IN BCC MATCH IS SET
5469                          ;AND THAT THE BCC WAS RECEIVED CORRECTLY
5470
5471 026630 004737 031066     JSR    PC,INRDY      ;WAIT FOR INRDY
5472 026634 104412          ROMCLK 021204       ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5473 026636 021204          MOV    4(R1),STMP2  ;GET FIRST HALF OF CRC
5474 026640 116137 000004 001302  MOVB   #177400,STMP2 ;PUT IN STMP2
5475 026646 042737 177400 001302  BIC    #177400,STMP2 ;CLEAR HI BYTE
5476 026654 004737 031066     JSR    PC,INRDY      ;WAIT FOR INRDY
5477 026660 104412          ROMCLK 021244       ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5478 026662 021244          MOV    4(R1),R4     ;PUT 'FOUND' IN R4
5479 026664 016104 000004          BIC    #376,R4      ;CLEAR UNWANTED BITS
5480 026670 042704 000376          MOV    #1,R5        ;PUT 'EXPECTED' IN R5
5481 026674 012705 000001          CMPB   R5,R4        ;IS IN BCC MATCH SET?
5482 026700 120504          BEQ    51$           ;IN BCC MATCH ERROR
5483 026702 001401          ERROR  15
5484 026704 104015          51$: ROMCLK 021204       ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5485 026706          MOV    4(R1),STMP1+1 ;GET LAST HALF
5486 026706 104412          MOV    #377,STMP1  ;PUT IN STMP1
5487 026710 021204          BIC    #377,STMP1  ;CLEAR LO BYTE
5488 026712 116137 000004 001301  BIS    STMP1,STMP2  ;16 BIT BCC NOW IN STMP2
5489 026720 042737 000377 001300  CMP    CALBCC,STMP2 ;IS IT CORRECT?
5490 026726 053737 001300 001302  BEQ    5$            ;BR IF OK
5491 026734 023737 031230 001302  ERROR  27
5492 026742 001401          5$:
5493 026744 104027
5494 026746
5495
5496
5497
5498                          ;***** TEST 54 *****
5499                          ;*EMPTY SILO TEST
5500                          ;*LOAD SILO WITH 2 SYNCs, 4 CHAR MESSAGE, SINGLE CLOCK
5501                          ;*UNTIL THE SILO IS EMPTY, LOAD 4 MORE CHARACTERS IN THE
5502                          ;*SILO. GIVE MORE TICKS, AND VERIFY THAT ONLY THE FIRST
5503                          ;*4 CHARACTER MESSAGE WAS RECEIVED AND THAT RTS IS CLEAR
5504                          ;*****
5505                          ; TEST 54
5506                          ;-----
5507                          ;*****
5508 026746 000004          TST54: SCOPE
5509 026750 012737 000054 001202  MOV    #54,STSTNM   ; LOAD THE NO. OF THIS TEST
5510 026756 012737 027200 001442  MOV    #TST55,NEXT  ; POINT TO THE START OF NEXT TEST.
5511                          ;R1 CONTAINS BASE KMC11 ADDRESS
5512 026764 104410          MSTCLR ;MASTER CLEAR KMC11
5513 026766 012711 004000          MOV    #BIT11,(R1) ;SET LINE UNIT LOOP
5514 026772 012702 032012          MOV    #MESDAT,R2  ;R2 POINTS TO MESSAGE
5515 026776 012700 000004          MOV    #4,R0        ;R0 = CHAR COUNT
5516 027002 004737 031374          JSR    PC,SYNLD     ;LOAD SILO WITH TWO SYNCs
5517 027006 004737 030412          JSR    PC,OUTRDY   ;WAIT FOR OUTRDY

```

```

5518 027012 004537 031530 JSR R5,MESLD ;LOAD MESSAGE IN SILO
5519 027016 032012 MESDAT ;START OF MESSAGE
5520 027020 000004 4 ;CHARACTER COUNT
5521 027022 004737 030260 JSR PC,OCOR ;WAIT FOR OCOR
5522 027026 104413 000065 DATACLK, 65 ;CLOCK DATA (EMPTY SILO)
5523 027032 004537 031530 JSR R5,MESLD ;PUT MORE CHARACTERS IN SILO
5524 027036 032012 MESDAT
5525 027040 000004 4
5526 027042 004737 030260 JSR PC,OCOR
5527 027046 104413 000005 DATACLK, 5 ;CLOCK UNTIL RTS IS CLEARED
5528 027052 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5529 027054 021264 021264 ;GET RTS
5530 027056 032761 000040 000004 BIT #BIT5,4(R1) ;IS IT CLEAR?
5531 027064 001401 BEQ 5$ ;BR IF YES
5532 027066 104034 ERROR 34 ;ERROR, RTS NOT CLEAR
5533 027070 104413 000041 5$: DATACLK, 41 ;CLOCK XMITTER SOME MORE
5534 027074 004737 031066 1$: JSR PC,INRDY ;OK LETS CHECK WHAT WAS RECEIVED
5535 027100 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5536 027102 021204 021204 ;GET RECEIVE DATA
5537 027104 016104 000004 MOV 4(R1),R4 ;PUT IT IN R4
5538 027110 112205 MOVB (R2)+,R5 ;R5 = 'EXPECTED'
5539 027112 120504 CMPB R5,R4 ;IS DATA CORRECT?
5540 027114 001401 BEQ 2$ ;BR IF OK
5541 027116 104010 ERROR 10 ;DATA ERROR
5542 027120 005300 2$: DEC RO ;DEC CHAR COUNT
5543 027122 001364 BNE 1$ ;BR IF NOT DONE YET
5544 027124 004737 031066 3$: JSR PC,INRDY ;WAIT FOR INRDY
5545 027130 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5546 027132 021204 021204 ;GET RECEIVE DATA
5547 027134 016104 000004 MOV 4(R1),R4 ;PUT IT IN 'FOUND'
5548 027140 012705 000377 MOV #377,R5 ;R5 = 'EXPECTED'
5549 027144 120504 CMPB R5,R4 ;SHOULD SEE 377
5550 027146 001401 BEQ 4$ ;BR IF OK
5551 027150 104010 ERROR 10 ;ERROR, TRANSMITTER DID NOT ABORT
5552 027152 004737 031066 4$: JSR PC,INRDY ;WAIT FOR INRDY
5553 027156 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5554 027160 021204 021204 ;GET RECEIVE DATA
5555 027162 016104 000004 MOV 4(R1),R4 ;PUT IT IN 'FOUND'
5556 027166 012705 000377 MOV #377,R5 ;R5 = 'EXPECTED'
5557 027172 120504 CMPB R5,R4 ;SHOULD SEE 377
5558 027174 001401 BEQ 10$ ;BR IF OK
5559 027176 104010 ERROR 10 ;ERROR, TRANSMITTER DID NOT ABORT
5560 027200 10$:

```

```

5561
5562
5563 ;***** TEST 55 *****
5564 ;*HALF DUPLEX TEST
5565 ;*SET LINE UNIT LOOP AND HALF DUPLEX, SEND SYNCs AND A
5566 ;*MESSAGE. VERIFY THAT IN-ACTIVE AND IN-READY ARE CLEAR
5567 ;*****
5568

```

```

5569 ; TEST 55
5570 ;-----
5571 ;*****
5572 027200 000004 TST55: SCOPE
5573 027202 012737 000055 001202 MOV #55,$STSNM ; LOAD THE NO. OF THIS TEST

```

```
5574 027210 012737 027316 001442      MOV      #TST56,NEXT      ; POINT TO THE START OF NEXT TEST.
5575                                     ;R1 CONTAINS BASE KMC11 ADDRESS
5576 027216 104410      MSTCLR     ;MASTER CLEAR KMC11
5577 027220 012702 000012      MOV      #12,R2         ;SAVE R2 FOR TYPEOUT
5578 027224 012711 004000      MOV      #BIT11,(R1)    ;SET LINE UNIT LOOP
5579 027230 012761 000020 000004      MOV      #BIT4,4(R1)   ;LOAD PORT4
5580 027236 104412      ROMCLK    ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5581 027240 122113      122113    ;SET H/D BIT
5582 027242 004737 031374      JSR      PC,SYNLD      ;LOAD 2 SYNCs
5583 027246 004737 030412      JSR      PC,OUTRDY    ;WAIT FOR OUTRDY
5584 027252 004537 031530      JSR      R5,MESLD     ;LOAD 4 CHAR MESSAGE
5585 027256 032012      MESDAT    ;ADDRESS OF MESSAGE
5586 027260 000004      4         ;CHARACTER COUNT
5587 027262 004737 030260      JSR      PC,OCOR      ;WAIT FOR OCOR
5588 027266 104413 000073      DATACLK, 73         ;SEND MESSAGE
5589 027272 104412      ROMCLK    ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5590 027274 021244      021244    ;READ LU-12
5591 027276 016104 000004      MOV      4(R1),R4      ;PUT "FOUND" IN R4
5592 027302 042704 000257      BIC      #257,R4       ;CLEAR UNWANTED BITS
5593 027306 005005      CLR      R5           ;R5 = 'EXPECTED'
5594 027310 120504      CMPB     R5,R4        ;IN-ACTIVE AND IN-RDY SHOULD BE CLEAR
5595 027312 001401      BEQ     1$           ;BR IF OK
5596 027314 104035      ERROR    35         ;ERROR BOTH ARE NOT CLEAR
5597 027316                                     1$:
```

```
5598
5599
5600      ;***** TEST 56 *****
5601      ;*DDCMP CABLE DATA TEST
5602      ;*THIS TEST LOADS OUT SILO WITH THE FOLLOWING:
5603      ;*4 SYNCs,16 CHAR,EOM,16 CHAR,EOM,16 CHAR,EOM
5604      ;*THE 16 CHARACTERS INCLUDE A FLOATING ONE AND ZERO
5605      ;*THE DATA IS TRANSMITTED OVER THE CABLE USING THE INTERNAL CLOCK
5606      ;*RECEIVED DATA IS VERIFIED AS IS IN BCC MATCH
5607      ;*LOOP-BACK CONNECTOR MUST BE ON TO RUN THIS TEST
5608      ;*****
```

```
5609      ; TEST 56
5610      ;-----
5611
```

```
5612      ;*****
5613 027316 000004      TST56: SCOPE
5614 027320 012737 000056 001202      MOV      #56,$STNM     ; LOAD THE NO. OF THIS TEST
5615 027326 012737 027706 001442      MOV      #TST57,NEXT  ; POINT TO THE START OF NEXT TEST.
5616                                     ;R1 CONTAINS BASE KMC11 ADDRESS
5617 027334 104410      MSTCLR     ;MASTER CLEAR KMC11
5618 027336 032737 040000 002050      BIT      #BIT14,STAT1 ;SKIP TEST IF NO
5619 027344 001557      BEQ     3$         ;LOOPBACK CONNECTOR ON
5620 027346 012711 004000      MOV      #BIT11,(R1)  ;SET LINE UNIT LOOP
5621 027352 004737 031374      JSR      PC,SYNLD    ;LOAD 2 SYNCs
5622 027356 004737 031374      JSR      PC,SYNLD    ;LOAD 2 MORE SYNCs
5623 027362 012737 120001 031226      MOV      #CRC16,XPOLY ;LOAD POLYNOMIAL FOR SOFT CRC CALC
5624 027370 005037 027420      CLR      6$         ;CLEAR OLD BCC
5625 027374 012703 000020      MOV      #16.,R3     ;CHARACTER COUNT
5626 027400 012702 032016      MOV      #FLTDAT,R2  ;R2= POINTER
5627 027404 112237 027416      MOVB    (R2)+,5$     ;LOAD CHAR FOR SOFT BCC CALC.
5628 027410 004537 031122      JSR      R5,SIMBCC   ;CALC SOFT BCC
5629 027414 000010      10          ;SHIFT COUNT
```

5630	027416	000000			5\$:	0		: CHARACTER
5631	027420	000000			6\$:	0		: OLD BCC
5632	027422	013737	031230	027420		MOV	CALBCC,68	: LOAD OLD BCC
5633	027430	005303				DEC	R3	: DEC COUNT
5634	027432	001364				BNE	7\$: BR IF NOT DONE YET
5635	027434	004537	031530			JSR	R5,MESLD	: LOAD SILO
5636	027440	032016				FLTDAT		: MESSAGE ADDRESS
5637	027442	000020				16.		: CHARACTER COUNT
5638	027444	004737	031504			JSR	PC,EOM	: LOAD AN EOM
5639	027450	004537	031530			JSR	R5,MESLD	: LOAD SILO
5640	027454	032016				FLTDAT		: MESSAGE ADDRESS
5641	027456	000020				16.		: CHARACTER COUNT
5642	027460	004737	031504			JSR	PC,EOM	: LOAD AN EOM
5643	027464	004537	031530			JSR	R5,MESLD	: LOAD SILO
5644	027470	032016				FLTDAT		: MESSAGE ADDRESS
5645	027472	000020				16.		: CHARACTER COUNT
5646	027474	004737	031504			JSR	PC,EOM	: LOAD AN EOM
5647	027500	004737	030260			JSR	PC,OCOR	: WAIT FOR OCOR
5648	027504	005011				CLR	(R1)	: CLEAR LINE UNIT LOOP
5649	027506	012700	000003			MOV	#3,R0	: R0 = MESSAGE COUNT
5650	027512	012703	000020			MOV	#16.,R3	: R3= CHARACTER COUNT
5651	027516	012702	032016			MOV	#FLTDAT,R2	: LOAD MESSAGE POINTER IN R2
5652	027522	004737	031066		1\$:	JSR	PC,INRDY	: WAIT FOR INRDY
5653	027526	104412				ROMCLK		: NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5654	027530	021204				021204		: GET DATA FROM IN SILO
5655	027532	016104	000004			MOV	4(R1),R4	: PUT CHARACTER IN 'FOUND'
5656	027536	112205				MOVB	(R2)+,R5	: PUT 'EXPECTED' IN R5
5657	027540	120504				CMPB	R5,R4	: IS RECEIVED DATA CORRECT
5658	027542	001401				BEQ	2\$: BR IF OK
5659	027544	104025				ERROR	25	: DATA ERROR
5660	027546				2\$:			
5661	027546	005303				DEC	R3	: DEC CHARACTER COUNT
5662	027550	001364				BNE	1\$: BR IF NOT DONE THIS MESSAGE
5663	027552	012703	000020			MOV	#16.,R3	: RESET CHARACTER COUNT
5664								
5665								: CHECK TO SEE THAT IN BCC MATCH IS SET
5666								: AND THAT THE BCC WAS RECEIVED CORRECTLY
5667								
5668	027556	004737	031066			JSR	PC,INRDY	: WAIT FOR INRDY
5669	027562	104412				ROMCLK		: NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5670	027564	021204				021204		: GET FIRST HALF OF CRC
5671	027566	116137	000004	001302		MOVB	4(R1),\$TMP2	: PUT IN \$TMP2
5672	027574	042737	177400	001302		BIC	#177400,\$TMP2	: CLEAR HI BYTE
5673	027602	004737	031066			JSR	PC,INRDY	: WAIT FOR INRDY
5674	027606	104412				ROMCLK		: NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5675	027610	021244				021244		
5676	027612	016104	000004			MOV	4(R1),R4	: PUT 'FOUND' IN R4
5677	027616	042704	000376			BIC	#376,R4	: CLEAR UNWANTED BITS
5678	027622	012705	000001			MOV	#1,R5	: PUT 'EXPECTED' IN R5
5679	027626	120504				CMPB	R5,R4	: IS IN BCC MATCH SET?
5680	027630	001401				BEQ	25\$	
5681	027632	104015				ERROR	15	: IN BCC MATCH ERROR
5682	027634				25\$:			
5683	027634	104412				ROMCLK		: NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5684	027636	021204				021204		: GET LAST HALF
5685	027640	116137	000004	001301		MOVB	4(R1),\$TMP1+1	: PUT IN \$TMP1

5686 027646 042737 000377 001300
5687 027654 053737 001300 001302
5688 027662 023737 031230 001302
5689 027670 001401
5690 027672 104027
5691 027674 012702 032016
5692 027700 005300
5693 027702 001307
5694 027704 104420
5695
5696
5697
5698
5699
5700
5701
5702
5703
5704
5705
5706
5707
5708
5709 027706 000004
5710 027710 012737 000057 001202
5711 027716 012737 003662 001442
5712
5713 027724 104410
5714 027726 032737 040000 002050
5715 027734 001533
5716 027736 012711 004000
5717 027742 004737 031374
5718 027746 004737 031374
5719 027752 012737 120001 031226
5720 027760 005037 030010
5721 027764 012703 000073
5722 027770 012702 032012
5723 027774 112237 030006 75:
5724 030000 004537 031122
5725 030004 000010
5726 030006 000000 55:
5727 030010 000000 65:
5728 030012 013737 031230 030010
5729 030020 005303
5730 030022 001364
5731 030024 004537 031530
5732 030030 032012
5733 030032 000073
5734 030034 004737 031504
5735 030040 004737 030260
5736 030044 005011
5737 030046 012700 000073
5738 030052 012702 032012
5739 030056 004737 031066 15:
5740 030062 104412
5741 030064 021204

```

BIC #377,$TMP1 ;CLEAR LO BYTE
BIS $TMP1,$TMP2 ;16 BIT BCC NOW IN $TMP2
CMP CALBCC,$TMP2 ;IS IT CORRECT?
BEQ 4$ ;BR IF OK
ERROR 27
MOV #R1,LTDAT,R2 ;RESET MESSAGE POINTER
DEC R0 ;DECREMENT COUNTER
BNE 1$ ;BR IF NOT DONE
ADVANCE ; ADVANCE TO NEXT TEST
4$:
3$:
***** TEST 57 *****
;DDCMP CABLE DATA TEST
;THIS TEST LOADS OUT SILO WITH THE FOLLOWING:
;*4 SYNCs,59 DATA CHARACTERS,EOM WITH GARBAGE CHARACTER
;*THE DATA IS TRANSMITTED OVER THE CABLE USING THE INTERNAL CLOCK
;*RECEIVED DATA IS VERIFIED AS IS IN BCC MATCH
;*LOOP-BACK CONNECTOR MUST BE ON TO RUN THIS TEST
*****
; TEST 57
-----
*****
TST57: SCOPE
MOV #57,$TSTNM ; LOAD THE NO. OF THIS TEST
MOV #SEOP,NEXT ; POINT TO THE END OF PASS HANDLER.
MSTCLR ;R1 CONTAINS BASE KMC11 ADDRESS
BIT #BIT14,STAT1 ;MASTER CLEAR KMC11
BEQ 3$ ;SKIP TEST IF NO
MOV #BIT11,(R1) ;LOOPBACK CONNECTOR ON
JSR PC,SYNLD ;SET LINE UNIT LOOP
JSR PC,SYNLD ;LOAD 2 SYNCs
MOV #CRC16,XPOLY ;LOAD POLYNOMIAL FOR SOFT CRC CALC
CLR 6$ ;CLEAR OLD BCC
MOV #59,R3 ;CHARACTER COUNT
MOV #MESDAT,R2 ;R2= POINTER
MOV (R2)+,5$ ;LOAD CHAR FOR SOFT BCC CALC.
JSR R5,SIMBCC ;CALC SOFT BCC
10 ;SHIFT COUNT
0 ;CHARACTER
0 ;CHARACTER
MOV CALBCC,6$ ;OLD BCL
DEC R3 ;LOAD OLD BCC
BNE 7$ ;DEC COUNT
JSR R5,MESLD ;BR IF NOT DONE YET
MESDAT ;LOAD SILO
59. ;MESSAGE ADDRESS
PC,EOM ;CHARACTER COUNT
PC,OCOR ;LOAD AN EOM
CLR (R1) ;WAIT FOR OCOR
MOV #59,R0 ;CLEAR LINE UNIT LOOP
MOV #MESDAT,R2 ;R0= CHARACTER COUNT
JSR PC,INRDY ;LOAD MESSAGE POINTER IN R2
ROMCLK ;WAIT FOR INRDY
021204 ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
;GET DATA FROM IN SILO

```

```

5742 030066 016104 000004      MOV      4(R1),R4      ;PUT CHARACTER IN 'FOUND'
5743 030072 112205      MOVB     (R2)+,R5     ;PUT 'EXPECTED' IN R5
5744 030074 120504      CMPB     R5,R4       ;IS RECEIVED DATA CORRECT
5745 030076 001401      BEQ      2$          ;BR IF OK
5746 030100 104025      ERROR   2$          ;DATA ERROR
5747 030102      2$:
5748 030102 005300      DEC      R0          ;DECREMENT COUNTER
5749 030104 001364      BNE      1$          ;BR IF NOT DONE
5750
5751      ;CHECK TO SEE THAT IN BCC MATCH IS SET
5752      ;AND THAT THE BCC WAS RECEIVED CORRECTLY
5753
5754 030106 004737 031066      JSR      PC,INRDY    ;WAIT FOR INRDY
5755 030112 104412      ROMCLK   021204     ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5756 030114 021204      021204     ;GET FIRST HALF OF CRC
5757 030116 116137 000004 001302      MOVB     4(R1),$TMP2 ;PUT IN $TMP2
5758 030124 042737 177400 001302      BIC      #177400,$TMP2 ;CLEAR HI BYTE
5759 030132 004737 031066      JSR      PC,INRDY    ;WAIT FOR INRDY
5760 030136 104412      ROMCLK   021244     ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5761 030140 021244      021244
5762 030142 016104 000004      MOV      4(R1),R4    ;PUT 'FOUND' IN R4
5763 030146 042704 000376      BIC      #376,R4     ;CLEAR UNWANTED BITS
5764 030152 012705 000001      MOV      #1,R5      ;PUT 'EXPECTED' IN R5
5765 030156 120504      CMPB     R5,R4       ;IS IN BCC MATCH SET?
5766 030160 001401      BEQ      25$         ;
5767 030162 104015      ERROR   15          ;IN BCC MATCH ERROR
5768 030164      25$:
5769 030164 104412      ROMCLK   021204     ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5770 030166 021204      021204     ;GET LAST HALF
5771 030170 116137 000004 001301      MOVB     4(R1),$TMP1+1 ;PUT IN $TMP1
5772 030176 042737 000377 001300      BIC      #377,$TMP1   ;CLEAR LO BYTE
5773 030204 053737 001300 001302      BIS      $TMP1,$TMP2  ;16 BIT BCC NOW IN $TMP2
5774 030212 023737 031230 001302      CMP      CALBCC,$TMP2 ;IS IT CORRECT?
5775 030220 001401      BEQ      3$          ;BR IF OK
5776 030222 104027      ERROR   27          ;
5777 030224 104420      3$: ADVANCE      ; ADVANCE TO NEXT TEST
5778
5779
5780      ;SUBROUTINES
5781      ;-----
5782
5783 030226      GETSI:
5784      ;THIS SUBROUTINE READS LU 17, AND PUTS IT INTO NITC.
5785      ;NITC IS ROTATED LEFT UNTILL THE SI BIT IS IN CARRY
5786
5787 030226 104412      ROMCLK   021364     ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5788 030230 021364      021364     ;PORT4_LU 17
5789 030232 017737 151636 030256      MOV      @KMP04,NITC ;STORE LU 17
5790 030240 106137 030256      ROLB     NITC
5791 030244 106137 030256      ROLB     NITC
5792 030250 106137 030256      ROLB     NITC      ;PUT SI IN THE CARRY BIT
5793 030254 000207      RTS      PC
5794 030256 000000      NITC: 0
5795
5796
5797 030260      OCOR:

```

```

5798                                     :THIS SUBROUTINE SPINS ON OCOR
5799
5800 030260 104412 ROMCLK                :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5801 030262 021364 021364                :PORT4 LU 17
5802 030264 032777 000020 151602 BIT      #BIT4,2KMP04 :IS OCOR SET?
5803 030272 001772 BEQ      OCOR          :BR IF NO
5804 030274 000207 RTS      PC            :OK OCOR IS SET, GO BACK
5805
5806
5807 030276 SYNC:                          :THIS SUBROUTINE LOADS THE SILO WITH THE NUMBER OF SYNC
5808                                     :CHARACTERS PASSED TO IT IN THE WORD AFTER THE JSR CALL
5809                                     :AND A NON-SYNC CHARACTER (301)
5810
5811
5812 030276 013637 001276 MOV      2(SP)+,$TMP0 :GET COUNT
5813 030302 062746 000002 ADD      #2,-(SP)   :ADJUST STACK
5814 030306 012761 000026 000004 MOV      #26,4(R1)  :LOAD PORT4
5815 030314 104412 ROMCLK                :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5816 030316 122114 122114                :LOAD SYNC REGISTER
5817 030320 004737 030412 1$: JSR      PC,OUTRDY  :WAIT FOR OUTRDY
5818 030324 012761 000001 000004 MOV      #1,4(R1)  :LOAD PORT4
5819 030332 104412 ROMCLK                :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5820 030334 122111 122111                :SET SOM
5821 030336 012761 000026 000004 MOV      #26,4(R1)  :LOAD PORT4
5822 030344 104412 ROMCLK                :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5823 030346 122110 122110                :LOAD OUT DATA
5824 030350 005337 001276 DEC      $TMP0     :ALL DONE?
5825 030354 001361 BNE      1$       :BR IF NOT
5826 030356 004737 030412 JSR      PC,OUTRDY :WAIT FOR OUTRDY
5827 030362 005061 000004 CLR      4(R1)     :LOAD PORT4
5828 030366 104412 ROMCLK                :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5829 030370 122111 122111                :SET SOM
5830 030372 012761 000301 000004 MOV      #301,4(R1) :LOAD PORT4
5831 030400 104412 ROMCLK                :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5832 030402 122110 122110                :LOAD OUT DATA
5833 030404 004737 030260 JSR      PC,OCOR   :WAIT FOR OCOR
5834 030410 000207 RTS      PC
5835
5836
5837 030412 OUTRDY:                          :THIS SUBROUTINE SPINS ON OUT READY
5838
5839
5840 030412 005037 001306 CLR      $TMP4     :CLEAR TIMER
5841 030416 1$:
5842 030416 104412 ROMCLK                :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5843 030420 021224 021224                :PORT4 LU11
5844 030422 032777 000020 151444 BIT      #BIT4,2KMP04 :IS OUT RDY SET?
5845 030430 001004 BNE      2$       :BR IF YES
5846 030432 005237 001306 INC      $TMP4     :INC TIMER
5847 030436 001367 BNE      1$       :KEEP CHECKING IF NOT DONE
5848 030440 104036 ERROR 36           :ERROR, OUT READY NOT SET
5849 030442 000207 RTS      PC
5850
5851
5852 030444 CHAR:                            :THIS SUBROUTINE LOADS THE SILO WITH 3 SYNC
5853
    
```



```

5854                                     :AND THE CHARACTER PASSED TO IT.
5855
5856 030444 013637 001300      MOV      @ (SP)+, $TMP1      :GET CHARACTER
5857 030450 062746 000002      ADD      #2, -(SP)         :ADJUST STACK
5858 030454 012737 000003 001276  MOV      #3, $TMP0         :SET FOR 3 SYNCs
5859 030462 012761 000026 000004  MOV      #26, 4(R1)        :LOAD PORT4
5860 030470 104412              ROMCLK              :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5861 030472 122114              122114              :LOAD SYNC REGISTER
5862 030474 004737 030412 1$: JSR      PC, OUTRDY       :WAIT FOR OUTRDY
5863 030500 012761 000001 000004  MOV      #1, 4(R1)        :LOAD PORT4
5864 030506 104412              ROMCLK              :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5865 030510 122111              122111              :SET SOM
5866 030512 012761 000026 000004  MOV      #26, 4(R1)        :LOAD PORT4
5867 030520 104412              ROMCLK              :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5868 030522 122110              122110              :LOAD OUT DATA
5869 030524 005337 001276      DEC      $TMP0            :ALL DONE?
5870 030530 001361              BNE      1$              :BR IF NOT
5871 030532 004737 030412  JSR      PC, OUTRDY       :WAIT FOR OUTRDY
5872 030536 013761 001300 000004  MOV      $TMP1, 4(R1)     :LOAD PORT4
5873 030544 104412              ROMCLK              :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5874 030546 122110              122110              :LOAD OUT DATA
5875 030550 004737 030260  JSR      PC, OCOR         :WAIT FOR OCOR
5876 030554 000207              RTS      PC
5877
5878
5879 030556      CHARSD:
5880                                     :THIS SUBROUTINE LOADS THE SILO WITH THE CHARACTER PASSED TO IT.
5881
5882 030556 013637 001300      MOV      @ (SP)+, $TMP1      :GET CHARACTER
5883 030562 062746 000002      ADD      #2, -(SP)         :ADJUST STACK
5884 030566 004737 030412  JSR      PC, OUTRDY       :WAIT FOR OUTRDY
5885 030572 013761 001300 000004  MOV      $TMP1, 4(R1)     :LOAD PORT4
5886 030600 104412              ROMCLK              :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5887 030602 122110              122110              :LOAD OUT DATA
5888 030604 004737 030412  JSR      PC, OUTRDY       :WAIT FOR OUTRDY
5889 030610 104412              ROMCLK              :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5890 030612 122110              122110              :LOAD GARBAGE CHAR
5891 030614 004737 030260  JSR      PC, OCOR         :WAIT FOR OCOR
5892 030620 000207              RTS      PC
5893
5894
5895 030622      SILOLD:
5896                                     :THIS SUBROUTINE FILLS THE OUT SILO
5897                                     : WITH A BINARY COUNT PATTERN
5898
5899 030622 012737 000073 001300  MOV      #73, $TMP1        :LOAD COUNT
5900 030630 005737 031062  TST      $CHAR            :FIRST TIME HERE?
5901 030634 100470              BMI      4$              :BR IF BITSTUFF
5902 030636 001032              BNE      2$              :BR IF NO
5903 030640 062737 000002 001300  ADD      #2, $TMP1        :ADD 2 TO CHARACTER COUNT
5904 030646 012737 000003 001276  MOV      #3, $TMP0         :SET FOR 3 SYNCs
5905 030654 012761 000026 000004  MOV      #26, 4(R1)        :LOAD PORT4
5906 030662 104412              ROMCLK              :NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5907 030664 122114              122114              :LOAD SYNC REGISTER
5908 030666 004737 030412 1$: JSR      PC, OUTRDY       :WAIT FOR OUTRDY
5909 030672 012761 000001 000004  MOV      #1, 4(R1)        :LOAD PORT4

```

```

5910 030700 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5911 030702 122111 ;SET SOM
5912 030704 012761 000026 000004 MOV #26,4(R1) ;LOAD PORT4
5913 030712 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5914 030714 122110 122110 ;LOAD OUT DATA
5915 030716 005337 001276 DEC $TMP0 ;ALL DONE?
5916 030722 001361 BNE 1$ ;BR IF NOT
5917 030724 004737 030412 2$: JSR PC,OUTRDY ;WAIT FOR OUTRDY
5918 030730 013761 031062 000004 MOV SCHAR,4(R1) ;LOAD PORT4
5919 030736 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5920 030740 122110 122110 ;LOAD OUT DATA
5921 030742 005737 031064 TST STUFLG ;BITSTUFF???
5922 030746 001407 BEQ 6$ ;BR IF NO
5923 030750 013737 031062 030762 MOV SCHAR,5$ ;IT IS SLDL SO CHECK BITSTUFFING
5924 030756 004537 031612 JSR R5,STFFCL ;ADD ANY BIT STUFF CLOCK TICKS
5925 030762 000000 5$: 0 ;CHARACTER
5926 030764 000010 10 ;CHIFT COUNT
5927 030766 005237 031062 6$: INC SCHAR ;NEXT CHARACTER
5928 030772 022737 000400 031062 CMP #400,SCHAR ;ALL DONE?
5929 031000 001403 BEQ 3$
5930 031002 005337 001300 DEC $TMP1 ;DECREMENT COUNT
5931 031006 001346 BNE 2$ ;BR IF NOT DONE
5932 031010 004737 030260 3$: JSR PC,OCOR ;WAIT FOR OCOR
5933 031014 000207 RTS PC
5934 031016 005037 031062 4$: CLR SCHAR ;START PATTERN AT ZERO
5935 031022 012737 177777 031064 MOV #-1,STUFLG ;SET BITSTUFF FLAG
5936 031030 005037 032010 CLR BITCON ;CLEAR STUFF COUNT
5937 031034 062737 000002 001300 ADD #2,$TMP1 ;ADD 2 TO CHARACTER COUNT
5938 031042 012761 000001 000004 MOV #1,4(R1) ;SET BITO IN PORT4
5939 031050 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5940 031052 122111 122111 ;SET SOM!
5941 031054 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5942 031056 122110 122110 ;LOAD GARBAGE CHAR
5943 031060 000721 BR 2$ ;GO LOAD SILO
5944 031062 000000 SCHAR: 0
5945 031064 000000 STUFLG: 0
5946
5947
5948 031066 INRDY:
5949 ;THIS SUBROUTINE SPINS ON INRDY
5950 ;IF INRDY FAILS TO SET THE DELAY TIMES OUT AND AN
5951 ;ERROR IS REPORTED. FOR BETTER SCOPE LOOPS THIS
5952 ;DELAY CAN BE MADE SHORTER BY ALTERING THE NUMBER
5953 ;INITIALLY LOADED INTO $TMP0, THE SMALLER THE NUMBER
5954 ;THE SHORTER THE DELAY. 0 IS THE LONGEST DELAY.
5955
5956 031066 012737 000000 001276 1$: MOV #0,$TMP0 ;SET UP DELAY COUNTER
5957 031074
5958 031074 104412 ROMCLK ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
5959 031076 021244 021244 ;PORT4 LU12
5960 031100 032777 000020 150766 BIT #BIT4,$KMP04 ;IS INRDY SET?
5961 031106 001004 BNE 2$ ;BR IF YES
5962 031110 005237 001276 INC $TMP0 ;INC DELAY
5963 031114 001367 BNE 1$ ;TRY AGAIN
5964 031116 104037 ERROR 37 ;ERROR,NO INRDY
5965 031120 000207 2$: RTS PC ;RETURN
    
```

```

5966
5967
5968 031122          SIMBCC:
5969                ;THIS SUBROUTINE CALCULATES THE CRC USING POLYNOMIAL GIVEN
5970                ;IN XPOLY. THE CORRECT CRC IS $LPADRED IN CALBCC, AND THE
5971                ;STATE OF THE LSB OF THE BCC IS $LPADRED IN THE C BIT.
5972
5973 031122 010046      MOV      RO,-(SP)          ;SAVE RO ON STACK
5974 031124 012537 001276  MOV      (R5)+,$TMP0        ;$TMP0 = SHIFT COUNT
5975 031130 012537 001300  MOV      (R5)+,$TMP1        ;$TMP1 = CHARACTER
5976 031134 012537 031230  MOV      (R5)+,CALBCC      ;CALBCC = OLD BCC
5977 031140 013700 031230 1$:      MOV      CALBCC,RO          ;PUT OLD BCC IN RO
5978 031144 000241      CLC
5979 031146 006037 031230  ROR      CALBCC          ;SHIFT OLD BCC
5980 031152 006037 031300  ROR      $TMP1          ;SHIFT CHARACTER
5981 031156 005500      ADC      RO              ;ADD CHAR CARRY TO OLD BCC
5982 031160 006000      ROR      RO              ;PUT BITO TO CARRY BIT
5983 031162 103011      BCC      2$              ;CARRY IS FEEDBACK BIT
5984 031164 013700 031226  MOV      XPOLY,RO          ;IF FEEDBACK = 1
5985 031170 043700 031230  BIC      CALBCC,RO          ;EXCLUSIVLY OR XPOLY TO CALBCC
5986 031174 043737 031226  BIC      XPOLY,CALBCC
5987 031202 050037 031230  BIS      RO,CALBCC
5988 031206 005337 001276 2$:      DEC      $TMP0          ;DEC SHIFT COUNT
5989 031212 001352      BNE      1$              ;BR IF NOT DONE
5990 031214 013700 031230  MOV      CALBCC,RO          ;PUT RESULT IN RO
5991 031220 006000      ROR      RO              ;SHIFT BITO TO CARRY
5992 031222 012600      MOV      (SP)+,RO          ;RESTORE RO
5993 031224 000205      RTS      R5              ;$LPADR
5994 031226 000000      XPOLY: 0
5995 031230 000000      CALBCC: 0
5996                LRC8=200
5997                CRC16=120001
5998                CRC.CCITT=102010
5999
6000
6001 031232          BCCLD:
6002                ;THIS SUBROUTINE LOADS THE OUT SILO WITH 2 SYNCs
6003                ;WITH SOM SET, AND ONE CHARACTER PASSED TO IT
6004                ;WITH THE SOM BIT CLEAR (ENABLE CRC)
6005
6006 031232 013637 001300  MOV      @(SP)+,$TMP1      ;GET CHARACTER
6007 031236 062746 000002  ADD      #2,-(SP)          ;ADJUST STACK
6008 031242 012737 000002  MOV      #2,$TMP0          ;SET FOR 2 SYNCs
6009 031250 012761 000026  MOV      #26,4(R1)        ;LOAD PORT4
6010 031256 104412      ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6011 031260 122114      122114          ;LOAD SYNC REGISTER
6012 031262 004737 030412 1$:      JSR      PC,OUTRDY        ;WAIT FOR OUTRDY
6013 031266 012761 000001 000004  MOV      #1,4(R1)        ;LOAD PORT4
6014 031274 104412      ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6015 031276 122111      122111          ;SET SOM
6016 031300 012761 000026 000004  MOV      #26,4(R1)        ;LOAD PORT4
6017 031306 104412      ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6018 031310 122110      122110          ;LOAD OUT DATA
6019 031312 005337 001276  DEC      $TMP0          ;ALL DONE?
6020 031316 001361      BNE      1$              ;BR IF NOT
6021 031320 004737 030412  JSR      PC,OUTRDY        ;WAIT FOR OUTRDY

```

```

6022 031324 013761 001300 000004      MOV    STMP1,4(R1)      ;LOAD PORT4
6023 031332 104412                    ROMCLK                 ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6024 031334 122110                    122110                ;LOAD OUT DATA
6025 031336 004737 030260            JSR    PC,OCOR        ;WAIT FOR OCOR
6026 031342 000207                    RTS    PC
6027
6028
6029 031344                          GETQO:
6030                                ;THIS SUBROUTINE READS THE STATE OF THE TRANSMIT
6031                                ;BCC LSB AND PUTS IT IN THE CARRY BIT
6032
6033 031344 104412                    ROMCLK                 ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6034 031346 021364                    021364                ;PORT4 LU-17
6035 031350 106177 150520            ROLB   @KMP04         ;PUT Q0 IN CARRY
6036 031354 000207                    RTS    PC              ;RETURN
6037
6038
6039 031356                          GETQI:
6040                                ;THIS SUBROUTINE READS THE STATE OF THE RECEIVE
6041                                ;BCC LSB AND PUTS IT IN THE CARRY BIT
6042
6043 031356 104412                    ROMCLK                 ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6044 031360 021364                    021364                ;PORT4 LU-17
6045 031362 106177 150506            ROLB   @KMP04         ;PUT Q0 IN CARRY
6046 031366 106177 150502            ROLB   @KMP04         ;PUT Q1 IN CARRY
6047 031372 000207                    RTS    PC              ;RETURN
6048
6049
6050 031374                          SYNLD:
6051                                ;THIS SUBROUTINE LOADS OUT SILO WITH
6052                                ;2 SYNC CHARACTERS WITH SOM SET
6053
6054 031374 012737 000002 001276      MOV    #2,$STMP0      ;LOAD COUNTER FOR 2 SYNC
6055 031402 012761 000026 000004      MOV    #26,4(R1)     ;PORT4 26
6056 031410 104412                    ROMCLK                 ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6057 031412 122114                    122114                ;LOAD SYNC REG
6058 031414 004737 030412 1$:      JSR    PC,OUTRDY     ;WAIT FOR OUTRDY
6059 031420 012761 000001 000004      MOV    #1,4(R1)      ;LOAD PORT4
6060 031426 104412                    ROMCLK                 ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6061 031430 122111                    122111                ;SET SOM
6062 031432 012761 000026 000004      MOV    #26,4(R1)     ;PORT 26
6063 031440 104412                    ROMCLK                 ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6064 031442 122110                    122110                ;LOAD OUT DATA WITH SYNC
6065 031444 005337 001276            DEC    $STMP0        ;DECREMENT COUNTER
6066 031450 001361                    BNE   1$             ;BR IF NOT DONE
6067 031452 000207                    RTS    PC              ;RETURN
6068
6069
6070 031454                          SOM:
6071                                ;THIS SUBROUTINE LOADS SOM AND OUT DATA WITH A
6072                                ;GARBAGE CHARACTER (0)
6073
6074 031454 004737 030412                    JSR    PC,OUTRDY     ;WAIT FOR OUTRDY
6075 031460 012761 000001 000004      MOV    #1,4(R1)      ;PORT4 1
6076 031466 104412                    ROMCLK                 ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6077 031470 122111                    122111                ;SET SOM

```

```

6078 031472 005061 000004          CLR      4(R1)          ;CLEAR DATA CHAR
6079 031476 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6080 031500 122110          122110          ;LOAD GARBAGE CHARACTER
6081 031502 000207          RTS      PC          ;RETURN
6082
6083
6084 031504          EOM:
6085          ;THIS SUBROUTINE LOADS EOM AND OUT DATA WITH A
6086          ;GARBAGE CHARACTER (2) TO ENABLE TRANSMISSION OF BCC
6087
6088 031504 004737 030412          JSR      PC,OUTRDY      ;WAIT FOR OUTRDY
6089 031510 012761 000002 000004      MOV      #2,4(R1)      ;PORT4 2
6090 031516 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6091 031520 122111          122111          ;SET EOM
6092 031522 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6093 031524 122110          122110          ;LOAD GARBAGE CHARACTER
6094 031526 000207          RTS      PC          ;RETURN
6095
6096
6097 031530          MESLD:
6098          ;THIS SUBROUTINE LOADS SILO WITH MESSAGE
6099          ;THE FIRST ARUGUMENT IS THE ADDRESS OF THE MESSAGE
6100          ;THE SECOND ARGUMENT IS THE NUMBER OF CHARACTERS IN THE MESSAGE
6101
6102 031530 010046          MOV      RO,-(SP)      ;SAVE RO
6103 031532 012500          MOV      (R5)+,RO      ;RO=MESSAGE POINTER
6104 031534 012537 001276          MOV      (R5)+,$TMPO    ;$TMPO=CHARACTER COUNT
6105 031540 004737 030412          JSR      PC,OUTRDY      ;WAIT FOR OUT RDY
6106 031544 112061 000004          MOV      (R0)+,4(R1)    ;LOAD PORT4 WITH CHARACTER
6107 031550 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6108 031552 122110          122110          ;LOAD OUT DATA SILO
6109 031554 005337 001276          DEC      $TMPO          ;DEC CHAR COUNT
6110 031560 001367          BNE      1$           ;BR IF NOT DONE
6111 031562 004737 030260          JSR      PC,OCOR        ;WAIT FOR OCOR
6112 031566 012600          MOV      (SP)+,RO      ;RESTORE RO
6113 031570 000205          RTS      R5           ;RETURN
6114
6115
6116 031572          CLR10:
6117          ;THIS SUBROUTINE SETS IN CLR AND OUT CLR TO
6118          ;CLEAR THE TRANSMIT AND RECEIVE BCC REGISTERS
6119
6120 031572 012761 000200 000004      MOV      #BIT7,4(R1)    ;LOAD PORT4
6121 031600 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6122 031602 122112          122112          ;SET IN CLR!
6123 031604 104412          ROMCLK          ;NEXT WORD IS INSTRUCTION, ROMCLK PC=5304
6124 031606 122111          122111          ;SET OUT CLR!
6125 031610 000207          RTS      PC          ;RETURN
6126
6127
6128 031612          STFFCL:
6129          ;THIS SUBROUTINE ADDS ANY NECESSARY BIT STUFF CLOCK TICKS
6130          ;FIRST ARGUMENT IS CHAR, SECOND ARGUMENT IS SHIFT COUNT.
6131
6132 031612 010046          MOV      RO,-(SP)      ;SAVE RO
6133 031614 012500          MOV      (R5)+,RO      ;PUT CHAR IN RO
    
```

```

6134 031616 012537 001302      MOV      (R5)+,$TMP2      ;PUT SHIFT COUNT IN $TMP2
6135 031622 106000      1$: RORB      RO            ;LOOK AT NEXT BIT
6136 031624 103403      BCS      2$              ;BR IF A MARK
6137 031626 005037 032010      CLR      BITCON          ;IT WAS A SPACE, CLEAR 1'S COUNTER
6138 031632 000412      BR       3$              ;CONTINUE
6139 031634 005237 032010      2$: INC      BITCON          ;INC CONSECUTIVE 1'S COUNTER
6140 031640 022737 000005 032010      CMP      #5,BITCON        ;IS IT 5 YET?
6141 031646 001004      BNE      3$              ;BR IF NO
6142 031650 005037 032010      CLR      BITCON          ;YES! SO START AGAIN
6143 031654 104413 000001      DATACL, 1              ;GIVE EXTRA TICK TO STUFF ZERO
6144 031660 005337 001302      3$: DEC      $TMP2         ;DEC SHIFT COUNT
6145 031664 001356      BNE      1$              ;BR IF NOT DONE
6146 031666 012600      MOV      (SP)+,RO        ;RESTORE RO
6147 031670 000205      RTS       R5              ;RETURN
6148
6149
6150 031672      STFFCK:
6151      ;THIS SUBROUTINE CHECKS TO SEE IF TRANSMITTER
6152      ;IS STUFFING ZEROS WHEN IT SHOULD. FIRST ARGUMENT
6153      ;IS THE CHARACTER, SECOND ARGUMENT IS SHIFT COUNT.
6154
6155 031672 010046      MOV      RO,-(SP)        ;SAVE RO
6156 031674 012500      MOV      (R5)+,RO        ;PUT CHAR IN RO
6157 031676 012537 001302      MOV      (R5)+,$TMP2     ;PUT SHIFT COUNT IN $TMP2
6158 031702 106000      1$: RORB      RO            ;SHIFT OUT NEXT BIT
6159 031704 103403      BCS      2$              ;BR IF IT IS A MARK
6160 031706 005037 032010      CLR      BITCON          ;IT WAS A SPACE, CLEAR 1'S COUNTER
6161 031712 000416      BR       3$              ;CONTINUE
6162 031714 005237 032010      2$: INC      BITCON          ;INC CONSECUTIVE 1'S COUNTER
6163 031720 022737 000005 032010      CMP      #5,BITCON        ;5 IN A ROW YET?
6164 031726 001010      BNE      3$              ;BR IF NO
6165 031730 005037 032010      CLR      BITCON          ;YES, SO START OVER
6166 031734 104413 000001      DATACL, 1              ;EXTRA TICK TO STUFF ZERO
6167 031740 004737 030226      JSR      PC,GETSI        ;LOOK AT WINDOW
6168 031744 103001      BCC      3$              ;IS IT A ZERO, BR IF YES
6169 031746 104030      ERROR   30              ;NO, ERROR ZERO WAS NOT STUFFED
6170 031750 005337 001302      3$: DEC      $TMP2         ;DEC SHIFT COUNT
6171 031754 001352      BNE      1$              ;BR IF NOT DONE
6172 031756 012600      MOV      (SP)+,RO        ;RESTORE RO
6173 031760 000205      RTS       R5              ;RETURN
6174
6175
6176 031762      CTSDLY:
6177      ;THIS SUBROUTINE WASTES TIME UNTIL CTS SETS,
6178      ;BUT HOPEFULLY NOT SO LONG THAT THE SILO RUNS OUT
6179
6180 031762 010046      MOV      RO,-(SP)        ;SAVE RO
6181 031764 012700 000032      MOV      #32,RO          ;LOAD RO WITH COUNT
6182 031770 027777 147250 147246 1$: CMP      @STKS,@STKS      ;WASTE TIME
6183 031776 005300      DEC      RO              ;DECREMENT COUNTER
6184 032000 001373      BNE      1$              ;DO IT AGAIN IF NOT = 0
6185 032002 012600      MOV      (SP)+,RO        ;RESTORE RO
6186 032004 000207      RTS       PC              ;RETURN
6187
6188
6189 032006 000176      FLAG:  *B<01111110>    ;FLAG CHARACTER
    
```

6190	032010	000000			BITCON: 0	
6191	032012	000	125	252	MESDAT: .BYTE	0,125,252,377
6192	032015	377				
6193	032016	001	002	004	FLTDAT: .BYTE	1,2,4,10,20,40,100,200,376,375,373,367,357,337,277,177
6194	032021	010	020	040		
6195	032024	100	200	376		
6196	032027	375	373	367		
6197	032032	357	337	277		
6198	032035	177				
6199	032036	100	140	160	STUFDT: .BYTE	100,140,160,170,3,300,174,176,177,1
6200	032041	170	003	300		
6201	032044	174	176	177		
6202	032047	001				
6203	032050	363	347	317	.BYTE	363,347,317,200,0,377,377,377,200,37
6204	032053	200	000	377		
6205	032056	377	377	200		
6206	032061	037				
6207					.EVEN	
6208	032062	046200	047111	020105	EM1:	.ASCIZ <200>/LINE UNIT INITIALIZATION TEST/
	032120	046200	047111	020105	EM2:	.ASCIZ <200>^LINE UNIT REGISTER READ/ONLY TEST^
	032163	200	044514	042516	EM3:	.ASCIZ <200>^LINE UNIT REGISTER WRITE/READ TEST^
	032227	200	044514	042516	EM4:	.ASCIZ <200>/LINE UNIT INTERNAL CLOCK FAILURE/
	032271	200	051124	047101	EM5:	.ASCIZ <200>/TRANSMITTER DATA ERROR/
	032321	200	042522	042503	EM6:	.ASCIZ <200>/RECEIVER TEST/
	032340	051200	041505	044505	EM7:	.ASCIZ <200>/RECEIVER DATA ERROR/
	032365				EM10:	
	032365	200	047515	042504	.ASCII	<200>/MODEM SIGNAL ERROR/
	032410	052200	044510	020123	.ASCII	<200>/THIS ERROR COULD BE CAUSED IF YOU HAVE V.35 AND /
	032471	200	052501	047524	.ASCIZ	<200>/AUTOSIZED. IF V.35, MANUALLY ANSWER QUESTIONS/
	032550	052200	040522	051516	EM11:	.ASCIZ <200>/TRANSMITTER CRC ERROR/
	032577	200	042522	042503	EM12:	.ASCIZ <200>/RECEIVER CRC ERROR/
	032623	200	047111	041040	EM13:	.ASCIZ <200>/IN BCC MATCH ERROR (LU REG 12)/
	032663	200	051124	047101	EM14:	.ASCIZ <200>/TRANSMITTER FAILED TO GO TO MARK STATE/
	032733	200	040503	046102	EM15:	.ASCIZ <200>/CABLE DATA TEST/
	032754	043200	040514	020107	EM16:	.ASCIZ <200>/FLAG ERROR/
	032770	052200	040522	051516	EM17:	.ASCIZ <200>/TRANSMITTER FAILED TO STUFF A ZERO/
	033034	051600	044527	041524	EM20:	.ASCIZ <200>/SWITCH PAC TEST/
	033055	200	041101	051117	EM21:	.ASCIZ <200>/ABORT ERROR/
	033072	052200	040522	051516	EM22:	.ASCIZ <200>/TRANSMITTER ERROR/
	033115	200	040510	043114	EM23:	.ASCIZ <200>/HALF DUPLEX TEST/
	033137	200	052517	020124	EM24:	.ASCIZ <200>/OUT READY NOT SET/
	033162	044600	020116	042522	EM25:	.ASCIZ <200>/IN READY NOT SET/
	033204	042600	050130	041505	DH1:	.ASCIZ <200>/EXPECTED FOUND/
	033225	200	054105	042520	DH2:	.ASCIZ <200>/EXPECTED FOUND LU-REGISTER/
	033263	200	044103	051101	DH3:	.ASCIZ <200>/CHARACTER BIT THAT FAILED/
	033321	200	047503	051122	DH4:	.ASCIZ <200>/CORRECT CRC BIT THAT FAILED/
	033361	200	054105	042520	DH5:	.ASCIZ <200>/EXPECTED FOUND SHIFT/
	033413	200	054105	042520	DH6:	.ASCIZ <200>/EXPECTED FOUND CHARACTER SHIFT/
	033461	200	046102	041517	DH7:	.ASCIZ <200>/BLOCK END NOT SET/
	033504	051200	051524	042040	DH10:	.ASCIZ <200>/RTS DID NOT CLEAR/
		033530			.EVEN	
	033530	000002			DT1:	2
	033532	003	007		.BYTE	3,7
	033534	001274			\$REG5	

033536	003	002		.BYTE	3,2
033540	001272			\$REG4	
033542	000003		DT2:	3	
033544	003	007		.BYTE	3,7
033546	001274			\$REG5	
033550	003	010		.BYTE	3,10
033552	001272			\$REG4	
033554	003	002		.BYTE	3,2
033556	001266			\$REG2	
033560	000002		DT3:	2	
033562	003	017		.BYTE	3,17
033564	001274			\$REG5	
033566	002	002		.BYTE	2,2
033570	001270			\$REG3	
033572	000002		DT4:	2	
033574	006	021		.BYTE	6,21
033576	031230			CALBCC	
033600	002	002		.BYTE	2,2
033602	001270			\$REG3	
033604	000003		DT5:	3	
033606	001	011		.BYTE	1,11
033610	001462			ZERO	
033612	001	011		.BYTE	1,11
033614	001464			ONE	
033616	002	002		.BYTE	2,2
033620	001262			\$REG0	
033622	000003		DT6:	3	
033624	001	011		.BYTE	1,11
033626	001464			ONE	
033630	001	011		.BYTE	1,11
033632	001462			ZERO	
033634	002	002		.BYTE	2,2
033636	001262			\$REG0	
033640	000004		DT7:	4	
033642	001	011		.BYTE	1,11
033644	001462			ZERO	
033646	001	011		.BYTE	1,11
033650	001464			ONE	
033652	003	007		.BYTE	3,7
033654	001274			\$REG5	
033656	002	001		.BYTE	2,1
033660	001270			\$REG3	
033662	000004		DT10:	4	
033664	001	011		.BYTE	1,11
033666	001464			ONE	
033670	001	011		.BYTE	1,11
033672	001462			ZERO	
033674	003	007		.BYTE	3,7
033676	001274			\$REG5	
033700	002	001		.BYTE	2,1
033702	001270			\$REG3	
033704	000002		DT11:	2	
033706	003	007		.BYTE	3,7
033710	032006			FLAG	
033712	002	002		.BYTE	2,2
033714	001270			\$REG3	

CZKCE MACY11 3GA(1052) 08-JUL-80 08:24 PAGE 122
CZKCE.P11 08-JUL-80 08:24 SUBROUTINES

E 10

SEQ 0121

033716	000002		DT12:	2	
033720	006	004		.BYTE	6.4
033722	031230			CALBCC	
033724	006	002		.BYTE	6.2
033726	001302			\$TMP2	

033730	000001		CORMAX:	
			.END	

ABASE = 000000	951	992		
ACDW1 = 000000	951	994		
ALDW2 = 000000	951	995		
ACPUOP = 000000	951	966		
ADDW0 = 000000	951	996		
ADDW1 = 000000	951	997		
ADDW10 = 000000	951	1006		
ADDW11 = 000000	951	1007		
ADDW12 = 000000	951	1008		
ADDW13 = 000000	951	1009		
ADDW14 = 000000	951	1010		
ADDW15 = 000000	951	1011		
ADDW2 = 000000	951	998		
ADDW3 = 000000	951	999		
ADDW4 = 000000	951	1000		
ADDW5 = 000000	951	1001		
ADDW6 = 000000	951	1002		
ADDW7 = 000000	951	1003		
ADDW8 = 000000	951	1004		
ADDW9 = 000000	951	1005		
ADEVCT = 000000	951	957		
ADEVN = 000000	951	993		
ADRCNT 006057	2098*	2113*	2122#	
ADVANC = 104420	2267#	5694	5777	
AENV = 000002	1#	951	962	
AENVN = 000000	951	963		
AFATAL = 000000	951	954		
AMADR1 = 000000	951	979		
AMADR2 = 000000	951	983		
AMADR3 = 000000	951	986		
AMADR4 = 000000	951	989		
AMAMS1 = 000000	951	973		
AMAMS2 = 000000	951	981		
AMAMS3 = 000000	951	984		
AMAMS4 = 000000	951	987		
AMSGAD = 000000	951	959		
AMSGLG = 000000	951	960		
AMSGTY = 000000	951	953		
AMTYP1 = 000000	951	974		
AMTYP2 = 000000	951	982		
AMTYP3 = 000000	951	985		
AMTYP4 = 000000	951	988		
APASS = 000000	951	956		
APRIOR = 000000	951			
APTSU = 000040	1823	1928#		
APTENV = 000001	1816	1884	1926#	2328
APTSIZ = 000200	1925#			
APTSPO = 000100	1818	1886	1927#	
APT.SI 013716	1491	2927#		
ASWREG = 000000	951	964		
ATESTN = 000000	951	955		
AUDONE 003354	1528	1549	1588#	
AUNIT = 000000	951	958		
AUSTRY 003126	1527#			
AUSWR = 000000	951	965		
AUTO.S 012236	1489	2646#		

CROSS REFERENCE TABLE -- USER SYMBOLS

SEQ 0135

	4002#	4038	4041#	4077	4080#	4116	4119#	4159	4162#	4205	4208#	4251	4254#
	4318	4321#	4375	4379#	4452	4456#	4529	4533#	4606	4610#	4682	4685#	4750
	4753#	4820	4823#	4922	4925#	4985	4988#	5234	5237#	5510	5513#	5574	5577#
	5615	5618#	5711	5714#									
\$SAVRE = ***** U	2256												
\$SAVR6 007322	2373*	2381	2382*	2383*	2406#								
\$SCOPE 004134	862	1733#	2907										
\$SETUP= 000000	1686	1734	1936	2033									
\$SVLAD 004316	1750	1768#											
\$SVPC = 000040	874#	879											
\$SWR = 164000	1#	696	943	944	1658	1686	1697	1703	1705	1727	1728	1729	1730
	1741	1753	1755	1756	1757	1758	1759	1771	1777	2403	2988	3014	3039
	3065	3095	3138	3181	3240	3293	3317	3341	3377	3411	3456	3515	3568
	3621	3674	3728	3788	3818	3848	3878	3909	3959	3998	4037	4076	4115
	4158	4204	4250	4317	4374	4451	4528	4605	4681	4749	4819	4921	4984
	5233	5509	5573	5614	5710								
\$SWREG 001340	964#	1447											
\$SWRMK= 000000	1730												
\$TESTN 001322	955#	1769*											
\$TIMES 001310	943#	1686*	1758*	1764	1767*	1777							
\$TKB U01246	923#	1740	1934	1951	1957	2496	2498	2540	2920				
\$TKS 001244	922#	1738	1934	1949	1955	2538	2918	6182					
\$TMP0 001276	938#	1502*	2469	2875*	2876*	5812*	5824*	5858*	5869*	5904*	5915*	5956*	5962*
	5974*	5988*	6008*	6019*	6054*	6065*	6104*	6109*					
\$TMP1 001300	939#	1503*	2471	5165*	5166*	5167	5208*	5209*	5210	5434*	5435*	5436	5488*
	5489*	5490	5685*	5686*	5687	5771*	5772*	5773	5856*	5872	5882*	5885	5899*
	5903*	5930*	5937*	5975*	5980*	6006*	6022						
\$TMP2 001302	940#	1505*	1526*	1553	1562*	2473	2663	2666	2778*	4952*	4953*	5151*	5152*
	5167*	5168	5194*	5195*	5210*	5211	5420*	5421*	5436*	5437	5474*	5475*	5490*
	5491	5671*	5672*	5687*	5688	5757*	5758*	5773*	5774	6134*	6144*	6157*	6170*
	6208												
\$TMP3 001304	941#	1506*	2475	2675	2678	2683	2686	2765	2768	2773	2776		
\$TMP4 001306	942#	1507*	2477	2658*	2670*	2861	5840*	5846*					
\$TN = 000060	1#	696	2986	2988#	3012	3014#	3037	3039#	3063	3065#	3093	3095#	3136
	3138#	3179	3181#	3238	3240#	3291	3293#	3315	3317#	3339	3341#	3375	3377#
	3409	3411#	3454	3456#	3513	3515#	3566	3568#	3619	3621#	3672	3674#	3726
	3728#	3786	3788#	3816	3818#	3846	3848#	3876	3878#	3907	3909#	3957	3959#
	3996	3998#	4035	4037#	4074	4076#	4113	4115#	4156	4158#	4202	4204#	4248
	4250#	4315	4317#	4372	4374#	4449	4451#	4526	4528#	4603	4605#	4679	4681#
	4747	4749#	4817	4819#	4919	4921#	4982	4984#	5231	5233#	5507	5509#	5571
	5573#	5612	5614#	5708	5710#								
\$TPB 001252	925#	1861*	1872	2279*	2543*	2923*							
\$TPFLG 001257	929#	1810	1872										
\$TPS 001250	924#	1859	1872	2277	2541	2921							
\$TRAP 006414	868	2227#											
\$TRAP2 006436	2238#	2249											
\$TRP = 000021	2242#	2251#	2253	2254#	2255#	2256#	2257#	2258#	2259#	2260#	2261#	2262#	2263#
	2264#	2265#	2266#	2267#	2268#								
\$TRPAD 006450	2232	2249#											
\$TSTM 002040	1191#												
\$TSTM# 001202	902#	1442*	1726	1768*	1769	1771	1778	2356	2410	2612	2619	2621	2988*
	3014*	3039*	3065*	3095*	3138*	3181*	3240*	3293*	3317*	3341*	3377*	3411*	3456*
	3515*	3568*	3621*	3674*	3728*	3788*	3818*	3848*	3878*	3909*	3959*	3998*	4037*
	4076*	4115*	4158*	4204*	4250*	4317*	4374*	4451*	4528*	4605*	4681*	4749*	4819*
	4921*	4984*	5233*	5509*	5573*	5614*	5710*						
\$TIYIN 005520	1977	1978	1990	2008	2022	2026#							

\$STUFF	686#														
\$SWPAC	686#	3281	3305												
\$TCHAR	686#	4826	4925	4991	5240										
\$TCRC	686#	4805	4967	5215											
\$STRANW	686#	4845	5014	5065	5264	5334									
\$STRANT	686#	3364	3398	3443											
\$TSTN	1#	2984	3010	3035	3061	3091	3134	3177	3236	3289	3313	3337	3373	3407	3452
	3511	3564	3617	3670	3724	3784	3814	3844	3874	3905	3955	3994	4033	4072	4111
	4154	4200	4246	4313	4370	4447	4524	4601	4677	4745	4815	4917	4980	5229	5505
	5569	5610	5706												
\$SUPADD	1#	2385													
\$SVARIA	1#	888													
\$SWINDO	686#	3501	3554	3607	3660										
\$XZ	1#	2976	2982	3002	3008	3027	3033	3053	3059	3083	3089	3126	3132	3169	3175
	3228	3234	3281	3287	3305	3311	3329	3335	3364	3371	3398	3405	3443	3450	3501
	3509	3554	3562	3607	3615	3660	3668	3713	3722	3776	3782	3806	3812	3836	3842
	3866	3872	3896	3903	3947	3953	3986	3992	4025	4031	4064	4070	4103	4109	4144
	4152	4190	4198	4237	4244	4305	4311	4361	4368	4438	4445	4515	4522	4592	4599
	4669	4675	4737	4743	4805	4813	4908	4915	4967	4978	5215	5227	5495	5503	5561
	5567	5598	5608	5695	5704										
\$ZEROS	686#														
\$SCMRE	893#	932	933	934	935	936	937								
\$SCMTM	893#	938	939	940	941	942									
\$SESCA	829#														
\$SNEWT	829#	2986	3012	3037	3063	3093	3136	3179	3238	3291	3315	3339	3375	3409	3454
	3513	3566	3619	3672	3726	3786	3816	3846	3876	3907	3957	3996	4035	4074	4113
	4156	4202	4248	4315	4372	4449	4526	4603	4679	4747	4817	4919	4982	5231	5507
	5571	5612	5708												
\$SSCOP	1#	1717													
\$SSET	2242#	2253	2254	2255	2256	2257	2258	2259	2260	2261	2262	2263	2264	2265	2266
	2267														
\$SSKIP	829#														
.EQUAT	1#	719													
.HEADE	1#	686													
.SETUP	1#														
.SACT1	1#	870													
.SAPT8	1#	948#													
.SAPTH	1#	1173													
.SAPTY	1#	1872													
.SCATC	1#														
.SCMTA	1#	893													
.SEOP	1#	1654													
.SERRO	1#														
.SERRT	1#														
.SPOWE	1#	2360													
.SRDOC	1#	2034													
.SREAD	1#	1931													
.SSCOP	1#	1721													
.STRAP	1#	2219													
.S1YPE	1#	1793													
.STYPO	1#														

K 11

CZKCE MACY11 30A(1052) 08-JUL-80 08:24 PAGE 143
CZKCE.P11 08-JUL-80 08:24 CROSS REFERENCE TABLE -- MACRO NAMES

SEQ 0140

ERRORS DETECTED: 0

CZKCE,CZKCE/NL:TOC/SOL/CRF_CZKCE.MAC,CZKCE.P11/EQ:DZDME
RUN-TIME: 30 25 2 SECONDS
RUN-TIME RATIO: 103/58=1.7
CORE USED: 53K (105 PAGES)