

.REM a

IDENTIFICATION

PRODUCT CODE: AC-F131C-MC
PRODUCT NAME: CZRLCO RL01/02 DRIVE COMPATABILITY
DATE CREATED: 5-JAN-79
REVISED: 4-FEB-82
MAINTAINER: DIAGNOSTIC ENGINEERING - COLORADO
AUTHORS: D. DEKNIS, C. CAMPBELL

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED TO THE PURCHASER UNDER A LICENSE FOR USE ON A SINGLE COMPUTER SYSTEM AND CAN BE COPIED (WITH INCLUSION OF DIGITAL'S COPYRIGHT NOTICE) ONLY FOR USE IN SUCH SYSTEM, EXCEPT AS MAY OTHERWISE BE PROVIDED IN WRITING BY DIGITAL.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1979, 1982 DIGITAL EQUIPMENT CORPORATION

TABLE OF CONTENTS

1.0	GENERAL INFORMATION
1.1	PROGRAM ABSTRACT
1.1.1	STRUCTURE OF PROGRAM
1.1.2	DIAGNOSTIC INFORMATION
1.2	SYSTEM REQUIREMENTS
1.2.1	HARDWARE REQUIREMENTS
1.2.2	SOFTWARE REQUIREMENTS
1.3	RELATED DOCUMENTS AND STANDARDS
1.4	DIAGNOSTIC HIERARCHY PREREQUISITES
1.5	ASSUMPTIONS
2.0	OPERATING INSTRUCTIONS
2.1	HOW TO RUN THIS DIAGNOSTIC
2.1.1	THE FIVE STEPS OF EXECUTION
2.1.2	SAMPLE RUN-THROUGH
2.2	CHAIN MODE OPERATION
2.3	DETAILS OF COMMANDS AND SYNTAX
2.3.1	TABLE OF COMMAND VALIDITY
2.3.2	COMMAND SYNTAX
2.4	EXTENDED P-TABLE DIALOGUE
2.5	HARDWARE PARAMETERS
2.6	SOFTWARE PARAMETERS
3.0	ERROR INFORMATION
3.1	ERROR REPORTING
3.2	ERROR HALTS
4.0	PERFORMANCE AND PROGRESS REPORTS
4.1	PERFORMANCE REPORTS
4.2	PROGRESS REPORTS
5.0	DEVICE INFORMATION TABLES
6.0	TEST SUMMARIES

1.0 GENERAL INFORMATION

1.1 PROGRAM ABSTRACT

1.1.1 STRUCTURE OF PROGRAM

THIS DIAGNOSTIC IS COMPATIBLE WITH BOTH XXDP+ AND ACT. IT CAN BE RUN STANDALONE UNDER XXDP+, AND CAN BE CHAINED UNDER XXDP+, ACT AND APT IN ACT MODE (SEE 2.2 "CHAIN MODE OPERATION" FOR DETAILS OF CHAINING PROCEDURE). IT IS A SINGLE PROGRAM FROM THE STANDPOINT OF THE DIAGNOSTIC USER, WHICH AT RUN TIME IS APPENDED TO A COMMON FRONT-END PIECE OF SUPERVISOR SOFTWARE THROUGH WHICH THE DIAGNOSTIC PROGRAM INTERFACES TO THE ENVIRONMENT AS IT EXECUTES.

WHEN THIS DIAGNOSTIC IS STARTED, CONTROL GOES FIRST TO THE SUPERVISOR PORTION, WHICH WILL ASK CERTAIN "HARD CORE" QUESTIONS ABOUT THE ENVIRONMENT. THEN IT WILL ENTER COMMAND MODE, INDICATED BY A PROMPT CHARACTER (DR>). AT COMMAND MODE THE OPERATOR MAY ENTER ANY OF SEVERAL COMMANDS AS DESCRIBED IN 2.0 "OPERATING INSTRUCTIONS".

THE DIAGNOSTIC PROGRAM IS LOADED IN THE LOWER 8K OF MEMORY. THE DIAGNOSTIC SUPERVISOR CODING OCCUPIES 6.25K OF THE UPPER PART OF MEMORY JUST BELOW THE XXDP+ MONITOR WHICH RESIDES IN THE UPPERMOST 1.5K OF MEMORY SPACE.

1.1.2 DIAGNOSTIC INFORMATION

THE RL01 DRIVE COMPATABILITY TEST IS A PDP-11 (LSI-11) BASED PROGRAM THAT WILL TEST INTERCHANGEABILITY OF CARTRIDGES BETWEEN DRIVES. THE TEST PERFORMS WRITES, READS, OVERWRITES, ADJACENT CYLINDER WRITES TO PROVE COMPATABILITY. SINCE THE PROGRAM RELIES ON MANUAL INTERVENTION, A TOTAL TEST TIME IS NOT APPLICABLE. HOWEVER, TO TEST TWO DRIVES REQUIRES A MINIMUM OF THREE PASS. EACH PASS REQUIRES APPROXIMATELY 70 SECONDS.

1.2 SYSTEM REQUIREMENTS

1.2.1 HARDWARE REQUIREMENTS

- * PDP-11/LSI-11 PROCESSOR WITH 16K OR MORE OF MEMORY
- * CONSOLE DEVICE (LA30,LA36,VT50,ETC.)

* 1 OR 2 RL11/RLV11 CONTROLLER(S) WITH:

- 1 - 8 RL01 DRIVES WITH RL01K CARTRIDGES CONTAINING A 'BAD SECTOR FILE'
- 1 - 8 RL02 DRIVES WITH RL02K CARTRIDGES CONTAINING A 'BAD SECTOR FILE'

* LINE PRINTER (OPTIONAL)

1.2.2 SOFTWARE REQUIREMENTS

CZRLLC0 RL01/02 DRIVE COMPATABILITY
(FORMERLY CZRLF8)

1.3 RELATED DOCUMENTS AND STANDARDS

RL01 DISK SUBSYSTEM USER'S GUIDE (EK-RL01-UG-002)
XXDP+/SUPERVISOR USER'S MANUAL

1.4 DIAGNOSTIC HIERARCHY PREREQUISITES

THE RL01/02 SUBSYSTEM SHOULD HAVE SUCCESSFULLY RUN THE FOLLOWING PROGRAMS:

CVRLAB0	RLV11 RL01/02 DISKLESS TEST (RLV11 ONLY)
CZRLGCO	RL11/RLV11 RL01/02 CONTROLLER TEST (PART 1)
CZRLHCO	RL11/RLV11 RL01/02 CONTROLLER TEST (PART 2)
CZRLIDO	RL01/02 DRIVE TEST (PART 1)
CZRLJBO	RL01/02 DRIVE TEST (PART 2)
CZRLKBO	RL11/RLV11 RL01/02 PERFORMANCE EXERCISER
CZRLNAO	RL01/02 DRIVE TEST (PART 3)

1.5 ASSUMPTIONS

THE HARDWARE OTHER THAN THE RL01/02 SUBSYSTEM IS ASSUMED TO WORK PROPERLY. FALSE ERRORS MAY BE REPORTED IF THE PROCESSOR, ETC., DO NOT FUNCTION PROPERLY.

2.0 OPERATING INSTRUCTIONS

2.1 HOW TO RUN THIS DIAGNOSTIC

2.1.1 THE FIVE STEPS OF EXECUTION

THIS DIAGNOSTIC PROGRAM SHOULD BE LOADED AND STARTED USING NORMAL XXDP+ PROCEDURES. START THE EXECUTION OF THE XXDP+ MONITOR BY USING THE APPROPRIATE BOOTSTRAP PROGRAM. THE MONITOR WILL PRINT A MESSAGE IDENTIFYING ITSELF AND REQUESTING THAT THE CURRENT DATE BE ENTERED. AN EXAMPLE OF THIS MESSAGE IS GIVEN BELOW FOR THE XXDP+ MONITOR:

```
CHMDKAO XXDP+ MONITOR
BOOTED VIA UNIT 0
ENTER DATE (DD-MM-YY):
```

AFTER THE DATE HAS BEEN ACCEPTED BY THE MONITOR THE RESTART ADDRESS OF THE MONITOR IS PRINTED. THEN THE FOLLOWING TWO QUESTIONS ARE ASKED:

```
50 HZ ? N
LSI ? N
```

THE DEFAULTS ARE BOTH 'NO'. TYPE 'R' AND THE PROGRAM NAME TO RUN THE PROGRAM. DO NOT TYPE THE EXTENSION.

WHEN THIS DIAGNOSTIC IS STARTED THE FOLLOWING 5 STEPS WILL OCCUR:

```
*****
* STEP 1 *
*****
```

THE DIAGNOSTIC WILL ISSUE THE PROMPT 'DR>'. FROM THIS POINT UNTIL THE TIME WHEN YOU RESTART XXDP+, YOU WILL BE TALKING TO THE DIAGNOSTIC, NOT XXDP+. WE WILL REFER TO THE PRESENCE OF THIS PROMPT AS BEING IN DIAGNOSTIC COMMAND MODE, AS OPPOSED TO XXDP+ COMMAND MODE.

AT THIS POINT YOU WILL ENTER A 'START' COMMAND. THIS IS NOT THE SAME AS THE XXDP+ 'START' COMMAND, WHICH YOU ALREADY ISSUED IN RESPONSE TO THE XXDP+ DOT PROMPT. THIS 'START' COMMAND CAN TAKE A NUMBER OF SWITCHES AND FLAGS (ALL OPTIONAL) AND THE DETAILS OF THESE ARE SET FORTH IN 2.3 'DETAILS OF COMMANDS AND SYNTAX'. HOWEVER, IN ORDER TO USE THE PROGRAM, ALL YOU NEED TO SAY IS SOMETHING LIKE THIS:

```
STA/PASS:1/FLAGS:HOE
```

THINGS TO NOTE HERE:

1. ONLY THE FIRST THREE CHARACTERS OF THIS OR ANY COMMAND AT THE 'DR>' LEVEL NEED TO BE TYPED.
2. THE 'PASS' SWITCH SPECIFIES HOW MANY PASSES YOU DESIRE. A PASS CONSISTS OF RUNNING THE FULL DIAGNOSTIC AGAINST ALL UNITS BEING TESTED (THIS WILL BE EXPLAINED SHORTLY). ONE PASS IS SPECIFIED IN THE ABOVE EXAMPLE.
3. THE 'FLAGS' SWITCH MAY SPECIFY ANY OF A NUMBER OF FLAGS, BUT THE MAIN USEFUL ONES ARE:

PNT	PRINT NUMBER OF TEST BEING EXECUTED
LOE	LOOP ON ERROR
HOE	HALT ON ERROR
IER	INHIBIT ERROR PRINTOUT

THE HOE FLAG IS SPECIFIED IN THE ABOVE EXAMPLE (WE'LL SEE WHY SHORTLY).

* STEP 2 *

WHEN YOU HAVE TYPED IN A 'START' COMMAND, THE DIAGNOSTIC WILL COME BACK WITH THE QUESTION '# UNITS?' TO WHICH YOU SHOULD RESPOND BY TYPING IN THE NUMBER OF DEVICES YOU WISH TO TEST.

A WORD OF WARNING HERE: THE NUMBER OF UNITS DEPENDS ON THE TARGET DEVICE OF THE DIAGNOSTIC. FOR EXAMPLE, IF THE DIAGNOSTIC IS DIRECTED AT A DISK DRIVE, THEN THE NUMBER OF UNITS WOULD BE THE NUMBER OF DRIVES TO BE TESTED. WHEREAS IF THE DIAGNOSTIC WAS DIRECTED AT THE DISK CONTROLLER, THEN THE NUMBER OF UNITS WOULD BE THE NUMBER OF CONTROLLERS. THE TARGET DEVICE OF A DIAGNOSTIC CAN ALWAYS BE DETERMINED BY INSPECTING THE 'HEADER' STATEMENT NEAR THE BEGINNING OF THE SOURCE CODE. ONE OF THE OPERANDS OF THIS 'HEADER' STATEMENT SHOULD BE THE DEVICE TYPE OF THE DIAGNOSTIC.

* STEP 3 *

WHEN YOU HAVE TYPED IN THE NUMBER OF UNITS TO BE TESTED, THE DIAGNOSTIC WILL ASK YOU THE 'HARDWARE QUESTIONS'. THE ANSWERS TO THESE QUESTIONS ARE USED TO BUILD TABLES IN CORE, CALLED 'HARDWARE P-TABLES'. ONE HARDWARE P-TABLE WILL BE BUILT FOR EACH UNIT TO BE TESTED.

THERE ARE SEVERAL HARDWARE QUESTIONS AND THE ENTIRE SERIES WILL BE POSED N TIMES, WHERE N IS THE NUMBER OF UNITS.

THIS REPRESENTS A NEW PHILOSOPHY IN DIAGNOSTIC ENGINEERING. DIAGNOSTICS IN THE FUTURE WILL NOT BE WRITTEN TO AUTOSIZE OR ASSUME STANDARD ADDRESSES: INSTEAD, THEY WILL ASK THE OPERATOR FOR ALL THE INFORMATION THEY NEED TO TEST THE DEVICE.

* STEP 4 *

AFTER YOU HAVE ANSWERED ALL THE HARDWARE QUESTIONS (SEC 2.5) FOR ALL THE UNITS, YOU WILL BE ASKED "CHANGE SW?" IF YOU WANT TO BE ASKED THE SOFTWARE QUESTIONS THAT DETERMINE THE BEHAVIOR OF THIS PROGRAM, TYPE 'Y'. IF YOU WANT TO TAKE ALL THE DEFAULTS TO THESE QUESTIONS, TYPE 'N'. IF YOU TYPE 'Y' YOU WILL BE ASKED THE SOFTWARE QUESTIONS (SEC 2.6), AND THE ANSWERS WILL BE PUT INTO THE SOFTWARE P-TABLE IN THE PROGRAM. THE SERIES OF QUESTIONS WILL BE ASKED JUST ONCE, REGARDLESS OF THE NUMBER OF UNITS TO BE TESTED.

* STEP 5 *

AFTER YOU HAVE ANSWERED THE SOFTWARE QUESTIONS, THE DIAGNOSTIC WILL BEGIN TO EXECUTE THE HARDWARE TEST CODE. THERE ARE SEVERAL THINGS THAT CAN HAPPEN NEXT, DEPENDING ON WHETHER A HARDWARE ERROR IS ENCOUNTERED AND ALSO ON WHAT SWITCH VALUES YOU SELECTED ON THE START COMMAND. CONSIDER THE POSSIBILITIES:

1. IF NO ERROR IS ENCOUNTERED, THEN THE DIAGNOSTIC WILL SIMPLY EXECUTE THE DESIRED NUMBER OF PASSES AND RETURN TO COMMAND MODE (PROMPT DR>).
2. IF AN ERROR IS ENCOUNTERED, THEN ONE OF THREE THINGS HAPPENS, DEPENDING ON THE SETTINGS OF THE HOE AND LOE FLAGS.

HOE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND THE DIAGNOSTIC WILL RETURN TO COMMAND MODE.

LOE SET: THE DIAGNOSTIC WILL LOOP ENDLESSLY ON THE BLOCK OF CODE THAT DETECTED THE ERROR.

NEITHER HOE NOR LCE SET: THE ERROR WILL BE REPORTED ON THE CONSOLE AND NORMAL EXECUTION WILL RESUME AS IF NO ERROR HAD OCCURRED.

2.1.2 SAMPLE RUN-THROUGH

LET'S SEE HOW ALL THIS WORKS IN A REAL SITUATION. RECALL THAT WE ENTERED THE COMMAND 'STA/PASS:1/FLAGS:HOE'. THIS WOULD BE A VERY TYPICAL WAY TO RUN THE DIAGNOSTIC. IF NO ERRORS ARE ENCOUNTERED, THE SINGLE REQUESTED PASS WILL BE EXECUTED AND THE PROMPT WILL BE RE-ISSUED.

IF AN ERROR IS ENCOUNTERED, THE ERROR WILL BE REPORTED AND THE PROMPT WILL BE REISSUED (BECAUSE THE HOE FLAG IS SET). AT THIS POINT THERE ARE FOUR DIFFERENT WAYS YOU CAN GET THE PROGRAM GOING AGAIN:

1. ISSUE ANOTHER 'START' COMMAND (THUS GOING THRU ALL OF STEPS 1, 2, 3, 4, AND 5 AGAIN)
2. ISSUE A 'RESTART' COMMAND (SAME AS START COMMAND EXCEPT THAT THE HARDWARE QUESTIONS ARE NOT ASKED)
3. ISSUE A 'CONTINUE' COMMAND (EXECUTION WILL RESUME AT THE BEGINNING OF THE PARTICULAR HARDWARE TEST (MOST DIAGNOSTICS CONSIST OF A NUMBER OF THESE) THAT IT WAS IN WHEN THE ERROR HALT OCCURRED. NO QUESTIONS ASKED.
4. ISSUE A 'PROCEED' COMMAND: EXECUTION WILL RESUME AT THE INSTRUCTION FOLLOWING THE ERROR REPORT (THIS IS A SPECIAL COMMAND AND CAN BE ISSUED ONLY AT A HALT

THE MOST TYPICAL THING TO DO HERE IS TO ISSUE THE PROCEED, BUT WITH DIFFERENT FLAG SETTINGS. PROBABLY YOU WOULD WANT TO SAY:

```
PRO/FLAGS:IER:LOE:HOE=0
```

THIS WILL DO THE FOLLOWING:

1. TURN ON THE IER (INHIBIT ERROR PRINTOUT) FLAG
2. TURN ON THE LOE FLAG
3. TURN OFF THE HOE FLAG
4. RESUME EXECUTION AT INSTRUCTION AFTER ERROR REPORT

THE DIAGNOSTIC WILL NOW LOOP ON THE BLOCK OF CODE THAT DETECTED AND REPORTED THE ERROR, BUT NO ERROR PRINTOUT WILL OCCUR. THUS YOU CAN STUDY THE ERROR OR SCOPE IT OR WHATEVER.

WHEN YOU'VE SEEN ENOUGH, YOU MAY HIT CONTROL/C. THIS WILL TAKE YOU OUT OF THE LOOP AND PUT YOU BACK INTO COMMAND MODE. YOU NOW HAVE THREE CHOICES:

1. START
2. RESTART
3. CONTINUE

LET'S SAY YOU'VE REPAIRED THE DEFECT FOUND ABOVE AND WANT TO FINISH RUNNING THE DIAGNOSTIC. YOU WOULD TYPE

CON/FLAGS:HOE:IER=0:LOE=0

THIS WILL RESTORE THE FLAGS TO THEIR ORIGINAL VALUES AND RESUME EXECUTION AT THE BEGINNING OF THE HARDWARE TEST YOU WERE IN. IF THE ERROR DOES NOT RECUR, THE EXECUTION WILL FLOW RIGHT ON THRU TO THE NEXT ERROR OR TO END OF PASS.

IF AT END OF PASS YOU WANT TO RUN THE DIAGNOSTIC AGAIN, YOU HAVE TWO CHOICES:

1. START
2. RESTART

YOU WOULD CHOOSE ONE, DEPENDING ON WHETHER YOU WANTED TO ANSWER THE HARDWARE QUESTIONS AGAIN.

THE FULL PRINT-OUT FROM THE ABOVE DIALOGUE MIGHT LOOK LIKE THIS
(O=OPERATOR, D=DIAGNOSTIC):

	BY WHOM ENTERED: -----
.R CZRLLC	O
DRS LOADED	D
DIAG. RUN-TIME SERVICES REV. C APR-79	D
CZRLC-B-0	D
CZRLC VERIFIES INTERCHANGEABILITY OF CARTRIDGES BETWEEN DRIVES	D
UNIT IS RL01, RL02	D
DR>STA/PASS:1/FLAGS:HOE	D,O
CHANGE HW (L) ? Y	D,O
# UNITS (D) ? 2	D,O
UNIT 0	D
BUS ADDRESS (O) 174400 ?	D,O
VECTOR (O) 160 ?	D,O
DRIVE (O) 0 ?	D,O
DRIVE TYPE = RL01 (L) Y ?	D,O
UNIT 1	D
BUS ADDRESS (O) 174400 ?	D,O
VECTOR (O) 160 ?	D,O
DRIVE (O) 0 ? 1	D,O
DRIVE TYPE = RL01 (L) ? N	D,O (N=RL02)
CZRLC HRD ERR 00004 TST 003 SUB 002 PC:004130 ERR HLT	
DR>PRO/FLAGS:IER:LOE:HOE=0	D,O

AT THIS POINT THE DIAGNOSTIC IS LOOPING ON THE ERROR WITHOUT PRINTING ANYTHING. YOU CAN SCOPE THE ERROR UNTIL YOU HAVE LOCATED IT, THEN ^C OUT.	

^C	O
DR>CON/FLAGS:HOE:IER:LOE=0	D,O

```
CZRL EOP 1          D
^C
DR>RESTART/PASS:1  D,0
```

```
-----
-----
-----
```

2.2 CHAIN MODE OPERATION

NOT THIS PROGRAM IS NOT CHAINABLE. CHAIN MODE OPERATION CONSISTS OF THE SEQUENTIAL EXECUTION OF PROGRAMS WITHOUT OPERATOR INTERVENTION. ONLY PROGRAMS THAT HAVE BEEN MODIFIED TO RUN IN CHAIN MODE CAN BE CHAINED. CHAINABLE PROGRAMS ARE IDENTIFIED IN THE DIRECTORY BY A BIC EXTENSION.

TO RUN CHAIN MODE, THE XXDP+ MONITOR USES AN ASCII FILE (KNOWN AS A CHAIN FILE) LISTING THE PROGRAMS TO BE RUN AND THE NUMBER OF PASSES EACH PROGRAM SHOULD RUN. THIS FILE MUST BE ON THE SYSTEM DEVICE.

A CHAIN FILE MAY BE GENERATED BY USE OF THE XTECO TEXT EDITOR. THIS FILE MUST HAVE A CCC EXTENSION. THE CHAIN FILE MAY CONTAIN ANY OF THE COMMANDS SUPPORTED BY THE XXDP+ MONITOR. THE COMMANDS IN THE ASCII FILE ARE EXECUTED IN THE ORDER IN WHICH THEY ARE ENCOUNTERED.

TO EXECUTE A CHAIN FILE THE USER TYPES:

```
C FILNAM <CR> OR
C FILNAM/QV <CR>
```

IN THE FIRST CASE THE PASS COUNT SPECIFIED IN THE CHAIN FILE IS USED BY THE XXDP+ MONITOR TO DETERMINE THE NUMBER OF PASSES TO EXECUTE EACH PROGRAM. IN THE SECOND CASE THE PASS COUNT IS NOT USED AND EACH PROGRAM IS EXECUTED ONLY ONCE. THE /QV SWITCH PROVIDES A SINGLE EXECUTION MODE OF OPERATION OF QUICK VERIFY.

WHEN PROGRAMS ARE RUN IN CHAIN MODE, THE SOFTWARE SWITCH REGISTER SHOULD BE SET TO 00000. THE XXDP+ MONITOR PRINTS EACH COMMAND TAKEN FROM THE CHAIN FILE AND THEN EXECUTES THE COMMAND. WHEN THE LAST COMMAND OTHER THAN ANOTHER C COMMAND HAS BEEN EXECUTED THE XXDP+ MONITOR TERMINATES CHAIN MODE AND TYPES A PROMPT (.). IT IS READY TO ACCEPT ANOTHER COMMAND FROM THE CONSOLE. IF THE LAST COMMAND IS ANOTHER C COMMAND, THE CHAIN MODE WILL CONTINUE AND THE CHAIN FILE SPECIFIED BY THIS NEW C COMMAND WILL BE USED.

IF THE USER WISHES TO TERMINATE CHAIN MODE BEFORE ITS NORMAL TERMINATION HE MAY DO SO BY TYPING A CONTROL/C. HOWEVER, THE MONITOR WILL NOT ABORT THE CHAIN MODE UNTIL IT RECEIVES PROGRAM CONTROL FROM THE PROGRAM CURRENTLY RUNNING.

2.3 DETAILS OF COMMANDS AND SYNTAX

2.3.1 TABLE OF COMMAND VALIDITY

THERE ARE FOUR WAYS OF ENTERING DIAGNOSTIC COMMAND MODE, AND DIFFERENT SUBSETS OF THE DIAG COMMAND SET ARE AVAILABLE WITH EACH:

<u>HOW ENTERED</u>	<u>LEGAL COMMANDS</u>
1. OPERATOR ENTERED 'RUN DIAG'	START PRINT DISPLAY FLAGS ZFLAGS EXIT
2. DIAGNOSTIC HAS FINISHED ALL ITS REQUESTED PASSES	START RESTART PRINT DISPLAY FLAGS ZFLAGS EXIT
3. OPERATOR INTERRUPTED THE DIAGNOSTIC WITH CTRL/C	START RESTART CONTINUE PRINT DISPLAY FLAGS ZFLAGS EXIT
4. AN ERROR WAS ENCOUNTERED WITH THE HOE FLAG SET SET	START RESTART CONTINUE PROCEED PRINT DISPLAY FLAGS ZFLAGS EXIT

2.3.2 COMMAND SYNTAX

 STA(RT)/TESTS:TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. THE MESSAGE "# UNITS?" IS PRINTED. THE START COMMAND MAY BE ISSUED WHEN DIAGNOSTIC COMMAND MODE HAS BEEN ENTERED VIA ONE OF THE FOLLOWING: A) OPERATOR TYPED 'RUN DIAGNOSTIC' B) DIAGNOSTIC FINISHED EXECUTING C) ERROR WAS ENCOUNTERED WITH HOE FLAG SET D) OPERATOR ENTERED CONTROL/C. AFTER THE OPERATOR RESPONDS TO "# UNITS?", THE HARDWARE DIALOGUE IS INITIATED. WHEN IT IS COMPLETED, THE QUESTIONS "CHANGE SW?" IS ISSUED, AND THE ANSWERS, IF GIVEN, BECOME THE NEW DEFAULTS. THEREFORE IT IS NECESSARY TO RELOAD THE PROGRAM IN ORDER TO RETURN TO THE LOAD DEFAULTS.

THE SWITCH ARGUMENTS ARE AS FOLLOWS:

'TEST-LIST' IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.) THAT SPECIFY THE TESTS TO BE EXECUTED. THE NUMBERS ARE SEPARATED BY COLONS. THE NUMBERS RANGE FROM 1 TO THE LARGEST TEST NUMBER IN THE DIAGNOSTIC. THEY MAY BE SPECIFIED IN ANY ORDER. TESTS WILL BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS.

'PASS-CNT' IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL DIAGNOSTIC (ALL SELECTED TESTS) AGAINST ALL UNITS SUBMITTED. THE DEFAULT IS NON-ENDING TEST EXECUTION. 'FLAG-LIST' IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>, <FLAG=1>, OR <FLAG=0>, SEPARATED BY COLONS, WHERE <FLAG> HAS ONE OF THE FOLLOWING VALUES:

HOE HALT ON ERROR, CAUSING COMMAND MODE TO BE ENTERED WHEN AN ERROR IS ENCOUNTERED

LOE LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK OF CODING (SEGMENT, SUB-TEST, OR TEST) CONTAINING THE ERROR

IER INHIBIT ERROR REPORTING

IBE INHIBIT BASIC ERROR REPORTS

IXE INHIBIT EXTENDED ERROR REPORTS

PRI DIRECT ALL MESSAGES TO A LINE PRINTER

PNT PRINT NUMBER OF TEST BEING EXECUTED

BOE BELL ON ERROR
 UAM RUN IN UNATTENDED MODE, BYPASSING MANUAL INTERVENTION TESTS
 ISR INHIBIT STATISTICAL REPORTS
 IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC
 ADR EXECUTE AUTODROP CODE
 LOT LOOP ON TEST
 EVL EVALUATE

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0 ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED.

'EOP-INCR' IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS.

 RES(TART)/TEST:TEST-LIST/PASS:PASS-CNT/FLAGS:FLAG-LIST/EOP:EOP-INCR/
 UNITS:UNIT-LIST

THE DIAGNOSTIC IN CORE IS EXECUTED IN ACCORDANCE WITH THE SWITCHES SPECIFIED. HOWEVER, NEW 'P-TABLES' ARE NOT BUILT. INSTEAD, THE ONES IN CORE ARE USED.

THE QUESTION "CHANGE SW?" IS ASKED AND THE ANSWERS GIVEN BECOME THE NEW DEFAULTS. THE COMMAND MAY BE ISSUED WHEN COMMAND MODE HAS BEEN ENTERED VIA A) DIAGNOSTIC IS FINISHED B) HALT ON ERROR C) CONTROL/C.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. 'UNIT-LIST' IS A SEQUENCE OF LOGICAL UNIT NUMBERS RANGING FROM 1 THRU N (N = NUMBER OF UNITS BEING TESTED) SPECIFYING WHICH UNITS ARE TO BE TESTED. THE LOGICAL UNIT NUMBER DESIGNATES THE POSITION OF THE P-TABLE IN CORE, ACCORDING TO THE ORDER IN WHICH THEY WERE BUILT. THE UNITS SPECIFIED MUST NOT HAVE BEEN DROPPED BY THE OPERATOR DROP COMMAND. THE UNIT-LIST DEFAULTS TO 'ALL THAT HAVE NOT BEEN DROPPED BY OPERATOR COMMAND'. THE EFFECT OF THE UNIT-LIST LASTS UNTIL THE NEXT START (WHERE IT IS AUTOMATICALLY RESET TO 'ALL') OR THE NEXT RESTART.
2. ALL UNSPECIFIED FLAG SETTINGS ARE UNCHANGED.

 CON(TINUE)/PASS:<PASS-CNT/FLAGS:<FLAG-LIST>

COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE RE-EXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

THE SWITCH ARGUMENTS ARE AS IN THE START COMMAND EXCEPT:

1. DEFAULT FOR PASS-CNT IS THE UNSATISFIED PASS-CNT FROM THE PREVIOUS START OR RESTART
2. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

 PRO(CEED)/FLAGS:<FLAG-LIST>

COMMAND MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE PARAMETERS MAY BE ALTERED.

THE SWITCH ARGUMENTS ARE THE SAME AS THE START COMMAND EXCEPT:

1. UNSPECIFIED FLAG SETTINGS ARE UNCHANGED

 EXIT

RETURN TO XXDP+ PROMPT MODE.

 DRO(P)/UNITS:UNIT-LIST

THE UNITS SPECIFIED ARE DROPPED FROM TESTING UNTIL THEY ARE ADDED BACK OR UNTIL A START COMMAND IS GIVEN. A DROP CANNOT BE FOLLOWED BY A PROCEED.

THERE IS ALSO A 'DROP' MACRO INTERNAL TO THE DIAGNOSTIC, WHICH GIVES THE FACILITY OF AUTO-DROPPING. THE DURATION OF A PROGRAM DROP, HOWEVER, IS ONLY UNTIL THE NEXT START OR RESTART.

 ADD/UNITS:UNIT-LIST

THE UNITS SPECIFIED ARE ADDED BACK (THEY MUST HAVE BEEN PREVIOUSLY DROPPED BY THE DROP COMMAND) TO THE TEST SEQUENCE. AN ADD CANNOT BE FOLLOWED BY A PROCEED.

 PRI(NT)

ALL STATISTICS TABLES ACCUMULATED BY THE DIAGNOSTIC ARE PRINTED. THE ISR (INHIBIT STATISTICAL REPORTING) FLAG IS CLEARED.

 DIS(PLAY)/UNITS:<UNIT-LIST>

THE HARDWARE P-TABLES FOR ALL UNITS UNDER TEST ARE PRINTED OUT IN THE FORMAT IN WHICH THEY WERE ENTERED. ANY UNITS THAT WERE DROPPED BY THE OPERATOR 'DROP' COMMAND ARE SO DESIGNATED.

 FLA(GS)

THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.

 ZFL(AGS)

ALL FLAGS ARE CLEARED.

2.4 EXTENDED P-TABLE DIALOGUE

THE FULL CAPABILITY OF THE HARDWARE DIALOGUE IS REVEALED BY THE FOLLOWING DISCUSSION OF WHAT HAPPENS INTERNALLY.

AS SOON AS THE QUESTION '# UNITS?' IS ANSWERED (WITH THE NUMBER N), SPACE IN CORE IS ALLOCATED FOR 'N' P-TABLES. ALL OF THE P-TABLES ARE OF THE SAME FORMAT, AND THERE IS A ONE-TO-ONE CORRESPONDENCE BETWEEN THE HARDWARE PARAMETER QUESTIONS AND THE SLOTS IN THE P-TABLE FORMAT.

IN GIVING A STRING OF VALUES, COMMAS WITHOUT INTERVENING VALUES MAY BE USED TO INDICATE A REPETITION OF THE LAST NAMED VALUE.

A STRING OF VALUES MAY BE GIVEN AS A RANGE (6-10 FOR EXAMPLE). IF THE VALUES REPRESENT PURE NUMERICAL DATA, THIS SAMPLE RANGE TRANSLATES TO THE STRING 6,7,8,9,10 (AN INCREMENT OF 1). IF THE VALUES ARE ADDRESSES, THE SAMPLE RANGE TRANSLATES TO THE STRING 6,8,10 (AN INCREMENT OF 2).

NOW LET US SEE HOW WE COULD USE THESE CAPABILITIES TO CONSTRUCT A SET OF P-TABLES. ASSUME THAT WE HAVE 8 RL UNITS, AND THAT THERE ARE FIVE (5) HARDWARE PARAMETERS FOR EACH (5 SLOTS IN THE P-TABLE, 5 HARDWARE QUESTIONS IN THE DIALOGUE).

FOLLOWING IS THE DIALOGUE FOR THIS 8 RLOX DRIVE SYSTEM. THIS SYSTEM HAS TWO (2) RL11 TYPE CONTROLLERS ALL TO BE SET AT 'BR LEVEL' 5. THE FIRST 4 DRIVES ARE RL01'S AND THE LAST 4 DRIVES ARE RL02'S (ON THE SECOND CONTROLLER):

UNITS (D) ? 8

UNIT 0
 BUS ADDRESS (0) 174400 ?
 VECTOR (0) 160 ?
 DRIVE (0) 0 ? 0-3
 DRIVE TYPE = RL01 (L) Y ?

UNIT 4
 BUS ADDRESS (0) 174400 ? 175400
 VECTOR (0) 160 ? 164
 DRIVE (0) 0 ? 0-3
 DRIVE TYPE = RL01 (L) Y ? N

THE FIRST TIME THRU THE P-TABLE QUESTIONS THE DEFAULT VALUES ARE USED FOR THE CSR ADDRESS OF THE CONTROLLER (QUESTION #1), THE CONTROLLER VECTOR ASSIGNMENT (QUESTION #2), AND THE DRIVE TYPE (QUESTION #4). THE ACTUAL UNIT NUMBERS OF THE RL01'S FOR QUESTION #3 WAS ASSIGNED 0 THRU 3 FOR THE FIRST 4 P-TABLE SLOTS.

THE SECOND TIME THRU THE P-TABLE QUESTIONS THE FIRST QUESTION WAS ANSWERED TO REFLECT THE CHANGE IN CSR ADDRESS FOR THE RL02 CONTROLLER (175400). THE SECOND CONTROLLER'S VECTOR WAS ALSO CHANGED TO 164 IN QUESTION #2. THE RL02 TEST UNIT NUMBERS WERE ASSIGNED VALUES 0 TO 3 IN QUESTION #3 AND THE DRIVE TYPE WAS SET FOR RL02'S FOR THE REMAINING 4 UNITS IN QUESTION #4.

2.5 HARDWARE PARAMETERS

THE FOLLOWING QUESTIONS WILL BE ASKED ON A START COMMAND. THE VALUE LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ON A CARRIAGE RETURN RESPONSE.

BUS ADDRESS (O) 174400?

ANSWER WITH THE BUS ADDRESS OF THE CONTROLLER.

VECTOR (O) 160?

ANSWER WITH THE INTERRUPT VECTOR OF THE CONTROLLER.

DRIVE (O) 0?

ANSWER WITH THE DRIVE(S) CONNECTED TO THE CONTROLLER

DRIVE TYPE = RL01 (L) ?

ANSWER NO (N) IF DRIVE IS AN RL02

2.6 SOFTWARE PARAMETERS

THE FOLLOWING QUESTIONS ARE ASKED IF REQUESTED ON A START, RESTART, OR CONTINUE. THEY ALLOW FLEXABILITY IN THE WAY THE PROGRAM BEHAVES. THE SOFTWARE PARAMETERS GIVE THE PROGRAM FLEXIBILITY IN THE WAY IT RUNS. THE PARAMETERS CAN BE MODIFIED ON A START, RESTART, OR CONTINUE BY ANSWERING (Y)ES TO THE FOLLOWING QUESTION:

"CHANGE S.W. ?"

A YES ANSWER WILL ASK THE FOLLOWING SOFTWARE PARAMETER QUESTIONS, WITH THE PRESENT DEFAULT VALUE PRINTED TO THE LEFT OF THE QUESTION MARK. (THE LAST ANSWER GIVEN IS THE DEFAULT) THE DEFAULT IS TAKEN ON A <CR>. CONTROL Z (^Z) WILL DEFAULT ALL REMAINING QUESTIONS AND START THE TEST.

THERE ARE NO SOFTWARE PARAMETERS.

3.0 ERROR INFORMATION

ERROR INFORMATION IS COMPLETE IN GIVING ALL INFORMATION NECESSARY. ALL REGISTERS ARE GIVEN AS WELL AT TRACK, SECTOR AND DRIVES INVOLVED IN ERROR.

3.1 ERROR REPORTING

ALL ERROR INFORMATION IS PRINTED ON THE CONSOLE DEVICE. ERROR REPORTS ARE AIMED AT BEING SELF EXPLANATORY. THE GENERAL FORMAT IS:

DZRLX XXX ERR YYYYY TST ZZZ SUB PPP PC: RRRRRR

WHERE:

? IS PROGRAM LETTER
 XXX IS SFT - SOFT ERROR
 HRD - HARD ERROR
 DV FAT - DEVICE FATAL ERROR
 SYS FAT - SYSTEM FATAL ERROR
 YYYYY IS THE ERROR NUMBER
 ZZZ IS THE TEST NUMBER
 PPP IS THE SUBTEST NUMBER
 RRRRRR IS THE PROGRAM LISTING LOCATION

ERRORS GIVE THE REGISTER CONTENTS BEFORE AND AFTER THE ERROR ALONG WITH A ONE LINE DESCRIPTION AND RELEVANT DATA.

EXAMPLE:

ONE LINE DESCRIPTION
 (OPTIONAL SECOND LINE)
 (OPTIONAL THIRD LINE)
 BEFORE CS:XXXXXX BA:XXXXXX DA:XXXXXX MP:XXXXXX
 AFTER CS:XXXXXX BA:XXXXXX DA:XXXXXX MP:XXXXXX
 OTHER PERTINENT INFORMATION IS GIVEN AT THIS TIME.

REGISTER DESCRIPTIONS CAN BE FOUND IN SECTION 5.0.

ERROR DESCRIPTIONS:

'ERROR READING SECTOR'

ERROR WAS ENCOUNTERED WHILE TRYING TO READ VERIFY THE SECTOR AFTER IT WAS WRITTEN BY THE SAME DRIVE.

'MINIMUM OF TWO DRIVES REQUIRED'

THE PROGRAM REQUIRES AT LEAST TWO DRIVES TO PROVE COMPATABILITY.

'MAXIMUM OF FOUR DRIVES ALLOWED''

THE PROGRAM ONLY ALLOWS A MAXIMUM OF FOUR DRIVES.

'CAN'T FIND FIVE ADJACENT TRACKS''

THE PROGRAM REQUIRES TEN SETS OF FIVE ADJACENT TRACKS AT PREDETERMINED SPOTS ACROSS THE PACK. IT WAS UNABLE TO FIND FIVE COMPLETELY GOOD ADJACENT TRACKS IN THE LIMITS GIVEN.

'ERROR WRITING SECTOR''

AN ERROR WAS ENCOUNTERED WHILE TRYING TO WRITE THE GIVEN SECTOR.

'OVERWRITE ERROR''

AN ERROR WAS ENCOUNTERED WHILE TRYING TO READ DATA AFTER AN OVERWRITE BY ONE DRIVE. BOTH DRIVES INVOLVED ARE GIVEN.

'READ RECOVERY ERROR''

AN ERROR WAS ENCOUNTERED WHILE TRYING TO RECOVER ANOTHER DRIVES DATA.

'ADJACENT TRACK TEST''

AN ERROR WAS ENCOUNTERED WHILE IN THE ADJACENT TEST PART, A FURTHER DESCRIPTION IS GIVEN.

3.2 ERROR HALTS

ERROR HALTS ARE SUPPORTED PER DESCRIBED IN THE PREVIOUS SECTION WITH /FLAG:HOE. THERE ARE NO OTHER HALTS.

4.0 PERFORMANCE AND PROGRESS REPORTS

4.1 PERFORMANCE REPORTS

THIS PROGRAM WILL NOT GIVE ANY PERFORMANCE REPORTS.

4.2 PROGRESS REPORTS

THIS PROGRAM WILL NOT GIVE ANY PROGRESS REPORTS.

5.0 DEVICE INFORMATION TABLES

THE RL11/RLV11 CONTROLLER HAS THE FOLLOWING FOUR(4) REGISTERS FOR CONTROL OF THE SUBSYSTEM.

RLCS - CONTROL AND STATUS REGISTER (XXXXX0)

BIT 15 - COMPOSITE ERROR
 BIT 14 - DRIVE ERROR
 BIT 13 - NON EXISTANT MEMORY ERROR
 BIT 12 - HEADER NOT FOUND (WITH BIT 10 SET)
 - DATA LATE (WITH BIT 10 CLEAR)
 BIT 11 - HEADER CRC (WITH BIT 10 SET)
 - DATA CRC (WITH BIT 10 CLEAR)
 BIT 10 - OPERATION INCOMPLETE
 BIT 9/8 - DRIVE SELECT (0-3)
 BIT 7 - CONTROLLER READY
 BIT 6 - INTERRUPT ENABLE
 BIT 5 - EXTENDED BUS ADDRESS (BIT 17)
 BIT 4 - EXTENDED BUS ADDRESS (BIT 16)
 BIT 3-1 - FUNCTION CODE
 0 - NOP (PDP-11) MAINT (LSI-11)
 1 - WRITE CHECK
 2 - GET DRIVE STATUS
 3 - SEEK
 4 - READ HEADER
 5 - WRITE DATA
 6 - READ DATA
 7 - READ WITHOUT HEADER COMPARE

BIT 0 - DRIVE READY

RLBA - BUS ADDRESS REGISTER (XXXXX2)

BITS 15-1 BUS ADDRESS OF DATA TRANSFER
 BIT 0 SHOULD BE 0

RLDA - DISK ADDRESS REGISTER (XXXXX4)

FOR READ/WRITE FUNCTIONS

BIT 15-7 - CYLINDER ADDRESS FOR TRANSFER
BIT 6 - SURFACE FOR TRANSFER
BIT 5-0 - SECTOR FOR TRANSFER (1-40.)

FOR SEEK FUNCTION

BIT 15-7 - DIFFERENCE TO NEW CYLINDER
BIT 6-5 - MUST BE ZERO (0)
BIT 4 - SURFACE (0=UPPER, 1=LOWER)
BIT 3 - MUST BE ZERO (0)
BIT 2 - SEEK DIRECTION(1=IN / 0=OUT)
BIT 1 - MUST BE ZERO (0)
BIT 0 - MUST BE ONE (1)

FOR GET STATUS FUNCTION

BIT 15-4 - IGNORED SHOULD BE ZERO (0)
BIT 3 - DRIVE RESET
BIT 2 - MUST BE ZERO (0)
BIT 1 - MUST BE ONE (1)
BIT 0 - MUST BE ONE (1)

RLMP - MULTIPURPOSE REGISTER

FOR READ/WRITE FUNCTION

BIT 15 - 0 - WORD COUNT (TWO'S COMPLIMENT)

FOR READ HEADER FUNCTION

BIT 15-0 - DISK HEADER OF SECTOR (FIRST READ)
- ZERO WORD (SECOND READ)
- HEADER CRC (THIRD READ)

FOR GET STATUS FUNCTION

HAS DRIVE STATUS

BIT 15 - WRITE DATA ERROR
BIT 14 - CURRENT HEAD ERROR (CHE)
BIT 13 - WRITE LOCK STATUS (WL)
BIT 12 - SEEK TIME OUT (SKTO)
BIT 11 - SPIN ERROR (SPE)
BIT 10 - WRITE GATE ERROR (WGE)

BIT 9 - VOLUME CHECK (VC)
 BIT 8 - DRIVE SELECT ERROR (DSE)
 BIT 7 - DRIVE TYPE IS RLO2 IF SET
 BIT 6 - SURFACE (0=UPPER, 1=LOWER)
 BIT 5 - COVER OPEN
 BIT 4 - HEADS HOME
 BIT 3 - BRUSHES HOME
 BIT 2-0 - STATE BITS
 0 - LOAD STATE
 1 - SPIN UP
 2 - BRUSH CYCLE
 3 - LOAD HEADS
 4 - SEEK - TRACK COUNTING
 5 - SEEK - LINEAR MODE
 6 - UNLOAD HEADS
 7 - SPIN DOWN

6.0 TEST SUMMARIES

THE FOLLOWING IS A BRIEF DESCRIPTION OF THE WAY THE PROGRAM EXECUTES. THE PROGRAM WILL CHECK COMPATIBILITY BETWEEN 2 - 4 DRIVES USING THE SAME RLO1K CARTRIDGE OR SAME RLO2K CARTRIDGE. THE PROGRAM WILL ASK THE OPERATOR TO SEQUENCE THE PACK BETWEEN THE DRIVES GIVEN IN THE FOLLOWING MANNER.

PLACE PACK IN DRIVE N ON CONTROLLER X AND LOAD
 UNLOAD DRIVE N ON CONTROLLER X
 PLACE PACK IN DRIVE N+1 ON CONTROLLER X AND LOAD
 UNLOAD DRIVE N+1 ON CONTROLLER X
 ETC.....

THE PROGRAM WILL SEQUENCE IN THE ORDER THAT WAS GIVEN IN THE HARDWARE QUESTIONS. I.E.

DRIVE ? 0,1,2,3
 PROGRAM WILL SEQUENCE 0,1,2,3,2,1,0
 DRIVE ? 1,0,3,2
 PROGRAM WILL SEQUENCE 1,0,3,2,3,0,1

WHEN THE FIRST DRIVE IS LOADED THE PROGRAM WILL ATTEMPT TO FIND TEN SETS OF FIVE ADJACENT TRACKS AT PREDETERMINED SPOTS THAT CONTAIN NO BAD SECTORS USING THE BAD SECTOR FILE. THE 10 SPOTS ARE: ON BOTH SURFACES, INNER, OUTER, MIDDLE, ONE QUARTER AND THREE QUARTERS. AFTER THIS IS DONE THE OVERWRITE TEST IS PREPARED (FIRST DRIVE CAN'T OVERWRITE) AS WELL AS THE ADJACENT TEST. AS THE PACK IS CYCLED BETWEEN DRIVES THE FOLLOWING CHECKS ARE MADE:

EACH DRIVE CAN OVERWRITE EACH OTHER DRIVE

EACH DRIVE CAN RECOVER EACH OTHERS DATA

EACH DRIVE CAN WRITE ADJACENT TO EVERY OTHER DRIVE WITHOUT DISTURBING THE OTHER'S DATA.

READS AND WRITES TAKE PLACE AFTER SEEKS FROM BOTH DIRECTIONS.

ADJACENT WRITES TAKE PLACE TO BOTH SIDES OF EACH WRITE

TESTS ARE PERFORMED AT ALL TEN SPOTS ACROSS THE PACK.

a

CZRLCO RL01/02 DRIVE COMPAT MACRO V04.00 16-FEB-82 13:32:06
TABLE OF CONTENTS

2-	8	MACRO DEFINITIONS
3-	36	GLOBAL EQUATES SECTION
3-	2	GLOBAL DATA SECTION
5-	1	GLOBAL TEXT SECTION
5-	35	GLOBAL ERROR REPORT SECTION
7-	1	INITIALIZATION SECTION
9-	1	GLOBAL SUBROUTINES SECTION
27-	51	CONTROL ROUTINE

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29

000000
002000

002000
000000
000000

002000

002000
002000
002001
002002
002003
002004
002005
002006
002007
002010
002011
002012
002014
002016
002020
002022
002024
002026
002030
002032
002034
002036
002040
002042
002044
002046
002050
002051
002052

103
132
122
114
114
000
000
000
103
060
000000
000000
033652
000000
022450
000000
034014
000000
000000
000001
000000
022464
000000
000000
000000
000000
003
003
000000

```
.TITLE CZRLLCO RL01/02 DRIVE COMPAT
.ENABLE AMA
.ENABLE ABS
.MCALL SVC
.=2000

.SBTTL MACRO DEFINITIONS

.MACRO WAITUS ARG ;MACRO MICRO-SECOND WAIT
MOV ARG,XDELAY ;SAVE ARGUMENT
JSR PC,TIME ;CALL TIMING ROUTING
.ENDM

.MACRO WAITMS ARG ;MACRO MILLI-SECOND WAIT
MOV ARG,YDELAY ;SAVE ARGUMENT
JSR PC,XTIME ;CALL TIMING ROUTINE
.ENDM

.NLIST CND,MD,ME

SVC
SVCINS=0
SVCTAG=0

POINTER NONE

BGNMOD MDHEDR
HEADER CZRLL,C,0,0,1
.ASCII /C/
.ASCII /Z/
.ASCII /R/
.ASCII /L/
.ASCII /L/
.BYTE 0
.BYTE 0
.BYTE 0
.ASCII /C/
.ASCII /O/
.WORD 0
.WORD 0
.WORD LSHARD
.WORD 0
.WORD LSHW
.WORD 0
.WORD L$LAST
.WORD 0
.WORD 0
.WORD 1
.WORD 0
.WORD L$DISPATCH
.WORD 0
.WORD 0
.WORD 0
.WORD 0
.BYTE C$REVISION
.BYTE C$EDIT
.WORD 0
```

002054	000000	.WORD	0
002056	000000	.WORD	0
002060	002222	.WORD	LSDV TYP
002062	000000	.WORD	0
002064	000000	.WORD	0
002066	000000	.WORD	0
002070	000000	.WORD	0
002072	000000	.WORD	0
002074	000000	.WORD	0
002076	002122	.WORD	LSDESC
002100	104035	EMT	ESLOAD
002102	000000	.WORD	0
002104	022466	.WORD	LSINIT
002106	024316	.WORD	LSCLEAN
002110	024312	.WORD	LSAUTO
002112	022440	.WORD	LSPROT
002114	000000	.WORD	0
002116	000000	.WORD	0
002120	000000	.WORD	0
002122		ENDMOD	

30
31
32
33
34
35
36
37
38
39
40

DESCRPT <CZRL VERIFIES INTERCHANGEABILITY OF CARTRIDGES BETWEEN DRIVES>
 .ASCIZ /CZRL VERIFIES INTERCHANGEABILITY OF CARTRIDGES BETWEEN DRIVES/

002122	103	132	122
002125	114	114	040
002130	126	105	122
002133	111	106	111
002136	105	123	040
002141	111	116	124
002144	105	122	103
002147	110	101	116
002152	107	105	101
002155	102	111	114
002160	111	124	131
002163	040	117	106
002166	040	103	101
002171	122	124	122
002174	111	104	107
002177	105	123	040
002202	102	105	124
002205	127	105	105
002210	116	040	104
002213	122	111	126
002216	105	123	000

.EVEN

DEV TYP <RL01,RL02>
 .ASCIZ /RL01,RL02/

002222	122	114	060
002225	061	054	122
002230	114	060	062
002233	000		

.EVEN

.SBTTL GLOBAL EQUATES SECTION
 ;DEFINITIONS
 BGNMOD GLBEQAT

41
42 002234

EQUALS

: BIT DEFINITIONS

100000 BIT15== 100000
040000 BIT14== 40000
020000 BIT13== 20000
010000 BIT12== 10000
004000 BIT11== 4000
002000 BIT10== 2000
001000 BIT09== 1000
000400 BIT08== 400
000200 BIT07== 200
000100 BIT06== 100
000040 BIT05== 40
000020 BIT04== 20
000010 BIT03== 10
000004 BIT02== 4
000002 BIT01== 2
000001 BIT00== 1

001000 BIT9== BIT09
000400 BIT8== BIT08
000200 BIT7== BIT07
000100 BIT6== BIT06
000040 BIT5== BIT05
000020 BIT4== BIT04
000010 BIT3== BIT03
000004 BIT2== BIT02
000002 BIT1== BIT01
000001 BIT0== BIT00

: EVENT FLAG DEFINITIONS
: EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION

000040 EF.START== 32. : START COMMAND WAS ISSUED
000037 EF.RESTART== 31. : RESTART COMMAND WAS ISSUED
000036 EF.CONTINUE== 30. : CONTINUE COMMAND WAS ISSUED
000035 EF.NEW== 29. : A NEW PASS HAS BEEN STARTED
000034 EF.PWR== 28. : A POWER-FAIL/POWER-UP OCCURRED

: PRIORITY LEVEL DEFINITIONS

000340 PRI07== 340
000300 PRI06== 300
000240 PRI05== 240
000200 PRI04== 200
000140 PRI03== 140
000100 PRI02== 100
000040 PRI01== 40
000000 PRI00== 0

: OPERATOR FLAG BITS

000004 EVL== 4

```

000010      LOT==      10
000020      ADR==      20
000040      IDU==      40
000100      ISR==     100
000200      UAM==     200
000400      BOE==     400
001000      PNT==    1000
002000      PRI==    2000
004000      IXE==    4000
010000      IBE==   10000
020000      IER==   20000
040000      LOF==   40000
100000      HOE==  100000

43
44      000000      CS=0          ;CONTROL AND STATUS OFFSET
45      000002      BA=2          ;BUSS ADDRESS OFFSET
46      000004      DA=4          ;DISK ADDRESS OFFSET
47      000006      MP=6          ;MULTI PURPOSE OFFSET
48
49      ;CONSTANT OFFSETS FOR INDIVIDUAL DRIVE BUFFERS
50
51      000000      CSR=0         ;CONTROLLER ADDRESS
52      000002      VEC=2         ;VECTOR OF CONTROLLER
53      000004      DSB=4         ;DRIVE SELECT
54      000006      PAT=6         ;PATTERN UNIQUE TO DRIVE
55
56
57      000001      DRDY=BIT0      ;DRIVE READY
58      000100      INTEN=BIT6     ;INTERRUPT ENABLE
59      100000      ERR=BIT15      ;COMPOSITE ERROR
60      040000      DERR=BIT14     ;DRIVE EPROR
61      020000      NXM=BIT13      ;NON-EXISTANT MEMORY ERROR
62      010000      DLT=BIT12      ;DATA LATE
63      004000      DCRC=BIT11     ;DATA CRC ERROR
64      004000      HCRC=BIT11     ;HEADER CRC ERROR
65      010000      HNF=BIT12      ;HEADER NOT FOUND ERROR
66      002000      OPI=BIT10      ;OPERATION INCOMPLETE ERROR
67      000200      CRDY=BIT7      ;CONTROLLER READY
68      000040      BA17=BIT5      ;EXTENDED BUS ADDRESS BIT 17
69      000020      BA16=BIT4      ;EXTENDED BUS ADDRESS BIT 16
70      000002      CRSET=BIT1      ;CONTROLLER RESET FUNCTION CODE
71      000004      GSTAT=BIT2     ;GET DRIVE STATUS FUNCTION CODE
72      000006      SEEK=BIT1!BIT2 ;SEEK FUNCTION CODE
73      000010      RDHDR=BIT3      ;READ HEADER FUNCTION CODE
74      000012      WRITE=BIT3!BIT1 ;WRITE FUNCTION CODE
75      000014      READ=BIT3!BIT2  ;READ FUNCTION CODE
76      000013      DRST=BIT3!BIT1!BIT0 ;DRIVE RESET COMMAND CODE FOR DRIVE COMMAND WORD
77      000003      GSBIT=BIT1!BIT0 ;GET STATUS COMMAND CODE FOR DRIVE COMMAND WORD
78      000001      MK=BIT0         ;MARKER BIT FOR DRIVE COMMAND WORD(SEEK,GET STATUS)
79      000004      SIGN=BIT2      ;DIRECTION FOR SEEK(0=AWAY FROM SPINDLE)
80      000020      SKHS=BIT4      ;HEAD SELECT FOR SEEK
81      000100      HEAD=BIT6      ;HEAD SELCT FOR READ,WRITE,GET STATUS
82
83      ;OFFSET FOR HARDWARE P-TABLE
84
85      000000      CSR= 0          ;BUS ADDRESS
86      000002      VECT= 2         ;VECTOR ADDRESS
    
```

87	000004	PRIOR= 4	:PRIORITY (BREAK LEVEL)
88	000006	TYPDR= 6	:DRIVE TYPE
89	000010	DRBT= 10	:DRIVE SELECT
90			
91	002234	ENDMOD	
92			
93			
94			

1
 2
 3
 4 002234
 5
 6 002234 000000
 7
 8
 9
 10
 11 002236 000000
 12 002240 000000
 13 002242 000000
 14 002244 000000
 15 002246 000000
 16 002250 000000
 17 002252 000000
 18 002254 000000
 19 002256 000000
 20 002260 000000
 21 002262 000000
 22 002264 000000
 23 002266 000000
 24 002270 000000
 25 002272 000000
 26 002274 000000
 27 002276 000000
 28 002300 000000
 29 002302 000000
 30 002304 000000
 31 002306 000000
 32 002310 000000
 33 002312 000000
 34 002314 000000
 35 002316 000000
 36 002320 000000
 37 002322 000000
 38 002324 000000
 39 002326 000000
 40 002330 000000
 41 002332 000000
 42 002334 000000
 43 002336 000000
 44 002340 000000
 45 002342 000000
 46 002344 000000
 47 002346 000000
 48 002350 000000
 49 002352 000000
 50 002354 000000
 51 002356 000000
 52 002360 000000
 53 002362 000000
 54 002364 000000
 55 002366 000000
 56 002370 000000
 57 002372 000000

```

.SBTTL GLOBAL DATA SECTION
BGNMOD GLBDAT
HDRFND: .WORD 0 ;1=HEADER IN BAD SECTOR LIST
;HERE IS THE LIST OF TRACKS TO USE FOR THIS TEST
;TRACKS ARE ENTERED BY 'FNDTRK' ROUTINE & 'FIXTRK' ROUTINE
OUT10: .WORD 0 ;OUTER TRK HEAD 0
OUT20: .WORD 0
OUT30: .WORD 0
OUT40: .WORD 0
OUT50: .WORD 0
OUT11: .WORD 0 ;OUTER TRK HEAD 1
OUT21: .WORD 0
OUT31: .WORD 0
OUT41: .WORD 0
OUT51: .WORD 0
OQU10: .WORD 0 ;1ST QUARTER TRK HEAD 0
OQU20: .WORD 0
OQU30: .WORD 0
OQU40: .WORD 0
OQU50: .WORD 0
OQU11: .WORD 0 ;1ST QUARTER TRK HEAD 1
OQU21: .WORD 0
OQU31: .WORD 0
OQU41: .WORD 0
OQU51: .WORD 0
MID10: .WORD 0 ;MIDDLE TRK HEAD 0
MID20: .WORD 0
MID30: .WORD 0
MID40: .WORD 0
MID50: .WORD 0
MID11: .WORD 0 ;MIDDLE TRK HEAD 1
MID21: .WORD 0
MID31: .WORD 0
MID41: .WORD 0
MID51: .WORD 0
TQU10: .WORD 0 ;3RD QUARTER TRK HEAD 0
TQU20: .WORD 0
TQU30: .WORD 0
TQU40: .WORD 0
TQU50: .WORD 0
TQU11: .WORD 0 ;3RD QUARTER TRK HEAD 1
TQU21: .WORD 0
TQU31: .WORD 0
TQU41: .WORD 0
TQU51: .WORD 0
INN10: .WORD 0 ;INNER TRK HEAD 0
INN20: .WORD 0
INN30: .WORD 0
INN40: .WORD 0
INN50: .WORD 0
INN11: .WORD 0 ;INNER TRK HEAD 1
INN21: .WORD 0
    
```

58 002374 000000
59 002376 000000
60 002400 000000
61
62
63
64
65
66 002402
67
68
69
70 002442
71
72
73
74
75
76 003022 002242
77 003024 002266
78 003026 002312
79 003030 002336
80 003032 002362
81 003034 002254
82 003036 002300
83 003040 002324
84 003042 002350
85 003044 002374
86
87 003046 152525
88 003050 133333
89 003052 066666
90 003054 155555
91

INN31: .WORD 0
INN41: .WORD 0
INN51: .WORD 0
.EVEN

:SECTOR LIST FOR LAST DRIVE WRITTEN
:MAP OF 16 SECTOR DRIVE BITS

SECLST: .BLKW 16.

:BUFFER TABLE FOR 24 X 5 MATRIX USED FOR ADJACENT CYLINDER TESTING.

SECBUF: .BLKW 5*24.

:LIST OF TRACKS USED TO OVERWRITE TEST.
:FIRST FIVE ARE CYLINDER ADDRESSES OF TOP SURFACE.
:LAST FIVE ARE CYLINDER ADDRESSES OF BOTTOM SURFACE.

OVWTRK: OUT30
OQU30
MID30
TQU30
INN30
OUT31
OQU31
MID31
TQU31
INN31

PATLST: .WORD 152525
.WORD 133333
.WORD 066666
.WORD 155555

1					
2	003056	000000	TEM:	.WORD	0
3	003060	000000	T.DRIVE:	.WORD	0
4	003062	000000	FOUR:	.WORD	0
5	003064	000000	FADJ:	.WORD	0
6	003066	000000	TEMP:	.WORD	0
7	003070	000000	LSTCLR:	.WORD	0
8	003072	000000	REASON:	.WORD	0
9	003074	000000	ERFLG:	.WORD	0
10	003076	000000	STFLG:	.WORD	0
11	003100	000000	ADJLOC:	.WORD	0
12	003102	000000	ADJFLG:	.WORD	0
13	003104	000000	ADJDIR:	.WORD	0
14	003106	000000	DRSTAT:	.WORD	0
15	003110	000000	HSFLG:	.WORD	0
16	003112	000000	OSECT:	.WORD	0
17	003114	000000	HEAD01:	.WORD	0
18	003116	000000	DIRC:	.WORD	0
19	003120	000000	SURF:	.WORD	0
20	003122	000000	CYL:	.WORD	0
21	003124	000000	REVSK:	.WORD	0
22	003126	000000	FORSK:	.WORD	0
23	003130	000000	UUT:	.WORD	0
24	003132	000000	SECT:	.WORD	0
25	003134	000000	LSTDRV:	.WORD	0
26	003136	000000	GDATA:	.WORD	0
27	003140	000000	BDATA:	.WORD	0
28	003142	000000	WCOUNT:	.WORD	0
29	003144	000000	SECWRD:	.WORD	0
30	003146	000000	OFFSET:	.WORD	0
31	003150	000000	LSTRK:	.WORD	0
32	003152	000000	FSTRK:	.WORD	0
33	003154	000000	PRSTRK:	.WORD	0
34	003156	000000	SURFACE:	.WORD	0
35	003160	000000	TRKFND:	.WORD	0
36	003162	000000	TRKCNT:	.WORD	0
37	003164	000000	E.CS:	.WORD	0
38	003166	000000	E.BA:	.WORD	0
39	003170	000000	E.DA:	.WORD	0
40	003172	000000	E.MP:	.WORD	0
41	003174	000000	E.MP1:	.WORD	0
42	003176	000000	E.MP2:	.WORD	0
43	003200	000000	BCS:	.WORD	0
44	003202	000000	BBA:	.WORD	0
45	003204	000000	BDA:	.WORD	0
46	003206	000000	BMP:	.WORD	0
47	003210	000000	SERNM1:	.WORD	0
48	003212	000000	SERNM2:	.WORD	0
49	003214	000000	ADJTRK:	.WORD	0
50	003216	000000	ADJUUT:	.WORD	0
51	003220	000000	ADJLC2:	.WORD	0
52	003222	000000	ADJLC3:	.WORD	0
53	003224	000000	ADJLC4:	.WORD	0
54	003226	000000	STSEC1:	.WORD	0
55	003230	000000	STSEC:	.WORD	0
56	003232		BUF:	.BLKW	3072.
57	017232	000000	XDELAY:	.WORD	0

```

:LAST CONTROLLER
:DRIVE ERROR REASON
:ERROR FLAG
:PROGRAM START UP FLAG
:TRACK INDEX FOR ADJ. CYL TEST
:FLAG FOR ADJ. STORE OR RETRIEVE
:ADJACENT SEEK DIRECTION

:SURFACE FLAG
:DIRECTION OF SEEK

:REVERSE SEEK
:FORWARD SEEK
:UNIT UNDER TEST
:SECTOR
:LAST DRIVE
:GOOD DATA
:BAD DATA
:WORD COUNT
:SECTOR WORD
:INCREMENT
:LAST TRACK OF SEARCH
:FIRST TRACK OF SEARCH
:PRESENT TRACK
:SURFACE
:TRACK FOUND
:TRACK COUNT
:IMAGE OF CSR
:IMAGE OF BUS ADDRESS
:IMAGE OF DISK ADDRESS
:IMAGE OF MULTI-PURPOSE WORD 1
: " " " " " " 2
: " " " " " " 3

:COMMAND LOADED
:BUS ADDRESS LOADED
:DISK ADDRESS LOADED
:WORD COUNT LOADED
:SERIAL NUMBER OF CATRIDGE
:INSIDE/OUTSIDE FLAG
:UUT FOR "ADJCYL"
:TEMP LOC FOR "ADJCYL"
: " " " " " "
:SECTORS TO WRITE "ADJCYL"
:BUFFER FOR 24 SECTOR READS
:DELAY FOR WAIT MICRO-SECOND MACRO
    
```

58	017234	000000	YDELAY: .WORD	0	:DELAY FOR WAIT MILLI-SECOND MACRO
59	017236	000000	OBUFF: .WORD	0	:RESPONSE BUFFER
60					
61					
62	017240		DRBUF:		:DRIVE INFORMATION BUFFERS
63					
67					
68		000004	.REPT	4.	
75					
	017240	000000	CSR		:CONTROLLER ADDRESS
	017242	000002	VEC		:VECTOR
	017244	000004	DSB		:DRIVE SELECT BITS
	017246	000006	PAT		:PATTERN UNIQUE TO DRIVE
	017250	000000	CSR		:CONTROLLER ADDRESS
	017252	000002	VEC		:VECTOR
	017254	000004	DSB		:DRIVE SELECT BITS
	017256	000006	PAT		:PATTERN UNIQUE TO DRIVE
	017260	000000	CSR		:CONTROLLER ADDRESS
	017262	000002	VEC		:VECTOR
	017264	000004	DSB		:DRIVE SELECT BITS
	017266	000006	PAT		:PATTERN UNIQUE TO DRIVE
	017270	000000	CSR		:CONTROLLER ADDRESS
	017272	000002	VEC		:VECTOR
	017274	000004	DSB		:DRIVE SELECT BITS
	017276	000006	PAT		:PATTERN UNIQUE TO DRIVE
76					
80	017300	000000	ENDBUF: .WORD	0	:END OF DRIVE BUFFERS
81	017302		ENDMOD		

```

1
2 017302          .SBTTL GLOBAL TEXT SECTION
3                BGNMOD GLBTXT
4                :GLOBAL TEXT
5
6
10
11 017302          103      117      116  OPR001: .ASCIZ  /CONTINUE TEST?/
12 017321          101      102      117  OPR002: .ASCIZ  /ABOVE CONDITIONS MET/
13 017346          103      117      116  CNTTOT: .ASCIZ  /CONTROLLER TIMED OUT/
14 017373          105      122      122  INITWR: .ASCIZ  /ERROR ON RECOVERING INITIAL WRITE BY FIRST DRIVE /
15 017455          105      122      122  DCKER:  .ASCIZ  /ERROR ON READ/
16 017473          115      111      116  FEW:    .ASCIZ  /MINIMUM OF TWO DRIVES REQUIRED/
17 017532          115      101      130  MANY:  .ASCIZ  /MAXIMUM OF FOUR DRIVES ALLOWED/
18 017571          124      105      123  NONE:  .ASCIZ  /TEST ABORTED - CAN'T FIND ANY GOOD SPOTS/
19 017642          124      122      131  OVMS:  .ASCIZ  /TRYING TO OVERWRITE DRIVE /
20 017675          124      122      131  RECMS: .ASCIZ  /TRYING TO READ DATA WRITTEN BY DRIVE /
21 017743          103      101      116  ERRFND: .ASCIZ /CAN'T FIND FIVE ADJACENT TRACKS/
22 020003          117      126      105  OVWER: .ASCIZ  /OVERWRITE ERROR/
23 020023          122      105      101  RECER: .ASCIZ  /READ RECOVERY ERROR/
24 020047          105      122      122  FUNERR: .ASCIZ /ERROR IN SEEK OPERATION/
25 020077          115      111      123  SKER:  .ASCIZ  /MIS SEEK ERROR/
26 020116          106      117      122  FWD:   .ASCIZ  /FORWARD/
27 020126          122      105      126  REV:   .ASCIZ  /REVERSE/
28 020136          105      122      122  WRIT1: .ASCIZ  /ERROR WRITING SECTOR/
29 020163          105      122      122  READ1: .ASCIZ  /ERROR READING SECTOR/
30 020210          101      104      112  ADJTXT: .ASCIZ /ADJACENT CYLINDER TEST/
31                .EVEN
32
33 020240          ENDMOD
34
35                .SBTTL GLOBAL ERROR REPORT SECTION
36
37 020240          BGNMOD GLBERR
38
39 020240          BGNMSG ERR1
40
41 020240          PRINTB #FRM10,FRTRK,LSTTRK,SURFACE ;BETWEEN _ _ HEAD _
42 020240          MOV     SURFACE,-(SP)
43 020244          013746  003150  MOV     LSTTRK,-(SP)
44 020250          013746  003152  MOV     FRTRK,-(SP)
45 020254          012746  021545  MOV     #FRM10,-(SP)
46 020260          012746  000004  MOV     #4,-(SP)
47 020264          010600  MOV     SP,R0
48 020266          104414  TRAP   C$PNTB
49 020270          062706  000012  ADD    #12,SP
50
51
52 020274          ENDMMSG
53 020274          L10000:
54 020274          104423  TRAP   C$MSG
55
56
57 020276          BGNMSG ERR2
58 020276          PRINTB #FRM4,CSR(R4),<B,DSB+1(R4)> ;CONTROLLER _ DRIVE _
59 020276          CLR     -(SP)
60 020300          005046  BLSB  DSB+1(R4),(SP)
61 020304          016446  000000  MOV     CSR(R4),-(SP)
62 020310          012746  021246  MOV     #FRM4,-(SP)
    
```

	020314	012746	000003	MOV	#3,-(SP)	
	020320	010600		MOV	SP,R0	
	020322	104414		TRAP	C\$PNTB	
	020324	062706	000010	ADD	#10,SP	
47	020330	004737	026522	JSR	PC,REGDMP	:REGISTER DUMP ROUTINE
48	020334			ENDMSG		
	020334			L10001:		
	020334	104423		TRAP	C\$MSG	
49				BGNMSG		
50	020336			ERR3		
51	020336			PRINTB	#FRM4,CSR(R4),<B,DSB+1(R4)>	:CONTROLLER _ DRIVE _
	020336	005046		CLR	-(SP)	
	020340	156416	000005	BISB	DSB+1(R4),(SP)	
	020344	016446	000000	MOV	CSR(R4),-(SP)	
	020350	012746	021246	MOV	#FRM4,-(SP)	
	020354	012746	000003	MOV	#3,-(SP)	
	020360	010600		MOV	SP,R0	
	020362	104414		TRAP	C\$PNTB	
	020364	062706	000010	ADD	#10,SP	
52	020370	004737	026522	JSR	PC,REGDMP	:REGISTER DUMP ROUTINE
53	020374			PRINTB	#FRM5,<SURF>,<CYL>,SECT	:HEAD _ CYLINDER _ SECTOR _
	020374	013746	003132	MOV	SECT,-(SP)	
	020400	013746	003122	MOV	CYL,-(SP)	
	020404	013746	003120	MOV	SURF,-(SP)	
	020410	012746	021307	MOV	#FRM5,-(SP)	
	020414	012746	000004	MOV	#4,-(SP)	
	020420	010600		MOV	SP,R0	
	020422	104414		TRAP	C\$PNTB	
	020424	062706	000012	ADD	#12,SP	
54						:ADJACENT WRITTEN BY CONTROLLER
55	020430			PRINTB	#FRM16,CSR(R3),<B,DSB+1(R3)>	:_ DRIVE _
	020430	005046		CLR	-(SP)	
	020432	156316	000005	BISB	DSB+1(R3),(SP)	
	020436	016346	000000	MOV	CSR(R3),-(SP)	
	020442	012746	022076	MOV	#FRM16,-(SP)	
	020446	012746	000003	MOV	#3,-(SP)	
	020452	010600		MOV	SP,R0	
	020454	104414		TRAP	C\$PNTB	
	020456	062706	000010	ADD	#10,SP	
56						
57	020462			ENDMSG		
	020462			L10002:		
	020462	104423		TRAP	C\$MSG	
58				BGNMSG		
59	020464			ERR4		
60						
61	020464			PRINTB	#FRM4,CSR(R4),<B,DSB+1(R4)>	:CONTROLLER _ DRIVE _
	020464	005046		CLR	-(SP)	
	020466	156416	000005	BISB	DSB+1(R4),(SP)	
	020472	016446	000000	MOV	CSR(R4),-(SP)	
	020476	012746	021246	MOV	#FRM4,-(SP)	
	020502	012746	000003	MOV	#3,-(SP)	
	020506	010600		MOV	SP,R0	
	020510	104414		TRAP	C\$PNTB	
	020512	062706	000010	ADD	#10,SP	
62	020516	004737	026522	JSR	PC,REGDMP	:REGISTER DUMP ROUTINE
63	020522			PRINTB	#FRM5,<SURF>,<CYL>,SECT	:HEAD _ CYLINDER _ SECTOR _

	020522	013746	003132	MOV	SECT,-(SP)	
	020526	013746	003122	MOV	CYL,-(SP)	
	020532	013746	003120	MOV	SURF,-(SP)	
	020536	012746	021307	MOV	#FRM5,-(SP)	
	020542	012746	000004	MOV	#4,-(SP)	
	020546	010600		MOV	SP,R0	
	020550	104414		TRAP	C\$PNTB	
	020552	062706	000012	ADD	#12,SP	
64	020556			PRINTB	#FRM6,REASON,LSTDRV,LSTCLR,LSTDRV	
	020556	013746	003134	MOV	LSTDRV,-(SP)	
	020562	013746	003070	MOV	LSTCLR,-(SP)	
	020566	013746	003134	MOV	LSTDRV,-(SP)	
	020572	013746	003072	MOV	REASON,-(SP)	
	020576	012746	021356	MOV	#FRM6,-(SP)	
	020602	012746	000005	MOV	#5,-(SP)	
	020606	010600		MOV	SP,R0	
	020610	104414		TRAP	C\$PNTB	
	020612	062706	000014	ADD	#14,SP	
65	020616			PRINTB	#FRM7,DIRC	:SEEK DIRECTION
	020616	013746	003116	MOV	DIRC,-(SP)	
	020622	012746	021377	MOV	#FRM7,-(SP)	
	020626	012746	000002	MOV	#2,-(SP)	
	020632	010600		MOV	SP,R0	
	020634	104414		TRAP	C\$PNTB	
	020636	062706	000006	ADD	#6,SP	
66						
67	020642			ENDMSG		
	020642			L10003:		
	020642	104423		TRAP	C\$MSG	
68						
69	020644			BGNMSG	ERR5	
70	020644			PRINTB	#FRM4,CSR(R4),<B,DSB+1(R4)>	:CONTROLLER _ DRIVE _
	020644	005046		CLR	-(SP)	
	020646	156416	000005	BISB	DSB+1(R4),(SP)	
	020652	016446	000000	MOV	CSR(R4),-(SP)	
	020656	012746	021246	MOV	#FRM4,-(SP)	
	020662	012746	000003	MOV	#3,-(SP)	
	020666	010600		MOV	SP,R0	
	020670	104414		TRAP	C\$PNTB	
	020672	062706	000010	ADD	#10,SP	
71	020676	004737	026522	JSR	PC,REGDMP	
72	020702			ENDMSG		
	020702			L10004:		
	020702	104423		TRAP	C\$MSG	
73						
74	020704			BGNMSG	ERR6	
75	020704			PRINTB	#FRM4,CSR(R4),<B,DSB+1(R4)>	
	020704	005046		CLR	-(SP)	
	020706	156416	000005	BISB	DSB+1(R4),(SP)	
	020712	016446	000000	MOV	CSR(R4),-(SP)	
	020716	012746	021246	MOV	#FRM4,-(SP)	
	020722	012746	000003	MOV	#3,-(SP)	
	020726	010600		MOV	SP,R0	
	020730	104414		TRAP	C\$PNTB	
	020732	062706	000010	ADD	#10,SP	
76	020736	004737	026522	JSR	PC,REGDMP	
77	020742			PRINTB	#FRM17,R1,E.MP	

	020742	013746	003172		MOV	E,MP,-(SP)
	020746	010146			MOV	R1,-(SP)
	020750	012746	022163		MOV	#FRM17,-(SP)
	020754	012746	000003		MOV	#3,-(SP)
	020760	010600			MOV	SP,R0
	020762	104414			TRAP	C\$PNTB
	020764	062706	000010		ADD	#10,SP
78	020770				ENDMSG	
	020770			L10005:		
	020770	104423			TRAP	C\$MSG

:FORMAT STATMENTS

79						
80						
81						
82						
83						
87						
88	020772	045	116	045	FRM1:	.ASCIZ /%N%UNLOAD DRIVE %01% ON CONTROLLER %06% AND REMOVE PACK%N/
89	021067	045	116	045	FRM2:	.ASCIZ /%N%APLACE PACK IN DRIVE %01% ON CONTROLLER %06% AND LOAD IT%N/
90	021167	045	116	045	FRM3:	.ASCIZ !%N%AWRONG PACK # IS %05%05% # S/B %05%05%N%N!
91	021246	045	101	103	FRM4:	.ASCIZ /%A%CONTROLLER: %06% DRIVE: %01%N/
92	021307	045	101	110	FRM5:	.ASCIZ /%A%HEAD: %01% CYL: %23% SECTOR: %22%N/
93	021356	045	124	045	FRM6:	.ASCIZ /%T%01% ON %06%N/
94	021377	045	101	123	FRM7:	.ASCIZ /%A%SEEK DIRECTION: %T%N%ADATA:%N/
95	021437	045	101	127	FRM8:	.ASCIZ !%A%WORD: %23% S/B: %06% WAS: %06%N!
96	021503	045	104	063	FRM9:	.ASCIZ /%D3% WORDS BAD OUT OF 128 READ%N/
97	021545	045	101	102	FRM10:	.ASCIZ /%A%BETWEEN %23% - %23% HEAD: %01%N/
98	021611	045	116	045	FRM11:	.ASCIZ /%N%APWR FAIL NOT SUPPORTED%N/
99	021646	045	101	102	FRM12:	.ASCIZ /%A%BEFORE CS: %06% BA: %06% DA: %06% MP: %06%/
100	021725	045	116	045	FRM13:	.ASCIZ /%N%AAFTER CS: %06% BA: %06% DA: %06% MP: %06%N/
101	022010	045	116	045	FRM14:	.ASCIZ /%N% DRIVE STATUS: %06%/
102	022037	045	116	045	FRM15:	.ASCIZ /%N%ACAN'T FIND BAD SECTOR FILE/
103	022076	045	101	101	FRM16:	.ASCIZ /%A%ADJACENT WRITTEN BY CONTROLLER: %06% DRIVE: %01%N/
104	022163	045	101	105	FRM17:	.ASCIZ /%A%EXP'D: %06% REC'D: %06%N/
105	022217	045	116	045	FRM18:	.ASCIZ /%N%UNLOAD AND WRITE ENABLE ALL DRIVES TO BE USED%N/
106	022303	045	116	045	FRM19:	.ASCIZ /%N%ADRIIVE TYPE IS DIFFERNT.%N/
107	022341	045	116	045	FRM20:	.ASCIZ /%N%ADRIIVE NUMBER PREVIOUSLY SPECIFIED.%N/
108	022412	045	116	045	ENDPAS:	.ASCIZ /%N% END OF TEST%N%N/
109						
113					.EVEN	
114						
115	022440				ENDMOD	
116						

```

1
2
3
4 022440      ;LOAD PROTECTION TABLE
5              BGNPROT
6 022440      .WORD      0          ;OFFSET OF CSR IN P-TABLE
7 022442      .WORD     -1          ;NOT A MASS-BUS DRIVE
8 022444      .WORD      6          ;OFFSET OF DRIVE IN P-TABLE
9
10 022446     ENDPROT
11
12
13 022446     BGNMOD  HPTCODE
14 022446     BGNHW
15 022446     000005      .WORD    L10007-L$HW/2
16 022450     174400      .WORD    174400      ;BASE ADDRESS DEFAULT
17 022452     000160      .WORD    160          ;VECTOR DEFAULT
18 022454     000240      .WORD    240          ;PRIORITY DEFAULT
19 022456     000001      .WORD     1          ;RL01 OR RL02 (RL01=1)
20 022460     000000      .WORD     0          ;DRIVE NUMBER DEFAULT
21 022462     ENDPHW
22 022462     L10007:
23
24
25 022462     BGNMOD  DSPCODE
26
27 022462     DISPATCH  1
28 022462     000001      .WORD     1
29 022464     032706      .WORD    T1
30
31
    ENDMOD
    ENDMOD
    
```

```

1          .SBTTL INITIALIZATION SECTION
2
3          022466      BGNMOD  INITCODE
4
5          022466      BGNINIT
6
7          022466      SETPRI  #340
          022466      MOV      #340,R0
          022472      TRAP    C$SPRI
8
9          022474      023727  002012  000002      CMP      LSUNIT,#2      ;MORE THAN TWO
10         022502      002006      BGE      90$      ;YES, OKAY
11
12         022504      ERRSF   19,FEW      ;MINIMUM OFF TWO DRIVE REQUIRED
          022504      TRAP    C$ERSF
          022506      .WORD  19
          022510      .WORD  FEW
          022512      .WORD  0
13         022514      000137  024266      JMP      CMPENA      ;CLEAN CODE WHEN < 2 DRIVES
14
15         022520      023727  002012  000004  90$:  CMP      LSUNIT,#4      ;MORE THAN FOUR
16         022526      003406      BLE      91$      ;NO, OKAY
17
18         022530      ERRSF   20,MANY     ;MAXIMUM OF FOUR DRIVES ALLOWED
          022530      TRAP    C$ERSF
          022532      .WORD  20
          022534      .WORD  MANY
          022536      .WORD  0
19         022540      000137  024266      JMP      CMPENA      ;CLEAN CODE WHEN > 4 DRIVES
20
21         022544      013737  002012  003130  91$:  MOV      LSUNIT,UUT      ;GET NUMBER OF UNITS
22         022552      005001      CLR      R1              ;INIT P-TABLE
23         022554      012704  017240      MOV      #DRBUF,R4      ;SET UP DRIVE BUFFER
24         022560      012702  003046      MOV      #PATLST,R2     ;GET LIST OF PATTERNS
25         022564      005737  003130      1$:  TST      UUT              ;ANY P-TABLES LEFT?
26         022570      001513      BEQ     END              ;NO,GO TO END
27         022572      GPHARD  R1,R0      ;GET A P-TABLE
          022572      MOV      R1,R0
          022574      TRAP    C$GPHRD
28         022576      012064  000000      MOV      (R0)+,CSR(R4)  ;GET CSR
29         022602      012064  000002      MOV      (R0)+,VEC(R4)  ;GET VECTOR
30         022606      012064  000004      MOV      (R0)+,PRIOR(R4);GET BREAK LEVEL
31         022612      012037  003060      MOV      (R0)+,T.DRIVE  ;RL01/2 TYPE ... RL01=1
32         022616      011064  000004      MOV      (R0),DSB(R4)   ;GET DRIVE
33         022622      011264  000006      MOV      (R2),PAT(R4)
34         022626      005722      TST     (R2)+
35
36          ;TEST FOR DRIVES OF SAME TYPE AND NO REPEATED DRIVE NUMBERS
37
38         022630      023737  002012  003130      CMP      LSUNIT,UUT      ;SKIP TEST FOR FIRST DRIVE
39         022636      001462      BEQ     6$
40
41         022640      GPHARD  #0,R5      ;BASE ADDRESS OF FIRST P TABLE
          022640      MOV      #0,R0
          022644      TRAP    C$GPHRD
          022646      MOV      R0,R5
42
    
```


43	022650	023765	003060	000006		CMP	T.DRIVE,TYPDR(R5)		;CHECK DRIVE TYPE
44	022656	001423				BEQ	4\$		
45	022660					PRINTF	#FRM19		;PROMPT - DRIVE TYPE DIFFERNT ...
	022660	012746	022303			MOV	#FRM19,-(SP)		
	022664	012746	000001			MOV	#1,-(SP)		
	022670	010600				MOV	SP,R0		
	022672	104417				TRAP	C\$PNTF		
	022674	062706	000004			ADD	#4,SP		
46	022700					GMANIL	OPR001,OBUFF,1,YES		;PROMPY - CONTINUE TEST
47	022700	104443				TRAP	C\$GMAN		
	022702	000404				BR	10000\$		
	022704	017236				.WORD	OBUFF		
	022706	000130				.WORD	T\$CODE		
	022710	017302				.WORD	OPR001		
	022712	000001				.WORD	1		
	022714				10000\$:				
48	022714	005737	017236			TST	OBUFF		
49	022720	001002				BNE	4\$		
50	022722	000137	024266			JMP	CMPENA		;RETURN TO SUPERVISOR
51	022726	026465	000004	000010	4\$:	CMP	DSB(R4),DRBT(R5)		;CHECK DRIVE NUMBER
52	022734	001023				BNE	6\$		
53	022736					PRINTF	#FRM20		;PROMPT - DRIVE NUMBER ..
54	022736	012746	022341			MOV	#FRM20,-(SP)		
	022742	012746	000001			MOV	#1,-(SP)		
	022746	010600				MOV	SP,R0		
	022750	104417				TRAP	C\$PNTF		
	022752	062706	000004			ADD	#4,SP		
55	022756					GMANIL	OPR001,OBUFF,1,YES		;PROMPT - CONTINUE TEST
56	022756	104443				TRAP	C\$GMAN		
	022760	000404				BR	10001\$		
	022762	017236				.WORD	OBUFF		
	022764	000130				.WORD	T\$CODE		
	022766	017302				.WORD	OPR001		
	022770	000001				.WORD	1		
	022772				10001\$:				
57	022772	005737	017236			TST	OBUFF		
58	022776	001002				BNE	6\$		
59	023000	000137	024266			JMP	CMPENA		;RETURN TO SUPERVISOR
60	023004	005201			6\$:	INC	R1		;NEXT P TABLE
61	023006	005337	003130			DEC	UUT		;NEXT DRIVE
62	023012	062704	000010			ADD	#PAT+2,R4		
63	023016	000662				BR	1\$		
64	023020	013737	002012	003130	END:	MOV	LSUNIT,UUT		
65	023026	012704	017240			MOV	#DRBUF,R4		;GET BEGINNING OF BUFFER
66	023032	005037	003064			CLR	FADJ		;CLEAR ADJ. TEST FLAG
67	023036	005037	003062			CLR	FOUR		;CLEAR OVERWRITE FLAG
68	023042					READEP	#EF.PWR		
69	023042	012700	000034			MOV	#EF.PWR,R0		
	023046	104447				TRAP	C\$REFG		
70	023050					BNCOMPLETE	SETUP		
	023050	103010				BCC	SETUP		
71	023052					PRINTF	#FRM11		;PROMPT - PWR FAIL NOT SUPPORTED
	023052	012746	021611			MOV	#FRM11,-(SP)		

```

023056 012746 000001      MOV    #1,-(SP)
023062 010600              MOV    SP,R0
023064 104417              TRAP  C$PNTF
023066 062706 000004      ADD    #4,SP

72
73
74      :INITIALIZE ROUTINE
75      :WE ATTEMPT TO LOCATE 5 PERFECT ADJACENT TRACKS AT 5 SPOTS
76      :ACROSS THE PACK.
77      :THE 5 SPOTS ARE: (EACH SURFACE)
78      :
79      :OUTER - TRACK 0 - 16 (BOTH RL01 & RL02)
80      :INNER - TRACK 238 - 254 (RL01) OR 494 - 510 (RL02)
81      :MIDDLE - TRACK 120 - 136 (RL01) OR 248 - 264 (RL02)
82      :ONE QUARTER - TRACK 56 - 72 (RL01) OR 120 - 136 (RL02)
83      :THREE QUARTER - TRACK 184 - 200 (RL01) OR 376 - 392 (RL02)
84      :
85      :IF WE FIND ANY BAD SPOTS, WE WILL REPORT SO.....
86
87
88 023072 005237 003076      SETUP: INC    STFLG      ;INDICATE A START COMMAND
89 023076 012737 177777 003210  MOV    #-1,SERNM1
90 023104 012737 177777 003212  MOV    #-1,SERNM2
91 023112              1$: PRINTF  #FRM18      ;PROMPT - UNLOAD DRIVES TO BE USED
    023112 012746 022217      MOV    #FRM18,-(SP)
    023116 012746 000001      MOV    #1,-(SP)
    023122 010600              MOV    SP,R0
    023124 104417              TRAP  C$PNTF
    023126 062706 000004      ADD    #4,SP
92 023132              G$MANIL OPRO02,OBUFF,1, NO ;PROMPT - ABOVE CONDITIONS MET
    023132 104443              TRAP  C$G$MAN
    023134 000404              BR    10002$
    023136 017236              .WORD OBUFF
    023140 000120              .WORD T$CODE
    023142 017321              .WORD OPRO02
    023144 000001              .WORD 1
    023146              10002$:
93 023146 005737 017236      TST    OBUFF      ;NO - ASK AGAIN
94 023152 001757              BEQ    1$
95
96 023154 004537 032300      JSR    R5,LOAD    ;TELL OPERATOR TO LOAD
97 023160 004537 031526      JSR    R5,SERNUM ;GET SERIAL NUMBER
98 023164 004537 031002      JSR    R5,MERGE   ;MERGE BAD SECTOR FILES
99 023170 012701 002236      MOV    #OUT10,R1  ;INITIALIZE ALL TRACKS
100 023174 012700 000062      MOV    #50,R0
101 023200 012721 177777      3$: MOV    #177777,(R1)+
102 023204 005300              DEC    R0
103 023206 001374              BNE    3$
104
105 023210 004537 031230      JSR    R5,FNDTRK ;TRY TO FIND FIVE TRACKS
106 023214 000001              1
107 023216 000000              0      ;INWARD SEARCH
    ;TOP SURFACE
108
109 023220 000000 000020      .WORD 0,16.
110 023224 000000 000020      .WORD 0,16.
111
112 023230 005737 003160      TST    TRKFND    ;WAS SEARCH SUCCESSFUL???
```

113	023234	001005		BNE	5\$:YES
114							
115	023236			ERRHRD	10.,ERRFND,ERR1		:CAN'T FIND 5 ADJACENT TRACKS
	023236	104456		TRAP	C\$ERHRD		
	023240	000012		.WORD	10		
	023242	017743		.WORD	ERRFND		
	023244	020240		.WORD	ERR1		
116	023246	000404		BR	7\$		
117							
118	023250	012700	002236	5\$:	MOV	#OUT10,R0	:STORE AWAY TRACKS FOUND
119	023254	004537	031472		JSR	R5,FIXCYL	
120							
121	023260	004537	031230	7\$:	JSR	R5,FNDTRK	:TRY TO FIND FIVE TRACKS
122	023264	000001			1		:INWARD SEARCH
123	023266	000001			1		:BOTTOM SURFACE
124	023270	000000	000020		.WORD	0,16.	
125	023274	000000	000020		.WORD	0,16.	
126							
127	023300	005737	003160	TST	TRKFND		:WAS SEARCH SUCCESSFUL????
128	023304	001005		BNE	9\$:YES
129							
130	023306			ERRHRD	10.,ERRFND,ERR1		:CAN'T FIND 5 ADJACENT TRACKS
	023306	104456		TRAP	C\$ERHRD		
	023310	000012		.WORD	10		
	023312	017743		.WORD	ERRFND		
	023314	020240		.WORD	ERR1		
131	023316	000404		BR	10\$		
132							
133	023320	012700	002250	9\$:	MOV	#OUT11,R0	:STORE TRACKS AWAY
134	023324	004537	031472		JSR	R5,FIXCYL	
135	023330	004537	031230	10\$:	JSR	R5,FNDTRK	:FIND NEXT 5 TRACK
136	023334	177777			-1		:OUTWARD SEARCH
137	023336	000000			0		:TOP SURFACE
138	023340	000376	000356		.WORD	254.,238.	:TRACK RANGE
139	023344	000776	000756		.WORD	510.,494.	
140							
141	023350	005737	003160	TST	TRKFND		:WAS SEARCH SUCCESSFUL?
142	023354	001005		BNE	12\$:YES
143							
144	023356			ERRHRD	10.,ERRFND,ERR1		:CAN'T FIND 5 ADJACENT TRACKS
	023356	104456		TRAP	C\$ERHRD		
	023360	000012		.WORD	10		
	023362	017743		.WORD	ERRFND		
	023364	020240		.WORD	ERR1		
145	023366	000404		BR	14\$:SKIP
146							
147	023370	012700	002356	12\$:	MOV	#INN10,R0	:STORE AWAY TRACKS FOUND
148	023374	004537	031472		JSR	R5,FIXCYL	
149							
150	023400	004537	031230	14\$:	JSR	R5,FNDTRK	:NEXT SET
151	023404	177777			-1		:OUTWARD SEARCH
152	023406	000001			1		:BOTTOM SURFACE
153	023410	000376	000356		.WORD	254.,238.	
154	023414	000776	000756		.WORD	510.,494.	
155							
156	023420	005737	003160	TST	TRKFND		:SEARCH SUCCESSFUL?
157	023424	001005		BNE	16\$:YES

```

158
159 023426          ERRHRD 10.,ERRFND,ERR1      ;CAN'T FIND 5 ADJACENT TRACKS
      023426 104456 TRAP      C$ERHRD
      023430 000012 .WORD    10
      023432 017743 .WORD    ERRFND
      023434 020240 .WORD    ERR1
160 023436 000404 BR        18$
161
162 023440 012700 002370      16$: MOV    #INW11,R0      ;STORE AWAY TRACKS FOUND
163 023444 004537 031472      JSR    R5,FXCYL
164
165 023450 004537 031230      18$: JSR    R5,FNDTRK      ;NEXT SET
166 023454 000001          1      ;INWARD SEARCH
167 023456 000000          0      ;TOP SURFACE
168 023460 000176 000210      .WORD  126.,136.      ;TRACK RANGE
169 023464 000376 000410      .WORD  254.,264.
170
171 023470 005737 003160      TST    TRKFND          ;DID WE FIND A SET
172 023474 001020          BNE    20$            ;YES
173
174 023476 004537 031230      JSR    R5,FNDTRK      ;NEXT SET (OTHER SIDE)
175 023502 177777          -1     ;OUTWARD SEARCH
176 023504 000000          0      ;TOP SURFACE
177 023506 000202 000170      .WORD  130.,120.      ;TRACK RANGE
178 023512 000402 000370      .WORD  258.,248.
179 023516 005737 003160      TST    TRKFND          ;DID WE FIND A SET
180 023522 001005          BNE    20$            ;YES
181
182 023524          ERRHRD 10.,ERRFND,ERR1      ;CAN'T FIND 5 ADJACENT TRACKS
      023524 104456 TRAP      C$ERHRD
      023526 000012 .WORD    10
      023530 017743 .WORD    ERRFND
      023532 020240 .WORD    ERR1
183 023534 000404 BR        22$
184
185 023536 012700 002306      20$: MOV    #MID10,R0     ;STORE AWAY
186 023542 004537 031472      JSR    R5,FXCYL
187 023546 004537 031230      22$: JSR    R5,FNDTRK      ;NEXT SET
188 023552 000001          1      ;INWARD SEARCH
189 023554 000001          1      ;BOTTOM SURFACE
190 023556 000176 000210      .WORD  126.,136.      ;RANGE
191 023562 000376 000410      .WORD  254.,264.
192
193 023566 005737 003160      TST    TRKFND          ;SUCCESS?
194 023572 001020          BNE    24$            ;YES
195
196 023574 004537 031230      JSR    R5,FNDTRK      ;LOOK THE OTHER SIDE
197 023600 177777          -1     ;OUTWARD
198 023602 000001          1      ;BOTTOM SURFACE
199 023604 000202 000170      .WORD  130.,120.
200 023610 000402 000370      .WORD  258.,248.
201
202 023614 005737 003160      TST    TRKFND          ;SUCCESS?
203 023620 001005          BNE    24$            ;YES
204
205 023622          ERRHRD 10.,ERRFND,ERR1      ;CAN'T FIND 5 ADJACENT TRACKS
      023622 104456 TRAP      C$ERHRD

```

	023624	000012		.WORD	10	
	023626	017743		.WORD	ERRFND	
	023630	020240		.WORD	ERR1	
206	023632	000404		BR	26\$	
207						
208	023634	012700	002320	24\$: MOV	#MID11,RO	:STORE AWAY THE TRACKS FOUND
209	023640	004537	031472	JSR	R5,FXCYL	
210						
211	023644	004537	031230	26\$: JSR	R5,FNDTRK	:NEXT SET
212	023650	000001		1		:INWARD
213	023652	000000		0		:TOP SURFACE
214	023654	000076	000110	.WORD	62.,72.	:RANGE
215	023660	000176	000210	.WORD	126.,136.	
216						
217	023664	005737	003160	TST	TRKFND	:SUCCESS?
218	023670	001020		BNE	28\$:YES
219						
220	023672	004537	031230	JSR	R5,FNDTRK	:LOOK OTHER SIDE
221	023676	177777		-1		:OUTWARD
222	023700	000000		0		:TOP SURFACE
223	023702	000102	000070	.WORD	66.,56.	:RANGE
224	023706	000202	000170	.WORD	130.,120.	
225						
226	023712	005737	003160	TST	TRKFND	:SUCCESS?
227	023716	001005		BNE	28\$:YES
228						
229	023720			ERRHRD	10.,ERRFND,ERR1	:CAN'T FIND 5 ADJACENT TRACKS
	023720	104456		TRAP	C\$ERRHRD	
	023722	000012		.WORD	10	
	023724	017743		.WORD	ERRFND	
	023726	020240		.WORD	ERR1	
230	023730	000404		BR	30\$	
231						
232	023732	012700	002262	28\$: MOV	#OQU10,RO	:STORE AWAY NEXT SET
233	023736	004537	031472	JSR	R5,FXCYL	
234	023742	004537	031230	30\$: JSR	R5,FNDTRK	:LOOK FOR NEXT SET
235	023746	000001		1		:INWARD
236	023750	000001		1		:BOTTOM
237	023752	000076	000110	.WORD	62.,72.	:RANGE
238	023756	000176	000210	.WORD	126.,136.	
239						
240	023762	005737	003160	TST	TRKFND	:SUCCESS?
241	023766	001020		BNE	32\$:YES
242						
243	023770	004537	031230	JSR	R5,FNDTRK	:LOOK FOR ANOTHER SET
244	023774	177777		-1		:OUTWARD
245	023776	000001		1		:BOTTOM
246	024000	000102	000070	.WORD	66.,56.	:RANGE
247	024004	000202	000170	.WORD	130.,120.	
248						
249	024010	005737	003160	TST	TRKFND	:SUCCESS?
250	024014	001005		BNE	32\$:YES
251						
252	024016			ERRHRD	10.,ERRFND,ERR1	:CAN'T FIND 5 ADJACENT TRACKS
	024016	104456		TRAP	C\$ERRHRD	
	024020	000012		.WORD	10	
	024022	017743		.WORD	ERRFND	

253	024024	020240		.WORD	ERR1	
254	024026	000404		BR	34\$	
255	024030	012700	002274	32\$:	MOV	#00U11,RO
256	024034	004537	031472		JSR	R5,FXCYL
257						;STORE AWAY TRACKS
258	024040	004537	031230	34\$:	JSR	R5,FNDTRK
259	024044	000001			1	;NEXT SET OF TRACKS
260	024046	000000			0	;INWARD
261	024050	000276	000310		.WORD	190.,200.
262	024054	000576	000610		.WORD	382.,392.
263						;TOP SURFACE
264	024060	005737	003160		TST	TRKFND
265	024064	001020			BNE	36\$
266						;SUCCESS?
267	024066	004537	031230		JSR	R5,FNDTRK
268	024072	177777			-1	;LOOK OTHER SIDE
269	024074	000000			0	;OUTWARD SEARCH
270	024076	000302	000270		.WORD	194.,184.
271	024102	000602	000570		.WORD	386.,376.
272						;TOP
273	024106	005737	003160		TST	TRKFND
274	024112	001005			BNE	36\$
275						;SUCCESS
276	024114				ERRHRD	10.,ERRFND,ERR1
	024114	104456			TRAP	C\$ERHRD
	024116	000012			.WORD	10
	024120	017743			.WORD	ERRFND
	024122	020240			.WORD	ERR1
277	024124	000404			BR	38\$
278						;CAN'T FIND 5 ADJACENT TRACKS
279	024126	012700	002332	36\$:	MOV	#TQU10,RO
280	024132	004537	031472		JSR	R5,FXCYL
281	024136	004537	031230	38\$:	JSR	R5,FNDTRK
282	024142	000001			1	;NEXT SET
283	024144	000001			1	;INWARD
284	024146	000276	000310		.WORD	190.,200.
285	024152	000576	000610		.WORD	382.,392.
286						;BOTTOM SURFACE
287	024156	005737	003160		TST	TRKFND
288	024162	001020			BNE	40\$
289						;SUCCESS?
290	024164	004537	031230		JSR	R5,FNDTRK
291	024170	177777			-1	;OTHER SET
292	024172	000001			1	;OUTWARD
293	024174	000302	000270		.WORD	194.,184.
294	024200	000602	000570		.WORD	386.,376.
295						;BOTTOM SURFACE
296	024204	005737	003160		TST	TRKFND
297	024210	001005			BNE	40\$
298						;SUCCESS
299	024212				ERRHRD	10.,ERRFND,ERR1
	024212	104456			TRAP	C\$ERHRD
	024214	000012			.WORD	10
	024216	017743			.WORD	ERRFND
	024220	020240			.WORD	ERR1
300	024222	000404			BR	42\$

301						
302	024224	012700	002344	40\$:	MOV	#TOU11,RO
303	024230	004537	031472		JSR	R5,FIXCYL
304						
305	024234	012700	002236	42\$:	MOV	#OUT10,RO
306	024240	012701	000062		MOV	#50.,R1
307	024244	022720	177777	44\$:	CMP	#-1,(RO)+
308	024250	001017			BNE	EXIT
309	024252	005301			DEC	R1
310	024254	001373			BNE	44\$
311	024256				ERRSF	3.,NONE
	024256	104454			TRAP	C\$ERSF
	024260	000003			.WORD	3
	024262	017571			.WORD	NONE
	024264	000000			.WORD	0
312	024266	005001		CMPENA:	CLR	R1
313	024270	013700	002012		MOV	L\$UNIT,RO
314	024274			48\$:	DODU	R1
	024274	010100			MOV	R1,RO
	024276	104451			TRAP	C\$DODU
315	024300	005201			INC	R1
316	024302	005300			DEC	RO
317	024304	001373			BNE	48\$
318	024306				DOCLN	
	024306	104444			TRAP	C\$DCLN
319						
320	024310			EXIT:		
321	024310			L10010:	ENDINIT	
	024310					
	024310	104411			TRAP	C\$INIT
322	024312				ENDMOD	
323						

;STORE SET AWAY

;DID WE FIND ANY AT ALL

;DO DROP UNIT

1				
2	024312	BGNMOD	AUTOCODE	;AUTO DROP SECTION
3	024312	BGNAUTO		
4				
5	024312		NOP	;DO NOTHING
6				
7	024314	ENDAUTO		
	024314	L10011:		
	024314		TRAP	C\$AUTO
8	024316	ENDMOD		
9				
10				
11	024316	BGNMOD	CLNCODE	
12	024316		BGNCLN	
13				
14	024316		NOP	
15				
16	024320		ENDCLN	
	024320	L10012:		
	024320		TRAP	C\$CLEAN
17	024322	ENDMOD		
18				
19	024322	BGNMOD	DRPCODE	
20	024322		BGNDU	
21	024322		NOP	
22	024324		ENDDU	
	024324	L10013:		
	024324		TRAP	C\$DU
23	024326	ENDMOD		
24				
25				
26				


```

1          .SBTTL GLOBAL SUBROUTINES SECTION
2
3 024326   BGMMOD GLBSUB
4
5          :
6          :TIMING ROUTINES
7
8          :CALL 1:      JSR      PC,TIME
9
10         :CALL 2:      JSR      PC,XTIME
11
12
13 024326  012737  000160  002116  TIME:  MOV      #160, LSDLY      :GET OUTER DELAY LOOP
14 024334  005437  017232                NEG      XDELAY          :GET NEGATIVE OF MULTIPLY FACTOR
15 024340                READBUS                :Q-BUS?
16 024340  104407                TRAP     CSRDBU
17 024342  103420                BCOMPLETE 2$           :BRANCH - IF YES
18 024344                BCS      2$
19 024344  012727  000001  1$:      DELAY 1           :WAIT
20 024350  000000                MOV      #1, (PC)+
21 024352  013727  002116                .WORD   0
22 024356  000000                MOV      LSDLY, (PC)+
23 024360  005367  177772                .WORD   0
24 024364  001375                DEC      -6(PC)
25 024366  005367  177756                BNE     -4
26 024372  001367                DEC     -22(PC)
27 024374  005237  017232                BNE     -20
28 024400  002761                INC     XDELAY          :WAIT FACTOR EXPIRED?
29 024402  000422                BLT     1$             :BRANCH - IF NO
30 024404  012737  000150  002116  2$:      BR      4$
31 024412  012727  000001  3$:      MOV      #150, LSDLY  :GET OUTER DELAY LOOP
32 024416  000000                DELAY 1           :WAIT WITH RESPECT TO FONZ BUS
33 024420  013727  002116                MOV      #1, (PC)+
34 024424  000000                .WORD   0
35 024426  005367  177772                MOV      LSDLY, (PC)+
36 024432  001375                DEC     -6(PC)
37 024434  005367  177756                BNE     -4
38 024440  001367                DEC     -22(PC)
39 024442  005237  017232                BNE     -20
40 024446  002761                INC     XDELAY          :WAIT FACTOR EXPIRED?
41 024450  000207                BLT     3$             :BRANCH - IF NO
42
43 024452  012737  000160  002116  4$:      RTS      PC           :RETURN
44
45 024452  012737  000160  002116  XTIME: MOV      #160, LSDLY  :GET OUTER DELAY LOOP
46 024460  006337  017234                ASL     YDELAY          :MULTIPLY FACTOR BY 4
47 024464  006337  017234                ASL     YDELAY
48 024470  005437  017234                NEG     YDELAY
49 024474                READBUS                :
50 024474  104407                TRAP     CSRDBU        :GET NEGATIVE OF RESULT
51 024476                BCOMPLETE 1$           :Q-BUS?
52 024476  103023                BCC     1$             :BRANCH - IF NO
53 024500  012737  000150  002116  2$:      MOV      #150, LSDLY  :GET OUTER DELAY LOOP
54 024506  012727  000020                DELAY 20           :WAIT WITH RESPECT TO FONZ BUS
55 024506  012727  000020                MOV      #20, (PC)+
56 024512  000000                .WORD   0
57 024514  013727  002116                MOV      LSDLY, (PC)+
    
```

	024520	000000		.WORD	0	
	024522	005367	177772	DEC	-6(PC)	
	024526	001375		BNE	.-4	
	024530	005367	177756	DEC	-22(PC)	
	024534	001367		BNE	.-20	
35	024536	005237	017234	INC	YDELAY	:WAIT FACTOR EXPIRED?
36	024542	002761		BLT	2\$:BRANCH - IF NO
37	024544	000417		BR	3\$:EXIT
38	024546			DELAY	50	:WAIT
	024546	012727	000050	MOV	#50,(PC)+	
	024552	000000		.WORD	0	
	024554	013727	002116	MOV	LSDLY,(PC)+	
	024560	000000		.WORD	0	
	024562	005367	177772	DEC	-6(PC)	
	024566	001375		BNE	.-4	
	024570	005367	177756	DEC	-22(PC)	
	024574	001367		BNE	.-20	
39	024576	005237	017234	INC	YDELAY	:WAIT FACTOR EXPIRED?
40	024602	002761		BLT	1\$:BRANCH - IF NO
41	024604	000207		RTS	PC	:RETURN
42						
43						

```

1
2
3
4
5
6
7 024606 010046      ;ROUTINE TO PERFORM OVERWRITE
8 024610 010146      ;CALL: JSR R5,OVWPER
9 024612 010246      ;SECTORS TO WRITE FORWARD
10 024614 010346     ;SECTORS TO WRITE REVERSE
11 024616 005000
12 024620 012537 003126
13 024624 012537 003124
14
15 024630 012701 003022
16 024634 011102
17 024636 021227 177777
18 024642 001500
19
20 024644 005037 003122
21 024650 005037 003120
22 024654 020027 000005
23 024660 002402
24 024662 005237 003120
25 024666 004537 026254
26 024672 005037 003122
27 024676 051237 003122
28 024702 004537 026254
29 024706 013703 003126
30 024712 004537 025070
31 024716 000034
32 024720 012737 020116 003116
33 024726 004537 027200
34 024732 004537 027564
35 024736 005037 003122
36 024742 022737 000001 003060
37 024750 001004
38 024752 052737 000377 003122
39 024760 000403
40 024762 052737 000777 003122 50$:
41 024770 004537 026254 51$:
42 024774 005037 003122
43 025000 005037 003120
44 025004 051237 003122
45 025010 004537 026254
46
47 025014 013703 003124
48 025020 004537 025070
49 025024 000034
50 025026 012737 020126 003116
51 025034 004537 027200
52 025040 004537 027564
53
54 025044 005721 3$:
55 025046 005200
56 025050 020027 000012
57 025054 001267
    
```

```
58  
59 025056 012603      MOV      (SP)+,R3      ;RESTORE REG.  
60 025060 012602      MOV      (SP)+,R2  
61 025062 012601      MOV      (SP)+,R1  
62 025064 012600      MOV      (SP)+,R0  
63 025066 000205      RTS      R5           ;EXIT
```

```

1      :ROUTINE TO WRITE SECTORS
2      :USED IN OVERWRITE TEST;ADJACENT CYLINDER TEST
3      :CALL JSR R5,WRSEC
4      :
5      :WRD :STARTING SECTOR
6      :R3 HAS BITMAP OF SECTORS TO WRITE
7      :R4 HAS DRIVE BUFFER POINTER
8 025070 010046 WRSEC: MOV R0,-(SP) :SAVE R0
9 025072 010146 MOV R1,-(SP) :SAVE R1
10 025074 010246 MOV R2,-(SP) :SAVE R2
11 025076 012701 003232 MOV #BUF,R1 :WRITE PATTERN INTO
12 025102 012702 000200 MOV #128,R2 :MEMORY THAT WE
13 025106 016421 000006 2$: MOV PAT(R4),(R1)+ :WILL WRITE ONTO
14 025112 005302 DEC R2 :PACK FOR THIS
15 025114 001374 BNE 2$ :DRIVE
16 025116 012701 100000 MOV #100000,R1 :MASK FOR BIT MAP
17 025122 012737 000007 003056 MOV #7,TEM
18 025130 053702 003122 BIS CYL,R2
19 025134 006302 120$: ASL R2
20 025136 005337 003056 DEC TEM
21 025142 001374 BNE 120$
22 025144 005737 003120 TST SURF
23 025150 001402 BEQ 3$
24 025152 052702 000100 BIS #HEAD,R2 :0, SKIP
25 025156 052502 3$: BIS (R5)+,R2 :SET BOTTOM HEAD
26 025160 030103 4$: BIT R1,R3 :START AT SECTOR 28.
27 025162 001452 BEQ 5$ :WRITE THIS SECTOR?
28 :NO
29 025164 005037 003110 CLR HSFLG
30 025170 012737 177600 003206 MOV #-128,BMP :LOAD WORD COUNT
31 025176 010237 003204 MOV R2,BDA :LOAD DISK ADDRESS
32 025202 010237 003066 MOV R2,TEMP :SAVE DISK ADDRESS
33 025206 042702 177700 BIC #177700,R2
34 025212 020227 000047 CMP R2,#39.
35 025216 003403 BLE 6$
36 025220 162737 000050 003204 SUB #40,BDA
37 025226 012737 003232 003202 6$: MOV #BUF,BBA :LOAD BUS ADDRESS
38 025234 013702 003066 MOV TEMP,R2 :RESTORE DISK ADDRESS
39 025240 004537 032404 11$: JSR R5,LDFUNC :GO WRITE
40 025244 000012 WRITE
41 025246 005737 003074 TST ERFLG :ERROR IN WRITING
42 025252 001416 BEQ 5$ :NO,OKAY
43 025254 005737 003110 TST HSFLG
44 025260 001007 BNE 10$
45 025262 ERRSOFT 100.,WRIT1,ERR2
025262 104457 TRAP C$ERRSOFT
025264 000144 .WORD 100
025266 020136 .WORD WRIT1
025270 020276 .WORD ERR2
46 025272 005237 003110 INC HSFLG
47 025276 000760 BR 11$
48 025300 10$: ERRHRD 110.,WRIT1,ERR2
025300 104456 TRAP C$ERRHRD
025302 000156 .WORD 110
025304 020136 .WORD WRIT1
025306 020276 .WORD ERR2
49
    
```

```
50 025310 005202          58:   INC   R2           :NEXT SECTOR
51 025312 000241          CLC           :CLEAR CARRY BIT
52 025314 006001          ROR    R1           :DONE?
53 025316 103320          BCC   4$           :NO GO BACK
54 025320 012602          MOV   (SP)+,R2     :RESTORE REGISTERS AND EXIT
55 025322 012601          MOV   (SP)+,R1
56 025324 012600          MOV   (SP)+,R0
57 025326 000205          RTS    R5
```

1	025330	005037	003214		ADJCYL: CLR	ADJTRK	:INSIDE/OUTSIDE TRACK FLAG
2	025334	005037	003114		CLR	HEAD01	:INIT TO TOP SURFACE
3	025340	012737	000001	003216	MOV	#1,ADJUUT	:START OF TRACK LIST
4	025346	012701	002236		21\$: MOV	#OUT10,R1	:
5	025352	012537	003100		20\$: MOV	(R5)+,ADJLOC	:PICK UP TRACK OFFSET
6	025356	001003			BNE	1\$:IS THERE ONE?
7	025360	005037	003104		CLR	ADJDIR	
8	025364	000205			RTS	R5	:NO EXIT
9	025366	012537	003220		1\$: MOV	(R5)+,ADJLC2	:YES, GET REST OF INFO
10	025372	012537	003222		MOV	(R5)+,ADJLC3	
11	025376	012537	003224		MOV	(R5)+,ADJLC4	
12	025402	113700	003100		2\$: MOVB	ADJLOC,R0	:GET OFFSET
13	025406	012737	000020	003230	MOV	#16.,STSEC	:STARTING SECTOR IS 16
14							
15	025414	010102			MOV	R1,R2	:GET START INTO R2
16							
17	025416	005300			3\$: DEC	R0	:DOWN COUNT OFFSET
18	025420	001414			BEQ	4\$:FOUND IT?
19							
20	025422	005722			TST	(R2)+	:INDEX (R2)
21	025424	062737	000042	003230	ADD	#34.,STSEC	:NO, NEXT SECTOR
22	025432	022737	000050	003230	CMP	#40.,STSEC	
23	025440	003366			BGT	3\$	
24	025442	162737	000050	003230	SUB	#40.,STSEC	
25	025450	000762			BR	3\$:BACK FOR NEXT
26							
27	025452	021227	177777		4\$: CMP	(R2),#-1	:LEGAL TRACK?
28	025456	001002			BNE	5\$:YES, CONTINUE
29							
30	025460	000137	026126		JMP	13\$:NO PICK UP NEXT SET
31							
32	025464	005037	003120		5\$: CLR	SURF	:SET UP FOR OUTER TRACK
33	025470	005037	003122		CLR	CYL	
34							
35	025474	005737	003114		TST	HEAD01	:WHICH HEAD?
36	025500	001403			BEQ	6\$:TOP, SKIP
37							
38	025502	052737	000001	003120	BIS	#1,SURF	:LOWER HEAD, SET IT!
39							
40	025510	004537	026254		6\$: JSR	R5,SKCYL	:SEEK TO OUTER TRACK
41							
42	025514	011237	003122		MOV	(R2),CYL	:GET DESIRED TRACK
43							
44	025520	004537	026254		JSR	R5,SKCYL	:SEEK TO IT
45	025524	012737	020116	003116	MOV	#FWD,DIRC	:SEEK DIRECTION
46	025532	113703	003101		MOVB	ADJLOC+1,R3	:GET SECTORS TO WRITE
47	025536	000303			SWAB	R3	:ALIGN IT
48	025540	042703	000377		BIC	#377,R3	:CLEAR OUT HIGH BYTE
49							
50	025544	022737	000047	003230	CMP	#39.,STSEC	:OVER FORTY?
51	025552	002003			BGE	7\$:NO, CONTINUE
52							
53	025554	162737	000050	003230	SUB	#40.,STSEC	:YES BACK IT UP
54	025562	013737	003230	025574	7\$: MOV	STSEC,8\$:STARTING SECTOR
55							
56	025570	004537	025070		JSR	R5,WRSEC	:WRITE SECTORS
57	025574	000000			8\$: .WORD	0	

58	025576	013737	025574	025610	MOV	R5,108\$	
59	025604	004537	030112		JSR	R5,VAJWR	:VERIFY THIS WRITE
60	025610	000000			.WORD	0	
61	025612	013737	025610	025624	108\$:	MOV	108\$,208\$
62	025620	004537	030356		JSR	R5,BSVWR	
63	025624	000000			208\$:	.WORD	0
64	025626	013737	003230	003226	MOV	STSEC,STSEC1	:GET OTHER SECTORS TO WRITE
65	025634	062737	000010	003226	ADD	#8.,STSEC1	:8 SECTORS GONE BY
66	025642	022737	000047	003226	CMP	#39.,STSEC1	:GONE PAST 40?
67	025650	002003			BGE	9\$:NO, OKAY
68							
69	025652	162737	000050	003226	SUB	#40.,STSEC1	:YES BACK IT UP
70							
71	025660	013703	003220		9\$:	MOV	ADJLC2,R3
72							:GET SECTORS TO WRITE
73	025664	013737	003226	025676	MOV	STSEC1,10\$:STARTING SECTORS
74							
75	025672	004537	025070		JSR	R5,WRSEC	:WRITE SECTORS
76	025676	000000			10\$:	.WORD	0
77	025700	013737	025676	025712	MOV	10\$,110\$	
78	025706	004537	030112		JSR	R5,VAJWR	:VERIFY THIS WRITE
79	025712	000000			110\$:	.WORD	0
80	025714	013737	025712	025726	MOV	110\$,210\$	
81	025722	004537	030356		JSR	R5,BSVWR	:VERIFY ADJ CYL + 1
82	025726	000000			210\$:	.WORD	0
83	025730	022737	000001	003060	CMP	#1,T.DRIVE	
84	025736	001004			BNE	77\$	
85	025740	012737	000377	003122	MOV	#377,CYL	
86	025746	000403			BR	88\$	
87							
88	025750	012737	000777	003122	77\$:	MOV	#777,CYL
89							
90	025756	004537	026254		88\$:	JSR	R5,SKCYL
91							
92	025762	011237	003122		MOV	(R2),CYL	:SEEK BACK TO PROPER TRACK
93							
94	025766	004537	026254		JSR	R5,SKCYL	:SEEK TO PROPER CYLINDER
95	025772	012737	020126	003116	MOV	#REV,DIRC	:SEEK DIRECTION
96	026000	113703	003223		MOV	ADJLC3+1,R3	:GET SECTORS TO WRITE
97							
98	026004	000303			SWAB	R3	:ALIGN IT
99	026006	042703	000377		BIC	#377,R3	:CLEAR OUT HIGH BYTE
100	026012	013737	003230	026024	MOV	STSEC,11\$	
101							
102	026020	004537	025070		JSR	R5,WRSEC	:WRITE PROPER SECTOR
103	026024	000000			11\$:	.WORD	0
104							
105	026026	013737	026024	026040	MOV	11\$,111\$	
106	026034	004537	030112		JSR	R5,VAJWR	:VERIFY THIS WRITE
107	026040	000000			111\$:	.WORD	0
108	026042	013737	026040	026054	MOV	111\$,211\$	
109	026050	004537	030356		JSR	R5,BSVWR	
110	026054	000000			211\$:	.WORD	0
111	026056	013703	003224		MOV	ADJLC4,R3	:GET SECTORS
112	026062	013737	003226	026074	MOV	STSEC1,12\$:GET SECTORS TO WRITE
113							
114	026070	004537	025070		JSR	R5,WRSEC	:WRITE PROPER SECTORS


```

115 026074 000000          12$: .WORD 0
116
117
118 026076 013737 026074 026110      MOV    12$,112$
119 026104 004537 030112      JSR    R5,VAJWR      ;VERIFY THIS WRITE
120 026110 000000          112$: .WORD 0
121
122
123 026112 013737 026110 026124      MOV    112$,212$
124 026120 004537 030356      JSR    R5,BSVWR      ;VERIFY ADJ CYLINDERS + 1
125 026124 000000          212$: .WORD 0
126
127
128 026126 005737 003114          13$:  TST    HEAD01      ;WHICH HEAD WERE WE DOING?
129 026132 001003          BNE    14$
130 026134 005237 003114          INC    HEAD01
131 026140 000402          BR     99$
132 026142 005037 003114          14$:  CLR    HEAD01      ;NEXT SET OF TRACKS
133 026146 062701 000012          99$:  ADD    #10.,R1      ;NEXT SET OF TRACKS
134 026152 020127 002400          CMP    R1,#INNS1     ;END OF LIST
135 026156 002002          BGE    18$           ;END OF TRACK LIST
136 026160 000137 025402          JMP    2$           ;NO GO BACK
137
138          ;AT END OF TRACK LIST NEXT GROUP OF WRITES
139
140 026164 005737 003064          18$:  TST    FADJ
141 026170 001403          BEQ    15$           ;FIRST SET?
142 026172 005037 003064          CLR    FADJ         ;NO, CONTINUE
143 026176 000421          BR     17$         ;YES, CLEAR FIRST
144 026200 005737 003214          15$:  TST    ADJTRK      ;DONE BOTH INSIDE OUTSIDE
145 026204 001004          BNE    16$         ;TRACKS, YES 16$
146 026206 005237 003214          INC    ADJTRK      ;NO, SET INSIDE FLAG
147 026212 000137 025346          JMP    21$         ;GO DO INSIDE TRACK
148 026216 005037 003214          16$:  CLR    ADJTRK      ;BACK TO OUTSIDE TRACK
149 026222 005237 003216          INC    ADJUUT      ;DONE WITH ANOTHER
150 026226 023737 003216 003130      CMP    ADJUUT,UUT   ;DONE TABLE FOR ALL UUT?
151 026234 001402          BEQ    17$         ;YES, FOR EXIT
152 026236 000137 025346          JMP    21$         ;NO, GO BACK FOR NEXT
153 026242 005725          17$:  TST    (R5)+      ;BUMP EXIT TO END OF
154 026244 001376          BNE    17$         ;TABLE FOR PROPER RETURN
155 026246 005037 003104          CLR    ADJDIR
156 026252 000205          RTS    R5          ;EXIT
    
```

```

1          :ROUTINE TO SEEK TO A DESIRED CYLINDER
2          :CALL: JSR      R5,SKCYL
3          :ROUTINE HAS DESIRED CYLINDER IN LOC "CYL"
4          :
5          :
6 026254 010146          SKCYL: MOV      R1,-(SP)          :SAVE R1
7 026256 004537 032404 90$: JSR      R5,LDFUNC          :GET PRESENT POSITION
8 026262 000010          RDHDR
9
10 026264 005737 003074          TST      ERFLG          :ERROR FLAG SET
11 026270 001104          BNE      5$          :YES, SKIP
12
13 026272 005001          CLR      R1
14 026274 012737 000007 003056  MOV     #7,TEM
15 026302 053701 003122          BIS     CYL,R1          :GET THE SELECTED CYLINDER NUMBER
16
17 026306 006301          120$: ASL     R1
18 026310 005337 003056          DEC     TEM
19 026314 001374          BNE     120$
20 026316 042737 000177 003172  BIC     #177,E.MP
21 026324 163701 003172          SUB     E.MP,R1          :CALCULATE DIFFERENCE WORD
22 026330 103002          BCC     1$          :IF POSITIVE SET DIRECTION
23 026332 005401          NEG     R1          :NEGATE
24 026334 000402          BR     2$          :SKIP SETTING DIRECTION
25 026336 052701 000004 1$: BIS     #SIGN,R1          :SET FOR FORWARD SEEK
26 026342 052701 000001 2$: BIS     #MK,R1          :SET MARKER BIT
27 026346 005737 003120          TST     SURF
28 026352 001402          BEQ    3$          :TOP
29 026354 052701 000020          BIS     #SKHS,R1        :BOTTOM
30 026360 010137 003204 3$: MOV     R1,BDA          :LOAD DIFFERENCE WORD
31 026364 004537 032404          JSR     R5,LDFUNC        :EXECUTE SEEK
32 026370 000006          SEEK
33
34 026372 005737 003074          TST     ERFLG          :ERROR?
35 026376 001041          BNE     5$          :YES, SKIP
36
37 026400 004537 032404          JSR     R5,LDFUNC        :VERIFY POSITION?
38 026404 000010          RDHDR
39 026406 005737 003074          TST     ERFLG
40 026412 001033          BNE     5$
41 026414 042737 000077 003172  BIC     #77,E.MP          :VERIFY POSITION
42 026422 005001          CLR     R1
43 026424 012737 000007 003056  MOV     #7,TEM
44 026432 053701 003122          BIS     CYL,R1
45 026436 006301          220$: ASL     R1
46 026440 005337 003056          DEC     TEM
47 026444 001374          BNE     220$
48 026446 005737 003120          TST     SURF
49 026452 001402          BEQ    4$          :
50 026454 052701 000100          BIS     #HEAD,R1
51 026460 020137 003172 4$: CMP     R1,E.MP
52 026464 001414          BEQ
53
54 026466          ERRDF 12,SKER,ERR6 :MIS SEEK ERROR
    026466          TRAP  C$ERRDF
    026470          .WORD 12
    026472          .WORD SKER
    
```

55	026474	020704		.WORD	ERR6		
56	026476	000137	026256	JMP	90\$		
57	026502			58:	ERRDF	13.	FUNERR,ERR5 ;ERROR IN SEEK OPERATION
	026502	104455			TRAP	C\$ERDF	
	026504	000015			.WORD	13	
	026506	020047			.WORD	FUNERR	
	026510	020644			.WORD	ERR5	
58	026512	000137	026256		JMP	90\$	
59	026516	012601		68:	MOV	(SP)+,R1	:CANT GET THERE
60	026520	000205			RTS	R5	:EXIT

```

1
2
3
4 026522          ;ROUTINE TO PERFORM REGISTER PRINTOUT DUMP
    026522 013746 003206 ;CALL: JSR PC,REGDMP
    026526 013746 003204
    026532 013746 003202
    026536 013746 003200
    026542 012746 021646
    026546 012746 000005
    026552 010600
    026554 104414
    026556 062706 000014
5
6 026562          ;PROMPT - BEFORE CS: _ BA: _ DA: _ MP: _
    026562 013746 003172 PRINTB #FRM12,BCS,BBA,BDA,BMP
    026566 013746 003170 MOV BMP,-(SP)
    026572 013746 003166 MOV BDA,-(SP)
    026576 013746 003164 MOV BBA,-(SP)
    026602 012746 021725 MOV BCS,-(SP)
    026606 012746 000005 MOV #FRM12,-(SP)
    026612 010600 MOV #5,-(SP)
    026614 104414 MOV SP,R0
    026616 062706 000014 TRAP C$PNTB
7 026622 032737 040000 003164 ADD #14,SP
8 026630 001437 BIT #BIT14,E.CS
9 026632 016403 000000 BEQ 1$
10 026636 012763 000013 000004 MOV CSR(R4),R3
11 026644 012737 000004 003200 MOV #13,DA(R3)
12 026652 056437 000004 003200 MOV #4,BCS
13 026660 013763 003200 000000 BIS DSB(R4),BCS
14 026666 032763 000200 000000 MOV BCS,CS(R3)
15 026674 001774 BEQ 2$
16 026676 016337 000006 003106 MOV MP(R3),DRSTAT
17 026704          ;PROMPT - DRIVE STATUS
    026704 013746 003106 PRINTB #FRM14,DRSTAT
    026710 012746 022010 MOV DRSTAT,-(SP)
    026714 012746 000002 MOV #FRM14,-(SP)
    026720 010600 MOV #2,-(SP)
    026722 104414 MOV SP,R0
    026724 062706 000006 TRAP C$PNTB
18 026730 000207 1$: ADD #6,SP
19          RTS PC
    
```

```

1          ;ROUTINE TO STORE OR RETRIEVE ADJACENT CYLINDER SECTOR DRIVE
2          ;INFORMATION FROM THE 24X5 "SECLST" BUFFER.
3          ;ENTER WITH R0 = SECTOR REQUEST
4          ;EXIT WITH R0 = ADJACENT CYLINDER DRIVE INFORMATION FOR SECTOR
5          ;EXIT WITH R0 = 0 IF SECTOR REQUESTED IS NOT IN BUFFER MAP
6          ;CALL 1:      JSR R5,RSADJS
7          ;              .WORD 0          ;RETRIEVE SECTOR INFO.
8          ;CALL 2:      JSR R5,RSADJS
9          ;              .WORD 1          ;STORE SECTOR INFO.
10         RSADJS: MOV   R1,-(SP)
11         MOV   R2,-(SP)
12         MOV   R3,-(SP)
13         BIC   #177700,R0          ;SAVE SECTOR BITS
14         MOV   (R5)+,ADJFLG        ;SAVE RETRIEVE/STORE FLAG
15         MOV   #1,R1              ;START WITH TRACK (N-2)
16         MOV   #SECBUF,R2         ;START OF 24X5 BUFFER
17         MOV   #16,R3            ;SECTOR 16 START FOR (N-2) TRACK
18         1$:  CMPB  ADJLOC,R1      ;CHECK TRACK INDEX
19         BEQ   2$
20         INC   R1                ;INDEX TRACK REFERENCE
21         ADD   #48,R2            ;UPDATE BUFFER TO NEXT TRACK REF.
22         ADD   #34,R3            ;UPDATE SECTOR START FOR NEXT TRACK
23         CMP   R3,#40.
24         BLT   1$
25         SUB   #40.,R3
26         BR   1$
27         2$:  MOV   #24.,R1        ;SET COUNTER FOR 24 SECTORS
28         3$:  CMP   R0,R3         ;COMPARE SECTOR TO SECTOR TABLE
29         BEQ   5$                ;YES, STORE OR RETRIEVE SECTOR INFO.
30         TST  (R2)+              ;INDEX SECLST BUFFER IN WORD FORMAT
31         INC   R3                ;INDEX SECTOR COUNT
32         CMP   R3,#39.          ;COMPARE SECTOR COUNT FOR <40
33         BLE   4$
34         SUB   #40.,R3
35         4$:  DEC   R1            ;KEEP SECTOR COUNT<40
36         BNE   3$              ;PASSED 24 SECTORS?
37         CLR   R0              ;COMPARE NEXT SECTOR
38         BR   7$              ;SETUP R0 FOR EXIT
39         5$:  TST  ADJFLG        ;EXIT ROUTINE, SECTOR NOT FOUND
40         BEQ   6$              ;FLAG=0 FOR RETRIEVE
41         MOV   R4,(R2)          ;STORE DRIVE INFO. INTO BUFFER
42         6$:  MOV   (R2),R0      ;SAVE DRIVE INFO. INTO R0 FOR EXIT
43         7$:  MOV   (SP)+,R3
44         MOV   (SP)+,R2
45         MOV   (SP)+,R1
46         RTS   R5              ;EXIT
    
```

```

1          ;ROUTINE TO SET DRIVE IN SECTOR LIST
2          ;CALL: JSR   R5,SETLST   ;RO HAS SECTOR
3          ;DRIVE GOTTEN FROM R4
4
5 027100 010146      SETLST: MOV   R1,-(SP)   ;SAVE R1
6
7 027102 162700 000034      SUB   #28.,R0   ;START LIST AT 0
8 027106 100002          BPL   3$
9 027110 062700 000050      ADD   #40.,R0
10 027114 012701 002402     3$:  MOV   #SECLST,R1   ;BEGINNING OF SECTOR LIST
11 027120 005700          1$:  TST   R0           ;FOUND SECTOR?
12 027122 001403          BEQ   2$           ;BRANCH IF YES
13 027124 005300          DEC   R0           ;DECREMENT SECTOR
14 027126 005721          TST   (R1)+        ;NEXT ENTRY IN LIST
15 027130 000773          BR    1$           ;GO BACK
16 027132 010411          2$:  MOV   R4,(R1)      ;STORE DRIVE BITS IN LIST
17 027134 012601          MOV   (SP)+,R1    ;RESTORE R1
18 027136 000205          RTS   R5
19
20          ;ROUTINE TO LOCATE DRIVE THAT WROTE SECTOR LAST
21          ;CALL: JSR   R5,FNDDRV   ;RO-CONTAINS SECTOR
22          ;ON EXIT RO-DRIVE
23
24 027140 010146      FNDDRV: MOV   R1,-(SP)   ;SAVE R1
25 027142 162700 000034      SUB   #28.,R0   ;START LIST AT 0
26 027146 100002          BPL   3$
27 027150 062700 000050      ADD   #40.,R0
28 027154 012701 002402     3$:  MOV   #SECLST,R1   ;START OF LIST
29 027160 005700          1$:  TST   R0           ;FOUND SECTOR?
30 027162 001403          BEQ   2$           ;YES, GET DRIVE #, EXIT
31 027164 005300          DEC   R0           ;NO, DOWN COUNT SECTOR
32 027166 005721          TST   (R1)+        ;NEXT ENTRY IN LIST
33 027170 000773          BR    1$           ;GO BACK
34 027172 011100          2$:  MOV   (R1),R0      ;GET DRIVE BUFFER POINTER
35 027174 012601          MOV   (SP)+,R1    ;RESTORE R1
36 027176 000205          RTS   R5           ;EXIT
    
```

```

1
2
3
4
5
6
7
8
9 027200 010046          :ROUTINE TO VERIFY THAT THE OVERWRITE DID ACTUALLY OVERWRITE THE
10 027202 010146          :PREVIOUS DATA ON THE PACK.
11 027204 010246          :CALL:  JSR      R5,VEROW      USES R3 AS BIT MAP OF SECTORS TO
12 027206 012737 000034 003132          :CHECK.  R3 IS LOADED PRIOR TO
13 027214 012701 100000          :WRITING SECTORS.
14 027220 016437 000006 003136          :
15
16 027226 012737 177600 003206 1$:  MOV      #-128.,BMP      ;SET UP READ-ONE SECTOR
17 027234 012737 003232 003202          :MOV      #BUF,BBA      ;BUS ADDRESS
18 027242 042737 000077 003204 2$:  BIC      #77,BDA      ;CLEAR OUT SECTOR BITS
19 027250 053737 003132 003204          :BIS      SECT,BDA      ;SET SECTOR
20 027256 030103          :BIT      R1,R3         ;DO WE READ THIS ONE?
21 027260 001521          :BEQ      5$           ;NO, BRANCH
22 027262 004537 032404          :JSR      R5,LDFUNC     ;READ
23 027266 000014          :READ
24
25 027270 005737 003164          :TST      E.CS         ;ERROR
26 027274 100107          :BPL      4$           ;NO CONTINUE
27
28 027276 005737 003062          :TST      FOUR         ;INITIAL WRITE
29 027302 001412          :BEQ      21$          ;NO
30 027304 012737 017373 003072          :MOV      #INITWR,REASON ;SETUP INITIAL WRITE OF SECTOR
31 027312 016437 000000 003070          :MOV      CSR(R4),LSTCLR
32 027320 016437 000005 003134          :MOV      DSB+1(R4),LSTDRV
33 027326 000415          :BR       22$
34 027330 012737 017642 003072 21$:  MOV      #OVWES,REASON  ;SET MESSAGE FOR OVERWRITE
35 027336 013700 003132          :MOV      SECT,R0      ;FIND DRIVE THAT LAST WROTE
36 027342 004537 027140          :JSR      R5,FNDDRV    ;SECTOR
37 027346 016037 000000 003070          :MOV      CSR(R0),LSTCLR ;GET IT'S CSR
38 027354 116037 000005 003134          :MOVB    DSB+1(R0),LSTDRV ;GET THE DRIVE
39 027362          :ERRDF   13.,OVWER,ERR4 ;PRINT ERROR
40 027362 104455          :TRAP    C$ERDF
41 027364 000015          :.WORD   13
42 027366 020003          :.WORD   OVWER
43 027370 020464          :.WORD   ERR4
44 027372 005037 003142          :CLR     WCOUNT        ;CLEAR BAD WORD COUNT W/IN SECTOR
45 027376 005037 003144          :CLR     SECWRD        ;CLEAR WORD IN SECTOR
46 027402 012702 003232          :MOV     #BUF,R2       ;GET BUFFER START
47 027406 023712 003136          :CMP     GDATA,(R2)    ;IS DATA CORRECT?
48 027412 001417          :BEQ     31$           ;YES CHECK NEXT
49 027414 005237 003142          :INC     WCOUNT        ;NO ACCOUNT FOR IT
50 027420          :PRINTF  #FRMB,SECWRD,GDATA,(R2)
51 027420 011246          :MOV     (R2),-(SP)
52 027422 013746 003136          :MOV     GDATA,-(SP)
53 027426 013746 003144          :MOV     SECWRD,-(SP)
54 027432 012746 021437          :MOV     #FRMB,-(SP)
55 027436 012746 000004          :MOV     #4,-(SP)
56 027442 010600          :MOV     SP,R0
57 027444 104417          :TRAP    C$PNTF
    
```

```

027446 062706 000012          ADD      #12,SP
47
48 027452 005722          31$:   TST      (R2)+      ;NEXT
49 027454 005237 003144      INC      SECWRD      ;NEXT
50 027460 023727 003144 000200  CMP      SECWRD,#128. ;DONE WITH SECTOR?
51 027466 001347          BNE      3$          ;NO GO BACK
52
53 027470          PRINTF  #FRM9,WCOUNT ;PRINT SUMMARY
    027470 013746 003142      MOV      WCOUNT,-(SP)
    027474 012746 021503      MOV      #FRM9,-(SP)
    027500 012746 000002      MOV      #2,-(SP)
    027504 010600          MOV      SP,R0
    027506 104417          TRAP    C$PNTF
    027510 062706 000006      ADD      #6,SP
54
55 027514 013700 003132      4$:   MOV      SECT,R0      ;SET SECTOR IN LIST TO THE
56 027520 004537 027100      JSR      R5,SETLST    ;CREDIT OF THIS DRIVE
57
58 027524 005237 003132      5$:   INC      SECT          ;NEXT SECTOR
59 027530 023727 003132 000050  CMP      SECT,#40.
60 027536 001003          BNE      6$
61 027540 162737 000050 003132  SUB      #40.,SECT
62 027546 000241          6$:   CLC              ;CLEAR CARRY
63 027550 006001          ROR      R1          ;NEXT BIT
64 027552 103225          BCC     1$          ;IF CLEAR NEXT
65
66 027554 012602          MOV      (SP)+,R2    ;RESTORE R2-R0, EXIT
67 027556 012601          MOV      (SP)+,R1
68 027560 012600          MOV      (SP)+,R0
69 027562 000205          RTS      R5

```



```

1          ;ROUTINE TO VERIFY THAT A DRIVE CAN RECOVER ANOTHER DRIVE'S DATA.
2          ;
3          ;CALL: JSR      R5,VEROD      USES R3 AS BIT MAP OF SECTORS TO
4          ;          ;          ;CHECK. R3 IS LOAD BY WRSEC (WE
5          ;          ;          ;USE R3 COMPLIMENTED.
6          ;
7          ;
8 027564 010046      VEROD: MOV      R0,-(SP)      ;SAVE R0-R2
9 027566 010146      MOV      R1,-(SP)
10 027570 010246      MOV      R2,-(SP)
11 027572 012701 100000      MOV      #100000,R1      ;BIT MASK FOR SECTORS
12 027576 012737 000034 003132      MOV      #28.,SECT      ;START WITH SECTOR 28
13 027604 005737 003062      TST      F0WR          ;CHECK FOR FIRST OVERWRITE
14 027610 001134      BNE      6$
15          ;
16 027612 012737 177600 003206 1$: MOV      #-128.,BMP      ;SET UP READ (ONE SECTOR)
17 027620 012737 003232 003202      MOV      #BUF,BBA      ;BUS ADDRESS
18 027626 042737 000077 003204 2$: BIC      #77,BDA      ;CLEAR SECTOR BITS
19 027634 053737 003132 003204      BIS      SECT,BDA      ;SET IN SECTOR BITS
20 027642 030103      BIT      R1,R3          ;CHECK THIS SECTOR?
21 027644 001103      BNE      5$          ;NO BRANCH
22          ;
23 027646 013700 003132      MOV      SECT,R0          ;FIND DRIVE THAT WROTE
24 027652 004537 027140      JSR      R5,FNDDRV      ;SECTOR LAST
25 027656 016037 000000 003070      MOV      CSR(R0),LSTCLR ;GET CSR OF DRIVE
26 027664 116037 000005 003134      MOV     DSB+1(R0),LSTDRV ;GET DRIVE
27 027672 016037 000006 003136      MOV     PAT(R0),GDATA   ;GET PATTERN
28          ;
29 027700 004537 032404      JSR      R5,LDFUNC      ;READ
30 027704 000014      READ
31          ;
32 027706 005737 003164      TST      E.CS          ;ERROR?
33 027712 100060      BPL      5$          ;NO, NEXT SECTOR
34 027714 012737 017675 003072      MOV     #RECMS,REASON   ;SET READ RECOVERY MESSAGE
35 027722      ERRDF 14.,RECER,ERR4 ;REPORT ERROR
36 027722 104455      TRAP   C$ERDF
37 027724 000016      .WORD 14
38 027726 020023      .WORD RECER
39 027730 020464      .WORD ERR4
40          ;
41 027732 005037 003142      CLR     WCOUNT          ;CLEAR BAD WORD COUNT
42 027736 005037 003144      CLR     SECWRD         ;CLEAR WORD W/I SECTOR
43 027742 012702 003232      MOV     #BUF,R2        ;START OF BUFFER
44 027746 023712 003136      CMP     GDATA,(R2)     ;DATA COMPARE
45 027752 001417      BEQ     4$          ;YES, CHECK NEXT
46          ;
47 027754 005237 003142      INC     WCOUNT          ;ACCOUNT FOR ERROR
48 027760      PRINTF #FRMB,SECWRD,GDATA,(R2) ;PRINT ERROR
49 027762 011246      MOV     (R2),-(SP)
50 027766 013746 003136      MOV     GDATA,-(SP)
51 027772 013746 003144      MOV     SECWRD,-(SP)
52 027776 012746 021437      MOV     #FRMB,-(SP)
53 030002 012746 000004      MOV     #4,-(SP)
54 030004 010600      MOV     SP,R0
55 030006 104417      TRAP   C$PNTF
56 030006 062706 000012      ADD     #12,SP

```

46	030012	005722		4\$:	TST	(R2)+	:NEXT
47	030014	005237	003144		INC	SECWRD	:NEXT WORD IN SECTOR
48	030020	023727	003144 000200		CMP	SECWRD,#128.	:DONE?
49	030026	001347			BNE	3\$:NO
50	030030				PRINTF	#FRM9,WCOUNT	:PRINT SUMMARY
	030030	013746	003142		MOV	WCOUNT,-(SP)	
	030034	012746	021503		MOV	#FRM9,-(SP)	
	030040	012746	000002		MOV	#2,-(SP)	
	030044	010600			MOV	SP,R0	
	030046	104417			TRAP	C\$PNTF	
	030050	062706	000006		ADD	#6,SP	
51							
52	030054	005237	003132	5\$:	INC	SECT	:NEXT SECTOR
53	030060	023727	003132 000050		CMP	SECT,#40.	
54	030066	000002			BNE	7\$	
55	030070	005037	003132		CLR	SECT	
56	030074	000241		7\$:	CLC		
57	030076	000001			ROR	R1	:NEXT BIT MAP
58	030100	103244			BCC	1\$	
59							
60	030102	012602		6\$:	MOV	(SP)+,R2	:RESTORE R2-R0, EXIT
61	030104	012601			MOV	(SP)+,R1	
62	030106	012600			MOV	(SP)+,R0	
63	030110	000205			RTS	R5	

```

1          ;ROUTINE TO VERIFY THE ADJ. CYL. WRITE IS GOOD
2          ;USES R3 AND WORD FOLLOWING CALL
3          ;IF WRITE WAS GOOD,SECTOR WILL BE STORED IN MAP
4          ;USING RSADJS/.WORD 1
5
6 030112 010046          VAJWR: MOV      R0,-(SP)          ;SAVE REGISTERS
7 030114 010146          MOV      R1,-(SP)
8 030116 010246          MOV      R2,-(SP)
9 030120 012701 100000  MOV      #100000,R1          ;BIT MASK FOR CYLINDER
10 030124 012502          MOV      (R5)+,R2          ;STARTING SECTOR
11 030126 005000          CLR      R0
12 030130 053700 003122  BIS      CYL,R0
13 030134 012737 0000C7 003056  MOV      #7,TEM
14
15 030142 006300          2$:   ASL      R0
16 030144 005337 003056  DEC      TEM
17 030150 001374          BNE     2$
18 030152 005737 003120  TST     SURF
19 030156 001402          BEQ     3$
20 030160 052700 000100  BIS     #HEAD,R0
21 030164 050200          3$:   BIS     R2,R0
22 030166 030103          4$:   BIT     R1,R3
23 030170 001462          BEQ     5$
24 030172 012737 177600 003206  MOV     #-128.,BMP
25 030200 010037 003204  MOV     R0,BDA
26 030204 010037 003066  MOV     R0,TEMP
27 030210 042700 177700  BIC     #177700,R0
28 030214 020027 000047  CMP     R0,#39.
29 030220 003406          BLE     6$
30 030222 162737 000050 003204  SUB     #40.,BDA
31 030230 162737 000050 003066  SUB     #40.,TEMP
32 030236 012737 003232 003202  6$:   MOV     #BUF,BBA
33 030244 005037 003110  CLR     HSFLG
34 030250 013700 003066  MOV     TEMP,R0
35 030254 004537 032404  10$:  JSR     R5,LDFUNC          ;READ FUNCTION
36 030260 000014          READ
37 030262 005737 003074  TST     ERFLG
38 030266 001416          BEQ     7$
39 030270 005737 003110  TST     HSFLG
40 030274 001007          BNE     11$
41 030276          ERRSOFT 120.,READ1,ERR2
42          TRAP     CSERSOFT
43          .WORD   120
44          .WORD   READ1
45          .WORD   ERR2
46 030306 005237 003110  INC     HSFLG
47 030312 000760          BR      10$
48          BR      11$
49 030314          ERRHRD 130.,READ1,ERR2
50          TRAP     CSERHRD
51          .WORD   130
52          .WORD   READ1
53          .WORD   ERR2
54 030324 010046          7$:   MOV     R0,-(SP)
55 030326 004537 026732  JSR     R5,RSADJS          ;STORE ADJ. CYL. SECTOR INFO.
56 030332 000001          .WORD   1
57 030334 012600          MOV     (SP)+,R0          ;RESTORE R0
58 030336 005200          5$:   INC     R0
    
```

50	030340	000241	CLC		
51	030342	006001	ROR	R1	
52	030344	103310	BCC	4\$	
53	030346	012602	MOV	(SP)+,R2	:RESTORE REGISTERS AND EXIT
54	030350	012601	MOV	(SP)+,R1	
55	030352	012600	MOV	(SP)+,R0	
56	030354	000205	RTS	R5	
57					

```

1          :ROUTINE TO VERIFY THAT WRITE DID NOT DISTURB ADJACENT TRACKS
2          :WRITTEN BY OTHER DRIVES.
3          :CALL JSR R5,BSVWR
4          :          .WORD          ;STARTING SECTOR
5          :
6          :USES "ADJLOC" TO GET +1/-1 CYLINDER OFFSET
7          :USES R3 FOR SECTOR MAP, USES MAP AT "SECBUF" FOR INFO
8
9 030356   010046      BSVWR:  MOV     R0,-(SP)          ;SAVE REGISTERS
10 030360   010146      MOV     R1,-(SP)
11 030362   010246      MOV     R2,-(SP)
12 030364   013746      MOV     R3,-(SP)
13 030370   013746      MOV     SURF,-(SP)
14 030374   012546      MOV     (R5)+,-(SP)      ;GET STARTING SECTOR
15 030376   123727      003100 000003  CMPB   ADJLOC,#3      ;ON MIDDLE TRACK???
16 030404   001455      BEQ    BSEXIT        ;YES, THEN NO CHECK
17 030406   162716      000042  SUB    #34,(SP)      ;SETUP SECTOR START FOR OUTSIDE
18 030412   100002      BPL    1$           ;IF POSITIVE OKAY ELSE FIX
19 030414   062716      000050  ADD    #40,(SP)      ;FIX IT
20 030420   123727      003100 000001 1$:  CMPB   ADJLOC,#1      ;ON OUTER LIMIT???
21 030426   001412      BEQ    INAWR        ;YES,SKIP CHECK
22 030430   105337      003100  DECB   ADJLOC        ;OUTER ADJ TRACK
23 030434   005337      003122  DEC    CYL
24 030440   004537      030566  JSR    R5,CHECK     ;GO CHECK ADJ SECTORS
25 030444   005237      003122  INC    CYL          ;FIX BACK
26 030450   105237      003100  INCB   ADJLOC
27 030454   062716      000104  INAWR: ADD    #68,(SP)      ;INNER SECTOR START
28 030460   021627      000050  CMP    (SP),#40     ;WITHIN LIMITS???
29 030464   002407      BLT    1$           ;YES, OKAY
30 030466   162716      000050  SUB    #40,(SP)     ;FIX SECTOR
31 030472   021627      000050  CMP    (SP),#40
32 030476   002402      BLT    1$
33 030500   162716      000050  SUB    #40,(SP)
34 030504   123727      003100 000005 1$:  CMPB   ADJLOC,#5      ;INNER LIMIT??
35 030512   001412      BEQ    BSEXIT        ;YES,SKIP CHECK
36 030514   105237      003100  INCB   ADJLOC        ;FIX FOR INNER
37 030520   005237      003122  INC    CYL
38 030524   004537      030566  JSR    R5,CHECK     ;GO CHECK ADJ SECTORS
39 030530   105337      003100  DECB   ADJLOC        ;FIX BACK
40 030534   005337      003122  DEC    CYL
41 030540   005726      BSEXIT: TST   (SP)+      ;THROW OFF SECTOR
42 030542   012637      003120  MOV    (SP)+,SURF
43 030546   012637      003122  MOV    (SP)+,CYL
44 030552   012602      NCHECK: MOV    (SP)+,R2
45 030554   012601      MOV    (SP)+,R1
46 030556   012600      MOV    (SP)+,R0
47 030560   004537      026254  JSR    R5,SKCYL     ;SEEK BACK
48 030564   000205      RTS     R5          ;RETURN
49

```

```

1          :ROUTINE TO VERIFY AN ADJACENT SECTOR
2          :CALLED FROM BSVWR
3          :CALL JSR R5,CHECK
4          :
5
6 030566 012701 100000 CHECK: MOV #100000,R1 :SECTOR MASK
7 030572 004537 026254 JSR R5,SKCYL :GET TO DESIRED CYLINDER
8 030576 005002 CLR R2 :CREATE ADDRESS
9 030600 053702 003122 BIS CYL,R2
10 030604 012737 000007 003056 MOV #7,TEM
11 030612 006302 2$: ASL R2
12 030614 005337 003056 DEC TEM
13 030620 001374 BNE 2$
14 030622 005737 003120 TST SURF
15 030626 001402 BEQ 3$ :NO
16 030630 052702 000100 BIS #HEAD,R2
17 030634 056602 000002 3$: BIS 2(SP),R2 :SET IN SECTOR
18 030640 030103 4$: BIT R1,R3 :THIS SECTOR IN LIST???
19 030642 001452 BEQ 5$ :NO, NEXT
20 030644 010200 MOV R2,R0 :COPY SECTOR
21 030646 042700 177700 BIC #177700,R0 :ONLY SECTOR LEFT
22 030652 020027 000050 CMP R0,#40. :SECTOR OKAY???
23 030656 002404 BLT 6$ :YES
24 030660 162700 000050 SUB #40.,R0
25 030664 162702 000050 SUB #40.,R2 :FIX SECTOR
26 030670 004537 026732 6$: JSR R5,RSADJS :FIND IF SECTOR PREVIOUSLY WRITTEN
27 030674 000000 .WORD 0
28 030676 005700 TST R0 :WAS IT??
29 030700 001433 BEQ 5$ :NO
30 030702 010237 003204 MOV R2,BDA :LOAD DISK ADDRESS
31 030706 012737 177600 003206 MOV #-128.,BMP :LOAD WC
32 030714 004537 032404 JSR R5,LDFUNC :LOAD
33 030720 000014 READ
34 030722 005737 003074 TST ERFLG :WAS READ GOOD
35 030726 001420 BEQ 5$
36 030730 010346 MOV R3,-(SP)
37 030732 010237 003132 MOV R2,SECT
38 030736 010003 MOV R0,R3
39 030740 042737 177700 003132 BIC #177700,SECT
40 030746 ERRHRD 140.,ADJTXT,ERR3
    030746 TRAP C$ERHRD
    030750 .WORD 140
    030752 .WORD ADJTXT
    030754 .WORD ERR3
41 030756 012603 MOV (SP)+,R3
42 030760 ERRHRD 110.,READ1,ERR2
    030760 TRAP C$ERHRD
    030762 .WORD 110
    030764 .WORD READ1
    030766 .WORD ERR2
43 030770 005202 5$: INC R2 :NEXT SECTOR
44 030772 000241 CLC
45 030774 006001 ROR R1 :SHIFT MASK
46 030776 103320 BCC 4$
47 031000 000205 RTS R5
    
```

```

1          :ROUTINE TO MERGE BAD SECTOR FILES
2          :ENTRY INTO THIS ROUTINE WILL OCCUR AFTER THE 'SERNUM' ROUTINE
3          :IS PERFORMED. THE FACTORY BAD SECTOR FILE WILL BE LOCATED IN
4          :FIRST 400(8) LOCATIONS.
5          :THIS ROUTINE WILL STORE THE FIELD BAD SECTORS INTO THE NEXT
6          :400 LOCATIONS AND THEN MERGE THE FACTORY BAD FILE
7          :WITH THE FIELD BAD FILE.
8
9          :FACTORY BAD AT BUF
10         :FIELD BAD AT BUF + 512.
11
12 031002 010146      MERGE:  MOV    R1,-(SP)      ;SAVE R1, R2, R3
13 031004 010246      MOV    R2,-(SP)
14 031006 010346      MOV    R3,-(SP)
15 031010 012737 003632 003202  MOV    #BUF+400,BBA ;BUFFER START FOR FIELD BAD
16 031016 022737 000001 003060  CMP    #1,T.DRIVE
17 031024 001004      BNE    55$
18 031026 012737 077724 003204  MOV    #77724,BDA
19 031034 000403      BR     66$
20 031036 012737 177724 003204 55$:  MOV    #177724,BDA
21
22 031044 012737 177400 003206 66$:  MOV    #-256.,BMP
23 031052 004537 032404 97$:  JSR   R5,LDFUNC ;LOAD READ FUNCTION
24 031056 000014      READ
25 031060 005737 003074      TST   ERFLG ;TEST ERROR FLAG
26 031064 001431      BEQ   98$ ;YES;MERGE BAD SECTOR FILES
27 031066 062737 000004 003204  ADD   #4,BDA ;TRY NEXT FIELD BAD SECTOR FILE
28 031074 022737 000001 003060  CMP    #1,T.DRIVE
29 031102 001004      BNE   400$
30 031104 022737 077750 003204  CMP    #77750,BDA
31 031112 001357      BNE   97$
32
33 031114 022737 177750 003204 400$:  CMP    #177750,BDA
34 031122 001353      BNE   97$ ;NO,DO NEXT FIELD BAD SECTOR
35 031124      PRINTF #FRM15
36 031124 012746 022037  MOV    #FRM15,-(SP)
37 031130 012746 000001  MOV    #1,-(SP)
38 031134 010600      MOV    SP,R0
39 031136 104417      TRAP  C$PNTF
40 031140 062706 000004  ADD   #4,SP
41 031144      999$:  BREAK
42 031144 104422      TRAP  C$BRK
43 031146 000776      BR     999$
44 031150 012701 003242 98$:  MOV    #BUF+10,R1 ;GET PAST ID ETC.
45 031154 012702 000176  MOV    #126.,R2 ;MAX = 126
46 031160 005721 1$:  TST   (R1)+ ;SECTOR OR END
47 031162 100404      BMI   2$ ;END, GO GET FIELD
48 031164 005721      TST   (R1)+ ;REST OF SECTOR
49 031166 005302      DEC   R2 ;MAX REACHED
50 031170 001373      BNE   1$ ;NO, KEEP GOING
51 031172 000401      BR     3$ ;YES, SKIP BACK UP
52 031174 005741 2$:  TST   -(R1) ;BACK UP PAST TERMINATOR
53 031176 012703 000176 3$:  MOV    #126.,R3 ;SET 126 MAX
54 031202 012702 003642  MOV    #BUF+410,R2 ;GET FIELD SECTORS
55 031206 012221 4$:  MOV    (R2)+,(R1)+ ;MERGE AT END OF FACTORY
56 031210 100403      BMI   5$ ;DONE?
57 031212 012221      MOV    (R2)+,(R1)+ ;NO, MERGE REST OF SECTOR
    
```

52	031214	005303	DEC	R3	:DONE
53	031216	001373	BNE	4\$:NO. GO BACK
54	031220	012603	SS: MOV	(SP)+,R3	:RESTORE R3, R2, R1
55	031222	012602	MOV	(SP)+,R2	
56	031224	012601	MOV	(SP)+,R1	
57	031226	000205	RTS	R5	:EXIT

1	031230	012537	003146		FNDTRK:	MOV	(R5)+,OFFSET	:GET INCREMENT/DECREMENT
2	031234	012537	003156			MOV	(R5)+,SURFACE	:GET HEAD (SURFACE)
3	031240	022737	000001	003060		CMP	#1,T.DRIVE	
4	031246	001001				BNE	80\$	
5	031250	000401				BR	90\$	
6	031252	022525			80\$:	CMP	(R5)+,(R5)+	
7	031254	012537	003152		90\$:	MOV	(R5)+,FRTRK	
8	031260	012537	003150			MOV	(R5)+,LSTTRK	
9	031264	005037	003160			CLR	TRKFND	:CLEAR OUT FLAG FOUND
10	031270	005037	003162			CLR	TRKCNT	:CLEAR OUT TRACK COUNT
11	031274	013737	003152	003154		MOV	FRTRK,PRSTRK	:GET FIRST TRACK
12	031302				1\$:			
13	031302	004537	031402			JSR	R5,FNDBSC	:IS TRACK IN BAD SECTOR FILE
14	031306	005737	002234			TST	HDRFND	:WAS IT?
15	031312	001003				BNE	2\$:YES, CLEAR TRKCNT
16	031314	005237	003162			INC	TRKCNT	:NO, INDICATE GOOD TRACK
17	031320	000402				BR	3\$:CONTINUE
18	031322	005037	003162		2\$:	CLR	TRKCNT	:START COUNT OVER
19	031326	023727	003162	000005	3\$:	CMP	TRKCNT,#5	:FIND 5 TRACKS YET?
20	031334	001011				BNE	4\$:NO, CONTINUE
21	031336	005237	003160			INC	TRKFND	:YES, EXIT WITH GOOD FLAG
22	031342	022737	000001	003060		CMP	#1,T.DRIVE	
23	031350	001002				BNE	81\$	
24	031352	062705	000004			ADD	#4,R5	
25								
26	031356	000205			81\$:	RTS	R5	
27	031360	023737	003154	003150	4\$:	CMP	PRSTRK,LSTTRK	:ARE WE DONE?
28	031366	001001				BNE	5\$:NO, KEEP LOOKING
29	031370	000205				RTS	R5	:EXIT WITH NOT FOUND
30	031372	063737	003146	003154	5\$:	ADD	OFFSET,PRSTRK	:NEXT TRACK
31	031400	000740				BR	1\$	
32								

```

1
2
3
4 031402 005037 002234      ;ROUTINE TO FIND BAD TRACK IN FILE
5 031406 010146              ;CALL   JSR      R5,FNDBSC
6 031410 010246              FNDASC: CLR      HDRFND      ;INITIALIZE FLAG
7 031412 012701 003242      MOV      R1,-(SP)      ;SAVE R1, R2
8 031416 005711              MOV      R2,-(SP)
9 031420 100421              MOV      #BUF+10,R1   ;SETUP FOR BEGINNING OF FILE
10 031422 023721 003154     1$:   TST      (R1)      ;END?
11 031426 001011              BMI      2$           ;IF MINUS AT END, EXIT
12 031430 105724              CMP      PRSTRK,(R1)+ ;CYLINDER CORRECT?
13 031432 123711 003156     BNE      3$           ;NO, NEXT
14 031436 001402              TSTB    (R4)+         ;UPPER HALF OF WORD
15 031440 105744              CMQB    SURFACE,(R1) ;CORRECT SURFACT
16 031442 000403              BEQ     4$           ;
17 031444 005237 002234     4$:   TSTB    -(R4)
18 031450 000405              BR      3$           ;SET FOUND
19
20 031452 005721              3$:   TST      (R1)+   ;NEXT WORD
21 031454 005202              INC     R2           ;ACCOUNT FOR IT
22 031456 020227 000374     CMP     R2,#252.    ;DONE?
23 031462 001355              BNE     1$           ;NO, KEEP CHECKING
24 031464 012601              2$:   MOV     (SP)+,R1 ;RESTORE R2, R1, EXIT
25 031466 012602              MOV     (SP)+,R2
26 031470 000205              RTS     R5
27
28 031472 013701 003154     FIXCYL: MOV     PRSTRK,R1 ;GET TRACK WHICH IS GOOD
29 031476 005737 003146     TST     OFFSET     ;WHICH WAY WERE WE LOOKING
30 031502 100402              BMI     1$           ;IN WORD, BRANCH
31 031504 162701 000004     SUB     #4,R1       ;BACK IT UP BY FOUR
32 031510 012702 000005     1$:   MOV     #5,R2   ;GOING STORE AWAY 5 TRACKS
33 031514 010120              2$:   MOV     R1,(R0)+ ;STORE THEM 1 WD/PER
34 031516 005201              INC     R1
35 031520 005302              DEC     R2
36 031522 001374              BNE     2$
37 031524 000205              RTS     R5
    
```

```

1          :ROUTINE TO GET SERIAL NUMBER
2
3          :CALL JSR R5,SERNUM
4
5 031526 012737 000013 003204 SERNUM: MOV #13,BDA
6 031534 004537 032404          JSR R5,LDFUNC          ;GET STATUS
7 031540 000004          GSTAT
8 031542 004537 032404          JSR R5,LDFUNC          ;READ HEADER
9 031546 000010          RDHDR
10 031550 013700 003172          MOV E,MP,R0          ;GET THE HEADER
11 031554 042700 000077          BIC #77,R0          ;CLEAR SECTOR BITS
12 031560 022737 000001 003060          CMP #1,T.DRIVE
13 031566 001003          BNE 23$
14 031570 020027 077700          CMP R0,#77700
15 031574 001446          BEQ 2$
16 031576 020027 177700          CMP R0,#177700
17 031602 001443          BEQ 2$
18 031604 042700 000100          BIC #100,R0          ;CLEAR HEAD
19 031610 022737 000001 003060          CMP #1,T.DRIVE
20 031616 001003          BNE 32$
21 031620 012701 077600          MOV #77600,R1
22 031624 000402          BR 33$
23 031626 012701 177600          MOV #177600,R1
24
25 031632 160001          33$: SUB R0,R1
26 031634 010137 003204          MOV R1,BDA          ;SET UP DIF WORD
27 031640 052737 000025 003204          BIS #25,BDA          ;SEEK IN, HEAD 1
28 031646 004537 032404          JSR R5,LDFUNC          ;SEEK
29 031652 000006          SEEK
30 031654 004537 032404          JSR R5,LDFUNC          ;VERIFY POSITION
31 031660 000010          RDHDR
32 031662 013700 003172          MOV E,MP,R0          ;GET HEADER
33 031666 022737 000001 003060          CMP #1,T.DRIVE
34 031674 001003          BNE 42$
35 031676 022700 077700          CMP #77700,R0
36 031702 000402          BR 43$
37 031704 022700 177700          CMP #177700,R0
38
39 031710 103321          43$: BHIS 1$
40 031712 022737 000001 003060          2$: CMP #1,T.DRIVE
41 031720 001004          BNE 52$
42 031722 012737 077700 003204          MOV #77700,BDA
43 031730 000403          BR 97$
44
45 031732 012737 177700 003204          52$: MOV #177700,BDA
46 031740 012737 003232 003202          97$: MOV #BUF,BBA
47 031746 012737 177400 003206          MOV #-256,BMP
48 031754 004537 032404          JSR R5,LDFUNC          ;READ
49 031760 000014          READ
50 031762 005737 003074          TST ERFLG          ;TEST ERROR FLAG
51 031766 001421          BEQ 98$          ;YES,COMPARE SERIAL NUMBERS
52 031770 062737 000004 003204          ADD #4,BDA          ;NO,SETUP FOR NEXT FACTORY BAD SECTOR
53 031776 022737 000001 003060          CMP #1,T.DRIVE
54 032004 001005          BNE 2$
55 032006 022737 077724 003204          CMP #77724,BDA
56 032014 001351          BNE 97$
57 032016 000453          BR 99$
    
```

58	032020	022737	177724	003204	62\$:	CMP	#177724,BDA	
59	032026	001344				BNE	97\$:GET NEXT FACTORY BAD SECTOR
60	032030	000446				BR	99\$:REPORT ERROR
61	032032	012701	003232		98\$:	MOV	#BUF,R1	:COMPARE SERIAL NUMBERS
62	032036	005737	003210			TST	SERNM1	:HAVE WE GOT ONE TO COMPARE
63	032042	100005				BPL	3\$:YES, BRANCH
64	032044	011137	003210			MOV	(R1),SERNM1	:NO, CALL THIS ONE IT
65	032050	016137	000002	003212		MOV	2(R1),SERNM2	:
66	032056	021137	003210		3\$:	CMP	(R1),SERNM1	:SERNUM OKAY
67	032062	001004				BNE	4\$:NO, PRINT ERROR
68	032064	026137	000002	003212		CMP	2(R1),SERNM2	:OTHER HALF OKAY
69	032072	001437				BEQ	5\$:YES, EXIT
70	032074				4\$:	PRINTF	#FRM3,2(R1),(R1),SERNM2,SERNM1	
	032074	013746	703210			MOV	SERNM1,-(SP)	
	032100	013746	003212			MOV	SERNM2,-(SP)	
	032104	011146				MOV	(R1),-(SP)	
	032106	016146	000002			MOV	2(R1),-(SP)	
	032112	012746	021167			MOV	#FRM3,-(SP)	
	032116	012746	000005			MOV	#5,-(SP)	
	032122	010600				MOV	SP,R0	
	032124	104417				TRAP	C\$PNTF	
	032126	062706	000014			ADD	#14,SP	
71	032132	004537	032174			JSR	R5,UNLOAD	:LET OPERATOR CHANGE
72	032136	004537	032300			JSR	R5,LOAD	:PACK
73	032142	000137	031526			JMP	SERNUM	:GO CHECK IT AGAIN.
74	032146				99\$:	PRINTF	#FRM15	:MESSAGE
	032146	012746	022037			MOV	#FRM15,-(SP)	
	032152	012746	000001			MOV	#1,-(SP)	
	032156	010600				MOV	SP,R0	
	032160	104417				TRAP	C\$PNTF	
	032162	062706	000004			ADD	#4,SP	
75	032166				999\$:	BREAK		
	032166	104422				TRAP	C\$BRK	
76	032170	000776				BR	999\$	
77	032172	000205			5\$:	RTS	R5	

```

1          :ROUTINE UNLOAD
2          :CALL   JSR   R5,UNLOAD
3
4
5          UNLOAD: PRINTF #FRM1,<B,DSB+1(R4)>,CSR(R4) ;PROMPT - UNLOAD DRIVE ON CONTROLLER -
6          MOV   CSR(R4),-(SP) ;AND REMOVE PACK
7          CLR   -(SP)
8          BISB  DSB+1(R4),(SP)
9          MOV   #FRM1,-(SP)
10         MOV   #3,-(SP)
11         MOV   SP,R0
12         TRAP  C$PNTF
13         ADD   #10,SP
14         MOV   #60,R1 ;SETUP 60 SECOND TIMER
15         MOV   #200,R0
16         BIS   DSB(R4),R0
17         MOV   R0,@CSR(R4)
18         BIT   #DRDY,@CSR(R4) ;CHECK DRDY FOR ZERO
19         BEQ   3$ ;PACK UNLOADED
20         WAITMS #10. ;WAIT 1 SECOND
21         DEC   R1 ;HAS 60 SEC PASSED?
22         BNE   2$ ;NO, RETEST DRDY, CONTINUE WAIT
23         BR    UNLOAD ;YES, REPEAT MESSAGE CONTINUE WAIT
24         3$:   RTS   R5 ;RETURN WITH PACK UNLOADED
25
26         :ROUTINE LOAD
27         :CALL   JSR   R5,LOAD
28
29
30         LOAD: PRINTF #FRM2,<B,DSB+1(R4)>,CSR(R4) ;PLACE PACK IN DRIVE ON CONTROLLER AND
31         MOV   CSR(R4),-(SP) ;LOAD IT
32         CLR   -(SP)
33         BISB  DSB+1(R4),(SP)
34         MOV   #FRM2,-(SP)
35         MOV   #3,-(SP)
36         MOV   SP,R0
37         TRAP  C$PNTF
38         ADD   #10,SP
39         MOV   #120,R1 ;SETUP 120 SEC TIMER
40         MOV   #200,R0 ;SETUP CONTROLLER READY BIT
41         BIS   DSB(R4),R0 ;SELECT DRIVE
42         MOV   R0,@CSR(R4)
43         BIT   #DRDY,@CSR(R4)
44         BNE   3$
45         WAITMS #10.
46         DEC   R1
47         BNE   2$
48         BR    LOAD
49         3$:   RTS   R5

```

```

1      ;ROUTINE LDFUNC
2      ;CALL JSR R5,LDFUNC
3
4 032404 010046 LDFUNC: MOV R0,-(SP)
5 032406 010346 MOV R3,-(SP)
6 032410 010146 MOV R1,-(SP)
7 032412 005037 003074 CLR ERFLG ;CLEAR ERROR FLAG
8 032416 016403 000000 MOV CSR(R4),R3 ;GET CSR
9 032422 013763 003206 000006 BMP,MP(R3) ;LOAD MULTIPURPOSE
10 032430 013763 003204 000004 MOV BDA,DA(R3) ;LOAD DISK ADDRESS
11 032436 013763 003202 000002 MOV BBA,BA(R3) ;LOAD BUS ADDRESS
12 032444 011537 003200 MOV (R5),BCS ;GET FUNCTION TO LOAD
13 032450 056437 000004 003200 BIS DSB(R4),BCS ;SELECT BITS
14 032456 012701 000031 MOV #25.,R1 ;SET WATCHDOG TO 250MS
15 032462 052737 000200 003200 BIS #200,BCS
16 032470 013763 003200 000000 MOV BCS,CS(R3) ;LOAD FUNCTION
17 032476 016337 000000 003200 MOV CS(R3),BCS
18 032504 042763 000200 000000 BIC #200,CS(R3)
19 032512 032763 000200 000000 1$: BIT #200,CS(R3) ;CNTLR READY?
20 032520 001036 BNE 2$ ;YES, GO
21 032522 WAITUS #100. ;WAIT 10 MILLISECONDS
22 032534 005301 DEC R1
23 032536 001365 BNE 1$
24
25 032540 016337 000000 003164 MOV CS(R3),E.CS ;READ ALL REGISTERS
26 032546 016337 000002 003166 MOV BA(R3),E.BA
27 032554 016337 000004 003170 MOV DA(R3),E.DA
28 032562 016337 000006 003172 MOV MP(R3),E.MP
29 032570 016337 000006 003174 MOV MP(R3),E.MP1
30 032576 016337 000006 003176 MOV MP(R3),E.MP2
31 032604 ERRDF 210.,CNTTOT,ERR5;CNTLR TIMEOUT
    032604 TRAP CSERDF
    032606 .WORD 210
    032610 .WORD CNTTOT
    032612 .WORD ERR5
32 032614 000425 BR 4$
33
34 032616 016337 000000 003164 2$: MOV CS(R3),E.CS ;READ ALL REGISTERS
35 032624 016337 000002 003166 MOV BA(R3),E.BA
36 032632 016337 000004 003170 MOV DA(R3),E.DA
37 032640 016337 000006 003172 MOV MP(R3),E.MP
38 032646 016337 000006 003174 MOV MP(R3),E.MP1
39 032654 016337 000006 003176 MOV MP(R3),E.MP2
40
41 032662 005737 003164 TST E.CS ;ANY ERRORS?
42 032666 100002 BPL 3$ ;YES, GO SERVICE
43 032670 005237 003074 4$: INC ERFLG
44 032674 005725 3$: TST (R5)+
45 032676 012601 MOV (SP)+,R1
46 032700 012603 MOV (SP)+,R3
47 032702 012600 MOV (SP)+,R0
48 032704 000205 RTS R5
49
50 032706 ENDMOD
51 .SBTTL CONTROL ROUTINE
    
```

```

CONTROL ROUTINE
1 032706
2 032706
3
4
5
6
7
8
9 032706 012701 002442
10 032712 012700 000170
11 032716 005021
12 032720 005300
13 032722 001375
14 032724 005237 003062
15 032730 004537 024606
16 032734 177400
17 032736 000377
18 032740 005037 003062
19 032744 005237 003064
20 032750 005237 003104
21 032754 004537 025330
22 032760 003 377
23 032762 170000
24 032764 003 000
25 032766 007777
26 032770 000000
27 032772 004537 032174
28 032776 062704 000010
29 033002 004537 032300
30 033006 004537 031526
31 033012 004537 024606
32 033016 000360
33 033020 000017
34 033022 005237 003104
35 033026 004537 025330
36 033032 002 360
37 033034 000000
38 033036 002 017
39 033040 000000
40 033042 004 360
41 033044 000000
42 033046 004 017
43 033050 000000
44 033052 000000
45 033054 004537 032174
46 033060 023727 003130 000002
47 033066 001002
48 033070 000137 033504
49 033074 062704 000010
50 033100 004537 032300
51 033104 004537 031526
52 033110 004537 024606
53 033114 006014
54 033116 001403
55 033120 005237 003104
56 033124 004537 025330
57 033130 002 000

          BGNMOD HRDWTST
          BGNSTST
          :CONTROL SECTION COMPATIBILITY PROGRAM
          :PRINT UNLOAD AND LOAD DRIVE MESSAGES
          :PERFORM SERIAL CHECK ROUTINE
          :PERFORM READ/WRITE CHECKS ON DRIVES

          COMPAT: MOV #SECBUF,R1 :ADJ. CYLINDER BUFFER
                   MOV #120,R0 :ADJ. CYLINDER BUFFER COUNT
          4$: CLR (R1)+ :CLEAR ADJ. CYL. BUFFER AT STARTUP
              DEC R0 :BUFFER CLEARED?
              BNE 4$ :CLEAR NEXT BUFFER WORD
              INC F0WR :SET FIRST OVERWRITE FLAG
              JSR R5,OVWPER :PERFORM OVERWRITE ON FIRST DRIVE
                   177400
                   377
              CLR F0WR :CLEAR FIRST OVERWRITE
              INC FADJ :SET FIRST ADJ. FLAG
              INC ADJDIR :UP = 1
              JSR R5,ADJCYL
              .BYTE 3,377 :TRACK AND SECTORS FOR
              .WORD 170000 :INWARD SEEK
              .BYTE 3,0 :TRACK AND SECTORS FOR
              .WORD 7777 :OUTWARD SEEK
              .WORD 0 :TERMINATOR
              JSR R5,UNLOAD :UNLOAD PACK FROM DRIVE UNIT
              ADD #PAT+2,R4 :UPDATE POINTER FOR NEXT DRIVE
              JSR R5,LOAD :LOAD INTO SECOND DRIVE UNIT
              JSR R5,SERNUM :CHECK PACK SERIAL NUMBER
              JSR R5,OVWPER :PERFORM R/W OVERWRITE
                   360
                   17
              INC ADJDIR
              JSR R5,ADJCYL
              .BYTE 2,360 :IN 1/0 OUTSIDE
              .WORD 0
              .BYTE 2,17 :OUT 1/0 OUTSIDE
              .WORD 0
              .BYTE 4,360 :IN 1/0 INSIDE
              .WORD 0
              .BYTE 4,17 :OUT 1/0 INSIDE
              .WORD 0
              .WORD 0
              JSR R5,UNLOAD :UNLOAD PACK FROM DRIVE UNIT
              CMP UUT,#2 :CHECK FOR > 2 DRIVES
              BNE 10$ :YES,GO TO NEXT DRIVE
              JMP 2$ :GO TO FIRST DRIVE
          10$: ADD #PAT+2,R4 :UPDATE DRIVE BUFFER FOR THIRD DRIVE
              JSR R5,LOAD :LOAD PACK FOR THIRD DRIVE
              JSR R5,SERNUM :CHECK SERIAL NUMBERS
              JSR R5,OVWPER :PERFORM R/W OVERWRITE ON THIRD DRIVE
                   6014
                   1403
              INC ADJDIR
              JSR R5,ADJCYL
              .BYTE 2,0 :IN 2/0 OUTSIDE

```

58	033132	170000			.WORD	170000	
59	033134	002	000		.BYTE	2,0	:OUT 2/0 OUTSIDE
60	033136	007400			.WORD	7400	
61	033140	004	000		.BYTE	4,0	:IN 2/0 INSIDE
62	033142	170000			.WORD	170000	
63	033144	004	000		.BYTE	4,0	:OUT 2/0 INSIDE
64	033146	007400			.WORD	7400	
65	033150	001	200		.BYTE	1,200	:IN 2/1 OUTSIDE
66	033152	000000			.WORD	0	
67	033154	001	100		.BYTE	1,100	:OUT 2/1 OUTSIDE
68	033156	000000			.WORD	0	
69	033160	005	200		.BYTE	5,200	:IN 2/1 INSIDE
70	033162	000000			.WORD	0	
71	033164	005	100		.BYTE	5,100	:OUT 2/1 INSIDE
72	033166	000000			.WORD	0	
73	033170	000000			.WORD	0	:TERMINATOR
74	033172	004537	032174		JSR	R5,UNLOAD	:UNLOAD PACK ON THIRD DRIVE
75	033176	023727	003130	000003	CMP	UIT,#3	:CHECK FOR > 3 DRIVES
76	033204	001500			BEQ	1\$:NO, GO TO 2ND DRIVE
77	033206	062704	000010		ADD	#PAT+2,R4	:UPDATE DRIVE BUFFER FOR 4TH DRIVE
78	033212	004537	032300		JSR	R5,LOAD	:LOAD PACK ON 4TH DRIVE
79	033216	004537	031526		JSR	R5,SERNUM	:CHECK PACK ON FOURTH DRIVE
80	033222	004537	024606		JSR	R5,OVWPER	:PERFORM R/W OVERWRITE
81	033226	001042				1042	
82	033230	000421				421	
83	033232	005237	003104		INC	ADJDIR	
84	033236	004537	025330		JSR	R5,ADJCYL	
85	033242	002	000		.BYTE	2,0	:IN 3/0 OUTSIDE
86	033244	000360			.WORD	360	
87	033246	002	000		.BYTE	2,0	:OUT 3/0 OUTSIDE
88	033250	000017			.WORD	17	
89	033252	004	000		.BYTE	4,0	:IN 3/0 INSIDE
90	033254	000360			.WORD	360	
91	033256	004	000		.BYTE	4,0	:OUT 3/0 INSIDE
92	033260	000017			.WORD	17	
93	033262	001	040		.BYTE	1,40	:IN 3/1 OUTSIDE
94	033264	000000			.WORD	0	
95	033266	001	020		.BYTE	1,20	:OUT 3/1 OUTSIDE
96	033270	000000			.WORD	0	
97	033272	005	040		.BYTE	5,40	:IN 3/1 INSIDE
98	033274	000000			.WORD	0	
99	033276	005	020		.BYTE	5,20	:OUT 3/1 INSIDE
100	033300	000000			.WORD	0	
101	033302	001	000		.BYTE	1,0	:IN 3/2 OUTSIDE
102	033304	100000			.WORD	100000	
103	033306	001	000		.BYTE	1,0	:OUT 3/2 OUTSIDE
104	033310	040000			.WORD	40000	
105	033312	005	000		.BYTE	5,0	:IN 3/2 INSIDE
106	033314	100000			.WORD	100000	
107	033316	005	000		.BYTE	5,0	:OUT 3/2 INSIDE
108	033320	040000			.WORD	40000	
109	033322	000000			.WORD	0	:TERMINATOR
110	033324	004537	032174		JSR	R5,UNLOAD	:UNLOAD PACK FROM 4TH DRIVE
111	033330	162704	000010		SUB	#PAT+2,R4	:SET DRIVE BUFFER FOR 3RD DRIVE
112	033334	004537	032300		JSR	R5,LOAD	:LOAD PACK ON 3RD DRIVE
113	033340	004537	031526		JSR	R5,SERNUM	:CHECK FOR PACK SERIAL NUMBER
114	033344	004537	024606		JSR	R5,OVWPER	:PERFORM R/W OVERWRITE ON 3RD DRIVE

115	033350	020000		20000		
116	033352	010000		10000		
117	033354	004537	025330	JSR	R5,ADJCYL	
118	033360	001 000		.BYTE	1,0	:IN 2/3 OUTSIDE
119	033362	000200		.WORD	200	
120	033364	001 000		.BYTE	1,0	:OUT 2/3 OUTSIDE
121	033366	000100		.WORD	100	
122	033370	005 000		.BYTE	5,0	:IN 2/3 INSIDE
123	033372	000200		.WORD	200	
124	033374	005 000		.BYTE	5,0	:OUT 2/3 INSIDE
125	033376	000100		.WORD	100	
126	033400	000000		.WORD	0	:TERMINATOR
127	033402	004537	032174	JSR	R5,UNLOAD	:UNLOAD PACK FROM 3RD DRIVE
128	033406	162704	000010	1\$: SUB	#PAT+2,R4	:SET DRIVE BUFFER FOR 2ND DRIVE
129	033412	004537	032300	JSR	R5,LOAD	:LOAD PACK ON THIRD DRIVE
130	033416	004537	031526	JSR	R5,SERNUM	:CHECK PACK SERIAL NUMBER
131	033422	004537	024606	JSR	R5,OVWPER	:PERFORM R/W OVERWRITE ON 2ND DRIVE
132	033426	004040			4040	
133	033430	002020			2020	
134	033432	004537	025330	JSR	R5,ADJCYL	
135	033436	001 000		.BYTE	1,0	:IN 1/2 OUTSIDE
136	033440	020000		.WORD	20000	
137	033442	001 000		.BYTE	1,0	:OUT 1/2 OUTSIDE
138	033444	010000		.WORD	10000	
139	033446	005 000		.BYTE	5,0	:IN 1/2 INSIDE
140	033450	020000		.WORD	20000	
141	033452	005 000		.BYTE	5,0	:OUT 1/2 INSIDE
142	033454	010000		.WORD	10000	
143	033456	001 000		.BYTE	1,0	:IN 1/3 OUTSIDE
144	033460	000040		.WORD	40	
145	033462	001 000		.BYTE	1,0	:OUT 1/3 OUTSIDE
146	033464	000020		.WORD	20	
147	033466	005 000		.BYTE	5,0	:IN 1/3 INSIDE
148	033470	000040		.WORD	40	
149	033472	005 000		.BYTE	5,0	:OUT 1/3 INSIDE
150	033474	000020		.WORD	20	
151	033476	000000		.WORD	0	:TERMINATOR
152	033500	004537	032174	JSR	R5,UNLOAD	:UNLOAD PACK FROM 2ND DRIVE
153	033504	162704	000010	2\$: SUB	#PAT+2,R4	:SET DRIVE BUFFER FOR 1ST DRIVE
154	033510	004537	032300	JSR	R5,LOAD	:LOAD PACK INTO FIRST DRIVE UNIT
155	033514	004537	031526	JSR	R5,SERNUM	:CHECK SERIAL NUMBER
156	033520	004537	024606	JSR	R5,OVWPER	:PERFORM R/W OVERWRITE
157	033524	001042			1042	
158	033526	000421			421	
159	033530	004537	025330	JSR	R5,ADJCYL	
160	033534	001 010		.BYTE	1,10	:IN 0/1 OUTSIDE
161	033536	000000		.WORD	0	
162	033540	001 004		.BYTE	1,4	:OUT 0/1 OUTSIDE
163	033542	000000		.WORD	0	
164	033544	005 010		.BYTE	5,10	:IN 0/1 INSIDE
165	033546	000000		.WORD	0	
166	033550	005 004		.BYTE	5,4	:OUT 0/1 INSIDE
167	033552	000000		.WORD	0	
168	033554	001 000		.BYTE	1,0	:IN 0/2 OUTSIDE
169	033556	004000		.WORD	4000	
170	033560	001 000		.BYTE	1,0	:OUT 0/2 OUTSIDE
171	033562	002000		.WORD	2000	

172	033564	005	000	.BYTE	5,0	;IN 0/2 INSIDE
173	033566	004000		.WORD	4000	
174	033570	005	000	.BYTE	5,0	;OUT 0/2 INSIDE
175	033572	002000		.WORD	2000	
176	033574	001	000	.BYTE	1,0	;IN 0/3 OUTSIDE
177	033576	000010		.WORD	10	
178	033600	001	000	.BYTE	1,0	;OUT 0/3 OUTSIDE
179	033602	000004		.WORD	4	
180	033604	005	000	.BYTE	5,0	;IN 0/3 INSIDE
181	033606	000010		.WORD	10	
182	033610	005	000	.BYTE	5,0	;OUT 0/3 INSIDE
183	033612	000004		.WORD	4	
184	033614	000000		.WORD	0	;TERMINATOR
185	033616	004537	032174	JSR	RS,UNLOAD	;UNLOAD PACK
186	033622			PRINTF	#ENDPAS	;END OF PASS
	033622	012746	022412	MOV	#ENDPAS,-(SP)	
	033626	012746	000001	MOV	#1,-(SP)	
	033632	010600		MOV	SP,RO	
	033634	104417		TRAP	C\$PNTF	
	033636	062706	000004	ADD	#4,SP	
187						
188	033642	000137	024266	JMP	CMPEA	;RETURN TO SUPERVISOR
189						
190						
191	033646			ENDTST		
	033646			L10014:		
	033646	104401		TRAP	C\$ETST	
192	033650			ENDMOD		
193						
194	033650			BGNMOD	HRDPRM	
195	033650			BGNHRD		
	033650	000025		.WORD	L10015-L\$HARD/2	
196						
197	033652			GPRMA	CSRMSG,CSR,0,160000,177776,YES	
	033652	000031		.WORD	T\$CODE	
	033654	033724		.WORD	CSRMSG	
	033656	160000		.WORD	T\$LOLIM	
	033660	177776		.WORD	T\$HILIM	
198						
199	033662			GPRMA	VECMSG,VECT,0,0,776,YES	
	033662	001031		.WORD	T\$CODE	
	033664	033762		.WORD	VECMSG	
	033666	000000		.WORD	T\$LOLIM	
	033670	000776		.WORD	T\$HILIM	
200						
201	033672			GPRMD	DRMSG,DRBT,0,03400,0,7,YES	
	033672	004032		.WORD	T\$CODE	
	033674	033771		.WORD	DRMSG	
	033676	003400		.WORD	03400	
	033700	000000		.WORD	T\$LOLIM	
	033702	000007		.WORD	T\$HILIM	
202						
203	033704			GPRML	DRTYPE,TYPDR,1,YES	
	033704	003130		.WORD	T\$CODE	
	033706	033740		.WORD	DRTYPE	
	033710	000001		.WORD	1	
204						

205	033712				GPRMD	BRMSG,PRIOR,0,340,0,7,YES
	033712	002032			.WORD	T\$CODE
	033714	033777			.WORD	BRMSG
	033716	000340			.WORD	340
	033720	000000			.WORD	T\$LOLIM
	033722	000007			.WORD	T\$HILIM

206					ENDHRD	
207	033724				.EVEN	

	033724				L10015:	
208						
209	033724	102	125	123	CSRMSG: .ASCIZ	/BUS ADDRESS/

	033727	040	101	104		
	033732	104	122	105		
	033735	123	123	000		
210	033740	104	122	111	DRTYPE: .ASCIZ	/DRIVE TYPE = RL01/

	033743	126	105	040		
	033746	124	131	120		
	033751	105	040	075		
	033754	040	122	114		
	033757	060	061	000		

211	033762	126	105	103	VECMSG: .ASCIZ	/VECTOR/
	033765	124	117	122		
	033770	000				

212	033771	104	122	111	DRMSG: .ASCIZ	/DRIVE/
	033774	126	105	000		
213	033777	102	122	040	BRMSG: .ASCIZ	/BR LEVEL/

	034002	114	105	126		
	034005	105	114	000		

214					.EVEN	
215						
216					ENDMOD	
217	034010					

218					LASTAD	
219	034010				.EVEN	
	034010	000000			.WORD	0
	034012	000000			.WORD	0
	034014				L\$LAST::	

220					.END	
221		000001				

ADJCYL 025330
 ADJDIR 003104
 ADJFLG 003102
 ADJLC2 003220
 ADJLC3 003222
 ADJLC4 003224
 ADJLOC 003100
 ADJTRK 003214
 ADJTXT 020210
 ADJUUT 003216
 ADR = 000020 G
 ASSEMB= 000010
 AUTOCO 024312 G
 BA = 000002
 BA16 = 000020
 BA17 = 000040
 BBA 003202
 BCS 003200
 BDA 003204
 BDATA 003140
 BIT0 = 000001 G
 BIT00 = 000001 G
 BIT01 = 000002 G
 BIT02 = 000004 G
 BIT03 = 000010 G
 BIT04 = 000020 G
 BIT05 = 000040 G
 BIT06 = 000100 G
 BIT07 = 000200 G
 BIT08 = 000400 G
 BIT09 = 001000 G
 BIT1 = 000002 G
 BIT10 = 002000 G
 BIT11 = 004000 G
 BIT12 = 010000 G
 BIT13 = 020000 G
 BIT14 = 040000 G
 BIT15 = 100000 G
 BIT2 = 000004 G
 BIT3 = 000010 G
 BIT4 = 000020 G
 BIT5 = 000040 G
 BIT6 = 000100 G
 BIT7 = 000200 G
 BIT8 = 000400 G
 BIT9 = 001000 G
 BMP 003206
 BOE = 000400 G
 BRMSG 033777
 BEXIT 030540
 BSVWR 030356
 BUF 003232
 CHECK 030566
 CLNCOD 024316 G
 CMPENA 024266
 CNTTOT 017346
 COMPAT 032706

CRDY = 000200
 CRSET = 000002
 CS = 000000
 CSR = 000090
 CSRMSG 033724
 CYL 003122
 CSAU = 000052
 CSAUTO= 000061
 CSBRK = 000022
 CSBSEG= 000004
 CSBSUB= 000002
 CSCEFG= 000045
 CSCCLK= 000062
 CSCLEA= 000012
 CSCLOS= 000035
 CSCLP1= 000006
 CSCVEC= 000036
 CSDCLN= 000044
 CSDODU= 000051
 CSDRPT= 000024
 CSDU = 000053
 CSEDIT= 000003
 CSERDF= 000055
 CSERHR= 000056
 CSERRO= 000060
 CSERSF= 000054
 CSERSO= 000057
 CSESCA= 000010
 CSESEG= 000005
 CSESUB= 000003
 CSETST= 000001
 CSEXIT= 000032
 C\$GETB= 000026
 C\$GETW= 000027
 C\$GMAN= 000043
 C\$GPHR= 000042
 C\$GPLO= 000030
 C\$GPRI= 000040
 C\$INIT= 000011
 C\$INLP= 000020
 C\$MANI= 000050
 C\$MEM = 000031
 C\$MSG = 000023
 C\$OPEN= 000034
 C\$PNTB= 000014
 C\$PNTF= 000017
 C\$PNTS= 000016
 C\$PNTX= 000015
 C\$QIO = 000377
 C\$RDBU= 000007
 C\$REFG= 000047
 C\$RESE= 000033
 C\$REVI= 000003
 C\$RFLA= 000021
 C\$RPT = 000025
 C\$SEFG= 000046
 C\$SPRI= 000041

C\$SVEC= 000037
 C\$TPRI= 000013
 DA = 000004
 DCKER 017455
 DCRC = 004000
 DERR = 040000
 DIAGMC= 000000
 DIRC 003116
 DLT = 010000
 DRBT = 000010
 DRBUF 017240
 DRDY = 000001
 DRMSG 033771
 DRPCOD 024322 G
 DRST = 000013
 DRSTAT 003106
 DRTYPE 033740
 DSB = 000004
 DSPCOD 022462 G
 EF.CON= 000036 G
 EF.NEW= 000035 G
 EF.PWR= 000034 G
 EF.RES= 000037 G
 EF.STA= 000040 G
 END 023020
 ENDBUF 017300
 ENDPAS 022412
 ERFLG 003074
 ERR = 100000
 ERRFND 017743
 ERR1 020240 G
 ERR2 020276 G
 ERR3 020336 G
 ERR4 020464 G
 ERR5 020644 G
 ERR6 020704 G
 EVL = 000004 G
 EXIT 024310
 E\$END = 002100
 E\$LOAD= 000035
 E.BA 003166
 E.CS 003164
 E.DA 003170
 E.MP 003172
 E.MP1 003174
 E.MP2 003176
 FADJ 003064
 FEW 017473
 FIXCYL 031472
 FNDBSC 031402
 FNDDRV 027140
 FNDTRK 031230
 FORSK 003126
 FOWR 003062
 FRM1 020772
 FRM10 021545
 FRM11 021611

FRM12 021646
 FRM13 021725
 FRM14 022010
 FRM15 022037
 FRM16 022076
 FRM17 022163
 FRM18 022217
 FRM19 022303
 FRM2 021067
 FRM20 022341
 FRM3 021167
 FRM4 021246
 FRM5 021307
 FRM6 021356
 FRM7 021377
 FRM8 021437
 FRM9 021503
 FRTRK 003152
 FUNERR 020047
 FWD 020116
 F\$AU = 000015
 F\$AUTO= 000020
 F\$BGN = 000040
 F\$CLEA= 000007
 F\$DU = 000016
 F\$END = 000041
 F\$HARD= 000004
 F\$HW = 000013
 F\$INIT= 000006
 F\$JMP = 000050
 F\$MOD = 000000
 F\$MSG = 000011
 F\$PROT= 000021
 F\$PWR = 000017
 F\$RPT = 000012
 F\$SEG = 000003
 F\$SOFT= 000005
 F\$SRV = 000010
 F\$SUB = 000002
 F\$SW = 000014
 F\$TEST= 000001
 GDATA 003136
 GLBDAT 002234 G
 GLBEQA 002234 G
 GLBERR 020240 G
 GLBSUB 024326 G
 GLBTXT 017302 G
 GSBIT = 000003
 GSTAT = 000004
 G\$CNT0= 000200
 G\$DELM= 000372
 G\$DISP= 000003
 G\$EXCP= 000400
 G\$HILI= 000002
 G\$LOLI= 000001
 G\$NO = 000000
 G\$OFFS= 000400

G\$OF SI= 000376
 G\$PRMA= 000001
 G\$PRMD= 000002
 G\$PRML= 000000
 G\$RADA= 000140
 G\$RADB= 000000
 G\$RADD= 000040
 G\$RADL= 000120
 G\$RADO= 000020
 G\$XFER= 000004
 G\$YES = 000010
 HCRC = 004000
 HDRFND 002234
 HEAD = 000100
 HEAD01 003114
 HNF = 010000
 HOE = 100000 G
 HPTCOD 022466 G
 HRDPRM 033650 G
 HRDWTs 032706 G
 HSFLG 003110
 IBE = 010000 G
 IDU = 000040 G
 IER = 020000 G
 INAWR 030454
 INITCO 022466 G
 INITWR 017373
 INN10 002356
 INN11 002370
 INN20 002360
 INN21 002372
 INN30 002362
 INN31 002374
 INN40 002364
 INN41 002376
 INN50 002366
 INN51 002400
 INTEN = 000100
 ISR = 000100 G
 IXE = 004000 G
 ISAU = 000041
 ISAUTO= 000041
 ISCLN = 000041
 ISDU = 000041
 ISHRD = 000041
 ISINIT= 000041
 ISMOD = 000041
 ISMSG = 000041
 ISPROT= 000040
 ISPTAB= 000041
 ISPWR = 000041
 ISRPT = 000041
 ISSEG = 000041
 ISSETU= 000041
 ISSRV = 000041
 ISSUB = 000041
 ISTST = 000041

J\$JMP = 000167	L\$SPC 002056 G	00U40 002270	REV 020126	T\$HILI= 000007
LDFUNC 032404	L\$SPCP 002020 G	00U41 002302	REVSK 003124	T\$LAST= 000001
LOAD 032300	L\$SPTP 002024 G	00U50 002272	RSADJS 026732	T\$LLOI= 000000
LOE = 040000 G	L\$STA 002030 G	00U51 002304	SECBUF 002442	T\$L CYM= 010000
LOT = 000010 G	L\$TEST 002114 G	OSECT 003112	SECLST 002402	T\$LTMO= 000001
LSTCLR 003070	L\$TIML 002014 G	OUT10 002236	SECT 003132	T\$NEST= 177777
LSTDRV 003134	L\$UNIT 002012 G	OUT11 002250	SECWRD 003144	T\$NSO = 000000
LSTTRK 003150	L10000 020274	OUT20 002240	SEEK = 000006	T\$NS1 = 000004
L\$ACP 002110 G	L10001 020334	OUT21 002252	SERNM1 003210	T\$PTMU= 000000
L\$APT 002036 G	L10002 020462	OUT30 002242	SERNM2 003212	T\$SAVL= 177777
L\$AUT 002070 G	L10003 020642	OUT31 002254	SERNM3 031526	T\$SEGL= 177777
L\$AUTO 024312 G	L10004 020702	OUT40 002244	SETLST 027100	T\$SUBN= 000000
L\$CCP 002106 G	L10005 020770	OUT41 002256	SETUP 023072	T\$TAGL= 177777
L\$CLEA 024316 G	L10007 022462	OUT50 002246	SIGN = 000004	T\$TAGN= 010016
L\$CO 002032 G	L10010 024310	OUT51 002260	SKCYL 026254	T\$TEMP= 000000
L\$DEPO 002011 G	L10011 024314	OVMS 017642	SKER 020077	T\$TEST= 000001
L\$DESC 002122 G	L10012 024320	OVWER 020003	SKHS = 000020	T\$TSM= 177777
L\$DESP 002076 G	L10013 024324	CVWPER 024606	STFLG 003076	T\$TSTS= 000001
L\$DEVP 002060 G	L10014 033646	OVWTRK 003022	STSEC 003230	T\$SAUT= 010011
L\$DISP 022464 G	L10015 033724	OSAPTS= 000000	STSEC1 003226	T\$SCLE= 010012
L\$DLY 002116 G	MANY 017532	OSAU = 000000	SURF 003120	T\$SDU = 010013
L\$DTP 002040 G	MDHEDR 002000 G	OSBGNR= 000000	SURFAC 003156	T\$SHAR= 010015
L\$DTYP 002034 G	MERGE 031002	OSBGNS= 000000	SVCGBL= 000000	T\$SHW = 010007
L\$DU 024322 G	MID10 002306	OSDU = 000000	SVCINS= 000000	T\$SINI= 010010
L\$DUT 002072 G	MID11 002320	OSERRT= 000000	SVCSUB= 177777	T\$SMG= 010005
L\$DVTY 002222 G	MID20 002310	OSGNSW= 000000	SVCTAG= 000000	T\$SPRO= 010006
L\$EF 002052 G	MID21 002322	OSPOIN= 000001	SVCTST= 177777	T\$STES= 010014
L\$ENV1 002044 G	MID30 002312	OSSETU= 000000	S\$LSYM= 010000	T.DRIV 003060
L\$ETP 002102 G	MID31 002324	PAT = 000006	TEM 003056	T1 032706 G
L\$EXP1 002046 G	MID40 002314	PATLST 003046	TEMP 003066	UAM = 000200 G
L\$EXP4 002064 G	MID41 002326	PNT = 001000 G	TIME 024326	UNLOAD 032174
L\$EXP5 002066 G	MID50 002316	PRI = 002000 G	TQU10 002332	UUT 003130
L\$HARD 033652 G	MID51 002330	PRIOR = 000004	TQU11 002344	VAJWR 030112
L\$HIME 002120 G	MK = 000001	PRI00 = 000000 G	TQU20 002334	VEC = 000002
L\$HPCP 002016 G	MP = 000006	PRI01 = 000040 G	TQU21 002346	VECMG 033762
L\$HPT 002022 G	NCHECK 030552	PRI02 = 000100 G	TQU30 002336	VECT = 000002
L\$HW 022450 G	NONE 017571	PRI03 = 000140 G	TQU31 002350	VEROD 027564
L\$ICP 002104 G	NXM = 020000	PRI04 = 000200 G	TQU40 002340	VEROW 027200
L\$INIT 022466 G	OBUFF 017236	PRI05 = 000240 G	TQU41 002352	WCOUNT 003142
L\$LADP 002026 G	OFFSET 003146	PRI06 = 000300 G	TQU50 002342	WRITE = 000012
L\$LAST 034014 G	OPI = 002000	PRI07 = 000340 G	TQU51 002354	WRIT1 020136
L\$LOAD 002100 G	OPR001 017302	PRSTRK 003154	TRCNT 003162	WRSEC 025070
L\$LUN 002074 G	OPR002 017321	RDHDR = 000010	TRKFD 003160	XDELAY 017232
L\$MPREV 002050 G	00U10 002262	READ = 000014	TYPDR = 000006	XTIME 024452
L\$NAME 002000 G	00U11 002274	READ1 020163	T\$ARGC= 000001	X\$ALWA= 000000
L\$PRIO 002042 G	00U20 002264	REASON 003072	T\$CODE= 002032	X\$FALS= 000040
L\$PROT 022440 G	00U21 002276	RECER 020023	T\$ERRN= 000322	X\$OFFS= 000400
L\$PRT 002112 G	00U30 002266	RECMS 017675	T\$EXCP= 000000	X\$TRUE= 000020
L\$REPP 002062 G	00U31 002300	REGDMP 026522	T\$GMAN= 000000	YDELAY 017234
L\$REV 002010 G				

. ABS. 034014 000
 000000 001
 ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 28672 WORDS (112 PAGES)
 DYNAMIC MEMORY AVAILABLE FOR 71 PAGES
 .A:CZRLLC/C=SVC33.SRC/P:1,A:CZRLLC

ISPLR	1-22#									
ISRPT	1-22#									
ISSEG	1-22#	27-2								
ISSETU	1-22#									
ISSRV	1-22#									
ISSUB	1-22#	27-2								
I\$TST	1-22#	27-2	27-2#	27-191	27-191#	27-191#				
IBE	1-42#									
IDU	1-42#									
IER	1-42#									
INAWR	19-21	19-27#								
INITCO	6-3#									
INITWR	4-14#	16-30								
INN10	2-51#	6-147								
INN11	2-56#	6-162								
INN20	2-52#									
INN21	2-57#									
INN30	2-53#	2-80								
INN31	2-58#	2-85								
INN40	2-54#									
INN41	2-59#									
INN50	2-55#									
INN51	2-60#	11-134								
INTEN	1-58#									
ISR	1-42#									
IXE	1-42#									
J\$JMP	1-22#									
L\$ACP	1-29#									
L\$APT	1-29#									
L\$AUT	1-29#									
L\$AUTO	1-29	7-3#								
L\$CCP	1-29#									
L\$CLEA	1-29	7-12#								
L\$CO	1-29#									
L\$DEPO	1-29#									
L\$DESC	1-29	1-32#								
L\$DESP	1-29#									
L\$DEVP	1-29#									
L\$DISP	1-29	5-27#								
L\$DLY	1-29#	8-13*	8-17	8-21*	8-22	8-27*	8-33*	8-34	8-38	
L\$DTP	1-29#									
L\$DTYF	1-29#									
L\$DU	7-20#									
L\$DUT	1-29#									
L\$DVTY	1-29	1-34#								
L\$EF	1-29#									
L\$ENVI	1-29#									
L\$ETP	1-29#									
L\$EXP1	1-29#									
L\$EXP4	1-29#									
L\$EXP5	1-29#									
L\$HARD	1-29	27-195	27-195#							
L\$HIME	1-29#									
L\$MPCP	1-29#									
L\$MPTP	1-29#									
L\$MW	1-29	5-14	5-14#							

LSICP	1-29#													
LSINIT	1-29	6-5#												
LSLADP	1-29#													
LSLAST	1-29	27-219#												
LSLOAD	1-29#													
LSLUN	1-29#													
LSPREV	1-29#													
LSNAME	1-29#													
LSPRIO	1-29#													
LSPROT	1-29	5-4#												
LSPRT	1-29#													
LSREPP	1-29#													
LSREV	1-29#													
LSSPC	1-29#													
LSSPCP	1-29#													
LSSPTP	1-29#													
LSSTA	1-29#													
LSTEST	1-29#													
LSTIPL	1-29#													
LSUNIT	1-29#	6-9	6-15	6-21	6-38	6-65	6-313							
L10000	4-43#													
L10001	4-48#													
L10002	4-57#													
L10003	4-67#													
L10004	4-72#													
L10005	4-78#													
L10007	5-14	5-20#												
L10010	6-321#													
L10011	7-7#													
L10012	7-16#													
L10013	7-22#													
L10014	27-191#													
L10015	27-195	27-207#												
LDFUNC	10-39	12-7	12-31	12-37	16-22	17-29	18-35	20-32	21-23	24-6	24-8	24-28	24-30	24-48
	26-4#													
LOAD	6-96	24-72	25-22#	25-32	27-29	27-50	27-78	27-112	27-129	27-154				
LOE	1-42#													
LOT	1-42#													
LSTCLR	3-7#	4-64	16-31*	16-37*	17-25*									
LSTDRV	3-25#	4-64	4-64	16-32*	16-38*	17-26*								
LSTTRK	3-31#	4-41	22-8*	22-27										
MANY	4-17#	6-18												
MDHEDR	1-28#													
MERGE	6-98	21-12#												
MID10	2-31#	6-185												
MID11	2-36#	6-208												
MID20	2-32#													
MID21	2-37#													
MID30	2-33#	2-78												
MID31	2-38#	2-83												
MID40	2-34#													
MID41	2-39#													
MID50	2-35#													
MID51	2-40#													
PK	1-78#	12-26												
MP	1-47#	13-16	26-9*	26-28	26-29	26-30	26-37	26-38	26-39					

TYPR	6-273	6-287	6-296	22-9*	22-21*					
UAM	1-88#	6-43	27-203	27-203	27-203					
UNLOAD	1-42#									
UUT	24-71	25-5#	25-15	27-27	27-45	27-74	27-110	27-127	27-152	27-185
VAJWR	3-23#	6-21*	6-25	6-38	6-62*	6-65*	11-150	27-46	27-75	
VEC	11-59	11-78	11-106	11-119	18-6#					
VECMG	1-52#	3-75	3-75	3-75	3-75	6-29*				
VECT	27-199	27-211#								
VEROD	1-86#	27-199	27-199	27-199						
VEROW	9-34	9-52	17-8#							
WCOUNT	9-33	9-51	16-9#							
WRIT1	3-28#	16-40*	16-45*	16-53	17-37*	17-43*	17-50			
WRITE	4-28#	10-45	10-48							
WRSEC	1-74#	10-40								
XSALWA	9-30	9-48	10-8#	11-56	11-75	11-102	11-114			
XSALWA	1-22#									
XSALS	1-22#									
XSOFFS	1-22#									
XSTRUE	1-22#									
XDELAY	3-57#	8-14*	8-18*	8-23*	26-21*					
XTIME	8-27#	25-12	25-29							
YDELAY	3-58#	8-28*	8-29*	8-30*	8-35*	8-39*	25-12*	25-29*		

