

.REM a

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44

IDENTIFICATION

PRODUCT CODE: AC-S072B-MC
PRODUCT NAME: CZRMVBO RM05/3/2 EXTENDED DRIVE TEST
PRODUCT DATE: APRIL 1981
MAINTAINER: CX DIAGNOSTIC GROUP
AUTHOR: MIKE LEAVITT

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS MANUAL.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL.

COPYRIGHT (C) 1980,1981 DIGITAL EQUIPMENT CORPCRATION

CONTENTS

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44

- 1. ABSTRACT
- 2. REQUIREMENTS
 - 2.1 EQUIPMENT
 - 2.2 PRELIMINARY PROGRAMS
 - 2.3 MEDIA
- 3. LOADING PROCEDURE
- 4. STARTING PROCEDURE
 - 4.1 STARTING ADDRESSES
 - 4.2 OPERATOR ACTION
 - 4.3 PROGRAM ACTION
 - 4.3.1 CONTROL SWITCH SELECTION
 - 4.3.2 RH11 - RH70 ADDRESS SELECTION
 - 4.3.3 DRIVE AND PARAMETER SELECTION
- 5. OPERATING PROCEDURE
 - 5.1 OPERATIONAL SWITCH SETTINGS
 - 5.2 CONTROL SWITCH SETTINGS
- 6. ERRORS
 - 6.1 ERROR TYPES
 - 6.2 ERROR RECOVERY
- 7. RESTRICTIONS
- 8. MISCELLANEOUS
 - 8.1 EXECUTION TIME
 - 8.2 STACK POINTER
 - 8.3 TIMING TEST (TESTS 12 - 15) PRINTOUTS
 - 8.4 END OF TEST
- 9. PROGRAM DESCRIPTION
- 10. PROGRAM LISTING

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57

1. ABSTRACT

THIS PROGRAM CONTAINS A SERIES OF TESTS THAT WILL VERIFY THAT THE DISK IS CAPABLE OF PERFORMING SEEKS, THAT THE ACCESS TIMES ARE WITHIN TOLERANCE AND THAT THE TRACK/SECTOR ADDRESSING CIRCUITRY OPERATES PROPERLY, AND THAT THE DATA STORAGE AND RETRIEVAL CAPABILITIES ARE FUNCTIONING.

2. REQUIREMENTS

2.1 EQUIPMENT

PDP-11 PROCESSOR
12K MEMORY
TELETYPE
PROGRAM LOADING DEVICE
KW11-L OR KW11-P (THE KW11-P IS REQUIRED FOR THE TIMING TESTS)
RH11 OR RH70 CONTROLLER
1 TO 8 DISK DRIVES (ANY COMBINATION OF RM05'S, RM03'S OR RM02'S)

2.2 PRELIMINARY PROGRAMS

RM05/3/2 DISKLESS TEST, PART 1 & 2
RM05/3/2 FUNCTIONAL TEST, PART 1, 2 & 3

2.3 MEDIA

THE PROGRAM REQUIRES THAT EACH DRIVE TO BE TESTED HAS A FORMATTED DISK PACK. THE PACK MAY BE FORMATTED IN EITHER 16-BIT OR 18-BIT MODE, DEPENDING ON THE TESTING REQUIREMENTS. NOTE THAT THE PROGRAM WILL NOT TEST A MIXTURE OF DRIVES WITH BOTH 16 AND 18 BIT MODE PACKS.

3. LOADING PROCEDURE

THE PROGRAM MAY BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER OR IT MAY BE LOADED FROM THE APPROPRIATE 'XXDP' MEDIA USING THE ASSOCIATED LOADER.

4. STARTING PROCEDURE

4.1 STARTING ADDRESSES

58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114

200 NORMAL STARTING ADDRESS
204 SELECT OPERATING PARAMETERS
210 SELECT RH11-RH70 ADDRESSES
214 COMBINATION OF 204 AND 210

NOTE: STARTING ADDRESSES 210 AND 214 ARE AVAILABLE WHEN THE PROGRAM IS INITIALLY STARTED; THESE STARTING ADDRESSES ARE TREATED AS ADDRESSES 200 OR 204 RESPECTIVELY ON RESTARTS.

4.2 OPERATOR ACTION

1. LOAD PROGRAM INTO MEMORY (SEE SECTION 3.)
2. LOAD A FORMATTED PACK INTO DRIVE(S) TO BE TESTED
3. BRING DRIVE(S) TO ONLINE STATE, WRITE ENABLED, AND LOCKED ON PORT.
4. LOAD ADDRESS 200.
5. SET SWITCHES (SEE SECTION 5.)
6. PRESS START.
7. THE PROGRAM WILL TYPEOUT THE STATUS OF THE DRIVES ATTACHED TO THE SELECTED MASSBUS SUBSYSTEM. TO INHIBIT THIS TYPEOUT, DO NOT RESTART THE PROGRAM FROM ANY OF THE STARTING ADDRESSES; INSTEAD TYPE A 'CONTROL C' ON THE KEYBOARD TO RETURN THE PROGRAM TO COMMAND ENTRY MODE.

4.3 PROGRAM ACTION

IN AN EFFORT TO ALLOW CONVERSATION WITH A PROGRAM FOR THE PURPOSE OF CONTROLLING ITS OPERATION AND PARAMETERS THE FOLLOWING CONSTRUCTIONS HAVE BEEN ADOPTED.

NOTE1. IN ALL EXAMPLES BRACKETS ARE USED FOR CLARITY AND ARE NOT TYPED BY THE USER.

NOTE2: THE CARRIAGE RETURN TYPED BY THE USER IS INDICATED BY <CR> AND WILL BE ECHOED AS A 'CARRIAGE RETURN-LINE FEED'.

<.><CR> PERIOD

A STATEMENT TERMINATOR: WHEN TYPED AT THE END OF A LINE (LEGAL ON ALL LINES) IT TELLS THE PARAMETER STRING INTERPRETER (PSI) THIS IS THE END OF CHANGES TO THE CURRENT PARAMETER STRING.

<..><CR> PERIOD PERIOD

THE 'PERIOD PERIOD' TERMINATOR IS TYPED TO INDICATE THE END OF TEST PARAMETER MODIFICATION AND TO SIGNAL THE START OF TEST EXECUTION.

<.,><CR> COMMA

THE COMMA IS USED AS A SEPARATOR BETWEEN DRIVE NUMBERS AND TEST NUMBERS.

</> SLASH

A MODIFICATION INDICATOR: IF A SLASH FOLLOWS A TEST

115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171

NUMBER, THE PROGRAM WILL OPEN THAT TEST FOR PARAMETER
MODIFICATION.

<^U> CONTROL-U

DELETE THE PRESENT INPUT STRING AND START A NEW
LINE, TYPED BY DEPRESSING THE "CONTROL KEY"
(CTRL) AND THEN STRIKING THE 'U'.

<\> RUBOUT

DELETE THE LAST CHARACTER FROM THE INPUT STRING,
TYPED BY STRIKING THE 'RUBOUT' KEY, WHICH WILL
BE ECHOED BY A BACKSLASH (\) FOLLOWED BY THE
CHARACTER DELETED.

4.3.1 CONTROL SWITCH SELECTION

STARTING THE PROGRAM AT ANY OF THE POSSIBLE STARTING ADDRESSES
WITH SW<07>=1 WILL RESULT IN ENTERING THE "CONTROL SWITCH
SETTING" MODE. THIS, ALLOWING THE OPERATOR TO SPECIFY THE
DESIRED STATE OF 'C.SWR'.

CONTROL SWITCH SELECTION EXAMPLES:

EXAMPLE #1

SET SW<07>=0
C.SWR=000000 / 400..

EXAMPLE #2

SET SW<07>=0
C.SWR=000000 / 220.
C.SWR=000000 / 220..

4.3.2 RH11 - RH70 ADDRESS SELECTION

STARTING THE PROGRAM AT 200 WILL RESULT IN AUTOMATIC
SELECT OF THE DEFAULT VALUES OF BUS ADDRESS (RMCS1),
VECTOR ADDRESS, AND PRIORITY LEVEL OF THE RH11-RH70.
IF THE DEFAULT VAULE OF THE BUS ADDRESS DOES NOT RESPOND
(TIMES OUT) WHEN ADDRESSED, AN ERROR IS REPORTED.
AFTER THE ERROR IS REPORTED ONE OF TWO COURSES OF ACTION
WILL BE TAKEN:

1. IF THERE IS A MONITOR -- RETURN TO THE MONITOR
2. IF THERE ISN'T A MONITOR -- ASK FOR NEW ADDRESSES

STARTING THE PROGRAM AT 210 OR 214 ALLOWS THE OPERATOR
TO CHANGE THE ADDRESS OF THE RH11 OR RH70 AND THE VECTOR
ADDRESS.

ADDRESS SELECTION EXAMPLES

172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228

EXAMPLE #1
RMCS1=176700 / 177200.

EXAMPLE #2
RMCS1=176700 / 176300<CR>
RMVEC=254 / 260<CR>

EXAMPLE #3
RMCS1=176700<CR>
RMVEC=254 / 260.

EXAMPLE #4
RH/RM FAILED TO RESPOND TO ADDRESSING
RMCS1 ERR PC
176300 XXXXXX
RMCS1=176300 / 176700.

EXAMPLE #5
RMCS1=176700 / 1776\67\6300<CR>
RMVEC=254<CR>
RMCS1=176300.

4.3.3 DRIVE AND PARAMETER SELECTION

STARTING THE PROGRAM AT 200 OR 210 WILL RESULT IN AUTOMATIC SELECTION OF THE DRIVES TO TEST AND THE TESTS TO RUN.

STARTING THE PROGRAM AT 204 OR 214 ALLOWS THE OPERATOR TO SELECT THE DRIVE(S) TO BE TESTED, THE TESTS TO BE EXECUTED, AND THE PARAMETERS TO USE.

EACH TEST CONTAINS TWO SETS OF TRACK LIMIT PARAMETERS. PARAMETERS 'LT', 'FT' AND 'IT' ARE USED BY RM03/2 DRIVES AND PARAMETERS 'LT', 'FT' AND 'IT' ARE USED BY RM05 DRIVES. THE PROGRAM DETERMINES WHICH DRIVE IS BEING TESTED AND SELECTS THE CORRECT SET OF TRACK LIMIT VALUES. IF THE PROGRAM IS BEING USED TO TEST A SUBSYSTEM WHICH CONTAINS BOTH RM03/2 AND RM05 DRIVES, THE OPERATOR MUST CHANGE BOTH SETS OF TRACK LIMITS IF THE TESTS ARE TO BE MODIFIED FOR ALL DRIVES TESTED.

4.3.3.1 DRIVE AND PARAMETER SELECTION DESCRIPTION

THE FOLLOWING IS A TABLE OF TERMS USED BY THE PSI.

'R'	REPEATS (ITERATIONS)
'FC'	FIRST CYLINDER ADDRESS
'LC'	LAST CYLINDER ADDRESS
'IC'	INCREMENT CYLINDER
'FT'	FIRST TRACK ADDRESS
'LT'	LAST TRACK ADDRESS
'IT'	INCREMENT TRACK

229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285

'FT'' FIRST TRACK ADDRESS ;RM05 PARAMETER
'LT'' LAST TRACK ADDRESS ;RM05 PARAMETER
'IT'' INCREMENT TRACK ;RM05 PARAMETER
'FS'' FIRST SECTOR ADDRESS
'LS'' LAST SECTOR ADDRESS
'PA'' PATTERN (USED FOR DATA TEST)
'WDX'' WORD OF PATTERN 0 WHERE X IS 1 TO 16

*'S'' ALL SEEK TESTS (TESTS 0 - 10)
*'T'' ALL TIMING TESTS (TESTS 12 - 15)
*'A'' ALL ADDRESS TESTS (TESTS 16 - 17)
*'D'' THE DATA TEST (TEST 20)
*'E'' THE EXERCISER (TEST 21)

* USED BY THE OPERATOR TO SELECT TEST GROUPS

NOTE: ALL NUMBERS WILL BE IN DECIMAL EXCEPT FOR THE PATTERN (PAT) AND WORDS (WDX) SELECTION. 'PAT' WILL BE SELECTED BY A BIT (I.E. 001000(8)=PATTERN 9) AND 'WDX' WILL BE IN OCTAL.

SPECIAL CASES OF CONTROL CHARACTERS

IF <.> IS TYPED WHILE A TEST IS OPEN FOR MODIFICATION (</>) AND OTHER TESTS IN THE 'TEST COMMAND' STRING ARE TO BE MODIFIED, THE REMAINING TESTS WILL BE UNCHANGED.

WHEN THE PROGRAM IS STARTED FROM LOCATION 200 OR 210, TESTS 0-10, 12,13,15-20 WILL BE RUN USING ALL AVAILABLE, ONLINE DRIVES. IF THE OPERATOR WISHES TO SELECT THE DRIVES TO BE TESTED, THE TESTS TO BE PERFORMED, OR THE PARAMETERS TO BE USED, THE CONVERSATION MODE MAY BE ENTERED BY TYPING A 'CONTROL C' OR BY STARTING THE PROGRAM FROM EITHER LOCATION 204 OR 214.

THE PROGRAM WILL THEN RESPOND WITH:

DRIVE(S)=

THE FOLLOWING EXAMPLES ASSUME THAT THE OPERATOR IS TO TEST DRIVE #3 USING TESTS 2 THRU 7 AND TEST 11 AND DOES NOT DESIRE TO CHANGE THE PARAMETERS (INITIAL CYLINDER ADDRESS, FINAL CYLINDER ADDRESS, ETC.). THE USER WOULD TYPE '3<CR>' WHICH SAYS 'THIS IS THE END OF DRIVE ENTRY'. THE PROGRAM WILL THEN REQUEST TEST NUMBERS.

THE TRANSACTION APPEARS AS FOLLOWS:

DRIVE(S)=3<CR>
TEST=

THE OPERATOR MAY NOW ENTER DESIRED TEST NUMBERS. IN THE EXAMPLE, HE WANTS TESTS 2 THRU 7 AND TEST 11 SO HE TYPES 2-7<,> (THE 'COMMA' SEPARATES ENTRIES), 11<.><CR> ('PERIOD' 'CARRIAGE RETURN' - END OF CHANGES, START TEST EXECUTION.)

IT NOW LOOKS LIKE THIS

286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342

DRIVE(S)=3<CR>
TEST=2-7,11.<CR>

IN THE NEXT EXAMPLE, IT IS ASSUMED THAT THE OPERATOR WISHES TO TEST DRIVE 4 AND TO RUN TESTS 1 AND 3 THRU 11, MODIFYING THE PARAMETERS FOR TESTS 3 AND 10.

THE TRANSACTION WOULD BE AS FOLLOWS:

DRIVE(S)=4<CR>
TEST=

THE OPERATOR NOW ENTERS THE TEST NUMBERS. THE TRANSACTION IS GIVEN BELOW:

DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11<CR>

NOTICE THIS SAYS SELECT TEST 1, CONTINUE<, >; SELECT TEST 3, OPEN</>; SELECT TESTS 4-7, CONTINUE<, >; SELECT TEST 10, OPEN</>; SELECT TEST 11, END OF INPUT <.>.

THE PROGRAM SCANS THE TEST NUMBER INPUT AND DETERMINES THAT THE PARAMETERS FOR TEST 3 AND TEST 10 ARE TO BE CHANGED. THE OTHER TESTS WILL NOT BE ALTERED.

(THE ENTIRE TRANSACTION IS REPEATED FOR CLARITY)

DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11<CR>
TEST 3
R=X / ;WHERE X IS ITERATION

THE NEW VALUE FOR 'R' MAY BE ENTERED. TERMINATING THE ENTRY WITH A <.> (PERIOD) WILL TERMINATE THE CHANGES FOR THIS TEST; TYPING A <CR> OR TERMINATING THE ENTRY WITH A <CR> WILL CAUSE THE PROGRAM TO MOVE TO THE NEXT PARAMETER.

DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11<CR>
TEST 3
R=1 / <CR> ;DO NOT ALTER-BUT CONTINUE
FC=N / ;WHERE 'N' IS FIRST CYLINDER ADDRESS

IF THE OPERATOR DOES NOT WISH TO CHANGE 'FC', THE FOLLOWING OCCURS:

DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11.<CR>
TEST 3
R=1 / <CR> ;DO NOT ALTER THIS LINE BUT CONTINUE
FC=0 / <CR> ;DO NOT ALTER THIS LINE BUT CONTINUE
LC=822 /

THE PROGRAM RESPONDS WITH THE PREVIOUSLY ASSIGNED PARAMETER FOR LAST CYLINDER ADDRESS IN THIS CASE USING 822 AS THE EXAMPLE. THIS IS WHAT THE OPERATOR INTENDED TO MODIFY AND IS WHY TEST 3 WAS OPENED. TO CHANGE THE VALUE TO '20', THE NEW VALUE IS TYPED

343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399

FOLLOWED BY A 'PERIOD' TERMINATOR (<,><CR>).

THE TOTAL TRANSACTION AND RESPONSE:

```
DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11<CR>
TEST 3
R=1 / <CR>
FC=0 / <CR>
LC= 822 / 20.<CR>
TEST 10
R=1 /
```

THE PROGRAM HAS LOADED TEST 3 WITH ITS NEW PARAMETERS AND THE PROGRAM IS WAITING FOR CHANGES TO TEST 10'S PARAMETERS.

```
DRIVE(S)=4<CR>
TEST=1,3/4-7,10/11<CR>
TEST 3
R=1 / <CR>
FC=0 / <CR>
LC= 822 / 20.<CR>
TEST 10
R=1 / 10.<CR>
```

THE OPERATOR TYPES THE NEW VALUE (10) AND TERMINATES THE ENTRY WITH A 'PERIOD' 'CARRIAGE RETURN'.

THE PROGRAM NOW LOADS TEST 10 WITH THE NEW PARAMETERS (TEST 11 RETAINS THE PREVIOUSLY ASSIGNED PARAMETERS) AND RESPONDS WITH:

DRIVE(S)=

SINCE THE USER DID NOT END THE CONVERSATION MODE WITH A 'PERIOD PERIOD', THE PROGRAM HAS LOOPED BACK TO THE BEGINNING LOOKING FOR MORE CHANGES. THAT IS TO SAY, AFTER THE ENTRY FOR DRIVE SELECTION, A <,><CR> WILL CAUSE THE TEST MESSAGE TO BE REPEATED AND FURTHER CHANGES CAN BE MADE. HOWEVER, AT SOME POINT IN ORDER TO EXECUTE THE PROGRAM, A 'PERIOD PERIOD' MUST BE TYPED.

IF A SINGLE 'PERIOD' IS TYPED WHILE DRIVE OR TEST NUMBERS ARE BEING ENTERED, THE PROGRAM WILL START EXECUTION IMMEDIATELY. A 'PERIOD PERIOD' MUST BE TYPED BEFORE THE PROGRAM WILL EXIT TEST PARAMETER CHANGE MODE TO GO TO EXECUTION.

4.3.3.2 DRIVE AND PARAMETER SELECTION EXAMPLES

EXAMPLE #1

```
DRIVE=4.<CR>          :SELECT DRIVE #4, TERMINATE AND
                       :BEGIN EXECUTION USING PREVIOUSLY ASSIGNED
                       :PARAMETERS
```

EXAMPLE #2

400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456

```
DRIVE=0<CR>           ;SELECT DRIVE #0 AND MAKE CHANGES ''''
TEST=1-5.<CR>         ;RUN TEST 1 THRU 5 ONLY, USE DEFAULT
                       ;PARAMETERS AND TERMINATE AND EXECUTE.''
```

EXAMPLE #3

```
DRIVE=2<CR>           ;SELECT DRIVE #2 AND MAKE CHANGES ''''
TEST=1-5,6/7/10/<CR> ;RUN TEST 1-5 WITH DEFAULT PARAMETERS, OPEN
TEST 6                ;TEST 6,7 AND 10 FOR CHANGES
R=1 / <CR>            ;LEAVE 'R' AS IS AND MOVE TO NEXT PARAMETER
FC=0 / 10.<CR>        ;SET 'FC' CYLINDER ADDRESS TO 10, END CHANGES
                       ;TO TEST 6.
```

```
TEST 7
R=1 / 50<CR>         ;50 ITERATIONS, MOVE TO NEXT PARAMETER
FC=0 / <CR>          ;DO NOT CHANGE 'FC' CYLINDER ADDRESS BUT CONTINUE
LC=822 / 50..<CR>   ;TEST 10 IS STILL PENDING AND WILL BE
                       ;RETAIN ITS PRESENT PARAMETERS.
```

EXAMPLE #4

```
DRIVE=0<CR>           ;SELECT DRIVE #0 AND MAKE CHANGES
TEST=S,E.<CR>         ;RUN ALL SEEK TESTS AND THE EXERCISER
```

EXAMPLE #5

```
DRIVE=1<CR>           ;RUN ALL SEEK TESTS (OPEN FOR CHANGES) AND
TEST=S/D<CR>         ;THE DATA TEST (WITH DEFAULT PARAMETERS).
TEST 0                ;RUN WITH 10 ITERATIONS
R=10 / <CR>           ;CHANGE FIRST CYLINDER ADDRESS
FC=0 / 10..<CR>      ;AND START EXECUTION
                       ;TESTS 1 - 10 WILL RETAIN THEIR PREVIOUSLY
                       ;ASSIGNED PARAMETERS.
```

EXAMPLE #6

```
DRIVE=1<CR>           ;OPEN THE SEEK TESTS (TESTS 0-10)
TEST=S/<CR>           ;
TEST 0                ;CHANGE TO 100 ITERATIONS, TO TO THE NEXT TEST
R=10 / 100.<CR>       ;
TEST 1                ;CHANGE 'R' TO 1000 ITERATIONS, MOVE TO NEXT TEST
R=100 / 1000.<CR>    ;
TEST 2                ;CHANGE 'R' TO 10 ITERATIONS, GO TO NEXT PARAMETER
R=1 / 10<CR>         ;CHANGE 'FC' TO 50, GO TO NEXT PARAMETER
FC=0 / 50<CR>        ;CHANGE 'LC' TO 51, GO TO THE NEXT TEST
LC=822 / 51.<CR>     ;
TEST 3                ;MOVE TO NEXT TEST
R=1.<CR>              ;
TEST 4                ;USE TEST 4'S PARAMETERS AND STAR* PROGRAM EXECUTION
R=1..<CR>            ;
```

457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513

EXAMPLE #7

```

DRIVE=1<CR>
TEST=D/<CR>                ;SELECT AND OPEN THE DATA TEST
TEST 20
R=1 / 1000<CR>            ;DO 1000 ITERATION OF TEST PATTERN
FC=0 / 10<CR>            ;#8 ON CYLINDER 10, TRACK 2, SECTOR 4
LC=822 / 10<CR>
IC=64 / 0<CR>
FT=0 / 2<CR>
LT=4 / 2<CR>
IT=1 / <CR>
FT'=0 / 2<CR>            ;RM05 PARAMETER
LT'=18 / 2<CR>          ;RM05 PARAMETER
IT'=1 / <CR>            ;RM05 PARAMETER
FS=0 / 4<CR>
LS=22 / 4<CR>
PAT=177777 / 400..<CR> ;RUN WITH PATTERN #8
    
```

EXAMPLE #8

```

DRIVE=1<CR>                ;USE THE SAME PARAMETERS AS IN EXAMPLE
TEST=D/<CR>                ;#7, BUT ALSO SPECIFY A DATA PATTERN (PAT #0).
TEST 20
R=1000 / <CR>
FC=10 / <CR>
LC=10 / <CR>
IC=0 / <CR>
FT=2 / <CR>
LT=2 / <CR>
IT=1 / <CR>
FT'=0 / 2<CR>            ;RM05 PARAMETER
LT'=18 / 2<CR>          ;RM05 PARAMETER
IT'=1 / <CR>            ;RM05 PARAMETER
FS=4 / <CR>
LS=4 / <CR>
PAT=000400 / 401<CR> ;RUN WITH PATTERNS #8 & #0 (O-OPERATOR INPUT)
WD1=165555 / 125252<CR> ;FIRST WORD OF PATTERN 0
WD2=133333 / 52525..<CR> ;SECOND WORD OF PATTERN 0
; <..> START EXECUTION
    
```

EXAMPLE #9

```

DRIVE=0,1,4<CR>          ;TEST DRIVES 0,1, AND 4 IN SEQUENCE
TEST=0-5/<CR>           ;CHANGE TEST 5
TEST 0
R=10 / <CR>
FC=0 / <CR>
LC=822 / 1..<CR>       ;CHANGE LAST CYLINDER FROM 822 TO 1
;START PROGRAM EXECUTION.
    
```

514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570

5. SWITCH SETTINGS

5.1 OPERATIONAL SWITCH SETTINGS

IF THE PROGRAM IS BEING RUN ON A SWITCHLESS PROCESSOR THE PROGRAM WILL DETERMINE THAT THE HARDWARE SWITCH REGISTER IS NOT PRESENT AND WILL USE A 'SOFTWARE' SWITCH REGISTER. THE 'SOFTWARE' SWITCH REGISTER IS LOCATED AT LOCATION 176. THE SETTINGS OF THE 'SOFTWARE' SWITCHES ARE CONTROLLED THROUGH A KEYBOARD ROUTINE WHICH IS CALLED BY TYPING A 'CONTROL G'. THE PROGRAM WILL RECOGNIZE THE 'CONTROL G' AT ANY TIME EXCEPT WHEN THE PROGRAM IS IN KEYBOARD ENTRY MODE, OR IS AT A HIGHER PRIORITY PROCESSING AN DRIVE INTERRUPT. THE 'SOFTWARE' SWITCH VALUES ARE ENTERED AS AN OCTAL NUMBER IN RESPONSE TO THE PROMPT FROM THE SWITCH ENTRY ROUTINE:

'SWR = NNNNNN NEW ='

EACH TIME SWITCH SETTINGS ARE ENTERED, THE ENTIRE SWITCH REGISTER IMAGE MUST BE ENTERED. LEADING ZEROS ARE NOT REQUIRED. 'RUBOUT' AND 'CONTROL U' FUNCTIONS MAY BE USED TO CORRECT TYPING ERRORS DURING SWITCH ENTRY.

ON PROCESSORS WITH HARDWARE SWITCH REGISTERS, THE 'SOFTWARE' SWITCH REGISTER MAY BE USED, IF THE PROGRAM FINDS ALL 1'S IN THE SWITCHES. ALL SWITCH REGISTER REFERENCES WILL BE TO THE 'SOFTWARE' REGISTER AND THE PROCEDURES DESCRIBED ABOVE MUST BE FOLLOWED.

THE SWITCH SETTINGS ARE:

SW<15>=1	HALT ON ERROR
SW<14>=1	LOOP ON TEST
SW<13>=1	INHIBIT ERROR TYPEOUTS
SW<12>=1	TYPE TEST NUMBER
SW<11>=1	INHIBIT ITERATIONS
SW<10>=1	RING BELL ON ERROR
SW<09>=1	LOOP ON ERROR
SW<08>=1	PRINT ERROR MESSAGE ON LINE PRINTER
SW<07>=1	READ 'C.SWR' SETTINGS FROM TTY
SW<06>=1	INHIBIT TIME REPORTS (TESTS 12-15)
SW<05>=1	REPORT ONE ERROR PER SECTOR (TESTS 16 & 17)
SW<04>=1	INHIBIT WRITES (TEST 20)
SW<03>=1	INHIBIT WRITE CHECKS (TEST 20)
SW<02>=1	INHIBIT READ AND SOFTWARE COMPARES (TEST 20)
SW<01>=1	INHIBIT SOFTWARE COMPARES (TEST 20)
SW<00>=1	PERFORM READ AFTER WRITE CHECK ERROR (TEST 20)

5.2 CONTROL SWITCH SETTINGS

THE CONTROL SWITCH SETTINGS ARE ENTERED THROUGH THE KEYBOARD.

TO ENTER THE CONTROL SWITCH SETTING MODE PLACE SW<07>=1 BEFORE PRESSING START. THEN UPON STARTING THE PROGRAM IT WILL TYPE THE PRESENT CONTENTS OF THE CONTROL SWITCH REGISTER (C.SWR) AND WAIT FOR THE NEW SETTING TO BE INPUT. THE INPUT

571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627

STRING MUST CONSIST OF 1 TO 6 OCTAL DIGITS, TWO PERIODS (...), AND A CARRIAGE RETURN.

THE C.SWR SETTINGS ARE:

- C.SWR<15>=0 WRITE PACK BEFORE TESTING (TEST16)
- =1 INHIBIT WRITE PACK BEFORE TESTING (TEST16)
- C.SWR<14>=0 NO STALL BETWEEN DRIVE FUNCTIONS
- =1 STALL AFTER EVERY DRIVE FUNCTION
- C.SWR<13>=0 USE SPECIFIC STALL TIMES
- =1 USE RANDOM STALL TIMES
- C.SWR<12>=0 NO INCREMENTING STALLS IN TEST 4
- =1 PERFORM INCREMENTING STALLS IN TEST 4
- C.SWR<08>=0 DO IMPLIED SEEKS WITH DATA TRANSFERS
- =1 DO EXPLICIT SEEKS BEFORE DATA TRANSFERS
- C.SWR<07>=0 DO READ HEADER AND DATA COMMANDS IN TESTS 0-7
- =1 DO EXPLICIT SEEK COMMANDS IN TESTS 0-7
- C.SWR<06>=0 60 HZ POWER SOURCE
- =1 50 HZ POWER SOURCE
- C.SWR<05>=0 ALLOW SOFTWARE TIMEOUTS(ENABLE WATCHDOG TIMER)
- =1 INHIBIT SOFTWARE TIMEOUTS(DISABLE WATCHDOG TIMER)
- C.SWR<00>=0 OPERATE IN 32. SECTOR (16 BIT) MODE
- =1 OPERATE IN 30. SECTOR (18 BIT) MODE

THE DEFAULT CONDITION OF C.SWR<15:00>=0.

REFER TO 4.3.1 FOR C.SWR SELECTION

6. ERRORS

THERE ARE A NUMBER OF ERRORS THAT CAN OCCUR IN THIS PROGRAM. WHEN AN ERROR IS ENCOUNTERED, THE CALL TO THE ERROR ROUTINE IS MADE AND IF SW<13> IS NOT SET, AN ERROR MESSAGE PERTAINING TO THE ERROR WILL BE TYPED. EACH ERROR TYPEOUT WILL CONTAIN THE FOLLOWING:

1. AN ERROR MESSAGE
2. A DATA HEADER
3. A DATA STRING

REFER TO THE FOLLOWING SECTION FOR THE DIFFERENT ERRORS THAT CAN OCCUR.

6.1 ERROR TYPES

THE ERRORS THAT OCCUR IN THIS PROGRAM FALL INTO THREE (3) CATEGORIES DEFINED AND EXPLAINED AS FOLLOWS:

6.1.1 DRIVER ERROR

THESE ERRORS WILL BE DETECTED BY THE RH/RM DRIVER. THERE ARE TWO CLASSES OF DRIVER ERRORS; THOSE THAT CAN NOT BE IDENTIFIED IN A MANNER THAT ALLOWS THE

628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684

INFORMATION TO BE RETURNED TO A 'DATA PARAMETER BLOCK' (DPB) AND THOSE THAT CAN. THE FIRST CLASS WILL BE REPORTED BY ERROR CALLS (EMT'S) 1-5 WITHIN THE DRIVER. THE SECOND CLASS WILL PASS THE ERROR CODES TO THE STATUS/ERROR WORD (DPB+16) OF THE PROPER DPB.

6.1.2 NON-FATAL ERRORS

THESE ERRORS WILL BE DUE TO 'DISK' OR 'DATA' FAILURES WHICH WILL BE REPORTED AS THEY OCCUR. AFTER REPORTING THE ERROR THE PROGRAM WILL CONTINUE TESTING.

6.1.3 FATAL ERRORS

THIS TYPE OF ERROR WILL BE THE RESULT OF ANY KIND OF ERROR THAT INHIBITS THE PROGRAM FROM TESTING THE DISK.

THIS ERROR WILL BE REPORTED WHEN IT OCCURS, THEN THE PROGRAM WILL ABORT THE TEST AND GO TO THE END OF PROGRAM.

6.2 ERROR RECOVERY

6.2.1 PRETEST ERROR

WHEN THIS TYPE OF ERROR OCCURS IT WILL BE REPORTED. THEN DEPENDING ON HOW THE PROGRAM WAS STARTED IT WILL ASK FOR THE DRIVES AND ADDRESSES FOR TESTING OR RETURN TO MONITOR.

6.2.2 NON-FATAL ERROR

WHEN THIS TYPE OF ERROR OCCURS IT WILL BE REPORTED AND THE PROGRAM WILL CONTINUE IN TEST.

6.2.3 FATAL ERROR

WHEN THIS TYPE OF ERROR OCCURS IT WILL BE REPORTED. THE PROGRAM WILL ABORT THE TEST AND GO TO THE END OF PROGRAM.

7. RESTRICTIONS

THE PROGRAM WILL TEST THE DRIVES IN EITHER 16 BIT MODE OR IN 18 BIT MODE DEPENDING ON THE SETTING OF 'S.SWR<00>'. IF 'C.SWR<00>' IS 0, ALL OF THE DRIVES WILL BE TESTED IN 16 BIT MODE; IF 'C.SWR<00>' IS 1, ALL OF THE DRIVES WILL BE TESTED IN 18 BIT MODE. THE PROGRAM HAS NO PROVISIONS FOR TESTING DRIVES WITH INTERMIXED PACKS OR TESTING BOTH 16 BIT MODE AND 18 BIT MODE DRIVES ON THE SAME SYSTEM. ACT11 AUTOMATIC MODE ASSUMES 16 BIT MODE.

BEFORE THE PROGRAM IS STARTED, PROPERLY FORMATTED PACKS MUST BE MOUNTED ON THE DRIVES WHICH WILL BE TESTED. THE PROGRAM ASSUMES A PROPERLY FORMATTED PACK. THE FORMAT OF THE PACK IS NOT ALTERED BY THE PROGRAM.

685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741

8. MISCELLANEOUS

8.1 EXECUTION TIME

THE PROGRAM REQUIRES APPROXIMATELY 26 MINUTES TO MAKE ONE PASS WITH RM03/2 DRIVES AND APPROXIMATELY 35 MINUTES TO A PASS WITH RM05 DRIVES. THIS ASSUMES THE DEFAULT TEST SEQUENCE (TESTS 0-10,12,13 & 15-20) AND DEFAULT TEST PARAMETERS.

8.2 STACK POINTER

THE STACK POINTER IS INITIALLY SET TO 1100.

8.3 TIMING TESTS (TESTS 12-15) PRINTOUTS

AT THE COMPLETION OF EACH OF THE TIMING TESTS THE TIME OF THE MINIMUM SEEK, MAXIMUM SEEK, AND THE AVERAGE OF ALL OF THE SEEKS PERFORMED ARE TYPED ON THE TTY. THE NUMBER OF SEEKS THAT HAD TIMES BELOW THE MINIMUM TIME ALLOWED WILL BE TYPED ON THE SAME LINE AS THE MINIMUM TIME. THE NUMBER ABOVE THE MAXIMUM WILL BE TYPED ON THE SAME LINE AS THE MAXIMUM TIME, AND THE TOTAL NUMBER OF SEEKS PERFORMED WILL BE ON THE SAME LINE AS THE AVERAGE.

8.3.1 TIMING TOLERANCES

1. TEST 12 -- ROTATIONAL SPEED TIMES

--TIMES FOR RM05/3 DRIVES--

60 HZ
MINIMUM=16340 US
MAXIMUM=17000 US
NOMINAL=16670 US

50 HZ
MINIMUM=16250 US
MAXIMUM=17090 US
NOMINAL=16670 US

--TIMES FOR RM02 DRIVES--

60 HZ
MINIMUM=24500 US
MAXIMUM=25500 US
NOMINAL=25000 US

50 HZ
MINIMUM=24370 US
MAXIMUM=25630 US
NOMINAL=25000 US

742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798

2. TEST 13 -- ONE CYLINDER SEEK TIMES

MAXIMUM=6000 US

3. TEST 14 -- AVERAGE SEEK TIMING TEST (NOT DEFAULT)

MAXIMUM=30000 US

** THERE ARE NO SPECIFICATIONS GIVEN FOR AN AVERAGE SEEK TIME **
** ON THIS PARTICULAR DRIVE. THEREFORE, THIS TEST SHOULD BE **
** USED FOR REFERENCE ONLY. **

4. TEST 15 -- MAXIMUM SEEK TIMES

MAXIMUM=55000 US

** THERE IS NO SPECIFICATION GIVEN FOR THE MAXIMUM REVERSE **
** SEEK TIME ON THIS PARTICULAR DRIVE. THEREFORE, ANY REVERSE **
** SEEK TIMES ABOVE THE MAXIMUM TIME OF 55.0 MS WILL NOT BE **
** TYPED IN THE TIMING REPORT. HOWEVER, THE TIMING REPORT **
** WILL STILL TYPE THE MINIMUM, MAXIMUM AND AVERAGE TIMES **
** FOR THE REVERSE SEEKS. (SEE SECTION 8.3.2, EX. 2) **

8.3.2. TIMING TESTS PRINTOUT EXAMPLES

EXAMPLE #1

ROTATIONAL SPEED TIMES

MIN=16670 US
MAX=16690 US
AVG=16680 US 10 SEARCHES TIMED

ALLOWABLE ROTATIONAL SPEED LIMITS FOR RM05/3

MIN=16250 US
MAX=17090 US

ONE CYLINDER SEEK TIMES

* FORWARD
MIN=5350 US
MAX=6920 US
AVG=5550 US 821 SEEKS TIMED

* REVERSE
MIN=5140 US
MAX=5960 US
AVG=5430 US 822 SEEKS TIMED

ALLOWABLE ONE CYLINDER SEEK LIMIT

MAX=6000 US

AVERAGE SEEK TIMES

* FORWARD
MIN=27770 US
MAX=28640 US
AVG=28230 US 128 SEEKS TIMED
* REVERSE

799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855

MIN=27990 US
MAX=28550 US
AVG=28220 US 128 SEEKS TIMED

ALLOWABLE AVERAGE TIME LIMIT
MAX=30000 US

MAXIMUM SEEK TIMES

* FORWARD
MIN=49990 JS
MAX=51980 US
AVG=51010 US 128 SEEKS TIMED

* REVERSE
MIN=48120 US
MAX=50650 US
AVG=49340 US 128 SEEKS TIMED

ALLOWABLE MAXIMUM (FORWARD) SEEK TIME LIMIT
MAX=55000 US

EXAMPLE #2

ROTATIONAL SPEED TIMES

MIN=16670 US
MAX=16690 US
AVG=16680 US 10 SEARCHES TIMED

ALLOWABLE ROTATIONAL SPEED LIMITS FOR RM05/3

MIN=16250 US
MAX=17090 US

ONE CYLINDER SEEK TIMES

* FORWARD
MIN=5470 US
MAX=7940 US 3 ABOVE THE MAXIMUM OF 6000 US
AVG=5830 US 821 SEEKS TIMED

* REVERSE
MIN=5040 US
MAX=5970 US
AVG=5330 US 822 SEEKS TIMED

ALLOWABLE ONE CYLINDER SEEK LIMIT
MAX=6000 US

AVERAGE SEEK TIMES

* FORWARD
MIN=29730 US
MAX=32620 US 73 ABOVE THE MAXIMUM OF 30000 US
AVG=29900 US 128 SEEKS TIMED

* REVERSE
MIN=28620 US
MAX=32230 US 108 ABOVE THE MAXIMUM OF 30000 US
AVG=32800 US 128 SEEKS TIMED

ALLOWABLE AVERAGE TIME LIMIT

856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912

MAX=30000 US

MAXIMUM SEEK TIMES

* FORWARD

MIN=57510 US

MAX=57240 US 128 ABOVE THE MAXIMUM OF 55000 US

AVG=57020 US 128 SEEKS TIMED

* REVERSE

MIN=57050 US

MAX=57550 US

AVG=57210 US 128 SEEKS TIMED

ALLOWABLE MAXIMUM (FORWARD) SEEK TIME LIMIT

MAX=55000 US

8.4 END OF TEST

WITH ALL SWITCHES ON A '0' AN 'END OF PASS' MESSAGE WILL BE TYPED AT THE COMPLETION OF TESTING A DRIVE AND THE 'END OF TEST' TIMEOUT WILL OCCUR WHEN ALL DRIVES HAVE BEEN TESTED. ALSO, THE END OF TEST COULD OCCUR ON A DRIVE, IF THE MAXIMUM ERROR LIMIT IN LOCATION 'ERMAX' IS EXCEEDED.

9. PROGRAM DESCRIPTION

THIS PROGRAM CONTAINS NINETEEN TESTS NUMBERED 0-22 IN OCTAL. TESTS 0-7 & 11 WILL READ THE CYLINDER, TRACK, AND SECTOR INFORMATION FROM THE HEADER, USING A 'READ HEADER AND DATA' COMMAND, AND THEN CHECK THE INFORMATION FOR VALIDITY. THUS, INSURING THE SEEK OPERATION FUNCTIONS PROPERLY. TESTS 12-15 WILL MEASURE THE ROTATIONAL SPEED, THE ONE CYLINDER SEEK, THE AVERAGE SEEK AND THE MAXIMUM SEEK TIMES TO ENSURE THEY ARE ALL WITHIN THE TOLERANCES ALLOWED. TEST 16 AND 17 ENSURES THE SECTOR AND TRACK ADDRESSING CIRCUITRY WORKS PROPERLY. TEST 20 VERIFIES THE DATA STORAGE AND RETRIEVAL CAPABILITIES ARE FUNCTIONAL. AND TEST 21 WILL STRESS AND CHECK THE READ/WRITE AND SERVO SYSTEMS.

THE PROGRAM WILL START BY IDENTIFYING ITSELF AND DETERMINING ALL DRIVES THAT ARE AVAILABLE FOR TESTING. THEN BEGINNING WITH THE LOWEST NUMERICAL DRIVE AND PROCEEDING IN SEQUENTIAL ORDER. ALL OF THE DRIVES WILL BE TESTED. ONE PASS THROUGH THE TEST SEQUENCE (TESTS 0-10,12-20) WILL BE PERFORMED ON EACH DRIVE BEFORE MOVING TO THE NEXT DRIVE IN SEQUENCE. DRIVE TO BE TESTED WILL BE TYPED AT THE BEGINNING OF EACH PASS, AN 'END OF PASS' MESSAGE WILL BE TYPED AT THE COMPLETION OF EACH PASS, AND AN 'END OF TEST' MESSAGE WILL BE TYPED AFTER TESTING ALL DRIVES.

REFER TO THE FOLLOWING SECTIONS FOR DETAILED DESCRIPTIONS OF EACH TEST.

9.1 TEST 0 - RECAL/RANDOM SEEK TEST

913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969

THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A RECALIBRATE COMMAND AND THEN SEEK TO A RANDOM CYLINDER BETWEEN 'FC' AND 'LC'. AT THE COMPLETION OF BOTH COMMANDS, STATUS INDICATORS ARE CHECKED TO ENSURE THAT NO ERRORS OCCURRED.

THE PARAMETERS USED BY THE TEST ARE GIVEN BELOW:

R	-	200
FC	-	0
LC	-	822
FT	-	0
FT'	-	0
FS	-	0

9.2 TEST 1 - SEEK/SEEK TEST

THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A FORWARD SEEK CYCLE TO 'LC', 'LT', 'LS' FOLLOWED BY A REVERSE SEEK CYCLE TO 'FC', 'FT', 'FS'. AT THE COMPLETION OF EACH SEEK, THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.

THE PARAMETERS USED BY THE TEST ARE GIVEN BELOW:

R	-	100
FC	-	0
LC	-	256
IC	-	0
FT	-	0
LT	-	0
FT'	-	0
LT'	-	0
FS	-	0
LS	-	0

9.3 TEST 2 - INCREMENTAL SEEK TEST

THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE CYLINDER ADDRESS FROM 'FC' TO 'LC' BY THE INCREMENT 'IC'. WHEN THE RESULTANT CYLINDER ADDRESS (NC) EXCEEDS 'LC' REVERSE SEEK CYCLES ARE INITIATED; STARTING AT THE LAST LEGAL 'NC' AND DECREMENTING BY 'IC' UNTIL 'NC' IS LESS THAN 'FC'. AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.

THE PARAMETERS USED BY THE TEST ARE GIVEN BELOW:

R	-	1
FC	-	0
LC	-	822
IC	-	1
FT	-	0
FT'	-	0
FS	-	0

9.4 TEST 3 - STEPPING SEEK TEST

970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026

THIS TEST WILL COMMAND SEEK CYCLES TO CYLINDER 0,1,2,4, 8,16,32,64,128,256 AND 512. AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO VERIFY PROPER OPERATION.

THE PARAMETERS USED BY THE TEST ARE GIVEN BELOW:

R	-	8
FC	-	0
LC	-	512
IC	-	1
FT	-	0
FT'	-	0
FS	-	0

9.5 TEST 4 - OSCILLATING SEEK TEST

THIS TEST WILL COMMAND SEEK CYCLES FROM 'FC' TO 'NC' AND BACK TO 'FC'. 'NC' STARTS AT 'FC' AND INCREMENTS BY 'IC' UP TO CYLINDER 'LC', THEN IS DECREMENTED BY 'IC' BACK TO CYLINDER 'FC'. AT THE COMPLETION OF EVERY SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST:

R	-	1
FC	-	0
LC	-	822
IC	-	1
FT	-	0
FT'	-	0
FS	-	0

9.6 TEST 5 - CONVERGING/DIVERGING SEEK TEST

THIS TEST WILL CAUSE THE DRIVE TO EXECUTE FORWARD AND REVERSE SEEKS FROM 'NC1' AND 'NC2' RESPECTIVELY, 'NC1' WILL BE INCREMENTED BY 'IC' AND 'NC2' WILL BE DECREMENTED BY 'IC' UNTIL 'NC1' IS GREATER THAN THE INITIAL VALUE OF 'NC2' AND 'NC2' IS LESS THAN THE INITIAL VALUE OF 'NC1'. AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION. 'NC1' AND 'NC2' DEFAULT TO 'FC' AND 'LC' RESPECTIVELY.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST:

R	-	1
FC	-	0
LC	-	822
IC	-	1
FT	-	0
FT'	-	0
FS	-	0

9.7 TEST 6 - SERVO ADDRESSING LOGIC NOISE GENERATOR TEST

IN THIS TEST A SEEK IS DONE TO CYL 'NC' THEN A SEEK 'O

1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083

NC+4 THEN NC+1 THEN NC+3 THEN NC+2 THEN NC+5. NOW 'NC' IS UPDATED BY 'IC' AND THE ABOVE SEQUENCE IS REPEATED UNTIL 'LC' IS EXCEEDED BY ANY OF THE ABOVE VALUES. THE INITIAL VALUE OF 'NC' IS 'FC'. AT THE COMPLETION OF EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST:

R	-	1
FC	-	0
LC	-	822
IC	-	1
FT	-	0
FT'	-	0
FS	-	0

9.8 TEST 7 - RANDOM SEEK TEST

THIS TEST PERFORMS RANDOM SEEK OPERATIONS BETWEEN CYLINDERS 'FC' 'LC'. AFTER EACH SEEK, THE POSITION OF THE DRIVE IS VERIFIED BY READING A SECTOR FROM THE CURRENTLY ADDRESSED CYLINDER AND TRACK. THE TRACK ADDRESS IS INCREMENTED FOR EACH SEEK SO THAT VERIFICATION OF POSITIONING OCCURS USING EACH HEAD. TRACK ADDRESSES ARE INCREMENTED BETWEEN PARAMETERS 'FT' AND 'LT'.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST:

R	-	5000
FC	-	0
LC	-	822
FT	-	0
LT	-	4
FT'	-	0
LT'	-	18

9.9 TEST 10 - SERVO SETTLE DOWN TEST

THIS TEST VERIFIES THAT THE SERVO HAS SETTLED DOWN AND THAT THE DRIVE IS ON CYLINDER WHEN THE DRIVE INDICATES SEEK COMPLETE. RANDOM SEEKS ARE ISSUED BETWEEN CYLINDERS 'NC1' AND 'NC1+IC' ('NC1' STARTS AT VALUE 'FC'). AT THE COMPLETION OF 1000 (10) SEEKS, 'NC1' IS INCREMENTED BY VALUE 'IC' AND THE SEQUENCE IS REPEATED. THE TEST IS COMPLETED WHEN 'NC1' HAS BEEN INCREMENTED BEYOND 'LC'.

WHEN THE SEEK COMPLETES, THE PROGRAM READS THE DRIVE'S LOOK-AHEAD REGISTER (RMLA) TO DETERMINE THE ADDRESS OF THE SECTOR ROTATING INTO POSITION. THE PROGRAM THEN ISSUES A WRITE HEADER AND DATA COMMAND FOR THAT SECTOR. ERRORS IN THIS TEST INDICATE THAT THE SERVO SYSTEM MAY NOT BE ADJUSTED CORRECTLY, THAT THE DRIVE IS MALFUNCTIONING, OR THAT A PACK WITH MARGINAL SERVO TRACKS IS MOUNTED ON THE DRIVE.

THIS TEST IS VALID ONLY IF THE OPERATION IS STARTED WITHIN A FEW HUNDRED MICRO-SECONDS AFTER SEEK DONE OCCURS. THE NECESSARY TIME DEPENDENT PARAMETERS OCCUR WITHIN THE REQUIRED TIME RANGE FREQUENTLY ENOUGH TO PERMIT THIS TEST TO BE EFFECTIVE.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST:

1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140

R	-	1
FC	-	0
LC	-	822
IC	-	100
FT	-	0
FT'	-	0

9.10 TEST 11 - ALL SEEKS TEST (NOT DEFAULT)

THIS TEST VERIFIES THAT THE DISK DRIVE CAN SEEK FROM EACH CYLINDER TO ALL OTHER CYLINDERS.

BEGINNING WITH CYLINDER 'FC', THE TEST SEEKS TO EACH CYLINDER BETWEEN 'FC' AND 'LC' FROM CYLINDER 'FC'. THE BEGINNING CYLINDER ADDRESS IS INCREMENTED AND THE TEST SEEKS BETWEEN THE NEW CYLINDER ADDRESS AND ALL CYLINDERS BETWEEN 'FC' AND 'LC'. THE SEQUENCE CONTINUES UNTIL ALL CYLINDERS HAVE BEEN CHECKED.

THE FOLLOWING PARAMETERS ARE USED BY THIS TEST:

R	-	1
FC	-	0
LC	-	822
IC	-	1
FT	-	0
FT'	-	0
FS	-	0

9.11 TEST 12 - ROTATIONAL SPEED TIMING TEST

THIS TEST WILL START A SEARCH TO CYLINDER 'FC', TRACK 'FT', SECTOR 'FS'. AS SOON AS THE INTERRUPT OCCURS, THE GO BIT IS SET AGAIN AND THE OPERATION IS TIMED. THIS PROCEDURE IS REPEATED 10 TIMES THEN THE AVERAGE TIME IS CALCULATED AND CHECKED TO ENSURE IT IS WITHIN TOLERANCE:

RM05/3:
16.67 MS/REV + OR - 2% IF 60HZ
16.67 MS/REV + OR - 2.5% IF 50HZ.

RM02:
25.00 MS/REV + OR - 2% IF 60HZ
25.00 MS/REV + OR - 2.5% IF 50HZ.

THE FOLLOWING PARAMETERS ARE USED BY THE TEST:

R	-	1
FC	-	0
FT	-	0
FT'	-	0
FS	-	0

9.12 TEST 13 - ONE CYLINDER SEEK TIMING TEST

THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE CYLINDER BY ONE UNTIL THE INCREMENT IS GREATER THAN THE

1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197

CYLINDER 'LC', THEN REVERSE SEEK TO CYLINDER 'FC'. THE TIME TO PERFORM EACH SEEK IS CHECKED TO ENSURE IT DOES NOT EXCEED THE MAXIMUM TIME PERMITTED FOR A ONE CYLINDER SEEK. MAXIMUM TIME IS 6.0 MS.

THE TEST USES THE FOLLOWING PARAMETERS:

R	-	1
FC	-	0
LC	-	822

9.13 TEST 14 - AVERAGE SEEK TIMING TEST (NOT DEFAULT)

THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 'FC' TO CYLINDER 'LC', THEN A REVERSE FROM CYLINDER 'LC' TO CYLINDER 'FC'. BOTH SEEKS ARE TIMED AND CHECKED TO ENSURE THEY ARE WITHIN THE TOLERANCE ALLOWED FOR THE AVERAGE SEEK. THIS SEQUENCE IS REPEATED 128 TIMES (FOR A TOTAL OF 256. SEEKS). MAXIMUM TIME IS 30.0 MS.

** THERE ARE NO SPECIFICATIONS GIVEN FOR AN AVERAGE SEEK TIME **
 ** ON THIS PARTICULAR DRIVE. THEREFORE, THIS TEST SHOULD BE **
 ** USED FOR REFERENCE ONLY. **

THE TEST USES THE FOLLOWING PARAMETERS:

R	-	1
FC	-	0
LC	-	220

9.14 TEST 15 - MAXIMUM SEEK TIMING TEST

THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 'FC' TO CYLINDER 'LC', THEN A REVERSE SEEK FROM CYLINDER 'LC' TO CYLINDER 'FC'. BOTH SEEKS ARE TIMED, BUT ONLY THE FORWARD SEEKS ARE CHECKED TO ENSURE THEY ARE WITHIN THE TOLERANCE ALLOWED FOR THE MAXIMUM SEEK TIME. THIS SEQUENCE IS REPEATED 128 TIMES (FOR A TOTAL OF 256. SEEKS). THE MAXIMUM (FORWARD) TIME IS 55.0 MS.

** THERE IS NO SPECIFICATION GIVEN FOR THE MAXIMUM REVERSE **
 ** SEEK TIME ON THIS PARTICULAR DRIVE. THEREFORE, ANY REVERSE **
 ** SEEK TIMES ABOVE THE MAXIMUM TIME OF 55.0 MS WILL NOT BE **
 ** TYPED IN THE TIMING REPORT. HOWEVER, THE TIMING REPORT **
 ** WILL STILL TYPE THE MINIMUM, MAXIMUM AND AVERAGE TIMES **
 ** FOR THE REVERSE SEEKS. (SEE SECTION 8.3.2, EX. 2) **

THE TEST USES THE FOLLOWING PARAMETERS:

R	-	1
FC	-	0
LC	-	822

9.15 TEST 16 - SECTOR ADDRESSING TEST

THIS TEST WRITES DATA INTO ALL SECTORS OF TRACK 'FT'. THE DATA WILL BE 256 WORDS OF THE SECTOR ADDRESS OF THE SECTOR BEING WRITTEN. A WRITE CHECK IS PERFORMED, THE BUFFER IS

1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254

CLEARED (TO 177400) AND THE DATA IS READ AND COMPARED. THEN SECTOR IS REWRITTEN AND SECTORS 0 - 31 ARE WRITE CHECKED. THEN SECTOR 1 IS REWRITTEN AND SECTORS 0 - 31 ARE WRITE CHECKED. THIS REWRITE AND WRITE CHECK PROCEDURE IS CONTINUED UP THROUGH REWRITE SECTOR 31 AND WRITE CHECK SECTORS 0-31.

THE TEST USES THE FOLLOWING PARAMETERS:

```
R      -      1
FC     -      0
FT     -      0
FT'    -      0
```

9.16 TEST 17 - TRACK ADDRESSING TEST

THIS TEST WILL WRITE DATA IN THE FORM OF TRACK ADDRESSES IN CYLINDER 'FC' SECTOR 'FS' OF EVERY TRACK WITH EACH TRACK GETTING ITS OWN TRACK ADDRESS. A WRITE CHECK IS THEN PERFORMED ON EACH TRACK TO INSURE THE DATA IS VALID. THEN TRACK 0 IS REWRITTEN AND TRACK 1 THROUGH LAST TRACK IS WRITE CHECKED. THEN TRACK 1 IS REWRITTEN AND TRACK 2 THROUGH LAST TRACK IS WRITE CHECKED. THIS PROCEDURE IS CONTINUED UP THROUGH REWRITING NEXT TO LAST TRACK AND WRITE CHECKING LAST TRACK.

THE TEST USES THE FOLLOWING PARAMETERS:

```
R      -      1
FC     -      0
FS     -      0
```

9.17 TEST 20 - DATA TEST

THIS TEST PERFORMS DATA STORAGE AND RETRIEVAL ON CYLINDERS 'FC' THROUGH 'LC' BY THE INCREMENT 'IC' USING THE DATA PATTERNS SPECIFIED. THE FOLLOWING SEQUENCE OCCURS FOR EACH CYLINDER:

1. SET 'NT' TO 'FT' THEN REPEAT 2-4 UNTIL 'NT' > 'LT'
2. WRITE THEN WRITE CHECK 'FS' THROUGH 'LS' OF TRACK 'NT'
3. READ THEN SOFTWARE COMPARE 'FS' THROUGH 'LS' OF TRACK 'NT'
4. INCREMENT 'NT' BY 'IT'
5. REPEAT STEPS 1-4 FOR EACH DATA PATTERN
6. REPEAT STEPS 1-5 FOR 'FC' THROUGH 'LC' ADVANCING BY 'IC'

IF A WRITE CHECK ERROR OCCURS THE ERROR IS REPORTED AND THE TRACK IN ERROR IS REWRITTEN AND CHECKED. THIS CHECK IS ACCOMPLISHED BY PERFORMING TWO(2) SUCCESSIVE ERROR FREE WRITE CHECKS. IF THE CHECK FAILS THE ERROR IS REPORTED AS FATAL AND NO READ OCCURS.

FS DEFAULTS TO 1 AND LS DEFAULTS TO 0
PAT DEFAULTS TO 177777 (ALL POSSIBLE PATTERNS)
THE POSSIBLE PATTERNS ARE:

*PAT 0	PAT 1	PAT 2	PAT 3	PAT 4	PAT 5	PAT 6	PAT 7
155555	000001	177776	000000	133331	052525	155555	026455
133333	000003	177774	000000	133331	052525	155555	026455
155555	000007	177770	000000	133331	052525	155555	026455

1255	133333	000017	177760	177777	133331	125252	155555	151322
1256	155555	000037	177740	177777	133331	125252	155555	151322
1257	133333	000077	177700	177777	133331	125252	155555	151322
1258	155555	000177	177600	000000	133331	052525	155555	026455
1259	133333	000377	177400	000000	133331	052525	155555	026455
1260	155555	000777	177000	177777	133331	125252	155555	151322
1261	133333	001777	176000	177777	133331	125252	155555	151322
1262	155555	003777	174000	000000	133331	052525	155555	026455
1263	133333	007777	170000	177777	133331	125252	155555	151322
1264	155555	017777	160000	000000	133331	052525	155555	026455
1265	133333	037777	140000	177777	133331	125252	155555	151322
1266	155555	077777	100000	000000	133331	052525	155555	026455
1267	133333	177777	000000	177777	133331	125252	155555	151322

1268								
1269	*PAT 8	PAT 9	PAT 10	PAT 11	PAT 12	PAT 13	PAT 14	PAT 15
1270	-----	-----	-----	-----	-----	-----	-----	-----
1271	155555	000001	177776	172666	077777	153333	000000	177777
1272	133333	000002	177775	155555	137777	066667	177777	000000
1273	155555	000004	177773	172666	157777	153333	177777	000000
1274	133333	000010	177767	155555	167777	066667	177777	000000
1275	155555	000020	177757	172666	173777	153333	177777	000000
1276	133333	000040	177737	155555	175777	066667	177777	000000
1277	155555	000100	177677	172666	176777	153333	177777	000000
1278	133333	000200	177577	155555	177377	066667	177777	000000
1279	155555	000400	177377	172666	177577	153333	177777	000000
1280	133333	001000	176777	155555	177677	066667	177777	000000
1281	155555	002000	175777	172666	177377	153333	177777	000000
1282	133333	004000	173777	155555	177577	066667	177777	000000
1283	155555	010000	167777	172666	177677	153333	177777	000000
1284	133333	020000	157777	155555	177773	066667	177777	000000
1285	155555	040000	137777	172666	177775	153333	177777	000000
1286	133333	100000	077777	155555	177776	066667	177777	000000

* WORST CASE PATTERN

THE TEST USES THE FOLLOWING PARAMETERS:

R	-	1
FC	-	0
LC	-	822
IC	-	64
FT	-	0
LT	-	4
IT	-	1
FT'	-	0
LT'	-	18
IT'	-	1
FS	-	1
LS	-	0
PAT	-	177777

9.18 TEST 21 - RANDOM ADDRESS AND RANDOM PATTERN TEST

STARTING AT 'FC' AND GOING THROUGH 'LC' THE DISK PACK IS WRITTEN WITH A RANDOM PATTERN. THE FIRST TWO WORDS OF EACH SECTOR WILL BE THE BASE OF THE RANDOM GENERATOR FOR THAT SECTOR.

1311

1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352

THE TEST THEN PERFORMS THE FOLLOWING SEQUENCE 'R' TIMES
'R' DEFAULTS TO 20,000.

- 1) GENERATE A RANDOM ADDRESS
- 2) WRITE A RANDOM PATTERN AT THE ADDRESS GENERATED IN 1.
- 3) GENERATE A RANDOM ADDRESS
- 4) READ THE SECTOR AT THE ADDRESS GENERATED IN 3.
- 5) DO A SOFTWARE CHECK OF THE DATA READ IN 4.
- 6) DO A WRITE CHECK OF THE DATA WRITTEN IN 2
- 7) GENERATE A RANDOM ADDRESS
- 8) READ THE SECTOR AT THE ADDRESS GENERATED IN 7.
- 9) DO A SOFTWARE CHECK OF THE DATA READ IN 8
- 10) DO A WRITE CHECK OF THE DATA WRITTEN IN 2

THE TEST USES THE FOLLOWING PARAMETERS:

R	-	20000
FC	-	0
LC	-	822

9.19 TEST 22 - SEEK TIME ADJUSTMENT TEST

THIS TEST PERFORMS SEEKS BETWEEN CYLINDERS 0 & 255 TO ALLOW THE OPERATOR TO ADJUST THE SEEK TIME ON AN RM05/3/2 USING THE DDU. THE PROGRAM STALLS APPROXIMATELY 5 SECONDS BETWEEN SEEKS SO THAT THE SEEK TIME INDICATORS ON THE DDU MAY BE OBSERVED.

THE TEST USES THE FOLLOWING PARAMETERS:

R	-	5000
FC	-	0
LC	-	255

10. PROGRAM LISTING

@

36
37

38

39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71

*LAST REVISION 04-APR-81

*TITLE CZPMVBC RM05/3/2 EXT'D DR TST

*COPYRIGHT (C) 1981
*DIGITAL EQUIPMENT CORPORATION
*COLORADO SPGS., CO. 80919

*PROGRAM BY MIKE LEAVITT

*THIS PROGRAM WAS ASSEMBLED USING THE PDP-11 MAINDEC SYSMAC
*PACKAGE (MAINDEC-11-DZQAC-C5), 18-MAR-81

.SBTTL OPERATIONAL SWITCH SETTINGS

SWITCH	USE
15	HALT ON ERROR
14	LOOP ON TEST
13	INHIBIT ERROR TYPEOUTS
12	TYPE TEST NUMBER
10	BELL ON ERROR
9	LOOP ON ERROR
8	PRINT ERROR MESSAGE ON LINE PRINTER
7	READ 'C.SWR' SETTINGS FROM TTY
6	INHIBIT TIME REPORTS (TESTS 12-15)
5	REPORT ONE ERROR PER SECTOR (TESTS 16 & 17)
4	INHIBIT WRITES (TEST 20)
3	INHIBIT WRITE CHECKS (TEST 20)
2	INHIBIT READ AND SOFTWARE COMPARES (TEST 20)
1	INHIBIT SOFTWARE COMPARES (TEST 20)
0	PERFORM READ AFTER WRITE CHECK ERROR (TEST 20)

.SBTTL CONTROL SWITCH SETTINGS

SWITCH	STATE	USE
15	0	WRITE PACK BEFORE TESTING (TEST 21)
	1	INHIBIT WRITING PACK BEFORE TESTING (TEST 21)
14	0	NO STALL BETWEEN DRIVE FUNCTIONS
	1	STALL AFTER EVERY DRIVE FUNCTION
13	0	USE SPECIFIC STALL TIME
	1	USE RANDOM STALL
12	0	NO INCREMENTING STALL IN TEST 4
	1	DO INCREMENTING STALL IN TEST 4
8	0	DO IMPLIED SEEKS WITH DATA TRANSFERS
	1	DO EXPLICIT SEEKS BEFORE DATA TRANSFERS
7	0	DO 'READ HEADER AND DATA' IN TESTS 0-11
	1	DO EXPLICIT SEEKS IN TESTS 0-11
6	0	60 HZ
	1	50 HZ
5	0	RUN WATCHDOG TIMER
	1	INHIBIT WATCHDOG TIMER
0	0	TEST DRIVE(S) IN 32. SECTOR (16 BIT) MODE
	1	TEST DRIVE(S) IN 30. SECTOR (8 BIT) MODE

.SBTTL BASIC DEFINITIONS

BASIC DEFINITIONS

```

001100      ;*INITIAL ADDRESS OF THE STACK POINTER *** 1100 ***
104000      STACK = 1100
000004      ERROR = EMT          ;;BASIC DEFINITION OF ERROR CALL
           SCOPE = IOT          ;;BASIC DEFINITION OF SCOPE CALL

;*MISCELLANEOUS DEFINITIONS
000011      HT = 11             ;;CODE FOR HORIZONTAL TAB
000012      LF = 12             ;;CODE FOR LINE FEED
000015      CR = 15             ;;CODE FOR CARRIAGE RETURN
000200      CRLF = 200          ;;CODE FOR CARRIAGE RETURN-LINE FEED
177776      PS = 177776        ;;PROCESSOR STATUS WORD
177776      PSW=PS
177774      STKLMY = 177774     ;;STACK LIMIT REGISTER
177772      PIRQ = 177772       ;;PROGRAM INTERRUPT REQUEST REGISTER
177570      DSWR = 177570       ;;HARDWARE SWITCH REGISTER
177570      DDISP = 177570      ;;HARDWARE DISPLAY REGISTER

;*GENERAL PURPOSE REGISTER DEFINITIONS
000000      R0 = %0             ;;GENERAL REGISTER
000001      R1 = %1             ;;GENERAL REGISTER
000002      R2 = %2             ;;GENERAL REGISTER
000003      R3 = %3             ;;GENERAL REGISTER
000004      R4 = %4             ;;GENERAL REGISTER
000005      R5 = %5             ;;GENERAL REGISTER
000006      R6 = %6             ;;GENERAL REGISTER
000007      R7 = %7             ;;GENERAL REGISTER
000006      SP = %6             ;;STACK POINTER
000007      PC = %7             ;;PROGRAM COUNTER

;*PRIORITY LEVEL DEFINITIONS
000000      PR0 = 0             ;;PRIORITY LEVEL 0
000040      PR1 = 40            ;;PRIORITY LEVEL 1
000100      PR2 = 100           ;;PRIORITY LEVEL 2
000140      PR3 = 140           ;;PRIORITY LEVEL 3
000200      PR4 = 200           ;;PRIORITY LEVEL 4
000240      PR5 = 240           ;;PRIORITY LEVEL 5
000300      PR6 = 300           ;;PRIORITY LEVEL 6
000340      PR7 = 340           ;;PRIORITY LEVEL 7

;*'SWITCH REGISTER' SWITCH DEFINITIONS
100000      SW15 = 100000
040000      SW14 = 40000
020000      SW13 = 20000
010000      SW12 = 10000
004000      SW11 = 4000
002000      SW10 = 2000
001000      SW09 = 1000
000400      SW08 = 400
000200      SW07 = 200
000100      SW06 = 100
000040      SW05 = 40
000020      SW04 = 20
000010      SW03 = 10
000004      SW02 = 4
000002      SW01 = 2
000001      SW00 = 1
001000      SW9-SW09

```

BASIC DEFINITIONS

```

000400      SW8=SW08
000200      SW7=SW07
000100      SW6=SW06
000040      SW5=SW05
000020      SW4=SW04
000010      SW3=SW03
000004      SW2=SW02
000002      SW1=SW01
000001      SW0=SW00
    
```

;*DATA BIT DEFINITIONS (BIT00 TO BIT15)

```

100000      BIT15 = 100000
040000      BIT14 = 40000
020000      BIT13 = 20000
010000      BIT12 = 10000
004000      BIT11 = 4000
002000      BIT10 = 2000
001000      BIT09 = 1000
000400      BIT08 = 400
000200      BIT07 = 200
000100      BIT06 = 100
000040      BIT05 = 40
000020      BIT04 = 20
000010      BIT03 = 10
000004      BIT02 = 4
000002      BIT01 = 2
000001      BIT00 = 1
001000      BIT9=BIT09
000400      BIT8=BIT08
000200      BIT7=BIT07
000100      BIT6=BIT06
000040      BIT5=BIT05
000020      BIT4=BIT04
000010      BIT3=BIT03
000004      BIT2=BIT02
000002      BIT1=BIT01
000001      BIT0=BIT00
    
```

;*BASIC "CPU" TRAP VECTOR ADDRESSES

```

000004      ERRVEC = 4          ;;TIME OUT AND OTHER ERRORS
000010      RESVEC = 10        ;;RESERVED AND ILLEGAL INSTRUCTIONS
000014      TBITVEC = 14       ;;'T' BIT
000014      TRTVEC = 14        ;;TRACE TRAP
000014      BPTVEC = 14        ;;BREAKPOINT TRAP (BPT)
000020      IOTVEC = 20        ;;INPUT/OUTPUT TRAP (IOT) **SCOPE**
000024      PWRVEC = 24        ;;POWER FAIL
000030      EMTVEC = 30        ;;EMULATOR TRAP (EMT) **ERROR**
000034      TRAPVEC = 34       ;;'TRAP' TRAP
000060      TKVEC = 60         ;;TTY KEYBOARD VECTOR
000064      TPVEC = 64         ;;TTY PRINTER VECTOR
000240      PIRQVEC = 240      ;;PROGRAM INTERRUPT REQUEST VECTOR
    
```

.SBITL RH REGISTERS

;;CONTROL AND STATUS REGISTER 1 (RMCS1)

```

000100      IE = 100          ;;INTERRUPT ENABLE (BIT #6)
    
```

72
73
74
75
76
77

78	000200	RDY	= 200	;READY (BIT #7)
79	000400	A16	= 400	;HIGH ORDER BUS ADDRESS BIT (BIT #8)
80	001000	A17	= 1000	;HIGH ORDER BUS ADDRESS BIT (BIT #9)
81	002000	PSEL	= 2000	;PORT SELECT (BIT #10)
82	020000	MCPE	= 20000	;MASSBUS PARITY ERROR (BIT #13)
83	040000	TRE	= 40000	;TRANSFER ERROR (BIT #14)
84		;SC	= 100000	;SPECIAL CONDITION (BIT #15)
85				
86				;WORD COUNT REGISTER (RMWC)
87				;(EACH BIT IS CALLED BY BIT NUMBER)
88				
89				;BUS ADDRESS REGISTER (RMBA)
90				;(EACH BIT IS CALLED BY BIT NUMBER)
91				
92				;CONTROL AND STATUS REGISTER 2 (RMCS2)
93				
94	000001	US1	= 1	;UNIT SELECT (BIT #0)
95	000002	US2	= 2	;UNIT SELECT (BIT #1)
96	000004	US4	= 4	;UNIT SELECT (BIT #2)
97	000010	BAI	= 10	;BUS ADDRESS INCREMENT INHIBIT (BIT #3)
98		;PAT	= 20	;MASSBUS PARITY TEST (BIT #4)
99	000040	CLR	= 40	;CLEAR (BIT #5)
100	000100	IR	= 100	;INPUT READY (BIT #6)
101	000200	OR	= 200	;OUTPUT READY (BIT #7)
102	000400	MPE	= 400	;MASS BUS PARITY ERROR (BIT #8)
103	001000	MXF	= 1000	;MISSED TRANSFER ERROR (BIT #9)
104	002000	PGE	= 2000	;PROGRAM ERROR (BIT #10)
105	004000	NEM	= 4000	;NON EXISTENT MEMORY (BIT #11)
106	010000	NED	= 10000	;NON EXISTENT DRIVE (BIT #12)
107	020000	UPE	= 20000	;UNIBUS PARITY ERROR (BIT #13)
108	040000	WCE	= 40000	;WRITE CHECK ERROR (BIT #14)
109	100000	DLT	= 100000	;DATA LATE (BIT #15)
110				
111				;DATA BUFFER REGISTER (RMDB)
112				;(EACH BIT IS CALLED BY BIT NUMBER)
113				
114				.SBTTL RM REGISTERS
115				
116				;CONTROL AND STATUS 1 REGISTER. (#00)
117				
118	000001	GO	= 1	;GO BIT (BIT #0)
119	000002	F1	= 2	;FUNCTION CODE BIT #1
120	000004	F2	= 4	;FUNCTION CODE BIT #2
121	000010	F3	= 10	;FUNCTION CODE BIT #3
122	000020	F4	= 20	;FUNCTION CODE BIT #4
123	000040	F5	= 40	;FUNCTION CODE BIT #5
124	004000	DVA	= 4000	;DEVICE AVAILABLE (BIT #11)
125				
126				;DRIVE STATUS REGISTER (RMDS, (#01)
127				
128	000001	OM	= 1	;OFFSET MODE
129	000100	VV	= 100	;VOLUME VALID (BIT #6)
130	000200	DRY	= 200	;DRIVE READY (BIT #7)
131	000400	DPR	= 400	;DRIVE PRESENT (BIT #8)
132	001000	PGM	= 1000	;PROGRAMABLE (BIT #9)
133	002000	LST	= 2000	;LAST SECTOR TRANSFERRED (BIT #10)
134	004000	WRL	= 4000	;WRITE LOCK (BIT #11)

135	010000	MOL	= 10000	:MEDIUM ON-LINE (BIT #12)
136	020000	PIP	= 20000	:POSITIONING OPERATION IN PROGRESS (BIT #13)
137	040000	ERR	= 40000	:COMPOSITE ERROR (BIT #14)
138	100000	ATA	= 100000	:ATTENTION ACTIVE (BIT #15)
139				
140		;ERROR REGISTER #01 (RMER1) (#02)		
141				
142	000001	ILF	= 1	:ILLEGAL FUNCTION (BIT #0)
143	000002	ILR	= 2	:ILLEGAL REGISTER (BIT #1)
144	000004	RMR	= 4	:REGISTER MODIFICATION REFUSED (BIT #2)
145	000010	PAR	= 10	:PARITY ERROR (BIT #3)
146	000020	FER	= 20	:FORMAT ERROR (BIT #4)
147	000040	WCF	= 40	:WRITE CLOCK FAIL (BIT #5)
148	000100	ECH	= 100	:ECC HARD ERROR (BIT #6)
149	000200	HCE	= 200	:HEADER COMPARE ERROR (BIT #7)
150	000400	HCRC	= 400	:HEADER CRC ERROR (BIT #8)
151	001000	AOE	= 1000	:ADDRESS OVERFLOW ERROR (BIT #9)
152	002000	IAE	= 2000	:INVALID ADDRESS ERROR (BIT #10)
153	004000	WLE	= 4000	:WRITE LOCK ERROR (BIT #11)
154	010000	DTE	= 10000	:DRIVE TIMING ERROR (BIT #12)
155	020000	OPT	= 20000	:OPERATION INCOMPLETE (BIT #13)
156	040000	UNS	= 40000	:DRIVE UNSAFE (BIT #14)
157	100000	DCK	= 100000	:DATA CHECK ERROR (BIT 15)
158				
159		;MAINTAINABILITY REGISTER #01 (RMMR1) (#03) - READ ONLY BITS		
160				
161	000001	DMD	= 1	:DIAGNOSTIC MODE
162	000002	LSIT	= 2	
163		:LS	= 4	
164	000010	WD	= 10	
165	000020	EECC	= 20	
166	000040	WC	= 40	
167	000100	CONT	= 100	
168	000200	PHA	= 200	
169	000400	PDA	= 400	
170	001000	ECRC	= 1000	
171	002000	PLFS	= 2000	
172	004000	ESRC	= 4000	
173	010000	REX	= 10000	
174	020000	EBL	= 20000	
175		:R/G	= 40000	
176	100000	OCC	= 100000	
177				
178		;MAINTAINABILITY REGISTER #01 (RMMR1) (#03) - WRITE ONLY BITS		
179				
180	000001	DMD	= 1	:DIAGNOSTIC MODE BIT
181	000002	MSC	= 2	
182	000004	MJ	= 4	
183	000010	MWP	= 10	
184	000020	DTG	= 20	
185	000040	MS	= 40	
186	000100	MDF	= 100	
187	000200	MSER	= 200	
188	000400	MOC	= 400	
189	001000	MUR	= 1000	
190	002000	MRD	= 2000	
191	004000	MCLK	= 4000	

192 010000
 193 020000
 194 040000
 195 100000

MSEN = 10000
 DT0 = 20000
 OBEN = 40000
 OBCK = 100000

;ATTENTION SUMMARY PSEUDO-REGISTER (RMAS) (#04)

199 000001
 200 000002
 201 000004
 202 000010
 203 000020
 204 000040
 205 000100
 206 000200

AT0 = 1 ;DEVICE 0 (BIT #0)
 AT1 = 2 ;DEVICE 1 (BIT #1)
 AT2 = 4 ;DEVICE 2 (BIT #2)
 AT3 = 10 ;DEVICE 3 (BIT #3)
 AT4 = 20 ;DEVICE 4 (BIT #4)
 AT5 = 40 ;DEVICE 5 (BIT #5)
 AT6 = 100 ;DEVICE 6 (BIT #6)
 AT7 = 200 ;DEVICE 7 (BIT #7)

;DESIRED SECTOR/TRACK ADDRESS REGISTER (RMDA) (#05)
 ;(EACH BIT IS CALLED BY BIT NUMBER)

;DRIVE TYPE REGISTER (RMDT) (#06)

213 000001
 214 000002
 215 000004
 216 000010
 217 000020
 218 000040
 219 000100
 220 000200
 221 000400
 222 004000
 223 020000
 224 040000
 225 100000

DT00 = 1 ;DRIVE TYPE NUMBER BIT 1
 DT01 = 2 ;DRIVE TYPE NUMBER BIT 2
 DT02 = 4 ;DRIVE TYPE NUMBER BIT 3
 DT03 = 10 ;DRIVE TYPE NUMBER BIT 4
 DT04 = 20 ;DRIVE TYPE NUMBER BIT 5
 DT05 = 40 ;DRIVE TYPE NUMBER BIT 6
 DT06 = 100 ;DRIVE TYPE NUMBER BIT 7
 DT07 = 200 ;DRIVE TYPE NUMBER BIT 8
 DT08 = 400 ;DRIVE TYPE NUMBER BIT 9
 DRQ = 4000 ;DRIVE REQUEST REQUIRED (BIT #11)
 MOH = 20000 ;MOVING HEAD (BIT #13)
 TAP = 40000 ;TAPE DRIVE (BIT #14)
 NBA = 100000 ;NOT BLOCK ADDRESSED (BIT #15)

;LOOK-AHEAD REGISTER (RMLA) (#07)

230 000100
 231 000200
 232 000400
 233
 234
 235

SC0 = 100 ;SECTOR COUNT FIELD 0 (BIT #6)
 SC1 = 200 ;SECTOR COUNT FIELD 1 (BIT #7)
 SC2 = 400 ;SECTOR COUNT FIELD 2 (BIT #8)
 ;SC3 = 1000 ;SECTOR COUNT FIELD 3 (BIT #9)
 ;SC4 = 2000 ;SECTOR COUNT FIELD 4 (BIT #10)

;RM MAINTAINABILITY REGISTER #2 (RMR2) (#10)

;RM ERROR REGISTER #02 (RMR2) (#10)

;OFFSET REGISTER (RMOF) (#11)

243 000200
 244 002000
 245 004000
 246 010000

OFD = 200 ;OFFSET DIRECTION (BIT #07)
 HCI = 2000 ;HEADER COMPARE INHIBIT (BIT #10)
 ECI = 4000 ;ERROR CORRECTION CODE INHIBIT (BIT #11)
 FMT16 = 10000 ;FORMAT BIT (BIT #12)

;DESIRED CYLINDER ADDRESS (RMDC) (#12)

247
 248


```

249      : (EACH BIT IS CALLED BY BIT NUMBER)
250
251      : CURRENT CYLINDER ADDRESS (RMHR) (#13)
252      : (EACH BIT IS CALLED BY BIT NUMBER)
253
254      : SERIAL NUMBER REGISTER (RMSN) (#14)
255      : (EACH IS CALLED BY BIT NUMBER)
256
257
258      : RM ERROR REGISTER #02 (RMER2) (#15)
259
260      020000      OPE      = 20000      : OPERATOR PLUG ERROR (BIT #13)
261      040000      SKI      = 40000      : SEEK INCOMPLETE (BIT #14)
262      100000      BSE      = 100000     : BAD SECTOR ERROR (BIT #15)
263
264      : ECC POSITION REGISTER (RMEC1) (#16)
265      : (EACH BIT IS CALLED BY BIT NUMBER)
266
267      : ECC PATTERN REGISTER (RMEC2) (#17)
268      : (EACH BIT IS CALLED BY BIT NUMBER)
269
270      : *****
271
272      : OP CODE DEFINITIONS
273      000101      NOOP      = 101
274      000103      UNLOAD    = 103
275      000105      SEEK      = 105
276      000107      RECAL     = 107
277      000111      DRVCLR    = 111
278      000113      RELEASE   = 113
279      000115      OFFSET    = 115
280      000117      RTC       = 117
281      000121      READIN    = 121
282      000123      PACK      = 123
283      000131      SEARCH    = 131
284      000151      WRCKD     = 151
285      000153      WRCKHD    = 153
286      000161      WRITE     = 161
287      000163      WRTHD     = 163
288      000171      READ      = 171
289      000173      READHD    = 173
290      000141      GETREG    = 141
291      000143      SETFORM   = 143
292      000145      SELDRV    = 145
293
294      : OTHER EQUATES
295
296      177400      SCTRWC     = -256.      : WORD COUNT FOR SECTOR
297

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14

```

.SBTTL TRAP CATCHER

000000      .=0
            ;*ALL UNUSED LOCATIONS FROM 4 - 776 CONTAIN A ".+2,HALT"
            ;*SEQUENCE TO CATCH ILLEGAL TRAPS AND INTERRUPTS
            ;*LOCATION 0 CONTAINS 0 TO CATCH IMPROPERLY LOADED VECTORS
000174      000174
000176      000000      .=174
DISPREG:    .WORD 0      ;;SOFTWARE DISPLAY REGISTER
SWREG:      .WORD 0      ;;SOFTWARE SWITCH REGISTER

.SBTTL STARTING ADDRESS(ES)

000200      000137 004670      JMP      @#START1      ;;JUMP TO STARTING ADDRESS OF PROGRAM
000204      000137 004712      JMP      @#START2      ;SELECT OPERATING PARAMETERS
000210      000137 004660      JMP      @#START3      ;SELECT RH/RM ADDRESSES
000214      000137 004702      JMP      @#START4      ;COMBINATION OF 204 AND 210

.SBTTL ACT11 HOOKS

*****
;HOOKS REQUIRED BY ACT11
000220      $SVPC=.      ;SAVE PC
000046      000046      .=46
000052      021560      $ENDAD      ;;1)SET LOC.46 TO ADDRESS OF $ENDAD IN .$EOP
000052      020000      .WORD 20000      ;;2)SET LOC.52 TO 20000
000220      000220      .=$SVPC      ;; RESTORE PC

. 1100
.SBTTL APT PARAMETER BLOCK

*****
;SET LOCATIONS 24 AND 44 AS REQUIRED FOR APT
*****
000024      001100      .SX=.      ;;SAVE CURRENT LOCATION
000024      000024      .=24      ;;SET POWER FAIL TO POINT TO START OF PROGRAM
000024      000200      200      ;;FOR APT START UP
000044      000044      .=44      ;;POINT TO APT INDIRECT ADDRESS PNTR.
000044      001100      $APTHDR ;;POINT TO APT HEADER BLOCK
001100      001100      .=$X      ;;RESET LOCATION COUNTER

*****
;SETUP APT PARAMETER BLOCK AS DEFINED IN THE APT-PDP11 DIAGNOSTIC
;INTERFACE SPEC.

001100      $APTHD:
001100      000000      $HIBTS: .WORD 0      ;;TWO HIGH BITS OF 18 BIT MAILBOX ADDR.
001102      001234      $MADR: .WORD $MAIL ;;ADDRESS OF APT MAILBOX (BITS 0-15)
001104      004064      $STMT: .WORD 2100. ;;RUN TIME OF LONGEST TEST
001106      004064      $PASTM: .WORD 2100. ;;RUN TIME IN SECS. OF 1ST PASS ON 1 UNIT (QUICK VERIFY)
001110      004064      $UNITM: .WORD 2100. ;;ADDITIONAL RUN TIME (SECS) OF A PASS FOR EACH ADDED UNIT
001112      000030      .WORD $ETEND-$MAIL/2 ;;LENGTH MAILBOX-ETABLE (WORDS)
TAB.XY=.      ;COMMON TAG STARTING ADDRESS
    
```

0

.SBTTL COMMON TAGS

 *THIS TABLE CONTAINS VARIOUS COMMON STORAGE LOCATIONS
 *USED IN THE PROGRAM.

001114	001114		SCMTAG: . =TAB.XY	:: START OF COMMON TAGS
001114	000000		.WORD 0	
001116	000		\$TSTNM: .BYTE 0	:: CONTAINS THE TEST NUMBER
001117	000		\$ERFLG: .BYTE 0	:: CONTAINS ERROR FLAG
001120	000000		\$ICNT: .WORD 0	:: CONTAINS SUBTEST ITERATION COUNT
001122	000000		\$LPADR: .WORD 0	:: CONTAINS SCOPE LOOP ADDRESS
001124	000000		\$LPERR: .WORD 0	:: CONTAINS SCOPE RETURN FOR ERRORS
001126	000000		\$ERTL: .WORD 0	:: CONTAINS TOTAL ERRORS DETECTED
001130	000		\$ITEMB: .BYTE 0	:: CONTAINS ITEM CONTROL BYTE
001131	001		\$ERMAX: .BYTE 1	:: CONTAINS MAX. ERRORS PER TEST
001132	000000		\$ERRPC: .WORD 0	:: CONTAINS PC OF LAST ERROR INSTRUCTION
001134	000000		\$GDADR: .WORD 0	:: CONTAINS ADDRESS OF 'GOOD' DATA
001136	000000		\$BDADR: .WORD 0	:: CONTAINS ADDRESS OF 'BAD' DATA
001140	000000		\$GDDAT: .WORD 0	:: CONTAINS 'GOOD' DATA
001142	000000		\$BDDAT: .WORD 0	:: CONTAINS 'BAD' DATA
001144	000000		.WORD 0	:: RESERVED--NOT TO BE USED
001146	000000		.WORD 0	
001150	000		\$AUTOB: .BYTE 0	:: AUTOMATIC MODE INDICATOR
001151	000		\$INTAG: .BYTE 0	:: INTERRUPT MODE INDICATOR
001152	000000		.WORD 0	
001154	177570		\$WR: .WORD DSWR	:: ADDRESS OF SWITCH REGISTER
001156	177570		DISPLAY: .WORD DDISP	:: ADDRESS OF DISPLAY REGISTER
001160	177560		\$TKS: 177560	:: TTY KBD STATUS
001162	177562		\$TKB: 177562	:: TTY KBD BUFFER
001164	177564		\$TPS: 177564	:: TTY PRINTER STATUS REG. ADDRESS
001166	177566		\$TPB: 177566	:: TTY PRINTER BUFFER REG. ADDRESS
001170	000		\$NULL: .BYTE 0	:: CONTAINS NULL CHARACTER FOR FILES
001171	002		\$FILLS: .BYTE 2	:: CONTAINS # OF FILLER CHARACTERS REQUIRED
001172	012		\$ILLC: .BYTE 12	:: INSERT FILL CHARS. AFTER A 'LINE FEED'
001173	000		\$TPFLG: .BYTE 0	:: 'TERMINAL AVAILABLE' FLAG (BIT<07>-0 YES)
001174	000000		\$REGAD: .WORD 0	:: CONTAINS THE ADDRESS FROM WHICH (\$REGO) WAS OBTAINED
001176	000000		\$REGO: .WORD 0	:: CONTAINS ((\$REGAD)+0)
001200	000000		\$REG1: .WORD 0	:: CONTAINS ((\$REGAD)+2)
001202	000000		\$REG2: .WORD 0	:: CONTAINS ((\$REGAD)+4)
001204	000000		\$REG3: .WORD 0	:: CONTAINS ((\$REGAD)+6)
001206	000000		\$REG4: .WORD 0	:: CONTAINS ((\$REGAD)+10)
001210	000000		\$REG5: .WORD 0	:: CONTAINS ((\$REGAD)+12)
001212	000000		\$TMP0: .WORD 0	:: USER DEFINED
001214	000000		\$TMP1: .WORD 0	:: USER DEFINED
001216	000000		\$TMP2: .WORD 0	:: USER DEFINED
001220	000000		\$TIMES: 0	:: MAX. NUMBER OF ITERATIONS
001222	000000		\$ESCAPE: 0	:: ESCAPE ON ERROR ADDRESS
001224	207	377	\$BELL: .ASCII <207><377><377>	:: CODE FOR BELL
001230	077		\$QUES: .ASCII /?/	:: QUESTION MARK
001231	015		\$CRLF: .ASCII <15>	:: CARRIAGE RETURN
001232	012	000	\$LF: .ASCII <12>	:: LINE FEED

 .SBTTL APT MAILBOX=ETABLE

```

001234
001234 000000
001236 000000
001240 000000
001242 000000
001244 000000
001246 000000
001250 000000
001252 000000
001254
001254 000
001255 000
001256 000000
001260 000000
001262 000000

001264 000
001265 000

001266 000000

001270 000
001271 000
001272 000000
001274 000
001275 000
001276 000000
001300 000
001301 000
001302 000000
001304 000000
001306 000000
001310 000000
001312 000000
001314
    
```

```

*****
.EVEN
$MAIL:
$MSGTY: .WORD   AMSGTY  ;; APT MAILBOX
$FATAL: .WORD   AFATAL  ;; MESSAGE TYPE CODE
$TESTN: .WORD   ATESTN  ;; FATAL ERROR NUMBER
$PASS:  .WORD   APASS   ;; TEST NUMBER
$DEVCT: .WORD   ADEVCT  ;; PASS COUNT
$UNIT:  .WORD   AUNIT   ;; DEVICE COUNT
$MSGAD: .WORD   AMSGAD  ;; I/O UNIT NUMBER
$MSGLG: .WORD   AMSGLG  ;; MESSAGE ADDRESS
$ETABLE: .WORD   AMSGAD  ;; MESSAGE LENGTH
$ENV:   .BYTE   AENV    ;; APT ENVIRONMENT TABLE
$ENVM:  .BYTE   AENVM   ;; ENVIRONMENT BYTE
$SWREG: .WORD   ASWREG  ;; ENVIRONMENT MODE BITS
$USWR:  .WORD   AUSWR   ;; APT SWITCH REGISTER
$CPUOP: .WORD   ACPUOP  ;; USER SWITCHES
          *          ;; CPU TYPE, OPTIONS
          *          ;; CPU TYPE
          *          ;; BITS 15-11=CPU TYPE
          *          ;; 11/04=01,11/05=02,11/20=03,11/40 04,11/45 05
          *          ;; 11/70=06,PDQ=07,Q=10
          *          ;; BIT 10=REAL TIME CLOCK
          *          ;; BIT 9=FLOATING POINT PROCESSOR
          *          ;; BIT 8=MEMORY MANAGEMENT
$MAMS1: .BYTE   AMAMS1  ;; HIGH ADDRESS, M.S. BYTE
$MTYP1: .BYTE   AMTYP1  ;; MEM. TYPE, BLK#1
          *          ;; MEM. TYPE BYTE -- (HIGH BYTE)
          *          ;; 900 NSEC CORE=001
          *          ;; 300 NSEC BIPOLAR=002
          *          ;; 500 NSEC MOS=003
$MADR1: .WORD   AMADR1  ;; HIGH ADDRESS, BLK#1
          *          ;; MEM. LAST ADDR.=3 BYTES, THIS WORD AND LOW OF "TYPE" ABOVE
$MAMS2: .BYTE   AMAMS2  ;; HIGH ADDRESS, M.S. BYTE
$MTYP2: .BYTE   AMTYP2  ;; MEM. TYPE, BLK#2
$MADR2: .WORD   AMADR2  ;; MEM. LAST ADDRESS, BLK#2
$MAMS3: .BYTE   AMAMS3  ;; HIGH ADDRESS, M.S. BYTE
$MTYP3: .BYTE   AMTYP3  ;; MEM. TYPE, BLK#3
$MADR3: .WORD   AMADR3  ;; MEM. LAST ADDRESS, BLK#3
$MAMS4: .BYTE   AMAMS4  ;; HIGH ADDRESS M.S. BYTE
$MTYP4: .BYTE   AMTYP4  ;; MEM. TYPE, BLK#4
$MADR4: .WORD   AMADR4  ;; MEM. LAST ADDRESS, BLK#4
$VECT1: .WORD   AVECT1  ;; INTERRUPT VECTOR#1, BUS PRIORITY#1
$VECT2: .WORD   AVECT2  ;; INTERRUPT VECTOR#2, BUS PRIORITY#2
$BASE:  .WORD   ABASE   ;; BASE ADDRESS OF EQUIPMENT UNDER TEST
$DEVCM: .WORD   ADEVCM  ;; DEVICE MAP
$ETEND:
.MEXIT
    
```

```

.SBTTL USER DEFINED TAGS

001314 000000 C.SWR: .WORD 0 ;CONTROL SWITCHES
001316 000031 ERMAX: .WORD 25. ;MAXIMUM NUMBER OF ERRORS ALLOWED PER DRIVE
001320 000000 SAVCSW: .WORD 0 ;PREVIOUS CONTENTS OF 'C.SWR'
001322 000000 CNTRLC: .WORD 0 ;CONTROL 'C' FLAG
001324 000000 BUSADR: .WORD 0 ;GET ADDRESSES FROM THE TTY FLAG (0=NO, -1=YES)
001326 000000 LPTAVL: .WORD 0 ;LPT AVAILABLE STATUS (0=NO,1=YES)
001330 000000 DRVSEL: .WORD 0 ;DRIVES SELECTED FOR TESTING
001332 166777 000003 TSTNMS: .WORD 166777,3 ;DEFAULT IS RUN TESTS 0-10,12,13 & 15-21
001336 000000 000000 OPNFLG: .WORD 0,0 ;MODIFY TEST PARAMETER FLAGS
001342 000000 CLKSTA: .WORD 0 ;CLOCK STATUS (0=NO CLOCK,+1=KW11-P,
;AND -1=KW11-L)

001344 000020 TICKMS: .WORD 16. ;16 MILLISECONDS PER CLOCK TICK
001346 040432 TICKUS: .WORD 16666. ;16666 MICROSECONDS PER CLOCK TICK
001350 000000 BYPASS: .WORD 0
001352 000000 CHKDRV: .WORD 0 ;DRIVE UNDER TEST
001354 000000 DRVMSK: .WORD 0 ;DRIVE MASK BIT
001356 000000 SVSTAT: .WORD 0 ;STATUS/ERROR INDICATOR IS
;SAVED HERE ON AN ERROR

001360 000000 CYL.RD: .WORD 0 ;CYLINDER READ
001362 000000 TRK.RD: .WORD 0 ;TRACK READ
001364 000000 SEC.RD: .WORD 0 ;SECTOR READ
001366 000000 CYL.DS: .WORD 0 ;CYLINDER DESIRED
001370 000000 SEC.DS: .WORD 0 ;SECTOR DESIRED
001372 000000 TRK.DS: .WORD 0 ;TRACK DESIRED
001374 000000 LSTRK: .WORD 0 ;CONTAINS THE LAST TRACK OF THE UNIT UNDER
;TEST. RM02/3 = 4., RM05 = 18.

001376 000000 TIM.UP: .WORD 0 ;MINIMUM TIME
001400 000000 .WORD 0 ;NUMBER OF COUNTS BELOW MIN. LIMIT
001402 000000 .WORD 0 ;MAXIMUM TIME
001404 000000 .WORD 0 ;NUMBER OF COUNTS ABOVE MAX. LIMIT
001406 000000 000000 .WORD 0,0 ;TOTAL TIME OF ALL SEEKS
001412 000000 .WORD 0 ;NUMBER OF SEEKS PERFORMED
001414 000000 TIM.DN: .WORD 0 ;MINIMUM TIME
001416 000000 .WORD 0 ;NUMBER OF COUNTS BELOW MIN. LIMIT
001420 000000 .WORD 0 ;MAXIMUM TIME
001422 000000 .WORD 0 ;NUMBER OF COUNTS ABOVE MAX. LIMIT
001424 000000 000000 .WORD 0,0 ;TOTAL TIME OF ALL SEEKS
001430 000000 .WORD 0 ;NUMBER OF SEEKS PERFORMED
001432 000000 TIM.PT: .WORD 0 ;POINTS TO TABLE OF TIMES
001434 000000 WCEFLG: .WORD 0 ;FATAL WRITE CHECK ERROR FLAG
001436 000000 STALLO: .WORD 0 ;VARIABLE STALL
001440 000000 000000 SVADR: .WORD 0,0 ;SAVE DISK ADDRESS
001444 000000 SEKTMR: .WORD 0 ;SEEK TIMER
001446 000000 SEKCNT: .WORD 0 ;SEEK COUNTER
001450 000000 DELTA: .WORD 0 ;TESTING RANGE FOR SERVO SETTLE DOWN TEST
001452 160000 TRCKWC: .WORD -<256.*32.> ;WORD COUNT FOR A FULL TRACK IN 16 BIT MODE
001454 000012 STALL1: .WORD 10. ;10 MILLISECONDS STALL
001456 000012 STALL2: .WORD 10. ;10 MILLISECONDS STALL
001460 011610 STALL3: .WORD 5000. ;5 SEC STALL
001462 000031 MXSTAL: .WORD 25. ;MAX. INCREMENTING STALL ALLOWED IN TEST 4
001464 020 ERR.CT: .BYTE 16. ;NUMBER OF ERRORS ALLOWED IN TESTS 16 - 21
;BEFORE GOING TO THE NEXT TEST
;RESERVED

001465 000 BASFLG: .BYTE 0 ;FLAG FOR DETECTING BAD SECTOR
001466 000000 .WORD 0
001470 000000 XXDP: .WORD 0 ;THE LOW BYTE CONTAINS THE DRIVE NUMBER FROM WHICH
  
```

;THE PROGRAM WAS LOADED. THE HIGH BYTE CONTAINS THE
 ;'XXDP' DEVICE CODE FOR THE RM05/3/2.

001472

ERRCN: .BLKB 8.

;TOTAL ERROR COUNT FOR DRIVES 0-7.

001502 176700
 001504 090254 000240
 001510 000104 000106
 001514 172540
 001516 172542
 001520 172544
 001522 000100 000102
 001526 177546
 001530 177564
 001532 177566
 001534 177514
 001536 177516

;ADDRESSES AND VECTORS
 RH.ADR: .WORD 176700
 RHVEC: .WORD 254,240
 PKV: .WORD 104,106
 PKCS: .WORD 172540
 PKB: .WORD 172542
 PKC: .WORD 172544
 LKV: .WORD 100,102
 LKS: .WORD 177546
 TPS: .WORD 177564
 TPB: .WORD 177566
 LPS: .WORD 177514
 LPB: .WORD 177516

;RH/RM UNIBUS ADDRESS
 ;VECTOR ADDRESS AND PRIORITY
 ;KW11-P VECTOR ADDRESS
 ;KW11-P CONTROL AND STATUS REG.
 ;KW11-P COUNT SET BUFFER
 ;KW11-P COUNTER
 ;KW11-L VECTOR ADDRESS
 ;KW11-L STATUS REGISTER
 ;TTY PRINTER STATUS
 ;TTY PRINTER BUFFER
 ;LINE PRINTER STATUS
 ;LINE PRINTER BUFFER

001540 000001
 001542 000002
 001544 000004
 001546 000010
 001550 000020
 001552 000040
 001554 000100
 001556 000200
 001560 000400
 001562 001000
 001564 002000
 001566 004000
 001570 010000
 001572 020000
 001574 040000
 001576 100000
 001600 000001
 001602 000002
 001604 000004
 001606 000010
 001610 000020
 001612 000040
 001614 000100
 001616 000200

;BIT TABLE
 BITS: .WORD BIT00
 .WORD BIT01
 .WORD BIT02
 .WORD BIT03
 .WORD BIT04
 .WORD BIT05
 .WORD BIT06
 .WORD BIT07
 .WORD BIT08
 .WORD BIT09
 .WORD BIT10
 .WORD BIT11
 .WORD BIT12
 .WORD BIT13
 .WORD BIT14
 .WORD BIT15
 .WORD BIT00
 .WORD BIT01
 .WORD BIT02
 .WORD BIT03
 .WORD BIT04
 .WORD BIT05
 .WORD BIT06
 .WORD BIT07

.SBTTL TIMING LIMITS

;ROTATIONAL TEST TABLES FOR RM05/3 DRIVES

001620 047754
 001622 000000
 001624 003142
 001626 003244

;60HZ TABLE
 T7A: .WORD ROTATE
 .WORD 0
 .WORD 1634.
 .WORD 1700.

;LO LIMIT (16.67MS - 2%)
 ;HI LIMIT (16.67MS + 2%)

001630 047754
 001632 000000

;50HZ TABLE
 T7B: .WORD ROTATE
 .WORD 0

001634 003131 .WORD 1625. ;LO LIMIT (16.67MS - 2.5%)
001636 003255 .WORD 1709. ;HI LIMIT (16.67MS + 2.5%)

:ROTATIONAL TEST TABLES FOR RM02 DRIVES

:60HZ TABLE
T7A1: .WORD ROTATE
.WORD 0
.WORD 2450. ;LO LIMIT (25.00MS - 2%)
.WORD 2550. ;HI LIMIT (25.00MS + 2%)

:50HZ TABLE
T7B1: .WORD ROTATE
.WORD 0
.WORD 2437. ;LO LIMIT (25.00MS - 2.5%)
.WORD 2563. ;HI LIMIT (25.00MS + 2.5%)

:SEEK TEST TABLES
T10: .WORD ONECYL ;FORWARD
.WORD REV ;REVERSE
.WORD 0 ;NO LO LIMIT
.WORD 600. ;HI LIMIT (6.0MS)

T11: .WORD AVERAGE ;FORWARD
.WORD REV ;REVERSE
.WORD 0 ;NO LO LIMIT
.WORD 3000. ;HI LIMIT (30.0MS)

T12: .WORD MXSEEK ;FORWARD
.WORD REV ;REVERSE
.WORD 0 ;NO LO LIMIT
.WORD 5500. ;HI LIMIT (55.0MS)

:SPECS. MESSAGE TABLES FOR ROTATIONAL AND TIMING TESTS

:ROTATIONAL MESSAGE AND LO/HI LIMITS FOR RM05/3 DRIVES

:60HZ TABLE
SP7A: .WORD MSG7XA
.WORD 1634. ;LO LIMIT (16.67MS - 2%)
.WORD 1700. ;HI LIMIT (16.67MS + 2%)

:50HZ TABLE
SP7B: .WORD MSG7XA
.WORD 1625. ;LO LIMIT (16.67MS - 2.5%)
.WORD 1709. ;HI LIMIT (16.67MS + 2.5%)

:ROTATIONAL MESSAGE AND LO/HI LIMITS FOR RM02 DRIVES

:60HZ TABLE
SP7A1: .WORD MSG7XB
.WORD 2450. ;LO LIMIT (25.00MS - 2%)
.WORD 2550. ;HI LIMIT (25.00MS + 2%)

:50HZ TABLE
SP7B1: .WORD MSG7XB
.WORD 2437. ;LO LIMIT (25.00MS - 2.5%)
.WORD 2563. ;HI LIMIT (25.00MS + 2.5%)

```

;TIMING TESTS MESSAGES AND LO/HI LIMITS
SP10: .WORD MSG10X
      .WORD 0 ;NO LO LIMIT
      .WORD 600. ;HI LIMIT (6.0MS)

SP11: .WORD MSG11X
      .WORD 0 ;NO LO LIMIT
      .WORD 3000. ;HI LIMIT (30.0MS)

SP12: .WORD MSG12X
      .WORD 0 ;NO LO LIMIT
      .WORD 5500. ;HI LIMIT (55.0MS)

;STATUS/ERROR MESSAGE POINTER TABLE
STATBL: .WORD MSGB14 ;OFFLINE OR UNSAFE DRIVE REQUESTED
        .WORD MSGB13 ;UNLOAD DRIVE REQUESTED
        .WORD MSGB12 ;PERSISTENT UNSAFE
        .WORD MSGB11 ;PARITY ERROR OCCURRED
        .WORD MSGB10 ;FATAL PARITY ERROR
        .WORD MSGB09 ;SOFTWARE TIMEOUT ON THIS DRIVE
        .WORD MSGB08 ;SOFTWARE TIMEOUT ON ANOTHER DRIVE
        .WORD MSGB06 ;ERROR OCCURRED DURING I/O OPERATION
        .WORD MSGB05 ;ERROR OCCURRED DURING NON-I/O OPERATION
        .WORD MSGB04 ;UNSAFE OCCURRED
        .WORD MSGB03 ;AUTOMATIC RECALIBRATE SEQUENCE OCCURRED
        .WORD MSGB02 ;DRIVE HAS NOT RESPONDED TO PORT REQUEST
        .WORD MSGB01 ;DRIVE HAS BECOME NONEXISTENT
    
```

001740 050500
 001742 000000
 001744 001130

 001746 050542
 001750 000000
 001752 005670

 001754 050604
 001756 000000
 001760 012574

001762 051536
 001764 051600
 001766 051631
 001770 051653
 001772 051701
 001774 051724
 001776 051763
 002000 052025
 002002 052071
 002004 052141
 002006 052161
 002010 052231
 002012 052301

28

.SBTTL ERROR POINTER TABLE

;*THIS TABLE CONTAINS THE INFORMATION FOR EACH ERROR THAT CAN OCCUR.
 ;*THE INFORMATION IS OBTAINED BY USING THE INDEX NUMBER FOUND IN
 ;*LOCATION \$ITEMB. THIS NUMBER INDICATES WHICH ITEM IN THE TABLE IS PERTINENT.
 ;*NOTE1: IF \$ITEMB IS 0 THE ONLY PERTINENT DATA IS (\$ERRPC).
 ;*NOTE2: EACH ITEM IN THE TABLE CONTAINS 4 POINTERS EXPLAINED AS FOLLOWS:

;* EM ;:POINTS TO THE ERROR MESSAGE
 ;* DH ;:POINTS TO THE DATA HEADER
 ;* DT ;:POINTS TO THE DATA
 ;* DF ;:POINTS TO THE DATA FORMAT

002014
 4
 5
 6
 7
 8
 9
 10
 11 002014 050660
 12 002016 052337
 13 002020 053714
 14 002022 054346
 15
 16
 17
 18
 19
 20
 21
 22 002024 050732
 23 002026 052354
 24 002030 053720
 25 002032 054352
 26
 27
 28
 29
 30
 31
 32
 33 002034 050770
 34 002036 052441
 35 002040 053736
 36 002042 054356
 37
 38
 39
 40
 41
 42
 43
 44 002044 051025
 45 002046 052476

\$ERRTB:

;*ERROR 1

;* RH CONTROLLER INTERRUPT OCCURED (RMAS=0)
 ;* ERR PC RMAS
 ;* \$ERRPC \$REG3

EM1
 DH1
 DT1
 DF1

;*ERROR 2

;* UNEXPECTED ATTENTION OCCURRED
 ;* ERR PC DRIVE RMAS RMDS RMER1 RMMR2 RMER2
 ;* \$ERRPC \$REG1 \$REG3 RMERRS RMERRS+2 RMERRS+4 RMERRS+6

EM2
 DH2
 DT2
 DF2

;*ERROR 3

;* MASSBUS PARITY ERROR (MCPE=1)
 ;* TEST ERR PC ADDRESS DATA
 ;* \$TMP0 \$ERRPC RD.ADR RD.WRD

EM3
 DH3
 DT3
 DF3

;*ERROR 4

;* MASSBUS PARITY ERROR (PAR=1)
 ;* TEST ERR PC ADDRESS GDDATA BDDATA
 ;* \$TMP0 \$ERRPC WRT.ADR WRT.WD RD.WRD

EM4
 DH4

46 002050 053746
 47 002052 054362

DT4
 DF4

48
 49

;*ERROR 5

50
 51

```

:* ADDRESS PLUG CHANGE BIT SET
:* ERR PC DRIVE RMAS RMDS RMER' RMMR2 RMR2
:* $ERRPC $REG1 $REG3 RMERRS RMERRS+2 RMERRS+4 RMERRS+6
    
```

52
 53

54
 55 002054 05106'
 56 002056 052354
 57 002060 053720
 58 002062 054352

EM5
 DH2
 DT2
 DF2

59
 60

;*ERROR 6 -- NOT USED

61

62 002064 000000
 63 002066 000000
 64 002070 000000
 65 002072 000000

0
 0
 0
 0

66
 67

;*ERROR 7 -- NOT USED

68

69 002074 000000
 70 002076 000000
 71 002100 000000
 72 002102 000000

0
 0
 0
 0

73
 74

;*ERROR 10

75
 76

```

:* RH CONTROLLER FAILED TO RESPOND TO ADDRESSING
:* RMCS1 ERR PC
:* RH.ADR $ERRPC
    
```

77
 78

79
 80 002104 051115
 81 002106 052545
 82 002110 054000
 83 002112 054366

EM10
 DH10
 DT10
 DF10

84
 85

;*ERROR 11

86
 87



```

:* DRIVE SELECTED IS NOT ONLINE
:* DRIVE ERR PC
:* $REG2 $ERRPC
    
```

88
 89

90
 91 002114 051173
 92 002116 052564
 93 002120 054004
 94 002122 054372

EM11
 DH11
 DT11
 DF11

95
 96

;*ERROR 12

97
 98

```

:* IMPROPER HEADER DATA
:* TEST ERR PC TST PC DRIVE CYLNR TRACK SECTOR
:* $TMP0 $ERRPC $REG0 CHKDRV CYL.DS TRK.DS SEC.DS
:* GDCYL GDTRK GDSCTR BDCYL BDTRK BDSCTR
:* CYL.DS TRK.DS SEC.DS CYL.RD TRK.RD SEC.RD
    
```

99
 100

101
 102

```

103          :*  CYLNDR, TRACK, AND SECTOR ARE DECIMAL
104
105 002124 051230          EM12
106 002126 052603          DH12
107 002130 054010          DT12
108 002132 054376          DF12
109
110          :*ERROR 13
111
112          :*  DATA COMPARE FAILURE
113          :*  TEST   ERR PC TST PC DRIVE  CYLNDR TRACK  SECTOR
114          :*  $TMPO  $ERRPC $REGO  CHKDRV  CYL.DS  TRK.DS  SEC.DS
115          :*          GDDAT  BDDAT  WRDCNT  GDADR  BDADR
116          :*          $GDDAT $BDDAT $REG4  $GDADR $BDADR
117          :*  CYLNDR, TRACK, SECTOR, AND WRDCNT ARE DECIMAL
118
119 002134 051255          EM13
120 002136 052603          DH12
121 002140 054042          DT13
122 002142 054406          DF13
123
124          :*ERROR 14 -- FOLLOWS #13
125
126          :*          $GDDAT $BDDAT $REG4  $GDADR $BDADR
127
128 002144 000000          0
129 002146 000000          0
130 002150 054060          DT13A
131 002152 054416          DF14
132
133          :*ERROR 15
134
135          :*  DATA COMPARE FAILURE
136          :*  TEST   ERR PC TST PC DRIVE  CYLNDR TRACK  SECTOR
137          :*  $TMPO  $ERRPC $REGO  CHKDRV  CYL.DS  TRK.DS  SEC.DS
138          :*          GDDAT  BDDAT  WRDCNT  GDADR  BDADR
139          :*          $GDDAT $BDDAT $REG4  $GDADR $BDADR
140          :*  CYLNDR, TRACK, SECTOR, AND WRDCNT ARE DECIMAL
141
142 002154 051255          EM13
143 002156 052603          DH12
144 002160 054042          DT13
145 002162 054406          DF13
146
147          :*ERROR 16 -- FOLLOWS #15
148
149          :*  $GDDAT $BDDAT $REG4  $GDADR $BDADR
150
151 002164 000000          0
152 002166 000000          0
153 002170 054060          DT13A
154 002172 054416          DF14
155
156          :*ERROR 17
157
158          :*  DISK ERROR IN TIMING TEST
159          :*  TEST   ERR PC DRIVE  RMCS1  RMDS  RMER1  RMMR2  RMER2
    
```

```

160      ;*   $TMP0   $ERRPC  CHKDRV  RM.REG  RM.REG+12 RM.REG+14 RM.REG+40 RM.REG+42
161
162      EM17
163 002174 051302      DH17
164 002176 053017      DT17
165 002200 054072      DF17
166 002202 054422
167
168      ;*ERROR 20
169
170      ;*   CLOCK (KW11-?) OVERFLOW IN TIMING TEST
171      ;*   TEST     ERR PC  DRIVE  RMCS1  RMDS      RMER1      RMMR2      RMER2
172      ;*   $TMP0   $ERRPC  CHKDRV  RM.REG  RM.REG+12 RM.REG+14 RM.REG+40 RM.REG+42
173
174      EM20
175 002204 051334      DH17
176 002206 053017      DT17
177 002210 054072      DF17
178 002212 054422
179
180      ;*ERROR 21
181
182      ;*   DATA COMPARE FAILURE
183      ;*   TEST     ERR PC  TST PC  DRIVE  CYLNR  TRACK
184      ;*   $TMP0   $ERRPC  $REGO  CHKDRV  CYL.DS  TRK.DS
185      ;*   GDDAT   BDDAT   WRDCNT  SECTOR
186      ;*   $REG1   $BDDAT  $REG4   $REG1
187      ;*   CYLINDR, TRACK, WRDCNT, AND SECTOR ARE DECIMAL
188
189      EM13
190 002214 051255      DH21
191 002216 053114      DT21
192 002220 054112      DF21
193
194      ;*ERROR 22--FOLLOWS #21
195
196      ;*   $REG1   $BDDAT  $REG4   $REG1
197
198      0
199 002224 000000      0
200 002226 000000      0
201 002230 054126      DT21A
202 002232 054436      DF22
203
204      ;*ERROR 23
205
206      ;*   DISK ERROR DURING SEEK
207      ;*   TEST     ERR PC  DRIVE  CYLNR  RMCS1  RMCS2  RMDS
208      ;*   $TMP0   $ERRPC  CHKDRV  CYL.DS  RM.REG  RM.REG+10 RM.REG+12
209      ;*   RMER1   RMMR2   RMER2   RMDC    RMMR
210      ;*   RM.REG+14 RM.REG+40 RM.REG+42 RM.REG+34 RM.REG+36
211
212      EM23
213 002234 051403      DH23
214 002236 053231      DT23
215 002240 054136      DF23
216 002242 054442
217
218      ;*ERROR 24
219
220      ;*   SEEK NOT COMPLETE WITHIN 120 MS
  
```

ERROR POINTER TABLE

```

217      :* TEST      ERR PC  DRIVE  CYLNDR  RMCS1  RMCS2  RMDS
218      :* $TMP0    $ERRPC  CHKDRV  CYL.DS  RM.REG  RM.REG+10  RM.REG+12
219      :*          RMER1    RMMR2    RMER2    RMDC    RMHR
220      :*          RM.REG+14  RM.REG+40  RM.REG+42  RM.REG+34  RM.REG+36
221
222      EM24
223      DH23
224      DT23
225      DF23
226
227      :*****
228      :* ERRORS 23-40 NOT USED
229      :* ERRORS 41-46 WILL HAVE AN EM THAT
230
231      :* VARIES DEPENDING ON THE ERROR, IT WILL BE IN THE FORM:
232      :* RH/RM ERROR (MESSAGE)
233      :* WHERE MESSAGE WILL BE ONE OR MORE OF THE FOLLOWING:
234      :* 1) OFFLINE OR UNSAFE DRIVE REQUESTED
235      :* 2) UNLOADED DRIVE REQUESTED
236      :* 3) PERSISTENT UNSAFE
237      :* 4) PARITY ERROR OCCURRED
238      :* 5) FATAL PARITY ERROR
239      :* 6) SOFTWARE TIMEOUT ON THIS DRIVE
240      :* 7) SOFTWARE TIMEOUT ON ANOTHER DRIVE
241      :* 8) ERROR OCCURRED DURING I/O OPERATION
242      :* 9) ERROR OCCURRED DURING NON-I/O OPERATION
243      :* 10) UNSAFE OCCURRED
244      :* 11) AUTOMATIC RECALIBRATE SEQUENCE OCCURRED
245      :*****
246
247      002254      ITEM41:
248
249      :*ERROR 41
250
251      :* RH/RM ERROR (MESSAGE)
252      :* TEST      ERR PC  TST PC  DRIVE
253      :* $TMP0    $ERRPC  $REGO  CHKDRV
254
255      EM41
256      DH41
257      DT41
258      DF41
259
260      :*ERROR 42
261
262      :* RH/RM ERROR (MESSAGE)
263      :* TEST      ERR PC  TST PC  DRIVE  RMCS1  RMCS2  RMDS
264      :* $TMP0    $ERRPC  $REGO  CHKDRV  RM.REG  RM.REG+10  RM.REG+12
265
266      EM41
267      DH42
268      DT42
269      DF42
270
271      :*ERROR 43
272
273      :* RH/RM ERROR (MESSAGE)

```

```

274      :*      TEST   ERR PC  TST PC  DRIVE  RMCS1  RMCS2  RMDS
275      :*      $TMPO  $ERRPC  $REGO  CHKDRV  RM.REG  RM.REG+10 RM.REG+12
276      :*              RMER1      RMMR2      RMER2
277      :*              RM.REG+14  RM.REG+40  RM.REG+42
278
279 002274 051472      EM41
280 002276 053421      DH42
281 002300 054214      DT43
282 002302 054462      DF43
283
284      :*ERROR 44
285
286      :*      RH/RM ERROR (MESSAGE)
287      :*      TEST   ERR PC  TST PC  DRIVE  CYLNDR  TRACK  SECTOR
288      :*      $TMPO  $ERRPC  $REGO  CHKDRV  CYL.DS  TRK.DS  SEC.DS
289      :*              RMCS1      RMCS2      RMDS      RMHR      RMDC      RMDA
290      :*              RM.REG      RM.REG+10  RM.REG+12  RM.REG+36  RM.REG+34  RM.REG+06
291      :*      RMER1      RMMR2      RMER2
292      :*      RM.REG+14  RM.REG+40  RM.REG+42
293      :*      CYLNDR,TRACK, AND SECTOR ARE DECIMAL
294
295 002304 051472      EM41
296 002306 052603      DH12
297 002310 054240      DT44
298 002312 054472      DF44
299
300      :*ERROR 45
301
302      :*      RH/RM ERROR (MESSAGE)
303      :*      TEST   ERR PC  TST PC  DRIVE  CYLNDR  TRACK  SECTOR
304      :*      $TMPO  $ERRPC  $REGO  CHKDRV  CYL.DS  TRK.DS  SEC.DS
305      :*              RMCS1      RMCS2      RMDS      RMHR      RMDC      RMDA
306      :*              RM.REG      RM.REG+10  RM.REG+12  RM.REG+36  RM.REG+34  RM.REG+06
307      :*      RMER1      RMMR2      RMER2      RMWC      RMBA      RMDB
308      :*      RM.REG+14  RM.REG+40  RM.REG+42  RM.REG+2  RM.REG+4  RM.REG+22
309      :*      CYLNDR,TRACK, AND SECTOR ARE DECIMAL
310
311 002314 051472      EM41
312 002316 052603      DH12
313 002320 054300      DT45
314 002322 054506      DF45
315
316      :*ERROR 46
317
318      :*      FATAL WRITE CHECK ERROR (MESSAGE)
319      :*      TEST   ERR PC  TST PC  DRIVE  CYLNDR  TRACK  SECTOR
320      :*      $TMPO  $ERRPC  $REGO  CHKDRV  CYL.DS  TRK.DS  SEC.DS
321      :*              RMCS1      RMCS2      RMDS      RMHR      RMDC      RMDA
322      :*              RM.REG      RM.REG+10  RM.REG+12  RM.REG+36  RM.REG+34  RM.REG+06
323      :*      RMER1      RMMR2      RMER2      RMWC      RMBA      RMDB
324      :*      RM.REG+14  RM.REG+40  RM.REG+42  RM.REG+2  RM.REG+4  RM.REG+22
325      :*      CYLNDR,TRACK, AND SECTOR ARE DECIMAL
326
327 002324 051506      EM46
328 002326 052603      DH12
329 002330 054300      DT45
330 002332 054506      DF45
    
```

```

1          .SBTTL TEST PARAMETER POINTERS AND TABLES
2
3          :COMMON STORAGE FOR TEST PARAMETERS
4 002334 000000 PRM: .WORD 0          :THIS WORD TELLS WHICH OF THE
5                                     :FOLLOWING PARAMETERS ARE TO BE USED
6 002336 000000 RPT: .WORD 0          :REPEAT COUNTS FOR ALL TESTS
7 002340 000000 FC: .WORD 0          :FIRST CYLINDER
8 002342 000000 LC: .WORD 0          :LAST CYLINDER
9 002344 000000 IC: .WORD 0          :INCREMENT CYLINDER
10 002346 000000 FT: .WORD 0         :FIRST TRACK
11 002350 000000 LT: .WORD 0         :LAST TRACK
12 002352 000000 IT: .WORD 0         :INCREMENT TRACK
13 002354 000000 FS: .WORD 0         :FIRST SECTOR
14 002356 000000 LS: .WORD 0         :LAST SECTOR
15 002360 000000 PAT: .WORD 0        :PATTERN CODE
16 002362 000000 000000 000000 .WORD 0,0,0 :FILLER WORDS FOR COMMON TABLE USED BY THE
17                                     :'OPNTST' ROUTINE.
18
19 002370 000000 NC1: .WORD 0         :NEW CYLINDER ADDRESS
20 002372 000000 NC2: .WORD 0         :NEW CYLINDER ADDRESS
21
22          :TABLE OF PARAMETER POINTERS
23 002374 003132 PRMPT: .WORD PRM0
24 002376 003150 .WORD PRM1
25 002400 003176 .WORD PRM2
26 002402 003216 .WORD PRM3
27 002404 003236 .WORD PRM4
28 002406 003256 .WORD PRM5
29 002410 003276 .WORD PRM6
30 002412 003316 .WORD PRM7
31 002414 003336 .WORD PRM10
32 002416 003354 .WORD PRM11
33 002420 003374 .WORD PRM12
34 002422 003410 .WORD PRM13
35 002424 003420 .WORD PRM14
36 002426 003430 .WORD PRM15
37 002430 003440 .WORD PRM16
38 002432 003452 .WORD PRM17
39 002434 003462 .WORD PRM20
40 002436 003516 .WORD PRM21
41 002440 003526 .WORD PRM22
42 002442 000000 .WORD 0          :TERMINATOR
43
44          :TABLE OF PARAMETER UPPER LIMITS
45 PRMLMT: .WORD 32767          :'R'
46          .WORD 822.          :'FC'
47          .WORD 822.          :'LC'
48          .WORD 822.          :'IC'
49          .WORD 4             :'FT'
50          .WORD 4             :'LT'
51          .WORD 4             :'IT'
52          .WORD 18.          :'FT'
53          .WORD 18.          :'LT'
54          .WORD 18.          :'IT'
55          .WORD 31.          :'FS'
56          .WORD 31.          :'LS'
57          .WORD 177777       :'PAT'
    
```

43

44

TABLE OF PARAMETER MESSAGE POINTERS

45	002476	047210	PRMMSG: .WORD	MSG.R
46	002500	047212	.WORD	MSG.FC
47	002502	047215	.WORD	MSG.LC
48	002504	047220	.WORD	MSG.IC
49	002506	047223	.WORD	MSG.FT
50	002510	047226	.WORD	MSG.LT
51	002512	047231	.WORD	MSG.IT
52	002514	047234	.WORD	MES.FT
53	002516	047240	.WORD	MES.LT
54	002520	047244	.WORD	MES.IT
55	002522	047250	.WORD	MSG.FS
56	002524	047253	.WORD	MSG.LS

57

58

:STATUS/ERROR INDICATOR MESSAGES POINTER TABLE

59

:DEFAULT VALUES OF TEST PARAMETERS

60

61	002526	002227	000310	000000	DFLT: .WORD	2227,200.,0,822.,0,0,0	:RECAL/RANDOM SEEK (T0)
62	002544	006677	000144	000000	.WORD	6677,100.,0,256.,0,0,0,0,0,0,0	:SEEK/SEEK (T1)
63	002572	002237	000001	000000	.WORD	2237,1,0,822.,1,0,0,0	:INCREMENT SEEK (T2)
64	002612	002237	000010	000000	.WORD	2237,10,0,512.,1,0,0,0	:STEPPING SEEK (T3)
65	002632	002237	000001	000000	.WORD	2237,1,0,822.,1,0,0,0	:OSCILLATING SEEK (T4)
66	002652	002237	000001	000000	.WORD	2237,1,0,822.,1,0,0,0	:CONVERGING/DIVERGING SEEK (T5)
67	002672	002237	000001	000000	.WORD	2237,1,0,822.,1,0,0,0	:SERVO ADDRESSING LOGIC NOISE (T6)
68	002712	000667	011610	000000	.WORD	667,5000.,0,822.,0,4,0,18.	:RANDOM SEEK TEST (T7)
69	002732	000237	000001	000000	.WORD	237,1,0,822.,100.,0,0	:SERVO SETTLE DOWN TEST (T10)
70	002750	002237	000001	000000	.WORD	2237,1,0,822.,1,0,0,0	:ALL SEEKS TEST (T11)
71	002770	002223	000001	000000	.WORD	2223,1,0,0,0,0,0	:ROTATIONAL SPEED TIMING TEST (T12)
72	003004	000007	000001	000000	.WORD	7,1,0,822.	:ONE CYLINDER SEEK TIMING TEST (T13)
73	003014	000007	000001	000000	.WORD	7,1,0,220.	:AVERAGE SEEK TIMING TEST (T14)
74	003024	000007	000001	000000	.WORD	7,1,0,822.	:MAXIMUM SEEK TIMING TEST (T15)
75	003034	000223	000001	000000	.WORD	223,1,0,0,0	:SECTOR ADDRESSING TEST (T16)
76	003046	002003	000001	000000	.WORD	2003,1,0,0	:TRACK ADDRESSING TEST (T17)
77	003056	017777	000001	000000	.WORD	17777,1,0,821.,64.,0,4,1,0,18.,1,1,0,177777	:DATA TEST (T20)
78	003112	000007	001750	000000	.WORD	7,1000.,0,821.	:EXERCISER (T21)
79	003122	000007	011610	000000	.WORD	7,5000.,0,255.	:SEEK TIME ADJUSTMENT TEST (T22)

80

81

:PARAMETER TABLES

82

83

:RECAL/RANDOM SEEK (T0)

84	003132	002227	PRMO: .WORD	2227
85	003134	000310	.WORD	200.
86	003136	000000	.WORD	0
87	003140	001466	.WORD	822.
88	003142	000000	.WORD	0
89	003144	000000	.WORD	0
90	003146	000000	.WORD	0

91

92

:SEEK/SEEK (T1)

93	003150	006677	PRM1: .WORD	6677
94	003152	000144	.WORD	100.
95	003154	000000	.WORD	0
96	003156	000400	.WORD	256.
97	003160	000000	.WORD	0
98	003162	000000	.WORD	0
99	003164	000000	.WORD	0


```

100 003166 000000 .WORD 0
101 003170 000000 .WORD 0
102 003172 000000 .WORD 0
103 003174 000000 .WORD 0
104
105 ;INCREMENT SEEK (T2)
106 003176 002237 PRM2: .WORD 2237
107 003200 000001 .WORD 1
108 003202 000000 .WORD 0
109 003204 001466 .WORD 822.
110 003206 000001 .WORD 1
111 003210 000000 .WORD 0
112 003212 000000 .WORD 0
113 003214 000000 .WORD 0
114
115 ;STEPPING SEEK (T3)
116 003216 002237 PRM3: .WORD 2237
117 003220 000001 .WORD 1
118 003222 000000 .WORD 0
119 003224 001000 .WORD 512.
120 003226 000001 .WORD 1
121 003230 000000 .WORD 0
122 003232 000000 .WORD 0
123 003234 000000 .WORD 0
124
125 ;OSCILLATING SEEK (T4)
126 003236 002237 PRM4: .WORD 2237
127 003240 000001 .WORD 1
128 003242 000000 .WORD 0
129 003244 001466 .WORD 822.
130 003246 000001 .WORD 1
131 003250 000000 .WORD 0
132 003252 000000 .WORD 0
133 003254 000000 .WORD 0
134
135 ;CONVERGING/DIVERGING SEEK (T5)
136 003256 002237 PRM5: .WORD 2237
137 003260 000001 .WORD 1
138 003262 000000 .WORD 0
139 003264 001466 .WORD 822.
140 003266 000001 .WORD 1
141 003270 000000 .WORD 0
142 003272 000000 .WORD 0
143 003274 000000 .WORD 0
144
145 ;SERVO ADDRESSING LOGIC NOISE GENERATOR (T6)
146 003276 002237 PRM6: .WORD 2237
147 003300 000001 .WORD 1
148 003302 000000 .WORD 0
149 003304 001466 .WORD 822.
150 003306 000001 .WORD 1
151 003310 000000 .WORD 0
152 003312 000000 .WORD 0
153 003314 000000 .WORD 0
154
155 ;RANDOM SEEK TEST (T7)
156 003316 000667 PRM7: .WORD 667

```

157 003320 0116'0
 158 003322 000000
 159 003324 001466
 160 003326 000000
 161 003330 000004
 162 003332 000000
 163 003334 000022
 164
 165
 166 003336 000237
 167 003340 000001
 168 003342 000000
 169 003344 001466
 170 003346 000144
 171 003350 000000
 172 003352 000000
 173
 174
 175 003354 002237
 176 003356 000001
 177 003360 000000
 178 003362 001466
 179 003364 000001
 180 003366 000000
 181 003370 000000
 182 003372 000000
 183
 184
 185 003374 002223
 186 003376 000001
 187 003400 000000
 188 003402 000000
 189 003404 000000
 190 003406 000000
 191
 192
 193 003410 000007
 194 003412 000001
 195 003414 000000
 196 003416 001466
 197
 198
 199 003420 000007
 200 003422 000001
 201 003424 000000
 202 003426 000334
 203
 204
 205 003430 000007
 206 003432 000001
 207 003434 000000
 208 003436 001466
 209
 210
 211 003440 000223
 212 003442 000001
 213 003444 000000

.WORD 5000.
 .WORD 0
 .WORD 822.
 .WORD 0
 .WORD 4
 .WORD 0
 .WORD 18.

;SERVO SETTLE DOWN TEST (T10)

PRM10: .WORD 237
 .WORD 1
 .WORD 0
 .WORD 822.
 .WORD 100.
 .WORD 0
 .WORD 0

;ALL SEEKS TEST (T11)

PRM11: .WORD 2237
 .WORD 1
 .WORD 0
 .WORD 822.
 .WORD 1
 .WORD 0
 .WORD 0
 .WORD 0

;ROTATIONAL SPEED TIMING TEST (T12)

PRM12: .WORD 2223
 .WORD 1
 .WORD 0
 .WORD 0
 .WORD 0
 .WORD 0

;ONE CYLINDER SEEK TIMING TEST (T13)

PRM13: .WORD 7
 .WORD 1
 .WORD 0
 .WORD 822.

;AVERAGE SEEK TIMING TEST (T14)

PRM14: .WORD 7
 .WORD 1
 .WORD 0
 .WORD 220.

;MAXIMUM SEEK TIMING TEST (T15)

PRM15: .WORD 7
 .WORD 1
 .WORD 0
 .WORD 822.

;SECTOR ADDRESSING TEST (T16)

PRM16: .WORD 223
 .WORD 1
 .WORD 0

214	003446	000000	.WORD	0
215	003450	000000	.WORD	0
216				
217			:TRACK ADDRESSING TEST (T17)	
218	003452	002003	PRM17: .WORD	2003
219	003454	000001	.WORD	1
220	003456	000000	.WORD	0
221	003460	000000	.WORD	0
222				
223			:DATA TEST (T20)	
224	003462	017777	PRM20: .WORD	17777
225	003464	000001	.WORD	1
226	003466	000000	.WORD	0
227	003470	001465	.WORD	821.
228	003472	000100	.WORD	64.
229	003474	000000	.WORD	0
230	003476	000004	.WORD	4
231	003500	000001	.WORD	1
232	003502	000000	.WORD	0
233	003504	000022	.WORD	18.
234	003506	000001	.WORD	1
235	003510	000001	.WORD	1
236	003512	000000	.WORD	0
237	003514	177777	PRM15: .WORD	177777
238				
239			:EXERCISER (T21)	
240	003516	000007	PRM21: .WORD	7
241	003520	001750	.WORD	1000.
242	003522	000000	.WORD	0
243	003524	001465	.WORD	821.
244				
245			:SEEK TIME ADJUSTMENT TEST (T22)	
246	003526	000007	PRM22: .WORD	7
247	003530	011610	.WORD	5000.
248	003532	000000	.WORD	0
249	003534	000377	.WORD	255.

Line	Address	Value	Label	Description
1			.SBTTL	DATA PATTERN POINTERS AND TABLES
2				
3	003536	003576	PAT.PT:	.WORD PAT0 ;DATA PATTERN 0
6	003540	003636		.WORD PAT1 ;DATA PATTERN 1
	003542	003676		.WORD PAT2 ;DATA PATTERN 2
	003544	003736		.WORD PAT3 ;DATA PATTERN 3
	003546	003776		.WORD PAT4 ;DATA PATTERN 4
	003550	004036		.WORD PAT5 ;DATA PATTERN 5
	003552	004076		.WORD PAT6 ;DATA PATTERN 6
	003554	004136		.WORD PAT7 ;DATA PATTERN 7
	003556	004176		.WORD PAT8 ;DATA PATTERN 8
	003560	004236		.WORD PAT9 ;DATA PATTERN 9
	003562	004276		.WORD PAT10 ;DATA PATTERN 10
	003564	004336		.WORD PAT11 ;DATA PATTERN 11
	003566	004376		.WORD PAT12 ;DATA PATTERN 12
	003570	004436		.WORD PAT13 ;DATA PATTERN 13
	003572	004476		.WORD PAT14 ;DATA PATTERN 14
	003574	004536		.WORD PAT15 ;DATA PATTERN 15
7				
8	003576	155555	PAT0:	.WORD 155555 ;PATTERN 0 (WORST CASE)
9	003600	133333		.WORD 133333
10	003602	155555		.WORD 155555
11	003604	133333		.WORD 133333
12	003606	155555		.WORD 155555
13	003610	133333		.WORD 133333
14	003612	155555		.WORD 155555
15	003614	133333		.WORD 133333
16	003616	155555		.WORD 155555
17	003620	133333		.WORD 133333
18	003622	155555		.WORD 155555
19	003624	133333		.WORD 133333
20	003626	155555		.WORD 155555
21	003630	133333		.WORD 133333
22	003632	155555		.WORD 155555
23	003634	133333		.WORD 133333
24				
25	003636	000001	PAT1:	.WORD 000001 ;PATTERN 1
26	003640	000003		.WORD 000003
27	003642	000007		.WORD 000007
28	003644	000017		.WORD 000017
29	003646	000037		.WORD 000037
30	003650	000077		.WORD 000077
31	003652	000177		.WORD 000177
32	003654	000377		.WORD 000377
33	003656	000777		.WORD 000777
34	003660	001777		.WORD 001777
35	003662	003777		.WORD 003777
36	003664	007777		.WORD 007777
37	003666	017777		.WORD 017777
38	003670	037777		.WORD 037777
39	003672	077777		.WORD 077777
40	003674	177777		.WORD 177777
41				
42	003676	177776	PAT2:	.WORD 177776 ;PATTERN 2
43	003700	177774		.WORD 177774
44	003702	177770		.WORD 177770
45	003704	177760		.WORD 177760

DATA PATTERN POINTERS AND TABLES

46	003706	177740		.WORD	177740	
47	003710	177700		.WORD	177700	
48	003712	177600		.WORD	177600	
49	003714	177400		.WORD	177400	
50	003716	177000		.WORD	177000	
51	003720	176000		.WORD	176000	
52	003722	174000		.WORD	174000	
53	003724	170000		.WORD	170000	
54	003726	160000		.WORD	160000	
55	003730	140000		.WORD	140000	
56	003732	100000		.WORD	100000	
57	003734	000000		.WORD	000000	
58						
59	003736	000000	PAT3:	.WORD	000000	:PATTERN 3
60	003740	000000		.WORD	000000	
61	003742	000000		.WORD	000000	
62	003744	177777		.WORD	177777	
63	003746	177777		.WORD	177777	
64	003750	177777		.WORD	177777	
65	003752	000000		.WORD	000000	
66	003754	000000		.WORD	000000	
67	003756	177777		.WORD	177777	
68	003760	177777		.WORD	177777	
69	003762	000000		.WORD	000000	
70	003764	177777		.WORD	177777	
71	003766	000000		.WORD	000000	
72	003770	177777		.WORD	177777	
73	003772	000000		.WORD	000000	
74	003774	177777		.WORD	177777	
75						
76	003776	133331	PAT4:	.WORD	133331	:PATTERN 4
77	004000	133331		.WORD	133331	
78	004002	133331		.WORD	133331	
79	004004	133331		.WORD	133331	
80	004006	133331		.WORD	133331	
81	004010	133331		.WORD	133331	
82	004012	133331		.WORD	133331	
83	004014	133331		.WORD	133331	
84	004016	133331		.WORD	133331	
85	004020	133331		.WORD	133331	
86	004022	133331		.WORD	133331	
87	004024	133331		.WORD	133331	
88	004026	133331		.WORD	133331	
89	004030	133331		.WORD	133331	
90	004032	133331		.WORD	133331	
91	004034	133331		.WORD	133331	
92						
93	004036	052525	PAT5:	.WORD	052525	:PATTERN 5
94	004040	052525		.WORD	052525	
95	004042	052525		.WORD	052525	
96	004044	125252		.WORD	125252	
97	004046	125252		.WORD	125252	
98	004050	125252		.WORD	125252	
99	004052	052525		.WORD	052525	
100	004054	052525		.WORD	052525	
101	004056	125252		.WORD	125252	
102	004060	125252		.WORD	125252	

103	004062	052525		.WORD	052525	
104	004064	125252		.WORD	125252	
105	004066	052525		.WORD	052525	
106	004070	125252		.WORD	125252	
107	004072	052525		.WORD	052525	
108	004074	125252		.WORD	125252	
109						
110	004076	155555	PAT6:	.WORD	155555	;PATTERN 6
111	004100	155555		.WORD	155555	
112	004102	155555		.WORD	155555	
113	004104	155555		.WORD	155555	
114	004106	155555		.WORD	155555	
115	004110	155555		.WORD	155555	
116	004112	155555		.WORD	155555	
117	004114	155555		.WORD	155555	
118	004116	155555		.WORD	155555	
119	004120	155555		.WORD	155555	
120	004122	155555		.WORD	155555	
121	004124	155555		.WORD	155555	
122	004126	155555		.WORD	155555	
123	004130	155555		.WORD	155555	
124	004132	155555		.WORD	155555	
125	004134	155555		.WORD	155555	
126						
127	004136	026455	PAT7:	.WORD	026455	;PATTERN 7
128	004140	026455		.WORD	026455	
129	004142	026455		.WORD	026455	
130	004144	151322		.WORD	151322	
131	004146	151322		.WORD	151322	
132	004150	151322		.WORD	151322	
133	004152	026455		.WORD	026455	
134	004154	026455		.WORD	026455	
135	004156	151322		.WORD	151322	
136	004160	151322		.WORD	151322	
137	004162	026455		.WORD	026455	
138	004164	151322		.WORD	151322	
139	004166	026455		.WORD	026455	
140	004170	151322		.WORD	151322	
141	004172	026455		.WORD	026455	
142	004174	151322		.WORD	151322	
143						
144	004176	155555	PAT8:	.WORD	155555	;PATTERN 8 (WORST CASE)
145	004200	133333		.WORD	133333	
146	004202	155555		.WORD	155555	
147	004204	133333		.WORD	133333	
148	004206	155555		.WORD	155555	
149	004210	133333		.WORD	133333	
150	004212	155555		.WORD	155555	
151	004214	133333		.WORD	133333	
152	004216	155555		.WORD	155555	
153	004220	133333		.WORD	133333	
154	004222	155555		.WORD	155555	
155	004224	133333		.WORD	133333	
156	004226	155555		.WORD	155555	
157	004230	133333		.WORD	133333	
158	004232	155555		.WORD	155555	
159	004234	133333		.WORD	133333	

160				
161	004236	000001	PAT9: .WORD	000001 ;PATTERN 9
162	004240	000002	.WORD	000002
163	004242	000004	.WORD	000004
164	004244	000010	.WORD	000010
165	004246	000020	.WORD	000020
166	004250	000040	.WORD	000040
167	004252	000100	.WORD	000100
168	004254	000200	.WORD	000200
169	004256	000400	.WORD	000400
170	004260	001000	.WORD	001000
171	004262	002000	.WORD	002000
172	004264	004000	.WORD	004000
173	004266	010000	.WORD	010000
174	004270	020000	.WORD	020000
175	004272	040000	.WORD	040000
176	004274	100000	.WORD	100000
177				
178	004276	177776	PAT10: .WORD	177776 ;PATTERN 10
179	004300	177775	.WORD	177775
180	004302	177773	.WORD	177773
181	004304	177767	.WORD	177767
182	004306	177757	.WORD	177757
183	004310	177737	.WORD	177737
184	004312	177677	.WORD	177677
185	004314	177577	.WORD	177577
186	004316	177377	.WORD	177377
187	004320	176777	.WORD	176777
188	004322	175777	.WORD	175777
189	004324	173777	.WORD	173777
190	004326	167777	.WORD	167777
191	004330	157777	.WORD	157777
192	004332	137777	.WORD	137777
193	004334	077777	.WORD	077777
194				
195	004336	172666	PAT11: .WORD	172666 ;PATTERN 11
196	004340	155555	.WORD	155555
197	004342	172666	.WORD	172666
198	004344	155555	.WORD	155555
199	004346	172666	.WORD	172666
200	004350	155555	.WORD	155555
201	004352	172666	.WORD	172666
202	004354	155555	.WORD	155555
203	004356	172666	.WORD	172666
204	004360	155555	.WORD	155555
205	004362	172666	.WORD	172666
206	004364	155555	.WORD	155555
207	004366	172666	.WORD	172666
208	004370	155555	.WORD	155555
209	004372	172666	.WORD	172666
210	004374	155555	.WORD	155555
211				
212	004376	077777	PAT12: .WORD	077777 ;PATTERN 12
213	004400	137777	.WORD	137777
214	004402	157777	.WORD	157777
215	004404	167777	.WORD	167777
216	004406	173777	.WORD	173777

217	004410	175777		.WORD	175777	
218	004412	176777		.WORD	176777	
219	004414	177377		.WORD	177377	
220	004416	177577		.WORD	177577	
221	004420	177677		.WORD	177677	
222	004422	177737		.WORD	177737	
223	004424	177757		.WORD	177757	
224	004426	177767		.WORD	177767	
225	004430	177773		.WORD	177773	
226	004432	177775		.WORD	177775	
227	004434	177776		.WORD	177776	
228						
229	004436	153333	PAT13:	.WORD	153333	;PATTERN 13
230	004440	066667		.WORD	066667	
231	004442	153333		.WORD	153333	
232	004444	066667		.WORD	066667	
233	004446	153333		.WORD	153333	
234	004450	066667		.WORD	066667	
235	004452	153333		.WORD	153333	
236	004454	066667		.WORD	066667	
237	004456	153333		.WORD	153333	
238	004460	066667		.WORD	066667	
239	004462	153333		.WORD	153333	
240	004464	066667		.WORD	066667	
241	004466	153333		.WORD	153333	
242	004470	066667		.WORD	066667	
243	004472	153333		.WORD	153333	
244	004474	066667		.WORD	066667	
245						
246	004476	000000	PAT14:	.WORD	000000	;PATTERN 14
247	004500	177777		.WORD	177777	
248	004502	177777		.WORD	177777	
249	004504	177777		.WORD	177777	
250	004506	177777		.WORD	177777	
251	004510	177777		.WORD	177777	
252	004512	177777		.WORD	177777	
253	004514	177777		.WORD	177777	
254	004516	177777		.WORD	177777	
255	004520	177777		.WORD	177777	
256	004522	177777		.WORD	177777	
257	004524	177777		.WORD	177777	
258	004526	177777		.WORD	177777	
259	004530	177777		.WORD	177777	
260	004532	177777		.WORD	177777	
261	004534	177777		.WORD	177777	
262						
263	004536	177777	PAT15:	.WORD	177777	;PATTERN 15
264	004540	000000		.WORD	000000	
265	004542	000000		.WORD	000000	
266	004544	000000		.WORD	000000	
267	004546	000000		.WORD	000000	
268	004550	000000		.WORD	000000	
269	004552	000000		.WORD	000000	
270	004554	000000		.WORD	000000	
271	004556	000000		.WORD	000000	
272	004560	000000		.WORD	000000	
273	004562	000000		.WORD	000000	

274	004564	000000	.WORD	000000
275	004566	000000	.WORD	000000
276	004570	000000	.WORD	000000
277	004572	000000	.WORD	000000
278	004574	000000	.WORD	000000

```

1                                     ;THIS ROUTINE HANDLES UNEXPECTED TIMEOUTS
2
3 004576 011600 BADTMO: MOV (SP),R0 ;SAVE PC WHERE THE TIME OUT OCCURED
4 004600 005740 TST -(R0) ;ADJUST PC -2
5 004602 022626 CMP (SP)+,(SP)+ ;RESTORE STACK POINTER
6 004604 104401 004612 TYPE .65$ ;:TYPE ASCII STRING
004610 000417 BR 64$ ;:GET OVER THE ASCIIZ
;:65$: .ASCIIZ <CRLF>/UNEXPECTED BUS TIMEOUT, PC=/
64$:
7 004650 MOV R0,-(SP) ;SETUP FOR TYPING OUT PC ;
8 004652 TYPOC
9 004654 NOP ;PUT 'HALT(0)' INSTRUCTION HERE IF YOU WISH
;TO STOP ON UNEXPECTED TIMEOUT.
10 BR START1 ;BRANCH TO START1
11 004656 000404
12
13 .SBTTL START OF PROGRAM
14
15 004660 012737 177777 001324 START3: MOV #-1,BUSADR ;GET BUSADR FLAG
16 004666 000402 BR STRT1A
17
18 004670 005037 001324 START1: CLR BUSADR ;CLR BUSADR FLAG
19 004674 005037 001322 STRT1A: CLR CNTRLC ;NO CONTROL 'C'
20 004700 000411 BR START
21
22 004702 012737 177777 001324 START4: MOV #-1,BUSADR ;SET BUSADR FLAG
23 004710 000402 BR STRT2A
24
25 004712 005037 001324 START2: CLR BUSADR ;CLR BUSADR FLAG
26 004716 012737 177777 001322 STRT2A: MOV #-1,CNTRLC ;SET CONTROL 'C' FLAG
27
28 004724 000240 START: NOP
29 004726 005227 000000 INC #0 ;TTY LOOP, WAIT FOR INCREMENT
30 004732 001375 BNE -.4 ;OF WORD
31 004734 000005 RESET ;CLEAR THE WORLD
32
33 .SBTTL INITIALIZE THE COMMON TAGS
;:CLEAR THE COMMON TAGS ($CMTAG) AREA
004736 012706 001114 MOV #SCMTAG,R6 ;:FIRST LOCATION TO BE CLEARED
004742 005026 CLR (R6)+ ;:CLEAR MEMORY LOCATION
004744 022706 001154 CMP #SWR,R6 ;:DONE?
004750 001374 BNE -.6 ;:LOOP BACK IF NO
004752 012706 001100 MOV #STACK,SP ;:SETUP THE STACK POINTER
;:INITIALIZE A FEW VECTORS
004756 012737 025356 000020 MOV #SCOPE,@IOTVEC ;:IOT VECTOR FOR SCOPE ROUTINE
004764 012737 000340 000022 MOV #340,@IOTVEC+2 ;:LEVEL 7
004772 012737 021620 000030 MOV #ERROR,@EMTVEC ;:EMT VECTOR FOR ERROR ROUTINE
005000 012737 000340 000032 MOV #340,@EMTVEC+2 ;:LEVEL 7
005006 012737 026052 000034 MOV #STRAP,@TRAPVEC ;:TRAP VECTOR FOR TRAP CALLS
005014 012737 000340 000036 MOV #340,@TRAPVEC+2 ;:LEVEL 7
005022 013737 021514 021506 MOV $ENDCT,$EOPCT ;:SETUP END-OF-PROGRAM COUNTER
005030 012737 176543 026524 MOV #176543,$HINUM ;:PRIME THE RANDOM NUMBER GENERATOR
005036 012737 123456 026526 MOV #123456,$LONUM ;:BOTH HIGH AND LOW WORDS
005044 005037 001220 CLR $TIMES ;:INITIALIZE NUMBER OF ITERATIONS
005050 005037 001222 CLR $ESCAPE ;:CLEAR THE ESCAPE ON ERROR ADDRESS
005054 112737 000001 001131 MOVB #1,$ERMAX ;:ALLOW ONE ERROR PER TEST
005062 012737 005062 001122 MOV #,$SLPADR ;:INITIALIZE THE LOOP ADDRESS FOR SCOPE
005070 012737 005070 001124 MOV #,$SLPERR ;:SETUP THE ERROR LOOP ADDRESS
    
```

```

        ::SIZE FOR A HARDWARE SWITCH REGISTER, IF NOT FOUND OR IT IS
        ::EQUAL TO A "-1", SETUP FOR A SOFTWARE SWITCH REGISTER.
005076 013746 000004      MOV    @#ERRVEC,-(SP)  ;;SAVE ERROR VECTOR
005102 012737 005136 000004  MOV    #64$,@#ERRVEC  ;;SET UP ERROR VECTOR
005110 012737 177570 001154  MOV    #DSWR,SWR      ;;SETUP FOR A HARDWAPE SWICH REGISTER
005116 012737 177570 001156  MOV    #DDISP,DISPLAY ;;AND A HARDWARE DISPLAY REGISTER
005124 022777 177777 174022  CMP    #-1,@SWR      ;;TRY TO REFERENCE HARDWARE SWR
005132 001012      BNE    66$           ;;BRANCH IF NO TIMEOUT TRAP OCCURRED
                                ;;AND THE HARDWARE SWR IS NOT. - 1
005134 000403      BR     65$           ;;BRANCH IF NO TIMEOUT
005136 012716 005144 64$:   MOV    #65$, (SP)    ;;SET UP FOR TRAP RETURN
005142 000002      RTI
005144 012737 000176 001154 65$:   MOV    #SWREG,SWR    ;;POINT TO SOFTWARE SWR
005152 012737 000174 001156  MCV    #DISPREG,DISPLAY
005160 012637 000004 66$:   MOV    (SP)+,@#ERRVEC ;;RESTORE ERROR VECTOR

005164 005037 001242      CLR    $PASS         ;;CLEAR PASS COUNT
005170 132737 000200 001255  BITB   #APTSIZE,$ENVM ;;TEST USER SIZE UNDER APT
005176 001403      BEQ    67$         ;;YES,USE NON-APT SWITCH
005200 012737 001256 001154  MOV    #SSWREG,SWR   ;;NO,USE APT SWITCH REGISTER
005206      67$:
34      ;SETUP "TIMEOUT" TRAP VECTOR FOR UNEXPECTED BUS TIMEOUTS
35 005206 012737 004576 000004  MOV    #BADTMO,ERRVEC ;;SETUP FOR UNEXPECTED TIMEOUT
36 005214 012737 000300 000006  MOV    #PR6,ERRVEC+2  ;;LEVEL 6
37
38      .SBTTL TYPE PROGRAM NAME
        ;;TYPE THE NAME OF THE PROGRAM IF FIRST PASS
005222 005227 177777      INC    #-1           ;;FIRST TIME?
005226 001034      BNE    68$         ;;BRANCH IF NO
005230 022737 021560 000042  CMP    #SENDAD,@#42  ;;ACT-11?
005236 001430      BEQ    68$         ;;BRANCH IF YES
005240 104401 005246      TYPE   .69$        ;;TYPE ASCIZ STRING
005244 000425      BR     68$         ;;GET OVER THE ASCIZ
        ;;69$: .ASCIZ <CRLF>@CZRMVBO - RM05/3/2 EXTENDED DRIVE TEST@<CRLF>
005320      68$:
        .SBTTL GET VALUE FOR SOFTWARE SWITCH REGISTER
005320 005737 000042      TST    @#42         ;;ARE WE RUNNING UNDER XXDP/ACT?
005324 001012      BNE    70$         ;;BRANCH IF YES
005326 123727 001254 000001  CMPB   $ENV,#1       ;;ARE WE RUNNING UNDER APT?
005334 001406      BEQ    70$         ;;BRANCH IF YES
005336 023727 001154 000176  CMP    SWR,#SWREG    ;;SOFTWARE SWITCH REG SELECTED?
005344 001005      BNE    71$         ;;BRANCH IF NO
005346 104406      GTSWR
005350 000403      BR     71$         ;;GET SOFT-SWR SETTINGS
005352 112737 000001 001150 70$:   MOVB   #1,$AUTOB     ;;SET AUTO-MODE INDICATOR
005360      71$:

39
40 005360 012700 001174      MOV    #SREGAD,RO    ;;FIRST ADDRESS
41 005364 005020 1$:     CLR    (RO)+         ;;CLEAR VARIABLE STORAGE
42 005366 022700 001224      CMP    #SBELL,RO    ;;DONE?
43 005372 001374      BNE    1$         ;;NO--BRANCH
44 005374 013737 001530 001164  MOV    TPS,$TPS     ;;SETUP THE STATUS AND BUFFER REG'S
45 005402 013737 001532 001166  MOV    TPB,$TPB     ;;FOR THE TYPE ROUTINE
46
47      ;THE FOLLOWING FINDS OUT THE PROGRAM CONTROL MODE:
48      ;PAPER TAPE (MANUAL), ACT11, XXDP CHAIN OR DUMP
49

```

```

50 005410 005037 001470 CLR XNDP ;CLEAR 'XNDP' LOAD DEVICE STORAGE
51 005414 122737 C00016 000041 CMPB #16,@#41 ;LOADED FROM AN RM05/3/2 ?
52 005422 001160 BNE 4$ ;BR IF NOT
53 005424 013737 000040 001470 MOV @#40,XNDP ;GET DEVICE INDICATOR AND NUMBER
54 005432 122737 000007 001470 CMPB #7,XNDP ;IS IT A VALID NUMBER ?
55 005440 103002 BHIS 2$ ;YES
56 005442 105037 001470 CLRB XNDP ;NO, DEFAULT TO DRIVE 0
57 005446 005737 000042 2$: TST @#42 ;CHAIN MODE OR ACT11 AUTO ACCEPT ?
58 005452 001425 BEQ 3$ ;BR IF NEITHER
59 005454 104401 005462 TYPE ,73$ ;;TYPE ASCIZ STRING
005460 000412 BR ,72$ ;;GET OVER THE ASCIZ
;;73$: .ASCIZ <CRLF>/NOT TESTING DRIVE /
72$:

60 005506 005046 CLR -(SP) ;CLEAR WORD ON STACK
61 005510 113716 001470 MOVB XNDP,(SP) ;GET DRIVE ADDRESS
62 005514 104403 TYPOS ;TYPE THE ADDRESS
63 005516 001 .BYTE 1 ;ONLY 1 CHARACTER
64 005517 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
65 005520 104401 001231 .TYPE ,$CRLF ;CR-LF
66 005524 000517 BR 4$ ;GET NUMBER OF DRIVES
67
68 005526 005227 177777 3$: INC #-1 ;FIRST TIME THRU HERE ?
69 005532 001114 BNE 4$ ;NO
70 005534 104401 005542 TYPE ,75$ ;;TYPE ASCIZ STRING
005540 000410 BR ,74$ ;;GET OVER THE ASCIZ
;;75$: .ASCIZ <CRLF>/TO TEST DRIVE /
74$:

71 005562 005046 CLR -(SP) ;CLEAR WORD ON STACK
72 005564 113716 001470 MOVB XNDP,(SP) ;GET DRIVE ADDRESS
73 005570 104403 TYPOS ;TYPE DRIVE ADDRESS
74 005572 001 .BYTE 1 ;ONLY 1 CHARACTER
75 005573 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
76 005574 104401 005602 TYPE ,77$ ;;TYPE ASCIZ STRING
005600 000431 BR ,76$ ;;GET OVER THE ASCIZ
;;77$: .ASCIZ /, HALT PROGRAM, REMOVE RRDPAK AND REPLACE IT/<CRLF>
76$:

005664 TYPE ,78$ ;;TYPE ASCIZ STRING
77 005664 104401 005672 BR 4$ ;;GET OVER THE ASCIZ
005670 000435 ;;78$: .ASCIZ /WITH A WORK PAK, CLEAR LOCATION 40 AND RESTART PROGRAM./<CRLF>
4$:

81 005764 004737 024060 JSR PC,$TKINT ;TURN ON THE TTY KEYBOARD INTERRUPT
82 005770 005227 177777 INC #-1 ;SEE IF FIRST START
83 005774 001002 BNE SRTINT ;BR IF NOT
84 005776 004737 046624 JSR PC,GETADR ;GET OR CHECK THE RH/RM ADDRESS
85
86 006002 105037 001472 SRTINT: CLRB ERRCN ;CLEAR DRV 0 ERROR COUNT
89 006006 105037 001473 CLRB ERRCN+1 ;CLEAR DRV 1 ERROR COUNT
006012 105037 001474 CLRB ERRCN+2 ;CLEAR DRV 2 ERROR COUNT
006016 105037 001475 CLRB ERRCN+3 ;CLEAR DRV 3 ERROR COUNT
006022 105037 001476 CLRB ERRCN+4 ;CLEAR DRV 4 ERROR COUNT
006026 105037 001477 CLRB ERRCN+5 ;CLEAR DRV 5 ERROR COUNT
006032 105037 001500 CLRB ERRCN+6 ;CLEAR DRV 6 ERROR COUNT
006036 105037 001501 CLRB ERRCN+7 ;CLEAR DRV 7 ERROR COUNT
90 006042 004737 027364 JSR PC,LP.AVL ;CHECK FOR A LINE PRINTER
91 006046 012737 000001 001120 MOV #1,$ICNT ;SET ITERATION COUNT TO 1
92 006054 004737 035450 JSR PC,GETSWR ;GO CHECK FOR CONTROL SWITCHES
93

```

```

94 006060 004737 027426 SETVEC: JSR PC,ST.CLK ;INITIALIZE THE CLOCK
95 006064 004737 C40660 JSR PC,RMINIT ;CHECK THE DRIVE STATUS
96 006070 012737 177777 040610 MOV #-1,SAVEFG ;SET THE SAVE REGISTERS FLAG
97 006076 004737 027334 JSR PC,CNTCLR ;GO CLEAR MASSBUS CONTROLLER
98 006102 005037 177776 CLR PS ;ENSURE THE PRIORITY = 0
99 006106 005227 177777 INC #-1 ;FIRST TIME THRU HERE ?
100 006112 001403 BEQ 1$ ;BR IF NO
101 006114 005737 001322 TST (NTRLC ;CONTROL 'C' SWITCH SET ?
102 006120 001105 BNE SRTDRV ;CONTINUE IF YES
103 006122 005004 1$: CLR R4 ;DRIVE TABLE POINTER
104 006124 104401 047313 TYPE ,UNSTAT ;TYPE 'UNIT STATUS'
105 006130 104401 001231 2$: TYPE ,$CRLF ;CR-LF
106 006134 010446 MOV R4,-(SP) ;;SAVE R4 FOR TYPEOUT
;TYPE DRIVE NUMBER
;GO TYPE--OCTAL ASCII
;TYPE 2 DIGIT(S)
006136 104403 TYPOS ;SUPPRESS LEADING ZEROS
006140 002 .BYTE 2 ;TYPE 4 SPACFS
006141 000 .BYTE 0 ;CHECK DRIVE'S STATUS
107 006142 104401 050343 TYPE ,BLNKS4 ;BR IF UNSAFE
108 006146 105764 040532 ~STB DRVSTA(R4) ;BR IF ONLINE
109 006152 100416 BMI 5$ ;SEE IF OFFLINE OR NONEXISTENT
110 006154 001020 BNE 6$ ;BR IF NONEXISTENT
111 006156 105764 040542 TSTB DRVTP(R4) ;BR IF OFFLINE
112 006162 001404 BEQ 3$ ;DRIVE NOT AN RM05/3/2
113 006164 100006 BPL 4$ ;CHECK NEXT DRIVE
114 006166 104401 047377 TYPE ,NOTRM
115 006172 000452 BR 11$ ;DRIVE NOT PRESENT
116 117 006174 104401 047352 3$: TYPE ,NOTPRS ;CHECK NEXT DRIVE
118 006200 000447 BR 11$
119 120 006202 104401 047331 4$: TYPE ,UNTOFF ;DRIVE OFFLINE
121 006206 000416 BR 8$ ;PRINT DRIVE TYPE
122 123 006210 104401 047367 5$: TYPE ,NOTSAF ;DRIVE UNSAFE
124 006214 000413 BR 8$ ;PRINT DRIVE TYPE
125 126 006216 005737 001470 6$: TST XXDP ;LOADED FROM THIS DEVICE ?
127 006222 001406 BEQ 7$ ;BR IF NO
128 006224 123704 001470 CMPB XXDP,R4 ;LOADED FROM THIS DRIVE ?
129 006230 001003 BNE 7$ ;BR IF NO
130 006232 104401 047420 TYPE ,LODEV ;DRIVE IS LOAD DEVICE
131 006236 000430 BR 11$
132 006240 104401 047342 7$: TYPE ,UNTON ;DRIVE ONLINE
133 006244 104401 050345 8$: TYPE ,BLNKS2 ;TYPE 2 SPACES
134 006250 005000 CLR RO
135 006252 116400 040542 MOVB DRVTP(R4),RO ;GET DRIVE TYPE
136 006256 012737 047445 006316 MOV #$RM03,10$ ;ASSUME ADDRESS OF RM03 MESSAGE
137 006264 122700 000004 CMPB #4,RO ;IS DEVICE AN RM03 ?
138 006270 001411 BEQ 9$ ;TYPE IT IF YES
139 006272 012737 047440 006316 MOV #$RM02,10$ ;ADDRESS OF RM02 MESSAGE
140 006300 122700 000005 CMPB #5,RO ;IS DEVICE AN RM02 ?
141 006304 001403 BEQ 9$ ;BR IF YES
142 006306 012737 047452 006316 MOV #$RM05,10$ ;ADDRESS OF RM05 MESSAGE
143 144 006314 104401 9$: TYPE ;TYPE THE DRIVE TYPE MESSAGE
145 006316 000000 10$: .WORD 0 ;MESSAGE ADDRESS HERE
146

```

147	006320	005204		11\$:	INC	R4	: INCREMENT DRIVE NUMBER/TABLE POINTER
148	006322	020427	C00010		CMP	R4,#8.	: FINISHED ?
149	006326	001300			BNE	2\$: BR IF NOT
150	006330	104401	001231		TYPE	,\$CRLF	: CR-LF

```

1          .SBTTL  GET UNIT STATUS
2
3 J06334  005737  001322  SRTDRV: TST  CNTRLC      ;CONTROL 'C' START/RESTART?
4 006340  001427          BEQ  2$          ;NO--BRANCH
5 006342  013746  001320  MOV  SAVCSW,-(SP)    ;GET THE PREVIOUS 'C.SWR' CONTENTS
6 006346  063716  001314  ADD  C.SWR,(SP)     ;SET UP TO SEE IF 'BIT00' IS DIFFERENT
7 006352  032726  000001  BIT  #BIT00,(SP)+   ;IS 'BIT00' DIFFERENT ?
8 006356  001405          BEQ  1$          ;BR IF NOT
9 006360  013737  001314  001320 MOV  C.SWR,SAVCSW   ;STORE PRESENT 'C.SWR' VALUE
10 006366  004737  027704  JSR  PC,LODFLT     ;RESET PARAMETERS TO THEIR DEFAULT VALUES
11 006372  004737  035700  1$: JSR  PC,GT,PRM   ;GET PARAMETERS
12 006376  005737  001332  TST  TSTNMS        ;ANY TEST SELECTED THIS CYCLE?
13 006402  001034          BNE  6$          ;BR IF YES
14 006404  005737  001334  TST  TSTNMS+2     ;ANY TEST SELECTED THIS CYCLE ?
15 006410  001031          BNE  6$          ;BR IF YES
16 006412  104401  047727  TYPE ,NOTEST      ;TYPE 'NO TESTS SPECIFIED'
17 006416  000765          BR   1$
18 006420  004737  027704  2$: JSR  PC,LODFLT  ;SETUP DEFAULT PARAMETERS
19 006424  005037  001330  CLR  DRVSEL       ;NO DRIVES SELECTED
20 006430  005000  CLR  RO           ;DETERMINE THE DRIVES THAT
21 006432  012701  000001  MOV  #1,R1        ;ARE AVAILABLE FOR TESTING
22
23 006436  105760  040532  3$: TSTB DRVSTA(RO) ;IS DRIVE ON-LINE ?
24 006442  003411          BLE  5$          ;BR IF NO
25 006444  005737  001470  TST  XXDP         ;LOADED FROM THIS DEVICE ?
26 006450  001403          BEQ  4$          ;BR IF NO
27 006452  123700  001470  CMPB XXDP,RO     ;LOADED FROM THIS DRIVE ?
28 006456  001403          BEQ  5$          ;BR IF YES
29 006460  156037  040636  001330 4$: BISB ATABIT(RO),DRVSEL ;YES, SELECT DRIVE FOR TESTING
30 006466  005200  5$: INC  RO         ;TRY NEXT DRIVE
31 006470  106301  ASLB R1          ;ANY MORE DRIVES TO CHECK ?
32 006472  001361          BNE  3$          ;BR IF YES
33
34 006474  005037  040612  6$: CLR  SEEKFG     ;CLEAR SEEK FLAG
35 006500  032737  000400  001314 BIT  #SW08,C.SWR   ;DO SEEK BEFORE DATA TRANSFER?
36 006506  001002          BNE  7$          ;YES--BRANCH
37 006510  005137  040612  COM  SEEKFG       ;NO
38 006514          7$:
39 006514  104401  047457  TYPE ,DRIVES     ;'DRIVES(S) TO BE TESTED'
40 006520  005037  021514  CLR  $ENDCT      ;DETERMINE PASSES TO MAKE AND
41 006524  005000  CLR  RO         ;THE DRIVES TO BE TESTED
42 006526  013701  001330  MOV  DRVSEL,R1   ;ANY DRIVES SELECTED?
43 006532  001017          BNE  9$          ;YES--BRANCH
44 006534  104401  047510  TYPE ,NONE       ;'NONE'
45 006540  104401  001231  TYPE ,$CRLF     ;CR-LF
46 006544  005737  000042  TST  #42         ;ANY MONITOR PRESENT ?
47 006550  001002          BNE  8$          ;BR IF YES
48 006552  000137  004712  JMP  START2      ;RETURN TO '^C' INPUT
49 006556  005300  8$: DEC  RO         ;THESE TWO LOOPS ARE ADDED TO
50 006560  001376  BNE  -2         ;WAIT FOR TTY
51 006562  005300  DEC  RO
52 006564  001376  BNE  -2
53 006566  000137  021550  JMP  $GET42     ;RETURN CONTROL TO MONITOR
54
55 006572  006201  9$: ASR  R1         ;REPORT THE DRIVES TO BE TESTED
56 006574  103011  BCC  10$
57 006576  005237  021514  INC  $ENDC1     ;GIVE THIS DRIVE A PASS

```

51

58	006602	010046			MOV	R0,-(SP)	::SAVE R0 FOR TYPEOUT
	006604	104403			TYPOS		::GO TYPE--OCTAL ASCII
	006606	001			.BYTE	1	::TYPE 1 DIGIT(S)
	006607	000			.BYTE	0	::SUPPRESS LEADING ZEROS
59	006610	005701			TST	R1	::MORE DRIVES?
60	006612	001404			BEQ	11\$::NO--BRANCH
61	006614	104401	047515		TYPE	,CL,MA	::
62	006620	005200		10\$:	INC	R0	::FORM DRIVE NUMBER
63	006622	000763			BR	9\$::
64							
65	006624	104401	001231		TYPE	,\$CR LF	::CR-LF
66	006630	013737	021514	021506	MOV	,\$ENDCT,\$EOPCT	
67	006636	005737	001342		TST	CLKSTA	::IS KW11-P AVAILABLE ?
68	006642	003006			BGT	12\$::BR IF YES
69	006644	032737	036000	001332	BIT	#36000,\$TSTNMS	::ANY TIMING TESTS TO BE PERFORMED ?
70	006652	001402			BEQ	12\$::BR IF NO
71	006654	104401	047520		TYPE	,NOCLOCK	::TYPE NO KW11-P CLOCK MESSAGE
72	006660	000414		12\$:	BR	RSTR11	


```

1          .SBTTL PROGRAM RESTARTS HERE
2
3          .ENABL LSB
4
5 006662 005737 001330 RSTART: TST   DRVSEL   ;ANY DRIVES SELECTED ?
6 006666 001022          BNE     3$      ;BR IF YES
7 006670 005737 000042 TST   @#42   ;ANY MONITOR PRESENT ?
8 006674 001402          BEQ     1$      ;BR IF NO
9 006676 000137 021550 JMP   $GET42 ;RETURN CONTROL TO MONITOR
10 006702 104401 047703 1$:   TYPE  ,NODRVS ;TYPE 'NO DRIVES TO TEST'
11 006706 000137 004712 JMP   START2 ;NO--GET DRIVE ENTRY & RESTART AT BEGINNING
12
13 006712 005037 001352 RSTR1: CLR  CHKDRV   ;START WITH DRIVE 0 AGAIN
14 006716 012737 000001 001354 MOV  #1,DRVMSK
15 006724 033737 001354 001330 2$:  BIT  DRVMSK,DRVSEL ;IS THIS DRIVE SELECTED?
16 006732 001006          BNE     4$      ;YES--GO CHECK IF DRIVE IS READY FOR TESTING
17 006734 005237 001352 3$:  INC  CHKDRV   ;MOVE TO NEXT DRIVE NUMBER
18 006740 106337 001354 ASLB  DRVMSK   ;DONE TESTING ALL DRIVES ?
19 006744 103762          BCS   RSTR1   ;BR IF YES
20 006746 000766          BR     2$      ;NO--CHECK DRIVE SELECT
21
22 006750 013702 001352 4$:  MOV  CHKDRV,R2 ;PICKUP THE DRIVE NUMBER
23 006754 105762 040532 TSTB DRVSTA(R2) ;IS DESIRED DRIVE ON-LINE?
24 006760 003007          BGT     5$      ;YES, BRANCH
25 006762 104011          EMT     11     ;DRIVE SELECTED IS NOT ONLINE
26 006764 043737 001354 001330 BIC  DRVMSK,DRVSEL ;DESELECT DRIVE FROM TEST
27 006772 005337 021506 DEC  $EOPCT   ;ADJUST 'EOP' COUNT
28 006776 000731          BR     RSTART ;RETURN
29
30 007000 004737 027334 5$:  JSR  PC,CNTCLR ;GO CLEAR MASSBUS CONTROLLER
31 007004 005037 177776 CLR  PS      ;ENSURE THE PRIORITY = 0
32 007010 010237 047016 MOV  R2,DPB.A ;SET THE DRIVE NUMBER INTO THE DPB'S
33 007014 010237 047036 MOV  R2,DPB.B
34 007020 010237 047056 MOV  R2,DPB.C
35 007024 010237 047076 MOV  R2,DTADPB
36 007030 004737 030336 JSR  PC,LDCMD ;LOAD COMMAND INTO DPB.B AND DPB.C
37 007034 012737 021334 001350 MOV  #$EOP,BYPASS ;IF ERROR GO TO END OF PROGRAM
38 007042 112737 000020 047017 MOV  #20,DPB.A+1 ;ASSUME 16 BIT FORMAT
39 007050 032737 000001 001314 BIT  #BIT00,C.SWR ;16 BIT FORMAT REQUESTED ?
40 007056 001402          BEQ     6$      ;BR IF YES
41 007060 105037 047017 CLR  DPB.A+1 ;CLEAR THE 'FMT16' BIT
42 007064 112737 000143 047020 6$:  MOV  #SETFORM,DPB.A+2 ;SET THE FORMAT BIT PER DPB.A+1
43 007072 004037 030402 JSR  R0,CALL.A ;GO EXECUTE THE COMMAND
44 007076 112737 000107 047020 MOV  #RECAL,DPB.A+2 ;RECAL=COMMAND
45 007104 004037 030402 JSR  R0,CALL.A ;GO EXECUTE THE COMMAND
46 007110 104401 001231 TYPE  ,SCLF   ;CR-LF
47 007114 104401 047625 TYPE  ,MSDRIV ;TYPE 'DRIVE '
48 007120 010246 MOV  R2,-(SP) ;SAVE R2 FOR TYPEOUT
   007122 104403 ;GO TYPE--OCTAL ASCII
   007124 002    ;TYPE 2 DIGIT(S)
   007125 000    ;SUPPRESS LEADING ZEROS
49 007126 104401 047515 TYPE  ,COMMA ;TYPE ','
50 007132 104401 047605 TYPE  ,SERIAL ;TYPE 'MBA SN# '
51 007136 012700 000004 MOV  #4,R0   ;FOUR DIGITS TO TYPE
52 007142 013701 047170 MOV  RM,REG+30,R1 ;SERIAL NUMBER
53 007146 005002 7$:  CLR  R2     ;ZERO
54 007150 006101 ROL  R1     ;PUT THE NEXT DIGIT

```

```

55 007152 006102          ROL    R2          ; INTO R2
56 007154 006101          ROL    R1
57 007156 006102          ROL    R2
58 007160 006101          ROL    R1
59 007162 006102          ROL    R2
60 007164 006101          ROL    R1
61 007166 006102          ROL    R2
62 007170 062702 000060  ADD    #0,R2      ; MAKE IT ASCII
63 007174 010227          MOV    R2,(PC)+   ; SAVE IT
64 007176 000000          8$: .WORD 0
65 007200 104401 007176  TYPE    ,8$      ; TYPE
66 007204 005300          DEC    R0        ; ALL DIGITS TYPED?
67 007206 003357          BGT    7$        ; NO -- BRANCH
68 007210 104401          TYPE    ,$CRLF   ; CR-LF
69 007214 113737 001464 001131 MOVB   ERR.CT,$ERMAX ; SETUP MAX ERROR COUNT
70
71          .DSABL  LSB

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
43
44

```

://////
*IN THE DESCRIPTIONS OF THE BELOW TESTS THE VARIABLES USED
*AND THEIR DEFAULT VALUES (UNLESS SPECIFIED OTHERWISE) ARE:
*
*MNEMONIC      VALUE      VARIABLE
*-----
*R              1          ITERATIONS (REPEATS)
*FC             0          FIRST CYLINDER ADDRESS
*LC             822.       LAST CYLINDER ADDRESS
*IC             1          INCREMENT VALUE
*NC OF NC1     FC+IC      NEW OR MODIFIED CYLINDER
                        ADDRESS
*NC2           LC-IC      NEW OR MODIFIED CYLINDER
                        ADDRESS
*
*FT             0          FIRST TRACK ADDRESS
*LT             4 OR 18.   LAST TRACK ADDRESS
*IT             1          INCREMENT VALUE
*NT             FT+IT      NEW OR MODIFIED TRACK ADDRESS
*
*FS             0          FIRST SECTOR ADDRESS
*LS             31.       LAST SECTOR ADDRESS
*
://////

```

.SBTTL SEEK TESTS

```

://////
*THE SEEK TESTS WILL BE EXECUTED USING IMPLIED SEEKS. THESE
*IMPLIED SEEKS WILL BE PERFORMED BY 'READ HEADER AND DATA'
*COMMANDS TO TRACK 'FT' SECTOR 'FS' OF THE DESIRED CYLINDER.
*THE WORD COUNT WILL BE SET SUCH THAT ONLY THE CYLINDER AND
*TRACK/SECTOR WORDS OF THE HEADER ARE READ.
://////

```

```

:*****
*TEST 0 RECAL/RANDOM SEEK TEST
*THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A RECALIBRATE COMMAND
*AND THEN SEEK TO A RANDOM CYLINDER BETWEEN 'FC' AND 'LC'. AT
*THE COMPLETION OF BOTH COMMANDS, STATUS INDICATORS ARE CHECKED
*TO ENSURE THAT NO ERRORS OCCURRED.
:*****

```

```

007222
007222 000240
007224 033737 001540 001332
007232 001002
007234 000137 007464

007240 012737 000000 001116
007246 004737 030142
007252 012737 007372 001124
007260 013737 002336 001220
007266 112737 000031 001131
007274 012737 000000 001240

NOP
BIT BITS+<0*2>,TSTNMS ;DO THIS TEST?
BNE +6 ;BR IF YES
JMP TST1 ;NO--JUMP TO TEST1

MOV #0,$TSTNM ;SET TEST #0 AND CLEAR ($SERFLG)
JSR PC,LODPRM ;LOAD THE PARMETERS FOR THE TEST
MOV #TEST0,$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
MOV RPT,$TIMES ;GET THE ITERATION COUNT
MOVB #25,$SERMAX ;MAX ERRORS ALLOWED FOR TEST
MOV #0,$TESTN ;SET TEST NUMBER IN APT MAIL BOX

```

```

007302 032777 010000 171644 BIT #SW12,@SWR ;INHIBIT TYPING TEST NUMBER ?
007310 001406 BEQ .+16 ;BR IF YES
007312 104401 047617 TYPE ,MSGTST ;TYPE 'TEST'
007316 013746 001240 MOV $TESTN,-(SP) ;;SAVE $TESTN FOR TYPEOUT
007322 104403 TYPOS ;;GO TYPE--OCTAL ASCII
007324 002 .BYTE 2 ;;TYPE 2 DIGIT(S)
007325 000 .BYTE 0 ;;SUPPRESS LEADING ZEROS

46 007326 112737 000107 047020 MOVB #RECAL,DPB.A+2 ;RECAL=COMMAND
47 007334 113737 002354 047046 MOVB FS,DPB.B+10 ;FS
48 007342 113737 002346 047047 MOVB FT,DPB.B+11 ;FT
49 007350 013737 002342 047050 MOV LC,DPB.B+12 ;LC
70 007356 012737 007462 001350 MOV #EXITO,BYPASS ;GO TO EXITO ON ERROR
007364 012737 007372 001122 MOV #TESTO,$LPADR ;SETUP LOOP ADDRESS
007372 012706 001100 TESTO: MOV #STACK,SP ;SET UP STACK POINTER
007376 004037 030402 JSR RO,CALL.A ;GO EXECUTE THE COMMAND
007402 013737 002340 047050 MOV FC,DPB.B+12 ;INITIAL CYLINDER ADDRESS
007410 023737 002340 002342 CMP FC,LC ;CYLINDER LIMITS THE SAME :
007416 001417 BEQ 1$ ;BR IF THEY ARE
007420 004737 026426 JSR PC,$RAND ;CYCLE THE RANDOM NUMBER GENERATOR
007424 013746 026524 MOV $HINUM,-(SP) ;USE THE HIGH RANDOM NUMBER
007430 005046 CLR -(SP) ;UPPER DIVIDEND
007432 013746 002342 MOV LC,-(SP) ;FORM THE DIVISOR
007436 005216 INC (SP) ;INCREMENT
007440 163716 002340 SUB FC,(SP) ;SUBTRACT THE LOWER LIMIT
007444 004737 026530 JSR PC,$DIV ;DIVIDE
007450 062637 047050 ADD (SP)+,DPB.B+12 ;ADD THE REMAINDER TO THE INITIAL CYLINDER
007454 005726 TST (SP)+ ;DISCARD THE QUOTENT
1$:
007456 004037 030550 JSR RO,CALL.B ;GO EXECUTE THE COMMAND
007462 000004 EXITO: SCOPE ;CALL SCOPE ROUTINE

```

71
78
79

```

*****
*TEST 1 SEEK/SEEK TEST
*THIS TEST WILL CAUSE THE DRIVE TO EXECUTE A FORWARD SEEK
*CYCLE TO 'LC', 'LT', 'LS' FOLLOWED BY A REVERSE SEEK CYCLE TO
*'FC', 'FT', 'FS'. AT THE COMPLETION OF EACH SEEK, THE PROPER
*INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.
*****

```

```

007464 000240 TST1: NOP
007466 033737 BIT BITS+<1*2>,TSTNMS ;DO THIS TEST?
007474 001002 BNE .+6 ;BR IF YES
007476 000137 007672 JMP TST2 ;NO--JUMP TO TEST2

007502 012737 000001 001116 MOV #1,$TSTNM ;SET TEST #1 AND CLEAR ($ERFLG)
007510 004737 030142 JSR PC,LODPRM ;LOAD THE PARMETERS FOR THE TEST
007514 012737 007654 001124 MOV #TEST1,$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
007522 013737 002336 001220 MOV RPT,$TIMES ;GET THE ITERATION COUNT
007530 112737 000031 001131 MOVB #25,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
007536 012737 000001 001240 MOV #1,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX

80 007544 032777 010000 171402 BIT #SW12,@SWR ;INHIBIT TYPING TEST NUMBER ?
007552 001406 BEQ .+16 ;BR IF YES
007554 104401 047617 TYPE ,MSGTST ;TYPE 'TEST'

```

```

007560 013746 001240
007564 104403
007566 002
007567 000

81 007570 005037 001466
82 007574 113737 002354 047046
83 007602 113737 002356 047066
84 007610 113737 002346 047047
85 007616 113737 002350 047067
86 007624 013737 002340 047050
87 007632 013737 002342 047070
92 007640 012737 007670 001350
007646 012737 007654 001122
007654

93 007654 012706 001100
94 007660 004037 030766
95 007664 004037 030550
96 007670 000004
97
108
109

```

```

MOV $TESTN,-(SP) ;:SAVE $TESTN FOR TYPEOUT
TYPOS ;:GO TYPE--OCTAL ASCII
.BYTE 2 ;:TYPE 2 DIGIT(S)
.BYTE 0 ;:SUPPRESS LEADING ZEROS

CLR BASFLG ;:CLEAR BAD SECTOR ENCOUNTER FOR THE DRIVE
MOVBS FS,DPB.B+10 ;:FS
MOVBS LS,DPB.C+10 ;:LS
MOVBS FT,DPB.B+11 ;:FT
MOVBS LT,DPB.C+11 ;:LT
MOV FC,DPB.B+12 ;:FC
MOV LC,DPB.C+12 ;:LC
MOV #EXIT1,BYPASS ;:GO TO EXIT1 ON ERROR
MOV #TEST1,$LPADR ;:SETUP LOOP ADDRESS

TEST1: MOV #STACK,SP ;:SET THE STACK POINTER
JSR RO,CALL.C ;:GO EXECUTE THE COMMAND
JSR RO,CALL.B ;:GO EXECUTE THE COMMAND
EXIT1: SCOPE ;:CALL SCOPE ROUTINE

```

```

:*****
:*TEST 2 INCREMENT/SEEK TEST
:*THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE
:*CYLINDER ADDRESS FROM 'FC' TO 'LC' BY THE INCREMENT 'IC'.
:*WHEN THE RESULTANT CYLINDER ADDRESS (NC) EXCEEDS
:*'LC' REVERSE SEEK CYCLES ARE INITIATED; STARTING
:*AT THE LAST LEGAL 'NC' AND DECREMENTING BY 'IC'
:*UNTIL 'NC' IS LESS THAN 'FC'. AT THE COMPLETION OF EACH
:*SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO
:*ENSURE PROPER OPERATION.
:*****

```

```

007672
007672 000240
007674 033737 001544 001332
007702 001002
007704 000137 010134

007710 012737 000002 001116
007716 004737 030142
007722 012737 010026 001124
007730 013737 002336 001220
007736 112737 000031 001131
007744 012737 000002 001240

110 007752 032777 010000 171174
007760 001406
007762 104401 047617
007766 013746 001240
007772 104403
007774 002
007775 000

111 007776 012737 010004 001122
112 010004 113737 002354 047046 1$:
113 010012 113737 002346 047047
117 010020 012737 010132 001350

```

```

TST2: NOP
BIT BITS+<2*2>,$TSTNMS ;:DO THIS TEST?
BNE +6 ;:BR IF YES
JMP TST3 ;:NO--JUMP TO TEST3

MOV #2,$TSTNM ;:SET TEST #2 AND CLEAR (SERFLG)
JSR PC,LODPRM ;:LOAD THE PARMETERS FOR THE TEST
MOV #TEST2,$LPERR ;:SETUP THE LOOP ON ERROR ADDRESS
MOV RPT,$TIMES ;:GET THE ITERATION COUNT
MOVBS #25,$ERMAX ;:MAX ERRORS ALLOWED FOR TEST
MOV #2,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX

BIT #SW12,@SWR ;:INHIBIT TYPING TEST NUMBER ?
BEQ +16 ;:BR IF YES
TYPE ,MSGTST ;:TYPE 'TEST'
MOV $TESTN,-(SP) ;:SAVE $TESTN FOR TYPEOUT
TYPOS ;:GO TYPE--OCTAL ASCII
.BYTE 2 ;:TYPE 2 DIGIT(S)
.BYTE 0 ;:SUPPRESS LEADING ZEROS

MOV #1,$$,$LPADR ;:SETUP LOOP ADDRESS
MOVBS FS,DPB.B+10 ;:FS
MCVBS FT,DPB.B+11 ;:FT
MOV #EXIT2,BYPASS ;:GO TO EXIT2 ON ERROR

```

118 010026 013737 002340 047050
 119 010034 012737 010034 001124
 120 010042 012706 001100
 121 010046 004037 030550
 122 010052 063737 002344 047050
 123 010060 023737 002342 047050
 124 010066 002367
 125 010070 013737 002342 047050
 126 010076 012737 010076 001124
 127 010104 012706 001100
 128 010110
 129 010114 004037 030550
 130 010122 163737 002344 047050
 131 010122 023737 002340 047050
 132 010130 003767
 133 010132 000004
 140
 141

TEST2:
 MOV FC,DPB.B+12 ;FC
 MOV #,\$LPERR ;SETUP THE ERROR LOOP ADDRESS
 MOV #STACK,SP ;LOAD THE STACK POINTER
 INCSK:
 JSR RO,CALL.B ;GO EXECUTE THE COMMAND
 ADD IC,DPB.B+12 ;MOVE TO NEXT CYLINDER
 CMP LC,DPB.B+12 ;OUT OF CYLINDERS?
 BGE INCSK ;NO--BRANCH
 MOV LC,DPB.B+12
 MOV #,\$LPERR ;SETUP THE ERROR LOOP ADDRESS
 MOV #STACK,SP ;LOAD THE STACK POINTER
 DECSK:
 JSR RO,CALL.B ;GO EXECUTE THE COMMAND
 SUB IC,DPB.B+12
 CMP FC,DPB.B+12
 BLE DECSK
 EXIT2: SCOPE ;CALL SCOPE ROUTINE

 *TEST 3 STEPPING SEEK TEST
 *THIS TEST WILL COMMAND SEEK CYCLES TO CYLINDER 0, 1, 2, 4,
 *8, 16, 32, 64, 128, 256 AND 512. AT THE COMPLETION OF EACH
 *SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO ENSURE
 *PROPER OPERATION.

142 010134 000240
 010136 033737 001546 001332
 010144 001002
 010146 000137 010354
 010152 012737 000003 001116
 010160 004737 030142
 010164 012737 010270 001124
 010172 013737 002336 001220
 010200 112737 000031 001131
 010206 012737 000003 001240
 010214 032777 010000 170732
 010222 001406
 010224 104401 047617
 010230 013746 001240
 010234 104403
 010236 002
 010237 000
 143 010240 012737 010246 001122
 144 010246 113737 002354 047046
 145 010254 113737 002346 047047
 149 010262 012737 010352 001350
 010270
 150 010270 013737 002340 047050
 151 010276 012737 010276 001124
 010304 012706 001100
 152 010310 004037 030550

TST3:
 NOP ;DO THIS TEST?
 BIT BITS+<3*2>,TSTNMS ;BR IF YES
 BNE +6 ;NO--JUMP TO TEST4
 JMP TST4
 MOV #3,\$TSTNM ;SET TEST #3 AND CLEAR (\$ERFLG)
 JSR PC,LODPRM ;LOAD THE PARAMETERS FOR THE TEST
 MOV #TEST3,\$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
 MOV RPT,\$TIMES ;GET THE ITERATION COUNT
 MOV #25,\$ERMAX ;MAX ERRORS ALLOWED FOR TEST
 MOV #3,\$TESTN ;SET TEST NUMBER IN APT MAIL BOX
 BIT #SW12,@SWR ;INHIBIT TYPING TEST NUMBER ?
 BEQ +16 ;BR IF YES
 TYPE ,MSGTST ;TYPE 'TEST'
 MOV \$TESTN,-(SP) ;SAVE \$TESTN FOR TYPEOUT
 TYPOS ;GO TYPE--OCTAL ASCII
 .BYTE 2 ;TYPE 2 DIGIT(S)
 .BYTE 0 ;SUPPRESS LEADING ZEROS
 1\$:
 MOV #1,\$LPADR ;SETUP TEST LOOP ADDRESS
 MOV# FS,DPB.B+10 ;FS
 MOV# FT,DPB.B+11 ;FT
 MOV #EXIT3,BYPASS ;GO TO BYPASS ON ERROR
 TEST3:
 MOV FC,DPB.B+12 ;FC
 MOV #,\$LPERR ;SETUP THE ERROR LOOP ADDRESS
 MOV #STACK,SP ;LOAD THE STACK POINTER
 JSR RO,CALL.B ;GO EXECUTE THE COMMAND

153 010314 013701 002344
 54 010320 012737 010320
 010326 012706 001100
 155 010332 010137 047050
 156 010336 004037 030550
 157 010342 006301
 158 010344 020137 002342
 159 010350 003770
 160 010352 000004
 161
 169
 170

```

001124      MOV      IC,R1          ;CYLINDER 1
              MOV      #,$LPERR      ;SETUP THE ERROR LOOP ADDRESS
              MOV      #STACK,SP     ;LOAD THE STACK POINTER
1$:          MOV      R1,DPB.B+12    ;DESIRED CYLINDER
              JSR      RO,CALL.B     ;GO EXECUTE THE COMMAND
              ASL      R1             ;MOVE TO NEXT CYLINDER
              CMP      R1,LC         ;DONE?
              BLE     1$             ;NO--LOOP
EXIT3:      SCOPE                    ;CALL SCOPE ROUTINE
    
```

```

*****
*TEST 4      OSCILLATING SEEK TEST
*THIS TEST WILL COMMAND SEEK CYCLES FROM 'FC' TO 'NC' AND BACK
*TO 'FC'. 'NC' STARTS AT 'FC' AND INCREMENTS BY 'IC' UP TO CYLINDER
*'LC', THEN IS DECREMENTED BY 'IC' BACK TO CYLINDER 'FC'. AT THE
*COMPLETION OF EVERY SEEK COMMAND THE PROPER INDICATORS ARE
*EXAMINED TO ENSURE PROPER OPERATION.
*****
TST4:
    
```

010354
 010354 000240
 010356 033737 001550 001332
 010364 001002
 010366 000137 010766

 010372 012737 000004 001116
 010400 004737 030142
 010404 012737 010524 001124
 010412 013737 002336 001220
 010420 112737 000031 001131
 010426 012737 000004 001240
 171
 010434 032777 010000 170512
 010442 001406
 010444 104401 047617
 010450 013746 001240
 010454 104403
 010456 002
 010457 000

 172 010460 012737 010466 001122
 173 010466 113737 002354 047046
 174 010474 113737 002346 047047
 182 010502 012737 010764 001350
 010510 005002
 010512 032737 010000 001314
 010520 001401
 010522 005102
 010524
 183 010524 013701 002340
 184 010530 005037 001436
 185 010534 012737 010534 001124
 010542 012706 001100
 186 010546 010137 047050
 187 010552 004037 030550
 188 010556 005702
 189 010560 001403

```

              NOP
              BIT      BITS+<4*2>,TSTNMS ;DO THIS TEST?
              BNE     +6             ;BR IF YES
              JMP     TST5          ;NO--JUMP TO TEST5
  

              MOV      #4,$TSTNM     ;SET TEST #4 AND CLEAR ($ERFLG)
              JSR      PC,LODPRM     ;LOAD THE PARAMETERS FOR THE TEST
              MOV      #TEST4,$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
              MOV      RPT,$TIMES    ;GET THE ITERATION COUNT
              MOVB     #25,$ERMAX    ;MAX ERRORS ALLOWED FOR TEST
              MOV      #4,$TESTN     ;SET TEST NUMBER IN APT MAIL BOX
  

              BIT      #SW12,@SWR    ;INHIBIT TYPING TEST NUMBER ?
              BEQ     +16            ;BR IF YES
              TYPE     ,MSGTST       ;TYPE 'TEST'
              MOV      $TESTN,-(SP)  ;SAVE $TESTN FOR TYPEOUT
              TYPOS   2              ;GO TYPE--OCTAL ASCII
              .BYTE   2              ;TYPE 2 DIGIT(S)
              .BYTE   0              ;SUPPRESS LEADING ZEROS
  

1$:          MOV      #1,$LPADR      ;SETUP LOOP ADDRESS
              MOVB     FS,DPB.B+10   ;FS
              MOVB     FT,DPB.B+11   ;FT
              MOV      #EXIT4,BYPASS ;GO TO EXIT4 ON ERROR
              CLR      R2            ;CLEAR STALL SWITCH (NO STALL)
              BIT      #SW12,C.SWR    ;STALL REQUIRED?
              BEQ     TEST4          ;NO--BRANCH
              COM      R2            ;YES--SET SWITCH
  

TEST4:      MOV      FC,R1          ;SET NC TO FC
              CLR      STALLO        ;START AT ZERO IF STALLS REQUIRED
              MOV      #,$LPERR      ;SETUP THE ERROR LOOP ADDRESS
              MOV      #STACK,SP     ;LOAD THE STACK POINTER
1$:          MOV      R1,DPB.B+12    ;NC
              JSR      RO,CALL.B     ;GO EXECUTE THE COMMAND
              IST      R2            ;STALL?
              BEQ     2$             ;NO--BRANCH
    
```

```

190 010562 004037 032326 JSR RO,STALL ;YES-GO TO STALL ROUTINE
191 010566 001436 .WORD STALLO ;TIME POINTER
192 010570 013737 002340 047050 2$: MOV FC,DPB.B+12 ;FC
193 010576 004037 030550 JSR RO,CALL.B ;GO EXECUTE THE COMMAND
194 010602 005702 TST R2 ;STALL?
195 010604 001413 BEQ 3$ ;NO--BRANCH
196 010606 004037 032326 JSR RO,STALL ;YES--GO TO STALL ROUTINE
197 010612 001436 .WORD STALLO ;TIME POINTER
198 010614 005237 001436 INC STALLO ;UPDATE THE TIME
199 010620 023737 001462 001436 CMP MXSTAL,STALLO ;TIME TO BIG?
200 010626 003347 BGT 1$ ;NO--BRANCH
201 010630 005037 001436 CLR STALLO ;YES--START OVER AT ZERO
202 010634 063701 002344 3$: ADD IC,R1 ;MOVE TO NEXT CYLINDER
203 010640 020137 002342 CMP R1,LC ;LAST CYLINDER COMPLETED?
204 010644 003740 BLE 1$ ;NO--BRANCH
205 010646 013701 002342 MOV LC,R1 ;SET NC TO LC
206 010652 012737 010652 001124 MOV #,$LPERR ;SETUP THE ERROR LOOP ADDRESS
207 010660 012706 001100 MOV #STACK,SP ;LOAD THE STACK POINTER
208 010664 010137 047050 4$: MOV R1,DPB.B+12 ;NC
209 010670 004037 030550 JSR RO,CALL.B ;GO EXECUTE THE COMMAND
210 010674 005702 TST R2 ;STALL?
211 010676 001403 BEQ 5$ ;NO--BRANCH
212 010700 004037 032326 JSR RO,STALL ;YES--GO TO STALL ROUTINE
213 010704 001436 .WORD STALLO ;TIME POINTER
214 010706 013737 002342 047050 5$: MOV LC,DPB.B+12 ;LC
215 010714 004037 030550 JSR RO,CALL.B ;GO EXECUTE THE COMMAND
216 010720 005702 TST R2 ;STALL?
217 010722 001413 BEQ 6$ ;NO--BRANCH
218 010724 004037 032326 JSR RO,STALL ;YES--GO TO STALL ROUTINE
219 010730 001436 .WORD STALLO ;TIME POINTER
220 010732 005237 001436 INC STALLO ;UPDATE STALL TIME
221 010736 023737 001462 001436 CMP MXSTAL,STALLO ;TIME TOO BIG?
222 010744 003347 BGT 4$ ;NO--BRANCH
223 010746 005037 001436 CLR STALLO ;YES--SET STALL TIME BACK TO ZERO
224 010752 163701 002344 6$: SUB IC,R1 ;NEXT CYLINDER
225 010756 020137 002340 CMP R1,FC ;DONE?
226 010762 002340 BGE 4$ ;NO--BRANCH
227 010764 000004 EXIT4: SCOPE ;CALL SCOPE ROUTINE
228
229

```

```

*****
;*TEST 5 CONVERGING/DIVERGING SEEK TEST
;*THIS TEST WILL CAUSE THE DRIVE TO EXECUTE FORWARD AND REVERSE
;*SEEKS FROM 'NC1' AND 'NC2' RESPECTIVELY, 'NC1' WILL BE INCREMENTED
;*BY 'IC' AND 'NC2' WILL BE DECREMENTED BY 'IC' UNTIL 'NC1' IS
;*GREATER THAN THE INITIAL VALUE OF 'NC2' AND 'NC2' IS
;*LESS THAN THE INITIAL VALUE OF 'NC1'. AT THE COMPLETION OF
;*EACH SEEK COMMAND THE PROPER INDICATORS ARE EXAMINED TO
;*ENSURE PROPER OPERATION. 'NC1' AND 'NC2' DEFAULT TO
;*FC' AND 'LC' RESPECTIVELY.
*****
TST5:

```

```

010766
010766 000240
010770 033737 001552 001332
010776 001002
011000 000137 011212
NOP
BIT BITS+<5*2>,TSTNMS ;DO THIS TEST?
BNE +6 ;BR IF YES
JMP TST6 ;NO--JUMP TO TEST6

```



```

011004 012737 000005 001116      MOV      #5,$STSTNM      ;SET TEST #5 AND CLEAR ($ERFLG)
011012 004737 030142                JSR      PC,LODPRM      ;LOAD THE PARMETERS FOR THE TEST
011016 012737 011122 001124      MOV      #TEST5,$LPERR  ;SETUP THE LOOP ON ERROR ADDRESS
011024 013737 002336 001220      MOV      RPT,$TIMES     ;GET THE ITERATION COUNT
011032 112737 000031 001131      MOVVB   #25,,$ERMAX    ;MAX ERRORS ALLOWED FOR TEST
011040 012737 000005 001240      MOV      #5,$TESTN     ;;SET TEST NUMBER IN APT MAIL BOX

240
011046 032777 010000 170100      BIT      #SW12,@SWR     ;INHIBIT TYPING TEST NUMBER ?
011054 001406                BEQ      .+16           ;BR IF YES
011056 104401 047617                TYPE    ,MSGTST        ;TYPE 'TEST'
011062 013746 001240                MOV      $TESTN,-(SP)   ;;SAVE $TESTN FOR TYPEOUT
011066 104403                TYPPOS                ;;GO TYPE--OCTAL ASCII
011070                .BYIE    2             ;;TYPE 2 DIGIT(S)
011071                .BYTE   0             ;;SUPPRESS LEADING ZEROS

241 011072 012737 011100 001122      MOV      #1$, $LPADR    ;SETUP LOOP ADDRESS
242 011100 113737 002354 047046 1$:  MOVVB   FS,DPB.B+10     ;FS
243 011106 113737 002346 047047      MOVVB   FT,DPB.B+11     ;FT
247 011114 012737 011210 001350      MOV      #EXIT5,BYPASS ;GO TO EXIT5 ON ERROR

TEST5:
248 011122 013701 002340                MOV      FC,R1          ;START NC1 AT FC
249 011126 013702 002342                MOV      LC,R2          ;START NC2 AT LC
250 011132 012737 011132 001124      MOV      #.,$LPERR     ;SETUP THE ERROR LOOP ADDRESS
011140 012706 001100                MOV      #STACK,SP     ;LOAD THE STACK POINTER
251 011144 010137 047050 1$:  MOV      R1,DPB.B+12    ;NC1
252 011150 004037 030550                JSR      R0,CALL.B      ;GO EXECUTE THE COMMAND
253 011154 010237 047050                MOV      R2,DPB.B+12    ;NC2
254 011160 004037 030550                JSR      R0,CALL.B      ;GO EXECUTE THE COMMAND
255 011164 063701 002344                ADD      IC,R1          ;NEXT NC1
256 011170 163702 002344                SUB      IC,R2          ;NEXT NC2
257 011174 020137 002342                CMP      R1,LC          ;DONE?
260 011200 003003                BGT      EXIT5         ;YES--BRANCH
261 011202 020237 002340                CMP      R2,FC          ;?
262 011206 002356                BGE     1$             ;NO--BRANCH
263 011210 000004      EXIT5: SCOPE          ;CALL SCOPE ROUTINE
264
273
274

```

```

*****
;*TEST 6      SERVO ADDRESSING LOGIC NOISE GENERATOR
;*IN THIS TEST A SEEK IS DONE TO CYL 'NC' THEN A SEEK TO
;*NC+4 THEN NC+1 THEN NC+3 THEN NC+2 THEN NC+5.  NOW 'NC' IS UPDATED
;*BY 'IC' AND THE ABOVE SEQUENCE IS REPEATED UNTIL 'LC' IS
;*EXCEEDED BY ANY OF THE ABOVE VALUES.  THE INITIAL VALUE OF 'NC'
;*IS 'FC'.  AT THE COMPLETION OF EACH SEEK COMMAND THE
;*PROPER INDICATORS ARE EXAMINED TO ENSURE PROPER OPERATION.
*****
TST6:

```

```

011212
011212 000240
011214 033737 001554 001332      NOP
011222 001002                BIT      BITS+<6*2>,$TSTNMS ;DO THIS TEST?
011224 000137 011502                BNE     .+6           ;BR IF YES
                                JMP      TST7         ;NO--JUMP TO TEST7

011230 012737 000006 001116      MOV      #6,$STSTNM    ;SET TEST #6 AND CLEAR ($ERFLG)
011236 004737 030142                JSR      PC,LODPRM     ;LOAD THE PARMETERS FOR THE TEST
011242 012737 011346 001124      MOV      #TEST6,$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
011250 013737 002336 001220      MOV      RPT,$TIMES    ;GET THE ITERATION COUNT
011256 112737 000031 001131      MOVVB   #25,,$ERMAX    ;MAX ERRORS ALLOWED FOR TEST

```

```

275 011264 012737 000006 001240      MOV      #6,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX
      011272 032777 010000 167654      BIT      #SW12,@SWR      ;INHIBIT TYPING TEST NUMBER ?
      011300 001406                      BEQ      .+16            ;BR IF YES
      011302 104401 047617                      TYPE     ,MSGTST        ;TYPE 'TEST'
      011306 013746 001240      MOV      $TESTN,-(SP)    ;;SAVE $TESTN FOR TYPEOUT
      011312 104403                      TYPOS    ;GO TYPE--OCTAL ASCII
      011314 002                                .BYTE   2              ;;TYPE 2 DIGIT(S)
      011315 000                                .BYTE   0              ;;SUPPRESS LEADING ZEROS

276 011316 012737 011324 001122      MOV      #1$,$LPADR     ;SETUP LOOP ADDRESS
277 011324 113737 002354 047046 1$:  MOVVB   FS,DPB.B+10     ;FS
278 011332 113737 002346 047047      MOVVB   FT,DPB.B+11     ;FT
282 011340 012737 011500 001350      MOV      #EXIT6,BYPASS  ;GO TO EXIT6 ON ERROR
      011346                      TEST6:
283 011346 013701 002340      MOV      FC,R1          ;PICKUP 'FC'
284 011352 013702 002342      MOV      LC,R2          ;FORM LAST CYLINDER THAT
285 011356 162702 000005                      SUB      #5,R2          ;IS AVAILABLE FOR TESTING
286 011362 012737 011362 001124      MOV      #,$LPERR       ;SETUP THE ERROR LOOP ADDRESS
      011370 012706 001100      MOV      #STACK,SP     ;LOAD THE STACK POINTER
287 011374 020102 1$:  CMP      R1,R2          ;LAST CYLINDER
290 011376 003040      BGT     EXIT6          ;YES--BRANCH
291 011400 010137 047050      MOV      R1,DPB.B+12   ;NC
292 011404 004037 030550      JSR     R0,CALL.B      ;GO EXECUTE THE COMMAND
293 011410 062737 000004 047050      ADD     #4,DPB.B+12   ;NC+4
294 011416 004037 030550      JSR     R0,CALL.B      ;GO EXECUTE THE COMMAND
295 011422 162737 000003 047050      SUB     #3,DPB.B+12   ;NC+1
296 011430 004037 030550      JSR     R0,CALL.B      ;GO EXECUTE THE COMMAND
297 011434 062737 000002 047050      ADD     #2,DPB.B+12   ;NC+3
298 011442 004037 030550      JSR     R0,CALL.B      ;GO EXECUTE THE COMMAND
299 011446 162737 000001 047050      SUB     #1,DPB.B+12   ;NC+2
300 011454 004037 030550      JSR     R0,CALL.B      ;GO EXECUTE THE COMMAND
301 011460 062737 000003 047050      ADD     #3,DPB.B+12   ;NC+5
302 011466 004037 030550      JSR     R0,CALL.B      ;GO EXECUTE THE COMMAND
303 011472 063701 002344      ADD     IC,R1
304 011476 000736      BR      1$
305 011500 000004      EXIT6: SCOPE          ;CALL SCOPE ROUTINE
306
315
316

```

```

*****
;*TEST 7      RANDOM SEEK TEST
;*THIS TEST PERFORMS RANDOM SEEK OPERATIONS BETWEEN CYLINDERS 'FC'
;*'LC'. AFTER EACH SEEK, THE POSITION OF THE DRIVE IS VERIFIED BY
;*READING A SECTOR FROM THE CURRENTLY ADDRESSED CYLINDER AND TRACK.
;*THE TRACK ADDRESS IS INCREMENTED FOR EACH SEEK SO THAT VERIFICATION
;*OF POSITIONING OCCURS USING EACH HEAD. TRACK ADDRESSES ARE INCREMENTED
;*BETWEEN PARAMTERS 'FT' AND 'LT'.
*****

```

```

TST7:
011502 000240      NOP
011504 033737 001556 001332      BIT      BITS+<7*2>,$TSTNMS ;DO THIS TEST?
011512 001002                      BNE     .+6            ;BR IF YES
011514 000137 012100      JMP     TST10          ;NO--JUMP TO TEST10

011520 012737 000007 001116      MOV      #7,$TSTNM     ;SET TEST #7 AND CLEAR ($ERFLG)
011526 004737 030142      JSR     PC,LODPRM      ;LOAD THE PARMETERS FOR THE TEST
011532 012737 011642 001124      MOV      #TEST7,$LPERR ;SETUP THE LOOP ON ERROR ADDRESS

```

	011540	013737	002336	001220	MOV	RPT,\$TIMES	;GET THE ITERATION COUNT
	011546	112737	C00031	001131	MOVB	#25,\$SERMAX	;MAX ERRORS ALLOWED FOR TEST
	011554	012737	000007	001240	MOV	#7,\$TESTN	;SET TEST NUMBER IN APT MAIL BOX
317	011562	032777	010000	167364	BIT	#SW12,@SWR	;INHIBIT TYPING TEST NUMBER ?
	011570	001406			BEQ	.+16	;BR IF YES
	011572	104401	047617		TYPE	,MSGTST	;TYPE 'TEST'
	011576	013746	001240		MOV	\$TESTN,-(SP)	;SAVE \$TESTN FOR TYPEOUT
	011602	104403			TYPOS		;GO TYPE--OCTAL ASCII
	011604	002			.BYTE	2	;TYPE 2 DIGIT(S)
	011605	000			.BYTE	0	;SUPPRESS LEADING ZEROS
318	011606	113737	002346	047047	MOVB	FT,DPB.B+11	;LOAD STARTING TRACK ADDRESS
319	011614	112737	000105	047020	MOVB	#SEEK,DPB.A+2	;SEEK=COMMAND
320	011622	013704	040650		MOV	RMADR,R4	;UNIBUS ADDRESS OF THE RH/RM
325	011626	012737	012076	001350	MOV	#EXIT7,BYPASS	;ERROR TERMINATION ADDRESS
	011634	012737	011642	C01122	MOV	#TEST7,\$LPADR	;SETUP THE LOOP ON TEST ADDRESS
	011642						
326	011642	012706	001100		MOV	#STACK,SP	;SETUP THE STACK POINTER
327	011646	013737	002340	047050	MOV	FC,DPB.B+12	;INITIAL CYLINDER ADDRESS
328	011654	023737	002340	C02342	CMP	FC,LC	;CYLINDER LIMITS THE SAME ?
329	011662	001422			BEQ	1\$;BR IF THEY ARE
330	011664	004737	026426		JSR	PC,\$RAND	;CYCLE THE RANDOM NUMBER GENERATOR
331	011670	013746	026524		MOV	\$HINUM,-(SP)	;USE THE HIGH RANDOM NUMBER
332	011674	005046			CLR	-(SP)	;UPPER DIVIDEND
333	011676	013746	002342		MOV	LC,-(SP)	;FORM THE DIVISOR
334	011702	005216			INC	(SP)	;INCREMENT
335	011704	163716	002340		SUB	FC,(SP)	;SUBTRACT THE LOWER LIMIT
336	011710	004737	026530		JSR	PC,\$DIV	;DIVIDE
337	011714	062637	047050		ADD	(SP)+,DPB.B+12	;ADD THE REMAINDER TO THE INITIAL CYLINDER
338	011720	005726			TST	(SP)+	;DISCARD THE QUOTIENT
339	011722	013737	047050	047030	MOV	DPB.B+12,DPB.A+12	;COPY NEW CYLINDER ADDRESS
340	011730						
	011730	012737	011730	001124	MOV	#, \$LPERR	;SETUP THE ERROR LOOP ADDRESS
	011736	012706	001100		MOV	#STACK,SP	;LOAD THE STACK POINTER
341	011742	004037	030402		JSR	RO,CALL.A	;GO EXECUTE THE COMMAND
342	011746	012737	011746	001124	MOV	#, \$LPERR	;SETUP THE ERROR LOOP ADDRESS
	011754	012706	001100		MOV	#STACK,SP	;LOAD THE STACK POINTER
343	011760	113764	047016	000010	MOVB	DPB.A,RMCS2(R4)	;SELECT THE DRIVE
344	011766	016446	000020		MOV	RMLA(R4),-(SP)	;GET THE LOOK AHEAD REGISTER
345	011772	006316			ASL	(SP)	;ALIGN THE SECTOR ADDRESS
346	011774	006316			ASL	(SP)	;ALIGN THE SECTOR ADDRESS
347	011776	000316			SWAB	(SP)	;PUT ADDRESS IN LOWER BYTE
348	012000	105766	000001		TSTB	1(SP)	;IN THE 1ST 20% OF SECTOR ?
349	012004	001401			BEQ	2\$;BR IF YES
350	012006	105216			INCB	(SP)	;INCREMENT THE SECTOR ADDRESS
351	012010	105216			INCB	(SP)	;INCREMENT THE SECTOR ADDRESS
352	012012	112637	047106		MOVB	(SP)+,DTADPB+10	;LOAD THE DPB
353	012016	013746	002470		MOV	PRMLM+24,-(SP)	;PUT LAST SECTOR ADDRESS ON THE STACK
354	012022	005216			INC	(SP)	;INCREMENT IT
355	012024	122637	047106		CMPB	(SI)+,DTADPB+10	;NEW SECTOR ADDRESS TOO LARGE ?
356	012030	103007			BHIS	4\$;BR IF NOT
357	012032	103403			BLO	3\$;BR IF ADDRESS IS 2 GREATER
358	012034	105037	047106		CLRB	DTADPB+10	;RESET TO SECTOR ADDRESS 0
359	012040	000403			BR	4\$;CONTINUE
360	012042	112737	000001	047106	MOVB	#1,DTADPB+10	;RESET ADDRESS TO SECTOR 1
361	012050						

```

012050 004037 030550
362 012054 105237 047047
363 012060 123737 047047 002350
366 012066 101403
367 012070 113737 0C.346 047047
368 012076 000004
369
391
392

```

```

JSR R0,CALL.B ;GO EXECUTE THE COMMAND
INCB DPB.B+11 ;INCREMENT THE TRACK ADDRESS
CMPB DPB.B+11,LT ;MAXIMUM ?
BLOS EXIT7 ;BR IF NOT
MOVB FT,DPB.B+11 ;RELOAD STARTING TRACK ADDRESS
EXIT7: SCOPE ;CALL SCOPE ROUTINE

```

```

*****
*TEST 10 SERVO SETTLE DOWN TEST
*THIS TEST VERIFIES THAT THE SERVO HAS SETTLED DOWN AND THAT
*THE DRIVE IS ON CYLINDER WHEN THE DRIVE INDICATES SEEK COMPLETE.
*RANDOM SEEKS ARE ISSUED BETWEEN CYLINDERS 'NC1' AND 'NC1+IC'
*('NC1' STARTS AT VALUE 'FC'). AT THE COMPLETION OF 1000 (10) SEEKS,
*'NC1' IS INCREMENTED BY VALUE 'IC' AND THE SEQUENCE IS REPEATED.
*THE TEST IS COMPLETED WHEN 'NC1' HAS BEEN INCREMENTED BEYOND 'LC'.
*
*WHEN THE SEEK COMPLETES, THE PROGRAM READS THE DRIVE'S LOOK-AHEAD
*REGISTER (RMLA) TO DETERMINE THE ADDRESS OF THE SECTOR ROTATING INTO
*POSITION. THE PROGRAM THEN ISSUES A WRITE HEADER AND DATA COMMAND
*FOR THAT SECTOR.
*ERRORS IN THIS TEST INDICATE THAT THE SERVO SYSTEM MAY NOT BE ADJUSTED
*CORRECTLY, THAT THE DRIVE IS MALFUNCTIONING, OR THAT A PACK WITH
*MARGINAL SERVO TRACKS IS MOUNTED ON THE DRIVE.
*
*THIS TEST IS VALID ONLY IF THE OPERATION IS STARTED WITHIN A FEW
*HUNDRED MICRO-SECONDS AFTER SEEK DONE OCCURS. THE NECESSARY
*TIME DEPENDENT PARAMETERS OCCUR FREQUENTLY ENOUGH WITHIN THE REQUIRED
*RANGE TO PERMIT THIS TEST TO BE EFFECTIVE.
*****

```

```

012100
012100 000240
012102 033737 001560 001332
012110 001002
012112 000137 013254

012116 012737 000010 001116
012124 004737 030142
012130 012737 012356 001124
012136 013737 002336 001220
012144 112737 000031 001131
393 012152 012737 000010 001240

012160 032777 010000 166766
012166 001406
012170 104401 047617
012174 013746 001240
012200 104403
012202 0C3
012203 000

394 012204 012737 012212 001122
395 012212
012212 112737 000105 047020
396 012220 112737 000161 047100
397 012226 113737 002346 047107
398 012234 013737 002340 047030

```

```

TST10:
NOP
BIT BITS+<10*2>,TSTNMS ;DO THIS TEST?
BNE .+6 ;BR IF YES
JMP TST11 ;NO--JUMP TO TEST11

MOV #10,$TSTNM ;SET TEST #10 AND CLEAR ($ERFLG)
JSR PC,LODPRM ;LOAD THE PARMETERS FOR THE TEST
MOV #TEST10,$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
MOV RPT,$TIMES ;GET THE ITERATION COUNT
MOVB #25,$SERMAX ;MAX ERRORS ALLOWED FOR TEST
MOV #10,$TESTN ;:SET TEST NUMBER IN APT MAIL BOX

BIT #SW12,@SWR ;INHIBIT TYPING TEST NUMBER ?
BEQ .+16 ;BR IF YES
TYPE ,MSGTST ;TYPE 'TEST'
MOV $TESTN,-(SP) ;:SAVE $TESTN FOR TYPEOUT
TYPOS ;:GO TYPE--OCTAL ASCII
.BYTE 3 ;:TYPE 3 DIGIT(S)
.BYTE 0 ;:SUPPRESS LEADING ZEROS

MOV #1$, $LPADR ;SETUP THE LOOP ADDRESS
1$:
MOVB #SEEK,DPB.A+2 ;SEEK=COMMAND
MOVB #WRITE,DTADPB+2 ;COMMAND
MOVB FT,DTADPB+11 ;TRACK ADDRESS FOR THE WRITE
MOV FC,DPB.A+12 ;CYLINDER ADDRESS FOR THE SEEK

```

```

T10 SERVO SETTLE DOWN TEST
399 012242 013737 002340 047110 MOV FC,DTADPB+12 ;CYLINDER ADDRESS FOR THE WRITE
400 012250 013737 002340 002370 MOV FC,NC1 ;STARTING CYLINDER
401 012256 013737 002342 001450 MOV LC,DELTA ;GET LAST CYLINDER
402 012264 163737 002340 001450 SUB FC,DELTA ;CALCULATE DELTA COUNT
403 012272 023737 001450 002344 CMP DELTA,IC ;IS CALCULATED COUNT <= 'IC' ?
404 012300 003403 BLE 2$ ;BR IF YES
405 012302 013737 002344 001450 MOV IC,DELTA ;CYLINDER INCREMENT VALUE
406 012310 012737 176000 047102 2$: MOV #-<256.*4.>,DTADPB+4 ;WORD COUNT
407 012316 012737 054522 047104 MOV #BUFFER,DTADPB+6 ;BUFFER ADDRESS
408 012324 005000 CLR R0 ;PATTERN POINTER (WC PATTERN)
409 012326 004737 034404 JSR PC,SETBUF ;LOAD THE WRITE BUFFER
410 012332 005001 CLR R1 ;CLEAR REGISTER
411 012334 113701 047016 MOVB DPB.A,R1 ;LOAD DRIVE ADDRESS
412 012340 013704 040650 MOV RMADR,R4 ;UNIBUS ADDRESS OF THE RH/RM
413 012344 004737 046336 JSR PC,CLRQUE ;CLEAR THE OPERATION QUEUES
454 012350 012737 013252 001350 MOV #EXIT10,BYPASS ;ERROR EXIT FROM TEST

TEST10:
012356 012737 012356 001124 MOV #,$LPERR ;SETUP THE ERROR LOOP ADDRESS
012364 012706 001100 MOV #STACK,SP ;LOAD THE STACK POINTER
012370 012737 000340 177776 MOV #PR7,PS ;SET PRIORITY TO 7
012376 005737 001342 TST CLKSTA ;SEE WHICH CLOCK ON SYSTEM
012402 001415 BEQ 3$ ;BR IF NO CLOCK
012404 100405 BMI 1$ ;BR IF KW11-L CLOCK
012406 017746 167076 MOV @PKV,-(SP) ;SAVE THE VECTOR
012412 013746 001510 MOV PKV,-(SP) ;SAVE THE VECTOR ADDRESS
012416 000404 BR 2$ ;CONTINUE
012420 017746 167076 1$: MOV @LKV,-(SP) ;SAVE THE 'L' CLOCK VECTOR
012424 013746 001522 MOV LKV,-(SP) ;SAVE THE VECTOR ADDRESS
012430 012776 013206 000000 2$: MOV #TST10B,@(SP) ;CHANGE THE VECTOR
012436 012777 032734 026206 3$: MOV #DORTI,@RMVEC ;CHANGE THE RM VECTOR
012444 012737 000010 001444 MOV #8.,SEKTMR ;LOAD THE SEEK TIMER
012452 012764 000040 000010 MOV #CLR,RMCS2(R4) ;INIT THE MASSBUS
012460 110164 000010 MOVB R1,RMCS2(R4) ;RESELECT THE DRIVE
012464 013764 047030 000034 MOV DPB.A+12,RMDC(R4) ;LOAD THE CYLINDER ADDRESS
012472 013737 047030 001366 MOV DPB.A+12,CYL.DS ;CYLINDER ADDRESS FOR ERROR MESSAGE
012500 112764 000105 000000 MOVB #SEEK,RMCS1(R4) ;START THE SEEK
012506 005037 177776 CLR PS ;CLEAR THE PRIORITY
012512 105764 000012 4$: TSTB RMD5(R4) ;HAS THE DRIVE FINISHED ?
012516 100402 BMI 5$ ;BR IF IT HAS
012520 000001 WAIT ;WAIT FOR THE OPERATION TO COMPLETE
012522 000773 BR 4$ ;CONTINUE
012524 012737 000340 177776 5$: MOV #PR7,PS ;CHANGE PRIORITY TO MAX
012532 032764 040000 000012 BIT #ERR,RMD5(R4) ;ERROR ?
012540 001412 BEQ 6$ ;BR IF NOT
012542 012702 047016 MOV #DPB.A,R2 ;DPB POINTER
012546 004737 045654 JSR PC,SVRH70 ;SAVE THE REGISTERS
012552 104023 EMT 23 ;ERROR DURING SEEK
012554 012764 000040 000010 MOV #CLR,RMCS2(R4) ;INIT THE MASSBUS
012562 110164 000010 MOVB R1,RMCS2(R4) ;RESELECT THE DRIVE
012566 012777 043306 026056 6$: MOV #ISR,@RMVEC ;SETUP THE RM VECTOR
012574 005737 001342 TST CLKSTA ;WHICH CLOCK
012600 001405 BEQ TST10A ;BR IF NONE
012602 016676 000002 000000 MOV 2(SP),@(SP) ;RELOAD THE CLOCK VECTOR
012610 062706 000004 ADD #4,SP ;CORRECT THE STACK POINTER
012614 TST10A:
455 012614 012737 012614 001124 MOV #,$LPERR ;SETUP THE ERROR LOOP ADDRESS
012622 012706 001100 MOV #STACK,SP ;LOAD THE STACK POINTER

```

456	012626	110164	000010		MOV B	R1, RMCS2(R4)	:SELECT THE DRIVE
457	012632	016446	000020		MOV	RMLA(R4), -(SP)	:GET THE LOOK AHEAD REGISTER
458	012636	006316			ASL	(SP)	:ALIGN THE SECTOR ADDRESS
459	012640	006316			ASL	(SP)	:ALIGN THE SECTOR ADDRESS
460	012642	000316			SWAB	(SP)	:PUT ADDRESS IN LOWER BYTE
461	012644	122766	000300	000001	CMP B	#300, 1(SP)	:IN THE LAST 20% OR SECTOR ?
462	012652	001001			BNE	2\$:BR IF NOT
463	012654	105216			INCB	(SP)	:INCREMENT THE SECTOR ADDRESS
464	012656	105216			INCB	(SP)	:INCREMENT THE SECTOR ADDRESS
465	012660	112637	047106		MOV B	(SP)+, DTADPB+10	:LOAD THE DPB
466	012664	013746	002470		MOV	PRMLM+24, -(SP)	:PUT MAXIMUM SECTOR ADDRESS ON THE STACK
467	012670	005216			INC	(SP)	:INCREMENT PAST THE MAXIMUM ADDRESS
468	012672	122637	047106		CMP B	(SP)+, DTADPB+10	:NEW SECTOR ADDRESS TOO LARGE ?
469	012676	101007			BHI	4\$:BR IF NOT
470	012700	103403			BLO	3\$:BR IF ADDRESS IS 2 GREATER THAN MAXIMUM
471	012702	105037	047106		CLRB	DTADPB+10	:RESET TO SECTOR ADDRESS 0
472	012706	000403			BR	4\$:CONTINUE
473	012710	112737	000001	047106	3\$: MOV B	#1, DTADPB+10	:RESET ADDRESS TO SECTOR 1
474	012716	012703	047102		4\$: MOV	#DTADPB+4, R3	:POINTER
475	012722	012764	000111	000000	MOV	#DRVCLR, RMCS1(R4)	:CLEAR THE DRIVE
476	012730	012364	000002		MOV	(R3)+, RMWC(R4)	:LOAD THE WORD COUNT
477	012734	012364	000004		MOV	(R3)+, RMBA(R4)	:LOAD THE BUFFER ADDRESS
478	012740	012364	000006		MOV	(R3)+, RMDA(R4)	:LOAD THE TRACK/SECTOR ADDR
479	012744	005037	047114		CLR	DTADPB+16	:RESET 'DONE' INDICATOR
480	012750	012737	047076	040572	MOV	#DTADPB, TRNSWT	:LOAD 'TRANSFER' DPB ADDRESS
481	012756	010137	040634		MOV	R1, DTUW	:ADDRESS OF DRIVE TRANSFERING
482	012762	112761	000001	040522	MOV B	#1, DRVACT(R1)	:SET DRIVE ACTIVE INDICATOR
483	012770	006301			ASL	R1	:SHIFT DRIVE ADDRESS
484	012772	012761	001750	040614	MOV	#1000., TIMER(R1)	:SETUP THE OPERATION TIMER
485	013000	006201			ASR	R1	:RESTORE R1
486	013002	013764	047100	000000	MOV	DTADPB+2, RMCS1(R4)	:START THE OPERATION
487	013010	005037	177776		CLR	PS	:CLEAR THE PRIORITY
488	013014	004037	031224		JSR	R0, DRVCL1	:WAIT FOR OPERATION TO COMPLETE
489	013020	023727	001446	001750	5\$: CMP	SEKCNT, #1000.	:FINISHED SEEKS ?
490	013026	001026			BNE	6\$:BR IF NOT
491	013030	005037	001446		CLR	SEKCNT	:CLEAR THE SEEK COUNT
492	013034	063737	002344	002370	ADD	IC, NC1	:ADD THE INCREMENT
493	013042	023737	002370	002342	CMP	NC1, LC	:EXCEEDED THE CYLINDER LIMIT ?
528	013050	103100			BHIS	EXIT10	:BR IF IT HAS
	013052	013737	002342	001450	MOV	LC, DELTA	:GET THE NEXT 'ZONE' ADDRESS
	013060	163737	002370	001450	SUB	NC1, DELTA	:CHECK THE DIFFERENCE
	013066	023737	002344	001450	CMP	IC, DELTA	:DIFFERENCE GREATER THAN THE INCREMENT ?
	013074	101003			BHI	6\$:BR IF IT IS
	013076	013737	002344	001450	MOV	IC, DELTA	:USE THE INCREMENT PARAMETER
	013104	005237	001446		6\$: INC	SEKCNT	:COUNT THE NEXT SEEK
	013110	023737	002340	002342	CMP	FC, LC	:BEGINNING AND ENDING CYLINDERS THE SAME ?
	013116	001002			BNE	7\$:BR IF NOT
	013120	000137	012356		JMP	TEST10	:BR IF THEY ARE
	013124	013737	002370	047030	7\$: MOV	NC1, DPB.A+12	:RESET THE CYLINDER ADDRESS
	013132	004737	026426		JSR	PC, \$RAND	:CYCLE THE RANDOM NUMBER GENERATOR
	013136	013746	026524		MOV	\$HINUM, -(SP)	:USE THE HIGH RANDOM NUMBER
	013142	005046			CLR	-(SP)	:CLEAR THE UPPER DIVIDEND
	013144	013746	001450		MOV	DELTA, -(SP)	:FORM THE DIVISOR
	013150	005216			INC	(SP)	:INCREMENT
	013152	004737	026530		JSR	PC, \$DIV	:DIVIDE
	013156	062637	047030		ADD	(SP)+, DPB.A+12	:ADD THE REMAINDER TO THE INITIAL CYLINDER
	013162	005726			TST	(SP)+	:DISCARD THE QUOTIENT

```

013164 023737 047030 047110 CMP DPB.A+12,DTADPB+12 ;SAME CYLINDER SELECTED AS LAST TIME ?
013172 001754 BEQ 7$ ;BR IF IT WAS
013174 013737 047030 047110 MOV DPB.A+12,DTADPB+12 ;COPY NEW CYLINDER ADDRESS
013202 000137 012356 JMP TEST10 ;CONTINUE
013206 TST10B: DEC SEKTRM ;DECREMENT THE SEEK TIMER
013206 005337 001444 BNE 1$ ;CONTINUE IF NOT DONE
013212 001016 MOV #DPB.A,R2 ;DPB ADDRESS
013214 012702 047016 JSR PC,SVR#70 ;SAVE THE REGISTERS
013220 004737 045654 EMT 24 ;TIMEOUT DURING SEEK
013224 104024 MOV #CLR,RMCS2(R4) ;INIT THE MASSBUS
013226 012764 000040 000010 MOV# R1,RMCS2(R4) ;RESELECT THE DRIVE
013234 110164 00001C MOV 2(SP),@ (SP) ;RESTORE THE CLOCK VECTOR ADDRESS
013240 016676 000002 000000 BR EXIT10 ;ABORT THE TEST
529 013250 000002 1$: RTI ;RETURN
530 013252 000004 EXIT10: SCOPE ;CALL SCOPE ROUTINE
531
542
543
  
```

```

:*****
:*TEST 11 ALL SEEKS TEST
:*THIS TEST VERIFIES THAT THE DISK DRIVE CAN SEEK FROM EACH CYLINDER
:*TO ALL OTHER CYLINDERS.
:*
:*BEGINNING WITH CYLINDER 'FC', THE TEST SEEKS TO EACH CYLINDER
:*BETWEEN 'FC' AND 'LC' FROM CYLINDER 'FC'. THE BEGINNING CYLINDER
:*ADDRESS IS INCREMENTED AND THE TEST SEEKS BETWEEN THE NEW CYLINDER
:*ADDRESS AND ALL CYLINDERS BETWEEN 'FC' AND 'LC'. THE SEQUENCE
:*CONTINUES UNTIL ALL CYLINDERS HAVE BEEN CHECKED.
:*****
  
```

```

013254 TST11: NOP
013254 000240 BIT BITS+<11*2>,TSTNMS ;DO THIS TEST?
013256 033737 001562 001332 BNE +6 ;BR IF YES
013264 001002 JMP TST12 ;NO--JUMP TO TEST12
013266 000137 013520
013272 012737 000011 001116 MOV #11,$TSTNM ;SET TEST #11 AND CLEAR (SERFLG)
013300 004737 030142 JSR PC,LODPRM ;LOAD THE PARAMETERS FOR THE TEST
013304 012737 013440 001124 MOV #TEST11,$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
013312 013737 002336 001220 MOV RPT,$TIMES ;GET THE ITERATION COUNT
013320 112737 000031 001131 MOV# #25,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
013326 012737 000011 001240 MOV #11,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
544 013334 032777 010000 165612 BIT #SW12,@SWR ;INHIBIT TYPING TEST NUMBER ?
013342 001406 BEQ +16 ;BR IF YES
013344 104401 047617 TYPE ,MSGTST ;TYPE 'TEST'
013350 013746 001240 MOV $TESTN,-(SP) ;;SAVE $TESTN FOR TYPEOUT
013354 104403 TYPOS ;GO TYPE--OCTAL ASCII
013356 003 .BYTE 3 ;TYPE 3 DIGIT(S)
013357 000 .BYTE 0 ;SUPPRESS LEADING ZEROS
545 013360 012737 013366 001122 MOV #1$, $LPADR ;SETUP THE LOOP ADDRESS
546 013366 113737 002354 047046 1$: MOV# FS,DPB.B+10 ;SECTOR ADDRESS
547 013374 113737 002354 047066 MOV# FS,DPB.C+10 ;SECTOR ADDRESS
548 013402 113737 002346 047047 MOV# FT,DPB.B+11 ;TRACK ADDRESS
549 013410 113737 002346 047067 MOV# FT,DPB.C+11 ;TRACK ADDRESS
550 013416 013737 002340 047050 MOV FC,DPB.B+12 ;STARTING CYLINDER ADDRESS
551 013424 013737 002340 047070 MOV FC,DPB.C+12 ;STARTING CYLINDER ADDRESS
  
```

555	013432	012737	013516	001350	MOV	#EXIT'1,BYPASS	;TEST ABORT EXIT
	013440				TEST'1:		
556	013440	012706	001100		MOV	#STACK,SP	;SETUP THE STACK POINTER
557	013444				1\$:		
	013444	004037	030766		JSR	RO,CALL.C	;GO EXECUTE THE COMMAND
558	013450	004037	030550		JSR	RO,CALL.B	;GO EXECUTE THE COMMAND
559	013454	063737	002344	047070	ADD	IC,DPB.C+12	;INCREMENT THE ENDING CYLINDER ADDRESS
560	013462	023737	002342	047070	CMP	LC,DPB.C+12	;CHECK IF EXCEEDING MAXIMUM
561	013470	002365			BGE	1\$;BR IF NOT
562	013472	013737	002340	047070	MOV	FC,DPB.C+12	;RESET ENDING CYLINDER ADDRESS
563	013500	063737	002344	047050	ADD	IC,DPB.B+12	;INCREMENT THE STARTING ADDRESS
564	013506	023737	002342	047050	CMP	LC,DPB.B+12	;EXCEEDING MAXIMUM ?
565	013514	002353			BGE	1\$;BR IF NOT
566	013516	000004			EXIT'1:	SCOPE	;CALL SCOPE ROUTINE

1
2
3
4
5
6
7
8
9
10
11
12
13
14

.SBTTL TIMING TESTS

```

://////
:*THE TIMING TESTS WILL ENSURE THAT THOSE FUNCTIONS BEING
:*TIMED ARE WITHIN THE TOLERANCES SPECIFIED IN THE 'RM05/3/2
:*ENGINEERING SPECIFICATIONS'.
:*THE SEEK TIMING WILL BE PERFORMED USING EXPLICIT SEEK
:*OPERATIONS. AT THE COMPLETION OF EACH OF THE TIMING
:*TESTS THE MINIMUM, MAXIMUM AND AVERAGE TIMES WILL BE
:*TYPED.
://////
    
```

```

:*****
:*TEST 12 ROTATIONAL SPEED TIMING TEST
:*THIS TEST WILL START A SEARCH TO CYLINDER 'FC', TRACK 'FT',
:*SECTOR 'FS'. AS SOON AS THE INTERRUPT OCCURS, THE GO BIT
:*IS SET AGAIN AND THE OPERATION IS TIMED. THIS PROCEDURE
:*IS REPEATED 10 TIMES THEN THE AVERAGE TIME IS CALCULATED
:*AND CHECKED TO ENSURE IT IS WITHIN TOLERANCE:
:*
:* RM05/3:
:* 16.67 MS/REV + OR - 2% IF 60HZ
:* 16.67 MS/REV + OR - 2.5% IF 50HZ.
:*
:* RM02:
:* 25.00 MS/REV + OR - 2% IF 60HZ
:* 25.00 MS/REV + OR - 2.5% IF 50HZ.
:*****
    
```

```

013520
013520 000240
013522 033737 001564 001332
013530 001002
013532 000137 014442

013536 012737 000012 001116
013544 004737 030142
013550 012737 014116 001124
013556 013737 002336 001220
013564 112737 000031 001131
013572 012737 000012 001240

30 013600 032777 010000 165346
013606 001406
013610 104401 047617
013614 013746 001240
013620 104403
013622 003
013623 000

31 013624 005737 001342
32 013630 003002
35 013632 000137 014440
36 013636 012737 013636 001122 1$:
37 013644 004037 032552
38 013650 000402
60 013652 000137 014440

TST12:
NOP
BIT BITS+<12*2> ,TSTNMS ;DO THIS TEST?
BNE .+6 ;BR IF YES
JMP TST13 ;NO--JUMP TO TEST13

MOV #12,$TSTNM ;SET TEST #12 AND CLEAR ($ERFLG)
JSR PC,LODPRM ;LOAD THE PARMETERS FOR THE TEST
MOV #TEST12,$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
MOV RPT,$TIMES ;GET THE ITERATION COUNT
MOV #25,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
MOV #12,$TESTN ;SET TEST NUMBER IN APT MAIL BOX

BIT #SW12,@SWR ;INHIBIT TYPING TEST NUMBER ?
BEQ .+16 ;BR IF YES
TYPE ,MSGTST ;TYPE 'TEST'
MOV $TESTN,-(SP) ;SAVE $TESTN FOR TYPEOUT
TYPOS ;GO TYPE--OCTAL ASCII
.BYTE 3 ;TYPE 3 DIGIT(S)
.BYTE 0 ;SUPPRESS LEADING ZEROS

TST CLKSTA ;KW11-P CLOCK?
BGT 1$ ;YES--START TEST
JMP EXIT12 ;NO--JUMP TO EXIT12
MOV #,$SLPADR ;SETUP LOOP ADDRESS
JSR RO,SRCHOO ;DO A MASSBUS INIT & RECAL
BR 2$ ;RETURN HERE IF NO ERROR
JMP EXIT12 ;RETURN HERE IF ERROR
    
```

```

013656 012737 013656 001122 2$: MOV #,$LPADR ;ERROR LOOP ADDRESS
013664 112737 000105 047020 MOVB #SEEK,DPB.A+2 ;SEEK=COMMAND
013672 005037 047026 CLR DPB.A+10 ;USE TRACK 0 & SECTOR 0
013676 013737 002340 047030 MOV FC,DPB.A+12 ;STARTING CYLINDER
013704 012737 014440 001350 MOV #EXIT12,BYPASS ;GO TO EXIT12 IF ERROR
013712 004037 030402 JSR R0,CALL.A ;GO EXECUTE THE COMMAND
013716 013764 002340 000034 MOV FC,RMDC(R4) ;FC
013724 013746 002354 MOV FS,-(SP) ;FS
013730 113766 002346 000001 MOVFB FT,1(SP) ;FT
013736 012664 000006 MOV (S2)+,RMDA(R4) ;LOAD FT/FS
013742 012737 014440 001222 MOV #EXIT12,$ESCAPE ;ESCAPE TO EXIT12 ON ERROR
013750 005005 CLR R5 ;COUNT UP

;SETUP PARAMETER TABLE FOR RM05/RM03/RM02
61 013752 010046 MOV R0,-(SP) ;SAVE R0
62 013754 113700 DTADPB,R0 ;DRIVE ADDRESS
63 013760 032737 000100 001314 BIT #SW06,C.SWR ;CHECK CONTROL SWR FOR 60 HZ.
64 013766 001425 BEQ 3$ ;BR IF YES
65 013770 012703 001650 MOV #T7B1,R3 ;LOAD 50 HZ. TABLE FOR RM02
66 013774 012737 001650 014430 MOV #T7B1,TP50 ;
67 014002 012737 001732 014436 MOV #SP7B1,TP550 ;
68 014010 122760 000005 040542 CMPB #5,DRVTYP(R0) ;AN RM02 DRIVE ?
69 014016 001435 BEQ 4$ ;BRANCH IF SO
70 014020 012703 001630 MOV #T7B,R3 ;LOAD 50 HZ. TABLE FOR RM05/3
71 014024 012737 001630 014430 MOV #T7B,TP50 ;
72 014032 012737 001716 014436 MOV #SP7B,TP550 ;
73 014040 000424 BR 4$ ;EXIT
74 014042 012737 001640 014412 3$: MOV #T7A1,TP60 ;LOAD 60 HZ. TABLE FOR RM02
75 014050 012737 001724 014420 MOV #SP7A1,TP560 ;
76 014056 012703 001640 MOV #T7A1,R3 ;
77 014062 122760 000005 040542 CMPB #5,DRVTYP(R0) ;AN RM02 DRIVE ?
78 014070 001410 BEQ 4$ ;BRANCH IF SO
79 014072 012737 001620 014412 MOV #T7A,TP60 ;LOAD 60 HZ. TABLE FOR RM05/3
80 014100 012703 001620 MOV #T7A,R3 ;
81 014104 012737 001710 014420 MOV #SP7A,TP560 ;
82 014112 012600 4$: MOV (SP)+,R0 ;RESTORE R0
83 014114 000240 NOP ;EXIT
84 014116 TEST12:
85 014116 012706 001100 MOV #STACK,SP ;SETUP STACK
86 014122 012701 000012 MOV #10,R1 ;TIME 10 SEARCHES
87 014126 004737 032736 JSR PC,STRTMR ;INITIALIZE THE TIMERS
88 014132 012777 014320 165350 MOV #7$,@PKV ;SETUP VECTOR IN CASE OF OVERFLOW
89 014140 012777 032734 024504 MOV #DORTI,@RMVEC ;SETUP RM VECTOR
90 014146 005077 165344 1$: CLR @PKB ;START COUNTING AT ZERO
91 014152 012777 000131 165334 MOV #131,@PKCS ;INT.EN., COUNT UP AT 100KHZ
92 014160 012714 000131 MOV #SEARCH,(R4) ;START A SEARCH
93 014164 000001 WAIT ;WAIT ON INTERRUPT
94 014166 042777 000101 165320 BIC #101,@PKCS ;STOP THE CLOCK
95 014174 032764 040000 000012 BIT #ERR,RMDS(R4) ;ERROR?
96 014202 001411 BEQ 2$ ;NO--BRANCH
97 014204 104412 SAVREG ;SAVE R0-R5
98 014206 012702 047076 MOV #DTADPB,R2 ;DPB POINTER
99 014212 004737 045654 JSR PC,SVRH70 ;SAVE ALL THE RH/RM REGISTERS
100 014216 004737 027334 JSR PC,CNTCLR ;GO CLEAR MASSBUS CONTROLLER
101 014222 104413 RESREG ;RESTORE R0-R5
102 014224 104017 EMT 17 ;DISK ERROR OCCURRED
103 014226 005077 165264 2$: CLR @PKB ;START THE COUNT AT ZERO

```

```

103 014232 012714 000131      MOV      #SEARCH,(R4)      ;START A SEARCH
104 014236 012777 000131 165250  MOV      #131,@PKCS      ;START THE CLOCK
105 014244 000001      WAIT     ;WAIT ON INTERRUPT
106 014246 042777 000101 165240  BIC      #101,@PKCS      ;STOP THE CLOCK
107 014254 032764 040000 000012  BIT      #ERR,RMDS(R4)   ;IS 'ERR=1'?
108 014262 001411      BEQ      3$              ;NO--BRANCH
109 014264 104412      SAVREG   ;SAVE R0-R5
      014266 012702 047076  MOV      #DTADPB,R2      ;DPB POINTER
      014272 004737 045654  JSR      PC,SVRH70      ;SAVE ALL THE RH/RM REGISTERS
      014276 004737 027334  JSR      PC,CNTCLR      ;GO CLEAR MASSBUS CONTROLLER
      014302 104413      RESREG   ;RESTORE R0-R5
110 014304 104017      EMT      17              ;DISK ERROR OCCURRED
111 014306 004737 033000      JSR      PC,COUNT      ;UPDATE THE COUNT
112 014312 005301      DEC      R1              ;DONE?
113 014314 003314      BGT      1$              ;NO--BRANCH
114 014316 000420      BR       8$              ;YES--GO TO THE EXIT
115 014320 042777 000101 165166 7$: BIC      #101,@PKCS      ;STOP THE CLOCK
116 014326 005037 177776      CLR      PS              ;DROP THE PRIORITY
117 014332 012600      MOV      (SP)+,R0      ;PC OF WAIT+2
118 014334 005726      TST      (SP)+          ;POP THE PS FROM THE STACK
119 014336 104412      SAVREG   ;SAVE R0-R5
      014340 012702 047076  MOV      #DTADPB,R2      ;DPB POINTER
      014344 004737 045654  JSR      PC,SVRH70      ;SAVE ALL THE RH/RM REGISTERS
      014350 004737 027334  JSR      PC,CNTCLR      ;GO CLEAR MASSBUS CONTROLLER
      014354 104413      RESREG   ;RESTORE R0-R5
120 014356 104020      EMT      20              ;CLOCK OVERFLOWED
121 014360 004737 027334      JSR      PC,CNTCLR      ;GO CLEAR MASSBUS CONTROLLER
122 014364 004737 027426      JSR      PC,ST.CLK      ;INITIALIZE THE CLOCK
123 014370 012777 043306 024254  MOV      #ISR,@RMVEC     ;RESTORE RH/RM INT. VECTOR
124 014376 032737 000100 001314  BIT      #SW06,C.SWR     ;60 HZ?
138 014404 001007      BNE      EXIT.A         ;NO--BRANCH
      014406 004037 033240  JSR      R0,TYPTIM      ;TYPE THE TIMING
      014412 001620      TP60:   JSR      R0,SPTYP ;TABLE ADDRESS
      014414 004037 033132  JSR      R0,SPTYP      ;TYPE THE SPEC
      014420 001710      TPS60: SP7A
      014422 000406      BR       EXIT12        ;EXIT
139 014424 004037 033240  EXIT.A: JSR      R0,TYPTIM ;TYPE THE TIMING
140 014430 001630      TP50:   JSR      R0,SPTYP ;TABLE ADDRESS
141 014432 004037 033132  JSR      R0,SPTYP      ;
142 014436 001716      TPS50:  SP7B
143 014440 000004  EXIT12: SCOPE          ;CALL SCOPE ROUTINE
144
153
154

```

```

*****
;*TEST 13      ONE CYLINDER SEEK TIMING TEST
;*THIS TEST WILL COMMAND FORWARD SEEK CYCLES TO ADVANCE THE
;*CYLINDER BY ONE UNTIL THE INCREMENT IS GREATER THAN THE
;*CYLINDER 'LC', THEN REVERSE SEEK TO CYLINDER 'FC'. THE
;*TIME TO PERFORM EACH SEEK IS CHECKED TO ENSURE IT DOES NOT
;*EXCEED THE MAXIMUM TIME PERMITTED FOR A ONE CYLINDER SEEK.
;*MAXIMUM TIME IS 6.0 MS.
*****

```

```

014442
014442 000240      NOP
014444 033737 001566 001332  BIT      BITS+<13*2>,TS13NMS ;DO THIS TEST?
014452 001002      BNE      +6              ;BR IF YES
014454 000137 015144      JMP      TST14          ;NO--JUMP TO TEST14

```

```

014460 012737 000013 001116      MOV    #13,$STSTNM      ;SET TEST #13 AND CLEAR ($SERFLG)
014466 004737 030142                JSR    PC,LODPRM        ;LOAD THE PARMETERS FOR THE TEST
014472 012737 014652 001124      MOV    #TEST13,$LPERR   ;SETUP THE LOOP ON ERROR ADDRESS
014500 013737 002336 001220      MOV    RPT,$TIMES       ;GET THE ITERATION COUNT
014506 112737 000031 001131      MOVVB  #25,$SERMAX      ;MAX ERRORS ALLOWED FOR TEST
014514 012737 000013 001240      MOV    #13,$TESTN      ;;SET TEST NUMBER IN APT MAIL BOX

155
014522 032777 010000 164424      BIT    #SW12,@SWR       ;INHIBIT TYPING TEST NUMBER ?
014530 001406                BEQ    .+16              ;BR IF YES
014532 104401 047617                TYPE  ,MSGTST           ;TYPE 'TEST'
014536 013746 001240                MOV    $TESTN,-(SP)     ;;SAVE $TESTN FOR TYPEOUT
014542 104403                TYPOS                ;;GO TYPE--OCTAL ASCII
014544      003                .BYTE  3                ;TYPE 3 DIGIT(S)
014545      000                .BYTE  0                ;;SUPPRESS LEADING ZEROS

156 014546 005737 001342                TST    CLKSTA           ;KW11-P CLOCK?
157 014552 003002                BGT    1$              ;YES--START TEST
160 014554 000137 015142                JMP    EXIT13           ;NO--JUMP TO EXIT13
161 014560 012737 014560 001122 1$:      MOV    #.,$LPADR        ;SETUP THE LOOP ADDRESS
162 014566 004037 032552                JSR    R0,SRCHOO       ;DO A MASSBUS INIT. AND RECAL
163 014572 000402                BR     2$              ;NO ERROR RETURN
175 014574 000137 015142                JMP    EXIT13           ;ERROR RETURN--SCOPE LOOP CALL
014600 012737 014600 001122 2$:      MOV    #.,$LPADR        ;ERROR LOOP ADDRESS
014606 112737 000105 047020      MOVVB  #SEEK,DPB.A+2    ;SEEK=COMMAND
014614 005037 047026                CLR    DPB.A+10        ;USE TRACK 0 & SECTOR 0
014620 013737 002340 047030      MOV    FC,DPB.A+12     ;STARTING CYLINDER
014626 012737 015142 001350      MOV    #EXIT13,BYPASS  ;GO TO EXIT13 IF ERROR
014634 004037 030402                JSR    R0,CALL.A       ;GO EXECUTE THE COMMAND
014640 012703 001660                MOV    #T10,R3         ;PARAMETER POINTER
014644 012737 015142 001222      MOV    #EXIT13,$ESCAPE ;:ESCAPE TO EXIT13 ON ERROR
014652                TEST13:

176 014652 012706 001100                MOV    #STACK,SP       ;SETUP STACK
177 014656 013737 002340 047110      MOV    FC,DTADPB+12    ;START WITH BEGINNING CYLINDER
178 014664 005237 047110                INC    DTADPB+12       ;INCREMENT THE BEGINNING CYLINDER
179 014670 005005                CLR    R5              ;SET THE UP/DOWN SWITCH TO UP
180 014672 004737 032736                JSR    PC,STRMR        ;INITIALIZE THE TIMERS
181 014676 012777 015050 164604      MOV    #7$,@PKV        ;SETUP INCASE OF OVERFLOW
182 014704 012777 032734 023740      MOV    #DORTI,@RMVEC   ;SET RM VECTOR
183 014712 005077 164600                CLR    @PKB            ;START THE COUNTER AT ZERO
184 014716 013764 047110 000034      MOV    DTADPB+12,RMDC(R4) ;:LOAD DESIRED CYLINDER
185 014724 012714 000105                MOV    #SEEK,(R4)      ;START A SEEK
186 014730 012777 000131 164556      MOV    #131,@PKCS     ;START THE CLOCK
187 014736 000001                WAIT                   ;WAIT ON INTERRUPT
188 014740 042777 000101 164546      BIC    #101,@PKCS     ;STOP THE CLOCK
189 014746 032764 040000 000012      BIT    #ERR,RMDS(R4)  ;ANY DISK ERRORS?
190 014754 001411                BEQ    2$              ;NO--BRANCH
191 014756 104412                SAVREG                ;SAVE R0-R5
014760 012702 047076                MOV    #DTADPB,R2     ;DPB POINTER
014764 004737 045654                JSR    PC,SVRH70       ;SAVE ALL THE RH/RM REGISTERS
014770 004737 027334                JSR    PC,CNTCLR      ;GO CLEAR MASSBUS CONTROLLER
014774 104413                RESREG                ;RESTORE R0-R5
192 014776 104017                EMT    17              ;DISK ERROR OCCURRED
193 015000 004737 033000 2$:      JSR    PC,COUNT       ;COUNT THIS SEEKS TIME
194 015004 005705                TST    R5              ;UP OR DOWN?
195 015006 001011                BNE    4$              ;DOWN--BRANCH
196 015010 005237 047110 3$:      INC    DTADPB+12      ;MOVE TO NEXT CYLINDER

```

```

197 015014 023737 047110 002342    CMP    DTADPB+12,LC    ;OUT OF CYLINDERS?
198 015022 002733                BLT    1$              ;NO--GO DO THE NEXT SEEK
199 015024 012705 177777                MOV    #-1,R5         ;SET UP/DOWN SWITCH TO DOWN
200 015030 000730                BR     1$              ;GO DO THE NEXT SEEK
201 015032 005337 047110                DEC    DTADPB+12      ;MOVE TO NEXT CYLINDER
202 015036 023737 047110 002340    4$:    CMP    DTADPB+12,FC    ;OUT OF CYLINDERS?
203 015044 003322                BGT    1$              ;NO--GO DO THE NEXT SEEK
204 015046 000420                BR     8$              ;GO TO THE EXIT
205 015050 042777 000101 164436    7$:    BIC    #101,@PKCS     ;STOP THE CLOCK
206 015056 005037 177776                CLR    PS              ;DROP THE PRIORITY
207 015062 012600                MOV    (SP)+,RO        ;PC OF WAIT+2
208 015064 005726                TST    (SP)+           ;POP THE PS FROM THE STACK
209 015066 104412                SAVREG                ;SAVE RO-R5
    015070 012702 047076                MOV    #DTADPB,R2     ;DPB POINTER
    015074 004737 045654                JSR    PC,SVRH70      ;SAVE ALL THE RH/RM REGISTERS
    015100 004737 027334                JSR    PC,CNTCLR      ;GO CLEAR MASSBUS CONTROLLER
    015104 104413                RESREG                ;RESTORE RO-R5
210 015106 104020                EMT    20              ;REPORT CLOCK OVERFLOW
211 015110 004737 027334    8$:    JSR    PC,CNTCLR      ;GO CLEAR MASSBUS CONTROLLER
212 015114 004737 027426                JSR    PC,ST.CLK      ;INITIALIZE THE CLOCK
213 015120 012777 043306 023524    MOV    #ISR,@RMVEC     ;RESTORE RH/RM INT. VECTOR
214 015126 004037 033240                JSR    RO,TYPTIM      ;GO TYPE THE TIMES
    015132 001660                T10                    ;POINTER
215 015134 004037 033132                JSR    RO,SPTYP
216 015140 001740                SP10
217 015142 000004                EXIT13: SCOPE         ;CALL SCOPE ROUTINE
218
232
233
  
```

```

:*****
:*TEST 14      AVERAGE SEEK TIMING TEST
:*THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 'FC' TO
:*CYLINDER 'LC', THEN A REVERSE SEEK FROM CYLINDER 'LC' TO
:*CYLINDER 'FC'. BOTH SEEKS ARE TIMED AND CHECKED TO ENSURE THEY
:*ARE WITHIN THE TOLERANCE ALLOWED FOR THE AVERAGE SEEK TIME.
:*THIS SEQUENCE IS REPEATED 128 TIMES (FOR A TOTAL OF 256 SEEKS).
:*MAXIMUM TIME IS 30.0 MS.
:*
:* THERE ARE NO SPECIFICATIONS GIVEN FOR AN AVERAGE SEEK TIME
:* ON THIS PARTICULAR DRIVE. THEREFORE, THIS TEST SHOULD BE
:* USED FOR REFERENCE ONLY.
:*
:*****
  
```

```

015144
015144 000240
015146 033737 001570 001332    NOP
015154 001002                BIT    BITS+<14*2>,TSTNMS ;DO THIS TEST?
015156 000137 015704                BNE    .+6             ;BR IF YES
                                JMP    TST15           ;NO--JUMP TO TEST15

015162 012737 000014 001116    MOV    #14,$TSTNM      ;SET TEST #14 AND CLEAR ($ERFLG)
015170 004737 030142                JSR    PC,LODPRM      ;LOAD THE PARMETERS FOR THE TEST
015174 012737 015354 001124    MOV    #TEST14,$LPERR  ;SETUP THE LOOP ON ERROR ADDRESS
015202 013737 002336 001220    MOV    RPT,$TIMES     ;GET THE ITERATION COUNT
015210 112737 000031 001131    MOV    #25,$ERMAX     ;MAX ERRORS ALLOWED FOR TEST
015216 012737 000014 001240    MOV    #14,$TESTN     ;SET TEST NUMBER IN APT MAIL BOX

234
015224 032777 010000 163722    BIT    #SW12,@SWR     ;INHIBIT TYPING TEST NUMBER ?
015232 001406                BEQ    .+16           ;BR IF YES
  
```

015234	104401	047617		TYPE	,MSGTST	:TYPE 'TEST'
015240	013746	001240		MOV	\$TESTN,-(SP)	::SAVE \$TESTN FOR TYPEOUT
015244	104403			TYPOS		::GO TYPE--OCTAL ASCII
015246	003			.BYTE	3	::TYPE 3 DIGIT(S)
015247	000			.BYTE	0	::SUPPRESS LEADING ZEROS
235	015250	005737	001342	TST	CLKSTA	:KW11-P CLOCK?
236	015254	003002		BGT	1\$:YES--START TEST
239	015256	000137	015702	JMP	EXIT14	:NO--JUMP TO EXIT14
240	015262	012737	015262	MOV	#, \$LPADR	:SET THE LOOP ADDRESS
241	015270	004037	032552	JSR	R0,SRCH00	:DO A MASSBUS INIT & RECAL
242	015274	000402		BR	2\$:RETURN HERE IF NO ERROR
254	015276	000137	015702	JMP	EXIT14	:RETURN HERE ON ERROR
	015302	012737	015302	MOV	#, \$LPADR	:ERROR LOOP ADDRESS
	015310	112737	000105	MOVB	#SEEK,DPB.A+2	:SEEK=COMMAND
	015316	005037	047026	CLR	DPB.A+10	:USE TRACK 0 & SECTOR 0
	015322	013737	002340	MOV	FC,DPB.A+12	:STARTING CYLINDER
	015330	012737	015702	MOV	#EXIT14,BYPASS	:GO TO EXIT14 IF ERROR
	015336	004037	030402	JSR	R0,CALL.A	:GO EXECUTE THE COMMAND
	015342	012703	001670	MOV	#T11,R3	:PARAMETER POINTER
	015346	012737	015702	MOV	#EXIT14,\$ESCAPE	:ESCAPE TO EXIT14 ON ERROR
	015354			TEST14:		
255	015354	012706	001100	MOV	#STACK,SP	:SETUP STACK
256	015360	012701	000200	MOV	#128,R1	:REPEAT "'FC'-'LC'-'FC'" 128 TIMES
257	015364	004737	032736	JSR	PC,STRMTR	:INIT. THE COUNTERS
258	015370	012777	015610	MOV	#7\$,@PKV	:SET UP VECTOR IN CASE OF OVERFLOW
259	015376	012777	032734	MOV	#DORTI,@RMVEC	:SETUP RM VECTOR
260	015404	005077	164106	CLR	@PKB	:START COUNT AT ZERO
261	015410	013764	002342	MOV	LC,RMDC(R4)	: 'MIDDLE' CYLINDER
262	015416	012764	000105	MOV	#SEEK,RMCS1(R4)	:START A SEEK
263	015424	012777	000131	MOV	#131,@PKCS	:START THE CLOCK
264	015432	000001		WAIT		:WAIT ON INTERRUPT
265	015434	042777	000101	BIC	#101,@PKCS	:STOP CLOCK
266	015442	032764	040000	BIT	#ERR,RMDS(R4)	:ERR=1?
267	015450	001411		BEQ	2\$:NO--BRANCH
268	015452	104412		SAVREG		:SAVE R0-R5
	015454	012702	047076	MOV	#DTADPB,R2	:DPB POINTER
	015460	004737	045654	JSR	PC,SVRH70	:SAVE ALL THE RH/RM REGISTERS
	015464	004737	027334	JSR	PC,CNTCLR	:GO CLEAR MASSBUS CONTROLLER
	015470	104413		RESREG		:RESTORE R0-R5
269	015472	104017		EMT	17	:DISK ERROR OCCURRED
270	015474	005005		CLR	R5	:SET UP/DOWN SWITCH TO UP
271	015476	004737	033000	JSR	PC,COUNT	:UPDATE THE COUNT
272	015502	005077	164010	CLR	@PKB	:START THE COUNT AT ZERO
273	015506	013764	002340	MOV	FC,RMDC(R4)	:BEGINNING CYLINDER
274	015514	012764	000105	MOV	#SEEK,RMCS1(R4)	:START A SEEK
275	015522	012777	000131	MOV	#131,@PKCS	:START THE CLOCK
276	015530	000001		WAIT		:WAIT ON INTERRUPT
277	015532	042777	000101	BIC	#101,@PKCS	:STOP THE CLOCK
278	015540	032764	040000	BIT	#ERR,RMDS(R4)	:ERR=1?
279	015546	001411		BEQ	3\$:NO--BRANCH
280	015550	104412		SAVREG		:SAVE R0-R5
	015552	012702	047076	MOV	#DTADPB,R2	:DPB POINTER
	015556	004737	045654	JSR	PC,SVRH70	:SAVE ALL THE RH/RM REGISTERS
	015562	004737	027334	JSR	PC,CNTCLR	:GO CLEAR MASSBUS CONTROLLER
	015566	104413		RESREG		:RESTORE R0-R5
281	015570	104017		EMT	17	:DISK ERROR OCCURRED

```

282 015572 012705 177777      3$:  MOV    #-1,R5      ;SET UP/DOWN SWITCH TO DOWN
283 015576 004737 033000      JSR    PC,COUNT    ;UPDATE THE COUNT
284 015602 005301             DEC    R1          ;DONE?
285 015604 003277             BGT    1$         ;NO--BRANCH
286 015606 000420             BR     8$         ;YES--EXIT
287 015610 042777 000101 163676 7$:  BIC    #101,@PKCS ;STOP THE CLOCK
288 015616 005037 177776      CLR    PS         ;DROP THE PRIORITY
289 015622 012600             MOV    (SP)+,RO   ;PC OF WAIT+2
290 015624 005726             TST   (SP)+      ;POP THE PS FROM THE STACK
291 015626 104412             SAVREG            ;SAVE R0-R5
      015630 012702 047076      MOV    #DTADPB,R2 ;DPB POINTER
      015634 004737 045654      JSR    PC,SVRH70  ;SAVE ALL THE RH/RM REGISTERS
      015640 004737 027334      JSR    PC,CNTCLR  ;GO CLEAR MASSBUS CONTROLLER
      015644 104413             RESREG            ;RESTORE R0-R5
292 015646 104020             EMT    20        ;CLOCK OVERFLOWED
293 015650 004737 027334      8$:  JSR    PC,CNTCLR  ;GO CLEAR MASSBUS CONTROLLER
294 015654 004737 027426      JSR    PC,ST.CLK ;INITIALIZE THE CLOCK
295 015660 012777 043306 022764 MOV    #ISR,@RMVEC ;RESTORE RH/RM INT. VECTOR
296 015666 004037 033240      JSR    RO,TYPTIM ;GO TYPE THE TIMES
      015672 001670             T11             ;POINTER
297 015674 004037 033132      JSR    RO,SPTYP
298 015700 001746             SP11
299 015702 000004      EXIT14: SCOPE    ;CALL SCOPE ROUTINE
300
317
318
  
```

```

*****
*TEST 15      MAXIMUM SEEK TIMING TEST
*THIS TEST WILL COMMAND A FORWARD SEEK FROM CYLINDER 'FC' TO
*CYLINDER 'LC', THEN A REVERSE SEEK FROM CYLINDER 'LC' TO
*CYLINDER 'FC'. BOTH SEEKS ARE TIMED, BUT ONLY THE FORWARD SEEKS
*ARE CHECKED TO ENSURE THEY ARE WITHIN THE TOLERANCE ALLOWED FOR
*THE MAXIMUM SEEK TIME. THIS SEQUENCE IS REPEATED 128 TIMES (FOR
*A TOTAL OF 256. SEEKS). MAXIMUM (FORWARD) TIME IS 55.0 MS.
*
* THERE IS NO SPECIFICATION GIVEN FOR THE MAXIMUM REVERSE
* SEEK TIME ON THIS PARTICULAR DRIVE. THEREFORE, ANY REVERSE
* SEEK TIMES ABOVE THE MAXIMUM TIME OF 55.0 MS WILL NOT BE
* TYPED IN THE TIMING REPORT. HOWEVER, THE TIMING REPORT
* WILL STILL TYPE THE MINIMUM, MAXIMUM AND AVERAGE TIMES
* FOR THE REVERSE SEEKS.
*
*****
  
```

```

015704
015704 000240
015706 033737 001572 001332
015714 001002
015716 000137 016454

015722 012737 000015 001116      MOV    #15,$TSTNM ;SET TEST #15 AND CLEAR ($ERFLG)
015730 004737 030142      JSR    PC,LODPRM ;LOAD THE PARMETERS FOR THE TEST
015734 012737 016114 001124      MOV    #TEST15,$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
015742 013737 002336 001220      MOV    RPT,$TIMES ;GET THE ITERATION COUNT
015750 112737 000031 001131      MOV    #25,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
015756 012737 000015 001240      MOV    #15,$TESTN ;SET TEST NUMBER IN APT MAIL BOX
319
015764 032777 010000 163162      BIT    #SW12,@SWR ;INHIBIT TYPING TEST NUMBER ?
015772 001406             BEQ    .+16      ;BR IF YES
  
```

```

015774 104401 047617 TYPE ,MSGTST ;TYPE 'TEST'
016000 013746 001240 MOV $TESTN,-(SP) ;;SAVE $TESTN FOR TYPEOUT
016004 104403 TYPOS ;;GO TYPE--OCTAL ASCII
016006 003 .BYTE 3 ;;TYPE 3 DIGIT(S)
016007 000 .BYTE 0 ;;SUPPRESS LEADING ZEROS

320 016010 005737 001342 TST CLKSTA ;KW11-P CLOCK
321 016014 003002 BGT 1$ ;YES--START TEST
324 016016 000137 016452 JMP EXIT15 ;NO--JUMP TO EXIT15
325 016022 012737 016022 001122 1$: MOV #.,$LPADR ;SETUP THE LOOP ADDRESS
326 016030 004037 032552 JSR R0,SRCH00 ;DO A MASSBUS INIT & RECAL
327 016034 000402 BR 2$ ;RETURN HERE IF NO ERROR
339 016036 000137 016452 JMP EXIT15 ;RETURN HERE ON ERROR
016042 012737 016042 001122 2$: MOV #.,$LPADR ;ERROR LOOP ADDRESS
016050 112737 000105 047020 MOVB #SEEK,DPB.A+2 ;SEEK=COMMAND
016056 005037 047026 CLR DPB.A+10 ;USE TRACK 0 & SECTOR 0
016062 013737 002340 047030 MOV FC,DPB.A+12 ;STARTING CYLINDER
016070 012737 016452 001350 MOV #EXIT15,BYPASS ;GO TO EXIT15 IF ERROR
016076 004037 030402 JSR R0,CALL.A ;GO EXECUTE THE COMMAND
016102 012703 001700 MOV #T12,R3 ;PARAMETER POINTER
016106 012737 016452 001222 MOV #EXIT15,$ESCAPE ;;ESCAPE TO EXIT15 ON ERROR
016114 TEST15:

340 016114 012706 001100 MOV #STACK,SP ;SETUP STACK
341 016120 012701 000200 MOV #128,,R1 ;REPEAT "'FC'-'LC'-'FC'" 128 TIMES
342 016124 004737 032736 JSR PC,STRMR ;INIT. THE TIMERS
343 016130 012777 016360 163352 MOV #7$,@PKV ;SETUP VECTOR IN CASE OF OVERFLOW
344 016136 012777 032734 022506 MOV #DORTI,@RMVEC ;SETUP RM VECTOR
345 016144 005077 163346 1$: CLR @PKB ;START COUNTING FROM ZERO
346 016150 013764 002342 000034 MOV LC,RMDC(R4) ;MAXIMUM CYLINDER
347 016156 012764 000105 000000 MOV #SEEK,RMCS1(R4) ;START A SEEK
348 016164 012777 000131 163322 MOV #131,@PKCS ;START THE CLOCK
349 016172 000001 WAIT ;WAIT ON INTERRUPT
350 016174 042777 000101 163312 BIC #101,@PKCS ;STOP THE CLOCK
351 016202 032764 040000 000012 BIT #ERR,RMDS(R4) ;ERR=1?
352 016210 001411 BEQ 2$ ;NO--BRANCH
353 016212 104412 SAVREG ;SAVE R0-R5
016214 012702 047076 MOV #DTADPB,R2 ;DPB POINTER
016220 004737 045654 JSR PC,SVRH70 ;SAVE ALL THE RH/RM REGISTERS
016224 004737 027334 JSR PC,CNTCLR ;GO CLEAR MASSBUS CONTROLLER
016230 104413 RESREG ;RESTORE R0-R5
354 016232 104017 EMT 17 ;DISK ERROR OCCURRED
355 016234 005005 2$: CLR R5 ;SET THE UP/DOWN SWITCH TO UP
:56 016236 004737 033000 JSR PC,COUNT ;UP THE COUNT
357 016242 005077 163250 CLR @PKB ;START COUNT AT ZERO
358 016246 013764 002340 000034 MOV FC,RMDC(R4) ;BEGINNING CYLINDER
359 016254 012764 000105 000000 MOV #SEEK,RMCS1(R4) ;START A SEEK
360 016262 012777 000131 163224 MOV #131,@PKCS ;START THE CLOCK
361 016270 000001 WAIT ;WAIT ON INTERRUPT
362 016272 042777 000101 163214 BIC #101,@PKCS ;STOP THE CLOCK
363 016300 032764 040000 000012 BIT #ERR,RMDS(R4) ;'ERR'=1?
364 016306 001411 BEQ 3$ ;NO--BRANCH
365 016310 104412 SAVREG ;SAVE R0-R5
016312 012702 047076 MOV #DTADPB,R2 ;DPB POINTER
016316 004737 045654 JSR PC,SVRH70 ;SAVE ALL THE RH/RM REGISTERS
016322 004737 027334 JSR PC,CNTCLR ;GO CLEAR MASSBUS CONTROLLER
016326 104413 RESREG ;RESTORE R0-R5
366 016330 104017 FMT 17 ;DISK ERROR OCCURRED

```



```

367 016332 012705 177777          3$:  MOV    #-1,R5          ;SET THE UP/DOWN SWITCH TO DOWN
368 016336 004737 C33000          JSR    PC,COUNT       ;UPDATE THE COUNT
369 016342 005037 001416          CLR    TIM.DN+2       ;FORGET ABOUT # OF SEEKS BELOW MINIMUM TIME
370 016346 005037 001422          CLR    TIM.DN+6       ;FORGET ABOUT # OF SEEKS ABOVE MAXIMUM TIME
371 016352 005301                   DEC    R1             ;DONE?
372 016354 003273                   BGT    1$            ;NO--BRANCH
373 016356 000420                   BR     8$            ;YES--EXIT
374 016360 042777 000101 163126 7$: BIC    #101,@PKCS     ;STOP THE CLOCK
375 016366 005037 177776          CLR    PS             ;DROP THE PRIORITY
376 016372 012600                   MOV    (S?)+,R0      ;PC OF WAIT+2
377 016374 005726                   TST   (SP)+          ;POP THE PS FROM THE STACK
378 016376 104412                   SAVREG              ;SAVE R0-R5
    016400 012702 047076          MOV    #DTADPB,R2    ;DPB POINTER
    016404 004737 045654          JSR    PC,SVRH70     ;SAVE ALL THE RH/RM REGISTERS
    016410 004737 027334          JSR    PC,CNTCLR     ;GO CLEAR MASSBUS CONTROLLER
    016414 104413                   RESREG              ;RESTORE R0-R5
379 016416 104020                   EMT    20            ;CLOCK OVERFLOWED
380 016420 004737 027334          JSR    PC,CNTCLR     ;GO CLEAR MASSBUS CONTROLLER
381 016424 004737 027426          JSR    PC,ST.CLK     ;INITIALIZE THE CLOCK
382 016430 012777 043306 022214 MOV    #ISR,@RMVEC    ;RESTORE RH/RM INT. VECTOR
383 016436 004037 033240          JSR    R0,TYPTIM     ;GO TYPE THE TIMES
    016442 001700                   T12                  ;POINTER
384 016444 004037 033132          JSR    R0,SPTYP      ;
385 016450 001754                   SP12                  ;
386 016452 000004                   EXIT15: SCOPE        ;CALL SCOPE ROUTINE
  
```

1
2
3
4
5
6
7
8
19
20

.SBTTL ADDRESSING TESTS

:::////////////////////////////////////
 ::*THE ADDRESSING TESTS ENSURES PROPER OPERATION OF THE TRACK
 ::*AND SECTOR ADDRESS CIRCUITRY. BOTH ADDRESSING TESTS WILL
 ::*BE PERFORMED ON CYLINDER FC.
 :::////////////////////////////////////

:::*****
 ::*TEST 16 SECTOR ADDRESSING TEST
 ::*THIS TEST WRITES DATA INTO ALL SECTORS OF TRACK 'FT'. THE
 ::*DATA WILL BE 256 WORDS OF THE SECTOR ADDRESS OF THE SECTOR
 ::*BEING WRITTEN. A WRITE CHECK IS PERFORMED, THE BUFFER IS
 ::*CLEARED (TO 177400) AND THE DATA IS READ AND COMPARED. THEN
 ::*SECTOR 0 IS REWRITTEN AND SECTORS 0 - 31 ARE WRITE CHECKED.
 ::*THEN SECTOR 1 IS REWRITTEN AND SECTORS 0 - 31 ARE WRITE CHECKED.
 ::*THIS REWRITE AND WRITE CHECK PROCEDURE IS CONTINUED UP THROUGH
 ::*REWRITE SECTOR 31 AND WRITE CHECK SECTORS 0-31.
 :::*****

TST16:

016454	016454	000240			NOP		
016456	033737	001574	001332		BIT	BITS+<16*2>,TSTNMS	;DO THIS TEST?
016464	001002				BNE	+.6	;BR IF YES
016466	000137	017076			JMP	TST17	;NO--JUMP TO TEST17
016472	012737	000016	001116		MOV	#16,\$TSTNM	;SET TEST #16 AND CLEAR (\$ERFLG)
016500	004737	030142			JSR	PC,LODPRM	;LOAD THE PARMETERS FOR THE TEST
016504	012737	016574	001124		MOV	#TEST16,\$LPERR	;SETUP THE LOOP ON ERROR ADDRESS
016512	013737	002336	001220		MOV	RPT,\$TIMES	;GET THE ITERATION COUNT
016520	113737	001464	001131		MOVB	ERR.CT,\$ERMAX	;MAX ERRORS ALLOWED FOR TEST
016526	012737	000016	001240		MOV	#16,\$TESTN	::SET TEST NUMBER IN APT MAIL BOX
21 016534	032777	010000	162412		BIT	#SW12,@SWR	;INHIBIT TYPING TEST NUMBER ?
016542	001406				BEQ	+.16	;BR IF YES
016544	104401	047617			TYPE	.MSGTST	;TYPE 'TEST'
016550	013746	001240			MOV	\$TESTN,-(SP)	::SAVE \$TESTN FOR TYPEOUT
016554	104403				TYPOS		::GO TYPE--OCTAL ASCII
016556	003				.BYTE	3	::TYPE 3 DIGIT(S)
016557	000				.BYTE	0	::SUPPRESS LEADING ZEROS
26 016560	012737	017074	001350		MOV	#EXIT16,BYPASS	
016566	012737	016574	001122		MOV	#TEST16,\$LPADR	;SETUP THE LOOP ADDRESS
016574							
27 016574	012706	001100			MOV	#STACK,SP	;SET THE STACK POINTER
28 016600	004737	033730			JSR	PC,FILBUF	;FILL THE BUFFER WITH SECTOR ADDRESSES
29 016604	013737	002340	047110		MOV	FC,DTADPB+12	;CYLINDER
30 016612	113737	002346	047107		MOVB	FT,DTADPB+11	;TRACK
31 016620	105037	047106			CLRB	DTADPB+10	;SECTOR
32 016624	013737	001452	047102		MOV	TRCKWC,DTADPB+4	;WORD COUNT
33 016637	12737	054522	047104		MOV	#BUFFER,DTADPB+6	;BUFFER ADDRESS
34 016644	012737	016640	001124		MOV	#,,\$LPERR	;SETUP THE ERROR LOOP ADDRESS
016646	012706	001100			MOV	#STACK,SP	;LOAD THE STACK POINTER
35 016652	012737	000161	047100		MOV	#WRITE,DTADPB+2	;COMMAND=WRITE DATA
36 016660	004037	031204			JSR	RO,DRVCAL	;START A DATA TRANSFER
37 016664	012737	000151	047100		MOV	#WRCKD,DTADPB+2	;COMMAND=WRITE CHECK DATA
38 016672	012737	016672	001124		MOV	#,,\$LPERR	;SETUP THE ERROR LOOP ADDRESS

```

39 016700 012706 001100      MOV      #STACK,SP      ;LOAD THE STACK POINTER
016704 004037 031204      JSR      RO,DRVCAL     ;START A DATA TRANSFER
40 016710 012737 016710 001124  MOV      #.,$LPERR     ;SETUP THE ERROR LOOP ADDRESS
016716 012706 001100      MOV      #STACK,SP     ;LOAD THE STACK POINTER
41 016722 004037 033766      JSR      RO,CLRBUF     ;CLEAR BUFFER
016726 012737 000171 047100  MOV      #READ,DTADPB+2 ;COMMAND = READ
43 016734 004037 031204      JSR      RO,DRVCAL     ;START A DATA TRANSFER
44 016740 004037 034034      JSR      RO,CKSCTR     ;CHECK THE SECTOR DATA READ
45 016744 012700 054522      MOV      #BUFFER,RO    ;BUFFER ADDRESS
46 016750 005001      CLR      R1           ;FIRST SECTOR
47 016752 012737 016752 001124  MOV      #.,$LPERR     ;SETUP THE ERROR LOOP ADDRESS
016760 012706 001100      MOV      #STACK,SP     ;LOAD THE STACK POINTER
48 016764 012737 000161 047100 1$: MOV      #WRITE,DTADPB+2 ;COMMAND=WRITE DATA
49 016772 012737 177400 047102  MOV      #SCTRWC,DTADPB+4 ;WORD COUNT
50 017000 010037 047104      MOV      RO,DTADPB+6   ;BUFFER ADDRESS
51 017004 110137 047106      MOVB    R1,DTADPB+10   ;SECTOR
52 017010 004037 031204      JSR      RO,DRVCAL     ;START A DATA TRANSFER
53 017014 012737 017014 001124  MOV      #.,$LPERR     ;SETUP THE ERROR LOOP ADDRESS
017022 012706 001100      MOV      #STACK,SP     ;LOAD THE STACK POINTER
54 017026 012737 000151 047100  MOV      #WRCKD,DTADPB+2 ;COMMAND=WRITE CHECK DATA
55 017034 013737 001452 047102  MOV      TRCKWC,DTADPB+4 ;WORD COUNT
56 017042 012737 054522 047104  MOV      #BUFFER,DTADPB+6 ;BUFFER ADDRESS
57 017050 105037 047106      CLRB    DTADPB+10     ;SECTOR
58 017054 004037 031204      JSR      RO,DRVCAL     ;START A DATA TRANSFER
59 017060 062700 001000      ADD     #512.,RO      ;MOVE TO NEXT SECTOR
60 017064 005201      INC     R1
61 017066 023701 002470      CMP     PRMLMT+24,R1  ;DONE?
62 017072 103334      BHIS   1$            ;NO--BRANCH
63 017074 000004      EXIT16: SCOPE      ;CALL SCOPE ROUTINE
64
76
77

```

```

:*****
:*TEST 17 TRACK ADDRESSING TEST
:*THIS TEST WILL WRITE DATA IN THE FORM OF TRACK ADDRESSES
:*IN CYLINDER 'FC' SECTOR 'FS' OF EVERY TRACK WITH EACH TRACK
:*GETTING ITS OWN TRACK ADDRESS.
:*A WRITE CHECK IS THEN PERFORMED ON EACH TRACK TO ENSURE
:*THE DATA IS VALID. THEN TRACK 0 IS REWRITTEN AND TRACK 1
:*THROUGH LAST TRACK IS WRITE CHECKED. THEN TRACK 1 IS
:*REWRITTEN AND TRACK 2 THROUGH LAST TRACK IS WRITE CHECKED.
:*THIS PROCEDURE IS CONTINUED UP THROUGH REWRITING NEXT TO LAST
:*TRACK AND WRITE CHECKING LAST TRACK.
:*****
TST17:

```

```

017076
017076 000240
017100 033737 001576 001332      NOP
017106 001002      BIT     BITS+<17*2>,TSTNMS ;DO THIS TEST?
017110 000137 017542      BNE    +6            ;BR IF YES
017114 012737 000017 001116      JMP    TST20        ;NO--JUMP TO TEST20
017114 012737 000017 001116      MOV     #17,$TSTNM   ;SET TEST #17 AND CLEAR ($ERFLG)
017122 004737 030142      JSR    PC,LODPKM    ;LOAD THE PARMETERS FOR THE TEST
017126 012737 017216 001124  MOV     #TEST17,$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
017134 013737 002336 001220  MOV     RPT,$TIMES   ;GET THE ITERATION COUNT
017142 113737 001464 001131  MOVB   ERR,CT,$ERMAX ;MAX ERRORS ALLOWED FOR TEST
017150 012737 000017 001240  MOV     #17,$TESTN  ;;SET TEST NUMBER IN APT MAIL BOX
78 017156 032777 010000 161770      BIT     #SW12,@SWR   ;INHIBIT TYPING TEST NUMBER ?

```

017164	001406				BEO	.+16	:BR IF YES
017166	104401	047617			*TYPE	.MSGTST	:TYPE 'TEST'
017172	013746	001240			MOV	\$TESTN,-(SP)	::SAVE \$TESTN FOR TYPEOUT
017176	104403				TYPOS		::GO TYPE--OCTAL ASCII
017200	003				.BYTE	3	::TYPE 3 DIGIT(S)
017201	000				.BYTE	0	::SUPPRESS LEADING ZEROS
83	017202	012737	017540	001350	MOV	#EXIT17,BYPASS	
	017210	012737	017216	001122	MOV	#TEST17,\$LPADR	:SETUP THE LOOP ADDRESS
	017216						
84	017216	012706	001100		MOV	#STACK,SP	:SET THE STACK POINTER
85	017222	004737	033730		JSR	PC,FILBUF	:FILL THE BUFFER WITH TRACK ADDRESS
86	017226	012737	000161	047100	MOV	#WRITE,DTADPB+2	:COMMAND=WRITE DATA
87	017234	013737	002340	047110	MOV	FC,DTADPB+12	:CYLINDER
88	017242	113737	002354	047106	MOV	FS,DTADPB+10	:SECTOR
89	017250	012737	177400	047102	MOV	#STRWC,DTADPB+4	:WORD COUNT
90	017256	012737	054522	047104	MOV	#BUFFER,DTADPB+6	:BUFFER ADDRESS
91	017264	005000			CLR	RO	:TRACK=C
92	017266	012737	017266	001124	MOV	#, \$LPERR	:SETUP THE ERROR LOOP ADDRESS
	017274	012706	001100		MOV	#STACK,SP	:LOAD THE STACK POINTER
93							
94	017300	110037	047107		1\$:	MOVB	RO,DTADPB+11 :TRACK ADDRESS
95	017304	004037	031204			JSR	RO,DRVCAL :START A DATA TRANSFER
96	017310	062737	001000	047104		ADD	#256.*2.,DTADPB+6 :UPDATE BUFFER ADDRESS
97	017316	005200				INC	RO :UPDATE TRACK NUMBER
98	017320	023700	001374			CMP	LSTRK,RO :OUT OF TRACKS?
99	017324	002365				BGE	1\$:NO--BRANCH
100	017326	012737	054522	047104		MOV	#BUFFER,DTADPB+6 :BUFFER ADDRESS
101	017334	005000				CLR	RO
102	017336	012737	017336	001124		MOV	#, \$LPERR :SETUP THE ERROR LOOP ADDRESS
	017344	012706	001100			MOV	#STACK,SP :LOAD THE STACK POINTER
103							
104	017350	012737	000151	047100		MOV	#WRCKD,DTADPB+2 :COMMAND=WRITE CHECK
105	017356	110037	047107		2\$:	MOVB	RO,DTADPB+11 :TRACK ADDRESS
106	017362	004037	031204			JSR	RO,DRVCAL :START A DATA TRANSFER
107	017366	062737	001000	047104		ADD	#256.*2.,DTADPB+6 :UPDATE BUFFER ADDRESS
108	017374	005200				INC	RO :UPDATE TRACK NUMBER
109	017376	023700	001374			CMP	LSTRK,RO :OUT OF TRACKS?
110	017402	002365				BGE	2\$:NO--BRANCH
111	017404	005000				CLR	RO :FIRST TRACK ADDRESS
112							
113	017406	110037	047107		3\$:	MOVB	RO,DTADPB+11 :TRACK
114	017412	010001				MOV	RO,R1 :FORM BUFFER ADDRESS
115	017414	012737	054522	047104		MOV	#BUFFER,DTADPB+6 :BUFFER ADDRESS
116	017422	005301			4\$:	DEC	R1
117	017424	002411				BLT	5\$
118	017426	062737	001000	047104		ADD	#256.*2.,DTADPB+6
119	017434	000772				BR	4\$
120	017436	012737	017436	001124		MOV	#, \$LPERR :SETUP THE ERROR LOOP ADDRESS
	017444	012706	001100			MOV	#STACK,SP :LOAD THE STACK POINTER
121	017450	012737	000161	047100	5\$:	MOV	#WRITE,DTADPB+2 :COMMAND=WRITE DATA
122	017456	004037	031204			JSR	RO,DRVCAL :START A DATA TRANSFER
123							
124	017462	062737	001000	047104	6\$:	ADD	#256.*2.,DTADPB+6 :UPDATE BUFFER ADDRESS
125	017470	105237	047107			INCB	DTADPB+11 :MOVE TO NEXT TRACK
126	017474	012737	017474	001124		MOV	#, \$LPERR :SETUP THE ERROR LOOP ADDRESS
	017502	012706	001100			MOV	#STACK,SP :LOAD THE STACK POINTER

```

127 017506 012737 000151 047100      MOV      #WRCKD,DTADPB+2 ;COMMAND=WRITE CHECK DATA
128 017514 004037 031204              JSR      R0,DRVCAL       ;START A DATA TRANSFER
129 017520 123737 001374 047107      CMPB    LSTRK,DTADPB+11 ;OUT OF TRACKS?
130 017526 003355              BGT     6$              ;NO--BRANCH
131 017530 005200              INC     R0              ;NEXT TRACK TO WRITE
132 017532 023700 001374      CMP     LSTRK,R0       ;OUT OF TRACKS?
133 017536 003323              BGT     3$              ;NO--BRANCH
134 017540 000004              EXIT17: SCOPE          ;CALL SCOPE ROUTINE
135
155
156

```

```

*****
*TEST 20      DATA TEST
*THIS TEST PERFORMS DATA STORAGE AND RETRIEVAL ON CYLINDERS
*FC THROUGH LC BY THE INCREMENT IC USING THE DATA PATTERNS
*SPECIFIED. THE FOLLOWING SEQUENCE OCCURS FOR EACH CYLINDER:
* (1. SET NT TO FT THEN REPEAT 2-4 UNTIL NT > LT
* (2. WRITE THEN WRITE CHECK FS THROUGH LS OF TRACK NT
* (3. READ THEN SOFTWARE COMPARE FS THROUGH LS OF TRACK NT
* (4. INCREMENT NT BY IT
* (5. REPEAT STEPS 1-4 FOR EACH DATA PATTERN
* (6. REPEAT STEPS 1-5 FOR FC THROUGH LC ADVANCING BY IC
*
*IF A WRITE CHECK ERROR OCCURS THE ERROR IS REPORTED AND
*THE TRACK IN ERROR IS REWRITTEN AND CHECKED. THIS CHECK IS
*ACCOMPLISHED BY PERFORMING TWO(2) SUCCESSIVE ERROR FREE
*WRITE CHECKS. IF THE CHECK FAILS THE ERROR IS REPORTED AS
*FATAL AND NO READ OCCURS.
*FS DEFAULTS TO 1 AND LS DEFAULTS TO 0
*PAT DEFAULTS TO 17777 (ALL POSSIBLE PATTERNS)
*****

```

```

017542
017542 000240
017544 033737 001540 001334
017552 001002
017554 000137 020322

017560 012737 000020 001116      MOV      #20,$TSTNM     ;SET TEST #20 AND CLEAR ($ERFLG)
017566 004737 030142              JSR      PC,LODPRM     ;LOAD THE PARMETERS FOR THE TEST
017572 012737 017770 001124      MOV      #TEST20,$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
017600 013737 002336 001220      MOV      RPT,$TIMES    ;GET THE ITERATION COUNT
017606 113737 001464 001131      MOVVB   ERR,CT,$ERMAX  ;MAX ERRORS ALLOWED FOR TEST
017614 012737 000020 001240      MOV      #20,$TESTN    ;;SET TEST NUMBER IN APT MAIL BOX

157
017622 032777 010000 161324      BIT      #SW12,@SWR    ;INHIBIT TYPING TEST NUMBER ?
017630 001406              BEQ     .+16           ;BR IF YES
017632 104401 047617              TYPE   ,MSGTST        ;TYPE 'TEST'
017636 013746 001240              MOV     $TESTN,-(SP)  ;;SAVE $TESTN FOR TYPEOUT
017642 104403              TYPOS  ;GO TYPE--OCTAL ASCII
017644 003              .BYTE  3              ;;TYPE 3 DIGIT(S)
017645 000              .BYTE  0              ;;SUPPRESS LEADING ZEROS

158
159
160
161 017646 012737 017646 001122      MOV      #.,$LPADR     ;SETUP THE LOOP ADDRESS
162 017654 005000              CLR     R0             ;CLEAR SWITCH
163 017656 005004              CLR     R4             ;FORM WORD COUNT IN R4

```

```

164 017660 013701 002356      MOV    LS,R1          ;LOAD LAST SECTOR
165 017664 163701 002354      SUB    FS,R1          ;COMPARE WITH FIRST SECTOR
166 017670 002004              BGE    1$            ;SKIP NEXT IF FS < OR = LS
167
168 017672 063701 002470      ADD    PRMLMT+24,R1   ;ADD MAXIMUM SECTOR ADDRESS TO
169 017676 005201              INC    R1            ;MAKE THE DIFFERENCE POSITIVE
170 017700 005100              COM    R0            ;SET SWITCH FOR FS > LS
171
172 017702 062704 000400      1$:   ADD    #256.,R4    ;WORDS/SECTOR
173 017706 005301              DEC    R1            ;LS - FS SECTORS MINUS ONE
174 017710 002374              BGE    1$            ;INCR. WORD COUNT IF NO. SECTORS STILL +
175 017712 005404              NEG    R4            ;FORM NEGATIVE WORD COUNT
176 017714 010405              MOV    R4,R5         ;COPY NORMAL WORD COUNT INTO SMALL WC
177 017716 005700              TST    R0            ;FS > LS SWITCH SET?
178 017720 001412              BEQ    3$            ;NO, SKIP NEXT
179
180 017722 005005              CLR    R5            ;FORM WORD COUNT FOR FS > LS
181 017724 013701 002470      MOV    PRMLMT+24,R1   ;MAX SECTOR ADDRESS
182 017730 163701 002354      SUB    FS,R1          ;SUBTRACT THE FIRST SECTOR
183 017734 062705 000400      2$:   ADD    #256.,R5    ;WORDS/SECTOR
184 017740 005301              DEC    R1            ;NO SECTORS MINUS ONE
185 017742 002374              BGE    2$            ;INCR. WORD COUNT IF NO. SECTORS STILL +
186 017744 005405              NEG    R5            ;FORM NEGATIVE WORD COUNT FOR THIS CASE
187
188                          ;SET UP FOR DATA TRANSFERS AND PATTERN VARIATIONS
189
190 017746 113737 002354 047106 3$:   MOVB   FS,DTADPB+10   ;SECTOR
191 017754 012737 054522 047104      MOV    #BUFFER,DTADPB+6 ;DATA BUFFER
220 017762 012737 020320 001350      MOV    #EXIT20,BYPASS
221 017770
222 017770 012706 001100      TEST20: MOV    #STACK,SP     ;LOAD THE STACK POINTER
223 017774 005037 001434      CLR    WCEFLG        ;CLEAR THE WRITE CHECK ERROR FLAG
224 020000 013701 002340      MOV    FC,R1         ;PICKUP FIRST CYLINDER
225 020004 000407              BR     2$            ;SKIP PATTERN SET-UP FIRST TIME THRU
226
227 020006 005720              1$:   TST    (R0)+        ;MOVE TO NEXT DATA PATTERN
228 020010 022700 000040      CMP    #16.*2.,R0    ;OUT OF PATTERNS?
229 020014 003004              BGT    3$            ;NO, STAY ON THIS CYLINDER UNTIL DONE
230 020016 004037 033654      JSR    R0,INCCYL     ;MOVE TO NEXT CYLINDER
231 020022 000536              BR     EXIT20        ;OUT OF CYLINDERS
232
233                          ;DO NEXT CYLINDER
234
235 020024 005000              2$:   CLR    R0            ;START WITH PATTERN 0
236 020026 036037 001540 002360 3$:   BIT    BITS(R0),PAT  ;THIS PATTERN SELECTED?
237 020034 001764              BEQ    1$            ;NO, GO BACK AND GET ONE THAT WAS
238 020036 013702 002346      MOV    FT,R2         ;FIRST TRACK
239 020042 010137 047110      MOV    R1,DTADPB+12  ;LOAD THE CYLINDER
240 020046 110237 047107      4$:   MOVB   R2,DTADPB+11  ;LOAD THE TRACK
241
242 020052 020127 001466      CMP    R1,#822.      ;CHECK FOR LAST DISK CYLINDER (DEC144 FILE)
243 020056 001003              BNE    10$           ;SKIP LAST TRACK CHECK IF NOT
244 020060 020237 001374      CMP    R2,LSTRK     ;LAST DISK TRACK ?
245 020064 001515              BEQ    EXIT20        ;DON'T TEST LAST TRACK AS IT HAS BAD
246                          ;BLOCK INFORMATION STORED ON IT
247
248 221 020066 010437 047102      10$:  MOV    R4,DTADPB+4   ;LOAD THE WORD COUNT
249 222 020072 023701 002342      CMP    LC,R1         ;LAST DISK CYLINDER TO TEST ?
    
```

```

223 020076 003005          BGT      5$          ;NO, SKIP TRACK CHECK
224 020100 023702 001374   CMP      LSTRK,R2     ;LAST DISK TRACK TO TEST ?
225 020104 002002          BGE      5$          ;NO, SKIP NEXT
226 020106 010537 047102   MOV      R5,DTADPB+4 ;SHORT WORD COUNT
227 020112 017703 161036   5$:    MOV      @SWR,R3  ;INHIBIT WRITE AND
228 020116 005103          COM      R3          ;WRITE CHECK?
229 020120 032703 000030   BIT      #SW04!SW03,R3
230 020124 001436          BEQ      7$          ;YES--BRANCH
231 020126 004737 034404   JSR      PC,SETBUF   ;MOVE DATA PATTERN INTO THE BUFFER
232 020132 032777 000020 161014   BIT      #SW04,@SWR  ;INHIBIT WRITE?
233 020140 001012          BNE      6$          ;YES, DO NEXT PORTION OF TESTING
234 020142 012737 020142 001124   MOV      #.,$LPERR   ;SETUP THE ERROR LOOP ADDRESS
          020150 012736 001100   MOV      #STACK,SP   ;LOAD THE STACK POINTER
235 020154 012737 000161 047100   MOV      #WRITE,DTADPB+2 ;COMMAND=WRITE DATA
236
237          ;DO A DATA TRANSFER
238
239 020162 004037 031204          JSR      R0,DRVCL    ;START A DATA TRANSFER
240 020166 032777 000010 160760 6$:    BIT      #SW03,@SWR  ;INHIBIT WRITE CHECK?
241 020174 001012          BNE      7$          ;YES--BRANCH
242 020176 012737 020176 001124   MOV      #.,$LPERR   ;SETUP THE ERROR LOOP ADDRESS
          020204 012706 001100   MOV      #STACK,SP   ;LOAD THE STACK POINTER
243 020210 012737 000151 047100   MOV      #WRCKD,DTADPB+2 ;COMMAND=WRITE CHECK DATA
244 020216 004037 031204          JSR      R0,DRVCL    ;START A DATA TRANSFER
245 020222 005737 001434          7$:    TST      WCEFLG ;WRITE CHECK ERROR FLAG SET?
246 020226 001404          BEQ      8$          ;NO--BRANCH
247 020230 032777 000001 160716   BIT      #SW00,@SWR  ;PERFORM READ AFTER 'FATAL 'WCE''?
248 020236 001424          BEQ      9$          ;NO--BRANCH
249 020240 032777 000004 160706 8$:    BIT      #SW02,@SWR  ;INHIBIT READ DATA AND SOFTWARE COMPARE?
250 020246 001020          BNE      9$          ;YES--BRANCH
251 020250 012737 020250 001124   MOV      #.,$LPERR   ;SETUP THE ERROR LOOP ADDRESS
          020256 012706 001100   MOV      #STACK,SP   ;LOAD THE STACK POINTER
252 020262 012737 000171 047100   MOV      #READ,DTADPB+2 ;COMMAND=READ
253 020270 004037 031204          JSR      R0,DRVCL    ;START A DATA TRANSFER
254 020274 032777 000002 160652   BIT      #SW01,@SWR  ;COMPARE THE DATA?
255 020302 001002          BNE      9$          ;NO--BRANCH
256 020304 004737 034474          JSR      PC,DATCMP   ;YES--DO IT
257 020310 004037 033624          9$:    JSR      R0,INCTRK  ;MOVE TO NEXT TRACK
258 020314 000634          BR      1$          ;OUT OF TRACKS GO TO NEXT PATTERN
259 020316 000653          BR      4$          ;LOOP
260 020320 000004          EXIT20: SCOPE      ;CALL SCOPE ROUTINE
261
286
287

```

```

:*****
:*TEST 21      RANDOM ADDRESS AND RANDOM PATTERN TEST
:*STARTING AT 'FC' AND GOING SEQUENTIALLY TO 'LC' THE DISK
:*PACK IS WRITTEN WITH A RANDOM PATTERN. THE FIRST TWO WORDS
:*OF EACH SECTOR WILL BE THE BASE OF THE RANDOM GENERATOR
:*FOR THAT SECTOR.

:*THE TEST THEN PERFORMS THE FOLLOWING SEQUENCE 'R' TIMES
:*'R' DEFAULTS TO 1000.
:*
:*1)  GENERATE A RANDOM SECTOR ADDRESS
:*2)  WRITE A RANDOM PATTERN AT THE ADDRESS
:*    GENERATED IN 1.
:*3)  GENERATE A NEW RANDOM SECTOR ADDRESS

```

```

:*4) READ THE SECTOR AT THE ADDRESS
:*   GENERATED IN 3.
:*5) DO A SOFTWARE CHECK OF THE DATA READ IN 4 AGAINST
:*   THE ORIGINAL RANDOM PACK DATA.
:*6) DO A WRITE CHECK OF THE DATA WRITTEN IN 2
:*7) GENERATE A NEW RANDOM SECTOR ADDRESS
:*8) READ THE SECTOR AT THE ADDRESS
:*   GENERATED IN 7.
:*9) DO A SOFTWARE CHECK OF THE DATA READ IN 8
:*10) DO A WRITE CHECK OF THE DATA WRITTEN IN 2
:*****

```

TST21:

020322					NOP			
020322	000240				BIT	BITS+<21*2-40>,TSTNMS+2	:DO THIS TEST ?	
020324	033737	001542	001334		.+6		:BR IF YES	
020332	001002				BNE			
020334	000137	021140			JMP	TST22	:NO--JUMP TO TEST22	
020340	012737	000021	001116		MOV	#21,\$TSTNM	:SET TEST #21 AND CLEAR (\$ERFLG)	
020346	004737	030142			JSR	PC,LODPRM	:LOAD THE PARAMETERS FOR THE TEST	
020352	012737	020616	001124		MOV	#TEST21,\$LPERR	:SETUP THE LOOP ON ERROR ADDRESS	
020360	013737	002336	001220		MOV	RPT,\$TIMES	:GET THE ITERATION COUNT	
020366	113737	001464	001131		MOV#B	ERR.CT,\$ERMAX	:MAX ERRORS ALLOWED FOR TEST	
020374	012737	000021	001240		MOV	#21,\$TESTN	:;SET TEST NUMBER IN APT MAIL BOX	
288								
020402	032777	010000	160544		BIT	#SW12,@SWR	:INHIBIT TYPING TEST NUMBER ?	
020410	001406				.+16		:BR IF YES	
020412	104401	047617			TYPE	.MSGTST	:TYPE 'TEST'	
020416	013746	001240			MOV	\$TESTN,-(SP)	:;SAVE \$TESTN FOR TYPEOUT	
020422	104403				TYPOS		:;GO TYPE--OCTAL ASCII	
020424	003				.BYTE	3	:;TYPE 3 DIGIT(S)	
020425	000				.BYTE	0	:;SUPPRESS LEADING ZEROS	
289	020426	012737	020426	001122	MOV	#,\$LPADR	:SETUP THE LOOP ADDRESS	
292	020434	012737	021136	001350	MOV	#EXIT21,BYPASS		
293	020442	012737	176543	026524	MOV	#176543,\$SHNUM	:PRIME THE RANDOM NUMBER GENERATOR	
294	020450	012737	123456	026526	MOV	#123456,\$LONUM		
295	020456	013737	002340	047110	MOV	FC,DTADPB+12	:CYLINDER	
296	020464	013737	001452	047102	MOV	TRCKWC,DTADPB+4	:WORD COUNT FOR 32/30 SECTORS (FULL TRACK)	
297	020472	012737	054522	047104	MOV	#BUFFER,DTADPB+6	:BUFFER ADDRESS	
298	020500	012737	000161	047100	MOV	#WRITE,DTADPB+2	:COMMAND	
299	020506	032737	100000	001314	BIT	#SW15,C.SWR	:WRITE THE DISK PACK BEFORE TESTING?	
300	020514	001027			BNE	3\$:NO--BEGIN TESTING	
301	020516	004037	035012		JSR	RO,FILRAN	:FILL DATA BUFFER WITH RANDOM DATA	
302	020522	005037	047106		CLR	DTADPB+10	:SECTOR AND TRACK	
303	020526	012737	020526	001124	MOV	#,\$LPERR	:SETUP THE ERROR LOOP ADDRESS	
	020534	012706	001100		MOV	#STACK,SP	:LOAD THE STACK POINTER	
304	020540						2\$:	
	020540	004037	031204		JSR	RO,DRVCAL	:START A DATA TRANSFER	
305	020544	105237	047107		INCB	DTADPB+11	:NEXT TRACK	
306	020550	123737	001374	047107	CM#B	LSTRK,DTADPB+11	:TIME FOR NEXT CYLINDER ?	
307	020556	002370			BGE	2\$:NO--DO NEXT TRACK ON THIS CYL.	
308	020560	005237	047110		INC	DTADPB+12	:INCR CYLINDER ADDRESS	
309	020564	023737	002342	047110	CM#B	LC,DTADPB+12	:OUT OF CYLINDERS?	
310	020572	002353			BGE	1\$:NO--CONTINUE SEQUENTIAL RANDOM WRITE	
311								
312								
313	020574	012737	177400	047102	3\$:	MOV	#SCTRWC,DTADPB+4	:WORD COUNT


```

318 020602 012737 020616 001122      MOV      #TEST21,$LPADR
      020610 012737 020616 001124      MOV      #TEST21,$LPERR
      020616                                TEST21:
319 020616 012706 001100      MOV      #STACK,SP          ;SET STACK POINIER
320 020622 004037 035266      JSR      RO,RANADR          ;GENERATE A RANDOM ADDRESS
321 020626 013737 047106      MOV      DTADPB+10,SVADR    ;SAVE THE TRACK/SECTOR
322 020634 013737 047110      MOV      DTADPB+12,SVADR+2  ;SAVE THE CYLINDER
323 020642 012737 000161 047100      MOV      #WRITE,DTADPB+2   ;COMMAND=WRITE DATA
324 020650 012701 054522      MOV      #BUFFER,R1        ;WRITE BUFFER ADDRESS FOR 'RANPAT'
325 020654 010137 047104      MOV      R1,DTADPB+6       ;INTO THE DATA PARAMETER BLOCK
326 020660 004037 035232      JSR      RO,RANPAT         ;GENERATE RANDOM 256 WORD PATTERN
327                                ;AND PUT INTO THE WRITE BUFFER
328 020664 012737 020664 001124      MOV      #,$LPERR         ;SETUP THE ERROR LOOP ADDRESS
      020672 012706 001100      MOV      #STACK,SP        ;LOAD THE STACK POINTER
329 020676 004037 031204      JSR      RO,DRVCL         ;START A DATA TRANSFER
330
331 020702 004037 035266      JSR      RO,RANADR         ;GENERATE A NEW RANDOM ADDRESS
332 020706 012737 000171 047100      MOV      #READ,DTADPB+2    ;COMMAND=READ DATA
333 020714 012737 055522 047104      MOV      #BUFFER+512.,DTADPB+6 ;READ BUFFER ADDRESS
334 020722 012737 020722 001124      MOV      #,$LPERR         ;SETUP THE ERROR LOOP ADDRESS
      020730 012706 001100      MOV      #STACK,SP        ;LOAD THE STACK POINTER
335 020734 004037 031204      JSR      RO,DRVCL         ;START A DATA TRANSFER
336 020740 005737 001466      TST      BASFLG           ;IF BAD SECTOR ENCOUNTERED,SKIP NEXT CALL
337 020744 100402                BMI      .+6              ;DON'T COMPARE DATA
338 020746 004037 035034      JSR      RO,RANCK         ;SOFTWARE CHECK THE DATA
339
340 020752 013737 001440 047106      MOV      SVADR,DTADPB+10   ;GET ADDRESS OF WHERE THE LAST
341 020760 013737 001442 047110      MOV      SVADR+2,DTADPB+12 ;WRITE WAS PERFORMED
342 020766 012737 000151 047100      MOV      #WRCKD,DTADPB+2  ;COMMAND=WRITE CHECK DATA
343 020774 012737 054522 047104      MOV      #BUFFER,DTADPB+6 ;DATA BUFFER ADDRESS FOR HARDWARE
344                                ;CHECK OF THE DATA
345 021002 012737 021002 001124      MOV      #,$LPERR         ;SETUP THE ERROR LOOP ADDRESS
      021010 012706 001100      MOV      #STACK,SP        ;LOAD THE STACK POINTER
346 021014 004037 031204      JSR      RO,DRVCL         ;START A DATA TRANSFER
347
348 021020 004037 035266      JSR      RO,RANADR         ;GENERATE A NEW RANDOM ADDRESS
349 021024 012737 000171 047100      MOV      #READ,DTADPB+2    ;COMMAND=READ
350 021032 012737 055522 047104      MOV      #BUFFER+512.,DTADPB+6 ;DATA BUFFER ADDRESS
351 021040 012737 021040 001124      MOV      #,$LPERR         ;SETUP THE ERROR LOOP ADDRESS
      021046 012706 001100      MOV      #STACK,SP        ;LOAD THE STACK POINTER
352 021052 004037 031204      JSR      RO,DRVCL         ;START A DATA TRANSFER
353 021056 005737 001466      TST      BASFLG           ;ENCOUNTER BAD SECTOR ?
354 021062 100402                BMI      .+6              ;DON'T COMPARE DATA IF SO
355 021064 004037 035034      JSR      RO,RANCK         ;SOFTWARE CHECK THE DATA
356
357 021070 013737 001440 047106      MOV      SVADR,DTADPB+10   ;GET DISK ADDRESS OF THE
358 021076 013737 001442 047110      MOV      SVADR+2,DTADPB+12 ;LAST WRITE
359 021104 012737 000151 047100      MOV      #WRCKD,DTADPB+2  ;COMMAND=WRITE CHECK DATA
360 021112 012737 054522 047104      MOV      #BUFFER,DTADPB+6 ;DATA BUFFER ADDRESS
361 021120 012737 021120 001124      MOV      #,$LPERR         ;SETUP THE ERROR LOOP ADDRESS
      021126 012706 001100      MOV      #STACK,SP        ;LOAD THE STACK POINTER
362 021132 004037 031204      JSR      RO,DRVCL         ;START A DATA TRANSFER
363 021136 000004                EXIT21: SCOPE             ;CALL SCOPE ROUTINE
364
371
372

```

 :*TEST 22 SEEK TIME ADJUSTMENT TEST

*THIS TEST PERFORMS SEEKS BETWEEN CYLINDERS 0 & 255 TO ALLOW THE
 *OPERATOR TO ADJUST THE AVERAGE SEEK TIME ON AN RM05/3/2 USING THE
 *DDU. THE PROGRAM STALLS APPROXIMATELY 5 SECONDS BETWEEN SEEKS
 *SO THAT THE AVERAGE SFEK TIME INDICATORS ON THE DDU MAY BE OBSERVED.
 *.....

```

TST22:
021140      NOP
021140 000240      BIT      BITS<<22*2-40>,TSTNMS+2 ;DO THIS TEST ?
021142 033737 001544 001334      BNE      .+6 ;BR IF YES
021150 001002      JMP      $EOP ;NO--GO TO THE FND OF THE PROGRAM
021152 000137 021334

021156 012737 000022 001116      MOV      #22,$TSTNM ;SET TEST #22 AND CLEAR ($ERFLG)
021164 004737 030142      JSR      PC,LODPRM ;LOAD THE PARMETERS FOR THE TEST
021170 012737 021252 001124      MOV      #TEST22,$LPERR ;SETUP THE LOOP ON ERROR ADDRESS
021176 013737 002336 001220      MOV      RPT,$TIMES ;GET THE ITERATION COUNT
021204 112737 000144 001131      MOV      #100,$SERMAX ;MAX ERRORS ALLOWED FOR TEST
021212 012737 000022 001240      MOV      #22,$TESTN ;;SET TEST NUMBER IN APT MAIL BOX
373
021220 032777 010000 157726      BIT      #SW12,@SWR ;INHIBIT TYPING TEST NUMBER ?
021226 001406      BEQ      .+16 ;BR IF YES
021230 104401 047617      TYPE      ,MSGTST ;TYPE 'TEST'
021234 013746 001240      MOV      $TESTN,-(SP) ;;SAVE $TESTN FOR TYPEOUT
021240 104403      TYPOS ;;GO TYPE--OCTAL ASCII
021242 003 ;;TYPE 3 DIGIT(S)
021243 000 ;;SUPPRESS LEADING ZEROS

377 021244 012737 021252 001122      MOV      #TEST22,$LPADR ;SETUP THE LOOP ADDRESS
021252      TEST22:
378 021252 012706 001100      MOV      #STACK,SP ;SETUP THE STACK POINTER
379 021256 013737 002342 047030      MOV      LC,DPB.A+12 ;ENDING CYLINDER
380 021264 112737 000105 047020      MOV      #SEEK,DPB.A+2 ;SEEK=COMMAND
381 021272 004037 030402      JSR      R0,CALL.A ;GO EXECUTE THE COMMAND
382 021276 004037 032326      JSR      R0,STALL ;STALL
383 021302 001460      .WORD   STALL3 ;ADDRESS OF STALL VALUE
384 021304 013737 002340 047030      MOV      FC,DPB.A+12 ;STARTING CYLINDER
385 021312 112737 000105 047020      MOV      #SEEK,DPB.A+2 ;SEEK=COMMAND
386 021320 004037 030402      JSR      R0,CALL.A ;GO EXECUTE THE COMMAND
387 021324 004037 032326      JSR      R0,STALL ;STALL
388 021330 001460      .WORD   STALL3 ;ADDRESS OF STALL VALUE
389 021332 000004      EXIT22: SCOPE ;CALL SCOPE ROUTINE
390
395
  
```

.SBTTL END OF PASS ROUTINE

 ;*INCREMENT THE PASS NUMBER (\$PASS)
 ;*INDICATE END-OF-PROGRAM AFTER 8. PASSES THRU THE PROGRAM
 ;*IF THERES A MONITOR GO TO IT
 ;*IF THERE ISN'T JUMP TO RETURN

021334
 021334 104401 021342
 021340 000407

\$EOP:
 TYPE .65\$;:TYPE ASCIZ STRING
 BR .64\$;:GET OVER THE ASCIZ
 ;:65\$: .ASCIZ <CRLF><LF>/END OF PASS/
 64\$:

021360
 021360 104401 021366
 021364 000405

TYPE .67\$;:TYPE ASCIZ STRING
 BR .66\$;:GET OVER THE ASCIZ
 ;:67\$: .ASCIZ / ON DRIVE/
 66\$:

021400
 021400 013746 001352
 021404 104403
 021406 002
 021407 000
 021410 005737 001126
 021414 001420
 021416 104401 021424
 021422 000412

MOV CHKDRV,-(SP) ;:SAVE CHKDRV FOR TYPEOUT
 TYP0S ;:GO TYPE--OCTAL ASCII
 .BYTE 2 ;:TYPE 2 DIGIT(S)
 .BYTE 0 ;:SUPPRESS LEADING ZEROS
 TST \$ERTTL ;:ANY ERRORS DETECTED ?
 BEQ 1\$;:BR IF NO
 TYPE .69\$;:TYPE ASCIZ STRING
 BR .68\$;:GET OVER THE ASCIZ
 ;:69\$: .ASCIZ / ERRORS DETECTED=
 68\$:

021450
 021450 013746 001126
 021454 104402
 021456 005037 001126
 021462 005037 001116
 021466 005037 001220
 021472 005237 001242
 021476 042737 100000 001242
 021504 005327
 021506 000010
 021510 003027
 021512 012737
 021514 000010
 021516 021506
 021520 104401 021526
 021524 000407

MOV \$ERTTL,-(SP) ;:SAVE \$ERTTL FOR TYPEOUT
 TYP0C ;:GO TYPE--OCTAL ASCII(ALL DIGITS)
 1\$: CLR \$ERTTL ;:ZERO ERROR TOTAL
 CLR \$TSTNM ;:ZERO THE TEST NUMBER
 CLR \$TIMES ;:ZERO THE NUMBER OF ITERATIONS
 INC \$PASS ;:INCREMENT THE PASS NUMBER
 BIC #100000,\$PASS ;:DON'T ALLOW A NEG. NUMBER
 DEC (PC)+ ;:LOOP?

021506 000010
 021510 003027
 021512 012737
 021514 000010
 021516 021506
 021520 104401 021526
 021524 000407

\$EOPCT: .WORD 8.
 BGT \$DOAGN ;:YES
 MOV (PC)+,@(PC)+ ;:RESTORE COUNTER

021544
 021544 104401 021574
 021550 013700 000042
 021554 001405
 021556 000005
 021560 004710
 021562 000240
 021564 000240
 021566 000240
 021570
 021570 000137
 021572 021600
 021574 377 377 000

SENDCT: .WORD 8.
 TYPE .65\$;:TYPE ASCIZ STRING
 BR .64\$;:GET OVER THE ASCIZ
 ;:65\$: .ASCIZ <CRLF>/END OF TEST/<CRLF>
 64\$:
 TYPE \$ENULL ;:TYPE NULL CHARACTER
 \$GET42: MOV @#42,R0 ;:GET MONITOR ADDRESS
 BEQ \$DOAGN ;:BRANCH IF NO MONITOR
 RESET ;:CLEAR THE WORLD
 \$ENDAD: JSR PC,(R0) ;:GO TO MONITOR
 NOP ;:SAVE ROOM
 NOP ;:FOR
 NOP ;:ACT11
 \$DOAGN: JMP @ (PC)+ ;:RETURN
 \$RTNAD: .WORD RTURN
 \$ENULL: .BYTE -1,-1,0 ;:NULL CHARACTER STRING
 .EVEN

2
3 021600 012706 001100
4 021604 004737 024060
5 021610 004737 027426
6 021614 000137 006662

RTURN: MOV #STACK,SP ;RESTORE STACK
JSR PC,\$TKINT ;MAKE SURE KEYBOARD INTERRUPT AND
JSR PC,ST.CLK ;INITIALIZE THE CLOCK
JMP RSTART ;RETURN TO RESTART

.SBTTL ERROR HANDLER ROUTINE

```

*****
*THIS ROUTINE WILL INCREMENT THE ERROR FLAG AND THE ERROR COUNT,
*SAVE THE ERROR ITEM NUMBER AND THE ADDRESS OF THE ERROR CALL
*AND GO TO TYPERR ON ERROR
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW15=1 HALT ON ERROR
*SW13=1 INHIBIT ERROR TYPEOUTS
*SW10=1 BELL ON ERROR
*SW09=1 LOOP ON ERROR
*CALL
*
*      ERROR      N      ;;ERROR=EMT AND N=ERROR ITEM NUMBER

021620 105037 022260 $ERROR: CLR      IBSAVE      ;;CLEAR THE ITEM BYTE SAVE LOCATION
021624 104407          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
021626 032777 000400 157320      BIT      #SW08,@SWR      ;;SEND ERROR MESSAGE TO TTY?
021634 001411          BEQ      7$          ;;YES--BRANCH
021636 005737 001326          TST      LPTAVL      ;;IS THERE A LINE PRINTER AVAILABLE?
021642 001406          BEQ      7$          ;;NO--BRANCH
021644 013737 001534 001164      MOV      LPS,$TPS      ;;YES--SETUP STATUS
021652 013737 001536 001166      MOV      LPB,$TPB      ;;AND BUFFER REG.'S FOR LINE PRINTER
021660 105237 001117      7$:      INCB      $ERFLG      ;;SET THE ERROR FLAG
021664 001775          BEQ      7$          ;;DON'T LET THE FLAG GO TO ZERO
021666 013777 001116 157262      MOV      $STNM,@DISPLAY ;;DISPLAY TEST NUMBER AND ERROR FLAG
021674 032777 002000 157252      BIT      #BIT10,@SWR   ;;BELL ON ERROR?
021702 001402          BEQ      1$          ;;NO - SKIP
021704 104401 001224          TYPE      $BELL      ;;RING BELL
021710 005237 001126      1$:      INC      $ERTTL      ;;COUNT THE NUMBER OF ERRORS
021714 011637 001132          MOV      (SP),$ERRPC   ;;GET ADDRESS OF ERROR INSTRUCTION
021720 162737 000002 001132      SUB      #2,$ERRPC
021726 117737 157200 001130      MOV      @ERRPC,$ITEMB ;;STRIP AND SAVE THE ERROR ITEM CODE
021734 032777 001000 157212      BIT      #BIT09,@SWR   ;;SEE IF LOOP ON ERROR IS SET
021742 001060          BNE      1004$        ;;BRANCH AROUND ROUTINE IF SO
021744 122737 000177 001130      CMP      #177,$ITEMB   ;;SEE IF THIS IS THE POWER FAIL CALL
021752 001454          BEQ      1004$        ;;BRANCH AROUND ROUTINE IF IT IS
021754 105737 022260          TSTB     IBSAVE      ;;SEE IF THIS IS THE 2ND ERROR CALL IN THIS ROUTINE
021760 001047          BNE      1003$        ;;BRANCH IF SO
021762 022737 177777 022256      CMP      #-1,CPSAVE    ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
021770 001445          BEQ      1004$        ;;BRANCH IF SO
021772 013746 000004          MOV      ERRVEC,-(SP)  ;;SAVE CONTENTS OF ERROR VECTOR
021776 012737 022014 000004      MOV      #1000$,ERRVEC ;;SETUP 'TRAP' RETURN ADDRESS
022004 013737 177766 022256      MOV      177766,CPSAVE ;;MOVE CPU ERROR REGISTER TO CPSAVE FOR TEST
022012 000406          BR      1001$
022014 012737 177777 022256 1000$: MOV      #-1,CPSAVE    ;;SET CPU ERROR REGISTER TIMEOUT INDICATOR
022022 012716 022030          MOV      #1001$, (SP)  ;;SETUP RETURN ADDRESS
022026 000002          RTI
022030 012637 000004          1001$: MOV      (SP)+,ERRVEC  ;;RESTORE CONTENTS OF ERROR VECTOR

022034 022737 177777 022256 1002$: CMP      #-1,CPSAVE    ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
022042 001420          BEQ      1004$        ;;BRANCH IF SO
022044 032737 000001 022256      BIT      #BIT00,CPSAVE ;;SEE IF POWER MONITOR BIT IS SET IN CPU ERR REG
022052 001414          BEQ      1004$        ;;BRANCH IF OK
022054 042737 000001 177766      BIC      #BIT00,177766 ;;CLEAR THE BIT FOUND SET
022062 113737 001130 022260      MOV      $ITEMB,IBSAVE ;;MAKE IBSAVE NON-ZERO FOR DUAL ERROR CALL
022070 112737 000177 001130      MOV      #177,$ITEMB  ;;SET $ITEMB TO SPECIAL POWER FAIL POINTER
022076 000402          BR      1004$        ;;BRANCH OVFR IBSAVE CLEARING
  
```

ERROR HANDLER ROUTINE

```

022100 105037 022260          1003$: CLRB   IBSAVE      ;;CLEAR IBSAVE SO 2ND TIME THROUGH EXITS
022104          1004$:
022104 032777 020000 157042  BIT   #BIT13,@SWR  ;;SKIP TYPEOUT IF SET
022112 001004          BNC   20$          ;;SKIP TYPEOUTS
022114 004737 022262  JSR   PC,TYPERR   ;;GO TO USER ERROR ROUTINE
022120 104401 001231          TYPE  .$CRLF
022124
022124 122737 000001 001254  20$:  CMPB  #APTENV,$ENV  ;;RUNNING IN APT MODE
022132 001007          BNE   2$          ;;NO,SKIP APT ERROR REPORT
022134 113737 001130 022146  MOVB  $ITEMB,21$  ;;SET ITEM NUMBER AS ERROR NUMBER
022142 004737 026766  JSR   PC,$ATY4   ;;REPORT FATAL ERROR TO APT
022146      000          21$:  .BYTE  0
022147      000          .BYTE  0
022150 000777          22$:  BR    22$          ;;APT ERROR LOOP
022152 105737 022260  2$:  TSTB  IBSAVE     ;;SEE IF IBSAVE IS LOADED
022156 001005          BNE   3$          ;;BRANCH IF NOT - NO HALT ON PWR MON BIT ERROR
022160 005777 156770  TST   @SWR       ;;HALT ON ERROR
022164 100002          BPL   3$          ;;SKIP IF CONTINUE
022166 000000          HALT                ;;HALT ON ERROR!
022170 104407          CKSWR                ;;TEST FOR CHANGE IN SOFT-SWR
022172
022172 105737 022260  3$:  TSTB  IBSAVE     ;;SEE IF ITEM BYTE SAVE LOCATION HAS AN ERROR CALL
022176 001230          BNE   7$          ;;BRANCH BACK TO CALL ORIGINAL ERROR
022200 032777 001000 156746  BIT   #BIT09,@SWR  ;;LOOP ON ERROR SWITCH SET?
022206 001402          BEQ   4$          ;;BR IF NO
022210 013716 001124  MOV   $LPERR,(5P)  ;;FUDGE RETURN FOR LOOPING
022214 005737 001222  4$:  TST   $ESCAPE   ;;CHECK FOR AN ESCAPE ADDRESS
022220 001402          BEQ   5$          ;;BR IF NONE
022222 013716 001222  MOV   $ESCAPE,(5P)  ;;FUDGE RETURN ADDRESS FOR ESCAPE
022226
022226 022737 021560 000042  5$:  CMP   #SENDAD,@#42  ;;ACT-11 AUTO-ACCEPT?
022234 001001          BNE   6$          ;;BRANCH IF NO
022236 000000          HALT                ;;YES
022240
022240 013737 001530 001164  6$:  MOV   TPS,$TPS   ;;SET STATUS AND BUFFER REG.'S
022246 013737 001532 001166  MOV   TPB,$TPB   ;;FOR TTY
022254 000002          RTI                    ;;RETURN FROM ERROR CALL
022256 000000          CPSAVE: .WORD  0  ;;LOCATION TO SAVE CPU ERROR REG CONTENTS
022260 000000          IBSAVE: .WORD  0  ;;LOCATION TO SAVE ITEM BYTE

```

2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
27
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58

.SBTTL TYPERR - TYPE ERROR ROUTINE

: THIS ROUTINE USES THE 'ITEM CONTROL BYTE' (\$ITEMB) TO DETERMINE
 : WHICH ERROR IS TO BE REPORTED, IT THEN OBTAINS, FROM THE 'ERROR
 : TABLE' (\$ERRTB), AND REPORTS THE APPROPRIATE INFORMATION
 : CONCERNING THE ERROR.

```

:CALL
:      JSR      PC,TYPERR
:      RETURN

TYPERR:  MOVB   $STNM,$TMP0      ;SAVE THE TEST NUMBER
        SAVREG                    ;SAVE R0 - R5
        SUB    #4,R0            ;FORM TEST PC
        MOV   R0,$REG0          ;COPY R0-R5 IN $REG0-$REG5
        MOV   R1,$REG1
        MOV   R2,$REG2
        MOV   R3,$REG3
        MOV   R4,$REG4
        MOV   R5,$REG5
        MOVB  $ITEMB,R0        ;PICKUP ERROR ITEM NUMBER
        CMPEB #177,R0         ;SEE IF THIS ERROR CALL IS SPECIAL POWER FAIL CALL
        BNE   1$              ;BRANCH IF NOT

        CLR   R1
        MOV   $TESTN,PFTSTN    ;GET TEST NUMBER
        MOV   #PFECH,R0       ;MOVE POWER FAIL ERROR CALL TABLE TO R0
        BR    3$
1$:      MOV   R0,R1           ;AND COPY IT INTO R1
        DEC   R0              ;FORM INDEX FOR ERROR TABLE
        ASLB  R0
        ASLB  R0
        ASLB  R0
        BCC   2$              ;IS ERROR > 37?
        ADD   #ITEM41-$ERRTB,R0 ;YES--FORM OFFSET
        ADD   #ERRTB,R0       ;FORM ADDRESS
2$:      MOV   (R0)+,4$        ;GET ERROR MESSAGE (EM) POINTER
3$:      BEQ   9$              ;BRANCH IF THERE ISN'T ONE
        JSR   PC,INCEC        ;INCREMENT ERROR COUNT
        TYPE  ,$CRLF          ;'CARRIAGE RETURN - LINE FEED

        .WORD 0                ;'EM' POINTER GOES HERE
4$:      SUB   #41,R1          ;SPECIAL ERROR ITEM NUMBER?
        BMI   9$              ;NO--BRANCH
        MOV   SVSTAT,R1       ;GET STATUS/ERROR INDICATOR
        ASLB  R1              ;STRIP 'DONE' BIT (BIT07)
        ASL   R1              ;STRIP 'ERROR' BIT (BIT15)
        MOV   #STATBL,R2     ;1ST ADDRESS ON STATUS MESSAGE POINTERS
        CLR   R3              ;CARRIAGE RETURN-LINE FEED SWITCH
        TYPE  ,65$           ;.TYPE ASCIZ STRING
        BR    64$           ;;GET OVER THE ASCIZ
        .ASCIZ / (/
        .:65$:
64$:
5$:      MOV   (R2)+,7$        ;MESSAGE POINTER
        ASL   R1              ;TYPE THIS MESSAGE?
        BCC   8$              ;NO--BRANCH
        COM   R3              ;YES--TYPE A 'CR' & 'LF'?
        BNE   6$              ;NO--BRANCH
        TYPE  ,$CRLF          ;YES
  
```

59	022502	104401		6\$:	TYPE			
60	022504	000000		7\$:	.WORD	0		;MESSAGE POINTER GOES HERE
61	022506	005701			TST	R1		;MORE TO TYPE?
62	022510	001403			BEQ	8\$;NO--BRANCH
63	022512	104401	050345		TYPE	,BLNKS2		;TYPE 2 SPACES
64	022516	000761			BR	5\$;LOOP
65	022520	001360		8\$:	BNE	5\$;BRANCH IF NOT FINISHED
66	022522	104401	022530		TYPE	,67\$;TYPE ASCIZ STRING
	022526	000401			BR	66\$;GET OVER THE ASCIZ
				::67\$:	.ASCIZ	/)/		
	022532			66\$:				
67	022532	012037	022546	9\$:	MOV	(R0)+,10\$;PICK 'IP DATA HEADER (DH) POINTER
68	022536	001404			BEQ	11\$;BRANCH IF NONE
69	022540	104401	001231		TYPE	,\$CRLF		;CARRIAGE RETURN-LINE FEED
70	022544	104401			TYPE			
71	022546	000000		10\$:	.WORD	0		;'DH' POINTER GOES HERE
72	022550	012001		11\$:	MOV	(R0)+,R1		;PICKUP DATA TABLE (DT) POINTER
73	022552	001450			BEQ	20\$;BRANCH IF NONE
74	022554	005005			CLR	R5		;SET INDENT SWITCH
75	022556	012000			MOV	(R0)+,R0		;DATA FORMAT (DF) POINTER
76	022560	012002			MOV	(R0)+,R2		;NUMBER OF DH'S TO TYPE
77	022562	001441			BEQ	19\$;BRANCH IF DH NUMBER IS 0
78	022564	005105			COM	R5		;NO INDENT
79	022566	104401	001231		TYPE	,\$CRLF		;CARRIAGE RETURN-LINE FEED
80	022572	112003		12\$:	MOVW	(R0)+,R3		;NUMBER OF DATA WORDS TO TYPE
81	022574	112004			MOVW	(R0)+,R4		;AND HOW TO TYPE THEM
82	022576	006004		13\$:	ROR	R4		;OCTAL OR DECIMAL?
83	022600	103403			BCS	14\$;DECIMAL--BRANCH
84	022602	013146			MOV	@(R1)+,-(SP)		;SAVE @(R1)+ FOR TYPEOUT
	022604	104402			TYPDC			;GO TYPE--OCTAL ASCII(ALL DIGITS)
85	022606	000402			BR	15\$		
86	022610			14\$:				
	022610	013146			MOV	@(R1)+,-(SP)		;SAVE @(R1)+ FOR TYPEOUT
	022612	104405			TYPD5			;GO TYPE--DECIMAL ASCII WITH SIGN
87	022614	005303		15\$:	DEC	R3		;MORE NUMBERS TO TYPE?
88	022616	001403			BEQ	16\$;NO--BRANCH
89	022620	104401	050345		TYPE	,BLNKS2		;TYPE 2 SPACES
90	022624	000764			BR	13\$;LOOP
91	022626	005302		16\$:	DEC	R2		;MORE DH'S?
92	022630	003421			BLE	20\$;NO--BRANCH
93	022632	104401	001231		TYPE	,\$CRLF		;YES--START A NEW LINE
94	022636	005105			COM	R5		;INDENT?
95	022640	001002			BNE	17\$;NO--BRANCH
96	022642	104401	050345		TYPE	,BLNKS2		;TYPE 2 SPACES
97	022646	012037	022654	17\$:	MOV	(R0)+,18\$;GET NEXT DH
98	022652	104401			TYPE			;AND TYPE IT
99	022654	000000		18\$:	.WORD	0		;DH POINTER GOES HERE
100	022656	104401	001231		TYPE	,\$CRLF		;CARRIAGE RETURN-LINE FEED
101	022662	005705			TST	R5		;INDENT?
102	022664	001342			BNE	12\$;NO--BRANCH
103	022666	104401	050345	19\$:	TYPE	,BLNKS2		;TYPE 2 SPACES
104	022672	000737			BR	12\$;LOOP
105	022674	104413		20\$:	RESREG			;RESTORE R0 - R5
106	022676	000207			RTS	PC		;RETURN
107	022700	022710	022772	023024	PFECH:	PFECH1,PFECH2,PFECH3,PFECH4		;WORDS DEFINING TABLES BELOW
108	022710	120	117	127	PFECH1:	.ASCIZ	?POWER MONITOR BIT IN CPU ERROR REGISTER FOUND SET?	
109	022772	124	105	123	PFECH2:	.ASCIZ	?TESTNO ERR PC CPUERREG?	

10												
11	023024	023040	001132	022256	PFECH3:	.EVEN						
12	023034	000001			PFECH4:	.WORD	1					
13	023036	003				.WORD	3					
14	023037	000				.BYTE	0					
15	023040	000000			PFTSTN:	.WORD	0					

MFTSTN,BERRPC,CPSAVE,0
 :NUMBER OF DATA HEADERS
 :NUMBER OF WORDS IN DATA TABLE
 :ALL 3 NUMBERS ARE OCTAL
 :CONTAINS TEST NUMBER FOR PF BIT ERROR

1

.SBT/L TYPE ROUTINE

*ROUTINE TO TYPE ASCIZ MESSAGE. MESSAGE MUST TERMINATE WITH A 0 BYTE.
*THE ROUTINE WILL INSERT A NUMBER OF NULL CHARACTERS AFTER A LINE FEED.
*NOTE1: \$NULL CONTAINS THE CHARACTER TO BE USED AS THE FILLER CHARACTER.
*NOTE2: \$FILLS CONTAINS THE NUMBER OF FILLER CHARACTERS REQUIRED.
*NOTE3: \$FILLC CONTAINS THE CHARACTER TO FILL AFTER.
*

*CALL:
*1) USING A TRAP INSTRUCTION
* TYPE ,MESADR ;:MESADR IS FIRST ADDRESS OF AN ASCIZ STRING
*OR
* TYPE
* MESADR
*

```
023042 105737 001173 $TYPE: TSTB $TPFLG ;:IS THERE A TERMINAL?  
023046 100002 BPL 1$ ;:BR IF YES  
023050 000000 HALT ;:HALT HERE IF NO TERMINAL  
023052 000430 BR 3$ ;:LEAVE  
023054 010046 1$: MOV R0,-(SP) ;:SAVE R0  
023056 017600 000002 MOV @2(SP),R0 ;:GET ADDRESS OF ASCIZ STRING  
023062 122737 000001 001254 CMPB #APTENV,$ENV ;:RUNNING IN APT MODE  
023070 001011 BNE 62$ ;:NO,GO CHECK FOR APT CONSOLE  
023072 132737 000100 001255 BITB #APTSPOOL,$ENVM ;:SPOOL MESSAGE TO APT  
023100 001405 BEQ 62$ ;:NO,GO CHECK FOR CONSOLE  
023102 010037 023112 MOV R0,61$ ;:SETUP MESSAGE ADDRESS FOR APT  
023106 004737 026756 JSR PC,$ATY3 ;:SPOOL MESSAGE TO APT  
023112 000000 61$: .WORD 0 ;:MESSAGE ADDRESS  
023114 132737 000040 001255 62$: BITB #APTCSUP,$ENVM ;:APT CONSOLE SUPPRESSED  
023122 001003 BNE 60$ ;:YES,SKIP TYPE OUT  
023124 112046 2$: MOVB (R0)+,-(SP) ;:PUSH CHARACTER TO BE TYPED ONTO STACK  
023126 001005 BNE 4$ ;:BR IF IT ISN'T THE TERMINATOR  
023130 005726 TST (SP)+ ;:IF TERMINATOR POP IT OFF THE STACK  
023132 012600 60$: MOV (SP)+,R0 ;:RESTORE R0  
023134 062716 000002 3$: ADD #2,(SP) ;:ADJUST RETURN PC  
023140 000002 RTI ;:RETURN  
023142 122716 000011 4$: CMPB #HT,(SP) ;:BRANCH IF <HT>  
023146 001430 BEQ 8$  
023150 122716 000200 CMPB #CRLF,(SP) ;:BRANCH IF NOT <CRLF>  
023154 001006 BNE 5$  
023156 005726 TST (SP)+ ;:POP <CR><LF> EQUIV  
023160 104401 TYPE ;:TYPE A CR AND LF  
023162 001231 $CRLF  
023164 105037 023372 CLRB $CHARCNT ;:CLEAR CHARACTER COUNT  
023170 000755 BR 2$ ;:GET NEXT CHARACTER  
023172 004737 023254 5$: JSR PC,$TYPEC ;:GO TYPE THIS CHARACTER  
023176 123726 001172 6$: CMPB $FILLC,(SP)+ ;:IS IT TIME FOR FILLER CHARS.?  
023202 001350 BNE 2$ ;:IF NO GO GET NEXT CHAR.  
023204 013746 001170 MOV $NULL,-(SP) ;:GET # OF FILLER CHARS. NEEDED  
 ;:AND THE NULL CHAR.  
023210 105366 000001 7$: DECB 1(SP) ;:DOES A NULL NEED TO BE TYPED?  
023214 002770 BLT 6$ ;:BR IF NO--GO POP THE NULL OFF OF STACK  
023216 004737 023254 JSR PC,$TYPEC ;:GO TYPE A NULL  
023222 105337 023372 DECB $CHARCNT ;:DO NOT COUNT AS A COUNT  
023226 000770 BR 7$ ;:LOOP
```

:HORIZONTAL TAB PROCESSOR

```

023230 112716 000040      8$:  MOVB  #' (SP)      ;; REPLACE TAB WITH SPACE
023234 004737 023254      9$:  JSR   PC,$TYPEC      ;; TYPE A SPACE
023240 132737 000007 023372  BITB  #7,$CHARCNT      ;; BRANCH IF NOT AT
023246 001372           BNE   9$          ;; TAB STOP
023250 005726           TST   (SP)+        ;; POP SPACE OFF STACK
023252 000724           BR    2$          ;; GET NEXT CHARACTER
023254           $TYPEC:
023254 105777 155700      TSTB  @STKS          ;; CHAR IN KYBD BUFFER?
023260 100022           BPL   10$          ;; BR IF NOT
023262 017746 155674      MOV   @STKB,-(SP)      ;; GET CHAR
023266 042716 177600      BIC   #177600,(SP)    ;; STRIP EXTRANEIOUS BITS
023272 122716 000023      CMPB  #$XOFF,(SP)    ;; WAS CHAR XOFF
023276 001012           BNE   102$         ;; BR IF NOT
023300           101$:
023300 105777 155654      TSTB  @STKS          ;; WAIT FOR CHAR
023304 100375           BPL   101$         ;;
023306 117716 155650      MOVB  @STKB,(SP)      ;; GET CHAR
023312 042716 177600      BIC   #177600,(SP)    ;; STRIP IT
023316 122716 000021      CMPB  #$XON,(SP)     ;; WAS IT XON?
023322 001366           BNE   101$         ;; BR IF NOT
023324           102$:
023324 005726           TST   (SP)+        ;; FIX STACK
023326           10$:
023326 105777 155632      TSTB  @STPS          ;; WAIT UNTIL PRINTER IS READY
023332 100375           BPL   10$          ;;
023334 116677 000002 155624  MOVB  2(SP),@STPB     ;; LOAD CHAR TO BE TYPED INTO DATA REG.
023342 122766 000015 000002  CMPB  #CR,2(SP)      ;; IS CHARACTER A CARRIAGE RETURN?
023350 001003           BNE   1$          ;; BRANCH IF NO
023352 105037 023372      CLRB  $CHARCNT      ;; YES--CLEAR CHARACTER COUNT
023356 000406           BR    $TYPEX      ;; EXIT
023360 122766 000012 000002 1$:  CMPB  #LF,2(SP)      ;; IS CHARACTER A LINE FEED?
023366 001402           BEQ   $TYPEX      ;; BRANCH IF YES
023370 105227           INCB  (PC)+        ;; COUNT THE CHARACTER
023372 000000      $CHARCNT: .WORD 0 ;; CHARACTER COUNT STORAGE
023374 000207      $TYPEX: RTS      PC
  
```

.SBITL BINARY TO OCTAL (ASCII) AND TYPE

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 6-DIGIT
*OCTAL (ASCII) NUMBER AND TYPE IT.
*$TYPOS---ENTER HERE TO SETUP SUPPRESS ZEROS AND NUMBER OF DIGITS TO TYPE
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOS    ;;CALL FOR TYPEOUT
*      .BYTE   N              ;;N=1 TO 6 FOR NUMBER OF DIGITS TO TYPE
*      .BYTE   M              ;;M=1 OR 0
*                               ;;1=TYPE LEADING ZEROS
*                               ;;0=SUPPRESS LEADING ZEROS
*
*$TYPON---ENTER HERE TO TYPE OUT WITH THE SAME PARAMETERS AS THE LAST
*$TYPOS OR $TYPOC
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPON    ;;CALL FOR TYPEOUT
*
*$TYPOC---ENTER HERE FOR TYPEOUT OF A 16 BIT NUMBER
*CALL:
*      MOV      NUM,-(SP)      ;;NUMBER TO BE TYPED
*      TYPOC    ;;CALL FOR TYPEOUT
    
```

```

023376 017646 000000
023402 116637 000001 023621
023410 112637 023623
023414 062716 000002
023420 000406
023422 112737 000001 023621
023430 112737 000006 023623
023436 112737 000005 023620
023444 010346
023446 010446
023450 010546
023452 113704 023623
023456 005404
023460 062704 000006
023464 110437 023622
023470 113704 023621
023474 016605 000012
023500 005003
023502 006105 1$:
023504 000404 BR 3$
023506 006105 2$:
023510 006105 ROL R5
023512 006105 ROL R5
023514 010503 MOV R5,R3
023516 006103 3$:
023520 105337 023622 DECB $OMODE
023524 100016 BPL 7$
023526 042703 177770 BIC #177770,R3
023532 001002 BNE 4$
023534 005704 TST R4
023536 001403 BEQ 5$
023540 005204 4$: INC R4
    
```

```

$TYPOS: MOV @ (SP),-(SP) ;;PICKUP THE MODE
MOV 1(SP),$OFILL ;;LOAD ZERO FILL SWITCH
MOV (SP)+,$OMODE+1 ;;NUMBER OF DIGITS TO TYPE
ADD #2,(SP) ;;ADJUST RETURN ADDRESS
BR $TYPON
$TYPOC: MOV #1,$OFILL ;;SET THE ZERO FILL SWITCH
MOV #6,$OMODE+1 ;;SET FOR SIX(6) DIGITS
$TYPON: MOV #5,$OCNT ;;SET THE ITERATION COUNT
MOV R3,-(SP) ;;SAVE R3
MOV R4,-(SP) ;;SAVE R4
MOV R5,-(SP) ;;SAVE R5
MOV $OMODE+1,R4 ;;GET THE NUMBER OF DIGITS TO TYPE
NEG R4
ADD #6,R4 ;;SUBTRACT IT FOR MAX. ALLOWED
MOV R4,$OMODE ;;SAVE IT FOR USE
MOV $OFILL,R4 ;;GET THE ZERO FILL SWITCH
MOV 12(SP),R5 ;;PICKUP THE INPUT NUMBER
CLR R3 ;;CLEAR THE OUTPUT WORD
ROL R5 ;;ROTATE MSB INTO 'C'
BR 3$ ;;GO DO MSB
ROL R5 ;;FORM THIS DIGIT
MOV R5,R3
ROL R3 ;;GET LSB OF THIS DIGIT
DECB $OMODE ;;TYPE THIS DIGIT?
BPL 7$ ;;BR IF NO
BIC #177770,R3 ;;GET RID OF JUNK
BNE 4$ ;;TEST FOR 0
TST R4 ;;SUPPRESS THIS 0?
BEQ 5$ ;;BR IF YES
INC R4 ;;DON'T SUPPRESS ANYMORE 0'S
    
```

023542	052703	000060		BIS	#'0,R3	::MAKE THIS DIGIT ASCII
023546	052703	000040	5\$:	BIS	#',R3	::MAKE ASCII IF NOT ALREADY
023552	110337	023616		MOVB	R3,8\$::SAVE FOR TYPING
023556	104401	023616		TYPE	8\$::GO TYPE THIS DIGIT
023562	105337	023620	7\$:	DECB	\$OCNT	::COUNT BY 1
023566	003347			BGT	2\$::BR IF MORE TO DO
023570	002402			SLT	6\$::BR IF DONE
023572	005204			INC	R4	::INSURE LAST DIGIT ISN'T A BLANK
023574	000744			BR	2\$::GO DO THE LAST DIGIT
023576	012605		6\$:	MOV	(SP)+,R5	::RESTORE R5
023600	012604			MOV	(SP)+,R4	::RESTORE R4
023602	012603			MOV	(SP)+,R3	::RESTORE R3
023604	016666	000002 000004		MOV	2(SP),4(SP)	::SET THE STACK FOR RETURNING
023612	012616			MOV	(SP)+,(SP)	
023614	000002			RTI		::RETURN
023616	000		8\$:	.BYTE	0	::STORAGE FOR ASCII DIGIT
023617	000			.BYTE	0	::TERMINATOR FOR TYPE ROUTINE
023620	000		\$OCNT:	.BYTE	0	::OCTAL DIGIT COUNTER
023621	000		\$OFILL:	.BYTE	0	::ZERO FILL SWITCH
023622	000000		\$OMODE:	.WORD	0	::NUMBER OF DIGITS TO TYPE

.SB*TL CONVERT BINARY TO DECIMAL AND TYPE ROUTINE

```

*****
*THIS ROUTINE IS USED TO CHANGE A 16-BIT BINARY NUMBER TO A 5-DIGIT
*SIGNED DECIMAL (ASCII) NUMBER AND TYPE IT. DEPENDING ON WHETHER THE
*NUMBER IS POSITIVE OR NEGATIVE A SPACE OR A MINUS SIGN WILL BE TYPED
*BEFORE THE FIRST DIGIT OF THE NUMBER. LEADING ZEROS WILL ALWAYS BE
*REPLACED WITH SPACES.
*CALL:
*      MOV      NUM,-(SP)      ;;PUT THE BINARY NUMBER ON THE STACK
*      TYPDS    ;;GO TO THE ROUTINE
  
```

```

023624
023624 010046
023626 010146
023630 010246
023632 010346
023634 010546
023636 012746 020200
023642 016605 000020
023646 100004
023650 005405
023652 112766 000055 000001
023660 005000
023662 012703 024040
023666 112723 000040
023672 005002
023674 016001 024030
023700 160105
023702 002402
023704 005202
023706 000774
023710 060105
023712 005702
023714 001002
023716 105716
023720 100407
023722 106316
023724 103003
023726 116663 000001 177777
023734 052702 000060
023740 052702 000040
023744 110223
023746 005720
023750 020027 000010
023754 002746
023756 003002
023760 010502
023762 000764
023764 105726
023766 100003
023770 116663 177777 177776
023776 105013
024000 012605
024002 012603
024004 012602
024006 012601

$TYPDS:
MOV      R0,-(SP)      ;;PUSH R0 ON STACK
MOV      R1,-(SP)      ;;PUSH R1 ON STACK
MOV      R2,-(SP)      ;;PUSH R2 ON STACK
MOV      R3,-(SP)      ;;PUSH R3 ON STACK
MOV      R5,-(SP)      ;;PUSH R5 ON STACK
MOV      #20200,-(SP)  ;;SET BLANK SWITCH AND SIGN
MOV      20(SP),R5     ;;GET THE INPUT NUMBER
BPL      1$            ;;BR IF INPUT IS POS.
NEG      R5            ;;MAKE THE BINARY NUMBER POS.
MOVB     #'-,1(SP)     ;;MAKE THE ASCII NUMBER NEG.
CLR      R0            ;;ZERO THE CONSTANTS INDEX
MOV      #$DBLK,R3     ;;SETUP THE OUTPUT POINTER
MOVB     #' ,(R3)+     ;;SET THE FIRST CHARACTER TO A BLANK
2$:      CLR      R2            ;;CLEAR THE BCD NUMBER
MOV      $DTBL(R0),R1  ;;GET THE CONSTANT
3$:      SUB      R1,R5         ;;FORM THIS BCD DIGIT
BLT      4$            ;;BR IF DONE
INC      R2            ;;INCREASE THE BCD DIGIT BY .1
BR       3$
4$:      ADD      R1,R5         ;;ADD BACK THE CONSTANT
TST      R2            ;;CHECK IF BCD DIGIT-0
BNE      5$            ;;FALL THROUGH IF 0
TSTB     (SP)          ;;STILL DOING LEADING 0'S?
BMI      7$            ;;BR IF YES
5$:      ASLB     (SP)          ;;MSD?
BCC      6$            ;;BR IF NO
MOVB     1(SP),-1(R3)  ;;YES--SET THE SIGN
6$:      BIS      #'0,R2        ;;MAKE THE BCD DIGIT ASCII
7$:      BIS      #' ,R2        ;;MAKE IT A SPACE IF NOT ALREADY A DIGIT
MOVB     R2,(R3)+     ;;PUT THIS CHARACTER IN THE OUTPUT BUFFER
TST      (R0)+         ;;JUST INCREMENTING
CMP      R0,#10        ;;CHECK THE TABLE INDEX
BLT      2$            ;;GO DO THE NEXT DIGIT
BGT      8$            ;;GO TO EXIT
MOV      R5,R2         ;;GET THE LSD
BR       6$            ;;GO CHANGE TO ASCII
8$:      TSTB     (SP)+        ;;WAS THE LSD THE FIRST NON-ZERO?
BPL      9$            ;;BR IF NO
MOVB     -1(SP),-2(R3) ;;YES--SET THE SIGN FOR TYPING
9$:      CLRB     (R3)          ;;SET THE TERMINATOR
MOV      (SP)+,R5     ;;POP STACK INTO R5
MOV      (SP)+,R3     ;;POP STACK INTO R3
MOV      (SP)+,R2     ;;POP STACK INTO R2
MOV      (SP)+,R1     ;;POP STACK INTO R1
  
```

024010	012600			MOV	(SP)+,RC	::POP STACK INTO RO
024012	104401	024040		TYPE	, \$DBLK	::NOW TYPE THE NUMBER
024016	016666	000002	000004	MOV	2(SP),4(SP)	::ADJUST THE STACK
024024	012616			MOV	(SP)+,(SP)	
024026	000002			RTI		::RETURN TO USER
024030	023420			\$DTBL:	10000.	
024032	001750				1000.	
024034	000144				100.	
024036	000012				10.	
024040				\$DBLK:	.BLKW 4	

.SBTTL TTY INPUT ROUTINE

```

*****
:ENABL LSB
024050 000000 $TKCNT: .WORD 0 ;;NUMBER OF ITEMS IN QUEUE
024052 000000 $TKQIN: .WORD 0 ;;INPUT POINTER
024054 000000 $TKQOUT: .WORD 0 ;;OUTPUT POINTER
024056 024057 $TKQSRT: .BLKB 1 ;;TTY KEYBOARD QUEUE
$TKQEND=.
.EVEN

;*TK INITIALIZE ROUTINE
;*THIS ROUTINE WILL INITIALIZE THE TTY KEYBOARD INPUT QUEUE
;*SETUP THE INTERRUPT VECTOR AND TURN ON THE KEYBOARD INTERRUPT
:CALL:
:JSR PC,$TKINT
:RETURN

024060 005037 024050 $TKINT: CLR $TKCNT ;;CLEAR COUNT OF ITEMS IN QUEUE
024064 012737 024056 024052 MOV # $TKQSRT,$TKQIN ;;MOVE THE STARTING ADDRESS OF THE
024072 013737 024052 024054 MOV $TKQIN,$TKQOUT ;;QUEUE INTO THE INPUT & OUTPUT POINTERS.
024100 012737 024130 000060 MOV # $TKSRV,@ $TKVEC ;;INITIALIZE THE KEYBOARD VECTOR
024106 012737 000200 000062 MOV #200,@ $TKVEC+2 ;;'BR' LEVEL 4
024114 005777 155042 TST @ $TKB ;;CLEAR DONE FLAG
024120 012777 000100 155032 MOV #100,@ $TKS ;;ENABLE TTY KEYBOARD INTERRUPT
024126 000207 RTS PC ;;RETURN TO CALLER

;*TK SERVICE ROUTINE
;*THIS ROUTINE WILL SERVICE THE TTY KEYBOARD INTERRUPT
;*BY READING THE CHARACTER FROM THE INPUT BUFFER AND PUTTING
;*IT IN THE QUEUE.
;*IF THE CHARACTER IS A 'CONTROL-C' (^C) $TKINT IS CALLED AND
;*UPON RETURN EXIT IS MADE TO THE 'CONTROL-C' RESTART ADDRESS (SHUT)
:
024130 117746 155026 $TKSRV: MOVB @ $TKB,-(SP) ;;PICKUP THE CHARACTER
024134 042716 177600 BIL #^C177,(SP) ;;STRIP THE JUNK
024140 021627 000021 CMP (SP),#$XON ;;IS IT A RANDOM XON?
024144 001002 BNE 30$ ;;BRANCH IF NO
024146 005726 TST (SP)+ ;;CLEAN RANDOM XON OFF STACK
024150 000002 RTI ;;RETURN
024152
30$:
024152 021627 000003 CMP (SP),#3 ;;IS IT A CONTROL C?
024156 001007 BNE 1$ ;;BRANCH IF NO
024160 104401 025272 TYPE , $CNTLC ;;TYPE A CONTROL-C (^C)
024164 004737 024060 JSR PC,$TKINT ;;INIT THE KEYBOARD
024170 005726 TST (SP)+ ;;CLEAN UP STACK
024172 000137 025334 JMP SHUT ;;CONTROL C RESTART
024176 021627 000007 1$: CMP (SP),#7 ;;IS IT A CONTROL G?
024202 001004 BNE 2$ ;;BRANCH IF NO
024204 022737 000176 001154 CMP #SWREG,SWR ;;IS SOFT-SWR SELECTED?
024212 001500 BEQ 6$ ;;GO TO SWR CHANGE

024214
024214 022737 000001 024050 2$: CMP #1,$TKCNT ;;IS THE QUEUE FULL?
024222 001004 BNE 'T ;;BRANCH IF NO
024224 104401 001224 TYPE , $BELL ;;RING THE TTY BELL

```



```

024462 104401 025322          TYPE      , $MNEW          ;; PROMPT FOR NEW SWR
024466 005046          19$: CLR      -(SP)          ;; CLEAR COUNTER
024470 005046          CLR      -(SP)          ;; THE NEW SWR
024472 105777 154462      7$: TSTB   @ $TKS          ;; CHAR THERE?
024476 100375          BPL      7$           ;; IF NOT TRY AGAIN

024500 117746 154456      MOVB   @ $TKB, -(SP)      ;; PICK UP CHAR
024504 042716 177600      BIC    #^C177, (SP)      ;; MAKE IT 7-BIT ASCII

024510 021627 000003      CMP     (SP), #3          ;; IS IT A CONTROL-C?
024514 001015          BNE     9$              ;; BRANCH IF NOT
024516 104401 025272      TYPE   , $CNTIC         ;; YES, ECHO CONTROL-C (^C)
024522 062706 000006      ADD    #6, SP           ;; CLEAN UP STACK
024526 123727 001151 000001 CMPB   $INTAG, #1        ;; REENABLE TTY KEYBOARD INTERRUPTS?
024534 001003          BNE     8$              ;; BRANCH IF NO
024536 012777 000000 154414 MOV    #100, @ $TKS      ;; ALLOW TTY KEYBOARD INTERRUPTS
024544 000137 025334      8$: JMP    SHUT          ;; CONTROL-C RESTART

024550 021627 000025      9$: CMP     (SP), #25         ;; IS IT A CONTROL-U?
024554 001005          BNE     10$             ;; BRANCH IF NOT
024556 104401 025277      TYPE   , $CNTLU        ;; YES, ECHO CONTROL-U (^U)
024562 062706 000006      20$: ADD    #6, SP           ;; IGNORE PREVIOUS INPUT
024566 000737          BR     19$             ;; LET'S TRY IT AGAIN

024570 021627 000015      10$: CMP     (SP), #15         ;; IS IT A <CR>?
024574 001022          BNE     16$             ;; BRANCH IF NO
024576 005766 000004      TST    4(SP)           ;; YES, IS IT THE FIRST CHAR?
024602 001403          BEQ    11$             ;; BRANCH IF YES
024604 016677 000002 154342 MOV    2(SP), @ $SWR     ;; SAVE NEW SWR
024612 062706 000006      11$: ADD    #6, SP           ;; CLEAN UP STACK
024616 104401 001231      14$: TYPE   , $CRLF         ;; ECHO <CR> AND <LF>
024622 123727 001151 000001 CMPB   $INTAG, #1        ;; RE-ENABLE TTY KBD INTERRUPTS?
024630 001003          BNE     15$             ;; BRANCH IF NOT
024632 012777 000100 154320 MOV    #100, @ $TKS     ;; RE-ENABLE TTY KBD INTERRUPTS
024640 000002          RTI                    ;; RETURN
024642 004737 023254      15$: JSR    PC, $TYPEC        ;; ECHO CHAR
024646 021627 000060      16$: CMP     (SP), #60         ;; CHAR < 0?
024652 002420          BLT    18$             ;; BRANCH IF YES
024654 021627 000067      CMP     (SP), #67         ;; CHAR > 7?
024660 003015          BGT    18$             ;; BRANCH IF YES
024662 042726 000060      BIC    #60, (SP)+        ;; STRIP-OFF ASCII
024666 005766 000002      TST    2(SP)           ;; IS THIS THE FIRST CHAR
024672 001403          BEQ    17$             ;; BRANCH IF YES
024674 006316          ASL    (SP)            ;; NO, SHIFT PRESENT
024676 006316          ASL    (SP)            ;; CHAR OVER TO MAKE
024700 006316          ASL    (SP)            ;; ROOM FOR NEW ONE.
024702 005266 000002      17$: INC    2(SP)           ;; KEEP COUNT OF CHAR
024706 056616 177776      BIS    -2(SP), (SP)     ;; SET IN NEW CHAR
024712 000667          BR     7$             ;; GET THE NEXT ONE
024714 104401 001230      18$: TYPE   , $QUES         ;; TYPE ?<CR><LF>
024720 000720          BR     20$           ;; SIMULATE CONTROL-U
.DSABL LSB

```

;;*****

;;THIS ROUTINE WILL INPUT A SINGLE CHARACTER FROM THE TTY

```

*CALL:
*      RDCHR          ;;GET A CHARACTER FROM THE QUEUE
*      RETURN HERE   ;;CHARACTER IS ON THE STACK
*                  ;;WITH PARITY BIT STRIPPED OFF
  
```

```

024722 011646          SRDCHR: MOV    (SP),-(SP)    ;;PUSH DOWN THE PC AND
024724 016666 000004 000002 MOV    4(SP),2(SP)    ;;THE PS
024732 005066 000004          CLR    4(SP)          ;;GET READY FOR A CHARACTER
024736 005046          CLR    -(SP)         ;;PUT NEW PS ON STACK
024740 012746 024746          MOV    #64$,-(SP)    ;;PUT NEW PC ON STACK
024744 000002          RTI          ;;POP NEW PC AND PS
024746          64$:
024746 005737 024050 1$:      TST    $TKCNT      ;;WAIT ON A CHARACTER
024752 001775          BEQ    1$
024754 005337 024050          DEC    $TKCNT      ;;DECREMENT THE COUNTER
024760 117766 177070 000004 MOVVB  @STKQOUT,4(SP)  ;;GET ONE CHARACTER
024766 005237 024054          INC    $TKQOUT    ;;UPDATE THE POINTER
024772 023727 024054 024057 CMP    $TKQOUT,#$TKQEND ;;DID IT GO OFF OF THE END?
025000 001003          BNE    2$          ;;BRANCH IF NO
025002 012737 024056 024054 MOV    #$TKQSRST,$TKQOUT ;;RESET THE POINTER
025010 000002          RTI          ;;RETURN
  
```

 ;;THIS ROUTINE WILL INPUT A STRING FROM THE TTY

```

*CALL:
*      RDLIN         ;;INPUT A STRING FROM THE TTY
*      RETURN HERE   ;;ADDRESS OF FIRST CHARACTER WILL BE ON THE STACK
*                  ;;TERMINATOR WILL BE A BYTE OF ALL 0'S
  
```

```

025012 010346          SRDLIN: MOV    R3,-(SP)    ;;SAVE R3
025014 005046          CLR    -(SP)         ;;CLEAR THE RUBOUT KEY
025016 012703 025246 1$:      MOV    #$TTYIN,R3    ;;GET ADDRESS
025022 022703 025272 2$:      CMP    #$TTYIN+20.,R3  ;;BUFFER FULL?
025026 101456          BLOS   4$          ;;BR IF YES
025030 104410          RDCHR          ;;GO READ ONE CHARACTER FROM THE TTY
025032 112613          MOVVB (SP)+,(R3)    ;;GET CHARACTER
025034 122713 000177 10$:     CMPB  #177,(R3)    ;;IS IT A RUBOUT
025040 001022          BNE    5$          ;;BR IF NO
025042 005716          TST    (SP)         ;;IS THIS THE FIRST RUBOUT?
025044 001007          BNE    6$          ;;BR IF NO
025046 112737 000134 025244 MOVVB  #'\",9$    ;;TYPE A BACK SLASH
025054 104401 025244          TYPE  ,9$
025060 012716 177777          MOV    #-1,(SP)    ;;SET THE RUBOUT KEY
025064 005303 6$:          DEC    R3          ;;BACKUP BY ONE
025066 020327 025246          CMP    R3,$$TTYIN    ;;STACK EMPTY?
025072 103434          BLO   4$          ;;BR IF YES
025074 111337 025244          MOVVB (R3),9$    ;;SETUP TO TYPEOUT THE DELETED CHAR.
025100 104401 025244          TYPE  ,9$    ;;GO TYPE
025104 000746          BR    2$          ;;GO READ ANOTHER CHAR.
025106 005716          5$:      TST    (SP)         ;;RUBOUT KEY SET?
025110 001406          BEQ    7$          ;;BR IF NO
025112 112737 000134 025244 MOVVB  #'\",9$    ;;TYPE A BACK SLASH
025120 104401 025244          TYPE  ,9$
025124 005016          CLR    (SP)         ;;CLEAR THE RUBOUT KEY
025126 122713 000025 7$:      CMPB  #25,(R3)    ;;IS CHARACTER A CTRL U?
025132 001003          BNE    8$          ;;BR IF NO
  
```

```

025134 104401 025277          TYPE      ,SCNTLU      ;;TYPE A CONTROL 'U'
025140 000726          BR          1$          ;;GO START OVER
025142 122713 000022      8$:      CMPB      #22,(R3)      ;;IS CHARACTER A 'R' ?
025146 001011          BNE          3$          ;;BRANCH IF NO
025150 105013          CLRB      (R3)          ;;CLEAR THE CHARACTER
025152 104401 001231          TYPE      ,$CRLF      ;;TYPE A 'CR' & 'LF'
025156 104401 025246          TYPE      , $TTYIN      ;;TYPE THE INPUT STRING
025162 000717          BR          2$          ;;GO PICKUP ANOTHER CHACTER
025164 104401 001230      4$:      TYPE      , $QUES      ;;TYPE A '?'
025170 000712          BR          1$          ;;CLEAR THE BUFFER AND LOOP
025172 111337 025244      3$:      MOVB      (R3),9$          ;;ECHO THE CHARACTER
025176 104401 025244          TYPE      ,9$
025202 122723 000015          CMPB      #15,(R3)+      ;;CHECK FOR RETURN
025206 001305          BNE          2$          ;;LOOP IF NOT RETURN
025210 105063 177777          CLRB      -1(R3)          ;;CLEAR RETURN (THE 15)
025214 104401 001232          TYPE      , $LF      ;;TYPE A LINE FEED
025220 005726          TST      (SP)+      ;;CLEAN RUBOUT KEY FROM THE STACK
025222 012603          MOV      (SP)+,R3      ;;RESTORE R3
025224 011646          MOV      (SP),-(SP)      ;;ADJUST THE STACK AND PUT ADDRESS OF THE
025226 016666 000004 000002      MOV      4(SP),2(SP)      ;; FIRST ASCII CHARACTER ON IT
025234 012766 025246 000004      MOV      # $TTYIN,4(SP)
025242 000002          RTI          ;;RETURN
025244 000          9$:      .BYTE      0          ;;STORAGE FOR ASCII CHAR. TO TYPE
025245 000          .BYTE      0          ;;TERMINATOR
025246          .BLKB      20.          ;;RESERVE 20. BYTES FOR TTY INPUT
025272 136 103 015 $TTYIN: .ASCIZ /^C/<15><12> ;;CONTROL 'C'
025277 136 125 015 $CNTLU: .ASCIZ /^U/<15><12> ;;CONTROL 'U'
025304 136 107 015 $CNTLG: .ASCIZ /^G/<15><12> ;;CONTROL 'G'
025311 015 012 123 $MSWR: .ASCIZ <15><12>/SWR = /
025322 040 040 116 $MNEW: .ASCIZ / NEW = /
          .EVEN

2
3 025334 005737 000042      SHUT:   TST      @#42          ;ANY MONITOR PRESENT ?
4 025340 001002          BNE      1$          ;BR IF YES
5 025342 000137 004712          JMP      START2      ;GO TO 'START2'
6 025346 005037 001330      1$:    CIR      DRVSEL      ;FUDGE NO DRIVES SELECTED
7 025352 000137 021334          JMP      $EOP        ;RETURN CONTROL TO MONITOR
  
```

1

.SBTTL SCOPE HANDLER ROUTINE

```

*****
*THIS ROUTINE CONTROLS THE LOOPING OF SUBTESTS. IT WILL INCREMENT
*AND LOAD THE TEST NUMBER($STNM) INTO THE DISPLAY REG.(DISPLAY<7:0>)
*AND LOAD THE ERROR FLAG ($ERFLG) INTO DISPLAY<15:08>
*THE SWITCH OPTIONS PROVIDED BY THIS ROUTINE ARE:
*SW14=1      LOOP ON TEST
*SW11=1      INHIBIT ITERATIONS
*SW09=1      LOOP ON ERROR
*CALL
*          SCOPE          ;;SCOPE=IOT

025356          $SCOPE:
025356 104407          CKSWR          ;;TEST FOR CHANGE IN SOFT-SWR
025360 032777 040000 153566 1$: BIT #BIT14,@SWR          ;;LOOP ON PRESENT TEST?
025366 001402          BEQ 9$          ;;NO IF SW14=0.
025370 000137 025740          JMP $OVER          ;;JUMP OVER SCOPE ROUTINE
025374          9$:
025374 000416          :*****START OF CODE FOR THE XOR TESTER*****
          $XTSTR: BR 6$          ;;IF RUNNING ON THE 'XOR' TESTER CHANGE
          ;;THIS INSTRUCTION TO A 'NOP' (NOP=240)
025376 013746 000004          MOV @WERRVEC,-(SP)          ;;SAVE THE CONTENTS OF THE ERROR VECTOR
025402 012737 025422 000004          MOV #5$,@WERRVEC          ;;SET FOR TIMEOUT
025410 005737 177060          TST @#177060          ;;TIME OUT ON XOR?
025414 012637 000004          MOV (SP)+,@WERRVEC          ;;RESTORE THE ERROR VECTOR
025420 000531          BR $SVLAD          ;;GO TO THE NEXT TEST
025422 022626          5$: CMP (SP)+,(SP)+          ;;CLEAR THE STACK AFTER A TIME OUT
025424 012637 000004          MOV (SP)+,@WERRVEC          ;;RESTORE THE ERROR VECTOR
025430 000474          BR 7$          ;;LOOP ON THE PRESENT TEST
025432          6$:*****END OF CODE FOR THE XOR TESTER*****
025432 105737 001117          2$: TSTB $ERFLG          ;;HAS AN ERROR OCCURRED?
025436 001502          BEQ 3$          ;;BR IF NO
025440 022737 177777 022256          CMP #-1,CPSAVE          ;;SEE IF TIMEOUT WAS PREVIOUSLY RECORDED
025446 001455          BEQ 2003$          ;;KICK AROUND ROUTINE IF SO
025450 013746 000004          MOV ERRVEC,-(SP)          ;;SAVE CONTENTS OF ERROR VECTOR
025454 012737 025472 000004          MOV #2000$,ERRVEC          ;;SETUP 'TRAP' RETURN ADDRESS
025462 013737 177766 022256          MOV 177766,CPSAVE          ;;MOVE CPU ERROR REGISTER TO CPSAVE FOR TEST
025470 000406          BR 2001$
025472 012737 177777 022256 2000$: MOV #-1,CPSAVE          ;;SET CPU ERROR REGISTER TIMEOUT INDICATOR
025500 012716 025506          MOV #2001$,(SP)          ;;SETUP RETURN ADDRESS
025504 000002          RTI
025506 012637 000004          2001$: MOV (SP)+,ERRVEC          ;;RESTORE CONTENTS OF ERROR VECTOR

025512 022737 177777 022256 2002$: CMP #-1,CPSAVE          ;;SEE IF CPSAVE HAS CPU ERR REG TIMEOUT INDICATION
025520 001430          BEQ 2003$          ;;BRANCH IF SO
025522 032737 000001 022256          BIT #BIT00,CPSAVE          ;;SEE IF THE POWER MONITOR BIT IS ON
025530 001424          BEQ 2003$          ;;BRANCH TO CONTINUE ROUTINE IF CLEAR
025532 042737 000001 177766          BIC #BIT00,177766          ;;CLEAR THE BIT FOUND TO BE SET
025540 013746 001154          MOV SWR,-(SP)          ;;SAVE SWR ADDRESS
025544 017646 000000          MOV @ (SP),-(SP)          ;;SAVE SWR VALUE
025550 012737 000176 001154          MOV #176,SWR          ;;GET SOFTWARE SWR ADDRESS
025556 011677 153372          MOV (SP),@SWR          ;;GET CURRENT SWR VALUE
025562 042777 001000 153364          BIC #BIT09,@SWR          ;;DON'T ALLOW LOOP ON ERROR ON THIS ERROR
025570 104177          EMT 177          ;;CALL SPECIAL POWER FAIL BIT ERROR CALL
025572 012676 000000          MOV (SP)+,@(SP)          ;;RESTORE SWR TO ORIGINAL VALUE
025576 012637 001154          MOV (SP)+,SWR          ;;RESTORE SWR ADDRESS

```

```

025602          123737 001131 001117 20038:  CMPB  $ERMAX,$ERFLG  ;;MAX. ERRORS FOR THIS TEST OCCURRED?
025610          101015          BHI   3$              ;;BR IF NO
025612          032777 001000 153334      BIT   #BIT09,@SWR    ;;LOOP ON ERROR?
025620          001404          BEQ   4$              ;;BR IF NO
025622          013737 001124 001122 7$:  MOV   $LPERR,$LPADR  ;;SET LOOP ADDRESS TO LAST SCOPE
025630          000443          BR    $OVER          ;;
025632          105037 001117          CLR  $ERFLG         ;;ZERO THE ERROR FLAG
025636          005037 001220          CLR  $TIMES        ;;(CLEAR THE NUMBER OF ITERATIONS TO MAKE
025642          000412          BR    1$           ;;ESCAPE TO THE NEXT TEST
025644          032777 004000 153302 3$:  BIT   #BIT11,@SWR   ;;INHIBIT ITERATIONS?
025652          001006          BNE  1$           ;;BR IF YES
025654          005237 001120          INC  $ICNT         ;;INCREMENT ITERATION COUNT
025660          023737 001220 001120      CMP   $TIMES,$ICNT  ;;CHECK THE NUMBER OF ITERATIONS MADE
025666          002024          BGE  $OVER        ;;BR IF MORE ITERATION REQUIRED
025670          012737 000001 001120 1$:  MOV   #1,$ICNT     ;;REINITIALIZE THE ITERATION COUNTER
025676          013737 025754 001220      MOV   $SMXCNT,$TIMES ;;SET NUMBER OF ITERATIONS TO DO
025704          105237 001116          INCB $STNM         ;;COUNT TEST NUMBERS
025710          113737 001116 001240      MOV  $STNM,$STESTN ;;SET TEST NUMBER IN APT MAILBOX
025716          011637 001122          MOV  (SP),$LPADR   ;;SAVE SCOPE LOOP ADDRESS
025722          011637 001124          MOV  (SP),$LPERR   ;;SAVE ERROR LOOP ADDRESS
025726          005037 001222          CLR  $ESCAPE       ;;CLEAR THE ESCAPE FROM ERROR ADDRESS
025732          112737 000001 001131 001131  MOV  #1,$ERMAX     ;;ONLY ALLOW ONE(1) ERROR ON NEXT TEST
025740          013777 001116 153210  $OVER: MOV  $STNM,@DISPLAY ;;DISPLAY TEST NUMBER
025746          013716 001122          MOV  $LPADR,(SP)  ;;FUDGE RETURN ADDRESS
025752          000002          RTI                ;;FIXES PS
025754          000001          SMXCNT: 1         ;;MAX. NUMBER OF ITERATIONS
    
```

.SBTTL SAVE AND RESTORE R0-R5 ROUTINES

```

:*****
:*SAVE R0-R5
:*CALL:
:* SAVREG
:*UPON RETURN FROM $SAVREG THE STACK WILL LOOK LIKE:
:*
:*TOP---(+16)
:* +2---(+18)
:* +4---R5
:* +6---R4
:* +8---R3
:*+10---R2
:*+12---R1
:*+14---R0
  
```

```

025756          $SAVREG:
025756 010046    MOV     R0,-(SP)      ;;PUSH R0 ON STACK
025760 010146    MOV     R1,-(SP)      ;;PUSH R1 ON STACK
025762 010246    MOV     R2,-(SP)      ;;PUSH R2 ON STACK
025764 010346    MOV     R3,-(SP)      ;;PUSH R3 ON STACK
025766 010446    MOV     R4,-(SP)      ;;PUSH R4 ON STACK
025770 010546    MOV     R5,-(SP)      ;;PUSH R5 ON STACK
025772 016646 000022  MOV     22(SP),-(SP)    ;;SAVE PS OF MAIN FLOW
025776 016646 000022  MOV     22(SP),-(SP)    ;;SAVE PC OF MAIN FLOW
026002 016646 000022  MOV     22(SP),-(SP)    ;;SAVE PS OF CALL
026006 016646 000022  MOV     22(SP),-(SP)    ;;SAVE PC OF CALL
026012 000002    RTI
  
```

```

:*RESTORE R0-R5
:*CALL:
:* RESREG
  
```

```

026014          $RESREG:
026014 012666 000022  MOV     (SP)+,22(SP)    ;;RESTORE PC OF CALL
026020 012666 000022  MOV     (SP)+,22(SP)    ;;RESTORE PS OF CALL
026024 012666 000022  MOV     (SP)+,22(SP)    ;;RESTORE PC OF MAIN FLOW
026030 012666 000022  MOV     (SP)+,22(SP)    ;;RESTORE PS OF MAIN FLOW
026034 012605    MOV     (SP)+,R5        ;;POP STACK INTO R5
026036 012604    MOV     (SP)+,R4        ;;POP STACK INTO R4
026040 012603    MOV     (SP)+,R3        ;;POP STACK INTO R3
026042 012602    MOV     (SP)+,R2        ;;POP STACK INTO R2
026044 012601    MOV     (SP)+,R1        ;;POP STACK INTO R1
026046 012600    MOV     (SP)+,R0        ;;POP STACK INTO R0
026050 000002    RTI
  
```

.SBTTL TRAP DECODER

```

:*****
:*THIS ROUTINE WILL PICKUP THE LOWER BYTE OF THE 'TRAP' INSTRUCTION
:*AND USE IT TO INDEX THROUGH THE TRAP TABLE FOR THE STARTING ADDRESS
:*OF THE DESIRED ROUTINE. THEN USING THE ADDRESS OBTAINED IT WILL
:*GO TO THAT ROUTINE.
  
```

```

026052 010046          $TRAP: MOV    RO,-(SP)      ;;SAVE R0
026054 016600 000002  MOV    2(SP),RO    ;;GET TRAP ADDRESS
026060 005740          TST    -(RO)        ;;BACKUP BY 2
026062 111000          MOVVB (RO),RO      ;;GET RIGHT BYTE OF TRAP
026064 006300          ASL   RO           ;;POSITION FOR INDEXING
026066 016000 026106  MOV    $TRPAD(RO),RO ;;INDEX TO TABLE
026072 000200          RTS     RO         ;;GO TO ROUTINE
  
```

::THIS IS USE TO HANDLE THE 'GETPRI' MACRO

```

026074 011646          $TRAP2: MOV   (SP),-(SP)  ;;MOVE THE PC DOWN
026076 016666 000004 000002 MOV   4(SP),2(SP)    ;;MOVE THE PSW DOWN
026104 000002          RTI                ;;RESTORE THE PSW
  
```

.SBTTL TRAP TABLE

```

:*THIS TABLE CONTAINS THE STARTING ADDRESSES OF THE ROUTINES CALLED
:*BY THE 'TRAP' INSTRUCTION.
  
```

		ROUTINE		

026106	026074	\$TRPAD: .WORD	\$TRAP2	
026110	023042	\$TYPE	::CALL=TYPE	TRAP+1(104401) TTY TYPEOUT ROUTINE
026112	023422	\$TYPOC	::CALL=TYPOC	TRAP+2(104402) TYPE OCTAL NUMBER (WITH LEADING ZEROS)
026114	023376	\$TYPOS	::CALL=TYPOS	TRAP+3(104403) TYPE OCTAL NUMBER (NO LEADING ZEROS)
026116	023436	\$TYPON	::CALL=TYPON	TRAP+4(104404) TYPE OCTAL NUMBER (AS PER LAST CALL)
026120	023624	\$TYPDS	::CALL=TYPDS	TRAP+5(104405) TYPE DECIMAL NUMBER (WITH SIGN)
026122	024450	\$GTSWR	::CALL=GTSWR	TRAP+6(104406) GET SOFT-SWR SETTING
026124	024360	\$CKSWR	::CALL=CKSWR	TRAP+7(104407) TEST FOR CHANGE IN SOFT-SWR
026126	024722	\$RDCHR	::CALL=RDCHR	TRAP+10(104410) TTY TYPEIN CHARACTER ROUTINE
026130	025012	\$RDLIN	::CALL=RDLIN	TRAP+11(104411) TTY TYPEIN STRING ROUTINE
026132	025756	\$SAVREG	::CALL=SAVREG	TRAP+12(104412) SAVE R0-R5 ROUTINE
026134	026014	\$RESREG	::CALL=RESREG	TRAP+13(104413) RESTORE R0-R5 ROUTINE

.SBTTL SINGLE LENGTH BINARY TO DECIMAL ASCII ROUTINE

 *THIS ROUTINE WILL CONVERT A 16-BIT UNSIGNED BINARY NUMBER TO AN
 *UNSIGNED DECIMAL ASCII NUMBER.

*CALL
 * MOV NUMBER,-(SP) ;;PUT BINARY NUMBER ON THE STACK
 * JSR PC,@#SSB2D ;;CALL
 * RETURN ;;ADDRESS OF THE 1ST ASCII CHAR.IS ON THE STACK

026136	016637	000002	026166	\$SB2D:	MOV	2(SP),1\$;;SAVE BINARY NUMBER
026144	012746	026166			MOV	#1\$,-(SP)	;;SET POINTER
026150	004737	026172			JSR	PC,@#SSB2D	;;CALL DOUBLE LENGTH CONVERT
026154	062716	000005			ADD	#5,(SP)	;;ONLY ALLOW FIVE CHARACTERS
026160	012666	000002			MOV	(SP)+,2(SP)	;;PICKUP POINTER
026164	000207				RTS	PC	;;RETURN
026166	000000	000000		1\$:	.WORD	0,0	

SBTTL DOUBLE LENGTH BINARY TO DECIMAL ASCII CONVERT ROUTINE

 *THIS ROUTINE WILL CONVERT A 32-BIT BINARY NUMBER TO AN UNSIGNED
 *DECIMAL (ASCII) NUMBER. THE SIGN OF THE BINARY NUMBER MUST BE
 *POSITIVE.
 *CALL

* MOV #PNTR,-(SP) ;; POINTER TO LOW WORD OF BINARY NUMBER
 * JSR PC,@#\$DB2D ;; THE FIRST ADDRESS OF ASCII
 * RETURN ;; IS ON THE STACK

026172	104412		\$DB2D:	SAVREG	;;SAVE REGISTERS
026174	016602	000002		MOV 2(SP),R2	;;PICKUP THE DATA POINTER
026200	012700	026352		MOV #\$DECVL,R0	;;GET ADDRESS OF '\$DECVL' STRING
026204	010066	000002		MOV R0,2(SP)	;;PUT ADDRESS OF ASCII STRING ON STACK
026210	012201			MOV (R2)+,R1	;;PICKUP THE BINARY NUMBER
026212	012202			MOV (R2)+,R2	
026214	012737	000012	026270	MOV #10,,4\$;;SET UP TO DO 10 CONVERSIONS
026222	012704	026302		MOV #\$TNPWR,R4	;;ADDRESS OF TEN POWER
026226	012705	026304		MOV #\$TNPWR+2,R5	
026232	005003		1\$:	CLR R3	;;CLEAR PARTIAL
026234	161401		2\$:	SUB (R4),R1	;;SUBTRACT TEN POWER
026236	005602			SBC R2	
026240	161502			SUB (R5),R2	
026242	002402			BLT 3\$;;BR IF TEN POWER TOO LARGE
026244	005203			INC R3	;;ADD 1 TO PARTIAL
026246	000772			BR 2\$;;LOOP
026250	062401		3\$:	ADD (R4)+,R1	;;RESTORE SUBTRACTED VALUE
026252	005502			ADC R2	
026254	062402			ADD (R4)+,R2	
026256	022525			CMR (R5)+,(R5)+	;;MOVE TO NEXT TEN POWER
026260	052703	000060		BIS #0,R3	;;CHANGE PARTIAL TO ASCII
026264	110320			MOVB R3,(R0)+	;;SAVE IT
026266	005327			DEC (PC)+	;;DONE?
026270	000000		4\$:	.WORD 0	
026272	001357			BNE 1\$;;BR IF NO
026274	105020			CLRB (R0)+	;;TERMINATOR
026276	104413			RESREG	;;RESTORE REGISTERS
026300	000207			RTS PC	;;RETURN
026302	145000		\$TNPWR:	145000	;;1.0E09
026304	035632			35632	
026306	160400			160400	;;1.0E08
026310	002765			2765	
026312	113200			113200	;;1.0E07
026314	000230			230	
026316	041100			041100	;;1.0E06
026320	000017			17	
026322	103240			103240	;;1.0E05
026324	000001			1	
026326	023420			23420	;;1.0E04
026330	000000			0	
026332	001750			1750	;;1.0E03
026334	000000			0	
026336	000144			144	;;1.0E02
026340	000000			0	

026342 000012
026344 000000
026346 000001
026350 000000
026352

12
0
1
0
\$DECL: .BLKB 12.

::1.0E01
::1.0E00
::RESERVE STORAGE FOR ASCII STRING

.SBTTL TYPE NUMERICAL ASCII STRING SUPPRESS LEADING ZEROS

```

*****
* THIS ROUTINE IS USED TO TYPE AN ASCII NUMBER SUPPRESSING THE
* LEADING NUMBERS.
* CALL
*   MOV    #NUMADR,-(SP)    ;; FIRST ADDRESS OF ASCII STRING
*   JSR    PC,@#$$SUPRS
  
```

026366	010046		\$\$SUPRS: MOV	RO,-(SP)	::SAVE R0	
026370	016600	000004		MOV	4(SP),R0	::PICKUP THE POINTER
026374	105710		1\$:	TSTB	(R0)	::TERMINATOR?
026376	001403			BEQ	2\$::BR IF YES
026400	122720	000060		CMPB	#'0',(R0)+	::IS THIS AN ASCII '0'?
026404	001773			BEQ	1\$::BR IF YES
026406	005300		2\$:	DEC	R0	::BACKUP BY '1'
026410	010037	026416		MOV	R0,3\$::SAVE FOR TYPING
026414	104401			TYPE		::GO TYPE
026416	000000		3\$:	WORD	0	::ASCII POINTER GOES HERE
026420	012600			MOV	(SP)+,R0	::RESTORE R0
026422	012616			MOV	(SP)+,(SP)	::RESTORE THE STACK
026424	000207			RTS	PC	::RETURN

.SBTTL RANDOM NUMBER GENERATOR ROUTINE

 *THIS ROUTINE IS A DOUBLE PRECISION PSEUDO RANDOM NUMBER GENERATOR
 *WITH A RANGE OF 0 TO 2(+33)-1.
 *CALL:

```

*CALL:      JSR      PC,$RAND      ;;CALL THE ROUTINE
*           RETURN                    ;;RETURN HERE THE RANDOM
*           ;;;NUMBER WILL BE IN
*           ;;;$HINUM,$LONUM
    
```

```

026426
026426 010046
026430 010146
026432 010246
026434 013700 026526
026440 013701 026524
026444 012702 177771
026450 006300
026452 006101
026454 005202
026456 001374
026460 063700 026526
026464 005501
026466 063701 026524
026472 062700 001057
026476 005501
026500 062701 047401
026504 010037 026526
026510 010137 026524
026514 012602
026516 012601
026520 012600
026522 000207
026524 176543
026526 123456
    
```

```

$RAND:
MOV      R0,-(SP)      ;;PUSH R0 ON STACK
MOV      R1,-(SP)      ;;PUSH R1 ON STACK
MOV      R2,-(SP)      ;;PUSH R2 ON STACK
MOV      $LONUM,R0     ;;SET R0 WITH LOW
MOV      $HINUM,R1     ;;SET R1 WITH HIGH
MOV      #-7,R2        ;;SET SHIFT COUNT
'S:      ASL      R0     ;;SHIFT R0 LEFT AND
          ROL      R1     ;;ROTATE CARRY INTO R1 AND
          INC      R2     ;;CHECK FOR DONE
          BNE     1$      ;;CONTINUE SHIFT LOOP
          ADD     $LONUM,R0 ;;ADD NUMBER TO MAKE X 129
          ADC     R1      ;;PROPOGATE CARRY
          ADD     $HINUM,R1 ;;ADD NUMBER TO MAKE X 129
          ADD     #1057,R0 ;;ADD LOW CONSTANT
          ADC     R1      ;;PROPOGATE CARRY
          ADD     #47401,R1 ;;ADD HIGH CONSTANT
          MOV     R0,$LONUM ;;SAVE R0
          MOV     R1,$HINUM ;;SAVE R1
          MOV     (SP)+,R2  ;;POP STACK INTO R2
          MOV     (SP)+,R1  ;;POP STACK INTO R1
          MOV     (SP)+,R0  ;;POP STACK INTO R0
          RTS      PC      ;;RETURN
$HINUM:  .WORD    176543
$LONUM:  .WORD    123456
    
```


026652	006101		6\$:	ROL	R1	:: QUOTIENT BIT ENTERS HERE
026654	005316			DEC	(SP)	:: DONE?
026656	001370			BNE	5\$:: BR IF NO
026660	005701			TST	R1	:: OVERFLOW?
026662	100005			BPL	8\$:: BR IF NO
026664	052766	000002 000014		BIS	#2,14(SP)	:: SET 'V' IN RETURN STATUS WORD
026672	005000			CLR	R0	:: SFT REMAINDER TO ALL ZEROS
026674	010001		7\$:	MOV	R0,R1	:: COPY REMAINDER INTO QUOTIENT
026676	005726		8\$:	TST	(SP)+	:: CLEAR COUNTER FROM STACK
026700	005716			TST	(SP)	:: REMAINDER SIGN CORRECTION NEEDED?
026702	002004			BGE	9\$:: BR IF NO
026704	005400			NEG	R0	:: NEGATE REMAINDER
026706	105066	000001		CLRB	1(SP)	:: CLEAR SIGN
026712	005316			DEC	(SP)	:: BUT DON'T FORGET QUOTIENT
026714	005726		9\$:	TST	(SP)+	:: QUOTIENT SIGN CORRECTION NEEDED?
026716	001401			BEQ	10\$:: BR IF NO
026720	005401			NEG	R1	:: NEGATE QUOTIENT
026722	010166	000020	10\$:	MOV	R1,20(SP)	:: RETURN QUOTIENT AND
026726	010066	000016		MOV	R0,16(SP)	:: REMAINDER TO USER
026732	012603			MOV	(SP)+,R3	:: POP STACK INTO R3
026734	012602			MOV	(SP)+,R2	:: POP STACK INTO R2
026736	012601			MOV	(SP)+,R1	:: POP STACK INTO R1
026740	012600			MOV	(SP)+,R0	:: POP STACK INTO R0
026742	012666	000002		MOV	(SP)+,2(SP)	:: SETUP TO RETURN CONDITION CODES
026746	000002			RTI		:: RETURN

.SBTTL APT COMMUNICATIONS ROUTINE

```

*****
026750 112737 000001 027214 $ATY1: MOVB #1,$FFLG ;;TO REPORT FATAL ERROR
026756 112737 000001 027212 $ATY3: MOVB #1,$MFLG ;;TO TYPE A MESSAGE
026764 000403 BR $ATYC
026766 112737 000001 027214 $ATY4: MOVB #1,$FFLG ;;TO ONLY REPORT FATAL ERROR
026774 $ATYC:
026774 010046 MOV R0,-(SP) ;;PUSH R0 ON STACK
026776 010146 MOV R1,-(SP) ;;PUSH R1 ON STACK
027000 105737 027212 TSTB $MFLG ;;SHOULD TYPE A MESSAGE?
027004 001450 BEQ 5$ ;;IF NOT: BR
027006 122737 000001 001254 CMPB #APTENV,$ENV ;;OPERATING UNDER APT?
027014 001031 BNE 3$ ;;IF NOT: BR
027016 132737 000100 001255 BITB #APTSPOOL,$ENVM ;;SHOULD SPOOL MESSAGES?
027024 001425 BEQ 3$ ;;IF NOT: BR
027026 017600 000004 MOV @4(SP),R0 ;;GET MESSAGE ADDR.
027032 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
027040 005737 001234 1$: TST $MSGTYPE ;;SEE IF DONE W/ LAST XMISSION?
027044 001375 BNE 1$ ;;IF NOT: WAIT
027046 010037 001250 MOV R0,$MSGAD ;;PUT ADDR IN MAILBOX
027052 105720 2$: TSTB (R0)+ ;;FIND END OF MESSAGE
027054 001376 BNE 2$
027056 163700 001250 SUB $MSGAD,R0 ;;SUB START OF MESSAGE
027062 006200 RO ;;GET MESSAGE LGTH IN WORDS
027064 010037 001252 MOV R0,$MSGGLT ;;PUT LENGTH IN MAILBOX
027070 012737 000004 001234 MOV #4,$MSGTYPE ;;TELL APT TO TAKE MSG.
027076 000413 BR 5$
027100 017637 000004 027124 3$: MOV @4(SP),4$ ;;PUT MSG ADDR IN JSR LINKAGE
027106 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDRESS
027114 013746 177776 MOV 177776,-(SP) ;;PUSH 177776 ON STACK
027120 004737 023042 JSR PC,$TYPE ;;CALL TYPE MACRO
027124 000000 4$: .WORD 0
027126 5$:
027126 105737 027214 10$: TSTB $FFLG ;;SHOULD REPORT FATAL ERROR?
027132 001416 BEQ 12$ ;;IF NOT: BR
027134 005737 001254 TST $ENV ;;RUNNING UNDER APT?
027140 001413 BEQ 12$ ;;IF NOT: BR
027142 005737 001234 11$: TST $MSGTYPE ;;FINISHED LAST MESSAGE?
027146 001375 BNE 11$ ;;IF NOT: WAIT
027150 017637 000004 001236 MOV @4(SP),$FATAL ;;GET ERROR #
027156 062766 000002 000004 ADD #2,4(SP) ;;BUMP RETURN ADDR.
027164 005237 001234 INC $MSGTYPE ;;TELL APT TO TAKE ERROR
027170 105037 027214 12$: CLRB $FFLG ;;CLEAR FATAL FLAG
027174 105037 027213 CLRB $LFLG ;;CLEAR LOG FLAG
027200 105037 027212 CLRB $MFLG ;;CLEAR MESSAGE FLAG
027204 012601 MOV (SP)+,R1 ;;POP STACK INTO R1
027206 012600 MOV (SP)+,R0 ;;POP STACK INTO R0
027210 000207 RTS ;;RETURN
027212 000 $MFLG: .BYTE 0 ;;MESSG. FLAG
027213 000 $LFLG: .BYTE 0 ;;LOG FLAG
027214 000 $FFLG: .BYTE 0 ;;FATAL FLAG
.EVEN
000200 APTSIZE = 200
000001 APTENV = 001
000100 APTSPOOL = 100
000040 APTCSUP = 040
  
```



```

2
3
4
5
6 027216 010046
7 027220 013700 040650
8 027224 016000 000010
9 027230 042700 177770
10 027234 136037 040636 001330
11 027242 001432
12 027244 105260 001472
13 027250 126037 001472 001316
14 027256 103424
15 027260 104401 001231
16 027264 104401 047625
17 027270 010046
    027272 104403
    027274 002
    027275 000
18 027276 104401 047634
19 027302 104401 047515
20 027306 104401 047645
21 027312 146037 040636 001330
22 027320 005337 021506
23 027324 000137 021334
24 027330 012600
25 027332 000207
26
27
28
29
30
31
32
33 027334 013704 040650
34 027340 012764 000040 000010
35 027346 042737 177770 001352
36 027354 013764 001352 000010
37 027362 000207
38
39
40
41
42
43
44
45
46 027364 005037 001326
47 027370 012737 027414 000004
48 027376 005037 000006
49 027402 005777 152126
50 027406 005237 001326
51 027412 000401
52 027414 022626
53 027416 012737 000006 000004
54 027424 000207

;THIS ROUTINE IS USED TO INCREMENT THE ERROR COUNT FOR EACH DRIVE BEING
;TESTED. IF THE TOTAL ERRORS ON ANY DRIVE EXCEEDS THE MAXIMUM ALLOWABLE
;ERRORS DESIGNATED IN LOCATION 'ERMAX', A MESSAGE WILL BE TYPED AND THE
;DRIVE IN ERROR WILL BE DROPPED FROM THE TEST.

INCEC: MOV RO,-(SP) ;SAVE RO
        MOV RMADR,RO ;GET RM BASE ADDRESS
        MOV RMCS2(RO),RO ;GET CONTENTS OF RMCS2
        BIC #^C7,RO ;SAVE UNIT SELECT BITS
        BITB ATABIT(RO),DRVSEL ;WAS THIS DRIVE SELECTED FOR TEST
        BEQ 1$ ;BR IF NO
        INCB ERRCN(RO) ;INCREMENT ERROR COUNT
        CMPB ERRCN(RO),ERMAX ;EXCEEDED ERROR LIMIT ?
        BLO 1$ ;BR IF NO
        TYPE ,SCLF ;CR-LF
        TYPE ,MSDRIV ;TYPE 'DRIVE'
        MOV RO,-(SP) ;;SAVE RO FOR TIMEOUT
        TYPOS ;;GO TYPE--OCTAL ASCII
        .BYTE 2 ;;TYPE 2 DIGIT(S)
        .BYTE 0 ;;SUPPRESS LEADING ZEROS
        TYPE ,DROP ;TYPE 'DROPPED'
        TYPE ,COMMA ;TYPE ','
        TYPE ,EXCEED ;TYPE 'EXCEEDED MAXIMUM ERROR LIMIT'
        BICB ATABIT(RO),DRVSEL ;DESELECT DRIVE FROM TEST
        DEC $EOPCT ;ADJUST 'EOP' COUNT
        JMP $EOP ;RETURN TO $EOP
1$: MOV (SP)+,RO ;RESTORE RO
    RTS PC

;THIS SUBROUTINE CLEARS THE MASSBUS CONTROLLER, MASSBUS ADAPTER,
;AND DRIVERS, THEN SELECTS THE DRIVE.
;CALL:
; JSR PC,CNTCLR ;CALL TO ROUTINE
;
;
CNTCLR: MOV RMADR,R4 ;GET RMCS1 BASE ADDRESS
        MOV #CLR,RMCS2(R4) ;ISSUE MASSBUS CLEAR AND
        BIC #^C7,CHKDRV ;SAVE UNIT SELECT BITS
        MOV CHKDRV,RMCS2(R4) ;SELECT THE DRIVE
        RTS PC ;RETURN

;SET 'LPTAVL' TO THE PROPER STATE.
; LPTAVL = 0 IF NO LINE PRINTER AVAILABLE
; LPTAVL = 1 IF LINE PRINTER IS AVAILABLE
;CALL
; JSR PC,LP.AVL
;
; RETURN

LP.AVL: CLR LPTAVL ;START WITH NO PRINTER AVAIABLE
        MOV #1$,ERRVEC ;SETUP THE TIMEOUT VECTOR
        CLR ERRVEC+2
        TST @LPS ;IS THERE A LINE PRINTER?
        INC LPTAVL ;YES--SET AVAILABLE SWITCH
        BR 2$
1$: CMP (SP)+,(SP)+ ;NO--POP STACK
2$: MOV #ERRVEC+2,ERRVEC ;RESTORE TIMEOUT VECTOR
    RTS PC ;RETURN

```

```

55
56
57
58
59
60
61
62
63
64
65
66
67
68
69
70
71
72 027426 010146
73 027430 012701 000006
74 027434 011146
75 027436 005011
76 027440 014146
77 027442 012711 027472
78 027446 005037 001342
79 027452 005777 152036
80 027456 012737 000001 001342
81 027464 004737 027574
82 027470 000414
83 027472 022626
84 027474 012711 027520
85 027500 005777 152022
86 027504 012737 177777 001342
87 027512 004737 027636
88 027516 000401
89 027520 022626
90 027522 012621
91 027524 012621
92 027526 012601
93 027530 032737 000100 001314
94 027536 001407
95 027540 012737 000020 001344
96 027546 012737 047040 001346
97 027554 000406
98 027556 012737 000016 001344
99 027564 012737 040432 001346
100 027572 000207
101
102 027574
103 027574 032737 000040 001314
104 027602 001014
105 027604 012777 027672 151676
106 027612 012777 000300 151672
107 027620 012777 000001 151670
108 027626 012777 000115 151660
109
110 027634 000207
111

```

```

: THIS ROUTINE WILL DETERMINE IF THERE IS A CLOCK ON THE SYSTEM
: AND IF THERE IS IT WILL SETUP THE VECTOR AND START THE CLOCK
: 'CLKSTA' WILL INDICATE THE CLOCK TYPE
: 0= NO CLOCK
: +1= KW11-P
: -1= KW11-L
: THIS ROUTINE WILL ALSO SETUP 'TICKMS' (TIME
: PER CLOCK TICK IN MILLISECONDS) AND 'TICKUS'
: (TIME PER CLOCK TICK IN MICROSECONDS) AS
: PER SW00.
: SW00=0 -- 60HZ
: SW00=1 -- 50HZ
: CALL
: JSR RETURN PC,ST.CLK
:
ST.CLK: MOV R1,-(SP) ;SAVE R1
MOV #ERRVEC+2,R1 ;SAVE AND SETUP TIMEOUT VECTOR
MOV (R1),-(SP)
CLR (R1) ;LEVEL 0
MOV -(R1),-(SP)
MOV #1$, (R1) ;GO TO 1$ ON TIMEOUT
CLR CLKSTA ;SET CLOCK STATUS TO NO CLOCK
TST @PKCS ;IS THERE A KW11-P?
MOV #1,CLKSTA ;YES--SET STATUS TO KW11-P
JSR PC,ST.PCLK ;START THE KW11-P
BR 3$ ;GO TO EXIT
1$: CMP (SP)+,(SP)+ ;CLEAN UP THE STACK
MOV #2$, (R1) ;IF TIMEOUT GO TO 2$
TST @LKS ;IS THERE A KW11-L?
MOV #-1,CLKSTA ;YES-- SET STATUS TO KW11-L
JSR PC,ST.LCLK ;START THE KW11-L
BR 3$ ;EXIT
2$: CMP (SP)+,(SP)+ ;CLEAN UP THE STACK
3$: MOV (SP)+,(R1)+ ;RESTORE THE TIMEOUT VECTOR
MOV (SP)+,(R1)+
MOV (SP)+,R1 ;RESTORE R1
BIT #SW06,C.SWR ;50HZ OR 60HZ?
BEQ 4$ ;BRANCH IF 60
MOV #20,TICKMS ;SETUP TIME PER
MOV #20000.,TICKUS ;TICK FOR 50HZ
BR 5$
4$: MOV #16,TICKMS ;SETUP TIME PER
MOV #16666.,TICKUS ;TICK FOR 60HZ
5$: RTS PC ;RETURN
ST.PCLK: BIT #SW05,C.SWR ;ALLOW SOFTWARE TIMEOUTS?
BNE 1$ ;NO--BRANCH
MOV #SRVCLK,@PKV ;SETUP THE KW11-P VECTOR
MOV #300,@PKV+2
MOV #1,@PKB ;COUNT ONE TICK
MOV #115,@PKCS ;'INT.EN.',COUNT DOWN'', 'MODE 1 (REPEAT)''
; 'LINE FREQ'', AND 'RUN'
1$: RTS PC ;RETURN

```

```

112 027636          ST.LCLK:
113 027636 032737 C0G040 001314      BIT      #SW05,C.SWR      ;ALLOW SOFTWARE TIMEOUTS?
114 027644 001011          BNE      1$              ;NO--BRANCH
115 027646 012777 027672 151646      MOV      #SRVCLK,@LKV  ;SETUP THE KW11-L VECTOR
116 027654 012777 000300 151642      MOV      #300,@LKV+2
117 027662 012777 000100 151636      MOV      #100,@LKS    ;START THE KW11-L
118 027670 000207          1$:      RTS      PC              ;RETURN
119
120 027672 013746 001344          SRVCLK. MOV      TICKMS,-(SP) ;TIME PER TICK IN MILLISECONDS
121 027676 004737 044670          JSR      PC,RMTMR      ;COUNT THE ELAPSED TIME
122 027702 000002          RTI              ;RETURN AFTER INTERRUPT
123
124          ;THIS ROUTINE SETS UP DEFAULT PARAMETER VALUES WHEN THE PROGRAM IS
125          ;STARTED OR WHEN THE VALUE OF BIT00 IN 'C.SWR' IS CHANGED.
126          ;CALL
127          ;      JSR      PC,LODFLT
128          ;      RETURN
129
130 027704          LODFLT:
      027704 010046          MOV      R0,-(SP)      ;;PUSH R0 ON STACK
      027706 010146          MOV      R1,-(SP)      ;;PUSH R1 ON STACK
      027710 010246          MOV      R2,-(SP)      ;;PUSH R2 ON STACK
      027712 010346          MOV      R3,-(SP)      ;;PUSH R3 ON STACK
131 027714 012737 166777 001332      MOV      #166777,TSTNMS ;SELECT TESTS 0-10,12,13 & 15-17
132 027722 012737 000003 001334      MOV      #3,TSTNMS+2   ;SELECT TESTS 20 & 21
133 027730 012700 002526          MOV      #DFLT,R0      ;DEFAULT PARAMETERS POINTER
134 027734 012701 003132          MOV      #PRMO,R1      ;TABLE POINTER
135 027740 010102          MOV      R1,R2        ;STOP ADDRESS
136 027742 012021          1$:      MOV      (R0)+,(R1)+   ;MOVE DEFAULT PARAMETERS INTO
137 027744 020002          CMP      R0,R2        ;RUN TIME TABLES ** DONE?
138 027746 103775          BLO     1$           ;NO--BRANCH
139 027750 012700 004176          MOV      #PAT8,R0      ;PATO DEFAULTS TO PATTERN 8
140 027754 012701 003576          MOV      #PATO,R1
141 027760 012021          2$:      MOV      (R0)+,(R1)+
142 027762 020027 004236          CMP      R0,#PAT9
143 027766 103774          BLO     2$
144 027770 032737 000001 001314      BIT      #BIT00,C.SWR   ;16 BIT MODE ?
145 027776 001012          BNE     3$           ;BR IF 18 BIT MODE
146 030000 012737 000037 002470      MOV      #31,PRMLMT+24 ;SET 'FS' LIMIT TO 31.
147 030006 012737 000037 002472      MOV      #31,PRMLMT+26 ;SET 'LS' LIMIT TO 31.
148 030014 012737 160000 001452      MOV      #-<256,*32.>,TRCKWC ;WORD COUNT FOR A 16 BIT TRACK
149 030022 000411          BR      4$           ;CONTINUE
150 030024 012737 000035 002470      3$:      MOV      #29,PRMLMT+24 ;SET 'FS' LIMIT TO 29.
151 030032 012737 000035 002472      MOV      #29,PRMLMT+26 ;SET 'LS' LIMIT TO 29.
152 030040 012737 161000 001452      MOV      #-<256,*30.>,TRCKWC ;WORD COUNT FOR AN 18 BIT TRACK
153 030046 012701 002374          4$:      MOV      #PRMPT,R1    ;ADDRESS OF PARAMETER POINTER TABLE
154 030052 005711          5$:      TST      (R1)        ;END OF PARAMETER POINTER TABLE ?
155 030054 001425          BEQ     8$           ;BR IF YES
156 030056 032731 004000          BIT      #BIT11,@(R1)+ ;IS 'LS' SELECTED AS A VARIABLE IN THIS TEST ?
157 030062 001773          BEQ     5$           ;BR IF NO
158 030064 016102 177776          MOV      -2(R1),R2    ;GET FIRST POSITION IN PARAMETER TABLE
159 030070 011246          MOV      (R2),-(SP)   ;AND SAVE VARIABLES BITS THAT ARE USED.
160 030072 012703 000014          MOV      #12,R3       ;POSITION OF 'LS' IN TEST PARAMETER TABLE
161 030076 006216          6$:      ASR      (SP)        ;IS THIS PARAMETER A VARIABLE ?
162 030100 103002          BCC     7$           ;BR IF NO
163 030102 062702 000002          ADD      #2,R2        ;YES, POINT TO NEXT PARAMETER IN TABLE
164 030106 005303          7$:      DEC      R3          ;AT 'LS' PARAMETER YET ?

```

```

165 030110 001372      BNE      6$          ;BR IF NO
166 030112 005726      TST      (SP)+       ;ADJUST THE STACK
167 030114 021237 002470  CMP      (R2),PRMLMT+24 ;IS 'LS' TOO LARGE FOR THE MODE SFELETED
168 030120 101754      BLOS     5$          ;BR IF NO
169 030122 013712 002470  MOV      PRMLMT+24,(R2) ;RESET VALUE FOR MODE USED
170 030126 000751      BR       5$          ;CONTINUE
171 030130
      8$:
      030130 012603      MOV      (SP)+,R3     ;;POP STACK INTO R3
      030132 012602      MOV      (SP)+,R2     ;;POP STACK INTO R2
      030134 012601      MOV      (SP)+,R1     ;;POP STACK INTO R1
      030136 012600      MOV      (SP)+,R0     ;;POP STACK INTO R0
172 030140 000207      RTS      PC          ;RETURN
173
174
175 ;THIS ROUTINE FILLS THE PARAMETER TABLE THE CURRENT TEST.
176 ;CALL
177 ;
178 ;   MOV      #TESTNUM,$STNUM ;LOAD THE TEST NUMBER
179 ;   JSR      PC,LODPRM
180 ;   RETURN
180 C30142
      LODPRM:
      030142 010146      MOV      R1,-(SP)     ;;PUSH R1 ON STACK
      030144 010246      MOV      R2,-(SP)     ;;PUSH R2 ON STACK
      030146 010346      MOV      R3,-(SP)     ;;PUSH R3 ON STACK
      030150 010446      MOV      R4,-(SP)     ;;PUSH R4 ON STACK
181 030152 005004      CLR      R4          ;CLEAR R4
182 030154 113704 001116  MOV#B    $STNUM,R4     ;GET THE TEST NUMBER
183 030160 006304      ASL      R4          ;SETUP TO ADDRESS WORDS
184 030162 016401 002374  MOV      PRMPT(R4),R1 ;GET THE TEST'S PARAMETER TABLE ADDRESS
185 030166 012702 002334  MOV      #PRM,R2      ;PARAMETER EXECUTION TABLE
186 030172 005003      CLR      R3          ;R3 IS USED AS A COUNTER
187 030174 013704 001352  MOV      CHKDRV,R4     ;GET DRIVE ADDRESS
188 030200 012122      MOV      (R1)+,(R2)+ ;LOAD PARAMETER SPECIFIER
189 030202 006237 002334  1$:      ASR      PRM          ;IS THIS PARAMETER USED IN THE TEST ?
190 030206 103002      BCC     2$          ;BR IF NOT
191 030210 012122      MOV      (R1)+,(R2)+ ;LOAD THE VALUE
192 030212 000401      BR       3$          ;CONTINUE
193 030214 005022      2$:      CLR      (R2)+     ;CLEAR THE UNUSED PARAMETER LOCATION
194 030216 005203      3$:      INC      R3          ;COUNT THE POSITION IN THE OUTPUT TABLE
195 030220 022702 002362  CMP      #PAT+2,R2     ;FINISHED ?
196 030224 001437      BEQ     7$          ;BR IF YES
197 030226 022703 000007  CMP      #7,R3         ;DOING TRACK PARAMETERS ?
198 030232 001363      BNE     1$          ;BR IF NO
199 030234 122764 000007 040542  CMP#B    #7,DRV TYP(R4) ;IS DEVICE AN RM05 ?
200 030242 001422      BEQ     6$          ;IF SO, OVERLAY FT, LT & IT WITH FT', L'' & IT'
201 030244 013737 002456 001374  MOV      PRMLMT+12,LSTRK ;GET LAST TRACK FOR AN RM03/2
202 030252 062703 000003  ADD      #3,R3         ;ADJUST COUNTER
203 030256 006237 002334  ASR      PRM          ;COUNT THE PARAMETER
204 030262 103001      BCC     4$          ;BR IF FT' IS NOT USED
205 030264 005721      TST     (R1)+       ;MOVE THE INPUT POINTER
206 030266 006237 002334  4$:      ASR      PRM          ;COUNT THE PARAMETER
207 030272 103001      BCC     5$          ;BR IF LT' NOT USED
208 030274 005721      TST     (R1)+       ;MOVE THE INPUT POINTER
209 030276 006237 002334  5$:      ASR      PRM          ;COUNT THE PARAMETER
210 030302 103337      BCC     1$          ;BR IF IT' NOT USED
211 030304 005721      TST     (R1)+       ;MOVE THE INPUT POINTER
212 030306 000735      BR       1$          ;KEEP GOING
213 030310 013737 002464 001374  6$:      MOV      PRMLMT+20,LSTRK ;GET LAST TRACK FOR AN RMC5
    
```

```

214 030316 162702 000006          SUB      #6,R2          ;BACKUP THE OUTPUT POINTER
215 030322 000727          BR       '$           ;KEEP GOING
216 030324          7$:      MOV      (SP)+,R4      ;;POP STACK INTO R4
      030326 012604      MOV      (SP)+,R3      ;;POP STACK INTO R3
      030330 012602      MOV      (SP)+,R2      ;;POP STACK INTO R2
      030332 012601      MOV      (SP)+,R1      ;;POP STACK INTO R1
217 030334 000207          RTS       PC           ;RETURN
218
219          ;THIS ROUTINE LOADS A READ HEADER AND DATA COMMAND OR A SEEK COMMAND
220          ;INTO DPB.B+2 AND DPB.C+2, DEPENDING ON THE STATE OF 'CONTROL SWITCH'
221          ;BIT07.
222          ;CALL
223          ;      JSR      PC,LDCMD
224          ;      RETURN
225
226 030336 032737 000200 001314  LDCMD:  BIT      #SW07,C.SWR  ;DO EXPLICIT SEEKS?
227 030344 001007          BNE      '$           ;YES--BRANCH
228 030346 012737 000173 047040      MOV      #READHD,DPB.B+2 ;NO--SET UP FOR READ HEADER AND
229 030354 012737 000173 047060      MOV      #RFADHD,DPB.C+2 ;DATA COMMAND
230 030362 000406          BR       '$           ;
231 030364 012737 000105 047040 1$:      MOV      #SEEK,DPB.B+2  ;SETUP FOR SEEK COMMAND
232 030372 012737 000105 047060      MOV      #SEEK,DPB.C+2
233 030400 000207          2$:      RTS       PC
234
235          ;THIS ROUTINE WILL CALL THE RM05 DRIVER AND THEN WAIT ON THE FUNCTION
236          ;TO COMPLETE. IF AN ERROR OCCURS IT IS REPORTED.
237          ;CALL
238          ;      FILL 'DPB' WITH COMMAND INFORMATION
239          ;      JSR      RO,CALL.A
240          ;      RETURN
241
242 030402 005037 001222          CALL.A: CLR      $ESCAPE  ;NO ESCAPE ADDRESS
243 030406 004037 041406          JSR      RO,RM05      ;CALL RM05 DRIVER
244 030412 047016          DPB.A
245 030414 000772          BR       CALL.A
246 030416 005737 047034          1$:      TST      DPB.A+16      ;DONE?
247 030422 001775          BEQ     '$           ;NO--LOOP
248 030424 100050          BPL     '$           ;BRANCH IF NO ERROR
249 030426 012737 030522 001222      MOV      #3,$ESCAPE    ;;ESCAPE TO 3$ ON ERROR
250 030434 013737 047030 001366      MOV      DPB.A+12,CYL.DS ;CYLINDER
      030442 113737 047027 001372      MOV      DPB.A+11,TRK.DS ;TRACK
      030450 113737 047026 001370      MOV      DPB.A+10,SEC.DS ;SECTOR
      030456 012746 047034          MOV      #DPB.A+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
      030462 004737 032170          JSR      PC,ERINDX     ;FORM DISPATCH INDEX
      030466 062607          ADD     (SP)+,PC       ;REPORT PROPER ERROR
      030470 104041          EMT     41           ;NON-EXIST DRIVE
      030472 104042          EMT     42           ;PARITY ERROR
      030474 104043          EMT     43           ;UNSAFE ERROR
      030476 104044          EMT     44           ;NON-I/O ERROR
251 030500 000240          NOP          ;TO SYNC THE CALLING SEQ OF ERINDX
252 030502 005737 047154          TST      RM.REG+RMER1  ;ANY DRIVE ERROR ?
253 030506 001004          BNE     '$           ;BRANCH IF SO
254 030510 032737 100000 047202      BIT      #BSE,RM.REG+RMER2 ;BAD SPOT ERROR
255 030516 001013          BNE     '$           ;BRANCH IF SO
256 030520          2$:      EMT     45           ;I/O ERROR
      030520 104045

```

```

257 030522 032737 040000 047202 3$: BIT #SKI, RM.REG+RMER2 ;SKI ERROR ?
258 030530 001402 BEQ 4$ ;BR IF NO
259 030532 004037 032016 JSR RO, CALL.R ;DO RECALIBRATE COMMAND
260 030536 013746 047034 4$: MOV DPB.A+16, -(SP) ;STATUS WORD
261 030542 004737 032130 JSR PC, LOP.CK ;SEE IF LOOP, ABORT, OR CONTINUE
262 030546 000200 5$: RTS RO ;RETURN
263
264 ;THIS ROUTINE IS THE SAME AS 'CALL.A' EXCEPT FOR THE DPB USED AND IF
265 ;THE COMMAND IS A READ HEADER AND DATA THE HEADFR (CYLINDER, TRACK,
266 ;AND SECTOR) READ IS CHECKED FOR VALIDITY.
267 ;CALL
268 ; FILL DPB
269 ; JSR RO, CALL.B
270 ; RETURN
271
272 030550 005037 001222 CALL.B: CLR $ESCAPE ;NO ESCAPE ADDRESS
273 030554 004037 041406 JSR RO, RMO5 ;CALL RMO5 DRIVER
274 030560 047036 DPB.B
275 030562 000772 BR CALL.B
276 030564 005737 047054 1$: TST DPB.B+16 ;DONE?
277 030570 001775 BEQ 1$ ;NO--BRANCH
278 030572 100055 BPL 5$ ;BRANCH IF NO ERROR
279 030574 012737 030700 001222 MOV #3$, $ESCAPE ;ESCAPE TO 3$ ON ERROR
280 030602 013737 047050 001366 MOV DPB.B+12, CYL.DS ;CYLINDER
030610 113737 047047 001372 MOV#B DPB.B+11, TRK.DS ;TRACK
030616 113737 047046 001370 MOV#B DPB.B+10, SEC.DS ;SECTOR
030624 012746 047054 MOV #DPB.B+16, -(SP) ;STATUS/ERROR INDICATOR ADDRESS
030630 004737 032170 JSR PC, ERINDX ;FORM DISPATCH INDEX
030634 062607 ADD (SP)+, PC ;REPORT PROPER ERROR
030636 104041 EMT 41 ;NON-EXIST DRIVE
030640 104042 EMT 42 ;PARITY ERROR
030642 104043 EMT 43 ;UNSAFE ERROR
030644 104044 EMT 44 ;NON-I/O ERROR
281 030646 000240 NOP ;TO SYNC THE CALLING SEQ OF ERINDX: RT.
282 030650 005737 047154 TST RM.REG+RMER1 ;DRIVE ERROR ?
283 030654 001404 BEQ 2$ ;BR IF NOT
284 030656 022737 000200 047154 CMP #HCE, RM.REG+RMER1 ;SEE IF ONLY 'HCE' SET
285 030664 001420 BEQ 5$ ;BR IF IT IS
286 030666 032737 100000 047202 2$: BIT #BSE, RM.REG+RMER2 ;BSE ERROR
287 030674 001033 BNE 7$ ;BRANCH IF SO
288 030676 104045 EMT 45 ;I/O ERROR
289 030700 032737 040000 047202 3$: BIT #SKI, RM.REG+RMER2 ;SKI ERROR ?
290 030706 001402 BEQ 4$ ;BR IF NO
291 030710 004037 032016 JSR RO, CALL.R ;DO RECALIBRATE COMMAND
292 030714 013746 047054 4$: MOV DPB.B+16, -(SP) ;STATUS WORD
293 030720 004737 032130 JSR PC, LOP.CK ;SEE IF LOOP, ABORT, OR CONTINUE
294 030724 000410 BR 6$ ;CHECK FOR STALL
295 030726 123727 047040 000173 5$: CMP#B DPB.B+2, #READHD ;DOING IMPLIED SEEKS?
296 030734 001004 BNE 6$ ;NO--BRANCH
297 030736 004037 032410 JSR RO, VERIFY ;YES--GO CHECK THE DATA
298 030742 047046 DPB.B+10
299 030744 000407 BR 7$ ;ERROR DURING VERIFY
300 030746 032737 040000 001314 6$: BIT #SW14, C.SWR ;STALL?
301 030754 001403 BEQ 7$ ;NO--BRANCH
302 030756 004037 032326 JSR RO, STALL ;YES--CALL STALL ROUTINE
303 030762 001454 .WORD STALL1 ;STALL TIME POINTER
304 030764 000200 7$: RTS RO ;RETURN
  
```

```

305
306           ;THIS ROUTINE IS THE SAME AS 'CALL,B' EXCEPT FOR THE DPB USED.
307           ;CALL
308           ;           FILL DPB
309           ;           JSR      RO,CALL.C
310           ;           RETURN
311
312 030766 005037 001222 CALL.C: CLR      $ESCAPE      ;NO ESCAPE ADDRESS
313 030772 004037 041406 JSR      RO,RM05      ;CALL RM05 DRIVER
314 030776 047056 DPB.C
315 031000 000772 BR      CALL.C
316 031002 005737 047074 1$: TST     DPB.C+16      ;DONE?
317 031006 001775 BEQ     1$           ;NO--LOOP
318 031010 100055 BPL     5$           ;YES--BRANCH IF NO ERROR
319 031012 012737 031116 001222 MOV     #3$, $ESCAPE  ;; ESCAPE TO 3$ ON ERROR
320 031020 013737 047070 001366 MOV     DPB.C+12,CYL.DS ;CYLINDER
      031026 113737 047067 001372 MOV     DPB.C+11,TRK.DS ;TRACK
      031034 113737 047066 001370 MOV     DPB.C+10,SEC.DS ;SECTOR
      031042 012746 047074 MOV     #DPB.C+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
      031046 004737 032170 JSR     PC,ERINDX    ;FORM DISPATCH INDEX
      031052 062607 ADD     (SP)+,PC     ;REPORT PROPER ERROR
      031054 104041 EMT     41          ;NON-EXIST DRIVE
      031056 104042 EMT     42          ;PARITY ERROR
      031060 104043 EMT     43          ;UNSAFE ERROR
      031062 104044 EMT     44          ;NON-I/O ERROR
321 031064 000240 NOP           ;TO SYNC THE CALLING SEQ OF ERINDX: RT.
322 031066 005737 047154 TST     RM.REG+RMER1 ;DRIVE ERROR ?
323 031072 001404 BEQ     2$           ;BR IF NOT
324 031074 022737 000200 047154 CMP     #HCE,RM.REG+RMER1 ;SEE IF ONLY 'HCE' SET
325 031102 001420 BEQ     5$           ;BR IF YES
326 031104 032737 100000 047202 2$: BIT     #BSE,RM.REG+RMER2 ;BSE ERROR ONLY ?
327 031112 001033 BNE     7$           ;BRANCH IF SO
328 031114 104045 EMT     45          ;I/O ERROR
329 031116 032737 040000 047202 3$: BIT     #SKI,RM.REG+RMER2 ;SKI ERROR ?
330 031124 001402 BEQ     4$           ;BR IF NO
331 031126 004037 032016 JSR     RO,CALL.R    ;DO RECALIBRATE COMMAND
332 031132 013746 047074 4$: MOV     DPB.C+16,-(SP) ;STATUS WORD
333 031136 004737 032130 JSR     PC,L0P.CK    ;SEE IF LOOP, ABORT, OR CONTINUE
334 031142 000410 BR      6$
335 031144 123727 047060 000173 5$: CMP     DPB.C+2,#READHD ;DOING IMPLIED SEEK?
336 031152 001004 BNE     6$           ;NO--EXIT
337 031154 004037 032410 JSR     RO,VERIFY    ;YES--CHECK THE DATA
338 031160 047066 DPB.C+10
339 031162 000407 BR      7$           ;ERROR DURING VERIFY
340 031164 032737 040000 001314 6$: BIT     #SW14,C.SWR  ;STALL?
341 031172 001403 BEQ     7$           ;NO--BRANCH
342 031174 004037 032326 JSR     RO,STALL    ;YES--CALL STALL ROUTINE
343 031200 001454 .WORD  STALL1      ;STALL TIME POINTER
344 031202 000200 7$: RTS     RO
345
346
347           ;THIS ROUTINE IS THE SAME AS 'CALL,A' EXCEPT FOR THE DPB USED AND
348           ;ON AN ERROR LOCATION 'ERR.CT' IS EXAMINED. IF ERR.CT IS EQUAL TO
349           ;$ERFLG EXIT IS TO THE NEXT TEST.
350           ;CALL
351           ;           FILL DPB
352           ;           JSR      RO,DRVCAL

```

```

353 ; RETURN
354
355 031204 005037 001222 DRVCL : CLR $ESCAPE ;NO ESCAPE ADDRESS
356 031210 005037 001434 CLR WCEFLG ;CLEAR WRITE CHECK ERROR FLAG
357 031214 004037 041406 JSR RO,RM05 ;CALL RM05 DRIVER
358 031220 047076 DTADPB
359 031222 000770 BR DRVCL
360
361 031224 005737 047114 DRVCL1: TST DTADPB+16 ;DONE
362 031230 001775 BEQ DRVCL1 ;NO--LOOP
363 031232 100402 BMI 1$ ;BR IF ERRORS
364 031234 000137 031776 JMP 15$ ;NO ERRORS
365 031240 1$:
366 031240 012737 031346 001222 MOV #3$, $ESCAPE ;;ESCAPE TO 3$ ON ERROR
031246 013737 047110 001366 MOV DTADPB+12,CYL.DS ;CYLINDER
031254 113737 047107 001372 MOV DTADPB+11,TRK.DS ;TRACK
031262 113737 047106 001370 MOV DTADPB+10,SFC.DS ;SECTOR
031270 012746 047114 MOV #DTADPB+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
031274 004737 032170 JSR PC,ERINDX ;FORM DISPATCH INDEX
031300 062607 ADD (SP)+,PC ;REPORT PROPER ERROR
031302 104041 EMT 41 ;NON-EXIST DRIVE
031304 104042 EMT 42 ;PARITY ERROR
031306 104043 EMT 43 ;UNSAFE ERROR
031310 104044 EMT 44 ;NON-I/O ERROR
367 031312 000240 NOP ;TO SYN THE CALLING SEQ OF THE ERINDX:
368 031314 005737 047154 TST RM.REG+RMER1 ;ANY DRIVE ERROR ?
369 031320 001011 BNE 2$ ;REPORT THE I/O ERROR IF SO
370 031322 032737 100000 047202 BIT #BSE,RM.REG+RMER2 ;BAD SPOT ERROR ?
371 031330 001405 BEQ 2$ ;BRANCH IF NOT
372 031332 012737 177777 001466 MOV #-1,BASFLG ;SET BAD SECTOR ENCOUNTER FLAG
373 031340 000137 031776 JMP 15$ ;OTHERWISE ,DON'T REPORT THE BSE
374 031344 2$:
031344 104045 EMT 45 ;I/O ERROR
375 031346 122737 000020 001116 3$: CMPB #20,$STNM ;TEST 20?
376 031354 001170 BNE 11$ ;NO--BRANCH
377 031356 013746 047114 MOV DTADPB+16,-(SP) ;STATUS WORD
378 031362 004737 032130 JSR PC,LOP.CK ;SEE IF LOOP, ABCRT, OR CONTINUE
379 031366 122737 000151 047100 CMPB #WRCKD,DTADPB+2 ;DOING A WRITE CHECK?
380 031374 001172 BNE 13$ ;NO--BRANCH
381 031376 032737 040000 047150 BIT #BIT14,RM.REG+10 ;IS 'WCE'=1?
382 031404 001566 BEQ 13$ ;NO--BRANCH
383 031406 032777 000020 147540 BIT #SW04,@SWR ;INHIBIT WRITES?
384 031414 001162 BNE 13$ ;YES--BRANCH
385 031416 112737 000161 047100 MOVB #WRITE,DTADPB+2 ;SETUP FOR A WRITE
386 031424 005037 001222 CLR $ESCAPE ;NO ESCAPE ADDRESS
387 031430 004037 041406 JSR RO,RM05 ;DO THE WRITE
388 031434 047076 DTADPB
389 031436 000240 NOP
390 031440 005737 047114 4$: TST DTADPB+16 ;DONE?
391 031444 001775 BEQ 4$ ;NO--LOOP
392 031446 100043 BPL 6$ ;YES--BRANCH IF NO ERROR
393 031450 012737 031736 001222 MOV #11$, $ESCAPE ;;ESCAPE TO 11$ ON ERROR
394 031456 013737 047110 001366 MOV DTADPB+12,CYL.DS ;CYLINDER
031464 113737 047107 001372 MOV DTADPB+11,TRK.DS ;TRACK
031472 113737 047106 001370 MOV DTADPB+10,SEC.DS ;SECTOR
031500 012746 047114 MOV #DTADPB+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
031504 004737 032170 JSR PC,ERINDX ;FORM DISPATCH INDEX

```



```

031510 062607 ADD (SP)+,PC ;REPORT PROPER ERROR
031512 104041 EMT 41 ;NON-EXIST DRIVE
031514 104042 EMT 42 ;PARITY ERROR
031516 104043 EMT 43 ;UNSAFE ERROR
031520 104044 EMT 44 ;NON-I/O ERROR
395 031522 000240 NOP ;SO SYN THE CALLING SEQ OF ERINDX
396 031524 005737 047154 TST RM.REG+RMER1 ;ANY DRIVE ERROR ?
397 031530 001011 BNE 5$ ;BRANCH IF SO
398 031532 032737 100000 047202 BIT #BSE,RM.REG+RMER2 ;BAD SOPT ERROR
399 031540 001405 BEQ 5$ ;BRANCH IF NOT
400 031542 012737 177777 001466 MOV #-1,BASFLG ;SET BAD SECTOR ENCOUNTER FLAG
401 031550 000137 031776 JMP 15$ ;EXIT
402 031554 5$:
031554 104045 EMT 45 ;I/O ERROR
403 031556 112737 000151 047100 6$: MOVB #WRCKD,DTADPB+2 ;COMMAND=WRITE CHECK DATA
404 031564 004037 041406 JSR R0,RM05 ;DO THE WRITE CHECK
405 031570 047076 DTADPB
406 031572 000240 NOP
407 031574 005737 047114 7$: TST DTADPB+16 ;DONE?
408 031600 001775 BEQ 7$ ;NO--LOOP
409 031602 100410 BMI 9$ ;YES--BRANCH IF ERROR
410 031604 004037 041406 JSR R0,RM05 ;DO A 2ND WRITE CHECK
411 031610 047076 DTADPB
412 031612 000240 NOP
413 031614 005737 047114 8$: TST DTADPB+16 ;DONE?
414 031620 001775 BEQ 8$ ;NO--LOOP
415 031622 100065 BPL 15$ ;YES--BRANCH IF NO ERROR
416 031624 012737 000001 001434 9$: MOV #1,WCEFLG ;SET THE WRITE CHECK ERROR FLAG
417 031632 012737 031736 001222 MOV #11$, $ESCAPE ;ESCAPE TO 11$ ON ERROR
418 031640 013737 047110 001366 MOV DTADPB+12,CYL.DS ;CYLINDER
031646 113737 047107 001372 MOVB DTADPB+11,TRK.DS ;TRACK
031654 113737 047106 001370 MOVB DTADPB+10,SEC.DS ;SECTOR
031662 012746 047114 MOV #DTADPB+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
031666 004737 032170 JSR PC,ERINDX ;FORM DISPATCH INDEX
031672 062607 ADD (SP)+,PC ;REPORT PROPER ERROR
031674 104041 EMT 41 ;NON-EXIST DRIVE
031676 104042 EMT 42 ;PARITY ERROR
031700 104043 EMT 43 ;UNSAFE ERROR
031702 104044 EMT 44 ;NON-I/O ERROR
419 031704 000240 NOP ;SO SYN THE CALLING SEQ OF ERINDX:
420 031706 005737 047154 TST RM.REG+RMER1 ;ANY DRIVE ERROR
421 031712 001010 BNE 10$ ;BRANCH IF SO
422 031714 032737 100000 047202 BIT #BSE,RM.REG+RMER2 ;BAD SOPT ERROR ?
423 031722 001404 BEQ 10$ ;BRANCH IF NOT
424 031724 012737 177777 001466 MOV #-1,BASFLG ;SET BAD SECTOR ENCOUNTER FLAG
425 031732 000421 BR 15$ ;OTHERWISE EXIT
426 031734 10$:
031734 104046 EMT 46 ;REPORT THE FATAL WRITE CHECK ERROR
427 031736 032737 040000 047202 11$: BIT #SKI,RM.REG+RMER2 ;SKI ERROR ?
428 031744 001402 BEQ 12$ ;BR IF NO
429 031746 004037 032016 JSR R0,CALL.R ;DO RECALIBRATE COMMAND
430 031752 013746 047114 12$: MOV DTADPB+16,-(SP) ;STATUS WORD
431 031756 004737 032130 JSR PC,LOP.CK ;SEE IF LOOP, ABORT, OR CONTINUE
432 031762 123737 001464 001117 13$: CMPB ERR.CT,$ERFLG ;GO TO NEXT TEST?
433 031770 101002 BHI 15$ ;NO--BRANCH
434 031772 013700 001350 14$: MOV BYPASS,R0 ;YES--GET EXIT ADDRESS
435 031776 032737 040000 001314 15$: BIT #SW14,C.SWR ;STALL?

```

```

436 032004 001403          BEQ      16$          ;NO--BRANCH
437 032006 004037 032326   JSR      RO,STALL      ;YES--CALL STALL ROUTINE
438 032012 001456          .WORD   STALL2        ;STALL TIME POINTER
439 032014 000200          RTS       RO
440
441                          ;THIS ROUTINE WILL ISSUE A RECALIBRATE COMMAND TO THE RM05 DRIVER
442                          ;AND WAIT FOR THE FUNCTION TO COMPLETE.
443                          ;CALL
444                          ;
445                          ;      JSR      RO,CALL.R
446                          ;      RETURN
447 032016 005037 001222   CALL.R: CLR      $ESCAPE ;NO ESCAPE ADDRESS
448 032022 004037 041406   JSR      RO,RM05      ;CALL RM05 DRIVER
449 032026 047116          DPB.R
450 032030 000772          BR
451 032032 005737 047134   1$:   TST      DPB.R+16 ;DONE?
452 032036 001775          BEQ      1$           ;NO--LOOP
453 032040 100032          BPL      3$           ;BRANCH IF NO ERROR
454 032042 012737 032116 001222  MOV      #2$, $ESCAPE ;: ESCAPE TO 2$ ON ERROR
455 032050 013737 047130 001366  MOV      DPB.R+12,CYL.DS ;CYLINDER
      032056 113737 047127 001372  MOV      DPB.R+11,TRK.DS ;TRACK
      032064 113737 047126 001370  MOV      DPB.R+10,SEC.DS ;SECTOR
      032072 012746 047134          MOV      #DPB.R+16,-(SP) ;STATUS/ERROR INDICATOR ADDRESS
      032076 004737 032170          JSR      PC,ERINDX    ;FORM DISPATCH INDEX
      032102 062607          ADD      (SP)+,PC    ;REPORT PROPER ERROR
      032104 104041          EMT      41          ;NON-EXIST DRIVE
      032106 104042          EMT      42          ;PARITY ERROR
      032110 104043          EMT      43          ;UNSAFE ERROR
      032112 104044          EMT      44          ;NON-I/O ERROR
456 032114 000240          NOP
457 032116 013746 047034   2$:   MOV      DPB.A+16,-(SP) ;:STATUS WORD
458 032122 004737 032130   JSR      PC,LOP.CK    ;SEE IF LOOP, ABORT, OR CONTINUE
459 032126 000200          RTS       RO         ;RETURN
460
461                          ;THIS SUBROUTINE CHECK FOR LOOP, ABORT, OR CONTINUE SWITCHES AFTER
462                          ;ERRORS 41, 42, 43, 44, 45, AND 46.
463                          ;CALL
464                          ;
465                          ;      MOV      DTA+16,-(SP) ;:STATUS WORD FROM DPB IN USE
466                          ;      JSR      PC,LOP.CK
467                          ;      RETURN
468 032130 032777 001000 147016  LOP.CK: BIT      #SW9,@SWR ;:LOOP ON ERROR
469 032136 001402          BEQ      1$           ;BR IF NOT
470 032140 000177 146760   JMP      @SLPERR      ;START AT THE LOOP ADDRESS
471 032144 005037 001222   1$:   CLR      $ESCAPE ;:CLEAR ERROR ESCAPE FLAG
472 032150 032766 072006 000002  BIT      #BIT14:BIT13:BIT12:BIT10:BIT02:BIT01,2(SP) ;:CHECK ERROR TYPE
473 032156 001402          BEQ      2$           ;BR IF DRIVE NOT OFFLINE, UNLOADED, OR
474                          ;PERSISTENT UNSAFE OR FATAL MASSBUS PARITY
475 032160 000137 021334   JMP      $EOP        ;TERMINATE DRIVE
476 032164 012616   2$:   MOV      (SP)+,(SP) ;:ADJUST RETURN ADDRESS
477 032166 000207          RTS       PC
478
479                          ;THIS ROUTINE FORMS AN INDEX THAT WILL BE USED TO DISPATCH
480                          ;TO THE PROPER ERROR CALL. THE INDEX IS FORMED BY EXAMINING
481                          ;THE STATUS/ERROR INDICATOR OF THE APPLICABLE DPB.
482                          ;INDEX      STATUS/ERROR
483                          ;-----

```

```

484      :      0 BIT14!BIT13!BIT08!BIT01
485      :      2 BIT11!BIT10!BIT02
486      :      4 BIT12!BIT04
487      :      6 BIT05!BIT03.<BIT09 & COMMAND=NON-I/O>
488      :      10 BIT06.<BIT09 & COMMAND=I/O>
489      :CALL
490      :      JSR      #DPB+16,-(SP)      ;ADDRESS OF STATUS/ERROR INDICATOR
491      :      JSR      PC,ERINDX        ;FORM INDEX
492      :      RETURN                     ;INDEX IS ON THE STACK
493
494 032170 010046      ERINDX: MOV      R0,-(SP)      ;SAVE R0
495 032172 010146      MOV      R1,-(SP)      ;SAVE R1
496 032174 016600      MOV      6(SP),R0      ;GET STATUS/ERROR INDICATOR POINTER
497 032200 011037      MOV      (R0),SVSTAT      ;SAVE THE STATUS/ERROR INDICATOR
498 032204 005001      CLR      R1      ;START INDEX AT ZERO
499 032206 032710      BIT      (PC)+,(R0)      ;FORM INDEX OF 0?
500 032210 020402      .WORD   BIT13!BIT08!BIT01
501 032212 001037      BNE     5$      ;YES--BRANCH
502 032214 032710      BIT      (PC)+,(R0)      ;FORM PARITY ERROR OR PORT REQUEST INDEX (2)?
503 032216 006004      .WORD   BIT11!BIT10!BIT02
504 032220 001033      BNE     4$      ;YES--BRANCH
505 032222 032710      BIT      (PC)+,(R0)      ;FORM UNSAFE INDEX (4)?
506 032224 050020      .WORD   BIT14!BIT12!BIT04
507 032226 001027      BNE     3$      ;YES--BRANCH
508 032230 032710      BIT      (PC)+,(R0)      ;FORM NON-I/O ERROR INDEX (6)?
509 032232 000050      .WORD   BIT05!BIT03
510 032234 001023      BNE     2$      ;YES--BRANCH
511 032236 032710      BIT      (PC)+,(R0)      ;FORM I/O ERROR INDEX (10)?
512 032240 000100      .WORD   BIT06
513 032242 001017      BNE     1$      ;YES--BRANCH
514 032244 032710      BIT      (PC)+,(R0)      ;SOFTWARE TIMEOUT?
515 032246 001000      .WORD   BIT09
516 032250 001420      BEQ     5$      ;NO--FORM INDEX OF 0
517 032252 122760      CMPB   #150,-16(R0)      ;YES--I/O?
518 032260 003011      BGT     2$      ;NO--BRANCH
519 032262 005737      TST    RM.REG+RMER1      ;ANY DRIVE ERROR ?
520 032266 001005      BNE     1$      ;BRANCH IF SO
521 032270 032737      BIT    #BSE,RM.REG+RMER2 ;BSE ERROR
522 032276 001401      BEQ     1$      ;BRANCH IF NOT
523 032300 005201      INC    R1      ;SKIP , NOT REPORT BSE ERROR
524 032302 005201      1$:   INC    R1      ;INDEX=10---ERROR=45 OR 46
525 032304 005201      2$:   INC    R1      ;INDEX=6---ERROR=44
526 032306 005201      3$:   INC    R1      ;INDEX=4---ERROR=43
527 032310 005201      4$:   INC    R1      ;INDEX=2---ERROR=42
528 032312 006301      5$:   ASL    R1      ;INDEX=0---ERROR=41
529 032314 010166      MOV    R1,6(SP)      ;RETURN INDEX TO USER
530 032320 012601      MOV    (SP)+,R1      ;RESTORE R1
531 032322 012600      MOV    (SP)+,R0      ;RESTORE R0
532 032324 000207      RTS    PC      ;RETURN FROM CALL
533
534      :      ;THIS ROUTINE WILL PROVIDE A STALL IN MILLISECONDS FOR A SPECIFIC
535      :      ;AMOUNT OF TIME IF BIT13 OF C.SWR = 0 OR A RANDOM AMOUNT OF TIME
536      :      ;IF BIT 13 OF C.SWR = 1.
537      :      ;STALL1 CONTAINS SPECIFIED TIME FOR TESTS 0 - 7, AND STALL2
538      :      ;CONTAINS THE TIME FOR TESTS 16-21.
539      :CALL
540      :      JSR      R0,STALL

```

```

541 ; TIME POINTER ;WHERE TO FIND THE STALL TIME
542
543 032326 013046 STALL: MOV @ (R0)+, -(SP) ; PICKUP STALL TIME
544 032330 032737 020000 001314 BIT #SW13, C.SWR ; USE A RANDOM TIME?
545 032336 001406 BEQ 1$ ; NO--BRANCH
546 032340 004737 026426 JSR PC, $RAND ; YES--FORM RANDOM NUMBER
547 032344 013716 026526 MOV $LONJM, (SP) ; AND USE IT FOR THE STALL TIME
548 032350 042716 177700 BIC #^C77, (SP) ; BUT NEVER > 64 MILLISECONDS
549 032354 005046 1$: CLR -(SP) ; CLEAR TEMP. LOCATION
550 032356 162766 000001 000002 2$: SUB #1, 2(SP) ; MORE STALL REQUIRED?
551 032364 103407 BLO 4$ ; NO--BRANCH
552 032366 012716 000144 MOV #100., (SP) ; STALL FOR ABOUT 1 MILLISECOND
553 032372 005700 3$: TST R0 ; NOP TO KILL TIME
554 032374 005366 000000 DEC 0(SP) ; COUNT
555 032400 001374 BNE 3$ ; LOOP IF MORE COUNTS NEEDED
556 032402 000765 BR 2$
557 032404 022626 4$: CMP (SP)+, (SP)+ ; CLEAN OFF THE STACK
558 032406 000200 RTS R0 ; EXIT

559
560 ;ROUTINE TO SOFTWARE COMPARE HEADER ON IMPLIED SEKS
561 ;CALL
562 ; JSR R0, VERIFY
563 ; ADR POINTER ;ADDRESS OF DPB+10 (SECTOR NUMBER)
564 ; RETURN
565
566 032410 010146 VERIFY: MOV R1, -(SP) ; SAVE R1
567 032412 012001 MOV (R0)+, R1 ; GET ADDRESS OF DPB+10
568 032414 042737 150000 054522 BIC #150000, BUFFER ; STRIP FORMAT AND BAD SECTOR BITS FROM CYLINDER NUMBER
569 032422 023761 054522 000002 CMP BUFFER, 2(R1) ; CYLINDER NUMBER OK?
570 032430 001003 BNE 1$ ; NO--BRANCH
571 032432 023711 054524 CMP BUFFER+2, (R1) ; YES--HOW ABOUT TRACK/SECTOR?
572 032436 001441 BEQ 3$ ; BRANCH IF GOOD
573 032440 013737 054522 001360 1$: MOV BUFFER, CYL.RD ; SAVE THE EXPECTED AND THE
574 032446 113737 054525 001362 MOVB BUFFER+3, TRK.RD ; RECIEVED CYLINDER, TRACK,
575 032454 113737 054524 001364 MOVB BUFFER+2, SEC.RD ; AND SECTOR
576 032462 112137 001370 MOVB (R1)+, SEC.DS
577 032466 112137 001372 MOVB (R1)+, TRK.DS
578 032472 011137 001366 MOV (R1), CYL.DS
579 032476 012737 032510 001222 MOV #2$, $ESCAPE ; ; ESCAPE TO 2$ ON ERROR
580 032504 005740 TST -(R0) ; MAKE IT TEST PC+4
581 032506 104012 EMT 12 ; IMPROPER HEADER DATA
582 032510 012737 000107 047020 2$: MOV #RECAL, DPB.A+2 ; LOAD RECALIBRATE ORDER CODE
583 032516 004037 030402 JSR R0, CALL.A ; GO EXECUTE THE COMMAND
584 032522 005037 001222 CLR $ESCAPE ; CLEAR ERROR ESCAPE FLAG
585 032526 032777 001000 146420 BIT #SW9, @SWR ; LOOP ON ERROR ?
586 032534 001404 BEQ 4$ ; BR IF NOT
587 032536 000177 146362 JMP @ $LPERR ; RETURN TO ERROR LOOP ADDRESS
588 032542 062700 000002 3$: ADD #2, R0 ; INCREMENT RETURN ADDRESS
589 032546 012601 4$: MOV (SP)+, R1 ; RESTORE R1
590 032550 000200 RTS R0 ; EXIT

591
592 ;THIS ROUTINE WILL PERFORM A 'MASSBUS' INIT. FOLLOWED BY
593 ;A 'RECALIBRATE' ON THE DRIVE UNDER TEST.
594 ;NOTE: THIS ROUTINE DESTROYS R1 AND R4
595 ;CALL
596 ; JSR R0, SRCH00 ;DO A MASSBUS INIT. AND RECAL
597 ; RETURN1 ;RETURN HERE IF NO ERROR

```

```

598 ; RETURN2 ; RETURN HERE ON ERROR
599
600 032552 005001 SRCH00: CLR R1 ; INCASE OF ERROR (TYPTIM)
601 032554 005037 177776 CLR PS
602 032560 012777 043306 006064 MOV #ISR,@RMVEC ; SETUP INTERRUPT VECTOR
603 032566 013704 040650 RMADR,R4 ; PICKUP ADDRESS OF RMCS1
604 032572 012764 000040 000010 MOV #CLR,RMCS2(R4) ; MASSBUS INIT.
605 032600 005037 047106 CLR DTADPB+10 ; TRACK=0; SECTOR=0
606 032604 005037 047110 CLR DTADPB+12 ; CYLINDER =0
607 032610 012737 000107 047100 MOV #RECAL,DTADPB+2 ; COMMAND = RECALIBRATE
608 032616 005037 001222 CLR $ESCAPE ; NO ESCAPE ADDRESS
609 032622 004037 041406 JSR RO,RM05 ; CALL THE DRIVER
610 032626 047076 DTADPB ; DPB POINTER
611 032630 000440 BR 4$ ; QUEUE IS FULL
612 032632 005737 047114 1$: TST DTADPB+16 ; WAIT ON DONE
613 032636 001775 BEQ 1$
614 032640 100030 BPL 3$ ; TAKE NORMAL EXIT IF NO ERROR
615 032642 012737 032716 001222 MOV #2$, $ESCAPE ; ESCAPE TO 2$ ON ERROR
616 032650 013737 047110 001366 MOV DTADPB+12,CYL.DS ; CYLINDER
032656 113737 047107 001372 MOV DTADPB+11,TRK.DS ; TRACK
032664 113737 047106 001370 MOV DTADPB+10,SEC.DS ; SECTOR
032672 012746 047114 MOV #DTADPB+16,-(SP) ; STATUS/ERROR INDICATOR ADDRESS
032676 004737 032170 JSR PC,ERINDX ; FORM DISPATCH INDEX
032702 062607 ADD (SP)+,PC ; REPORT PROPER ERROR
032704 104041 EMT 41 ; NON-EXIST DRIVE
032706 104042 EMT 42 ; PARITY ERROR
032710 104043 EMT 43 ; UNSAFE ERROR
032712 104044 EMT 44 ; NON-I/O ERROR
032714 104045 EMT 45 ; I/O ERROR
617 032716 005720 2$: TST (RO)+ ; ADJUST FOR ERROR EXIT
618 032720 000404 BR 4$ ; GO TO THE EXIT
619 032722 005064 000006 3$: CLR RMDA(R4) ; TRACK AND SECTOR 0
620 032726 005064 000034 CLR RMDC(R4) ; CYLINDER = 0
621 032732 000200 4$: RTS RO ; RETURN
622
623 ; THIS IS AN RTI WHICH IS USED BY THE TIMING TESTS & THE SERVO SETTLE DOWN TEST
624
625 032734 000002 DORTI: RTI ; RETURN FROM INTERRUPT
626
627 ; THIS ROUTINE WILL INITIALIZE THE TIMERS USED BY THE TIMING ROUTINES
628 ; CALL
629 ; JSR PC,STRTMR
630 ; RETURN
631
632 032736 104412 STRTMR: SAVREG ; SAVE R0-R5
633 032740 012700 001376 MOV #TIM.UP,RO ; START AT TIM.UP
634 032744 005020 1$: CLR (RO)+ ; CLEAR THE TIME TABLES
635 032746 020027 001432 CMP RO,#TIM.PT ; DONE?
636 032752 103774 BLO 1$ ; NO--BRANCH
637 032754 012710 054522 MOV #BUFFER,(RO) ; SETUP POINTER
638 032760 012737 077777 001376 MOV #^CBIT15,TIM.UP ; SET MINIMUM TIME TO MAXIMUM
639 032766 012737 077777 001414 MOV #^CBIT15,TIM.DN ; POSITIVE NUMBER
640 032774 104413 RESREG ; RESTORE R0-R5
641 032776 000207 RTS PC ; RETURN
642
643 ; THIS ROUTINE WILL ADD THE ELAPSED TIME TO THE AVERAGE COUNTER AND
644 ; MAINTAIN THE MINIMUM AND MAXIMUM TIMES.

```

```

645      ;NOTE: THIS ROUTINE DESTROYS R2
646      ;CALL
647      :      MOV      #TP,R3      ;PARAMETER POINTER
648      :      MOV      FLAG,R5     ;FLAG=0=COUNT UP
649      :      :
650      :      JSR      PC,COUNT     ;FLAG=-1=COUNT DOWN
651      :      RETURN
652
653 033000 012702 001376      COUNT:  MOV      #TIM.UP,R2     ;PICKUP THE 'UP' POINTER
654 033004 005705           TST      R5              ;USE IT?
655 033006 001402           BEQ      1$             ;YES--BRANCH
656 033010 012702 001414     MOV      #TIM.DN,R2     ;NO--PICKUP 'DOWN' POINTER
657 033014 027722 146500     1$:     CMP      @PKC,(R2)+    ;LESS THAN PREVIOUS LOW?
658 033020 002003           BGE      2$             ;NO--BRANCH
659 033022 017762 146472 177776  MOV      @PKC,-2(R2)    ;YES--SAVE IT
660 033030 027763 146464 000004  2$:     CMP      @PKC,4(R3)    ;LESS THAN THE LOW LIMIT?
661 033036 002001           BGE      3$             ;NO--BRANCH
662 033040 005212           INC      (R2)          ;YES--COUNT IT
663 033042 005722           TST      (R2)+        ;ADVANCE THE POINTER
664 033044 027722 146450     CMP      @PKC,(R2)+    ;GREATER THAN PREVIOUS HIGH?
665 033050 003403           BLE      4$             ;NO--BRANCH
666 033052 017762 146442 177776  MOV      @PKC,-2(R2)    ;YES--SAVE IT
667 033060 027763 146434 000006  4$:     CMP      @PKC,6(R3)    ;GREATER THAN THE HIGH LIMIT?
668 033066 003401           BLE      5$             ;NO--BRANCH
669 033070 005212           INC      (R2)          ;YES--COUNT IT
670 033072 005722           TST      (R2)+        ;ADVANCE THE POINTER
671 033074 067722 146420     ADD      @PKC,(R2)+    ;ADD THIS COUNT TO THE TOTAL
672 033100 005522           ADC      (R2)+
673 033102 005212           INC      (R2)
674 033104 022737 063052 001432  CMP      #BUFFER+<4*822.> ;COUNT THIS READING
675 033112 101406           BLOS     6$             ;TIM.PT ;SAVE THIS COUNT?
676 033114 017777 146400 146310  MOV      @PKC,@TIM.PT  ;NO--BRANCH
677 033122 062737 000002 001432  ADD      #2,TIM.PT     ;YES--WELL SAVE IT THEN
678 033130 000207           RTS      PC            ;ADVANCE THE POINTER
679      :
680      :
681      :      ;THIS ROUTINE PRINTS THE SPEC OF ALL TIMING TESTS
682      :      ;CALL
683      :      JSR      R0,SPTYP     ;TABLE ADDRESS
684      :      :
685      :      TABLE: .WORD  ASCIZ MESSAGE POINTER
686      :      :      .WORD  MIN VALUE
687      :      :      .WORD  MAX VALUE
688
689 033132 012002           SPTYP:  MOV      (R0)+,R2     ;THE TABLE ADDRESS
690 033134 032777 000100 146012  BIT      #SW06,@SWR    ;ALLOW PRINT
691 033142 001035           BNE      3$             ;EXIT IF NOT
692 033144 104401 001231     TYPE    , $CRLF
693 033150 104401 001231     TYPE    , $CRLF
694 033154 012237 033162     MOV      (R2)+,1$      :
695 033160 104401           TYPE
696 033162 000000           1$:     .WORD    0
697 033164 012246           MOV      (R2)+,-(SP)   ;LOAD MIN VALUE
698 033166 001410           BEQ      2$             ;SKIP IF MIN VALUE IS 0
699 033170 104401 050166     TYPE    ,MSGMIN
700 033174 004737 026136     JSR      PC,$SB2D      ;CONVERT TO DECIMAL
701 033200 004737 026366     JSR      PC,$SUPRS     ;TYPE IT

```

```

702 033204 104401 050210
703 033210 104401 050174
704 033214 011246
705 033216 004737 026136
706 033222 004737 026366
707 033226 104401 050210
708 033232 104401 001231
709 033236 000200
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728 033240
      033240 010246
      033242 010346
      033244 010446
      033246 010546
729 033250 012002
730 033252 032777 000100 145674
731 033260 001154
732 033262 012237 033302
733 033266 012205
734 033270 012203
735 033272 011202
736 033274 012704 001376
737 033300 104401
738 033302 000000
739 033304 005764 000014
740 033310 001536
741 033312 104401 050166
742 033316 012446
      033320 004737 026136
      033324 004737 026366
743 033330 104401 050210
744 033334 005724
745 033336 001421
746 033340 104401 050345
747 033344 016446 177776
      033350 004737 026136
      033354 004737 026366
748 033360 104401 050215
749 033364 010346
      033366 004737 026136

```

```

2$:   TYPE      ,MSGOUS      ;0 US
      TYPE      ,MSGMAX      ;
      MOV       (R2),-(SP)    ;MAXIMUM VALUE
      JSR       PC,$SB2D      ;
      JSR       PC,$SUPRS     ;
      TYPE      ,MSGOUS      ;
      TYPE      ,$CRLF       ;CR-LF
3$:   RTS       R0           ;

::THIS ROUTINE IS USED TO TYPE THE MINIMUM,
::MAXIMUM, AND AVERAGE TIMES FOR THE TIMING TESTS
::IT WILL ALSO CHECK THE TIMES TO ENSURE
::THEY ARE WITHIN TOLERANCE AND IF NOT FLAG THE BAD TIMES.
::NOTE: THIS ROUTINE DESTROYS R2-R5
::CALL
      JSR       R0,TYPTIM     ;GO REPORT THE TIMES
      TABLE    ;POINT TO THE PROPER TABLE
      RETURN
      TABLE:  MSGADR1       ;ADDRESS OF ASCIZ MESSAGE NUMBER 1
      MSGADR2   ;ADDRESS OF ASCIZ MESSAGE NUMBER 2
      MIN.ALLOWED ;MINIMUM TIME ALLOWED
      MAX.ALLOWED ;MAXIMUM TIME ALLOWED

TYPTIM:
      MOV       R2,-(SP)      ;:PUSH R2 ON STACK
      MOV       R3,-(SP)      ;:PUSH R3 ON STACK
      MOV       R4,-(SP)      ;:PUSH R4 ON STACK
      MOV       R5,-(SP)      ;:PUSH R5 ON STACK
      MOV       (R0)+,R2      ;:PICKUP THE TABLE POINTER
      BIT       #SW06,@SWR    ;:INHIBIT TIME REPORTS?
      BNE       9$           ;:YES--BRANCH
      MOV       (R2)+,2$      ;:ADDRESS OF MESSAGE NUMBER 1
      MOV       (R2)+,R5      ;:ADDRESS OF MESSAGE NUMBER 2
      MOV       (R2)+,R3      ;:PICKUP THE LOW LIMIT
      MOV       (R2),R2       ;:AND THE HIGH LIMIT
      MOV       #TIM.UP,R4    ;:PARAMETER POINTER
1$:   TYPE      ;TYPE THE MESSAGE
2$:   .WORD     0             ;:ASCIZ MESSAGE POINTER GOES HERE
      TST      14(R4)        ;:DID ANY COUNTS OCCUR?
      BEQ      8$           ;:NO--BRANCH
      TYPE      ,MSGMIN      ;:'MIN='
      MOV       (R4)+,-(SP)   ;:PUT (R4)+ ON THE STACK
      JSR       PC,$SB2D     ;:CHANGE TO DECIMAL ASCIZ
      JSR       PC,$SUPRS     ;:TYPE WITHOUT LEADING ZEROS
      TYPE      ,MSGOUS      ;:'0 US'
      TST      (R4)+         ;:ANY SEEKS BELOW THE LOW LIMIT
      BEQ      3$           ;:NO--BRANCH
      TYPE      ,BLNKS2      ;:TYPE 2 SPACES
      MOV       -2(R4),-(SP)  ;:PUT -2(R4) ON THE STACK
      JSR       PC,$SB2D     ;:CHANGE TO DECIMAL ASCIZ
      JSR       PC,$SUPRS     ;:TYPE WITHOUT LEADING ZEROS
      TYPE      ,M BELOW    ;:'BELOW THE MINIMUM OF'
      MOV       R3,-(SP)     ;:PUT R3 ON THE STACK
      JSR       PC,$SB2D     ;:CHANGE TO DECIMAL ASCIZ

```

	033372	004737	026366		JSR	PC,\$SUPRS	:TYPE WITHOUT LEADING ZEROS
750	033376	104401	050210		TYPE	,MSGOUS	
751	033402	104401	050174	3\$:	TYPE	,MSGMAX	: 'MAX='
752	033406	012446			MOV	(R4)+,-(SP)	:PUT (R4)+ ON THE STACK
	033410	004737	026136		JSR	PC,\$SB2D	:CHANGE TO DECIMAL ASCIZ
	033414	004737	026366		JSR	PC,\$SUPRS	:TYPE WITHOUT LEADING ZEROS
753	033420	104401	050210		TYPE	,MSGOUS	
754	033424	005724			TST	(R4)+	:ANY SEEKS ABOVE THE HIGH LIMIT
755	033426	001421			BEQ	4\$:NO--BRANCH
756	033430	104401	050345		TYPE	,BLNKS2	:TYPE 2 SPACES
757	033434	016446	177776		MOV	-2(R4),-(SP)	:PUT -2(R4) ON THE STACK
	033440	004737	026136		JSR	PC,\$SB2D	:CHANGE TO DECIMAL ASCIZ
	033444	004737	026366		JSR	PC,\$SUPRS	:TYPE WITHOUT LEADING ZEROS
758	033450	104401	050244		TYPE	,MABOVE	: 'ABOVE THE MAXIMUM OF'
759	033454	010246			MOV	R2,-(SP)	:PUT R2 ON THE STACK
	033456	004737	026136		JSR	PC,\$SB2D	:CHANGE TO DECIMAL ASCIZ
	033462	004737	026366		JSR	PC,\$SUPRS	:TYPE WITHOUT LEADING ZEROS
760	033466	104401	050210		TYPE	,MSGOUS	
761	033472	104401	050202	4\$:	TYPE	,MSGAVG	: 'AVG='
762	033476	012446			MOV	(R4)+,-(SP)	:FORM THE AVERAGE
763	033500	012446			MOV	(R4)+,-(SP)	
764	033502	012446			MOV	(R4)+,-(SP)	
765	033504	004737	026530		JSR	PC,\$DIV	
766	033510	006126			RGL	(SP)+	:IS THE REMAINDER OVER HALF
767	033512	100001			BPL	5\$:NO--BRANCH
768	033514	005216			INC	(SP)	:YES--ROUND UP
769	033516			5\$:			
	033516	004737	026136		JSR	PC,\$SB2D	:CHANGE TO DECIMAL ASCIZ
	033522	004737	026366		JSR	PC,\$SUPRS	:TYPE WITHOUT LEADING ZEROS
770	033526	104401	050210		TYPE	,MSGOUS	
771	033532	104401	050345		TYPE	,BLNKS2	:TYPE 2 SPACES
772	033536	016446	177776		MOV	-2(R4),-(SP)	:PUT -2(R4) ON THE STACK
	033542	004737	026136		JSR	PC,\$SB2D	:CHANGE TO DECIMAL ASCIZ
	033546	004737	026366		JSR	PC,\$SUPRS	:TYPE WITHOUT LEADING ZEROS
773	033552	022737	000012	001116	CMF	#12,\$STNM	:TEST '2'
774	033560	001403			BEQ	6\$:BRANCH IF SO
775	033562	104401	050313		TYPE	,MSGNUM	:TYPE 'SEEKS TIMED'
776	033566	000402			BR	7\$:TYPE IT
777	033570	104401	050273	6\$:	TYPE	,MSGSEA	:TYPE 'SEARCHES TIMED'
778							
779	033574	010537	033302	7\$:	MOV	R5,2\$:NEXT MESSAGE POINTER
780	033600	001404			BEQ	9\$:IF NONE EXIT
781	033602	005005			CLR	R5	:NO MORE THAN 2
782	033604	000635			BR	1\$	
783	033606	104401	050330	8\$:	TYPE	,MSGNON	
784	033612			9\$:			
	033612	012605			MOV	(SP)+,R5	::POP STACK INTO R5
	033614	012604			MOV	(SP)+,R4	::POP STACK INTO R4
	033616	012603			MOV	(SP)+,R3	::POP STACK INTO R3
	033620	012602			MOV	(SP)+,R2	::POP STACK INTO R2
785	033622	000200			RTS	R0	:EXIT

786
787
788
789
790

```

:THIS SUBROUTINE WILL INCREMENT THE TRACK
:NUMBER (R2) BY THE AMOUNT SPECIFIED BY 'IT'.
:CALL
:
: JSR R0,INCRK
: RETURN1
: TRACK NUMBER GREATER THAN L'15
    
```



```

792                                     :      RETURN2                               ;TRACK NUMBER INCREMENTED
793
794 033624 020237 002350 INCTRK: CMP      R2,LT                       ;LAST TRACK COMPLETED?
795 033630 001410          BEQ      2$                               ;YES--EXIT
796 033632 063702 002352          ADD      IT,R2                       ;NO--UPDATE TRACK
797 033636 020237 002350          CMP      R2,LT                       ;TRACK TO BIG?
798 033642 003402          BLE      1$                               ;NO--EXIT
799 033644 013702 002350          MOV      LT,R2                       ;YES--SET TRACK TO LAST TRACK
800 033650 005720          1$: TST      (R0)+                       ;ADJUST FOR RETURN 2
801 033652 000200          2$: RTS      R0                               ;RETURN
802
803
804                                     ;THIS SUBROUTINE WILL INCREMENT THE CYLINDER
805                                     ;NUMBER (R1) BY THE AMOUNT SPECIFIED BY 'IC'.
806                                     ;CALL
807                                     :
808                                     :      JSR      R0,INCCYL
809                                     :      RETURN1
810                                     :      RETURN2                               ;CYLINDER NUMBER GREATER THAN LC15
811                                     ;CYLINDER NUMBER INCREMENTED
812
811 033654 020137 002342 INCCYL: CMP      R1,LC                       ;LAST CYLINDER COMPLETED?
812 033660 001410          BEQ      2$                               ;YES--EXIT
813 033662 063701 002344          ADD      IC,R1                       ;NO--UPDATE CYLINDER
814 033666 020137 002342          CMP      R1,LC                       ;CYLINDER TO BIG?
815 033672 003402          BLE      1$                               ;NO--EXIT
816 033674 013701 002342          MOV      LC,R1                       ;YES--SET CYLINDER TO LAST CYLINDER
817 033700 005720          1$: TST      (R0)+                       ;ADJUST FOR RETURN 2
818 033702 000200          2$: RTS      R0                               ;RETURN
819
820                                     ;THIS ROUTINE DECREASES THE SECTOR ADDRESS.
821                                     ;CALL
822                                     :
823                                     :      CLR      -(SP)                       ;CLEAR THE STACK
824                                     :      JSR      PC,DECSEC                       ;SUBROUTINE ENTRY
825                                     :      RETURN
826
826 033704 113766 047146 000002 DECSEC: MOVW    RM,REG+RMDA,2(SP)           ;PUT THE SECTOR ADDRESS ON THE STACK
827 033712 005366 000002          DEC      2(SP)                       ;DECREMENT THE ADDRESS
828 033716 100003          BPL      1$                               ;BR IF NOT CORRECTION NEEDED
829 033720 013766 002470 000002          MOV      PRMLMT+24,2(SP)           ;OVERFLOW OCCURED, FORCE TO MAXIMUM ADDRESS
830 033726 000207          1$: RTS      PC                               ;RETURN
831
832                                     ;THIS SUBROUTINE IS USED TO FILL THE DATA BUFFER
833                                     ;WITH ADDRESSES FROM 0 TO 31 WITH EACH ADDRESS
834                                     ;BEING STORED IN 256 CONSECUTIVE LOCATIONS
835                                     ;CALL
836                                     :
837                                     :      JSR      PC,FILBUF
838                                     :      RETURN
839
839 033730 104412          FILBUF: SAVREG
840 033732 005000          CLR      R0                               ;SAVE R0 - R5
841 033734 012701 054522          MOV      #BUFFER,R1                       ;FIRST DISK ADDRESS
842 033740 012702 000400          1$: MOV      #256,R2                       ;START FILLING HERE
843 033744 010021          2$: MOV      R0,(R1)+                       ;DO 256 WORDS
844 033746 005302          DEC      R2                               ;STORE
845 033750 003375          BGT      2$                               ;MORE?
846 033752 005200          INC      R0                               ;YES--BRANCH
847 033754 023700 002470          CMP      PRMLMT+24,R0                       ;NO--UPDATE DISK ADDRESS
848 033760 103367          BHIS   1$                               ;DONE?
                                         ;NO--BRANCH

```

```

849 033762 104413          RESREG          ;RESTORE R0 - R5
850 033764 000207          RTS            PC          ;RETURN
851
852                          ;THIS ROUTINE WILL CLEAR THE BUFFER BY
853                          ;SETTING EACH WORD TO '177400'.
854                          ;CALL
855                          ;
856                          ;      JSR      R0,CLRBUF
857                          ;      RETURN
858 033766 104412          CLRBUF: SAVREG          ;SAVE R0 - R5
859 033770 012701 177400    MOV      #177400,R1      ;WORD TO FILL BUFFER WITH
860 033774 012702 054522    MOV      #BUFFER,R2     ;FIRST ADDRESS OF BUFFER
861 034000 012703 114522    MOV      #BUFFER+<512.*32>,R3 ;LAST ADDRESS+2 OF BUFFER
862 034004 010122          1$: MOV      R1,(R2)+      ;FILL WORDS 1, 9,...249,...5625
863 034006 010122          MOV      R1,(R2)+      ;FILL WORDS 2,10,...250,...5626
864 034010 010122          MOV      R1,(R2)+      ;FILL WORDS 3,11,...251,...5627
865 034012 010122          MOV      R1,(R2)+      ;FILL WORDS 4,12,...252,...5628
866 034014 010122          MOV      R1,(R2)+      ;FILL WORDS 5,13,...253,...5629
867 034016 010122          MOV      R1,(R2)+      ;FILL WORDS 6,14,...254,...5630
868 034020 010122          MOV      R1,(R2)+      ;FILL WORDS 7,15,...255,...5631
869 034022 010122          MOV      R1,(R2)+      ;FILL WORDS 8,16,...256,...5632
870 034024 020203          CMP      R2,R3          ;DONE?
871 034026 103766          BLO     1$             ;NO--BRANCH
872 034030 104413          RESREG          ;RESTORE R0 - R5
873 034032 000200          RTS            R0          ;RETURN FROM CALL
874
875                          ;THIS ROUTINE IS USED TO CHECK THE DATA BUFFER
876                          ;FOR ADDRESSES 0 THROUGH 31 WITH EACH ADDRESS
877                          ;BEING STORED IN 256 CONSECUTIVE LOCATIONS
878                          ;CALL
879                          ;
880                          ;      JSR      R0,CKSCTR
881                          ;      RETURN
882 034034 104412          CKSCTR: SAVREG          ;SAVE R0 - R5
883 034036 162706 000004    SUB      #4,SP          ;RESERVE TEMP. STORAGE AREA
884 034042 005001          CLR      R1            ;FIRST SECTOR
885 034044 012716 054522    MOV      #BUFFER,(SP)  ;FIRST ADDRESS OF DATA BUFFER
886 034050 005066 000002    CLR      2(SP)         ;NO ERRORS
887 034054 012702 000020    1$: MOV      #16.,R2     ;LOOP COUNT (16*16=256)
888 034060 011603          MOV      (SP),R3       ;GET 1ST ADDRESS OF THIS SECTORS DATA
889 034062
893 034062 020123          2$: CMP      R1,(R3)+    ;WORD 1
894 034064 001063          BNE     7$             ;BRANCH IF BAD
895 034066 020123          CMP      R1,(R3)+    ;WORD 2
896 034070 001061          BNE     7$             ;BRANCH IF BAD
897 034072 020123          CMP      R1,(R3)+    ;WORD 3
898 034074 001057          BNE     7$             ;BRANCH IF BAD
899 034076 020123          CMP      R1,(R3)+    ;WORD 4
900 034100 001055          BNE     7$             ;BRANCH IF BAD
901 034102 020123          CMP      R1,(R3)+    ;WORD 5
902 034104 001053          BNE     7$             ;BRANCH IF BAD
903 034106 020123          CMP      R1,(R3)+    ;WORD 6
904 034110 001051          BNE     7$             ;BRANCH IF BAD
905 034112 020123          CMP      R1,(R3)+    ;WORD 7
906 034114 001047          BNE     7$             ;BRANCH IF BAD
907 034116 020123          CMP      R1,(R3)+    ;WORD 8
908 034120 001045          BNE     7$             ;BRANCH IF BAD
    
```

034122	020123			CMP	R1,(R3)+	:WORD 9
034124	001043			BNE	7\$:BRANCH IF BAD
034126	020123			CMP	R1,(R3)+	:WORD 10
034130	001041			BNE	7\$:BRANCH IF BAD
034132	020123			CMP	R1,(R3)+	:WORD 11
034134	001037			BNE	7\$:BRANCH IF BAD
034136	020123			CMP	R1,(R3)+	:WORD 12
034140	001035			BNE	7\$:BRANCH IF BAD
034142	020123			CMP	R1,(R3)+	:WORD 13
034144	001033			BNE	7\$:BRANCH IF BAD
034146	020123			CMP	R1,(R3)+	:WORD 14
034150	001031			BNE	7\$:BRANCH IF BAD
034152	020123			CMP	R1,(R3)+	:WORD 15
034154	001027			BNE	7\$:BRANCH IF BAD
034156	020123			CMP	R1,(R3)+	:WORD 16
034160	001025			BNE	7\$:BRANCH IF BAD
894 034162	005302			DEC	R2	:FINISHED WITH THIS SECTORS DATA?
895 034164	001336			BNE	2\$:NO--BRANCH
896 034166	062716	001000	3\$:	ADD	#512.,(SP)	:YES--FIRST ADDRESS OF NEXT SECTOR
897 034172	005201			INC	R1	:MOVE TO NEXT SECTOR
898 034174	023701	002470		CMP	PRMLMT+24,R1	:DONE?
899 034200	103325			BHIS	1\$:NO--BRANCH
900 034202	005766	000002	4\$:	TST	2(SP)	:ERROR OCCUR?
901 034206	001406			BEQ	6\$:NO--BRANCH
902 034210	123737	001464	00117	CMPB	ERR.CT,\$ERFLG	:MAX. ERROR OCCURRED?
903 034216	101002			BHI	6\$:NO--BRANCH
904 034220	013700	001350	5\$:	MOV	BYPASS,R0	:TAKE ERROR EXIT
905 034224	062706	000004	6\$:	ADD	#4,SP	:FREE TEMP. AREA
906 034230	104413			RESREG		:RESTORE R0 - R5
907 034232	000200			RTS	R0	:RETURN FROM CALL
908 034234	010304		7\$:	MOV	R3,R4	:FORM WORD NUMBER AND
909 034236	161604			SUB	(SP),R4	:ADDRESS TO CONTINUE FROM
910 034240	010405			MOV	R4,R5	
911 034242	006204			ASR	R4	:WORD NUMBER
912 034244	042705	177740		BIC	#^C37,R5	
913 034250	001002			BNE	8\$:BRANCH IF NOT A MULTIPLE OF 16
914 034252	012705	000040		MOV	#40,R5	:SET TO WORD 16
915 034256	006305		8\$:	ASL	R5	
916 034260	062705	034062		ADD	#2\$,R5	:ADDRESS
917 034264	016337	177776	001142	MOV	-2(R3),\$BDDAT	:SAVE BAD DATA
918 034272	005766	000002		TST	2(SP)	:FIRST ERROR?
919 034276	001015			BNE	10\$:NO--BRANCH
920 034300	013737	047110	001366	MOV	DTADPB+12,CYL.DS	:CYLINDER NUMBER
921 034306	113737	047107	001372	MOV	B DTADPB+11,TRK.DS	:TRACK NUMBER
922 034314	012737	034324	001222	MOV	#9\$,\$ESCAPE	::ESCAPE TO 9\$ ON ERROR
923 034322	104021			EMT	21	:DATA COMPARE FAILURE
924 034324	105166	000002	9\$:	COMB	2(SP)	:SET ERROR SWITCH
925 034330	000404			BR	11\$	
926						
927 034332			10\$:			
034332	012737	034342	001222	MOV	#11\$,\$ESCAPE	::ESCAPE TO 11\$ ON ERROR
928 034340	104022			EMT	22	:FOLLOWS EMT 21
929 034342	032777	001000	144604	11\$:	#SW09,@SWR	:LOOP ON ERROR?
930 034350	001323			BNE	5\$:YES
931 034352	032777	000002	144574	BIT	#SW01,@SWR	:STOP DATA COMPARE?
932 034360	001310			BNE	4\$:YES--BRANCH
933 034362	123737	001464	001117	CMPB	ERR.CT,\$ERFLG	:MAX. ERRORS?

```

934 034370 101713      BLOS 5$ ;YES--BRANCH
935 034372 032777 000040 144554 BIT #SW05,@SWR ;REPORT ONLY 1ST ERROR PER SECTOR?
936 034400 001272      BNE 3$ ;YES--BRANCH
937 034402 000115      JMP (R5)
938
939 ;THIS ROUTINE WILL MOVE THE 16 WORDS OF THE
940 ;DESIRED PATTERN INTO THE DATA BUFFER.
941 ;CALL
942 ;
943 ; MOV #NX,R0 ;PATTERN NUMBER INDEX TO R0
944 ; JSR PC,SETBUF
945
945 034404 104412      SETBUF: SAVREG ;SAVE R0 - R5
946 034406 012701 054522 MOV #BUFFER,R1 ;FIRST ADDRESS
947 034412 013702 047102 MOV DTADPB+4,R2 ;WORD COUNT
948 034415 016003 003536 1$: MOV PAT,PT(R0),R3 ;PICKUP PATTERN POINTER
951 034422 012321 MOV (R3)+,(R1)+ ;MOVE WORD 1 INTO DATA BUFFER
    034424 012321 MOV (R3)+,(R1)+ ;MOVE WORD 2 INTO DATA BUFFER
    034426 012321 MOV (R3)+,(R1)+ ;MOVE WORD 3 INTO DATA BUFFER
    034430 012321 MOV (R3)+,(R1)+ ;MOVE WORD 4 INTO DATA BUFFER
    034432 012321 MOV (R3)+,(R1)+ ;MOVE WORD 5 INTO DATA BUFFER
    034434 012321 MOV (R3)+,(R1)+ ;MOVE WORD 6 INTO DATA BUFFER
    034436 012321 MOV (R3)+,(R1)+ ;MOVE WORD 7 INTO DATA BUFFER
    034440 012321 MOV (R3)+,(R1)+ ;MOVE WORD 8 INTO DATA BUFFER
    034442 012321 MOV (R3)+,(R1)+ ;MOVE WORD 9 INTO DATA BUFFER
    034444 012321 MOV (R3)+,(R1)+ ;MOVE WORD 10 INTO DATA BUFFER
    034446 012321 MOV (R3)+,(R1)+ ;MOVE WORD 11 INTO DATA BUFFER
    034450 012321 MOV (R3)+,(R1)+ ;MOVE WORD 12 INTO DATA BUFFER
    034452 012321 MOV (R3)+,(R1)+ ;MOVE WORD 13 INTO DATA BUFFER
    034454 012321 MOV (R3)+,(R1)+ ;MOVE WORD 14 INTO DATA BUFFER
    034456 012321 MOV (R3)+,(R1)+ ;MOVE WORD 15 INTO DATA BUFFER
    034460 012321 MOV (R3)+,(R1)+ ;MOVE WORD 16 INTO DATA BUFFER
952 034462 062702 000020 ADD #16,,R2 ;DONE?
953 034466 001353 BNE 1$ ;NO--BRANCH
954 034470 104413 RESREG ;RESTORE R0 - R5
955 034472 000207 RTS PC ;RETURN
956
957 ;THIS ROUTINE COMPARES A 16 WORD DATA PATTERN
958 ;AGAINST THE DATA BUFFER
959 ;CALL
960 ;
961 ; MOV #NX,R0 ;PATTERN NUMBER INDEX TO R0
962 ; JSR PC,DATCMP
963 ; RETURN
964
964 034474 104412      DATCMP: SAVREG ;SAVE R0 - R5
965 034476 012701 054522 MOV #BUFFER,R1 ;FIRST ADDRESS OF BUFFER
966 034502 013702 047102 MOV DTADPB+4,R2 ;WORD COUNT
967 034506 005046 CLR -(SP) ;NO ERROR
968 034510 016003 003536 1$: MOV PAT,PT(R0),R3 ;PATTERN POINTER
969 034514 2$:
972 034514 162321 SUB (R3)+,(R1)+ ;CHECK WORD 1
    034516 001044 BNE 4$ ;BRANCH IF DIFFERENT
    034520 162321 SUB (R3)+,(R1)+ ;CHECK WORD 2
    034522 001042 BNE 4$ ;BRANCH IF DIFFERENT
    034524 162321 SUB (R3)+,(R1)+ ;CHECK WORD 3
    034526 001040 BNE 4$ ;BRANCH IF DIFFERENT
    034530 162321 SUB (R3)+,(R1)+ ;CHECK WORD 4
    034532 001036 BNE 4$ ;BRANCH IF DIFFERENT
  
```

	034534	162321			SUB	(R3)+,(R1)+	:CHECK WORD 5
	034536	001034			BNE	4\$:BRANCH IF DIFFERENT
	034540	162321			SUB	(R3)+,(R1)+	:CHECK WORD 6
	034542	001032			BNE	4\$:BRANCH IF DIFFERENT
	034544	162321			SUB	(R3)+,(R1)+	:CHECK WORD 7
	034546	001030			BNE	4\$:BRANCH IF DIFFERENT
	034550	162321			SUB	(R3)+,(R1)+	:CHECK WORD 8
	034552	001026			BNE	4\$:BRANCH IF DIFFERENT
	034554	162321			SUB	(R3)+,(R1)+	:CHECK WORD 9
	034556	001024			BNE	4\$:BRANCH IF DIFFERENT
	034560	162321			SUB	(R3)+,(R1)+	:CHECK WORD 10
	034562	001022			BNE	4\$:BRANCH IF DIFFERENT
	034564	162321			SUB	(R3)+,(R1)+	:CHECK WORD 11
	034566	001020			BNE	4\$:BRANCH IF DIFFERENT
	034570	162321			SUB	(R3)+,(R1)+	:CHECK WORD 12
	034572	001016			BNE	4\$:BRANCH IF DIFFERENT
	034574	162321			SUB	(R3)+,(R1)+	:CHECK WORD 13
	034576	001014			BNE	4\$:BRANCH IF DIFFERENT
	034600	162321			SUB	(R3)+,(R1)+	:CHECK WORD 14
	034602	001012			BNE	4\$:BRANCH IF DIFFERENT
	034604	162321			SUB	(R3)+,(R1)+	:CHECK WORD 15
	034606	001010			BNE	4\$:BRANCH IF DIFFERENT
	034610	162321			SUB	(R3)+,(R1)+	:CHECK WORD 16
	034612	001006			BNE	4\$:BRANCH IF DIFFERENT
973	034614	062702	000020		ADD	#16.,R2	:DONE ?
974	034620	001333			BNE	1\$:NO--BRANCH
975	034622	005726		3\$:	TST	(SP)+	:YES -- CLEAN UP STACK
976	034624	104413			RESREG		:RESTORE R0 - R5
977	034626	000207			RTS	PC	
978							
979	034630	010104			MOV	R1,R4	:FORM THE WORD NUMBER
980	034632	162704	054522		SUB	#BUFFER,R4	
981	034636	006204			ASR	R4	:WORD NUMBER
982	034640	010305			MOV	R3,R5	:FORM ADDRESS TO CONTINUE FROM
983	034642	166005	003536		SUB	PAT.PT(R0),R5	
984	034646	006305			ASL	R5	
985	034650	062705	034514		ADD	#2\$,R5	:ADDRESS
986	034654	064341			ADD	-(R3),-(R1)	:RECONSTRUCT THE BAD WORD
987	034656	010137	001136		MOV	R1,\$BDADR	:SAVE THE ERROR INFORMATION
988	034662	010337	001134		MOV	R3,\$GDADR	:
989	034666	012137	001142		MOV	(R1)+,\$BDDAT	:
990	034672	012337	001140		MOV	(R3)+,\$GDDAT	:
991	034676	005716			TST	(SP)	:1ST DATA COMPARE ERROR?
992	034700	001023			BNE	6\$:NO--BRANCH
993	034702	013737	047110	001366	MOV	DTADPB+12,CYL.DS	:CYLINDER
994	034710	113737	047107	001372	MOV	DTADPB+11,TRK.DS	:TRACK
995	034716	113737	047106	001370	MOV	DTADPB+10,SEC.DS	:SECTOR
996	034724	016600	000026		MOV	26(SP),R0	:GET TEST PC+4
997	034730	012737	034740	001222	MOV	#5\$, \$ESCAPE	:ESCAPE TO 5\$ ON ERROR
998	034736	104013			EMT	13	:DATA COMPARE FAILURE
999	034740	016600	000020	5\$:	MOV	20(SP),R0	:PATTERN NUMBER INDEX
1000	034744	105116			COMB	(SP)	:SET THE ERROR SWITCH
1001	034746	000404			BR	7\$	
1002							
1003	034750						
	034750	012737	034760	001222	MOV	#7\$, \$ESCAPE	:ESCAPE TO 7\$ ON ERROR
1004	034756	104014			EMT	14	:FOLLOWS EMT 13

```

1005 034760 032777 000002 144166 7$: BIT #JW01,@SWR ;STOP DATA COMPARE?
1006 034766 001315 BNE 3$ ;YES--EXIT
1007 034770 123737 001464 001117 CMPB ERR.CT,$ERFLG ;MAX. ERRORS?
1008 034776 101004 BHI 8$ ;NO--BRANCH
1009 035000 013766 001350 000002 MOV BYPASS,2(SP) ;YES--ERROR EXIT
1010 035006 000705 BR 3$
1011 035010 000115 8$: JMP (R5) ;NO--CONTINUE AT NEXT WORD
1012
1013 ;THIS ROUTINE WILL FILL THE DATA BUFFER (256*32 WORDS) WITH
1014 ;A RANDOM PATTERN. THE FIRST TWO WORDS OF EVERY 256 WILL
1015 ;BE THE BASE OF THE RANDOM NUMBER GENERATOR FOR THE
1016 ;NEXT 254 WORDS.
1017 ;NOTE: THIS ROUTINE DESTROYS R1 AND R2
1018 ;CALL
1019 ; JSR RO,FILRAN
1020 ; RETURN
1021
1022 035012 012701 054522 FILRAN: MOV #BUFFER,R1
1023 035016 013702 002470 MOV PRMLMT+24,R2 ;MAXIMUM NUMBER OF SECTORS
1024 035022 004037 035232 1$: JSR RO,RANPAT
1025 035026 005302 DEC R2
1026 035030 100374 BPL 1$
1027 035032 000200 RTS RO
1028
1029 ;THIS ROUTINE USES THE FIRST TWO WORDS OF THE
1030 ;READ BUFFER TO GENERATED A RANDOM PATTERN. THEN
1031 ;THE READ BUFFER IS COMPARED TO THE PATTERN GENERATED.
1032 ;NOTE: THIS ROUTINE DESTROYS R1-R4
1033 ;CALL
1034 ; JSR RO,RANCK
1035 ; RETURN
1036
1037 035034 013746 026524 RANCK: MOV $HINUM,-(SP) ;SAVE THE PRESENT RANDOM NUMBER
1038 035040 013746 026526 MOV $LONUM,-(SP)
1039 035044 012702 055522 MOV #BUFFER+512.,R2 ;READ BUFFER ADDRESS
1040 035050 012701 056522 MOV #BUFFER+1024.,R1 ;RANDOM PATTERN ADDRESS
1041 035054 010103 MOV R1,R3 ;COPY IT INTO R3 FOR LATER USE
1042 035056 011237 026526 MOV (R2),$LONUM ;PRIME THE RANDOM NUMBER GENERATOR
1043 035062 016237 000002 026524 MOV 2(R2),$HINUM
1044 035070 004037 035232 JSR RO,RANPAT ;GENERATE A RANDOM PATTERN
1045 035074 012637 026526 MOV (SP)+,$LONUM ;RESTORE PRESENT RANDOM NUMBER
1046 035100 012637 026524 MOV (SP)+,$HINUM
1047 035104 005046 CLR -(SP) ;NO ERRORS
1048 035106 162322 1$: SUB (R3)+,(R2)+ ;ARE THESE TWO WORDS DIFFERENT?
1049 035110 001441 BEQ 4$ ;NO--BRANCH
1050 035112 012737 035164 001222 MOV #3$, $ESCAPE ;ESCAPE TO 3$ ON ERROR
1051 035120 064342 ADD -(R3),-(R2) ;RECREATE THE BAD WORD
1052 035122 010237 001136 MOV R2,$BDADR ;ADDRESS OF BAD DATA
1053 035126 010337 001134 MOV R3,$GDADR ;ADDRESS OF GOOD DATA
1054 035132 012237 001147 MOV (R2)+,$BDDAT ;BAD DATA
1055 035136 012337 001140 MOV (R3)+,$GDDAT ;GOOD DATA
1056 035142 010204 MOV R2,R4 ;FORM WORD NUMBER (1 TO 256)
1057 035144 162704 055522 SUB #BUFFER+512.,R4
1058 035150 006204 ASR R4
1059 035152 005716 TST (SP) ;FIRST ERROR
1060 035154 001002 BNE 2$ ;NO--BRANCH
1061 035156 105116 COMB (SP) ;YES--SET ERROR SWITCH

```

```

1062 035160 104015          EMT      15          ;DATA COMPARE FAILURE
1063 035162          2$:      EMT      16          ;FOLLOWS EMT 15
      035162 104016          BIT      #SW09,@SWR    ;LOOP ON ERROR?
1064 035164 032777 001000 143762 3$:      BNF      5$          ;YES--BRANCH
1065 035172 001012          CMPB    ERR.CT,$ERFLG ;MAX. ERRORS OCCURRED?
1066 035174 123737 001464 001117          BLOS    5$          ;YES--BRANCH
1067 035202 101406          BIT      #SW01,@SWR    ;STOP COMPARING?
1068 035204 032777 000002 143742          BNE     5$          ;YES--BRANCH
1069 035212 001002          4$:      LMP     R1,R3      ;ALL DATA BEEN COMPARED?
1070 035214 020103          BHI     1$          ;NO--BRANCH
1071 035216 101333          5$:      TST     (SP)+    ;ERROR OCCUR?
1072 035220 005726          BEQ     6$          ;NO--BRANCH
1073 035222 001402          MOV     BYPASS,R0    ;TAKE ERROR EXIT
1074 035224 013700 001350          6$:      RTS      R0      ;EXIT
1075 035230 000200
1076
1077          ;THIS ROUTINE FILLS A 256 WORD BUFFER WITH A RANDOM
1078          ;PATTERN OF WHICH THE FIRST TWO WORDS ARE THE BASE
1079          ;OF THE PATTERN.
1080          ;CALL
1081          ;      MOV     #ADR,R1      ;ADDRESS OF THE BUFFER
1082          ;      JSR     R0,RANPAT
1083          ;      RETURN
1084
1085 035232 010246          RANPAT: MOV     R2,-(SP)    ;SAVE R2
1086 035234 012702 000200          MOV     #256/2.,R2    ;GENERATE 256 WORDS
1087 035240 000402          BR      2$
1088 035242 004737 026426          1$:      JSR     PC,$RAND    ;GENERATE A RANDOM NUMBER
1089 035246 013721 026526          2$:      MOV     $LONUM,(R1)+ ;PUT LOW WORD IN BUFFER
1090 035252 013721 026524          MOV     $HINUM,(R1)+  ;PUT HIGH WORD IN BUFFER
1091 035256 005302          DEC     R2          ;DONE?
1092 035260 003370          BGT     1$          ;NO--BRANCH
1093 035262 012602          MOV     (SP)+,R2    ;RESTORE R2
1094 035264 000200          RTS      R0      ;EXIT
1095
1096          ;THIS ROUTINE GENERATES RANDOM CYLINDER, TRACK, AND SECTOR
1097          ;ADDRESSES AND SAVES THEM IN THE DPB (DTADPB+10, 11 & DTADPB+12).
1098          ;NOTE: THIS ROUTINE DESTROYS R1-R3
1099          ;CALL
1100          ;      JSR     R0,RANADR
1101          ;      RETURN
1102
1103 035266 004737 026426          RANADR: JSR     PC,$RAND    ;GENERATE A RANDOM NUMBER
1104 035272 113701 026526          MOVB    $LONUM,R1    ;FORM SECTOR IN R1
1105 035276 113702 026527          MOVB    $LONUM+1,R2  ;FORM TRACK IN R2
1106 035302 013703 026524          MOV     $HINUM,R3    ;FORM CYLINDER IN R3
1107 035306 105701          TSTB   R1          ;ENSURE THE SECTOR IS BETWEEN 0 AND 31
1108 035310 002403          BLT     2$
1109 035312 123701 002470          1$:      CMPB    PRMLMT+24,R1 ;CHECK MAXIMUM SECTOR ADDRESS
1110 035316 103003          BHIS   3$
1111 035320 000241          2$:      CLC
1112 035322 106001          RORB   R1
1113 035324 000772          BR      1$
1114 035326 105702          3$:      TSTB   R2          ;ENSURE THE TRACK IS BETWEEN 0 AND LAST TRACK
1115 035330 002403          BLT     5$
1116 035332 123702 001374          4$:      CMPB    LSTRK,R2
1117 035336 002003          BGE     6$

```

```

1118 035340 000241          5$:   CLC
1119 035342 106002          RORB   R2
1120 035344 000772          BR     4$
1121 035346 023703 002340    6$:   CMP   FC,R3      ;ENSURE THE CYLINDER IS BETWEEN FC AND LC
1122 035352 003413          BLE   7$
1123 035354 000241          CLC
1124 035356 006003          ROR   R3
1125 035360 005503          ADC   R3
1126 035362 001371          BNE   6$
1127 035364 010103          MOV   R1,R3
1128 035366 000303          SWAB  R3
1129 035370 060203          ADD   R2,R3
1130 035372 005203          INC   R3
1131 035374 003364          BGT   6$
1132 035376 005403          NEG   R3
1133 035400 000762          BR    6$
1134 035402 023703 002342    7$:   CMP   LC,R3
1135 035406 002003          BGE   8$
1136 035410 000241          CLC
1137 035412 006003          ROR   R3
1138 035414 000772          BR    7$
1139 035416 023703 002340    8$:   CMP   FC,R3
1140 035422 003403          BLE   9$
1141 035424 005203          INC   R3
1142 035426 000303          SWAB  R3
1143 035430 000764          BR    7$
1144 035432 110137 047106    9$:   MOVB  R1,DTADPB+10 ;SAVE SECTOR ADDRESS
1145 035436 110237 047107    MOVB  R2,DTADPB+11 ;SAVE TRACK ADDRESS
1146 035442 010337 047110    MOV   R3,DTADPB+12 ;SAVE CYLINDER ADDRESS
1147 035446 000200          RTS   R0           ;RETURN
1148
1149
1150 ;THIS ROUTINE IS USED TO INPUT THE 'CONTROL SWITCHES'.
1151 ;IF SWR<07>=1 THE PRESENT SETTING WILL BE TYPED AND THE NEW
1152 ;SETTING IS READ AND STORED.
1153 ;NOTE: THIS ROUTINE DESTROYS R3 AND R4
1154 ;CALL
1155 ;      JSR   PC,GETSWR
1156 ;      RETURN ;(C.SWR)=DESIRED CONTROL SWITCHES
1157 035450 032777 000200 143476 GETSWR: BIT   #SW07,@SWR ;READ CONTROL SWITCHES?
1158 035456 001430          BEQ   2$           ;NO--BRANCH
1159 035460 104401 035466    TYPE  ,65$        ;TYPE ASCIZ STRING
1160 035464 000410          BR    64$        ;GET OVER THE ASCIZ
1161          ;:65$: .ASCIZ <CRLF>/SET SWR<07>=0/
1162          64$:
1163          1$:   MOV   #MSG.CS,R3 ;'CONTROL SWITCHES='
1164          MOV   C.SWR,R4 ;PRESENT CONTROL SWITCH SETTINGS
1165          JSR   R0,GETNUM ;GET THE NEW SWITCH SETTINGS
1166          BR    1$           ;COMMA
1167          NOP          ;PERIOD
1168          MOV   C.SWR,SAVCSW ;SAVE PREVIOUS VALUE
1169          MOV   R4,C.SWR ;DOUBLE PERIOD-SAVE NEW SWITCH SETTING
1170          2$:   RTS   PC           ;RETURN FROM CALL
1171
1172 ;THIS ROUTINE WILL TYPE AN ASCIZ MESSAGE AND THEN
1173 ;INPUT AN ASCIZ STRING AND CHANGE THE STRING TO OCTAL
1174 ;IF REQUIRED.

```



```

1172                                     ;NOTE: THIS ROUTINE DESTROYS R1
1173                                     ;CALL
1174                                     MOV     #ADR,R3           ;ADDRESS OF ASCIZ MESSAGE
1175                                     MOV     #NUM,R4           ;OCTAL NUMBER
1176                                     JSR     R0,GETNUM
1177                                     RETURN1
1178                                     RETURN2
1179                                     RETURN3
1180                                     ;INPUT TERMINATED WITH A COMMA
1181                                     ;WITH A PERIOD
1182                                     ;WITH A DOUBLE PERIOD
1183                                     ;R4=INPUT NUMBER AND
1184                                     ;R2=R4*32 FOR ALL
1185                                     ;THREE RETURNS
1184 035542 010337 035550 GETNUM: MOV     R3,2$           ;SAVE MESSAGE POINTER
1185 035546 104401 1$      TYPE           ;TYPE THE MESSAGE
1186 035550 000000 2$      .WORD     0           ;MESSAGE POINTER GOES HERE
1187 035552 010446 MOV     R4,-(SP)        ;SAVE R4 FOR TYPEOUT
1188 035554 104402 TYPOC           ;GO TYPE--OCTAL ASCII(ALL DIGITS)
1189 035556 104401 TYPE     .SLASH        ; /
1189 035562 104411 RDLIN         ;READ AN ASCIZ STRING
1190 035564 012601 MOV     (SP)+,R1       ;ADDRESS OF FIRST CHARACTER
1191 035566 004037 JSR     R0,CK.CHR      ;CHECK ONE CHARACTER
1191 035572 035546 1$      ILLEGAL CHARACTER
1191 035574 035546 1$      CARRIAGE RETURN
1191 035576 035610 4$      ;
1191 035600 035634 8$      ;
1191 035602 035642 9$      ;
1191 035604 035606 3$      DIGIT 0-9
1192 035606 005301 3$      DEC     R1           ;DECREMENT THE INPUT POINTER
1193 035610 004037 4$      JSR     R0,CK.NUM      ;CHECK THE NUMBER
1193 035614 035546 1$      ILLEGAL INPUT
1193 035616 035630 7$      TERMINATED WITH A "" OR "CR"
1193 035620 035626 6$      TERMINATED WITH A ""
1193 035622 035624 5$      TERMINATED WITH A ""
1194 035624 005720 5$      TST     (R0)+       ;DOUBLE PERIOD
1195 035626 005720 6$      TST     (R0)+       ;SINGLE PERIOD
1196 035630 010204 7$      MOV     R2,R4           ;COMMA--SAVE INPUT NUMBER
1197 035632 000414 BR      11$           ;GO TO EXIT
1198 035634 105711 8$      TSTB   (R1)         ;TERMINATOR AFTER A COMMA?
1199 035636 001343 BNE    1$           ;NO--LOOP
1200 035640 000411 BR      11$           ;YES--EXIT
1201 035642 105711 9$      TSTB   (R1)         ;TERMINATOR AFTER A PERIOD?
1202 035644 001406 BEQ    10$          ;YES--EXIT
1203 035646 122721 000056 CMPB   #'',(R1)+     ;NO--DOUBLE PERIOD?
1204 035652 001335 BNE    1$           ;NO--LOOP
1205 035654 105711 TSTB   (R1)         ;YES--TERMINATOR?
1206 035656 001333 BNE    1$           ;NO--LOOP
1207 035660 005720 TST     (R0)+       ;DOUBLE PERIOD
1208 035662 005720 10$: TST     (R0)+       ;PERIOD
1209 035664 010402 11$: MOV     R4,R2           ;COMMA--POSITION THE
1210 035666 000302 SWAB   R2           ;NUMBER IN CASE IT
1211 035670 006202 ASR    R2           ;IS THE PRIORITY LEVEL
1212 035672 006202 ASR    R2
1213 035674 006202 ASR    R2
1214 035676 000200 RTS     R0           ;EXIT
1215
1216                                     ;THIS ROUTINE IS USED TO CHANGE OR MODIFY

```

```

1217      ;THE TEST PARAMETERS. IT GIVES THE OPERATOR
1218      ;THE CAPABILITY OF SPECIFYING WHICH DRIVES TO TEST, WHICH
1219      ;TESTS TO RUN AND HOW MANY TIMES TO REPEAT EACH TEST
1220
1221 035700 104412          GT.PRM: SAVREG          ;SAVE R0 - R5
1222 035702 005037 001330  GT.PR1: CLR      DRVSEL      ;NO DRIVE SELECTED
1223 035706 104401 035714  TYPE      ,65$      ;:TYPE ASCIZ STRING
      035712 000406      BR      64$      ;:GET OVER THE ASCIZ
      ;:65$: .ASCIZ <CRLF>/DRIVE(S)=/
      64$:
1224 035730 104411      RDLIN          ;:READ TTY
1225 035732 012601      MOV      (SP)+,R1      ;:ADDRESS OF ASCIZ STRING
1226 035734 004037 040132  JSR      R0,CK.CHR      ;:CHECK ONE CHARACTER
      035740 035702      GT.PR1          ;:ILLEGAL CHARACTER
      035742 035702      GT.PR1          ;:CARRIAGE RETURN
      035744 035702      GT.PR1          ;:/'
      035746 035702      GT.PR1          ;:.'
      035750 035702      GT.PR1          ;:.'
      035752 035754      i$           ;:DIGIT 0-9
1227 035754 005301      1$:      DEC      R1
1228 035756          2$:
      035756 012702 000007  MOV      #7,R2      ;:UPPER LIMIT OF INPUT
      035762 004037 040206  JSR      R0,CK.DIG      ;:CHECK THE DIGIT(S)
      035766 035702      GT.PR1          ;:ILLEGAL INPUT
      035770 035702      GT.PR1          ;:INPUT TOO LARGE
      035772 036000      3$           ;:TERMINATED WITH A '' OR ''CR''
      035774 036024      4$           ;:TERMINATED WITH A ''
      035776 036024      4$           ;:TERMINATED WITH A ''
1229 036000 156237 040636 001330 3$:  BISB   ATABIT(R2),DRVSEL ;:SET THE DRIVE SELECTED BIT
1230 036006 105741      TSTB   -(R1)      ;:WAS THE LINE TERMINATED?
1231 036010 001362      BNE    2$           ;:NO-GET THE NEXT DRIVE
1232 036012 005037 001332  CLR    TSTNMS      ;:DESELECT ALL TESTS
1233 036016 005037 001334  CLR    TSTNMS+2
      036022 000405      BR     GTTST1      ;:YES--SELECT TEST
1235 036024 156237 040636 001330 4$:  BISB   ATABIT(R2),DRVSEL ;:SET THE SELECTED DRIVE BITS
1236 036032 104413      GT.PR2: RESREG      ;:RESTORE R0 - R5
1237 036034 000207      RTS     PC          ;:EXIT
1238
1239 036036          GTTST1:
      036036 104401 036044  TYPE    ,65$      ;:TYPE ASCIZ STRING
      036042 000403      BR     64$      ;:GET OVER THE ASCIZ
      ;:65$: .ASCIZ /TEST=/
      64$:
1240 036052          RDLIN          ;:READ AN ASCIZ STRING
1241 036054 012601      MOV    (SP)+,R1      ;:POINTER TO R1
1242 036056 122711 000056  CMPB   #'.,(R1)      ;:DOUBLE PERIOD?
1243 036062 001007      BNE    1$           ;:NO--BRANCH
1244 036064 122761 000056 000001  CMPB   #'.,1(R1)
1245 036072 001003      BNE    1$           ;:'CR'?
1246 036074 105761 000002  TSTB   2(R1)
1247 036100 001754      BEQ    GT.PR2      ;:YES--EXIT
1248 036102 005037 001332  1$:    CLR    TSTNMS      ;:NO TEST SELECTED
1249 036106 005037 001334  CLR    TSTNMS+2
1250 036112 005037 001336  CLR    OPNFLG      ;:NO TESTS TO BE OPENED
1251 036116 005037 001340  CLR    OPNFLG+2
1252
1253 036122 121127 000123  GTTST2: CMPB   (R1),#'S      ;:ALL SEEK TESTS?

```

1254	036126	001004			BNE	1\$:NO--BRANCH
1255	036130	052737	G00777	001332	BIS	#777,TSTNMS		:YES--SELECT TESTS 0-10
1256	036136	000552			BR	GTTST3		
1257	036140	121127	000124		1\$: CMPB	(R1),#T		:ALL TIMING TESTS?
1258	036144	001004			BNE	2\$:NO--BRANCH
1259	036146	052737	026000	001332	BIS	#26000,TSTNMS		:YES--SELECT TESTS 12,13 & 15
1260	036154	000543			BR	GTTST3		
1261	036156	121127	000101		2\$: CMPB	(R1),#A		:ALL ADDRESSING TESTS?
1262	036162	001004			BNE	3\$:NO--BRANCH
1263	036164	052737	140000	001332	BIS	#140000,TSTNMS		:YES--SELECT TESTS 16 & 17
1264	036172	000534			BR	GTTST3		
1265	036174	121127	000104		3\$: CMPB	(R1),#D		:DATA TEST?
1266	036200	001004			BNE	4\$:NO--BRANCH
1267	036202	052737	000001	001334	BIS	#1,TSTNMS+2		:YES--SELECT TEST 20
1268	036210	000525			BR	GTTST3		
1269	036212	121127	000105		4\$: CMPB	(R1),#E		:EXERCISER TEST?
1270	036216	001004			BNE	5\$:NO--BRANCH
1271	036220	052737	000002	001334	BIS	#2,TSTNMS+2		:YES--SELECT TEST 21
1272	036226	000516			BR	GTTST3		
1273	036230	004037	040056		5\$: JSR	R0,CK.OCT		:OCTAL DIGIT?
1274	036234	000514			BR	GTTST4		:NO--BRANCH
1275	036236	010205			MOV	R2,R5		:YES--SAVE IT
1276	036240	005201			INC	R1		:MOVE TO NEXT CHARACTER
1277	036242	004037	040056		JSR	R0,CK.OCT		:OCTAL DIGIT
1278	036246	000405			BR	6\$:NO--BRANCH
1279	036250	005201			INC	R1		:MOVE TO NEXT CHARACTER
1280	036252	006305			ASL	R5		:SCALE HIGH DIGIT
1281	036254	006305			ASL	R5		
1282	036256	006305			ASL	R5		
1283	036260	060502			ADD	R5,R2		:COMBINE HIGH & LOW DIGITS
1284	036262				6\$:			
1287	036262	020227	000022		CMP	R2,#22		:VALID TEST NUMBER?
1288	036266	003263			BGT	GTTST1		:NO--BRANCH
1289	036270	010237	036462		MOV	R2,9\$:SAVE THE TEST NUMBER
1290	036274	010204			MOV	R2,R4		:CONVERT TEST NUMBER INTO AN INDEX
1291	036276	042704	000017		BIC	#17,R4		:CLEAR UNWANTED BITS
1292	036302	006204			ASR	R4		:SHIFT THE BITS
1293	036304	006204			ASR	R4		
1294	036306	006204			ASR	R4		
1295	036310	006302			ASL	R2		
1296	036312	056264	001540	001332	BIS	BITS(R2),TSTNMS(R4)		:SELECT TEST
1297	036320	121127	000055		CMPB	(R1),#'-		:TEST STRING?
1298	036324	001060			BNE	GTTST4		:NO--BRANCH
1299	036326	005201			INC	R1		:YES--MOVE TO NEXT CHARACTER
1300	036330	004037	040056		JSR	R0,CK.OCT		:OCTAL DIGIT?
1301	036334	000640			BR	GTTST1		:NO--BRANCH
1302	036336	010205			MOV	R2,R5		:YES--SAVE IT
1303	036340	005201			INC	R1		:MOVE TO NEXT CHARACTER
1304	036342	004037	040056		JSR	R0,CK.OCT		:OCTAL DIGIT?
1305	036346	000405			BR	7\$:NO--BRANCH
1306	036350	005201			INC	R1		:YES--MOVE TO NEXT CHARACTER
1307	036352	006305			ASL	R5		:SCALE HIGH DIGIT
1308	036354	006305			ASL	R5		
1309	036356	006305			ASL	R5		
1310	036360	060502			ADD	R5,R2		:COMBINE HIGH & LOW DIGIT
1311	036362				7\$:			
1314	036362	020227	000022		CMP	R2,#22		:VALID TEST NUMBER?

```

1315 036366 003223          BGT  GTTST1          ;NO--BRANCH
1316 036370 023702 036462  CMP  9$,R2          ;IS THE FIRST NUMBER OF THE
1317                                ;STRING SMALLER THAN THE LAST?
1318 036374 002220          BGE  GTTST1          ;NO--BRANCH
1319 036376 010246          MOV  R2,-(SP)        ;SAVE ENDING TEST NUMBER
1320 036400 013702 036462  MOV  9$,R2          ;GET STARTING TEST NUMBER
1321 036404 012637 036462  MOV  (SP)+,9$       ;STORE ENDING TEST NUMBER
1322 036410 006337 036462  ASL  9$             ;SHIFT ENDING TEST NUMBER
1323 036414 006302          ASL  R2             ;SHIFT TEST NUMBER
1324 036416 010204          MOV  R2,R4          ;COPY TEST NUMBER INTO R4
1325 036420 042704 000037  BIC  #37,R4         ;CLEAR LOWER BITS
1326 036424 006204          ASR  R4             ;SHIFT THE TEST NUMBER
1327 036426 006204          ASR  R4
1328 036430 006204          ASR  R4
1329 036432 006204          ASR  R4
1330 036434 056264 001540 001332  BIS  BITS(R2),TSTNMS(R4) ;SELECT THE TEST
1331 036442 062702 000002  ADD  #2,R2          ;INCREMENT THE TEST NUMBER
1332 036446 020237 036462  CMP  R2,9$         ;SEE IF FINISHED
1333 036452 101761          BLOS 8$            ;BR IF NOT
1334 036454 162702 000002  SUB  #2,R2          ;CORRECT TEST NUMBER
1335 036460 000402          BR   GTTST4        ;CONTINUE
1336 036462 000000          BR   .WORD 0       ;STORE TEST NUMBER HERE
1337
1338 036464 005201          GTTST3: INC  R1          ;MOVE TO NEXT CHARACTER
1339 036466 121127 000056  GTTST4: CMPB (R1),#'.' ;'PERIOD'?
1340 036472 001511          BEQ  GTTST5        ;YES--BRANCH
1341 036474 005737 001332  TST  TSTNMS        ;ANY TEST SELECTED THIS CYCLE?
1342 036500 001005          BNE  1$            ;BR IF YES
1343 036502 005737 001334  TST  TSTNMS+2      ;ANY TEST SELECTED THIS CYCLE ?
1344 036506 001002          BNE  1$            ;BR IF YES
1345 036510 000137 036036  JMP  GTTST1        ;NO
1346
1347                                ;CHECK TO OPEN TESTS FOR PARAMETER CHANGES
1348
1349 036514 121127 000057  1$:  CMPB (R1),#'/'    ;'OPEN'?
1350 036520 001054          BNE  7$            ;NO--BRANCH
1351 036522 126127 177777 000123  CMPB -1(R1),#'S'   ;ALL SEEK TESTS?
1352 036530 001004          BNE  2$            ;NO--BRANCH
1353 036532 052737 000777 001336  BIS  #777,OPNFLG   ;YES--OPEN TESTS 0-10
1354 036540 000451          BR   8$
1355 036542 126127 177777 000124  2$:  CMPB -1(R1),#'T'   ;ALL TIMING TESTS?
1356 036550 001004          BNE  3$            ;NO--BRANCH
1357 036552 052737 026000 001336  BIS  #26000,OPNFLG ;YES--OPEN TESTS 12,13 & 15
1358 036560 000441          BR   8$
1359 036562 126127 177777 000101  3$:  CMPB -1(R1),#'A'   ;ALL ADDRESSING TESTS?
1360 036570 001004          BNE  4$            ;NO--BRANCH
1361 036572 052737 140000 001336  BIS  #140000,OPNFLG ;YES--OPEN TESTS 16 & 17
1362 036600 000431          BR   8$
1363 036602 126127 177777 000104  4$:  CMPB -1(R1),#'D'   ;DATA TEST?
1364 036610 001004          BNE  5$            ;NO--BRANCH
1365 036612 052737 000001 001340  BIS  #1,OPNFLG+2   ;YES--OPEN TEST 20
1366 036620 000421          BR   8$
1367 036622 126127 177777 000105  5$:  CMPB -1(R1),#'E'   ;EXERCISER TEST?
1368 036630 001004          BNE  6$            ;NO--BRANCH
1369 036632 052737 000002 001340  BIS  #2,OPNFLG+2   ;YES--OPEN TEST 21
1370 036640 000411          BR   8$
1371 036642 056264 001540 001336  6$:  BIS  BITS(R2),OPNFLG(R4) ;YES--SET BITS FOR TEST TO OPEN

```

```

1372 036650 000405          BR      8$
*373
1374 036652 121127 000054    7$:  CMPB   (R1),#'.      ;'COMMA'?
1375 036656 001402          BEQ     8$              ;BR IF YES
1376 036660 000137 036036    JMP     GTTST1         ;NO
1377 036664 005201          8$:  INC     R1          ;MOVE TO NEXT CHARACTER
1378 036666 105711          TSTB   (R1)           ;'CR'?
1379 036670 001402          BEQ     9$              ;BR IF 'CR'
1380 036672 000137 036122    JMP     GTTST2         ;NO--GO GET NEXT CHARACTER
1381 036676 005737 001336    9$:  TST     OPNFLG      ;ANY TESTS TO OPEN ?
1382 036702 001042          BNE     OPNTST         ;BR IF YES
1383 036704 005737 001340    TST     OPNFLG+2      ;ANY TESTS TO OPEN ?
1384 036710 001037          BNE     OPNTST         ;BR IF YES
1385 036712 000137 036036    JMP     GTTST1         ;NO--START AGAIN
1386
1387 036716 005201          GTTST5: INC     R1          ;MOVE TO NEXT CHARACTER
1388 036720 121127 000056    CMPB   (R1),#'.      ;'PERIOD'?
1389 036724 001414          BEQ     GTTST6         ;YES--BRANCH
1390 036726 105711          TSTB   (R1)           ;'CR'?
1391 036730 001402          BFC     1$              ;YES--BRANCH
1392 036732 000137 036036    JMP     GTTST1
1393 036736 005737 001336    1$:  TST     OPNFLG      ;ANY TESTS TO OPEN ?
1394 036742 001022          BNE     OPNTST         ;BR IF YES
1395 036744 005737 001340    TST     OPNFLG+2      ;ANY TESTS TO OPEN ?
1396 036750 001017          BNE     OPNTST         ;BR IF YES
1397 036752 000137 036032    JMP     GT.PR2         ;NO--GO START TESTING
1398
1399 036756 005201          GTTST6: INC     R1          ;MOVE TO NEXT CHARACTER
1400 036760 105711          TSTB   (R1)           ;'CR'?
1401 036762 001402          BEQ     1$              ;YES--BRANCH
1402 036764 000137 036036    JMP     GTTST1         ;NO--GO ASK FOR TEST
1403 036770 005737 001336    1$:  TST     OPNFLG      ;ANY TESTS TO OPEN ?
1404 036774 001005          BNE     OPNTST         ;BR IF YES
1405 036776 005737 001340    TST     OPNFLG+2      ;ANY TESTS TO OPEN ?
1406 037002 001002          BNE     OPNTST         ;BR IF YES
1407 037004 000137 036032    JMP     GT.PR2         ;NO--GO START TESTING
1408
1409          ;OPEN THE SELECTED TEST FOR CHANGES
1410
1411 037010 104412          OPNTST: SAVREG          ;SAVE R0 - R5
1412 037012 005027          CLR     (PC)+          ;START WITH TEST 0
1413 037014 000000          OPN.CT: .WORD 0        ;COUNT STORED HERE
1414 037016 000411          BR      OPN.2          ;SKIP THE INCREMENT
1415
1416 037020 005237 037014          OPN.1: INC     OPN.CT    ;MOVE TO THE NEXT TEST
1419 037024 022737 000022 037014    CMP     #22,OPN.CT    ;TEST NUMBER TOO BIG?
1420 037032 002003          BGE     OPN.2          ;NO--OPEN THE NEXT TEST
1421 037034 104413          RESREG          ;RESTORE R0 - R5
1422 037036 000137 036036    JMP     GTTST1         ;YES--GO ASK FOR MORE TESTS
1423
1424 037042 013705 037014          OPN.2: MOV     OPN.CT,R5  ;SETUP TO USE THE
1425 037046 006305          ASL     R5            ;TEST NUMBER AS AN INDEX
1426 037050 013703 037014          MOV     OPN.CT,R3     ;GET INDEX
1427 037054 042703 000017          BIC     #17,R3        ;CLEAR LOWER TEST BITS
1428 037060 006203          ASR     R3            ;SHIFT TEST NUMBER
1429 037062 006203          ASK     R3
1430 037064 006203          ASR     R3

```

```

1431 037066 036563 001540 001336 BIT BITS(R5),OPNFLG(R3) ;OPEN THIS TEST?
1432 037074 001751 BEQ OPN.1 ;NO--MOVE TO NEXT TEST
1433 037076 104401 037104 TYPE ,65$ ;:TYPE ASCIZ STRING
      037102 000404 BR 64$ ;:GET OVER THE ASCIZ
      ;:65$: .ASCIZ / TEST /
      64$:
1434 037114 MOV OPN.CT,-(SP) ;:SAVE OPN.CT FOR TYPE(OUT)
      037120 104403 TYPOS ;:GO TYPE--OCTAL ASCII
      037122 002 .BYTE 2 ;:TYPE 2 DIGIT(S)
      037123 000 .BYTE 0 ;:SUPPRESS LEADING ZEROS
1435 037124 104401 001231 TYPE ,$CRLF ;:CR-LF
1436 037130 016500 002374 MOV PRMPT(R5),RO ;:PICKUP PARAMETER POINTER
1437 037134 011046 MOV (RO),-(SP) ;:SAVE THE VARIABLE INDICATOR
1438 037136 012702 002334 MOV #PRM,R2 ;:FIRST ADDRESS OF TABLE
1439 037142 000405 BR 2$
1440 037144 006216 1$: ASR (SP) ;:CHECK FOR A VARIABLE
1441 037146 103403 BCS 2$ ;:GO MOVE THIS ONE
1442 037150 001404 BEQ OPNPRM ;:DONE
1443 037152 005722 *ST (R2)+ ;:BUMP THE POINTER
1444 037154 000773 BR 1$
1445 037156 012022 2$: MOV (R0)+,(R2)+ ;:MOVE THIS VARIABLE INTO THE
1446 037160 000771 BR 1$ ;:COMMON AREA
1447
1448 037162 013716 002334 OPNPRM: MOV PRM,(SP) ;:GET THE VARIABLE INDICATOR
1449 037166 005004 CLR R4 ;:ZERO THE INDEX
1450 037170 006216 1$: ASR (SP) ;:CHECK FOR A VARIABLE
1451 037172 103403 BCS 3$ ;:GO GET IT
1452 037174 001772 BEQ OPNPRM ;:OUT OF VARIABLES
1453 037176 005724 2$: TST (R4)+ ;:UPDATE THE INDEX
1454 037200 000773 BR 1$
1455 037202 005764 002444 3$: TST PRMLMT(R4) ;:IS THE MAX. MAGNITUDE NEG?
1456 037206 100466 BMI OPNPAT ;:YES--THEN IT IS THE PATTERN
1457 037210 104401 050345 TYPE ,BLNKS2 ;:TYPE 2 SPACES
1458 037214 016437 002476 037224 MOV PRMSG(R4),4$ ;:TYPE THE NAME OF THIS VARIABLE
1459 037222 104401 TYPE
1460 037224 000000 4$: .WORD 0
1461 037226 104401 TYPE ,MSG.EQ ;:TYPE '='
1462 037232 016446 002336 MOV RPT(R4),-(SP) ;:PUT RPT(R4) ON THE STACK
      037236 004737 026136 JSR PC,$SB2D ;:CHANGE TO DECIMAL ASCII
      037242 004737 026366 JSR PC,$SUPRS ;:TYPE WITHOUT LEADING ZEROS
1463 037246 104401 047307 TYPE ,SLASH ;:TYPE ' / '
1464 037252 104411 RDLIN
1465 037254 012601 MOV (SP)+,R1 ;:READ AN ASCIZ STRING
1466 037256 004037 040132 JSR RO,CK.CHR ;:CHECK ONE CHARACTER
      037262 037202 3$ ;:ILLEGAL CHARACTER
      037264 037176 2$ ;:CARRIAGE RETURN
      037266 037334 9$ ;:
      037270 037276 5$ ;:
      037272 037304 6$ ;:
      037274 037332 8$ ;:DIGIT 0-9
1467 037276 105711 5$: TSTB (R1) ;:'CR'?
1468 037300 001340 BNE 3$ ;:NO--STAY ON THIS VARIABLE
1469 037302 000735 BR 2$ ;:YES--MOVE TO NEXT VARIABLE
1470 037304 105711 6$: TSTB (R1) ;:IS THERE A 'CR' AFTER THE PERIOD?
1471 037306 001002 BNE 7$ ;:NO
1472 037310 000137 037724 JMP OPN.N2 ;:YES--GO CLOSE THIS TEST
1473 037314 122721 000056 7$: CMPB #'',(R1)+ ;:DOUBLE PERIOD?
  
```

```

1474 037320 001330      BNE      3$      ;NO--GO ASK FOR THIS VARIABLE
1475 037322 105711      TSTB     (R1)    ;YES--IS A 'CR' AFTER THE DOUBLE PERIOD?
1476 037324 001326      BNE      3$      ;NO--ASK FOR THIS VARIABLE AGAIN
1477 037326 000137 037742  JMP      OPN.X2  ;YES--CLOSE ALL TEST
1478
1479 037332 005301      8$:     DEC      R1      ;BACK THE POINTER UP BY ONE
1480 037334      9$:
      037334 016402 002444      MOV      PRMLMT(R4),R2 ;UPPER LIMIT OF INPUT
      037340 004037 040206      JSR      RO,CK.DIG    ;CHECK THE DIGIT(S)
      037344 037202      3$      ;ILLEGAL INPUT
      037346 037202      3$      ;INPUT TOO LARGE
      037350 037336      10$     ;TERMINATED WITH A '...' OR 'CR'
      037352 037720      OPN.N1   ;TERMINATED WITH A '...'
      037354 037736      OPN.X1   ;TERMINATED WITH A '...'
1481 037356 010264 002336 10$:     MOV      R2,RPT(R4)  ;SAVE THIS VARIABLE
1482 037362 000705      BR       2$      ;MOVE TO NEXT VARIABLE
1483
1484
1485 ;OPEN PATTERN FOR CHANGES
1486 037364 104401 050345  OPNPAT: TYPE ,BLNKS2 ;TYPE 2 SPACES
1487 037370 104401 047256      TYPE ,MSG.PAT ;TYPE 'PAT'
1488 037374 104401 047262      TYPE ,MSG.EQ  ;TYPE '='
1489 037400 016446 002336      MOV      RPT(R4),-(SP) ;SAVE RPT(R4) FOR TYPEOUT
      037404 104402      TYP0C    ;GO TYPE--OCTAL ASCII(ALL DIGITS)
1490 037406 104401 050346      TYPE ,BLNKS1 ;TYPE ONE SPACE
1491 037412 104411      RDLIN    ;READ ASCII STRING
1492 037414 012601      MOV      (SP)+,R1   ;PICKUP POINTER
1493 037416 004037 040132  JSR      RO,CK.CHR  ;CHECK ONE CHARACTER
      037422 037364      OPNPAT   ;ILLEGAL CHARACTER
      037424 037162      OPNPRM  ;CARRIAGE RETURN
      037426 037460      3$      ;'...'
      037430 037162      OPNPRM  ;'...'
      037432 037436      1$      ;'...'
      037434 037456      2$      ;DIGIT 0-9
1494 037436 105711      1$:     TSTB     (R1)    ;'CR' AFTER THE PERIOD?
1495 037440 001531      BEQ      OPN.N2   ;YES--GO CLOSE THIS TEST
1496 037442 122721 000056  CMPSB   #'',(R1)+ ;NO--PERIOD?
1497 037446 001346      BNE      OPNPAT   ;NO--LOOP
1498 037450 105711      TSTB     (R1)    ;'CR' AFTER A DOUBLE PERIOD?
1499 037452 001533      BEQ      OPN.X2   ;YES--GO START TESTING
1500 037454 000743      BR       OPNPAT   ;NO--LOOP
1501 037456 005301      2$:     DEC      R1      ;BACKUP THE ASCII POINTER
1502 037460      3$:
      037460 004037 040372      JSR      RO,CK.NUM  ;CHECK THE NUMBER
      037464 037364      OPNPAT   ;ILLEGAL INPUT
      037466 037474      4$      ;TERMINATED WITH A '...' OR 'CR'
      037470 037720      OPN.N1   ;TERMINATED WITH A '...'
      037472 037736      OPN.X1   ;TERMINATED WITH A '...'
1503 037474 010264 002336 4$:     MOV      R2,RPT(R4)  ;SAVE THE INPUT NUMBER
1504 037500 006002      ROR      R2      ;OPEN PATTERN 0?
1505 037502 103227      BCC      OPNPRM  ;NO--START AT BEGINNING OF PARAMETER TABLE
1506 037504 104412      SAVREG   ;SAVE R0 - R5
1507
1508 ;OPEN WORDS IN PATTERN #0 FOR CHANGES
1509
1510 037506 005000  OPNWDS: CLR      R0      ;START WITH WORD 0
1511 037510 012704 003576      MOV      #PAT0,R4

```

```

1512 037514
      037514 104401 037522
      037520 000403

      037530
1513 037530 010046
      037532 004737 026136
      037536 004737 026366
1514 037542 104401 047262
1515 037546 011446
      037550 104402
1516 037552 104411
1517 037554 012601
1518 037556 004037 040132
      037562 037514
      037564 037616
      037566 037600
      037570 037616
      037572 037632
      037574 037576
1519 037576 005301
1520 037600
      037600 004037 040372
      037604 037514
      037606 037614
      037610 037652
      037612 037664
1521 037614 010214
1522 037616 005724
1523 037620 005200
1524 037622 022700 000020
1525 037626 003332
1526 037630 000726
1527 037632 105711
1528 037634 001407
1529 037636 122721 000056
1530 037642 001324
1531 037644 105711
1532 037646 001407
1533 037650 000721
1534 037652 010224
1535 037654 004737 037676
1536 037660 104413
1537 037662 000420
1538 037664 010224
1539 037666 004737 037676
1540 037672 104413
1541 037674 000422
1542
1543
1544
1545 037676 012701 003576
1546 037702 005200
1547 037704 022700 000017
1548 037710 002402
1549 037712 012124
1550 037714 000772

```

```

1$:
      TYPE      .65$      ;;TYPE ASCIZ STRING
      BR        64$      ;;GET OVER THE ASCIZ
      .:65$: .ASCIZ / WD/
      64$:
      MOV       R0,-(SP)   ;PUT R0 ON THE STACK
      JSR      PC,$$SB2D  ;CHANGE TO DECIMAL ASCIZ
      JSR      PC,$$SUPRS ;TYPE WITHOUT LEADING ZEROS
      TYPE     ,MSG.E0    ;TYPE '='
      MOV      (R4),-(SP) ;SAVE (R4) FOR TYPEOUT
      TYPOC    ;GO TYPE--OCTAL ASCII(ALL DIGITS)
      RDLIN   ;READ ASCIZ STRING
      MOV     (SP)+,R1    ;PICKUP THE POINTER
      JSR     R0,CK.CHR  ;CHECK ONE CHARACTER
      1$      ;ILLEGAL CHARACTER
      5$      ;CARRIAGE RETURN
      3$      ;/
      .:..:
      .:..:
      2$      ;DIGIT 0-9
      DEC     R1         ;BACKUP THE ASCII POINTER
      3$:
      JSR     R0,CK.NUM  ;CHECK THE NUMBER
      1$      ;ILLEGAL INPUT
      4$      ;TERMINATED WITH A '...' OR 'CR'
      7$      ;TERMINATED WITH A '...'
      9$      ;TERMINATED WITH A '...'
      4$: MOV     R2,(R4) ;SAVE THE INPUT
      5$: TST    (R4)+   ;MOVE TO NEXT WORD
      INC     R0         ;INCREMENT THE COUNT
      CMP     #16.,R0   ;COUNT TO LARGE?
      BGT     1$        ;NO--BRANCH
      BR     OPNWDS     ;YES--BRANCH
      6$: TSTB   (R1)    ;'CR' AFTER THE PERIOD?
      BEQ    8$        ;YES--GO CLOSE THIS TEST
      CMPB   #'.,(R1)+ ;NO--PERIOD?
      BNE    1$        ;NO--BRANCH ILLEGAL INPUT STRING
      TSTB   (R1)    ;'CR' AFTER THE 'PERIOD-PERIOD'?
      BEQ    10$       ;YES--GO START TESTING
      BR     1$        ;NO--LOOP
      7$: MOV     R2,(R4)+ ;SAVE THE INPUT
      8$: JSR     PC,CLSWDS ;CLOSE THE DATA PATTERN
      RESREG ;RESTORE R0 - R5
      BR     OPN.N2    ;MOVE TO NEXT TEST
      9$: MOV     R2,(R4)+ ;SAVE THE INPUT
      10$: JSR    PC,CLSWDS ;CLOSE THE DATA PATTERN
      RESREG ;RESTORE R0 - R5
      BR     OPN.X2    ;START TESTING

;CLOSE PATTERN #0 AND SAVE CHANGED WORDS
CLSWDS: MOV     #PATO,R1 ;FIRST ADDRESS OF DATA PATTERN
1$: INC     R0         ;COUNT THE LAST WORD THAT WAS STORED
      CMP     #15.,R0  ;END OF TABLE
      BLT    2$        ;YES--EXIT
      MOV    (R1)+,(R4)+ ;COPY
      BR     1$        ;LOOP

```



```

1551 037716 000207          2$:   RTS      PC           ;RETURN
1552
1553 037720 010264 002336  OPN.N1: MOV     R2,RPT(R4)   ;SAVE THIS VARIABLE
1554 037724 005726          OPN.N2: TST     (SP)+       ;CLEAN OFF THE STACK
1555 037726 004737 037776          JSR     PC,CLOSE         ;CLOSE THIS TEST
1556 037732 000137 037020          JMP     OPN.1           ;GO OPEN THE NEXT TEST
1557
1558 037736 010264 002336  OPN.X1: MOV     R2,RPT(R4)   ;SAVE THIS VARIABLE
1559 037742 005726          OPN.X2: TST     (SP)+       ;CLEAN OFF THE STACK
1560 037744 004737 037776          1$:   JSR     PC,CLOSE         ;CLOSE THIS TEST
1561 037750 005725          2$:   TST     (R5)+       ;UPDATE THE INDEX
1562 037752 020527 000034          CMP     R5,#16*2        ;INDEX TO BIG?
1563 037756 002403          BLT     3$             ;NO--BRANCH
1564 037760 104413          RESREG ;RESTORE R0 - R5
1565 037762 000137 036032          JMP     GT.PR2         ;GO TO EXIT
1566 037766 036503 001540          3$:   BIT     BITS(R5),R3    ;IS THIS TEST OPEN FOR CHANGE?
1567 037772 001364          BNE     1$             ;YES--GO CLOSE IT
1568 037774 000765          BR      2$             ;NO--MOVE TO NEXT TEST
1569
1570          ;CLOSE CURRENT TEST THAT WAS OPEN FOR CHANGES
1571
1572 037776 104412          CLOSE: SAVREG          ;SAVE R0 - R5
1573 040000 012700 002334          MOV     #PRM,R0        ;'FROM' ADDRESS
1574 040004 016501 002374          MOV     PRMPT(R5),R1   ;'TO' ADDRESS
1575 040010 012002          MOV     (R0)+,R2       ;'FROM' INDICATOR
1576 040012 012103          MOV     (R1)+,R3       ;'TO' INDICATOR
1577 040014 012704 000001          MOV     #1,R4         ;TEST BIT START A 'RPT'
1578 040020 030402          1$:   BIT     R4,R2        ;PARAMETER TO BE MOVED?
1579 040022 001403          BEQ     2$             ;NO--BRANCH
1580 040024 030403          BIT     R4,R3         ;A PLACE TO PUT IT?
1581 040026 001404          BEQ     3$             ;NO--BRANCH
1582 040030 011011          MOV     (R0),(R1)      ;YES--MOVE 'FROM' TO 'TO'
1583 040032 030403          2$:   BIT     R4,R3      ;'TO' PARAMETER?
1584 040034 001401          BEQ     3$             ;NO--BRANCH
1585 040036 005721          TST     (R1)+         ;YES--UPDATE THE POINTER
1586 040040 005720          3$:   TST     (R0)+         ;UPDATE FROM POINTER
1587 040042 006304          ASL     R4             ;POSITION THE TEST BIT
1588 040044 032704 002000          BIT     #BIT10,R4     ;DONE?
1589 040050 001763          BEQ     1$             ;NO--BRANCH
1590 040052 104413          RESREG ;RESTORE R0 - R5
1591 040054 000207          RTS      PC           ;RETURN
1592
1593          ;THIS ROUTINE IS USED TO CHECK IF AN
1594          ;ASCII CHARACTER IS A DIGIT BETWEEN 0 AND 7.
1595          ;CALL
1596          ;:   MOV     #ADR,R1      ;ADDRESS OF ASCII CHARACTER
1597          ;:   JSR     RO,CK.OCT   ;CHECK THE CHARACTER
1598          ;:   RETURN1          ;CHARACTER IS NOT BETWEEN 0-7
1599          ;:   RETURN2          ;CHARACTER IS IN R2 AS A
1600          ;:                   ;OCTAL DIGIT
1601
1602 040056 121127 000060  CK.OCT: CMPB    (R1),#'0    ;LESS THAN ZERO?
1603 040062 103407          BLO     1$             ;YES -- BRANCH
1604 040064 121127 000067          CMPB    (R1),#'7      ;GREATER THAN SEVEN?
1605 040070 101004          BMI     1$             ;YES -- BRANCH
1606 040072 111102          MOVB    (R1),R2       ;GET THE CHARACTER
1607 040074 042702 177770          BIC     #'C?,R2      ;STRIP AWAY THE ASCII

```

```

1608 040100 005720          TST      (R0)+      ;ADJUST FOR RETURN
1609 040102 000200          1$:     RTS      RO        ;RETURN
1610
1611          ;THIS ROUTINE IS USED TO CHECK AN ASCII CHARACTER
1612          ;AND DETERMINE IF IT IS A DIGIT BETWEEN 0 AND 9.
1613          ;CALL
1614          ;:
1615          ;   MOV      #ADR,R1      ;ADDRESS OF ASCII CHARACTER
1616          ;   JSR      RO,CK.DEC   ;CHECK THE CHARACTER
1617          ;   RETURN1  ;NOT BETWEEN 0 AND 9
1618          ;   RETURN2  ;BETWEEN 0 AND 9
1619          ;   ;R2 = DIGIT
1620 040104 121127 000060      CK DEC: CMPB   (R1),#'0      ;LESS THAN ZERO?
1621 040110 103407          BLO     1$          ;YES -- BRANCH
1622 040112 121127 000071          CMPB   (R1),#'9      ;GREATER THAN NINE?
1623 040116 101004          BHI     1$          ;YES -- BRANCH
1624 040120 111102          MOVB   (R1),R2      ;GET THE CHARACTER
1625 040122 042702 000060          BIC   #'0,R2      ;STRIP AWAY THE ASCII
1626 040126 005720          TST   (R0)+      ;ADJUST FOR RETURN
1627 040130 000200          1$:     RTS      RO        ;RETURN
1628
1629          ;THIS ROUTINE WILL CHECK AN ASCII CHARACTER TO
1630          ;DETERMINE WHAT IT IS.
1631          ;CALL
1632          ;:
1633          ;   MOV      #ADR,R1      ;ADDRESS OF ASCII CHARACTER
1634          ;   JSR      RO,CK.CHR   ;CHECK CHARACTER
1635          ;   RETURN  ADR1      ;UNKNOWN CHARACTER
1636          ;   RETURN  ADR2      ;CARRIAGE RETURN * (R1)-ADR+1
1637          ;   RETURN  ADR3      ;SLASH * (R1)=ADR+1
1638          ;   RETURN  ADR4      ;COMMA * (R1)=ADR+1
1639          ;   RETURN  ADR5      ;PERIOD * (R1)=ADR+1
1640          ;   RETURN  ADR6      ;DIGIT BETWEEN 0 AND 9.
1641          ;   ;R2 = DIGIT * (R1)-ADR+1
1642 040132 105711          CK.CHR: TSTB  (R1)      ;'CARRIAGE RETURN'?
1643 040134 001420          BEQ   4$          ;YES -- BRANCH
1644 040136 121127 000057          CMPB  (R1),# '/'   ;'SLASH'?
1645 040142 001414          BEQ   3$          ;YES -- BRANCH
1646 040144 121127 000054          CMPB  (R1),# ','   ;'COMMA'?
1647 040150 001410          BEQ   2$          ;YES -- BRANCH
1648 040152 121127 000056          CMPB  (R1),# '.'   ;'PERIOD'?
1649 040156 001404          BEQ   1$          ;YES -- BRANCH
1650 040160 004037 040104          JSR   RO,CK.DEC   ;'DIGIT'?
1651 040164 000406          BR    5$          ;NO -- BRANCH
1652 040166 005720          TST   (R0)+      ;DIGIT BETWEEN 0-9
1653 040170 005720          1$:     TST   (R0)+      ;PERIOD
1654 040172 005720          2$:     TST   (R0)+      ;COMMA
1655 040174 005720          3$:     TST   (R0)+      ;SLASH
1656 040176 005720          4$:     TST   (R0)+      ;CARRIAGE RETURN
1657 040200 005201          INC   R1          ;MOVE POINTER TO NEXT CHARACTER
1658 040202 011000          5$:     MOV   (R0),RO   ;UNKNOWN CHARACTER
1659 040204 000200          RTS   RO        ;RETURN
1660
1661          ;THIS ROUTINE CHECKS AN ASCII STRING FOR LEGAL
1662          ;CHARACTERS AND FORMS A DECIMAL VALUE BINARY NUMBER IN R2.
1663          ;CALL
1664          ;:
1664          ;   MOV      #ADR,R1      ;ADDRESS OF ASCII STRING

```

```

1665      :      MOV      #NUM,R2      :MAX. MAGNITUDE OF INPUT NUMBER
1666      :      JSR      R0,CK.DIG     :CHECK DIGITS
1667      :      RETURN   ADR1          :ILLEGAL CHARACTER -- R2=?
1668      :      RETURN   ADR2          :INPUT NUMBER TOO LARGE -- R2=?
1669      :      RETURN   ADR3          :'COMMA' -- R2 = NUMBER
1670      :      RETURN   ADR4          :'PERIOD' -- R2 = NUMBER
1671      :      RETURN   ADR5          :'PERIOD-PERIOD' -- R2 = NUMBER
1672
1673 040206 010446      CK.DIG: MOV      R4,-(SP)      :SAVE R4
1674 040210 010346      MOV      R3,-(SP)      :SAVE R3
1675 040212 010246      MOV      R2,-(SP)      :SAVE THE MAX. SIZE ON THE STACK
1676 040214 005002      CLR      R2            :START WITH 0
1677 040216 005003      CLR      R3
1678 040220 005004      CLR      R4
1679 040222 004037 040132 JSR      R0,CK.CHR     :CHECK ONE CHARACTER
1680      :      9$           :ILLEGAL CHARACTER
1681      :      9$           :CARRIAGE RETURN
1682      :      9$           :'/ '
1683      :      9$           :'. '
1684      :      9$           :'. '
1685      :      9$           :'. '
1686      :      1$          :DIGIT 0-9
1687 040242 006303      1$: ASL      R3            :2
1688 040244 010346      MOV      R3,-(SP)     :SAVE *2
1689 040246 006303      ASL      R3            :4
1690 040250 006303      ASL      R3            :8
1691 040252 062603      ADD      (SP)+,R3     :(*8)+(*2)=*10.
1692 040254 060203      ADD      R2,R3        :UPDATE THE INPUT NUMBER
1693 040256 004037 040132 JSR      R0,CK.CHR     :CHECK ONE CHARACTER
1694      :      9$           :ILLEGAL CHARACTER
1695      :      2$           :CARRIAGE RETURN
1696      :      9$           :'/ '
1697      :      4$           :'. '
1698      :      3$           :'. '
1699 040276 005301      2$: DEC      R1            :DIGIT 0-9
1700 040300 000401      BR       4$           :BACKUP THE CHARACTER POINTER
1701 040302 005724      3$: TST      (R4)+      :CONTINUE
1702 040304 005724      4$: TST      (R4)+      :'PERIOD'
1703 040306 004037 040132 JSR      R0,CK.CHR     :'COMMA' OR 'CR'
1704      :      9$           :CHECK ONE CHARACTER
1705      :      7$           :ILLEGAL CHARACTER
1706      :      9$           :CARRIAGE RETURN
1707      :      9$           :'/ '
1708      :      5$           :'. '
1709      :      6$           :'. '
1710 040326 005724      5$: TST      (R4)+      :DIGIT 0-9
1711 040330 105711      TSTB    (R1)          :'PERIOD-PERIOD'
1712 040332 001405      BEQ     7$           :'CR'?
1713 040334 000410      BR       9$           :YES--BRANCH
1714 040336 126127 177776 000054 6$: (MPB    -2(R1),#',     :WAS CHARACTER BEFORE THE DIGIT A 'COMMA'?
1715 040344 001004      BNE     9$           :NO--EXIT
1716 040346 020316      CMP     R3,(SP)      :INPUT TOO LARGE?
1717 040350 101601      BHI     8$           :YES -- BRANCH
1718 040352 060400      ADD     R4,R0        :ADJUST RETURN ADDRESS
1719 040354 005720      8$: TST      (R0)+      :NUMBER TO R2
1720 040356 010302      9$: MOV      R3,R2
1721 040360 005726      TST     (SP)+        :CLEAN MAX. SIZE OFF OF STACK

```

```

1704 040362 012603      MOV      (SP)+,R3      ;RESTORE R3
1705 040364 012604      MOV      (SP)+,R4      ;RESTORE R4
1706 040366 011000      MOV      (R0),R0       ;GET RETURN ADDRESS
1707 040370 000200      RTS      R0            ;RETURN
1708
1709                    ;THIS ROUTINE CHECKS AN ASCIZ STRING FOR LEGAL CHARACTERS
1710                    ;AND FORMS AN OCTAL NUMBER IN R2
1711                    ;CALL:
1712                    :      MOV      #ADR,R1      ;ADDRESS OF ASCIZ STRING
1713                    :      JSR      R0,CK.NUM     ;GO FORM THE NUMBER
1714                    :      RETURN  ADR1        ;ILLEGAL CHARACTER IN THE INPUT STRING
1715                    :      RETURN  ADR2        ;'COMMA' OR 'CR'--R2=NUMBER
1716                    :      RETURN  ADR3        ;'PERIOD'--R2=NUMBER
1717                    :      RETURN  ADR4        ;'PERIOD-PERIOD'--R2=NUMBER
1718
1719 040372 010346      CK.NUM: MOV      R3,-(SP) ;SAVE R3
1720 040374 005003      CLR      R3            ;START NUMBER AT ZERO
1721 040376 004037      JSR      R0,CK.OCT    ;OCTAL DIGIT?
1722 040402 000440      BR      6$            ;NO--BRANCH
1723 040404 005201      1$: INC      R1        ;MOVE TO NEXT CHARACTER
1724 040406 006303      ASL      R3            ;FOR THE OCTAL NUMBER IN R3
1725 040410 103435      BCS      6$            ;DON'T LET IT GET TO BIG
1726 040412 006303      ASL      R3
1727 040414 103433      BCS      6$
1728 040416 006303      ASL      R3
1729 040420 103431      BCS      6$
1730 040422 060203      ADD      R2,R3
1731 040424 004037      JSR      R0,CK.OCT    ;IS THIS AN OCTAL DIGIT?
1732 040430 000401      BR      2$            ;NO--FIND OUT WHAT IT IS
1733 040432 000764      BR      1$            ;YES--MAKE IT PART OF THE NUMBER
1734 040434 010302      2$: MOV      R3,R2     ;SAVE THE OCTAL NUMBER
1735 040436 005003      CLR      R3            ;START WITH ZERO INDEX
1736 040440 004037      JSR      R0,CK.CHR    ;CHECK ONE CHARACTER
1737 040444 040504      6$          ;ILLEGAL CHARACTER
1738 040446 040474      5$          ;CARRIAGE RETURN
1739 040450 040504      6$          ;'/'
1740 040452 040474      5$          ;'.'
1741 040454 040460      3$          ;'.'
1742 040456 040504      6$          ;DIGIT 0-9
1743 040460 005723      3$: TST      (R3)+     ;'PERIOD'
1744 040462 121127      000056     ;'PERIOD-PERIOD'?
1745 040466 001002      BNE      5$          ;NO--BRANCH
1746 040470 005201      INC      R1          ;YES--ADVANCE THE POINTER
1747 040472 005723      4$: TST      (R3)+     ;'PERIOD-PERIOD'
1748 040474 005723      5$: TST      (R3)+     ;'COMMA'
1749 040476 105711      TSTB     (R1)        ;'CR'?
1750 040500 001001      BNE      6$          ;NO--BRANCH
1751 040502 060300      ADD      R3,R0        ;YES--SAVE THE OCTAL NUMBER
1752 040504 012603      6$: MOV      (SP)+,R3   ;RESTORE R3
1753 040506 011000      MOV      (R0),R0     ;PICKUP EXIT ADDRESS
1754 040510 000200      RTS      R0            ;RETURN

```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
33
34
35
36
37
38
39
40
43
44
45
46
47
48
49

.SBTTL SINGLE/DUAL PORT RH/RM DRIVER (REV 6.5) 1981

;NEW DRIVE TYPE ID FOR RM02 *****
;10-AUG-77 *****
;10-MAR-78 THE SC, SC5 CHANGES
;NEW DRIVE TYPE ID FOR RM05 *****
;1980 *****

;COPYRIGHT (C) 1977,1981
;DIGITAL EQUIPMENT CORP.
;MAYNARD, MA 01754
;AUTHOR(S): JIM LACEY/CHUCK HESS
;REVISED BY: MIKE LEAVITT 11-APR-80, 27-MAR-81

;*****

;STORAGE FOR RMD5, RMER1, RMER2, AND RMMR2 ON AN ERROR '2'
;RMERRS = RMD5
;RMERRS+2 = RMER1
;RMERRS+4 = RMER2
;RMERRS+6 = RMMR2

040512 000000 000000 000000 RMERRS: .WORD 0,0,0,0

;TABLE OF DRIVE ACTIVE INDICATORS (DRVACT=8 BYTES)
;DRVACT=0 IF DRIVE IS IDLE
;DRVACT>0 IF DRIVE IS ACTIVE WITH A COMMAND
;DRVACT<0 IF DRIVE IS ACTIVE WITH AN ERROR RECOVERY OPERATION

040522	000	DRVACT: .BYTE	0	:DRIVE 0
040523	000	.BYTE	0	:DRIVE 1
040524	000	.BYTE	0	:DRIVE 2
040525	000	.BYTE	0	:DRIVE 3
040526	000	.BYTE	0	:DRIVE 4
040527	000	.BYTE	0	:DRIVE 5
040530	000	.BYTE	0	:DRIVE 6
040531	000	.BYTE	0	:DRIVE 7

;TABLE OF DRIVE STATUS INDICATORS (DRVSTA=8 BYTES)
;DRVSTA=0 IF DRIVE IS OFFLINE OR NONEXISTENT
;DRVSTA>0 IF DRIVE IS ONLINE
;DRVSTA<0 IF DRIVE IS UNSAFE

040532	000	DRVSTA: .BYTE	0	:DRIVE 0
040533	000	.BYTE	0	:DRIVE 1
040534	000	.BYTE	0	:DRIVE 2
040535	000	.BYTE	0	:DRIVE 3
040536	000	.BYTE	0	:DRIVE 4
040537	000	.BYTE	0	:DRIVE 5
040540	000	.BYTE	0	:DRIVE 6
040541	000	.BYTE	0	:DRIVE 7

;TABLE OF DRIVE TYPES (DRV TYP=8 BYTES)
;DRV TYP=0 IF DRIVE IS NONEXISTENT (DRVSTA=0, ALSO)
;DRV TYP=7 IF DRIVE IS RM05 *****
;DRV TYP=5 IF DRIVE IS RM02 *****
;DRV TYP=4 IF DRIVE IS RM03

```

50                                     ;DRVTYP=-1 IF NOT RM05/3/2
51
52 040542      000      DRVTYP: .BYTE 0          ;DRIVE 0
55 040543      000          .BYTE 0          ;DRIVE 1
   040544      000          .BYTE 0          ;DRIVE 2
   040545      000          .BYTE 0          ;DRIVE 3
   040546      000          .BYTE 0          ;DRIVE 4
   040547      000          .BYTE 0          ;DRIVE 5
   040550      000          .BYTE 0          ;DRIVE 6
   040551      000          .BYTE 0          ;DRIVE 7
56
57                                     ;TABLE OF DUAL PORT INITIALIZATION INDICATORS
58                                     ;DPINT=0 IF INITIALIZATION IS NOT ACTIVE ON THE DRIVE
59                                     ;DPINT<0 IF INITIALIZATION IS IN PROGRESS
60
61 040552      000      DPINT: .BYTE 0          ;DRIVE 0
64 040553      000          .BYTE 0          ;DRIVE 1
   040554      000          .BYTE 0          ;DRIVE 2
   040555      000          .BYTE 0          ;DRIVE 3
   040556      000          .BYTE 0          ;DRIVE 4
   040557      000          .BYTE 0          ;DRIVE 5
   040560      000          .BYTE 0          ;DRIVE 6
   040561      000          .BYTE 0          ;DRIVE 7
65
66                                     ;TABLE OF PENDING DUAL PORT REQUESTS
67                                     ;DPRQS=0 IF THAT A DUAL PORT REQUEST IS NOT PENDING FOR THAT DRIVE
68                                     ;DPRQS<0 IF THAT A DUAL PORT REQUEST IS PENDING FOR THAT DRIVE
69
70 040562      000      DPRQS: .BYTE 0          ;DRIVE 0
73 040563      000          .BYTE 0          ;DRIVE 1
   040564      000          .BYTE 0          ;DRIVE 2
   040565      000          .BYTE 0          ;DRIVE 3
   040566      000          .BYTE 0          ;DRIVE 4
   040567      000          .BYTE 0          ;DRIVE 5
   040570      000          .BYTE 0          ;DRIVE 6
   040571      000          .BYTE 0          ;DRIVE 7
74
75                                     ;TRANSFER WAIT FLAG (TRNSWT=1 WORD)
76                                     ;THIS IS A ONE WORD QUEUE. IT WILL CONTAIN THE ADDRESS OF
77                                     ;'DPB' OF THE I/O OPERATION.
78
79 040572      000000      TRNSWT: .WORD 0
80
81                                     ;SEARCH WAIT KEYS (SRCHWT=1 WORD)
82                                     ;THIS IS A ONE WORD QUEUE THAT WILL CONTAIN A KEY FOR EACH OF
83                                     ;THE DRIVES THAT ARE PERFORMING A SEARCH COMMAND FOR THE I/O
84                                     ;REQUEST THAT IS AT THE TOP OF THEIR REQUEST QUEUE.
85                                     ;EACH DRIVE IS ASSIGNED ONE BIT, STARTING AT BIT00 FOR DRIVE 0.
86
87 040574      000000      SRCHWT: .WORD 0
88
89                                     ;RM DRIVER ACTIVE FLAG (ACTDRV=1 BYTE)
90                                     ;ACTDRV=0 IF DRIVER IS INACTIVE
91                                     ;ACTDRV>0 IF DRIVER IS ACTIVE
92
93 040576      000      ACTDRV: .BYTE 0
94

```

```

95 ;SOFTWARE TIMER ROUTINE ACTIVE FLAG (ACTSTR=1 BYTE)
96 ;ACTSTR=0 IF SOFTWARE TIMER ROUTINE IS INACTIVE
97 ;ACTSTR>0 IF SOFTWARE TIMER ROUTINE IS ACTIVE
98
99 040577 000 ACTSTR: .BYTE 0
100
101 ;UNLOAD FLAG (ULDFLG=8 BYTES)
102 ;ULDFLG=0 IF NO UNLOAD COMMAND
103 ;ULDFLG>0 IF UNLOAD COMMAND IN PROGRESS
104 ;ULDFLG<0 IF UNLOAD COMMAND IN WAIT QUEUE
105
106 040600 000 ULDFLG: .BYTE 0 ;DRIVE 0
109 040601 000 .BYTE 0 ;DRIVE 1
    040602 000 .BYTE 0 ;DRIVE 2
    040603 000 .BYTE 0 ;DRIVE 3
    040604 000 .BYTE 0 ;DRIVE 4
    040605 000 .BYTE 0 ;DRIVE 5
    040606 000 .BYTE 0 ;DRIVE 6
    040607 000 .BYTE 0 ;DRIVE 7
110
111 ;SAVE REGISTERS FLAG (SAVEFG =1 WORD)
112 ;SAVEFG <0 IF SAVE THE RH/RM REGISTERS WHEN THE
113 ;OPERATION IS COMPLETED AS PER (DPB+14).
114 ;SAVEFG=0 IF SAVE THE RH/RM REGISTERS, AS PER
115 ;(DPB+14), AFTER AN ERROR.
116
117 040610 000000 SAVEFG: .WORD 0
118
119 ;SEEK FLAG (SEEKFG=1 WORD)
120 ;SEEKFG=0 IF WHEN THE DISK ADDRESS ISN'T IN THE WINDOW
121 ;FOR A DATA TRANSFER START A SEARCH COMMAND
122 ;SEEKFG<0 IF DATA TRANSFER WILL DO IMPLIED SEEKS,
123 ;DISREGARD THE WINDOW
124
125 040612 177777 SEEKFG: .WORD -1
126
127 ;TIMEOUT TABLE (TIMER=8 WORDS)
128 ;THIS TABLE CONTAINS THE TIME ALLOWED FOR AN OPERATION
129
130 040614 177777 TIMER: .WORD -1 ;DRIVE 0
133 040616 177777 .WORD -1 ;DRIVE 1
    040620 177777 .WORD -1 ;DRIVE 2
    040622 177777 .WORD -1 ;DRIVE 3
    040624 177777 .WORD -1 ;DRIVE 4
    040626 177777 .WORD -1 ;DRIVE 5
    040630 177777 .WORD -1 ;DRIVE 6
    040632 177777 .WORD -1 ;DRIVE 7
134
135 ;DATA TRANSFER UNDERWAY INDICATOR (DTUW=1 WORD)
136 ;DTUW<0 IF NO DATA TRANSFER UNDERWAY
137 ;DTUW=+N (WHERE N=0 TO 7) IMPLIES DATA TRANSFER UNDERWAY ON DRIVE N
138
139 040634 177777 DTUW: .WORD -1
140
141 ;ATTENTION BITS TABLE (ATABIT=8 BYTES)
142 ;THIS TABLE CONTAINS THE CORRESPONDING BIT TO EACH DRIVES
143 ;ATTENTION BIT
    
```

144
145 040636 001
146 040637 002
147 040640 004
148 040641 010
149 040642 020
150 040643 040
151 040644 100
152 040645 200

ATABIT: .BYTE 1 :DRIVE 0
.BYTE 2 :DRIVE 1
.BYTE 4 :DRIVE 2
.BYTE 10 :DRIVE 3
.BYTE 20 :DRIVE 4
.BYTE 40 :DRIVE 5
.BYTE 100 :DRIVE 6
.BYTE 200 :DRIVE 7

153
154
155
156
157 040646 000003

:NUMBER OF 'MASSBUS CONTROL PARITY ERRORS' (MCPE) ALLOWED BEFORE
:CALLING IT FATAL (MCPEMX=1 WORD)

MCPEMX: .WORD 3

158
159
160
161

:STORAGE FOR RMADR (THE FIRST ADDRESS (776700) OF THE RH/RM),
:RMVEC (THE VECTOR ADDRESS (254)), AND RMVEC+2 (THE BR LEVEL (5)).

162 040650 176700
163 040652 000254 0C0240

RMADR: .WORD 176700
RMVEC: .WORD 254,5*32.

167
168
169 040656 000005

:MAXIMUM SEARCH FOR I/O WINDOW IS 5 SECTORS (MXWNDW-1 WORD)
MXWNDW: .WORD 5

170
171

:DEFINITIONS OF THE RH/RM ADDRESS INDEXES

172
173 000000
174 000002
175 000004
176 000006
177 000010
178 000012
179 000014
180 000016
181 000020
182 000022
183 000024
184 000026
185 000030
186 000032
187 000034
188 000036
189 000040
190 000042
191 000044
192 000046

RMCS1 = 0 :CONTROL AND STATUS REGISTER #1 (DRIVE REG. 0)
RMWC = 2 :WORD COUNT REGISTER (NOT A DRIVE REG)
RMBA = 4 :UNIBUS ADDRESS REGISTER (NOT A DRIVE REG)
RMDA = 6 :DESIRED SECTOR/TRACK ADDRESS REGISTER (DRIVE REG. 5)
RMCS2 = 10 :CONTROL AND STATUS REGISTER #2 (NOT A DRIVE REG)
RMDS = 12 :DRIVE STATUS REGISTER (DRIVE REG 1)
RMER1 = 14 :ERROR REGISTER #1 (DRIVE REG. 2)
RMAS = 16 :ATTENTION SUMMARY PSEUDO REGISTER (DRIVE REG. 4)
RMLA = 20 :LOOK AHEAD REGISTER (DRIVE REG. 7)
RMDB = 22 :DATA BUFFER REGISTER (NOT A DRIVE REG.)
RMMR1 = 24 :MAINTAINABILITY REGISTER (DRIVE REG. 3)
RMDT = 26 :DRIVE TYPE REGISTER (DRIVE REG. 6)
RMSN = 30 :SERIAL NUMBER REGISTER (DRIVE REG. 10)
RMOF = 32 :OFFSET REGISTER (DRIVE REG. 11)
RMDC = 34 :DESIRED CYLINDER ADDRESS REGISTER (DRIVE REG. 12)
RMHR = 36 :DUMMY ADDRESS REGISTER (DRIVE REG. 13)
RMMR2 = 40 :MAINTENANCE REGISTER #2
RMER2 = 42 :ERROR REGISTER #2 (DRIVE REG. 15)
RMEC1 = 44 :ECC POSITION REGISTER (DRIVE REG. 16)
RMEC2 = 46 :ECC PATTERN REGISTER (DRIVE REG. 17)

197
198
199

.SBTTL RH/RM DRIVER INITIALIZATION CODE

200
201
202
203
204
205
206
207

:THIS ROUTINE WILL DETERMINE WHICH RM DRIVES ARE
:AVAILABLE FOR TESTING AND SET THE DRVSTA INDICATOR
:TO THE PROPER STATE FOR EACH DRIVE.
:NOTE: THIS ROUTINE CALLS DRVINT
:
:CALL
:
: JSR PC,RMINIT


```

208      :      RETURN
209      :
210      :NOTE: THE 'P' OR 'L' CLOCK MUST BE STARTED
211      :
212 040660 104412      RMINIT: SAVREG      ;SAVE R0 - R5
213 040662 013746 177776      MOV PS, -(SP)      ;SAVE THE PRESENT PROCESSOR STATUS
214 040666 012737 000240 177776      MOV #<5*32.>, PS ;CHANGE THE PRIORITY TO 5
215 040674 004737 046336      JSR PC, CLRQUE    ;CLEAR ALL REQUEST QUEUES
216 040700 012701 040512      MOV #RMERRS, R1   ;FIRST ADDRESS TO BE CLEARED
217 040704 012702 040612      MOV #SEKFG, R2    ;LAST ADDRESS TO BE CLEARED
218 040710 005021      1$: CLR (R1)+          ;CLEAR
219 040712 020102      CMP R1, R2        ;ARE WE DONE?
220 040714 103775      BLO 1$           ;BR IF NO
221 040716 012702 040634      MOV #DTUW, R2     ;LAST ADDRESS
222 040722 012721 177777      2$: MOV #-1, (R1)+  ;INITIALIZE
223 040726 020102      CMP R1, R2        ;DONE?
224 040730 101774      BLOS 2$          ;LOOP IF NO
225 040732 005037 040532      CLR DRVSTA       ;SET ALL DRIVES TO OFFLINE
226 040736 005037 040534      CLR DRVSTA+2
227 040742 005037 040536      CLR DRVSTA+4
228 040746 005037 040540      CLR DRVSTA+6
229 040752 013703 040652      MOV RMVEC, R3    ;SETUP THE RH/RM VECTOR
230 040756 012723 043306      MOV #ISR, (R3)+
231 040762 013713 040654      MOV RMVEC+2, (R3)
232 040766 013704 040650      MOV RMADR, R4
233 040772 012764 000040 000010      MOV #CLR, RMCS2(R4) ;FIRST ADDRESS OF RH/RM
234 041000 005001      CLR R1           ;MASSBUS INIT
235 041002 004037 041072      3$: JSR R0, DRVINT ;START WITH DRIVE 0
236 041006 000401      BR 4$           ;INIT THE DRIVE
237 041010 000402      BR 5$           ;'DVA' NOT SET OR PARITY ERROR
238 041012 105061 040532      4$: CLRB DRVSTA(R1) ;NORMAL RETURN
239 041016 005201      5$: INC R1           ;SET DRIVE STATUS TO OFFLINE
240 041020 042701 177770      BIC #^C7, R1    ;GO TO NEXT DRIVE
241 041024 001366      BNE 3$          ;MASK OUT UNUSED BITS
242 041026 012701 000007      MOV #7, R1      ;BR IF MORE DRIVES TO GO
243 041032 005037 177776      CLR PS          ;START WITH DRIVE 7
244 041036 105761 040552      6$: TSTB DPINT(R1) ;CLEAR THE PROCESSOR STATUS
245 041042 001405      BEQ 8$          ;WAITING FOR DRIVE TO SWITCH PORTS ?
246 041044 004737 045772      JSR PC, SET.IE  ;BR NOT WAITING
247 041050 105761 040552      7$: TSTB DPINT(R1) ;SET INTERRUPT
248 041054 001375      BNE 7$          ;DRIVE SWITCHED PORTS ?
249 041056 005301      8$: DEC R1        ;BR IF NOT
250 041060 100366      BPL 6$          ;GO TO THE NEXT DRIVE
251 041062 012637 177776      MOV (SP)+, PS   ;CHECK NEXT DRIVE
252 041066 104413      RESREG         ;RESTORE THE PROCESSOR STATUS
253 041070 000207      RTS PC        ;RESTORE R0 - R5
254      :
255      :DRIVE INITIALIZATION ROUTINE
256      :THIS ROUTINE DETERMINES IF A DRIVE EXIST AND IF IT IS
257      :AN RM05/3/2. IF IT IS, A 'READ-IN PRESET' IS ISSUED AND FMT16
258      :IS SET TO A '1'. THEN MOL, DPR, DRY, AND VV ARE CHECKED TO
259      :INSURE THEY ARE ALL ON A '1'. AND DEPENDING ON THEIR STATE,
260      :DRVSTA IS SET TO THE PROPER CONDITION.
261      :CALL
262      :      MOV #DRVNUM, R1      ;DRIVE NUMBER TO R1
263      :      MOV RMADR, R4        ;UNIBUS ADDRESS OF RH/RM (RMCS1)
264      :      JSR R0, DRVINT      ;CALLED BY A JSR

```

```

265          :          RETURN1          :ERROR OCCURRED (PARITY)
266          :          RETURN2          :NORMAL RETURN
267          :          :
268          :          :
269 041072 010546          :          :
270 041074 105061 040532  DRVINT: MOV    R5,-(SP)          :SAVE R5
271 041100 105061 040542          :CLRB  DRVSTA(R1)          :START DRIVE STATUS AS OFFLINE
272 041104 105061 040600          :CLRB  DRVSTYP(R1)         :CLEAR THE DRIVE TYPE INDICATOR
273 041110 010164 000010          :CLRB  ULDFLG(R1)         :CLEAR THE UNLOAD FLAG
274 041114 112764 000111 000000  MOV    R1,RMCS2(R4)        :SELECT A DRIVE
275 041122 032764 010000 000010  MOVB  #11,RMCS1(R4)       :DO A DRIVE CLEAR COMMAND (& SFIZE DRIVE)
276 041130 001403          :BIT   #BIT12,RMCS2(R4)   :NONEXISTENT DRIVE?
277 041132 004737 045772          :BEQ   1$                :NO
278 041136 000520          :JSR   PC,SET.IE         :GO SET 'IE' WITHOUT A 'TRE'
279          :          :
280 041140 105061 040532 1$:      :CLRB  DRVSTA(R1)          :SET DRIVE STATUS TO OFFLINE
281 041144 032764 004000 000000  :BIT   #BIT11,RMCS1(R4)   :SEE IF DRIVE AVAILABLE
282 041152 001512          :BEQ   4$                :BR IF DRIVE NOT AVAILABLE
283 041154 004037 045302          :JSR   R0,RD.RM          :READ THE DRIVE TYPE REG.
284 041160 000026          :RMDT          :
285 041162 041402          :S$          :ERROR RETURN ADDRESS
286 041164 012605          :MOV    (SP)+,R5          :PUT DRIVE TYPE IN R5
287 041166 112761 000004 040542  :MOVB  #4,DRVSTYP(R1)     :SET RM03 INDICATOR
288 041174 022705 020024          :CMP   #20024,R5          :SINGLE PORT RM03 ?
289 041200 001431          :BEQ   2$                :BR IF YES
290 041202 022705 024024          :CMP   #24024,R5          :DUAL PORT RM03 ?
291 041206 001426          :BEQ   2$                :BR IF YES
292 041210 112761 000005 040542  :MOVB  #5,DRVSTYP(R1)     :SET RM02 INDICATOR
293 041216 022705 020025          :CMP   #20025,R5          :SINGLE PORT RM02 ?
294 041222 001420          :BEQ   2$                :BR IF SO
295 041224 022705 024025          :CMP   #24025,R5          :DUAL PORT RM02 ?
296 041230 001415          :BEQ   2$                :BR IF SO
297 041232 112761 000007 040542  :MOVB  #7,DRVSTYP(R1)     :SET RM05 INDICATOR
298 041240 022705 020027          :CMP   #20027,R5          :SINGLE PORT RM05 ?
299 041244 001407          :BEQ   2$                :BR IF YES
300 041246 022705 024027          :CMP   #24027,R5          :DUAL PORT RM05 ?
301 041252 001404          :BEQ   2$                :BR IF YES
302 041254 112761 177777 040542  :MOVB  #-1,DRVSTYP(R1)    :SET INDICATOR TO 'OTHER'
303 041262 000446          :BR    4$                :EXIT
304          :          :
305 041264 012746 000121 2$:      :MOV   #121,-(SP)         :DO A 'READ-IN PRESET'
306 041270 004037 045462          :JSR   R0,WRT.RM         :
307 041274 000000          :RMCST          :
308 041276 041402          :S$          :
309 041300 012746 010000          :MOV   #BIT12,-(SP)       :SET FMT16=1
310 041304 004037 045462          :JSR   R0,WRT.RM         :
311 041310 000032          :RMOF          :
312 041312 041402          :S$          :
313 041314 004037 045302          :JSR   R0,RD.RM          :READ RMDS
314 041320 000012          :RMDS          :
315 041322 041402          :S$          :
316 041324 012605          :MOV   (SP)+,R5          :AND SAVE IT IN R5
317 041326 100015          :BPL   3$                :BR IF ATA=0
318 041330 116164 040636 000016  :MOVB  ATABIT(R1),RMAS(R4) :CLEAR ATTENTION BIT
319 041336 004037 045302          :JSR   R0,RD.RM          :FIND OUT WHY ATA-1
320 041342 000014          :RMER1          :
321 041344 041402          :S$          :

```

```

322 041346 006126          ROL      (SP)+          ;IS IT UNSAFE?
323 041350 100004          BPL      3$              ;BR IF NOT
324 041352 112761 177777 040532  MOVB    #-1,DRVSTA(R1) ;SET UNSAFE INDICATOR
325 041360 000407          BR       4$              ;EXIT
326
327 041362 005105          3$:     COM      R5              ;CHECK MOL, DPR, DRY, AND VV
328 041364 042705 167077    BIC      #^C<BIT12:BIT08:BIT07:BIT06>,R5
329 041370 001003          BNE      4$              ;BR IF MOL, DPR, DRY, OR VV IS CLEAR
330 041372 112761 000001 040532  MOVB    #1,DRVSTA(R1) ;SET DRIVE STATUS TO ONLINE
331 041400 005720          4$:     TST      (R0)+          ;STEP OVER THE ERROR RETURN
332 041402 012605          5$:     MOV      (SP)+,R5      ;RESTORE R5
333 041404 000200          RTS      R0              ;EXIT
334
335          ;REQUEST PRE-PROCESSOR-HANDLES SUBSYSTEM REQUEST
336          ;
337          ;CALL
338          ;
339          JSR      R0,RM05    ;CALL THE RM05 DRIVER
340          PNTADR   ;ADDRESS OF POINTER OF DRIVES PARAMETER BLOCK
341          RETURN1  ;RETURN HERE IF QUEUE IS FULL
342          ;
343          RETURN2  ;RETURN HERE IF REQUEST IS IN QUEUE OR THERE
344          ;IS AN ERROR CONDITION
345 041406 013746 177776  RM05:  MOV      PS,-(SP)          ;SAVE THE CALLING STATUS
346 041412 013737 040654 177776  MOV      RMVEC+2,PS      ;DON'T ALLOW ANY RM INTERRUPTS
347 041420 112737 000001 040576  MOVB    #1,ACTDRV       ;SET "ACTIVE DRIVER" FLAG
348 041426 104412          SAVREG   ;SAVE R0 - R5
349 041430 011002          MOV      (R0),R2        ;PICKUP THE DRIVE PARAMETER BLOCK POINTER
350 041432 005062 000016          CLR      16(R2)        ;CLEAR THE STATUS/ERROR INDICATOR
351 041436 111201          MOVB    (R2),R1        ;PICKUP THE DRIVE NUMBER
352 041440 013704 040650          MOV      RMADR,R4      ;UNIBUS ADDRESS OF RMCS1
353 041444 105761 040532          TSTB    DRVSTA(R1)    ;CHECK DRIVES STATUS
354 041450 003014          BGT      1$            ;BR IF ONLINE
355 041452 105761 040600          TSTB    ULDFLG(R1)    ;UNLOAD COMMAND IN QUEUE?
356 041456 001036          BNE      3$            ;BR IF YES
357 041460 105761 040552          TSTB    DPINT(R1)    ;TRYING TO INIT THE DRIVE
358 041464 001042          BNE      5$            ;BR IF YES
359 041466 004037 041072          JSR      R0,DRVINT     ;GO INIT. THE DRIVE
360 041472 000434          BR       4$            ;ERROR RETURN
361 041474 105761 040532          TSTB    DRVSTA(R1)    ;IS DRIVE STATUS ONLINE?
362 041500 003445          BLE      6$            ;BR IF NOT
363 041502 105761 040562          1$:     TSTB    DPRQS(R1)  ;OUTSTANDING PORT REQUEST FOR THE DRIVE ?
364 041506 001031          BNE      5$            ;BR IF YES
365 041510 010164 000010          MOV      R1,RMCS2(R4) ;SELECT THE DRIVE
366 041514 004037 046434          JSR      R0,DRVQUE     ;PUT THIS REQUEST IN QUEUE
367 041520 000460          BR       9$            ;QUEUE IS FULL
368 041522 122762 000103 000002  CMPB    #103,2(R2)     ;IS THIS REQ. FOR AN UNLOAD?
369 041530 001003          BNE      2$            ;BR IF NO
370 041532 112761 177777 040600  MOVB    #-1,ULDFLG(R1) ;SET THE "UNLOAD IN QUEUE" FLAG
371 041540 105761 040522          2$:     TSTB    DRVACT(R1) ;IS THIS DRIVE ACTIVE?
372 041544 001043          BNE      8$            ;BR IF YES
373 041546 004737 041700          JSR      PC,OPT        ;CALL THE OPTIMIZER
374 041552 000440          BR       8$            ;
375 041554 012762 120000 000016 3$:     MOV      #BIT15:BIT13,16(R2) ;SET THE "UNLOAD IN QUEUE" ERROR FLAG
376 041562 000434          BR       8$            ;EXIT
377 041564 004737 042756          4$:     JSR      PC,C17    ;GO HANDLE THE PARITY ERROR
378 041570 000431          BR       8$

```

```

379 041572 004037 046434 5$: JSR R0,DRVQUE ;PUT REQUEST IN QUEUE
380 041576 000431 BR 9$ ;QUEUE IS FULL
381 041600 032714 000100 BIT #BIT06,(R4) ;IE BIT SET?
382 041604 001023 BNE 8$ ;YES
383 041606 004737 045772 JSR PC,SET.IE ;SET THE INTERRUPT
384 041612 000420 BR 8$ ;RETURN
385 041614 105761 040532 6$: TSTB DRVSTA(R1) ;SEE IF DRIVE OFFLINE OR UNSAFE
386 041620 002412 BLT 7$ ;BR IF UNSAFE
387 041622 012762 140000 000016 MOV #BIT15:BIT14,16(R2) ;SET OFFLINE ERROR INDICATOR
388 041630 105761 040542 TSTB DRVSTYP(R1) ;SEE IF OFFLINE OR NONEXISTENT
389 041634 001007 BNE 8$ ;BR IF OFFLINE
390 041636 012762 100002 000016 MOV #BIT15:BIT01,16(R2) ;REPORT DRIVE NONEXISTENT
391 041644 000403 BR 8$ ;GO TO EXIT
392 041646 012762 110000 000016 7$: MOV #BIT15.BIT12,16(R2) ;DRIVE IS UNSAFE
393 041654 104413 8$: RESREG ;RESTORE R0 - R5
394 041656 005720 TST (R0)+ ;SETUP FOR NORMAL RETURN
395 041660 000401 BR 10$ ;FINISH UP, THEN EXIT
396 041662 104413 9$: RESREG ;RESTORE R0 - R5
397 041664 005720 10$: TST (R0)+ ;CORRECT THE RETURN ADDRESS
398 041666 105037 040576 CLR B ACTDRV ;CLEAR 'ACTIVE DRIVER' FLAG
399 041672 012637 177776 MOV (SP)+,PS ;RETURN 'PS' TO USER LEVEL
400 041676 000200 RTS R0 ;RETURN TO CALLER
401
402 ;OPTIMIZER-CALLED FOR A PARTICULAR DRIVE
403
404 ;CALL
405 ; MOV #DRVNUM,R1 ;DRIVE NUMBER TO R1
406 ; JSR PC,OPT ;SETUP A COMMAND
407
408 041700 104412 OPT: SAVREG ;SAVE R0 - R5
409 041702 013746 177776 MOV PS,-(SP) ;SAVE PROC. STATUS
410 041706 146137 040636 040574 BIC B ATABIT(R1),SRCHWT ;CLEAR LA SEACH FLAG
411 041714 105061 040562 CLR B DPRQS(R1) ;RESET THE PORT REQ FLAG ****
412 041720 004737 046510 JSR PC,GETREQ ;GET 'DPB' POINTER OF REQUEST
413 041724 005702 TST R2 ;IS THERE A REQUEST IN QUEUE?
414 041726 001466 BEQ 7$ ;NO--BR TO EXIT
415 041730 010164 000010 MOV R1,RMCS2(R4) ;LOAD THE DRIVE ADDRESS *****
416 041734 012764 000111 000000 MOV #111,RMCS1(R4) ;CLEAR THE DRIVE
417 041742 032764 004000 000000 BIT #BIT11,RMCS1(R4) ;DVA SET?
418 041750 001442 BEQ 5$ ;TO PORT REQUEST,IF NOT
419 041752 105761 040532 1$: TSTB DRVSTA(R1) ;IS DRIVE ONLINE?
420 041756 003014 BGT 2$ ;YES
421 041760 004737 046532 JSR PC,POPQUE ;NO--REMOVE REQUEST FROM QUEUE
422 041764 012762 140000 000016 MOV #BIT15:BIT14,16(R2) ;SET OFFLINE STATUS/ERROR INDICATOR
423 041772 105761 040532 TSTB DRVSTA(R1) ;IS DRIVE UNSAFE?
424 041776 100047 BPL 8$ ;BR TO EXIT IF NOT
425 042000 012762 110000 000016 MOV #BIT15.BIT12,16(R2) ;SET UNSAFE STATUS/ERROR INDICATOR
426 042006 000443 BR 8$ ;BR TO EXIT
427 042010
436 042010 122762 000150 000002 2$: CMP B #150,2(R2) ;IS THE REQUEST FOR I/O?
437 042016 002403 BLT 3$ ;YES
438 042020 004737 042342 JSR PC,C14 ;CALL THE COMMAND INITIATOR
439 042024 000434 BR 8$ ;BR TO EXIT
440 042026 005737 040634 3$: TST DTUW ;DATA TRANSFER UNDERWAY?
441 042032 002006 BGE 4$ ;YES--GO START A SEARCH
442 042034 005737 040612 TST SEEKFG ;DO IMPLIED SEEKS?
443 042040 100003 BPL 4$ ;NO, DO A SEARCH

```

```

444 042042 004737 042126      JSR    PC,C11          ;START A DATA TRANSFER
445 042046 000423              BR     8$              ;
446 042050 004737 042234      4$:   JSR    PC,C13          ;START A SEARCH
447 042054 000420              BR     8$              ;GO TO THE EXIT
448 042056 112761 177777 040562 5$:   MOVB   #-1,DPROS(R1)    ;SET PORT REQUEST INDICATOR
449 042064 010103              MOV    R1,R3          ;SET UP TO ADDRESS WORDS
450 042066 006303              ASL    R3              ;CONVERT TO WORD INDEX
451 042070 012763 035230 040614  MOV    #15000.,TIMER(R3) ;START 15. SECOND TIMER
452 042076 000402              BR     7$              ;EXIT
453 042100 004737 042756      6$:   JSR    PC,C17          ;PROCESS THE PARITY ERROR
454 042104 032714 000100      7$:   BIT    #BIT06,(R4)    ;SEE IF 'IE' ALREADY SET
455 042110 001002              BNE    8$              ;BR IF SET
456 042112 004737 045772      JSR    PC,SET.IE      ;SET 'IE' WITHOUT A 'TRE'
457 042116 012637 177776      8$:   MOV    (SP)+,PS      ;RESTORE PROC. STATUS
458 042122 104413              RESREG                ;RESTORE R0 - R5
459 042124 000207              RTS    PC
460
461                               ;COMMAND INITIATOR
462                               ;
463                               ;CALL
464                               ;
465                               ;   MOV    #DRVNUM,R1      ;DRIVE NUMBER
466                               ;   MOV    #DPB,R2        ;ADDRESS OF DPB
467                               ;   JSR    PC,C1?          ;C1?= C11,C13, OR C14
468                               ;WHERE:
469                               ;C11=DATA TRANSFER
470                               ;C13=SEARCH REQUESTED BY DATA XFER
471                               ;C14=NOT DATA TRANSFER
472 042126 004737 046532      C11:  JSR    PC,POPQUE      ;REMOVE REQUEST FROM 'DRIVES WAIT' QUEUE
473 042132 010237 040572      MOV    R2,TRNSWT     ;PUT REQ. IN TRANSFER WAIT QUEUE
474 042136 010203              MOV    R2,R3          ;DPB ADDRESS TO R3
475 042140 013704 040650      MOV    RMADR,R4       ;RMCS1 ADDRESS
476 042144 010164 000010      MOV    R1,RMCS2(R4)  ;SELECT DRIVE
477 042150 062703 000004      ADD    #4,R3          ;DESIRED WORD COUNT
478 042154 062704 000002      ADD    #2,R4          ;RMWC ADDRESS
479 042160 012324              MOV    (R3)+,(R4)+    ;LOAD WORD COUNT
480 042162 012324              MOV    (R3)+,(R4)+    ;LOAD BUFFER ADDRESS
481 042164 012346              MOV    (R3)+,-(SP)    ;LOAD SECTOR AND TRACK
482 042166 004037 045462      JSR    R0,WRT.RM     ;CALL THE LOAD(WRITE) ROUTINE
483 042172 000006              RMDA                ;INDEX OF REGISTER TO LOAD
484 042174 042756              C17                  ;ERROR RETURN ADDRESS
485 042176 012346              MOV    (R3)+,-(SP)    ;LOAD CYLINDER ADDRESS
486 042200 004037 045462      JSR    R0,WRT.RM
487 042204 000034              RMDC
488 042206 042756              C17
489 042210 016246 000002      MOV    2(R2),-(SP)    ;LOAD 'COMMAND+GO', 'A17&A16', AND 'PSEL'
490 042214 004037 045462      JSR    R0,WRT.RM
491 042220 000000              RMCS1
492 042222 042756              C17
493 042224 010137 040634      MOV    R1,DTUW        ;SET 'DATA TRANSFER UNDERWAY'
494 042230 000137 042720      JMP    C15
495
496 042234 013704 040650      C13:  MOV    RMADR,R4       ;RMCS1 ADDRESS
497 042240 010164 000010      MOV    R1,RMCS2(R4)  ;SELECT DRIVE
498 042244 016246 000012      MOV    12(R2),-(SP)  ;DESIRED CYLINDER ADDRESS
499 042250 004037 045462      JSR    R0,WRT.RM
500 042254 000034              RMDC
  
```

501	042256	042756			C17		
502	042260	116203	C00010		MOV B	10(R2),R3	; PICKUP SECTOR ADDRESS
503	042264	163703	040656		SUB	MXWINDW,R3	; BACKUP BY MAX. SEARCH FOR I/O WINDOW
504	042270	002002			BGE	1\$	
505	042272	062703	000040		ADD	#32.,R3	
506	042276	010346		1\$:	MOV	R3,-(SP)	; COMBINE THE ADJUSTED SECTOR WITH
507	042300	116266	000011	000001	MOV B	11(R2),1(SP)	; THE DESIRED TRACK
508	042306	004037	045462		JSR	RO,WRT.RM	; LOAD DESIRED TRACK & SECTOR
509	042312	000006			RMDA		
510	042314	042756			C17		
511	042316	012746	000131		MOV	#131,-(SP)	; START A SEARCH
512	042322	004037	045462		JSR	RO,WRT.RM	
513	042326	000000			RMCS1		
514	042330	042756			C17		
515	042332	156137	040636	040574	BIS B	ATAB1,(R1),SRCHWT	; SET 'SEARCH WAIT' KEY
516	042340	000567			BR	C15	
517							
518	042342	013704	040650		C14:	MOV	RMADR,R4
519	042346	010164	000010		MOV	R1,RMCS2(R4)	; SELECT DRIVE
520	042352	116203	000002		MOV B	2(R2),R3	; PICKUP THE REQUESTED COMMAND
521	042356	122703	000131		CMPS	#131,R3	; IS IT A SEARCH COMMAND?
522	042362	001007			BNE	1\$; BR IF NO
523	042364	016246	C00010		MOV	10(R2),-(SP)	; LOAD DESIRED TRACK & SECTOR
524	042370	004037	045462		JSR	RO,WRT.RM	
525	042374	000006			RMDA		
526	042376	042756			C17		
527	042400	000403			BR	2\$; GO LOAD CYLINDER
528	042402	122703	000105	1\$:	CMPS	#105,R3	; IS IT A SEEK COMMAND
529	042406	001007			BNE	3\$; BR IF NO
530	042410	016246	000012	2\$:	MOV	12(R2),-(SP)	; LOAD DESIRED CYLINDER
531	042414	004037	045462		JSR	RO,WRT.RM	
532	042420	000034			RMDC		
533	042422	042756			C17		
534	042424	000546			BR	C16	
535	042426	122703	000115	3\$:	CMPS	#115,R3	; IS IT AN 'OFFSET' COMMAND?
536	042432	001013			BNE	4\$; BR IF NO
537	042434	004037	045302		JSR	RO,RD.RM	; MERGE THE OFFSET VALUE INTO RMOF
538	042440	000032			RMOF		; BUT DON'T CHANGE THE UPPER
539	042442	042756			C17		
540	042444	116216	000001		MOV B	1(R2),(SP)	; BYTE WHEN LOADING THE
541	042450	004037	045462		JSR	RO,WRT.RM	; REGISTER (RMOF)
542	042454	000032			RMOF		
543	042456	012756			C17		
544	042460	000530			BR	C16	; GO START THE COMMAND
545	042462	122703	000107	4\$:	CMPS	#107,R3	; IS IT A 'RECALIBRATE' COMMAND?
546	042466	001525			BEQ	C16	; BR IF YES
547	042470	122703	000117		CMPS	#117,R3	; IS IT A RETURN TO CENTER?
548	042474	001522			BEQ	C16	; BR IF YES
549	042476	122703	000103		CMPS	#103,R3	; IS IT AN 'UNLOAD' COMMAND?
550	042502	001016			BNE	5\$; BR IF NO
551	042504	112761	000001	040522	MOV B	#1,DRVACT(R1)	; SET THE DRIVE ACTIVE INDICATOR
552	042512	105061	040532		CLRB	DRVSTA(R1)	; PUT DRIVE STATUS TO OFFLINE
553	042516	112761	000001	040600	MOV B	#1,ULDFLG(R1)	; SET 'UNLOAD IN PROGRESS' FLAG
554	042524	010346			MOV	R3,-(SP)	; START THE 'UNLOAD' COMMAND
555	042526	004037	045462		JSR	RO,WRT.RM	
556	042532	000000			RMCS1		
557	042534	042756			C17		

558	042536	000207			RTS	PC		:RETURN TO USER
559	042540	122703	C00143	5\$:	CMPB	#143,R3		:IS IT A 'SET FORMAT' COMMAND?
560	042544	001014			BNE	6\$:BR IF NO
561	042546	004037	045302		JSR	RO,RD,RM		:READ THE OFFSET REGISTER
562	042552	000032			RMCS1			
563	042554	042756			C17			
564	042556	116266	000001	000001	MOVB	1(R2),1(SP)		:COMBINE 'FMT16','ECI', AND 'HCI'
565	042564	004037	045462		JSR	RO,WRT,RM		:LOAD 'FMT16','ECI', AND/OR 'HCI'.
566	042570	000032			RMCS1			
567	042572	042756			C17			
568	042574	000436			BR	12\$		
569	042576	122703	000141	6\$:	CMPB	#141,R3		:IS IT A 'GET REGISTER' COMMAND?
570	042602	001023			BNE	10\$:BR IF NO
571	042604	016203	000006	7\$:	MOV	6(R2),R3		:POINTS TO 1ST ADDRESS OF WHERE
572								:TO PUT THE REGISTER(S)
573	042610	116237	000010	042626	MOVB	10(R2),9\$:INIT. THE INDEX FOR THE FIRST REG.
574	042616	116205	000011		MOVB	11(R2),R5		:INDEX OF LAST REG. TO MOVE
575	042622	004037	045302	8\$:	JSR	RO,RD,RM		:READ RH/RM REGISTER
576	042626	000000		9\$:	RMCS1			:INDEX OF REG. TO READ
577	042630	042756			C17			
578	042632	012623			MOV	(SP)+,(R3)+		:GET THE CONTENTS OF RH/RM REG.
579	042634	023705	042626		CMP	9\$,R5		:LAST REG. BEEN READ?
580	042640	001414			BEQ	12\$:GET OUT IF YES
581	042642	062737	000002	042626	ADD	#2,9\$:INCREASE THE INDEX BY 2
582	042650	000764			BR	8\$:LOOP--MORE TO READ
583	042652	122703	000145	10\$:	CMPB	#145,R3		:IS IT A 'SELECT DRIVE' COMMAND?
584	042656	001405			BEQ	12\$:BR IF YES
585	042660	010346		11\$:	MOV	R3,-(SP)		:LOAD THE COMMAND
586	042662	004037	045462		JSR	RO,WRT,RM		
587	042666	000000			RMCS1			
588	042670	042756			C17			
589	042672	004737	046532	12\$:	JSR	PC,POPQUE		:REMOVE REG. FROM QUEUE
590	042676	052762	000200	000016	BIS	#BIT07,16(R2)		:SET THE 'DONE' BIT
591	042704	005737	040610		TST	SAVEFG		:SAVE THE RH/RM REGISTERS?
592	042710	100002			BPL	13\$:BR IF NO
593	042712	004737	045654		JSR	PC,SVRH70		:YES--GO SAVE THE REGISTERS
594	042716	000207		13\$:	RTS	PC		:RETURN TO USER
595								
596	042720	006301		15:	ASL	R1		
597	042722	012761	023420	040614	MOV	#10000.,TIMER(R1)		:START 10. SECOND TIMER
598	042730	006201			ASR	R1		
599	042732	112761	000001	040522	MOVB	#1,DRVACT(R1)		:SET THE DRIVE ACTIVE
600	042740	000207			RTS	PC		:RETURN TO THE USER
601								
602	042742	010346		16:	MOV	R3,-(SP)		:LOAD THE COMMAND
603	042744	004037	045462		JSR	RO,WRT,RM		
604	042750	000000			RMCS1			
605	042752	042756			C17			
606	042754	000761			BR	C15		
607								
608	042756	032764	010000	000010	BIT	#BIT12,RMCS2(R4)		:DRIVE NON-EXISTENT ?
612	042764	005702		1\$:	TST	R2		:ANYTHING IN QUEUE ?
616	042766	001001			BNE	2\$:BR IF QUEUE IS THERE
617	042770	000207			RTS	PC		:OTHERWISE EXIT
618	042772	012762	104000	000016	MOV	#BIT15.BIT11,16(R2)		:SET 'PARITY' ERROR INDICATOR
622								
623	043000	012746	000111	17B:	MOV	#111,-(SP)		:DO A 'DRIVE CLEAR'

```

624 043004 004037 045467 JSR RO,WRT,RM
625 043010 000000 RMCS1
626 043012 043056 C18
627 043014 004737 046414 1$: JSR PC,EMPTYQ ;EMPTY THE QUEUE
628 043020 105061 040562 CLR B DPRQS(R1) ;CLEAR THE PORT REQUEST FLAG
629 043024 105061 040600 CLR B ULDFLG(R1) ;CLEAR THE UNLOAD IN QUEUE FLAG
630 043030 105061 040522 CLR B DRVACT(R1) ;DRIVE IS IDLE
631 043034 020237 040572 CMP R2,TRNSWT ;IF THIS DRIVE HAD AN I/O REQUEST
635 043040 001005 BNE Z$ ;IN PROGRESS CLEAR ALL OF THE FLAGS
636 043042 005037 040572 CLR TRNSWT
637 043046 012737 177777 040634 MOV # -1,DTUW
638 043054 000207 2$: RTS PC
639
640 043056 104412 C18: SAVREG ;SAVE R0 - R5
641 043060 005001 CLR R1
642 043062 005003 CLR R3
643 043064 105761 040522 1$: TST B DRVACT(R1) ;DRIVE ACTIVE?
644 043070 001003 BNE Z$ ;BR IF IN ACTIVE
645 043072 105761 040562 TST B DPRQS(R1) ;PORT REQUEST
646 043076 001443 BEQ 6$ ;BR IF NOT
647 043100 013702 040572 2$: MOV TRNSWT,R2 ;GET THE 'TRANSFER WAIT' QUEUE
648 043104 020137 040634 CMP R1,DTUW ;DID THIS DRIVE HAVE AN I/O IN PROGRESS?
649 043110 001402 BEQ 3$ ;BR IF YES
650 043112 004737 046510 JSR PC,GETREQ ;GET THE DPB POINTER
651 043116 005702 3$: TST R2 ;QUEUE ENTRY FOR DRIVE ?
652 043120 001413 BEQ 5$ ;BR IF NOT
653 043122 032764 010000 000010 BIT #BIT12,RMCS2(R4) ;'NED' SET ?
654 043130 001404 BEQ 4$ ;BR IF NOT
655 043132 012762 100002 000016 MOV #BIT15:BIT01,16(R2) ;SET 'DRIVE NON-EXISTENT' INDICATOR
656 043140 000403 BR 5$ ;CONTINUE
657 043142 012762 102000 000016 4$: MOV #BIT15:BIT10,16(R2) ;SET 'NON-CLEARABLE PARITY' ERROR INDICATOR
661 043150 012763 177777 040614 5$: MOV # -1,TIMER(R3) ;STOP THE TIMER
662 043156 105061 040522 CLR B DRVACT(R1) ;SET 'DRIVE ACTIVE' TO IDLE
663 043162 105061 040562 CLR B DPRQS(R1) ;CLEAR PORT REQUEST FLAG
664 043166 020137 040634 CMP R1,DTUW ;IS THIS DRIVE SETUP FOR A TRANSFER
665 043172 001005 BNE 6$ ;BR IF NOT
666 043174 012737 177777 040634 MOV # -1,DTUW ;RESET THE INDICATOR
667 043202 005037 040572 CLR TRNSWT ;CLEAR THE TRANSFER QUEUE
668 043206 105061 040600 6$: CLR B ULDFLG(R1) ;CLEAR UNLOAD FLAG
669 043212 032764 010000 000010 BIT #BIT12,RMCS2(R4) ;'NED' SET ?
673 043220 005201 INC R1 ;MOVE TO THE NEXT DRIVE
674 043222 062703 000902 ADD #2,R3
675 043226 042701 177770 BIC #C7,R1
676 043232 001314 BNE 1$ ;BR IF MORE DRIVES
677 043234 012737 177777 040634 MOV # -1,DTUW ;NO DATA TRANSFERS UNDERWAY
678 043242 005037 040572 CLR TRNSWT ;CLEAR THE 'TRANSFER WAIT' QUEUE
679 043246 004737 046336 JSR PC,CLRQUE ;CLEAR ALL OF THE REQUEST QUEUES
680 043252 012764 000040 C00010 MOV #CLR,RMCS2(R4) ;DO A MASSBUS INIT.
681 043260 000406 BR 8$ ;CONTINUE
682 043262 004737 046414 7$: JSR PC,EMPTYQ ;CLEAR THE DRIVE'S QUEUE
683 043266 105061 040532 CLR B DRVSTA(R1) ;SET DRIVE TO OFFLINE
684 043272 105061 040542 CLR B DRVTYPE(R1) ;CLEAR THE DRIVE TYPE INDICATOR
685 043276 004737 045772 8$: JSR PC,SET.IE ;SET 'IE' WITHOUT 'TR'
686 043302 104413 RESREG ;RESTORE R0 - R5
687 043304 000207 RTS PC ;RETURN
688
689 ;INTERRUPT SERVICE ROUTINE

```



```

690
691 043306 112737 000001 040576 ISR:  MOVB  #1,ACTDRV      ;SET "ACTIVE DRIVER" FLAG
692 043314 104412          SAVREG          ;SAVE R0 - R5
693 043316 013704 040650  MOV      RMADR,R4    ;ADDRESS OF RMCS1
694 043322 013701 040634  MOV      DTUW,R1     ;GET "DATA TRANSFER UNDERWAY" INDICATOR
695 043326 002402          BLT      1$         ;BR IF NO DATA TRANSFER UNDERWAY
696 043330 004737 043350  JSR      PC,"D       ;CALL TRANSFER DONE
697 043334 004737 043520  1$:     JSR      PC,SC    ;CALL SPECIAL CONDITIONS
698 043340 104413          2$:     RESREG          ;RESTORE R0 - R5
699 043342 105037 040576  CLR      AC'DRV     ;CLEAR "ACTIVE DRIVER" FLAG
700 043346 000002          RTI              ;RETURN
701
702          ;TRANSFER DONE ROUTINE
703
704 043350 105061 040522  TD:     CLR      DRVACT(R1) ;SET DRIVE ACTIVE INDICATOR TO IDLE
705 043354 012737 177777 040634  MOV      #-1,DTUW     ;NO DATA TRANSFERS UNDERWAY
706 043362 006301          ASL      R1
707 043364 012761 177777 040614  MOV      #-1,TIMER(R1) ;CANCEL TIMEOUT
708 043372 006201          ASR      R1
709 043374 013702 040572  MOV      TRNSWT,R2    ;GET "DPB" ADDRESS FROM THE
710 043400 005037 040572  CLR      TRNSWT      ;TRANSFER WAIT QUEUE--CLEAR QUEUE
711 043404 052762 000200 000016  BIS      #BIT07,16(R2) ;SET DONE
712 043412 010164 000010  MOV      R1,RMCS2(R4) ;SELECT THE DRIVE
713 043416 004037 045302  JSR      R0,RD.RM    ;TRANSFER ERROR(TRE=1)?
714 043422 000000          RMCS1
715 043424 042756          C17
716 043426 006126          ROL      (SP)+      ;IS TRE=1 ?
717 043430 100417          BMI      3$         ;BR IF YES
718 043432 005737 040610  TST      SAVEFG      ;SAVE THE RH/RM REGISTERS?
719 043436 100002          BPL      1$         ;BR IF NO
720 043440 004737 045654  JSR      PC,SVRH70   ;YES--SAVE THE REGISTERS
721 043444 004737 046510  1$:     JSR      PC,GETREQ ;GET DPB POINTER
722 043450 005702          TST      R2         ;ENTRY FOR DRIVE ?
723 043452 001403          BEQ      2$         ;BR IF NOT
724 043454 004737 041700  JSR      PC,OPT      ;CALL OPTIMIZER
725 043460 000207          RTS      PC        ;RETURN
726 043462 012714 000113  2$:     MOV      #113,(R4) ;RELEASE THE DRIVE
727 043466 000207          RTS      PC        ;RETURN
728
729 043470 052762 100100 000016  3$:     BIS      #BIT15!BIT06,16(R2) ;SET DATA ERROR FLAG
730 043476 004737 046414  JSR      PC,EMPTYQ   ;EMPTY THE "DRIVE'S WAIT" QUEUE
731 043502 004737 045654  JSR      PC,SVRH70   ;SAVE THE RH/RM REGISTERS
732 043506 012714 040111  MOV      #40111,(R4) ;ISSUE A "DRIVE CLEAR"
733 043512 012714 000113  MOV      #113,(R4)  ;ISSUE A RELEASE TO THE DRIVE
734 043516 000207          RTS      PC        ;RETURN
735
736          ;SPECIAL CONDITION ROUTINE
737
738 043520 116403 000016  SC:     MOV      RMAS(R4),R3 ;READ "RMAS"
739 043524 001014          BNE      2$         ;BR IF ANY "ATA" BITS SET
740 043526 004037 045302  JSR      R0,RD.RM    ;READ CONTROL AND STATUS REGISTER
741 043532 000000          RMCS1
742 043534 043056          C18
743 043536 106126          ROL      (SP)+      ;IS "IE"=1?
744 043540 100405          BMI      1$         ;YES, NO DRIVES TO CHECK
745 043542 004037 046600  JSR      R0,ES.SAV   ;SAVE THE ADDRESS IN "$ESCAPE"
746 043546 104001          EMT      1         ;REPORT AN ILLEGAL INTERRUPT
  
```

```

773 043550 004737 045772          JSR    PC,SET.IE      ;SET INTERRUPT ENABLE
774 043554 000207          1$:   RTS    PC        ;RETURN
775 043556 005046          2$:   CLR    -(SP)     ;PROCESS ALL DRIVES THAT HAVE
776 043560 110316          MOVB   R3,(SP)       ;AN 'ATA'=1
777 043562 012703 000001      MOV    #1,R3
778 043566 005001          CLR    R1
779
780 043570 030316          SC3:  BIT    R3,(SP)   ;ATA=1?
781 043572 001005          BNE   SC5            ;YES
782
783 043574 005201          SC4:  INC    R1        ;MOVE TO THE NEXT DRIVE
784 043576 106303          ASLB  R3
785 043600 001373          BNE   SC3            ;BR IF MORE TO CHECK?
786 043602 005726          TST   (SP)+         ;CLEAN OFF THE STACK
787 043604 000207          RTS    PC            ;RETURN TO USER
788
789 043606 105761 040552      SC5:  TSTB  DPINT(R1)  ;INITIALIZING THE DRIVE ?
790 043612 001402          BEQ   1$            ;BR IF NOT
791 043614 000137 044532      JMP   SC13          ;PROCESS THE DRIVE
792 043620 105761 040562      1$:   TSTB  DPRQS(R1)  ;PORT REQUEST OUTSTANDING ?
793 043624 001402          BEQ   2$            ;BR IF NOT
794 043626 000137 044532      JMP   SC13          ;START THE OUTSTANDING COMMAND
795 043632 105761 040532      2$:   TSTB  DRVSTA(R1) ;CHECK THE DRIVE STATUS
796 043636 003023          BGT   4$            ;BR IF ONLINE
797 043640 105761 040600      TSTB  ULDFLG(R1)    ;UNLOAD IN PROGRESS?
798 043644 003420          BLE   4$            ;BR IF NOT
799 043646 004737 046510      JSR   PC,GETREQ     ;GET DPS POINTER
800 043652 004737 045654      JSR   PC,SVRH70     ;SAVE THE RH/RM REGISTERS
801 043656 004737 044462      JSR   PC,SC12       ;SAVE RMD5, RMER1, RMER2, AND RMMR2
802
803 043662 105761 040532      TSTB  DRVSTA(R1)    ;DID DRIVE COME ONLINE?
804 043666 003414          BLE   5$            ;NO
805 043670 032737 040000 040512  BIT    #BIT14,RMERRS ;WAS THERE AN ERROR?
806 043676 001000          BNE   3$            ;BR IF ERROR
807 043700 013705 040514      3$:   MOV    RMERRS+2,R5 ;YES -- PICKUP RMER1 AND
808 043704 000504          BR    SC6A          ;GO PROCESS THE ERROR
809 043706 105761 040522      4$:   TSTB  DRVACT(R1) ;DRIVE ACTIVE WITH COMMAND OR ERROR RECOVERY ?
810 043712 001033          BNE   SC6           ;BR IF EITHER
811 043714 004737 044462      JSR   PC,SC12       ;SAVE RMD5, RMER1, RMER2, AND RMMR2
812
813 043720 105761 040552      5$:   TSTB  DPINT(R1)  ;TRYING TO INIT THE DRIVE ?
814 043724 001323          BNE   SC4           ;BR IF YES, CHECK ON MORE DRIVES
815 043726 105761 040532      TSTB  DRVSTA(R1)    ;CHECK ON DRIVE'S STATUS
816 043732 100412          BMI   6$            ;BR IF UNSAFE
817 043734 032737 020000 040516  BIT    #BIT13,RMERRS+4 ;ADDRESS PLUG CHANGED ?
818 043742 001013          BNE   7$            ;BR IF YES
819 043744 012746 000111      MOV    #111,-(SP)   ;DRIVE CLEAR
820 043750 004037 045462      JSR   R0,WRT.RM     ;WRITE THE COMMAND INTO RMC51
821 043754 000000          RMC51
822 043756 044322          SC8
823 043760 011605          6$:   MOV    (SP),R5    ;PICKUP (RMA5) BEFORE THE ERROR CALL
824 043762 004037 046600      JSR   R0,ES.SAV     ;SAVE THE ADDRESS IN '$ESCAPE'
825 043766 104002          EMT   2             ;REPORT THE UNEXPECTED ATTENTION
826 043770 000701          BR    SC4           ;GO CHECK FOR MORE ATA'S
827
828 043772 004037 046600      7$:   JSR   R0,ES.SAV     ;SAVE THE ADDRESS IN '$ESCAPE'
829 043776 104005          EMT   5             ;REPORT THE ADDRESS PLUG CHANGE
    
```

```

833 044000 000675          BR      SC4          ;CHECK FOR MORE DRIVES
834
835 044002 006301          SC6:  ASL      R1          ;SETUP TO ADDRESS WORDS
836 044004 012761 177777 040614  MOV     #-1,TIMER(R1) ;STOP THE TIMER
837 044012 006201          ASR      R1          ;RESTORE THE DRIVE ADDRESS
838 044014 004737 046510   JSR     PC,GETREQ    ;GET THE DPB POINTER FROM THE QUEUE
839 044020 010164 000010   MOV     R1,RMCS2(R4) ;SELECT DRIVE
840 044024 000137 044352   JMP     SC11        ;PROCESS THE SEARCH
841 044030 004037 045302   JSR     R0,RD.RM    ;READ THE RM'S STATUS REG.
842 044034 000012          RMDS
843 044036 044322          SC8
844 044040 011605          MOV     (SP),R5     ;AND PUT IT IN R5
845 044042 006126          ROL     (SP)+       ;WAS THERE AN ERROR?
846 044044 100407          BMI     1$         ;BR IF ERROR
847 044046 105761 040522   TSTB   DRVACT(R1)  ;CHECK DRIVE'S STATE
848 044052 003137          BGT     SC11       ;BR IF DRIVE ACTIVE WITH ORDER
849 044054 052762 100210 000016  BIS    #BIT15:BIT07:BIT03,16(R2) ;INFORM USER OF ERROR RECOVER COMPLETION
850 044062 000470          BR      SC7
851 044064 004037 045302   1$:   JSR     R0,RD.RM    ;READ ERROR REGISTER #1
852 044070 000014          RMER1
853 044072 044322          SC8
854 044074 012605          MOV     (SP)+,R5   ;AND SAVE IT IN R5
855 044076 004737 045654   JSR     PC,SVRH70  ;SAVE RH/RM REGISTERS
856 044102 012746 000111   MOV     #11,-(SP)  ;ISSUE A DRIVE CLEAR
857 044106 004037 045462   JSR     R0,WRT.RM
858 044112 000000          RMCS1
859 044114 044322          SC8
860
861 044116 006105          SC6A: ROL     R5          ;WAS 'UNSAFE' CONDITION -1?
862 044120 100406          BMI     1$         ;BR IF YES
863 044122 005702          TST     R2          ;ANYTHING IN QUEUE ?
864 044124 001447          BEQ     SC7         ;BR IF NOT
865 044126 052762 100240 000016  BIS    #BIT15:BIT07:BIT05,16(R2) ;INFORM USER OF ERROR
866 044134 000443          BR      SC7
867 044136 004037 045302   1$:   JSR     R0,RD.RM    ;READ DRIVE STATUS REG. #1
868 044142 000012          RMDS
869 044144 044322          SC8
870 044146 011605          MOV     (SP),R5   ;SAVE RMDS IN R5
871 044150 006126          ROL     (SP)+       ;'ERR'=1?
872 044152 100011          BPL     2$         ;BR IF NO--UNSAFE CLEARED
873 044154 112761 177777 040532  MOVB   #-1,DRVSTA(R1) ;DRIVE IS UNSAFE
874 044162 004737 045654   JSR     PC,SVRH70  ;SAVE RH/RM REGISTERS
875 044166 052762 110000 000016  BIS    #BIT15:BIT12,16(R2) ;INFORM USER OF UNSAFE ERROR
876 044174 000423          BR      SC7
877 044176 032705 010000          2$:   BIT     #BIT12,R5   ;'MOL' = 1 ?
878 044202 001015          BNE     3$         ;BR IF YES
879 044204 112761 177777 040522  MOVB   #-1,DRVACT(R1) ;ACTIVE ERROR RECOVER
880 044212 112761 000001 040532  MOVB   #1,DRVSTA(R1) ;ONLINE
881 044220 006301          ASL     R1
882 044222 012761 035230 040614  MOV     #15000.,TIMER(R1) ;START 15. SECOND TIMER
883 044230 006201          ASR     R1
884 044232 000137 043574   JMP     SC4
885 044236 052762 100220 000016  3$:   BIS    #BIT15:BIT07:BIT04,16(R2) ;INFORM USER OF ERROR
886
887 044244 105061 040522          SC7:  CLRB   DRVACT(R1)  ;DRIVE IS IDLE
889 044250 004737 046532   JSR     PC,POPQUE  ;REMOVE THE QUEUE
892 044254 105761 040600   TSTB   ULDFLG(R1)  ;UNLOAD IN PROGRESS OR QUEUE?

```

```

893 044260 003002          BGT      1$          ;BR IF NOT
894 044262 105061 040600    CLRB    ULDFLG(R1)  ;CLEAR UNLOAD FLAG
895 044266 116164 040636    000016 1$:  MOVB   ATABIT(R1),RMAS(R4) ;CLEAR ATTENTION BIT
896 044274 105761 040532    TSTB   DRVSTA(R1)  ;IS THE DRIVE UNSAFE ?
897 044300 100406          BMI     2$          ;BR IF IT IS
901 044302 012746 000111    MOV     #111,-(SP)  ;DRIVE CLEAR COMMAND
902 044306 004037 045462    JSR    RO,WRT,RM   ;WRITE THE COMMAND INTO RPCS1
903 044312 000000          RMCS1  ;REGISTER INDEX
904 044314 044322          SCB    ;PARITY EXIT ADDRESS
905 044316 000137 043574    2$:    JMP     SC4      ;CHECK FOR MORE DRIVES
906
907 044322 105761 040522    SC8:   TSTB   DRVACT(R1) ;IS DRIVE IDLE?
908 044326 001405          BEQ    1$          ;YES
909 044330 004737 046510    JSR    PC,GETREQ   ;GET DPB POINTER
910 044334 004737 042756    JSR    PC,C17      ;PROCESS THE PARITY ERROR
911 044340 000402          BR     2$          ;CONTINUE
912 044342
916 044342 004737 043000    1$:    JSR    PC,C17B   ;PROCESS THE UNCORRECTABLE PARITY ERROR
917 044346 000137 043574    2$:    JMP     SC4      ;CHECK MORE DRIVES
918
919 044352 105761 040600    SC11: TSTB   ULDFLG(R1)  ;'UNLOAD IN PROGRESS'?
920 044356 003402          BLE    1$          ;BR IF NO
921 044360 105061 040600    CLRB   ULDFLG(R1)  ;CLEAR UNLOAD FLAG
922 044364 105061 040522    1$:    CLRB   DRVACT(R1)  ;SET DRIVE IDLE
923 044370 136137 040636    040574 BITB   ATABIT(R1),SRCHWT ;DOING A SEARCH OPERATION FOR
924                                     ;AN I/O COMMAND?
925 044376 001012          BNE    2$          ;BR IF YES
926 044400 004737 046532    JSR    PC,POPQUE   ;REMOVE REQUEST FROM QUEUE
927 044404 052762 000200    000016 BIS    #BIT07,16(R2) ;SET 'DONE' BIT
928 044412 005737 040610    TST    SAVEFG     ;SAVE THE REGISTERS?
929 044416 100002          BPL    2$          ;BR IF NO
930 044420 004737 045654    JSR    PC,SVRH70  ;YES--SAVE ALL OF THE RH/RM REG'S
931 044424 116164 040636    000016 2$:  MOVB   ATABIT(R1),RMAS(R4) ;CLEAR ATTENTION BIT
932 044432 146137 040636    040574 BICB   ATABIT(R1),SRCHWT ;CLEAR IMPLIED SEEK SET
933 044440 006301          ASL    R1          ;WORD INDEX
934 044442 012761 177777    040614 MOV    #-1,TIMER(R1) ;STOP CLOCK
935 044450 006201          ASR    R1          ;RESTORE R1
936 044452 004737 041700    JSR    PC,OPT     ;START A REQUEST
937 044456 000137 043574    JMP    SC4        ;CHECK FOR MORE DRIVES
938
939 044462 010164 000010    SC12: MOV    R1,RMCS2(R4) ;SELECT DRIVE
940 044466 016437 000012    040512 MOV    RMDS(R4),RMERRS ;SAVE THE FOUR REGISTERS THAT
941 044474 016437 000014    040514 MOV    RMER1(R4),RMERRS+2 ;WILL TELL US SOMETHING
942 044502 016437 000042    040516 MOV    RMER2(R4),RMERRS+4
943 044510 016437 000040    040520 MOV    RMMR2(R4),RMERRS+6
944 044516 004037 041072    JSR    RO,DRVINT  ;INIT. THE STATE OF THE DRIVE
945 044522 000401          BR     1$          ;TAKE ERROR EXIT
946 044524 000207          RTS    PC          ;RETURN
947 044526 005726          1$:    TST    (SP)+      ;POP PC OFF OF THE STACK
948 044530 000674          BR     SC8        ;PROCESS THE PARITY ERROR
949
950 044532 006301          SC13: ASL    R1          ;SETUP TO ADDRESS WORDS
951 044534 012761 177777    040614 MOV    #-1,TIMER(R1) ;STOP THE TIMER
952 044542 006201          ASR    R1          ;
953 044544 010164 000010    MOV    R1,RMCS2(R4) ;SELECT THE DRIVE
954 044550 116164 040636    000016 MOVB   ATABIT(R1),RMAS(R4) ;CLEAR THE ATTENTION BIT
955 044556 105761 040552    1$:    TSTB   DPINT(R1)  ;INITIALIZING THE DRIVE ?

```

```

956 044562 001424      BEQ      2$      ;BR IF NOT
957 044564 105061 040552  CLRB     DPINT(R1) ;CLEAR THE INIT INDICATOR
958 044570 004037 041072  JSR      RO,DRVINT ;GO INIT THE DRIVE
959 044574 000240      NOP              ;DUMMY PARITY ERROR RETURN
960 044576 105761 040532  TSTB    DRVSTA(R1) ;DRIVE ONLINE ?
961 044602 003014      BGT      2$      ;BR IF YES -- START ORDER
962 044604 005702      TST      R2      ;QUEUE ENTRY FOR THE DRIVE
963 044606 001426      BEQ      3$      ;BR IF NOT
964 044610 004737 046510  JSR      PC,GETREQ ;GET DPB ADDRESS
965 044614 052762 140000 000016  BIS     #BIT15,BIT14,16(R2) ;INFORM USER THAT DRIVE OFFLINE
966 044622 004737 045654  JSR      PC,SVH70 ;SAVE THE REGISTERS
970 044626 004737 046532  JSR      PC,POPQUE ;REMOVE THE QUEUE
971 044632 000414      BR       3$
972 044634 032764 004000 000000 2$:  BIF     #BIT11,RMCS1(R4) ;DVA SET ?
973 044642 001006      BNE     4$      ;SET THEN CALL OPT
974 044644 006301      ASL     R1
975 044646 012761 035230 040614  MOV     #15000.,TIMER(R1) ;START 15. SECOND TIMER
976 044654 006201      ASR     R1
977 044656 000402      BR       3$
978 044660 004737 041700      4$:  JSR     PC,OPT   ;START THE PENDING REQUEST
979 044664 000137 043574      3$:  JMP     SC4     ;PROCESS OTHER DRIVES
980
981      ;RM TIMER ROUTINE
982      ;CALL
983      ;
984      ;      MOV     #TIME,-(SP) ;ELAPSED TIME IN MILLISECONDS ON THE STACK
985      ;      JSR     PC,RMTMR   ;CALL RM05 TIME ROUTINE
986 044670 005737 040576      RMTMR: TST     ACTDRV   ;CHECK 'ACTDRV & ACTSTR'
987 044674 001027      BNE     4$      ;IF NON ZERO EXIT
988 044676 112737 000001 040577  MOV     #1,ACTSTR ;SET 'ACTSTR'
989 044704 104412      SAVREG ;SAVE R0 - R5
990 044706 005001      CLR     R1      ;START WITH DRIVE 0
991 044710 005003      CLR     R3
992 044712 005763 040614      1$:  TST     TIMER(R3) ;IS THE TIMER RUNNING?
993 044716 002406      BLT     2$      ;BR IF NO
994 044720 166663 000002 040614  SUB     2(SP),TIMER(R3) ;COUNT THE INTERVAL
995 044726 003002      BGT     2$      ;BR IF NO SOFTWARE TIMEOUT
996 044730 004737 044760      JSR     PC,STO   ;CALL SOFTWARE TIMEOUT ROUTINE
997 044734 005201      2$:  INC     R1      ;MOVE TO NEXT DRIVE
998 044736 005723      TST     (R3)+
999 044740 022701 000010      CMP     #8.,R1   ;OUT OF DRIVES?
1000 044744 003362      BGT     1$      ;BR IF NO
1001 044746 104413      3$:  RESREG ;RESTORE R0 - R5
1002 044750 105037 040577      CLRB   ACTSTR   ;ZERO ACTIVE SOFTWARE TIMEOUT ROUTINE FLAG
1003 044754 012616      4$:  MOV     (SP)+,(SP) ;ADJUST THE STACK
1004 044756 000207      RTS    PC      ;RETURN
1005
1006      ;SOFTWARE TIMEOUT ROUTINE
1007
1008      ;NOTE: THIS ROUTINE MUST BE ENTERED AT PRIORITY 6
1009      ;OR GREATER
1010
1011      ;CALL:
1012      ;      STO
1013      ;      MOV     #DRVNUM,R1 ;DRIVE NUMBER
1014      ;      JSR     PC,STO   ;CALL
1015      ;      RETURN

```

1016	044760	010146			STO:	MOV	R1,-(SP)	:SAVE R1
1017	044762	010246				MOV	R2,-(SP)	:SAVE R2
1018	044764	010346				MOV	R3,-(SP)	:SAVE R3
1019	044766	010446				MOV	R4,-(SP)	:SAVE R4
1020	044770	013704	040650			MOV	RMADR,R4	:GET ADDRESS OF 'RMCS1'
1021	044774	010164	000010			MOV	R1,RMCS2(R4)	:SELECT THE DRIVE
1022	045000	004037	04530?			JSR	R0,RD.RM	:READ 'DRIVE STATUS REG'
1023	045004	000012				RMDS		
1027	045006	045270				STO9		
1028	045010	105726				TSTB	(SP)+	:IS 'DRY'=1?
1029	045012	100436				BMI	STO2	:BR IF YES
1030	045014	105761	040552		STO1:	TSTB	DPINT(R1)	:TRYING TO INITIALIZE THE DRIVE ?
1031	045020	001033				BNE	STO2	:BR IF YES
1032	045022	105761	040562			TSTB	DPRQS(R1)	:OUTSTANDING PORT REQUEST FOR THE DRIVE ?
1033	045026	001030				BNE	STO2	:BR IF YES
1034	045030	013702	040572			MOV	TRNSWT,R2	:PICKUP TRANSFER WAIT QUEUE
1035	045034	020137	040634			CMR	R1,DTUW	:TRANSFER UNDERWAY ON THIS DRIVE?
1036	045040	001404				BEQ	1\$:BR IF YES
1037	045042	000137	045270			JMP	STO9	:IF NOT DON'T BOTHER DRIVES
1038	045046	004737	046510			JSR	PC,GETREQ	:GET DPB ADDRESS
1039	045052	052762	101000	000016	1\$:	BIS	#BIT15:BIT09,16(R2)	:SET THE ERROR FLAGS
1040	045060	004737	045654			JSR	PC,SVRH70	:SAVE RH/RM REGISTERS
1044	045064	105061	040522			CLRB	DRVACT(R1)	:DRIVE IS IDLE
1045	045070	105061	040600			CLRB	ULDFLG(R1)	:CLEAR THE UNLOAD FLAG
1046	045074	005037	040572			CLR	TRNSWT	:CLEAR DPB ADDRESS
1047	045100	012737	177777	040634		MOV	#-1,DTUW	:CLEAR THE TRANSFER DRIVE #
1048	045106	000470				BR	STO9	:DON'T BOTHER OTHER DRIVES
1049								
1050	045110	116405	000016		STO2:	MOV	RMAS(R4),R5	:READ ATTENTION REG
1051	045114	136105	040636			BITB	ATABIT(R1),R5	:IS ATTENTION FOR THIS DRIVE UP ?
1052	045120	001007				BNE	STO3	:YES
1053	045122	105761	040552			TSTB	DPINT(R1)	:TRYING TO INITIALIZE THE DRIVE ?
1054	045126	001021				BNE	STO6	:BR IF YES - DRIVE NOT ONLINE
1055	045130	105761	040562			TSTB	DPRQS(R1)	:OUTSTANDING PORT REQUEST FOR THE DRIVE ?
1056	045134	001035				BNE	STO7	:BR IF YES - NO RESPONSE TO REQUEST
1057	045136	000454				BR	STO9	:OTHER WISE EXIT
1058								
1059	045140	105761	040552		STO3:	TSTB	DPINT(R1)	:INITIALIZING THE DRIVE ?
1060	045144	001003				BNE	1\$:BR IF INIT PENDING
1061	045146	105761	040562			TSTB	DPRQS(R1)	:PORT REQUEST PENDING ?
1062	045152	001446				BEQ	STO9	:BR IF NOT
1063	045154	012763	177777	040614	1\$:	MOV	#-1,TIMER(R3)	:STOP THE TIMER
1064	045162	000442				BR	STO9	:EXIT
1065								
1066	045164	004737	043056		STO5:	JSR	PC,C18	:GO HANDLE THE PARITY ERROR
1067	045170	000437				BR	STO9	
1068								
1069	045172	105061	040552		STO6:	CLRB	DPINT(R1)	:CLEAR THE INITIALIZE INDICATOR
1070	045176	105061	040532			CLRB	DRVSTA(R1)	:SET UNIT OFFLINE
1071	045202	012763	177777	040614		MOV	#-1,TIMER(R3)	:STOP THE TIMER
1072	045210	004737	046510			JSR	PC,GETREQ	:GET THE DPB ADDRESS
1073	045214	005702				TST	R2	:REQUEST IN QUEUE ?
1074	045216	001424				BEQ	STO9	:BR IF NOT
1075	045220	052762	140000	000016		BIS	#BIT15:BIT14,16(R2)	:INFORM THE USER DRIVE NOT AVAILABLE
1076	045226	000414				BR	STO8	:FINISH
1077								
1078	045230	012763	177777	040614	STO7:	MOV	#-1,TIMER(R3)	:STOP THE TIMER

```

1079 045236 105061 040562 CLR B DPRQS(R1) ;CLEAR PORT REQUEST INDICATOR
1080 045242 004737 046510 JSR PC.GETREQ ;GET DPB ADDRESS
1081 045246 005702 TST R2 ;QUEUE ENTRY FOR DRIVE ?
1082 045250 001407 BEQ ST09 ;BR IF NONE
1083 045252 012762 100004 000016 MOV #BIT15:BIT2,16(R2) ;INFORM USER OF PORT REQUEST ERROR
1084 045260 004737 046414 ST08: JSR PC.EMPTYQ ;CLEAR THE QUEUE FOR THE DRIVE
1085 045264 004737 045654 JSR PC.SVRH70 ;SAVE THE REGISTERS
1086 045270 012604 ST09: MOV (SP)+,R4 ;RESTORE R4
1087 045272 012603 MOV (SP)+,R3 ;RESTORE R3
1088 045274 012602 MOV (SP)+,R2 ;RESTORE R2
1089 045276 012601 MOV (SP)+,R1 ;RESTORE R1
1090 045300 000207 RTS PC ;RETURN
1091
1092 ;ROUTINE TO READ A RH/RM REGISTER
1093
1094 :CALL
1095 JSR RO,RD,RM ;GO READ A REGISTER
1096 INDEX ;REG. INDEX FROM BASE
1097 ERRADR ;ERROR ADDRESS--PROCESS ERROR STARTING
1098 ;AT THIS ADDRESS
1099 RETURN ;CONTENTS OF REG. IS ON THE STACK
1100
1101 045302 013737 040646 045450 RD,RM: MOV MCPEMX,RD,RM2 ;MAX. RETRYS ALLOWED
1102 045310 011646 MOV (SP)-,(SP) ;SAVE RO FOR RETURN
1103 045312 013737 040650 045326 MOV RMADR,RD,ADR ;FORM THE DESIRED ADDRESS
1104 045320 062037 045326 ADD (RO)+,RD,ADR ;USING THE BASE AND THE INDEX
1105 045324 013727 RD,RM1: MOV @(PC)+,(PC)+ ;READ THE DESIRED REGISTER OF THE RM DRIVE
1106 045326 000000 RD,ADR: .WORD 0 ;ADDRESS IS FORMED HERE
1107 045330 000000 RD,WRD: .WORD 0 ;REG. CONTENTS PUT HERE
1108 045332 013766 045330 000002 MOV RD,WRD,2(SP) ;RETURN IT TO THE USER
1109 045340 013746 040650 MOV RMADR,-(SP) ;PUT THE ADDRESS ON THE STACK
1110 045344 062716 000010 ADD #RMCS2,(SP) ;FORM THE ADDRESS OF RMCS2
1111 045350 032736 010000 BIT #BIT12,@(SP)+ ;CHECK THE 'NED' BIT
1112 045354 001037 BNE RD,RM3 ;BR IF DRIVE NON-EXISTENT
1113 045356 017746 173266 MOV @RMADR,-(SP) ;READ RMCS1
1114 045362 032716 020000 BIT #BIT13,(SP) ;DID MCPE SET?
1115 045366 001002 BNE 1$ ;BR IF YES
1116 045370 022620 CMP (SP)+,(RO)+ ;ADJUST FOR RETURN
1117 045372 000432 BR RD,RM4 ;EXIT
1118 045374 004037 046600 1$: JSR RO,ES.SAV ;SAVE THE ADDRESS IN '$ESCAPE'
1119 045400 104003 EMT 3 ;REPORT 'MCPE' ERROR
1120 045402 005737 040634 TST DTUW ;DATA TRANSFER UNDERWAY?
1121 045406 100405 BMI 2$ ;NO
1122 045410 032716 040000 BIT #BIT14,(SP) ;'TRE' = 1 ?
1123 045414 001402 BEQ 2$ ;NO
1124 045416 005726 TST (SP)+ ;YES--CLEAN OFF THE STACK AND
1125 045420 000415 BR RD,RM3 ;TAKE THE FATAL ERROR EXIT
1126 045422 052716 040000 2$: BIS #BIT14,(SP) ;CLEAR 'MCPE' BY SENDING A '1' TO 'TRE'
1127 045430 000316 SWAB (SP) ;POSITION BEFORE WRITING
1128 045436 005237 040650 045444 MOV RMADR,3$ ;FORM ADDRESS OF HIGH BYTE
1129 045442 112637 INC 3$
1130 045444 000000 MOV B (SP)+,@(PC)+ ;WRITE THE HIGH BYTE OF RMCS1
1131 045446 005327 3$: .WORD 0 ;ADDRESS STORAGE
1132 045450 000003 PD,RM2: DEC (PC)+ ;EXCEEDED MAX. RETRYS
1133 045452 002324 BGE RD,RM1 ;BR IF NO

```

```

1134 045454 011000 RD.RM3: MOV (R0),R0 ;FATAL ERROR EXIT
1135 045456 012616 MOV (SP)+,(SF)
1136 045460 000200 RD.RM4: RTS R0
1137
1138 ;ROUTINE TO WRITE A REGISTER
1139 :
1140 :CALL
1141 : MOV DATA,-(SP) ;DATA TO BE LOADED ON THE STACK
1142 : JSR R0,WRT.RM ;CALL THE ROUTINE TO LOAD(WRITE) THE REG.
1143 : INDEX ;INDEX OF THE REGISTER TO BE LOADED
1144 : ERRADR ;ADDRESS TO RETURN TO ON AN ERROR
1145 : RETURN ;ERROR FREE RETURN
1146
1147 045462 013737 040646 045640 WRT.RM: MOV MCPERM,WRT.R2 ;MAX RETRYS ALLOWED
1148 045470 016637 000002 045550 MOV 2(SP),WRT.WD ;SAVE THE WORD TO WRITE
1149 045476 012616 MOV (SP)+,(SP) ;ADJUST THE STACK
1150 045500 012037 045552 MOV (R0)+,WRT.AD ;GET INDEX OF REGISTER TO BE WRITTEN
1151 045504 001015 BNE 1$ ;BR IF NOT RMCS1
1152 045506 122737 000150 045550 CMPB #150,WRT.WD ;IS THE COMMAND FOR DATA TRANSFERS?
1153 045514 002411 BLT 1$ ;YES--DON'T GET THE OLD A16 & A17, & PSEL
1154 045516 004037 045302 JSR R0,RD.RM ;NO---COMBINE A16&A17, & PSEL WITH
1155 045522 000000 RMCS1 ;THE COMMAND BEFORE SENDING IT TO
1156 045524 045644 WRT.R3 ;THE RH/RM
1157 045526 000316 SWAB (SP)
1158 045530 042716 177770 BIC #^C7,(SP)
1159 045534 112637 045551 MOVB (SP)+,WRT.WD+1
1160 045540 063737 040650 045552 1$: ADD RMADR,WRT.AD ;FORM THE ADDRESS OF THE DISK REG.
1161 045546 012737 WRT.R1: MOV (PC)+,@(PC)+ ;LOAD THE DESIRED REG.
1162 045550 000000 WRT.WD: .WORD 0 ;WORD TO WRITE GOES HERE
1163 045552 000000 WRT.AD: .WORD 0 ;ADDRESS IS FORMED HERE
1164 045554 013746 040650 MOV RMADR,-(SP) ;PUT THE ADDRESS ON THE STACK
1165 045560 062716 000010 ADD #RMCS2,(SP) ;FORM THE ADDRESS OF RMCS2
1166 045564 032736 010000 BIT #BIT12,@(SP)+ ;CHECK THE 'NED' BIT
1167 045570 001025 BNE WRT.R3 ;BR IF DRIVE NON-EXISTENT
1168 045572 004037 045302 JSR R0,RD.RM ;CHECK FOR PARITY ERROR ON WRITE
1169 045576 000014 RMER1
1170 045600 045644 WRT.R3
1171 045602 032726 000010 BIT #BIT03,(SP)+
1172 045606 001420 WRT.R4: BEQ WRT.R4 ;BR IF 'PAR=0'
1173 045610 016037 177776 045622 MOV -2(R0),1$ ;PICKUP THE INDEX
1174 045616 004037 045302 JSR R0,RD.RM ;READ THE REG.
1175 045622 000000 1$: .WORD 0 ;REG. INDEX
1176 045624 045644 WRT.R3 ;RETURN TO THIS ADDRESS ON ERROR
1177 045626 004037 046600 JSR R0,ES.SAV ;SAVE THE ADDRESS IN '$ESCAPE'
1178 045632 104004 EMT 4 ;REPORT THE PARITY ON WRITE ERROR
1179 045636 005327 TST (SP)+ ;CLEAR OFF THE STACK
1180 045640 000003 WRT.R2: DEC (PC)+ ;DECREMENT THE ERROR COUNT
1181 045642 002341 BGE WRT.R1 ;RETRY COUNTER
1182 045644 011000 WRT.R3: MOV (R0),R0 ;TRY AGAIN IF NOT FINISHED
1183 045646 000401 BR WRT.R5 ;TAKE THE 'PARITY ON WRITE' ERROR EXIT
1184 045650 005720 WRT.R4: TST (R0)+ ;EXIT
1185 045652 000200 WRT.R5: RTS R0 ;ADJUST FOR ERROR FREE EXIT
1186
1187 ;ROUTINE TO SAVE THE RH/RM REGISTERS AS PER DPB+14
1188 :
1189 :CALL

```



```

1190      :      MOV      #DPBNUM,R2      ;DPB POINTER TO R2
1191      :      JSR      PC,SVRH70        ;SAVE THE DRIVES REG'S
1192
1193 045654 104412      SVRH70: SAVREG      ;SAVE R0 - R5
1194 045656 005702      TST      R2      ;QUEUE ENTRY FOR THE DRIVE ?
1195 045660 001442      BEQ      6$      ;BR IF NONE
1196 045662 013704 040650      MOV      RMADR,R4
1197 045666 111264 000010      MOVB    (R2),RMCS2(R4) ;SELECT DRIVE
1198 045672 016203 000014      MOV      14(R2),R3      ;GET THE ERROR TABLE POINTER
1199 045676 001433      BEQ      6$      ;EXIT IF NO ADDRESS
1200 045700 005037 045734      CLR      3$      ;COUNTER & POINTER
1201 045704 023727 045734 000022 1$:  CMP      3$,#RMDB      ;REACHED THE BUFFER REGISTER ?
1202 045712 001006      BNE      2$      ;BR IF NOT
1203 045714 032764 000200 000010      BIT      #BIT07,RMCS2(R4) ;'OR' SET ?
1204 045722 001002      BNE      2$      ;BR IF SET
1205 045724 005023      CLR      (R3)+      ;STORE RMDB AS ZEROES
1206 045726 000405      BR      4$      ;CONTINUE
1207 045730 004037 045302      2$:  JSR      R0,AD.RM      ;READ THE SELECTED REGISTER
1208 045734 000000      3$:  .WORD 0      ;REGISTER INDEX
1209 045736 045762      5$:  MOV      (SP)+,(R3)+      ;ERROR RETURN ADDRESS
1210 045740 012623      ;STORE THE REGISTER CONTENTS
1211 045742 023727 045734 000046 4$:  CMP      3$,#RMEC2      ;REACHED THE END ?
1212 045750 001406      BEQ      6$      ;BR IF YES
1213 045752 062737 000002 045734      ADD      #2,3$      ;INCREMENT THE REGISTER INDEX
1214 045760 000751      BR      1$      ;CONTINUE READING THE REGISTERS
1215 045762 004737 042756      5$:  JSR      PC,C17      ;PROCESS THE UNCORRECTABLE PARITY ERROR
1226 045766 104413      6$:  RESREG      ;RESTORE R0 - R5
1228 045770 000207      RTS      PC      ;RETURN
1229
1230      ;ROUTINE TO SET THE INTERRUPT WITHOUT GETTING A 'TRE'
1231      ;CALL
1232      :      MOV      #DRVNUM,R1      ;DRIVE NUMBER TO R1
1233      :      JSR      PC,SET.IE      ;SET 'IE'
1234      :      RETURN
1235
1236 045772 010446      SET.IE: MOV      R4,-(SP)      ;SAVE R4
1237 045774 013704 040650      MOV      RMADR,R4      ;PICKUP ADDRESS OF RMCS1
1238 046000 010164 000010      MOV      R1,RMCS2(R4) ;SELECT DRIVE
1239 046004 011446      MOV      (R4),-(SP)      ;READ RMCS1
1240 046006 052716 040000      BIS      #BIT14,(SP)      ;SET THE 'TRE' BIT OF THE WORD READ
1241 046012 000316      SWAB    (SP)      ;ADJUST FOR DATO
1242 046014 112714 000100      MOVB    #BIT06,(R4)      ;SET 'IE'
1243 046020 032764 010000 000010      BIT      #BIT12,RMCS2(R4) ;IS 'NED'=1?
1244 046026 001002      BNE      1$      ;YES--CLEAR 'TRE'
1245 046030 005726      TST      (SP)+      ;CLEAN OFF THE STACK
1246 046032 030402      BR      2$      ;
1247 046034 112664 000001      1$:  MOVB    (SP)+,1(R4)      ;CLEAR 'TRE'
1248 046040 012604      2$:  MOV      (SP)+,R4      ;RESTORE R4
1249 046042 000207      RTS      PC      ;RETURN TO CALLER
1250
1251      ;QUEUE COUNT
1252
1253 046044 000      QCNT:  .BYTE 0      ;DRIVE 0
1254 046045 000      .BYTE 0      ;DRIVE 1
1255 046046 000      .BYTE 0      ;DRIVE 2
1256 046047 000      .BYTE 0      ;DRIVE 3
1257 046050 000      .BYTE 0      ;DRIVE 4

```

```

046051    000                .BYTE 0                ;DRIVE 5
046052    000                .BYTE 0                ;DRIVE 6
046053    000                .BYTE 0                ;DRIVE 7

1257
1258      ;QUEUE INPUT POINTERS
1259
1260 046054 046136      QINPT: .WORD QDRV0            ;DRIVE 0
1263 046056 046156      .WORD QDRV1            ;DRIVE 1
      046060 046176      .WORD QDRV2            ;DRIVE 2
      046062 046216      .WORD QDRV3            ;DRIVE 3
      046064 046236      .WORD QDRV4            ;DRIVE 4
      046066 046256      .WORD QDRV5            ;DRIVE 5
      046070 046276      .WORD QDRV6            ;DRIVE 6
      046072 046316      .WORD QDRV7            ;DRIVE 7

1264
1265      ;QUEUE OUTPUT POINTERS
1266
1267 046074 046136      QOUTPT: .WORD QDRV0           ;DRIVE 0
1270 046076 046156      .WORD QDRV1           ;DRIVE 1
      046100 046176      .WORD QDRV2           ;DRIVE 2
      046102 046216      .WORD QDRV3           ;DRIVE 3
      046104 046236      .WORD QDRV4           ;DRIVE 4
      046106 046256      .WORD QDRV5           ;DRIVE 5
      046110 046276      .WORD QDRV6           ;DRIVE 6
      046112 046316      .WORD QDRV7           ;DRIVE 7

1271
1272 046114 046136      QSTART: .WORD QDRV0           ;DRIVE 0 START ADDRESS
1273 046116 046156      QSTOP: .WORD QDRV1          ;DRIVE 0 STOP ADDRESS & DRIVE 1 START ADDRESS
1274 046120 046176      .WORD QDRV2           ;STOP DRIVE 1--START DRIVE 2
1275 046122 046216      .WORD QDRV3           ;STOP DRIVE 2--START DRIVE 3
1276 046124 046236      .WORD QDRV4           ;STOP DRIVE 3--START DRIVE 4
1277 046126 046256      .WORD QDRV5           ;STOP DRIVE 4--START DRIVE 5
1278 046130 046276      .WORD QDRV6           ;STOP DRIVE 5--START DRIVE 6
1279 046132 046316      .WORD QDRV7           ;STOP DRIVE 6--START DRIVE 7
1280 046134 046336      .WORD QTERM          ;STOP DRIVE 7

1281
1282      ;DRIVE REQUEST QUEUES
1283
1286 046136      QDRV0: .BLKW 10
      046156      QDRV1: .BLKW 10
      046176      QDRV2: .BLKW 10
      046216      QDRV3: .BLKW 10
      046236      QDRV4: .BLKW 10
      046256      QDRV5: .BLKW 10
      046276      QDRV6: .BLKW 10
      046316      QDRV7: .BLKW 10
1287      QTERM=.

1288
1289      ;ROUTINE TO CLEAR ALL OF THE REQUEST QUEUES
1290      ;
1291      ;CALL
1292      ; JSR PC,CLRQUE
1293
1294 046336 104412      CLRQUE: SAVREG                ;SAVE R0 - R5
1295 046340 012702      MOV #QCNT,R2                ;ZERO THE QUEUE COUNTS
1296 046344 005022      CLR (R2)+                ;DRIVES 0 & 1
1297 046346 005022      CLR (R2)+                ;DRIVES 2 & 3
  
```

```

1298 046350 005022 CLR (R2)+ ;DRIVES 4 & 5
1299 046352 005022 CLR (R2)+ ;DRIVES 6 & 7
1300 046354 012703 000010 MOV #8,R3 ;MOVE THE STARTING
1301 046360 012701 046114 MOV #QSTART,R1 ;ADDRESS OF THE QUEUE INTO
1302 046364 012122 1$: MOV (R1)+,(R2)+ ;THE QUEUE INPUT POINTER
1303 046366 005303 DEC R3
1304 046370 001375 BNE 1$
1305 046372 012703 000010 MOV #8,R3 ;MOVE THE STARTING ADDRESS
1306 046376 012701 046114 MOV #QSTART,R1 ;OF THE QUEUE INTO THE
1307 046402 012122 2$: MOV (R1)+,(R2)+ ;QUEUE OUTPUT POINTER
1308 046404 005303 DEC R3
1309 046406 001375 BNE 2$
1310 046410 104413 RESREG ;RESTORE R0 - R5
1311 046412 000207 RTS PC
1312
1313 ;EMPTY THE QUEUE SPECIFIED BY R1
1314 :
1315 :CALL
1316 : MOV DRVNUM,R1 ;DRIVE NUMBER TO R1
1317 : JSR PC,EMPTYQ
1318
1319 046414 105061 046044 EMPTYQ: CLRB QCNT(R1) ;CLEAR NUMBER OF ITEMS IN QUEUE
1320 046420 006301 ASL R1
1321 046422 016161 046054 046074 MOV QINPT(R1),QOUTPT(R1) ;SET OUTPUT QUEUE POINTER-INPUT POINTER
1322 046430 006201 ASR R1
1323 046432 000207 RTS PC
1324
1325 ;ROUTINE TO PUT A REQUEST IN QUEUE
1326 :
1327 :CALL
1328 : MOV #DRVNUM,R1 ;DRIVE NUMBER
1329 : MOV #DPB,R2 ;ADDRESS OF PARAMETER BLOCK
1330 : JSR R0,DRVQUE ;GO PUT REQUEST IN QUEUE
1331 : RETURN1 ;RETURN HERE IF QUEUE IS FULL
1332 : RETURN2 ;RETURN HERE IF REQUEST IS IN QUEUE
1333
1334 046434 122761 000010 046044 DRVQUE: CMPB #10,QCNT(R1) ;IS QUEUE FULL?
1335 046442 001421 BEQ 2$ ;BR IF YES-TAKE RETURN1
1336 046444 105261 046044 INCB QCNT(R1) ;INCREMENT QUEUE COUNT
1337 046450 006301 ASL R1
1338 046452 010271 046054 MOV R2,@QINPT(R1) ;PUT THIS REQUEST IN QUEUE
1339 046456 062761 000002 046054 ADD #2,QINPT(R1) ;UPDATE THE QUEUE POINTER
1340 046464 026161 046054 046116 CMP QINPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER
1341 046472 001003 BNE 1$ ;BR IF NO
1342 046474 016161 046114 046054 MOV QSTART(R1),QINPT(R1) ;YES--RESET POINTER
1343 046502 006201 1$: ASR R1
1344 046504 005720 TST (R0)+ ;TAKE RETURN 2
1345 046506 000200 2$: RTS R0 ;RETURN TO USER
1346
1347 ;ROUTINE TO GET THE 'DPB' ADDRESS OF NEXT REQUEST IN QUEUE
1348 :
1349 :CALL
1350 : MOV #DRVNUM,R1 ;DRIVE NUMBER TO R1
1351 : JSR PC,GETREQ ;GO GET THE REQUEST
1352 : RETURN ;R2='DPB' ADDRESS OF THE REQUEST
1353 : ;R2=0 IF NO REQUEST IN QUEUE
1354 :

```

```

1355 046510 005002          GETREQ: CLR      R2
1356 046512 105761 046044  TSTB    QCNT(R1)      ;IS THERE ANY REQUEST IN QUEUE?
1357 046516 001404          BEQ     2$           ;NO
1358 046520 006301          1$:    ASL     R1
1359 046522 017102 046074  MOV     @QOUTPT(R1),R2 ;PICKUP 'DPB' POINTER FOR THIS DRIVE
1360 046526 006201          ASR     R1
1361 046530 000207          2$:    RTS     PC           ;RETURN TO USER
1362
1363          ;ROUTINE TO 'POP' THE REQUEST FROM QUEUE
1364
1365          ;CALL
1366          MOV     #DRVNUM,R1      ;DRIVE NUMBER TO R1
1367          JSR     PC,POPQUE      ;CALL TO REMOVE REQUEST
1368          RETURN                ;R2=ADDRESS OF DPB REMOVED
1369
1370 046532 105361 046044  POPQUE: DECB   QCNT(R1)      ;DECREMENT QUEUE COUNT
1371 046536 006301          ASL     R1
1372 046540 017102 046074  MOV     @QOUTPT(R1),R2      ;GET THE 'DPB' POINTER
1373 046544 005071 046074  CLR     @QOUTPT(R1)        ;REMOVE DPB ADDRESS FROM THE QUEUE
1374 046550 062761 0C0002 046074  ADD     #2,QOUTPT(R1)      ;UPDATE THE QUEUE POINTER
1375 046556 026161 046074 046116  CMP     QOUTPT(R1),QSTOP(R1) ;TIME TO RESET THE POINTER?
1376 046564 001003          BNE     1$           ;NO--BR TO EXIT
1377 046566 016161 046114 046074  MOV     QSTART(R1),QOUTPT(R1) ;YES--RESET THE POINTER
1378 046574 006201          1$:    ASR     R1
1379 046576 000207          RTS     PC           ;RETURN TO USER
1380
1382          ;ROUTINE TO SAVE THE CONTENTS OF '$ESCAPE' WHEN THE DRIVER
1383          ;REPORTS AN ERROR DIRECTLY.
1384
1385          ;CALL
1386          JSR     RO,ES.SAV      ;: THE ERROR CALL
1387          ERROR  N              ;: THE RETURN IS PAST THE ERROR CALL
1388          RETURN
1389
1390 046600 012037 046614  ES.SAV: MOV     (RO)+,1$          ;GET THE ERROR CALL
1391 046604 013746 001222  MOV     $ESCAPE,-(SP)        ;SAVE THE ADDRESS IN '$ESCAPE'
1392 046610 005037 001222  CLR     $ESCAPE              ;CLEAR THE ESCAPE RETURN
1393 046614 000000          1$:    .WORD 0                ;THE ERROR CALL IS MOVED HERE
1394 046616 012637 001222  MOV     (SP)+,$ESCAPE        ;RESTORE THE ESCAPE ADDRESS
1395 046622 000200          RTS     RO                 ;RETURN
  
```

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50

.SBTTL GETADR - GET BUS ADDRESS AND VECTOR ADDRESS

; THIS ROUTINE IS USED TO ENSURE THE BUS ADDRESS
 ; OF THE RH/RM IS SETUP TO READ THE PROPER VALUE.
 ; IT WILL ALSO READ THE ADDRESS FROM THE TTY IF
 ; REQUIRED.
 ; NOTE: THIS ROUTINE DESTROYS R0-R4
 ; CALL

; JSR PC,GETADR
 ; RETURN

```

GETADR: TST     BUSADR      ;INPUT FROM TTY REQUESTED?
        BEQ     5$         ;NO--BRANCH
        CLR     BUSADR     ;YES--CLEAR THE REQUEST FLAG
1$:     MOV     #RH.ADR,R0 ;FIRST ADDRESS
        MOV     #MRMCS1,R3 ;'RMCS1='
        MOV     (R0),R4    ;PRESENT RMCS1 ADDRESS
        JSR    R0,GETNUM  ;GET NEW RMCS1
        BR     2$         ;COMMA
        BR     1$         ;PERIOD
        BR     4$         ;DOUBLE PERIOD
2$:     MOV     R4,(R0)+   ;SAVE NEW RMCS1
        MOV     #MRMVEC,R3 ;'RMVEC='
        MOV     (R0),R4    ;PRESENT RH/RM VECTOR ADDRESS
        JSR    R0,GETNUM  ;GET NEW RMVEC
        BR     3$         ;COMMA
        BR     1$         ;PERIOD
        BR     4$         ;DOUBLE PERIOD
3$:     MOV     R4,(R0)+   ;SAVE NEW RMVEC
4$:     MOV     R4,(R0)    ;SAVE INPUT
5$:     MOV     ERRVEC,R1  ;SAVE THE ERROR VECTOR
        MOV     #6$,ERRVEC ;SETUP FOR TRAP
        TST    @RH.ADR    ;CHECK FOR RH/RM
        MOV     R1,ERRVEC ;RESTORE ERROR VECTOR
        MOV     #RH.ADR,R0 ;FIRST ADDRESS OF NEW PARAMETERS
        MOV     #RMADR,R1 ;FIRST ADDRESS OF WHERE TO PUT THEM
        MOV     (R0)+,(R1)+ ;BUS ADDRESS
        MOV     (R0)+,(R1)+ ;VECTOR ADDRESS
        RTS    PC        ;RETURN
6$:     MOV     R1,ERRVEC  ;RESTORE ERROR VECTOR
        CMP    (SP)+,(SP)+ ;CLEAN OFF THE STACK
        EMT    10
        TST    @#42
        BEQ    1$         ;IS THERE A MONITOR?
        CLR    DRVSEL     ;NO--GO ASK FOR ADDRESS
        JMP    $EOP       ;FUDGE NO DRIVES SELECTED
                          ;RETURN TO $EOP
  
```

115 MRMCS1: .ASCIZ <CRLF>/RMCS1=/
 115 MRMVEC: .ASCIZ <CRLF>/RMVEC-/
 000004

200 122
 200 122

```

1
2
3 047016 000
4 047017 000
5 047020 000
6 047021 000
7 047022 000000
8 047024 054522
9
10 047026 000
11
12 047027 000
13
14 047030 000000
15 047032 047140
16
17
18
19
20
21 047034 000000
22
23
24
25
26
27 047036 000
28 047037 000
29 047040 000
30 047041 000
31 047042 177776
32 047044 054522
33
34 047046 000
35
36 047047 000
37
38 047050 000000
39 047052 047140
40
41
42
43
44
45 047054 000000
46
47
48
49
50
51 047056 000
52 047057 000
53 047060 000
54 047061 000
55 047062 177776
56 047064 054522
57

.SBTTL DPB (DATA PARAMETER BLOCKS)

DPB.A: .BYTE 0 ;(0) DRIVE NUMBER
        .BYTE 0 ;(1) OFFSET VALUE OR FMT16, ECI, AND HCI
        .BYTE 0 ;(2) COMMAND
        .BYTE 0 ;(3) PSEL AND A17 AND A16
        .WORD 0 ;(4) WORD COUNT (MUST BE NEG.)
        .WORD BUFFER ;(6) BUFFER ADDRESS OR
        ;REGISTER TABLE POINTER
        .BYTE 0 ;(10) SECTOR ADDRESS OR
        ;FIRST REG. INDEX
        .BYTE 0 ;(11) TRACK ADDRESS OR
        ;LAST REG. INDEX
        .WORD 0 ;(12) CYLINDER ADDRESS
        .WORD RM.REG ;(14) ERROR TABLE POINTER
        ;POINTS TO THE FIRST OF TWENTY
        ;LOCATIONS OF WHERE THE DRIVER
        ;IS TO STORE THE RH/RM
        ;REGISTERS ON AN ERROR. IF LEFT
        ;ZERO REGISTERS ARE NOT SAVED.
        .WORD 0 ;(16) STATUS/ERROR INDICATOR
        ;BIT15=1=>ERROR OCCURRED
        ;BIT07=1=>DONE
        ;BIT14-BIT09 AND BIT06-BIT03
        ;INDICATE TYPE OF ERROR

DPB.B: .BYTE 0 ;(0) DRIVE NUMBER
        .BYTE 0 ;(1) OFFSET VALUE OR FMT16, ECI, AND HCI
        .BYTE 0 ;(2) COMMAND
        .BYTE 0 ;(3) PSEL AND A17 AND A16
        .WORD -2 ;(4) WORD COUNT (MUST BE NEG.)
        .WORD BUFFER ;(6) BUFFER ADDRESS OR
        ;REGISTER TABLE POINTER
        .BYTE 0 ;(10) SECTOR ADDRESS OR
        ;FIRST REG. INDEX
        .BYTE 0 ;(11) TRACK ADDRESS OR
        ;LAST REG. INDEX
        .WORD 0 ;(12) CYLINDER ADDRESS
        .WORD RM.REG ;(14) ERROR TABLE POINTER
        ;POINTS TO THE FIRST OF TWENTY
        ;LOCATIONS OF WHERE THE DRIVER
        ;IS TO STORE THE RH/RM
        ;REGISTERS ON AN ERROR. IF LEFT
        ;ZERO REGISTERS ARE NOT SAVED.
        .WORD 0 ;(16) STATUS/ERROR INDICATOR
        ;BIT15=1=>ERROR OCCURRED
        ;BIT07=1=>DONE
        ;BIT14-BIT09 AND BIT06-BIT03
        ;INDICATE TYPE OF ERROR

DPB.C: .BYTE 0 ;(0) DRIVE NUMBER
        .BYTE 0 ;(1) OFFSET VALUE OR FMT16, ECI, AND HCI
        .BYTE 0 ;(2) COMMAND
        .BYTE 0 ;(3) PSEL AND A17 AND A16
        .WORD -2 ;(4) WORD COUNT (MUST BE NEG.)
        .WORD BUFFER ;(6) BUFFER ADDRESS OR
        ;REGISTER TABLE POINTER

```

58	047066	000		.BYTE	0	;(10) SECTOR ADDRESS OR
59						;FIRST REG. INDEX
60	047067	000		.BYTE	0	;(11) TRACK ADDRESS OR
61						;LAST REG. INDEX
62	047070	000000		.WORD	0	;(12) CYLINDER ADDRESS
63	047072	047140		.WORD	RM.REG	;(14) ERROR TABLE POINTER
64						;POINTS TO THE FIRST OF TWENTY
65						;LOCATIONS OF WHERE THE DRIVER
66						;IS TO STORE THE RH/RM
67						;REGISTERS ON AN ERROR. IF LEFT
68						;ZERO REGISTERS ARE NOT SAVED.
69	047074	000000		.WORD	0	;(16) STATUS/ERROR INDICATOR
70						;BIT15=1=>ERROR OCCURRED
71						;BIT07=1=>DONE
72						;BIT14-BIT09 AND BIT06-BIT03
73						;INDICATE TYPE OF ERROR
74						
75	047076	000	DTADPB:	.BYTE	0	;(0) DRIVE NUMBER
76	047077	000		.BYTE	0	;(1) OFFSET VALUE OR FMT16, ECI, AND HCI
77	047100	000		.BYTE	0	;(2) COMMAND
78	047101	000		.BYTE	0	;(3) PSEL AND A17 AND A16
79	047102	000000		.WORD	0	;(4) WORD COUNT (MUST BE NEG.)
80	047104	054522		.WORD	BUFFER	;(6) BUFFER ADDRESS OR
81						;REGISTER TABLE POINTER
82	047106	000		.BYTE	0	;(10) SECTOR ADDRESS OR
83						;FIRST REG. INDEX
84	047107	000		.BYTE	0	;(11) TRACK ADDRESS OR
85						;LAST REG. INDEX
86	047110	000000		.WORD	0	;(12) CYLINDER ADDRESS
87	047112	047140		.WORD	RM.REG	;(14) ERROR TABLE POINTER
88						;POINTS TO THE FIRST OF TWENTY
89						;LOCATIONS OF WHERE THE DRIVER
90						;IS TO STORE THE RH/RM
91						;REGISTERS ON AN ERROR. IF LEFT
92						;ZERO REGISTERS ARE NOT SAVED.
93	047114	000000		.WORD	0	;(16) STATUS/ERROR INDICATOR
94						;BIT15=1=>ERROR OCCURRED
95						;BIT07=1=>DONE
96						;BIT14-BIT09 AND BIT06-BIT03
97						;INDICATE TYPE OF ERROR
98						
99	047116	000	DPB.R:	.BYTE	0	;(0) DRIVE NUMBER
100	047117	000		.BYTE	0	;(1) OFFSET VALUE OR FMT16, ECI, AND HCI
101	047120	107		.BYTE	RECAL	;(2) COMMAND
102	047121	000		.BYTE	0	;(3) PSEL AND A17 AND A16
103	047122	000000		.WORD	0	;(4) WORD COUNT (MUST BE NEG.)
104	047124	054522		.WORD	BUFFER	;(6) BUFFER ADDRESS OR
105						;REGISTER TABLE POINTER
106	047126	000		.BYTE	0	;(10) SECTOR ADDRESS OR
107						;FIRST REG. INDEX
108	047127	000		.BYTE	0	;(11) TRACK ADDRESS OR
109						;LAST REG. INDEX
110	047130	000000		.WORD	0	;(12) CYLINDER ADDRESS
111	047132	047140		.WORD	RM.REG	;(14) ERROR TABLE POINTER
112						;POINTS TO THE FIRST OF TWENTY
113						;LOCATIONS OF WHERE THE DRIVER
114						;IS TO STORE THE RH/RM

```

115                                     ;REGISTERS ON AN ERROR. IF LEFT
116                                     ;ZERO REGISTERS ARE NOT SAVED.
117 047134 000000                       .WORD 0                               ;(16) STATUS/ERROR INDICATOR
118                                     ;BIT15=1=>ERROR OCCURRED
119                                     ;BIT07=1=>DONE
120                                     ;BIT14-BIT09 AND BIT06-BIT03
121                                     ;INDICATE TYPE OF ERROR
122 047136 000000                       .WORD 0                               ;SKIP SECTOR ENABLE INDICATOR (ENABLED =1)
123
124                                     ;SAVE RH/RM REGISTERS HERE ON ERROR
125
126 047140 000000                       RM.REG: .WORD 0                               ;RMCS1 (776700) CONTROL & STATUS #1
127 047142 000000                       .WORD 0                               ;RMWC (776702) WORD COUNT
128 047144 000000                       .WORD 0                               ;RMBB (776704) BUS ADDRESS
129 047146 000000                       .WORD 0                               ;RMDA (776706) DESIRED SECTOR/TRACK
130 047150 000000                       .WORD 0                               ;RMCS2 (776710) CONTROL & STATUS #2
131 047152 000000                       .WORD 0                               ;RMDS (776712) DISK STATUS
132 047154 000000                       .WORD 0                               ;RMER1 (776714) ERROR REG. #1
133 047156 000000                       .WORD 0                               ;RMAS (776716) ATTENTION SUMMARY
134 047160 000000                       .WORD 0                               ;RMLA (776720) LOOK AHEAD
135 047162 000000                       .WORD 0                               ;RMDB (776722) DATA BUFFER
136 047164 000000                       .WORD 0                               ;RMMR1 (776724) MAINTAINABILITY
137 047166 000000                       .WORD 0                               ;RMDT (776726) DRIVE TYPE
138 047170 000000                       .WORD 0                               ;RMSN (776730) SERIAL NUMBER
139 047172 000000                       .WORD 0                               ;RMOF (776732) OFFSET
140 047174 000000                       .WORD 0                               ;RMDC (776734) DESIRED CYLINDER
141 047176 000000                       .WORD 0                               ;RMHR (776736) CURRENT CYLINDER
142 047200 000000                       .WORD 0                               ;RMMR2 (776740) ERROR REG #2
143 047202 000000                       .WORD 0                               ;RMER2 (776742) ERROR REG #3
144 047204 000000                       .WORD 0                               ;RMEC1 (776744) ECC POSITION
145 047206 000000                       .WORD 0                               ;RMEC2 (776746) ECC PATTERN
146                                     .EVEN

```



```

1
2
3 .SBTTL ASCIZ MESSAGES
3 047210 122 000 MSG.R: .ASCIZ /R/
4 047212 106 103 000 MSG.FC: .ASCIZ /FC/
5 047215 114 103 000 MSG.LC: .ASCIZ /LC/
6 047220 111 103 000 MSG.IC: .ASCIZ /IC/
7 047223 106 124 000 MSG.FT: .ASCIZ /FT/
8 047226 114 124 000 MSG.LT: .ASCIZ /LT/
9 047231 111 124 000 MSG.IT: .ASCIZ /IT/
10 047234 106 124 047 MES.FT: .ASCIZ /F'/
11 047240 114 124 047 MES.LT: .ASCIZ /LT'/
12 047244 111 124 047 MES.IT: .ASCIZ /IT'/
13 047250 106 123 000 MSG.FS: .ASCIZ /FS/
14 047253 114 123 000 MSG.LS: .ASCIZ /LS/
15 047256 120 101 124 MSG.PAT: .ASCIZ /PAT/
16 047262 075 000 MSG.EQ: .ASCIZ /=/
17 047264 200 103 117 MSG.CS: .ASCIZ <CRLF>/CONTROL SWITCHES=/
18
19 047307 040 057 040 SLASH: .ASCIZ @ / @
20 047313 200 125 116 UNSTAT: .ASCIZ <CRLF>/UNIT STATUS:/
21 047331 040 117 106 UNTOFF: .ASCIZ / OFFLINE/
22 047342 040 117 116 UNTON: .ASCIZ / ONLINE/
23 047352 040 116 117 NOTPRS: .ASCIZ / NOT PRESENT/
24 047367 040 125 116 NOTSAF: .ASCIZ / UNSAFE/
25 047377 040 116 117 NOTRM: .ASCIZ @ NOT AN RM05/3/2@
26 047420 040 111 123 LODEV: .ASCIZ / IS LOAD DEVICE/
27 047440 122 115 060 $RM02: .ASCIZ /RM02/
28 047445 122 115 060 $RM03: .ASCIZ /RM03/
29 047452 122 115 060 $RM05: .ASCIZ /RM05/
30 047457 200 104 122 DRIVES: .ASCIZ <CRLF>/DRIVE(S) TO BE TESTED. /
31 047510 116 117 116 NONE: .ASCIZ /NONE/
32 047515 054 040 000 COMMA: .ASCIZ /, /
33 047520 200 116 117 NOCLOK: .ASCIZ <CRLF>/NO KW11-P CLOCK, TIMING TESTS WILL NOT BE PERFORMED/
34 047605 115 102 101 SERIAL: .ASCIZ @MBA S/N: @
35 047617 200 124 105 MSGTST: .ASCIZ <CRLF>/TEST/
36 047625 200 104 122 MSDRIV: .ASCIZ <CRLF>/DRIVE/
37 047634 040 104 122 DROP: .ASCIZ / DROPPED/
38 047645 105 130 103 EXCEED: .ASCIZ /EXCEEDED MAXIMUM ERROR LIMIT/<CRLF>
39 047703 200 116 117 NODRVS: .ASCIZ <CRLF>/NO DRIVES TO TEST/<CRLF>
40 047727 200 116 117 NOTEST: .ASCIZ <CRLF>/NO TESTS SPECIFIED/<CRLF>
41
42 047754 200 012 122 ROTATE: .ASCIZ <CRLF><LF>/ROTATIONAL SPEED TIMES/
43 050005 200 012 117 ONECYL: .ASCIZ <CRLF><LF>/ONE CYLINDER SEEK TIMES/<CRLF>/ * FORWARD/
44 050052 200 012 101 AVERAGE: .ASCIZ <CRLF><LF>/AVERAGE SEEK TIMES/<CRLF>/ * FORWARD/
45 050112 200 012 115 MXSEEK: .ASCIZ <CRLF><LF>/MAXIMUM SEEK TIMES/
46 050136 200 040 052 FWD: .ASCIZ <CRLF>/ * FORWARD/
47 050152 200 040 052 REV: .ASCIZ <CRLF>/ * REVERSE/
48
49 050166 200 115 111 MSGMIN: .ASCIZ <CRLF>/MIN=/
50 050174 200 115 101 MSGMAX: .ASCIZ <CRLF>/MAX=/
51 050202 200 101 126 MSGAVG: .ASCIZ <CRLF>/AVG=/
52 050210 060 040 125 MSGOUS: .ASCIZ /0 US/
53 050215 040 102 105 MBELOW: .ASCIZ / BELOW THE MINIMUM OF /
54 050244 040 101 102 MABOVE: .ASCIZ / ABOVE THE MAXIMUM OF /
55 050273 040 123 105 MSGSEA: .ASCIZ / SEARCHES TIMED/
56 050313 040 123 105 MSGNUM: .ASCIZ / SEEKS TIMED/
57 050330 040 116 117 MSGNON: .ASCIZ / NOT TIMED/

```

ASCIZ MESSAGES

58	050343	040			BLNKS4:	.ASCII	//
59	050344	040			BLNKS3:	.ASCII	//
60	050345	040			BLNKS2:	.ASCII	//
61	050346	040	000		BLNKS1:	.ASCIZ	//
62	050350	101	114	114	MSG7XA:	.ASCIZ	@ALLOWABLE ROTATIONAL SPEED LIMITS FOR RM05/3@
63	050425	101	114	114	MSG7XB:	.ASCIZ	/ALLOWABLE ROTATIONAL SPEED LIMITS FOR RM02/
64	050500	101	114	114	MSG10X:	.ASCIZ	/ALLOWABLE ONE CYLINDER SEEK LIMIT/
65	050542	101	114	114	MSG11X:	.ASCIZ	/ALLOWABLE AVERAGE SEEK TIME LIMIT/
66	050604	101	114	114	MSG12X:	.ASCIZ	/ALLOWABLE MAXIMUM (FORWARD) SEEK TIME LIMIT/

				.SBTTL ERROR HEADER (EM) MESSAGES	
1					
2					
3	050660	122	110	040	EM1: .ASCIZ /RH CONTROLLER INTERRUPT OCCURRED (RMAS 0)/
4	050732	125	116	105	EM2: .ASCIZ /UNEXPECTED ATTENTION OCCURRED/
5	050770	115	101	123	EM3: .ASCIZ /MASSBUS PARITY ERROR(MCPE=1)/
6	051025	115	101	123	EM4: .ASCIZ /MASSBUS PARITY ERROR(PAR=1)/
7	051061	101	104	104	EM5: .ASCIZ /ADDRESS PLUG CHANGE BIT SET/
8	051115	122	110	040	EM10: .ASCIZ /RH CONTROLLER FAILED TO RESPOND TO ADDRESSING/
9	051173	104	122	111	EM11: .ASCIZ /DRIVE SELECTED IS NOT ONLINE/
10	051230	111	115	120	EM12: .ASCIZ /IMPROPER HEADER DATA/
11	051255	104	101	124	EM13: .ASCIZ /DATA COMPARE FAILURE/
12	051302	104	111	123	EM17: .ASCIZ /DISK ERROR IN TIMING TEST/
13	051334	103	114	117	EM20: .ASCIZ /CLOCK (KW11-P) OVERFLOW IN TIMING TEST/
14	051403	104	111	123	EM23: .ASCIZ /DISK ERROR DURING SEEK/
15	051432	123	105	105	EM24: .ASCIZ /SEEK NOT COMPLETE WITHIN 120 MS/
16	051472	122	110	057	EM41: .ASCIZ @RH/RM ERROR@
17	051506	106	101	124	EM46: .ASCIZ /FATAL WRITE CHECK ERROR/

STATUS/ERROR INDICATOR MESSAGES		.SBTTL STATUS/ERROR INDICATOR MESSAGES			
3	051536	117	106	106	MSG014: .ASCIZ /OFFLINE OR UNSAFE DRIVE REQUESTED/
4	051600	125	116	114	MSG013: .ASCIZ /UNLOADED DRIVE REQUESTED/
5	051631	120	105	122	MSG012: .ASCIZ /PERSISTENT UNSAFE/
6	051653	120	101	122	MSG011: .ASCIZ /PARITY ERROR OCCURRED/
7	051701	106	101	124	MSG010: .ASCIZ /FATAL PARITY ERROR/
8	051724	123	117	106	MSG009: .ASCIZ /SOFTWARE TIMEOUT ON THIS DRIVE/
9	051763	125	117	106	MSG008: .ASCIZ /SOFTWARE TIMEOUT ON ANOTHER DRIVE/
10	052025	105	122	122	MSG006: .ASCIZ 'ERROR OCCURRED DURING I/O OPERATION'
11	052071	105	122	122	MSG005: .ASCIZ 'ERROR OCCURRED DURING NON-I/O OPERATION'
12	052141	125	116	123	MSG004: .ASCIZ /UNSAFE OCCURRED/
13	052161	101	125	124	MSG003: .ASCIZ /AUTOMATIC RECALIBRATE SEQUENCE OCCURRED/
14	052231	104	122	111	MSG002: .ASCIZ /DRIVE HAS NOT RESPONDED TO PORT REQUEST/
15	052301	104	122	111	MSG001: .ASCIZ /DRIVE HAS BECOME NON-EXISTENT/

```

1
2
3 .SBTTL DATA HEADER (DT) MESSAGES
3 052337 105 122 122 DH1: .ASCIZ /ERR PC RMAS/
4 052354 105 122 122 DH2: .ASCIZ /ERR PC DRIVE RMAS RMDS RMER1 RMMR2 RMER2/
5 052441 124 105 123 DH3: .ASCIZ /TEST ERR PC ADDRESS DATA/
6 052476 124 105 123 DH4: .ASCIZ /TEST ERR PC ADDRESS GDDATA BDDATA/
7 052545 122 115 103 DH10: .ASCIZ /RMCS1 ERR PC/
8 052564 104 122 111 DH11: .ASCIZ /DRIVE ERR PC/
9 052603 124 105 123 DH12: .ASCIZ /TEST ERR PC TST PC DRIVE CYLNDR TRACK SECTOR/
10 052672 107 104 103 DH12A: .ASCIZ /GDCYL GDTRK GDSCTR BDCYL BDTRK BDSCTR/
11 052751 107 104 104 DH13A: .ASCIZ /GDDAT BDDAT WRDCNT GDADR BDADR/
12 053017 124 105 123 DH17: .ASCIZ /TEST ERR PC DRIVE RMCS1 RMDS RMER1 RMMR2 RMER2/
13 053114 124 105 123 DH21: .ASCIZ /TEST ERR PC TST PC DRIVE CYLNDR TRACK/
14 053172 107 104 104 DH21A: .ASCIZ /GDDAT BDDAT WRDCNT SECTOR/
15 053231 124 105 123 DH23: .ASCIZ /TEST ERR PC DRIVE CYLNDR RMCS1 RMCS2 RMDS/
16 053316 122 115 105 DH23A: .ASCIZ /RMER1 RMMR2 RMER2 RMDC RMHR/
17 053363 124 105 123 DH41: .ASCIZ /TEST ERR PC TST PC DRIVE/
18 053421 124 105 123 DH42: .ASCIZ /TEST ERR PC TST PC DRIVE RMCS1 RMCS2 RMDS/
19 053506 122 115 105 DH43A: .ASCIZ /RMER1 RMMR2 RMER2/
20 053534 122 115 103 DH44A: .ASCIZ /RMCS1 RMCS2 RMDS RMHR RMDC RMDA/
21 053610 122 115 105 DH44B: .ASCIZ /RMER1 RMMR2 RMER2/
22 053636 122 115 105 DH45A: .ASCIZ /RMER1 RMMR2 RMER2 RMWC RMBA RMDB/
23 .EVEN
    
```

				.SBTTL DATA TABLE (DT)		
1						
2						
3	053714	001132	001204	DT1:	.WORD	\$ERRPC,\$REG3
4	053720	001132	001200	001204	DT2:	.WORD \$ERRPC,\$REG1,\$REG3, RMERRS, RMERRS+2, RMERRS+6, RMERRS+4
5	053736	001212	001132	045326	DT3:	.WORD \$TMP0,\$ERRPC, RD.ADR, RD.WRD
6	053746	001212	001132	045552	DT4:	.WORD \$TMP0,\$ERRPC, WRT.ADR, WRT.WD, RD.WRD
7	053760	001212	001132	001200	DT5:	.WORD \$TMP0,\$ERRPC,\$REG1,\$REG5, RMERRS, RMERRS+2, RMERRS+6, RMERRS+4
8	054000	001502	001132	DT10:	.WORD	RH.ADR,\$ERRPC
9	054004	001202	001132	DT11:	.WORD	\$REG2,\$ERRPC
10	054010	001212	001132	001176	DT12:	.WORD \$TMP0,\$ERRPC,\$REG0,CHKDRV,CYL.DS,TRK.DS,SEC.DS
11	054026	001366	001372	001370	DT12A:	.WORD CYL.DS,TRK.DS,SEC.DS,CYL.RD,TRK.RD,SEC.RD
12	054042	001212	001132	001176	DT13:	.WORD \$TMP0,\$ERRPC,\$REG0,CHKDRV,CYL.DS,TRK.DS,SEC.DS
13	054060	001140	001142	001206	DT13A:	.WORD \$GDDAT,\$BDDAT,\$REG4,\$GDADR,\$BDADR
14	054072	001212	001132	001352	DT17:	.WORD \$TMP0,\$ERRPC,CHKDRV, RM.REG, RM.REG+12, RM.REG+14, RM.REG+40, RM.REG+42
15	054112	001212	001132	001176	DT21:	.WORD \$TMP0,\$ERRPC,\$REG0,CHKDRV,CYL.DS,TRK.DS
16	054126	001200	001142	001206	DT21A:	.WORD \$REG1,\$BDDAT,\$REG4,\$REG1
17	054136	001212	001132	001352	DT23:	.WORD \$TMP0,\$ERRPC,CHKDRV,CYL.DS, RM.REG, RM.REG+10, RM.REG+12
18	054154	047154	047200	047202	DT23A:	.WORD RM.REG+14, RM.REG+40, RM.REG+42, RM.REG+34, RM.REG+36
19	054166	001212	001132	001176	DT41:	.WORD \$TMP0,\$ERRPC,\$REG0,CHKDRV
20	054176	001212	001132	001176	DT42:	.WORD \$TMP0,\$ERRPC,\$REG0,CHKDRV, RM.REG, RM.REG+10, RM.REG+12
21	054214	001212	001132	001176	DT43:	.WORD \$TMP0,\$ERRPC,\$REG0,CHKDRV, RM.REG, RM.REG+10, RM.REG+12
22	054232	047154	047200	047202	DT43A:	.WORD RM.REG+14, RM.REG+40, RM.REG+42
23	054240	001212	001132	001176	DT44:	.WORD \$TMP0,\$ERRPC,\$REG0,CHKDRV,CYL.DS,TRK.DS,SEC.DS
24	054256	047140	047150	047152	DT44A:	.WORD RM.REG, RM.REG+10, RM.REG+12, RM.REG+36, RM.REG+34, RM.REG+C6
25	054272	047154	047200	047202	DT44B:	.WORD RM.REG+14, RM.REG+40, RM.REG+42
26	054300	001212	001132	001176	DT45:	.WORD \$TMP0,\$ERRPC,\$REG0,CHKDRV,CYL.DS,TRK.DS,SEC.DS
27	054316	047140	047150	047152	DT45A:	.WORD RM.REG, RM.REG+10, RM.REG+12, RM.REG+36, RM.REG+34, RM.REG+06
28	054332	047154	047200	047202	DT45B:	.WORD RM.REG+14, RM.REG+40, RM.REG+42, RM.REG+2, RM.REG+4, RM.REG+22

1
2
3 054346 000001
4 054350 002
5 054351 000
6
7 054352 000001
8 054354 007
9 054355 000
10
11 054356 000001
12 054360 004
13 054361 000
14
15 054362 000001
16 054364 005
17 054365 000
18
19 054366 000001
20 054370 002
21 054371 000
22
23 054372 000001
24 054374 002
25 054375 000
26
27 054376 000002
28 054400 007
29 054401 160
30 054402 052672
31 054404 006
32 054405 000
33
34 054406 000002
35 054410 007
36 054411 160
37 054412 052751
38 054414 005
39 054415 004
40
41 054416 000000
42 054420 005
43 054421 004
44
45 054422 000001
46 054424 010
47 054425 000
48
49 054426 000002
50 054430 006
51 054431 060
52 054432 053172
53 054434 004
54 054435 014
55
56 054436 000000
57 054440 004

.SBTTL DATA FORMAT (DF) TABLE

DF1: .WORD 1
.BYTE 2
.BYTE 0

DF2: .WORD 1
.BYTE 7
.BYTE 0

DF3: .WORD 1
.BYTE 4
.BYTE 0

DF4: .WORD 1
.BYTE 5
.BYTE 0

DF10: .WORD 1
.BYTE 2
.BYTE 0

DF11: .WORD 1
.BYTE 2
.BYTE 0

DF12: .WORD 2
.BYTE 7
.BYTE 160
.WORD DH12A
.BYTE 6
.BYTE 0

DF13: .WORD 2
.BYTE 7
.BYTE 160
.WORD DH13A
.BYTE 5
.BYTE 4

DF14: .WORD 0
.BYTE 5
.BYTE 4

DF17: .WORD 1
.BYTE ^D8
.BYTE 0

DF21: .WORD 2
.BYTE 6
.BYTE 60
.WORD DH21A
.BYTE 4
.BYTE 14

DF22: .WORD 0
.BYTE 4

;NUMBER OF DATA HEADERS
;NUMBER OF WORDS IN DATA TABLE
;ALL 3 NUMBERS ARE OCTAL

;2 DH'S TO BE TYPED
;7 DATA WORDS FOLLOW THE 1ST DH
;WORDS 1-4 ARE OCTAL 5-7 ARE DECIMAL
;ADDRESS OF 2ND DH
;6 DATA WORDS FOLLOW THE 2ND DH
;ALL WORDS ARE OCTAL

;WORD 3 IS DECIMAL

;WORD 3 IS DECIMAL

DATA FORMAT (DF) TABLE

58	054441	014		.BYTE	14	
59						
60	054442	000002	DF23:	.WORD	2	
61	054444	007		.BYTE	7	
62	054445	010		.BYTE	10	
63	054446	053316		.WORD	DH23A	;WORD 4 IS DECIMAL
64	054450	005		.BYTE	5	
65	054451	000		.BYTE	0	
66						
67						
68	054452	000001	DF41:	.WORD	1	
69	054454	004		.BYTE	4	
70	054455	000		.BYTE	0	
71						
72	054456	000003	DF42:	.WORD	1	
73	054460	007		.BYTE	7	
74	054461	000		.BYTE	0	
75						
76	054462	000002	DF43:	.WORD	2	
77	054464	007		.BYTE	7	
78	054465	000		.BYTE	0	
79	054466	053506		.WORD	DH43A	
80	054470	003		.BYTE	3	
81	054471	000		.BYTE	0	
82						
83	054472	000003	DF44:	.WORD	3	
84	054474	007		.BYTE	7	
85	054475	160		.BYTE	160	
86	054476	053534		.WORD	DH44A	
87	054500	006		.BYTE	6	
88	054501	000		.BYTE	0	
89	054502	053610		.WORD	DH44B	
90	054504	003		.BYTE	3	
91	054505	000		.BYTE	0	
92						
93	054506	000003	DF45:	.WORD	3	
94	054510	007		.BYTE	7	
95	054511	160		.BYTE	160	
96	054512	053534		.WORD	DH44A	
97	054514	006		.BYTE	6	
98	054515	000		.BYTE	0	
99	054516	053636		.WORD	DH45A	
100	054520	006		.BYTE	6	
101	054521	000		.BYTE	0	
102						
103						
104	054522		.SBTTL	START OF READ/WRITE BUFFER		
105			BUFFER:			
106		000200	.END	200		

ABASE = 000000	AT4 = 000020	CI4 = 042342	DH11 = 052564	DT07 = 000200
ACDW1 = 000000	AT5 = 000040	CI5 = 042720	DH12 = 052603	DT08 = 000400
ACDW2 = 000000	AT6 = 000100	CI6 = 042742	DH12A = 052672	DT1 = 053714
ACPUOP = 000000	AT7 = 000200	CI7 = 042756	DH13A = 052751	DT10 = 054000
ACTDRV = 040576	AUNIT = 000000	CI7B = 043000	DH17 = 053017	DT11 = 054004
ACTSTR = 040577	AUSWR = 000000	CI8 = 043056	DH2 = 052354	DT12 = 054010
ADDW0 = 000000	AVECT1 = 000000	CKSCTR = 034034	DH21 = 053114	DT12A = 054026
ADDW1 = 000000	AVECT2 = 000000	CKSWR = 104407	DH21A = 053172	DT13 = 054042
ADDW10 = 000000	AVERGE = 050052	CK.CHR = 040132	DH23 = 053231	DT13A = 054060
ADDW11 = 000000	A16 = 000400	CK.DEC = 040104	DH23A = 053316	DT17 = 054072
ADDW12 = 000000	A17 = 001000	CK.DIG = 040206	DH3 = 052441	DT2 = 053720
ADDW13 = 000000	BADTMO = 004576	CK.NUM = 040372	DH4 = 052476	DT21 = 054112
ADDW14 = 000000	BAI = 000010	CK.OCT = 040056	DH41 = 053363	DT21A = 054126
ADDW15 = 000000	BASFLG = 001466	CLKSTA = 001342	DH42 = 053421	DT23 = 054136
ADDW2 = 000000	BITS = 001540	CLOSE = 037776	DH43A = 053506	DT23A = 054154
ADDW3 = 000000	BIT0 = 000001	CLR = 000040	DH44A = 053534	DT3 = 053736
ADDW4 = 000000	BIT00 = 000001	CLRBUF = 033766	DH44B = 053610	DT4 = 053746
ADDW5 = 000000	BIT01 = 000002	CLRQUE = 046336	DH45A = 053636	DT41 = 054166
ADDW6 = 000000	BIT02 = 000004	CLSWDS = 037676	DISPLA = 001156	DT42 = 054176
ADDW7 = 000000	BIT03 = 000010	CNTCLR = 027334	DISPRE = 000174	DT43 = 054214
ADDW8 = 000000	BIT04 = 000020	CNTRLC = 001322	DLT = 100000	DT43A = 054232
ADDW9 = 000000	BIT05 = 000040	COMMA = 047515	DMD = 000001	DT44 = 054240
ADEVCT = 000000	BIT06 = 000100	CONT = 000100	DORTI = 032734	DT44A = 054256
ADEVN = 000000	BIT07 = 000200	COUNT = 033000	DPB.A = 047016	DT44B = 054272
AENV = 000000	BIT08 = 000400	CPSAVE = 022256	DPB.B = 047036	DT45 = 054300
AENVN = 000000	BIT09 = 001000	CR = 000015	DPB.C = 047056	DT45A = 054316
AFATAL = 000000	BIT1 = 000002	CRLF = 000200	DPB.R = 047116	DT45B = 054332
AMADR1 = 000000	BIT10 = 002000	CYL.DS = 001366	DPINT = 040552	DT5 = 053760
AMADR2 = 000000	BIT11 = 004000	CYL.RD = 001360	DPR = 000400	DVA = 004000
AMADR3 = 000000	BIT12 = 010000	C.SWR = 001314	DPRQS = 040562	EBL = 020000
AMADR4 = 000000	BIT13 = 020000	DATCMP = 034474	DRIVES = 047457	ECH = 000100
AMAMS1 = 000000	BIT14 = 040000	DCK = 100000	DROP = 047634	ECI = 004000
AMAMS2 = 000000	BIT15 = 100000	DDISP = 177570	DRQ = 004000	ECRC = 001000
AMAMS3 = 000000	BIT2 = 000004	DECSEC = 033704	DRVACT = 040522	EECC = 000020
AMAMS4 = 000000	BIT3 = 000010	DECSK = 010110	DRVCAL = 031204	EMPTYQ = 046414
AMSGAD = 000000	BIT4 = 000020	DELTA = 001450	DRVCLR = 000111	EMTVEC = 000030
AMSGLG = 000000	BIT5 = 000040	DFLT = 002526	DRVCL1 = 031224	EM1 = 050660
AMSGTY = 000000	BIT6 = 000100	DF1 = 054346	DRVINT = 041072	EM10 = 051115
AMTYP1 = 000000	BIT7 = 000200	DF10 = 054366	DRVMSK = 001354	EM11 = 051173
AMTYP2 = 000000	BIT8 = 000400	DF11 = 054372	DRVQUE = 046434	EM12 = 051230
AMTYP3 = 000000	BIT9 = 001000	DF12 = 054376	DRVSEL = 001330	EM13 = 051255
AMTYP4 = 000000	BLNKS1 = 050346	DF13 = 054406	DRVSTA = 040532	EM17 = 051302
AOE = 001000	BLNKS2 = 050345	DF14 = 054416	DRVSTYP = 040542	FM2 = 050732
APASS = 000000	BLNKS3 = 050344	DF17 = 054422	DRY = 000200	EM20 = 051334
APRIOR = 000000	BLNKS4 = 050343	DF2 = 054352	DSWR = 177570	EM23 = 051403
APTCSU = 000040	BPTVEC = 000014	DF21 = 054426	DTADPB = 047076	EM24 = 051432
APTENV = 000001	BSE = 100000	DF22 = 054436	DTE = 010000	EM3 = 050770
APTSIZ = 000200	BUFFER = 054522	DF23 = 054442	DTG = 000020	EM4 = 051020
APTSPO = 000100	BUSADR = 001324	DF3 = 054356	DTO = 020000	EM41 = 051472
ASWREG = 000000	BYPASS = 001350	DF4 = 054362	DTUW = 040634	EM46 = 051506
ATA = 100000	CALL.A = 030402	DF41 = 054452	DT00 = 000001	EM5 = 051061
ATABIT = 040636	CALL.B = 030550	DF42 = 054456	DT01 = 000002	ERINDX = 032170
ATESIN = 000000	CALL.C = 030766	DF43 = 054462	DT02 = 000004	ERMAX = 001316
ATO = 000001	CALL.R = 032016	DF44 = 054472	DT03 = 000010	ERR = 040000
AT1 = 000002	CHKDRV = 001352	DF45 = 054506	DT04 = 000020	ERRCN = 001472
AT2 = 000004	CI1 = 042126	DH1 = 052337	DT05 = 000040	ERROR = 104000
AT3 = 000010	CI3 = 042234	DH10 = 052545	DT06 = 000100	ERRVEC = 000004

SYMBOL TABLE	
ERR.CT	001464
ESRC =	004000
ES.SAV	046600
EXCEED	047645
EXIT.A	014424
EXITG	007462
EXIT1	007670
EXIT10	013252
EXIT11	013516
EXIT12	014440
EXIT13	015142
EXIT14	015702
EXIT15	016452
EXIT16	017074
EXIT17	017540
EXIT2	010132
EXIT20	020320
EXIT21	021136
EXIT22	021332
EXIT3	010352
EXIT4	010764
EXIT5	011210
EXIT6	011500
EXIT7	012076
FC	002340
FER =	000020
FILBUF	033730
FILRAN	035012
FMT16 =	010000
FS	002354
FT	002346
FWD	050136
F1 =	000002
F2 =	000004
F3 =	000010
F4 =	000020
F5 =	000040
GETADR	046624
GETNUM	035542
GETREG-	000141
GETREQ	046510
GETSWR	035450
GO -	000001
GTSWR =	104406
GTTST1	036036
GTTST2	036122
GTTST3	036464
GTTST4	036466
GTTST5	036716
GTTST6	036756
GT.PRM	035700
GT.PR1	035702
GT.PR2	036032
HCE =	000200
HCI =	002000
HCRC =	000400
HT =	000011
IAE -	002000
IBSAVE	022260
IC	002344
IE =	000100
ILF =	000001
ILR =	000002
INCCYL	033654
INCEC	027216
INCSK	010046
INCTRK	033624
IOTVEC-	000020
IR	000100
ISR	043306
IT	002352
ITEM41	002254
LC	002342
LDCMD	030336
LF =	000012
LKS	001526
LKV	001522
LODEV	047420
LODFLT	027704
LODPRM	030142
LOP.CK	032130
LPB	001536
LPS	001534
LPTAVL	001326
LP.AVL	027364
LS	002356
LSIT =	000002
LST -	002000
LSTRK	001374
LT	002350
MABOVE	050244
MBELOW	050215
MCLK =	004000
MCPE =	020000
MCPEMX	040646
MDF	000100
MES.FT	047234
MES.IT	047244
MES.LT	047240
MI	000004
MOC	000400
MOH	020000
MOL =	010000
MPE =	000400
MRD -	002000
MRMCS1	046776
MRMVEC	047006
MS =	000040
MSC =	000002
MSDRIV	047625
MSEN	010000
MSER -	000200
MSGAVG	050202
MSGB01	052301
MSGB02	052231
MSGB03	052161
MSGB04	052141
MSGB05	052071
MSGB06	052025
MSGB08	051763
MSGB09	051724
MSGB10	051701
MSGB11	051653
MSGB12	051631
MSGB13	051600
MSGB14	051536
MSGMAX	050174
MSGMIN	050166
MSGNOM	050330
MSGNUM	050313
MSGSEA	050273
MSGTST	047617
MSG.CS	047264
MSG.EQ	047262
MSG.FC	047212
MSG.FS	047250
MSG.FT	047223
MSG.IC	047220
MSG.IT	047231
MSG.LC	047215
MSG.LS	047253
MSG.LT	047226
MSG.PA	047256
MSG.R	047210
MSG0US	050210
MSG10X	050500
MSG11X	050542
MSG12X	050604
MSG7XA	050350
MSG7XB	050425
MUR =	001000
MWP =	000010
MXF =	001000
MXSEEK	050112
MXSTAL	001462
MXWINDW	040656
NBA =	100000
NC1	002370
NC2	002372
NED =	010000
NEM =	004000
NOCLOK	047520
NODRVS	047703
NONE	047510
NOOP =	000101
NOTEST	047727
NOTPRS	047352
NOTRM	047377
NOTSAF	047367
OBCK -	100000
OBEN	040000
OCC -	100000
OFD =	000200
OFFSET=	000115
OM =	000001
ONECYL	050005
OPE =	020000
OPI =	020000
OPNFLG	001336
OPNPAT	037364
OPNPRM	037162
OPNTST	037010
OPNWDS	037506
OPN.CT	037014
OPN.N1	037720
OPN.N2	037724
OPN.X1	037736
OPN.X2	037742
OPN.1	037020
OPN.2	037042
OPT	041700
OR =	000200
PACK =	000123
PAR =	000010
PAT	002360
PAT.PT	003536
PAT0	003576
PAT1	003636
PAT10	004276
PAT11	004336
PAT12	004376
PAT13	004436
PAT14	004476
PAT15	004536
PAT2	003676
PAT3	003736
PAT4	003776
PAT5	004036
PAT6	004076
PAT7	004136
PAT8	004176
PAT9	004236
PDA =	000400
PFECH	022700
PFECH1	022710
PFECH2	022772
PFECH3	023024
PFECH4	023034
PFTSTN	023040
PGE -	002000
PGM =	001000
PHA =	000200
PIP =	020000
PIRQ =	177772
PIRQVE=	000240
PKB	001516
PKC	001520
PKCS	001514
PKV	001510
PLFS -	002000
POPQUE	046532
PRM	002334
PRMLMT	002444
PRMMSG	002476
PRMPT	002374
PRM0	003132
PRM1	003150
PRM10	003336
PRM11	003354
PRM12	003374
PRM13	003410
PRM14	003420
PRM15	003430
PRM16	003440
PRM17	003452
PRM2	003176
PRM20	003462
PRM21	003516
PRM22	003526
PRM3	003216
PRM4	003236
PRM5	003256
PRM6	003276
PRM7	003316
PRO -	000000
PR1 -	000040
PR2 -	000100
PR3 =	000140
PR4 =	000200
PR5 =	000240
PR6 -	000300
PR7 -	000340
PS	177776
PSEL -	002000
PSW	177776
PTRN15	003514
PWRVEC=	000024
QCNT	046044
QDRV0	046136
QDRV1	046156
QDRV2	046176
QDRV3	046216
QDRV4	046236
QDRV5	046256
QDRV6	046276
QDRV7	046316
QINPT	046054
QOUTPT	046074
QSTART	046114
QSTOP	046116
QTERM =	046336
RANADR	035266
RANCK	035034
RANPAT	035232
RDCHR =	104410

RDLIN	4411	SAVEFG	040610	START4	004702	TEST12	014116	TST7	011502
RDY	00200	SAVREG-	104412	STATBL	001762	TEST13	014652	*YPDS =	104405
RD.ADR	045326	SC	043520	STKLMT=	177774	TEST14	015354	TYPE =	104401
RD.RM	045302	SCOPE =	000004	STO	044760	TEST15	016114	TYPERR	022262
RD.RM1	045324	SCTRWC=	177400	STO1	045014	TEST16	016574	TYPOC =	104402
RD.RM2	045450	SCO	= 000100	STO2	045110	TEST17	017216	*YPON =	104404
RD.RM3	045454	SC1	= 000200	STO3	045140	TEST2	010026	TYPOS =	104403
RD.RM4	045460	SC11	044352	STO5	045164	TEST20	017770	TYPTIM	033240
RD.WRD	045330	SC12	044462	STO6	045172	TEST21	020616	T10	001660
READ =	000171	SC13	044532	STO7	045230	TEST22	021252	T11	001670
READHD=	000173	SC2	= 000400	STO8	045260	TEST3	010270	T12	001700
READIN=	000121	SC3	043570	STO9	045270	TEST4	010524	T7A	001620
RECAL =	000107	SC4	043574	STRTMR	032736	TEST5	011122	T7A1	001640
RELEAS=	000113	SC5	043606	STRT1A	004674	TEST6	011346	T7B	001630
RESREG=	104413	SC6	044002	STRT2A	004716	TEST7	011642	T7B1	001650
RESVEC=	000010	SC6A	044116	ST.CLK	027426	TICKMS	001344	ULDFLG	040600
REV	050152	SC7	044244	ST.LCL	027636	TICKUS	001346	UNLOAD=	000103
REX =	010000	SC8	044322	ST.PCL	027574	TIMER	040614	UNS =	040000
RHVEC	001504	SEARCH=	000131	SVADR	001440	TIM.DN	001414	UNSTAT	047313
RH.ADR	001502	SEC.DS	001370	SVRH70	045654	TIM.PT	001432	UNTOFF	047331
RMADR	040650	SEC.RD	001364	SVSTAT	001356	TIM.UP	001376	JANTON	047342
RMAS -	000016	SEEK -	000105	SWR	001154	TKVEC =	000060	UPE =	020000
RMBB =	000004	SEEKFG	040612	SWREG	000176	TPB	001532	US1 =	000001
RMCS1	000000	SEKCNT	001446	SW0	= 000001	TPS	001530	US2 =	000002
RMCS2	000010	SEPTMR	001444	SW00	= 000001	TPS50	014436	US4 =	000004
RMDA -	000006	SELDIV=	000145	SW01	= 000002	TPS60	014420	VERIFY	032410
RMDB -	000022	SERIAL	047605	SW02	= 000004	TPVEC =	000064	VV =	000100
RMDC -	000034	SETBUF	034404	SW03	= 000010	TP50	014430	WC =	000040
RMDS	000012	SETFOR-	000143	SW04	= 000020	TP60	014412	WCE =	040000
RMDT -	000026	SETVEC	006060	SW05	= 000040	TRAPVE=	000034	WCEFLG	001434
RMEC1 -	000044	SET.IE	045772	SW06	= 000100	TRCKWC	001452	WCF =	000040
RMEC2 -	000046	SHUT	025334	SW07	= 000200	TRE =	040000	WD =	000010
RMERRS	040512	SKI -	040000	SW08	= 000400	TRK.DS	001372	WLE =	004000
RMER1 -	000014	SLASH	047307	SW09	= 001000	TRK.RD	001362	WRCKD =	000151
RMER2 -	000042	SPTYP	033132	SW1	= 000002	TRNSWT	040572	WRCKHD=	000153
RMHR -	000036	SP10	001740	SW10	= 002000	TRTVEC=	000014	WRITE =	000161
RMINIT	040660	SP11	001746	SW11	= 004000	TSTNMS	001332	WRL =	004000
RMLA	000020	SP12	001754	SW12	= 010000	TST0	007222	WRTHD -	000163
RMMR1 -	000024	SP7A	001710	SW13	= 020000	TST1	007464	WRT.AD	045552
RMMR2	000040	SP7A1	001724	SW14	= 040000	TST10	012100	WRT.RM	045462
RMOF -	000032	SP7B	001716	SW15	= 100000	TST10A	012614	WRT.R1	045546
RMR =	000004	SP7B1	001732	SW2	= 000004	TST10B	013206	WRT.R2	045640
RMSN -	000030	SRCHWT	040574	SW3	= 000010	TST11	013254	WRT.R3	045644
RMTMR	044670	SRCH00	032552	SW4	= 000020	TST12	013520	WRT.R4	045650
RMVEC	040652	SRTDRV	006334	SW5	= 000040	TST13	014442	WRT.R5	045652
RMWC	000002	SRTINT	006002	SW6	= 000100	TST14	015144	WRT.WD	045550
RM.REG	047140	SRVCLK	027672	SW7	= 000200	TST15	015704	XXDP	001470
RM05	041406	STACK -	001100	SW8	= 000400	TST16	016454	\$APTHD	001100
ROTATE	047754	STALL	032326	SW9	= 001000	TST17	017076	\$ATYC	026774
RPT	002336	STALLO	001436	TAB.XY	= 001114	TST2	007672	\$ATY1	026750
RSTART	006662	STALL1	001454	TAP -	040000	TST20	017542	\$ATY3	026756
RSTRT1	006712	STALL2	001456	TBITVE=	000014	TST21	020322	\$ATY4	026766
RTC =	000117	STALL3	001460	TD	043350	TST22	021140	\$AUTOB	001150
RTURN	021600	START	004724	TEST0	007372	TST3	010134	\$BASE	001310
R6 -	%000006	START1	004670	TEST1	007654	TST4	010354	\$BDADR	001136
R7 -	%000007	START2	004712	TEST10	012356	TST5	010766	\$BDDAT	001142
SAVCSW	001320	START3	004660	TEST11	013440	TST6	011212	\$BELL	001224

\$CHARC	023372	\$ERRTB	002014	\$MAMS3	001274	\$REG4	001206	\$TMP2	001216
\$CKSWR	024360	\$ERTTL	001126	\$MAMS4	001300	\$REG5	001210	\$TN =	000023
\$CMTAG	001114	\$ESCAP	001222	\$MBADR	001102	\$RESRE	026014	\$TNPWR	026302
\$CM1 =	000006	\$ETABL	001254	\$MFLG	027212	\$RM02	047440	\$TPB	001166
\$CM2 =	000014	\$ETEND	001314	\$MNEW	025322	\$RM03	047445	\$TPFLG	001173
\$CM3 =	000006	\$FATAL	001236	\$MSGAD	001250	\$RM05	047452	\$TPS	001164
\$CM4 =	000003	\$FFLG	027214	\$MSGLG	001252	\$RTNAD	021572	\$TRAP	026052
\$CNTLC	025272	\$FILLC	001172	\$MSGTY	001234	\$SAVRE	025756	\$TRAP2	026074
\$CNTLG	025304	\$FILLS	001171	\$MSWR	025311	\$SB2D	026136	\$TRP =	000014
\$CNTLU	025277	\$GDADR	001134	\$MTYP1	001265	\$SCOPE	025356	\$TRPAD	026106
\$CPUOP	001262	\$GDDAT	001140	\$MTYP2	001271	\$SETUP=	000167	\$STM	001104
\$CRLF	001231	\$GET42	021550	\$MTYP3	001275	\$STUP =	177777	\$STNM	001116
\$DBLK	024040	\$GTSWR	024450	\$MTYP4	001301	\$SUPRS	026366	\$TTYIN	025246
\$DB2D	026172	\$HD =	000000	\$MXCNT	025754	\$SVLAD	025704	\$TYPDS	023624
\$DECVL	026352	\$HIBTC	001100	\$NULL	001170	\$SSVPC =	000220	\$TYPE	023042
\$DEVCT	001244	\$HINUM	026524	\$NWTST=	000001	\$SWR =	167000	\$TYPEC	023254
\$DEVM	001312	\$ICNT	001120	\$OCNT	023620	\$SWREG	001256	\$TYPEX	023374
\$DIV	026530	\$INTAG	001151	\$OMODE	023622	\$SWRMK=	000000	\$TYOC	023422
\$DOAGN	021570	\$ITEMB	001130	\$OVER	025740	\$TESTN	001240	\$TYPON	023436
\$DTBL	024030	\$LF	001232	\$PASS	001242	\$TIMES	001220	\$TYPOS	023376
\$ENDAD	021560	\$LFLG	027213	\$PASTM	001106	\$TKB	001162	\$UNIT	001246
\$ENDCT	021514	\$LONUM	026526	\$QUES	001230	\$TKCNT	024050	\$UNITM	001110
\$ENULL	021574	\$LPADR	001122	\$RAND	026426	\$TKINT	024060	\$USWR	001260
\$ENV	001254	\$LPERR	001124	\$RDCHR	024722	\$TKQEN=	024057	\$VECT1	001304
\$ENVM	001255	\$MADR1	001266	\$RDLIN	025012	\$TKQIN	024052	\$VECT2	001306
\$EOP	021334	\$MADR2	001272	\$RDSZ =	000024	\$TKQOU	024054	\$XOFF =	000023
\$EOPCT	021506	\$MADR3	001276	\$REGAD	001174	\$TKQSR	024056	\$XON =	000021
\$ERFLG	001117	\$MADR4	001302	\$REG0	001176	\$TKS	001160	\$XTSTR	025374
\$ERMAX	001131	\$MAIL	001234	\$REG1	001200	\$TKSRV	024130	\$SGET4=	000000
\$ERROR	021620	\$MAMS1	001264	\$REG2	001202	\$TMP0	001212	\$OFILL	023621
\$ERRPC	001132	\$MAMS2	001270	\$REG3	001204	\$TMP1	001214	\$.X =	001100

. ABS. 054522 000
000000 001
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 62464 WORDS (244 PAGES)
DYNAMIC MEMORY AVAILABLE FOR 70 PAGES
CZRMVB.BIC,CZRMVB/C CZRMVB.DOC,CZRMVB,SYSMAC/M

\$SET4	17-1	17-1#																
\$FILL	21-1	21-1#	21-1*	21-1*														
\$LOCAT	18-1	24-1																
\$APTHD	5-12	5-12#																
\$ASTAT	32-1	32-1																
\$ATY1	32-1#																	
\$ATY3	20-1	32-1#																
\$ATY4	18-1	32-1#																
\$ATYC	32-1	32-1#																
\$AUTOB	6-0#	11-38*	23-1	23-1	23-1													
\$BASE	6-0#																	
\$BDADR	6-0#	33-987*	33-:52*	41-13														
\$BDDAT	6-0#	33-917*	33-989*	33-:54*	41-13	41-16												
\$BELL	6-0#	11-42	18-1	18-1	18-1	23-1	23-1	23-1										
\$CHARC	20-1	20-1#	20-1*	20-1*	20-1*													
\$CKSWR	23-1#	26-1	26-1															
\$CM1	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0#	6-0#			
\$CM2	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0	6-0#	6-0#			
\$CM3	6-0	6-0	6-0#	6-0#	6-0#													
\$CM4	6-0	6-0	6-0	6-0	6-0	6-0	6-0#	6-0#	6-0#	6-0#								
\$CMTAG	6-0#	11-33	11-33	11-33	11-33	11-33	11-33	11-33	11-33									
\$CNTLC	23-1	23-1	23-1	23-1	23-1#													
\$CNTLG	23-1	23-1#																
\$CNTLU	23-1	23-1	23-1#															
\$CPUOP	6-0#																	
\$CRLF	6-0#	11-65	11-105	11-150	12-45	12-65	13-46	13-68	18-1	18-1	18-1	19-42	19-58	19-69				
	19-79	19-93	19-100	20-1	20-1	20-1	23-1	23-1	23-1	23-1	33-15	33-692	33-693	33-708				
	33->35																	
\$DB2D	27-1	28-1#																
\$DBLK	22-1	22-1	22-1#															
\$DECVL	28-1	28-1#																
\$DEVCT	6-0#																	
\$DEVVM	6-0#																	
\$DIV	14-70	14-336	14-528	31-1#	33-765													
\$DUAGN	17-1	17-1	17-1#															
\$DTBL	22-1	22-1#																
\$ENDAD	5-9	11-38	17-1#	18-1														
\$ENDCT	11-33	12-40*	12-57*	12-66	17-1#													
\$ENULL	17-1	17-1#																
\$ENV	6-0#	11-38	18-1	20-1	32-1	32-1												
\$ENVVM	6-0#	11-33	20-1	20-1	32-1													
\$EOP	13-37	16-372	17-1#	23-7	33-23	33-475	35-47											
\$EOPCT	11-33*	12-66*	13-27*	17-1	17-1#	33-22*												
\$ERFLG	6-0#	18-1	18-1	18-1*	24-1	24-1	24-1	24-1	24-1	24-1	24-1*	33-432	33-902	33-933	33-:07			
	33-:66																	
\$ERMAX	6-0#	11-33*	13-69*	14-44*	14-79*	14-109*	14-141*	14-170*	14-239*	14-274*	14-316*	14-392*	14-543*	15-29*				
	15-154*	15-233*	15-318*	16-20*	16-77*	16-156*	16-287*	16-372*	24-1	24-1	24-1	24-1*						
\$ERROR	11-33	18-1#																
\$ERRPC	6-0#	18-1	18-1	18-1	18-1*	18-1*	19-111	41-3	41-4	41-5	41-6	41-7	41-8	41-9				
	41-10	41-12	41-14	41-15	41-17	41-19	41-20	41-21	41-23	41-26								
\$ERRTB	8-0#	19-37	19-38															
\$ERTTL	6-0#	17-1	17-1	17-1*	18-1	18-1	18-1*	18-1	18-1	18-1	18-1	24-1*	33-242*	33-249*	33-272*			
\$ESCAP	6-0#	11-33*	15-60*	15-175*	15-254*	15-339*	18-1	18-1	18-1	18-1	18-1	24-1*	33-242*	33-249*	33-272*			
	33-279*	33-312*	33-319*	33-355*	33-365*	33-386*	33-393*	33-417*	33-447*	33-454*	33-471*	33-579*	33-584*	33-608*				

	33-615*	33-922*	33-927*	33-997*	33-:03*	33-:50*	34-772	34-830	34-832	34-;18	34-;77	34-=81	34-=91	34--92*
\$ETABL	6-0#													
\$ETEND	5-12	6-0#												
\$FATAL	6-0#	32-1*												
\$FFLG	32-1	32-1#	32-1*	32-1*	32-1*									
\$FILLC	6-0#	20-1	20-1	20-1										
\$FILLS	6-0#	20-1	20-1	20-1										
\$GDADR	6-0#	33-988*	33-:53*	41-13										
\$GDDAT	6-0#	33-990*	33-:55*	41-13										
\$GET42	12-53	13-9	17-1#											
\$GTSWR	23-1#	26-1	26-1											
\$HD	4-37	4-37	4-37											
\$HIBTS	5-12#													
\$HINUM	11-33*	14-70	14-331	14-528	16-293*	30-1	30-1	30-1#	30-1*	33-:37	33-:43*	33-:46*	33-:90	33-:06
\$ICNT	6-0#	11-91*	24-1	24-1	24-1	24-1*	24-1*							
\$INTAG	6-0#	23-1	23-1	23-1	23-1	23-1*								
\$ITEMB	6-0#	18-1	18-1	18-1	18-1	18-1	18-1*	18-1*	19-20					
\$LF	6-0#	18-1	18-1	20-1	20-1	23-1	23-1	23-1						
\$LFLG	32-1#	32-1*												
\$LONUM	11-33*	16-294*	30-1	30-1	30-1#	30-1*	33-547	33-:38	33-:42*	33-:45*	33-:89	33-:04	33-:05	
\$LPADR	6-0#	11-33*	14-70*	14-92*	14-111*	14-143*	14-172*	14-241*	14-276*	14-325*	14-394*	14-545*	15-36*	15-60*
	15-161*	15-175*	15-240*	15-254*	15-325*	15-339*	16-26*	16-83*	16-161*	16-289*	16-318*	16-377*	24-1	24-1
	24-1	24-1*	24-1*											
\$LPERR	6-0#	11-33*	14-44*	14-79*	14-109*	14-119*	14-126*	14-141*	14-151*	14-154*	14-170*	14-185*	14-206*	14-239*
	14-250*	14-274*	14-286*	14-316*	14-340*	14-342*	14-392*	14-454*	14-455*	14-543*	15-29*	15-154*	15-233*	15-318*
	16-20*	16-34*	16-38*	16-40*	16-47*	16-53*	16-77*	16-92*	16-102*	16-120*	16-126*	16-156*	16-234*	16-242*
	16-251*	16-287*	16-303*	16-318*	16-328*	16-334*	16-345*	16-351*	16-361*	16-372*	18-1	24-1	24-1	24-1
	24-1*	33-470	33-587											
\$MADR1	6-0#													
\$MADR2	6-0#													
\$MADR3	6-0#													
\$MADR4	6-0#													
\$MAIL	5-12	5-12	6-0#	11-33	11-38	14-44	14-79	14-109	14-141	14-170	14-239	14-274	14-316	14-392
	14-543	15-29	15-154	15-233	15-318	16-20	16-77	16-156	16-287	16-372	18-1	20-1	24-1	
\$MAMS1	6-0#													
\$MAMS2	6-0#													
\$MAMS3	6-0#													
\$MAMS4	6-0#													
\$MBADR	5-12#													
\$MFLG	32-1	32-1#	32-1*	32-1*										
\$MNEW	23-1	23-1#												
\$MSGAD	6-0#	32-1	32-1*											
\$MSGLG	6-0#	32-1*												
\$MSGTY	4-0#	32-1	32-1	32-1*	32-1*									
\$MSWR	23-1	23-1#												
\$MTYP1	6-0#													
\$MTYP2	6-0#													
\$MTYP3	6-0#													
\$MTYP4	6-0#													
\$MXCNT	24-1	24-1	24-1	24-1#										
\$NULL	6-0#	20-1	20-1	20-1										
\$NWTST	14-44	14-44	14-44#	14-44#	14-79	14-79	14-79#	14-79#	14-109	14-109	14-109#	14-109#	14-141	14-141
	14-141#	14-141#	14-170	14-170	14-170#	14-170#	14-239	14-239	14-239#	14-239#	14-274	14-274	14-274#	14-274#
	14-316	14-316	14-316#	14-316#	14-392	14-392	14-392#	14-392#	14-543	14-543	14-543#	14-543#	15-29	15-29
	15-29#	15-29#	15-154	15-154	15-154#	15-154#	15-233	15-233	15-233#	15-233#	15-318	15-318	15-318#	15-318#
	16-20	16-20	16-20#	16-20#	16-77	16-77	16-77#	16-77#	16-156	16-156	16-156#	16-156#	16-287	16-287

	16-287#	16-287#	16-372	16-372	16-372#	16-372#									
\$OCNT	21-1#	21-1*	21-1*												
\$OMODE	21-1	21-1#	21-1*	21-1*	21-1*	21-1*									
\$OVER	24-1	24-1	24-1	24-1#											
\$PASS	6-0#	11-33*	17-1	17-1	17-1*	17-1*									
\$PASTM	5-12#														
\$QUES	6-0#	18-1	18-1	20-1	20-1	23-1	23-1	23-1	23-1						
\$R2A	26-1														
\$RAND	14-70	14-330	14-528	30-1#	33-546	33-:88	33-;03								
\$RDCHR	23-1#	26-1	26-1												
\$RDDEC	26-1														
\$RDLIN	23-1#	26-1	26-1												
\$RDOC*	26-1														
\$RDSZ	23-1	23-1#													
\$REG0	6-0#	19-14*	41-10	41-12	41-15	41-19	41-20	41-21	41-23	41-26					
\$REG1	6-0#	19-15*	41-4	41-7	41-16	41-16									
\$REG2	6-0#	19-16*	41-9												
\$REG3	6-0#	19-17*	41-3	41-4											
\$REG4	6-0#	19-18*	41-13	41-16											
\$REG5	6-0#	19-19*	41-7												
\$REGAD	6-0#	11-40													
\$RESRE	25-1#	26-1													
\$RHEXT	34-164	34-193	34-<16												
\$RMO2	11-139	37-27#													
\$RMO3	11-136	37-28#													
\$RMO5	11-142	37-29#													
\$RTNAD	17-1#														
\$SAVRE	25-1#	26-1	26-1												
\$SB2D	27-1#	33-700	33-705	33-742	33-747	33-749	33-752	33-757	33-759	33-769	33-772	33->62	33-?13		
\$SCOPE	11-33	24-1#													
\$SETUP	4-298	4-298	4-298	4-298	4-298	4-298	4-298#	4-298#	4-298#	4-298#	4-298#	4-298#	4-298#	4-298#	11-33
	11-33	11-33	11-33	11-33	11-33	11-33	11-33	11-33	11-33	11-33	11-33	11-33	11-33	11-38	11-38
	17-1	17-1	18-1	18-1	18-1	18-1	23-1	23-1	23-1	23-1	23-1	23-1	24-1		
\$STUP	4-298	4-298	4-298	4-298	4-298	4-298	4-298#	4-298#	4-298#	4-298#	4-298#	4-298#	4-298#	4-298#	4-298#
	4-298#	4-298#	4-298#	4-298#											
\$SUPRS	29-1#	33-701	33-706	33-742	33-747	33-749	33-752	33-757	33-759	33-769	33-772	33->62	33-?13		
\$SVLAD	24-1	24-1#													
\$SVPC	5-9	5-9#													
\$SWR	4-27#	4-37	4-38	4-38	4-38	4-38	4-38	4-38	4-38	4-38	5-217#	6-0	6-0	6-0	
	11-33	11-33	11-33	11-33	11-33	14-44	14-79	14-109	14-141	14-170	14-239	14-274	14-316	14-392	
	14-543	15-29	15-154	15-233	15-318	16-20	16-77	16-156	16-287	16-372	17-1	17-1	17-1	17-1	
	17-1	18-1	18-1	18-1	18-1	18-1	18-1	18-1	18-1	18-1	18-1	18-1	18-1	18-1	
	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	24-1	
	24-1	24-1	24-1												
\$SWREG	6-0#	11-33													
\$SWRPMK	24-1														
\$TESTN	6-0#	14-44*	14-45	14-79*	14-80	14-109*	14-110	14-141*	14-142	14-170*	14-171	14-239*	14-240	14-274*	
	14-275	14-316*	14-317	14-392*	14-393	14-543*	14-544	15-29*	15-30	15-154*	15-155	15-233*	15-234	15-318*	
	15-319	16-20*	16-21	16-77*	16-78	16-156*	16-157	16-287*	16-288	16-372*	16-373	19-24	19-27	24-1*	
\$TIMES	6-0#	11-33*	14-44*	14-79*	14-109*	14-141*	14-170*	14-239*	14-274*	14-316*	14-392*	14-543*	15-29*	15-154*	
	15-233*	15-318*	16-20*	16-77*	16-156*	16-287*	16-372*	17-1*	24-1	24-1	24-1	24-1*	24-1*		
\$TKB	6-0#	20-1	20-1	23-1	23-1	23-1	23-1	23-1	23-1	23-1					
\$TKCNT	23-1	23-1	23-1#	23-1*	23-1*	23-1*									
\$TKINT	11-81	17-4	23-1	23-1	23-1#										
\$TKQEN	23-1	23-1	23-1#												
\$TKQIN	23-1	23-1	23-1#	23-1*	23-1*	23-1*	23-1*								
\$TKQOU	23-1	23-1	23-1#	23-1*	23-1*	23-1*									

\$XON	20-1	20-1	23-1			
\$XTSTR	24-1#					
.\$ASTA	32-1	32-1				
.\$X	5-12	5-12#				
A16	4-79#					
A17	4-80#					
ABASE	6-0	6-0				
ACDW1	6-0					
ACDW2	6-0					
ACPUOP	6-0	6-0				
ACTDRV	34-93#	34-347*	34-398*	34-691*	34-699*	34-986
ACTSTR	34-99#	34-988*	34-:02*			
ADDW0	6-0					
ADDW1	6-0					
ADDW10	6-0					
ADDW11	6-0					
ADDW12	6-0					
ADDW13	6-0					
ADDW14	6-0					
ADDW15	6-0					
ADDW2	6-0					
ADDW3	6-0					
ADDW4	6-0					
ADDW5	6-0					
ADDW6	6-0					
ADDW7	6-0					
ADDW8	6-0					
ADDW9	6-0					
ADEVCT	6-0	6-0				
ADEVN	6-0	6-0				
AENV	6-0	6-0				
AENVN	6-0	6-0				
AFATAL	6-0	6-0				
AMADR1	6-0	6-0				
AMADR2	6-0	6-0				
AMADR3	6-0	6-0				
AMADR4	6-0	6-0				
AMAMS1	6-0	6-0				
AMAMS2	6-0	6-0				
AMAMS3	6-0	6-0				
AMAMS4	6-0	6-0				
AMSGAD	6-0	6-0				
AMSGLG	6-0	6-0				
AMSGTY	6-0	6-0				
AMTYP1	6-0	6-0				
AMTYP2	6-0	6-0				
AMTYP3	6-0	6-0				
AMTYP4	6-0	6-0				
AOE	4-151#					
APASS	6-0	6-0				
APRIOR	6-0					
APTCSU	20-1	32-1#				
APTENV	18-1	20-1	32-1	32-1#		
APTSIZ	11-33	32-1#				
APTSP0	20-1	32-1	32-1#			
ASWREG	6-0	6-0				
ATO	4-199#					

AT1	4-200#														
AT2	4-201#														
AT3	4-202#														
AT4	4-203#														
AT5	4-204#														
AT6	4-205#														
AT7	4-206#														
ATA	4-138#														
ATABIT	12-29	33-10	33-21	33-<29	33-<35	34-145#	34-318	34-410	34-515	34-895	34-923	34-931	34-932	34-954	
	34-.51														
ATESTN	6-0	6-0													
AUNIT	6-0	6-0													
AUSWR	6-0	6-0													
AVECT1	6-0	6-0													
AVECT2	6-0	6-0													
AVERGE	7-0	37-44#													
BADTMO	11-3#	11-35													
BAI	4-97#														
BASFLG	7-0#	14-81*	16-336	16-353	33-372*	33-400*	33-424*								
BIT0	4-71#														
BIT00	4-71	4-71#	7-0	7-0	12-7	13-39	18-1	18-1	24-1	24-1	33-144				
BIT01	4-71	4-71#	7-0	7-0	33-472	33-500	34-390	34-655							
BIT02	4-71	4-71#	7-0	7-0	33-472	33-503									
BIT03	4-71	4-71#	7-0	7-0	33-509	34-849	34-;	71							
BIT04	4-71	4-71#	7-0	7-0	33-506	34-885									
BIT05	4-71	4-71#	7-0	7-0	33-509	34-865									
BIT06	4-71	4-71#	7-0	7-0	33-512	34-328	34-381	34-454	34-734	34-<42					
BIT07	4-71	4-71#	7-0	7-0	34-328	34-590	34-711	34-849	34-865	34-885	34-927	34-<03			
BIT08	4-71	4-71#	7-0	33-500	34-328										
BIT09	4-71	4-71#	7-0	18-1	18-1	24-1	24-1	33-515	34-;	39					
BIT1	4-71#														
BIT10	4-71#	7-0	18-1	33-472	33-503	33-?88	34-657								
BIT11	4-71#	7-0	24-1	33-156	33-503	34-281	34-417	34-618	34-972						
BIT12	4-71#	7-0	33-472	33-506	34-275	34-309	34-328	34-392	34-425	34-608	34-653	34-669	34-875	34-877	
	34-;	34-;	66	34-;	43										
BIT13	4-71#	7-0	18-1	33-472	33-500	34-375	34-820	34-;	14						
BIT14	4-71#	7-0	24-1	33-381	33-472	33-506	34-387	34-422	34-805	34-965	34-;	75	34-;	21	
BIT15	4-71#	7-0	33-638	33-639	34-375	34-387	34-390	34-392	34-422	34-425	34-618	34-655	34-657	34-<40	
	34-849	34-865	34-875	34-885	34-965	34-;	39	34-;	75	34-;	83				
BIT2	4-71#	34-;	83												
BIT3	4-71#														
BIT4	4-71#														
BIT5	4-71#														
BIT6	4-71#														
BIT7	4-71#														
BIT8	4-71#														
BIT9	4-71#														
BITS	7-0#	14-44	14-79	14-109	14-141	14-170	14-239	14-274	14-316	14-392	14-543	15-29	15-154	15-;	
	15-318	16-20	16-77	16-156	16-220	16-287	16-372	33-<96	33-;	30	33-;	71	33-;	31	
BLNKS1	33->90	37-61#													
BLNKS2	11-133	19-63	19-89	19-96	19-103	33-746	33-756	33-771	33->57	33->86	37-60#				
BLNKS3	37-59#														
BLNKS4	11-107	37-58#													
BPTVEC	4-71#														
BSE	4-262#	33-254	33-286	33-326	33-370	33-398	33-422	33-521							
BUFFER	14-407	16-33	16-45	16-56	16-90	16-100	16-115	16-191	16-297	16-324	16-333	16-343	16-350	16-360	
	33-568*	33-569	33-571	33-573	33-574	33-575	33-637	33-674	33-841	33-860	33-861	33-885	33-946	33-965	

DF11	8-94	42-23#												
DF12	8-108	42-27#												
DF13	8-122	8-145	42-34#											
DF14	8-131	8-154	42-41#											
DF17	8-165	8-176	42-45#											
DF2	8-25	8-58	42-7#											
DF21	8-190	42-49#												
DF22	8-199	42-56#												
DF23	8-212	8-225	42-60#											
DF3	8-36	42-11#												
DF4	8-47	42-15#												
DF41	8-258	42-68#												
DF42	8-269	42-72#												
DF43	8-282	42-76#												
DF44	8-298	42-83#												
DF45	8-314	8-330	42-93#											
DFLT	9-61#	33-133												
DH1	8-12	40-3#												
DH10	8-81	40-7#												
DH11	8-92	40-8#												
DH12	8-106	8-120	8-143	8-296	8-312	8-328	40-9#							
DH12A	40-10#	42-30												
DH13A	40-11#	42-37												
DH17	8-163	8-174	40-12#											
DH2	8-23	8-56	40-4#											
DH21	8-188	40-13#												
DH21A	40-14#	42-52												
DH23	8-210	8-223	40-15#											
DH23A	40-16#	42-63												
DH3	8-34	40-5#												
DH4	8-45	40-6#												
DH41	8-256	40-17#												
DH42	8-267	8-280	40-18#											
DH43A	40-19#	42-79												
DH44A	40-20#	42-86	42-96											
DH44B	40-21#	42-89												
DH45A	40-22#	42-99												
DISPLA	6-0#	11-33*	11-33*	18-1*	24-1*									
DISPRE	5-1#	11-33												
DLT	4-109#													
DMD	4-161#	4-180#												
DORTI	14-454	15-92	15-182	15-259	15-344	33-625#								
DPB.A	13-32*	13-38*	13-41*	13-42*	13-44*	14-46*	14-319*	14-339*	14-343	14-395*	14-398*	14-411	14-454	14-454
	14-454	14-528	14-528	14-528	14-528*	14-528*	15-60*	15-60*	15-60*	15-175*	15-175*	15-175*	15-254*	15-254*
	15-254*	15-339*	15-339*	15-339*	16-379*	16-380*	16-384*	16-385*	33-244	33-246	33-250	33-250	33-250	33-250
	33-260	33-457	33-582*	36-3#										
DPB.B	13-33*	14-47*	14-48*	14-49*	14-70*	14-70*	14-82*	14-84*	14-86*	14-112*	14-113*	14-118*	14-122*	14-123
	14-125*	14-129*	14-130	14-144*	14-145*	14-150*	14-155*	14-173*	14-174*	14-186*	14-192*	14-207*	14-213*	14-242*
	14-243*	14-251*	14-253*	14-277*	14-278*	14-291*	14-293*	14-295*	14-297*	14-299*	14-301*	14-318*	14-327*	14-337*
	14-339	14-362*	14-363	14-367*	14-546*	14-548*	14-550*	14-563*	14-564	33-228*	33-231*	33-274	33-276	33-280
	33-280	33-280	33-280	33-292	33-295	33-298	36-27#							
DPB.C	13-34*	14-83*	14-85*	14-87*	14-547*	14-549*	14-551*	14-559*	14-560	14-562*	33-229*	33-232*	33-314	33-316
	33-320	33-320	33-320	33-320	33-332	33-335	33-338	36-51#						
DPB.R	33-449	33-451	33-455	33-455	33-455	33-455	36-99#							
DPINT	34-61#	34-244	34-247	34-357	34-789	34-816	34-955	34-957*	34-:30	34-:53	34-:59	34-:69*		
DPR	4-131#													
DPROS	34-70#	34-363	34-411*	34-448*	34-628*	34-645	34-663*	34-792	34-:32	34-:55	34-:61	34-:79*		

DRIVES	12-39	37-30#													
DROP	33-18	37-37#													
DRQ	4-222#														
DRVACT	14-482*	34-30#	34-371	34-551*	34-599*	34-630*	34-643	34-662*	34-704*	34-812	34-847	34-879*	34-867*	34-907	
	34-922*	34-44*													
DRVCL	16-36	16-39	16-43	16-52	16-58	16-95	16-106	16-122	16-128	16-239	16-244	16-253	16-304	16-329	
	16-335	16-346	16-352	16-362	33-355#	33-359									
DRVCL1	14-488	33-361#	33-362												
DRVCLR	4-277#	14-475													
DRVINT	34-235	34-269#	34-359	34-944	34-958										
DRVMSK	7-0#	13-14*	13-15	13-18*	13-26										
DRVQUE	34-366	34-379	34-34#												
DRVSEL	7-0#	12-19*	12-29*	12-42	13-5	13-15	13-26*	23-6*	33-10	33-21*	33-<22*	33-<29*	33-<35*	35-46*	
DRVSTA	11-108	12-23	13-23	34-40#	34-225*	34-226*	34-227*	34-228*	34-238*	34-270*	34-280*	34-324*	34-330*	34-353	
	34-361	34-385	34-419	34-423	34-552*	34-683*	34-795	34-803	34-818	34-873*	34-880*	34-896	34-960	34-970*	
DRVSTYP	11-111	11-135	15-69	15-78	33-199	34-52#	34-271*	34-287*	34-292*	34-297*	34-302*	34-388	34-684*		
DRY	4-130#														
DSWR	4-71#	6-0	11-33												
DT00	4-213#														
DT01	4-214#														
DT02	4-215#														
DT03	4-216#														
DT04	4-217#														
DT05	4-218#														
DT06	4-219#														
DT07	4-220#														
DT08	4-221#														
DT1	8-13	41-3#													
DT10	8-82	41-8#													
DT11	8-93	41-9#													
DT12	8-107	41-10#													
DT12A	41-11#														
DT13	8-121	8-144	41-12#												
DT13A	8-130	8-153	41-13#												
DT17	8-164	8-175	41-14#												
DT2	8-24	8-57	41-4#												
DT21	8-189	41-15#													
DT21A	8-198	41-16#													
DT23	8-211	8-224	41-17#												
DT23A	41-18#														
DT3	8-35	41-5#													
DT4	8-46	41-6#													
DT41	8-257	41-19#													
DT42	8-268	41-20#													
DT43	8-281	41-21#													
DT43A	41-22#														
DT44	8-297	41-23#													
DT44A	41-24#														
DT44B	41-25#														
DT45	8-313	8-329	41-26#												
DT45A	41-27#														
DT45B	41-28#														
DT5	41-7#														
DTADPB	13-35*	14-352*	14-355	14-358*	14-360*	14-396*	14-397*	14-399*	14-406*	14-407*	14-465*	14-468	14-471*	14-473*	
	14-474	14-479*	14-480	14-486	14-528	14-528*	15-63	15-100	15-109	15-119	15-177*	15-178*	15-184	15-191	
	15-196*	15-197	15-201*	15-202	15-209	15-268	15-280	15-291	15-353	15-365	15-378	16-29*	16-30*	16-31*	
	16-32*	16-33*	16-35*	16-37*	16-42*	16-48*	16-49*	16-50*	16-51*	16-54*	16-55*	16-56*	16-57*	16-86*	

TIM.UP	7-0#	33-633	33-638*	33-653	33-736									
TIMER	14-484*	34-130#	34-451*	34-597*	34-661*	34-707*	34-836*	34-882*	34-934*	34-951*	34-975*	34-992	34-994*	34-:63*
	34-:71*	34-:78*												
TKVEC	4-71#		23-1*											
TP50	15-67*	15-72*	15-140#											
TP60	15-75*	15-80*	15-138#											
TPB	7-0#	11-45	18-1											
TPS	7-0#	11-44	18-1											
TPS50	15-68*	15-73*	15-142#											
TPS60	15-76*	15-82*	15-138#											
TPVEC	4-71#													
TRAPVE	4-71#	11-33*	11-33*											
TRCKWC	7-0#	16-32	16-55	16-296	33-148*	33-152*								
TRE	4-83#													
TRK.DS	7-0#	33-250*	33-280*	33-320*	33-366*	33-394*	33-418*	33-455*	33-577*	33-616*	33-921*	33-994*	41-10	41-11
	41-12	41-15	41-23	41-26										
TRK.RD	7-0#	33-574*	41-11											
TRNSWT	14-480*	34-79#	34-473*	34-631	34-636*	34-647	34-667*	34-678*	34-709	34-710*	34-:34	34-:46*		
TRTVEC	4-71#													
TST0	14-44#													
TST1	14-44	14-79#												
TST10	14-316	14-392#												
iST10A	14-454	14-454#												
TST10B	14-454	14-528#												
TST11	14-392	14-543#												
TST12	14-543	15-29#												
TST13	15-29	15-154#												
TST14	15-154	15-233#												
TST15	15-233	15-318#												
TST16	15-318	16-20#												
TST17	16-20	16-77#												
TST2	14-79	14-109#												
TST20	16-77	16-156#												
TST21	16-156	16-287#												
TST22	16-287	16-372#												
TST3	14-109	14-141#												
TST4	14-141	14-170#												
TST5	14-170	14-239#												
TST6	14-239	14-274#												
TST7	14-274	14-316#												
TSTNPS	7-0#	12-12	12-14	12-69	14-44	14-79	14-109	14-141	14-170	14-239	14-274	14-316	14-392	14-543
	15-29	15-154	15-233	15-318	16-20	16-77	16-156	16-287	16-372	33-131*	33-132*	33-<32*	33-<33*	33-<48*
	33-<49*	33-<55*	33-<59*	33-<63*	33-<67*	33-<71*	33-<96*	33-=30*	33-=41	33-=43				
TYPDS	19-86	26-1#												
TYPE	11-6	11-38	11-59	11-65	11-70	11-76	11-77	11-104	11-105	11-107	11-114	11-117	11-120	11-123
	11-130	11-132	11-133	11-144	11-150	12-16	12-39	12-44	12-45	12-61	12-65	12-71	13-10	13-46
	13-47	13-49	13-50	13-65	13-68	14-45	14-80	14-110	14-142	14-171	14-240	14-275	14-317	14-393
	14-544	15-30	15-155	15-234	15-319	16-21	16-78	16-157	16-288	16-373	17-1	17-1	17-1	17-1
	17-1	18-1	18-1	19-42	19-43	19-52	19-58	19-59	19-63	19-66	19-69	19-70	19-79	19-89
	19-93	19-96	19-98	19-100	19-103	20-1	21-1	22-1	23-1	23-1	23-1	23-1	23-1	23-1
	23-1	23-1	23-1	23-1	23-1	23-1	23-1	23-1	23-1	23-1	23-1	23-1	23-1	23-1
	33-15	33-16	33-18	33-19	33-20	33-692	33-693	33-695	33-699	33-702	33-703	33-707	33-708	33-737
	33-741	33-743	33-746	33-748	33-750	33-751	33-753	33-756	33-758	33-760	33-761	33-770	33-771	33-775
	33-777	33-783	33-;59	33-;85	33-;88	33-<23	33-<39	33->33	33->35	33->57	33->59	33->61	33->63	33->86
	33->87	33->88	33->90	33-?12	33-?14									
TYPERR	18-1	19-11#												
TYP0C	11-8	17-1	19-84	23-1	26-1#	33-;87	33->89	33-?15						

TYPON	26-1#													
TYPOS	11-62	11-73	11-106	12-58	13-48	14-45	14-80	14-110	14-142	14-171	14-240	14-275	14-317	14-393
	14-544	15-30	15-155	15-234	15-319	16-21	16-78	16-157	16-288	16-373	17-1	26-1#	33-17	33->34
TYPTIM	15-138	15-139	15-214	15-296	15-383	33-728#								
ULDFLG	34-106#	34-272*	34-355	34-370*	34-553*	34-629*	34-668*	34-797	34-892	34-894*	34-919	34-921*	34-:45*	
UNLOAD	4-274#													
UNSTAT	4-156#													
UNTOFF	11-104	37-20#												
UNTON	11-120	37-21#												
UPE	11-132	37-22#												
US1	4-107#													
US2	4-94#													
US4	4-95#													
VERIFY	4-96#													
VV	33-297	33-337	33-566#											
WC	4-129#													
WCE	4-166#													
WCEFLG	4-108#													
WCF	7-0#	16-220*	16-245	33-356*	33-416*									
WCHKX	4-147#													
WD	34-721	34-741												
WLE	4-164#													
WRCKD	4-153#													
WRCKHD	4-284#	16-37	16-54	16-104	16-127	16-243	16-342	16-359	33-379	33-403				
WRITE	4-285#													
WRL	4-286#	14-396	16-35	16-48	16-86	16-121	16-235	16-298	16-323	33-385				
WRT.AD	4-134#													
WRT.R1	34-:50*	34-:60*	34-:63#	41-6										
WRT.R2	34-:61#	34-:81												
WRT.R3	34-:47*	34-:80#												
WRT.R4	34-:56	34-:67	34-:70	34-:76	34-:82#									
WRT.R5	34-:72	34-:84#												
WRT.RM	34-:83	34-:85#												
	34-306	34-310	34-482	34-486	34-490	34-499	34-508	34-512	34-524	34-531	34-541	34-555	34-565	34-586
	34-603	34-624	34-826	34-857	34-902	34-:47#								
WRT.WD	34-:48*	34-:52	34-:59*	34-:62#	41-6									
WRTHD	4-287#													
XXDP	7-0#	11-50*	11-53*	11-54	11-56*	11-61	11-72	11-126	11-128	12-25	12-27			

SSCMPRE	5-219#	6-0	6-0	6-0	6-0	6-0	6-0							
SSCMTM	5-219#	6-0	6-0	6-0										
SSDESCA	4-71#													
SSNEWT	4-71#	14-44	14-79	14-109	14-141	14-170	14-239	14-274	14-316	14-392	14-543	15-29	15-154	15-233
	15-318	16-20	16-77	16-156	16-287	16-372								
SSSET	26-1	26-1	26-1	26-1	26-1	26-1	26-1	26-1	26-1	26-1	26-1	26-1#		
SSSETM	11-33	11-33#												
SSSKIP	4-71#													
.\$ACT1	4-32#	5-9												
.\$APT8	4-33#	6-0	6-0#											
.\$APTH	4-33#	5-12												
.\$APTY	4-33#	32-1												
.\$CATC	4-30#	5-1												
.\$CMTA	4-30#	5-219												
.\$DB2D	4-32#	28-1												
.\$DIV	4-31#	31-1												
.\$EOP	4-30#	17-1												
.\$ERRO	4-30#	18-1												
.\$RAND	4-32#	30-1												
.\$RDE	4-31#													
.\$RDOC	4-31#													
.\$READ	4-31#	23-1												
.\$SAVE	4-32#	25-1												
.\$SB2D	4-32#	27-1												
.\$SCOP	4-32#	24-1												
.\$SIZE	4-32#													
.\$SUPR	4-32#	29-1												
.\$TRAP	4-30#	26-1												
.\$TYPD	4-31#	22-1												
.\$TYPE	4-30#	20-1												
.\$TYPO	4-31#	21-1												
.\$EQUAT	4-30#	4-71												
.\$HEADE	4-31#	4-37												
.\$SETUP	4-31#	4-298												
.\$SWRHI	4-30#	4-38												
.\$SWRLO	4-38#	4-39	4-40	4-41	4-42	4-43	4-44	4-45	4-46					
CKCHR	10-409#	33-;91	33-<26	33->66	33->93	33-?18	33-?79	33-?86	33-?91	33-A36				
CKDIG	10-419#	33-<28	33->80											
CKNUM	10-429#	33-;93	33-?02	33-?20										
COMPEN	4-71#													
COMIND	10-346#	13-44	14-46	14-319	14-395	15-60	15-175	15-254	15-339	16-380	16-385			
DO	10-355#	13-43	13-45	14-70	14-70	14-94	14-95	14-121	14-128	14-152	14-156	14-187	14-193	14-208
	14-214	14-252	14-254	14-292	14-294	14-296	14-298	14-300	14-302	14-341	14-361	14-557	14-558	15-60
	15-175	15-254	15-339	16-381	16-386	33-583								
DODTA	10-370#	16-36	16-39	16-43	16-52	16-58	16-95	16-106	16-122	16-128	16-239	16-244	16-253	16-304
	16-329	16-335	16-346	16-352	16-362									
ENDCOM	4-71#													
ENDPAS	16-391#	17-1												
ER.NDX	10-374#	33-250	33-280	33-320	33-366	33-394	33-418	33-455	33-616					
ERRCAL	33-A49#	34-772	34-830	34-832	34-;18	34-;77								
ERREND	10-402#	18-1												
ERROR	4-71#	13-25	14-454	14-528	15-101	15-110	15-120	15-192	15-210	15-269	15-281	15-292	15-354	15-366
	15-379	24-1	33-250	33-250	33-250	33-250	33-256	33-280	33-280	33-280	33-280	33-288	33-320	33-320
	33-320	33-320	33-328	33-366	33-366	33-366	33-366	33-374	33-394	33-394	33-394	33-394	33-402	33-418
	33-418	33-418	33-418	33-426	33-455	33-455	33-455	33-455	33-581	33-616	33-616	33-616	33-616	33-616
	33-923	33-928	33-998	33-:04	33-:62	33-:63	35-43							

