

B01

REV 1

IDENTIFICATION

PRODUCT CODE:    MAINDEC-11-DZKGA-B-D  
PRODUCT NAME:    KG11A - CYCLIC REDUNDANCY CHECK TEST  
DATE RELEASED:    MARCH, 1977  
MAINTAINER:        DIAGNOSTIC GROUP  
NOTE: REV. A OF THIS PROGRAM OBSOLETE MD-11-DBK

COPYRIGHT 1971, 1977 BY DIGITAL EQUIPMENT CORPORATION  
THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT  
NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL  
EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES  
NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS  
DOCUMENT.

THE SOFTWARE DESCRIBED IN THIS DOCUMENT IS FURNISHED UNDER A  
LICENSE AND MAY ONLY BE USED OR COPIED IN ACCORDANCE WITH  
THE TERMS OF SUCH LICENSE.

DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY  
FOR THE USE OR RELIABILITY OF ITS SOFTWARE ON EQUIPMENT  
THAT IS NOT SUPPLIED BY DIGITAL.

CONTENTS

ABSTRACT	PG. 3
REQUIREMENTS	PG. 3
LOADING--STORAGE	PG. 3
OPERATION	PG. 3
SWITCH REGISTER	PG. 4
NOTES	PG. 4
FULL TEST MODE	PG. 5
SELECT TEST MODE	PG. 6
ERRORS	PG. 8
SCOPE LOOP	PG. 9
FORCED ERROR TYPEOUT	PG. 10
INSTRUCTION TABLE	PG. 13
DATA WORD TABLE	PG. 16
TESTA	PG. 23
TESTB	PG. 24

ABSTRACT.

THIS PROGRAM TESTS THE LOGIC OF THE CYCLIC REDUNDANCY CHECK DEVICE (KG11A).

REQUIREMENTS.

A STANDARD PDP-11 (WITH OR WITHOUT A HARDWARE SWITCH REGISTER) AND A KG11

LOADING--STORAGE.

LOADING PROCEDURE FOR NORMAL BINARY TAPES SHOULD BE FOLLOWED.

DEVICE ADDRESS CHANGE.

\*\*\*\*\*

TO CHANGE THE DEVICE ADDRESS (WHICH WAS LOADED AS 170700), CHANGE THE CONTENTS OF THE LOCATION "DEVADR" SHOWN ON PAGE 24/ SET THIS LOCATION TO THE ADDRESS OF THE CSR DESIRED, THEN START (OR RESTART) AS GIVEN IN OPERATION BELOW.

OPERATION.

1. THIS PROGRAM MAY BE OPERATED IN TWO MODES.
  - A. FULL TEST MODE.  
THIS IS THE MAIN BODY OF THE PROGRAM AND SHOULD BE USED TO ACCEPT OR DIAGNOSE A DEVICE.  
TO RUN: START AT LOC. 200 WITH SWR15 SET.  
(DETAIL ON PAGE 5.)
  - B. SELECT TEST MODE  
THIS IS A SUBPROGRAM TO ALLOW THE OPERATOR TO RUN A SELECT INSTRUCTION ON A SELECT DATA WORD.  
TO RUN: START AT LOC. 204 WITH SWR15 SET.  
SELECT INSTRUCTION ON SWR5-0.  
SELECT DATA WORD ON SWR11-6.  
(DETAIL ON PAGE 6.)

SWITCH REGISTER.

IF THE DIAGNOSTIC IS RUN ON A CPU WITHOUT A SWITCH REGISTER THEN A SOFTWARE SWITCH REGISTER IS USED WHICH ALLOWS THE USER THE SAME SWITCH OPTIONS AS THE HARDWARE SWITCH REGISTER. IF THE HARDWARE SWITCH REGISTER DOES NOT EXIST OR IF ONE DOES AND IT CONTAINS ALL ONES (177777) THEN THE SOFTWARE SWITCH REGISTER (LOC. 176) IS USED.

## CONTROL:

THIS PROGRAM ALSO SUPPORTS THE DYNAMIC LOADING OF THE SOFTWARE SWITCH REGISTER (LOC. 176) FROM THE TTY. THIS CAN BE ACCOMPLISHED BY DOING THE FOLLOWING:

- 1) TYPE CONTROL G (<G>); THIS WILL ALLOW THE TTY TO ENTER DATA INTO LOC. 176 AT SELECTED POINTS WITHIN THE PROGRAM.
- 2) THE MACHINE WILL THEN TYPE: SWR=XXXXXXNEW= (XXXXXX IS THE OCTAL CONTENTS OF THE SOFTWARE SWITCH REGISTER.)
- 3) AFTER THE 'NEW=' HAS BEEN TYPED THEN THE OPERATOR CAN DO ONE OF THE FOLLOWING AT THE TTY:
  - A) TYPE A NUMBER TO BE LOADED INTO LOC. 176 FOLLOWED BY A <CR>. (ONLY NUMBERS BETWEEN 0-7 WILL BE ACCEPTED AND ONLY 6 NUMBERS WILL BE ALLOWED) IF A <CR> IS THE FIRST KEY DEPRESSED THE SOFTWARE SWITCH REGISTER CONTENTS WILL NOT BE CHANGED.
  - B) IF A CONTROL U (<U>) IS DEPRESSED THEN THE PROGRAM WILL SEND YOU BACK TO STEP 2.

1. SWR15 SET, HALT ON ERROR.  
RESÉT, BYPASS ERROR.
2. SWR14 SET, SCOPE LOOP ON ERROR.  
RESÉT, BYPASS ERROR.
3. SWR13 SET, INHIBIT PRINTOUTS DURING SCOPE LOOP.  
RESÉT, ALLOW PRINTOUTS DURING SCOPE LOOP.
4. SWR12 SET, INHIBIT TRACE TRAPPING.  
RESÉT, ALLOW TRACE TRAPPING.
5. SWR11 SET, INHIBIT ITERATIONS.  
RESÉT, ALLOW ITERATIONS.
6. SWR11 - SWR6 AND SWR5 - SWR0 ARE DEFINED IN THE SELECT TEST MODE SECTION ON PG. 6 & 7.

FULL TEST MODE.

1. START OR RESTART.
  - A. ZERO THE SWR
  - B. LOAD 200 AND START
2. PROGRAM ACTION.
  - A. WHENEVER THE PROGRAM IS STARTED, OR RESTARTED, THE TTY WILL TYPE: KG11A.
  - B. IF THE SOFTWARE SWITCH REGISTER IS SELECTED THEN THE FOLLOWING WILL BE TYPED:  
SWR=XXXXXX NEW=(REFER TO SWITCH REGISTER SECTION FOR OPERATOR ACTIONS)
  - C. IF THERE ARE NO ERRORS DETECTED, THE PROGRAM WILL LOOP INDEFINITELY AND WILL RING THE TTY BELL ONCE FOR EACH PASS. TRACE TRAP IS EFFECTIVE AND EACH SUBTEST IS BEING ITERATED 100 TIMES.
  - D. IF AN ERROR OCCURS, A ONE LINE ERROR MESSAGE WILL BE TYPED ON THE TTY AND THE PROGRAM WILL HALT. (SEE THE ERROR SECTION ON PAGE 8.)
3. OPERATER CONTROL VIA THE SWR.

(REFER TO SECTION ON SWITCH REGISTER SETTINGS FOR SOFTWARE SWITCH REGISTER.)

  - A. SWR15 SET. (NORMAL)  
HALT ON ERROR AFTER ERROR MESSAGE IS TYPED.  
  
SWR15 RESET.  
TYPE THE ERROR MESSAGE AND CONTINUE TO THE NEXT ITERATION OF THE CURRENT TEST OR TO THE NEXT SUBTEST.
  - B. SWR12 SET.  
INHIBIT TRACE TRAP.  
  
SWR12 RESET (NORMAL)  
ALLOW TRACE TRAP.
  - C. SWR11 SET.  
INHIBIT ITERATIONS  
  
SWR11 RESET (NORMAL)  
ALLOW ITERATIONS

SELECT TEST MODE.

1. START OR RESTART.
  - A. RESET SWR15 THRU SWR0.
  - B. LOAD ADDRESS 204
  - C. SELECT THE INSTRUCTION TO BE TESTED FROM THE LIST OF INSTRUCTIONS ON PAGE NN OF THE PROGRAM LISTING. SET SWR5 THRU SWR0 TO THE "I" NUMBER GIVEN WITH SAID INSTRUCTION.
  - D. SELECT THE DATA WORD TO BE TESTED FROM THE LIST OF DATA WORDS GIVEN ON PAGES NN AND NN OF THE PROGRAM LISTING. SET SWR11 THRU SWR6 TO THE "D" NUMBER GIVEN WITH THE SAID DATA WORD.
  - E. START.
  - F. \*\*\*\*REFER TO SECTION ON SWITCH SETTINGS FOR SOFTWARE SWITCH REGISTER ACTION.

SPECIAL NOTES ON C. AND D. ABOVE.

1. THE SELECTED INSTRUCTION AND/OR THE SELECTED DATA MAY BE CHANGED WHILE THE PROGRAM IS RUNNING.
2. IF SWR11 THRU SWR6 ARE ALL RESET, THEN THE SELECTED INSTRUCTION WILL RUN ON ALL DATA WORDS.
3. IF SWR5 THRU SWR0 ARE ALL RESET THEN ALL INSTRUCTIONS WILL BE RUN ON THE SELECTED DATA WORD.
4. IF SWR11 THRU SWR6 AND SWR5 THRU SWR0 ARE ALL RESET, THEN ALL INSTRUCTIONS WILL BE RUN ON ALL DATA WORDS.

## 2. PROGRAM ACTION

- A. IF THERE ARE NO ERRORS THE PROGRAM WILL LOOP THE SELECTED INSTRUCTION (SWR5-0) USING THE SELECTED DATA (SWR11-6). TRACE TRAP IS EFFECTIVE.
- B. IF AN ERROR OCCURS, A ONE LINE ERROR MESSAGE WILL BE TYPED ON THE TTY AND THE PROGRAM WILL HALT. (SEE THE ERROR SECTION ON PAGE 8.)

(REFER TO SWITCH SETTING SECTION FOR USE OF SOFTWARE SWITCH REGISTER)

## 3. OPERATER CONTROL VIA THE SWR.

(REFER TO SECTION ON SWITCH SETTING'S FOR SOFTWARE SWITCH REGISTER DYNAMIC CHANGING.)

- A. SWR15 SET. (NORMAL)  
HALT ON ERROR AFTER ERROR MESSAGE IS TYPED.
- SWR15 RESET.  
TYPE THE ERROR MESSAGE AND CONTINUE TESTING THE SELECTED INSTRUCTION (SWR5-0) USING THE SELECTED DATA (SWR11-6)
- B. SWR12 SET.  
INHIBIT TRACE TRAP.
- SWR12 RESET. (NORMAL)  
ALLOW TRACE TRAP.
- C. SWR11 THRU SWR6.  
SELECTED DATA WORD.
- D. SWR5 THRU SWR0.  
SELECTED INSTRUCTION.

ERRORS

1. ERROR MESSAGE

\*\*\*ROUTINE CHECKS FOR THE DYNAMIC CHANGING OF THE SOFTWARE SWITCH REGISTER REFER TO SWITCH SETTING SECTION FOR OPERATOR ACTION.  
TESTX IXX DXX SXXXXXX HXXXXXX

TESTX (X = A OR B)  
THIS IS THE NAME (TAG) OF THE TEST THAT WAS IN USE AT THE TIME OF THE ERROR.  
TESTA IS ON PAGE 27 OF THE PROG. LIST.  
TESTB IS ON PAGE 28 OF THE PROG. LIST.

IXX (XX = A NUMBER FROM 01 THRU 57)  
THIS IS THE NAME/NUMBER (TAG) OF THE INSTRUCTION IN USE AT THE TIME OF THE ERROR.  
R1 (INST. POINTER) POINTS AT THIS INSTRUCTION.  
THE INSTRUCTION TABLE IS ON PAGE 18 OF THE PROG. LIST.

DXX (XX = A NUMBER FROM 01 THRU 77)  
THIS IS THE NAME/NUMBER (TAG) OF THE DATA WORD IN USE AT THE TIME OF THE ERROR.  
R2 (DATA WORD POINTER) POINTS AT THIS DATA WORD.  
THE DATA WORD TABLE IS ON PG. 20 OF THE PROG. LIST.

SXXXXXX (XXXXXX = ANY 6 DIGIT, 16 BIT, OCTAL NUMBER)  
THIS IS THE SIMULATED (GOOD) BCC WORD.

HXXXXXX (XXXXXX = ANY 6 DIGIT, 16 BIT, OCTAL NUMBER)  
THIS IS THE HARDWARE (BAD) BCC WORD.

DONE BIT: S\ S (EACH X CAN =0 OR 1)  
THIS IS THE STATUS OF THE DONE BIT (BIT 7 OF THE CSR).  
THE FIRST NUMBER (X\ ) IS WHAT THE DONE BIT SHOULD BE (GOOD). THE SECOND NUMBER (\X) IS WHAT THE DONE BIT ACTUALLY WAS.

2. OPTIONS AFTER A HALT ON ERROR.

\*\*\*IF THE SOFTWARE SWITCH REGISTER IS USED THEN THE OPERATOR CAN CHANGE THE SWREG LOCATION BY TYPING A 1G AND THEN CONTINUING.\*\*\*  
A. SCOPE LOOP. SEE SCOPE LOOP SECTION.

B. BYPASS THIS ERROR AND CONTINUE TO THE NEXT ITERATION OR SUBTEST.

1. RESET SWR14 AND SWR15.
2. CONTINUE.

C. UTILIZE SELECT TEST MODE (PAGE 6)



SCOPE LOOP

\*\*\*ROUTINE CHECKS FOR 1G FUNCTION.\*\*\*

1. SET UP.

- A. SET SWR14.
- B. RESET SWR15.
- C. CONTINUE.

2. PROGRAM ACTION.

THE PROGRAM WILL SCOPE LOOP ON THE FAILING TEST FOR AS LONG AS SWR14 IS SET, AND SWR15 IS RESET.

3. OPERATOR CONTROL VIA THE SWR.

- A. SWR13 SET.  
INHIBIT ERROR TYPEOUTS.

SWR13 RESET.  
ALLOW ERROR TYPEOUTS.

- B. SWR12 SET.  
INHIBIT TRACE TRAPS.

SWR12 RESET.  
ALLOW TRACE TRAPS.

FORCED ERROR TYPEOUT.  
-----

IN THE EVENT OF AN UNEXPECTED OR ILLEGAL TRAP, OR AT ANY TIME THE OPERATOR DEEMS IT USEFUL, THE PROGRAM CAN BE HALTED (IF IT HASN'T ALREADY) AND A TYPEOUT CAN BE OBTAINED AS TO THE STATUS OF THE PROGRAM.

THIS TYPEOUT IS THE SAME ONE USED IN THE EVENT OF AN ACTUAL ERROR. (SEE ERROR MESSAGE ON PG. 8.)

1. HALT THE PROGRAM
2. START AT LOC. 210. (SWR SETTINGS ARE IMMATERIAL.)

THE TYPEOUT WILL BE MADE AND THE PROGRAM WILL HALT. THE PROGRAM CAN NOW BE RESTARTED. (SEE OPERATION, PG. 3.)

%

415  
416  
417  
418  
419  
420  
421  
422  
423  
424  
425  
426  
427  
428  
429  
430  
431  
432  
433  
434  
435  
436  
437  
438  
439  
440  
441  
442  
443  
444  
445  
446  
447  
448  
449  
450  
451  
452  
453  
454  
455  
456  
457  
458  
459  
460  
461  
462  
463  
464  
465  
466  
467  
468  
469  
470  
471  
472  
473  
474  
475  
476  
477  
478  
479  
480  
481  
482  
483  
484  
485  
486  
487  
488  
489  
490  
491  
492  
493  
494  
495  
496  
497  
498  
499  
500

:KG11A CYCLIC REDUNDANCY CHECK DEVICE TEST.  
:COPYRIGHT 1976,1977 DIGITAL EQUIPMENT CORP., MAYNARD, MASS. 01754.

:PROGRAM OBSOLETES MD-11-D8K  
:RELEASED 21 MAY 76 BY SAM CARPENTER  
:SUPPORTS THE SOFTWARE SWITCH REGISTER LOC.176  
:ALSO SUPPORTS THE DYNAMIC LOADING OF LOC. 176  
:REVISED TO MEET ALL ACT11 SPEC.S; REV. B RELEASED FEB. 1977

;TRAP CATCHER (LOC. 0 TO LOC. 776)\*\*\*\*\*

000030	.REPT 30 .+2 HALT .ENDR	;TRAPPED TO PREVIOUS ADDRESS.
000030	.REPT 30 .+2 HALT .ENDR	;TRAPPED TO PREVIOUS ADDRESS.
000030	.REPT 30 .+2 HALT .ENDR	;TRAPPED TO PREVIOUS ADDRESS.
000030	.REPT 30 .+2 HALT .ENDR	;TRAPPED TO PREVIOUS ADDRESS.
000030	.REPT 30 .+2 HALT .ENDR	;TRAPPED TO PREVIOUS ADDRESS.
000030	.REPT 30 .+2 HALT .ENDR	;TRAPPED TO PREVIOUS ADDRESS.
000010	.REPT 10 .+2 HALT .ENDR	;TRAPPED TO PREVIOUS ADDRESS.

```

458
459          000014      004042      . =14
460          000014      004042      TRTRTN
461          000016      000340      340
462          000030      000030      . =30
463          000030      003154      ERR
464          000032      000340      340
465          000034      000034      . =34
466          000034      004030      SCORCD
467          000036      000340      340
468          000046      000046      . =46
469          000046      002406      $ENDAD
470          000052      000052      . =52
471          000052      000000      000000
472
473          ;;SOFTWARE SWITCH REGISTER*****
474
475          000176      000176      . =176
476          000176      000000      SWREG: 0          ;SOFTWARE SWITCH REGISTER
477
478          ;;PROGRAM STARTS*****
479
480          000200      000200      . =200
481          000200      000167      001456      NORMAL: JMP      IDENT
482          000204      000204      . =204
483          000204      000167      001606      SELECT: JMP      INTA
484          000210      000210      . =210
485          000210      000167      003122      FORERR: JMP      FORCER
486

```

		; INSTRUCTION TABLE	
487			
488		001000	
489	001000	000402	101: ;LRC8 1 STEP.
490	001002	004104	
491	001004	001002	102: ;LRC8 2 STEPS.
492	001006	004104	
493	001010	001402	103: ;LRC8 3 STEPS.
494	001012	004104	
495	001014	002002	104: ;LRC8 4 STEPS.
496	001016	004104	
497	001020	002402	105: ;LRC8 5 STEPS.
498	001022	004104	
499	001024	003002	106: ;LRC8 6 STEPS.
500	001026	004104	
501	001030	003402	107: ;LRC8 7 STEPS.
502	001032	004104	
503	001034	004002	110: ;LRC8 10 STEPS.
504	001036	004104	
505	001040	000403	111: ;LRC16 1 STEP.
506	001042	004060	
507	001044	001003	112: ;LRC16 2 STEPS.
508	001046	004060	
509	001050	001403	113: ;LRC16 3 STEPS.
510	001052	004060	
511	001054	002003	114: ;LRC16 4 STEPS.
512	001056	004060	
513	001060	002403	115: ;LRC16 5 STEPS.
514	001062	004060	
515	001064	003003	116: ;LRC16 6 STEPS.
516	001066	004060	
517	001070	003403	117: ;LRC16 7 STEPS.
518	001072	004060	
519	001074	004003	120: ;LRC16 10 STEPS.
520	001076	004060	
521	001100	000401	121: ;CRC16 1 STEP.
522	001102	004214	
523	001104	001001	122: ;CRC16 2 STEPS.
524	001106	004214	
525	001110	001401	123: ;CRC16 3 STEPS.
526	001112	004214	
527	001114	002001	124: ;CRC16 4 STEPS.
528	001116	004214	
529	001120	002401	125: ;CRC16 5 STEPS.
530	001122	004214	
531	001124	003001	126: ;CRC16 6 STEPS.
532	001126	004214	
533	001130	003401	127: ;CRC16 7 STEPS.
534	001132	004214	
535	001134	004001	130: ;CRC16 10 STEPS.
536	001136	004214	
537	001140	000405	131: ;CCITT 1 STEP.
538	001142	004352	
539	001144	001005	132: ;CCITT 2 STEPS.
540	001146	004352	

541	001150	001405	I33:	001405	;CCITT 3 STEPS.
542	001152	004352		SMCITC	
543	001154	002005	I34:	002005	;CCITT 4 STEPS.
544	001156	004352		SMCITC	
545	001160	002405	I35:	002405	;CCITT 5 STEPS.
546	001162	004352		SMCITC	
547	001164	003005	I36:	003005	;CCITT 6 STEPS.
548	001166	004352		SMCITC	
549	001170	003405	I37:	003405	;CCITT 7 STEPS.
550	001172	004352		SMCITC	
551	001174	004005	I40:	004005	;CCITT 10 STEPS.
552	001176	004352		SMCITC	
553	001200	000400	I41:	000400	;CRC12 1 STEP.
554	001202	004502		SMC12B	
555	001204	001000	I42:	001000	;CRC12 2 STEPS.
556	001206	004502		SMC12B	
557	001210	001400	I43:	001400	;CRC12 3 STEPS.
558	001212	004502		SMC12B	
559	001214	002000	I44:	002000	;CRC12 4 STEPS.
560	001216	004502		SMC12B	
561	001220	002400	I45:	002400	;CRC12 5 STEPS.
562	001222	004502		SMC12B	
563	001224	003000	I46:	003000	;CRC12 6 STEPS.
564	001226	004502		SMC12B	
565	001230	000102	I47:	000102	;LRCB ONE BYTE DATA.
566	001232	004076		SMLRCE	
567	001234	000112	I50:	000112	;LRCB TWO BYTE DATA.
568	001236	004076		SMLRCD	
569	001240	000103	I51:	000103	;LRC16 ONE BYTE DATA.
570	001242	004052		SMLRCB	
571	001244	000113	I52:	000113	;LRC16 TWO BYTE DATA.
572	001246	004044		SMLRCA	
573	001250	000101	I53:	000101	;CRC16 ONE BYTE DATA.
574	001252	004206		SMC16B	
575	001254	000111	I54:	000111	;CRC16 TWO BYTE DATA.
576	001256	004200		SMC16A	
577	001260	000105	I55:	000105	;CCITT ONE BYTE DATA.
578	001262	004344		SMCITB	
579	001264	000115	I56:	000115	;CCITT TWO BYTE DATA
580	001266	004336		SMCITA	
581	001270	000100	I57:	000100	;CRC12 ONE BYTE DATA.
582	001272	004474		SMC12A	
583	001274	000102	I60:	000102	;RESERVED.
584	001276	004076		SMLRCE	
585	001300	000102	I61:	000102	;RESERVED.
586	001302	004076		SMLRCE	
587	001304	000102	I62:	000102	;RESERVED.
588	001306	004076		SMLRCE	
589	001310	000102	I63:	000102	;RESERVED.
590	001312	004076		SMLRCE	
591	001314	000102	I64:	000102	;RESERVED.
592	001316	004076		SMLRCE	
593	001320	000102	I65:	000102	;RESERVED
594	001322	004076		SMLRCE	

596	001324	000102	166:	000102	: RESERVED
597	001326	004076		SMLRCE	
598	001330	000102	167:	000102	: RESERVED
599	001332	004076		SMLRCE	
600	001334	000102	170:	000102	: RESERVED
601	001336	004076		SMLRCE	
602	001340	000102	171:	000102	: RESERVED
603	001342	004076		SMLRCE	
604	001344	000102	172:	000102	: RESERVED
605	001346	004076		SMLRCE	
606	001350	000102	173:	000102	: RESERVED
607	001352	004076		SMLRCE	
608	001354	000102	174:	000102	: RESERVED
609	001356	004076		SMLRCE	
610	001360	000102	175:	000102	: RESERVED
611	001362	004076		SMLRCE	
612	001364	000102	176:	000102	: RESERVED
613	001366	004076		SMLRCE	
614	001370	000102	177:	000102	: RESERVED
615	001372	004076		SMLRCE	
616					

			:DATA WORD TABLE
617			
618			
619	001374	000001	001: 000001
620	001376	000002	002: 000002
621	001400	000004	003: 000004
622	001402	000010	004: 000010
623	001404	000020	005: 000020
624	001406	000040	006: 000040
625	001410	000100	007: 000100
626	001412	000200	010: 000200
627	001414	000400	011: 000400
628	001416	001000	012: 001000
629	001420	002000	013: 002000
630	001422	004000	014: 004000
631	001424	010000	015: 010000
632	001426	020000	016: 020000
633	001430	040000	017: 040000
634	001432	100000	020: 100000
635	001434	177776	021: 177776
636	001436	177775	022: 177775
637	001440	177773	023: 177773
639	001442	177767	024: 177767
639	001444	177757	025: 177757
640	001446	177737	026: 177737
641	001450	177677	027: 177677
642	001452	177577	030: 177577
643	001454	177377	031: 177377
644	001456	176777	032: 176777
645	001460	175777	033: 175777
646	001462	173777	034: 173777
647	001464	167777	035: 167777
648	001466	157777	036: 157777
649	001470	137777	037: 137777
650	001472	077777	040: 077777



651	001474	052525	D41:	052525
652	001476	125252	D42:	125252
653	001500	031463	D43:	031463
654	001502	146314	D44:	146314
655	001504	070707	D45:	070707
656	001506	107070	D46:	107070
657	001510	007417	D47:	007417
658	001512	170360	D50:	170360
659	001514	041045	D51:	041045
660	001516	136732	D52:	136732
661	001520	154321	D53:	154321
662	001522	023456	D54:	023456
663	001524	133333	D55:	133333
664	001526	044444	D56:	044444
665	001530	000000	D57:	000000
666	001532	177777	D60:	177777
667	001534	000000	D61:	000000
668	001536	111111	D62:	111111
669	001540	022222	D63:	022222
670	001542	133333	D64:	133333
671	001544	044444	D65:	044444
672	001546	155555	D66:	155555
673	001550	066666	D67:	066666
674	001552	177777	D70:	177777
675	001554	101010	D71:	101010
676	001556	111111	D72:	111111
677	001560	121212	D73:	121212
678	001562	131313	D74:	131313
679	001564	141414	D75:	141414
680	001566	151515	D76:	151515
681	001570	161616	D77:	161616

682  
 683  
 684  
 685  
 686  
 687  
 688  
 689  
 690  
 691  
 692  
 693  
 694  
 695  
 696  
 697  
 698  
 699  
 700  
 701  
 702  
 703  
 704  
 705  
 706  
 707  
 708  
 709  
 710  
 711  
 712  
 713  
 714  
 715  
 716  
 717  
 718  
 719  
 720  
 721  
 722  
 723  
 724  
 725  
 726  
 727  
 728  
 729  
 730  
 731  
 732  
 733  
 734

000000  
 000001  
 000002  
 000003  
 000004  
 000005  
 000006  
 000007  
 000007  
 001572 177570  
 177776  
 104400  
 104000  
 000240  
 177560  
 177562  
 177564  
 177566  
 001000  
 001270  
 001374  
 001570  
 001574 170700  
 001576 000000  
 001600 000000  
 001602 000000  
 001604 000000  
 001606 000000  
 001610 000000  
 001612 000000  
 001614 000000  
 001616 000100  
 001620 000000  
 001622 000000  
 001624 000000  
 001626 000000  
 001630 000000  
 001632 000000  
 001634 000000  
 001636 000000  
 001640 000000  
 001642 000000  
 001644 000000  
 001646 000000  
 001650 000000  
 001652 000000  
 001654 000000  
 001656 000000  
 001660 000000

; EQUATES, CONSTANTS AND VARIABLES

R0=%0 ; WORK  
 R1=%1 ; INSTRUCTION POINTER.  
 R2=%2 ; DATA POINTER.  
 R3=%3 ; DEVICE ADDRESS POINTER (BCC).  
 R4=%4 ; WORK  
 R5=%5 ; SUBROUTINES.  
 SP=%6 ; STACK POINTER  
 PC=%7 ; PC  
 R7=PC  
 SWR: 177570 ; SWITCH REGISTER.  
 PS=177776 ; PROCESSOR STATUS  
 SCOPE=TRAP  
 HLT=EMT  
 NOP=240  
 TKCSR= 177560 ; TTY KEYBOARD STATUS  
 TKOBR= 177562 ; TTY KEYBOARD BUFFER  
 TPCSR= 177564 ; PRINTER STATUS  
 TPDBR= 177566 ; PRINTER BUFFER  
 INTBEG=101  
 INTEND=157  
 DATBEG=001  
 DATEND=077  
 DEVADR: 170700  
 DFLG: 0  
 DFLGA: 0  
 EFLG: 0  
 HBCC: 0  
 HDONE: 0  
 IFLG: 0  
 IFLGA: 0  
 ITACNT: 0  
 ITANO: 100  
 OPSTAT: 0  
 OTACNT: 0  
 OTAWKA: 0  
 OTAWKB: 0  
 SELFLG: 0  
 SCORTN: 0  
 SMBCC: 0  
 SMBCCA: 0  
 SMCNT: 0  
 SMDATA: 0  
 SMDONE: 0  
 SMWKA: 0  
 SMWKB: 0  
 STCNT: 0  
 TEWK: 0  
 FTITLE: 0 ; TITLE PRINTED = 1  
 PASCNT: 0

```

735
736                                     ;; INIALIZATION
737
738 001662 000005          IDENT: RESET
739 001664 012706 001000  MOV      #1000,SP          ;SET SP TO 1000.
740 001670 023737 000042 000046  CMP      @#42,@#46      ;IN ACT11 AUTOMATIC MODE?
741 001676 001444          BEQ      INIT          ;YES, SKIP TITLE
742 001700 005767 177752  TST      FTITLE       ;HAS TITLE BEEN PRINTED BEFORE?
743 001704 001041          BNE      INIT          ;YES, SKIP TITLE
744 001706 004567 001746  JSR      R5,TYPE       ;TYPE THE PROG. NAME.
745 001712 077536 043513 030461  .ASCII  /+/(177)/KG11A - CYCLIC REDUNDANCY CHECK TEST, MD-11-DZKGA-B/(177)/+//
746 001720 020101 020055 054503
747 001726 046103 041511 051040
748 001734 042105 047125 040504
749 001742 041516 020131 044103
750 001750 041505 020113 02524
751 001756 052123 020054 042115
752 001764 030455 026461 055104
753 001772 043513 026501 077502
754 002000 057536
755
756 002002 012767 000001 177646  .EVEN
757 002010 005067 177614  INIT:  MOV      #1,FTITLE   ;SET FLAG
758 002014 000402          CLR      SELFLG      ;CLEAR SELFLG (START WAS FROM LOC. 200.)
759 002016 005267 177606  BR      INTB         ;BRANCH.
760 002022 000005          INTA:  INC      SELFLG   ;SET SELFLG (START WAS FROM LOC. 204.)
761 002024 005067 177552  INTB:  RESET
762 002030 012706 001000  CLR      EFLG
763 002034 023737 000042 000046  MOV      #1000,SP
764 002042 001402          CMP      @#42,@#46   ;ARE WE IN ACT11 AUTOMATIC MODE?
765 002044 004767 002600  BEQ      ,+6         ;YES, NEVER MIND ABOUT SWR
766 002050 016703 177520  JSR      PC,SUSWR    ;CHECK FOR HARDWARE SWITCH REGISTER
767 002054 005723          MOV      DEVAR,R3   ;R3 + DEVICE ADDRESS.
768 002056 004567 000012  TST      (R3)+       ;ADJUST R3 TO POINT AT BCC.
769 002062 005767 177542  JSR      R5,OPCHG   ;READ SWR & SET UP PROG. ACCORDINGLY.
770 002066 001434          TST      SELFLG     ;WAS START FROM LOC. 200?
771 002070 000167 000324  BEQ      FULMOD     ;YES - BRANCH.
772                                     JMP      SELMOD     ;NO. - JUMP.
773
774 002074 017767 177472 177516  OPCHG: MOV      @SWR,OPSTAT ;STORE SWR.
775 002102 052767 000020 175666  BIS      #20,PS      ;SET "T" BIT IN PS.
776 002110 032767 010000 177502  BIT      #10000,OPSTAT ;INHIBIT TRACE TRAP?
777 002116 001403          BEQ      OPCA       ;NO. - BRANCH
778 002120 042767 000020 175650  BIC      #20,PS     ;YES. - CLEAR "T" BIT IN PS.
779 002126 005767 177476  OPCA:  TST      SELFLG ;SELECT MODE (START WAS FROM 202)?
780 002132 001011          BNE      OPCB       ;YES. - BRANCH.
781 002134 016767 177456 177452  MOV      ITANO,ITACNT ;NO. - SET ITERATE CNT. TO ITERATE NO.
782 002142 032767 004000 177450  BIT      #4000,OPSTAT ;INHIBIT ITERATIONS?
783 002150 001402          BEQ      OPCB       ;NO. - BRANCH.
784 002152 005067 177436  CLR      ITACNT     ;YES. - CLEAR ITERATE COUNTER
785 002156 000205          OPCB:  RTS      R5   ;RETURN.

```

786  
787  
788  
789  
790  
791  
792  
793  
794  
795  
796  
797  
798  
799  
800  
801  
802  
803  
804  
805  
806  
807  
808  
809  
810  
811  
812  
813  
814  
815  
816  
817  
818  
819  
820  
821  
822  
823  
824  
825  
826  
827  
828  
829  
830  
831  
832  
833  
834  
835  
836  
837  
838  
839  
840  
841

002160 012701 001000  
002164 012702 001374  
002170 116167 000001 177442  
002176 004767 002542  
002202 005067 177426  
002206 052767 000200 177430  
002214 004571 000002  
002220 105761 000001  
002224 001413  
002226 031127 004000  
002232 001005  
002234 021167 176764  
002240 001402  
002242 005067 177376  
002246 004567 000476  
002252 000402  
002254 004567 000606  
002260 027767 177306 177332  
002266 001403  
002270 004567 177600  
002274 000731  
002276 032767 004000 177314  
002304 001011  
002306 005767 177346  
002312 001406  
002314 005367 177274  
002320 001337  
002322 016767 177270 177264  
002330 020227 001570  
002334 001403  
002336 062702 000002  
002342 000712  
002344 020127 001270  
002350 001403  
002352 062701 000004  
002356 000702  
002360 004567 001274  
002364 025007  
002366 005015  
002370 057400  
002372 005267 177262  
002376 013700 000042  
002402 001405  
002404 000005  
002406 004710  
002410 000240  
002412 000240  
002414 000240  
002416 000660

;FULL TEST MODE. CONTROL THE TESTING OF ALL KG11 INSTRUCTIONS  
;IN THE INSTRUCTION TABLE USING ALL DATA WORDS IN THE DATA  
;WORD TABLE WITH EACH INSTRUCTION.

FULMOD: MOV #INTBEG,R1  
FULA: MOV #DATBEG,R2  
FULB: MOVB +1(R1),SMCNT  
JSR PC,CKSWR  
CLR SMBC  
BIS #200,SMDONE  
JSR R5,@+2(R1)  
FULC: TSTB +1(R1)  
FULE: BEQ  
BIT (R1),#4000  
BNE FULD  
CMP (R1),I46  
BEQ FULD  
CLR SMDONE  
FULD: JSR R5,TESTA  
BR FULF  
FULG: JSR R5,TESTB  
FULF: CMP @SWR,OPSTAT  
BEQ FULG  
JSR R5,OPCHG  
BR FULMOD  
FULG: BIT #4000,OPSTAT  
BNE FULH  
TST PASCNT  
BEQ FULH  
DEC ITACNT  
BNE FULC  
FULH: MOV ITANO,ITACNT  
FULI: CMP R2,#DATEND  
BEQ FULI  
ADD #2,R2  
BR FULB  
FULJ: CMP R1,#INTEND  
BEQ FULJ  
ADD #4,R1  
BR FULA  
FULJ: JSR R5,TYPE  
O25007  
O05015  
O57400  
INC PASCNT  
MOV @#42,R0  
BEQ RETURN  
RESET  
SENDAD: JSR 7,(R0)  
NOP  
NOP  
NOP  
RETURN: BR FULMOD

;INST. POINTER (R1) SET TO BEGIN OF INST. TABLE.  
;DATA POINTER (R2) SET TO BEGIN OF DATA TABLE.  
;STEP COUNT (IF ANY) SET FOR SIMULATE.  
;CHECK FOR CNTL G TO LOAD SWR  
;SIMULATED BCC SET TO 0.  
;SET THE SIMULATED DONE BIT.  
;SIMULATE INST. (VIA R1) ON DATA (VIA R2).  
;IS THE INST. A STEP TYPE?  
;NO - BRANCH.  
;YES. - IS THE INST. I10,I20,I30, OR I40?  
;YES. - BRANCH.  
;NO. - IS THE INST. I46?  
;YES. - BRANCH.  
;NO. - CLEAR THE SIMULATED DONE BIT.  
;DO TEST A (STEP INST. TEST).  
;BRANCH.  
;NO. - DO TEST B (NON-STEP INST. TEST).  
;HAS OPERATION STATUS STATUS (SWR) CHANGED?  
;NO. - BRANCH.  
;YES. - GO SET UP NEW OPERATION STATUS.  
;BRANCH.  
;NO. - ITERATE?  
;NO. - BRANCH  
;FIRST PASS?  
;YES, SKIP ITERATIONS THIS TIME  
;YES. - DECREMENT ITERATE COUNTER. IS IT=0?  
;NO. - BRANCH. (KEEP ITERATING).  
;YES. - SET ITERATE CTR. TO ITERATE NUMBER.  
;HAVE ALL DATA WORDS BEEN TESTED?  
;YES - BRANCH.  
;NO. - ADVANCE DATA POINTER (R2).  
;BRANCH.  
;HAVE ALL INSTS. BEEN TESTED?  
;YES. - BRANCH.  
;NO. - ADVANCE INST. POINTER (R1).  
;BRANCH.  
;YES. PASS COMPLETE. RING TTY BELL AND PRINT '\*'.  
;INCREMENT PASS COUNT SO SUBSEQUENT  
;PASSES WILL ITERATE  
;START TEST OVER



898	002732	001403	
899	002734	062701	000004
900	002740	000711	
901	002742	012701	001000
902	002746	000706	
903			

	BEG	SELI
	ADD	#4,R1
	BR	SELB
SELI:	MOV	#INTBEG,R1
	BR	SELB

```

;YES. - BRANCH.
;NO. - ADVANCE INST. POINTER (R1).
;BRANCH.
;INST. POINTER (R1) SET TO BEGIN OF INST. TABLE.
;BRANCH.

```

904  
905  
906  
907  
908  
909  
910  
911  
912  
913  
914  
915  
916  
917  
918  
919  
920  
921  
922  
923  
924  
925  
926  
927  
928  
929  
930  
931

002750 104400  
002752 116167 000001 176672  
002760 012763 000020 177776  
002766 111163 177776  
002772 011263 000002  
002776 052763 000040 177776  
003004 000240  
003006 016367 177776 176572  
003014 011367 176564  
003020 005367 176626  
003024 001364  
003026 042767 177577 176552  
003034 026767 176546 176602  
003042 001004  
003044 026767 176534 176562  
003052 001401  
003054 104000  
003056 005767 176520  
003062 001374  
003064 000205

:TEST A.  
:TEST THE INSTRUCTION POINTED AT BY R1 USING THE DATA WORD  
:POINTED AT BY R2. (HIGH BYTE OF THE INST. WORD IS THE STEP COUNT  
:& LOW BYTE IS THE ACTUAL INST.) THE FINAL RESULT IS STORED  
:INTO LOC. "HBCC" TO BE COMPARED WITH THE SIMULATED RESULT  
:WHICH HAS BEEN STORED IN LOC. "SMBCC".  
  
TESTA: SCOPE :GO RECORD ENTRY TO THIS TEST.  
MOVB +1(R1),STCNT :SET UP STEP COUNT.  
MOV #20,-2(R3) :CLEAR THE BCC & THE DONE BIT.  
MOVB (R1),-2(R3) :MOVE INST. TO CSR.  
MOV (R2),+2(R3) :MOVE DATA TO DSR.  
TAA: BIS #40,-2(R3) :STEP (SHIFT) ONE.  
NOP :PAUSE.  
MOV -2(R3),HDONE :READ & STORE CSR (DONE BIT)  
MOV (R3),HBCC :READ & STORE BCC.  
DEC STCNT :IS STEP COUNT = 0?  
BNE TAA :NO - BRANCH.  
BIC #177577,HDONE :YES. - CLEAR ALL BUT THE DONE BIT.  
CMP HDONE,SMDONE :HARDWARE DONE BIT = SIMULATED DONE BIT?  
BNE TAB :NO. - BRANCH. (ERROR)  
CMP HBCC,SMBCC :YES. - HARDWARE BCC = SIMULATED BCC?  
BEQ TAC :YES. - BRANCH.  
TAB: HLT :NO. - TRAP TO ERROR HANDLER.  
TAC: TST EFLG :IS AN ERROR SCOPE LOOP RUNNING?  
BNE TAB :YES. - BRANCH.  
RTS R5 :NO. - RETURN.

```

932
933
934
935
936
937
938
939 003066 104400
940 003070 012763 000020 177776
941 003076 011163 177776
942 003102 011263 000002
943 003106 000240
944 003110 016367 177776 176470
945 003116 011367 176462
946 003122 032767 000200 176456
947 003130 001404
948 003132 026767 176446 176474
949 003140 001401
950 003142 104000
951 003144 005767 176432
952 003150 001374
953 003152 000205
    
```

```

;TEST B.
;TEST THE INSTRUCTION POINTED AT BY R1 USING THE DATA WORD
;POINTED AT BY R2. THE RESULT IS STORED IN LOC. "HBCC" TO BE
;COMPARED WITH THE SIMULATED RESULT WHICH HAS BEEN STORED
;IN LOC. "SMBCC".
    
```

```

TESTB: SCOPE
        MOV     #20,-2(R3)      ;GO RECORD ENTRY TO THIS TEST.
        MOV     (R1),-2(R3)    ;CLEAR THE BCC.
        MOV     (R2),+2(R3)    ;MOVE INST. TO CSR.
        NOP                    ;MOVE DATA TO DBR (COMPUTE BCC).
        MOV     -2(R3),HDONE    ;PAUSE.
        BIT     #200,HDONE     ;READ & STORE CSR (DONE BIT)
        BEQ     TBA,HBCC      ;READ & STORE BCC.
        CMP     HBCC,SMBCC    ;IS DONE BIT = 1?
        BEQ     TBB           ;NO. - BRANCH. (ERROR)
        HLT     TBA           ;HARDWARE BCC = SIMULATED BCC?
        TST     EFLG          ;YES. - BRANCH.
        BNE     TBA           ;NO. - TRAP TO ERROR HANDLER.
        RTS     R5           ;IS AN ERROR SCOPE LOOP RUNNING.
                                ;YES. - BRANCH.
                                ;NO. - RETURN.
    
```



```

954
955      ;TRAP SERVICE ROUTINE (CALLED BY PSUEDO-OP HLT)
956      ;ERROR HANDLER. - TYPEOUTS - HALT - SCOPE LOOP.
957
958 003154 004767 001564      ERR:   JSR   PC,CKSWR      ;CHECK FOR CNTL G TO LOAD SWREG
959 003160 005767 176416      TST   EFLG          ;FIRST ERR CALL FOR CURRENT TEST?
960 003164 001003      BNE   ERA          ;NO. - BRANCH.
961 003166 005267 176410      INC   EFLG          ;YES. - SET ERR FLAG.
962 003172 000404      BR    ERA          ;BRANCH. (UNCONDITIONAL TYPE OUT).
963 003174 032767 020000 176416 ERA:   BIT   #20000,OPSTAT ;INHIBIT TYPE OUT?
964 003202 001002      BNE   ERC          ;YES. - BRANCH.
965 003204 004567 000140      JSR   RS,TYPERR    ;NO. - TYPE ERR MESSAGE.
966 003210 023737 000042 000046 ERC:   CMP   @#42,@#46 ;ARE WE IN ACT11 AUTOMATIC MODE?
967 003216 001404      BEQ   .+12         ;YES. HALT ON ERROR
968 003220 032777 100000 176344 BIT   #100000,@SWR ;HALT ON ERR?
969 003226 001401      BEQ   ERD          ;NO. - BRANCH.
970 003230 000000      HALT                ;YES. - HALT HERE AND WAIT FOR OPERATOR.
971 003232 004767 001506      JSR   PC,CKSWR    ;CHECK FOR CNTL G TO LOAD SWREG
972 003236 027767 176330 176354 ERD:   CMP   @SWR,OPSTAT ;HAS OPERATION STATUS (SWR) CHANGED?
973 003244 001402      BEQ   ERA          ;NO. - BRANCH.
974 003246 004567 176622      JSR   RS,OPCHG    ;YES - GO SET UP NEW OPERATION STATUS.
975 003252 032767 040000 176340 ERE:   BIT   #40000,CPSTAT ;SCOPE LOOP?
976 003260 001403      BEQ   ERF          ;NO. - BRANCH.
977 003262 022626      CMP   (SP)+,(SP)+ ;YES. - POP STACK
978 003264 000177 176342      JMP   @SCORTN     ;RETURN (SCOPE LOOP).
979 003270 005067 176306      CLR   EFLG        ;CLEAR ERR FLAG.
980 003274 005767 176330      TST   SELFLG      ;SELECT MODE?
981 003300 001001      BNE   ERG          ;YES. - BRANCH.
982 003302 000002      RTI                ;NO. - RETURN (CONTINUE TESTING).
983 003304 032777 000077 176260 ERG:   BIT   #77,@SWR   ;SWR5-0 = 0?
984 003312 001410      BEQ   ERH          ;YES. - BRANCH.
985 003314 032777 007700 176250 BIT   #7700,@SWR  ;NO. - SWR6-11 = 0?
986 003322 001404      BEQ   ERH          ;YES. - BRANCH.
987 003324 062706 000006      ADD   #6,SP        ;NO. - POP STACK.
988 003330 000167 177064      JMP   SELMOD      ;RESTART AT SELMOD.
989 003334 000002      ERH:   RTI        ;RETURN (CONTINUE TESTING).
990
991
992
993 00333E 000005      FORCER: RESET      ;FORCE AN ERROR-TYPE TYPEOUT
994 003340 004567 000004      JSR   RS,TYPERR   ;WHENEVER STARTED FROM LOC.210.
995 003344 000000      FEA:   HALT        ;THEN HALT.
996 003346 000776      BR    FEA
997

```

998  
 999  
 1000  
 1001  
 1002  
 1003  
 1004  
 1005  
 1006  
 1007  
 1008  
 1009  
 1010  
 1011  
 1012  
 1013  
 1014  
 1015  
 1016  
 1017  
 1018  
 1019  
 1020  
 1021  
 1022  
 1023  
 1024  
 1025  
 1026  
 1027  
 1028  
 1029  
 1030  
 1031  
 1032  
 1033  
 1034  
 1035  
 1036  
 1037  
 1038  
 1039  
 1040  
 1041  
 1042  
 1043  
 1044  
 1045  
 1046

003350 105761 000001  
 002354 001404  
 003356 012767 020101 000214  
 003364 000403  
 003366 012767 020102 000204  
 003374 010167 176254  
 003400 162767 000774 176246  
 003406 006067 176242  
 003412 006067 176236  
 003416 042767 177700 176230  
 003424 004567 000306  
 003430 001654  
 003432 003606  
 003434 000002  
 003436 010267 176212  
 003442 162767 001372 176204  
 003450 006067 176200  
 003454 042767 177700 176172  
 003462 004567 000250  
 003466 001654  
 003470 003613  
 003472 000002  
 003474 004567 000236  
 003500 001634  
 003502 003624  
 003504 000006  
 003506 004567 000224  
 003512 001604  
 003514 003635  
 003516 000006  
 003520 112767 000061 000123  
 003526 032767 000200 176110  
 003534 001003  
 003536 112767 000060 000105  
 003544 112767 000061 000101  
 003552 032767 000200 176026  
 003560 001003  
 003562 112767 000060 000063  
 003570 004567 000064  
 003574 042524  
 003576 052123  
 003600 020077  
 003602 044440  
 003604 037477  
 003606 020040  
 003610 037504

;SUBROUTINE - SET UP AND TYPE THE ERROR MESSAGE THAT STARTS AT EMA.

TYPERR: TSTB +1(R1)  
 BEQ TEA  
 MOV #20101,EMC  
 BR TEB  
 TEA: MOV #20102,EMC  
 TEB: MOV R1,TEWK  
 SUB #INTBEG-4,TEWK  
 ROR TEWK  
 ROR TEWK  
 BIC #177700,TEWK  
 JSR R5,OTA  
 TEWK  
 EMF  
 2  
 MOV R2,TEWK  
 SUB #DATBEG-2,TEWK  
 ROR TEWK  
 BIC #177700,TEWK  
 JSR R5,OTA  
 TEWK  
 EMH+1  
 2  
 JSR R5,OTA  
 SMBC  
 EMM  
 6  
 JSR R5,OTA  
 HBCC  
 EMQ+1  
 6  
 MOVB #61,EMX+1  
 BIT #200,SMDONE  
 BNE TEC  
 MOVB #60,EMX+1  
 MOVB #61,EMY+1  
 BIT #200,HDONE  
 BNE TED  
 MOVB #60,EMY+1  
 JSR R5,TYPE  
 EMA: .ASCII /TE/  
 EMB: .ASCII /ST/  
 EMC: .ASCII /? /  
 EMD: .ASCII / I /  
 EME: .ASCII /??/  
 EMF: .ASCII / /  
 EMG: .ASCII /D?/

1047 003612 020077  
 1048 003614 051440  
 1049 003616 037477  
 1050 003620 037477  
 1051 003622 037477  
 1052 003624 020040  
 1053 003626 037510  
 1054 003630 037477  
 1055 003632 037477  
 1056 003634 020077  
 1057 003636 042040  
 1058 003640 047117  
 1059 003642 020105  
 1060 003644 044502  
 1061 003646 035124  
 1062 003650 037440  
 1063 003652 037534  
 1064 003654 057536  
 1065 003656 000205

EMH: .ASCII /? /  
 EMI: .ASCII /S /  
 EMJ: .ASCII /?? /  
 EMK: .ASCII /?? /  
 EML: .ASCII /?? /  
 EMM: .ASCII / /  
 EMN: .ASCII /H? /  
 EMO: .ASCII /?? /  
 EMP: .ASCII /?? /  
 EMQ: .ASCII /? /  
 EMR: .ASCII /D /  
 EMS: .ASCII /ON /  
 EMU: .ASCII /E /  
 EMV: .ASCII /BI /  
 EMW: .ASCII /T: /  
 EMX: .ASCII /? /  
 EMY: .ASCII /\? /  
 EMZ: .ASCII /!+ /  
 RTS RS

```

1066
1067
1068
1069
1070
1071 003660 105767 173700
1072 003664 100375
1073 003666 121527 000136
1074 003672 001005
1075 003674 105725
1076 003676 004567 177756
1077 003702 005015
1078 003704 000137
1079 003706 121527 000137
1080 003712 001403
1081 003714 112567 173646
1082 003720 000757
1083 003722 105725
1084 003724 032705 000001
1085 003730 001401
1086 003732 005205
1087 003734 000205

```

```

:SUBROUTINE - TYPE ON THE TTY THE MESSAGE IMMEDIATELY FOLLOWING
:THE CALL TO THIS SUBROUTINE. UP-ARROW (^) CAUSES A CRLF AND BACK-ARROW
:(+) CAUSES TERMINATION OF TYPEOUT. RETURN WILL BE TO THE INSTRUCTION
:FOLLOWING THE MESSAGE.

```

```

TYPE: TSTB TPCSR
      BPL TYPE
      CMPB (RS),#136
      BNE TPA
      TSTB (RS)+
      JSR RS,TYPE
      005015
      000137
TPA: CMPB (RS),#137
      BEQ TPB
      MOVB (RS)+,TPDBR
      BR TYPE
TPB: TSTB (RS)+
      BIT #1,RS
      BEQ TPC
      INC RS
TPC: RTS RS

```

```

1088
1089
1090
1091
1092
1093
1094
1095
1096 003736 013567 175662
1097 003742 012504
1098 003744 012567 175652
1099 003750 016767 175650 175650
1100 003756 000241
1101 003760 006067 175640
1102 003764 000241
1103 003766 006067 175632
1104 003772 000241
1105 003774 006067 175624
1106 004000 042767 177770 175620
1107 004006 052767 000060 175612
1108 004014 116744 175606
1109 004020 005367 175576
1110 004024 001351
1111 004026 000205
1112
1113

```

```

:SUBROUTINE - OCTAL TO ALPHA CONVERSION ACCORDING TO THE THREE WORDS
:IMMEDIATELY FOLLOWING THE CALL TO THIS SUBROUTINE. THE FIRST WORD POINTS
:AT THE WORD TO BE CONVERTED. THE SECOND WORD POINTS AT THE STARTING
:LOC. WHERE THE RESULT IS TO BE MOVED. THE THIRD WORD IS THE NUMBER
:OF CHARACTERS TO BE CONVERTED AND MOVED. RETURN WILL BE TO THE
:INSTRUCTION FOLLOWING THESE THREE WORDS.

```

```

OTA:  MOV  2(R5)+,OTAWKA
      MOV  (R5)+,R4
      MOV  (R5)+,OTACNT
OTALA: MOV  OTAWKA,OTAWKB
      CLC
      ROR  OTAWKA
      CLC
      ROR  OTAWKA
      CLC
      ROR  OTAWKA
      BIC  #177770,OTAWKB
      BIS  #60,OTAWKB
      MOVB OTAWKB,-(R4)
      DEC  OTACNT
      BNE  OTALA
      RTS  R5

```

```
1114  
1115 ;TRAP SERVICE ROUTINE - SCOPE = TRAP.  
1116  
1117 004030 011667 175576 SCORCD: MOV (SP), SCORTN ;SAVE THE STARTING LOC. OF TESTA OR TESTB.  
1118 004034 004767 000704 JSR PC, CKSWR ;CHECK FOR CNTL G TO LOAD SWREG  
1119 004040 000002 RTI ;RETURN.  
1120  
1121 ;TRAP SERVICE ROUTINE - "T" BIT SET =TRAP.  
1122  
1123 004042 000002 TRTRTN: RTI ;GOOD BOY, NOW RETURN.  
1124
```

```

1125 :SUBROUTINE - SIMULATE ALL MODES OF LRC
1126 004044 012767 000010 175566 SMLRCA: MOV #10, SMCNT ;ENTRY LRC16 DOUBLE BYTE DATA.
1127 004052 062767 000010 175560 SMLRCB: ADD #10, SMCNT ;ENTRY LRC16 SINGLE BYTE DATA.
1128 004060 042767 100000 000070 SMLRCC: BIC #100000, SMLRCJ ;ENTRY STEP LRC16.
1129 004066 000411 BR SMLRCG
1130 004070 012767 000010 175542 SMLRCD: MOV #10, SMCNT ;ENTRY LRCB DOUBLE BYTE DATA.
1131 004076 062767 000010 175534 SMLRCE: ADD #10, SMCNT ;ENTRY LRCB SINGLE BYTE DATA.
1132 004104 052767 100000 000044 SMLRCF: BIS #100000, SMLRCJ ;ENTRY STEP LRCB.
1133 004112 005767 175522 SMLRCG: TST SMCNT
1134 004116 001002 BNE SMLRCH
1135 004120 005267 175514 INC SMCNT
1136 004124 016767 175504 175504 SMLRCH: MOV SMBCC, SMBCCA
1137 004132 011267 175504 MOV (R2), SMDATA
1138 004136 016767 175472 175502 SMLRCI: MOV SMBCC, SMWKA
1139 004144 066767 175472 175474 ADD SMDATA, SMWKA
1140 004152 006067 175470 ROR SMWKA
1141 004156 006067 175452 SMLRCJ: ROR SMBCC ;INSTR. MODIFIED: LRC16=ROR LRCB=RORB.
1142 004162 000241 CLC
1143 004164 006067 175452 ROR SMDATA
1144 004170 005367 175444 DEC SMCNT
1145 004174 001360 BNE SMLRCI
1146 004176 000205 RTS
1147
    
```

```

1148
1149
1150 ;SUBROUTINE - SIMULATE ALL MODES OF CRC16.
1151
1152 004200 012767 000010 175432 SMC16A: MOV #10, SMCNT ;ENTRY CRC16 DOUBLE BYTE DATA.
1153 004206 062767 000010 175424 SMC16B: ADD #10, SMCNT ;ENTRY CRC16 SINGLE BYTE DATA.
1154 004214 005767 175420 SMC16C: TST SMCNT ;ENTRY STEP CRC16.
1155 004220 001002 BNE SMC16D
1156 004222 005267 175412 INC SMCNT
1157 004226 016767 175402 175402 SMC16D: MOV SMBCC, SMBCCA
1158 004234 011267 175402 MOV (R2), SMDATA
1159 004240 016767 175370 175400 SMC16E: MOV SMBCC, SMWKA
1160 004246 066767 175370 175372 ADD SMDATA, SMWKA
1161 004254 000241 CLC
1162 004256 006067 175352 ROR SMBCC
1163 004262 000241 CLC
1164 004264 006067 175352 ROR SMDATA
1165 004270 006067 175352 ROR SMWKA
1166 004274 103014 BCC SMC16F
1167 004276 012767 120001 175342 MOV #120001, SMWKA
1168 004304 046767 175324 175334 BIC SMBCC, SMWKA
1169 004312 042767 120001 175314 BIC #120001, SMBCC
1170 004320 066767 175322 175306 ADD SMWKA, SMBCC
1171 004326 005367 175306 SMC16F: DEC SMCNT
1172 004332 001342 BNE SMC16E
1173 004334 000205 RTS R5
1174
1175 ;SUBROUTINE - SIMULATE ALL MODES OF CCITT.
1176
1177 004336 012767 000010 175274 SMC17A: MOV #10, SMCNT ;ENTRY CCITT DOUBLE BYTE DATA.
1178 004344 062767 000010 175266 SMC17B: ADD #10, SMCNT ;ENTRY CCITT SINGLE BYTE DATA.
1179 004352 005767 175262 SMC17C: TST SMCNT ;ENTRY STEP CCITT.
1180 004356 001002 BNE SMC17D
1181 004360 005267 175254 INC SMCNT
1182 004364 016767 175244 175244 SMC17D: MOV SMBCC, SMBCCA
1183 004372 011267 175244 MOV (R2), SMDATA
1184 004376 016767 175232 175242 SMC17E: MOV SMBCC, SMWKA
1185 004404 066767 175232 175234 ADD SMDATA, SMWKA
1186 004412 000241 CLC
1187 004414 006067 175214 ROR SMBCC
1188 004420 000241 CLC
1189 004422 006067 175214 ROR SMDATA
1190 004426 006067 175214 ROR SMWKA
1191 004432 103014 BCC SMC17F
1192 004434 012767 102010 175204 MOV #102010, SMWKA
1193 004442 046767 175166 175176 BIC SMBCC, SMWKA
1194 004450 042767 102010 175156 BIC #102010, SMBCC
1195 004456 066767 175164 175150 ADD SMWKA, SMBCC
1196 004464 005367 175150 SMC17F: DEC SMCNT
1197 004470 001342 BNE SMC17E
1198 004472 000205 RTS R5
1199
1200 ;SUBROUTINE - SIMULATE ALL MODES OF CRC12.
1201
1202 004474 012767 000006 175136 SMC12A: MOV #6, SMCNT ;ENTRY CRC12 SINGLE BYTE DATA.
1203 004502 005767 175132 SMC12B: TST SMCNT ;ENTRY STEP CRC12.

```



1204	004506	001002				BNE	SMC12C
1205	004510	005267	175124			INC	SMCNT
1206	004514	016767	175114	175114	SMC12C:	MOV	SMBCC, SMBCCA
1207	004522	011267	175114			MOV	(R2), SMDATA
1208	004526	016767	175102	175112	SMC12D:	MOV	SMBCC, SMWKA
1209	004534	066767	175102	175104		ADD	SMDATA, SMWKA
1210	004542	106367	175066			ASLB	SMBCC
1211	004546	106367	175062			ASLB	SMBCC
1212	004552	006067	175056			ROR	SMBCC
1213	004556	106067	175052			RORB	SMBCC
1214	004562	106067	175046			RORB	SMBCC
1215	004566	042767	160000	175040		BIC	#160000, SMBCC
1216	004574	006067	175046			ROR	SMWKA
1217	004600	103014				BCC	SMC12E
1218	004602	012767	036001	175036		MOV	#36001, SMWKA
1219	004610	046767	175020	175030		BIC	SMBCC, SMWKA
1220	004616	042767	036001	175010		BIC	#36001, SMBCC
1221	004624	066767	175016	175002		ADD	SMWKA, SMBCC
1222	004632	000241			SMC12E:	CLC	
1223	004634	006067	175002			ROR	SMDATA
1224	004640	005367	174774			DEC	SMCNT
1225	004644	001330				BNE	SMC12D
1226	004646	000205				RTS	RS

```

1227
1228
1229
1230
1231 004650 013746 000006 SUSWR: MOV @#6, -(SP) ;SAVE VECTORS
1232 004654 013746 000004 MOV @#4, -(SP)
1233 004660 012737 004700 000004 MOV @#6, @#4 ;SET UP FOR TIMEOUT
1234 004666 022777 177777 174676 CMP #-1, @SWR ;REFERENCE HARDWARE SWITCH REGISTER
1235 004674 001402 BEQ 65$
1236 004676 000404 BR 66$
1237 004700 022626 64$: CMP (SP)+, (SP)+ ;ADJUST STACK
1238 004702 012767 000176 174662 65$: MOV #SWREG, SWR ;POINT TO SOFTWARE SWITCH REG
1239 004710 012637 000004 66$: MOV (SP)+, @#4 ;RESTORE VECTORS
1240 004714 012637 000006 MOV (SP)+, @#6
1241 004720 022767 000176 174644 CMP #SWREG, SWR ;IS SWREG USED
1242 004726 001002 BNE 67$
1243 004730 004767 000070 JSR PC, CNTLU ;ALLOW SWREG TO BE LOADED
1244 004734 000207 67$: RTS PC
1245
1246
1247 ;CHECK SWITCH REGISTER ROUTINE. CHECKS FOR ↑G TO ALLOW CHANGING
1248 ;OF LOC.176.
1249 ;LOCATIONS USED:
1250 004736 000000 TEMPST: .WORD 0
1251 004740 000000 COUNT: .WORD 0
1252 004742 000000 TIB: .WORD 0
1253
1254
1255 004744 022767 000176 174620 CKSWR: CMP #SWREG, SWR ;SOFTWARE SWITCH REGISTER PRESENT
1256 004752 001143 BNE OUT ;NO GET OUT
1257 004754 105767 172600 TSTB TKCSR ;YES, WAIT FOR
1258 004760 100140 BPL OUT ;READY, GET CHARACTER
1259 004762 016767 172574 177752 MOV TKDAR, TIB ;AND STRIP OFF
1260 004770 042767 177600 177744 BIC #177600, TIB ;THE GARBAGE
1261 004776 022767 000007 177736 CMP #7, TIB ;IS IT ^ (↑G)
1262 005004 001126 BNE OUT
1263 005006 004567 176646 JSR RS, TYPE ;TYPE CNTL G
1264 005012 041536 052116 020114 .ASCII /↑CNTL G↑+/
1265 005020 057107 137
1266 005024
1267 005024 004567 176706 CNTLU: JSR RS, OTA ;MOVE CONTENTS
1268 005030 000176 SWREG ;OF SWREG TO BE
1269 005032 005055 MSWREG ;TYPED FOLLOWING
1270 005034 000006 6 ;THE MESSAGE SWR=
1271 005036 004567 176616 JSR RS, TYPE ;TYPE THE COMPLETE MESSAGE
1272
1273 005042 051536 051127 075 MSWR: .ASCII /↑SWR=/ ;SWR=
1274 005047 077 037477 037477 .ASCII /?????/ ; XXXXXX
1275 005054 077
1276 005055 040 020040 020040 MSWREG: .ASCII / /
1277 005062 040
1278 005063 040 042516 036527 MNEW: .ASCII / NEW= +/ ; NEW=
1279 005070 057440
1280 .EVEN
1281

```



```

1314
1315
1316
1317 005264 005067 172270
1318 005270 005067 172266
1319 005274 005067 177442
1320 005300 005267 172254
1321 005304 105767 172250
1322 005310 100375
1323 005312 016767 172244 177422
1324 005320 105767 172240
:325 005324 100375
1326 005326 116767 177410 172232
:327 005334 000207
1328
1329          000001

```

;TTY INPUT SUBROUTINE\*\*\*\*\*

```

TTIN:  CLR  TKCSR
        CLR  TKDBR
        CLR  TIB
        INC  TKCSR
TTIN1:  TSTB TKCSR
        BPL  TTIN1
        MOV  TKDBR, TIB
TTIN2:  TSTB TPCSR
        BPL  TTIN2
        MOVB TIB, TPDBR
        RTS  PC
        .END

```

CKSWR	004744	D56	001526	FEA	003344	I32	001144	PASCNT	001660
CNTLU	005024	D57	001530	FORCER	003336	I33	001150	PS	= 177776
COJNT	004740	D60	001532	FORERR	000210	I34	001154	RETURN	002416
DATBEG=	001374	D61	001534	FTITLE	001656	I35	001160	R7	=%000007
DATEND=	001570	D62	001536	FULA	002164	I36	001164	SCOPE	= 104400
DEVADR	001574	D63	001540	FULB	002170	I37	001170	SCORCD	004030
DFLG	001576	D64	001542	FULC	002220	I40	001174	SCORTM	001632
DFLGA	001600	D65	001544	FULD	002246	I41	001200	SELA	002474
D01	001374	D66	001546	FULE	002254	I42	001204	SELB	002564
D02	001376	D67	001550	FULF	002260	I43	001210	SELC	002642
D03	001400	D70	001552	FULG	002276	I44	001214	SELD	002650
D04	001402	D71	001554	FULH	002330	I45	001220	SELE	002654
D05	001404	D72	001556	FULI	002344	I46	001224	SELECT	000204
D06	001406	D73	001560	FULJ	002360	I47	001230	SELF	002672
D07	001410	D74	001562	FULMOD	002160	I50	001234	SELFLG	001630
D10	001412	D75	001564	HBCC	001604	I51	001240	SELG	002714
D11	001414	D76	001566	HDONE	001606	I52	001244	SELH	002720
D12	001416	D77	001570	HLT	= 104000	I53	001250	SELI	002742
D13	001420	EFLG	001602	IDENT	001662	I54	001254	SELMOD	002420
D14	001422	EMA	003574	IFLG	001610	I55	001260	SMBCC	001634
D15	001424	EMB	003576	IFLGA	001612	I56	001264	SMBCCA	001636
D16	001426	EMC	003600	INIT	002010	I57	001270	SMCITA	004336
D17	001430	EMD	003602	INTA	002016	I60	001274	SMCITB	004344
D20	001432	EME	003604	INTB	002022	I61	001300	SMCITC	004352
D21	001434	EMF	003606	INTBEG=	001000	I62	001304	SMCITD	004364
D22	001436	EMG	003610	INTEND=	001270	I63	001310	SMCITE	004376
D23	001440	EMH	003612	ITACNT	001614	I64	001314	SMCITF	004464
D24	001442	EMI	003614	ITANO	001616	I65	001320	SMCNT	001640
D25	001444	EMJ	003616	I01	001000	I66	001324	SMC12A	004474
D26	001446	EMK	003620	I02	001004	I67	001330	SMC12B	004502
D27	001450	EML	003622	I03	001010	I70	001334	SMC12C	004514
D30	001452	EMM	003624	I04	001014	I71	001340	SMC12D	004526
D31	001454	EMN	003626	I05	001020	I72	001344	SMC12E	004632
D32	001456	EMO	003630	I06	001024	I73	001350	SMC16A	004200
D33	001460	EMP	003632	I07	001030	I74	001354	SMC16B	004206
D34	001462	EMQ	003634	I10	001034	I75	001360	SMC16C	004214
D35	001464	EMR	003636	I11	001040	I76	001364	SMC16D	004226
D36	001466	EMS	003640	I12	001044	I77	001370	SMC16E	004240
D37	001470	EMU	003642	I13	001050	MNEW	005063	SMC16F	004326
D40	001472	EMV	003644	I14	001054	MSWR	005042	SMDATA	001642
D41	001474	EMW	003646	I15	001060	MSWREG	005055	SMDONE	001644
D42	001476	EMX	003650	I16	001064	NOP	= 000240	SMLRCA	004044
D43	001500	EMY	003652	I17	001070	NORMAL	000200	SMLRCB	004052
D44	001502	EMZ	003654	I20	001074	OPCA	002126	SMLRCC	004060
D45	001504	ERA	003174	I21	001100	PCB	002156	SMLRCD	004070
D46	001506	ERB	003204	I22	001104	OPCHG	002074	SMLRCE	004076
D47	001510	ERC	003210	I23	001110	OPSTAT	001620	SMLRCF	004104
D50	001512	ERD	003232	I24	001114	OTA	003736	SMLRCG	004112
D51	001514	ERE	003252	I25	001120	OTACNT	001622	SMLRCH	004124
D52	001516	ERF	003270	I26	001124	OTALA	003750	SMLRCI	004136
D53	001520	ERG	003304	I27	001130	OTAWKA	001624	SMLRCJ	004156
D54	001522	ERH	003334	I30	001134	OTAWKB	001626	SMWKA	001646
D55	001524	ERR	003154	I31	001140	OUT	005262	SMWKB	001650

STCNT	001652	TBA	003142	TESTA	002750	TPB	003722	TTIN2	005320
SUSWR	004650	TBB	003144	TESTB	003066	TPC	003734	TYPE	00366C
SWR	001572	TEA	003366	TEWK	001654	TPCSR =	177564	TYPERR	003350
SWREG	000176	TEB	003374	TIB	004742	TPDBR =	177566	\$ENDAD	002406
*AA	002776	TEC	003544	TKCSR =	177560	TRTRTN	004042	\$READ	005072
*AB	003054	*ED	003570	TKDBR =	177562	TTIN	005264	.	= 00533E
*AC	003056	TEMPST	004736	TPA	003706	TTIN1	005304		

. ABS. 005336 000

ERRORS DETECTED: 0  
 DEFAULT GLOBALS GENERATED: 0

DSKZ:DZKGA.B, DSKZ:DZKGA.B/SOL=DSKZ:DZKGA.B.P11  
 RUN-TIME: 4 9 1 SECONDS  
 RUN-TIME RATIO: 145/14=10.0  
 CORE USED: 5K (9 PAGES)