```
;    0001  0     module ZRQAM1 (
;    0002  0
;    0003  0
;    0004  0     %title 'RD/RX EXERCISER'
;    0005  0                    ident = 'V02.3',
;    0006  0                    addressing_mode (absolute),
;    0007  0                    environment (noeis)
;    0008  0                    ) =
;    0009  0
;    0010  1     begin
;    0011  1
;    0012  1
; C  0013  1     %(
; C  0014  1                                    IDENTIFICATION
; C  0015  1                                    --------------
; C  0016  1
; C  0017  1             PRODUCT CODE:          AC-T398H-MC
; C  0018  1
; C  0019  1             PRODUCT NAME:          CZRQAH0 RQDX/RUX50 EXERCISER
; C  0020  1
; C  0021  1             PRODUCT DATE:          10-OCT-85
; C  0022  1
; C  0023  1             MAINTAINER:            DIAGNOSTIC ENGINEERING
; C  0024  1
; C  0025  1             AUTHOR:                RAVINDER K. KARWAN
; C  0026  1                                    BOB POWERS
; C  0027  1
; C  0028  1
; C  0029  1             Copyright (C) 1983, 1985
; C  0030  1
; C  0031  1             Digital Equipment Corporation, Maynard, Massachusetts  01754
; C  0032  1
; C  0033  1             This software is furnished  under a license for use only on a single
; C  0034  1             computer  system and  may be  copied only with  the inclusion of the
; C  0035  1             above copyright notice.  This software, or any other copies thereof,
; C  0036  1             may not be provided or  otherwise made available to any other person
; C  0037  1             except for use on such system and to one who agrees to these license
; C  0038  1             terms.  Title to and  ownership of the  software  shall at all times
; C  0039  1             remain in DEC.
; C  0040  1
; C  0041  1             the information in this document is subject to change without notice
; C  0042  1             and should  not be construed  as a commitment  by Digital  Equipment
; C  0043  1             Corporation.
; C  0044  1
; C  0045  1             DEC assumes  no  responsibility  for  the use or  reliability of its
; C  0046  1             software on equipment which is not supplied by DEC.
; C  0047  1
; C  0048  1
; C  0049  1             The following are trademarks of Digital Equipment Corporation:
; C  0050  1
; C  0051  1             DIGITAL          PDP              UNIBUS           MASSBUS
; C  0052  1             DEC              DECUS            DECTAPE
```

```
;  0001  0     !*****************************************************************************
;  0002  0     !                                                                            *
;  0003  0     !                          L I T E R A L S                                   *
;  0004  0     !                                                                            *
;  0005  0     !*****************************************************************************
;  0006  0     !
;  0007  0     LITERAL
;  0008  0     !
;  0009  0     !****** ODT TRAP VECTOR LOCATION
;  0010  0     !
;  0011  0             O_TVEC          = %o'14',
;  0012  0     !
;  0013  0     !****** HARDWARE ADDRESSES ETC.
;  0014  0     !
;  0015  0             INIT_INTR_VECT  = %o'154',                      ! VECTOR ADDRESS
;  0016  0             INIT_IP_ADDR    = %o'172150',                   ! IP REGISTER ADDRESS
;  0017  0             INIT_BR_LEVEL   = %o'4',                        ! BUS REQUEST LEVEL
;  0018  0     !
;  0019  0             LINE_CLOCK      = %o'177546',                   ! LINE-CLOCK ADDRESS
;  0020  0     !
;  0021  0     !****** HARDWARE LIMITS
;  0022  0     !
;  0023  0             MAX_CTLR        = 1,                            ! MAXIMUM NUMBER OF LCP CONTROLLERS ALLOWED
;  0024  0             UNITS_PER_CNTR  = 4,                            ! MAXIMUM UNITS PER CONTROLLER
;  0025  0             MAX_UNITS       = MAX_CTLR * UNITS_PER_CNTR,    ! MAXIMUM NUMBER OF UNITS TO TEST
;  0026  0
;  0027  0     !                                                       !HIGHEST RD51 LBN = 52137 OCT
;  0028  0             RD51_MAX_TRACK  = 1200,                         ! MAXIMUM NUMBER OF TRACKS FOR RD51
;  0029  0             RD51_SEC_PER_TRK= 18,                           ! NUMBER OF SECTORS PER TRACK FOR RD51
;  0030  0             RD51_MAX_LBN    = RD51_MAX_TRACK * RD51_SEC_PER_TRK - 1,! MAX LBN FOR RD51
;  0031  0
;  0032  0             RD52_MAX_TRACK  = 2976,                         ! MAXIMUM NUMBER OF TRACKS FOR RD52
;  0033  0             RD52_SEC_PER_TRK= 18,                           ! NUMBER OF SECTORS PER TRACK FOR RD52
;  0034  0             RD52_MAX_LBN    = RD52_MAX_TRACK * RD52_SEC_PER_TRK - 1,! MAX LBN FOR RD52
;  0035  0
;  0036  0             RX50_MAX_TRACK  = 80,                           ! MAXIMUM NUMBER OF TRACKS FOR RX50
;  0037  0             RX50_SEC_PER_TRK= 10,                           ! NUMBER OF SECTORS PER TRACK FOR RX50
;  0038  0             RX50_MAX_LBN    = RX50_MAX_TRACK * RX50_SEC_PER_TRK - 1,! MAX LBN FOR RX50
;  0039  0
;  0040  0     !                                                       !HIGHEST RD53 LBN = 416660 OCT (2/016660)
;  0041  0     !                                                       !RD51  SEAGATE 4 HEADS
;  0042  0     !                                                       !RD52A QUANTUM 8 HEADS 98%
;  0043  0     !                                                       !RD52B ATASI   7 HEADS
;  0044  0     !                                                       !RD53  MICROPOLIS 8 HEADS
;  0045  0     !                                                       !RQDX2 18 SKS/TK
;  0046  0     !                                                       !RQDX2 17 SKS/TK
;  0047  0
;  0048  0             BYTES_PER_SECT  = 512,                          ! BYTES/SECTOR (AT PRESENT SAME FOR RDs AND RXs)
;  0049  0     !       MAX_XFER_SIZE   = 2 * BYTES_PER_SECT,           ! ARTBITRARY MAX SIZE OF EACH DISK I/O
;  0050  0             MAX_XFER_SIZE   = BYTES_PER_SECT * 3 / 2,
;  0051  0     !
;  0052  0     ! NOTE - BOTH OF THESE NUMBERS ARE NOW ARBITRARILY CHOSEN AS THE NUMBER OF LBNS CONTAINED PER UNIT/10 .
;  0053  0
```

```
;    0054  0      !
;    0055  0      !****** RING SIZES
;    0056  0      !
;    0057  0              CR_LOG          = 2,                                    ! LOG2 LENGTH OF COMMAND RING
;    0058  0              RR_LOG          = 2,                                    ! LOG2 LENGTH OF RESPONSE RING
;    0059  0              CRING_LEN       = 1 ^ CR_LOG,                           ! COMMAND RING LENGTH
;    0060  0              RRING_LEN       = 1 ^ RR_LOG,                           ! RESPONSE RING LENGTH
;    0061  0      !
;    0062  0      !****** OFFSETS (IN WORDS)
;    0063  0      !
;    0064  0              OF_UN           = 3,                                    ! OFFSET FROM START OF CST TO FIRST UNIT
;    0065  0              OF_DATA         = 0,                                    ! OFFSET TO DISK UNIT FLAGS   WITHIN UNIT'S CST
;    0066  0              OF_BEG          = 1,                                    ! OFFSET TO BEGINNING BLK NO. WITHIN UNIT'S CST
;    0067  0              OF_BEG1         = 2,          !OFFSET TO START BK HI          ZZZ
;    0068  0              OF_END          = 3,          !OFFSET TO END BLOCK LO         ZZZ
;    0069  0              OF_END1         = 4,          !OFFSET TO END BK HI            ZZZ
;    0070  0              OF_NAME_0       = 5,          !OFFSET TO 1st 2 CHARS OF NAME  ZZZ
;    0071  0              OF_NAME_2       = 6,          !OFFSET TO 2nd 2 CHARS OF NAME  ZZZ
;    0072  0              OF_DUPFLAGS     = 8,          !OFFSET TO DUP FLAGS            ZZZ
;    0073  0              OF_COUNT        = 9,          !OFFSET TO MSCP FUNCTION COUNTER ZZZ
;    0074  0              OF_DBN          = 8,          !OFFSET TO RELATIVE DBN         ZZZ
;    0075  0      !
;    0076  0      !
;    0077  0      !****** TABLE AND OTHER STRUCTURE SIZES
;    0078  0      !
;    0079  0              LBNADR_LEN      = 2,                                    !MAX_LBN'S ARE 2 WD ADDRESSES
 ZZZ
;    0080  0              HWPT_LEN        = 8,                                    ! SIZE (WORDS) OF HW P-TABLE
 ZZZ
;    0081  0              COMM_LEN        = (RRING_LEN * 2) + (CRING_LEN * 2) + 4,! SIZE (WORDS) OF COMMUNICATION AREA PER CONTROLLER
;    0082  0              UNIT_SIZE       = 10,                                   ! SIZE (WORDS) OF CST UNIT ENTRY
 ZZZ
;    0083  0              CST_LEN         = UNITS_PER_CNTR * UNIT_SIZE + OF_UN,   ! SIZE (WORDS) OF A CONTROLLER STATUS TABLE
;    0084  0              TALLY_CLEAR     = 7,                                    ! SIZE (WORDS) OF STATISTICS TBL CLEARED EVERY PASS
;    0085  0              TALLY_TOTALS    = 20,                                   ! SIZE (WORDS) OF STATISTICS TABLE FOR TOTALS
 ZZZ
;    0086  0              TALLY_LEN       = TALLY_CLEAR + TALLY_TOTALS,           ! SIZE (WORDS) OF A STATISTICS TABLE
;    0087  0              C_ERR_LEN       = 1,                                    ! SIZE (WORDS) OF CONTROLLER ERROR TABLE
;    0088  0              RP_LEN          = 22,                                   ! SIZE (WORDS) OF A RETURN PACKET
;    0089  0              MSG_LEN         = 30,                                   ! SIZE (WORDS) OF AN MSCP MESSAGE (TEXT PORTION)
;    0090  0              PKT_LEN         = MSG_LEN + 5,                          ! SIZE (WORDS) OF AN MSCP PACKET
;    0091  0              DCT_LEN         = 9,                                    ! SIZE (WORDS) OF A DRIVER CONTROLLER TABLE
;    0092  0              RDM_LEN         = 16,                                   ! SIZE (WORDS) OF THE RANDOM NUMBER TABLE
;    0093  0              MAX_UDP_CNT     = 16,                                   ! MAX SIZE OF USER DATA PATTERN
;    0094  0              MAX_BUF_CNT     = (CRING_LEN * 2) * MAX_CTLR,           ! MAX NO. OF I/O BUFFERS (BUFF_ADDR & BUFF_OWN)
;    0095  0              PKT_CNT         = ((CRING_LEN * 2) + RRING_LEN) * MAX_CTLR,
;    0096  0                                                                      ! NO. OF MSCP PACKETS IN POOL
;    0097  0              RP_CNT          = PKT_CNT - (RRING_LEN * MAX_CTLR),     ! NO. OF RETURN PACKETS IN POOL
;    0098  0              IODQ_LEN        = RP_CNT,                               ! NO. OF ENTRIES IN I/O DONE QUEUE (IODQ)
;    0099  0              OUTC_CNT        = CRING_LEN * 2,                        ! NO. OF ENTRIES/CONTROLLER'S OUTSTANDING CMD LIST
;    0100  0              DP_CNT          = 21,                                   ! NO. OF PRE-DEFINED DATA PATTERNS
;    0101  0              EP_CNT          = MAX_CTLR * RRING_LEN * 3,             ! NO. OF ERROR-LOG PACKET SAVE BUFFERS
;    0102  0              EP_LEN          = PKT_LEN - 3 + 1,                      ! LENGTH OF EACH ERROR-LOG SAVE BUFFER
;    0103  0              LAST_PKT_LEN    = 3,                                    ! BUFFER LENGTH TO SAVE INFO. ABOUT LAST RESPONSE
;    0104  0              DESC_SIZ        = 4,                                    !NO. OF BYTES IN A PACKET DESCRIPTOR          ZZZ
;    0105  0      !
;    0106  0      !****** SW P-TABLE FLAGS (SWP_FLAGS)
```

```
;  0107  0      !
;  0108  0      !ZZZ    SWF_TRC          = %o'000001',                    ! DIAGNOSTIC TRACE
;  0109  0              SWF_APT          = %o'000001',                    !RUNNING UNDER A.P.T. MONITOR                    ZZZ
;  0110  0              SWF_RDM          = %o'000002',                    ! RANDOM SEEK MODE
;  0111  0              SWF_CRC          = %o'000004',                    ! READ-COMPARE AT CONTROLLER
;  0112  0      !       SWF_DCC          = %o'000010',                    ! DRIVE COMPLEMENT COMPLETE
;  0113  0              SWF_CWC          = %o'000020',                    ! WRITE-COMPARE AT CONTROLLER
;  0114  0              SWF_HWC          = %o'000040',                    ! WRITE-COMPARE AT HOST
;  0115  0              SWF_UDP          = %o'000100',                    ! USER-DEFINED DATA PATTERN
;  0116  0              SWF_CST          = %o'000200',                    ! CLEAR STATISTICAL TABLES
;  0117  0      !       SWF_DIA          = %o'000400',                    ! DIAGNOSTIC PACKAGE, WHEN THIS IS SELECTED
;  0118  0                                                                ! ALL INTERRUPTS ARE WAITED FOR, E.G. ONLY
;  0119  0                                                                ! ONE MSCP PACKET IS OUTSTANDING AT A TIME
;  0120  0              SWF_SEQ          = %o'001000',                    ! RANDOM OR FIXED SEQUENTIAL STEPPING
;  0121  0      !       SWF_DUP          = %o'002000',                    ! RUN DUP DIAGNOSTIC
;  0122  0              SWF_FER          = %o'004000',                    ! REWRITE BLOCKS WHEN "FORCED ERROR" BIT DETECTED
;  0123  0              SWF_HRD          = %o'010000',                    ! HALT ON HARD ERRORS ALSO WITH 'HOE' DRS FLAG?
;  0124  0              SWF_SFT          = %o'020000',                    ! HALT ON SOFT ERRORS ALSO WITH 'HOE' DRS FLAG?
;  0125  0              SWF_BLK          = %o'040000',                    ! HALT ON BAD-BLOCK ERRORS ALSO WITH 'HOE' DRS FLAG?
;  0126  0              SWF_TRY          = %o'100000',                    ! COUNT EACH RETRY AS ANOTHER EXTRA SOFT-ERROR
;  0127  0      !
;  0128  0      !****** FLAGS FOR DUP EXERCISER (DUP_FLAGS)                                  ZZZ
;  0129  0      !                                                                           ZZZ
;  0130  0              SWP_DINT         = %o'2',              !DUP CAUSED INIT           ZZZ
;  0131  0
;  0132  0      !
;  0133  0      !****** ENTRY_REASON VALUES
;  0134  0      !               (HOW PROGRAM WAS INVOKED)
;  0135  0      !
;  0136  0              START            = 1,                             ! START
;  0137  0              RESTART          = 2,                             ! RESTART
;  0138  0              CONT             = 3,                             ! CONTINUE
;  0139  0              PWR_FAIL         = 4,                             ! POWER FAIL
;  0140  0              NEW_PASS         = 5,                             ! NEW PASS
;  0141  0      !
;  0142  0      !****** DROP UNIT REASONS
;  0143  0      !               (LOADED INTO DUR VECTOR)
;  0144  0      !
;  0145  0              DU_USER          = 0,                             ! USER COMMAND
;  0146  0              DU_CONF          = 1,                             ! CONFIGURATION ERROR
;  0147  0              DU_INIT          = 2,                             ! INITIALIZATION ERROR
;  0148  0              DU_XFER          = 3,                             ! TRANSFER LIMIT REACHED
;  0149  0              DU_HERR          = 4,                             ! HARD ERROR LIMIT REACHED
;  0150  0              DU_DFATAL        = 5,                             ! UNRECOVERABLE DEVICE ERROR
;  0151  0              DU_CFATAL        = 6,                             ! UNRECOVERABLE CONTROLLER ERROR
;  0152  0              DU_ONLINE        = 7,                             ! ONLINE FAILED
;  0153  0              DU_ACCESS        = 8,                             ! ACCESS TO LAST TRACK FAILED
;  0154  0              DU_PROTECT       = 9,                             ! WRITE PROTECT CONFLICT
;  0155  0              DU_TIME          = 10,                            ! COMMAND TIME OUT
;  0156  0      !
;  0157  0      !****** MISCELLANEOUS LITERALS
;  0158  0      !
;  0159  0              MAX_DBN          = 63,                            !HIGHEST RELATIVE DBN NUMBER                     ZZ
Z
```

```
;  0160  0          INI_ATT         = 2,                                ! NO. OF HW INIT ATTEMPTS BEFORE FAILURE IS ASSUMED
;  0161  0          WR_RING         = ((%o'200') or (CR_LOG + 3) or (RR_LOG)),
;  0162  0                                                              ! WR-BIT-AND-RING-LENGTH (STEP 1 WRITE/STEP 2 READ)
;  0163  0          QIO_PER_CTLR    = CRING_LEN * 2.                    ! MAXIMUM NUMBER OF OUTSTANDING QIOS PER CONTROLLER
;  0164  0    !     MAX_XFER        = 256.                              ! MAXIMUM SIZE (WORDS) OF AN I/O TRANSFER
;  0165  0          REMOVABLE_BIT   = %o'0',                            ! BIT IN HARDWARE TABLES MARKING A REMOVABLE DISK
;  0166  0          FIXED_BIT       = %o'20',                           ! BIT IN HARDWARE TABLES MARKING A FIXED     DISK
;  0167  0          REMOVABLE       = 0,                                ! NUMBER FOR REMOVABLE DISK WHEN SHIFTED RIGHT
;  0168  0          FIXED           = 1,                                ! NUMBER FOR FIXED     DISK WHEN SHIFTED RIGHT
;  0169  0          RX_50           = 0,                !D_TYPE FLAG = 0 FOR RX50  (THESE FLAGS AREN'T USED. INSTEAD,)   ZZZ
;  0170  0          RD_51           = 1,                !D_TYPE FLAG = 1 FOR RD51  (D_TYPE = 1 FOR FIXED, 0 FOR REMOV)   ZZZ
;  0171  0          RD_52           = 2,                !               2 FOR RD52                                       ZZZ
;  0172  0
;  0173  0    !
;  0174  0    !****** MSCP PACKET DESCRIPTOR
;  0175  0    !
;  0176  0          ED_OWN          = %o'100000',                       ! OWNERSHIP BIT
;  0177  0          ED_FLAG         = %o'040000',                       ! FLAG BIT
;  0178  0    !
;  0179  0    !****** MSCP COMMAND PACKET OPCODES
;  0180  0    !
;  0181  0          OP_MSK          = %o'177',                          ! OPCODE MASK
;  0182  0          OP_END          = %o'200',                          ! ENDCODE DESIGNATOR
;  0183  0          OP_ACC          = %o'20',                           ! ACCESS COMMAND
;  0184  0          OP_ONL          = %o'11',                           ! ONLINE COMMAND
;  0185  0          OP_RD           = %o'41',                           ! READ COMMAND
;  0186  0          OP_SCC          = %o'4',                            ! SET CONTROLLER CHARACTERISTICS COMMAND
;  0187  0          OP_WRT          = %o'42',                           ! WRITE COMMAND
;  0188  0          OP_GDS          = %o'1',            !get dust status          ZZZ
;  0189  0          OP_ESP          = %o'2',            !execute supplied prog    ZZZ
;  0190  0          OP_ELP          = %o'3',            !execute local program    ZZZ
;  0191  0          OP_SDD          = %o'4',            !send data                ZZZ
;  0192  0          OP_RCD          = %o'5',            !receive data             ZZZ
;  0193  0          OP_ABT          = %o'6',            !abort program            ZZZ
;  0194  0
;  0195  0    !
;  0196  0    !****** PACKET SIZES
;  0197  0    !
;  0198  0          SZ_ACC = %decimal '32',                             ! ACCESS
;  0199  0          SZ_ONL = %decimal '36',                             ! ON LINE COMMAND
;  0200  0          SZ_RD  = %decimal '32',                             ! READ
;  0201  0          SZ_SCC = %decimal '32',                             ! SET CONTROLLER CHARACTERISTICS
;  0202  0          SZ_WRT = %decimal '32',                             ! WRITE
;  0203  0          SZ_GEN = %decimal '32',                             ! GENERAL PACKET SIZE
;  0204  0          SZ_REC = %DECIMAL '28',             !                 ZZZ
;  0205  0          SZ_SEN = %DECIMAL '28',             !                 ZZZ
;  0206  0          SZ_ELP = %DECIMAL '18',             !                 ZZZ
;  0207  0          SZ_ABT = %DECIMAL '12',             !                 ZZZ
;  0208  0          SZ_GDS = %DECIMAL '12',             !                 ZZZ
;  0209  0    !
;  0210  0    !****** MSCP COMMAND MODIFIERS
;  0211  0    !
;  0212  0          MD_CMP          = %o'040000',                       ! COMPARE
```

```
;    0213  0              MD_EXP          = %o'100000',                          ! EXPRESS REQUEST
;    0214  0      !
;    0215  0      !****** CONNECTION ID VALUES (MSCP_PKT, RETPKT)
;    0216  0      !               (SERVE AS SOURCES AND DESTINATIONS OF MSCP MESSAGES)
;    0217  0      !
;    0218  0              CID_DISK        = 0,                                   ! DISK MSCP
;    0219  0              CID_MSCP        = 0,                                   !DISK MSCP
!ZZZ
;    0220  0              CID_TAPE        = 1,                                   ! TAPE MSCP
;    0221  0              CID_DUP         = 2,                                   ! DIAGNOSTIC AND UTILITIES PROTOCOL
;    0222  0              CID_DRIVER      = 3,                                   ! EXERCISER "DRIVER"
;    0223  0      !
;    0224  0      !****** MESSAGE TYPE VALUES
;    0225  0      !
;    0226  0              MT_SEQ          = 0,                                   ! SEQUENTIAL (FROM PORT)
;    0227  0              MT_DG           = 1,                                   ! DATAGRAM (FROM PORT)
;    0228  0              MT_CRD          = 2,                                   ! CREDIT NOTIFICATION (FROM PORT)
;    0229  0              MT_FATAL        = 3,                                   ! FATAL DEVICE ERROR (FROM "DRIVER")
;    0230  0              MT_TIMEOUT      = 4,                                   ! COMMAND TIMEOUT (FROM "DRIVER")
;    0231  0      !
;    0232  0      !****** CONTROLLER FLAGS
;    0233  0      !               (IN SET CONTROLLER CHARACTERISTICS COMMAND AND RESPONSE)
;    0234  0      !
;    0235  0              CF_ATN          = %o'000200',                          ! ENABLE ATTENTION MESSAGES
;    0236  0              CF_MSC          = %o'000100',                          ! ENABLE MISCELLANEOUS ERROR LOG MESSAGES
;    0237  0              CF_OTH          = %o'000040',                          ! ENABLE OTHER HOST'S ERROR LOG MESSAGES
;    0238  0              CF_THS          = %o'000020',                          ! ENABLE THIS HOST'S ERROR LOG MESSAGES
;    0239  0      !       CF_MASK         = CF_ATN or CF_MSC or CF_THS,
;    0240  0              CF_MASK         = CF_MSC or CF_THS,                    ! RELEVENT BITS IN CTLR FLAGS WORD
;    0241  0      !
;    0242  0      !****** UNIT FLAGS
;    0243  0      !               (IN ONLINE COMMAND AND RESPONSE)
;    0244  0      !
;    0245  0              UF_REMOVABLE    = %o'000200',                          ! REMOVABLE MEDIA
;    0246  0              UF_WPH          = %o'020000',                          ! WRITE PROTECT (HARDWARE)
;    0247  0      !
;    0248  0      !****** STATUS / EVENT CODE DEFINITIONS
;    0249  0      !
;    0250  0              ST_SUC          = %o'0',                               ! SUCCESS
;    0251  0              ST_CMD          = %o'1',                               ! INVALID COMMAND
;    0252  0              ST_ABO          = %o'2',                               ! COMMAND ABORTED
;    0253  0              ST_OFL          = %o'3',                               ! UNIT OFFLINE
;    0254  0              ST_AVL          = %o'4',                               ! DRIVE AVAILABLE
;    0255  0              ST_MFE          = %o'5',                               ! MEDIA FORMAT ERROR
;    0256  0              ST_WPT          = %o'6',                               ! WRITE PROTECTED
;    0257  0              ST_CMP          = %o'7',                               ! COMPARE ERROR
;    0258  0              ST_DAT          = %o'10',                              ! DATA ERROR
;    0259  0              ST_HST          = %o'11',                              ! HOST BUFFER ACCESS ERROR
;    0260  0              ST_CNT          = %o'12',                              ! CONTROLLER ERROR
;    0261  0              ST_DRV          = %o'13',                              ! DRIVE ERROR
;    0262  0              ST_BRC          = %o'24',                              ! BAD BLOCK REPLACEMENT COMPLETION MMM
;    0263  0              ST_DIA          = %o'37',                              ! MESSAGE FROM INTERNAL DIAGNOSTICS
;    0264  0      !
;    0265  0      !****** END MESSAGE FLAGS
```

```
;    0266  0     !
;    0267  0             EF_BBR          = %o'200',                  ! BAD BLOCK REPORTED
;    0268  0             EF_BBU          = %o'100',                  ! BAD BLOCK NOT REPORTED
;    0269  0     !
;    0270  0     !****** RDRX LITERALS
;    0271  0     !
;    0272  0             RCIP            = 0,                        ! IP REGISTER
;    0273  0             RCSA            = 1,                        ! SA REGISTER
;    0274  0     !
;    0275  0     !****** COMMON SA REGISTER BIT DEFINITIONS
;    0276  0     !
;    0277  0             SA_S1           = %o'004000',               ! STEP 1 STATUS BIT
;    0278  0             SA_S2           = %o'010000',               !   :  2
;    0279  0             SA_S3           = %o'020000',               !   :  3
;    0280  0             SA_S4           = %o'040000',               !   V  4
;    0281  0             SA_ERR          = %o'100000',               ! ERROR INDICATOR
;    0282  0             SA_INT          = %o'000200',               ! INTERRUPT ENABLE DURING INITIALIZATION
;    0283  0             SA_GO           = %o'000001',               ! GO BIT TO START FIRMWARE
;    0284  0     !
;    0285  0     !****** INITIALIZATION STEP READ MASKS
;    0286  0     !
;    0287  0             S1_MASK         = %o'176000',               ! STEP 1 READ BITS
;    0288  0             S2_MASK         = %o'174377',               !   :  2
;    0289  0             S3_MASK         = %o'174377',               !   :  3
;    0290  0             S4_MASK         = %o'174000',               !   V  4
;    0291  0     !
;    0292  0     !****** COMMAND TYPES
;    0293  0     !
;    0294  0             IMM_CMD         = 0,                        ! IMMEDIATE COMMAND
;    0295  0             SEQ_CMD         = 1,                        ! SEQUENTIAL COMMAND
;    0296  0             NON_SEQ_CMD     = 2,                        ! NON-SEQUENTIAL COMMAND
;    0297  0     !
;    0298  0     !****** ERROR-LOG FORMAT TYPES
;    0299  0     !
;    0300  0             FORMAT_CNTR     = %o'0',                    ! CONTROLLER ERROR
;    0301  0             FORMAT_HOST     = %o'1',                    ! HOST MEMORY ACCESS ERROR
;    0302  0             FORMAT_XFER     = %o'2',                    ! DISK TRANSFER ERROR
;    0303  0             FORMAT_SDI      = %o'3',                    ! 'STANDARD DISK INTECONNECT' ERROR
;    0304  0             FORMAT_SDE      = %o'4',                    ! SMALL DISK ERROR
;    0305  0             FORMAT_BRA      = %o'11',                   ! BAD BLOCK REPLACEMENT ATTEMPT MMM
;    0306  0     !
;    0307  0     !****** ERROR-LOG BLOCK NUMBER INFORMATION
;    0308  0     !
;    0309  0             TYPE_LBN        = %o'0000',                 ! LOGICAL BLOCK NUMBER
;    0310  0             TYPE_RBN        = %o'0110',                 ! REPLACEMENT BLOCK NUMBER
;    0311  0     !
;    0312  0     !****** MSCP DISK MODEL CODES
;    0313  0     !
;    0314  0     !       MODEL_RX50      = 7,                        ! RX50  THESE ARE NO LONGER USED. THE
;    0315  0     !       MODEL_RD51      = 6,                        ! RD51  MODEL IS DETERMINED ANOTHER WAY.
;    0316  0     !       MODEL_RD52      = 8,                        ! RD52
;    0317  0     !
;    0318  0     !****** LITERALS FOR READABILITY
```

```
;    0319  0     !
;    0320  0             YES             = 1,
;    0321  0             NO              = 0,
;    0322  0             TRUE            = 1,
;    0323  0             FALSE           = 0,
;    0324  0             SUCCESS         = 1,
;    0325  0             FAILURE         = 0,
;    0326  0             FOUND           = 1,
;    0327  0             NOT_FOUND       = 0,
;    0328  0             PRESENT         = 1,                    ! DISK IS PRESENT IN CONTROLLER
;    0329  0             NOT_PRESENT     = 0,                    ! DISK IS NOT PRESENT IN CONTROLLER
;    0330  0             UNPROTECTED     = 1,                    ! DISK HAS UNPROTECTED CUSTOMER LBN'S
;    0331  0             PROTECTED       = 0,                    ! DISK HAS PROTECTED CUSTOMER LBN'S
;    0332  0             ONLINE          = 1,
;    0333  0             OFFLINE         = 0,
;    0334  0             IDLE            = 0,                    !IDLE
 !ZZZ
;    0335  0             ACTIVE          = 1,                    !ACTIVE
 !ZZZ
;    0336  0             FULL            = 1,                    ! ERROR-LOG SAVE PACKET FILLED
;    0337  0             EMPTY           = 0,                    ! ERROR-LOG SAVE PACKET PRINTED
;    0338  0             HRD_OCCURED     = 1,                    ! HARD ERROR DETECTED IN RESPONSE PACKET
;    0339  0             HRD_NOT_OCCURED = 0,                    ! HARD ERROR NOT DETECTED
;    0340  0             ALL_ONES        = %o'177777';
```

```
;  0341  0     !*****************************************************************************
;  0342  0     !                                                                            *
;  0343  0     !                          F I E L D S                                       *
;  0344  0     !                                                                            *
;  0345  0     !*****************************************************************************
;  0346  0     !
;  0347  0     FIELD
;  0348  0     !
;  0349  0     !****** HARDWARE P-TABLE FIELDS
;  0350  0     !
;  0351  0     HWP_FIELDS =
;  0352  0             set
;  0353  0             HWP_IP_ADDR     = [0, 0, 16, 0],                ! IP ADDRESS
;  0354  0             HWP_VECTOR      = [1, 0, 16, 0],                ! VECTOR ADDRESS
;  0355  0             HWP_BR_LEVEL    = [2, 0, 16, 0],                ! BUS REQUEST LEVEL
;  0356  0             HWP_DISK        = [3, 0, 16, 0],                ! DISK (ALL FIELDS)
;  0357  0             HWP_DISK_NUM    = [3, 0, 4, 0],                 ! DISK NUMBER
;  0358  0             HWP_DISK_TYPE   = [3, 4, 1, 0],                 ! DISK TYPE
;  0359  0             HWP_DISK_DUPEX  = [3, 5, 1, 0],                 !RUN DUP EXERCISER              !ZZZ
;  0360  0             HWP_DISK_DUPWT  = [3, 6, 1, 0],                 !DUP WRITE FLAG                 !ZZZ
;  0361  0             HWP_ENTIRE      = [3, 7, 1, 0],                 !TEST ENTIRE DISK               !ZZZ
;  0362  0             HWP_DISK_CP     = [3, 15, 1, 0],                ! PROTECT CUSTOMER DATA BIT
;  0363  0             HWP_BEG_TRK     = [4, 0, 16, 0],                ! BEGINNING TRACK LO            !ZZZ
;  0364  0             HWP_BEG_TRK1    = [5, 0, 16, 0],                ! BEGINNING TRACK HI            !ZZZ
;  0365  0             HWP_END_TRK     = [6, 0, 16, 0],                ! ENDING TRACK LO               !ZZZ
;  0366  0             HWP_END_TRK1    = [7, 0, 16, 0]                 ! ENDING TRACK HI               !ZZZ
;  0367  0             tes,
;  0368  0     !
;  0369  0     !****** COMMUNICATION AREA HEADER FIELDS
;  0370  0     !
;  0371  0     COM_FIELDS =
;  0372  0             set
;  0373  0             ADAP_CH         = [1, 8, 8, 0],                 ! ADAPTER CHANNEL NUMBER FOR PURGES
;  0374  0             CMD_INT         = [2, 0, 16, 0],                ! COMMAND RING INTERRUPT
;  0375  0             RSP_INT         = [3, 0, 16, 0]                 ! RESPONSE RING INTERRUPT
;  0376  0             tes,
;  0377  0
;  0378  0     !                                                               ZZZ
;  0379  0     !       DUP BUFFER FIELD                                        ZZZ
;  0380  0     !                                                               ZZZ
;  0381  0     DP_FIELDS =                                                    !ZZZ
;  0382  0             SET                                                    !ZZZ
;  0383  0             DUPBF0          = [0, 0, 16, 0],                       !ZZZ
;  0384  0             DUPBF1          = [1, 0, 16, 0],                       !ZZZ
;  0385  0             DUPBF2          = [2, 0, 16, 0],                       !ZZZ
;  0386  0             DUPTYPE         = [0, 12, 4, 0],                       !ZZZ
;  0387  0             DUPMESG         = [0, 0, 12, 0]                        !ZZZ
;  0388  0             TES,                                                   !ZZZ
;  0389  0
;  0390  0
;  0391  0     !****** CONTROLLER STATUS TABLE (CST) FIELDS
;  0392  0     !
;  0393  0     CST_FIELDS =
```

```
;  0394  0              set
;  0395  0              IP_ADDR          = [0, 0, 16, 0],                    ! IP ADDRESS
;  0396  0              VEC_ADDR         = [1, 0, 9, 0],                     ! VECTOR ADDRESS
;  0397  0              STATE            = [1, 15, 1, 0],                    ! CONTROLLER STATUS
;  0398  0              BR_LEV           = [2, 0, 8, 0],                     ! BUS REQUEST LEVEL
;  0399  0              U_CNT            = [2, 8, 8, 0]                      ! NUMBER OF UNITS (DISKS) FOR THIS CONTROLLER
;  0400  0      !
;  0401  0      !       DO_ALL           = [3, 0, 16, 0],                    ! DISK 0 (ALL FIELDS)
;  0402  0      !       DO_DISK_NUM      = [3, 0, 4, 0],                     ! DISK NUMBER
;  0403  0      !       DO_TYPE          = [3, 4, 1, 0],                     ! DISK TYPE
;  0404  0      !       DO_UNIT          = [3, 8, 4, 0],                     ! DISK 0 UNIT NUMBER (DRS UNIT)
;  0405  0      !       DO_FATAL         = [3, 12, 1, 0],                    ! DISK 0 FATAL ERROR BIT
;  0406  0      !       DO_STAT          = [3, 13, 1, 0],                    ! DISK 0 STATUS BIT
;  0407  0      !       DO_PRES          = [3, 14, 1, 0],                    ! DISK 0 PRESENT BIT
;  0408  0      !       DO_PROT          = [3, 15, 1, 0],                    ! DK 0 PROTECT CUSTOMER DATA
;  0409  0      !       DO_BEG0          = [4, 0, 16, 0],      !DK 0 BEGIN TK LO          ZZZ
;  0410  0      !       DO_BEG1          = [5, 0, 16, 0],      !DK 0 BEGIN TK HI          ZZZ
;  0411  0      !       DO_END0          = [6, 0, 16, 0],      !DK 0 END T'( LO           ZZZ
;  0412  0      !       DO_END1          = [7, 0, 16, 0],      !DK 0 END TK HI            ZZZ
;  0413  0      !       DO_NAME0         = [8, 0, 8, 0],       !DK 0 MANE BYTE 0          ZZZ
;  0414  0      !       DO_NAME1         = [8, 8, 8, 0],       !DK 0 NAME BYTE 1          ZZZ
;  0415  0      !       DO_NAME2         = [9, 0, 8, 0],       !DK 0 NAME BYTE 2          ZZZ
;  0416  0      !       DO_NAME3         = [9, 8, 8, 0],       !DK 0 NAME BYTE 3          ZZZ
;  0417  0      !       DO_NUL           = [10, 0, 16, 0]      !NUL AFTER NAME            ZZZ
;  0418  0      !       DO_DBN           = [11, 0, 8, 0],      !DK 0 RELATIVE DBN         ZZZ
;  0419  0      !       DO_WRITE         = [11, 12, 1, 0],     !DK 0 DUP WRITE FLAG       ZZZ
;  0420  0      !       DO_ACTIVE        = [11, 13, 1, 0],     !DK 0 ACTIVE FLAG          ZZZ
;  0421  0      !       DO_DUPERROR      = [11, 14, 1, 0],     !DK 0 DUP ERROR FLAG       ZZZ
;  0422  0      !       DONODUPMED       = [11, 15, 1, 0],     !DK 0 NO DUP MEDIA FLAG    ZZZ
;  0423  0      !       DO_COUNT         = [12, 0, 16, 0],     !DK 0 RELATIVE MSCP FUN-   ZZZ
;  0424  0      !                                                    CTION COUNTER         ZZZ
;  0425  0      !                                                                          ZZZ
;  0426  0      !       ! REPEAT WORDS 3 THROUGH 12 ABOVE AS: !                            ZZZ
;  0427  0      !       ! WORDS 13 THROUGH 21 FOR DRIVE 1     !                            ZZZ
;  0428  0      !       ! WORDS 22 THROUGH 30 FOR DRIVE 2     !                            ZZZ
;  0429  0      !       ! WORDS 31 THROUGH 39 FOR DRIVE 3     !                            ZZZ
;  0430  0      !       !                                     !                            ZZZ
;  0431  0      !                                                                          ZZZ
;  0432  0              tes.
;  0433  0      !
;  0434  0      !****** MSCP PACKET FIELDS
;  0435  0      !               (NOTE: BASE ADDRESS OF PACKET REFERENCES THE PACKET'S OWN
;  0436  0      !               BUFFER DESCRIPTOR, RATHER THAN THE MESSAGE BODY (TEXT + 0).
;  0437  0      !               SEE DOCUMENTATION FOR LAYOUT OF MSCP PACKETS.)
;  0438  0      !
;  0439  0      PKT_FIELDS =
;  0440  0              set
;  0441  0      !
;  0442  0      !       HEADER FIELDS
;  0443  0      !
;  0444  0              PKT_LO           = [0, 0, 16, 0],                    ! PACKET DESCRIPTOR (LO ORDER)
;  0445  0              PKT_HI           = [1, 0, 16, 0],                    ! PACKET DESCRIPTOR (HI ORDER - ALL FIELDS)
;  0446  0              PKT_U            = [1, 0, 2  0],                     ! PACKET DESCRIPTOR (HI ORDER UNIBUS BITS)
```

```
;  0447  0              PKT_Q           = [1, 2, 4, 0],                     ! PACKET DESCRIPTOR (HI ORDER Q-BUS BITS)
;  0448  0              PKT_F           = [1, 14, 1, 0],                    ! PACKET DESCRIPTOR FLAG BIT
;  0449  0              PKT_O           = [1, 15, 1, 0],                    ! PACKET DESCRIPTOR OWNERSHIP BIT
;  0450  0              CMD_TYPE        = [2, 0, 8, 0],                     ! COMMAND TYPE
;  0451  0              RSP_RECEIVED    = [2, 8, 8, 0],                     ! FLAG SET IF RESPONSE TO COMMAND RECEIVED
;  0452  0              MSGLEN          = [3, 0, 16, 0],                    ! MESSAGE LENGTH
;  0453  0              CREDITS         = [4, 0, 4, 0],                     ! CREDITS
;  0454  0              MSGTYP          = [4, 4, 4, 0],                     ! MESSAGE TYPE
;  0455  0              CONNID          = [4, 8, 8, 0],                     ! CONNECTION ID
;  0456  0      !
;  0457  0      !       GENERIC COMMAND PACKET AND END PACKET HEADER FILEDS
;  0458  0      !
;  0459  0              CRN_LO          = [5, 0, 16, 0],                    ! COMMAND REF NUMBER (LO ORDER)
;  0460  0              CRN_HI          = [6, 0, 16, 0],                    ! COMMAND REF NUMBER (HI ORDER)
;  0461  0              DK_NUM          = [7, 0, 16, 0],                    ! DISK ADDRESS (RD/RX DISK NUMBER)
;  0462  0              OPCODE          = [9, 0, 8, 0],                     ! OPCODE AND ENDCODE
;  0463  0              MODIFY          = [10, 0, 16, 0],                   ! COMMAND MODIFIERS
;  0464  0              STATUS_CODE     = [10, 0, 5, 0],                    ! STATUS (PART OF RESPONSE PACKET)
;  0465  0              STATUS_SUBCODE  = [10, 5, 11, 0],                   ! SUBCODE (PART OF RESPONSE PACKET)
;  0466  0      !
;  0467  0      !       READ, WRITE, AND ACCESS COMMAND FIELDS (FOR COMMAND AND END PACKETS)
;  0468  0      !
;  0469  0              BC_LO           = [11, 0, 16, 0],                   ! BYTE COUNT (LO ORDER)
;  0470  0              BC_HI           = [12, 0, 16, 0],                   ! BYTE COUNT (HI ORDER)
;  0471  0              BUF_0           = [13, 0, 16, 0],                   ! I/O BUFFER DESCRIPTOR
;  0472  0              BUF_1           = [14, 0, 16, 0],                   !       :
;  0473  0              BUF_2           = [15, 0, 16, 0],                   !       :
;  0474  0              BUF_3           = [16, 0, 16, 0],                   !       :
;  0475  0              BUF_4           = [17, 0, 16, 0],                   !       :
;  0476  0              BUF_5           = [18, 0, 16, 0],                   !       V
;  0477  0              LBN_L           = [19, 0, 16, 0],                   ! LOGICAL BLOCK NUMBER (LO ORDER)
;  0478  0              LBN_H           = [20, 0, 16, 0],                   ! LOGICAL BLOCK NUMBER (HI ORDER)
;  0479  0
;  0480  0      !
;  0481  0      ! DUP PROGRAM LETTER FIELDS (FOR EXECUTE LOCAL PROGRAM CMD)                  ZZZ
;  0482  0      !                                                                           ZZZ
;  0483  0              L1              = [11, 0, 8, 0],        !LETTER NO 1               ZZZ
;  0484  0              L2              = [11, 8, 8, 0],        !LETTER NO 2               ZZZ
;  0485  0              L3              = [12, 0, 8, 0],        !LETTER NO 3               ZZZ
;  0486  0              L4              = [12, 8, 8, 0],        !LETTER NO 4               ZZZ
;  0487  0              L5              = [13, 0, 8, 0],        !LETTER NO 5               ZZZ
;  0488  0              L6              = [13, 8, 8, 0],        !LETTER NO 6               ZZZ
;  0489  0      !
;  0490  0      !       SET CONTROLLER CHARACTERISTICS COMMAND FIELDS
;  0491  0      !
;  0492  0              C_FLAGS         = [12, 0, 16, 0],                   ! CONTROLLER FLAGS
;  0493  0      !
;  0494  0      !       ONLINE COMMAND FIELDS
;  0495  0      !
;  0496  0              U_FLAGS         = [12, 0, 16, 0],                   ! UNIT FLAGS
;  0497  0              DDPAR           = [19, 0, 16, 0]                    ! DEVICE-DEPENDENT PARAMETERS
;  0498  0              tes,
;  0499  0      !
```

```
;  0500  0     !****** RETURN PACKET (RETPKT) FIELDS
;  0501  0     !                (SIMILAR, BUT NOT IDENTICAL, TO MSCP PACKET FIELDS)
;  0502  0     !
;  0503  0     RP_FIELDS =
;  0504  0             set
;  0505  0     !
;  0506  0     !       COMMON TO ALL RETURN PACKETS FROM DISK MSCP
;  0507  0     !
;  0508  0             MESLEN          = [0, 0, 16, 0],                ! MESSAGE LENGTH
;  0509  0             CTLR            = [1, 0, 4, 0],                 ! CONTROLLER NUMBER (CREDITS OVERWRITTEN)
;  0510  0             MESTYP          = [1, 4, 4, 0],                 ! MESSAGE TYPE
;  0511  0             CONID           = [1, 8, 8, 0],                 ! CONNECTION ID
;  0512  0             CRF_LO          = [2, 0, 16, 0],                ! COMMAND REFERENCE NUMBER (LO ORDER)
;  0513  0             CRF_HI          = [3, 0, 16, 0],                ! COMMAND REFERENCE NUMBER (HI ORDER)
;  0514  0             DISK            = [4, 0, 16, 0],                ! DISK ADDRESS (RD/RX DISK NUMBER)
;  0515  0             CMDMOD          = [5, 0, 16, 0],                ! COMMAND MODIFIERS
;  0516  0             ENDCOD          = [6, 0, 8, 0],                 ! END CODE
;  0517  0             FLAGS           = [6, 8, 8, 0],                 ! FLAGS
;  0518  0             STATUS          = [7, 0, 16, 0],                ! STATUS AND SUB-CODE
;  0519  0             STSCOD          = [7, 0, 5, 0],                 ! STATUS CODE
;  0520  0             SUBCOD          = [7, 5, 11, 0],                ! SUB-CODE
;  0521  0     !
;  0522  0     !       READ, WRITE, AND ACCESS COMMAND RETURN PACKETS
;  0523  0     !
;  0524  0             BCNT_LO         = [8, 0, 16, 0],                ! BYTE COUNT (LO ORDER)
;  0525  0             BCNT_HI         = [9, 0, 16, 0],                ! BYTE COUNT (HI ORDER)
;  0526  0             BUFF_0          = [10, 0, 16, 0],               ! I/O BUFFER DESCRIPTOR (WORD 0)
;  0527  0             BUFF_1          = [11, 0, 16, 0],               ! I/O BUFFER DESCRIPTOR (WORD 1)
;  0528  0             BUFF_2          = [12, 0, 16, 0],               ! I/O BUFFER DESCRIPTOR (WORD 2)
;  0529  0             BUFF_3          = [13, 0, 16, 0],               ! I/O BUFFER DESCRIPTOR (WORD 3)
;  0530  0             BUFF_4          = [14, 0, 16, 0],               ! I/O BUFFER DESCRIPTOR (WORD 4)
;  0531  0             BUFF_5          = [15, 0, 16, 0],               ! I/O BUFFER DESCRIPTOR (WORD 5)
;  0532  0             BBLK_LO         = [16, 0, 16, 0],               ! FIRST BAD BLOCK (LO ORDER)
;  0533  0             BBLK_HI         = [17, 0, 16, 0],               ! FIRST BAD BLOCK (HI ORDER)
;  0534  0             CBCNT_LO        = [18, 0, 16, 0],               ! BYTE COUNT FROM CMD PACKET (LO ORDER)
;  0535  0             CBCNT_HI        = [19, 0, 16, 0],               ! BYTE COUNT FROM CMD PACKET (HI ORDER)
;  0536  0             LBN_LO          = [20, 0, 16, 0],               ! LOGICAL BLOCK NUMBER (LO ORDER)
;  0537  0             LBN_HI          = [21, 0, 16, 0],               ! LOGICAL BLOCK NUMBER (HI ORDER)
;  0538  0     !
;  0539  0     !       SET CONTROLLER CHARACTERISTICS RETURN PACKET
;  0540  0     !
;  0541  0             C_FLGS          = [9, 0, 16, 0],                ! CONTROLLER FLAGS
;  0542  0             C_TIME          = [10, 0, 16, 0],               ! CONTROLLER TIMEOUT
;  0543  0     !
;  0544  0     !       UNIT ONLINE RETURN PACKET
;  0545  0     !
;  0546  0             U_FLGS          = [9, 0, 16, 0],                ! UNIT FLAGS
;  0547  0             R_MODEL         = [13, 0, 8, 0],                ! 2 DIGIT MODEL NUMBER                          ZZZ
;  0548  0             NAME_NUM        = [14, 0, 6, 0],                ! MODEL NAME - 2 DIGIT NUMBER
;  0549  0             NAME_1_LO       = [14, 12, 4, 0],               ! MODEL NAME - 2ND CHARACTER (LOW  ORDER 4 BITS)
;  0550  0             NAME_1_HI       = [15, 0, 1, 0],                ! MODEL NAME - 2ND CHARACTER (HIGH ORDER 1 BIT)
;  0551  0             NAME_0          = [15, 1, 5, 0],                ! MODEL NAME - 1ST CHARACTER
;  0552  0     !ZZZ    USIZ_LO         = [18, 0, 16, 0],               ! UNIT SIZE (LO ORDER)
```

```
;  0553  0     'ZZZ    USIZ_HI         = [19, 0, 16, 0],                ! UNIT SIZE (HI ORDER)
;  0554  0             SIZE0           = [18, 0, 16, 0],                !LOWER WD OF MAX LBNS OR UNIT SIZE          ZZZ
;  0555  0             SIZE1           = [19, 0, 16, 0]                 !UPPER WD     "          "       "          ZZZ
;  0556  0             tes,
;  0557  0     !
;  0558  0     !****** STATISTICS TABLE (TALLY) FIELDS
;  0559  0     !
;  0560  0     T_FIELDS =
;  0561  0             set
;  0562  0             BYTES_READ_LO   = [0, 0, 16, 0],                 ! NUMBER OF BYTES READ (LO ORDER)
;  0563  0             BYTES_READ_HI   = [1, 0, 16, 0],                 ! NUMBER OF BYTES READ (HI ORDER)
;  0564  0             MBYTES_READ     = [2, 0, 16, 0],                 ! MEGABYTES READ
;  0565  0             BYTES_WRIT_LO   = [3, 0, 16, 0],                 ! NUMBER OF BYTES WRITTEN (LO ORDER)
;  0566  0             BYTES_WRIT_HI   = [4, 0, 16, 0],                 ! NUMBER OF BYTES WRITTEN (HI ORDER)
;  0567  0             MBYTES_WRIT     = [5, 0, 16, 0],                 ! MEGABYTES WRITTEN
;  0568  0             ERR_HARD        = [6, 0, 16, 0],                 ! NUMBER OF HARD ERRORS
;  0569  0     !
;  0570  0             TOT_READS_LO    = [7, 0, 16, 0],                 ! TOTAL NUMBER OF READS (LO ORDER)
;  0571  0             TOT_READS_HI    = [8, 0, 16, 0],                 ! TOTAL NUMBER OF READS (HI ORDER)
;  0572  0             TOT_WRITES_LO   = [10, 0, 16, 0],                ! TOTAL NUMBER OF WRITES (LO ORDER)
;  0573  0             TOT_WRITES_HI   = [11, 0, 16, 0],                ! TOTAL NUMBER OF WRITES (HI ORDER)
;  0574  0             TOT_BYT_RED_LO  = [13, 0, 16, 0],                ! TOTAL BYTES READ (LO ORDER)
;  0575  0             TOT_BYT_RED_HI  = [14, 0, 16, 0],                ! TOTAL BYTES READ (HI ORDER)
;  0576  0             MTOT_BYT_RED    = [15, 0, 16, 0],                ! TOTAL MEGABYTES READ
;  0577  0             TOT_BYT_WRT_LO  = [16, 0, 16, 0],                ! TOTAL BYTES WRITTEN (LO ORDER)
;  0578  0             TOT_BYT_WRT_HI  = [17, 0, 16, 0],                ! TOTAL BYTES WRITTEN (HI ORDER)
;  0579  0             MTOT_BYT_WRT    = [18, 0, 16, 0],                ! TOTAL MEGABYTES WRITTEN
;  0580  0             ERR_HRD_SEK     = [19, 0, 8, 0],                 ! TOTAL HARD ERRORS - SEEK
;  0581  0             ERR_HRD_DAT     = [19, 8, 8, 0],                 ! TOTAL HARD ERRORS - DATA
;  0582  0             ERR_HRD_DRV     = [20, 0, 8, 0],                 ! TOTAL HARD ERRORS - DRIVE
;  0583  0             ERR_HRD_HST     = [20, 8, 8, 0],                 ! TOTAL HARD ERRORS - HOST
;  0584  0             ERR_SFT_SEK     = [21, 0, 8, 0],                 ! TOTAL SOFT ERRORS - SEEK
;  0585  0             ERR_SFT_DAT     = [21, 8, 8, 0],                 ! TOTAL SOFT ERRORS - DATA
;  0586  0             ERR_SFT_DRV     = [22, 0, 8, 0],                 ! TOTAL SOFT ERRORS - DRIVE
;  0587  0             ERR_SFT_HST     = [22, 8, 8, 0],                 ! TOTAL SOFT ERRORS - HOST
;  0588  0             T_BLK_WT        = [23, 0,16, 0],                 !                            ZZZ
;  0589  0             T_DBN_WT        = [24, 0,16, 0],                 !DBNS WRITTEN                ZZZ
;  0590  0             T_BLK_RD        = [25, 0,16, 0],                 !                            ZZZ
;  0591  0             T_DBN_RD        = [26, 0,16, 0]                  !DBNS READ                   ZZZ
;  0592  0
;  0593  0             tes,
;  0594  0     !
;  0595  0     !****** CONTROLLER ERROR TALLY FIELDS
;  0596  0     !
;  0597  0     C_ERR_FIELDS =
;  0598  0             set
;  0599  0             C_ERR_HRD       = [0, 0, 8, 0],                  ! HARD ERRORRS
;  0600  0             C_ERR_SFT       = [0, 8, 8, 0]                   ! SOFT ERRORS
;  0601  0             tes,
;  0602  0     !
;  0603  0     !****** DRIVER CONTROLLER TABLE (DCT) FIELDS
;  0604  0     !
;  0605  0     DCT_FIELDS =
```

```
;  0606  0              set
;  0607  0              WORD0           = [0, 0, 16, 0],        ! ALL FIELDS IN WORD 0
;  0608  0              CRING_CNT       = [0, 0, 8, 0],         ! NUMBER OF SLOTS IN CRING NOT YET RETURNED TO HOST
;  0609  0              IG_INT          = [0, 14, 1, 0],        ! IGNORE INTERRUPT BIT
;  0610  0              STAT            = [0, 15, 1, 0],        ! ONLINE / OFFLINE STATUS
;  0611  0              SA_SAVE         = [1, 0, 16, 0],        ! SA REGISTER SAVE WORD
;  0612  0              RR_BEG          = [2, 0, 16, 0],        ! FIXED ADDRESSES OF START AND
;  0613  0              RR_END          = [3, 0, 16, 0],        !       END OF EACH RING
;  0614  0              CR_BEG          = [4, 0, 16, 0],        !             :
;  0615  0              CR_END          = [5, 0, 16, 0],        !             V
;  0616  0              RR_POLL         = [6, 0, 16, 0],        ! ADDR OF NEXT RRING SLOT TO BE POLLED
;  0617  0              CR_POLL         = [7, 0, 16, 0],        ! ADDR OF NEXT CRING SLOT TO BE POLLED
;  0618  0              CR_NEXT         = [8, 0, 16, 0]         ! ADDR OF NEXT AVAIL CRING SLOT
;  0619  0              tes,
;  0620  0      !
;  0621  0      !****** ERROR LOG PACKET SAVE AREA FIELDS
;  0622  0      !
;  0623  0      EP_FIELDS =
;  0624  0              set
;  0625  0              EL_CNTR         = [0, 0, 8, 0],         ! CONTROLLER NUMBER
;  0626  0              EL_CONTENTS     = [0, 8, 8, 0],         ! FLAG INDICATES IF PACKET CONTENTS ALREADY PRINTED
;  0627  0              EL_MSGLEN       = [1, 0, 16, 0],        ! PACKET LENGTH
;  0628  0              EL_CRN_LO       = [3, 0, 16, 0],        ! COMMAND REFERENCE NUMBER
;  0629  0              EL_CRN_HI       = [4, 0, 16, 0],        !
;  0630  0              EL_DK_NUM       = [5, 0, 16, 0],        ! DISK ADDRESS (RD/RX DISK NUMBER)
;  0631  0              EL_FORMAT       = [7, 0, 8, 0],         ! FORMAT
;  0632  0              EL_EDR          = [7, 12, 1, 0],        ! ERROR DURING REPLACEMENT FLAG MMM
;  0633  0              EL_BRR          = [7, 13, 1, 0],        ! BAD BLOCK REPLACEMENT REQUEST FLAG  MMM
;  0634  0              EL_CONTINUE     = [7, 14, 1, 0],        ! CONTINUE FLAG
;  0635  0              EL_SUCCESS      = [7, 15, 1, 0],        ! SUCCESS FLAG
;  0636  0              EL_CODE         = [8, 0, 5, 0],         ! ERROR CODE
;  0637  0              EL_SUBCODE      = [8, 5, 11, 0],        ! SUB CODE
;  0638  0              EL_RETRY        = [20, 8, 8, 0],        ! RETRY COUNT
;  0639  0              EL_BLOCK        = [23, 0, 16, 0],       ! BLOCK NUMBER
;  0640  0              EL_BLOCK_HI     = [24, 0, 12, 0],       !HIGH BITS OF BLOCK NUMBER                      ZZZ
;  0641  0              EL_BLOCK_TYPE   = [24, 12, 4, 0]        ! TYPE OF BLOCK NUMBER INFO RETURNED
;  0642  0              tes,
;  0643  0      !
;  0644  0      !****** INFORMATION ABOUT LAST RESPONSE PACKET
;  0645  0      !
;  0646  0      LAST_PKT_FIELDS =
;  0647  0              set
;  0648  0              LAST_HRD_ERR    = [0, 0, 16, 0],        ! FLAG INDICATES IF HARD ERROR OCCURED
;  0649  0              LAST_CRN_LO     = [1, 0, 16, 0],        ! COMMAND REFERENCE NUMBER
;  0650  0              LAST_CRN_HI     = [2, 0, 16, 0]         !
;  0651  0              tes,
;  0652  0      !
;  0653  0      !****** RDRX REGISTER FIELDS
;  0654  0      !
;  0655  0      RC_REG =
;  0656  0              set
;  0657  0              RC_ALL          = [0, 16, 0]            ! DEFINE ALL BITS
;  0658  0              tes;
```

```
;   0659  0     !*****************************************************************************
;   0660  0     !                                                                            *
;   0661  0     !                          M A C R O S                                       *
;   0662  0     !                                                                            *
;   0663  0     !*****************************************************************************
;   0664  0     !
;   0665  0     macro
;   0666  0     !
;   0667  0     !****** CST FIELDS. MODEL FOR WDS 3-12, 13-21, 22-30, AND 31-39.        ZZZ
;   0668  0     !
;   0669  0             D_ALL           = 0, 16, 0%,                        ! ALL FIELDS
;   0670  0             D_DISK_NUM      = 0, 4, 0%,                         ! DISK ADDRESS
;   0671  0             D_TYPE          = 4, 1, 0%,                         !DISK TYPE - 1 BIT        ZZZ
;   0672  0             D_UNIT          = 8, 4, 0%,                         ! DISK UNIT NUMBER (DRS UNIT)
;   0673  0             D_FATAL         = 12, 1, 0%,                        ! FATAL ERROR BIT
;   0674  0             D_STAT          = 13, 1, 0%,                        ! DISK STATUS BIT
;   0675  0             D_PRES          = 14, 1, 0%,                        ! DISK PRESENT BIT
;   0676  0             D_PROT          = 15, 1, 0%,                        ! DISK PROTECTION BIT
;   0677  0             D_BEG0          = 0, 16, 0%,        !BEGIN TRACK LO           ZZZ
;   0678  0             D_BEG1          = 0, 16, 0%,        !BEGIN TRACK HI           ZZZ
;   0679  0             D_END0          = 0, 16, 0%,        !END TRACK LO             ZZZ
;   0680  0             D_END1          = 0, 16, 0%,        !END TRACK HI             ZZZ
;   0681  0             D_NAME_0        = 0, 8, 0%,         ! NAME (FIRST  CHARACTER)
;   0682  0             D_NAME_1        = 8, 8, 0%,         ! NAME (SECOND CHARACTER)
;   0683  0             D_NAME_2        = 0, 8, 0%,         ! NAME (THIRD  CHARACTER)
;   0684  0             D_NAME_3        = 8, 8, 0%,         ! NAME (FOURTH CHARACTER)
;   0685  0     !       D_NUL           = 0, 16, 0%,        !NUL AFTER NAME           ZZZ
;   0686  0             D_DBN           = 0, 8, 0%,         !RELATIVE DBN             ZZZ
;   0687  0             DUPWRITE        = 12, 1, 0%,        !DUP WRITE FLAG           ZZZ
;   0688  0             D_ACTIVE        = 13, 1, 0%,        !ACTIVE STATE             ZZZ
;   0689  0             DUPERROR        = 14, 1, 0%,        !DUP ERROR FLAG           ZZZ
;   0690  0             NODUPMEDIA      = 15, 1, 0%,        !NO DUP MEDIA             ZZZ
;   0691  0             D_COUNT         = 0, 16, 0%,        !MSCP FUNCTION COUNTER    ZZZ
;   0692  0
;   0693  0
;   0694  0     !************ BST FIELDS **************                                   ZZZ
;   0695  0     !                                                                       ZZZ
;   0696  0             HI_WRD          = 1, 0, 16, 0%,     !HI LBN                   ZZZ
;   0697  0             LO_WRD          = 0, 0, 16, 0%,     !LO LBN                   ZZZ
;   0698  0     !
;   0699  0     !****** BIT TEST
;   0700  0     !               (CAUTION: THE FIRST ARGUMENT IS THE ADDRESS AND NOT THE CONTENTS)
;   0701  0     !
; M 0702  0     BIT_TST (ADDR, EXPECTED) =
; M 0703  0         (if (.ADDR and EXPECTED) eql EXPECTED
; M 0704  0         then
; M 0705  0             TRUE
; M 0706  0         else
;   0707  0             FALSE )%,
;   0708  0     !
;   0709  0     !****** RDRX WRITE
;   0710  0     !
; M 0711  0     WRT_RDRX (0, FIELDNAM, IMAGE) =
```

```
;  M 0712  0          begin
;  M 0713  0          local
;  M 0714  0              RC_REG;
;  M 0715  0          RC_REG <%fieldexpand (FIELDNAM)> = .IMAGE;
;  M 0716  0          (.RDRX_ADDR + (%upval * 0)) = .RC_REG;
;    0717  0          end%;
```

```
;    0718  0     !**************************************************************************************
;    0719  0     !                                                                                     *
;    0720  0     !                          S T R U C T U R E S                                        *
;    0721  0     !                                                                                     *
;    0722  0     !**************************************************************************************
;    0723  0     !
;    0724  0     !****** NIBBLE (4-BIT) VECTOR STRUCTURE
;    0725  0     !
;    0726  0     !structure
;    0727  0     !    NIBVECTOR [I; N] =
;    0728  0     !        [(N + 1) / 2]
;    0729  0     !        (NIBVECTOR + I / 2) <(I + 2) and 4, 4>;
;    0730  0     !
;    0731  0     !****** RDRX ACCESS ALGORITHM
;    0732  0     !
;    0733  0     structure
;    0734  0         RDRX [O, P, S, E] =
;    0735  1             begin
;    0736  1             local
;    0737  1                 RC_REG;
;    0738  1             RC_REG = .(RDRX + %upval * O) <O, %bpval, O>;
;    0739  1             RC_REG
;    0740  1             end
;    0741  0             <P, S, E>;
;
;                                        COMMAND QUALIFIERS
;
;       BLISS/PDP11 ZRQAH0.REQ/LIST=ZRQAH0.LIS/LIBRARY=ZRQAH0.L16/SOURCE=PAGE:53
;
; Run Time:          00:04.7
; Elapsed Time:      00:16.0
; Lines/CPU Min:      9540
; Lexemes/CPU-Min: 50317
; Memory Used:   73 pages
; Library Precompilation Complete
```

```
;  C 0053  1
;  C 0054  1
;  C 0055  1               REVISION HISTORY:
;  C 0056  1
;  C 0057  1               REV 1.6    11-APR-84   MERGED FIELD AND MANUFACTURING VERSIONS OF THF RD/RX EXERCISER.
;  C 0058  1                                      ADDED SUPPORT FOR THE RUX50.
;  C 0059  1
;  C 0060  1               REV 1.7    01-MAY-84   ADDED CODE TO GET DEVICE TYPE FROM CONTROLLER CHARACTERISTICS;
;  C 0061  1                                      ADDED APT BREAKS IN UNIT_INIT ROUTINE; CORRECTED SOFT SEEK ERROR
;  C 0062  1                                      TOTALS; PROTECT MEDIA ON DEFAULT.
;  C 0063  1
;  C 0064  1               REV 1.8    06-JUL-84   ELIMINATE GETTING DISK TYPE FROM ID BLOCK ON A RESTART;
;  C 0065  1
;  C 0066  1               REV 1.9    19-SEP-84   ON END OF PASS, WAIT UNTIL LAST PACKET RETURNED BEFORE WRITING IP.

;  C 0067  1
;  C 0068  1               REV 2.0    09-NOV-84   DON'T OUTPUT DUP STATS HEADER IF NO WINCHESTER.
;  C 0069  1                                      FIXED 'CMD REF NO. NOT SENT BY HOST' PROBLEM BY USING OPERATOR-
;  C 0070  1                                      SPECIFIED BR LEVEL WHEN SENDING PACKETS.
;  C 0071  1
;  C 0072  1               REV 2.1    27-DEC-84   ADDED APT MODE QUESTION; ADDED RETRIES TO DUP TESTS. ADDED CODE TO
;  C 0073  1                                      INT_GEN ROUTINE TO MAKE IT COMPATIBLE WITH MICROCODE VERSION 9.1.
;  C 0074  1
;  C 0075  1               REV 2.2    04-APR-85   IN POLL_RRING AND POLL_CRING ROUTINES, ZERO INTERRUPT COUNTERS ON
;  C 0076  1                                      ENTRY TO PREVENT SLOWDOWN PROBLEM. ADDED 32-BIT LBN ADDRESSING.
;  C 0077  1                                      CHANGED HEADER MACRO AND .REQ FILE FOR COMPATIBILITY WITH XXDP V2.
;  C 0078  1                                      MADE DUP COMMAND TYPE = 0.
;  C 0079  1
;  C 0080  1               REV 2.3    17-JUN-85   ADDED CODE TO HANDLE DUP'S OUT OF RANGE STATUS. REPORT BOTH WORDS
;  C 0081  1                                      OF LBN ADDRESS IN ERROR MESSAGES. ACCESS LBNS 0 AND 100 IN ACCESS
;  C 0082  1                                      ROUTINE.
;  C 0083  1
;  C 0084  1               REV 2.4    18-JUN-85   ADD AND REARRANGE APT BREAKS FOR APT COMPATIBILITY.  BALANCE RATIO
;  C 0085  1                                      OF READS TO WRITES (2:1) WHEN RUNNING WITH FASTER CPU.  PRINT DUP
;  C 0086  1                                      FATAL MESSAGE NUMBER.  INCLUDE DUP FATAL MESSAGE, ERROR CODE 5.
;  C 0087  1                                      COUNT "ZERO FILL" AS DATA TRANSFERED ON PARTIAL BLOCK TRANSFERS
;  C 0088  1                                      FOR DISK ERROR RATE CALCULATION.
;  C 0089  1
;  C 0090  1               REV 2.5    27-JUN-85   QIO_OK WILL BE TRUE WHEN QIO COUNT IS LESS THAN COMMAND RING - 2
;  C 0091  1                                      TO AVOID DISCARDING PACKECTS AND HENCE SEQUENTIAL AND RANDOM
;  C 0092  1                                      NUMBERS DURING OPERATION.  REMOVE DUP AND PLACE INTO ANOTHER
;  C 0093  1                                      EXERCISER.
;  C 0094  1
```

```
;  C 0095  1
;  C 0096  1                        TABLE OF CONTENTS
;  C 0097  1
;  C 0098  1
;  C 0099  1
;  C 0100  1                1.0     GENERAL INFORMATION
;  C 0101  1                1.1     PROGRAM ABSTRACT
;  C 0102  1                1.2     SYSTEM REQUIREMENTS
;  C 0103  1                1.2.1   HARDWARE REQUIREMENTS
;  C 0104  1                1.2.2   SOFTWARE REQUIREMENTS
;  C 0105  1                1.3     RELATED DOCUMENTS AND STANDARDS
;  C 0106  1                1.4     DIAGNOSTIC HIERARCHY PREREQUISITES
;  C 0107  1                1.5     ASSUMPTIONS
;  C 0108  1                1.6     MEMORY MAP
;  C 0109  1
;  C 0110  1                2.0     OPERATING INSTRUCTIONS
;  C 0111  1                2.1     HARDWARE QUESTIONS
;  C 0112  1                2.2     SOFTWARE QUESTIONS
;  C 0113  1
;  C 0114  1                3.0     ERROR TYPES
;  C 0115  1                3.1     ERROR INFORMATION
;  C 0116  1                3.2     INITIALIZATION ERRORS
;  C 0117  1                3.3     EXERCISER ERRORS
;  C 0118  1                3.4     ERROR LOG MESSAGES
;  C 0119  1                3.5     MSCP ERRORS
;  C 0120  1                3.6     SAMPLE ERROR STATEMENT
;  C 0121  1
;  C 0122  1                4.0     PERFORMANCE AND PROGRESS REPORTS
;  C 0123  1
;  C 0124  1                5.0     TEST SUMMARY
;  C 0125  1                5.1     INITIALIZATION SUBTEST
;  C 0126  1                5.2     EXERCISER
;  C 0127  1                5.3     DROP UNIT SUMMARY
;  C 0128  1
;  C 0129  1                6.0     ERROR CODES
;  C 0130  1
;  C 0131  1                7.0     DATA PATTERNS
```

```
; C 0132  1               1.0   GENERAL INFORMATION
; C 0133  1                     ------------------
; C 0134  1
; C 0135  1
; C 0136  1               1.1   PROGRAM ABSTRACT
; C 0137  1                     ---------------
; C 0138  1
; C C139  1                     This program will functionally verify and exercise RQDX
; C 0140  1                     or RUX50 Controller/Disk Drive subsystems. It is designed
; C 0141  1                     to verify that the subsystem is functioning correctly and
; C 0142  1                     operating within design specifications.
; C 0143  1
; C 0144  1
; C 0145  1
; C 0146  1               1.2   SYSTEM REQUIREMENTS
; C 0147  1                     ------------------
; C 0148  1
; C 0149  1               1.2.1 HARDWARE REQUIREMENTS
; C 0150  1                     --------------------
; C 0151  1
; C 0152  1                     LSI - 11/23 processor with 28K or more of memory, console
; C 0153  1                     device (eg. VT100) and RQDX or RUX50 controller board and
; C 0154  1                     attached RD51 or RD52 WINCHESTER drive(s) and RX-50 FLOPPY
; C 0155  1                     drive(s)
; C 0156  1
; C 0157  1               1.2.2 SOFTWARE REQUIREMENTS
; C 0158  1                     --------------------
; C 0159  1
; C 0160  1                     This diagnostic is designed to run with the Diagnostic
; C 0161  1                     Supervisor as described in paragraph 2.0.
; C 0162  1
; C 0163  1
; C 0164  1               1.3   RELATED DOCUMENTS AND STANDARDS
; C 0165  1                     -------------------------------
; C 0166  1
; C 0167  1                     XXDP+ SUPERVISOR/USERS MANUAL   CHAOS
; C 0168  1                     UQSSP UNIBUS/Q-BUS STORAGE SYSTEM  PORT
; C 0169  1                     MSCP  MASS STORAGE SYSTEM PROTOCOL
; C 0170  1
; C 0171  1               1.4   DIAGNOSTIC HIERARCHY PREREQUISITES
; C 0172  1                     ---------------------------------
; C 0173  1
; C 0174  1                     NONE
; C 0175  1
; C 0176  1
; C 0177  1               1.5   ASSUMPTIONS
; C 0178  1                     -----------
; C 0179  1
; C 0180  1                     The hardware, other than the subsystem being tested, is
; C 0181  1                     assumed to work properly. False errors may be reported if
; C 0182  1                     the processor, memory, etc., do not function properly.
```

```
; C 0183  1              1.6     MEMORY MAP
; C 0184  1                      ----------
; C 0185  1
; C 0186  1
; C 0187  1                      Memory layout on 28k machine - XXDP environment
; C 0188  1                      ----------------------------------------------
; C 0189  1
; C 0190  1                                                          ADDRESS
; C 0191  1
; C 0192  1                              +-------------------------+   160000
; C 0193  1                              !                         !
; C 0194  1                              !      XXDP+ MONITOR      !
; C 0195  1                              !                         !
; C 0196  1                              +-------------------------+
; C 0197  1                              !                         !
; C 0198  1                              !  XXDP+   TTY I/O AREA   !
; C 0199  1                              !                         !
; C 0200  1                              +-------------------------+
; C 0201  1                              !                         !
; C 0202  1                              !                         !
; C 0203  1                              !          DRS            !
; C 0204  1                              !                         !
; C 0205  1                              !                         !
; C 0206  1                              +-------------------------+   121000
; C 0207  1                              !                         !
; C 0208  1                              !       EXERCISER         !
; C 0209  1                              !                         !
; C 0210  1                              +-------------------------+   2000
; C 0211  1                              !                         !
; C 0212  1                              !         STACKS          !
; C 0213  1                              !                         !
; C 0214  1                              +-------------------------+   400
; C 0215  1                              !                         !
; C 0216  1                              !       VECTOR AREA       !
; C 0217  1                              !                         !
; C 0218  1                              +-------------------------+   0
; C 0219  1
; C 0220  1
; C 0221  1                      In a machine  with more memory,  free space will occur
; C 0222  1                      between the exerciser and the DRS.
```

```
;C 0223  1               2.0   OPERATING INSTRUCTIONS
;C 0224  1               ----------------------
;C 0225  1
;C 0226  1
;C 0227  1                    This is a Rev C  Supervisor  Diagnostic;  for operating
;C 0228  1                    instructions,  please see chapter 5 of XXDP+ operator's
;C 0229  1                    manual.  They are no longer  included in the diagnostic
;C 0230  1                    because  it is desired  that a change in those instruc-
;C 0231  1                    tions not require a re-assembly of all Supervisor Diag-
;C 0232  1                    nostics.
;C 0233  1
;C 0234  1
;C 0235  1               2.1   HARDWARE QUESTIONS
 C 0236  1               ------------------
;C 0237  1
;C 0238  1                    The  following series  of questions collect the para-
;C 0239  1                    meters necessary to identify each disk subsystem.
;C 0240  1
;C 0241  1
;C 0242  1                    Hardware Configuration Questions
;C 0243  1                    --------------------------------
;C 0244  1
;C 0245  1                The  program  will  ask  the  following  questions  in
;C 0246  1                response to a START command (non-script).
;C 0247  1
;C 0248  1               1.  CHANGE HW (L) Y ?
;C 0249  1
;C 0250  1                    Answer NO to use the pre-built answers for all  hardware
;C 0251  1                    questions.  This  program will be released pre-built to
;C 0252  1                    test three units with default answers  shown below.  The
;C 0253  1                    pre-built  answers  may  be changed at any time with the
;C 0254  1                    setup utility.  Answer YES if you want all the  hardware
;C 0255  1                    questions to be asked.
;C 0256  1
;C 0257  1               2.  NUMBER OF UNITS (D) ?
;C 0258  1
;C 0259  1                    No default  Answer with the number of  disk drive units
;C 0260  1                    to be exercised or tested.  This  answer will determine
;C 0261  1                    how  many  times  the  following questions are asked.  A
;C 0262  1                    range  of 1 to 4 units  may be specified.  A unit number
;C 0263  1                    will be assigned  sequentially from 0  by the Diagnostic
;C 0264  1                    supervisor for each unit.
;C 0265  1
;C 0266  1               3.  IP ADDRESS (O) 172150 ?
;C 0267  1
;C 0268  1                    Enter the address of the IP register of one RQDX or RUX50
;C 0269  1                   as addressed by the processor with memory management turned
;C 0270  1                    off.  The program expects an even 16-bit address in  the
;C 0271  1                    range of 160000 to 177774.  172150 is the default.
```

```
;  C 0272  1              4.  VECTOR ADDRESS (O) 154 ?
;  C 0273  1
;  C 0274  1                  Answer with the interrupt vector ofthe same RQDX or RUX50
;  C 0275  1                  controller described in the above question. A vector address
;  C 0276  1                  in the range of 4 to 774 may be specified. 154 is the default.
;  C 0277  1
;  C 0278  1              5.  BR LEVEL [USUALLY 4-RQDX 5-RUX50] (D) 4 ?
;  C 0279  1
;  C 0280  1                  Answer with the bus request interrupt level used by  the
;  C 0281  1                  above controller. Levels 4 through 7 are acceptable. 4 is the
;  C 0282  1                  default.
;  C 0283  1
;  C 0284  1
;  C 0285  1              6.  DRIVE NUMBER (D) 0 ?
;  C 0286  1
;  C 0287  1                  Enter the logical unit number for one drive associated
;  C 0288  1                  with the IP address above. Drive numbers are in the
;  C 0289  1                  range of 0 through 15. The number entered here must
;  C 0290  1                  match the unit plug on the front  panel of the drive, and
;  C 0291  1                  must be within the range implied by the jumper (LUN0-7)
;  C 0292  1                  on the RQDX or RUX50 controller board. 0 is the default
;  C 0293  1                  answer.
;  C 0294  1
;  C 0295  1
;  C 0296  1              7.  ALSO RUN DUP EXERCISER (L) N ?
;  C 0297  1
;  C 0298  1                  ANSWER Y TO HAVE TESTS PERFORMED SPECIFICALLY WITH THE
;  C 0299  1                  DIAGNOSTIC BLOCKS. SUCH DUP TESTING, IF SELECTED, IS
;  C 0300  1                  INTERLEAVED WITH NORMAL EXERCISER TESTING.
;  C 0301  1
;  C 0302  1
;  C 0303  1
;  C 0304  1              8.  WRITE ON DIAGNOSTIC AREA (L) N ?
;  C 0305  1
;  C 0306  1                  IF THE DUP EXERCISER IS CHOSEN TO BE RUN, ANSWERING Y
;  C 0307  1                  TO THIS QUESTION ADDS WRITE TESTING IN THE DIAGNOSTIC
;  C 0308  1                  BLOCK AREA. THIS CAN BE USED TO DETERMINE WHETHER A
;  C 0309  1                  UNIT IS WRITING PROPERLY, WITHOUT USING THE CUSTOMER AREA.
;  C 0310  1
;  C 0311  1
;  C 0312  1
;  C 0313  1              9.  TEST ENTIRE CUSTOMER DATA AREA OF THIS DISK (L) Y?
;  C 0314  1
;  C 0315  1                  This question is asked to give the opportunity of limiting the
;  C 0316  1                  addressing range over which the testing will be performed.
;  C 0317  1                  An affirmative answer will cause no limits to be imposed for
;  C 0318  1                  the unit in question. A negative answer will cause limits
;  C 0319  1                  to be imposed, as defined by the following four questions.
;  C 0320  1
;  C 0321  1
;  C 0322  1             10.  LOWER OCTAL WORD OF BEGINNING LBN ADDRESS (O) 0?
;  C 0323  1
;  C 0324  1                  Enter in octal the less significant 16-bit word of the lowest
```

```
; C 0325  1                LBN address in the test range. The value may be from 000000
; C 0326  1                to 177777.
; C 0327  1
; C 0328  1
; C 0329  1           11.  HIGHER OCTAL WORD OF BEGINNING LBN ADDRESS (O) 0?
; C 0330  1
; C 0331  1                Enter in octal the more significant 16-bit word of the
; C 0332  1                lowest LBN address in the test range.
; C 0333  1
; C 0334  1
; C 0335  1           12.  LOWER OCTAL WORD OF ENDING LBN ADDRESS (O) 150477?
; C 0336  1
; C 0337  1                Enter in octal the less significant 16-bit word of the
; C 0338  1                highest LBN address in the test range. 150477 is the
; C 0339  1                highest LBN address for an RD52.
; C 0340  1
; C 0341  1
; C 0342  1           13.  HIGHER OCTAL WORD OF ENDING LBN ADDRESS (O) 0?
; C 0343  1
; C 0344  1                Enter in octal the more significant 16-bit word of the
; C 0345  1                highest LBN address in the test range.
; C 0346  1
; C 0347  1
; C 0348  1                 Note:
; C 0349  1                      The four previous questions are usually software
; C 0350  1                      Parameter questions, but since three different disk
; C 0351  1                      drives exist on the subsystem, this becomes a  unit
; C 0352  1                      by unit question.  It is possible to specify an LBN
; C 0353  1                      which is too large since we are dealing with different
; C 0354  1                      drives. The program will check for block number bounds,
; C 0355  1                      and, if they are exceeded, will assign the maximum
; C 0356  1                      bounds for that drive.
; C 0357  1
; C 0358  1
; C 0359  1
; C 0360  1           14.  WRITE ON CUSTOMER DATA AREA ON THIS DISK UNIT (L) ?
; C 0361  1
; C 0362  1                Answering YES will destroy any customer data that is  on
; C 0363  1                the  disk; therefore, the following warning message will
; C 0364  1                appear, followed by a confirmation prompt:
; C 0365  1
; C 0366  1                ** WARNING - CUSTOMER DATA AREA WILL BE OVERWRITTEN! ...
; C 0367  1                 CONFIRM (L) ?
; C 0368  1
; C 0369  1                This question will default to NO if the operator has de-
; C 0370  1                cided  to  bypass  the  hardware  questions.  Otherwise,
; C 0371  1                there is no default.
```

```
;  C 0372  1
;  C 0373  1
;  C 0374  1
;  C 0375  1
;  C 0376  1
;  C 0377  1
;  C 0378  1
;  C 0379  1
;  C 0380  1
;  C 0381  1
;  C 0382  1
;  C 0383  1
;  C 0384  1
;  C 0385  1
;  C 0386  1
;  C 0387  1
;  C 0388  1
;  C 0389  1
;  C 0390  1
;  C 0391  1
;  C 0392  1
;  C 0393  1
;  C 0394  1
;  C 0395  1
;  C 0396  1
;  C 0397  1
;  C 0398  1
;  C 0399  1
;  C 0400  1
;  C 0401  1
;  C 040'  1
;  C 040.  1
;  C 0404  1
;  C 0405  1
;  C 0406  1
;  C 0407  1
;  C 0408  1
;  C 0409  1
;  C 0410  1
;  C 0411  1
;  C 0412  1
;  C 0413  1
;  C 0414  1
;  C 0415  1
;  C 0416  1
;  C 0417  1
```

2.2 SOFTWARE QUESTIONS

Software Parameter Questions

The program will ask the following questions in response to the START, RESTART, and CONTINUE commands.

1. CHANGE SW (L) Y ?

   Answer NO to bypass the following questions in this section. This question should normally be answered NO when the Exerciser is first run. A NO answer will cause the Exerciser to select the default parameters shown with each question below. Then, depending on the errors detected, it may be desireable to change this answer to YES to alter the test parameters and further isolate the problem.

2. ENTER TIME AS HHMM (EXAMPLE: 1305) (D) 0 ?

   Enter the time of day (in 24 hour format). DRS does not ALLOW leading zeros ENTERED FOR numeric values.
   For example, for 14 minutes past midnight, you would enter 14, and for 30 minutes past 3 in the afternoon, enter 1530.

3. HARD ERROR LIMIT (D) 32 ?

   Enter the number of hard errors allowed before a unit is dropped from testing. A number in the range of 1 to 65535 will be accepted.

4. TRANSFER LIMIT IN MEGABYTES (0 FOR QUICK PASS) (D) 0 ?

   When the specified number of bytes have been transferred to/from a unit, the unit will be dropped from testing. When all units are dropped, an end-of-pass will be indicated. This is the method used to determine how long the Exerciser is to run.

   The only other way the Exerciser will declare end-of-pass is if all units are dropped because the error limit on each is exceeded. However, the operator can always abort the program at any time by typing CONTROL-C.

```
;  C 0418  1
;  C 0419  1
;  C 0420  1
;  C 0421  1
;  C 0422  1
;  C 0423  1
;  C 0424  1
;  C 0425  1
;  C 0426  1
;  C 0427  1
;  C 0428  1
;  C 0429  1
;  C 0430  1
;  C 0431  1
;  C 0432  1
;  C 0433  1
;  C 0434  1
;  C 0435  1
;  C 0436  1
;  C 0437  1
;  C 0438  1
;  C 0439  1
;  C 0440  1
;  C 0441  1
;  C 0442  1
;  C 0443  1
;  C 0444  1
;  C 0445  1
;  C 0446  1
;  C 0447  1
;  C 0448  1
;  C 0449  1
;  C 0450  1
;  C 0451  1
;  C 0452  1
;  C 0453  1
;  C 0454  1
;  C 0455  1
;  C 0456  1
;  C 0457  1
;  C 0458  1
;  C 0459  1
;  C 0460  1
;  C 0461  1
;  C 0462  1
;  C 0463  1
;  C 0464  1
;  C 0465  1
;  C 0466  1
;  C 0467  1
;  C 0468  1
```

5. PERCENTAGE OF 'FIXED DISK' OPERATIONS OUT OF TOTAL OPERATIONS (D) 99 ?

   In order to maintain typical usage for the devices of this exercise, a certain percentage of operations must be directed to the RD51/52s (the rest go to the RX50s). It turns out that this percentage is very high (as indicated by the 99% figure given as the default). It may be desirable in some cases to direct more activity to the RX50s. This is easily done by directing a smaller percentage of the operations to the RD51/52s. The numbers associated with usage are adjusted internally by the program according to drive type and percentage.

6. CLEAR STATISTICAL TABLES AFTER PRINTING (L) N ?

   Answering YES causes the statistical fields to be cleared to zero after the report is printed (either at end of pass, or at operator request). Otherwise, cumulative totals are maintained.

7. REWRITE BLOCKS WHEN "FORCED ERROR" DETECTED ON READS (L) Y ?

   On encountering a bad block on the RD51 or RD52 disk (during either a read or a write operation), the RQDX or RUX50 controller will revector the logical block to another physical location on the disk. This operation is transparent to the user. However, if the revectoring was done subsequent to a write operation (i.e. the write operation detected the bad block), the data is flagged with a "Forced Error" code, signifying that the data at the revectored location is suspect. The controller returns an error code whenever the block is re-read. Answer 'Yes' to the question to force a WRITE operation on the same block whenever a "Forced Error" flag is detected on a read. This is to avoid the same error code (the "Forced Error") being reported for the same block repeatedly. The re-write will, however, take place only if writes are enabled for the particular disk unit.

8. HALT ON BAD-BLOCK HARD ERRORS (#s 35, 38) (L) Y ?

   When the Exerciser is run with the DRS "Halt on Error" switch set (eg. START/FLAGS:HOE), the Exerciser halts on on encountering ANY error. If it is desired that the testing continue on a bad-block error, even with the HOE switch set, answer No to the question.

9. HALT ON OTHER HARD ERRORS (#s 31-34, 36-37, 39-45) (L) Y ?

   This question is similar to question 8, but refers to non-bad block type of Hard Errors.

```
;  C 0469  1
;  C 0470  1
;  C 0471  1
;  C 0472  1
;  C 0473  1
;  C 0474  1
;  C 0475  1
;  C 0476  1
;  C 0477  1
;  C 0478  1
;  C 0479  1
;  C 0480  1
;  C 0481  1
;  C 0482  1
;  C 0483  1
;  C 0484  1
;  C 0485  1
;  C 0486  1
;  C 0487  1
;  C 0488  1
;  C 0489  1
;  C 0490  1
;  C 0491  1
;  C 0492  1
;  C 0493  1
;  C 0494  1
;  C 0495  1
;  C 0496  1
;  C 0497  1
;  C 0498  1
;  C 0499  1
;  C 0500  1
;  C 0501  1
;  C 0502  1
;  C 0503  1
;  C 0504  1
;  C 0505  1
;  C 0506  1
;  C 0507  1
;  C 0508  1
;  C 0509  1
;  C 0510  1
;  C 0511  1
;  C 0512  1
;  C 0513  1
;  C 0514  1
;  C 0515  1
;  C 0516  1
;  C 0517  1
;  C 0518  1
;  C 0519  1
```

10. HALT ON SOFT ERRORS (#s 50-54) (L) N ?

    This question is similar to question 8, but refers to Soft Errors.

11. COUNT EACH RETRY AS A SEPARATE SOFT ERROR (L) N ?

    On encountering any error on a read/write, the controller retries the operation a number of times. If the operation is eventually successful, this is reported as a Soft Error. The error log packet contains the number of retries performed before the operation was successful. Normally, the whole sequence of retries is classified as one Soft Error. Answer Yes to the question if it is desired to count each internal retry attempt as a separate Soft Error.

12. RANDOM SEEK MODE (L) Y ?

    Answer YES to cause block numbers to be chosen randomly. Answer NO to cause block numbers to be selected sequentially.

13. UNITS TO BE SELECTED AT RANDOM (NO, IMPLIES SEQUENTIAL) (L) N ?

    This question is optionally asked if the answer to the previous question is N[o]. The selection of units for sequential operations is affected by the answer to this question. If the default answer is chosen (N[o]), then units shall be selected in a predetermined manner in accordance with the typical seek time margins for each drive. If the alternate answer is chosen (Y[es]), then the units will be chosen at random in accordance with the percentages specified in Software question 4.

14. READ-COMPARES PERFORMED AT THE CONTROLLER (L) Y ?

    Answering YES causes all read commands to include the "compare" modifier. This essentially forces the controller to perform two read operations on the same disk address, and to compare the results.

    The following message will appear after the operator has answered this question:

15. RUNNING UNDER THE A.P.T. MONITOR (L) N ?

    THIS QUESTION SHOULD BE ANSWERED N (DEFAULT) IN THE FIELD. IT ENABLES THE PROGRAM TO KNOW THAT IT IS RUNNING UNDER A SPECIAL (AUTOMATED PRODUCT TEST) MONITOR.

```
; C 0520  1
; C 0521  1
; C 0522  1
; C 0523  1                THE REMAINING QUESTI^NS ONLY APPLY TO UNPROTECTED DISK UNITS.
; C 0524  1
; C 0525  1
; C 0526  1            16. WRITE-COMPARES PERFORMED AT THE CONTROLLER (L) N ?
; C 0527  1
; C 0528  1                Answering YES causes all write I/O requests to be
; C 0529  1                changed to write-compare.  After each write, the con-
; C 0530  1                troller will read the data and compare it to data
; C 0531  1                re-obtained from the host.
; C 0532  1
; C 0533  1
; C 0534  1            17. CHECK ALL WRITES AT HOST BY READING (L) Y ?
; C 0535  1
; C 0536  1                This question will only be asked if the previous ques-
; C 0537  1                tion was answered NO.  Answering YES causes all writes
; C 0538  1                to be checked by the host by reading the data immediate-
; C 0539  1                ly after the write operation.  This option consumes
; C 0540  1                extra CPU time, and doubles the amount of storage re-
; C 0541  1                quired for writes.  Therefore, it is only recommended
; C 0542  1                when drive write-compare operations are suspect.
; C 0543  1
; C 0544  1
; C 0545  1            18. USER-DEFINED DATA PATTERN (L) N ?
; C 0546  1
; C 0547  1                An answer of YES allows the operator to define his/her
; C 0548  1                own data pattern to be used in all write operations.  A
; C 0549  1                NO answer will allow the operator to select a
; C 0550  1                pre-defined data pattern in the next question.
; C 0551  1
; C 0552  1
; C 0553  1            19. SELECT PRE-DEFINED DATA PATTERN (0 FOR SEQUENTIAL SELEC-
; C 0554  1                TION) (D) 0 ?
; C 0555  1
; C 0556  1                There are 21 pre-defined data patterns available,
; C 0557  1                selected as 1 to 21 (see section 4.9).  A zero answer
; C 0558  1                will cause patterns 1 to 21 to be sequentially selected
; C 0559  1                for each write.  (Note that pattern 1 consists entirely
; C 0560  1                of random numbers).
; C 0561  1
; C 0562  1
; C 0563  1            20. NUMBER OF WORDS IN DATA PATTERN (16 MAXIMUM) (D) 16 ?
; C 0564  1                PATTERN VALUES (O) ?
; C 0565  1
; C 0566  1                These questions will only be asked if the operator has
; C 0567  1                decided to define his/her own data pattern.  The actual
; C 0568  1                bit patterns will be entered as octal (PDP-11).
```

```
;C 0569  1               3.0   ERROR TYPES
;C 0570  1                     ---- ------
;C 0571  1
;C 0572  1                     This program has four types of error  classifications;
;C 0573  1                     system fatal, drive fatal, hard and soft.
;C 0574  1
;C 0575  1                     SYSTEM FATAL ERRORS
;C 0576  1                     --------- --------
;C 0577  1
;C 0578  1                     System fatal errors are used to indicate that an error
;C 0579  1                     was detected by the  Diagnostic Supervisor in relation
;C 0580  1                     to loading/controlling the diagnostic process.
;C 0581  1
;C 0582  1                     The content  of each  error is  such that it should be
;C 0583  1                     self explanatory.  However,  the messages utilize some
;C 0584  1                     terms that are specific to the disk subsystem, and may
;C 0585  1                     require some getting use to.
;C 0586  1
;C 0587  1
;C 0588  1                     DRIVE FATAL ERRORS
;C 0589  1                     ------------------
;C 0590  1
;C 0591  1                     Drive fatal errors are a result of:
;C 0592  1
;C 0593  1                     an error that is  considered fatal to  the drive,  but
;C 0594  1                     testing will continue.
;C 0595  1
;C 0596  1
;C 0597  1                     HARD ERRORS
;C 0598  1                     -----------
;C 0599  1
;C 0600  1                     Hard errors are a result of:
;C 0601  1
;C 0602  1                             1.  retries of a soft error or *
;C 0603  1                             2.  a non-recoverable error
;C 0604  1                             3.  a soft error if retries are not set.
;C 0605  1
;C 0606  1                             *  Note: Retries are executed in the controller
;C 0607  1
;C 0608  1                     SOFT ERRORS
;C 0609  1                     -----------
;C 0610  1
;C 0611  1                     Soft errors  are media related errors.  All soft errors
;C 0612  1                     will be retried by the controller.
;C 0613  1
;C 0614  1                     Note: Soft errors are retrieved from the controller via
;C 0615  1                     the error log  capabilities of  MSCP.
```

```
; C 0616  1
; C 0617  1
; C 0618  1
; C 0619  1
; C 0620  1
; C 0621  1
; C 0622  1
; C 0623  1
; C 0624  1
; C 0625  1
; C 0626  1
; C 0627  1
; C 0628  1
; C 0629  1
; C 0630  1
; C 0631  1
; C 0632  1
; C 0633  1
; C 0634  1
; C 0635  1
; C 0636  1
; C 0637  1
; C 0638  1
; C 0639  1
; C 0640  1
; C 0641  1
; C 0642  1
; C 0643  1
; C 0644  1
; C 0645  1
; C 0646  1
; C 0647  1
; C 0648  1
; C 0649  1
; C 0650  1
; C 0651  1
; C 0652  1
; C 0653  1
; C 0654  1
; C 0655  1
; C 0656  1
; C 0657  1
; C 0658  1
; C 0659  1
; C 0660  1
; C 0661  1
; C 0662  1
; C 0663  1
; C 0664  1
```

3.1 ERROR INFORMATION

All general error messages will include the type of error (system-fatal, drive-fatal, hard, soft) and a unit number. If the error applies to a controller, then only the first unit number of the controller will be given. (The user will know the other unit numbers when subsequent "drop unit" messages are printed).

Basic error messages provide more details about the error. The Exerciser will print all basic error messages, along with the disk address, if applicable. In some cases where a drive-fata_ error applies to a controller, the controller's IP address will be printed.

Extended error messages will be used to print the relevant fields of command and end message packets, status codes, SA register contents, and error log messages. All values will be in octal (PDP-11).

The error messages in this section do not include errors detected and printed by the Diagnostic Supervisor.

3.2 INITIALIZATION ERRORS

Two kinds of errors will be reported to the operator during the Initialization Test. The System-fatal error is too many units specified. A system-fatal error will cause the Exerciser to abort.

Drive-fatal errors only affect the unit(s) involved. Testing will continue on all other units. This class of errors includes, but is not limited to, the following:

1. Register Existence Test failure (no drive present)
2. Vector Test failure
3. BR Level Test failure
4. Initialization sequence failure
5. Online failed
6. Access failed

```
;  C 0665  1
;  C 0666  1
;  C 0667  1
;  C 0668  1
;  C 0669  1
;  C 0670  1
;  C 0671  1
;  C 0672  1
;  C 0673  1
;  C 0674  1
;  C 0675  1
;  C 0676  1
;  C 0677  1
;  C 0678  1
;  C 0679  1
;  C 0680  1
;  C 0681  1
;  C 0682  1
;  C 0683  1
;  C 0684  1
;  C 0685  1
;  C 0686  1
;  C 0687  1
;  C 0688  1
;  C 0689  1
;  C 0690  1
;  C 0691  1
;  C 0692  1
;  C 0693  1
;  C 0694  1
;  C 0695  1
;  C 0696  1
;  C 0697  1
;  C 0698  1
;  C 0699  1
;  C 0700  1
;  C 0701  1
;  C 0702  1
;  C 0703  1
;  C 0704  1
;  C 0705  1
;  C 0706  1
;  C 0707  1
;  C 0708  1
;  C 0709  1
;  C 0710  1
;  C 0711  1
```

3.3 EXERCISER ERRORS

Most errors reported during this test will originate from MSCP end message packets. The status code field will be converted to text and printed as part of a basic error message. Any subcode value will follow if extended error messages are enabled.

The following list represents some of the error conditions reported via MSCP:

1. Disk unit went offline (a sub-code may follow detailing the reason)
2. Compare error
3. Data error (a sub-code may follow)
4. Drive error (a sub-code may follow)
5. Host buffer access error
6. Media format error (a sub-code may follow)

3.4 ERROR LOG MESSAGES

The contents of the error-log messages received from the controller are printed as received, and should be deciphered using the MSCP specs.

3.5 MSCP ERRORS

An MSCP error occurs when the host receives an Invalid Command End Message from the controller. In such cases, the host will print out the erroneous command followed by the reason for the error. If extended printouts are enabled, then the entire contents of the end message will be displayed in octal without interpretation of the data.

```
; C 0712  1          3.6   SAMPLE ERROR STATEMENT
; C 0713  1                ----------------------
; C 0714  1
; C 0715  1
; C 0716  1          The errors listed by the exerciser are  usually very des
; C 0717  1          criptive and  are self explanatory.  The  following is an example
; C 0718  1          error  statement.  This  error  statement  is  the extended error
; C 0719  1          message.
; C 0720  1
; C 0721  1
; C 0722  1          (example)                          (comments)
; C 0723  1
; C 0724  1          DISK XXX                           !DISK UNIT NUMBER
; C 0725  1          INVALID COMMAND                    !MAJOR STATUS CODE RECEIVED BACK
; C 0726  1          SUB-CODE XXXX                      !SUB-CODE OF GIVEN COMMAND
; C 0727  1          COMMAND: READ                      !COMMAND GIVEN TO DRIVE
; C 0728  1          LBN: XXXXX                         !LOGICAL BLOCK NUMBER GIVEN
; C 0729  1          BYTE COUNT IN COMMAND XXXXX        !NUMBER OF BYTES WANTED TO READ
; C 0730  1          ACTUAL # OF BYTES TRANSFERRED XXXXX !NUMBER OF BYTES ACTUALLY READ
; C 0731  1
; C 0732  1
; C 0733  1
; C 0734  1          The  status  code in  an end  messages is  broken into two
; C 0735  1          pieces. The first 5 bits represent the major status which is given
; C 0736  1          by the "invalid command" message.  The 11 remaining bits represent
; C 0737  1          the sub-code,  which tells in greater detail the error in the con-
; C 0738  1          troller.  The LBN is the logical  block on the disk the controller
; C 0739  1          was trying to read.  The byte count refers  to the number of bytes
; C 0740  1          the controller was going to read off the LBN. The actual number of
; C 0741  1          bytes transferred refers  to the  number of bytes  read before the
; C 0742  1          error.
```

```
; C 0743  1
; C 0744  1
; C 0745  1
; C 0746  1
; C 0747  1
; C 0748  1
; C 0749  1
; C 0750  1
; C 0751  1
; C 0752  1
; C 0753  1
; C 0754  1
; C 0755  1
; C 0756  1
; C 0757  1
; C 0758  1
; C 0759  1
; C 0760  1
; C 0761  1
; C 0762  1
; C 0763  1
; C 0764  1
; C 0765  1
; C 0766  1
; C 0767  1
; C 0768  1
; C 0769  1
; C 0770  1
; C 0771  1
; C 0772  1
; C 0773  1
; C 0774  1
; C 0775  1
; C 0776  1
```

4.0 PERFORMANCE AND PROGRESS REPORTS

A summary report is printed at the end of each pass of the Exerciser or upon demand by the operator. The fields may be cleared to zero after the report is printed depending on the operator's response to this option in the software questions. Any units added to the test cycle will also begin with cleared statistics.

Errors are grouped into two basic categories: hard and soft. Each is sub divided into four more categories, depending on the most probable classification for that error.

The sub categories are:

1. disk related errors

2. seek (or format) related errors

3. controller or drive related errors

4. host (the CPU) related errors.

All numeric values are in decimal radix.

UNT #	TYPE	# OF READS	BYTS READ	# OF WRITES	BYTES WRITTEN	HRD ERS DAT	HRD ERS SEK	HRD ERS DRV	HRD ERS HST	SFT ERS DAT	SFT ERS SEK	SFT ERS DRV	SFT ERS HST
X	XXXX	XXXX	XXXX	XXXXX	XXXXXX	X	X	X	X	X	X	X	X
.	..	..	..	...	....	.	.	.	.	.	.	.	.
.	..	..	..	...	....	.	.	.	.	.	.	.	.

```
; C 0777  1
; C 0778  1
; C 0779  1
; C 0780  1
; C 0781  1
; C 0782  1
; C 0783  1
; C 0784  1
; C 0785  1
; C 0786  1
; C 0787  1
; C 0788  1
; C 0789  1
; C 0790  1
; C 0791  1
; C 0792  1
; C 0793  1
; C 0794  1
; C 0795  1
; C 0796  1
; C 0797  1
; C 0798  1
; C 0799  1
; C 0800  1
; C 0801  1
; C 0802  1
; C 0803  1
; C 0804  1
; C 0805  1
; C 0806  1
; C 0807  1
; C 0808  1
; C 0809  1
; C 0810  1
; C 0811  1
; C 0812  1
; C 0813  1
; C 0814  1
; C 0815  1
; C 0816  1
; C 0817  1
; C 0818  1
; C 0819  1
; C 0820  1
; C 0821  1
; C 0822  1
; C 0823  1
; C 0824  1
; C 0825  1
; C 0826  1
```

5.0 TEST SUMMARY

This exerciser consists of two parts: the initialization subtest, and the performance exerciser. The operator is not able to select which of these two parts he/she wishes to run; they both must be executed.

5.1 INITIALIZATION SUBTEST

The purpose of this subtest is to verify the hardware configuration as specified by the operator, and to bring each unit online. The Initialization Subtest will always precede the execution of any other test.

First, the presence of each drive register will be verified, along with a check on the BR level specified by the operator. Then, an initialization will be issued to each controller configured for testing. When the initialization sequence has been completed, an attempt will be made to bring each unit online. If this succeeds, one or two MSCP reads will be issued to the inner-most LBN of each selected disk to to ensure that each disk drive can seek and be read.

Any drive-fatal or hard errors encountered during this test will cause the appropriate unit(s) to be dropped. If basic error messages are enabled, then the program will print out the specific reason for dropping the unit(s). Henceforth, the failed unit(s) will not be tested unless the operator intervenes (adds unit(s) or restarts Exerciser).

Upon successful completion of the Initialization Subtest, the program will begin executing the Exerciser.

5.2 EXERCISER

The purpose of this subtest is to exercise the disk drives in a manner similar to the typical usage under standard operating systems. Execution of this test should give an indication of the operating performance of the disk drive subunits. This test will utilize random disk addresses, random word counts, and data patterns, all subject to the limits and specifications made by the operator. All protected disks will be subject to read-only operations, while unprotected disks may be read or written, depending on the answers given to the software parameter questions. End-of-pass will be declared when the specified number of bytes have been transferred for all the disks taken as a whole.

```
;  C 0827  1               If a read/write error occurs during this test,  then the
;  C 0828  1               controller will initiate a  appropriate number of re-
;  C 0829  1               tries.  If all retries fail, then a hard error will be repor-
;  C 0830  1               ted to the host,  an error message  will  be displayed on the
;  C 0831  1               console  terminal and  the error will be tallied for the sum-
;  C 0832  1               mary report. The unit will be dropped if the hard error count
;  C 0833  1               has exceeded the specified limit.
;  C 0834  1
;  C 0835  1
;  C 0836  1
;  C 0837  1           5.3   DROP UNIT SUMMARY
;  C 0838  1                 ----------------
;  C 0839  1               During the Initialization Subtest, individual units will
;  C 0840  1               be dropped from  the test  sequence if they are unable  to be
;  C 0841  1               brought online or the operator specified drive does not match
;  C 0842  1               the hardware.
;  C 0843  1
;  C 0844  1               During  the Exercise,  the program will  drop a unit for
;  C 0845  1               one of  three reasons.  The normal path is for  each unit  to
;  C 0846  1               complete the transfer of N megabytes, where N is specified by
;  C 0847  1               the  operator  during SW  questioning  and  be  soft-dropped.
;  C 0848  1               Otherwise,  a unit will be hard-dropped if the number of hard
;  C 0849  1               errors encountered exceeds  the operator-specified limit,  or
;  C 0850  1               if a fatal error is detected. Units hard-dropped may later be
;  C 0851  1               added to the  test cycle.  However,  statistics for the hard-
;  C 0852  1               added  unit  will be  cleared to  zero;  if a transfer  limit
;  C 0853  1               was specified,  in which case the unit was soft-dropped,  the
;  C 0854  1               statistics may  or may not be cleared  depending on the oper-
;  C 0855  1               ators answer to Software question 12.
```

```
; C 0856  1              6.0   ERROR CODES
; C 0857  1                    This section describes the error codes generated by this exerciser.
; C 0858  1
; C 0859  1
; C 0860  1                 SYSTEM FATAL ERRORS
; C 0861  1                 ------------------
; C 0862  1
; C 0863  1                 1   More than 4 units specified
; C 0864  1
; C 0865  1
; C 0866  1                 DRIVE FATAL ERRORS
; C 0867  1                 ------------------
; C 0868  1
; C 0869  1                 10  Controller couldn't be  addressed  Wrong IP address selected
; C 0870  1                     at the address given.
; C 0871  1
; C 0872  1                 11  Controller  didn't  interrupt  at  Wrong vector address sel-
; C 0873  1                     the interrupt vector given.        ected.
; C 0874  1
; C 0875  1                 12  Controller  didn't  interrupt  at  Wrong BR level selected.
; C 0876  1                     the BR level given.
; C 0877  1
; C 0878  1                 13  Init sequence failed.              Either  one of  the  four
; C 0879  1                                                        initialization  steps did
; C 0880  1                                                        not receive  the  correct
; C 0881  1                                                        response  from  the  Con-
; C 0882  1                                                        troller,  or  one  of the
; C 0883  1                                                        steps timed-out.
; C 0884  1
; C 0885  1                 14  Fatal Controller error.            The error bit (bit 15) in
; C 0886  1                                                        the SA register was set.
; C 0887  1
; C 0888  1                 15  Failed to bring unit on-line.      On-line  response had  an
; C 0889  1                                                        error  code.   (see  also
; C 0890  1                                                        #s 22 and 23.)
; C 0891  1
; C 0892  1                 16  Write protect conflict.           The  unit  was  hardware
; C 0893  1                                                       write protected  and write
; C 0894  1                                                       operations  were requested
; C 0895  1                                                       on the unit.
; C 0896  1
; C 0897  1                 17  Access  to either  the  inner or  Innermost  or  outermost
; C 0898  1                     the outer track failed.           track's header may be cor-
; C 0899  1                                                       repeated.
; C 0900  1
; C 0901  1                 18  Unit went off-line.               ---
; C 0902  1
; C 0903  1                 19  Drive type not known.             The  version of the  Exer-
; C 0904  1                                                       ciser  being run  does not
; C 0905  1                                                       support this disk type.
```

```
;C 0906  1                20  Failed to send 'Set Controller      Either the unit is off-
;C 0907  1                    Characteristics" command.           line or the Diagnostic is
;C 0908  1                                                        corrupted because of any
;C 0909  1                                                        problems with its RAM.
;C 0910  1
;C 0911  1                21  Controller returned wrong 'end     Problem with the Control-
;C 0912  1                    code' for the 'Set Controller       ler microcode or the port/
;C 0913  1                    Characteristics' command.           DMA interface.
;C 0914  1
;C 0915  1                22  Failed to send 'On-line' command   Either the unit is off-
;C 0916  1                                                        line or the diagnostic is
;C 0917  1                                                        corrupted because of any
;C 0918  1                                                        problems with its RAM.
;C 0919  1
;C 0920  1                23  Controller returned wrong 'end     Problem with the Control-
;C 0921  1                    code' for the 'On-line' command.    ler's microcode or the
;C 0922  1                                                        port/DMA interface.
;C 0923  1
;C 0924  1                24  Drive went to the 'Available'     ---
;C 0925  1                    state.
;C 0926  1
;C 0927  1                HARD ERRORS
;C 0928  1                -----------
;C 0929  1
;C 0930  1                31  Controller received an invalid   The diagnostic is corrup-
;C 0931  1                    command.                            ted because of any prob-
;C 0932  1                                                        lems with its RAM, or
;C 0933  1                                                        there is a problem with
;C 0934  1                                                        the Controller microcode
;C 0935  1                                                        (RAM or ROM) or there is
;C 0936  1                                                        problem with the port/DMA
;C 0937  1                                                        interface.
;C 0938  1
;C 0939  1                32  Command aborted by the Control-   Command timed-out in the
;C 0940  1                    ler.                                Controller.
;C 0941  1
;C 0942  1                35  Media format error.               ---
;C 0943  1
;C 0944  1                36  Drive write protected.            ---
;C 0945  1
;C 0946  1                37  Controller read or write com-     ---
;C 0947  1                    pare error.
;C 0948  1
;C 0949  1                38  Data error.                       CRC error in the data
;C 0950  1                                                        field of a disk block.
;C 0951  1
;C 0952  1                39  Host buffer access error         ---
;C 0953  1
;C 0954  1                40  Controller error.                 Difficult to categorize
;C 0955  1                                                        without looking at the
;C 0956  1                                                        error sub-code or any
;C 0957  1                                                        associated error-log mes-
;C 0958  1                                                        sage.
```

```
;C 0959  1
;C 0960  1
;C 0961  1                41  Drive error.                    See #40.
;C 0962  1
;C 0963  1                42  Host write compare error.       Error detected when Host
;C 0964  1                                                    CPU compared the data
;C 0965  1                                                    written and read back. May
;C 0966  1                                                    be a problem with the Host
;C 0967  1                                                    or Controller RAM.
;C 0968  1
;C 0969  1                43 Message from internal diagnostics  See #40.
;C 0970  1
;C 0971  1                44  Duplicate unit number detected  ---
;C 0972  1                    by the Controller.
;C 0973  1
;C 0974  1                45  Unknown end code received.      Problem with the Control-
;C 0975  1                                                    ler microcode or the port/
;C 0976  1                                                    DMA interface.
;C 0977  1
;C 0978  1
;C 0979  1
;C 0980  1
;C 0981  1                SOFT ERRORS
;C 0982  1                -----------
;C 0983  1
;C 0984  1                50  Controller error.              See error-log packet for
;C 0985  1                                                    details as the exact cause
;C 0986  1                                                    may not be evident.
;C 0987  1
;C 0988  1                51  Host memory access error.       See #50.
;C 0989  1
;C 0990  1                52  Disk transfer error.           See #50.
;C 0991  1
;C 0992  1                53  'Standard Disk Interconnect'   See #50.
;C 0993  1                    error.
;C 0994  1
;C 0995  1                54  'Small Disk' error.            See #50.
;C 0996  1
;C 0997  1
;C 0998  1
;C 0999  1
;C 1000  1                DUP ERRORS
;C 1001  1                ----------
;C 1002  1
;C 1003  1                60 Unable to load local controller DUP media.
;C 1004  1
;C 1005  1                61 (Not used)
;C 1006  1
;C 1007  1                62 Illegal unit number.
;C 1008  1
;C 1009  1                63 Illegal relative or physical block.
;C 1010  1
;C 1011  1                64 Device error.
```

```
; C 1012  1
; C 1013  1                65 Zero length message.
; C 1014  1
; C 1015  1                66 Unknown DUP status code.
; C 1016  1
; C 1017  1                67 Invalid command.
```

```
;  C 1018  1
;  C 1019  1
;  C 1020  1
;  C 1021  1                    DUP ERRORS  (CONTINUED)
;  C 1022  1                    -----------
;  C 1023  1
;  C 1024  1
;  C 1025  1                    68 No region available.
;  C 1026  1
;  C 1027  1                    69 No region suitable.
;  C 1028  1
;  C 1029  1                    70 Program not known.
;  C 1030  1
;  C 1031  1                    71 Load failure.
;  C 1032  1
;  C 1033  1                    72 Standalone.
;  C 1034  1
;  C 1035  1                    73 Unknown DUP status code.
;  C 1036  1
;  C 1037  1
```

; C 1038 1 7.0 DATA PATTERNS
; C 1039 1 -------- ----
; C 1040 1
; C 1041 1
; C 1042 1
; C 1043 1
; C 1044 1
; C 1045 1
; C 1046 1
; C 1047 1
; C 1048 1
; C 1049 1
; C 1050 1
; C 1051 1
; C 1052 1
; C 1053 1
; C 1054 1
; C 1055 1
; C 1056 1
; C 1057 1
; C 1058 1
; C 1059 1
; C 1060 1
; C 1061 1
; C 1062 1
; C 1063 1
; C 1064 1
; C 1065 1
; C 1066 1
; C 1067 1
; C 1068 1
; C 1069 1
; C 1070 1
; C 1071 1
; C 1072 1
; C 1073 1
; C 1074 1
; C 1075 1
; C 1076 1
; C 1077 1
; C 1078 1
; C 1079 1
; C 1080 1
; C 1081 1
; C 1082 1
; C 1083 1
; C 1084 1
; C 1085 1
; C 1086 1
; C 1087 1
; C 1088 1
; C 1089 1

	HEX	OCTAL	BINARY

Pattern 1	R A N D O M	N U M B E R S	
Pattern 2	0000	000000	0 000 000 000 000 000
Pattern 3	FFFF	177777	1 111 111 111 111 111
Pattern 4	8888	105613	1 000 101 110 001 011
Pattern 5	3333	031463	0 011 001 100 110 011
Pattern 6	3091	030221	0 011 000 010 010 001
Pattern 7	0001	000001	0 000 000 000 000 001
	0003	000003	0 000 000 000 000 011
	0007	000007	0 000 000 000 000 111
	000F	000017	0 000 000 000 001 111
	001F	000037	0 000 000 000 011 111
	003F	000077	0 000 000 000 111 111
	007F	000177	0 000 000 001 111 111
	00FF	000377	0 000 000 011 111 111
	01FF	000777	0 000 000 111 111 111
	03FF	001777	0 000 001 111 111 111
	07FF	003777	0 000 011 111 111 111
	0FFF	007777	0 000 111 111 111 111
	1FFF	017777	0 001 111 111 111 111
	3FFF	037777	0 011 111 111 111 111
	7FFF	077777	0 111 111 111 111 111
	FFFF	177777	1 111 111 111 111 111
Pattern 8	FFFE	177776	1 111 111 111 111 110
	FFFC	177774	1 111 111 111 111 100
	FFF8	177770	1 111 111 111 111 000
	FFF0	177760	1 111 111 111 110 000
	FFE0	177740	1 111 111 111 100 000
	FFC0	177700	1 111 111 111 000 000
	FF80	177600	1 111 111 110 000 000
	FF00	177400	1 111 111 100 000 000
	FE00	177000	1 111 111 000 000 000
	FC00	176000	1 111 110 000 000 000
	F800	174000	1 111 100 000 000 000
	F000	170000	1 111 000 000 000 000
	E000	160000	1 110 000 000 000 000
	C000	140000	1 100 000 000 000 000
	8000	100000	1 000 000 000 000 000
	0000	000000	0 000 000 000 000 000

```
;  C 1090  1          Pattern 9       0000    000000          0 000 000 000 000 000
;  C 1091  1                          0000    000000          0 000 000 000 000 000
;  C 1092  1                          0000    000000          0 000 000 000 000 000
;  C 1093  1                          FFFF    177777          1 111 111 111 111 111
;  C 1094  1                          FFFF    177777          1 111 111 111 111 111
;  C 1095  1                          FFFF    177777          1 111 111 111 111 111
;  C 1096  1                          0000    000000          0 000 000 000 000 000
;  C 1097  1                          0000    000000          0 000 000 000 000 000
;  C 1098  1                          FFFF    177777          1 111 111 111 111 111
;  C 1099  1                          FFFF    177777          1 111 111 111 111 111
;  C 1100  1                          0000    000000          0 000 000 000 000 000
;  C 1101  1                          FFFF    177777          1 111 111 111 111 111
;  C 1102  1                          0000    000000          0 000 000 000 000 000
;  C 1103  1                          FFFF    177777          1 111 111 111 111 111
;  C 1104  1                          0000    000000          0 000 000 000 000 000
;  C 1105  1                          FFFF    177777          1 111 111 111 111 111
;  C 1106  1
;  C 1107  1          Pattern 10      B6D9    133331          1 011 011 011 011 001
;  C 1108  1
;  C 1109  1          Pattern 11      5555    052525          0 101 010 101 010 101
;  C 1110  1                          5555    052525          0 101 010 101 010 101
;  C 1111  1                          5555    052525          0 101 010 101 010 101
;  C 1112  1                          AAAA    125252          1 010 101 010 101 010
;  C 1113  1                          AAAA    125252          1 010 101 010 101 010
;  C 1114  1                          AAAA    125252          1 010 101 010 101 010
;  C 1115  1                          5555    052525          0 101 010 101 010 101
;  C 1116  1                          5555    052525          0 101 010 101 010 101
;  C 1117  1                          AAAA    125252          1 010 101 010 101 010
;  C 1118  1                          AAAA    125252          1 010 101 010 101 010
;  C 1119  1                          5555    052525          0 101 010 101 010 101
;  C 1120  1                          AAAA    125252          1 010 101 010 101 010
;  C 1121  1                          5555    052525          0 101 010 101 010 101
;  C 1122  1                          AAAA    125252          1 010 101 010 101 010
;  C 1123  1                          5555    052525          0 101 010 101 010 101
;  C 1124  1                          AAAA    125252          1 010 101 010 101 010
```

```
;  C 1125  1          Pattern 12      2D2D    026455          0 010 110 100 101 101
;  C 1126  1                          2D2D    026455          0 010 110 100 101 101
;  C 1127  1                          2D2D    026455          0 010 110 100 101 101
;  C 1128  1                          D2D2    151322          1 101 001 011 010 010
;  C 1129  1                          D2D2    151322          1 101 001 011 010 010
;  C 1130  1                          D2D2    151322          1 101 001 011 010 010
;  C 1131  1                          2D2D    026455          0 010 110 100 101 101
;  C 1132  1                          2D2D    026455          0 010 110 100 101 101
;  C 1133  1                          D2D2    151322          1 101 001 011 010 010
;  C 1134  1                          D2D2    151322          1 101 001 011 010 010
;  C 1135  1                          2D2D    026455          0 010 110 100 101 101
;  C 1136  1                          2D2D    026455          0 010 110 100 101 101
;  C 1137  1                          D2D2    151322          1 101 001 011 010 010
;  C 1138  1                          2D2D    026455          0 010 110 100 101 101
;  C 1139  1                          D2D2    151322          1 101 001 011 010 010
;  C 1140  1                          2D2D    026455          0 010 110 100 101 101
;  C 1141  1                          D2D2    151322          1 101 001 011 010 010
;  C 1142  1                          2D2D    026455          0 010 110 100 101 101
;  C 1143  1                          D2D2    151322          1 101 001 011 010 010
;  C 1144  1                          2D2D    026455          0 010 110 100 101 101
;  C 1145  1
;  C 1146  1          Pattern 13      6DB6    066666          0 110 110 110 110 110
;  C 1147  1
;  C 1148  1          Pattern 14      0001    000001          0 000 000 000 000 001
;  C 1149  1                          0002    000002          0 000 000 000 000 010
;  C 1150  1                          0004    000004          0 000 000 000 000 100
;  C 1151  1                          0008    000010          0 000 000 000 001 000
;  C 1152  1                          0010    000020          0 000 000 000 010 000
;  C 1153  1                          0020    000040          0 000 000 000 100 000
;  C 1154  1                          0040    000100          0 000 000 001 000 000
;  C 1155  1                          0080    000200          0 000 000 010 000 000
;  C 1156  1                          0100    000400          0 000 000 100 000 000
;  C 1157  1                          0200    001000          0 000 001 000 000 000
;  C 1158  1                          0400    002000          0 000 010 000 000 000
;  C 1159  1                          0800    004000          0 000 100 000 000 000
;  C 1160  1                          1000    010000          0 001 000 000 000 000
;  C 1161  1                          2000    020000          0 010 000 000 000 000
;  C 1162  1                          4000    040000          0 100 000 000 000 000
;  C 1163  1                          8000    100000          1 000 000 000 000 000
```

```
;  C 1164  1          Pattern 15      FFFE    177776          1 111 111 111 111 110
;  C 1165  1                          FFFD    177775          1 111 111 111 111 101
;  C 1166  1                          FFFB    177773          1 111 111 111 111 011
;  C 1'67  1                          FFF7    177767          1 111 111 111 110 111
;  C 1168  1                          FFEF    177757          1 111 111 111 101 111
;  C 1169  1                          FFDF    177737          1 111 111 111 011 111
;  C 1170  1                          FFBF    177677          1 111 111 110 111 111
;  C 1171  1                          FF7F    177577          1 111 111 101 111 111
;  C 1172  1                          FEFF    177377          1 111 111 011 111 111
;  C 1173  1                          FDFF    176777          1 111 110 111 111 111
;  C 1174  1                          FBFF    175777          1 111 101 111 111 111
;  C 1175  1                          F7FF    173777          1 111 011 111 111 111
;  C 1176  1                          EFFF    167777          1 110 111 111 111 111
;  C 1177  1                          DFFF    157777          1 101 111 111 111 111
;  C 1178  1                          BFFF    137777          1 011 111 111 111 111
;  C 1179  1                          7FFF    077777          0 111 111 111 111 111
;  C 1180  1
;  C 1181  1          Pattern 16      B6D9    133331          1 011 011 011 011 001
;  C 1182  1                          B6D9    133331          1 011 011 011 011 001
;  C 1183  1                          B6D9    133331          1 011 011 011 011 001
;  C 1184  1                          DB6C    155554          1 101 101 101 101 100
;  C 1185  1                          DB6C    155554          1 101 101 101 101 100
;  C 1186  1                          DB6C    155554          1 101 101 101 101 100
;  C 1187  1                          B6D9    133331          1 011 011 011 011 001
;  C 1188  1                          B6D9    133331          1 011 011 011 011 001
;  C 1189  1                          DB6C    155554          1 101 101 101 101 100
;  C 1190  1                          DB6C    155554          1 101 101 101 101 100
;  C 1191  1                          B6D9    133331          1 011 011 011 011 001
;  C 1192  1                          DB6C    155554          1 101 101 101 101 100
;  C 1193  1                          B6D9    133331          1 011 011 011 011 001
;  C 1194  1                          DB6C    155554          1 101 101 101 101 100
;  C 1195  1                          B6D9    133331          1 011 011 011 011 001
;  C 1196  1                          DB6C    155554          1 101 101 101 101 100
```

```
;  C 1197  1          Pattern 17      (LBN)*   (LBN)              (LBN)
;  C 1198  1                          8D36     106466     1 000 110 100 110 110
;  C 1199  1                          8D36     106466     1 000 110 100 110 110
;  C 1200  1                          72C9     071311     0 111 001 011 001 001
;  C 1201  1                          72C9     071311     0 111 001 011 001 001
;  C 1202  1                          72C9     071311     0 111 001 011 001 001
;  C 1203  1                          8D36     106466     1 000 110 100 110 110
;  C 1204  1                          8D36     106466     1 000 110 100 110 110
;  C 1205  1                          8D36     106466     1 000 110 100 110 110
;  C 1206  1                          8D36     106466     1 000 110 100 110 110
;  C 1207  1                          72C9     071311     0 111 001 011 001 001
;  C 1208  1                          72C9     071311     0 111 001 011 001 001
;  C 1209  1                          72C9     071311     0 111 001 011 001 001
;  C 1210  1                          72C9     071311     0 111 001 011 001 001
;  C 1211  1                          72C9     071311     0 111 001 011 001 001
;  C 1212  1                          8D36     106466     1 000 110 100 110 110
;  C 1213  1                          8D36     106466     1 000 110 100 110 110
;  C 1214  1                          8D36     106466     1 000 110 100 110 110
;  C 1215  1                          8D36     106466     1 000 110 100 110 110
;  C 1216  1                          8D36     106466     1 000 110 100 110 110
;  C 1217  1                          8D36     106466     1 000 110 100 110 110
;  C 1218  1
;  C 1219  1                  * This word position contains the number of the locical
;  C 1220  1                    block to be written.
;  C 1221  1
;  C 1222  1
;  C 1223  1
;  C 1224  1          Pattern 18      8D36     106466     1 000 110 100 110 110
;  C 1225  1                          (LBN)    (LBN)              (LBN)
;  C 1226  1                          72C9     071311     0 111 001 011 001 001
;  C 1227  1                          8D36     106466     1 000 110 100 110 110
;  C 1228  1                          8D36     106466     1 000 110 100 110 110
;  C 1229  1                          8D36     106466     1 000 110 100 110 110
;  C 1230  1                          72C9     071311     0 111 001 011 001 001
;  C 1231  1                          72C9     071311     0 111 001 011 001 001
;  C 1232  1                          72C9     071311     0 111 001 011 001 001
;  C 1233  1                          72C9     071311     0 111 001 011 001 001
;  C 1234  1                          8D36     106466     1 000 110 100 110 110
;  C 1235  1                          8D36     106466     1 000 110 100 110 110
;  C 1236  1                          8D36     106466     1 000 110 100 110 110
;  C 1237  1                          8D36     106466     1 000 110 100 110 110
;  C 1238  1                          8D36     106466     1 000 110 100 110 110
;  C 1239  1                          72C9     071311     0 111 001 011 001 001
;  C 1240  1                          72C9     071311     0 111 001 011 001 001
;  C 1241  1                          72C9     071311     0 111 001 011 001 001
;  C 1242  1                          72C9     071311     0 111 001 011 001 001
;  C 1243  1                          72C9     071311     0 111 001 011 001 001
;  C 1244  1                          72C9     071311     0 111 001 011 001 001
```

```
;  C 1245  1          Pattern 19      (LBN)   (LBN)              (LBN)
;  C 1246  1                          B999    134631     1 011 100 110 011 001
;  C 1247  1                          B999    134631     1 011 100 110 011 001
;  C 1248  1                          4666    043146     0 100 011 001 100 110
;  C 1249  1                          4666    043146     0 100 011 001 100 110
;  C 1250  1                          4666    043146     0 100 011 001 100 110
;  C 1251  1                          B999    134631     1 011 100 110 011 001
;  C 1252  1                          B999    134631     1 011 100 110 011 001
;  C 1253  1                          B999    134631     1 011 100 110 011 001
;  C 1254  1                          B999    134631     1 011 100 110 011 001
;  C 1255  1                          4666    043146     0 100 011 001 100 110
;  C 1256  1                          4666    043146     0 100 011 001 100 110
;  C 1257  1                          4666    043146     0 100 011 001 100 110
;  C 1258  1                          4666    043146     0 100 011 001 100 110
;  C 1259  1                          4666    043146     0 100 011 001 100 110
;  C 1260  1                          B999    134631     1 011 100 110 011 001
;  C 1261  1                          B999    134631     1 011 100 110 011 001
;  C 1262  1                          B999    134631     1 011 100 110 011 001
;  C 1263  1                          B999    134631     1 011 100 110 011 001
;  C 1264  1                          B999    134631     1 011 100 110 011 001
;  C 1265  1                          B999    134631     1 011 100 110 011 001
;  C 1266  1
;  C 1267  1          Pattern 20      B999    134631     1 011 100 110 011 001
;  C 1268  1                          (LBN)   (LBN)              (LBN)
;  C 1269  1                          4666    043146     0 100 011 001 100 110
;  C 1270  1                          B999    134631     1 011 100 110 011 001
;  C 1271  1                          B999    134631     1 011 100 110 011 001
;  C 1272  1                          B999    134631     1 011 100 110 011 001
;  C 1273  1                          4666    043146     0 100 011 001 100 110
;  C 1274  1                          4666    043146     0 100 011 001 100 110
;  C 1275  1                          4666    043146     0 100 011 001 100 110
;  C 1276  1                          4666    043146     0 100 011 001 100 110
;  C 1277  1                          B999    134631     1 011 100 110 011 001
;  C 1278  1                          B999    134631     1 011 100 110 011 001
;  C 1279  1                          B999    134631     1 011 100 110 011 001
;  C 1280  1                          B999    134631     1 011 100 110 011 001
;  C 1281  1                          B999    134631     1 011 100 110 011 001
;  C 1282  1                          4666    043146     0 100 011 001 100 110
;  C 1283  1                          4666    043146     0 100 011 001 100 110
;  C 1284  1                          4666    043146     0 100 011 001 100 110
;  C 1285  1                          4666    043146     0 100 011 001 100 110
;  C 1286  1                          4666    043146     0 100 011 001 100 110
;  C 1287  1                          4666    043146     0 100 011 001 100 110
;  C 1288  1
;  C 1289  1          Pattern 21      (LBN)   (LBN)              (LBN)
;  C 1290  1
;    1291  1      )⌘
```

```
;    1292  1      %sbttl 'PROGRAM HEADER'
;    1293  1
;    1294  1      library 'ZRQAHO.L16';                           ! RDRX EXERCISER GLOBAL LIBRARY
;    1295  1
;    1296  1      !MMMrequire 'BLSMAC.REQ';                       ! DIAGNOSTIC SUPERVISOR LIBRARY      ZZZ
;    1297  1      require 'HSAXAO.BLB';                           ! DIAGNOSTIC SUPERVISOR LIBRARY      ZZZ
;    3038  1
;    3039  1      literal
;    3040  1          DS%NBR_OF_TESTS = 1;                        ! NUMBER OF TESTS IN THIS DIAGNOSTIC
;    3041  1
;    3042  1      EQUALS;
;    3043  1
;    3044  1      POINTER (ALL);
;    3045  1
;    3046  1      !+
;    3047  1      ! THE PROGRAM HEADER IS THE INTERFACE BETWEEN
;    3048  1      ! THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
;    3049  1      !-
;    3050  1
;    3051  1      !ZZZ HEADER (%ascii'ZRQA', %ascii'G', %ascii'0', 32000, 1, PRI00);       !ZZZ NEED POSITIVE NUMBER
;    3052  1      HEADER (%ascii'ZRQA', %ascii'H', %ascii'0', 32000, 1, PRI00,1);          !ZZZ FINAL 1 = NO TESTING ON TRAPS (SAVE TI
ME)
;    3053  1      !MMM HEADER (%ascii'ZRQA', %ascii'X', %ascii'8', 32000, 1, PRI00,1);          !MMM FINAL 1 = NO TESTING ON TRAPS (SA
VE TIME)
;    3054  1
```

```
;    3055  1     %sbttl 'DISPATCH TABLE'
;    3056  1
;    3057  1     !+
;    3058  1     ! THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
;    3059  1     ! IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
;    3060  1     !-
;    3061  1
;    3062  1     DISPATCH (DS$NBR_OF_TESTS);
```

```
;    3063  1      %sbttl 'GLOBAL DATA SECTION'
;    3064  1
;    3065  1      !+
;    3066  1      ! THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
;    3067  1      ! IN MORE THAN ONE TEST.
;    3068  1      !-
;    3069  1
;    3070  1      psect
;    3071  1          global = $FFF$ (read, write, noexecute, global, concatenate);
;    3072  1
;    3073  1      global
;    3074  1          CST : blockvector [MAX_CTLR, CST_LEN, word] field (CST_FIELDS),
;    3075  1                              ! RUN-TIME CONTROLLER STATUS TABLES
;    3076  1          CST_ADDR : ref block [CST_LEN, word] field (CST_FIELDS),
;    3077  1                              ! CONTROLLER STATUS TABLE ADDRESS OF "CURRENT" CONTROLLER
;    3078  1          DCT : blockvector [MAX_CTLR, DCT_LEN, word] field (DCT_FIELDS),
;    3079  1                              ! DRIVER CONTROLLER TABLES
;    3080  1          DCT_ADDR : ref block [DCT_LEN, word] field (DCT_FIELDS),
;    3081  1                              ! ADDRESS OF "CURRENT" DRIVER CONTROLLER TABLE
;    3082  1          RDRX_ADDR : ref rdrx field (RC_REG),
;    3083  1                              ! DEVICE ADDRESS OF "CURRENT" CONTROLLER
;    3084  1          IRDRX_ADDR : ref rdrx field (RC_REG),
;    3085  1                              ! DEVICE ADDRESS OF INTERRUPTING CONTROLLER
;    3086  1
;    3087  1          BST : BLOCKVECTOR [MAX_UNITS, 2, WORD],                                 !ZZZ
;    3088  1                              !CONTAINS LO+ HI LBN FIELDS FOR SEQUENTIAL          !ZZZ
;    3089  1                              !I/O TRANSFER FOR EACH UNIT.                        !ZZZ
;    3090  1          TALLY : vector [MAX_UNITS * TALLY_LEN, word] field (T_FIELDS),
;    3091  1                              ! STATISTICS TABLES
;    3092  1          T_ADDR : ref block [TALLY_LEN, word] field (T_FIELDS),
;    3093  1                              ! ADDRESS OF STATISTICS TABLE (TALLY) FOR CURRENT UNIT
;    3094  1
;    3095  1          !MMM DUPPKT : BLOCK [257, WORD] FIELD (DP_FIELDS),  !BUFFER FOR DUP  ZZZ
;    3096  1      !MMM                    !INFO FROM RECEIVE + SEND CMDS                      ZZZ
;    3097  1          TRK_SGN : VECTOR [MAX_UNITS, BYTE, SIGNED] INITIAL (BYTE (REP          !ZZZ
;    3098  1                  MAX_UNITS OF (1))),         !CURRENT TRACK DIRECTION           ZZZ
;    3099  1          RDM_CNT : WORD INITIAL (RDM_LEN),   !NO OF RANDOM NOS   \\KEEP         ZZZ
;    3100  1          RANDOM : VECTOR [RDM_LEN, WORD],    !RANDOM NO. TABLE   //TOGETHER     ZZZ
;    3101  1
;    3102  1          C_ERR_TBL : blockvector [MAX_CTLR, C_ERR_LEN, word] field (C_ERR_FIELDS),
;    3103  1                              ! STATISTICS TABLE FOR CONTROLLER ERRORS
;    3104  1          MSCP_PKT : blockvector [PKT_CNT, PKT_LEN, word] field (PKT_FIELDS),
;    3105  1                              ! MSCP PACKET POOL
;    3106  1          IPKT_ADDR : ref block [PKT_LEN, word] field (PKT_FIELDS),
;    3107  1                              ! ADDRESS OF AN MSCP PACKET (INTERUPT PROCESSING)
;    3108  1          PKT_USE : vector [PKT_CNT, byte, signed],
;    3109  1                              ! MSCP PACKET POOL ALLOCATION TABLE
;    3110  1          RETPKT : blockvector [RP_CNT, RP_LEN, word] field (RP_FIELDS),
;    3111  1                              ! RETURN PACKET POOL
;    3112  1          RP_USE : vector [RP_CNT, byte, signed],
;    3113  1                              ! RETURN PACKET POOL ALLOCATION TABLE
;    3114  1          RP_INDX : word,     ! CURRENT RETURN PACKET INDEX
;    3115  1          RP_ADDR : ref block [RP_LEN, word] field (RP_FIELDS),
```

```
;    3116  1                              ! CURRENT RETURN PACKET ADDRESS
;    3117  1          ELOG_PKT : blockvector [EP_CNT + 1, EP_LEN, word] field (EP_FIELDS),
;    3118  1                              ! ERROR-LOG PACKET SAVE AREA
;    3119  1          BUFF_ADDR : vector [MAX_BUF_CNT],                  ! TABLE OF I/O BUFFER DESCRIPTORS
;    3120  1          BUFF_OWN : vector [MAX_BUF_CNT, byte, signed],     ! I/O BUFFER OWNERSHIP (CONTROLLER NUMBER)
;    3121  1          IODQ : vector [IODQ_LEN, byte],                    ! I/O DONE QUEUE - CIRCULAR QUEUE OF RETPKT INDECES
;    3122  1          IODQ_IN : word,                                    ! I/O DONE QUEUE IN POINTER
;    3123  1          IODQ_OUT : word,                                   ! I/O DONE QUEUE OUT POINTER
;    3124  1          ENTRY_REASON : byte,                               ! CURRENT OPERATOR COMMAND
;    3125  1          EOP_FLAG : byte,                                   ! END-OF-PASS FLAG
;    3126  1          DUP_FLAGS : WORD,                                  !DUP FLAGS        ZZZ
;    3127  1          CCTLR : word,                                      ! NUMBER OF "CURRENT" CONTROLLER
;    3128  1          CDISK : word,                                      ! CURRENT DISK ADDRESS (RD/RX DISK NUMBER)
;    3129  1          CUOFF : word,                                      ! CURRENT UNIT CST OFFSET
;    3130  1          CTLR_CNT : word,                                   ! TOTAL NUMBER OF CONFIGURED CONTROLLERS
;    3131  1          DUR : vector [MAX_UNITS, byte],                    ! DROP UNIT REASON
;    3132  1          QIO : vector [MAX_CTLR, byte],                     ! NUMBER OF OUTSTANDING QIOs PER CONTROLLER
;    3133  1          FREE_MEM_ADDR,                                     ! START OF FREE MEMORY
;    3134  1          BYTS_PER_QIO : word,                               ! SIZE (BYTES) OF AN I/O BUFFER
;    3135  1          ST_CODE : word,                                    ! CURRENT STATUS CODE
;    3136  1          SB_CODE : word,                                    ! CURRENT SUB-CODE
;    3137  1          STEP : word,                                       ! CURRENT STEP IN HARD_INIT
;    3138  1          OF_RC : signed word,                               ! OFFSET (0 OR 2) TO READ IP OR SA
;    3139  1          SA_REG : word,                                     ! STORAGE FOR SA REGISTER READS AND WRITES
;    3140  1          CMD_TIME : word,                                   ! COMMAND TIMEOUT VALUE (IN SECONDS)
;    3141  1          NEX : word,                                        ! NON-EXISTENT MEMORY TRAP INDICATOR
;    3142  1          CRN_LOW : word,                                    ! COMMAND REF NUMBER OF LAST COMMAND SENT
;    3143  1          CRN_HIGH : word,                                   ! COMMAND REF NUMBER (HI ORDER)
;    3144  1          TEMP1 : WORD,                                      !TEMPORARY STORAGE WD USED IN BGNCLN              !ZZZ
;    3145  1          TEMP2 : WORD,                                      !TEMPORARY STORAGE WD USED IN BGNCLN              !ZZZ
;    3146  1          CREDIT_BAL : word,                                 ! CREDIT BALANCE
;    3147  1          NEXT_PKT_USE : byte,                               ! POINTER TO NEXT ENTRY IN PKT_USE TABLE
;    3148  1          HOURS : byte,                                      ! TIME OF DAY (HOURS)
;    3149  1          MINUTES : byte,                                    ! TIME OF DAY (MINUTES)
;    3150  1          CLK_TICKS : word,                                  ! TIME OF DAY (LINE-CLOCK TICKS)
;    3151  1          FER0_LBN : word,                                   !LO LBN ADR OF THE "FORCED ERROR" BLOCK                 ZZZ
;    3152  1          FER1_LBN : word,                                   !HI LBN ADR OF THE "FORCED ERROR" BLOCK                 ZZZ
;    3153  1          CLK_PRESENT : byte,                                ! FLAG INDICATES IF LINE-CLOCK PRESENT
;    3154  1          HOE_FLAG : byte,                                   ! FLAG INDICATES IF "HALT ON ERROR" FLAG SET
;    3155  1
;    3156  1          TYPER : VECTOR [MAX_UNITS, WORD],    !READ I/O COUNTER                    ZZZ MMM
;    3157  1          TYPEW : VECTOR [MAX_UNITS, WORD],    !WRITE I/O COUNTER                   ZZZ MMM
;    3158  1          BAL_IN_PROGRESS : VECTOR [MAX_UNITS, WORD],  !FLAG SET TO BALANCE I/O TYPES      ZZZ MMM
;    3159  1          FORCE_WR : VECTOR [MAX_UNITS, WORD],           ! MMM
;    3160  1          CSR_MEM : WORD,                                ! MMM
;    3161  1          CSR_ADD : WORD INITIAL (%o'172100'),           ! MMM
;    3162  1      !MMM    S_PATTERN : WORD,                        !PATTERN FOR DUP WRITES              ZZZ
;    3163  1      !MMM    S_DUPPKT : WORD,                         !DBN BYTE COUNTER                    ZZZ
;    3164  1          P_INDEX : SIGNED WORD,                 !CURRENT MESSAGE PACKET INDEX       ZZZ
;    3165  1          RD_COUNT : WORD INITIAL (0),           ! NUMBER OF WINCHESTER UNITS        ZZZ
;    3166  1          BRLEVEL : WORD,                        !BUS REQUEST LEVEL FROM OPERATOR    ZZZ
;    3167  1          D_FAIL : BYTE,                         !SIGNIFIES DUP TYPE ERROR           ZZZ
;    3168  1          FORCED_ERROR : byte,                               ! "FORCED ERROR" DETECTED IN LAST READ
```

```
;    3169  1          FER_LBN : word,                                 ! LBN OF THE "FORCED ERROR" BLOCK
;    3170  1          FER_BC : word,                                  ! BYTE COUNT OF THE "FORCED ERROR" BLOCK
;    3171  1          INIT_OCCURED : byte initial (byte (FALSE)),     ! EXERCISER INITIALIZATION COMPLETE
;    3172  1          ADDR_VECT_OK : byte initial (byte (FALSE));     ! FLAG INDICATES IF ADDRESS/VECTOR TEST PASSED
;    3173  1
;    3174  1      ERRTBL;
```

```
;    3175  1      %ebttl 'GLOBAL TEXT SECTION'
;    3176  1
;    3177  1      !+
;    3178  1      ! THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
;    3179  1      ! MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
;    3180  1      ! MORE THAN ONE TEST.
;    3181  1      !-
;    3182  1
;    3183  1      global bind
;    3184  1      !
;    3185  1      ! HARDWARE DIALOG
;    3186  1      !
;    3187  1          PTCH1 = uplit (%asciz'                                                  '),  !AREA TO PATCH IF NEEDED      ZZZ
;    3188  1          PTCH2 = uplit (%asciz'                                                  '),  !                             ZZZ
;    3189  1          PTCH3 = uplit (%asciz'                                                  '),  !                             ZZZ
;    3190  1          PTCH4 = uplit (%asciz'                                                  '),  !                             ZZZ

;    3191  1          PTCH5 = uplit (%asciz'                                                  '),  !                             ZZZ
;    3192  1          HWQ1 = uplit (%asciz'IP address'),
;    3193  1          HWQ2 = uplit (%asciz'Vector'),
;    3194  1          HWQ3 = uplit (%asciz'BR Level [usually 4-RQDX 5-RUX50]'),              !ZZZ
;    3195  1          HWQ4 = uplit (%asciz'Drive number'),                                   !ZZZ
;    3196  1          HWQ5 = uplit (%asciz'Test entire customer area of this disk'),         !ZZZ
;    3197  1          HWQ6A = uplit (%asciz'Lower octal word of beginning LBN address'),     !ZZZ
;    3198  1          HWQ6B = uplit (%asciz'Higher octal word of beginning LBN address'),    !ZZZ
;    3199  1          HWQ7A = uplit (%asciz'Lower octal word of ending LBN address'),        !ZZZ
;    3200  1          HWQ7B = uplit (%asciz'Higher octal word of ending LBN address'),       !ZZZ
;    3201  1          HWQ8 = uplit (%asciz'Write on customer data area of this disk unit'), !ZZZ
;    3202  1          HWQ9 = uplit (%asciz'** WARNING - CUSTOMER DATA AREA MAY BE OVERWRITTEN! ... CONFIRM'),
;    3203  1      !MMM    HWQ10 = uplit (%asciz'Also run DUP exerciser'),                    !ZZZ
;    3204  1      !MMM    HWQ11 = uplit (%asciz'Write on diagnostic area'),                  !ZZZ
;    3205  1      !
;    3206  1      ! SOFTWARE DIALOG
;    3207  1      !
;    3208  1          SWQ1  = uplit (%asciz'Hard error limit'),                                                          !ZZZ
;    3209  1          SWQ2  = uplit (%asciz'Transfer limit in megabytes (0 for quick pass)'),                            !ZZZ
;    3210  1          SWQ4  = uplit (%asciz'Random seek mode'),
;    3211  1          SWQ7  = uplit (%asciz'Read-compares performed at the controller'),
;    3212  1          SWQ9  = uplit (%asciz'Write-compares performed at the controller'),
;    3213  1          SWQ10 = uplit (%asciz'Check all writes at host by reading'),
;    3214  1          SWQ11 = uplit (%asciz'User-defined data pattern'),
;    3215  1          SWQ12 = uplit (%asciz'Select pre-defined data pattern (0 for sequential selection)'),
;    3216  1          SWQ13 = uplit (%asciz'Number of words in data pattern (16 maximum)'),
;    3217  1          SWQ14 = uplit (%asciz'Pattern value (no leading zeros allowed)'),
;    3218  1          SWQ15 = uplit (%asciz'Clear statistical tables after printing'),
;    3219  1          SWQ17 = uplit (%asciz'Percentage of "Fixed Disk" operations out of total operations'),
;    3220  1          SWQ19 = uplit (%asciz'Units to be selected at random (No, implies sequential)'),
;    3221  1          SWQ20 = uplit (%asciz'Rewrite blocks when "Forced Error" detected on reads'),
;    3222  1          SWQ21 = uplit (%asciz'Halt on other hard errors (@s 31-34, 36-37, 39-45)'),                        !ZZZ
;    3223  1          SWQ22 = uplit (%asciz'Halt on soft errors (@s 50-54)'),                                            !ZZZ
;    3224  1          SWQ23 = uplit (%asciz'Halt on bad-block hard errors (@s 35, 38)'),                                 !ZZZ
;    3225  1          SWQ24 = uplit (%asciz'Enter time as MMMM (example: 1305)'),                                        !ZZZ
;    3226  1      !MMM    SWQ25 = uplit (%asciz'Count each retry as a seperate soft error'),                                 !ZZZ
;    3227  1          SWQ26 = uplit (%asciz'Running under the A.P.T. Monitor'),                                          !ZZZ
```

```
;    3228  1          SWM1  = uplit (%asciz'The remaining questions only apply to unprotected disk units'),          !ZZZ
;    3229  1          SWQ27 = uplit (%asciz'Manufacturing Test'),                                                   !MMM
;    3230  1          SWQ28 = uplit (%asciz'Enable Host Memory (MSV11-P,L,J) Parity'),                              !MMM
;    3231  1
;    3232  1
;    3233  1          NULL  = uplit (%asciz''),
;    3234  1
;    3235  1      !++
;    3236  1      !  THE FOLLOWING DBMs ARE DEBUG MESSAGES, AND SHOULD BE REMOVED BEFORE
;    3237  1      !  RELEASING THE PROGRAM.  THEY INCLUDE THE NAMES OF EACH ROUTINE, PLUS
;    3238  1      !  FORMAT STATEMENTS FOR PRINTING OUT OTHER INFORMATION.
;    3239  1      !--
;    3240  1
;    3241  1          DBM5   = uplit (%asciz'%N%A** Drop unit %D2'),
;    3242  1          DBM12  = uplit (%asciz'%N%A** PROC_RETPKT: Conn ID %O6%A received'),
;    3243  1          DBM15  = uplit (%asciz'%N%A** Multi-drive test'),
;    3244  1          DBM18  = uplit (%asciz'%N%A** FATAL_ERROR: RETPKT not available'),
;    3245  1          DBM19  = uplit (%asciz'%N%A** FSET_UPAR: Can''t find disk %D3%A in CST %D1'),
;    3246  1          DBM20  = uplit (%asciz'%N%A** Bad conn ID %O6%A received from %O6'),
;    3247  1          DBM21  = uplit (%asciz'%N%A** Message type %O2%A received in MSCP packet'),
;    3248  1          DBM22  = uplit (%asciz'%N%A** SEQUEN: RETPKT not available'),
;    3249  1          DBM23  = uplit (%asciz'%N%A** Error in SET_CTLR_CHAR'),
;    3250  1          DBM25  = uplit (%asciz'%N%A** Ctlr timeout = %D3%A, seconds'),
;    3251  1          DBM26  = uplit (%asciz'%N%A** Error in UNIT_INIT'),
;    3252  1          DBM27  = uplit (%asciz'%N%A** UNIT_INIT: RETPKT has bad ENDCODE'),
;    3253  1          DBM28A = uplit (%asciz'%N%A** Unit size (Lo) = %D5%A.'),
;    3254  1          DBM28B = uplit (%asciz'%N%A** Unit size (Hi) = %D5%A.'),
;    3255  1          DBM29  = uplit (%asciz'%N%A** ACCESS: RETPKT has bad ENDCODE'),
;    3256  1          DBM32  = uplit (%asciz'%N%A** QIO_UNIT: CST %D1%A no unit selected'),
;    3257  1          DBM101 = uplit (%asciz'%N%A** Unit # is: %O6'),
;    3258  1          DBM104 = uplit (%asciz'%N%A** Removable disk is selected'),
;    3259  1          DBM105 = uplit (%asciz'%N%A** Fixed disk is selected'),
;    3260  1          DBM107 = uplit (%asciz'%N%A** Illegal function: %O6'),
;    3261  1          DBM108 = uplit (%asciz'%N%A** Command ref # %O6%A/%O6%A (Oct) not sent by Host'),
;    3262  1          DBM109 = uplit (%asciz'%N%A** Unknown Error Log format %O3%A received'),
;    3263  1      !   DBM110 = uplit (%asciz'%N%A** Error-Log save area full'),
;    3264  1          DBM111 = uplit (%asciz'%N%A** Op-code %O3%A, End-code %O3%A for ref # %O6%A/%O6%A (8)'),
;    3265  1          DBM112 = uplit (%asciz'%N%A** Cmd-bc %O6%A/%O6%A Rsp-bc %O6%A/%O6%A for %O6%A/%O6%A (8)'),
;    3266  1          DBM120 = uplit (%asciz'%N%A** Response already received for cmd %O6%A/%O6%A (8)'),
;    3267  1          DBM121 = uplit (%asciz'%N%A** Failure to send command after # %O6%A/%O6%A (8)'),
;    3268  1          DBM123 = uplit (%asciz'%N%A** Response has Error Log(s):'),                                   !MMM
;    3269  1          DBM125 = uplit (%asciz'%N%A** HOST MEMORY ERROR, CSR =  %O6%A'),                              !MMM
;    3270  1          DBM126 = uplit (%asciz'%N%A** HOST MEMORY ERROR, EXTENTED CSR =  %O6%A'),                     !MMM
;    3271  1          DBM127 = uplit (%asciz'%N%A** BAD BLOCK REPLACEMENT REQUEST FLAG SET'),                       !MMM
;    3272  1          DBM128 = uplit (%asciz'%N%A** ERROR DURING REPLACEMENT (BAD BLOCK) FLAG SET'),                !MMM
;    3273  1
;    3274  1
;    3275  1      !
;    3276  1      ! DROP UNIT MESSAGES
;    3277  1      !
;    3278  1          DU_MSG = uplit (%asciz'%N%AUNIT%D2%A DROPPED - '),
;    3279  1          DU_RSN = uplit (
;    3280  1                   uplit (%asciz'%AUSER COMMAND%N'),
```

```
;    3281  1                uplit (%asciz'%ACONFIGURATION ERROR%N'),
;    3282  1                uplit (%asciz'%AINIT ERROR%N'),
;    3283  1                uplit (%asciz'%ATRANSFER LIMIT REACHED%N'),
;    3284  1                uplit (%asciz'%AERROR LIMIT REACHED%N'),
;    3285  1                uplit (%asciz'%AUNRECOVERABLE DRIVE ERROR%N'),
;    3286  1                uplit (%asciz'%AUNRECOVERABLE CONTROLLER ERROR%N'),
;    3287  1                uplit (%asciz'%AFAILED TO COME ONLINE%N'),
;    3288  1                uplit (%asciz'%AFAILED TO ACCESS EITHER FIRST OR LAST TRACK DURING INIT%N'),
;    3289  1                uplit (%asciz'%ADISK WRITE PROTECTED%N'),
;    3290  1                uplit (%asciz'%ACOMMAND TIME OUT%N')) : vector [11],
;    3291  1      !
;    3292  1      ! SYSTEM MESSAGES (PRINTF)
;    3293  1      !
;    3294  1          MSG_01 = uplit (%asciz'%N%APOWER DELAY - WAITING'),
;    3295  1          MSG_02 = uplit (%asciz'%N%AFUNCTIONAL TEST STARTED'),
;    3296  1          MSG_03 = uplit (%asciz'%N%N%AEXERCISER STARTED%N'),
;    3297  1      !
;    3298  1      ! REPORT MESSAGES (PRINTS)
;    3299  1      !
;    3300  1          RPT1  = uplit (%asciz'%N%N%AUNT DSK%S8%A# OF    # BYTES    # OF     # BYTES'),
;    3301  1          RPT2  = uplit (%asciz'%A  --HARD ERRORS-- --SOFT ERRORS--'),
;    3302  1          RPT3  = uplit (%asciz'%N%A #    #  TYPE  READS     READ    WRITES   WRITTEN'),
;    33C3  1          RPT4  = uplit (%asciz'%A  SEK DAT DRV HST SEK DAT DRV HST'),
;    3304  1          RPT5  = uplit (%asciz'%N%A--- --- ----  -----  --------- ------  ---------'),
;    3305  1          RPT6  = uplit (%asciz'%A --- --- --- --- --- --- --- ---'),
;    3306  1          RPT7  = uplit (%asciz'%N%D2%D4%S2%T'),
;    3307  1          RPT8  = uplit (%asciz'%D4%Z3%D3%A,%Z3%A,%Z3'),
;    3308  1          RPT9  = uplit (%asciz'%D4%D4%D4%D4%D4%D4%D4%D4'),
;    3309  1          RPT10 = uplit (%asciz'%N%A .   .   CNTR      .  .........      .  .........'),
;    3310  1          RPT11 = uplit (%asciz'%A   .   .%D4%A    .   .   .%D4%A    .'),
;    3311  1          RPT12 = uplit (%asciz'%A   .   .%D4%A    .   .   .%D4%A    .'),
;    3312  1          RPT13 = UPLIT(%ASCIZ'%N%N%AUNIT  DISK          # OF    # BLKS       # OF     # BLKS '),
;    3313  1          RPT14 = UPLIT(%ASCIZ'%N%A  #     #     TYPE   READS     READ      WRITES  WRITTEN '),
;    3314  1          RPT15 = UPLIT(%ASCIZ'%N%A----  ----  -------  ------  ------    ------  ------  '),
;    3315  1          RPT16 = UPLIT(%ASCIZ'%N%S1%D2%S4%D2%A   DBN I/O  %D6%S3%D6%S5%D6%S3%D6'),
;    3316  1      !ZZZ     RPT17  = uplit (%asciz'%N%D2%D4%A  RD52'),
;    3317  1      !ZZZ     RPT18 = UPLIT(%ASCIZ'%N%S1%D2%S4%D2%A   D8NRD52  %D6%S3%D6%S5%D6%S3%D6'),
;    3318  1      !ZZZ     RPT19  = uplit (%asciz'%N%D2%D4%A  ????'),
;    3319  1
;    3320  1      !
;    3321  1      ! GENERAL ERROR MESSAGES
;    3322  1      !
;    3323  1      !       SYSTEM FATAL (ERRSF)
;    3324  1      !
;    3325  1          EGS_01 = uplit (%asciz'TOO MANY UNITS'),
;    3326  1          EGS_02 = uplit (%asciz'NOT ENOUGH FREE MEMORY FOR ALLOCATING READ/WRITE BUFFERS'),
;    3327  1      !
;    3328  1      !       DRIVE FATAL (ERRDF)
;    3329  1      !
;    3330  1          EGD_10 = uplit (%asciz'REGISTER EXISTENCE TEST FAILED'),
;    3331  1          EGD_11 = uplit (%asciz'VECTOR TEST FAILED'),
;    3332  1          EGD_12 = uplit (%asciz'BR LEVEL TEST FAILED'),
;    3333  1          EGD_13 = uplit (%asciz'INIT SEQUENCE FAILED'),
```

```
;    3334  1          EGD_14 = uplit (%asciz'FATAL CONTROLLER ERROR'),
;    3335  1          EGD_15 = uplit (%asciz'ONLINE FAILED'),
;    3336  1          EGD_16 = uplit (%asciz'WRITE-PROTECT CONFLICT'),
;    3337  1          EGD_17 = uplit (%asciz'ACCESS FAILED'),
;    3338  1          EGD_18 = uplit (%asciz'FATAL I/O ERROR'),
;    3339  1      !   EGD_19 = uplit (%asciz'CONTROLLER TIMEOUT'),
;    3340  1          EGD_19 = uplit (%asciz'DISK TYPE UNKNOWN TO EXERCISER'),
;    3341  1          EGD_20 = uplit (%asciz'FAILED TO SEND SET-CONTROLLER-CHARACTERISTICS COMMAND'),
;    3342  1          EGD_21 = uplit (%asciz'SET-CONTROLLER-CHARACTERISTICS RESPONSE HAS BAD ENDCODE OR FLAGS IN EPROR'),
;    3343  1          EGD_22 = uplit (%asciz'FAILED TO SEND ON-LINE COMMAND'),
;    3344  1          EGD_23 = uplit (%asciz'ON-LINE RESPONSE HAS BAD ENDCODE'),
;    3345  1          EGD_24 = uplit (%asciz'ON-LINE RESPONSE HAS UNKNOWN DEVICE'),
;    3346  1      !
;    3347  1      !       HARD or SOFT (ERRHRD or ERRSOFT)
;    3348  1      !
;    3349  1          EGH_30 = uplit (%asciz'I/O REQUEST FAILED'),
;    3350  1      !
;    3351  1      ! BASIC ERROR MESSAGES (PRINTB)
;    3352  1      !
;    3353  1      !       SYSTEM FATAL (ERRSF)
;    3354  1      !
;    3355  1          EBS_01 = uplit (%asciz'%AMORE THAN %D2%A UNITS SPECIFIED'),
;    3356  1      !
;    3357  1      !       DRIVE FATAL (ERRDF)
;    3358  1      !
;    3359  1          EBD_10 = uplit (%asciz'%A+ NO RESPONSE AT ADDRESS %O6'),
;    3360  1          EBD_12 = uplit (%asciz'%A+ INCORRECT BR LEVEL FOR DRIVE %O6'),
;    3361  1          EBD_13 = uplit (%asciz'%A+ STEP %D1%A READ ERROR'),
;    3362  1          EBD_14 = uplit (%asciz'%A+ BAD SA CODE FROM DRIVE %O6'),
;    3363  1          EBD_18 = uplit (%asciz'%A+ DISK%D2%A WENT OFFLINE'),
;    3364  1          EBD_19 = uplit (%asciz'%A+ DRIVE %O6%A NOT PROCESSING COMMAND PACKETS'),
;    3365  1          EBD_24 = uplit (%asciz'%A+ DISK%D2%A WENT TO THE "AVAILABLE" STATE'),
;    3366  1      !
;    3367  1      !
;    3368  1      !       HARD or SOFT (ERRHRD or ERRSOFT)
;    3369  1      !
;    3370  1      EH_0 = UPLIT (%ASCIZ' - UNRECOGNIZED MESSAGE TYPE'),                    !ZZZ
;    3371  1      EH_1 = UPLIT (%ASCIZ' - UNRECOGNIZED CONNECTION ID'),                   !ZZZ
;    3372  1      EH_2 = UPLIT (%ASCIZ' - UNRECOGNIZED RETURN MESSAGE'),                  !ZZZ
;    3373  1      EH_3 = UPLIT (%ASCIZ' - UNRECOGNIZED RETURN PACKET'),                   !ZZZ
;    3374  1      EH_4 = UPLIT (%ASCIZ' - UNRECOGNIZED CRN'),                             !ZZZ
;    3375  1      EH_5 = UPLIT (%ASCIZ' - UNRECOGNIZED OPCODE'),                          !ZZZ
;    3376  1      EH_6 = UPLIT (%ASCIZ' - MSCP STATUS CODE ERR'),                         !ZZZ
;    3377  1      EH_7 = UPLIT (%ASCIZ' - DUP STATUS CODE ERR'),                          !ZZZ
;    3378  1      EH_8 = UPLIT (%ASCIZ' - UNRECOGNIZED STATUS CODE'),                     !ZZZ
;    3379  1      EH_9 = UPLIT (%ASCIZ' - LBN HOST COMPARE ERR'),                         !ZZZ
;    3380  1      EH_10 = UPLIT (%ASCIZ' - DBN HOST COMPARE ERR'),                        !ZZZ
;    3381  1      EH_12 = UPLIT (%ASCIZ' - UNABLE TO LOAD DUP MEDIA'),                    !ZZZ
;    3382  1      EH_13 = UPLIT (%ASCIZ' - ERR IN DUP PKT WHEN USING CTLR LC PROG'),      !ZZZ
;    3383  1      !
;    3384  1          ERR_00  = uplit (%asciz'%A+ DISK%D2'),
;    3385  1          ERR_COD = uplit (
;    3386  1                    uplit (%asciz'%AINVALID COMMAND'),
```

```
;    3387  1                    uplit (%asciz'%ACOMMAND ABORTED'),
;    3388  1                    uplit (%asciz'%AUNIT OFFLINE'),
;    3389  1                    uplit (%asciz'%ATRANSITION TO AVAILABLE STATE'),
;    3390  1                    uplit (%asciz'%AMEDIA FORMAT ERROR'),
;    3391  1                    uplit (%asciz'%AWRITE-PROTECTED'),
;    3392  1                    uplit (%asciz'%ADEVICE COMPARE ERROR'),
;    3393  1                    uplit (%asciz'%ADATA ERROR'),
;    3394  1                    uplit (%asciz'%AHOST BUFFER ACCESS ERROR'),
;    3395  1                    uplit (%asciz'%ACONTROLLER ERROR'),
;    3396  1                    uplit (%asciz'%ADRIVE ERROR'),
;    3397  1                    uplit (%asciz'%AMESSAGE FROM INTERNAL DIAGNOSTICS'),
;    3398  1                    uplit (%asciz'%AHOST COMPARE ERROR'),
;    3399  1                    uplit (%asciz'%ACOMMAND TIMEOUT'),
;    3400  1                    uplit (%asciz'%ABAD BLOCK REPLACEMENT COMPLETION')) : vector [15],                    !MMM
;    3401  1        !
;    3402  1        !       ERROR LOG MESSAGE (ERRSOFT)
;    3403  1        !
;    3404  1            ELG_00  = uplit (%asciz'%AERROR LOG MESSAGE RECEIVED:%N'),
;    3405  1            ELG_FMT = uplit (
;    3406  1                    uplit (%asciz'%A* CONTROLLER ERROR%N'),
;    3407  1                    uplit (%asciz'%A* HOST MEMORY ACCESS ERROR%N'),
;    3408  1                    uplit (%asciz'%A* DISK%D2%A - DISK TRANSFER ERROR%N'),
;    3409  1                    uplit (%asciz'%A* DISK%D2%A - "STANDARD DISK INTERCONNECT" ERROR%N'),
;    3410  1                    uplit (%asciz'%A* DISK%D2%A - "SMALL DISK" ERROR%N'),
;    3411  1                    uplit (%asciz'%A* DISK%D2%A - "BAD BLOCK REPLACEMENT ATTEMPT"%N')) : vector [6],      !MMM
;    3412  1        !
;    3413  1        ! EXTENDED ERROR MESSAGES (PRINTX)
;    3414  1        !
;    3415  1            EX_SA  = uplit (%asciz'%N%A* SA: %O6'),
;    3416  1            EX_SC  = uplit (%asciz'%N%A* STATUS CODE: %O2'),
;    3417  1            EX_SBO = uplit (%asciz'%O4'),
;    3418  1            EX_SB  = uplit (%asciz'%N%A* SUB_CODE: '),
;    3419  1            EX_CMD = uplit (%asciz'%N%A* COMMAND: '),
;    3420  1            EX_RD  = uplit (%asciz'%AREAD'),
;    3421  1            EX_WRT = uplit (%asciz'%AWRITE'),
;    3422  1            EX_CMP = uplit (%asciz'%A-COMPARE'),
;    3423  1            EX_ONL = uplit (%asciz'%AONLINE'),
;    3424  1            EX_ACC = uplit (%asciz'%AACCESS'),
;    3425  1            EX_OP  = uplit (%asciz'%O3'),
;    3426  1        !ZZZ    EX_BB  = uplit (%asciz'%N%A* BAD BLOCK (Host replaceable): %D5%A. (OCT %O6%A)'),
;    3427  1        !ZZZ    EX_BB1 = uplit (%asciz'%N%A* 1st BAD BLOCK (Host replaceable): %D5%A. (OCT %O6%A)'),
;    3428  1        !ZZZ    EX_BBU = uplit (%asciz'%N%A* BAD BLOCK REPORTED (Replaced): %D%A. (OCT %O6%A)'),
;    3429  1        !ZZZ    EX_LBN = uplit (%asciz'%N%A* LBN: %D5%A. (OCT %O6%A)'),
;    3430  1        !ZZZ    EX_PBN = uplit (%asciz'%N%A* PBN: %D5%A. (OCT %O6%A)'),
;    3431  1        !ZZZ    EX_LBR = uplit (%asciz'%N%A* LBN: (READ) %D5%A. (OCT %O6%A)'),
;    3432  1        !ZZZ    EX_LBW = uplit (%asciz'%N%A* LBN: (WRITE) %D5%A. (OCT %O6%A)'),
;    3433  1        !ZZZ    EX_RBN = uplit (%asciz'%N%A* REPLACEMENT BLOCK NO. %D5%A. (OCT %O6%A)'),
;    3434  1            EX_BB2 = uplit (%asciz'%N%A* BAD BLOCK: %O6%A %O6%A  (OCTAL)'),                           !ZZZ
;    3435  1            EX_BB12 = uplit (%asciz'%N%A* 1ST BAD BLOCK: %O6%A %O6%A  (OCTAL)'),                      !ZZZ
;    3436  1            EX_BBU2 = uplit (%asciz'%N%A* BAD BLOCK REPLACED: %O6%A %O6%A  (OCTAL)'),                 !ZZZ
;    3437  1            EX_LBN2 = uplit (%asciz'%N%A* LBN: %O6%A %O6%A  (OCTAL)'),                                !ZZZ
;    3438  1            EX_PBN2 = uplit (%asciz'%N%A* PBN: %O6%A %O6%A  (OCTAL)'),                                !ZZZ
;    3439  1            EX_LBR2 = uplit (%asciz'%N%A* LBN READ: %O6%A %O6%A  (OCTAL)'),                           !ZZZ
```

```
;    3440  1          EX_LBW2 = uplit (%asciz'%N%A* LBN WRITTEN: %O6%A %O6%A  (OCTAL)'),                                  !ZZZ
;    3441  1          EX_RBN2 = uplit (%asciz'%N%A* RBN: %O6%A %O6%A  (OCTAL)'),                                         !ZZZ
;    3442  1          EX_CBC = uplit (%asciz'%N%A* BYTE COUNT IN COMMAND: %D5%A.'),
;    3443  1          EX_CBR = uplit (%asciz'%N%A* BYTE COUNT IN READ COMMAND: %D5%A.'),
;    3444  1          EX_CBW = uplit (%asciz'%N%A* BYTE COUNT IN WRITE COMMAND: %D5%A.'),
;    3445  1          EX_BC  = uplit (%asciz'%N%A* ACTUAL # OF BYTES TRANSFERRED: %D5%A.'),
;    3446  1          EX_BD  = uplit (%asciz'%N%A* I/O BUFFER ADDRESS (32 bits): %O6%A %O6'),
;    3447  1          EX_BDR = uplit (%asciz'%N%A* I/O BUFFER ADDRESS FOR READ (32 bits): %O6%A %O6'),
;    3448  1          EX_BDW = uplit (%asciz'%N%A* I/O BUFFER ADDRESS FOR WRITE (32 bits): %O6%A %O6'),
;    3449  1          EX_RP  = uplit (%asciz'%N%ACONTENTS OF COMMAND/RESPONSE PACKET SAVE AREA:%N'),
;    3450  1          EX_WRD = uplit (%asciz'%A %O6'),
;    3451  1          EX_TIM = uplit (%asciz'%N%ATIME: %Z2%A:%Z2%A HOURS%N'),                                             !MMM
;    3452  1      !    EX_DUP = uplit (%asciz'%N%A* DUP FATAL TYPE MESSAGE, ERROR CODE: %O4%A (OCTAL)'),                   !MMM
;    3453  1          EX_LB = uplit (%asciz'%N%A* BAD LBN: %O6%A %O6%A  (OCTAL)'),                                !MMM
;    3454  1
;    3455  1
;    3456  1          XX13 = UPLIT (%ASCIZ'%N%A * DISK : %D2'),                                   !ZZZ
;    3457  1          XX23 = UPLIT (%ASCIZ'%N%ADBN: %D5%A, (OCT %O6%A)'),                         !ZZZ
;    3458  1          XX32 = UPLIT (%ASCIZ'%N%ABYTE NUMBER: %D3'),                                !ZZZ
;    3459  1          XX33 = UPLIT (%ASCIZ'%N%ARANDOM WRITTEN WORD :%B16'),                       !ZZZ
;    3460  1          XX34 = UPLIT (%ASCIZ'%N%ARANDOM READ WORD bin:%B16%A oct:%O6'),             !ZZZ
;    3461  1
;    3462  1      !
;    3463  1      ! CONFIGURATION ERROR MESSAGES (PRINTF)
;    3464  1      !
;    3465  1          CER_01 = uplit (%asciz'%N%ADUPLICATE UNIT:%D2%A AT IP: %O6'),
;    3466  1          CER_02 = uplit (%asciz'%N%AMORE THAN %D1%A DIFFERENT IP ADDRESSES'),
;    3467  1      !
;    3468  1      ! ERROR/EVENT SUB CODES (PRINTX)
;    3469  1      !
;    3470  1          SC_SDI = uplit (%asciz'%ASPIN-DOWN IGNORED'),
;    3471  1          SC_CON = uplit (%asciz'%ASTILL CONNECTED'),
;    3472  1          SC_DUP = uplit (%asciz'%ADUPLICATE UNIT NUMBER'),
;    3473  1          SC_ONL = uplit (%asciz'%AALREADY ONLINE'),
;    3474  1          SC_SON = uplit (%asciz'%ASTILL ONLINE'),
;    3475  1          SC_INR = uplit (%asciz'%AINCOMPLETE REPLACEMENT'),                          !MMM
;    3476  1          SC_INV = uplit (%asciz'%AINVALID RCT'),                                     !MMM
;    3477  1          SC_UNK = uplit (%asciz'%AUNIT UNKNOWN OR ONLINE TO ANOTHER CONTROLLER'),
;    3478  1          SC_VOL = uplit (%asciz'%ANO VOLUME MOUNTED OR DRIVE DISABLED BY SWITCH'),
;    3479  1          SC_IOP = uplit (%asciz'%AUNIT INOPERATIVE (RD51/52 write fault)'),
;    3480  1          SC_DIS = uplit (%asciz'%AUNIT DISABLED BY FIELD SERVICE OR INTERNAL DIAGNOSTICS'),
;    3481  1          SC_FER = uplit (%asciz'%A"FORCED ERROR" DETECTED WHILE ACCESSING FCT OR RCT'),
;    3482  1          SC_FE2 = uplit (%asciz'%ASECTOR HAD BEEN WRITTEN WITH "FORCED ERROR" MODIFIER'),
;    3483  1          SC_ISH = uplit (%asciz'%AFCT OR RCT UNREADABLE - INVALID SECTOR HEADER'),
;    3484  1          SC_IS2 = uplit (%asciz'%AHEADER COMPARE ERROR (Valid header not found)'),
;    3485  1          SC_DST = uplit (%asciz'%AFCT OR RCT UNREADABLE - DATA SYNC TIMEOUT'),
;    3486  1          SC_DS2 = uplit (%asciz'%ADATA SYNC NOT FOUND (Data sync timeout)'),
;    3487  1          SC_ECC = uplit (%asciz'%AFCT OR RCT UNREADABLE - UNCORRECTABLE ECC ERROR'),
;    3488  1          SC_ECD = uplit (%asciz'%AUNCORRECTABLE ECC ERROR'),
;    3489  1          SC_RCT = uplit (%asciz'%ARCT CORRUPTED'),
;    3490  1          SC_FUL = uplit (%asciz'%ANO REPLACEMENT BLOCK AVAILABLE (RCT full)'),
;    3491  1          SC_576 = uplit (%asciz'%ADISK NOT FORMATTED WITH 512 BYTE SECTORS'),
;    3492  1          SC_FCT = uplit (%asciz'%ADISK NOT FORMATTED OR FCT CORRUPTED'),
```

```
;    3493  1          SC_EC1 = uplit (%asciz'%AONE SYMBOL ECC ERROR'),
;    3494  1          SC_EC2 = uplit (%asciz'%ATWO SYMBOL ECC ERROR'),
;    3495  1          SC_EC3 = uplit (%asciz'%ATHREE SYMBOL ECC ERROR'),
;    3496  1          SC_EC4 = uplit (%asciz'%AFOUR SYMBOL ECC ERROR'),
;    3497  1          SC_EC5 = uplit (%asciz'%AFIVE SYMBOL ECC ERROR'),
;    3498  1          SC_EC6 = uplit (%asciz'%ASIX SYMBOL ECC ERROR'),
;    3499  1          SC_EC7 = uplit (%asciz'%ASEVEN SYMBOL ECC ERROR'),
;    3500  1          SC_EC8 = uplit (%asciz'%AEIGHT SYMBOL ECC ERROR'),
;    3501  1          SC_EC9 = uplit (%asciz'%ACORRECTABLE ERROR IN ECC FIELD'),
;    3502  1          SC_SWP = uplit (%asciz'%AUNIT SOFTWARE WRITE PROTECTED'),
;    3503  1          SC_HWP = uplit (%asciz'%AUNIT HARDWARE WRITE PROTECTED'),
;    3504  1          SC_SAF = uplit (%asciz'%AUNIT DATA SAFETY WRITE PROTECTED'),      !MMM
;    3505  1          SC_ODA = uplit (%asciz'%AODD TRANSFER ADDRESS'),
;    3506  1          SC_ODB = uplit (%asciz'%AODD BYTE COUNT'),
;    3507  1          SC_NXM = uplit (%asciz'%ANON-EXISTENT HOST MEMORY'),
;    3508  1          SC_PAR = uplit (%asciz'%AHOST MEMORY PARITY ERROR'),
;    3509  1          SC_CTO = uplit (%asciz'%ACOMMAND TIMOUT OR RETRY LIMIT EXCEEDED'),
;    3510  1          SC_SDS = uplit (%asciz'%ASERIALIZER/DESERIALIZER OVERRUN OR UNDERRUN'),
;    3511  1          SC_EDC = uplit (%asciz'%A"ERROR DETECTION CODE" ERROR'),
;    3512  1          SC_IDS = uplit (%asciz'%AINCONSISTENT INTERNAL DATA STRUCTURE'),
;    3513  1          SC_SRT = uplit (%asciz'%ADRIVE COMMAND TIMEOUT (No response or seek incomplete)'),
;    3514  1          SC_SRI = uplit (%asciz'%ACONTROLLER DETECTED TRANSMISSION OR PROTOCOL ERROR'),
;    3515  1          SC_POE = uplit (%asciz'%APOSITION ERROR (Mis-seek)'),
;    3516  1          SC_RDY = uplit (%asciz'%ALOST READ/WRITE READY DURING/BETWEEN TRANSFERS'),
;    3517  1          SC_CLK = uplit (%asciz'%ADRIVE CLOCK DROPOUT'),
;    3518  1          SC_RSP = uplit (%asciz'%ALOST RECEIVER READY BETWEEN SECTORS'),
;    3519  1          SC_SUR = uplit (%asciz'%ADRIVE DETECTED ERROR'),
;    3520  1          SC_PSP = uplit (%asciz'%ACONTROLLER DETECTED PULSE OR STATE PARITY ERROR'),
;    3521  1          SC_REP = uplit (%asciz'%ABAD BLOCK SUCCESSFULLY REPLACED'),                                  !MMM
;    3522  1          SC_NBB = uplit (%asciz'%ABLOCK VERIFIED OK -- NOT A BAD BLOCK'),                             !MMM
;    3523  1          SC_REF = uplit (%asciz'%AREPLACEMENT FAILURE'),                                              !MMM
;    3524  1      !
;    3525  1      ! CONTROLLER GENERIC ERROR CODES
;    3526  1      !
;    3527  1          CNTR_ERR = uplit (
;    3528  1                     uplit (%asciz'%ACONTROLLER TIMEOUT'),
;    3529  1                     uplit (%asciz'%AENVELOPE/PACKET READ ERROR (Parity or timeout)'),
;    3530  1                     uplit (%asciz'%AENVELOPE/PACKET WRITE ERROR (Parity or timeout)'),
;    3531  1                     uplit (%asciz'%ACONTROLLER ROM AND RAM PARITY ERROR'),
;    3532  1                     uplit (%asciz'%ACONTROLLER RAM PARITY ERROR'),
;    3533  1                     uplit (%asciz'%ACONTROLLER ROM PARITY ERROR'),
;    3534  1                     uplit (%asciz'%ARING READ ERROR (Parity or timeout)'),
;    3535  1                     uplit (%asciz'%ARING WRITE ERROR (Parity or timeout)'),
;    3536  1                     uplit (%asciz'INTERRUPT MASTER FAILURE'),
;    3537  1                     uplit (%asciz'%AHOST ACCESS TIMEOUT (Higher level protocol dependent)'),
;    3538  1                     uplit (%asciz'%ACREDIT LIMIT EXCEEDED'),
;    3539  1                     uplit (%asciz'%AQ-BUS MASTER ERROR'),
;    3540  1                     uplit (%asciz'%ACONTROLLER FATAL ERROR'),
;    3541  1                     uplit (%asciz'%AINSTRUCTION LOOP TIMEOUT'),
;    3542  1                     uplit (%asciz'%AILLEGAL VIRTUAL CIRCUIT ID'),
;    3543  1                     uplit (%asciz'%AINTERRUPT VECTOR ILLEGAL'),
;    3544  1                     uplit (%asciz'%AMAINTENANCE READ/WRITE INVALID REGION IDENTIFIER'),
;    3545  1                     uplit (%asciz'%AMAINTENANCE WRITE LOAD TO NON-LOADABLE CONTROLLER'),
```

```
;    3546  1                    uplit (%asciz'%ACONTROLLER RAM ERROR (Non-parity)'),
;    3547  1                    uplit (%asciz'%AINIT SEQUENCE ERROR'),
;    3548  1                    uplit (%asciz'%AHIGHER LEVEL PROTOCOL INCOMPATIBILITY ERROR'),
;    3549  1                    uplit (%asciz'%APURGE/POLL HARDWARE FAILURE'),
;    3550  1                    uplit (%asciz'%AMAPPING REGISTER READ FAILURE (Parity or timeout)')) : vector [23],
;    3551  1      !
;    3552  1      ! RD/RX CONTROLLER DEPENDENT ERRORS CODES
;    3553  1      !
;    3554  1         RDRX_ERR = uplit (
;    3555  1                    uplit (%asciz'%AT11 CPU FAILURE'),
;    3556  1                    uplit (%asciz'%ANON-PARITY RAM ERROR'),
;    3557  1                    uplit (%asciz'%ASTATE MACHINE FAILURE - T11 ADDRESS REGISTER'),
;    3558  1                    uplit (%asciz'%ASTATE MACHINE FAILURE - Q-BUS ADDRESS REGISTER'),
;    3559  1                    uplit (%asciz'%ASTATE MACHINE FAILURE - CRC REGISTER'),
;    3560  1                    uplit (%asciz'%ASTATE MACHINE FAILURE - SERIALIZER/DESERIALIZER REGISTER'),
;    3561  1                    uplit (%asciz'%ASTATE MACHINE FAILURE - WRONG HARDWARE VERSION')) : vector [7],
;    3562  1      !
;    3563  1      ! PRINTOUTS THAT FAKE THE DRS ERROR MESSAGES
;    3564  1      !
;    3565  1         DF_MSG  = uplit (%asciz'%N%AZRQA DEV FTL  %Z5%A ON UNIT %Z2%A TST 001 SUB 000 PC: %06'),
;    3566  1         HRD_MSG = uplit (%asciz'%N%AZRQA HRD ERR  %Z5%A ON UNIT %Z2%A TST 001 SUB 000 PC: %06'),
;    3567  1         SFT_MSG = uplit (%asciz'%N%AZRQA SFT ERR  %Z5%A ON UNIT %Z2%A TST 001 SUB 000 PC: %06%N'),
;    3568  1         HRD_SUB = uplit (%asciz'%N%AI/O REQUEST FAILED%N'),
;    3569  1
;    3570  1
;    3571  1      !
;    3572  1      ! MISCELLANEOUS
;    3573  1      !
;    3574  1         SPACE4    = uplit (%asciz'%S4'),
;    3575  1         CRLF      = uplit (%asciz'%N'),
;    3576  1         DASH      = uplit (%asciz'%A - '),
;    3577  1         ASTERISK  = uplit (%asciz'%A* ');
```

```
;    3578  1      %sbttl 'DEFAULT HARDWARE P-TABLE'
;    3579  1
;    3580  1      !+
;    3581  1      ! THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
;    3582  1      ! THE TEST-DEVICE PARAMETERS.  THE STRUCTURE OF THIS TABLE
;    3583  1      ! IS IDENTICAL TO THE STRUCTURE OF THE HARDWARE P-TABLES,
;    3584  1      ! AND IS USED AS A "TEMPLATE" FOR BUILDING THE P-TABLES.
;    3585  1      !-
;    3586  1
;    3587  1      BGNHW (DFPTBL);
;    3588  1
;    3589  1      global
;    3590  1          HWPT_IP_ADDR : word initial (INIT_IP_ADDR),         ! IP ADDRESS
;    3591  1          HWPT_VECTOR : word initial (INIT_INTR_VECT),        ! VECTOR ADDRESS
;    3592  1          HWPT_BR_LEVEL : word initial (INIT_BR_LEVEL),       ! BR LEVEL
;    3593  1          HWPT_DISK : WORD INITIAL (%o'000200'),              !PROTECT, WHOLE DISK, NO DUP   ZZZ
;    3594  1                                                              ! DK 0        ZZZ
;    3595  1          HWPTS0_LBN : word initial (0),                      ! STARTING TRACK LO ZZZ
;    3596  1          HWPTS1_LBN : word initial (0),                      ! STARTING TRACK HI ZZZ
;    3597  1          HWPTE0_LBN : word initial (%o'177777'),             ! ENDING TRACK LO   ZZZ
;    3598  1          HWPTE1_LBN : word initial (0),                      ! ENDING TRACK HI   ZZZ
;    3599  1          NAME_LO    : WORD INITIAL (%o'020040'),             !DISK TYPE          ZZZ
;    3600  1          NAME_HI    : WORD INITIAL (%o'020040');             !DISK TYPE          ZZZ
;    3601  1
;    3602  1      ENDHW;
```

```
;    3603  1      %sbttl 'SOFTWARE P-TABLE'
;    3604  1
;    3605  1      !+
;    3606  1      ! THE SOFTWARE TABLE CONTAINS VARIOUS DATA USED BY THE
;    3607  1      ! PROGRAM AS OPERATIONAL PARAMETERS.  THESE PARAMETERS ARE
;    3608  1      ! SET UP AT ASSEMBLY TIME AND MAY BE VARIED BY THE OPERATOR
;    3609  1      ! AT RUN TIME.
;    3610  1      !-
;    3611  1
;    3612  1      BGNSW (SFPTBL);
;    3613  1
;    3614  1      global
;    3615  1          SWP_ERROR : word initial (32),                                  ! HARD ERROR LIMIT FOR DROPPING UNIT
;    3616  1          SWP_XFER : WORD INITIAL (0),                                    !XFER LIMIT. DEFAULT = QUICK PASS       !ZZZ
;    3617  1          SWP_FLAGS : word initial (SWF_RDM or SWF_CRC or SWF_HWC or SWF_FER  ! FLAGS (SEE DOCUMENTATION)         !ZZZ
;    3618  1                                   or SWF_HRD or SWF_BLK),                !                                       !ZZZ
;    3619  1          SWP_DPAT : word initial (0),                                    ! DATA PATTERN NUMBER
;    3620  1          SWP_RAT : word initial (99),                                    ! RD51/52 OPERATION RATIO
;    3621  1          SWP_TIME : word initial (0),                                    ! START TIME (HHMM)
;    3622  1      !MMM    DUPROUND : WORD INITIAL (11),              !NO OF I/Os PER DBN TEST ZZZ
;    3623  1
;    3624  1      !       THE NEXT TWO LOCATIONS SHOULD BE TOGETHER
;    3625  1
;    3626  1          SWP_UCNT : word initial (MAX_UDP_CNT),                          ! USER DATA PATTERN COUNT
;    3627  1          SWP_UDPAT : vector [MAX_UDP_CNT, word],                         ! USER DATA PATTERN
;    3628  1
;    3629  1          DUPROUND : WORD INITIAL (11),              !NO OF I/Os PER DBN TEST ZZZ
;    3630  1          MAN_TST : word initial (0),                                     ! Reduce Seek Duty cycle for Manufacturing MMM
;    3631  1          TST_PAR : word initial (1);                                     ! Enable Host Memory Parity MMM
;    3632  1
;    3633  1      ENDSW;
```

```
;    3634  1     %sbttl 'PROTECTION TABLE'
;    3635  1
;    3636  1     !+
;    3637  1     ! THIS TABLE IS USED BY THE RUNTIME SERVICES
;    3638  1     ! TO PROTECT THE LOAD MEDIA.
;    3639  1     !-
;    3640  1
;    3641  1     BGNPROT (0, -1, 6);
;    3642  1
;    3643  1     !1ST ARG =      OFFSET INTO P-TABLE FOR CSR ADDRESS
;    3644  1     !2ND ARG =      OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
;    3645  1     !3RD ARG =      OFFSET INTO P-TABLE FOR DRIVE NUMBER
;    3646  1
;    3647  1     ENDPROT;
;    3648  1     end
;    3649  1
;    3650  0     eludom


                                            .TITLE  ZRQAM1 RD/RX EXERCISER
                                            .IDENT  /V02.3/
                                            .ENABL  AMA

000000                                      .PSECT  $CODE$,  RO
000000     132     122     121      L$NAME::.ASCII  /ZRQ/
000003     101                              .ASCII  /A/
000004     000                              .BYTE   0
000005     000                              .BYTE   0
000006     000                              .BYTE   0
000007     000                              .BYTE   0
000010                              L$REV::
000010     110                              .ASCII  /H/
000011     060                              .ASCII  /0/
000012  000000G                     L$UNIT::.WORD   T$PTHV
000014  076400                      L$TIML::.WORD   76400
000016  000000G                     L$HPCP::.WORD   L$HARD
000020  000000G                     L$SPCP::.WORD   L$SOFT
000022  023764'                     L$HPTP::.WORD   L$HW
000024  024014'                     L$SPTP::.WORD   L$SW
000026  000000G                     L$LADP::.WORD   L$LAST
000030  000000                      L$STA:: .WORD   0
000032  000000                      L$CO::  .WORD   0
000034  000001                      L$DTYP::.WORD   1
000036  000000                      L$APT:: .WORD   0
000040  000124'                     L$DTP:: .WORD   L$DISPATCH
000042  000000                      L$PRIO::.WORD   0
000044  000000                      L$ENVI::.WORD   0
000046  000000                      L$EXP1::.WORD   0
000050                              L$MREV::
000050     004                              .BYTE   4
000051     000                              .BYTE   0
000052  000000                      L$EF::  .WORD   0
```

```
000054  000000                          .WORD   0
000056  000000                  L$SPC:: .WORD   0
000060  000000G                 L$DEVP::.WORD   L$DVTYP
000062  000000G                 L$REPP::.WORD   L$RPT
000064  000000                  L$EXP4::.WORD   0
000066  000000                  L$EXP5::.WORD   0
000070  000000G                 L$AUT:: .WORD   L$AU
000072  000000G                 L$DUT:: .WORD   L$DU
000074  000000                  L$LUN:: .WORD   0
000076  000000G                 L$DESP::.WORD   L$DESC
000100  104035                  L$LOAD::.WORD   -73743
000102  000126'                 L$ETP:: .WORD   L$ERRTBL
000104  000000G                 L$ICP:: .WORD   L$INIT
000106  000000G                 L$CCP:: .WORD   L$CLEAN
000110  000000G                 L$ACP:: .WORD   L$AUTO
000112  024102'                 L$PRT:: .WORD   L$PROT
000114  000001                  L$TEST::.WORD   1
000116  000000                  L$DLY:: .WORD   0
000120  000000                  L$HIME::.WORD   0
000122  000001                  D$PCNT::.WORD   1
000124  000000G                 L$DISPATCH::
                                        .WORD   T1
000126                          ERRTYP::.BLKW   1
000130                          ERRNBR::.BLKW   1
000132                          ERRMSG::.BLKW   1
000134                          ERRBLK::.BLKW   1
000136  040     040     040     P.AAA:  .ASCII  /   /
000141  040     040     040             .ASCII  /   /
000144  040     040     040             .ASCII  /   /
000147  040     040     040             .ASCII  /   /
000152  040     040     040             .ASCII  /   /
000155  040     040     040             .ASCII  /   /
000160  040     040     040             .ASCII  /   /
000163  040     040     040             .ASCII  /   /
000166  040     040     040             .ASCII  /   /
000171  040     040     040             .ASCII  /   /
000174  040     040     040             .ASCII  /   /
000177  040     040     040             .ASCII  /   /
000202  040     040     040             .ASCII  /   /
000205  040     040     000             .ASCII  /   /<00>
000210  040     040     040     P.AAB:  .ASCII  /   /
000213  040     040     040             .ASCII  /   /
000216  040     040     040             .ASCII  /   /
000221  040     040     040             .ASCII  /   /
000224  040     040     040             .ASCII  /   /
000227  040     040     040             .ASCII  /   /
000232  040     040     040             .ASCII  /   /
000235  040     040     040             .ASCII  /   /
000240  040     040     040             .ASCII  /   /
000243  040     040     040             .ASCII  /   /
000246  040     040     040             .ASCII  /   /
000251  040     040     040             .ASCII  /   /
000254  040     040     040             .ASCII  /   /
```

```
000257  040  040  000            .ASCII  /  /<00>
000262  040  040  040  P.AAC:    .ASCII  /  /
000265  040  040  040            .ASCII  /  /
000270  040  040  040            .ASCII  /  /
000273  040  040  040            .ASCII  /  /
000276  040  040  040            .ASCII  /  /
000301  040  040  040            .ASCII  /  /
000304  040  040  040            .ASCII  /  /
000307  040  040  040            .ASCII  /  /
000312  040  040  040            .ASCII  /  /
000315  040  040  040            .ASCII  /  /
000320  040  040  040            .ASCII  /  /
000323  040  040  040            .ASCII  /  /
000326  040  040  040            .ASCII  /  /
000331  040  040  000            .ASCII  /  /<00>
000334  040  040  040  P.AAD:    .ASCII  /  /
000337  040  040  040            .ASCII  /  /
000342  040  040  040            .ASCII  /  /
000345  040  040  040            .ASCII  /  /
000350  040  040  040            .ASCII  /  /
000353  040  040  040            .ASCII  /  /
000356  040  040  040            .ASCII  /  /
000361  040  040  040            .ASCII  /  /
000364  040  040  040            .ASCII  /  /
000367  040  040  040            .ASCII  /  /
000372  040  040  040            .ASCII  /  /
000375  040  040  040            .ASCII  /  /
000400  040  040  040            .ASCII  /  /
000403  040  040  000            .ASCII  /  /<00>
000406  040  040  040  P.AAE:    .ASCII  /  /
000411  040  040  040            .ASCII  /  /
000414  040  040  040            .ASCII  /  /
000417  040  040  040            .ASCII  /  /
000422  040  040  040            .ASCII  /  /
000425  040  040  040            .ASCII  /  /
000430  040  040  040            .ASCII  /  /
000433  040  040  040            .ASCII  /  /
000436  040  040  040            .ASCII  /  /
000441  040  040  040            .ASCII  /  /
000444  040  040  040            .ASCII  /  /
000447  040  040  040            .ASCII  /  /
000452  040  040  040            .ASCII  /  /
000455  040  040  000            .ASCII  /  /<00>
000460  111  120  040  P.AAF:    .ASCII  /IP /
000463  141  144  144            .ASCII  /add/
000466  162  145  163            .ASCII  /res/
000471  163  000  000            .ASCII  /s/<00><00>
000474  126  145  143  P.AAG:    .ASCII  /Vec/
000477  164  157  162            .ASCII  /tor/
000502  000  000                 .ASCII  <00><00>
000504  102  122  040  P.AAH:    .ASCII  /BR /
000507  114  145  166            .ASCII  /Lev/
000512  145  154  040            .ASCII  /el /
```

```
000515  133  165  163                .ASCII  /[us/
000520  165  141  154                .ASCII  /ual/
000523  154  171  040                .ASCII  /ly /
000526  064  055  122                .ASCII  /4-R/
000531  121  104  130                .ASCII  /QDX/
000534  040  065  055                .ASCII  / 5-/
000537  122  125  130                .ASCII  /RUX/
000542  065  060  135                .ASCII  /50]/
000545  000                        .ASCII  <00>
000546  104  162  151  P.AAI:        .ASCII  /Dri/
000551  166  145  040                .ASCII  /ve /
000554  156  165  155                .ASCII  /num/
000557  142  145  162                .ASCII  /ber/
000562  000  000                    .ASCII  <00><00>
000564  124  145  163  P.AAJ:        .ASCII  /Tes/
000567  164  040  145                .ASCII  /t e/
000572  156  164  151                .ASCII  /nti/
000575  162  145  040                .ASCII  /re /
000600  143  165  163                .ASCII  /cus/
000603  164  157  155                .ASCII  /tom/
000606  145  162  040                .ASCII  /er /
000611  141  162  145                .ASCII  /are/
000614  141  040  157                .ASCII  /a o/
000617  146  040  164                .ASCII  /f t/
000622  150  151  163                .ASCII  /his/
000625  040  144  151                .ASCII  / di/
000630  163  153  000                .ASCII  /sk/<00>
000633  000                        .ASCII  <00>
000634  114  157  167  P.AAK:        .ASCII  /Low/
000637  145  162  040                .ASCII  /er /
000642  157  143  164                .ASCII  /oct/
000645  141  154  040                .ASCII  /al /
000650  167  157  162                .ASCII  /wor/
000653  144  040  157                .ASCII  /d o/
000656  146  040  142                .ASCII  /f b/
000661  145  147  151                .ASCII  /egi/
000664  156  156  151                .ASCII  /nni/
000667  156  147  040                .ASCII  /ng /
000672  114  102  116                .ASCII  /LBN/
000675  040  141  144                .ASCII  / ad/
000700  144  162  145                .ASCII  /dre/
000703  163  163  000                .ASCII  /ss/<00>
000706  110  151  147  P.AAL:        .ASCII  /Hig/
000711  150  145  162                .ASCII  /her/
000714  040  157  143                .ASCII  / oc/
000717  164  141  154                .ASCII  /tal/
000722  040  167  157                .ASCII  / wo/
000725  162  144  040                .ASCII  /rd /
000730  157  146  040                 ASCII  /of /
000733  142  145  147                .ASCII  /beg/
000736  151  156  156                .ASCII  /inn/
000741  151  156  147                .ASCII  /ing/
000744  040  114  102                .ASCII  / LB/
```

```
000747  116  040  141            .ASCII  /N a/
000752  144  144  162            .ASCII  /ddr/
000755  145  163  163            .ASCII  /ess/
000760  000  000                 .ASCII  <00><00>
000762  114  157  167  P.AAM:     .ASCII  /Low/
000765  145  162  040            .ASCII  /er /
000770  157  143  164            .ASCII  /oct/
000773  141  154  040            .ASCII  /al /
000776  167  157  162            .ASCII  /wor/
001001  144  040  157            .ASCII  /d o/
001004  146  040  145            .ASCII  /f e/
001007  156  144  151            .ASCII  /ndi/
001012  156  147  040            .ASCII  /ng /
001015  114  102  116            .ASCII  /LBN/
001020  040  141  144            .ASCII  / ad/
001023  144  162  145            .ASCII  /dre/
001026  163  163  000            .ASCII  /ss/<00>
001031  000                     .ASCII  <00>
001032  110  151  147  P.AAN:     .ASCII  /Hig/
001035  150  145  162            .ASCII  /her/
001040  040  157  143            .ASCII  / oc/
001043  164  141  154            .ASCII  /tal/
001046  040  167  157            .ASCII  / wo/
001051  162  144  040            .ASCII  /rd /
001054  157  146  040            .ASCII  /of /
001057  145  156  144            .ASCII  /end/
001062  151  156  147            .ASCII  /ing/
001065  040  114  102            .ASCII  / LB/
001070  116  040  141            .ASCII  /N a/
001073  144  144  162            .ASCII  /ddr/
001076  145  163  163            .ASCII  /ess/
001101  000                     .ASCII  <00>
001102  127  162  151  P.AAO:     .ASCII  /Wri/
001105  164  145  040            .ASCII  /te /
001110  157  156  040            .ASCII  /on /
001113  143  165  163            .ASCII  /cus/
001116  164  157  155            .ASCII  /tom/
001121  145  162  040            .ASCII  /er /
001124  144  141  164            .ASCII  /dat/
001127  141  040  141            .ASCII  /a a/
001132  162  145  141            .ASCII  /rea/
001135  040  157  146            .ASCII  / of/
001140  040  164  150            .ASCII  / th/
001143  151  163  040            .ASCII  /is /
001146  144  151  163            .ASCII  /dis/
001151  153  040  165            .ASCII  /k u/
001154  156  151  164            .ASCII  /nit/
001157  000                     .ASCII  <00>
001160  052  052  040  P.AAP:     .ASCII  /** /
001163  127  101  122            .ASCII  /WAR/
001166  116  111  116            .ASCII  /NIN/
001171  107  040  055            .ASCII  /G -/
001174  040  103  123            .ASCII  / CU/
```

```
001177  123  124  117                .ASCII  /STO/
001202  115  105  122                .ASCII  /MER/
001205  040  104  101                .ASCII  / DA/
001210  124  101  040                .ASCII  /TA /
001213  101  122  105                .ASCII  /ARE/
001216  101  040  115                .ASCII  /A M/
001221  101  131  040                .ASCII  /AY /
001224  102  105  040                .ASCII  /BE /
001227  117  126  105                .ASCII  /OVE/
001232  122  127  122                .ASCII  /RWR/
001235  111  124  124                .ASCII  /ITT/
001240  105  116  041                .ASCII  /EN!/
001243  040  056  056                .ASCII  / ../
001246  056  040  103                .ASCII  /. C/
001251  117  116  106                .ASCII  /ONF/
001254  111  122  115                .ASCII  /IRM/
001257  000                        .ASCII  <00>
001260  110  141  162  P.AAQ:        .ASCII  /Har/
001263  144  040  145                .ASCII  /d e/
001266  162  162  157                .ASCII  /rro/
001271  162  040  154                .ASCII  /r l/
001274  151  155  151                .ASCII  /imi/
001277  164  000  000                .ASCII  /t/<00><00>
001302  124  162  141  P.AAR:        .ASCII  /Tra/
001305  156  163  146                .ASCII  /nsf/
001310  145  162  040                .ASCII  /er /
001313  154  151  155                .ASCII  /lim/
001316  151  164  040                .ASCII  /it /
001321  151  156  040                .ASCII  /in /
001324  155  145  147                .ASCII  /meg/
001327  141  142  171                .ASCII  /aby/
001332  164  145  163                .ASCII  /tes/
001335  040  050  060                .ASCII  / (0/
001340  040  146  157                .ASCII  / fo/
001343  162  040  161                .ASCII  /r q/
001346  165  151  143                .ASCII  /uic/
001351  153  040  160                .ASCII  /k p/
001354  141  163  163                .ASCII  /ass/
001357  051  000  000                .ASCII  /)/<00><00>
001362  122  141  156  P.AAS:        .ASCII  /Ran/
001365  144  157  155                .ASCII  /dom/
001370  040  163  145                .ASCII  / se/
001373  145  153  040                .ASCII  /ek /
001376  155  157  144                .ASCII  /mod/
001401  145  000  000                .ASCII  /e/<00><00>
001404  122  145  141  P.AAT:        .ASCII  /Rea/
001407  144  05?  143                .ASCII  /d c/
001412  157  155  160                .ASCII  /omp/
001415  141  162  145                .ASCII  /are/
001420  163  040  160                .ASCII  /s p/
001423  145  162  146                .ASCII  /erf/
001426  157  162  155                .ASCII  /orm/
001431  145  144  040                .ASCII  /ed /
```

```
001434  141  164  040                .ASCII  /at /
001437  164  150  145                .ASCII  /the/
001442  040  143  157                .ASCII  / co/
001445  156  164  162                .ASCII  /ntr/
001450  157  154  154                .ASCII  /oll/
001453  145  162  000                .ASCII  /er/<00>
001456  127  162  151      P.AAU:    .ASCII  /Wri/
001461  164  145  055                .ASCII  /te-/
001464  143  157  155                .ASCII  /com/
001467  160  141  162                .ASCII  /par/
001472  145  163  040                .ASCII  /es /
001475  160  145  162                .ASCII  /per/
001500  146  157  162                .ASCII  /for/
001503  155  145  144                .ASCII  /med/
001506  040  141  164                .ASCII  / at/
001511  040  164  150                .ASCII  / th/
001514  145  040  143                .ASCII  /e c/
001517  157  156  164                .ASCII  /ont/
001522  162  157  154                .ASCII  /rol/
001525  154  145  162                .ASCII  /ler/
001530  000  000                     .ASCII  <00><00>
001532  103  150  145      P.AAV:    .ASCII  /Che/
001535  143  153  040                .ASCII  /ck /
001540  141  154  154                .ASCII  /all/
001543  040  167  162                .ASCII  / wr/
001546  151  164  145                .ASCII  /ite/
001551  163  040  141                .ASCII  /s a/
001554  164  040  150                .ASCII  /t h/
001557  157  163  164                .ASCII  /ost/
001562  040  142  171                .ASCII  / by/
001565  040  162  145                .ASCII  / re/
001570  141  144  151                .ASCII  /adi/
001573  156  147  000                .ASCII  /ng/<00>
001576  125  163  145      P.AAW:    .ASCII  /Use/
001601  162  055  144                .ASCII  /r-d/
001604  145  146  151                .ASCII  /efi/
001607  156  145  144                .ASCII  /ned/
001612  040  144  141                .ASCII  / da/
001615  164  141  040                .ASCII  /ta /
001620  160  141  164                .ASCII  /pat/
001623  164  145  162                .ASCII  /ter/
001626  156  000                     .ASCII  /n/<00>
001630  123  145  154      P.AAX:    .ASCII  /Sel/
001633  145  143  164                .ASCII  /ect/
001636  040  160  162                .ASCII  / pr/
001641  145  055  144                .ASCII  /e-d/
001644  145  146  151                .ASCII  /efi/
001647  156  145  144                .ASCII  /ned/
001652  040  144  141                .ASCII  / da/
001655  164  141  040                .ASCII  /ta /
001660  160  141  164                .ASCII  /pat/
001663  164  145  162                .ASCII  /ter/
001666  156  040  050                .ASCII  /n (/
```

```
001671  060     040     146             .ASCII  /0 f/
001674  157     162     040             .ASCII  /or /
001677  163     145     161             .ASCII  /seq/
001702  165     145     156             .ASCII  /uen/
001705  164     151     141             .ASCII  /tia/
001710  154     040     163             .ASCII  /l s/
001713  145     154     145             .ASCII  /ele/
001716  143     164     151             .ASCII  /cti/
001721  157     156     051             .ASCII  /on)/
001724  000     000                     .ASCII  <00><00>
001726  116     165     155     P.AAY:  .ASCII  /Num/
001731  142     145     162             .ASCII  /ber/
001734  040     157     146             .ASCII  / of/
001737  040     167     157             .ASCII  / wo/
001742  162     144     163             .ASCII  /rds/
001745  040     151     156             .ASCII  / in/
001750  040     144     141             .ASCII  / da/
001753  164     141     040             .ASCII  /ta /
001756  160     141     164             .ASCII  /pat/
001761  164     145     162             .ASCII  /ter/
001764  156     040     050             .ASCII  /n (/
001767  061     066     040             .ASCII  /16 /
001772  155     141     170             .ASCII  /max/
001775  151     155     165             .ASCII  /imu/
002000  155     051     000             .ASCII  /m)/<00>
002003  000                             .ASCII  <00>
002004  120     141     164     P.AAZ:  .ASCII  /Pat/
002007  164     145     162             .ASCII  /ter/
002012  156     040     166             .ASCII  /n v/
002015  141     154     165             .ASCII  /alu/
002020  145     040     050             .ASCII  /e (/
002023  156     157     040             .ASCII  /no /
002026  154     145     141             .ASCII  /lea/
002031  144     151     156             .ASCII  /din/
002034  147     040     172             .ASCII  /g z/
002037  145     162     157             .ASCII  /ero/
002042  163     040     141             .ASCII  /s a/
002045  154     154     157             .ASCII  /llo/
002050  167     145     144             .ASCII  /wed/
002053  051     000     000             .ASCII  /)/<00><00>
002056  103     154     145     P.ABA:  .ASCII  /Cle/
002061  141     162     040             .ASCII  /ar /
002064  163     164     141             .ASCII  /sta/
002067  164     151     163             .ASCII  /tis/
002072  164     151     143             .ASCII  /tic/
002075  141     154     040             .ASCII  /al /
002100  164     141     142             .ASCII  /tab/
002103  154     145     163             .ASCII  /les/
002106  040     141     146             .ASCII  / af/
002111  164     145     162             .ASCII  /ter/
002114  040     160     162             .ASCII  / pr/
002117  151     156     164             .ASCII  /int/
002122  151     156     147             .ASCII  /ing/
```

```
002125  000                             .ASCII  <00>
002126  120     145     162     P.ABB:  .ASCII  /Per/
002131  143     145     156             .ASCII  /cen/
002134  164     141     147             .ASCII  /tag/
002137  145     040     157             .ASCII  /e o/
002142  146     040     042             .ASCII  /f "/
002145  106     151     170             .ASCII  /Fix/
002150  145     144     040             .ASCII  /ed /
002153  104     151     163             .ASCII  /Dis/
002156  153     042     040             .ASCII  /k" /
002161  157     160     145             .ASCII  /ope/
002164  162     141     164             .ASCII  /rat/
002167  151     157     156             .ASCII  /ion/
002172  163     040     157             .ASCII  /s o/
002175  165     164     040             .ASCII  /ut /
002200  157     146     040             .ASCII  /of /
002203  164     157     164             .ASCII  /tot/
002206  141     154     040             .ASCII  /al /
002211  157     160     145             .ASCII  /ope/
002214  162     141     164             .ASCII  /rat/
002217  151     157     156             .ASCII  /ion/
002222  163     000                     .ASCII  /s/<00>
002224  125     156     151     P.ABC:  .ASCII  /Uni/
002227  164     163     040             .ASCII  /ts /
002232  164     157     040             .ASCII  /to /
002235  142     145     040             .ASCII  /be /
002240  163     145     154             .ASCII  /sel/
002243  145     143     164             .ASCII  /ect/
002246  145     144     040             .ASCII  /ed /
002251  141     164     040             .ASCII  /at /
002254  162     141     156             .ASCII  /ran/
002257  144     157     155             .ASCII  /dom/
002262  040     050     116             .ASCII  / (N/
002265  157     054     040             .ASCII  /o, /
002270  151     155     160             .ASCII  /imp/
002273  154     151     145             .ASCII  /lie/
002276  163     040     163             .ASCII  /s s/
002301  145     161     165             .ASCII  /equ/
002304  145     156     164             .ASCII  /ent/
002307  151     141     154             .ASCII  /ial/
002312  051     000                     .ASCII  /)/<00>
002314  122     145     167     P.ABD:  .ASCII  /Rew/
002317  162     151     164             .ASCII  /rit/
002322  145     040     142             .ASCII  /e b/
002325  154     157     143             .ASCII  /loc/
002330  153     163     040             .ASCII  /ks /
002333  167     150     145             .ASCII  /whe/
002336  156     040     042             .ASCII  /n "/
002341  106     157     162             .ASCII  /For/
002344  143     145     144             .ASCII  /ced/
002347  040     105     162             .ASCII  / Er/
002352  162     157     162             .ASCII  /ror/
002355  042     040     144             .ASCII  /" d/
```

```
002360  145     164     145             .ASCII  /ete/
002363  143     164     145             .ASCII  /cte/
002366  144     040     157             .ASCII  /d o/
002371  156     040     162             .ASCII  /n r/
002374  145     141     144             .ASCII  /ead/
002377  163     000     000             .ASCII  /s/<00><00>
002402  110     141     154     P.ABE:  .ASCII  /Hal/
002405  164     040     157             .ASCII  /t o/
002410  156     040     157             .ASCII  /n o/
002413  164     150     145             .ASCII  /the/
002416  162     040     150             .ASCII  /r h/
002421  141     162     144             .ASCII  /ard/
002424  040     145     162             .ASCII  / er/
002427  162     157     162             .ASCII  /ror/
002432  163     040     050             .ASCII  /s (/
002435  043     163     040             .ASCII  /#s /
002440  063     061     055             .ASCII  /31-/
002443  063     064     054             .ASCII  /34,/
002446  040     063     066             .ASCII  / 36/
002451  055     063     067             .ASCII  /-37/
002454  054     040     063             .ASCII  /, 3/
002457  071     055     064             .ASCII  /9-4/
002462  065     051     000             .ASCII  /5)/<00>
002465  000                             .ASCII  <00>
002466  110     141     154     P.ABF:  .ASCII  /Hal/
002471  164     040     157             .ASCII  /t o/
002474  156     040     163             .ASCII  /n s/
002477  157     146     164             .ASCII  /oft/
002502  040     145     162             .ASCII  / er/
002505  162     157     162             .ASCII  /ror/
002510  163     040     050             .ASCII  /s (/
002513  043     163     040             .ASCII  /#s /
002516  065     060     055             .ASCII  /50-/
002521  065     064     051             .ASCII  /54)/
002524  000     000                     .ASCII  <00><00>
002526  110     141     154     P.ABG:  .ASCII  /Hal/
002531  164     040     157             .ASCII  /t o/
002534  156     040     142             .ASCII  /n b/
002537  141     144     055             .ASCII  /ad-/
002542  142     154     157             .ASCII  /blo/
002545  143     153     040             .ASCII  /ck /
002550  150     141     162             .ASCII  /har/
002553  144     040     145             .ASCII  /d e/
002556  162     162     157             .ASCII  /rro/
002561  162     163     040             .ASCII  /rs /
002564  050     043     163             .ASCII  /(#s/
002567  040     063     065             .ASCII  / 35/
002572  054     040     063             .ASCII  /, 3/
002575  070     051     000             .ASCII  /8)/<00>
002600  105     156     164     P.ABH:  .ASCII  /Ent/
002603  145     162     040             .ASCII  /er /
002606  164     151     155             .ASCII  /tim/
002611  145     040     141             .ASCII  /e a/
```

```
002614  163  040  110                .ASCII  /s H/
002617  110  115  115                .ASCII  /HMM/
002622  040  050  145                .ASCII  / (e/
002625  170  141  155                .ASCII  /xam/
002630  160  154  145                .ASCII  /ple/
002633  072  040  061                .ASCII  /: 1/
002636  063  060  065                .ASCII  /305/
002641  051  000  000                .ASCII  /)/<00><00>
002644  122  165  156  P.ABI:        .ASCII  /Run/
002647  156  151  156                .ASCII  /nin/
002652  147  040  165                .ASCII  /g u/
002655  156  144  145                .ASCII  /nde/
002660  162  040  164                .ASCII  /r t/
002663  150  145  040                .ASCII  /he /
002666  101  056  120                .ASCII  /A.P/
002671  056  124  056                .ASCII  /.T./
002674  040  115  157                .ASCII  / Mo/
002677  156  151  164                .ASCII  /nit/
002702  157  162  000                .ASCII  /or/<00>
002705  000                        .ASCII  <00>
002706  124  150  145  P.ABJ:        .ASCII  /The/
002711  040  162  145                .ASCII  / re/
002714  155  141  151                .ASCII  /mai/
002717  156  151  156                .ASCII  /nin/
002722  147  040  161                .ASCII  /g q/
002725  165  145  163                .ASCII  /ues/
002730  164  151  157                .ASCII  /tio/
002733  156  163  040                .ASCII  /ns /
002736  157  156  154                .ASCII  /onl/
002741  171  040  141                .ASCII  /y a/
002744  160  160  154                .ASCII  /ppl/
002747  171  040  164                .ASCII  /y t/
002752  157  040  165                .ASCII  /o u/
002755  156  160  162                .ASCII  /npr/
002760  157  164  145                .ASCII  /ote/
002763  143  164  145                .ASCII  /cte/
002766  144  040  144                .ASCII  /d d/
002771  151  163  153                .ASCII  /isk/
002774  040  165  156                .ASCII  / un/
002777  151  164  163                .ASCII  /its/
003002  000  000                    .ASCII  <00><00>
003004  115  141  156  P.ABK:        .ASCII  /Man/
003007  165  146  141                .ASCII  /ufa/
003012  143  164  165                .ASCII  /ctu/
003015  162  151  156                .ASCII  /rin/
003020  147  040  124                .ASCII  /g T/
003023  145  163  164                .ASCII  /est/
003026  000  000                    .ASCII  <00><00>
003030  105  156  141  P.ABL:        .ASCII  /Ena/
003033  142  154  145                .ASCII  /ble/
003036  040  110  157                .ASCII  / Ho/
003041  163  164  040                .ASCII  /st /
003044  115  145  155                .ASCII  /Mem/
```

```
003047  157  162  171                .ASCII  /ory/
003052  040  050  115                .ASCII  / (M/
003055  123  126  061                .ASCII  /SV1/
003060  061  055  120                .ASCII  /1-P/
003063  054  114  054                .ASCII  /,L,/
003066  112  051  040                .ASCII  /J) /
003071  120  141  162                .ASCII  /Par/
003074  151  164  171                .ASCII  /ity/
003077  000                        .ASCII  <00>
003100  000  000           P.ABM:   .ASCII  <00><00>
003102  045  116  045     P.ABN:   .ASCII  /%N%/
003105  101  052  052                .ASCII  /A**/
003110  040  104  162                .ASCII  / Dr/
003113  157  160  040                .ASCII  /op /
003116  165  156  151                .ASCII  /uni/
003121  164  040  045                .ASCII  /t %/
003124  104  062  000                .ASCII  /D2/<00>
003127  000                        .ASCII  <00>
003130  045  116  045     P.ABO:   .ASCII  /%N%/
003133  101  052  052                .ASCII  /A**/
003136  040  120  122                .ASCII  / PR/
003141  117  103  137                .ASCII  /OC_/
003144  122  105  124                .ASCII  /RET/
003147  120  1'3  124                .ASCII  /PKT/
003152  072  04?  103                .ASCII  /: C/
003155  157  156  156                .ASCII  /onn/
003160  040  111  104                .ASCII  / ID/
003163  040  045  117                .ASCII  / %O/
003166  066  045  10?                .ASCII  /6%A/
003171  040  162  14?                .ASCII  / re/
003174  143  145  ?51                .ASCII  /cei/
003177  166  145  ?14                .ASCII  /ved/
003202  000  000                    .ASCII  <00><00>
003204  045  116  045     P.ABP:   .ASCII  /%N%/
003207  101  052  052                .ASCII  /A**/
003212  040  115  165                .ASCII  / Mu/
003215  154  164  151                .ASCII  /lti/
003220  055  144  162                .ASCII  /-dr/
003223  151  166  145                .ASCII  /ive/
003226  040  164  145                .ASCII  / te/
003231  163  164  000                .ASCII  /st/<00>
003234  045  11?  045     P.ABQ:   .ASCII  /%N%/
003237  101  052  052                .ASCII  /A**/
003242  040  106  101                .ASCII  / FA/
003245  124  101  114                .ASCII  /TAL/
003250  137  105  122                .ASCII  /_ER/
003253  122  117  122                .ASCII  /ROR/
003256  072  040  122                .ASCII  /: R/
003261  105  124  120                .ASCII  /ETP/
003264  113  124  040                .ASCII  /KT /
003267  156  157  164                .ASCII  /not/
003272  040  141  166                .ASCII  / av/
003275  141  151  154                .ASCII  /ail/
```

```
003300  141  142  154              .ASCII  /abl/
003303  145  000  000              .ASCII  /e/<00><00>
003306  045  116  045  P.ABR:      .ASCII  /%N%/
003311  101  052  052              .ASCII  /A**/
003314  040  106  123              .ASCII  / FS/
003317  105  124  137              .ASCII  /ET_/
003322  125  120  101              .ASCII  /UPA/
003325  122  072  040              .ASCII  /R: /
003330  103  141  156              .ASCII  /Can/
003333  047  164  040              .ASCII  /'t /
003336  146  151  156              .ASCII  /fin/
003341  144  040  144              .ASCII  /d d/
003344  151  163  153              .ASCII  /isk/
003347  040  045  104              .ASCII  / %D/
003352  063  045  101              .ASCII  /3%A/
003355  040  151  156              .ASCII  / in/
003360  040  103  123              .ASCII  / CS/
003363  124  040  045              .ASCII  /T %/
003366  104  061  000              .ASCII  /D1/<00>
003371  000                       .ASCII  <00>
003372  045  116  045  P.ABS:      .ASCII  /%N%/
003375  101  052  052              .ASCII  /A**/
003400  040  102  141              .ASCII  / Ba/
003403  144  040  143              .ASCII  /d c/
003406  157  156  156              .ASCII  /onn/
003411  040  111  104              .ASCII  / ID/
003414  040  045  117              .ASCII  / %O/
003417  066  045  101              .ASCII  /6%A/
003422  040  162  145              .ASCII  / re/
003425  143  145  151              .ASCII  /cei/
003430  166  145  144              .ASCII  /ved/
003433  040  146  162              .ASCII  / fr/
003436  157  155  040              .ASCII  /om /
003441  045  117  066              .ASCII  /%O6/
003444  000  000                   .ASCII  <00><00>
003446  045  116  045  P.ABT:      .ASCII  /%N%/
003451  101  052  052              .ASCII  /A**/
003454  040  115  145              .ASCII  / Me/
003457  163  163  141              .ASCII  /ssa/
003462  147  145  040              .ASCII  /ge /
003465  164  171  160              .ASCII  /typ/
003470  145  040  045              .ASCII  /e %/
003473  117  062  045              .ASCII  /02%/
003476  101  040  162              .ASCII  /A r/
003501  145  143  145              .ASCII  /ece/
003504  151  166  145              .ASCII  /ive/
003507  144  040  151              .ASCII  /d i/
003512  156  040  115              .ASCII  /n M/
003515  123  103  120              .ASCII  /SCP/
003520  040  160  141              .ASCII  / pa/
003523  143  153  145              .ASCII  /cke/
003526  164  000                   .ASCII  /t/<00>
003530  045  116  045  P.ABU:      .ASCII  /%N%/
```

```
003533  101  052  052                .ASCII  /A**/
003536  040  123  105                .ASCII  / SE/
003541  121  125  105                .ASCII  /QUE/
003544  116  072  040                .ASCII  /N: /
003547  122  105  124                .ASCII  /RET/
003552  120  113  124                .ASCII  /PKT/
003555  040  156  157                .ASCII  / no/
003560  164  040  141                .ASCII  /t a/
003563  166  141  151                .ASCII  /vai/
003566  154  141  142                .ASCII  /lab/
003571  154  145  000                .ASCII  /le/<00>
003574  045  116  045        P.ABV:  .ASCII  /%N%/
003577  101  052  052                .ASCII  /A**/
003602  040  105  162                .ASCII  / Er/
003605  162  157  162                .ASCII  /ror/
003610  040  151  156                .ASCII  / in/
003613  040  123  105                .ASCII  / SE/
003616  124  137  103                .ASCII  /T_C/
003621  124  114  122                .ASCII  /TLR/
003624  137  103  110                .ASCII  /_CH/
003627  101  122  000                .ASCII  /AR/<00>
003632  045  116  045        P.ABW:  .ASCII  /%N%/
003635  101  052  052                .ASCII  /A**/
003640  040  103  164                .ASCII  / Ct/
003643  154  162  040                .ASCII  /lr /
003646  164  151  155                .ASCII  /tim/
003651  145  157  165                .ASCII  /eou/
003654  164  040  075                .ASCII  /t =/
003657  040  045  104                .ASCII  / %D/
003662  063  045  101                .ASCII  /3%A/
003665  056  040  163                .ASCII  /. s/
003670  145  143  157                .ASCII  /eco/
003673  156  144  163                .ASCII  /nds/
003676  000  000                     .ASCII  <00><00>
003700  045  116  045        P.ABX:  .ASCII  /%N%/
003703  101  052  052                .ASCII  /A**/
003706  040  105  162                .ASCII  / Er/
003711  162  157  162                .ASCII  /ror/
003714  040  151  156                .ASCII  / in/
003717  040  125  116                .ASCII  / UN/
003722  111  124  137                .ASCII  /IT_/
003725  111  116  111                .ASCII  /INI/
003730  124  000                     .ASCII  /T/<00>
003732  045  116  045        P.ABY:  .ASCII  /%N%/
003735  101  052  052                .ASCII  /A**/
003740  040  125  116                .ASCII  / UN/
003743  111  124  137                .ASCII  /IT_/
003746  111  116  111                .ASCII  /INI/
003751  124  072  040                .ASCII  /T: /
003754  122  105  124                .ASCII  /RET/
003757  120  113  124                .ASCII  /PKT/
003762  040  150  141                .ASCII  / ha/
003765  163  040  142                .ASCII  /s b/
```

```
003770  141  144  040                .ASCII  /ad /
003773  105  116  104                .ASCII  /END/
003776  103  117  104                .ASCII  /COD/
004001  105  000  000                .ASCII  /E/<00><00>
004004  045  116  045      P.ABZ:    .ASCII  /%N%/
004007  101  052  052                .ASCII  /A**/
004012  040  125  156                .ASCII  / Un/
004015  151  164  040                .ASCII  /it /
004020  163  151  172                .ASCII  /siz/
004023  145  040  050                .ASCII  /e (/
004026  114  157  051                .ASCII  /Lo)/
004031  040  075  040                .ASCII  / = /
004034  045  104  065                .ASCII  /%D5/
004037  045  101  056                .ASCII  /%A./
004042  000  000                     .ASCII  <00><00>
004044  045  116  045      P.ACA:    .ASCII  /%N%/
004047  101  052  052                .ASCII  /A**/
004052  040  125  156                .ASCII  / Un/
004055  151  164  040                .ASCII  /it /
004060  163  151  172                .ASCII  /siz/
004063  145  040  050                .ASCII  /e (/
004066  110  151  051                .ASCII  /Hi)/
004071  040  075  040                .ASCII  / = /
004074  045  104  065                .ASCII  /%D5/
004077  045  101  056                .ASCII  /%A./
004102  000  000                     .ASCII  <00><00>
004104  045  116  045      P.ACB:    .ASCII  /%N%/
004107  101  052  052                .ASCII  /A**/
004112  040  101  103                .ASCII  / AC/
004115  103  105  123                .ASCII  /CES/
004120  123  072  040                .ASCII  /S: /
004123  122  105  124                .ASCII  /RET/
004126  120  113  124                .ASCII  /PKT/
004131  040  150  141                .ASCII  / ha/
004134  163  040  142                .ASCII  /s b/
004137  141  144  040                .ASCII  /ad /
004142  105  116  104                .ASCII  /END/
004145  103  117  104                .ASCII  /COD/
004150  105  000                     .ASCII  /E/<00>
004152  045  116  045      P.ACC:    .ASCII  /%N%/
004155  101  052  052                .ASCII  /A**/
004160  040  121  111                .ASCII  / QI/
004163  117  137  125                .ASCII  /O_U/
004166  116  111  124                .ASCII  /NIT/
004171  072  040  103                .ASCII  /: C/
004174  123  124  040                .ASCII  /ST /
004177  045  104  061                .ASCII  /%D1/
004202  045  101  040                .ASCII  /%A /
004205  156  157  040                .ASCII  /no /
004210  165  156  151                .ASCII  /uni/
004213  164  040  163                .ASCII  /t s/
004216  145  154  145                .ASCII  /ele/
004221  143  164  145                .ASCII  /cte/
```

```
004224  144  000                      .ASCII  /d/<00>
004226  045  116  045      P.ACD:     .ASCII  /%N%/
004231  101  052  052                 .ASCII  /A**/
004234  040  125  156                 .ASCII  / Un/
004237  151  164  040                 .ASCII  /it /
004242  043  040  151                 .ASCII  /# i/
004245  163  072  040                 .ASCII  /s: /
004250  045  117  066                 .ASCII  /%06/
004253  000                          .ASCII  <00>
004254  045  116  045      P.ACE:     .ASCII  /%N%/
004257  101  052  052                 .ASCII  /A**/
004262  040  122  145                 .ASCII  / Re/
004265  155  157  166                 .ASCII  /mov/
004270  141  142  154                 .ASCII  /abl/
004273  145  040  144                 .ASCII  /e d/
004276  151  163  153                 .ASCII  /isk/
004301  040  151  163                 .ASCII  / is/
004304  040  163  145                 .ASCII  / se/
004307  154  145  143                 .ASCII  /lec/
004312  164  145  144                 .ASCII  /ted/
004315  000                          .ASCII  <00>
004316  045  116  045      P.ACF:     .ASCII  /%N%/
004321  101  052  052                 .ASCII  /A**/
004324  040  106  151                 .ASCII  / Fi/
004327  170  145  144                 .ASCII  /xed/
004332  040  144  151                 .ASCII  / di/
004335  163  153  040                 .ASCII  /sk /
004340  151  163  040                 .ASCII  /is /
004343  163  145  154                 .ASCII  /sel/
004346  145  143  164                 .ASCII  /ect/
004351  145  144  000                 .ASCII  /ed/<00>
004354  045  116  045      P.ACG:     .ASCII  /%N%/
004357  101  052  052                 .ASCII  /A**/
004362  040  111  154                 .ASCII  / Il/
004365  154  145  147                 .ASCII  /leg/
004370  141  154  040                 .ASCII  /al /
004373  146  165  156                 .ASCII  /fun/
004376  143  164  151                 .ASCII  /cti/
004401  157  156  072                 .ASCII  /on:/
004404  040  045  117                 .ASCII  / %O/
004407  066  000  000                 .ASCII  /6/<00><00>
004412  045  116  045      P.ACH:     .ASCII  /%N%/
004415  101  052  052                 .ASCII  /A**/
004420  040  103  157                 .ASCII  / Co/
004423  155  155  141                 .ASCII  /mma/
004426  156  144  040                 .ASCII  /nd /
004431  162  145  146                 .ASCII  /ref/
004434  040  043  040                 .ASCII  / # /
004437  045  117  066                 .ASCII  /%06/
004442  045  101  057                 .ASCII  /%A/<57>
004445  045  117  066                 .ASCII  /%06/
004450  045  101  040                 .ASCII  /%A /
004453  050  117  143                 .ASCII  /(Oc/
```

```
004456  164     051     040             .ASCII  /t) /
004461  156     157     164             .ASCII  /not/
004464  040     163     145             .ASCII  / se/
004467  156     164     040             .ASCII  /nt /
004472  142     171     040             .ASCII  /by /
004475  110     157     163             .ASCII  /Hos/
004500  164     000                     .ASCII  /t/<00>
004502  045     116     045     P.ACI:  .ASCII  /%N%/
004505  101     052     052             .ASCII  /A**/
004510  040     125     156             .ASCII  / Un/
004513  153     156     157             .ASCII  /kno/
004516  167     156     040             .ASCII  /wn /
004521  105     162     162             .ASCII  /Err/
004524  157     162     040             .ASCII  /or /
004527  114     157     147             .ASCII  /Log/
004532  040     146     157             .ASCII  / fo/
004535  162     155     141             .ASCII  /rma/
004540  164     040     045             .ASCII  /t %/
004543  117     063     045             .ASCII  /03%/
004546  101     040     162             .ASCII  /A r/
004551  145     143     145             .ASCII  /ece/
004554  151     166     145             .ASCII  /ive/
004557  144     000     000             .ASCII  /d/<00><00>
004562  045     116     045     P.ACJ:  .ASCII  /%N%/
004565  101     052     052             .ASCII  /A**/
004570  040     117     160             .ASCII  / Op/
004573  055     143     157             .ASCII  /-co/
004576  144     145     040             .ASCII  /de /
004601  045     117     063             .ASCII  /%03/
004604  045     101     054             .ASCII  /%A,/
004607  040     105     156             .ASCII  / En/
004612  144     055     143             .ASCII  /d-c/
004615  157     144     145             .ASCII  /ode/
004620  040     045     117             .ASCII  / %O/
004623  063     045     101             .ASCII  /3%A/
004626  040     146     157             .ASCII  / fo/
004631  162     040     162             .ASCII  /r r/
004634  145     146     040             .ASCII  /ef /
004637  043     040     045             .ASCII  /# %/
004642  117     066     045             .ASCII  /O6%/
004645  101     057     045             .ASCII  /A/<57>/%/
004650  117     066     045             .ASCII  /O6%/
004653  101     040     050             .ASCII  /A (/
004656  070     051     000             .ASCII  /8)/<00>
004661  000                             .ASCII  <00>
004662  045     116     045     P.ACK:  .ASCII  /%N%/
004665  101     052     052             .ASCII  /A**/
004670  040     103     155             .ASCII  / Cm/
004673  144     055     142             .ASCII  /d-b/
004676  143     040     045             .ASCII  /c %/
004701  117     066     045             .ASCII  /O6%/
004704  101     057     045             .ASCII  /A/<57>/%/
004707  117     066     045             .ASCII  /O6%/
```

```
004712  101  040  122                .ASCII  /A R/
004715  163  160  055                .ASCII  /sp-/
004720  142  143  040                .ASCII  /bc /
004723  045  117  066                .ASCII  /%06/
004726  045  101  057                .ASCII  /%A/<57>
004731  045  117  066                .ASCII  /%06/
004734  045  101  040                .ASCII  /%A /
004737  146  157  162                .ASCII  /for/
004742  040  045  117                .ASCII  / %O/
004745  066  045  101                .ASCII  /6%A/
004750  057  045  117                .ASCII  <57>/%O/
004753  066  045  101                .ASCII  /6%A/
004756  040  050  070                .ASCII  / (8/
004761  051  000  000                .ASCII  /)/<00><00>
004764  045  116  045  P.ACL:        .ASCII  /%N%/
004767  101  052  052                .ASCII  /A**/
004772  040  122  145                .ASCII  / Re/
004775  163  160  157                .ASCII  /spo/
005000  156  163  145                .ASCII  /nse/
005003  040  141  154                .ASCII  / al/
005006  162  145  141                .ASCII  /rea/
005011  144  171  040                .ASCII  /dy /
005014  162  145  143                .ASCII  /rec/
005017  145  151  166                .ASCII  /eiv/
005022  145  144  040                .ASCII  /ed /
005025  146  157  162                .ASCII  /for/
005030  040  143  155                .ASCII  / cm/
005033  144  040  045                .ASCII  /d %/
005036  117  066  045                .ASCII  /06%/
005041  101  057  045                .ASCII  /A/<57>/%/
005044  117  066  045                .ASCII  /06%/
005047  101  040  050                .ASCII  /A (/
005052  070  051  000                .ASCII  /8)/<00>
005055  000                         .ASCII  <00>
005056  045  116  045  P.ACM:        .ASCII  /%N%/
005061  101  052  052                .ASCII  /A**/
005064  040  106  141                .ASCII  / Fa/
005067  151  154  165                .ASCII  /ilu/
005072  162  145  040                .ASCII  /re /
005075  164  157  040                .ASCII  /to /
005100  163  145  156                .ASCII  /sen/
005103  144  040  143                .ASCII  /d c/
005106  157  155  155                .ASCII  /omm/
005111  141  156  144                .ASCII  /and/
005114  040  141  146                .ASCII  / af/
005117  164  145  162                .ASCII  /ter/
005122  040  043  040                .ASCII  / # /
005125  045  117  066                .ASCII  /%06/
005130  045  101  057                .ASCII  /%A/<57>
005133  045  117  066                .ASCII  /%06/
005136  045  101  040                .ASCII  /%A /
005141  050  070  051                .ASCII  /(8)/
005144  000  000                     .ASCII  <00><00>
```

```
005146  045  116  045  P.ACN:  .ASCII  /%N%/
005151  101  052  052          .ASCII  /A**/
005154  040  122  145          .ASCII  / Re/
005157  163  160  157          .ASCII  /spo/
005162  156  163  145          .ASCII  /nse/
005165  040  150  141          .ASCII  / ha/
005170  163  040  105          .ASCII  /s E/
005173  162  162  157          .ASCII  /rro/
005176  162  040  114          .ASCII  /r L/
005201  157  147  050          .ASCII  /og(/
005204  163  051  072          .ASCII  /s):/
005207  000                    .ASCII  <00>
005210  045  116  045  P.ACO:  .ASCII  /%N%/
005213  101  052  052          .ASCII  /A**/
005216  040  110  117          .ASCII  / HO/
005221  123  124  040          .ASCII  /ST /
005224  115  105  115          .ASCII  /MEM/
005227  117  122  131          .ASCII  /ORY/
005232  040  105  122          .ASCII  / ER/
005235  122  117  122          .ASCII  /ROR/
005240  054  040  103          .ASCII  /, C/
005243  123  122  040          .ASCII  /SR /
005246  075  040  040          .ASCII  /=  /
005251  045  117  066          .ASCII  /%O6/
005254  045  101  000          .ASCII  /%A/<00>
005257  000                    .ASCII  <00>
005260  045  116  045  P.ACP:  .ASCII  /%N%/
005263  101  052  052          .ASCII  /A**/
005266  040  110  117          .ASCII  / HO/
005271  123  124  040          .ASCII  /ST /
005274  115  105  115          .ASCII  /MEM/
005277  117  122  131          .ASCII  /ORY/
005302  040  105  122          .ASCII  / ER/
005305  122  117  122          .ASCII  /ROR/
005310  054  040  105          .ASCII  /, E/
005313  130  124  105          .ASCII  /XTE/
005316  116  124  105          .ASCII  /NTE/
005321  104  040  103          .ASCII  /D C/
005324  123  122  040          .ASCII  /SR /
005327  075  040  040          .ASCII  /=  /
005332  045  117  066          .ASCII  /%O6/
005335  045  101  000          .ASCII  /%A/<00>
005340  045  116  045  P.ACQ:  .ASCII  /%N%/
005343  101  052  052          .ASCII  /A**/
005346  040  102  101          .ASCII  / BA/
005351  104  040  102          .ASCII  /D B/
005354  114  117  103          .ASCII  /LOC/
005357  113  040  122          .ASCII  /K R/
005362  105  120  114          .ASCII  /EPL/
005365  101  103  105          .ASCII  /ACE/
005370  115  105  116          .ASCII  /MEN/
005373  124  040  122          .ASCII  /T R/
005376  105  121  125          .ASCII  /EQU/
```

```
005401  105  123  124            .ASCII  /EST/
005404  040  106  114            .ASCII  / FL/
005407  101  107  040            .ASCII  /AG /
005412  123  105  124            .ASCII  /SET/
005415  000                      .ASCII  <00>
005416  045  116  045  P.ACR:    .ASCII  /%N%/
005421  101  052  052            .ASCII  /A**/
005424  040  105  122            .ASCII  / ER/
005427  122  117  122            .ASCII  /ROR/
005432  040  104  125            .ASCII  / DU/
005435  122  111  116            .ASCII  /RIN/
005440  107  040  122            .ASCII  /G R/
005443  105  120  114            .ASCII  /EPL/
005446  101  103  105            .ASCII  /ACE/
005451  115  105  116            .ASCII  /MEN/
005454  124  040  050            .ASCII  /T (/
005457  102  101  104            .ASCII  /BAD/
005462  040  102  114            .ASCII  / BL/
005465  117  103  113            .ASCII  /OCK/
005470  051  040  106            .ASCII  /) F/
005473  114  101  107            .ASCII  /LAG/
005476  040  123  105            .ASCII  / SE/
005501  124  000  000            .ASCII  /T/<00><00>
005504  045  116  045  P.ACS:    .ASCII  /%N%/
005507  101  125  116            .ASCII  /AUN/
005512  111  124  045            .ASCII  /IT%/
005515  104  062  045            .ASCII  /D2%/
005520  101  040  104            .ASCII  /A D/
005523  122  117  120            .ASCII  /ROP/
005526  120  105  104            .ASCII  /PED/
005531  040  055  040            .ASCII  / - /
005534  000  000                 .ASCII  <00><00>
005536  045  101  125  P.ACU:    .ASCII  /%AU/
005541  123  105  122            .ASCII  /SER/
005544  040  103  117            .ASCII  / CO/
005547  115  115  101            .ASCII  /MMA/
005552  116  104  045            .ASCII  /ND%/
005555  116  000  000            .ASCII  /N/<00><00>
005560  045  101  103  P.ACV:    .ASCII  /%AC/
005563  117  116  106            .ASCII  /ONF/
005566  111  107  125            .ASCII  /IGU/
005571  122  101  124            .ASCII  /RAT/
005574  111  117  116            .ASCII  /ION/
005577  040  105  122            .ASCII  / ER/
005602  122  117  122            .ASCII  /ROR/
005605  045  116  000            .ASCII  /%N/<00>
005610  045  101  111  P.ACW:    .ASCII  /%AI/
005613  116  111  124            .ASCII  /NIT/
005616  040  105  122            .ASCII  / ER/
005621  122  117  122            .ASCII  /ROR/
005624  045  116  000            .ASCII  /%N/<00>
005627  000                      .ASCII  <00>
005630  045  101  124  P.ACX:    .ASCII  /%AT/
```

```
005633  122     101     116             .ASCII  /RAN/
005636  123     106     105             .ASCII  /SFE/
005641  122     040     114             .ASCII  /R L/
005644  111     115     111             .ASCII  /IMI/
005647  124     040     122             .ASCII  /T R/
005652  105     101     103             .ASCII  /EAC/
005655  110     105     104             .ASCII  /HED/
005660  045     116     000             .ASCII  /%N/<00>
005663  000                             .ASCII  <00>
005664  045     101     105     P.ACY:  .ASCII  /%AE/
005667  122     122     117             .ASCII  /RRO/
005672  122     040     114             .ASCII  /R L/
005675  111     115     111             .ASCII  /IMI/
005700  124     040     122             .ASCII  /T R/
005703  105     101     103             .ASCII  /EAC/
005706  110     105     104             .ASCII  /HED/
005711  045     116     000             .ASCII  /%N/<00>
005714  045     101     125     P.ACZ:  .ASCII  /%AU/
005717  116     122     105             .ASCII  /NRE/
005722  103     117     126             .ASCII  /COV/
005725  105     122     101             .ASCII  /ERA/
005730  102     114     105             .ASCII  /BLE/
005733  040     104     122             .ASCII  / DR/
005736  111     126     105             .ASCII  /IVE/
005741  040     105     122             .ASCII  / ER/
005744  122     117     122             .ASCII  /ROR/
005747  045     116     000             .ASCII  /%N/<00>
005752  045     101     125     P.ADA:  .ASCII  /%AU/
005755  116     122     105             .ASCII  /NRE/
005760  103     117     126             .ASCII  /COV/
005763  105     122     101             .ASCII  /ERA/
005766  102     114     105             .ASCII  /BLE/
005771  040     103     117             .ASCII  / CO/
005774  116     124     122             .ASCII  /NTR/
005777  117     114     114             .ASCII  /OLL/
006002  105     122     040             .ASCII  /ER /
006005  105     122     122             .ASCII  /ERR/
006010  117     122     045             .ASCII  /OR%/
006013  116     000     000             .ASCII  /N/<00><00>
006016  045     101     106     P.ADB:  .ASCII  /%AF/
006021  101     111     114             .ASCII  /AIL/
006024  105     104     040             .ASCII  /ED /
006027  124     117     040             .ASCII  /TO /
006032  103     117     115             .ASCII  /COM/
006035  105     040     117             .ASCII  /E O/
006040  116     114     111             .ASCII  /NLI/
006043  116     105     045             .ASCII  /NE%/
006046  116     000                     .ASCII  /N/<00>
006050  045     101     106     P.ADC:  .ASCII  /%AF/
006053  101     111     114             .ASCII  /AIL/
006056  105     104     040             .ASCII  /ED /
006061  124     117     040             .ASCII  /TO /
006064  101     103     103             .ASCII  /ACC/
```

```
006067      105       123       123                 .ASCII  /ESS/
006072      040       105       111                 .ASCII  / EI/
006075      124       110       105                 .ASCII  /THE/
006100      122       040       106                 .ASCII  /R F/
006103      111       122       123                 .ASCII  /IRS/
006106      124       040       117                 .ASCII  /T O/
006111      122       040       114                 .ASCII  /R L/
006114      101       123       124                 .ASCII  /AST/
006117      040       124       122                 .ASCII  / TR/
006122      101       103       113                 .ASCII  /ACK/
006125      040       104       125                 .ASCII  / DU/
006130      122       111       116                 .ASCII  /RIN/
006133      107       040       111                 .ASCII  /G I/
006136      116       111       124                 .ASCII  /NIT/
006141      045       116       000                 .ASCII  /%N/<00>
006144      045       101       104       P.ADD:    .ASCII  /%AD/
006147      111       123       113                 .ASCII  /ISK/
006152      040       127       122                 .ASCII  / WR/
006155      111       124       105                 .ASCII  /ITE/
006160      040       120       122                 .ASCII  / PR/
006163      117       124       105                 .ASCII  /OTE/
006166      103       124       105                 .ASCII  /CTE/
006171      104       045       116                 .ASCII  /D%N/
006174      000       000                           .ASCII  <00><00>
006176      045       101       103       P.ADE:    .ASCII  /%AC/
006201      117       115       115                 .ASCII  /OMM/
006204      101       116       104                 .ASCII  /AND/
006207      040       124       111                 .ASCII  / TI/
006212      115       105       040                 .ASCII  /ME /
006215      117       125       124                 .ASCII  /OUT/
006220      045       116       000                 .ASCII  /%N/<00>
006223      000                                     .ASCII  <00>
006224   005536'                            P.ACT:   .WORD   P.ACU
006226   005560'                                     .WORD   P.ACV
006230   005610'                                     .WORD   P.ACW
006232   005630'                                     .WORD   P.ACX
006234   005664'                                     .WORD   P.ACY
006236   005714'                                     .WORD   P.ACZ
006240   005752'                                     .WORD   P.ADA
006242   006016'                                     .WORD   P.ADB
006244   006050'                                     .WORD   P.ADC
006246   006144'                                     .WORD   P.ADD
006250   006176'                                     .WORD   P.ADE
006252      045       116       045       P.ADF:    .ASCII  /%N%/
006255      101       120       117                 .ASCII  /APO/
006260      127       105       122                 .ASCII  /WER/
006263      040       104       105                 .ASCII  / DE/
006266      114       101       131                 .ASCII  /LAY/
006271      040       055       040                 .ASCII  / - /
006274      127       101       111                 .ASCII  /WAI/
006277      124       111       116                 .ASCII  /TIN/
006302      107       000                           .ASCII  /G/<00>
006304      045       116       045       P.ADG:    .ASCII  /%N%/
```

```
006307  101  106  125                .ASCII  /AFU/
006312  116  103  124                .ASCII  /NCT/
006315  111  117  116                .ASCII  /ION/
006320  101  114  040                .ASCII  /AL /
006323  124  105  123                .ASCII  /TES/
006326  124  040  123                .ASCII  /T S/
006331  124  101  122                .ASCII  /TAR/
006334  124  105  104                .ASCII  /TED/
006337  000                        .ASCII  <00>
006340  045  116  045  P.ADH:       .ASCII  /%N%/
006343  116  045  101                .ASCII  /N%A/
006346  105  130  105                .ASCII  /EXE/
006351  122  103  111                .ASCII  /RCI/
006354  123  105  122                .ASCII  /SER/
006357  040  123  124                .ASCII  / ST/
006362  101  122  124                .ASCII  /ART/
006365  105  104  045                .ASCII  /ED%/
006370  116  000                    .ASCII  /N/<00>
006372  045  116  045  P.AD1:       .ASCII  /%N%/
006375  116  045  101                .ASCII  /N%A/
006400  125  116  124                .ASCII  /UNT/
006403  040  104  123                .ASCII  / DS/
006406  113  045  123                .ASCII  /K%S/
006411  070  045  101                .ASCII  /8%A/
006414  043  040  117                .ASCII  /# O/
006417  106  040  040                .ASCII  /F  /
006422  040  043  040                .ASCII  / # /
006425  102  131  124                .ASCII  /BYT/
006430  105  123  040                .ASCII  /ES /
006433  040  040  043                .ASCII  /  #/
006436  040  117  106                .ASCII  / OF/
006441  040  040  040                .ASCII  /   /
006444  040  043  040                .ASCII  / # /
006447  102  131  124                .ASCII  /BYT/
006452  105  123  000                .ASCII  /ES/<00>
006455  000                        .ASCII  <00>
006456  045  101  040  P.ADJ:       .ASCII  /%A /
006461  040  055  055                .ASCII  / --/
006464  110  101  122                .ASCII  /HAR/
006467  104  040  105                .ASCII  /D E/
006472  122  122  117                .ASCII  /RRO/
006475  122  123  055                .ASCII  /RS-/
006500  055  040  055                .ASCII  /- -/
006503  055  123  117                .ASCII  /-SO/
006506  106  124  040                .ASCII  /FT /
006511  105  122  122                .ASCII  /ERR/
006514  117  122  123                .ASCII  /ORS/
006517  055  055  000                .ASCII  /--/<00>
006522  045  116  045  P.ADK:       .ASCII  /%N%/
006525  101  040  043                .ASCII  /A #/
006530  040  040  040                .ASCII  /   /
006533  043  040  040                .ASCII  /#  /
006536  124  131  120                .ASCII  /TYP/
```

```
006541  105  040  040              .ASCII  /E  /
006544  122  105  101              .ASCII  /REA/
006547  104  123  040              .ASCII  /DS /
006552  040  040  040              .ASCII  /   /
006555  040  122  105              .ASCII  / RE/
006560  101  104  040              .ASCII  /AD /
006563  040  040  127              .ASCII  /  W/
006566  122  111  124              .ASCII  /RIT/
006571  105  123  040              .ASCII  /ES /
006574  040  040  127              .ASCII  /  W/
006577  122  111  124              .ASCII  /RIT/
006602  124  105  116              .ASCII  /TEN/
006605  000                       .ASCII  <00>
006606  045  101  040  P.ADL:      .ASCII  /%A /
006611  040  123  105              .ASCII  / SE/
006614  113  040  104              .ASCII  /K D/
006617  101  124  040              .ASCII  /AT /
006622  104  122  126              .ASCII  /DRV/
006625  040  110  123              .ASCII  / HS/
006630  124  040  123              .ASCII  /T S/
006633  105  113  040              .ASCII  /EK /
006636  104  101  124              .ASCII  /DAT/
006641  040  104  122              .ASCII  / DR/
006644  126  040  110              .ASCII  /V H/
006647  123  124  000              .ASCII  /ST/<00>
006652  045  116  045  P.ADM:      .ASCII  /%N%/
006655  101  055  055              .ASCII  /A--/
006660  055  040  055              .ASCII  /- -/
006663  055  055  040              .ASCII  /-- /
006666  055  055  055              .ASCII  /---/
006671  055  040  040              .ASCII  /-  /
006674  055  055  055              .ASCII  /---/
006677  055  055  040              .ASCII  /-- /
006702  040  055  055              .ASCII  / --/
006705  055  055  055              .ASCII  /---/
006710  055  055  055              .ASCII  /---/
006713  055  040  055              .ASCII  /- -/
006716  055  055  055              .ASCII  /---/
006721  055  055  040              .ASCII  /-- /
006724  040  055  055              .ASCII  / --/
006727  055  055  055              .ASCII  /---/
006732  055  055  055              .ASCII  /---/
006735  055  000  000              .ASCII  /-/<00><00>
006740  045  101  040  P.ADN:      .ASCII  /%A /
006743  055  055  055              .ASCII  /---/
006746  040  055  055              .ASCII  / --/
006751  055  040  055              .ASCII  /- -/
006754  055  055  040              .ASCII  /-- /
006757  055  055  055              .ASCII  /---/
006762  040  055  055              .ASCII  / --/
006765  055  040  055              .ASCII  /- -/
006770  055  055  040              .ASCII  /-- /
006773  055  055  055              .ASCII  /---/
```

```
006776  040  055  055              .ASCII  / --/
007001  055  000  000              .ASCII  /-/<00><00>
007004  045  116  045  P.ADO:      .ASCII  /%N%/
007007  104  062  045              .ASCII  /D2%/
007012  104  064  045              .ASCII  /D4%/
007015  123  062  045              .ASCII  /S2%/
007020  124  000                   .ASCII  /T/<00>
007022  045  104  064  P.ADP:      .ASCII  /%D4/
007025  045  132  063              .ASCII  /%Z3/
007030  045  104  063              .ASCII  /%D3/
007033  045  101  054              .ASCII  /%A,/
007036  045  132  063              .ASCII  /%Z3/
007041  045  101  054              .ASCII  /%A,/
007044  045  132  063              .ASCII  /%Z3/
007047  000                       .ASCII  <00>
007050  045  104  064  P.ADQ:      .ASCII  /%D4/
007053  045  104  064              .ASCII  /%D4/
007056  045  104  064              .ASCII  /%D4/
007061  045  104  064              .ASCII  /%D4/
007064  045  104  064              .ASCII  /%D4/
007067  045  104  064              .ASCII  /%D4/
007072  045  104  064              .ASCII  /%D4/
007075  045  104  064              .ASCII  /%D4/
007100  000  000                   .ASCII  <00><00>
007102  045  116  045  P.ADR:      .ASCII  /%N%/
007105  101  040  056              .ASCII  /A ./
007110  040  040  040              .ASCII  /   /
007113  056  040  040              .ASCII  /.  /
007116  103  116  124              .ASCII  /CNT/
007121  122  040  040              .ASCII  /R  /
007124  040  040  040              .ASCII  /   /
007127  040  056  040              .ASCII  / . /
007132  040  056  056              .ASCII  / ../
007135  056  056  056              .ASCII  /.../
007140  056  056  056              .ASCII  /.../
007143  056  040  040              .ASCII  /.  /
007146  040  040  040              .ASCII  /   /
007151  040  056  040              .ASCII  / . /
007154  040  056  056              .ASCII  / ../
007157  056  056  056              .ASCII  /.../
007162  056  056  056              .ASCII  /.../
007165  056  000  000              .ASCII  /./<00><00>
007170  045  101  040  P.ADS:      .ASCII  /%A /
007173  040  040  056              .ASCII  /  ./
007176  040  040  040              .ASCII  /   /
007201  056  045  104              .ASCII  /.%D/
007204  064  045  101              .ASCII  /4%A/
007207  040  040  040              .ASCII  /   /
007212  056  040  040              .ASCII  /.  /
007215  040  056  040              .ASCII  / . /
007220  040  040  056              .ASCII  /  ./
007223  045  104  064              .ASCII  /%D4/
007226  045  101  040              .ASCII  /%A /
```

```
007231  040     040     056                     .ASCII  /  ./
007234  000     000                             .ASCII  <00><00>
007236  045     101     040             P.ADT:  .ASCII  /%A /
007241  040     040     056                     .ASCII  /  ./
007244  040     040     040                     .ASCII  /   /
007247  056     045     104                     .ASCII  /.%D/
007252  064     045     101                     .ASCII  /4%A/
007255  040     040     040                     .ASCII  /   /
007260  056     040     040                     .ASCII  /.  /
007263  040     056     040                     .ASCII  / . /
007266  040     040     056                     .ASCII  /  ./
007271  045     104     064                     .ASCII  /%D4/
007274  045     101     040                     .ASCII  /%A /
007277  040     040     056                     .ASCII  /  ./
007302  000     000                             .ASCII  <00><00>
007304  045     116     045             P.ADU:  .ASCII  /%N%/
007307  116     045     101                     .ASCII  /N%A/
007312  125     116     111                     .ASCII  /UNI/
007315  124     040     040                     .ASCII  /T  /
007320  104     111     123                     .ASCII  /DIS/
007323  113     040     040                     .ASCII  /K  /
007326  040     040     040                     .ASCII  /   /
007331  040     040     040                     .ASCII  /   /
007334  040     040     040                     .ASCII  /   /
007337  040     043     040                     .ASCII  / # /
007342  117     106     040                     .ASCII  /OF /
007345  040     040     043                     .ASCII  /  #/
007350  040     102     114                     .ASCII  / BL/
007353  113     123     040                     .ASCII  /KS /
007356  040     040     040                     .ASCII  /   /
007361  040     040     040                     .ASCII  /   /
007364  043     040     117                     .ASCII  /# O/
007367  106     040     040                     .ASCII  /F  /
007372  040     040     043                     .ASCII  /  #/
007375  040     102     114                     .ASCII  / BL/
007400  113     123     040                     .ASCII  /KS /
007403  000                                     .ASCII  <00>
007404  045     116     045             P.ADV:  .ASCII  /%N%/
007407  101     040     040                     .ASCII  /A  /
007412  043     040     040                     .ASCII  /#  /
007415  040     040     040                     .ASCII  /   /
007420  043     040     040                     .ASCII  /#  /
007423  040     040     040                     .ASCII  /   /
007426  124     131     120                     .ASCII  /TYP/
007431  105     040     040                     .ASCII  /E  /
007434  040     122     105                     .ASCII  / RE/
007437  101     104     123                     .ASCII  /ADS/
007442  040     040     040                     .ASCII  /   /
007445  040     040     122                     .ASCII  /  R/
007450  105     101     104                     .ASCII  /EAD/
007453  040     040     040                     .ASCII  /   /
007456  040     040     040                     .ASCII  /   /
007461  127     122     111                     .ASCII  /WRI/
```

```
007464  124     105     123             .ASCII  /TES/
007467  040     040     127             .ASCII  /  W/
007472  122     111     124             .ASCII  /RIT/
007475  124     105     116             .ASCII  /TEN/
007500  040     000                     .ASCII  / /<00>
007502  045     116     045     P.ADW:  .ASCII  /%N%/
007505  101     055     055             .ASCII  /A--/
007510  055     055     040             .ASCII  /-- /
007513  040     055     055             .ASCII  / --/
007516  055     055     040             .ASCII  /-- /
007521  040     055     055             .ASCII  / --/
007524  055     055     055             .ASCII  /---/
007527  055     055     040             .ASCII  /-- /
007532  040     055     055             .ASCII  / --/
007535  055     055     055             .ASCII  /---/
007540  055     040     040             .ASCII  /-  /
007543  040     055     055             .ASCII  / --/
007546  055     055     055             .ASCII  /---/
007551  055     040     040             .ASCII  /-  /
007554  040     040     040             .ASCII  /   /
007557  055     055     055             .ASCII  /---/
007562  055     055     055             .ASCII  /---/
007565  040     040     040             .ASCII  /   /
007570  055     055     055             .ASCII  /---/
007573  055     055     055             .ASCII  /---/
007576  040     040     000             .ASCII  /  /<00>
007601  000                             .ASCII  <00>
007602  045     116     045     P.ADX:  .ASCII  /%N%/
007605  123     061     045             .ASCII  /S1%/
007610  104     062     045             .ASCII  /D2%/
007613  123     064     045             .ASCII  /S4%/
007616  104     062     045             .ASCII  /D2%/
007621  101     040     040             .ASCII  /A  /
007624  040     104     102             .ASCII  / DB/
007627  116     040     111             .ASCII  /N I/
007632  057     117     040             .ASCII  <57>/O /
007635  040     045     104             .ASCII  / %D/
007640  066     045     123             .ASCII  /6%S/
007643  063     045     104             .ASCII  /3%D/
007646  066     045     123             .ASCII  /6%S/
007651  065     045     104             .ASCII  /5%D/
007654  066     045     123             .ASCII  /6%S/
007657  063     045     104             .ASCII  /3%D/
007662  066     000                     .ASCII  /6/<00>
007664  124     117     117     P.ADY:  .ASCII  /TOO/
007667  040     115     101             .ASCII  / MA/
007672  116     131     040             .ASCII  /NY /
007675  125     116     111             .ASCII  /UNI/
007700  124     123     000             .ASCII  /TS/<00>
007703  000                             .ASCII  <00>
007704  116     117     124     P.ADZ:  .ASCII  /NOT/
007707  040     105     116             .ASCII  / EN/
007712  117     125     107             .ASCII  /OUG/
```

```
007715  110  040  106              .ASCII  /H F/
007720  122  105  105              .ASCII  /REE/
007723  040  115  105              .ASCII  / ME/
007726  115  117  122              .ASCII  /MOR/
007731  131  040  106              .ASCII  /Y F/
007734  117  122  040              .ASCII  /OR /
007737  101  114  114              .ASCII  /ALL/
007742  117  103  101              .ASCII  /OCA/
007745  124  111  116              .ASCII  /TIN/
007750  107  040  122              .ASCII  /G R/
007753  105  101  104              .ASCII  /EAD/
007756  057  127  122              .ASCII  <57>/WR/
007761  111  124  105              .ASCII  /ITE/
007764  040  102  125              .ASCII  / BU/
007767  106  106  105              .ASCII  /FFE/
007772  122  123  000              .ASCII  /RS/<00>
007775  000                       .ASCII  <00>
007776  122  105  107  P.AEA:      .ASCII  /REG/
010001  111  123  124              .ASCII  /IST/
010004  105  122  040              .ASCII  /ER /
010007  105  130  111              .ASCII  /EXI/
010012  123  124  105              .ASCII  /STE/
010015  116  103  105              .ASCII  /NCE/
010020  040  124  105              .ASCII  / TE/
010023  123  124  040              .ASCII  /ST /
010026  106  101  111              .ASCII  /FAI/
010031  114  105  104              .ASCII  /LED/
010034  000  000                   .ASCII  <00><00>
010036  126  105  103  P.AEB:      .ASCII  /VEC/
010041  124  117  122              .ASCII  /TOR/
010044  040  124  105              .ASCII  / TE/
010047  123  124  040              .ASCII  /ST /
010052  106  101  111              .ASCII  /FAI/
010055  114  105  104              .ASCII  /LED/
010060  000  000                   .ASCII  <00><00>
010062  102  122  040  P.AEC:      .ASCII  /BR /
010065  114  105  126              .ASCII  /LEV/
010070  105  114  040              .ASCII  /EL /
010073  124  105  123              .ASCII  /TES/
010076  124  040  106              .ASCII  /T F/
010101  101  111  114              .ASCII  /AIL/
010104  105  104  000              .ASCII  /ED/<00>
010107  000                       .ASCII  <00>
010110  111  116  111  P.AED:      .ASCII  /INI/
010113  124  040  123              .ASCII  /T S/
010116  105  121  125              .ASCII  /EQU/
010121  105  116  103              .ASCII  /ENC/
010124  105  040  106              .ASCII  /E F/
010127  101  111  114              .ASCII  /AIL/
010132  105  104  000              .ASCII  /ED/<00>
010135  000                       .ASCII  <00>
010136  106  101  124  P.AEE:      .ASCII  /FAT/
010141  101  114  040              .ASCII  /AL /
```

```
010144  103  117  116              .ASCII  /CON/
010147  124  122  117              .ASCII  /TRO/
010152  114  114  105              .ASCII  /LLE/
010155  122  040  105              .ASCII  /R E/
010160  122  122  117              .ASCII  /RRO/
010163  122  000  000              .ASCII  /R/<00><00>
010166  117  116  114  P.AEF:      .ASCII  /ONL/
010171  111  116  105              .ASCII  /INE/
010174  040  106  101              .ASCII  / FA/
010177  111  114  105              .ASCII  /ILE/
010202  104  000                   .ASCII  /D/<00>
010204  127  122  111  P.AEG:      .ASCII  /WRI/
010207  124  105  055              .ASCII  /TE-/
010212  120  122  117              .ASCII  /PRO/
010215  124  105  103              .ASCII  /TEC/
010220  124  040  103              .ASCII  /T C/
010223  117  116  106              .ASCII  /ONF/
010226  114  111  103              .ASCII  /LIC/
010231  124  000  000              .ASCII  /T/<00><00>
010234  101  103  103  P.AEH:      .ASCII  /ACC/
010237  105  123  123              .ASCII  /ESS/
010242  040  106  101              .ASCII  / FA/
010245  111  114  105              .ASCII  /ILE/
010250  104  000                   .ASCII  /D/<00>
010252  106  101  124  P.AEI:      .ASCII  /FAT/
010255  101  114  040              .ASCII  /AL /
010260  111  057  117              .ASCII  /I/<57>/O/
010263  040  105  122              .ASCII  / ER/
010266  122  117  122              .ASCII  /ROR/
010271  000                        .ASCII  <00>
010272  104  111  123  P.AEJ:      .ASCII  /DIS/
010275  113  040  124              .ASCII  /K T/
010300  131  120  105              .ASCII  /YPE/
010303  040  125  116              .ASCII  / UN/
010306  113  116  117              .ASCII  /KNO/
010311  127  116  040              .ASCII  /WN /
010314  124  117  040              .ASCII  /TO /
010317  105  130  105              .ASCII  /EXE/
010322  122  103  111              .ASCII  /RCI/
010325  123  105  122              .ASCII  /SER/
010330  000  000                   .ASCII  <00><00>
010332  106  101  111  P.AEK:      .ASCII  /FAI/
010335  114  105  104              .ASCII  /LED/
010340  040  124  117              .ASCII  / TO/
010343  040  123  105              .ASCII  / SE/
010346  116  104  040              .ASCII  /ND /
010351  123  105  124              .ASCII  /SET/
010354  055  103  117              .ASCII  /-CO/
010357  116  124  122              .ASCII  /NTR/
010362  117  114  114              .ASCII  /OLL/
010365  105  122  055              .ASCII  /ER-/
010370  103  110  101              .ASCII  /CHA/
010373  122  101  103              .ASCII  /RAC/
```

```
010376  124  105  122                .ASCII  /TER/
010401  111  123  124                .ASCII  /IST/
010404  111  103  123                .ASCII  /ICS/
010407  040  103  117                .ASCII  / CO/
010412  115  115  101                .ASCII  /MMA/
010415  116  104  000                .ASCII  /ND/<00>
010420  123  105  124  P.AEL:        .ASCII  /SET/
010423  055  103  117                .ASCII  /-CO/
010426  116  124  122                .ASCII  /NTR/
010431  117  114  114                .ASCII  /OLL/
010434  105  122  055                .ASCII  /ER-/
010437  103  110  101                .ASCII  /CHA/
010442  122  101  103                .ASCII  /RAC/
010445  124  105  122                .ASCII  /TER/
010450  111  123  124                .ASCII  /IST/
010453  111  103  123                .ASCII  /ICS/
010456  040  122  105                .ASCII  / RE/
010461  123  120  117                .ASCII  /SPO/
010464  116  123  105                .ASCII  /NSE/
010467  040  110  101                .ASCII  / HA/
010472  123  040  102                .ASCII  /S B/
010475  101  104  040                .ASCII  /AD /
010500  105  116  104                .ASCII  /END/
010503  103  117  104                .ASCII  /COD/
010506  105  040  117                .ASCII  /E O/
010511  122  040  106                .ASCII  /R F/
010514  114  101  107                .ASCII  /LAG/
010517  123  040  111                .ASCII  /S I/
010522  116  040  105                .ASCII  /N E/
010525  122  122  117                .ASCII  /RRO/
010530  122  000                     .ASCII  /R/<00>
010532  106  101  111  P.AEM:        .ASCII  /FAI/
010535  114  105  104                .ASCII  /LED/
010540  040  124  117                .ASCII  / TO/
010543  040  123  105                .ASCII  / SE/
010546  116  104  040                .ASCII  /ND /
010551  117  116  055                .ASCII  /ON-/
010554  114  111  116                .ASCII  /LIN/
010557  105  040  103                .ASCII  /E C/
010562  117  115  115                .ASCII  /OMM/
010565  101  116  104                .ASCII  /AND/
010570  000  000                     .ASCII  <00><0C>
010572  117  116  055  P.AEN:        .ASCII  /ON-/
010575  114  111  116                .ASCII  /LIN/
010600  105  040  122                .ASCII  /E R/
010603  105  123  120                .ASCII  /ESP/
010606  117  116  123                .ASCII  /ONS/
010611  105  040  110                .ASCII  /E H/
010614  101  123  040                .ASCII  /AS /
010617  102  101  104                .ASCII  /BAD/
010622  040  105  116                .ASCII  / EN/
010625  104  103  117                .ASCII  /DCO/
010630  104  105  000                .ASCII  /DE/<00>
```

```
010633  000                             .ASCII  <00>
010634  117     116     055     P.AEO:  .ASCII  /ON-/
010637  114     111     116             .ASCII  /LIN/
010642  105     040     122             .ASCII  /E R/
010645  105     123     120             .ASCII  /ESP/
010650  117     116     123             .ASCII  /ONS/
010653  105     040     110             .ASCII  /E H/
010656  101     123     040             .ASCII  /AS /
010661  125     116     113             .ASCII  /UNK/
010664  116     117     127             .ASCII  /NOW/
010667  116     040     104             .ASCII  /N D/
010672  105     126     111             .ASCII  /EVI/
010675  103     105     000             .ASCII  /CE/<00>
010700  111     057     117     P.AEP:  .ASCII  /I/<57>/O/
010703  040     122     105             .ASCII  / RE/
010706  121     125     105             .ASCII  /QUE/
010711  123     124     040             .ASCII  /ST /
010714  106     101     111             .ASCII  /FAI/
010717  114     105     104             .ASCII  /LED/
010722  000     000                     .ASCII  <00><00>
010724  045     101     115     P.AEQ:  .ASCII  /%AM/
010727  117     122     105             .ASCII  /ORE/
010732  040     124     110             .ASCII  / TH/
010735  101     116     040             .ASCII  /AN /
010740  045     104     062             .ASCII  /%D2/
010743  045     101     040             .ASCII  /%A /
010746  125     116     111             .ASCII  /UNI/
010751  124     123     040             .ASCII  /TS /
010754  123     120     105             .ASCII  /SPE/
010757  103     111     106             .ASCII  /CIF/
010762  111     105     104             .ASCII  /IED/
010765  000                             .ASCII  <00>
010766  045     101     052     P.AER:  .ASCII  /%A*/
010771  040     116     117             .ASCII  / NO/
010774  040     122     105             .ASCII  / RE/
010777  123     120     117             .ASCII  /SPO/
011002  116     123     105             .ASCII  /NSE/
011005  040     101     124             .ASCII  / AT/
011010  040     101     104             .ASCII  / AD/
011013  104     122     105             .ASCII  /DRE/
011016  123     123     040             .ASCII  /SS /
011021  045     117     066             .ASCII  /%06/
011024  000     000                     .ASCII  <00><00>
011026  045     101     052     P.AES:  .ASCII  /%A*/
011031  040     111     116             .ASCII  / IN/
011034  103     117     122             .ASCII  /COR/
011037  122     105     103             .ASCII  /REC/
011042  124     040     102             .ASCII  /T B/
011045  122     040     114             .ASCII  /R L/
011050  105     126     105             .ASCII  /EVE/
011053  114     040     106             .ASCII  /L F/
011056  117     122     040             .ASCII  /OR /
011061  104     122     111             .ASCII  /DRI/
```

```
011064  126  105  040                .ASCII  /VE /
011067  045  117  066                .ASCII  /%06/
011072  000  000                     .ASCII  <00><00>
011074  045  101  052          P.AET: .ASCII  /%A*/
011077  040  123  124                .ASCII  / ST/
011102  105  120  040                .ASCII  /EP /
011105  045  104  061                .ASCII  /%D1/
011110  045  101  040                .ASCII  /%A /
011113  122  105  101                .ASCII  /REA/
011116  104  040  105                .ASCII  /D E/
011121  122  122  117                .ASCII  /RRO/
011124  122  000                     .ASCII  /P/<00>
011126  045  101  052          P.AEU: .ASCII  /%A*/
011131  040  102  101                .ASCII  / BA/
011134  104  040  123                .ASCII  /D S/
011137  101  040  103                .ASCII  /A C/
011142  117  104  105                .ASCII  /ODE/
011145  040  106  122                .ASCII  / FR/
011150  117  115  040                .ASCII  /OM /
011153  104  122  111                .ASCII  /DRI/
011156  126  105  040                .ASCII  /VE /
011161  045  117  066                .ASCII  /%06/
011164  000  000                     .ASCII  <00><00>
011166  045  101  052          P.AEV: .ASCII  /%A*/
011171  040  104  111                .ASCII  / DI/
011174  123  113  045                .ASCII  /SK%/
011177  104  062  045                .ASCII  /D2%/
011202  101  040  127                .ASCII  /A W/
011205  105  116  124                .ASCII  /ENT/
011210  040  117  106                .ASCII  / OF/
011213  106  114  111                .ASCII  /FLI/
011216  116  105  000                .ASCII  /NE/<00>
011221  000                         .ASCII  <00>
011222  045  101  052          P.AEW: .ASCII  /%A*/
011225  040  104  122                .ASCII  / DR/
011230  111  126  105                .ASCII  /IVE/
011233  040  045  117                .ASCII  / %O/
011236  066  045  101                .ASCII  /6%A/
011241  040  116  117                .ASCII  / NO/
011244  124  040  120                .ASCII  /T P/
011247  122  117  103                .ASCII  /ROC/
011252  105  123  123                .ASCII  /ESS/
011255  111  116  107                .ASCII  /ING/
011260  040  103  117                .ASCII  / CO/
011263  115  115  101                .ASCII  /MMA/
011266  116  104  040                .ASCII  /ND /
011271  120  101  103                .ASCII  /PAC/
011274  113  105  124                .ASCII  /KET/
011277  123  000  000                .ASCII  /S/<00><00>
011302  045  101  052          P.AEX: .ASCII  /%A*/
011305  040  104  111                .ASCII  / DI/
011310  123  113  045                .ASCII  /SK%/
011313  104  062  045                .ASCII  /D2%/
```

```
011316  101  040  127                .ASCII  /A W/
011321  105  116  124                .ASCII  /ENT/
011324  040  124  117                .ASCII  / TO/
011327  040  124  110                .ASCII  / TH/
011332  105  040  042                .ASCII  /E "/
011335  101  126  101                .ASCII  /AVA/
011340  111  114  107                .ASCII  /ILA/
011343  102  114  105                .ASCII  /BLE/
011346  042  040  123                .ASCII  /" S/
011351  124  101  124                .ASCII  /TAT/
011354  105  000                     .ASCII  /E/<00>
011356  040  055  040      P.AEY:    .ASCII  / - /
011361  125  116  122                .ASCII  /UNR/
011364  105  103  117                .ASCII  /ECO/
011367  107  116  111                .ASCII  /GNI/
011372  132  105  104                .ASCII  /ZED/
011375  040  115  105                .ASCII  / ME/
011400  123  123  101                .ASCII  /SSA/
011403  107  105  040                .ASCII  /GE /
011406  124  131  120                .ASCII  /TYP/
011411  105  000  000                .ASCII  /E/<00><00>
011414  040  055  040      P.AEZ:    .ASCII  / - /
011417  125  116  122                .ASCII  /UNR/
011422  105  103  117                .ASCII  /ECO/
011425  107  116  111                .ASCII  /GNI/
011430  132  105  104                .ASCII  /ZED/
011433  040  103  117                .ASCII  / CO/
011436  116  116  105                .ASCII  /NNE/
011441  103  124  111                .ASCII  /CTI/
011444  117  116  040                .ASCII  /ON /
011447  111  104  000                .ASCII  /ID/<00>
011452  040  055  040      P.AFA:    .ASCII  / - /
011455  125  116  122                .ASCII  /UNR/
011460  105  103  117                .ASCII  /ECO/
011463  107  116  111                .ASCII  /GNI/
011466  132  105  104                .ASCII  /ZED/
011471  040  122  105                .ASCII  / RE/
011474  124  125  122                .ASCII  /TUR/
011477  116  040  115                .ASCII  /N M/
011502  105  123  123                .ASCII  /ESS/
011505  101  107  105                .ASCII  /AGE/
011510  000  000                     .ASCII  <00><00>
011512  040  055  040      P.AFB:    .ASCII  / - /
011515  125  116  122                .ASCII  /UNR/
011520  105  103  117                .ASCII  /ECO/
011523  107  116  111                .ASCII  /GNI/
011526  132  105  104                .ASCII  /ZED/
011531  040  122  105                .ASCII  / RE/
011534  124  125  122                .ASCII  /TUR/
011537  116  040  120                .ASCII  /N P/
011542  101  103  113                .ASCII  /ACK/
011545  105  124  000                .ASCII  /ET/<00>
011550  040  055  040      P.AFC:    .ASCII  / - /
```

```
011553  125  116  122          .ASCII  /UNR/
011556  105  103  117          .ASCII  /ECO/
011561  107  116  111          .ASCII  /GNI/
011564  132  105  104          .ASCII  /ZED/
011567  040  103  122          .ASCII  / CR/
011572  116  000              .ASCII  /N/<00>
011574  040  055  040  P.AFD:  .ASCII  / - /
011577  125  116  122          .ASCII  /UNR/
011602  105  103  117          .ASCII  /ECO/
011605  107  116  111          .ASCII  /GNI/
011610  132  105  104          .ASCII  /ZED/
011613  040  117  120          .ASCII  / OP/
011616  103  117  104          .ASCII  /COD/
011621  105  000  000          .ASCII  /E/<00><00>
011624  040  055  040  P.AFE:  .ASCII  / - /
011627  115  123  103          .ASCII  /MSC/
011632  120  040  123          .ASCII  /P S/
011635  124  101  124          .ASCII  /TAT/
011640  125  123  040          .ASCII  /US /
011643  103  117  104          .ASCII  /COD/
011646  105  040  105          .ASCII  /E E/
011651  122  122  000          .ASCII  /RR/<00>
011654  040  055  040  P.AFF:  .ASCII  / - /
011657  104  125  120          .ASCII  /DUP/
011662  040  123  124          .ASCII  / ST/
011665  101  124  125          .ASCII  /ATU/
011670  123  040  103          .ASCII  /S C/
011673  117  104  105          .ASCII  /ODE/
011676  040  105  122          .ASCII  / ER/
011701  122  000  000          .ASCII  /R/<00><00>
011704  040  055  040  P.AFG:  .ASCII  / - /
011707  125  116  122          .ASCII  /UNR/
011712  105  103  117          .ASCII  /ECO/
011715  107  116  111          .ASCII  /GNI/
011720  132  105  104          .ASCII  /ZED/
011723  040  123  124          .ASCII  / ST/
011726  101  124  125          .ASCII  /ATU/
011731  123  040  103          .ASCII  /S C/
011734  117  104  105          .ASCII  /ODE/
011737  000                    .ASCII  <00>
011740  040  055  040  P.AFH:  .ASCII  / - /
011743  114  102  116          .ASCII  /LBN/
011746  040  110  117          .ASCII  / HO/
011751  123  124  040          .ASCII  /ST /
011754  103  117  115          .ASCII  /COM/
011757  120  101  122          .ASCII  /PAR/
011762  105  040  105          .ASCII  /E E/
011765  122  122  000          .ASCII  /RR/<00>
011770  040  055  040  P.AFI:  .ASCII  / - /
011773  104  102  116          .ASCII  /DBN/
011776  040  110  117          .ASCII  / HO/
012001  123  124  040          .ASCII  /ST /
012004  103  117  115          .ASCII  /COM/
```

```
012007  120  101  122            .ASCII  /PAR/
012012  105  040  105            .ASCII  /E E/
012015  122  122  000            .ASCII  /RR/<00>
012020  040  055  040  P.AFJ:    .ASCII  / - /
012023  125  116  101            .ASCII  /UNA/
012026  102  114  105            .ASCII  /BLE/
012031  040  124  117            .ASCII  / TO/
012034  040  114  117            .ASCII  / LO/
012037  101  104  040            .ASCII  /AD /
012042  104  125  120            .ASCII  /DUP/
012045  040  115  105            .ASCII  / ME/
012050  104  111  101            .ASCII  /DIA/
012053  000                      .ASCII  <00>
012054  040  055  040  P.AFK:    .ASCII  / - /
012057  105  122  122            .ASCII  /ERR/
012062  040  111  116            .ASCII  / IN/
012065  040  104  125            .ASCII  / DU/
012070  120  040  120            .ASCII  /P P/
012073  113  124  040            .ASCII  /KT /
012076  127  110  105            .ASCII  /WHE/
012101  116  040  125            .ASCII  /N U/
012104  123  111  116            .ASCII  /SIN/
012107  107  040  103            .ASCII  /G C/
012112  124  114  122            .ASCII  /TLR/
012115  040  114  103            .ASCII  / LC/
012120  040  120  122            .ASCII  / PR/
012123  117  107  000            .ASCII  /OG/<00>
012126  045  101  C52  P.AFL:    .ASCII  /%A*/
012131  040  104  111            .ASCII  / DI/
012134  123  113  045            .ASCII  /SK%/
012137  104  062  000            .ASCII  /D2/<00>
012142  045  101  111  P.AFN:    .ASCII  /%AI/
012145  116  126  101            .ASCII  /NVA/
012150  114  111  104            .ASCII  /LID/
012153  040  103  117            .ASCII  / CO/
012156  115  115  101            .ASCII  /MMA/
012161  116  104  000            .ASCII  /ND/<00>
012164  045  101  103  P.AFO:    .ASCII  /%AC/
012167  117  115  115            .ASCII  /OMM/
012172  101  116  104            .ASCII  /AND/
012175  040  101  102            .ASCII  / AB/
012200  117  122  124            .ASCII  /ORT/
012203  105  104  000            .ASCII  /ED/<00>
012206  045  101  125  P.AFP:    .ASCII  /%AU/
012211  116  111  124            .ASCII  /NIT/
012214  040  117  106            .ASCII  / OF/
012217  106  114  111            .ASCII  /FLI/
012222  116  105  000            .ASCII  /NE/<00>
012225  000                      .ASCII  <00>
012226  045  101  124  P.AFQ:    .ASCII  /%AT/
012231  122  101  116            .ASCII  /RAN/
012234  123  111  124            .ASCII  /SIT/
012237  111  117  116            .ASCII  /ION/
```

```
012242  040     124     117                     .ASCII  / TO/
012245  040     101     126                     .ASCII  / AV/
012250  101     111     114                     .ASCII  /AIL/
012253  101     102     114                     .ASCII  /ABL/
012256  105     040     123                     .ASCII  /E S/
012261  124     101     124                     .ASCII  /TAT/
012264  105     000                             .ASCII  /E/<00>
012266  045     101     115     P.AFR:          .ASCII  /%AM/
012271  105     104     111                     .ASCII  /EDI/
012274  101     040     106                     .ASCII  /A F/
012277  117     122     115                     .ASCII  /ORM/
012302  101     124     040                     .ASCII  /AT /
012305  105     122     122                     .ASCII  /ERR/
012310  117     122     000                     .ASCII  /OR/<00>
012313  000                                     .ASCII  <00>
012314  045     101     127     P.AFS:          .ASCII  /%AW/
012317  122     111     124                     .ASCII  /RIT/
012322  105     055     120                     .ASCII  /E-P/
012325  122     117     124                     .ASCII  /ROT/
012330  105     103     124                     .ASCII  /ECT/
012333  105     104     000                     .ASCII  /ED/<00>
012336  045     101     104     P.AFT:          .ASCII  /%AD/
012341  105     126     111                     .ASCII  /EVI/
012344  103     105     040                     .ASCII  /CE /
012347  103     117     115                     .ASCII  /COM/
012352  120     101     122                     .ASCII  /PAR/
012355  105     040     105                     .ASCII  /E E/
012360  122     122     117                     .ASCII  /RRO/
012363  122     000     000                     .ASCII  /R/<00><00>
012366  045     101     104     P.AFU:          .ASCII  /%AD/
012371  101     124     101                     .ASCII  /ATA/
012374  040     105     122                     .ASCII  / ER/
012377  122     117     122                     .ASCII  /ROR/
012402  000     000                             .ASCII  <00><00>
012404  045     101     110     P.AFV:          .ASCII  /%AH/
012407  117     123     124                     .ASCII  /OST/
012412  040     102     125                     .ASCII  / BU/
012415  106     106     105                     .ASCII  /FFE/
012420  122     040     101                     .ASCII  /R A/
012423  103     103     105                     .ASCII  /CCE/
012426  123     123     040                     .ASCII  /SS /
012431  105     122     122                     .ASCII  /ERR/
012434  117     122     000                     .ASCII  /OR/<00>
012437  000                                     .ASCII  <00>
012440  045     101     103     P.AFW:          .ASCII  /%AC/
012443  117     116     124                     .ASCII  /ONT/
012446  122     117     114                     .ASCII  /ROL/
012451  114     105     122                     .ASCII  /LER/
012454  040     105     122                     .ASCII  / ER/
012457  122     117     122                     .ASCII  /ROR/
012462  000     000                             .ASCII  <00><00>
012464  045     101     104     P.AFX:          .ASCII  /%AD/
012467  122     111     126                     .ASCII  /RIV/
```

```
012472      105      040      105                    .ASCII  /E E/
012475      122      122      117                    .ASCII  /RRO/
012500      122      000                             .ASCII  /R/<00>
012502      045      101      115          P.AFY:    .ASCII  /%AM/
012505      105      123      123                    .ASCII  /ESS/
012510      101      107      105                    .ASCII  /AGE/
012513      040      106      122                    .ASCII  / FR/
012516      117      115      040                    .ASCII  /OM /
012521      111      116      124                    .ASCII  /INT/
012524      105      122      116                    .ASCII  /ERN'
012527      101      114      040                    .ASCII  /AL /
012532      104      111      101                    .ASCII  /DIA/
012535      107      116      117                    .ASCII  /GNO/
012540      123      124      111                    .ASCII  /STI/
012543      103      123      000                    .ASCII  /CS/<00>
012546      045      101      110          P.AFZ:    .ASCII  /%AH/
012551      117      123      124                    .ASCII  /OST/
012554      040      103      117                    .ASCII  / CO/
012557      115      120      101                    .ASCII  /MPA/
012562      122      105      040                    .ASCII  /RE /
012565      105      122      122                    .ASCII  /ERR/
012570      117      122      000                    .ASCII  /OR/<00>
012573      000                                      .ASCII  <00>
012574      045      101      103          P.AGA:    .ASCII  /%AC/
012577      117      115      115                    .ASCII  /OMM/
012602      101      116      104                    .ASCII  /AND/
012605      040      124      111                    .ASCII  / TI/
012610      115      105      117                    .ASCII  /MEO/
012613      125      124      000                    .ASCII  /UT/<00>
012616      045      101      102          P.AGB:    .ASCII  /%AB/
012621      101      104      040                    .ASCII  /AD /
012624      102      114      117                    .ASCII  /BLO/
012627      103      113      040                    .ASCII  /CK /
012632      122      105      120                    .ASCII  /REP/
012635      114      101      103                    .ASCII  /LAC/
012640      105      115      105                    .ASCII  /EME/
012643      116      124      040                    .ASCII  /NT /
012646      103      117      115                    .ASCII  /COM/
012651      120      114      105                    .ASCII  /PLE/
012654      124      111      117                    .ASCII  /TIO/
012657      116      000      000                    .ASCII  /N/<00><00>
012662   012142'                            P.AFM:    .WORD   P.AFN
012664   012164'                                      .WORD   P.AFO
012666   012206'                                      .WORD   P.AFP
012670   012226'                                      .WORD   P.AFQ
012672   012266'                                      .WORD   P.AFR
012674   012314'                                      .WORD   P.AFS
012676   012336'                                      .WORD   P.AFT
012700   012366'                                      .WORD   P.AFU
012702   012404'                                      .WORD   P.AFV
012704   012440'                                      .WORD   P.AFW
012706   012464'                                      .WORD   P.AFX
012710   012502'                                      .WORD   P.AFY
```

```
012712  012546'                                 .WORD   P.AFZ
012714  012574'                                 .WORD   P.AGA
012716  012616'                                 .WORD   P.AGB
012720      045     101     105         P.AGC:  .ASCII  /%AE/
012723      122     122     117                 .ASCII  /RRO/
012726      122     040     114                 .ASCII  /R L/
012731      117     107     040                 .ASCII  /OG /
012734      115     105     123                 .ASCII  /MES/
012737      123     101     107                 .ASCII  /SAG/
012742      105     040     122                 .ASCII  /E R/
012745      105     103     105                 .ASCII  /ECE/
012750      111     126     105                 .ASCII  /IVE/
012753      104     072     045                 .ASCII  /D:%/
012756      116     000                         .ASCII  /N/<00>
012760      045     101     052         P.AGE:  .ASCII  /%A*/
012763      040     103     117                 .ASCII  / CO/
012766      116     124     122                 .ASCII  /NTR/
012771      117     114     114                 .ASCII  /OLL/
012774      105     122     040                 .ASCII  /ER /
012777      105     122     122                 .ASCII  /ERR/
013002      117     122     045                 .ASCII  /OR%/
013005      116     000     000                 .ASCII  /N/<00><00>
013010      045     101     052         P.AGF:  .ASCII  /%A*/
013013      040     110     117                 .ASCII  / HO/
013016      123     124     040                 .ASCII  /ST /
013021      115     105     115                 .ASCII  /MEM/
013024      117     122     131                 .ASCII  /ORY/
013027      040     101     103                 .ASCII  / AC/
013032      103     105     123                 .ASCII  /CES/
013035      123     040     105                 .ASCII  /S E/
013040      122     122     117                 .ASCII  /RRO/
013043      122     045     116                 .ASCII  /R%N/
013046      000     000                         .ASCII  <00><00>
013050      045     101     052         P.AGG:  .ASCII  /%A*/
013053      040     104     111                 .ASCII  / DI/
013056      123     113     045                 .ASCII  /SK%/
013061      104     062     045                 .ASCII  /D2%/
013064      101     040     055                 .ASCII  /A -/
013067      040     104     111                 .ASCII  / DI/
013072      123     113     040                 .ASCII  /SK /
013075      124     122     101                 .ASCII  /TRA/
013100      116     123     106                 .ASCII  /NSF/
013103      105     122     040                 .ASCII  /ER /
013106      105     122     122                 .ASCII  /ERR/
013111      117     122     045                 .ASCII  /OR%/
013114      116     000                         .ASCII  /N/<00>
013116      045     101     052         P.AGH:  .ASCII  /%A*/
013121      040     104     111                 .ASCII  / DI/
013124      123     113     045                 .ASCII  /SK%/
013127      104     062     045                 .ASCII  /D2%/
013132      101     040     055                 .ASCII  /A -/
013135      040     042     123                 .ASCII  / "S/
013140      124     101     116                 .ASCII  /TAN/
```

```
013143      104      101      122                .ASCII  /DAR/
013146      104      040      104                .ASCII  /D D/
013151      111      123      113                .ASCII  /ISK/
013154      040      111      116                .ASCII  / IN/
013157      124      105      122                .ASCII  /TER/
013162      103      117      116                .ASCII  /CON/
013165      116      105      103                .ASCII  /NEC/
013170      124      042      040                .ASCII  /T" /
013173      105      122      122                .ASCII  /ERR/
013176      117      122      045                .ASCII  /OR%/
013201      116      000      000                .ASCII  /N/<00><00>
013204      045      101      052      P.AGI:    .ASCII  /%A*/
013207      040      104      111                .ASCII  / DI/
013212      123      113      045                .ASCII  /SK%/
013215      104      062      045                .ASCII  /D2%/
013220      101      040      055                .ASCII  /A -/
013223      040      042      123                .ASCII  / "S/
013226      115      101      114                .ASCII  /MAL/
013231      114      040      104                .ASCII  /L D/
013234      111      123      113                .ASCII  /ISK/
013237      042      040      105                .ASCII  /" E/
013242      122      122      117                .ASCII  /RRO/
013245      122      045      116                .ASCII  /R%N/
013250      000      000                         .ASCII  <00><00>
013252      045      101      052      P.AGJ:    .ASCII  /%A*/
013255      040      104      111                .ASCII  / DI/
013260      123      113      045                .ASCII  /SK%/
013263      104      062      045                .ASCII  /D2%/
013266      101      040      055                .ASCII  /A -/
013271      040      042      102                .ASCII  / "B/
013274      101      104      040                .ASCII  /AD /
013277      102      114      117                .ASCII  /BLO/
013302      103      113      040                .ASCII  /CK /
013305      122      105      120                .ASCII  /REP/
013310      114      101      103                .ASCII  /LAC/
013313      105      115      105                .ASCII  /EME/
013316      116      124      040                .ASCII  /NT /
013321      101      124      124                .ASCII  /ATT/
013324      105      115      120                .ASCII  /EMP/
013327      124      042      045                .ASCII  /T"%/
013332      116      000                         .ASCII  /N/<00>
013334   012760'                      P.AGD:    .WORD   P.AGE
013336   013010'                                .WORD   P.AGF
013340   013050'                                .WORD   P.AGG
013342   013116'                                .WORD   P.AGH
013344   013204'                                .WORD   P.AGI
013346   013252'                                .WORD   P.AGJ
013350      045      116      045      P.AGK:    .ASCII  /%N%/
013353      101      052      040                .ASCII  /A* /
013356      123      101      072                .ASCII  /SA:/
013361      040      045      117                .ASCII  / %O/
013364      066      000                         .ASCII  /6/<00>
013366      045      116      045      P.AGL:    .ASCII  /%N%/
```

```
013371  101  052  040                .ASCII  /A  /
013374  123  124  101                .ASCII  /STA/
013377  124  125  123                .ASCII  /TUS/
013402  040  103  117                .ASCII  / CO/
013405  104  105  072                .ASCII  /DE:/
013410  040  045  117                .ASCII  / %O/
013413  062  000  000                .ASCII  /2/<00><00>
013416  045  117  064      P.AGM:    .ASCII  /%04/
013421  000                         .ASCII  <00>
013422  045  116  045      P.AGN:    .ASCII  /%N%/
013425  101  052  040                .ASCII  /A  /
013430  123  125  102                .ASCII  /SUB/
013433  137  103  117                .ASCII  /_CO/
013436  104  105  072                .ASCII  /DE:/
013441  040  000  000                .ASCII  / /<00><00>
013444  045  116  04_      P.AGO:    .ASCII  /%N%/
013447  101  052  040                .ASCII  /A  /
013452  103  117  115                .ASCII  /COM/
013455  115  101  116                .ASCII  /MAN/
013460  104  072  040                .ASCII  /D: /
013463  000                         .ASCII  <00>
013464  045  101  122      P.AGP:    .ASCII  /%AR/
013467  105  101  104                .ASCII  /EAD/
013472  000  000                    .ASCII  <00><00>
013474  045  101  127      P.AGQ:    .ASCII  /%AW/
013477  122  111  124                .ASCII  /RIT/
013502  105  000                    .ASCII  /E/<00>
013504  045  101  055      P.AGR:    .ASCII  /%A-/
013507  103  117  115                .ASCII  /COM/
013512  120  101  122                .ASCII  /PAR/
013515  105  000  000                .ASCII  /E/<00><00>
013520  045  101  117      P.AGS:    .ASCII  /%AO/
013523  116  114  111                .ASCII  /NLI/
013526  116  105  000                .ASCII  /NE/<00>
013531  000                         .ASCII  <00>
013532  045  101  101      P.AGT:    .ASCII  /%AA/
013535  103  103  105                .ASCII  /CCE/
013540  123  123  000                .ASCII  /SS/<00>
013543  000                         .ASCII  <00>
013544  045  117  063      P.AGU:    .ASCII  /%03/
013547  000                         .ASCII  <00>
013550  045  116  045      P.AGV:    .ASCII  /%N%/
013553  101  052  040                .ASCII  /A  /
013556  102  101  104                .ASCII  /BAD/
013561  040  102  114                .ASCII  / BL/
013564  117  103  113                .ASCII  /OCK/
013567  072  040  045                .ASCII  /: %/
013572  117  066  045                .ASCII  /06%/
013575  101  040  045                .ASCII  /A %/
013600  117  066  045                .ASCII  /06%/
013603  101  040  040                .ASCII  /A  /
013606  050  117  103                .ASCII  /(OC/
013611  124  101  114                .ASCII  /TAL/
```

```
013614  051  000                    .ASCII  /)/<00>
013616  045  116  045       P.AGW:  .ASCII  /%N%/
013621  101  052  040               .ASCII  /A* /
013624  061  123  124               .ASCII  /1ST/
013627  040  102  101               .ASCII  / BA/
013632  104  040  102               .ASCII  /D B/
013635  114  117  103               .ASCII  /LOC/
013640  113  072  040               .ASCII  /K: /
013643  045  117  066               .ASCII  /%O6/
013646  045  101  040               .ASCII  /%A /
013651  045  117  066               .ASCII  /%O6/
013654  045  101  040               .ASCII  /%A /
013657  040  050  117               .ASCII  / (O/
013662  103  124  101               .ASCII  /CTA/
013665  114  051  000               .ASCII  /L)/<00>
013670  045  116  045       P.AGX:  .ASCII  /%N%/
013673  101  052  040               .ASCII  /A* /
013676  102  101  104               .ASCII  /BAD/
013701  040  102  114               .ASCII  / BL/
013704  117  103  113               .ASCII  /OCK/
013707  040  122  105               .ASCII  / RE/
013712  120  114  101               .ASCII  /PLA/
013715  103  105  104               .ASCII  /CED/
013720  072  040  045               .ASCII  /: %/
013723  117  066  045               .ASCII  /O6%/
013726  101  040  045               .ASCII  /A %/
013731  117  066  045               .ASCII  /O6%/
013734  101  040  040               .ASCII  /A  /
013737  050  117  103               .ASCII  /(OC/
013742  124  101  114               .ASCII  /TAL/
013745  051  000  000               .ASCII  /)/<00><00>
013750  045  116  045       P.AGY:  .ASCII  /%N%/
013753  101  052  040               .ASCII  /A* /
013756  114  102  116               .ASCII  /LBN/
013761  072  040  045               .ASCII  /: %/
013764  117  066  045               .ASCII  /O6%/
013767  101  040  045               .ASCII  /A %/
013772  117  066  045               .ASCII  /O6%/
013775  101  040  040               .ASCII  /A  /
014000  050  117  103               .ASCII  /(OC/
014003  124  101  114               .ASCII  /TAL/
014006  051  000                    .ASCII  /)/<00>
014010  045  116  045       P.AGZ:  .ASCII  /%N%/
014013  101  052  040               .ASCII  /A* /
014016  120  102  116               .ASCII  /PBN/
014021  072  040  045               .ASCII  /: %/
014024  117  066  045               .ASCII  /O6%/
014027  101  040  045               .ASCII  /A %/
014032  117  066  045               .ASCII  /O6%/
014035  101  040  040               .ASCII  /A  /
014040  050  117  103               .ASCII  /(OC/
014043  124  101  114               .ASCII  /TAL/
014046  051  000                    .ASCII  /)/<00>
```

```
014050  045  116  045  P.AHA:  .ASCII  /%N%/
014053  101  052  040          .ASCII  /A* /
014056  114  102  116          .ASCII  /LBN/
014061  040  122  105          .ASCII  / RE/
014064  101  104  072          .ASCII  /AD:/
014067  040  045  117          .ASCII  / %O/
014072  066  045  101          .ASCII  /6%A/
014075  040  045  117          .ASCII  / %O/
014100  066  045  101          .ASCII  /6%A/
014103  040  040  050          .ASCII  /  (/
014106  117  103  124          .ASCII  /OCT/
014111  101  114  051          .ASCII  /AL)/
014114  000  000               .ASCII  <00><00>
014116  045  116  045  P.AHB:  .ASCII  /%N%/
014121  101  052  040          .ASCII  /A* /
014124  114  102  116          .ASCII  /LBN/
014127  040  127  122          .ASCII  / WR/
014132  111  124  124          .ASCII  /ITT/
014135  105  116  072          .ASCII  /EN:/
014140  040  045  117          .ASCII  / %O/
014143  066  045  101          .ASCII  /6%A/
014146  040  045  117          .ASCII  / %O/
014151  066  045  101          .ASCII  /6%A/
014154  040  040  050          .ASCII  /  (/
014157  117  103  124          .ASCII  /OCT/
014162  101  114  051          .ASCII  /AL)/
014165  000                    .ASCII  <00>
014166  045  116  045  P.AHC:  .ASCII  /%N%/
014171  101  052  040          .ASCII  /A* /
014174  122  102  116          .ASCII  /RBN/
014177  072  040  045          .ASCII  /: %/
014202  117  066  045          .ASCII  /O6%/
014205  101  040  045          .ASCII  /A %/
014210  117  066  045          .ASCII  /O6%/
014213  101  040  040          .ASCII  /A  /
014216  050  117  103          .ASCII  /(OC/
014221  124  101  114          .ASCII  /TAL/
014224  051  000               .ASCII  /)/<00>
014226  045  116  045  P.AHD:  .ASCII  /%N%/
014231  101  052  040          .ASCII  /A* /
014234  102  131  124          .ASCII  /BYT/
014237  105  040  103          .ASCII  /E C/
014242  117  125  116          .ASCII  /OUN/
014245  124  040  111          .ASCII  /T I/
014250  116  040  103          .ASCII  /N C/
014253  117  115  115          .ASCII  /OMM/
014256  101  116  104          .ASCII  /AND/
014261  072  040  045          .ASCII  /: %/
014264  104  065  045          .ASCII  /D5%/
014267  101  056  000          .ASCII  /A./<00>
014272  045  116  045  P.AHE:  .ASCII  /%N%/
014275  101  052  040          .ASCII  /A* /
014300  102  131  124          .ASCII  /BYT/
```

```
014303  105  040  103                .ASCII  /E C/
014306  117  125  116                .ASCII  /OUN/
014311  124  040  111                .ASCII  /T I/
014314  116  040  122                .ASCII  /N R/
014317  105  101  104                .ASCII  /EAD/
014322  040  103  117                .ASCII  / CO/
014325  115  115  101                .ASCII  /MMA/
014330  116  104  072                .ASCII  /ND:/
014333  040  045  104                .ASCII  / %D/
014336  065  045  101                .ASCII  /5%A/
014341  056  000  000                .ASCII  /./<00><00>
014344  045  116  045  P.AHF:        .ASCII  /%N%/
014347  101  052  040                .ASCII  /A* /
014352  102  131  124                .ASCII  /BYT/
014355  105  040  103                .ASCII  /E C/
014360  117  125  116                .ASCII  /OUN/
014363  124  040  111                .ASCII  /T I/
014366  116  040  127                .ASCII  /N W/
014371  122  111  124                .ASCII  /RIT/
014374  105  040  103                .ASCII  /E C/
014377  117  115  115                .ASCII  /OMM/
014402  101  116  104                .ASCII  /AND/
014405  072  040  045                .ASCII  /: %/
014410  104  065  045                .ASCII  /D5%/
014413  101  056  000                .ASCII  /A./<00>
014416  045  116  045  P.AHG:        .ASCII  /%N%/
014421  101  052  040                .ASCII  /A* /
014424  101  103  124                .ASCII  /ACT/
014427  125  101  114                .ASCII  /UAL/
014432  040  043  040                .ASCII  / # /
014435  117  106  040                .ASCII  /OF /
014440  102  131  124                .ASCII  /BYT/
014443  105  123  040                .ASCII  /ES /
014446  124  122  101                .ASCII  /TRA/
014451  116  123  106                .ASCII  /NSF/
014454  105  122  122                .ASCII  /ERR/
014457  105  104  072                .ASCII  /ED:/
014462  040  045  104                .ASCII  / %D/
014465  065  045  101                .ASCII  /5%A/
014470  056  000                     .ASCII  /./<00>
014472  045  116  045  P.AHH:        .ASCII  /%N%/
014475  101  052  040                .ASCII  /A* /
014500  111  057  117                .ASCII  /I/<57>/O/
014503  040  102  125                .ASCII  / BU/
014506  106  106  105                .ASCII  /FFE/
014511  122  040  101                .ASCII  /R A/
014514  104  104  122                .ASCII  /DDR/
014517  105  123  123                .ASCII  /ESS/
014522  040  050  063                .ASCII  / (3/
014525  062  040  142                .ASCII  /2 b/
014530  151  164  163                .ASCII  /its/
014533  051  072  040                .ASCII  /): /
014536  045  117  066                .ASCII  /%O6/
```

```
014541  045     101     040             .ASCII  /%A /
014544  045     117     066             .ASCII  /%06/
014547  000                             .ASCII  <00>
014550  045     116     045     P.AHI:  .ASCII  /%N%/
014553  101     052     040             .ASCII  /A* /
014556  111     057     117             .ASCII  /I/<57>/O/
014561  040     102     125             .ASCII  / BU/
014564  106     106     105             .ASCII  /FFE/
014567  122     040     101             .ASCII  /R A/
014572  104     104     122             .ASCII  /DDR/
014575  105     123     123             .ASCII  /ESS/
014600  040     106     117             .ASCII  / FO/
014603  122     040     122             .ASCII  /R R/
014606  105     101     104             .ASCII  /EAD/
014611  040     050     063             .ASCII  / (3/
014614  062     040     142             .ASCII  /2 b/
014617  151     164     163             .ASCII  /its/
014622  051     072     040             .ASCII  /): /
014625  045     117     066             .ASCII  /%06/
014630  045     101     040             .ASCII  /%A /
014633  045     117     066             .ASCII  /%06/
014636  000     000                     .ASCII  <00><00>
014640  045     116     045     P.AHJ:  .ASCII  /%N%/
014643  101     052     040             .ASCII  /A* /
014646  111     057     117             .ASCII  /I/<57>/O/
014651  040     102     125             .ASCII  / BU/
014654  106     106     105             .ASCII  /FFE/
014657  122     040     101             .ASCII  /R A/
014662  104     104     122             .ASCII  /DDR/
014665  105     123     123             .ASCII  /ESS/
014670  040     106     117             .ASCII  / FO/
014673  122     040     127             .ASCII  /R W/
014676  122     111     124             .ASCII  /RIT/
014701  105     040     050             .ASCII  /E (/
014704  063     062     040             .ASCII  /32 /
014707  142     151     164             .ASCII  /bit/
014712  163     051     072             .ASCII  /s):/
014715  040     045     117             .ASCII  / %O/
014720  066     045     101             .ASCII  /6%A/
014723  040     045     117             .ASCII  / %O/
014726  066     000                     .ASCII  /6/<00>
014730  045     116     045     P.AHK:  .ASCII  /%N%/
014733  101     103     117             .ASCII  /ACO/
014736  116     124     105             .ASCII  /NTE/
014741  116     124     123             .ASCII  /NTS/
014744  040     117     106             .ASCII  / OF/
014747  040     103     117             .ASCII  / CO/
014752  115     115     101             .ASCII  /MMA/
014755  116     104     057             .ASCII  /ND/<57>
014760  122     105     123             .ASCII  /RES/
014763  120     117     116             .ASCII  /PON/
014766  123     105     040             .ASCII  /SE /
014771  120     101     103             .ASCII  /PAC/
```

```
014774  113  105  124                .ASCII  /KET/
014777  040  123  101                .ASCII  / SA/
015002  126  105  040                .ASCII  /VE /
015005  101  122  105                .ASCII  /ARE/
015010  101  072  045                .ASCII  /A %/
015013  116  000  000                .ASCII  /N/<00><00>
015016  045  101  040  P.AHL:        .ASCII  /%A /
015021  045  117  066                .ASCII  /%06/
015024  000  000                     .ASCII  <00><00>
015026  045  116  045  P.AHM:        .ASCII  /%N%/
015031  101  124  111                .ASCII  /ATI/
015034  115  105  072                .ASCII  /ME:/
015037  040  045  132                .ASCII  / %Z/
015042  062  045  101                .ASCII  /2%A/
015045  072  045  132                .ASCII  /:%Z/
015050  062  045  101                .ASCII  /2%A/
015053  040  110  117                .ASCII  / HO/
015056  125  122  123                .ASCII  /URS/
015061  045  116  000                .ASCII  /%N/<00>
015064  045  116  045  P.AHN:        .ASCII  /%N%/
015067  101  052  040                .ASCII  /A* /
015072  102  101  104                .ASCII  /BAD/
015075  040  114  102                .ASCII  / LB/
015100  116  072  040                .ASCII  /N: /
015103  045  117  066                .ASCII  /%06/
015106  045  101  040                .ASCII  /%A /
015111  045  117  066                .ASCII  /%06/
015114  045  101  040                .ASCII  /%A /
015117  040  050  117                .ASCII  / (O/
015122  103  124  101                .ASCII  /CTA/
015125  114  051  000                .ASCII  /L)/<00>
015130  045  116  045  P.AHO:        .ASCII  /%N%/
015133  101  040  052                .ASCII  /A *
015136  040  104  111                .ASCII  / DI/
015141  123  113  040                .ASCII  /SK /
015144  072  040  045                .ASCII  /: %/
015147  104  062  000                .ASCII  /D2/<00>
015152  045  116  045  P.AHP:        .ASCII  /%N%/
015155  101  104  102                .ASCII  /ADB/
015160  116  072  040                .ASCII  /N: /
015163  045  104  065                 ASCII  /%D5/
015166  045  101  056                .ASCII  /%A./
015171  040  050  117                .ASCII  / (O/
015174  103  124  040                .ASCII  /CT /
015177  045  117  066                .ASCII  /%06/
015202  045  101  051                .ASCII  /%A)/
015205  000                         .ASCII  <00>
015206  045  116  045  P.AHQ:        .ASCII  /%N%/
015211  101  102  131                .ASCII  /ABY/
015214  124  105  040                .ASCII  /TE /
015217  116  125  115                .ASCII  /NUM/
015222  102  105  122                .ASCII  /BER/
015225  072  040  045                .ASCII  /: %/
```

```
015230  104  063  000                .ASCII  /D3/<00>
015233  000                         .ASCII  <00>
015234  045  116  045       P.AHR:   .ASCII  /%N%/
015237  101  122  101                .ASCII  /ARA/
015242  116  104  117                .ASCII  /NDO/
015245  115  040  127                .ASCII  /M W/
015250  122  111  124                .ASCII  /RIT/
015253  124  105  116                .ASCII  /TEN/
015256  040  127  117                .ASCII  / WO/
015261  122  104  040                .ASCII  /RD /
015264  072  045  102                .ASCII  /:%B/
015267  061  066  000                .ASCII  /16/<00>
015272  045  116  045       P.AHS:   .ASCII  /%N%/
015275  101  122  101                .ASCII  /ARA/
015300  116  104  117                .ASCII  /NDO/
015303  115  040  122                .ASCII  /M R/
015306  105  101  104                .ASCII  /EAD/
015311  040  127  117                .ASCII  / WO/
015314  122  104  040                .ASCII  /RD /
015317  142  151  156                .ASCII  /bin/
015322  072  045  102                .ASCII  /:%B/
015325  061  066  045                .ASCII  /16%/
015330  101  040  157                .ASCII  /A o/
015333  143  164  072                .ASCII  /ct:/
015336  045  117  066                .ASCII  /%O6/
015341  000                         .ASCII  <00>
015342  045  116  045       P.AHT:   .ASCII  /%N%/
015345  101  104  125                .ASCII  /ADU/
015350  120  114  111                .ASCII  /PLI/
015353  103  101  124                .ASCII  /CAT/
015356  105  040  125                .ASCII  /E U/
015361  116  111  124                .ASCII  /NIT/
015364  072  045  104                .ASCII  /:%D/
015367  062  045  101                .ASCII  /2%A/
015372  040  101  124                .ASCII  / AT/
015375  040  111  120                .ASCII  / IP/
015400  072  040  045                .ASCII  /: %/
015403  117  066  000                .ASCII  /O6/<00>
015406  045  116  045       P.AHU:   .ASCII  /%N%/
015411  101  115  117                .ASCII  /AMO/
015414  122  105  040                .ASCII  /RE /
015417  124  110  101                .ASCII  /THA/
015422  116  040  045                .ASCII  /N %/
015425  104  061  045                .ASCII  /D1%/
015430  101  040  104                .ASCII  /A D/
015433  111  106  106                .ASCII  /IFF/
015436  105  122  105                .ASCII  /ERE/
015441  116  124  040                .ASCII  /NT /
015444  111  120  040                .ASCII  /IP /
015447  101  104  104                .ASCII  /ADD/
015452  122  105  123                .ASCII  /RES/
015455  123  105  123                .ASCII  /SES/
015460  000  000                     .ASCII  <00><00>
```

```
015462  045  101  123        P.AHV:  .ASCII  /%AS/
015465  120  111  116                .ASCII  /PIN/
015470  055  104  117                .ASCII  /-DO/
015473  127  116  040                .ASCII  /WN /
015476  111  107  116                .ASCII  /IGN/
015501  117  122  105                .ASCII  /ORE/
015504  104  000                     .ASCII  /D/<00>
015506  045  101  123        P.AHW:  .ASCII  /%AS/
015511  124  111  114                .ASCII  /TIL/
015514  114  040  103                .ASCII  /L C/
015517  117  116  116                .ASCII  /ONN/
015522  105  103  124                .ASCII  /ECT/
015525  105  104  000                .ASCII  /ED/<00>
015530  045  101  104        P.AHX:  .ASCII  /%AD/
015533  125  120  114                .ASCII  /UPL/
015536  111  103  101                .ASCII  /ICA/
015541  124  105  040                .ASCII  /TE /
015544  125  116  111                .ASCII  /UNI/
015547  124  040  116                .ASCII  /T N/
015552  125  115  102                .ASCII  /UMB/
015555  105  122  000                .ASCII  /ER/<00>
015560  045  101  101        P.AHY:  .ASCII  /%AA/
015563  114  122  105                .ASCII  /LRE/
015566  101  104  131                .ASCII  /ADY/
015571  040  117  116                .ASCII  / ON/
015574  114  111  116                .ASCII  /LIN/
015577  105  000  000                .ASCII  /E/<00><00>
015602  045  101  123        P.AHZ:  .ASCII  /%AS/
015605  124  111  114                .ASCII  /TIL/
015610  114  040  117                .ASCII  /L O/
015613  116  114  111                .ASCII  /NLI/
015616  116  105  000                .ASCII  /NE/<00>
015621  000                         .ASCII  <00>
015622  045  101  111        P.AIA:  .ASCII  /%AI/
015625  116  103  117                .ASCII  /NCO/
015630  115  120  114                .ASCII  /MPL/
015633  105  124  105                .ASCII  /ETE/
015636  040  122  105                .ASCII  / RE/
015641  120  114  101                .ASCII  /PLA/
015644  103  105  115                .ASCII  /CEM/
015647  105  116  124                .ASCII  /ENT/
015652  000  000                     .ASCII  <00><00>
015654  045  101  111        P.AIB:  .ASCII  /%AI/
015657  116  126  101                .ASCII  /NVA/
015662  114  111  104                .ASCII  /LID/
015665  040  122  103                .ASCII  / RC/
015670  124  000                     .ASCII  /T/<00>
015672  045  101  125        P.AIC:  .ASCII  /%AU/
015675  116  111  124                .ASCII  /NIT/
015700  040  125  116                .ASCII  / UN/
015703  113  116  117                .ASCII  /KNO/
015706  127  116  040                .ASCII  /WN /
015711  117  122  040                .ASCII  /OR /
```

```
015714  117  116  114                .ASCII  /ONL/
015717  111  116  105                .ASCII  /INE/
015722  040  124  117                .ASCII  / TO/
015725  040  101  116                .ASCII  / AN/
015730  117  124  110                .ASCII  /OTH/
015733  105  122  040                .ASCII  /ER /
015736  103  117  116                .ASCII  /CON/
015741  124  122  117                .ASCII  /TRO/
015744  114  114  105                .ASCII  /LLE/
015747  122  000  000                .ASCII  /R/<00><00>
015752  045  101  116  P.AID:        .ASCII  /%AN/
015755  117  040  126                .ASCII  /O V/
015760  117  114  125                .ASCII  /OLU/
015763  115  105  040                .ASCII  /ME /
015766  115  117  125                .ASCII  /MOU/
015771  116  124  105                .ASCII  /NTE/
015774  104  040  117                .ASCII  /D O/
015777  122  040  104                .ASCII  /R D/
016002  122  111  126                .ASCII  /RIV/
016005  105  040  104                .ASCII  /E D/
016010  111  123  101                .ASCII  /ISA/
016013  102  114  105                .ASCII  /BLE/
016016  104  040  102                .ASCII  /D B/
016021  131  040  123                .ASCII  /Y S/
016024  127  111  124                .ASCII  /WIT/
016027  103  110  000                .ASCII  /CH/<00>
016032  045  101  125  P.AIE:        .ASCII  /%AU/
016035  116  111  124                .ASCII  /NIT/
016040  040  111  116                .ASCII  / IN/
016043  117  120  105                .ASCII  /OPE/
016046  122  101  124                .ASCII  /RAT/
016051  111  126  105                .ASCII  /IVE/
016054  040  050  122                .ASCII  / (R/
016057  104  065  061                .ASCII  /D51/
016062  057  065  062                .ASCII  <57>/52/
016065  040  167  162                .ASCII  / wr/
016070  151  164  145                .ASCII  /ite/
016073  040  146  141                .ASCII  / fa/
016076  165  154  164                .ASCII  /ult/
016101  051  000  000                .ASCII  /)/<00><00>
016104  045  101  125  P.AIF:        .ASCII  /%AU/
016107  116  111  124                .ASCII  /NIT/
016112  040  104  111                .ASCII  / DI/
016115  123  101  102                .ASCII  /SAB/
016120  114  105  104                .ASCII  /LED/
016123  040  102  131                .ASCII  / BY/
016126  040  106  111                .ASCII  / FI/
016131  105  114  104                .ASCII  /ELD/
016134  040  123  105                .ASCII  / SE/
016137  122  126  111                .ASCII  /RVI/
016142  103  105  040                .ASCII  /CE /
016145  117  122  040                .ASCII  /OR /
016150  111  116  124                .ASCII  /INT/
```

```
016153  105     122     116             .ASCII  /ERN/
016156  101     114     040             .ASCII  /AL /
016161  104     111     101             .ASCII  /DIA/
016164  107     116     117             .ASCII  /GNO/
016167  123     124     111             .ASCII  /STI/
016172  103     123     000             .ASCII  /CS/<00>
016175  000                             .ASCII  <00>
016176  045     101     042     P.AIG:  .ASCII  /%A"/
016201  106     117     122             .ASCII  /FOR/
016204  103     105     104             .ASCII  /CED/
016207  040     105     122             .ASCII  / ER/
016212  122     117     122             .ASCII  /ROR/
016215  042     040     104             .ASCII  /" D/
016220  105     124     105             .ASCII  /ETE/
016223  103     124     105             .ASCII  /CTE/
016226  104     040     127             .ASCII  /D W/
016231  110     111     114             .ASCII  /HIL/
016234  105     040     101             .ASCII  /E A/
016237  103     103     105             .ASCII  /CCE/
016242  123     123     111             .ASCII  /SSI/
016245  116     107     040             .ASCII  /NG /
016250  106     103     124             .ASCII  /FCT/
016253  040     117     122             .ASCII  / OR/
016256  040     122     103             .ASCII  / RC/
016261  124     000     000             .ASCII  /T/<00><00>
016264  045     101     123     P.AIH:  .ASCII  /%AS/
016267  105     103     124             .ASCII  /ECT/
016272  117     122     040             .ASCII  /OR /
016275  110     101     104             .ASCII  /HAD/
016300  040     102     105             .ASCII  / BE/
016303  105     116     040             .ASCII  /EN /
016306  127     122     111             .ASCII  /WRI/
016311  124     124     105             .ASCII  /TTE/
016314  116     040     127             .ASCII  /N W/
016317  111     124     110             .ASCII  /ITH/
016322  040     042     106             .ASCII  / "F/
016325  117     122     103             .ASCII  /ORC/
016330  105     104     040             .ASCII  /ED /
016333  105     122     122             .ASCII  /ERR/
016336  117     122     042             .ASCII  /OR"/
016341  040     115     117             .ASCII  / MO/
016344  104     111     106             .ASCII  /DIF/
016347  111     105     122             .ASCII  /IER/
016352  000     000                     .ASCII  <00><00>
016354  045     101     106     P.AII:  .ASCII  /%AF/
016357  103     124     040             .ASCII  /CT /
016362  117     122     040             .ASCII  /OR /
016365  122     103     124             .ASCII  /RCT/
016370  040     125     116             .ASCII  / UN/
016373  122     105     101             .ASCII  /REA/
016376  104     101     102             .ASCII  /DAB/
016401  114     105     040             .ASCII  /LE /
016404  055     040     111             .ASCII  /- I/
```

```
016407  116  126  101              .ASCII  /NVA/
016412  114  111  104              .ASCII  /LID/
016415  040  123  105              .ASCII  / SE/
016420  103  124  117              .ASCII  /CTO/
016423  122  040  110              .ASCII  /R H/
016426  105  101  104              .ASCII  /EAD/
016431  105  122  000              .ASCII  /ER/<00>
016434  045  101  110    P.AIJ:    .ASCII  /%AH/
016437  105  101  104              .ASCII  /EAD/
016442  105  122  040              .ASCII  /ER /
016445  103  117  115              .ASCII  /COM/
016450  120  101  122              .ASCII  /PAR/
016453  105  040  105              .ASCII  /E E/
016456  122  122  117              .ASCII  /RRO/
016461  122  040  050              .ASCII  /R (/
016464  126  141  154              .ASCII  /Val/
016467  151  144  040              .ASCII  /id /
016472  150  145  141              .ASCII  /hea/
016475  144  145  162              .ASCII  /der/
016500  040  156  157              .ASCII  / no/
016503  164  040  146              .ASCII  /t f/
016506  157  165  156              .ASCII  /oun/
016511  144  051  000              .ASCII  /d)/<00>
016514  045  101  103    P.AIK:    .ASCII  /%AF/
016517  103  124  040              .ASCII  /CT /
016522  117  122  040              .ASCII  /OR /
016525  122  103  124              .ASCII  /RCT/
016530  040  125  116              .ASCII  / UN/
016533  122  105  101              .ASCII  /REA/
016536  104  101  102              .ASCII  /DAB/
016541  114  105  040              .ASCII  /LE /
016544  055  040  104              .ASCII  /- D/
016547  101  124  101              .ASCII  /ATA/
016552  040  123  131              .ASCII  / SY/
016555  116  103  040              .ASCII  /NC /
016560  124  111  115              .ASCII  /TIM/
016563  105  117  125              .ASCII  /EOU/
016566  124  000                   .ASCII  /T/<00>
016570  045  101  104    P.AIL:    .ASCII  /%AD/
016573  101  124  101              .ASCII  /ATA/
016576  040  123  131              .ASCII  / SY/
016601  116  103  040              .ASCII  /NC /
016604  116  117  124              .ASCII  /NOT/
016607  040  106  117              .ASCII  / FO/
016612  125  116  104              .ASCII  /UND/
016615  040  050  104              .ASCII  / (D/
016620  141  164  141              .ASCII  /ata/
016623  040  163  171              .ASCII  / sy/
016626  156  143  040              .ASCII  /nc /
016631  164  151  155              .ASCII  /tim/
016634  145  157  165              .ASCII  /eou/
016637  164  051  000              .ASCII  /t)/<00>
016642  045  101  106    P.AIM:    .ASCII  /%AF/
```

```
016645  103  124  040                .ASCII  /CT /
016650  117  122  040                .ASCII  /OR /
016653  122  103  124                .ASCII  /RCT/
016656  040  125  116                .ASCII  / UN/
016661  122  105  101                .ASCII  /REA/
016664  104  101  102                .ASCII  /DAB/
016667  114  105  040                .ASCII  /LE /
016672  055  040  125                .ASCII  /- U/
016675  116  103  117                .ASCII  /NCO/
016700  122  122  105                .ASCII  /RRE/
016703  103  124  101                .ASCII  /CTA/
016706  102  114  105                .ASCII  /BLE/
016711  040  105  103                .ASCII  / EC/
016714  103  040  105                .ASCII  /C E/
016717  122  122  117                .ASCII  /RRO/
016722  122  000                    .ASCII  /R/<00>
016724  045  101  125       P.AIN:   .ASCII  /%AU/
016727  116  103  117                .ASCII  /NCO/
016732  122  122  105                .ASCII  /RRE/
016735  103  124  101                .ASCII  /CTA/
016740  102  114  105                .ASCII  /BLE/
016743  040  105  103                .ASCII  / EC/
016746  103  040  105                .ASCII  /C E/
016751  122  122  117                .ASCII  /RRO/
016754  122  000                    .ASCII  /R/<00>
016756  045  101  122       P.AIO:   .ASCII  /%AR/
016761  103  124  040                .ASCII  /CT /
016764  103  117  122                .ASCII  /COR/
016767  122  125  120                .ASCII  /RUP/
016772  124  105  104                .ASCII  /TED/
016775  000                         .ASCII  <00>
016776  045  101  116       P.AIP:   .ASCII  /%AN/
017001  117  040  122                .ASCII  /O R/
017004  105  120  114                .ASCII  /EPL/
017007  101  103  105                .ASCII  /ACE/
017012  115  105  116                .ASCII  /MEN/
017015  124  040  102                .ASCII  /T B/
017020  114  117  103                .ASCII  /LOC/
017023  113  040  101                .ASCII  /K A/
017026  126  101  111                .ASCII  /VAI/
017031  114  101  102                .ASCII  /LAB/
017034  114  105  040                .ASCII  /LE /
017037  050  122  103                .ASCII  /(RC/
017042  124  040  146                .ASCII  /T f/
017045  165  154  154                .ASCII  /ull/
017050  051  000                    .ASCII  /)/<00>
017052  045  101  104       P.AIQ:   .ASCII  /%AD/
017055  111  123  113                .ASCII  /ISK/
017060  040  116  117                .ASCII  / NO/
017063  124  040  106                .ASCII  /T F/
017066  117  122  115                .ASCII  /ORM/
017071  101  124  124                .ASCII  /ATT/
017074  105  104  040                .ASCII  /ED /
```

```
017077  127  111  124              .ASCII  /WIT/
017102  110  040  065              .ASCII  /H 5/
017105  061  062  040              .ASCII  /12 /
017110  102  131  124              .ASCII  /BYT/
017113  105  040  123              .ASCII  /E S/
017116  105  103  124              .ASCII  /ECT/
017121  117  122  123              .ASCII  /ORS/
017124  000  000                   .ASCII  <00><00>
017126  045  101  104  P.AIR:      .ASCII  /%AD/
017131  111  123  113              .ASCII  /ISK/
017134  040  116  117              .ASCII  / NO/
017137  124  040  106              .ASCII  /T F/
017142  117  122  115              .ASCII  /ORM/
017145  101  124  124              .ASCII  /ATT/
017150  105  104  040              .ASCII  /ED /
017153  117  122  040              .ASCII  /OR /
017156  106  103  124              .ASCII  /FCT/
017161  040  103  117              .ASCII  / CO/
017164  122  122  125              .ASCII  /RRU/
017167  120  124  105              .ASCII  /PTE/
017172  104  000                   .ASCII  /D/<00>
017174  045  101  117  P.AIS:      .ASCII  /%AO/
017177  116  105  040              .ASCII  /NE /
017202  123  131  115              .ASCII  /SYM/
017205  102  117  114              .ASCII  /BOL/
017210  040  105  103              .ASCII  / EC/
017213  103  040  105              .ASCII  /C E/
017216  122  122  117              .ASCII  /RRO/
017221  122  000  000              .ASCII  /R/<00><00>
017224  045  101  124  P.AIT:      .ASCII  /%AT/
017227  127  117  040              .ASCII  /WO /
017232  123  131  115              .ASCII  /SYM/
017235  102  117  114              .ASCII  /BOL/
017240  040  105  103              .ASCII  / EC/
017243  103  040  105              .ASCII  /C E/
017246  122  122  117              .ASCII  /RRO/
017251  122  000  000              .ASCII  /R/<00><00>
017254  045  101  124  P.AIU:      .ASCII  /%AT/
017257  110  122  105              .ASCII  /HRE/
017262  105  040  123              .ASCII  /E S/
017265  131  115  102              .ASCII  /YMB/
017270  117  114  040              .ASCII  /OL /
017273  105  103  103              .ASCII  /ECC/
017276  040  105  122              .ASCII  / ER/
017301  122  117  122              .ASCII  /ROR/
017304  000  000                   .ASCII  <00><00>
017306  045  101  106  P.AIV:      .ASCII  /%AF/
017311  117  125  122              .ASCII  /OUR/
017314  040  123  131              .ASCII  / SY/
017317  115  102  117              .ASCII  /MBO/
017322  114  040  105              .ASCII  /L E/
017325  103  103  040              .ASCII  /CC /
017330  105  122  122              .ASCII  /ERR/
```

```
017333  117  122  000            .ASCII  /OR/<00>
017336  045  101  106  P.AIW:     .ASCII  /%AF/
017341  111  126  105            .ASCII  /IVE/
017344  040  123  131            .ASCII  / SY/
017347  115  102  117            .ASCII  /MBO/
017352  114  040  105            .ASCII  /L E/
017355  103  103  040            .ASCII  /CC /
017360  105  122  122            .ASCII  /ERR/
017363  117  122  000            .ASCII  /OR/<00>
017366  045  101  123  P.AIX:     .ASCII  /%AS/
017371  111  130  040            .ASCII  /IX /
017374  123  131  115            .ASCII  /SYM/
017377  102  117  114            .ASCII  /BOL/
017402  040  105  103            .ASCII  / EC/
017405  103  040  105            .ASCII  /C E/
017410  122  122  117            .ASCII  /RRO/
017413  122  000  000            .ASCII  /R/<00><00>
017416  045  101  123  P.AIY:     .ASCII  /%AS/
017421  105  126  105            .ASCII  /EVE/
017424  116  040  123            .ASCII  /N S/
017427  131  115  102            .ASCII  /YMB/
017432  117  114  040            .ASCII  /OL /
017435  105  103  103            .ASCII  /ECC/
017440  040  105  122            .ASCII  / ER/
017443  122  117  122            .ASCII  /ROR/
017446  000  000                 .ASCII  <00><00>
017450  045  101  105  P.AIZ:     .ASCII  /%AE/
017453  111  107  110            .ASCII  /IGH/
017456  124  040  123            .ASCII  /T S/
017461  131  115  102            .ASCII  /YMB/
017464  117  114  040            .ASCII  /OL /
017467  105  103  103            .ASCII  /ECC/
017472  040  105  122            .ASCII  / ER/
017475  122  117  122            .ASCII  /ROR/
017500  000  000                 .ASCII  <00><00>
017502  045  101  103  P.AJA:     .ASCII  /%AC/
017505  117  122  122            .ASCII  /ORR/
017510  105  103  124            .ASCII  /ECT/
017513  101  102  114            .ASCII  /ABL/
017516  105  040  105            .ASCII  /E E/
017521  122  122  117            .ASCII  /RRO/
017524  122  040  111            .ASCII  /R I/
017527  116  040  105            .ASCII  /N E/
017532  103  103  040            .ASCII  /CC /
017535  106  111  105            .ASCII  /FIE/
017540  114  104  000            .ASCII  /LD/<00>
017543  000                      .ASCII  <00>
017544  045  101  125  P.AJB:     .ASCII  /%AU/
017547  116  111  124            .ASCII  /NIT/
017552  040  123  117            .ASCII  / SO/
017555  106  124  127            .ASCII  /FTW/
017560  101  122  105            .ASCII  /ARE/
017563  040  127  122            .ASCII  / WR/
```

```
017566  111  124  105            .ASCII  /ITE/
017571  040  120  122            .ASCII  / PR/
017574  117  124  105            .ASCII  /OTE/
017577  103  124  105            .ASCII  /CTE/
017602  104  000                 .ASCII  /D/<00>
017604  045  101  125  P.AJC:     .ASCII  /%AU/
017607  116  111  124            .ASCII  /NIT/
017612  040  110  101            .ASCII  / HA/
017615  122  104  127            .ASCII  /RDW/
017620  101  122  105            .ASCII  /ARE/
017623  040  127  122            .ASCII  / WR/
017626  111  124  105            .ASCII  /ITE/
017631  040  120  122            .ASCII  / PR/
017634  117  124  105            .ASCII  /OTE/
017637  103  124  105            .ASCII  /CTE/
017642  104  000                 .ASCII  /D/<00>
017644  045  101  125  P.AJD:     .ASCII  /%AU/
017647  116  111  124            .ASCII  /NIT/
017652  040  104  101            .ASCII  / DA/
017655  124  101  040            .ASCII  /TA /
017660  123  101  106            .ASCII  /SAF/
017663  105  124  131            .ASCII  /ETY/
017666  040  127  122            .ASCII  / WR/
017671  111  124  105            .ASCII  /ITE/
017674  040  120  122            .ASCII  / PR/
017677  117  124  105            .ASCII  /OTE/
01770   103  124  105            .ASCII  /CTE/
017705  104  000  000            .ASCII  /D/<00><00>
017710  045  101  117  P.AJE:     .ASCII  /%AO/
017713  104  104  040            .ASCII  /DD /
017716  124  122  101            .ASCII  /TRA/
017721  116  123  106            .ASCII  /NSF/
017724  105  122  040            .ASCII  /ER /
017727  101  104  104            .ASCII  /ADD/
017732  122  105  123            .ASCII  /RES/
017735  123  000  000            .ASCII  /S/<00><00>
017740  045  101  117  P.AJF:     .ASCII  /%AO/
017743  104  104  040            .ASCII  /DD /
017746  102  131  124            .ASCII  /BYT/
017751  105  040  103            .ASCII  /E C/
017754  117  125  116            .ASCII  /OUN/
017757  124  000  000            .ASCII  /T/<00><00>
017762  045  101  116  P.AJG:     .ASCII  /%AN/
017765  117  116  055            .ASCII  /ON-/
017770  105  130  111            .ASCII  /EXI/
017773  123  124  105            .ASCII  /STE/
017776  116  124  040            .ASCII  /NT /
020001  110  117  123            .ASCII  /HOS/
020004  124  040  115            .ASCII  /T M/
020007  105  115  117            .ASCII  /EMO/
020012  122  131  000            .ASCII  /RY/<00>
020015  000                     .ASCII  <00>
020016  045  101  110  P.AJH:     .ASCII  /%AH/
```

```
020021  117     123     124             .ASCII  /OST/
020024  040     115     105             .ASCII  / ME/
020027  115     117     122             .ASCII  /MOR/
020032  131     040     120             .ASCII  /Y P/
020035  101     122     111             .ASCII  /ARI/
020040  124     131     040             .ASCII  /TY /
020043  105     122     122             .ASCII  /ERR/
020046  117     122     000             .ASCII  /OR/<00>
020051  000                             .ASCII  <00>
020052  045     101     103     P.AJI:  .ASCII  /%AC/
020055  117     115     115             .ASCII  /OMM/
020060  101     116     104             .ASCII  /AND/
020063  040     124     111             .ASCII  / TI/
020066  115     117     125             .ASCII  /MOU/
020071  124     040     117             .ASCII  /T O/
020074  122     040     122             .ASCII  /R R/
020077  105     124     122             .ASCII  /ETR/
020102  131     040     114             .ASCII  /Y L/
020105  111     115     111             .ASCII  /IMI/
020110  124     040     105             .ASCII  /T E/
020113  130     103     105             .ASCII  /XCE/
020116  105     104     105             .ASCII  /EDE/
020121  104     000     000             .ASCII  /D/<00><00>
020124  045     101     123     P.AJJ:  .ASCII  /%AS/
020127  105     122     111             .ASCII  /ERI/
020132  101     114     111             .ASCII  /ALI/
020135  132     105     122             .ASCII  /ZER/
020140  057     104     105             .ASCII  <57>/DE/
020143  123     105     122             .ASCII  /SER/
020146  111     101     114             .ASCII  /IAL/
020151  111     132     105             .ASCII  /IZE/
020154  122     040     117             .ASCII  /R O/
020157  126     105     122             .ASCII  /VER/
020162  122     125     116             .ASCII  /RUN/
020165  040     117     122             .ASCII  / OR/
020170  040     125     116             .ASCII  / UN/
020173  104     105     122             .ASCII  /DER/
020176  122     125     116             .ASCII  /RUN/
020201  000                             .ASCII  <00>
020202  045     101     042     P.AJK:  .ASCII  /%A"/
020205  105     122     122             .ASCII  /ERR/
020210  117     122     040             .ASCII  /OR /
020213  104     105     124             .ASCII  /DET/
020216  105     103     124             .ASCII  /ECT/
020221  111     117     116             .ASCII  /ION/
020224  040     103     117             .ASCII  / CO/
020227  104     105     042             .ASCII  /DE"/
020232  040     105     122             .ASCII  / ER/
020235  122     117     122             .ASCII  /ROR/
020240  000     000                     .ASCII  <00><00>
020242  045     101     111     P.AJL:  .ASCII  /%AI/
020245  116     103     117             .ASCII  /NCO/
020250  116     123     111             .ASCII  /NSI/
```

```
020253  123  124  105                .ASCII  /STE/
020256  116  124  040                .ASCII  /NT /
020261  111  116  124                .ASCII  /INT/
020264  105  122  116                .ASCII  /ERN/
020267  101  114  040                .ASCII  /AL /
020272  104  101  124                .ASCII  /DAT/
020275  101  040  123                .ASCII  /A S/
020300  124  122  125                .ASCII  /TRU/
020303  103  124  125                .ASCII  /CTU/
020306  122  105  000                .ASCII  /RE/<00>
020311  000                        .ASCII  <00>
020312  045  101  104        P.AJM:  .ASCII  /%AD/
020315  122  111  126                .ASCII  /RIV/
020320  105  040  103                .ASCII  /E C/
020323  117  115  115                .ASCII  /OMM/
020326  101  116  104                .ASCII  /AND/
020331  040  124  111                .ASCII  / TI/
020334  115  105  117                .ASCII  /MEO/
020337  125  124  040                .ASCII  /UT /
020342  050  116  157                .ASCII  /(No/
020345  040  162  145                .ASCII  / re/
020350  163  160  157                .ASCII  /spo/
020353  156  163  145                .ASCII  /nse/
020356  040  157  162                .ASCII  / or/
020361  040  163  145                .ASCII  / se/
020364  145  153  040                .ASCII  /ek /
020367  151  156  143                .ASCII  /inc/
020372  157  155  160                .ASCII  /omp/
020375  154  145  164                .ASCII  /let/
020400  145  051  000                .ASCII  /e)/<00>
020403  000                        .ASCII  <00>
020404  045  101  103        P.AJN:  .ASCII  /%AC/
020407  117  116  124                .ASCII  /ONT/
020412  122  117  114                .ASCII  /ROL/
020415  114  105  122                .ASCII  /LER/
020420  040  104  105                .ASCII  / DE/
020423  124  105  103                .ASCII  /TEC/
020426  124  105  104                .ASCII  /TED/
020431  040  124  122                .ASCII  / TR/
020434  101  116  123                .ASCII  /ANS/
020437  115  111  123                .ASCII  /MIS/
020442  123  111  117                .ASCII  /SIO/
020445  116  040  117                .ASCII  /N O/
020450  122  040  120                .ASCII  /R P/
020453  122  117  124                .ASCII  /ROT/
020456  117  103  117                .ASCII  /OCO/
020461  114  040  105                .ASCII  /L E/
020464  122  122  117                .ASCII  /RRO/
020467  122  000  000                .ASCII  /R/<00><00>
020472  045  101  120        P.AJO:  .ASCII  /%AP/
020475  117  123  111                .ASCII  /OSI/
020500  124  111  117                .ASCII  /TIO/
020503  116  040  105                .ASCII  /N E/
```

```
020506  122     122     117             .ASCII  /RRO/
020511  122     040     050             .ASCII  /R (/
020514  115     151     163             .ASCII  /Mis/
020517  055     163     145             .ASCII  /-se/
020522  145     153     051             .ASCII  /ek)/
020525  000                             .ASCII  <00>
020526  045     101     114     P.AJP:  .ASCII  /%AL/
020531  117     123     124             .ASCII  /OST/
020534  040     122     105             .ASCII  / RE/
020537  101     104     057             .ASCII  /AD/<57>
020542  127     122     111             .ASCII  /WRI/
020545  124     105     040             .ASCII  /TE /
020550  122     105     101             .ASCII  /REA/
020553  104     131     040             .ASCII  /DY /
020556  104     125     122             .ASCII  /DUR/
020561  111     116     107             .ASCII  /ING/
020564  057     102     105             .ASCII  <57>/BE/
020567  124     127     105             .ASCII  /TWE/
020572  105     116     040             .ASCII  /EN /
020575  124     122     101             .ASCII  /TRA/
020600  116     123     106             .ASCII  /NSF/
020603  105     122     123             .ASCII  /ERS/
020606  000     000                     .ASCII  <00><00>
020610  045     101     104     P.AJQ:  .ASCII  /%AD/
020613  122     111     126             .ASCII  /RIV/
020616  105     040     103             .ASCII  /E C/
020621  114     117     103             .ASCII  /LOC/
020624  113     040     104             .ASCII  /K D/
020627  122     117     120             .ASCII  /ROP/
020632  117     125     124             .ASCII  /OUT/
020635  000                             .ASCII  <00>
020636  045     101     114     P.AJR:  .ASCII  /%AL/
020641  117     123     124             .ASCII  /OST/
020644  040     122     105             .ASCII  / RE/
020647  103     105     111             .ASCII  /CEI/
020652  126     105     122             .ASCII  /VER/
020655  040     122     105             .ASCII  / RE/
020660  101     104     131             .ASCII  /ADY/
020663  040     102     105             .ASCII  / BE/
020666  124     127     105             .ASCII  /TWE/
020671  105     116     040             .ASCII  /EN /
020674  123     105     103             .ASCII  /SEC/
020677  124     117     122             .ASCII  /TOR/
020702  123     000                     .ASCII  /S/<00>
020704  045     101     104     P.AJS:  .ASCII  /%AD/
020707  122     111     126             .ASCII  /RIV/
020712  105     040     104             .ASCII  /E D/
020715  105     124     105             .ASCII  /ETE/
020720  103     124     105             .ASCII  /CTE/
020723  104     040     105             .ASCII  /D E/
020726  122     122     117             .ASCII  /RRO/
020731  122     000     000             .ASCII  /R/<00><00>
020734  045     101     103     P.AJT:  .ASCII  /%AC/
```

```
020737  117     116     124                     .ASCII  /ONT/
020742  122     117     114                     .ASCII  /ROL/
020745  114     105     122                     .ASCII  /LER/
020750  040     104     105                     .ASCII  / DE/
020753  124     105     103                     .ASCII  /TEC/
020756  124     105     104                     .ASCII  /TED/
020761  040     120     125                     .ASCII  / PU/
020764  114     123     105                     .ASCII  /LSE/
020767  040     117     122                     .ASCII  / OR/
020772  040     123     124                     .ASCII  / ST/
020775  101     124     105                     .ASCII  /ATE/
021000  040     120     101                     .ASCII  / PA/
021003  122     111     124                     .ASCII  /RIT/
021006  131     040     105                     .ASCII  /Y E/
021011  122     122     117                     .ASCII  /RRO/
021014  122     000                             .ASCII  /R/<00>
021016  045     101     102             P.AJU:  .ASCII  /≠AB/
021021  101     104     040                     .ASCII  /AD /
021024  102     114     117                     .ASCII  /BLO/
021027  103     113     040                     .ASCII  /CK /
021032  123     125     103                     .ASCII  /SUC/
021035  103     105     123                     .ASCII  /CES/
021040  123     106     125                     .ASCII  /SFU/
021043  114     114     131                     .ASCII  /LLY/
021046  040     122     105                     .ASCII  / RE/
021051  120     114     101                     .ASCII  /PLA/
021054  103     105     104                     .ASCII  /CED/
021057  000                                     .ASCII  <00>
021060  045     101     102             P.AJV:  .ASCII  /≠AB/
021063  114     117     103                     .ASCII  /LOC/
021066  113     040     126                     .ASCII  /K V/
021071  105     122     111                     .ASCII  /ERI/
021074  106     111     105                     .ASCII  /FIE/
021077  104     040     117                     .ASCII  /D O/
021102  113     040     055                     .ASCII  /K -/
021105  055     040     116                     .ASCII  /- N/
021110  117     124     040                     .ASCII  /OT /
021113  101     040     102                     .ASCII  /A B/
021116  101     104     040                     .ASCII  /AD /
021121  102     114     117                     .ASCII  /BLO/
021124  103     113     000                     .ASCII  /CK/<00>
021127  000                                     .ASCII  <00>
021130  045     101     122             P.AJW:  .ASCII  /≠AR/
021133  105     120     114                     .ASCII  /EPL/
021136  101     103     105                     .ASCII  /ACE/
021141  115     105     116                     .ASCII  /MEN/
021144  124     040     106                     .ASCII  /T F/
021147  101     111     114                     .ASCII  /AIL/
021152  125     122     105                     .ASCII  /URE/
021155  000                                     .ASCII  <00>
021156  045     101     103             P.AJY:  .ASCII  /≠AC/
021161  117     116     124                     .ASCII  /ONT/
021164  122     117     114                     .ASCII  /ROL/
```

```
021167  114     105     122             .ASCII  /LER/
021172  040     124     111             .ASCII  / TI/
021175  115     105     117             .ASCII  /MEO/
021200  125     124     000             .ASCII  /UT/<00>
021203  000                             .ASCII  <00>
021204  045     101     105     P.AJZ:  .ASCII  /%AE/
021207  116     126     105             .ASCII  /NVE/
021212  114     117     120             .ASCII  /LOP/
021215  105     057     120             .ASCII  /E/<57>/P/
021220  101     103     113             .ASCII  /ACK/
021223  105     124     040             .ASCII  /ET /
021226  122     105     101             .ASCII  /REA/
021231  104     040     105             .ASCII  /D E/
021234  122     122     117             .ASCII  /RRO/
021237  122     040     050             .ASCII  /R (/
021242  120     141     162             .ASCII  /Par/
021245  151     164     171             .ASCII  /ity/
021250  040     157     162             .ASCII  / or/
021253  040     164     151             .ASCII  / ti/
021256  155     145     157             .ASCII  /meo/
021261  165     164     051             .ASCII  /ut)/
021264  000     000                     .ASCII  <00><00>
021266  045     101     105     P.AKA:  .ASCII  /%AE/
021271  116     126     105             .ASCII  /NVE/
021274  114     117     120             .ASCII  /LOP/
021277  105     057     120             .ASCII  /E/<57>/P/
021302  101     103     113             .ASCII  /ACK/
021305  105     124     040             .ASCII  /ET /
021310  127     122     111             .ASCII  /WRI/
021313  124     105     040             .ASCII  /TE /
021316  105     122     122             .ASCII  /ERR/
021321  117     122     040             .ASCII  /OR /
021324  050     120     141             .ASCII  /(Pa/
021327  162     151     164             .ASCII  /rit/
021332  171     040     157             .ASCII  /y o/
021335  162     040     164             .ASCII  /r t/
021340  151     155     145             .ASCII  /ime/
021343  157     165     164             .ASCII  /out/
021346  051     000                     .ASCII  /)/<00>
021350  045     101     103     P.AKB:  .ASCII  /%AC/
021353  117     116     124             .ASCII  /ONT/
021356  122     117     114             .ASCII  /ROL/
021361  114     105     122             .ASCII  /LER/
021364  040     122     117             .ASCII  / RO/
021367  115     040     101             .ASCII  /M A/
021372  116     104     040             .ASCII  /ND /
021375  122     101     115             .ASCII  /RAM/
021400  040     120     101             .ASCII  / PA/
021403  122     111     124             .ASCII  /RIT/
021406  131     040     105             .ASCII  /Y E/
021411  122     122     117             .ASCII  /RRO/
021414  122     000                     .ASCII  /R/<00>
021416  045     101     103     P.AKC:  .ASCII  /%AC/
```

```
021421  117     116     124             .ASCII  /ONT/
021424  122     117     114             .ASCII  /ROL/
021427  114     105     122             .ASCII  /LER/
021432  040     122     101             .ASCII  / RA/
021435  115     040     120             .ASCII  /M P/
021440  101     122     111             .ASCII  /ARI/
021443  124     131     040             .ASCII  /TY /
021446  105     122     122             .ASCII  /ERR/
021451  117     122     000             .ASCII  /OR/<00>
021454  045     101     103     P.AKD:  .ASCII  /%AC/
021457  117     116     124             .ASCII  /ONT/
021462  122     117     114             .ASCII  /ROL/
021465  114     105     122             .ASCII  /LER/
021470  040     122     117             .ASCII  / RO/
021473  115     040     120             .ASCII  /M P/
021476  101     122     111             .ASCII  /ARI/
021501  124     131     040             .ASCII  /TY /
021504  105     122     122             .ASCII  /ERR/
021507  117     122     000             .ASCII  /OR/<00>
021512  045     101     122     P.AKE:  .ASCII  /%AR/
021515  111     116     107             .ASCII  /ING/
021520  040     122     105             .ASCII  / RE/
021523  101     104     040             .ASCII  /AD /
021526  105     122     122             .ASCII  /ERR/
021531  117     122     040             .ASCII  /OR /
021534  050     120     141             .ASCII  /(Pa/
021537  162     151     164             .ASCII  /rit/
021542  171     040     157             .ASCII  /y o/
021545  162     040     164             .ASCII  /r t/
021550  151     155     145             .ASCII  /ime/
021553  157     165     164             .ASCII  /out/
021556  051     000                     .ASCII  /)/<00>
021560  045     101     122     P.AKF:  .ASCII  /%AR/
021563  111     116     107             .ASCII  /ING/
021566  040     127     122             .ASCII  / WR/
021571  111     124     105             .ASCII  /ITE/
021574  040     105     122             .ASCII  / ER/
021577  122     117     122             .ASCII  /ROR/
021602  040     050     120             .ASCII  / (P/
021605  141     162     151             .ASCII  /ari/
021610  164     171     040             .ASCII  /ty /
021613  157     162     040             .ASCII  /or /
021616  164     151     155             .ASCII  /tim/
021621  145     157     165             .ASCII  /eou/
021624  164     051     000             .ASCII  /t)/<00>
021627  000                             .ASCII  <00>
021630  111     116     124     P.AKG:  .ASCII  /INT/
021633  105     122     122             .ASCII  /ERR/
021636  125     120     124             .ASCII  /UPT/
021641  040     115     101             .ASCII  / MA/
021644  123     124     105             .ASCII  /STE/
021647  122     040     106             .ASCII  /R F/
021652  101     111     114             .ASCII  /AIL/
```

```
021655  125  122  105                .ASCII  /URE/
021660  000  000                     .ASCII  <00><00>
021662  045  101  110       P.AKH:    .ASCII  /%AH/
021665  117  123  124                 .ASCII  /OST/
021670  040  101  103                 .ASCII  / AC/
021673  103  105  123                 .ASCII  /CES/
021676  123  040  124                 .ASCII  /S T/
021701  111  115  105                 .ASCII  /IME/
021704  117  125  124                 .ASCII  /OUT/
021707  040  050  110                 .ASCII  / (H/
021712  151  147  150                 .ASCII  /igh/
021715  145  162  040                 .ASCII  /er /
021720  154  145  166                 .ASCII  /lev/
021723  145  154  040                 .ASCII  /el /
021726  160  162  157                 .ASCII  /pro/
021731  164  157  143                 .ASCII  /toc/
021734  157  154  040                 .ASCII  /ol /
021737  144  145  160                 .ASCII  /dep/
021742  145  156  144                 .ASCII  /end/
021745  145  156  164                 .ASCII  /ent/
021750  051  000                     .ASCII  /)/<00>
021752  045  101  103       P.AKI:    .ASCII  /%AC/
021755  122  105  104                 .ASCII  /RED/
021760  111  124  040                 .ASCII  /IT /
021763  114  111  115                 .ASCII  /LIM/
021766  111  124  040                 .ASCII  /IT /
021771  105  130  103                 .ASCII  /EXC/
021774  105  105  104                 .ASCII  /EED/
021777  105  104  000                 .ASCII  /ED/<00>
022002  045  101  121       P.AKJ:    .ASCII  /%AQ/
022005  055  102  125                 .ASCII  /-BU/
022010  123  040  115                 .ASCII  /S M/
022013  101  123  124                 .ASCII  /AST/
022016  105  122  040                 .ASCII  /ER /
022021  105  122  122                 .ASCII  /ERR/
022024  117  122  000                 .ASCII  /OR/<00>
022027  000                         .ASCII  <00>
022030  045  101  103       P.AKK:    .ASCII  /%AC/
022033  117  116  124                 .ASCII  /ONT/
022036  122  117  114                 .ASCII  /ROL/
022041  114  105  122                 .ASCII  /LER/
022044  040  106  101                 .ASCII  / FA/
022047  124  101  114                 .ASCII  /TAL/
022052  040  105  122                 .ASCII  / ER/
022055  122  117  122                 .ASCII  /ROR/
022060  000  000                     .ASCII  <00><00>
022062  045  101  111       P.AKL:    .ASCII  /%AI/
022065  116  123  124                 .ASCII  /NST/
022070  122  125  103                 .ASCII  /RUC/
022073  124  111  117                 .ASCII  /TIO/
022076  116  040  114                 .ASCII  /N L/
022101  117  117  120                 .ASCII  /OOP/
022104  040  124  111                 .ASCII  / TI/
```

```
022107  115     105     117                     .ASCII  /MEO/
022112  125     124     000                     .ASCII  /UT/<00>
022115  000                                     .ASCII  <00>
022116  045     101     111     P.AKM:          .ASCII  /%AI/
022121  114     114     105                     .ASCII  /LLE/
022124  107     101     114                     .ASCII  /GAL/
022127  040     126     111                     .ASCII  / VI/
022132  122     124     125                     .ASCII  /RTU/
022135  101     114     040                     .ASCII  /AL /
022140  103     111     122                     .ASCII  /CIR/
022143  103     125     111                     .ASCII  /CUI/
022146  124     040     111                     .ASCII  /T I/
022151  104     000     000                     .ASCII  /D/<00><00>
022154  045     101     111     P.AKN:          .ASCII  /%AI/
022157  116     124     105                     .ASCII  /NTE/
022162  122     122     125                     .ASCII  /RRU/
022165  120     124     040                     .ASCII  /PT /
022170  126     105     103                     .ASCII  /VEC/
022173  124     117     122                     .ASCII  /TOR/
022176  040     111     114                     .ASCII  / IL/
022201  114     105     107                     .ASCII  /LEG/
022204  101     114     000                     .ASCII  /AL/<00>
022207  000                                     .ASCII  <00>
022210  045     101     115     P.AKO:          .ASCII  /%AM/
022213  101     111     116                     .ASCII  /AIN/
022216  124     105     116                     .ASCII  /TEN/
022221  101     116     103                     .ASCII  /ANC/
022224  105     040     122                     .ASCII  /E R/
022227  105     101     104                     .ASCII  /EAD/
022232  057     127     122                     .ASCII  <57>/WR/
022235  111     124     105                     .ASCII  /ITE/
022240  040     111     116                     .ASCII  / IN/
022243  126     101     114                     .ASCII  /VAL/
022246  111     104     040                     .ASCII  /ID /
022251  122     105     107                     .ASCII  /REG/
022254  111     117     116                     .ASCII  /ION/
022257  040     111     104                     .ASCII  / ID/
022262  105     116     124                     .ASCII  /ENT/
022265  111     106     111                     .ASCII  /IFI/
022270  105     122     000                     .ASCII  /ER/<00>
022273  000                                     .ASCII  <00>
022274  045     101     115     P.AKP:          .ASCII  /%AM/
022277  101     111     116                     .ASCII  /AIN/
022302  124     105     116                     .ASCII  /TEN/
022305  101     116     103                     .ASCII  /ANC/
022310  105     040     127                     .ASCII  /E W/
022313  122     111     124                     .ASCII  /RIT/
022316  105     040     114                     .ASCII  /E L/
022321  117     101     104                     .ASCII  /OAD/
022324  040     124     117                     .ASCII  / TO/
022327  040     116     117                     .ASCII  / NO/
022332  116     055     114                     .ASCII  /N-L/
022335  117     101     104                     .ASCII  /OAD/
```

```
022340  101  102  114            .ASCII  /ABL/
022343  105  040  103            .ASCII  /E C/
022346  117  116  124            .ASCII  /ONT/
022351  122  117  114            .ASCII  /ROL/
022354  114  105  122            .ASCII  /LER/
022357  000                      .ASCII  <00>
022360  045  101  103  P.AKQ:     .ASCII  /%AC/
022363  117  116  124            .ASCII  /ONT/
022366  122  117  114            .ASCII  /ROL/
022371  114  105  122            .ASCII  /LER/
022374  040  122  101            .ASCII  / RA/
022377  115  040  105            .ASCII  /M E/
022402  122  122  117            .ASCII  /RRO/
022405  122  040  050            .ASCII  /R (/
022410  116  157  156            .ASCII  /Non/
022413  055  160  141            .ASCII  /-pa/
022416  162  151  164            .ASCII  /rit/
022421  171  051  000            .ASCII  /y)/<00>
022424  045  101  111  P.AKR:     .ASCII  /%AI/
022427  116  111  124            .ASCII  /NIT/
022432  040  123  105            .ASCII  / SE/
022435  121  125  105            .ASCII  /QUE/
022440  116  103  105            .ASCII  /NCE/
022443  040  105  122            .ASCII  / ER/
022446  122  117  122            .ASCII  /ROR/
022451  000                      .ASCII  <00>
022452  045  101  110  P.AKS:     .ASCII  /%AH/
022455  111  107  110            .ASCII  /IGH/
022460  105  122  040            .ASCII  /ER /
022463  114  105  126            .ASCII  /LEV/
022466  105  114  040            .ASCII  /EL /
022471  120  122  117            .ASCII  /PRO/
022474  124  117  103            .ASCII  /TOC/
022477  117  114  040            .ASCII  /OL /
022502  111  116  103            .ASCII  /INC/
022505  117  115  120            .ASCII  /OMP/
022510  101  124  111            .ASCII  /ATI/
022513  102  111  114            .ASCII  /BIL/
022516  111  124  131            .ASCII  /ITY/
022521  040  105  122            .ASCII  / ER/
022524  122  117  122            .ASCII  /ROR/
022527  000                      .ASCII  <00>
022530  045  101  120  P.AKT:     .ASCII  /%AP/
022533  125  122  107            .ASCII  /URG/
022536  105  057  120            .ASCII  /E/<57>/P/
022541  117  114  114            .ASCII  /OLL/
022544  040  110  101            .ASCII  / HA/
022547  122  104  127            .ASCII  /RDW/
022552  101  122  105            .ASCII  /ARE/
022555  040  106  101            .ASCII  / FA/
022560  111  114  125            .ASCII  /ILU/
022563  122  105  000            .ASCII  /RE/<00>
022566  045  101  115  P.AKU:     .ASCII  /%AM/
```

```
022571      101     120     120                 .ASCII  /APP/
022574      111     116     107                 .ASCII  /ING/
022577      040     122     105                 .ASCII  / RE/
022602      107     111     123                 .ASCII  /GIS/
022605      124     105     122                 .ASCII  /TER/
022610      040     122     105                 .ASCII  / RE/
022613      101     104     040                 .ASCII  /AD /
022616      106     101     111                 .ASCII  /FAI/
022621      114     125     122                 .ASCII  /LUR/
022624      105     040     050                 .ASCII  /E (/
022627      120     141     162                 .ASCII  /Par/
022632      151     164     171                 .ASCII  /ity/
022635      040     157     162                 .ASCII  / or/
022640      040     164     151                 .ASCII  / ti/
022643      155     145     157                 .ASCII  /meo/
022646      165     164     051                 .ASCII  /ut)/
022651      000                                 .ASCII  <00>
022652  021156'                         P.AJX:  .WORD   P.AJY
022654  021204'                                 .WORD   P.AJZ
022656  021266'                                 .WORD   P.AKA
022660  021350'                                 .WORD   P.AKB
022662  021416'                                 .WORD   P.AKC
022664  021454'                                 .WORD   P.AKD
022666  021512'                                 .WORD   P.AKE
022670  021560'                                 .WORD   P.AKF
022672  021630'                                 .WORD   P.AKG
022674  021662'                                 .WORD   P.AKH
022676  021752'                                 .WORD   P.AKI
022700  022002'                                 .WORD   P.AKJ
022702  022030'                                 .WORD   P.AKK
022704  022062'                                 .WORD   P.AKL
022706  022116'                                 .WORD   P.AKM
022710  022154'                                 .WORD   P.AKN
022712  022210'                                 .WORD   P.AKO
022714  022274'                                 .WORD   P.AKP
022716  022360'                                 .WORD   P.AKQ
022720  022424'                                 .WORD   P.AKR
022722  022452'                                 .WORD   P.AKS
022724  022530'                                 .WORD   P.AKT
022726  022566'                                 .WORD   P.AKU
022730      045     101     124         P.AKW:  .ASCII  /%AT/
022733      061     061     040                 .ASCII  /11 /
022736      103     120     125                 .ASCII  /CPU/
022741      040     106     101                 .ASCII  / FA/
022744      111     114     125                 .ASCII  /ILU/
022747      122     105     000                 .ASCII  /RE/<00>
022752      045     101     116         P.AKX:  .ASCII  /%AN/
022755      117     116     055                 .ASCII  /ON-/
022760      120     101     122                 .ASCII  /PAR/
022763      111     124     131                 .ASCII  /ITY/
022766      040     122     101                 .ASCII  / RA/
022771      115     040     105                 .ASCII  /M E/
022774      122     122     117                 .ASCII  /RRO/
```

```
022777  122  000  000            .ASCII  /R/<00><00>
023002  045  101  123  P.AKY:     .ASCII  /%AS/
023005  124  101  124            .ASCII  /TAT/
023010  105  040  115            .ASCII  /E M/
023013  101  103  110            .ASCII  /ACH/
023016  111  116  105            .ASCII  /INE/
023021  040  106  101            .ASCII  / FA/
023024  111  114  125            .ASCII  /ILU/
023027  122  105  040            .ASCII  /RE /
023032  055  040  124            .ASCII  /- T/
023035  061  061  040            .ASCII  /11 /
023040  101  104  104            .ASCII  /ADD/
023043  122  105  123            .ASCII  /RES/
023046  123  040  122            .ASCII  /S R/
023051  105  107  111            .ASCII  /EGI/
023054  123  124  105            .ASCII  /STE/
023057  122  000  000            .ASCII  /R/<00><00>
023062  045  101  123  P.AKZ:     .ASCII  /%AS/
023065  124  101  124            .ASCII  /TAT/
023070  105  040  115            .ASCII  /E M/
023073  101  103  110            .ASCII  /ACH/
023076  111  116  105            .ASCII  /INE/
023101  040  106  101            .ASCII  / FA/
023104  111  114  125            .ASCII  /ILU/
023107  122  105  040            .ASCII  /RE /
023112  055  040  121            .ASCII  /- Q/
023115  055  102  125            .ASCII  /-BU/
023120  123  040  101            .ASCII  /S A/
023123  104  104  122            .ASCII  /DDR/
023126  105  123  123            .ASCII  /ESS/
023131  040  122  105            .ASCII  / RE/
023134  107  111  123            .ASCII  /GIS/
023137  124  105  122            .ASCII  /TER/
023142  000  000                 .ASCII  <00><00>
023144  045  101  123  P.ALA:     .ASCII  /%AS/
023147  124  101  124            .ASCII  /TAT/
023152  105  040  115            .ASCII  /E M/
023155  101  103  110            .ASCII  /ACH/
023160  111  116  105            .ASCII  /INE/
023163  040  106  101            .ASCII  / FA/
023166  111  114  125            .ASCII  /ILU/
023171  122  105  040            .ASCII  /RE /
023174  055  040  103            .ASCII  /- C/
023177  122  103  040            .ASCII  /RC /
023202  122  105  107            .ASCII  /REG/
023205  111  123  124            .ASCII  /IST/
023210  105  122  000            .ASCII  /ER/<00>
023213  000                      .ASCII  <00>
023214  045  101  123  P.ALB:     .ASCII  /%AS/
023217  124  101  124            .ASCII  /TAT/
023222  105  040  115            .ASCII  /E M/
023225  101  103  110            .ASCII  /ACH/
023230  111  116  105            .ASCII  /INE/
```

```
023233      040      106      101                .ASCII  / FA/
023236      111      114      125                .ASCII  /ILU/
023241      122      105      040                .ASCII  /RE /
023244      055      040      123                .ASCII  /- S/
023247      105      122      111                .ASCII  /ERI/
023252      101      114      111                .ASCII  /ALI/
023255      132      105      122                .ASCII  /ZER/
023260      057      104      105                .ASCII  <57>/DE/
023263      123      105      122                .ASCII  /SER/
023266      111      101      114                .ASCII  /IAL/
023271      111      132      105                .ASCII  /IZE/
023274      122      040      122                .ASCII  /R R/
023277      105      107      111                .ASCII  /EGI/
023302      123      124      105                .ASCII  /STE/
023305      122      000      000                .ASCII  /R/<00><00>
023310      045      101      123      P.ALC:    .ASCII  /%AS/
023313      124      101      124                .ASCII  /TAT/
023316      105      040      115                .ASCII  /E M/
023321      101      103      110                .ASCII  /ACH/
023324      111      116      105                .ASCII  /INE/
023327      040      106      101                .ASCII  / FA/
023332      111      114      125                .ASCII  /ILU/
023335      122      105      040                .ASCII  /RE /
023340      055      040      127                .ASCII  /- W/
023343      122      117      116                .ASCII  /RON/
023346      107      040      110                .ASCII  /G H/
023351      101      122      104                .ASCII  /ARD/
023354      127      101      122                .ASCII  /WAR/
023357      105      040      126                .ASCII  /E V/
023362      105      122      123                .ASCII  /ERS/
023365      111      117      116                .ASCII  /ION/
023370      000      000                         .ASCII  <00><00>
023372   022730'                        P.AKV:    .WORD   P.AKW
023374   022752'                                  .WORD   P.AKX
023376   023002'                                  .WORD   P.AKY
023400   023062'                                  .WORD   P.AKZ
023402   023144'                                  .WORD   P.ALA
023404   023214'                                  .WORD   P.ALB
023406   023310'                                  .WORD   P.ALC
023410      045      116      045      P.ALD:    .ASCII  /%N%/
023413      101      132      122                .ASCII  /AZR/
023416      121      101      040                .ASCII  /QA /
023421      104      105      126                .ASCII  /DEV/
023424      040      106      124                .ASCII  / FT/
023427      114      040      040                .ASCII  /L  /
023432      045      132      065                .ASCII  /%Z5/
023435      045      101      040                .ASCII  /%A /
023440      117      116      040                .ASCII  /ON /
023443      125      116      111                .ASCII  /UNI/
023446      124      040      045                .ASCII  /T %/
023451      132      062      045                .ASCII  /Z2%/
023454      101      040      124                .ASCII  /A T/
023457      123      124      040                .ASCII  /ST /
```

```
023462  060     060     061             .ASCII  /001/
023465  040     123     125             .ASCII  / SU/
023470  102     040     060             .ASCII  /B 0/
023473  060     060     040             .ASCII  /00 /
023476  120     103     072             .ASCII  /PC:/
023501  040     045     117             .ASCII  / %O/
023504  066     000                     .ASCII  /6/<00>
023506  045     116     045     P.ALE:  .ASCII  /%N%/
023511  101     132     122             .ASCII  /AZR/
023514  121     101     040             .ASCII  /QA /
023517  110     122     104             .ASCII  /HRD/
023522  040     105     122             .ASCII  / ER/
023525  122     040     040             .ASCII  /R  /
023530  045     132     065             .ASCII  /%Z5/
023533  045     101     040             .ASCII  /%A /
023536  117     116     040             .ASCII  /ON /
023541  125     116     111             .ASCII  /UNI/
023544  124     040     045             .ASCII  /T %/
023547  132     062     045             .ASCII  /Z2%/
023552  101     040     124             .ASCII  /A T/
023555  123     124     040             .ASCII  /ST /
023560  060     060     061             .ASCII  /001/
023563  040     123     125             .ASCII  / SU/
023566  102     040     060             .ASCII  /B 0/
023571  060     060     040             .ASCII  /00 /
023574  120     103     072             .ASCII  /PC:/
023577  040     045     117             .ASCII  / %O/
023602  066     000                     .ASCII  /6/<00>
023604  045     116     045     P.ALF:  .ASCII  /%N%/
023607  101     132     122             .ASCII  /AZR/
023612  121     101     040             .ASCII  /QA /
023615  123     106     124             .ASCII  /SFT/
023620  040     105     122             .ASCII  / ER/
023623  122     040     040             .ASCII  /R  /
023626  045     132     065             .ASCII  /%Z5/
023631  045     101     040             .ASCII  /%A /
023634  117     116     040             .ASCII  /ON /
023637  125     116     111             .ASCII  /UNI/
023642  124     040     045             .ASCII  /T %/
023645  132     062     045             .ASCII  /Z2%/
023650  101     040     124             .ASCII  /A T/
023653  123     124     040             .ASCII  /ST /
023656  060     060     061             .ASCII  /001/
023661  040     123     125             .ASCII  / SU/
023664  102     040     060             .ASCII  /B 0/
023667  060     060     040             .ASCII  /00 /
023672  120     103     072             .ASCII  /PC:/
023675  040     045     117             .ASCII  / %O/
023700  066     045     116             .ASCII  /6%N/
023703  000                             .ASCII  <00>
023704  045     116     045     P.ALG:  .ASCII  /%N%/
023707  101     111     057             .ASCII  /AI/<57>
023712  117     040     122             .ASCII  /O R/
```

```
023715      105      121      125                    .ASCII  /EQU/
023720      105      123      124                    .ASCII  /EST/
023723      040      106      101                    .ASCII  / FA/
023726      111      114      105                    .ASCII  /ILE/
023731      104      045      116                    .ASCII  /D%N/
023734      000      000                             .ASCII  <00><00>
023736      045      123      064          P.ALH:    .ASCII  /%S4/
023741      000                                      .ASCII  <00>
023742      045      116      000          P.ALI:    .ASCII  /%N/<00>
023745      000                                      .ASCII  <00>
023746      045      101      040          P.ALJ:    .ASCII  /%A /
023751      055      040      000                    .ASCII  /- /<00>
023754      045      101      052          P.ALK:    .ASCII  /%A*/
023757      040      000      000                    .ASCII  / /<00><00>
023762  000000C                          L$HWLEN::
                                                    .WORD   <<L$NDHW-L$HWLEN>/2>
023764  172150                           HWPT.IP.ADDR::
                                                    .WORD   -5630
023766  000154                           HWPT.VECTOR::
                                                    .WORD   154
023770  000004                           HWPT.BR.LEVEL::
                                                    .WORD   4
023772  000200                           HWPT.DISK::
                                                    .WORD   200
023774  000000                           HWPTS0.LBN::
                                                    .WORD   0
023776  000000                           HWPTS1.LBN::
                                                    .WORD   0
024000  177777                           HWPTE0.LBN::
                                                    .WORD   -1
024002  000000                           HWPTE1.LBN::
                                                    .WORD   0
024004  020040                           NAME.LO::
                                                    .WORD   20040
024006  020040                           NAME.HI::
                                                    .WORD   20040
024010                                   L$NDHW::.BLKW   1
024012  000000C                          L$SWLEN::
                                                    .WORD   <<L$NDSW-L$SWLEN>/2>
024014  000040                           SWP.ERROR::
                                                    .WORD   40
024016  000000                           SWP.XFER::
                                                    .WORD   0
024020  054046                           SWP.FLAGS::
                                                    .WORD   54046
024022  000000                           SWP.DPAT::
                                                    .WORD   0
024024  000143                           SWP.RAT::
                                                    .WORD   143
024026  000000                           SWP.TIME::
                                                    .WORD   0
024030  000020                           SWP.UCNT::
                                                    .WORD   20
```

```
024032                          SWP.UDPAT::
                                        .BLKW   20
024072  000013                  DUPROUND::
                                        .WORD   13
024074  000000                  MAN.TST::
                                        .WORD   0
024076  000001                  TST.PAR::
                                        .WORD   1
024100                          L$NDSW::.BLKW   1
024102  000000                  L$PROT::.WORD   0
024104  177777                          .WORD   -1
024106  000006                          .WORD   6


000000                                  .PSECT  $FFF$,  D  ,  GBL
000000                          CST::   .BLKW   53
000126                          CST.ADDR::
                                        .BLKW   1
000130                          DCT::   .BLKW   11
000152                          DCT.ADDR::
                                        .BLKW   1
000154                          RDRX.ADDR::
                                        .BLKW   1
000156                          IRDRX.ADDR::
                                        .BLKW   1
000160                          BST::   .BLKW   10
000200                          TALLY:: .BLKW   154
000530                          T.ADDR::.BLKW   1
000532                          TRK.SGN::
000532     001                          .BYTE   1
000533     001                          .BYTE   1
000534     001                          .BYTE   1
000535     001                          .BYTE   1
000536  000020                  RDM.CNT::
                                        .WORD   20
000540                          RANDOM::.BLKW   20
000600                          C.ERR.TBL::
                                        .BLKW   1
000602                          MSCP.PKT::
                                        .BLKW   644
002312                          IPKT.ADDR::
                                        .BLKW   1
002314                          PKT.USE::
                                        .BLKW   6
002330                          RETPKT::.BLKW   260
003070                          RP.USE::.BLKW   4
003100                          RP.INDX::
                                        .BLKW   1
003102                          RP.ADDR::
                                        .BLKW   1
003104                          ELOG.PKT::
                                        .BLKW   655
```

```
004636                          BUFF.ADDR::
                                        .BLKW   10
004656                          BUFF.OWN::
                                        .BLKW   4
004666                          IODQ::  .BLKW   4
004676                          IODQ.IN::
                                        .BLKW   1
004700                          IODQ.OUT::
                                        .BLKW   1
004702                          ENTRY.REASON::
                                        .BLKB   1
004703                          EOP.FLAG::
                                        .BLKB   1
004704                          DUP.FLAGS::
                                        .BLKW   1
004706                          CCTLR:: .BLKW   1
004710                          CDISK:: .BLKW   1
004712                          CUOFF:: .BLKW   1
004714                          CTLR.CNT::
                                        .BLKW   1
004716                          DUR::   .BLKW   2
004722                          QIO::   .BLKB   1
                                        .EVEN
004724                          FREE.MEM.ADDR::
                                        .BLKW   1
004726                          BYTS.PER.QIO::
                                        .BLKW   1
004730                          ST.CODE::
                                        .BLKW   1
004732                          SB.CODE::
                                        .BLKW   1
004734                          STEP::  .BLKW   1
004736                          OF.RC:: .BLKW   1
004740                          SA.REG::.BLKW   1
004742                          CMD.TIME::
                                        .BLKW   1
004744                          NEX::   .BLKW   1
004746                          CRN.LOW::
                                        .BLKW   1
004750                          CRN.HIGH::
                                        .BLKW   1
004752                          TEMP1:: .BLKW   1
004754                          TEMP2:: .BLKW   1
004756                          CREDIT.BAL::
                                        .BLKW   1
004760                          NEXT.PKT.USE::
                                        .BLKB   1
004761                          HOURS:: .BLKB   1
004762                          MINUTES::
                                        .BLKB   1
                                        .EVEN
004764                          CLK.TICKS::
                                        .BLKW   1
```

```
004766                          FERO.LBN::
                                        .BLKW   1
004770                          FER1.LBN::
                                        .BLKW   1
004772                          CLK.PRESENT::
                                        .BLKB   1
004773                          HOE.FLAG::
                                        .BLKB   1
004774                          TYPER::  .BLKW   4
005004                          TYPEW::  .BLKW   4
005014                          BAL.IN.PROGRESS::
                                        .BLKW   4
005024                          FORCE.WR::
                                        .BLKW   4
005034                          CSR.MEM::
                                        .BLKW   1
005036  172100                  CSR.ADD::
                                        .WORD    5700
005040                          P.INDEX::
                                        .BLKW   1
005042  000000                  RD.COUNT::
                                        .WORD   0
005044                          BRLEVEL::
                                        .BLKW   1
005046                          D.FAIL::.BLKB   1
005047                          FORCED.ERROR::
                                        .BLKB   1
005050                          FER.LBN::
                                        .BLKW   1
005052                          FER.BC::.BLKW   1
005054                          INIT.OCCURED::
005054     000                          .BYTE   0
005055                          ADDR.VECT.OK::
005055     000                          .BYTE   0


                                .GLOBL  L$RPT, L$INIT, L$CLEAN, L$LAST
                                .GLOBL  L$HARD, L$DU, L$AU, L$AUTO, L$SOFT
                                .GLOBL  T$PTHV, L$DVTYP, L$DESC, T1


        000001                  ON=:            1
        000002                  OFF=:           2
        100000                  BIT15=:         -100000
        040000                  BIT14=:         40000
        020000                  BIT13=:         20000
        010000                  BIT12=:         10000
        004000                  BIT11=:         4000
        002000                  BIT10=:         2000
        001000                  BIT09=:         1000
        000400                  BIT08=:         400
        000200                  BIT07=:         200
        000100                  BIT06=:         100
```

```
000040                  BIT05==         40
000020                  BIT04==         20
000010                  BIT03==         10
000004                  BIT02==         4
000002                  BIT01==         2
000001                  BIT00==         1
001000                  BIT9==          1000
000400                  BIT8==          400
000200                  BIT7==          200
000100                  BIT6==          100
000040                  BIT5==          40
000020                  BIT4==          20
000010                  BIT3==          10
000004                  BIT2==          4
000002                  BIT1==          2
000001                  BIT0==          1
000035                  EF.NEW==        35
000034                  EF.PWR==        34
000040                  EF.START==      40
000037                  EF.RESTART==    37
000036                  EF.CONTINUE==   36
000340                  PRI07==         340
000300                  PRI06==         300
000240                  PRI05==         240
000200                  PRI04==         200
000140                  PRI03==         140
000100                  PRI02==         100
000040                  PRI01==         40
000000                  PRI00==         0
000004                  EVL==           4
000010                  LOT==           10
000020                  ADR==           20
000040                  IDU==           40
000100                  ISR==           100
000200                  UAM==           200
000400                  BOE==           400
001000                  PNT==           1000
002000                  PRI==           2000
004000                  IXE==           4000
010000                  IBE==           10000
020000                  IER==           20000
040000                  LOE==           40000
100000                  HOE==           -100000
000126'                 L$ERRTBL==      ERRTYP
024014'                 L$SW==          L$SWLEN+2
023764'                 L$HW==          L$HWLEN+2
000011'                 L$DEPO==        L$REV+1
000136'                 PTCH1==         P.AAA
000210'                 PTCH2==         P.AAB
000262'                 PTCH3==         P.AAC
000334'                 PTCH4==         P.AAD
000406'                 PTCH5==         P.AAE
000460'                 HWQ1==          P.AAF
```

```
000474'                 HWQ2--          P.AAG
000504'                 HWQ3--          P.AAH
000546'                 HWQ4--          P.AAI
000564'                 HWQ5--          P.AAJ
000634'                 HWQ6A--         P.AAK
000706'                 HWQ6B--         P.AAL
000762'                 HWQ7A--         P.AAM
001032'                 HWQ7B--         P.AAN
001102'                 HWQ8--          P.AAO
001160'                 HWQ9--          P.AAP
001260'                 SW[illegible]--         P.AAQ
001302'                 SWQ2--          P.AAR
001362'                 SWQ4--          P.AAS
001404'                 SWQ7--          P.AAT
001456'                 SWQ9--          P.AAU
001532'                 SWQ10--         P.AAV
001576'                 SWQ11--         P.AAW
001630'                 SWQ12--         P.AAX
001726'                 SWQ13--         P.AAY
002004'                 SWQ14--         P.AAZ
002056'                 SWQ15--         P.ABA
002126'                 SWQ17--         P.ABB
002224'                 SWQ19--         P.ABC
002314'                 SWQ20--         P.ABD
002402'                 SWQ21--         P.ABE
002466'                 SWQ22--         P.ABF
002526'                 SWQ23--         P.ABG
002600'                 SWQ24--         P.ABH
002644'                 SWQ26--         P.ABI
002706'                 SWM1--          P.ABJ
003004'                 SWQ27--         P.ABK
003030'                 SWQ28--         P.ABL
003100'                 NULL--          P.ABM
003102'                 DBM5--          P.ABN
003130'                 DBM12--         P.ABO
003204'                 DBM15--         P.ABP
003234'                 DBM18--         P.ABQ
003306'                 DBM19--         P.ABR
003372'                 DBM20--         P.ABS
003446'                 DBM21--         P.ABT
003530'                 DBM22--         P.ABU
003574'                 DBM23--         P.ABV
003632'                 DBM25--         P.ABW
003700'                 DBM26--         P.ABX
003732'                 DBM27--         P.ABY
004004'                 DBM28A--        P.ABZ
004044'                 DBM28B--        P.ACA
004104'                 DBM29--         P.ACB
004152'                 DBM32--         P.ACC
004226'                 DBM101--        P.ACD
004254'                 DBM104--        P.ACE
004316'                 DBM105--        P.ACF
004354'                 DBM107--        P.ACG
```

```
004412'                 DBM108--        P.ACH
004502'                 DBM109--        P.ACI
004562'                 DBM111--        P.ACJ
004662'                 DBM112--        P.ACK
004764'                 DBM120--        P.ACL
005056'                 DBM121--        P.ACM
005146'                 DBM123--        P.ACN
005210'                 DBM125--        P.ACO
005260'                 DBM126--        P.ACP
005340'                 DBM127--        P.ACQ
005416'                 DBM128--        P.ACR
005504'                 DU.MSG--        P.ACS
006224'                 DU.RSN--        P.ACT
006252'                 MSG.01--        P.ADF
006304'                 MSG.02--        P.ADG
006340'                 MSG.03--        P.ADH
006372'                 RPT1--          P.ADI
006456'                 RPT2--          P.ADJ
006522'                 RPT3--          P.ADK
006606'                 RPT4--          P.ADL
006652'                 RPT5--          P.ADM
006740'                 RPT6--          P.ADN
007004'                 RPT7--          P.ADO
007022'                 RPT8--          P.ADP
007050'                 RPT9--          P.ADQ
007102'                 RPT10--         P.ADR
007170'                 RPT11--         P.ADS
007236'                 RPT12--         P.ADT
007304'                 RPT13--         P.ADU
007404'                 RPT14--         P.ADV
007502'                 RPT15--         P.ADW
007602'                 RPT16--         P.ADX
007664'                 EGS.01--        P.ADY
007704'                 EGS.02--        P.ADZ
007776'                 EGD.10--        P.AEA
010036'                 EGD.11--        P.AEB
010062'                 EGD.12--        P.AEC
010110'                 EGD.13--        P.AED
010136'                 EGD.14--        P.AEE
010166'                 EGD.15--        P.AEF
010204'                 EGD.16--        P.AEG
010234'                 EGD.17--        P.AEH
010252'                 EGD.18--        P.AEI
010272'                 EGD.19--        P.AEJ
010332'                 EGD.20--        P.AEK
010420'                 EGD.21--        P.AEL
010532'                 EGD.22--        P.AEM
010572'                 EGD.23--        P.AEN
010634'                 EGD.24--        P.AEO
010700'                 EGH.30--        P.AEP
010724'                 EBS.01--        P.AEQ
010766'                 EBD.10--        P.AER
011026'                 EBD.12--        P.AES
```

```
011074'                 EBD.13**        P.AET
011126'                 EBD.14**        P.AEU
011166'                 EBD.18**        P.AEV
011222'                 EBD.19**        P.AEW
011302'                 EBD.24**        P.AEX
011356'                 EH.0**          P.AEY
011414'                 EH.1**          P.AEZ
011452'                 EH.2**          P.AFA
011512'                 EH.3**          P.AFB
011550'                 EH.4**          P.AFC
011574'                 EH.5**          P.AFD
011624'                 EH.6**          P.AFE
011654'                 EH.7**          P.AFF
011704'                 EH.8**          P.AFG
011740'                 EH.9**          P.AFH
011770'                 EH.10**         P.AFI
012020'                 EH.12**         P.AFJ
012054'                 EH.13**         P.AFK
012126'                 ERR.OO**        P.AFL
012662'                 ERR.COD**       P.AFM
012720'                 ELG.OO**        P.AGC
013334'                 ELG.FMT**       P.AGD
013350'                 EX.SA**         P.AGK
013366'                 EX.SC**         P.AGL
013416'                 EX.SBO**        P.AGM
013422'                 EX.SB**         P.AGN
013444'                 EX.CMD**        P.AGO
013464'                 EX.RD**         P.AGP
013474'                 EX.WRT**        P.AGQ
013504'                 EX.CMP**        P.AGR
013520'                 EX.ONL**        P.AGS
013532'                 EX.ACC**        P.AGT
013544'                 EX.OP**         P.AGU
013550'                 EX.BB2**        P.AGV
013616'                 EX.BB12**       P.AGW
013670'                 EX.BBU2**       P.AGX
013750'                 EX.LBN2**       P.AGY
014010'                 EX.PBN2**       P.AGZ
014050'                 EX.LBR2**       P.AHA
014116'                 EX.LBW2**       P.AHB
014166'                 EX.RBN2**       P.AHC
014226'                 EX.CBC**        P.AHD
014272'                 EX.CBR**        P.AHE
014344'                 EX.CBW**        P.AHF
014416'                 EX.BC**         P.AHG
014472'                 EX.BD**         P.AHH
014550'                 EX.BDR**        P.AHI
014640'                 EX.BDW**        P.AHJ
014730'                 EX.RP**         P.AHK
015016'                 EX.WRD**        P.AHL
015026'                 EX.TIM**        P.AHM
015064'                 EX.LB**         P.AHN
015130'                 XXi3**          P.AHO
```

```
015152'                 XX23--          P.AHP
015206'                 XX32--          P.AHQ
015234'                 XX33--          P.AHR
015272'                 XX34--          P.AHS
015342'                 CER.01--        P.AHT
015406'                 CER.02--        P.AHU
015462'                 SC.SDI--        P.AHV
015506'                 SC.CON--        P.AHW
015530'                 SC.DUP--        P.AHX
015560'                 SC.ONL--        P.AHY
015602'                 SC.SON--        P.AHZ
015622'                 SC.INR--        P.AIA
015654'                 SC.INV--        P.AIB
015672'                 SC.UNK--        P.AIC
015752'                 SC.VOL--        P.AID
016032'                 SC.IOP--        P.AIE
016104'                 SC.DIS--        P.AIF
016176'                 SC.FER--        P.AIG
016264'                 SC.FE2--        P.AIH
016354'                 SC.ISH--        P.AII
016434'                 SC.IS2--        P.AIJ
016514'                 SC.DST--        P.AIK
016570'                 SC.DS2--        P.AIL
016642'                 SC.ECC--        P.AIM
016724'                 SC.ECD--        P.AIN
016756'                 SC.RCT--        P.AIO
016776'                 SC.FUL--        P.AIP
017052'                 SC.576--        P.AIQ
017126'                 SC.FCT--        P.AIR
017174'                 SC.EC1--        P.AIS
017224'                 SC.EC2--        P.AIT
017254'                 SC.EC3--        P.AIU
017306'                 SC.EC4--        P.AIV
017336'                 SC.EC5--        P.AIW
017366'                 SC.EC6--        P.AIX
017416'                 SC.EC7--        P.AIY
017450'                 SC.EC8--        P.AIZ
017502'                 SC.EC9--        P.AJA
017544'                 SC.SWP--        P.AJB
017604'                 SC.HWP--        P.AJC
017644'                 SC.SAF--        P.AJD
017710'                 SC.ODA--        P.AJE
017740'                 SC.ODB--        P.AJF
017762'                 SC.NXM--        P.AJG
020016'                 SC.PAR--        P.AJH
020052'                 SC.CTO--        P.AJI
020124'                 SC.SDS--        P.AJJ
020202'                 SC.EDC--        P.AJK
020242'                 SC.IDS--        P.AJL
020312'                 SC.SRT--        P.AJM
020404'                 SC.SRI--        P.AJN
020472'                 SC.POE--        P.AJO
020526'                 SC.RDY--        P.AJP
```

```
        020610'                         SC.CLK==            P.AJQ
        020636'                         SC.RSP==            P.AJR
        020704'                         SC.SUR==            P.AJS
        020734'                         SC.PSP==            P.AJT
        021016'                         SC.REP==            P.AJU
        021060'                         SC.NBB==            P.AJV
        021130'                         SC.REF==            P.AJW
        022652'                         CNTR.ERR==          P.AJX
        023372'                         RDRX.ERR==          P.AKV
        023410'                         DF.MSG==            P.ALD
        023506'                         HRD.MSG==           P.ALE
        023604'                         SFT.MSG==           P.ALF
        023704'                         HRD.SUB==           P.ALG
        023736'                         SPACE4==            P.ALH
        023742'                         CRLF==              P.ALI
        023746'                         DASH==              P.ALJ
        023754'                         ASTERISK==          P.ALK
        023764'                         DFPTBL==            L$HWLEN+2
        024014'                         SFPTBL==            L$SWLEN+2


;                                       PSECT SUMMARY
;
;       Psect Name                      Words     Attributes
;         $CODE$                         5156       RO  ,  I  ,  LCL,  REL,  CON
;         $FFF$                          1303       RW  ,  D  ,  GBL,  REL,  CON


;                               Library Statistics
;
;                                       --------  Symbols  --------      Pages       Processing
;       File                            Total     Loaded     Percent     Mapped      Time
;
;  DISK$USER2:[MLYNAR.ZRQ]ZRQAH0.L16;10   411        178          43          21        00:00.1


;                                       COMMAND QUALIFIERS
;
;       BLISS/PDP11 ZRQAH0.BL1/LIST=ZRQAH0.LS1/OBJECT=ZRQAH0.OB1/SOURCE=PAGE:53
```

```
;  3651  0     module ZRQAM2 (
;  3652  0
;  3653  0     %title 'RD/RX EXERCISER'
;  3654  0                    ident = 'V02.3',
;  3655  0                    addressing_mode (absolute),
;  3656  0                    environment (noeis)
;  3657  0                    ) =
;  3658  0
;  3659  1     begin
;  3660  1
;  3661  1     %sbttl 'DECLARATIONS'
;  3662  1
;  3663  1     library 'ZRQAHO.L16';                          ! RDRX EXERCISER GLOBAL LIBRARY
;  3664  1
;  3665  1     !MMM require 'BLSMAC.REQ';                     ! DIAGNOSTIC SUPERVISOR LIBRARY      ZZZ
;  3666  1     require 'HSAXAO.BLB';                          ! DIAGNOSTIC SUPERVISOR LIBRARY      ZZZ
;  5407  1
;  5408  1     forward routine
;  5409  1         NEX_TRAP : L%ISR novalue,
;  5410  1         EMS_01 : novalue,
;  5411  1         EMS_TIM : novalue,
;  5412  1     !MMM    EMS_DBN : NOVALUE,                                                  !ZZZ
;  5413  1         EMS_BLK : NOVALUE,                                                !ZZZ
;  5414  1         SET_CPAR : novalue,
;  5415  1         SET_UPAR : novalue;
;  5416  1
;  5417  1     external
;  5418  1         CST : blockvector [MAX_CTLR, CST_LEN, word] field (CST_FIELDS),
;  5419  1                        ! RUN-TIME CONTROLLER STATUS TABLES
;  5420  1         CST_ADDR : ref block [CST_LEN, word] field (CST_FIELDS),
;  5421  1                        ! CONTROLLER STATUS TABLE ADDRESS OF "CURRENT" CONTROLLER
;  5422  1         DCT : blockvector [MAX_CTLR, DCT_LEN, word] field (DCT_FIELDS),
;  5423  1                        ! DRIVER CONTROLLER TABLES
;  5424  1         DCT_ADDR : ref block [DCT_LEN, word] field (DCT_FIELDS),
;  5425  1                        ! ADDRESS OF "CURRENT" DRIVER CONTROLLER TABLE
;  5426  1         RDRX_ADDR : ref rdrx field (RC_REG),
;  5427  1                        ! DEVICE ADDRESS OF "CURRENT" CONTROLLER
;  5428  1         IRDRX_ADDR : ref rdrx field (RC_REG),
;  5429  1                        ! DEVICE ADDRESS OF INTERRUPTING CONTROLLER
;  5430  1         BST : BLOCKVECTOR [MAX_UNITS, 2, WORD],                             !ZZZ
;  5431  1                         !CONTAINS LBNS (HI + LO FIELDS) FOR SEQUENTIAL     !ZZZ
;  5432  1                         !I/O TRANSFER FOR EACH UNIT.                       !ZZZ
;  5433  1         TALLY : vector [MAX_UNITS * TALLY_LEN, word] field (T_FIELDS),
;  5434  1                        ! STATISTICS TABLES
;  5435  1         T_ADDR : ref block [TALLY_LEN, word] field (T_FIELDS),
;  5436  1                        ! ADDRESS OF STATISTICS TABLE (TALLY) FOR CURRENT UNIT
;  5437  1     !MMM    DUPPKT : BLOCK [257, WORD] FIELD (DP_FIELDS),   !BUFFER FOR DUP  ZZZ
;  5438  1     !MMM                              !INFO FROM RECEIVE AND SEND CMDS                ZZZ
;  5439  1         TRK_SGN : VECTOR [MAX_UNITS, BYTE, SIGNED], !CURRENT TRACK DIRECTION ZZZ
;  5440  1         RDM_CNT : WORD,                    !NO OF RANDOM NOS    \\KEEP       ZZZ
;  5441  1         RANDOM : VECTOR [RDM_LEN, WORD],    !RANDOM NO TABLE    //TOGETHER   ZZZ
;  5442  1         C_ERR_TBL : blockvector [MAX_CTLR, C_ERR_LEN, word] field (C_ERR_FIELDS),
;  5443  1                        ! STATISTICS TABLE FOR CONTROLLER ERRORS
```

```
;    5444  1          MSCP_PKT : blockvector [PKT_CNT, PKT_LEN, word] field (PKT_FIELDS),
;    5445  1                                 ! MSCP PACKET POOL
;    5446  1          IPKT_ADDR : ref block [PKT_LEN, word] field (PKT_FIELDS),
;    5447  1                                 ! ADDRESS OF AN MSCP PACKET (INTERRUPT PROCESSING)
;    5448  1          PKT_USE : vector [PKT_CNT, byte, signed],
;    5449  1                                 ! MSCP PACKET POOL ALLOCATION TABLE
;    5450  1          RETPKT : blockvector [RP_CNT, RP_LEN, word] field (RP_FIELDS),
;    5451  1                                 ! RETURN PACKET POOL
;    5452  1          RP_USE : vector [RP_CNT, byte, signed],
;    5453  1                                 ! RETURN PACKET POOL ALLOCATION TABLE
;    5454  1          RP_INDX : word,        ! CURRENT RETURN PACKET INDEX
;    5455  1          RP_ADDR : ref block [RP_LEN, word] field (RP_FIELDS),
;    5456  1                                 ! CURRENT RETURN PACKET ADDRESS
;    5457  1          ELOG_PKT : blockvector [EP_CNT + 1, EP_LEN, word] field (EP_FIELDS),
;    5458  1                                 ! ERROR-LOG PACKET SAVE AREA
;    5459  1          BUFF_ADDR : vector [MAX_BUF_CNT],                   ! TABLE OF I/O BUFFER DESCRIPTORS
;    5460  1          BUFF_OWN : vector [MAX_BUF_CNT, byte, signed],      ! I/O BUFFER OWNERSHIP (CONTROLLER NUMBER)
;    5461  1          IODQ : vector [IODQ_LEN, byte],                     ! I/O DONE QUEUE - CIRCULAR QUEUE OF RETPKT INDECES
;    5462  1          IODQ_IN : word,                                     ! I/O DONE QUEUE IN POINTER
;    5463  1          IODQ_OUT : word,                                    ! I/O DONE QUEUE OUT POINTER
;    5464  1          ENTRY_REASON : byte,                                ! CURRENT OPERATOR COMMAND
;    5465  1          EOP_FLAG : byte,                                    ! END-OF-PASS FLAG
;    5466  1          DUP_FLAGS : WORD,                                   !DUP FLAGS       ZZZ
;    5467  1          CCTLR : word,                                       ! NUMBER OF "CURRENT" CONTROLLER
;    5468  1          CDISK : word,                                       ! CURRENT DISK ADDRESS (RD/RX DISK NUMBER)
;    5469  1          CUOFF : word,                                       ! CURRENT UNIT CST OFFSET
;    5470  1          CTLR_CNT : word,                                    ! TOTAL NUMBER OF CONFIGURED CONTROLLERS
;    5471  1          DUR : vector [MAX_UNITS, byte],                     ! DROP UNIT REASON
;    5472  1          QIO : vector [MAX_CTLR, byte],                      ! NUMBER OF OUTSTANDING QIOs PER CONTROLLER
;    5473  1          FREE_MEM_ADDR,                                      ! START OF FREE MEMORY
;    5474  1          BYTS_PER_QIO : word,                                ! SIZE (BYTES) OF AN I/O BUFFER
;    5475  1          ST_CODE : word,                                     ! CURRENT STATUS CODE
;    5476  1          SB_CODE : word,                                     ! CURRENT SUB-CODE
;    5477  1          STEP : word,                                        ! CURRENT STEP IN HARD_INIT
;    5478  1          OF_RC : signed word,                                ! OFFSET (0 OR 2) TO READ IP OR SA
;    5479  1          SA_REG : word,                                      ! STORAGE FOR SA REGISTER READS AND WRITES
;    5480  1          CMD_TIME : word,                                    ! COMMAND TIMEOUT VALUE (IN SECONDS)
;    5481  1          NEX : word,                                         ! NON-EXISTENT MEMORY TRAP INDICATOR
;    5482  1          CRN_LOW : word,                                     ! COMMAND REF NUMBER OF LAST COMMAND SENT
;    5483  1          CRN_HIGH : word,                                    ! COMMAND REF NUMBER (HI ORDER)
;    5484  1          TEMP1 : WORD,                                       !TEMPORARY STORAGE WD USED IN BGNCLN          !ZZZ
;    5485  1          TEMP2 : WORD,                                       !TEMPORARY STORAGE WD USED IN BGNCLN          !ZZZ
;    5486  1          CREDIT_BAL : word,                                  ! CREDIT BALANCE
;    5487  1          NEXT_PKT_USE : byte,                                ! POINTER TO NEXT ENTRY IN PKT_USE TABLE
;    5488  1          HOURS: byte,                                        ! TIME OF DAY (HOURS)
;    5489  1          MINUTES : byte,                                     ! TIME OF DAY (MINUTES)
;    5490  1          CLK_TICKS : word,                                   ! TIME OF DAY (LINE-CLOCK TICKS)
;    5491  1          FER0_LBN : word,                                    !LO LBN ADR OF THE "FORCED ERROR" BLOCK              ZZZ
;    5492  1          FER1_LBN : word,                                    !HI LBN ADR OF THE "FORCED ERROR" BLOCK              ZZZ
;    5493  1          CLK_PRESENT : byte,                                 ! FLAG INDICATES IF LINE-CLOCK PRESENT
;    5494  1          HOE_FLAG : byte,                                    ! FLAG INDICATES IF "HALT ON ERROR" FLAG SET
;    5495  1          FORCED_ERROR : byte,                                ! "FORCED ERROR" DETECTED IN LAST READ
;    5496  1          FER_LBN : word,                                     ! LBN OF THE "FORCED ERROR" BLOCK
```

```
;    5497  1          FER_BC : word,                                  ! BYTE COUNT OF THE "FORCED ERROR" BLOCK
;    5498  1          INIT_OCCURED : byte,                            ! EXERCISER INITIALIZATION COMPLETE
;    5499  1          ADDR_VECT_OK : byte,                            ! FLAG INDICATES IF ADDRESS/VECTOR TEST PASSED
;    5500  1          DBM5,
;    5501  1          DBM125,                                         !MMM
;    5502  1          DBM126,                                         !MMM
;    5503  1
;    5504  1          TYPER : VECTOR [MAX_UNITS, WORD],   !READ I/O COUNTER                   ZZZ MMM
;    5505  1          TYPEW : VECTOR [MAX_UNITS, WORD],   !WRITE I/O COUNTER                  ZZZ MMM
;    5506  1          BAL_IN_PROGRESS : VECTOR [MAX_UNITS, WORD],     !FLAG SET TO BALANCE I/O TYPES     ZZZ MMM
;    5507  1          FORCE_WR : VECTOR [MAX_UNITS, WORD],        ! MMM
;    5508  1          CSR_MEM : WORD,                             ! MMM
;    5509  1          CSR_ADD : WORD,                             ! MMM
;    5510  1          P_INDEX : SIGNED WORD,              !CURRENT MESSAGE PACKET INDEX       ZZZ
;    5511  1      !MMM    S_PATTERN : WORD,                       !PATTERN FOR DUP WRITES             ZZZ
;    5512  1      !MMM    S_DUPPKT : WORD,                        !DBN BYTE COUNTER                   ZZZ
;    5513  1          RD_COUNT : WORD,                ! NUMBER OF WINCHESTER UNITS        ZZZ
;    5514  1          BRLEVEL : WORD,                 !BUS REQUEST PRIORITY LEVEL         ZZZ
;    5515  1          D_FAIL : BYTE,                  !SIGNIFIES DUP TYPE ERROR           ZZZ
;    5516  1          DBM107,
;    5517  1          DU_MSG,
;    5518  1          DU_RSN : vector [11],
;    5519  1          RPT1,
;    5520  1          RPT2,
;    5521  1          RPT3,
;    5522  1          RPT4,
;    5523  1          RPT5,
;    5524  1          RPT6,
;    5525  1          RPT7,
;    5526  1          RPT8,
;    5527  1          RPT9,
;    5528  1          RPT10,
;    5529  1          RPT11,
;    5530  1          RPT12,
;    5531  1          RPT13,
;    5532  1          RPT14,
;    5533  1          RPT15,
;    5534  1          RPT16,
;    5535  1      !ZZZ    RPT17,
;    5536  1      !ZZZ    RPT18,
;    5537  1      !ZZZ    RPT19,
;    5538  1
;    5539  1          MSG_01,
;    5540  1          EGS_01,
;    5541  1          EBS_01,
;    5542  1          EBD_10,
;    5543  1          EBD_12,
;    5544  1          EBD_13,
;    5545  1          EBD_14,
;    5546  1          EBD_18,
;    5547  1          EBD_19,
;    5548  1          EBD_24,
;    5549  1          ERR_00,
```

```
;    5550  1          ERR_COD : vector [14],
;    5551  1          ELG_OO,
;    5552  1          ELG_FMT : vector [5],
;    5553  1          EX_TIM,
;    5554  1          !EX_DUP,                                                    !MMM
;    5555  1          EX_LB,                                                     !MMM
;    5556  1          XX13,                                                      !ZZZ
;    5557  1          XX23,                                                      !ZZZ
;    5558  1          XX32,                                                      !ZZZ
;    5559  1          XX33,                                                      !ZZZ
;    5560  1          XX34,                                                      !ZZZ
;    5561  1          EX_SA,
;    5562  1          EX_SC,
;    5563  1          EX_SBO,
;    5564  1          EX_SB,
;    5565  1          EX_RP,
;    5566  1          EX_WRD,
;    5567  1          EX_CMD,
;    5568  1          EX_RD,
;    5569  1          EX_WRT,
;    5570  1          EX_CMP,
;    5571  1          EX_ONL,
;    5572  1          EX_ACC,
;    5573  1          EX_OP,
;    5574  1          EX_BB2,
;    5575  1          EX_BB12,
;    5576  1          EX_BBU2,
;    5577  1          EX_LBN2,
;    5578  1          EX_PBN2,
;    5579  1          EX_LBR2,
;    5580  1          EX_LBW2,
;    5581  1          EX_RBN2,
;    5582  1          EX_CBC,
;    5583  1          EX_CBR,
;    5584  1          EX_CBW,
;    5585  1          EX_BC,
;    5586  1          EX_BD,
;    5587  1          EX_BDR,
;    5588  1          EX_BDW,
;    5589  1          SC_SDI,
;    5590  1          SC_CON,
;    5591  1          SC_DUP,
;    5592  1          SC_ONL,
;    5593  1          SC_SON,
;    5594  1          SC_INR,                    !MMM
;    5595  1          SC_INV,                    !MMM
;    5596  1          SC_UNK,
;    5597  1          SC_VOL,
;    5598  1          SC_IOP,
;    5599  1          SC_DIS,
;    5600  1          SC_FER,
;    5601  1          SC_FE2,
;    5602  1          SC_ISH,
```

```
;    5603  1          SC_IS2,
;    5604  1          SC_DST,
;    5605  1          SC_DS2,
;    5606  1          SC_ECC,
;    5607  1          SC_ECD,
;    5608  1          SC_RCT,
;    5609  1          SC_FUL,
;    5610  1          SC_576,
;    5611  1          SC_FCT,
;    5612  1          SC_SWP,
;    5613  1          SC_MWP,
;    5614  1          SC_SAF,                                 !MMM
;    5615  1          SC_EC1,
;    5616  1          SC_EC2,
;    5617  1          SC_EC3,
;    5618  1          SC_EC4,
;    5619  1          SC_EC5,
;    5620  1          SC_EC6,
;    5621             SC_EC7,
;    5622             SC_EC8,
;    5623             SC_EC9,
;    5624             SC_ODA,
;    5625  1          SC_ODB,
;    5626  1          SC_NXM,
;    5627  1          SC_PAR,
;    5628  1          SC_CTO,
;    5629  1          SC_SDS,
;    5630  1          SC_EDC,
;    5631  1          SC_IDS,
;    5632  1          SC_SRT,
;    5633  1          SC_SRI,
;    5634  1          SC_POE,
;    5635  1          SC_RDY,
;    5636  1          SC_CLK,
;    5637  1          SC_RSP,
;    5638  1          SC_SUR,
;    5639  1          SC_PSP,
;    5640  1          SC_REP,                         !MMM
;    5641  1          SC_NXB,                         !MMM
;    5642  1          SC_REF,                         !MMM
;    5643  1          CER_01,
;    5644  1          CER_02,
;    5645  1          CNTR_ERR : vector [23],
;    5646  1          RDRX_ERR : vector [7],
;    5647  1          SPACE4,
;    5648  1          CRLF,
;    5649  1          DASH,
;    5650  1          ASTERISK,
;    5651  1          HWQ1,
;    5652  1          HWQ2,
;    5653  1          HWQ3,
;    5654  1          HWQ4,
;    5655  1          HWQ5,
```

```
;    5656  1          HWQ6A,
;    5657  1          HWQ6B,
;    5658  1          HWQ7A,
;    5659  1          HWQ7B,
;    5660  1          HWQ8,
;    5661  1          HWQ9,
;    5662  1      !MMMMWQ10,                                          !ZZZ
;    5663  1      !MMM    HWQ11,                                              !ZZZ
;    5664  1          SWQ1,
;    5665  1          SWQ2,
;    5666  1          SWQ4,
;    5667  1          SWQ7,
;    5668  1          SWQ9,
;    5669  1          SWQ10,
;    5670  1          SWQ11,
;    5671  1          SWQ12,
;    5672  1          SWQ13,
;    5673  1          SWQ14,
;    5674  1          SWQ15,
;    5675  1          SWQ17,
;    5676  1          SWG19
;    5677  1          SWQ20,
;    5678  1          SWw21,
;    5679  1          SWQ22,
;    5680  1          SWQ23,
;    5681  1          SWQ24,
;    5682  1          !MMMSWQ25,
;    5683  1          SWQ26,                                              !ZZZ
;    5684  1          SWQ27,                                              !MMM
;    5685  1          SWQ28,                                              !MMM
;    5686  1          EH_0,                                               !ZZZ
;    5687  1          EH_1,                                               !ZZZ
;    5688  1          EH_2,                                               !ZZZ
;    5689  1          EH_3,                                               !ZZZ
;    5690  1          EH_4,                                               !ZZZ
;    5691  1          EH_5,                                               !ZZZ
;    5692  1          EH_6,                                               !ZZZ
;    5693  1          EH_7,                                               !ZZZ
;    5694  1          EH_8,                                               !ZZZ
;    5695  1          EH_9,                                               !ZZZ
;    5696  1          EH_10,                                              !ZZZ
;    5697  1          EH_12,                                              !ZZZ
;    5698  1          EH_13,                                              !ZZZ
;    5699  1          SWM1,
;    5700  1          NULL,
;    5701  1          SWP_FLAGS : word,
;    5702  1          L$HIMEM,
;    5703  1          L$LUN,
;    5704  1          L$UNIT;
;    5705  1      !   O_BRK;
;    5706  1
;    5707  1      own
;    5708  1      !MMM    TBL_SUC : vector [17] initial (NULL, SC_SDI, SC CON, NULL, SC_DUP, NULL, NULL,
```

```
;    5709  1      !MMM            NULL, SC_ONL, NULL, NULL, NULL, NULL, NULL, NULL, NULL, SC_SON),
;    5710  1          TBL_SUC : vector [19] initial (NULL, SC_SDI, SC_CON, NULL, SC_DUP, NULL, NULL,
;    5711  1                    NULL, SC_ONL, NULL, NULL, NULL, NULL, NULL, NULL, NULL, SC_SON, SC_INR, SC_INV),       !MMM
;    5712  1          TBL_OFL : vector [9] initial (SC_UNK, SC_VOL, SC_IOP, NULL, SC_DUP, NULL, NULL,
;    5713  1                    NULL, SC_DIS),
;    5714  1          TBL_MFE : vector [11] initial (SC_FER, NULL, SC_ISH, SC_DST, SC_EC9, SC_576,
;    5715  1                    SC_FCT, SC_ECC, SC_RCT, SC_FUL, SC_EC1),
;    5716  1      !MMM    TBL_WPT : vector [3] initial (NULL, SC_SWP, SC_HWP),
;    5717  1          TBL_WPT : vector [4] initial (NULL, SC_SWP, SC_HWP, SC_SAF),                                      !MMM
;    5718  1          TBL_DAT : vector [16] initial (SC_FE2, NULL, SC_IS2, SC_DS2, SC_EC9, NULL, NULL,
;    5719  1                    SC_ECD, SC_EC1, SC_EC2, SC_EC3, SC_EC4, SC_EC5, SC_EC6, SC_EC7, SC_EC8),
;    5720  1          TBL_HST : vector [5] initial (NULL, SC_ODA, SC_ODB, SC_NXM, SC_PAR),
;    5721  1          TBL_CNT : vector [4] initial (SC_CTO, SC_SDS, SC_EDC, SC_IDS),
;    5722  1          TBL_DRV : vector [9] initial (NULL, SC_SRT, SC_SRI, SC_POE, SC_RDY, SC_CLK, SC_RSP,
;    5723  1                    SC_SUR, SC_PSP),
;    5724  1          TBL_BRC : vector [5] initial (SC_REP, SC_NBB, SC_REF, SC_REF, SC_REF);                            !MMM
;    5725  1
;    5726  1
```

```
;    5727  1     %sbttl 'TYPE AND DESCRIPTION'
;    5728  1
;    5729  1     EQUALS;
;    5730  1
;    5731  1     DEVTYP (%asciz RQDX or RUX50');                 ! NAME OF DEVICE SUPPORTED BY PROGRAM
;    5732  1     DESCRIPT (%asciz RD/RX EXERCISER );      ! TEST DESCRIPTION
```

```
;    5733  1      %sbttl 'HARDWARE PARAMETER CODING SECTION'
;    5734  1
;    5735  1      !+
;    5736  1      ! THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
;    5737  1      ! THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
;    5738  1      ! MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
;    5739  1      ! INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
;    5740  1      ! MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
;    5741  1      ! WITH THE OPERATOR.
;    5742  1      !-
;    5743  1
;    5744  1      BGNHRD;
;    5745  1
;    5746  1      GPRMA (HWQ1, 0, 0, %c'160000', %o'177777', YES, 1);                     ! IP ADDRESS
;    5747  1      GPRMA (HWQ2, 2, 0, %o'4', %o'774', YES, 1);                             ! VECTOR
;    5748  1      GPRMD (HWQ3, 4, 0, %o'377', %o'0', %o'7', YES, 1);                      ! BR LEVEL
;    5749  1      GPRMD (HWQ4, 6, 0, %o'17', %decimal'0', %decimal'15', YES, 1);          ! RDRX DRIVE NUMBER
;    5750  1      !MMMGPRML (HWQ10, 6, %o'000040', YES, 1);                                     !ALSO RUN DUP EXERCISER      ZZZ
;    5751  1      !MMMXFERF (NODU);                                                        !                            ZZZ
;    5752  1      !MMMGPRML (HWQ11, 6, %o'000100', YES, 1);                                     !WRITE DIAG AREA             ZZZ
;    5753  1      !MMM$L (NODU);                                                           !                            ZZZ
;    5754  1      GPRML (HWQ5, 6, %o'000200', YES, 1);                                    !TEST ENTIRE CUSTOMER AREA?  ZZZ
;    5755  1      XFERT (TOQ8);                                                           !BR IF YES                   ZZZ
;    5756  1      GPRMD (HWQ6A, 8, 0, %o'177777', %decimal'0', %o'177777', YES, 1);       ! STARTING LBN LO            ZZZ
;    5757  1      GPRMD (HWQ6B, 10, 0, %o'177777', %decimal'0', %o'177777', YES, 1);      ! STARTING LBN HI            ZZZ
;    5758  1      GPRMD (HWQ7A, 12, 0, %o'177777', GP$ATLO (8), %o'177777', YES, 1);      ! ENDING LBN LO              ZZZ
;    5759  1      GPRMD (HWQ7B, 14, 0, %o'177777', %decimal'0', %o'177777', YES, 1);      ! ENDING LBN HI              ZZZ
;    5760  1      $L (TOQ8);                                                              !                            ZZZ
;    5761  1      GPRML (HWQ8, 6, %o'100000', NO, 0);                                     ! WRITE ON CUST DATA AREA
;    5762  1      XFERF (HWDONE);                                                         ! NO - DONE
;    5763  1      GPRML (HWQ9, 6, %o'100000', NO, 1);                                     ! ** WARNING / CONFIRM
;    5764  1      $L (HWDONE);
;    5765  1
;    5766  1      ENDHRD;
```

```
;    5767  1     %sbttl  SOFTWARE PARAMETER CODING SECTION'
;    5768  1
;    5769  1     !+
;    5770  1     ! THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
;    5771  1     ! THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES.  THE
;    5772  1     ! MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
;    5773  1     ! INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES.  THE
;    5774  1     ! MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
;    5775  1     ! WITH THE OPERATOR.
;    5776  1     !-
;    5777  1
;    5778  1     BGNSFT;
;    5779  1
;    5780  1     !GPRML (SWQ16, 4, SWF_TRC, YES, 1);                     ! ENABLE DIAGNOSTIC TRACE
;    5781  1     GPRMD (SWQ24, 10, D, %o'177777', 0, 2359, YES, 1);      ! START TIME
;    5782  1     GPRMD (SWQ1, 0, D, %o'177777', 0, 65535, YES, 1);       ! ERROR LIMIT
;    5783  1     GPRMD (SWQ2, 2, D, %o'177777', 0, 99, YES, 1);          ! TRANSFER LIMIT
;    5784  1     GPRMD (SWQ17, 8, D, %o'177777', 0, 100, YES, 1);        ! PERCENT OF RD OPERATIONS
;    5785  1     CPRML (SWQ15, 4, SWF_CST, YES, 1);                      ! CLEAR STATISTICAL TABLES ?
;    5786  1     GPRML (SWQ20, 4, SWF_FER, YES, 1);                      ! REWRITE BLOCKS WHEN "FORCED ERROR" BIT SET?
;    5787  1     GPRML (SWQ23, 4, SWF_BLK, YES, 1);                      ! HALT ON BAD-BLOCK TYPE ERRORS WITH 'HOE' FLAG?
;    5788  1     GPRML (SWQ21, 4, SWF_HRD, YES, 1);                      ! HALT ON HARD ERRORS WITH 'HOE' FLAG SET?
;    5789  1     GPRML (SWQ22, 4, SWF_SFT, YES, 1);                      ! HALT ON SOFT ERRORS WITH 'HOE' FLAG SET?
;    5790  1     !MMMGPRML (SWQ25, 4, SWF_TRY, YES, 1);                  ! COUNT EACH RETRY AS ANOTHER SOFT-ERROR?
;    5791  1     GPRML (SWQ4, 4, SWF_RDM, YES, 1);                       ! RANDOM SEEK MODE ?
;    5792  1     XFERF (SW1);                                            ! IF NO, DO NEXT QUESTION
;    5793  1     XFER (SW2);                                             !
;    5794  1     %L (SW1);                                               !
;    5795  1     GPRML (SWQ19, 4, SWF_SEQ, YES, 1);                      ! RANDOM OR SEQUENTIAL SELECTION OF DRIVES
;    5796  1     %L (SW2);                                               !
;    5797  1     GPRML (SWQ7, 4, SWF_CRC, YES, 1);                       ! READ-COMPARES AT CONTROLLER ?
;    5798  1     GPRML (SWQ26, 4, SWF_APT, YES, 1);                      !RUNNING UNDER A.P.T. MONITOR?          ZZZ
;    5799  1     DISPLAY (SWM1);                                         ! REMAINING QUESTIONS ONLY APPLY ...
;    5800  1     GPRML (SWQ9, 4, SWF_CWC, YES, 1);                       ! WRITE-COMPARES AT CONTROLLER ?
;    5801  1     XFERF (SW3);                                            ! IF NO, DO NEXT QUESTION
;    5802  1     XFER (SW4);                                             !
;    5803  1     %L (SW3);                                               !
;    5804  1     GPRML (SWQ10, 4, SWF_HWC, YES, 1);                      ! CHECK WRITES AT HOST BY READING ?
;    5805  1     %L (SW4);                                               !
;    5806  1     GPRML (SWQ11, 4, SWF_UDP, YES, 1);                      ! USER-DEFINED DATA PATTERN ?
;    5807  1     XFERF (SW5);                                            ! IF NO, DO NEXT QUESTION
;    5808  1     XFER (SW6);                                             !
;    5809  1     %L (SW5);                                               !
;    5810  1     GPRMD (SWQ12, 6, D, %o'177777', 0, DP_CNT, YES, 1);     ! SELECT PRE-DEFINED DATA PATTERN
;    5811  1     XFER (SW7);                                             ! DONE
;    5812  1     %L (SW6);                                               !
;    5813  1     GPRMD (SWQ13, 12, D, %o'177777', 1, MAX_UDP_CNT, YES, 1);! NO. OF WORDS IN USER DATA PATTERN
;    5814  1     !MMMGPRMD (SWQ14, 14, D, %o'177777', 0, %o'177777', NO, 12);! PATTERN VALUES
;    5815  1     GPRMD (SWQ14, 14, D, %o'177777', 0, %o'177777', YES, 12);! PATTERN VALUES MMM
;    5816  1     %L (SW7);
;    5817  1     GPRML (SWQ27, 48, %o'000001', YES, 1);                          ! Manufacturing Test (Reduce Duty Cycle) MMM
;    5818  1     GPRML (SWQ28, 50, %o'000001', YES, 1);                           ! Enable Host Memory Parity MMM
;    5819  1     ENDSFT;
```

```
;    5820  1
;    5821  1
;    5822  1     %sbttl 'REPORT CODING SECTION'
;    5823  1
;    5824  1
;    5825  1     !+
;    5826  1     ! THE REPORT CODING SECTION CONTAINS THE
;    5827  1     ! "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.
;    5828  1     !-
;    5829  1
;    5830  1
;    5831  2     BGNRPT;
;    5832  2
;    5833  2     local
;    5834  2         CUR_PRIORITY : word;
;    5835  2
;    5836  2     GETPRI (CUR_PRIORITY);
;    5837  2     !ZZZ SETPRI (PRIO4);                                    !ZZZ
;    5838  2     SETPRI (.BRLEVEL);                              !ZZZ
;    5839  2
;    5840  2
;    5841  2     PRINTS (RPT1);
;    5842  2     PRINTS (RPT2);
;    5843  2     PRINTS (RPT3);
;    5844  2     PRINTS (RPT4);
;    5845  2     PRINTS (RPT5);
;    5846  2     PRINTS (RPT6);
;    5847  2
;    5848  2     incr CTLR from 0 to MAX_CTLR - 1 do
;    5849  2
;    5850  3         begin
;    5851  3         SET_CPAR (.CTLR);
;    5852  3
;    5853  3         incr DISK from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do
;    5854  3
;    5855  4             begin
;    5856  4             SET_UPAR (.DISK);
;    5857  4
;    5858  4
;    5859  4             if .CST_ADDR [.DISK + OF_DATA, D_PRES] eql PRESENT
;    5860  4             then
;    5861  4
;    5862  5                 begin
; P  5863  5                 PRINTS (RPT7,
;    5864  5                     .L$LUN, .CST_ADDR [.DISK + OF_DATA, D_DISK_NUM], CST [.CTLR, .DISK + OF_NAME_0, D_NAME_0]);
; P  5865  5                 PRINTS (RPT8,
; P  5866  5                     .T_ADDR [TOT_READS_HI], .T_ADDR [TOT_READS_LO],
;    5867  5                     .T_ADDR [MTOT_BYT_RED], .T_ADDR [TOT_BYT_RED_HI], .T_ADDR [TOT_BYT_RED_LO]);
; P  5868  5                 PRINTS (RPT8,
; P  5869  5                     .T_ADDR [TOT_WRITES_HI], .T_ADDR [TOT_WRITES_LO],
;    5870  5                     .T_ADDR [MTOT_BYT_WRT], .T_ADDR [TOT_BYT_WRT_HI], .T_ADDR [TOT_BYT_WRT_LO]);
; P  5871  5                 PRINTS (RPT9,
; P  5872  5                     .T_ADDR [ERR_HRD_SEK], .T_ADDR [ERR_HRD_DAT], .T_ADDR [ERR_HRD_DRV], .T_ADDR [ERR_HRD_HST],
```

```
;    5873  5                      .T_ADDR [ERR_SFT_SEK], .T_ADDR [ERR_SFT_DAT], .T_ADDR [ERR_SFT_DRV], .T_ADDR [ERR_SFT_HST]);
;    5874  4                  end;
;    5875  3              end;
;    5876  3
;    5877  3
;    5878  3          ;f .CST [.CTLR, STATE] eql PRESENT
;    5879  3          then
;    5880  3
;    5881  4              begin
;    5882  4              PRINTS (RPT10);
;    5883  4              PRINTS (RPT11, .C_ERR_TBL [.CTLR, C_ERR_HRD], .C_ERR_TBL [.CTLR, C_ERR_SFT]);
;    5884  3              end;
;    5885  3
;    5886  3
;    5887  2          end;
;    5888  2
;    5889  2      SETPRI (.CUR_PRIORITY);
;    5890  2
;    5891  2      !MMMIF .RD_COUNT NEQ 0                                                  !IF THERE IS A WINCHESTER      ZZZ
;    5892  2      !MMMTHEN                                                                !THEN OUTPUT EXTRA LINES       ZZZ
;    5893  2
;    5894  2      !MMMbegin                                                                   ! PRINTS DUP DATA
;    5895  2      !MMMprints(crlf);
;    5896  2      !MMMPRINTS(RPT13);
;    5897  2      !MMMPRINTS(PPT14);
;    5898  2      !MMMPRINTS(RPT15);
;    5899  2      !MMMINCR CTLR FROM 0 TO MAX_CTLR-1 DO
;    5900  2      !MMM            BEGIN
;    5901  2      !MMM    SET_CPAR(.CTLR);
;    5902  2      !MMM    INCR DISK FROM (0+OF_UN) TO (3*UNIT_SIZE+OF_UN) BY UNIT_SIZE DO
;    5903  2      !MMM            BEGIN
;    5904  2      !MMM            SET_UPAR(.DISK);
;    5905  2      !MMM            IF .CST_ADDR[.DISK, D_TYPE] EQLU RD_51 and .CST_ADDR [.DISK, D_PRES] eql PRESENT
;    5906  2      !MMM            THEN
;    5907  2      !MMM        PRINTS (RPT16,
;    5908  2      !MMM            .L$LUN, .CST_ADDR [.DISK, D_DISK_NUM],
;    5909  2      !MMM            .T_ADDR [T_DBN_RD], .T_ADDR [T_BLK_RD], .T_ADDR [T_DBN_WT], .T_ADDR [T_BLK_WT]);
;    5910  2
;    5911  2      !ZZZ            IF .CST_ADDR[.DISK, D_TYPE] EQLU RD_52 and .CST_ADDR [.DISK, D_PRES] eql PRESENT
;    5912  2      !ZZZ            THEN
;    5913  2      !ZZZ        PRINTS (RPT18,
;    5914  2      !ZZZ            .L$LUN, .CST_ADDR [.DISK, D_DISK_NUM],
;    5915  2      !ZZZ            .T_ADDR [T_DBN_RD], .T_ADDR [T_BLK_RD], .T_ADDR [T_DBN_WT], .T_ADDR [T_BLK_WT]);
;    5916  2      !MMM            END;
;    5917  2      !MMM    END;
;    5918  2      !MMM          PRINTS (CRLF);
;    5919  2      !MMMEND;
;    5920  2
;    5921  2      PRINTS (CRLF);                                  !MMM
;    5922  2      EMS_TIM ();                                     !MMM
;    5923  2
;    5924  1      ENDRPT;
```

```
                                        .TITLE  ZRQAM2 RD/RX EXERCISER
                                        .IDENT  /V02.3/
                                        .ENABL  AMA

000000                                  .PSECT  $CODE$,  RO
000000     122     121     104  L$DVTYP::
                                        .ASCII  /RQD/
000003     130     040     157          .ASCII  /X o/
000006     162     040     122          .ASCII  /r R/
000011     125     130     065          .ASCII  /UX5/
000014     060     000                  .ASCII  /0/<00>
000016                                  .BLKB   2
000020     122     104     057  L$DESC::.ASCII  /RD/<57>
000023     122     130     040          .ASCII  /RX /
000026     105     130     105          .ASCII  /EXE/
000031     122     103     111          .ASCII  /RCI/
000034     123     105     122          .ASCII  /SER/
000037     000                          .ASCII  <00>
000040                                  .BLKB   2
000042  000000C                 L$HRDLN::
                                        .WORD   <<<L$NDHRD-L$HRDLN>/2>-1>
000044  000031                  GP$1::  .WORD   31
000046  000000G                         .WORD   HWQ1
000050  160000                          .WORD   -20000
000052  177777                          .WORD   -1
000054  001031                  GP$2::  .WORD   1031
000056  000000G                         .WORD   HWQ2
000060  000004                          .WORD   4
000062  000774                          .WORD   774
000064  002032                  GP$3::  .WORD   2032
000066  000000G                         .WORD   HWQ3
000070  000377                          .WORD   377
000072  000000                          .WORD   0
000074  000007                          .WORD   7
000076  003052                  GP$4::  .WORD   3052
000100  000000G                         .WORD   HWQ4
000102  000017                          .WORD   17
000104  000000                          .WORD   0
000106  000017                          .WORD   17
000110  003130                  GP$5::  .WORD   3130
000112  000000G                         .WORD   HWQ5
000114  000200                          .WORD   200
000116  000000C                 $TOQ8:  .WORD   <<<<$LTOQ8-$TOQ8>*400>+4>+20>
000120  004032                  GP$6::  .WORD   4032
000122  000000G                         .WORD   HWQ6A
000124  177777                          .WORD   -1
000126  000000                          .WORD   0
000130  177777                          .WORD   -1
000132  005032                  GP$7::  .WORD   5032
000134  000000G                         .WORD   HWQ6B
000136  177777                          .WORD   -1
```

```
000140  000000                          .WORD   0
000142  177777                          .WORD   -1
000144  006432              GP$ ::      .WORD   6432
000146  000000G                         .WORD   HWQ7A
000150  177777                          .WORD   -1
000152  000004                          .WORD   4
000154  177777                          .WORD   -1
000156  000001                          .WORD   1
000160  007032              GP$9::      .WORD   7032
000162  000000G                         .WORD   HWQ7B
000164  177777                          .WORD   -1
000166  000000                          .WORD   0
000170  177777                          .WORD   -1
000172  001004              $LTOQ8:     .WORD   1004
000174  003120              GP$10::     .WORD   3120
000176  000000G                         .WORD   HWQ8
000200  100000                          .WORD   -100000
000202  000000C              $HWDONE:.  WORD   <<<<$LHWDONE-$HWDONE>*400>+4>+40>
000204  003120              GP$11::     .WORD   3120
000206  000000G                         .WORD   HWQ9
000210  100000                          .WORD   -100000
000212  001004              $LHWDONE:
                                        .WORD   1004
000214                      L$NDHRD::
                                        .BLKW   1
000216  000000C             L$SFTLN::
                                        .WORD   <<<L$NDSFT-L$SFTLN>/2>-1>
000220  005052              GP$12::     .WORD   5052
000222  000000G                         .WORD   SWQ24
000224  177777                          .WORD   -1
000226  000000                          .WORD   0
000230  004467                          .WORD   4467
000232  000052              GP$13::     .WORD   52
000234  000000G                         .WORD   SWQ1
000236  177777                          .WORD   -1
000240  000000                          .WORD   0
000242  177777                          .WORD   -1
000244  001052              GP$14::     .WORD   1052
000246  000000G                         .WORD   SWQ2
000250  177777                          .WORD   -1
000252  000000                          .WORD   0
000254  000143                          .WORD   143
000256  004052              GP$15::     .WORD   4052
000260  000000G                         .WORD   SWQ17
000262  177777                          .WORD   -1
000264  000000                          .WORD   0
000266  000144                          .WORD   144
000270  002130              GP$16::     .WORD   2130
000272  000000G                         .WORD   SWQ15
000274  000200                          .WORD   200
000276  002130              GP$17::     .WORD   2130
000300  000000G                         .WORD   SWQ20
000302  004000                          .WORD   4000
```

```
000304  002130                          GP$18::  .WORD   2130
000306  000000G                                  .WORD   SWQ23
000310  040000                                   .WORD   40000
000312  002130                          GP$19::  .WORD   2130
000314  000000G                                  .WORD   SWQ21
000316  010000                                   .WORD   10000
000320  002130                          GP$20::  .WORD   2130
000322  000000G                                  .WORD   SWQ22
000324  020000                                   .WORD   20000
000326  002130                          GP$21::  .WORD   2130
000330  000000G                                  .WORD   SWQ4
000332  000002                                   .WORD   2
000334  000000C                         $SW1:    .WORD   <<<<$LSW1-$SW1>*400>+4>+40>
000336  000000C                         $SW2:    .WORD   <<<$LSW2-$SW2>*400>+4>
000340  001004                          $LSW1:   .WORD   1004
000342  002130                          GP$22::  .WORD   2130
000344  000000G                                  .WORD   SWQ19
000346  001000                                   .WORD   1000
000350  001004                          $LSW2:   .WORD   1004
000352  002130                          GP$23::  .WORD   2130
000354  000000G                                  .WORD   SWQ7
000356  000004                                   .WORD   4
000360  002130                          GP$24::  .WORD   2130
000362  000000G                                  .WORD   SWQ26
000364  000001                                   .WORD   1
000366  000003                          GP$DISP::
                                                 .WORD   3
000370  000000G                                  .WORD   SWM1
000372  002130                          GP$25::  .WORD   2130
000374  000000G                                  .WORD   SWQ9
000376  000020                                   .WORD   20
000400  000000C                         $SW3:    .WORD   <<<<$LSW3-$SW3>*400>+4>+40>
000402  000000C                         $SW4:    .WORD   <<<$LSW4-$SW4>*400>+4>
000404  001004                          $LSW3:   .WORD   1004
000406  002130                          GP$26::  .WORD   2130
000410  000000G                                  .WORD   SWQ10
000412  000040                                   .WORD   40
000414  001004                          $LSW4:   .WORD   1004
000416  002130                          GP$27::  .WORD   2130
000420  000000G                                  .WORD   SWQ11
000422  000100                                   .WORD   100
000424  000000C                         $SW5:    .WORD   <<<<$LSW5-$SW5>*400>+4>+40>
000426  000000C                         $SW6:    .WORD   <<<$LSW6-$SW6>*400>+4>
000430  001004                          $LSW5:   .WORD   1004
000432  003052                          GP$28::  .WORD   3052
000434  000000G                                  .WORD   SWQ12
000436  177777                                   .WORD   -1
000440  000000                                   .WORD   0
000442  000025                                   .WORD   25
000444  000000C                         $SW7:    .WORD   <<<$LSW7-$SW7>*400>+4>
000446  001004                          $LSW6:   .WORD   1004
000450  006052                          GP$29::  .WORD   6052
000452  000000G                                  .WORD   SWQ13
```

```
000454  177777                          .WORD   -1
000456  000001                          .WORD   1
000460  000020                          .WORD   20
000462  007232          GP$30::         .WORD   7232
000464  000000G                         .WORD   SWQ14
000466  177777                          .WORD   -1
000470  000000                          .WORD   0
000472  177777                          .WORD   -1
000474  000006                          .WORD   6
000476  001004          $LSW7:          .WORD   1004
000500  030130          GP$31::         .WORD   30130
000502  000000G                         .WORD   SWQ27
000504  000001                          .WORD   1
000506  031130          GP$32::         .WORD   31130
000510  000000G                         .WORD   SWQ28
000512  000001                          .WORD   1
000514                  L$NDSFT::
                                        .BLKW   1


000000                                  .PSECT  $OWN$,  D
000000  000000G          TBL.SUC::       .WORD   NULL
000002  000000G                         .WORD   SC.SDI
000004  000000G                         .WORD   SC.CON
000006  000000G                         .WORD   NULL
000010  000000G                         .WORD   SC.DUP
000012  000000G                         .WORD   NULL
000014  000000G                         .WORD   NULL
000016  000000G                         .WORD   NULL
000020  000000G                         .WORD   SC.ONL
000022  000000G                         .WORD   NULL
000024  000000G                         .WORD   NULL
000026  000000G                         .WORD   NULL
000030  000000G                         .WORD   NULL
000032  000000G                         .WORD   NULL
000034  000000G                         .WORD   NULL
000036  000000G                         .WORD   NULL
000040  000000G                         .WORD   SC.SON
000042  000000G                         .WORD   SC.INR
000044  000000G                         .WORD   SC.INV
000046  000000G          TBL.OFL::       .WORD   SC.UNK
000050  000000G                         .WORD   SC.VOL
000052  000000G                         .WORD   SC.IOP
000054  000000G                         .WORD   NULL
000056  000000G                         .WORD   SC.DUP
000060  000000G                         .WORD   NULL
000062  000000G                         .WORD   NULL
000064  000000G                         .WORD   NULL
000066  000000G                         .WORD   SC.DIS
000070  000000G          TBL.MFE::       .WORD   SC.FER
000072  000000G                         .WORD   NULL
000074  000000G                         .WORD   SC.ISH
```

```
000076  000000G                                 .WORD   SC.DST
000100  000000G                                 .WORD   SC.EC9
000102  000000G                                 .WORD   SC.576
000104  000000G                                 .WORD   SC.FCT
000106  000000G                                 .WORD   SC.ECC
000110  000000G                                 .WORD   SC.RCT
000112  000000G                                 .WORD   SC.FUL
000114  000000G                                 .WORD   SC.EC1
000116  000000G                         TBL.WPT:.WORD   NULL
000120  000000G                                 .WORD   SC.SWP
000122  000000G                                 .WORD   SC.MWP
000124  000000G                                 .WORD   SC.SAF
000126  000000G                         TBL.DAT:.WORD   SC.FE2
000130  000000G                                 .WORD   NULL
000132  000000G                                 .WORD   SC.IS2
000134  000000G                                 .WORD   SC.DS2
000136  000000G                                 .WORD   SC.EC9
000140  000000G                                 .WORD   NULL
000142  000000G                                 .WORD   NULL
000144  000000G                                 .WORD   SC.ECD
000146  000000G                                 .WORD   SC.EC1
000150  000000G                                 .WORD   SC.EC2
000152  000000G                                 .WORD   SC.EC3
000154  000000G                                 .WORD   SC.EC4
000156  000000G                                 .WORD   SC.EC5
000160  000000G                                 .WORD   SC.EC6
000162  000000G                                 .WORD   SC.EC7
000164  000000G                                 .WORD   SC.EC8
000166  000000G                         TBL.HST:.WORD   NULL
000170  000000G                                 .WORD   SC.ODA
000172  000000G                                 .WORD   SC.ODB
000174  000000G                                 .WORD   SC.NXM
000176  000000G                                 .WORD   SC.PAR
000200  000000G                         TBL.CNT:.WORD   SC.CTO
000202  000000G                                 .WORD   SC.SDS
000204  000000G                                 .WORD   SC.EDC
000206  000000G                                 .WORD   SC.IDS
000210  000000G                         TBL.DRV:.WORD   NULL
000212  000000G                                 .WORD   SC.SRT
000214  000000G                                 .WORD   SC.SRI
000216  000000G                                 .WORD   SC.POE
000220  000000G                                 .WORD   SC.RDY
000222  000000G                                 .WORD   SC.CLK
000224  000000G                                 .WORD   SC.RSP
000226  000000G                                 .WORD   SC.SUR
000230  000000G                                 .WORD   SC.PSP
000232  000000G                         TBL.BRC:.WORD   SC.REP
000234  000000G                                 .WORD   SC.NBB
000236  000000G                                 .WORD   SC.REF
000240  000000G                                 .WORD   SC.REF
000242  000000G                                 .WORD   SC.REF
```

```
.GLOBL  CST, CST.ADDR, DCT, DCT.ADDR, RDRX.ADDR
.GLOBL  IRDRX.ADDR, BST, TALLY, T.ADDR
.GLOBL  TRK.SGN, RDM.CNT, RANDOM, C.ERR.TBL
.GLOBL  MSCP.PKT, IPKT.ADDR, PKT.USE, RETPKT
.GLOBL  RP.USE, RP.INDX, RP.ADDR, ELOG.PKT
.GLOBL  BUFF.ADDR, BUFF.OWN, IODQ, IODQ.IN
.GLOBL  IODQ.OUT, ENTRY.REASON, EOP.FLAG
.GLOBL  DUP.FLAGS, CCTLR, CDISK, CUOFF
.GLOBL  CTLR.CNT, DUR, QIO, FREE.MEM.ADDR
.GLOBL  BYTS.PER.QIO, ST.CODE, SB.CODE
.GLOBL  STEP, OF.RC, SA.REG, CMD.TIME
.GLOBL  NEX, CRN.LOW, CRN.HIGH, TEMP1
.GLOBL  TEMP2, CREDIT.BAL, NEXT.PKT.USE
.GLOBL  HOURS, MINUTES, CLK.TICKS, FERO.LBN
.GLOBL  FER1.LBN, CLK.PRESENT, HOE.FLAG
.GLOBL  FORCED.ERROR, FER.LBN, FER.BC
.GLOBL  INIT.OCCURED, ADDR.VECT.OK, DBM5
.GLOBL  DBM125, DBM126, TYPER, TYPEW, BAL.IN.PROGRESS
.GLOBL  FORCE.WR, CSR.MEM, CSR.ADD, P.INDEX
.GLOBL  RD.COUNT, BRLEVEL, D.FAIL, DBM107
.GLOBL  DU.MSG, DU.RSN, RPT1, RPT2, RPT3
.GLOBL  RPT4, RPT5, RPT6, RPT7, RPT8, RPT9
.GLOBL  RPT10, RPT11, RPT12, RPT13, RPT14
.GLOBL  RPT15, RPT16, MSG.01, EGS.01, EBS.01
.GLOBL  EBD.10, EBD.12, EBD.13, EBD.14
.GLOBL  EBD.18, EBD.19, EBD.24, ERR.00
.GLOBL  ERR.COD, ELG.00, ELG.FMT, EX.TIM
.GLOBL  EX.LB, XX13, XX23, XX32, XX33
.GLOBL  XX34, EX.SA, EX.SC, EX.SBO, EX.SB
.GLOBL  EX.RP, EX.WRD, EX.CMD, EX.RD, EX.WRT
.GLOBL  EX.CMP, EX.ONL, EX.ACC, EX.OP
.GLOBL  EX.BB2, EX.BB12, EX.BBU2, EX.LBN2
.GLOBL  EX.PBN2, EX.LBR2, EX.LBW2, EX.RBN2
.GLOBL  EX.CBC, EX.CBR, EX.CBW, EX.BC
.GLOBL  EX.BD, EX.BDR, EX.BDW, SC.SDI
.GLOBL  SC.CON, SC.DUP, SC.ONL, SC.SON
.GLOBL  SC.INR, SC.INV, SC.UNK, SC.VOL
.GLOBL  SC.IOP, SC.DIS, SC.FER, SC.FE2
.GLOBL  SC.ISH, SC.IS2, SC.DST, SC.DS2
.GLOBL  SC.ECC, SC.ECD, SC.RCT, SC.FUL
.GLOBL  SC.576, SC.FCT, SC.SWP, SC.HWP
.GLOBL  SC.SAF, SC.EC1, SC.EC2, SC.EC3
.GLOBL  SC.EC4, SC.EC5, SC.EC6, SC.EC7
.GLOBL  SC.EC8, SC.EC9, SC.ODA, SC.ODB
.GLOBL  SC.NXM, SC.PAR, SC.CTO, SC.SDS
.GLOBL  SC.EDC, SC.IDS, SC.SRT, SC.SRI
.GLOBL  SC.POE, SC.RDY, SC.CLK, SC.RSP
.GLOBL  SC.SUR, SC.PSP, SC.REP, SC.NBB
.GLOBL  SC.REF, CER.01, CER.02, CNTR.ERR
.GLOBL  RDRX.ERR, SPACE4, CRLF, DASH, ASTERISK
.GLOBL  HWQ1, HWQ2, HWQ3, HWQ4, HWQ5, HWQ6A
.GLOBL  HWQ6B, HWQ7A, HWQ7B, HWQ8, HWQ9
.GLOBL  SWQ1, SWQ2, SWQ4, SWQ7, SWQ9, SWQ10
```

```
                .GLOBL  SWQ11, SWQ12, SWQ13, SWQ14, SWQ15
                .GLOBL  SWQ17, SWQ19, SWQ20, SWQ21, SWQ22
                .GLOBL  SWQ23, SWQ24, SWQ26, SWQ27, SWQ28
                .GLOBL  EH.0, EH.1, EH.2, EH.3, EH.4, EH.5
                .GLOBL  EH.6, EH.7, EH.8, EH.9, EH.10
                .GLOBL  EH.12, EH.13, SWM1, NULL, SWP.FLAGS
                .GLOBL  L$HIMEM, L$LUN, L$UNIT

000001          ON==            1
000002          OFF==           2
100000          BIT15==         -100000
040000          BIT14==         40000
020000          BIT13==         20000
010000          BIT12==         10000
004000          BIT11==         4000
002000          BIT10==         2000
001000          BIT09==         1000
000400          BIT08==         400
000200          BIT07==         200
000100          BIT06==         100
000040          BIT05==         40
000020          BIT04==         20
000010          BIT03==         10
000004          BIT02==         4
000002          BIT01==         2
000001          BIT00==         1
001000          BIT9==          1000
000400          BIT8==          400
000200          BIT7==          200
000100          BIT6==          100
000040          BIT5==          40
000020          BIT4==          20
000010          BIT3==          10
000004          BIT2==          4
000002          BIT1==          2
000001          BIT0==          1
000035          EF.NEW==        35
000034          EF.PWR==        34
000040          EF.START==      40
000037          EF.RESTART==    37
000036          EF.CONTINUE==   36
000340          PRI07==         340
000300          PRI06==         300
000240          PRI05==         240
000200          PRI04==         200
000140          PRI03==         140
000100          PRI02==         100
000040          PRI01==         40
000000          PRI00==         0
000004          EVL==           4
000010          LOT==           10
000020          ADR==           20
```

```
000040          IDU==           40
000100          ISR==           100
000200          UAM==           200
000400          BOE==           400
001000          PNT==           1000
002000          PRI==           2000
004000          IXE==           4000
010000          IBE==           10000
020000          IER==           20000
040000          LOE==           40000
100000          HOE==           100000
000044'         L$HARD==        L$HRDLN*2
000220'          $SOFT==        L$SFTLN*2


                                .SBTTL  LRPT REPORT CODING SECTION
000516                          .PSECT  $CODE$,  RO

000000  004137  C00000G       LRPT:   JSR     R1,$SAVE4               ;                               5819
000004  104440                         TRAP    40                      ;                               5836
000006  010004                         MOV     R0,R4                   ; *,CUR.PRIORITY
000010  013700  000000G                MOV     BRLEVEL,R0              ;                               5838
000014  104441                         TRAP    41
000016  012746  000000G                MOV     #RPT1,-(SP)             ;                               5841
000022  012746  000001                 MOV     #1,-(SP)
000026  010600                         MOV     SP,R0                   ; SP,*
000030  104416                         TRAP    16
000032  012716  000000G                MOV     #RPT2,(SP)              ;                               5842
000036  012746  000001                 MOV     #1,-(SP)
000042  010600                         MOV     SP,R0                   ; SP,*
000044  104416                         TRAP    16
000046  012716  000000G                MOV     #RPT3,(SP)              ;                               5843
000052  012746  000001                 MOV     #1,-(SP)
000056  010600                         MOV     SP,R0                   ; SP,*
000060  104416                         TRAP    16
000062  012716  000000G                MOV     #RPT4,(SP)              ;                               5844
000066  012746  000001                 MOV     #1,-(SP)
000072  010600                         MOV     SP,R0                   ; SP,*
000074  104416                         TRAP    16
000076  012716  000000G                MOV     #RPT5,(SP)              ;                               5845
000102  012746  000001                 MOV     #1,-(SP)
000106  010600                         MOV     SP,R0                   ; SP,*
000110  104416                         TRAP    16
000112  012716  000000G                MOV     #RPT6,(SP)              ;                               5846
000116  012746  000001                 MOV     #1,-(SP)
000122  010600                         MOV     SP,R0                   ; SP,*
000124  104416                         TRAP    16
000126  005002                         CLR     R2                      ; CTLR                          5848
000130  010216                 1$:     MOV     R2,(SP)                 ; CTLR,*                        5851
000132  004737  000000V                JSR     PC,SET.CPAR
000136  012703  000003                 MOV     #3,R3                   ; *,DISK                        5853
000142  010316                 2$:     MOV     R3,(SP)                 ; DISK,*                        5856
000144  004737  000000V                JSR     PC,SET.UPAR
```

```
000150  010301                  MOV     R3,R1                           ; DISK,*                        5859
000152  006301                  ASL     R1
000154  063701  000000G         ADD     CST.ADDR,R1
000160  032711  040000          BIT     #40000,(R1)
000164  001535                  BFQ     3$
000166  010216                  MOV     R2,(SP)                         ; CTLR,*                        5864
000170  012746  000053          MOV     #53,-(SP)
000174  004737  000000G         JSR     PC,BL$MUL
000200  060300                  ADD     R3,R0                           ; DISK,*
000202  006300                  ASL     R0
000204  062700  000000G         ADD     #CST,R0
000210  010016                  MOV     R0,(SP)
000212  062716  000012          ADD     #12,(SP)
000216  111146                  MOVB    (R1),-(SP)
000220  042716  177760          BIC     #177760,(SP)
000224  013746  000000G         MOV     L$LUN,-(SP)
000230  012746  000000G         MOV     #RPT7,-(SP)
000234  012746  000004          MOV     #4,-(SP)
000240  010600                  MOV     SP,R0                           ; SP,*
000242  104416                  TRAP    16
000244  013700  000000G         MOV     T.ADDR,R0                       ;                               5867
000250  016016  000032          MOV     32(R0),(SP)
000254  016046  000034          MOV     34(R0),-(SP)
000260  016046  000036          MOV     36(R0),-(SP)
000264  016046  000016          MOV     16(R0),-(SP)
000270  016046  000020          MOV     20(R0),-(SP)
000274  012746  000000G         MOV     #RPT8,-(SP)
000300  012746  000006          MOV     #6,-(SP)
000304  010600                  MOV     SP,R0                           ; SP,*
000306  104416                  TRAP    16
000310  013700  000000G         MOV     T.ADDR,R0                       ;                               5870
000314  016016  000040          MOV     40(R0),(SP)
000320  016046  000042          MOV     42(R0),-(SP)
000324  016046  000044          MOV     44(R0),-(SP)
000330  016046  000024          MOV     24(R0),-(SP)
000334  016046  000026          MOV     26(R0),-(SP)
000340  012746  000000G         MOV     #RPT8,-(SP)
000344  012746  000006          MOV     #6,-(SP)
000350  010600                  MOV     SP,R0                           ; SP,*
000352  104416                  TRAP    16
000354  013700  000000G         MOV     T.ADDR,R0                       ;                               5873
000360  005016                  CLR     (SP)
000362  116016  000055          MOVB    55(R0),(SP)
000366  005046                  CLR     -(SP)
000370  116016  000054          MOVB    54(R0),(SP)
000374  005046                  CLR     -(SP)
000376  116016  000053          MOVB    53(R0),(SP)
000402  005046                  CLR     -(SP)
000404  116016  000052          MOVB    52(R0),(SP)
000410  005046                  CLR     -(SP)
000412  116016  000051          MOVB    51(R0),(SP)
000416  005046                  CLR     -(SP)
000420  116016  000050          MOVB    50(R0),(SP)
```

```
000424  005046                          CLR     -(SP)
000426  116016  000047                  MOVB    47(R0),(SP)
000432  005046                          CLR     -(SP)
000434  116016  000046                  MOVB    46(R0),(SP)
000440  012746  000000G                 MOV     #RPT9,-(SP)
000444  012746  000011                  MOV     #11,-(SP)
000450  010600                          MOV     SP,R0                   ; SP,*
000452  104416                          TRAP    16
000454  062706  000064                  ADD     #64,SP                  ;                               5862
000460  062703  000012          3$:     ADD     #12,R3                  ; *,DISK                        5853
000464  020327  000041                  CMP     R3,#41                  ; DISK,*
000470  003624                          BLE     2$
000472  010216                          MOV     R2,(SP)                 ; CTLR,*                        5878
000474  012746  000126                  MOV     #126,-(SP)
000500  004737  000000G                 JSR     PC,@L$MUL
000504  005726                          TST     (SP)+
000506  005760  000002G                 TST     CST+2(R0)
000512  100026                          BPL     4$
000514  012716  000000G                 MOV     #RPT10,(SP)             ;                               5882
000520  012746  000001                  MOV     #1,-(SP)
000524  010600                          MOV     SP,R0                   ; SP,*
000526  104416                          TRAP    16
000530  010200                          MOV     R2,R0                   ; CTLR,*                        5883
000532  006300                          ASL     R0
000534  005016                          CLR     (SP)
000536  116016  000001G                 MOVB    C.ERR.TBL+1(R0),(SP)
000542  005046                          CLR     -(SP)
000544  116016  000000G                 MOVB    C.ERR.TBL(R0),(SP)
000550  012746  000000G                 MOV     #RPT11,-(SP)
000554  012746  000003                  MOV     #3,-(SP)
000560  010600                          MOV     SP,R0                   ; SP,*
000562  104416                          TRAP    16
000564  062706  000010                  ADD     #10,SP                  ;                               5881
000570  005202                  4$:     INC     R2                      ; CTLR                          5848
000572  000243                          .WORD CLV!CLC

000574  003002                          BGT     5$
000576  000137  000646'                 JMP     1$
000602  010400                  5$:     MOV     R4,R0                   ; CUR.PRIORITY,*                5889
000604  104441                          TRAP    41
000606  012716  000000G                 MOV     #CRLF,(SP)              ;                               5921
000612  012746  000001                  MOV     #1,-(SP)
000616  010600                          MOV     SP,R0                   ; SP,*
000620  104416                          TRAP    16
000622  004737  000000V                 JSR     PC,@EMS.TIM             ;                               5922
000626  062706  000020                  ADD     #20,SP                  ;                               5819
000632  000207                          RTS     PC

; Routine Size:  206 words,    Routine Base:  $CODE$ + 0516
; Maximum stack depth per invocation:  40 words
```

```
                                        .SBTTL  L$RPT REPORT CODING SECTION
000000  004737  000516'        L$RPT:: JSR     PC,LRPT                 ;                       5922
000004  104425                          TRAP    25
000006  000207                          RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 1352
; Maximum stack depth per invocation:  2 words


;   5925  1
```

```
;  5926  1     %sbttl 'INITIALIZE SECTION'
;  5927  1
;  5928  2     BGNINIT;
;  5929  2
;  5930  2     local
;  5931  2         DELAY_MULT : word,
;  5932  2         FLAG : byte,
;  5933  2         TEMP : word,
;  5934  2         HWPT_REF : ref block [HWPT_LEN, word] field (HWP_FIELDS),
;  5935  2         CLEAR_TABLES : byte,
;  5936  2         SMALLEST_DRIVE : byte,
;  5937  2         BLANKS : WORD INITIAL (%o'020040'),                          !ZZZ
;  5938  2         HWPT_ADDRESS : vector [MAX_UNITS, word];
;  5939  2
;  5940  2     SETPRI (PRI07);                                                  ! NO INTERRUPTS ALLOWED DURING INIT
;  5941  2
;  5942  2     if READEF (EF_NEW)                                               ! IS THIS A NEW PASS?
;  5943  2     then
;  5944  3         begin
;  5945  3         ENTRY_REASON = NEW_PASS;
;  5946  3
;  5947  4         if not BIT_TST (SWP_FLAGS, SWF_CST)
;  5948  3         then
;  5949  3             CLEAR_TABLES = FALSE
;  5950  3         else
;  5951  3             CLEAR_TABLES = TRUE;
;  5952  3
;  5953  2         end;
;  5954  2
;  5955  2     if READEF (EF_START)                                             ! IS THIS A START?
;  5956  2     then
;  5957  3         begin
;  5958  3         BRESET;
;  5959  3         ENTRY_REASON = START;
;  5960  3         CLEAR_TABLES = TRUE;
;  5961  3         ADDR_VECT_OK = FALSE;
;  5962  3         INIT_OCCURED = FALSE;
;  5963  2         end;
;  5964  2
;  5965  2     if READEF (EF_RESTART)                                           ! IS THIS A RESTART?
;  5966  2     then
;  5967  3         begin
;  5968  3         ENTRY_REASON = RESTART;
;  5969  3         CLEAR_TABLES = TRUE;
;  5970  2         end;
;  5971  2
;  5972  2     if READEF (EF_CONTINUE)                                          ! IS THIS A CONTINUE?
;  5973  2     then
;  5974  3         begin
;  5975  3         ENTRY_REASON = CONT;
;  5976  3
;  5977  4         if not BIT_TST (SWP_FLAGS, SWF_CST)
;  5978  3         then
```

```
;  5979  3              CLEAR_TABLES = FALSE
;  5980  3          else
;  5981  3              CLEAR_TABLES = TRUE;
;  5982  3
;  5983  2          end;
;  5984  2
;  5985  2      if READEF (EF_PWR)                                          ! ARE WE HERE BECAUSE OF POWER FAIL
;  5986  2      then
;  5987  3          begin
;  5988  3          ENTRY_REASON = PWR_FAIL;
;  5989  3          ADDR_VECT_OK = FALSE;
;  5990  3          INIT_OCCURED = FALSE;
;  5991  3          CLEAR_TABLES = TRUE;
;  5992  3          PRINTF (MSG_ 1);                                        ! "POWER DELAY - WAITING"
;  5993  3
;  5994  3          incr COUNT from 0 to 60 do                              ! WAIT APPROX. 60 SECONDS
;  5995  4              begin
;  5996  4              DELAY_MULT = 333;
;  5997  4              DELAY (.DELAY_MULT);
;  5998  4              BREAK;                                              ! BREAK FOR ACT
;  5999  3              end;
;  6000  3
;  6001  2          end;
;  6002  2
;  6003  2      !SETVEC (O_TVEC, O_BRK, PRIO7);                             ! SET ODT TRAP VECTOR
;  6004  2
;  6005  2      !+
;  6006  2      !       MAKE SURE THAT NOT MORE THAN MAX_UNITS HAVE BEEN SPECIFIED.
;  6007  2      !       IF THERE ARE TOO MANY, NOTIFY USER AND RETURN TO SUPERVISOR.
;  6008  2      !       (DIAGNOSTIC IS ABORTED).
;  6009  2      !-
;  6010  2
;  6011  2      if .L$UNIT gtru MAX_UNITS
;  6012  2      then
;  6013  3          begin
;  6014  3          ERRSF (1, EGS_01, EMS_01);
;  6015  3          DOCLN;
;  6016  2          end;
;  6017  2
;  6018  2      !+
;  6019  2      !       THE FOLLOWING CODE IS EXECUTED FOR ALL ENTRY REASONS EXCEPT NEW_PASS.
;  6020  2      !       ALL RUN-TIME CONTROLLER STATUS TABLES (CSTs) ARE CLEARED TO 0, THEN
;  6021  2      !       LOADED WITH CONFIGURATION DATA FROM THE HARDWARE P-TABLES.
;  6022  2      !-
;  6023  2
;  6024  2      if .ENTRY_REASON neq NEW_PASS
;  6025  2      then
;  6026  3          begin
;  6027  3          SMALLEST_DRIVE = 255;                                   ! LARGEST DISK NO. ALLOWED BY MSCP
;  6028  3
;  6029  3          incr COUNT from 0 to ((MAX_CTLR * CST_LEN * 2) - 2) by 2 do
;  6030  3              (CST + .COUNT) = 0;
;  6031  3
```

```
;    6032  3          incr UNIT from 0 to (.L$UNIT - 1) do                                    ! LOOP THROUGH ALL UNITS
;    6033  3
;    6034  3              if (HWPT_ADDRESS [.UNIT] = GPHARD (.UNIT, HWPT_REF)) neqa 0        ! IF HWP TABLE FOUND
;    6035  3              then
;    6036  3
;    6037  3                  if .HWPT_REF [HWP_DISK_NUM] lssu .SMALLEST_DRIVE               ! FIND OUT THE SMALLEST DISK NUMBER
;    6038  3                  then
;    6039  3                      SMALLEST_DRIVE = .HWPT_REF [HWP_DISK_NUM];
;    6040  3
;    6041  3          incr UNIT from 0 to (.L$UNIT - 1) do                                    ! LOOP THROUGH ALL UNITS
;    6042  3
;    6043  3              if .HWPT_ADDRESS [.UNIT] neqa 0                                    ! IF HWP TABLE FOUND
;    6044  3              then
;    6045  4                  begin
;    6046  4                  FLAG = NOT_FOUND;
;    6047  4                  HWPT_REF = .HWPT_ADDRESS [.UNIT];
;    6048  4
;    6049  4                  incr CTLR from 0 to (MAX_CTLR - 1) do                          ! LOOP THROUGH ALL CSTs
;    6050  4
;    6051  4                      if .CST [.CTLR, IP_ADDR] eqla .HWPT_REF [HWP_IP_ADDR]
;    6052  4                      then
;    6053  4
;    6054  4                          if .CST [.CTLR, (.HWPT_REF [HWP_DISK_NUM] - .SMALLEST_DRIVE) * UNIT_SIZE
;    6055  4                                  + OF_UN + OF_DATA, D_PRES] eql NOT_PRESENT
;    6056  4                          then
;    6057  5                              begin                                              ! IF EMPTY SLOT FOUND
;    6058  5                              TEMP = (.HWPT_REF [HWP_DISK_NUM] - .SMALLEST_DRIVE) * UNIT_SIZE + OF_UN;
;    6059  5                              CST [.CTLR, .TEMP + OF_DATA, D_ALL] = .HWPT_REF [HWP_DISK];
;    6060  5                                                                                 ! COPY DISK ADDR AND PROT BIT
;    6061  5                              CST [.CTLR, .TEMP + OF_DATA, D_UNIT] = .UNIT;
;    6062  5                              CST [.CTLR, .TEMP + OF_DATA, D_FATAL] = FALSE;
;    6063  5                              CST [.CTLR, .TEMP + OF_DATA, D_PRES] = PRESENT;
;    6064  5
;    6065  5                              IF .HWPT_REF [HWP_ENTIRE] EQL TRUE             !ZZZ IF DEFAULT TEST RANGE,
;    6066  5                              THEN HWPT_REF [HWP_END_TRK1] = ALL_ONES;       !ZZZ MAKE HI ADDR ALL ONES
;    6067  5
;    6068  5                              CST [.CTLR, .TEMP + OF_BEG, D_BEG0] =
;    6069  5                                      .HWPT_REF [HWP_BEG_TRK];               !ZZZ
;    6070  5                              CST [.CTLR, .TEMP + OF_BEG1, D_BEG1] =         !ZZZ
;    6071  5                                      .HWPT_REF [HWP_BEG_TRK1];              !ZZZ
;    6072  5                              CST [.CTLR, .TEMP + OF_END, D_END0] =          !ZZZ
;    6073  5                                      .HWPT_REF [HWP_END_TRK];               !ZZZ
;    6074  5                              CST [.CTLR, .TEMP + OF_END1, D_END1] =         !ZZZ
;    6075  5                                      .HWPT_REF [HWP_END_TRK1];              !ZZZ
;    6076  5
;    6077  5                              CST [.CTLR, .TEMP + OF_NAME_0, D_ALL] = .BLANKS;       !ZZZ BLANK NAME
;    6078  5                              CST [.CTLR, .TEMP + OF_NAME_2, D_ALL] = .BLANKS;       !ZZZ BLANK NAME
;    6079  5
;    6080  5
;    6081  5                              CST [.CTLR, .TEMP + OF_DUPFLAGS, D_DBN] = 0;   !ZZZ
;    6082  5                              CST [.CTLR, .TEMP + OF_DUPFLAGS, NODUPMEDIA] =  !ZZZ
;    6083  5                                      NOT (.HWPT_REF [HWP_DISK_DUPEX]);      !ZZZ
;    6084  5
```

```
;  6085  5                            CST [.CTLR, .TEMP + OF_DUPFLAGS, DUPWRITE] =     !ZZZ
;  6086  5                                  (.HWPT_REF [HWP_DISK_DUPWT]);              !ZZZ
;  6087  5                            CST [.CTLR, .TEMP + OF_COUNT, D_COUNT] = 0;      !ZZZ
;  6088  5                            FLAG = FOUND;
;  6089  5                            exitloop;
;  6090  5                            end
;  6091  4                        else
;  6092  5                            begin                                            ! DUPLICATE UNIT
;  6093  5                            PRINTF (CER_01, .HWPT_REF [HWP_DISK_NUM], .HWPT_REF [HWP_IP_ADDR]);
;  6094  5                                                                             ! "DUPLICATE UNIT: X AT IP: XXXXXX"
;  6095  5                            DUR [.UNIT] = DU_CONF;                           ! CONFIGURATION ERROR
;  6096  5                            DODU (.UNIT);                                    ! DROP UNIT
;  6097  5                            FLAG = FOUND;
;  6098  5                            exitloop;
;  6099  4                            end;
;  6100  4
;  6101  4                    if .FLAG eql NOT_FOUND                                   ! IF NO IP MATCH TO EXISTING CST
;  6102  4                    then
;  6103  5                        begin
;  6104  5
;  6105  5                        incr CTLR from 0 to (MAX_CTLR - 1) do                ! LOOP THROUGH EACH CST
;  6106  5
;  6107  5                            if .CST [.CTLR, IP_ADDR] eqla 0                  ! IF EMPTY CST FOUND
;  6108  5                            then
;  6109  6                                begin
;  6110  6                                CST [.CTLR, IP_ADDR] = .HWPT_REF [HWP_IP_ADDR];
;  6111  6                                CST [.CTLR, VEC_ADDR] = .HWPT_REF [HWP_VECTOR];
;  6112  6                                CST [.CTLR, BR_LEV] = .HWPT_REF [HWP_BR_LEVEL];
;  6113  6                                TEMP = (.HWPT_REF [HWP_DISK_NUM] - .SMALLEST_DRIVE) * UNIT_SIZE + OF_UN;
;  6114  6                                CST [.CTLR, .TEMP + OF_DATA, D_ALL] = .HWPT_REF [HWP_DISK];
;  6115  6                                                                             ! COPY DISK ADDR AND PROT BIT
;  6116  6                                CST [.CTLR, .TEMP + OF_DATA, D_UNIT] = .UNIT;
;  6117  6                                CST [.CTLR, .TEMP + OF_DATA, D_FATAL] = FALSE;
;  6118  6                                CST [.CTLR, .TEMP + OF_DATA, D_PRES] = PRESENT;
;  6119  6
;  6120  6                                IF .HWPT_REF [HWP_ENTIRE] EQL TRUE           !ZZZ IF DEFAULT TEST RANGE,
;  6121  6                                THEN HWPT_REF [HWP_END_TRK1] = ALL_ONES;     !ZZZ MAKE HI ADDR ALL ONES
;  6122  6
;  6123  6                                CST [.CTLR, .TEMP + OF_BEG, D_BEG0] =        !ZZZ
;  6124  6                                        .HWPT_REF [HWP_BEG_TRK];             !ZZZ
;  6125  6                                CST [.CTLR, .TEMP + OF_BEG1, D_BEG1] =       !ZZZ
;  6126  6                                        .HWPT_REF [HWP_BEG_TRK1];            !ZZZ
;  6127  6                                CST [.CTLR, .TEMP + OF_END, D_END0] =        !ZZZ
;  6128  6                                        .HWPT_REF [HWP_END_TRK];             !ZZZ
;  6129  6                                CST [.CTLR, .TEMP + OF_END1, D_END1] =       !ZZZ
;  6130  6                                        .HWPT_REF [HWP_END_TRK1];            !ZZZ
;  6131  6
;  6132  6                                CST [.CTLR, .TEMP + OF_NAME_C, D_ALL] = .BLANKS;     !ZZZ BLANK NAME
;  6133  6                                CST [.CTLR, .TEMP + OF_NAME_2, D_ALL] = .BLANKS;     !ZZZ BLANK NAME
;  6134  6
;  6135  6
;  6136  6                                CST [.CTLR, .TEMP + OF_DUPFLAGS, D_DBN] = 0;     !ZZZ
;  6137  6                                CST [.CTLR, .TEMP + OF_DUPFLAGS, NODUPMEDIA] =   !ZZZ
```

```
;   6138  6                                   NOT (.HWPT_REF [HWP_DISK_DUPEX]);                       !ZZZ
;   6139  6                           CST [.CTLR, .TEMP + OF_DUPFLAGS, DUPWRITE] =                    !ZZZ
;   6140  6                                 (.HWPT_REF [HWP_DISK_DUPWT]);                             !ZZZ
;   6141  6                           CST [.CTLR, .TEMP + OF_COUNT, D_COUNT] = 0;                     !ZZZ
;   6142  6                           FLAG = FOUND;
;   6143  6                           exitloop;
;   6144  5                           end;                                                            ! IF EMPTY CST FOUND
;   6145  5
;   6146  5                       if .FLAG eql NOT_FOUND                                              ! IF NO EMPTY CST FOUND
;   6147  5                       then
;   6148  6                           begin
;   6149  6                           PRINTF (CER_02, MAX_CTLR);                                      ! "MORE THAN X IP ADDRESSES."
;   6150  6                           DUR [.UNIT] = DU_CONF;                                          ! CONFIGURATION ERROR
;   6151  6                           DODU (.UNIT);                                                   ! DROP UNIT
;   6152  5                           end;
;   6153  5
;   6154  4                       end;                                                                ! IF NO IP ADDR MATCH IN CST
;   6155  4
;   6156  3                   end;                                                                    ! IF GPHARD RETURNS A HWP TABLE
;   6157  3           !
;   6158  3           ! CONFIGURATON CHECK FOR LEGAL RDRX UNIT MIX BECAUSE WE HAVE DIFFERENT
;   6159  3           ! DRIVES :  THE RD51, RD52, AND RX50.
;   6160  3           ! (NEEDED?)
;   6161  3           !
;   6162  2           end;                                                                            ! END OF "NON NEW_PASS" INIT
;   6163  2
;   6164  2       if .ENTRY_REASON eql NEW_PASS
;   6165  2       then
;   6166  3           begin
;   6167  3
;   6168  3           incr UNIT from 0 to (.L$UNIT - 1) do
;   6169  3               GPHARD (.UNIT, HWPT_REF);                                                   ! DUMMY GPHARDs FOR NEW PASS
;   6170  3
;   6171  3           incr CTLR from 0 to (MAX_CTLR - 1) do
;   6172  4               begin
;   6173  4               CST [.CTLR, U_CNT] = 0;                                                     ! REINITIALIZE UNIT COUNT
;   6174  4
;   6175  4               incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do
;   6176  4                   CST [.CTLR, .OFFSET + OF_DATA, D_STAT] = OFFLINE;                       ! START EACH UNIT AS OFFLINE
;   6177  4
;   6178  3               end;
;   6179  3
;   6180  2           end;
;   6181  2
;   6182  2       if .ENTRY_REASON eql START
;   6183  2       then
;   6184  3           begin
;   6185  3           CTLR_CNT = 0;                                                                   ! NUMBER OF CONFIGURED CONTROLLERS
;   6186  3
;   6187  3           incr CTLR from 0 to (MAX_CTLR - 1) do
;   6188  3
;   6189  3               if .CST [.CTLR, IP_ADDR] neqa 0                                             ! IF CONTROLLER IS PRESENT
;   6190  3               then
```

```
;    6191  3                CTLR_CNT = .CTLR_CNT + 1;                                  ! INCREMENT CONTROLLER COUNT
;    6192  3
;    6193  3            MEMORY (FREE_MEM_ADDR);                                        ! GET START OF FREE MEMORY
;    6194  3
;    6195  2            end;                                                           ! END OF "START" INITIALIZATION
;    6196  2
;    6197  2        !+
;    6198  2        !       CLEAR STATISTICS TABLES
;    6199  2        !-
;    6200  2
;    6201  2        incr UNITS from 0 to MAX_UNITS - 1 do                              ! CLEAR CURRENT STATISTICS
;    6202  2            incr COUNT from 0 to TALLY_CLEAR - 1 do
;    6203  2                TALLY [.UNITS * TALLY_LEN + .COUNT] = 0;
;    6204  2
;    6205  2        if .CLEAR_TABLES                                                   ! IF CLEAR TABLES ON EVERY PASS
;    6206  2        then
;    6207  2            incr UNITS from 0 to MAX_UNITS - 1 do
;    6208  2                incr COUNT from TALLY_CLEAR to TALLY_LEN - 1 do            ! INITIALIZE TOTALS
;    6209  2                    TALLY [.UNITS * TALLY_LEN + .COUNT] = 0;               !
;    6210  2
;    6211  2        if .CLEAR_TABLES
;    6212  2        then
;    6213  2            incr CTLR from 0 to MAX_CTLR - 1 do
;    6214  3                begin
;    6215  3                C_ERR_TBL [.CTLR, C_ERR_HRD] = 0;                          ! INITALIZE CONTROLLE  ERRORS
;    6216  3                C_ERR_TBL [.CTLR, C_ERR_SFT] = 0;                          !
;    6217  2                end;
;    6218  2
;    6219  2        !+
;    6220  2        !       MISCELLANEOUS INITIALIZATON
;    6221  2        !-
;    6222  2
;    6223  2        incr CTLR from 0 to (MAX_CTLR - 1) do                              ! INIT NO. OF OUTSTANDING QIOs
;    6224  2            QIO [.CTLR] = 0;
;    6225  2
;    6226  2        incr COUNT from 0 to (RP_CNT - 1) do                               ! INITIALIZE RETURN PACKET POOL
;    6227  2            RP_USE [.COUNT] = -1;
;    6228  2
;    6229  2        if .CLK_PRESENT                                                    ! STOP CLOCK IF PRESENT
;    6230  2        then
;    6231  2            LINE_CLOCK = 0;
;    6232  2
;    6233  2        IODQ_IN = IODQ_OUT = 0;                                            ! INIT I/O DONE QUEUE POINTERS
;    6234  2        CRN_LOW = CRN_HIGH = 0;                                            ! INIT COMMAND REFERENCE NUMBER
;    6235  2        SETPRI (PRI00);                                                    ! SET PROGRAM PRIORITY TO 0
;    6236  2
;    6237  2
;    6238  1        ENDINIT;

                                                .GLOBL  L$DLY
```

```
                                        .SBTTL  LINIT INITIALIZE SECTION
000000 004137 000000G          LINIT:   JSR     R1,$SAVE5                ;                                      5924
000004 162706 000030                    SUB     #30,SP
000010 012746 020040                    MOV     #20040,-(SP)             ; *,C ...KS
000014 012700 000340                    MOV     #340,R0                  ;                                      5940
000020 104441                           TRAP    41
000022 012700 000035                    MOV     #35,R0                   ;                                      5942
000026 104447                           TRAP    47
000030 103014                           BHIS    2$
000032 112737 000005 000000G            MOVB    #5,ENTRY.REASON          ;                                      5945
000040 105737 000000G                   TSTB    SWP.FLAGS                ;                                      5947
000044 100403                           BMI     1$
000046 105066 000012                    CLRB    12(SP)                   ; CLEAR.TABLES                         5949
000052 000403                           BR      2$                       ;                                      5947
000054 112766 000001 000012     1$:     MOVB    #1,12(SP)                ; *,CLEAR.TABLES                       5951
000062 012700 000040            2$:     MOV     #40,R0                   ;                                      5955
000066 104447                           TRAP    47
000070 103013                           BHIS    3$
000072 104433                           TRAP    33                       ;                                      5957
000074 112737 000001 000000G            MOVB    #1,ENTRY.REASON          ;                                      5959
000102 112766 000001 000012             MOVB    #1,12(SP)                ; *,CLEAR.TABLES                       5960
000110 105037 000000G                   CLRB    ADDR.VECT.OK             ;                                      5961
000114 105037 000000G                   CLRB    INIT.OCCURED             ;                                      5962
000120 012700 000037            3$:     MOV     #37,R0                   ;                                      5965
000124 104447                           TRAP    47
000126 103006                           BHIS    4$
00013( 112737 000002 000000G            MOVB    #2,ENTR...,REASON        ;                                      5968
00013( 112766 000001 000012             MOVB    #1,12(SP)                ; *,CLEAR.TABLES                       5969
000144 012700 000036            4$:     MOV     #36,R0                   ;                                      5972
000150 104447                           TRAP    47
000152 103014                           BHIS    6$
000154 112737 000003 000000G            MOVB    #3,ENTRY.REASON          ;                                      5975
000162 105737 000000G                   TSTB    SWP.FLAGS                ;                                      5977
000166 100403                           BMI     5$
000170 105066 000012                    CLRB    12(SP)                   ; CLEAR.TABLES                         5979
000174 000403                           BR      6$                       ;                                      5977
000200 112766 000001 000012     5$:     MOVB    #1,12(SP)                ; *,CLEAR.TABLES                       5981
000204 012700 000034            6$:     MOV     #34,R0                   ;                                      5985
000210 104447                           TRAP    47
000212 103043                           BHIS    12$
000214 112737 000004 000000G            MOVB    #4,ENTRY.REASON          ;                                      5988
000222 105037 000000G                   CLRB    ADDR.VECT.OK             ;                                      5989
000226 105037 000000G                   CLRB    INIT.OCCURED             ;                                      5990
000232 112766 000001 000012             MOVB    #1,12(SP)                ; *,CLEAR.TABLES                       5991
000240 012746 000000G                   MOV     #MSG.01,-(SP)            ;                                      5992
000244 012746 000001                    MOV     #1,-(SP)
000250 010600                           MOV     SP,R0                    ; SP,*
000252 104417                           TRAP    17
000254 012702 000075                    MOV     #75,R2                   ; *,COUNT                              5994
000260 012703 000515            7$:     MOV     #515,R3                  ; *,DELAY.MULT                         5996
000264 010301                           MOV     R3,R1                    ; DELAY.MULT,$$TMP2                    5997
000266 001411                   8$:     BEQ     11$
000270 013700 000000G                   MOV     L$DLY,R0                 ; *,$$TMP1
```

```
000274  001404                          BEQ     10$
000276  005066  000024          9$:     CLR     24(SP)                  ; $$TMP
000302  005300                          DEC     R0                      ; $$TMP1
000304  001374                          BNE     9$
000306  005301                  10$:    DEC     R1                      ; $$TMP2
000310  000766                          BR      8$
000312  104422                  11$:    TRAP    22
000314  005302                          DEC     R2                      ; COUNT                                 5994
000316  001360                          BNE     7$
000320  022626                          CMP     (SP)+,(SP)+             ;                                       5987
000322  023727  000000G 000004  12$:    CMP     L$UNIT,#4               ;                                       6011
000330  101405                          BLOS    13$
000332  104454                          TRAP    54                      ;                                       6014
000334  000001                          .WORD   1
000336  000000G                         .WORD   EGS.01
000340  000000V                         .WORD   EMS.01
000342  104444                          TRAP    44
000344  123727  000000G 000005  13$:    CMPB    ENTRY.REASON,#5         ;                                       6024
000352  001002                          BNE     14$
000354  000137  003462'                 JMP     43$
000360  112766  000377  000010  14$:    MOVB    #377,10(SP)             ; *,SMALLEST.DRIVE                      6027
000366  005000                          CLR     R0                      ; COUNT                                 6029
000370  005060  000000G         15$:    CLR     CST(R0)                 ; *(COUNT)                              6030
000374  062700  000002                  ADD     #2,R0                   ; *,COUNT                               6029
000400  020027  000124                  CMP     R0,#124                 ; COUNT,*
000404  003771                          BLE     15$
000406  013704  000000G                 MOV     L$UNIT,R4               ;                                       6032
000412  005003                          CLR     R3                      ; UNIT
000414  000435                          BR      18$
000416  010302                  16$:    MOV     R3,R2                   ; UNIT,*                                6034
000420  006302                          ASL     R2
000422  012700  000022                  MOV     #22,R0
000426  060600                          ADD     SP,R0                   ; HWPT.ADDRESS,*
000430  060002                          ADD     R0,R2
000432  010300                          MOV     R3,R0                   ; UNIT,*
000434  104442                          TRAP    42
000436  010001                          MOV     R0,R1                   ; *,HWPT.REF
000440  010112                          MOV     R1,(R2)                 ; HWPT.REF,*
000442  001421                          BEQ     17$
000444  005002                          CLR     R2                      ;                                       6037
000446  156602  000010                  BISB    10(SP),R2               ; SMALLEST.DRIVE,*
000452  116100  000006                  MOVB    6(R1),R0                ; *(HWPT.REF),*
000456  042700  177760                  BIC     #177760,R0
000462  020002                          CMP     R0,R2
000464  103010                          BHIS    17$
000466  116100  000006                  MOVB    6(R1),R0                ; *(HWPT.REF),*                         6039
000472  042700  177760                  BIC     #177760,R0
000476  105066  000010                  CLRB    10(SP)                  ; SMALLEST.DRIVE
000502  050066  000010                  BIS     R0,10(SP)               ; *,SMALLEST.DRIVE
000506  005203                  17$:    INC     R3                      ; UNIT                                  6032
000510  020304                  18$:    CMP     R3,R4                   ; UNIT,*
000512  002741                          BLT     16$
000514  013766  000000G 000016          MOV     L$UNIT,16(SP)           ;                                       6041
```

```
000522  005004                          CLR     R4                              ; UNIT
000524  000137  003440'                  JMP     41$
000530  010400                  19$:     MOV     R4,R0                           ; UNIT,*                        6043
000532  006300                          ASL     R0
000534  012703  000022                  MOV     #22,R3
000540  060603                          ADD     SP,R3                           ; HWPT.ADDRESS,*
000542  060300                          ADD     R3,R0
000544  005710                          TST     (R0)
000546  001002                          BNE     20$
000550  000137  003436'                  JMP     40$
000554  105066  000006          20$:     CLRB    6(SP)                           ; FLAG                          6046
000560  011001                          MOV     (R0),R1                         ; *,HWPT.REF                    6047
000562  005066  000002                  CLR     2(SP)                           ; CTLR                          6049
000566  016646  000002          21$:     MOV     2(SP),-(SP)                     ; CTLR,*                        6051
000572  012746  000126                  MOV     #126,-(SP)
000576  004737  000000G                 JSR     PC,BL$MUL
000602  022626                          CMP     (SP)+,(SP)+
000604  026011  000000G                 CMP     CST(R0),(R1)                    ; *,HWPT.REF
000610  001402                          BEQ     22$
000612  000137  002660'                  JMP     28$
000616  012766  000001  000014  22$:     MOV     #1,14(SP)                       ;                               6088
000624  112766  000001  000006          MOVB    #1,6(SP)                        ; *,FLAG
000632  012705  000006                  MOV     #6,R5                           ;                               6054
000636  060105                          ADD     R1,R5                           ; HWPT.REF,*
000640  111546                          MOVB    (R5),-(SP)
000642  042716  177760                  BIC     #177760,(SP)
000646  005000                          CLR     R0
00065C  156600  000012                  BISB    12(SP),R0                       ; SMALLEST.DRIVE,*
000654  160016                          SUB     R0,(SP)
000656  012746  000012                  MOV     #12,-(SP)
000662  004737  000000G                 JSR     PC,BL$MUL
000666  010066  000010                  MOV     R0,10(SP)
000672  005726                          TST     (SP)+
000674  016616  000004                  MOV     4(SP),(SP)                      ; CTLR,*                        6055
000700  012746  000053                  MOV     #53,-(SP)
000704  004737  000000G                 JSR     PC,BL$MUL
000710  010003                          MOV     R0,R3
000712  022626                          CMP     (SP)+,(SP)+
000714  066600  000004                  ADD     4(SP),R0
000720  006300                          ASL     R0
000722  032760  040000  000006G         BIT     #40000,CST+6(R0)
000730  001140                          BNE     27$
000732  016602  000004                  MOV     4(SP),R2                        ; *,TEMP                        6058
000736  062702  000003                  ADD     #3,R2                           ; *,TEMP
000742  010300                          MOV     R3,R0                           ;                               6059
000744  060200                          ADD     R2,R0                           ; TEMP,*
000746  006300                          ASL     R0
000750  062700  000000G                 ADD     #CST,R0
000754  011510                          MOV     (R5),(R0)
000756  010446                          MOV     R4,-(SP)                        ; UNIT,*                        6061
000760  000316                          SWAB    (SP)
000762  042716  170377                  BIC     #170377,(SP)
000766  042710  007400                  BIC     #7400,(R0)
```

```
000772  052610                          BIS     (SP)+,(R0)
000774  042710  010000                  BIC     #10000,(R0)             ;                               6062
001000  052710  040000                  BIS     #40000,(R0)             ;                               6063
001004  105715                          TSTB    (R5)                    ;                               6065
001006  100303                          BPL     23$
001010  012761  177777  000016          MOV     #-1,16(R1)              ; *,*(HWPT.REF)                 6066
001016  010300                  23$:    MOV     R3,R0                   ;                               6068
001020  060200                          ADD     R2,R0                   ; TEMP,*
001022  006300                          ASL     R0
001024  016160  000010  000002G         MOV     10(R1),CST+2(R0)        ; *(HWPT.REF),*
001032  010300                          MOV     R3,R0                   ;                               6070
001034  060200                          ADD     R2,R0                   ; TEMP,*
001036  006300                          ASL     R0
001040  016160  000012  000004G         MOV     12(R1),CST+4(R0)        ; *(HWPT.REF),*
001046  010300                          MOV     R3,R0                   ;                               6072
001050  060200                          ADD     R2,R0                   ; TEMP,*
001052  006300                          ASL     R0
001054  016160  000014  000006G         MOV     14(R1),CST+6(R0)        ; *(HWPT.REF),*
001062  010300                          MOV     R3,R0                   ;                               6074
001064  060200                          ADD     R2,R0                   ; TEMP,*
001066  006300                          ASL     R0
001070  016160  000016  000010G         MOV     16(R1),CST+10(R0)       ; *(HWPT.REF),*
001076  010300                          MOV     R3,R0                   ;                               6077
001100  060200                          ADD     R2,R0                   ; TEMP,*
001102  006300                          ASL     R0
001104  011660  000012G                 MOV     (SP),CST+12(R0)         ; BLANKS,*
001110  010300                          MOV     R3,R0                   ;                               6078
001112  060200                          ADD     R2,R0                   ; TEMP,*
001114  006300                          ASL     R0
001116  011660  000014G                 MOV     (SP),CST+14(R0)         ; BLANKS,*
001122  010300                          MOV     R3,R0                   ;                               6081
001124  060200                          ADD     R2,R0                   ; TEMP,*
001126  006300                          ASL     R0
001130  062700  000020G                 ADD     #CST+20,R0
001134  105010                          CLRB    (R0)
001136  111546                          MOVB    (R5),-(SP)              ;                               6083
001140  005046                          CLR     -(SP)
001142  032766  000040  000002          BIT     #40,2(SP)
001150  001401                          BEQ     24$
001152  005216                          INC     (SP)
001154  005116                  24$:    COM     (SP)
001156  011646                          MOV     (SP),-(SP)
001160  042710  100000                  BIC     #100000,(R0)
001164  006026                          ROR     (SP)+
001166  103002                          BCC     25$
001170  052710  100000                  BIS     #100000,(R0)
001174  005726                  25$:    TST     (SP)+
001176  111516                          MOVB    (R5),(SP)               ;                               6085
001200  042710  010000                  BIC     #10000,(R0)
001204  032726  000100                  BIT     #100,(SP)+
001210  001402                          BEQ     26$
001212  052710  010000                  BIS     #10000,(R0)
001216  010300                  26$:    MOV     R3,R0                   ;                               6087
```

```
001220  060200                          ADD     R2,R0                   ; TEMP,*
001222  006300                          ASL     R0
001224  005060  000022G                 CLR     CST+22(R0)
001230  000430                          BR      29$                     ;                       6057
001232  011146                  27$:    MOV     (R1),-(SP)              ; HWPT.REF,*            6093
001234  111546                          MOVB    (R5),-(SP)
001236  042716  177760                  BIC     #177760,(SP)
001242  012746  000000G                 MOV     #CER.01,-(SP)
001246  012746  000003                  MOV     #3,-(SP)
001252  010600                          MOV     SP,R0                   ; SP,*
001254  104417                          TRAP    17
001256  062706  000010                  ADD     #10,SP
001262  112764  000001  000000G         MOVB    #1,DUR(R4)              ; *,*(UNIT)             6095
001270  010400                          MOV     R4,R0                   ; UNIT,*                6096
001272  104451                          TRAP    51
001274  000406                          BR      29$                     ;                       6092
001276  005266  000002          28$:    INC     2(SP)                   ; CTLR                  6049
001302  000243                          .WORD CLV!CLC

001304  003002                          BGT     29$
001306  000137  002150'                 JMP     21$
001312  105766  000006          29$:    TSTB    6(SP)                   ; FLAG                  6101
001316  001402                          BEQ     30$
001320  000137  003436'                 JMP     40$
001324  005066  000014          30$:    CLR     14(SP)                  ; CTLR                  6105
001330  016646  000014          31$:    MOV     14(SP),-(SP)            ; CTLR,*                6107
001334  012746  000126                  MOV     #126,-(SP)
001340  004737  000000G                 JSR     PC,BL$MUL
001344  022626                          CMP     (SP)+,(SP)+
001346  005760  000000G                 TST     CST(R0)
001352  001402                          BEQ     32$
001354  000137  003356'                 JMP     37$
001360  011160  000000G         32$:    MOV     (R1),CST(R0)            ; HWPT.REF,*            6110
001364  016103  000002                  MOV     2(R1),R3                ; *(HWPT.REF),*         6111
001370  042703  177000                  BIC     #177000,R3
001374  042760  000777  000002G         BIC     #777,CST+2(R0)
001402  050360  000002G                 BIS     R3,CST+2(R0)
001406  116160  000004  000004G         MOVB    4(R1),CST+4(R0)         ; *(HWPT.REF),*         6112
001414  012705  000006                  MOV     #6,R5                   ;                       6113
001420  060105                          ADD     R1,R5                   ; HWPT.REF,*
001422  111546                          MOVB    (R5),-(SP)
001424  042716  177760                  BIC     #177760,(SP)
001430  005000                          CLR     R0
001432  156600  000012                  BISB    12(SP),R0               ; SMALLEST.DRIVE,*
001436  160016                          SUB     R0,(SP)
001440  012746  000012                  MOV     #12,-(SP)
001444  004737  000000G                 JSR     PC,BL$MUL
001450  005726                          TST     (SP)+
001452  010002                          MOV     R0,R2                   ; *,TEMP
001454  062702  000003                  ADD     #3,R2                   ; *,TEMP
001460  016616  000016                  MOV     16(SP),(SP)             ; CTLR,*                6114
001464  012746  000053                  MOV     #53,-(SP)
001470  004737  000000G                 JSR     PC,BL$MUL
```

```
001474  010003                          MOV     R0,R3
001476  005726                          TST     (SP)+
001500  060200                          ADD     R2,R0                   ; TEMP,*
001502  006300                          ASL     R0
001504  062700  000000G                 ADD     #CST,R0
001510  011510                          MOV     (R5),(R0)
001512  010416                          MOV     R4,(SP)                 ; UNIT,*                        6116
001514  000316                          SWAB    (SP)
001516  042716  170377                  BIC     #170377,(SP)
001522  042710  007400                  BIC     #7400,(R0)
001526  052610                          BIS     (SP)+,(R0)
001530  042710  010000                  BIC     #10000,(R0)             ;                               6117
001534  052710  040000                  BIS     #40000,(R0)             ;                               6118
001540  105715                          TSTB    (R5)                    ;                               6120
001542  100003                          BPL     33$
001544  012761  177777  000016          MOV     #-1,16(R1)              ; *,*(HWPT.REF)                 6121
001552  010300                  33$:    MOV     R3,R0                   ;                               6123
001554  060200                          ADD     R2,R0                   ; TEMP,*
001556  006300                          ASL     R0
001560  016160  000010  000002G         MOV     10(R1),CST+2(R0)        ; *(HWPT.REF),*
001566  010300                          MOV     R3,R0                   ;                               6125
001570  060200                          ADD     R2,R0                   ; TEMP,*
001572  006300                          ASL     R0
001574  016160  000012  000004G         MOV     12(R1),CST+4(R0)        ; *(HWPT.REF),*
001602  010300                          MOV     R3,R0                   ;                               6127
001604  060200                          ADD     R2,R0                   ; TEMP,*
001606  006300                          ASL     R0
001610  016160  000014  000006G         MOV     14(R1),CST+6(R0)        ; *(HWPT.REF),*
001616  010300                          MOV     R3,R0                   ;                               6129
001620  060200                          ADD     R2,R0                   ; TEMP,*
001622  006300                          ASL     R0
001624  016160  000016  000010G         MOV     16(R1),CST+10(R0)       ; *(HWPT.REF),*
001632  010300                          MOV     R3,R0                   ;                               6132
001634  060200                          ADD     R2,R0                   ; TEMP,*
001636  006300                          ASL     R0
001640  011660  000012G                 MOV     (SP),CST+12(R0)         ; BLANKS,*
001644  010300                          MOV     R3,R0                   ;                               6133
001646  060200                          ADD     R2,R0                   ; TEMP,*
001650  006300                          ASL     R0
001652  011660  000014G                 MOV     (SP),CST+14(R0)         ; BLANKS,*
001656  010300                          MOV     R3,R0                   ;                               6136
001660  060200                          ADD     R2,R0                   ; TEMP,*
001662  006300                          ASL     R0
001664  062700  000020G                 ADD     #CST+20,R0
001670  105010                          CLRB    (R0)
001672  111546                          MOVB    (R5),-(SP)              ;                               6138
001674  005046                          CLR     -(SP)
001676  032766  000040  000002          BIT     #40,2(SP)
001704  001401                          BEQ     34$
001706  005216                          INC     (SP)
001710  005116                  34$:    COM     (SP)
001712  011646                          MOV     (SP),-(SP)
001714  042710  100000                  BIC     #100000,(R0)
```

```
001720  006026                          ROR     (SP)+
001722  103002                          BCC     35$
001724  052710  100000                  BIS     #100000,(R0)
001730  005726                  35$:    TST     (SP)+
001732  111516                          MOVB    (R5),(SP)               ;                                       6139
001734  042710  010000                  BIC     #10000,(R0)
001740  032726  000100                  BIT     #100,(SP)+
001744  001402                          BEQ     36$
001746  052710  010000                  BIS     #10000,(R0)
001752  010300                  36$:    MOV     R3,R0                   ;                                       6141
001754  060200                          ADD     R2,R0                   ; TEMP,*
001756  006300                          ASL     R0
001760  005060  000022G                 CLR     CST+22(R0)
001764  112766  000001  000006          MOVB    #1,6(SP)                ; *,FLAG                                6142
001772  000410                          BR      39$                     ;                                       6109
001774  005266  000014          37$:    INC     14(SP)                  ; CTLR                                  6105
002000  000243                          .WORD CLV!CLC

002002  003002                          BGT     38$
002004  000137  002712'                 JMP     31$
002010  105766  000006          38$:    TSTB    6(SP)                   ; FLAG                                  6146
002014  001017          39$:    BNE     40$
002016  012746  000001                  MOV     #1,-(SP)                ;                                       6149
002022  012746  000000G                 MOV     #CER.02,-(SP)
002026  012746  000002                  MOV     #2, (SP)
002032  010600                          MOV     SP,R0                   ; SP,*
002034  104417                          TRAP    17
002036  112764  000001  000000G         MOVB    #1,DUR(R4)              ; *,*(UNIT)                             6150
002044  010400                          MOV     R4,R0                   ; UNIT,*                                6151
002046  104451                          TRAP    51
002050  062706  000006                  ADD     #6,SP                   ;                                       6148
002054  005204                  40$:    INC     R4                      ; UNIT                                  6041
002056  020466  000016          41$:    CMP     R4,16(SP)               ; UNIT,*
002062  002002                          BGE     42$
002064  000137  002112'                 JMP     19$
002070  123727  000000G 000005  42$:    CMPB    ENTRY.REASON,#5         ;                                       6164
002076  001051                          BNE     48$
002100  013703  000000G          43$:    MOV     L$UNIT,R3               ;                                       6168
002104  005004                          CLR     R4                      ; UNIT
002106  000404                          BR      45$
002110  010400                  44$:    MOV     R4,R0                   ; UNIT,*                                6169
002112  104442                          TRAP    42
002114  010001                          MOV     R0,R1                   ; *,HWPT.REF
002116  005204                          INC     R4                      ; UNIT                                  6168
002120  020403                  45$:    CMP     R4,R3                   ; UNIT,*
002122  002772                          BLT     44$
002124  005003                          CLR     R3                      ; CTLR                                  6171
002126  010346                  46$:    MOV     R3,-(SP)                ; CTLR,*                                6173
002130  012746  000126                  MOV     #126,-(SP)
002134  004737  000000G                 JSR     PC,BL$MUL
002140  105060  000005G                 CLRB    CST+5(R0)
002144  010316                          MOV     R3,(SP)                 ; CTLR,*                                6176
002146  012746  000053                  MOV     #53,-(SP)
```

```
002152  004737  000000G                        JSR     PC,BL$MUL
002156  012701  000003                         MOV     #3,R1           ; *,OFFSET                      6175
002162  010002                          47$:    MOV     R0,R2           ;                               6176
002164  060102                                  ADD     R1,R2           ; OFFSET,*
002166  006302                                  ASL     R2
002170  042762  020000  000000G                BIC     #20000,CST(R2)
002176  062701  000012                         ADD     #12,R1          ; *,OFFSET                      6175
002202  020127  000041                         CMP     R1,#41          ; OFFSET,*
002206  003765                                  BLE     47$
002210  062706  000006                         ADD     #6,SP           ;                               6172
002214  005203                                  INC     R3              ; CTLR                          6171
002216  000243                                  .WORD CLV!CLC

002220  003742                                  BLE     46$
002222  123727  000000G 000001          48$:    CMPB    ENTRY.REASON,#1 ;                               6182
002230  001017                                  BNE     51$
002232  005037  000000G                        CLR     CTLR.CNT        ;                               6185
002236  005000                                  CLR     R0              ; CTLR                          6187
002240  005760  C00000G                 49$:    TST     CST(R0)         ; *(CTLR)                       6189
002244  001402                                  BEQ     50$
002246  005237  000000G                        INC     CTLR.CNT        ;                               6191
002252  062700  000126                 50$:    ADD     #126,R0         ; *,CTLR                        6187
002256  000243                                  .WORD CLV!CLC

002260  003767                                  BLE     49$
002262  104431                                  TRAP    31              ;                               6193
002264  010037  000000G                        MOV     R0,FREE.MEM.ADDR
002270  005001                          51$:    CLR     R1              ; UNITS                         6201
002272  005003                          52$:    CLR     R3              ; COUNT                         6202
002274  010300                          53$:    MOV     R3,R0           ; COUNT,*                       6203
002276  060100                                  ADD     R1,R0           ; UNITS,*
002300  006300                                  ASL     R0
002302  005060  000000G                        CLR     TALLY(R0)
002306  005203                                  INC     R3              ; COUNT                         6202
002310  020327  000006                         CMP     R3,#6           ; COUNT,*
002314  003767                                  BLE     53$
002316  062701  000033                         ADD     #33,R1          ; *,UNITS                       6201
002322  020127  000121                         CMP     R1,#121         ; UNITS,*
002326  003761                                  BLE     52$
002330  032766  000001  000012                 BIT     #1,12(SP)       ; *,CLEAR.TABLES                6205
002336  001436                                  BEQ     57$
002340  005001                                  CLR     R1              ; UNITS                         6207
002342  012703  000007                 54$:    MOV     #7,R3           ; *,COUNT                       6208
002346  010300                          55$:    MOV     R3,R0           ; COUNT,*                       6209
002350  060100                                  ADD     R1,R0           ; UNITS,*
002352  006300                                  ASL     R0
002354  005060  000000G                        CLR     TALLY(R0)
002360  005203                                  INC     R3              ; COUNT                         6208
002362  020327  000032                         CMP     R3,#32          ; COUNT,*
002366  003767                                  BLE     55$
002370  062701  000033                         ADD     #33,R1          ; *,UNITS                       6207
002374  020127  000121                         CMP     R1,#121         ; UNITS,*
002400  003760                                  BLE     54$
```

```
002402  032766  000001  000012                  BIT     #1,12(SP)                       ; *,CLEAR.TABLES                        6211
002410  001411                                  BEQ     57$
002412  005000                                  CLR     R0                              ; CTLR                                  6213
002414  105060  000000G                 56$:    CLRB    C.ERR.TBL(R0)                   ; *(CTLR)                               6215
002420  105060  000001G                         CLRB    C.ERR.TBL+1(R0)                 ; *(CTLR)                               6216
002424  062700  000002                          ADD     #2,R0                           ; *,CTLR                                6213
002430  000243                                  .WORD CLV!CLC

002432  003770                                  BLE     56$
002434  005000                          57$:    CLR     R0                              ; CTLR                                  6223
002436  105060  000000G                 58$:    CLRB    QIO(R0)                         ; *(CTLR)                               6224
002442  005200                                  INC     R0                              ; CTLR                                  6223
002444  000243                                  .WORD CLV!CLC

002446  003773                                  BLE     58$
002450  005000                                  CLR     R0                              ; COUNT                                 6226
002452  112760  000377  000000G         59$:    MOVB    #377,RP.USE(R0)                 ; *,*(COUNT)                            6227
002460  005200                                  INC     R0                              ; COUNT                                 6226
002462  020027  C00007                          CMP     R0,#7                           ; COUNT,*
002466  003771                                  BLE     59$
002470  132737  000001  000000G                 BITB    #1,CLK.PRESENT                  ;                                       6229
002476  001402                                  BEQ     60$
002500  005037  177546                          CLR     @#177546                        ;                                       6231
002504  005037  000000G                 60$:    CLR     IODQ.OUT                        ;                                       6233
002510  005037  000000G                         CLR     IODQ.IN
002514  005037  000000G                         CLR     CRN.HIGH                        ;                                       6234
002520  005037  000000G                         CLR     CRN.LOW
002524  005000                                  CLR     R0                              ;                                       6235
002526  104441                                  TRAP    41
002530  062706  000032                          ADD     #32,SP                          ;                                       5924
002534  000207                                  RTS     PC

; Routine Size:  687 words,     Routine Base:  $CODE$ + 1362
; Maximum stack depth per invocation:  25 words




                                                .SBTTL  L$INIT INITIALIZE SECTION
000000  004737  001362'                 L$INIT::JSR     PC,LINIT                        ;                                       6235
000004  104411                                  TRAP    11
000006  000207                                  RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 4120
; Maximum stack depth per invocation:  2 words
```

```
;    6239  1     %sbttl 'AUTODROP SECTION'
;    6240  1
;    6241  1     !+
;    6242  1     ! THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
;    6243  1     ! THE "ADR" FLAG WAS SET.  THE UNIT(S) UNDER TEST ARE CHECKED TO
;    6244  1     ! SEE IF THEY WILL RESPOND.  THOSE THAT DON'T ARE IMMEDIATELY
;    6245  1     ! DROPPED FROM TESTING.
;    6246  1     !-
;    6247  1
;    6248  2     BGNAUTO;
;    6249  2
;    6250  2     !if BIT_TST (SWP_FLAGS, SWF_TRC)
;    6251  2     !then
;    6252  2     !   PRINTF (DBM3);
;    6253  2
;    6254  2     return;
;    6255  2
;    6256  1     ENDAUTO;


                                        .SBTTL  LAUTO AUTODROP SECTION
000000  000207                  LAUTO:  RTS     PC                      ;                                       6238

; Routine Size:  1 word,        Routine Base:  $CODE$ + 4130
; Maximum stack depth per invocation:  0 words



                                        .SBTTL  L$AUTO AUTODROP SECTION
000000  004737  004130'           L$AUTO::JSR     PC,LAUTO                ;                                       6254
000004  104461                           TRAP    61
000006  000207                           RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 4132
; Maximum stack depth per invocation:  2 words
```

```
;    6257  1     %sbttl 'CLEANUP CODING SECTION'
;    6258  1
;    6259  1     !+
;    6260  1     ! THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
;    6261  1     ! AFTER THE HARDWARE TESTS HAVE BEEN PERFORMED.
;    6262  1     !-
;    6263  1
;    6264  2     BGNCLN;
;    6265  2
;    6266  2     LABEL                                                                                                   !ZZZ
;    6267  2         LZ1;                                                                                                !ZZZ
;    6268  2
;    6269  2     DORPT;
;    6270  2
;    6271  2     !CLRVEC (O_TVEC);                                   ! RETURN ODT TRAP TO DIAGNOSTIC SUPERVISER
;    6272  2
;    6273  2     if .CLK_PRESENT
;    6274  2     then
;    6275  3         begin
;    6276  3         LINE_CLOCK = 0;                                 ! STOP THE LINE-CLOCK
;    6277  3     !   CLRVEC (%o'100');                               ! RETURN LINE-CLOCK'S VECTOR TO SUPERVISOR
;    6278  2         end;
;    6279  2
;    6280  2     incr CTLR from 0 to (MAX_CTLR - 1) do               ! FOR EACH CONTROLLER
;    6281  2
;    6282  2         if (RDRX_ADDR = .CST [.CTLR, IP_ADDR]) neqa 0   ! IF CONTROLLER EXISTS
;    6283  2         then
;    6284  3             begin
;    6285  3
;    6286  3             if .ADDR_VECT_OK
;    6287  3             then
;    6288  4     LZ1:        begin                                                                                       !ZZZ
;    6289  4
;    6290  4                 if .DCT [.CTLR, STAT] eql ONLINE        ! IF CONTROLLER ALIVE
;    6291  4                 then
;    6292  4
;    6293  4     !MMM                    incr COUNT from 1 to 10000 do
;    6294  4                             incr COUNT from 1 to 200 do                                                     !MMM
;    6295  5                         begin
;    6296  5                         DELAY (1);
;    6297  5                         BREAK;                                                                          !MMM
;    6298  5                         if .DCT [.CTLR, CRING_CNT] eql 0    ! WAIT TILL OUTSTANDING COMMANDS FINISHED
;    6299  5                         then
;    6300  5
;    6301  5                              INCR Z  FROM 0 TO 3  DO                                                    !ZZZ
;    6302  6                                 BEGIN                                                                   !ZZZ
;    6303  6                                 TEMP1 =  (.DCT [.CTLR, RR_BEG]) + 4 * .Z;       !DESCRIPTOR ADDRESS     !ZZZ
;    6304  6                                 TEMP2 = ..TEMP1;                                !PACKET ADDRESS         !ZZZ
;    6305  6                                 IF ..TEMP2  EQL CRN_LOW                         !CRN                    !ZZZ
;    6306  6                                 THEN                                            !IF THE LAST CRN IS BACK,!ZZZ
;    6307  6                                     (WRT_RDRX (RCIP, RC_ALL, ALL_ONES); LEAVE LZ1); !THEN STOP WAITING  !ZZZ
;    6308  5                                 END;                                                                    !ZZZ
;    6309  4                         end;
```

```
;    6310  4
;    6311  4                 WRT_RDRX (RCIP, RC_ALL, ALL_ONES);          ! WRITE IP TO STOP DEVICE
;    6312  3                 end;
;    6313  3
;    6314  3             CLRVEC (.CST[.CTLR, VEC_ADDR]);                 ! RETURN CONTROLLER'S TRAP VECTOR TO SUPERVISOR
;    6315  2             end;
;    6316  2
;    6317  1     ENDCLN;


                                        .SBTTL  LCLEAN CLEANUP CODING SECTION
000000  004137  000000G            LCLEAN: JSR     R1,$SAVE5                       ;                                       6256
000004  005746                          TST     -(SP)
000006  104424                          TRAP    24                              ;                                       6267
000010  132737  000001  000000G          BITB    #1,CLK.PRESENT                  ;                                       6273
000016  001402                          BEQ     1$
000020  005037  177546                  CLR     @#177546                        ;                                       6276
000024  005005                      1$: CLR     R5                              ; CTLR                                  6280
000026  010546                      2$: MOV     R5,-(SP)                        ; CTLR,*                                6282
000030  012746  000126                  MOV     #126,-(SP)
000034  004737  000000G                JSR     PC,BL$MUL
000040  010003                          MOV     R0,R3
000042  022626                          CMP     (SP)+,(SP)+
000044  016337  000000G 000000G          MOV     CST(R3),RDRX.ADDR
000052  001501                          BEQ     13$
000054  132737  000001  000000G          BITB    #1,ADDR.VECT.OK                 ;                                       6286
000062  001470                          BEQ     12$
000064  010546                          MOV     R5,-(SP)                        ; CTLR,*                                6290
000066  012746  000022                  MOV     #22,-(SP)
000072  004737  000000G                JSR     PC,BL$MUL
000076  010001                          MOV     R0,R1
000100  022626                          CMP     (SP)+,(SP)+
000102  005761  000000G                TST     DCT(R1)
000106  100052                          BPL     11$
000110  012704  000310                  MOV     #310,R4                         ; *,COUNT                               6294
000114  012702  000001              3$: MOV     #1,R2                           ; *,$$TMP2                              6296
000120  001410                      4$: BEQ     7$
000122  013700  000000G                MOV     L$DLY,R0                        ; *,$$TMP1
000126  001403                          BEQ     6$
000130  005016                      5$: CLR     (SP)                            ; $$TMP
000132  005300                          DEC     R0                              ; $$TMP1
000134  001375                          BNE     5$
000136  005302                      6$: DEC     R2                              ; $$TMP2
000140  000767                          BR      4$
000142  104422                      7$: TRAP    22
000144  105761  000000G                TSTB    DCT(R1)                         ;                                       6298
000150  001027                          BNE     10$
000152  005000                          CLR     R0                              ; Z                                     6301
000154  016137  000004G 000000G      8$: MOV     DCT+4(R1),TEMP1                 ;                                       6303
000162  060037  000000G                ADD     R0,TEMP1                        ; Z,*
000166  017737  000000G 000000G          MOV     @TEMP1,TEMP2                    ;                                       6304
000174  027727  000000G 000000G          CMP     @TEMP2,#CRN.LOW                 ;                                       6305
000202  001005                          BNE     9$
```

```
000204  012702  177777                        MOV     #-1,R2                  ; #,RC.REG                      6307
000210  010277  000000G                       MOV     R2,@RDRX.ADDR           ; RC.REG,#
000214  000413                                BR      12$
000216  062700  000004              9$:       ADD     #4,R0                   ; #,Z                           6301
000222  020027  000014                        CMP     R0,#14                  ; Z,#
000226  003752                                BLE     8$
000230  005304                      10$:      DEC     R4                      ; COUNT                         6294
000232  001330                                BNE     3$
000234  012700  177777                11$:      MOV     #-1,R0                  ; #,RC.REG                      6311
000240  010077  000000G                       MOV     R0,@RDRX.ADDR           ; RC.REG,#
000244  016300  000002G               12$:      MOV     CST+2(R3),R0            ;                               6314
000250  042700  177000                        BIC     #177000,R0
000254  104436                                TRAP    36
000256  005205                      13$:      INC     R5                      ; CTLR                          6280
000260  000243                                .WORD CLV!CLC

000262  003661                                BLE     2$
000264  005726                                TST     (SP)+                   ;                               6256
000266  000207                                RTS     PC

; Routine Size:  92 words,      Routine Base:  $CODE$ + 4142
; Maximum stack depth per invocation:  10 words



                                              .SBTTL  L$CLEAN CLEANUP CODING SECTION
000000  004737  004142'            L$CLEAN::
                                              JSR     PC,LCLEAN               ;                               6315
000004  104412                                TRAP    12
000006  000207                                RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 4432
; Maximum stack depth per invocation:  2 words
```

```
;    6318  1     %sbttl 'DROP UNIT SECTION'
;    6319  1
;    6320  1     !+
;    6321  1     ! THE DROP-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
;    6322  1     ! TO NO LONGER BE TESTED.
;    6323  1     !-
;    6324  1
;    6325  2     BGNDU;
;    6326  2
;    6327  2     local
;    6328  2         UNIT : word,                                                        ! UNIT NUMBER
;    6329  2         PRINT : byte initial (byte (FALSE));                                ! NO PRINTING
;    6330  2
;    6331  2     label
;    6332  2         SEARCH;
;    6333  2
;    6334  3     begin
;    6335  3
;    6336  3     register
;    6337  3         INPUT = 0;                                                          ! R0 = UNIT NO.
;    6338  3
;    6339  3     UNIT = .INPUT;                                                          ! GET UNIT NUMBER
;    6340  2     end;                                                                    ! UNDECLARE R0
;    6341  2
;    6342  2     !ZZZif BIT_TST (SWP_FLAGS, SWF_TRC)
;    6343  2     !ZZZthen
;    6344  2     !ZZZ    PRINTF (DBM5, .UNIT);
;    6345  2
;    6346  2     SEARCH :                                                                ! SEARCH BLOCK
;    6347  3     begin
;    6348  3
;    6349  3     incr CTLR from 0 to (MAX_CTLR - 1) do                                   ! FOR EACH CNTR
;    6350  3
;    6351  3         incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do  ! FOR EACH UNIT
;    6352  3
;    6353  3             if (.CST [.CTLR, .OFFSET + OF_DATA, D_UNIT] eql .UNIT) and      ! IF UNIT MATCHES
;    6354  4                (.CST [.CTLR, .OFFSET + OF_DATA, D_PRES] eql PRESENT)
;    6355  3             then
;    6356  4                 begin
;    6357  4
;    6358  4                 if (.CST [.CTLR, .OFFSET + OF_DATA, D_STAT] eql ONLINE) or  ! IF UNIT ALIVE
;    6359  4                    (.DUR [.UNIT] eql DU_ONLINE) or
;    6360  5                    (.DUR [.UNIT] eql DU_PROTECT)
;    6361  4                 then
;    6362  5                     begin
;    6363  5                     PRINT = TRUE;                                          ! O.K. TO PRINT
;    6364  5
;    6365  5                     if (.CST [.CTLR, U_CNT] gtru 0) and
;    6366  6                        (.CST [.CTLR, .OFFSET + OF_DATA, D_STAT] eql ONLINE)
;    6367  5                     then
;    6368  5                         CST [.CTLR, U_CNT] = .CST [.CTLR, U_CNT] - 1;      ! DECREMENT COUNT
;    6369  5
;    6370  5                     if (.CST [.CTLR, U_CNT] eql 0) and
```

```
;    6371  6                        (.CST [.CTLR, .OFFSET + OF_DATA, D_STAT] eql ONLINE)
;    6372  5                    then
;    6373  5                        EOP_FLAG = TRUE;                                                    ! ALL UNITS OFFLINE
;    6374  5
;    6375  5                    CST [.CTLR, .OFFSET + OF_DATA, D_STAT] = OFFLINE;                       ! MARK UNIT OFFLINE
;    6376  4                    end;                                                                    ! IF UNIT ALIVE
;    6377  4
;    6378  4                leave SEARCH;                                                               ! EXIT SEARCH BLOCK
;    6379  3                end;                                                                        ! IF UNIT FOUND
;    6380  3
;    6381  2        end;
;    6382  2
;    6383  2        if .PRINT or                                                                        ! IF OK TO PRINT
;    6384  2           (.DUR [.UNIT] eql DU_CONF) or
;    6385  2           (.DUR [.UNIT] eql DU_INIT) or
;    6386  2           (.DUR [.UNIT] eql DU_ONLINE) or
;    6387  3           (.DUR [.UNIT] eql DU_PROTECT)
;    6388  2        then
;    6389  3            begin
;    6390  3            PRINTF (DU_MSG, .UNIT);                                                         ! "UNIT XX DROPPED"
;    6391  3            PRINTF (.DU_RSN [.DUR [.UNIT]]);                                                ! REASON
;    6392  2            end;
;    6393  2
;    6394  1        ENDDU;


                                        .SBTTL  LDU DROP UNIT SECTION
000000  004137  000000G          LDU:  JSR     R1,$SAVE5                 ;                                   6317
000004  024646                        CMP     -(SP),-(SP)
000006  105066  000002                CLRB    2(SP)                     ; PRINT
000012  010001                        MOV     R0,R1                     ; INPUT.UNIT                        6339
000014  005005                        CLR     R5                        ; CTLR                              6349
000016  010546                  1$:   MOV     R5,-(SP)                  ; CTLR,*                            6353
000020  012746  000053                MOV     #53,-(SP)
000024  004737  000000G               JSR     PC,@L$MUL
000030  010066  000004                MOV     R0,4(SP)
000034  012703  000003                MOV     #3,R3                     ; *,OFFSET                          6351
000040  010300                  2$:   MOV     R3,R0                     ; OFFSET,*                          6353
000042  066600  000004                ADD     4(SP),R0
000046  006300                        ASL     R0
000050  012702  000000G               MOV     #CST,R2
000054  060002                        ADD     R0,R2
000056  010104                        MOV     R1,R4                     ; UNIT,*
000060  011200                        MOV     (R2),R0
000062  000300                        SWAB    R0
000064  042700  177760                BIC     #177760,R0
000070  020004                        CMP     R0,R4
000072  001055                        BNE     8$
000074  032712  040000                BIT     #40000,(R2)               ;                                   6354
000100  001452                        BEQ     8$
000102  005004                        CLR     R4                        ;                                   6358
000104  032712  020000                BIT     #20000,(R2)
000110  001402                        BEQ     3$
```

```
000112  005204                          INC     R4
000114  000410                          BR      4$
000116  126127  000000G 000007   3$:     CMPB    DUR(R1),#7              ; *(UNIT),*                     6359
000124  001404                          BEQ     4$
000126  126127  000000G 000011           CMPB    DUR(R1),#11             ; *(UNIT),*                     6360
000134  001032                          BNE     7$
000136  112766  000001  000006   4$:     MOVB    #1,6(SP)                ; *,PRINT                       6363
000144  010516                          MOV     R5,(SP)                 ; CTLR,*                        6365
000146  012746  000126                  MOV     #126,-(SP)
000152  004737  000000G                 JSR     PC,BL$MUL
000156  005726                          TST     (SP)+
000160  062700  000004G                 ADD     #CST+4,R0
000164  105760  000001                  TSTB    1(R0)
000170  001404                          BEQ     5$
000172  006004                          ROR     R4                      ;                               6366
000174  105660  000001                  SBCB    1(R0)                   ;                               6368
000200  001006                          BNE     6$                      ;                               6370
000202  032712  020000           5$:     BIT     #20000,(R2)             ;                               6371
000206  001403                          BEQ     6$
000210  112737  000001  000000G         MOVB    #1,EOP.FLAG             ;                               6373
000216  042712  020000           6$:     BIC     #20000,(R2)             ;                               6375
000222  022626                   7$:     CMP     (SP)+,(SP)+             ;                               6356
000224  000411                          BR      9$
000226  062703  000012           8$:     ADD     #12,R3                  ; *,OFFSET                      6351
000232  020327  000041                  CMP     R3,#41                  ; OFFSET,*
000236  003700                          BLE     2$
000240  022626                          CMP     (SP)+,(SP)+
000242  005205                          INC     R5                      ; CTLR                          6349
000244  000243                  .WORD CLV!CLC

000246  003663                          BLE     1$
000250  032766  000001  000002   9$:     BIT     #1,2(SP)                ; *,PRINT                       6383
000256  001020                          BNE     10$
000260  126127  000000G 000001           CMPB    DUR(R1),#1              ; *(UNIT),*                     6384
000266  001414                          BEQ     10$
000270  126127  000000G 000002           CMPB    DUR(R1),#2              ; *(UNIT),*                     6385
000276  001410                          BEQ     10$
000300  126127  000000G 000007           CMPB    DUR(R1),#7              ; *(UNIT),*                     6386
000306  001404                          BEQ     10$
000310  126127  000000G 000011           CMPB    DUR(R1),#11             ; *(UNIT),*                     6387
000316  001024                          BNE     11$
000320  010146                  10$:     MOV     R1,-(SP)                ; UNIT,*                        6390
000322  012746  000000G                 MOV     #DU.MSG,-(SP)
000326  012746  000002                  MOV     #2,-(SP)
000332  010600                          MOV     SP,R0                   ; SP,*
000334  104417                          TRAP    17
000336  116101  000000G                 MOVB    DUR(R1),R1              ; *(UNIT),*                     6391
000342  042701  177400                  BIC     #177400,R1
000346  006301                          ASL     R1
000350  016116  000000G                 MOV     DU.RSN(R1),(SP)
000354  012746  000001                  MOV     #1,-(SP)
000360  010600                          MOV     SP,R0                   ; SP,*
000362  104417                          TRAP    17
```

```
000364  062706  000010                    ADD     #10,SP                          ;                       6389
000370  022626                    11$:    CMP     (SP)+,(SP)+                     ;                       6317
000372  000207                            RTS     PC

; Routine Size:  126 words,      Routine Base:  $CODE$ + 4442
; Maximum stack depth per invocation:  14 words



                                        .SBTTL  L$DU DROP UNIT SECTION
000000  004737  004442'            L$DU::  JSR     PC,LDU                          ;                       6392
000004  104453                            TRAP    53
000006  000207                            RTS     PC

; Routine Size:  4 words,      Routine Base:  $CODE$ + 5036
; Maximum stack depth per invocation:  2 words
```

```
;    6395  1     %sbttl 'ADD UNIT SECTION'
;    6396  1
;    6397  1     !+
;    6398  1     ! THE ADD-UNIT SECTION CONTAINS ANY CODE THE PROGRAMMER WISHES
;    6399  1     !  TO BE EXECUTED IN CONJUNCTION WITH THE ADDING OF A UNIT BACK
;    6400  1     !  TO THE TEST CYCLE.
;    6401  1     !-
;    6402  1
;    6403  2     BGNAU;
;    6404  2
;    6405  2     local
;    6406  2         STINDX : word,
;    6407  2         ENDIDX : word;
;    6408  2
;    6409  2     register
;    6410  2         UNIT = 0;                                   ! UNIT NUMBER APPEARS IN R0 UPON ENTRY
;    6411  2
;    6412  3     if BIT_TST (SWP_FLAGS, SWF_CST)
;    6413  2     then
;    6414  3         begin                                       ! IF CLEAR STAT. TABLES TRUE....
;    6415  3         STINDX = .UNIT * TALLY_LEN;                 ! ZERO OUT
;    6416  3         ENDIDX = .STINDX + TALLY_LEN - 1;           !    ADDED
;    6417  3
;    6418  3         incr COUNT from .STINDX to .ENDIDX do       !    UNIT'S
;    6419  3             TALLY [.COUNT] = 0;                     !    STATISTICS
;    6420  3
;    6421  2         end;
;    6422  2
;    6423  1     ENDAU;


                                        .SBTTL  LAU ADD UNIT SECTION
000000  004137  000000G         LAU:    JSR     R1,$SAVE2               ;                                   6394
000004  105737  000000G                 TSTB    SWP.FLAGS               ;                                   6412
000010  100023                          BPL     3$
000012  010046                          MOV     R0,-(SP)                ; UNIT,*                            6415
000014  012746  000033                  MOV     #33,-(SP)
000020  004737  000000G                 JSR     PC,BL$MUL
000024  010002                          MOV     R0,R2                   ; STINDX,ENDIDX                     6416
000026  062702  000032                  ADD     #32,R2                  ; *,ENDIDX
000032  010001                          MOV     R0,R1                   ; STINDX,COUNT                      6418
000034  005301                          DEC     R1                      ; COUNT
000036  000404                          BR      2$
000040  010100                  1$:     MOV     R1,R0                   ; COUNT,*                           6419
000042  006300                          ASL     R0
000044  005060  000000G                 CLR     TALLY(R0)
000050  005201                  2$:     INC     R1                      ; COUNT                             6418
000052  020102                          CMP     R1,R2                   ; COUNT,ENDIDX
000054  003771                          BLE     1$
000056  022626                          CMP     (SP)+,(SP)+             ;                                   6414
000060  000207                  3$:     RTS     PC                      ;                                   6394

; Routine Size:  25 words,      Routine Base:  $CODE$ + 5046
```

```
; Maximum stack depth per invocation:  6 words


                                        .SBTTL  L$AU ADD UNIT SECTION
000000  004737  005046'          L$AU::  JSR     PC,LAU                  ;                       6421
000004  104452                          TRAP    52
000006  000207                          RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 5130
; Maximum stack depth per invocation:  2 words
```

```
;    6424  1     %sbttl 'NON-EXISTENT MEMORY TRAP HANDLER'
;    6425  1
;    6426  1     !+
;    6427  1     !       THIS TRAP HANDLER IS VECTORED FROM LOCATION 4 FOR ALL UNIBUS TIMEOUT
;    6428  1     !       ERRORS, INDICATING THAT AN ATTEMPT WAS MADE TO REFERENCE A NON-EXISTENT
;    6429  1     !       MEMORY LOCATION. ITS MAIN PURPOSE IS TO SET A FLAG FOR THE RDRX
;    6430  1     !       REGISTER EXISTENCE TEST, INDICATING THE ABSENCE OF A DEVICE REGISTER.
;    6431  1     !-
;    6432  1
;    6433  2     BGNSRV (NEX_TRAP);
;    6434  2
;    6435  2     NEX = TRUE;                                     ! NEX TRAP OCCURRED
;    6436  2
;    6437  1     ENDSRV;


                                            .SBTTL  NEX.TRAP NON-EXISTENT MEMORY TRAP HANDLER
000000  012737  000001  000000G     NEX.TRAP::
                                            MOV     #1,NEX                          ;                       6435
000006  000002                              RTI                                     ;                       6433

; Routine Size:  4 words,       Routine Base:  $CODE$ + 5140
; Maximum stack depth per invocation:  0 words
```

```
;    6438  1     %sbttl 'HOST MEMORY PARITY TRAP HANDLER'                          !MMM
;    6439  1
;    6440  1     !+
;    6441  1     !       THIS TRAP HANDLER IS VECTORED FROM LOCATION 114 FOR ALL HOST MEMORY PARITY
;    6442  1     !       ERRORS, INDICATING THAT AN ATTEMPT WAS MADE TO READ A MEMORY LOCATION WITH
;    6443  1     !       PARITY/UNCORRECTABLE ECC ERROR DETECTED BY THE MEMORY'S PARITY OR ECC LOGIC.
;    6444  1     !-
;    6445  1
;    6446  2     BGNSRV (PARITY);
;    6447  2
;    6448  2     builtin
;    6449  2           HALT;
;    6450  2
;    6451  2     PRINTF (DBM125, ..CSR_ADD);
;    6452  2
;    6453  2     .CSR_ADD = %o'40000';
;    6454  2
;    6455  2     PRINTF (DBM126, ..CSR_ADD);
;    6456  2
;    6457  2     HALT ();
;    6458  2
;    6459  1     ENDSRV;


                                          .SBTTL  PARITY HOST MEMORY PARITY TRAP HANDLER
000000  010046                        PARITY::MOV     R0,-(SP)                          ;                                6446
000002  017746  000000G                       MOV     @CSR.ADD,-(SP)                    ;                                6451
000006  012746  000000G                       MOV     #DBM125,-(SP)
000012  012746  000002                        MOV     #2,-(SP)
000016  010600                                MOV     SP,R0                             ; SP,*
000020  104417                                TRAP    17
000022  012777  040000  000000G               MOV     #40000,@CSR.ADD                   ;                                6453
000030  012716  040000                        MOV     #40000,(SP)                       ;                                6455
000034  012746  000000G                       MOV     #DBM126,-(SP)
000040  012746  000002                        MOV     #2,-(SP)
000044  010600                                MOV     SP,R0                             ; SP,*
000046  104417                                TRAP    17
000050  000000                                HALT                                      ;                                6457
000052  062706  000012                        ADD     #12,SP                            ;                                6446
000056  012600                                MOV     (SP)+,R0
000060  000002                                RTI

; Routine Size:  25 words,      Routine Base:  $CODE$ + 5150
; Maximum stack depth per invocation:  8 words


;    6460  1
```

```
;    6461  1     %sbttl 'TIME OF DAY'
;    6462  1
;    6463  1     !+
;    6464  1     !       THIS INTERRUPT SERVICE ROUTINE KEEPS TRACK OF THE TIME-OF-DAY
;    6465  1     !-
;    6466  1
;    6467  2     BGNSRV (TIME);
;    6468  2
;    6469  2     CLK_TICKS = .CLK_TICKS + 1;             ! INCREMENT CLOCK-TICKS
;    6470  2
;    6471  2     if .CLK_TICKS gequ 3600
;    6472  2     then
;    6473  3         begin
;    6474  3         MINUTES = .MINUTES + 1;             ! UPDATE MINUTE COUNT
;    6475  3         CLK_TICKS = 0;
;    6476  2         end;
;    6477  2
;    6478  2     if .MINUTES gequ 60
;    6479  2     then
;    6480  3         begin
;    6481  3         HOURS = .HOURS + 1;                 ! UPDATE HOUR COUNT
;    6482  3         MINUTES = 0;
;    6483  2         end;
;    6484  2
;    6485  2     if .HOURS gequ 24
;    6486  2     then
;    6487  2         HOURS = 0;                          ! RATIONALIZE HOURS
;    6488  2
;    6489  1     ENDSRV;


                                        .SBTTL  TIME TIME OF DAY
000000  005237  000000G            TIME::  INC     CLK.TICKS                       ;  6469
000004  023727  000000G 007020          CMP     CLK.TICKS,#7020                 ;  6471
000012  103404                          BLO     1$
000014  105237  000000G                 INCB    MINUTES                         ;  6474
000020  005037  000000G                 CLR     CLK.TICKS                       ;  6475
000024  123727  000000G 000074      1$: CMPB    MINUTES,#74                     ;  6478
000032  103404                          BLO     2$
000034  105237  000000G                 INCB    HOURS                           ;  6481
000040  105037  000000G                 CLRB    MINUTES                         ;  6482
000044  123727  000000G 000030      2$: CMPB    HOURS,#30                       ;  6485
000052  103402                          BLO     3$
000054  105037  000000G                 CLRB    HOURS                           ;  6487
000060  000002                      3$: RTI                                     ;  6467

; Routine Size:  25 words,    Routine Base:  $CODE$ + 5232
; Maximum stack depth per invocation:  0 words
```

```
;    6490  1      %sbttl 'GLOBAL ROUTINES'
;    6491  1
;    6492  1      global routine SET_CPAR (CTLR) : novalue =
;    6493  1
;    6494  1      !+
;    6495  1      !       THIS ROUTINE SETS UP THE COMMONLY-USED CONTROLLER-RELATED DATA ITEMS
;    6496  1      !       FOR THE GIVEN CONTROLLER NUMBER.
;    6497  1      !
;    6498  1      !       INPUTS:
;    6499  1      !               CTLR - CONTROLLER NUMBER
;    6500  1      !
;    6501  1      !       IMPLICIT OUTPUTS:
;    6502  1      !               CCTLR - CURRENT CONTROLLER NUMBER
;    6503  1      !               CST_ADDR - ADDRESS OF CONTROLLER'S STATUS TABLE
;    6504  1      !               DCT_ADDR - ADDRESS OF CONTROLLER'S DRIVER TABLE
;    6505  1      !               RDRX_ADDR - ADDRESS OF CONTROLLER'S IP REGISTER
;    6506  1      !-
;    6507  1
;    6508  2          begin
;    6509  2          CCTLR = .CTLR;                              ! SET CURRENT CONTROLLER NUMBER
;    6510  2          CST_ADDR = CST + (.CTLR * CST_LEN * 2);     ! CALCULATE ADDRESS OF CONTROLLER'S CST
;    6511  2          DCT_ADDR = DCT + (.CTLR * DCT_LEN * 2);     ! CALCULATE ADDRESS OF CONTROLLER'S DCT
;    6512  2          RDRX_ADDR = .CST_ADDR [IP_ADDR];            ! GET CONTROLLER'S DEVICE ADDRESS
;    6513  1          end;


                                        .SBTTL  SET.CPAR GLOBAL ROUTINES
000000  010146                         SET.CPAR::
                                                MOV     R1,-(SP)                        ;                               6492
000002  016601  000004                          MOV     4(SP),R1                        ; CTLR,*                        6509
000006  010137  000000G                         MOV     R1,CCTLR
000012  010146                                  MOV     R1,-(SP)                        ;                               6510
000014  012746  000126                          MOV     #126,-(SP)
000020  004737  000000G                         JSR     PC,BL$MUL
000024  062700  000000G                         ADD     #CST,R0
000030  010037  000000G                         MOV     R0,CST.ADDR
000034  010116                                  MOV     R1,(SP)                         ;                               6511
000036  012746  000022                          MOV     #22,-(SP)
000042  004737  000000G                         JSR     PC,BL$MUL
000046  062700  000000G                         ADD     #DCT,R0
000052  010037  000000G                         MOV     R0,DCT.ADDR
000056  017737  000000G 000000G                 MOV     @CST.ADDR,RDRX.ADDR             ;                               6512
000064  062706  000006                          ADD     #6,SP                           ;                               6508
000070  012601                                  MOV     (SP)+,R1                        ;                               6492
000072  000207                                  RTS     PC

; Routine Size:  30 words,      Routine Base:  $CODE$ + 5314
; Maximum stack depth per invocation:  5 words
```

```
;    6514  1      global routine SET_UPAR (OFFSET) : novalue =
;    6515  1      !+
;    6516  1      !       THIS ROUTINE SETS UP THE COMMONLY-USED UNIT-RELATED DATA ITEMS FOR
;    6517  1      !       THE CURRENT CONTROLLER AND GIVEN CST OFFSET.
;    6518  1      !
;    6519  1      !       INPUTS:
;    6520  1      !               OFFSET - WORD OFFSET INTO CURRENT CONTROLLER'S CST WHICH
;    6521  1      !                        DESCRIBES A UNIT
;    6522  1      !
;    6523  1      !       IMPLICIT INPUTS:
;    6524  1      !               CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
;    6525  1      !
;    6526  1      !       IMPLICIT OUTPUTS:
;    6527  1      !               CUOFF - CURRENT UNIT'S CST OFFSET
;    6528  1      !               CDISK - CURRENT DISK ADDRESS (RD/RX DISK NUMBER)
;    6529  1      !               L$LUN - CURRENT UNIT NUMBER (DRS UNIT NUMBER)
;    6530  1      !               T_ADDR - ADDRESS OF CURRENT UNIT'S STATISTICS BLOCK (TALLY)
;    6531  1      !-
;    6532  2          begin
;    6533  2          CUOFF = .OFFSET;
;    6534  2          CDISK = .CST_ADDR [.OFFSET + OF_DATA, D_DISK_NUM];
;    6535  2          L$LUN = .CST_ADDR [.OFFSET + OF_DATA, D_UNIT];
;    6536  2          T_ADDR = TALLY + (.L$LUN * TALLY_LEN * 2);
;    6537  1          end;


                                        .SBTTL  SET.UPAR GLOBAL ROUTINES
000000  010146                     SET.UPAR::
                                        MOV     R1,-(SP)                        ;                                       6514
000002  016637  000004  000000G        MOV     4(SP),CUOFF                     ; OFFSET,*                              6533
000010  016600  000004                  MOV     4(SP),R0                        ; CUOFF,*                               6534
000014  006300                          ASL     R0
000016  063700  000000G                 ADD     CST_ADDR,R0
000022  111037  000000G                 MOVB    (R0),CDISK
000026  042737  177760  000000G        BIC     #177760,CDISK
000034  011001                          MOV     (R0),R1                         ;                                       6535
000036  000301                          SWAB    R1
000040  042701  177760                  BIC     #177760,R1
000044  010137  000000G                 MOV     R1,L$LUN
000050  010146                          MOV     R1,-(SP)                        ; L$LUN,*                               6536
000052  012746  000066                  MOV     #66,-(SP)
000056  004737  000000G                 JSR     PC,BL$MUL
000062  062700  000000G                 ADD     #TALLY,R0
000066  010037  000000G                 MOV     R0,T_ADDR
000072  022626                          CMP     (SP)+,(SP)+                     ;                                       6532
000074  012601                          MOV     (SP)+,R1                        ;                                       6514
000076  000207                          RTS     PC

; Routine Size:  32 words,      Routine Base:  $CODE$ + 5410
; Maximum stack depth per invocation:  4 words
```

```
;    6538  1
;    6539  1     global routine GET_PKT (CTLR) =
;    6540  1
;    6541  1     !+
;    6542  1     !       THIS ROUTINE SEARCHES THE MSCP PACKET POOL ALLOCATION TABLE (PKT_USE)
;    6543  1     !       FOR A FREE MSCP PACKET TO ALLOCATE TO THE GIVEN CONTROLLER. IF ONE IS
;    6544  1     !       FOUND, THE PACKET IS ZEROED OUT, AND THE PACKET INDEX IS RETURNED
;    6545  1     !       TO THE CALLER. OTHERWISE, A -1 IS RETURNED INDICATING NONE AVAILABLE.
;    6546  1     !
;    6547  1     !       INPUTS:
;    6548  1     !               CTLR - CONTROLLER NUMBER REQUESTING ALLOCATION
;    6549  1     !-
;    6550  1
;    6551  2         begin
;    6552  2
;    6553  2         local
;    6554  2             index : signed word initial (-1),
;    6555  2             RING_ADDR : word,
;    6556  2             PACKET_OWNED : byte,
;    6557  2             NEXT_PACKET : byte;
;    6558  2
;    6559  2
;    6560  2         NEXT_PACKET = .NEXT_PKT_USE;                        ! NEXT PACKET TO TRY
;    6561  2
;    6562  2         incr COUNT from 0 to (PKT_CNT - 1) do               ! FOR EACH ENTRY IN ALLOCATION TABLE
;    6563  3             begin
;    6564  3             PACKET_OWNED = FALSE;
;    6565  3
;    6566  3             if .PKT_USE [.NEXT_PACKET] lss 0                ! IF ENTRY INDICATES FREE PACKET
;    6567  3
;    6568  3             then
;    6569  4                 begin
;    6570  4                 RING_ADDR = .DCT_ADDR [RR_BEG];             ! FIRST RESPONSE PACKET'S ADDRESS
;    6571  4
;    6572  4                 incr I from 1 to (RRING_LEN + CRING_LEN) do ! FOR EACH PACKET ADDRESS
;    6573  4
;    6574  4                     if (..RING_ADDR eqla .MSCP_PKT [.NEXT_PACKET, PKT_LO]) and
;    6575  4     !MMM                (((.RING_ADDR + 2) and ED_OWN) eql ED_OWN)
;    6576  5                         (((.(.RING_ADDR + 2)) and ED_OWN) eql ED_OWN)                                   !MMM
;    6577  5
;    6578  4                     then
;    6579  5                         begin                               ! CHECK ADDRESS AND OWNERSHIP
;    6580  5                         PACKET_OWNED = TRUE;                ! PACKET OWNED BY CONTROLLER
;    6581  5                         exitloop;
;    6582  5                         end
;    6583  4                     else
;    6584  4                         RING_ADDR = .RING_ADDR + 4;         ! ADDRESS OF NEXT PACKET IN RING
;    6585  4
;    6586  4                 if not .PACKET_OWNED                        ! IF NOT ALREADY USED
;    6587  4
;    6588  4                 then
;    6589  5                     begin
;    6590  5                     PKT_USE [.NEXT_PACKET] = .CTLR;         ! ALLOCATE PACKET TO CONTROLLER
```

```
;    6591  5                      index = .NEXT_PACKET;
;    6592  5
;    6593  5                      incr J from 2 to (PKT_LEN - 1) do       ! ZERO OUT PACKET
;    6594  5                          MSCP_PKT [.NEXT_PACKET, .J, 0, 16, 0] = 0;
;    6595  5
;    6596  5                      exitloop;                               ! DONE
;    6597  5
;    6598  4                      end;
;    6599  4
;    6600  3                  end;
;    6601  3
;    6602  3              NEXT_PACKET = .NEXT_PACKET + 1;                 ! TRY NEXT PACKET IN RING
;    6603  3
;    6604  3              if .NEXT_PACKET gequ PKT_CNT
;    6605  3
;    6606  3              then
;    6607  3                  NEXT_PACKET = 0;                            ! IF BEYOND ALL PACKETS, START AT THE TOP
;    6608  3
;    6609  2              end;
;    6610  2
;    6611  2          if (.index geq 0) and                               ! IF PACKET FOUND
;    6612  3             (.PKT_USE [.index] geq 0)
;    6613  2          then
;    6614  2
;    6615  3              begin
;    6616  3              MSCP_PKT [.index, MSGLEN] = SZ_GEN;             ! PACKET SIZE - ONLY ONLINE AND SCC CHANGE IT
;    6617  3              MSCP_PKT [.index, CREDITS] = 1;                 ! CREDIT SIZE
;    6618  3              NEXT_PKT_USE = .NEXT_PACKET + 1;                ! NEXT PACKET TO ALLOCATE
;    6619  3
;    6620  3              if.NEXT_PKT_USE gequ PKT_CNT
;    6621  3              then
;    6622  3                  NEXT_PKT_USE = 0;                           ! CYCLE BACK TO BEGINNING IF AT END
;    6623  3
;    6624  2              end;
;    6625  2
;    6626  2          return .index;
;    6627  2
;    6628  1          end;


                                        .SBTTL  GET.PKT GLOBAL ROUTINES
000000  004137  000000G          GET.PKT::
                                        JSR     R1,$SAVE5                       ;                                       6539
000004  162706  000006                  SUB     #6,SP
000010  012704  177777                  MOV     #-1,R4                          ; *,INDEX                               6551
000014  113766  000000G 000004          MOVB    NEXT.PKT.USE,4(SP)              ; *,NEXT.PACKET                         6560
000022  012766  000014  000002          MOV     #14,2(SP)                       ; *,COUNT                               6562
000030  105016                  1$:     CLRB    (SP)                            ; PACKET.OWNED                          6564
000032  005001                          CLR     R1                              ;                                       6566
000034  156601  000004                  BISB    4(SP),R1                        ; NEXT.PACKET,*
000040  105761  000000G                 TSTB    PKT.USE(R1)
000044  002071                          BGE     7$
000046  013700  000000G                 MOV     DCT.ADDR,R0                     ;                                       6570
```

```
000052  016005  000004                          MOV     4(R0),R5                ; *,RING.ADDR
000056  010146                                  MOV     R1,-(SP)                ;                                               6574
000060  012746  000106                          MOV     #106,-(SP)
000064  004737  000000G                         JSR     PC,BL$MUL
000070  012702  000010                          MOV     #10,R2                  ; *,I                                           6572
000074  021560  000000G                 2$:     CMP     (R5),MSCP.PKT(R0)       ; RING.ADDR,*                                   6574
000100  001013                                  BNE     3$
000102  016503  000002                          MOV     2(R5),R3                ; *(RING.ADDR),*                                6576
000106  042703  077777                          BIC     #77777,R3
000112  020327  100000                          CMP     R3,#-100000
000116  001004                                  BNE     3$
000120  112766  000001  000004                  MOVB    #1,4(SP)                ; *,PACKET.OWNED                                6580
000126  000404                                  BR      4$                      ;                                               6579
000130  062705  000004                  3$:     ADD     #4,R5                   ; *,RING.ADDR                                   6584
000134  005302                                  DEC     R2                      ; I                                             6572
000136  001356                                  BNE     2$
000140  032766  000001  000004          4$:     BIT     #1,4(SP)                ; *,PACKET.OWNED                                6586
000146  001027                                  BNE     6$
000150  116661  000030  000000G                 MOVB    30(SP),PKT.USE(R1)      ; CTLR,*                                        6590
000156  010104                                  MOV     R1,R4                   ; *,INDEX                                       6591
000160  010116                                  MOV     R1,(SP)                 ;                                               6594
000162  012746  000043                          MOV     #43,-(SP)
000166  004737  000000G                         JSR     PC,BL$MUL
000172  005726                                  TST     (SP)+
000174  012702  000002                          MOV     #2,R2                   ; *,J                                           6593
000200  010003                          5$:     MOV     R0,R3                   ;                                               6594
000202  060203                                  ADD     R2,R3                   ; J,*
000204  006303                                  ASL     R3
000206  005063  000000G                         CLR     MSCP.PKT(R3)
000212  005202                                  INC     R2                      ; J                                             6593
000214  020227  000042                          CMP     R2,#42                  ; J,*
000220  003767                                  BLE     5$
000222  022626                                  CMP     (SP)+,(SP)+             ;                                               6589
000224  000414                                  BR      9$
000226  022626                          6$:     CMP     (SP)+,(SP)+             ;                                               6569
000230  105266  000004                  7$:     INCB    4(SP)                   ; NEXT.PACKET                                   6602
000234  126627  000004  000014                  CMPB    4(SP),#14               ; NEXT.PACKET,*                                 6604
000242  103402                                  BLO     8$
000244  105066  000004                          CLRB    4(SP)                   ; NEXT.PACKET                                   6607
000250  005366  000002                  8$:     DEC     2(SP)                   ; COUNT                                         6562
000254  001265                                  BNE     1$
000256  005704                          9$:     TST     R4                      ; INDEX                                         6611
000260  002435                                  BLT     11$
000262  105764  000000G                         TSTB    PKT.USE(R4)             ; *(INDEX)                                      6612
000266  002432                                  BLT     11$
000270  010446                                  MOV     R4,-(SP)                ; INDEX,*                                       6616
000272  012746  000106                          MOV     #106,-(SP)
000276  004737  000000G                         JSR     PC,BL$MUL
000302  012760  000040  000006G                 MOV     #40,MSCP.PKT+6(R0)
000310  142760  000017  000010G                 BICB    #17,MSCP.PKT+10(R0)     ;                                               6617
000316  152760  000001  000010G                 BISB    #1,MSCP.PKT+10(R0)
000324  005000                                  CLR     R0                      ;                                               6618
000326  156600  000010                          BISB    10(SP),R0               ; NEXT.PACKET,*
```

```
000332  005200                          INC     R0
000334  110037  000000G                 MOVB    R0,NEXT.PKT.USE
000340  120027  000014                  CMPB    R0,#14                  ; NEXT.PKT.USE,*                6620
000344  103402                          BLO     10$
000346  105037  000000G                 CLRB    NEXT.PKT.USE            ;                               6622
000352  022626                  10$:    CMP     (SP)+,(SP)+             ;                               6615
000354  010400                  11$:    MOV     R4,R0                   ; INDEX,*                       6551
000356  062706  000006                  ADD     #6,SP                   ;                               6539
000362  000207                          RTS     PC

; Routine Size:  122 words,    Routine Base:  $CODE$ + 5510
; Maximum stack depth per invocation:  13 words


;   6629  1
;   6630  1
```

```
;   6631  1
;   6632  1
;   6633  1     global routine PUT_PKT (index) : novalue =
;   6634  1
;   6635  1     !+
;   6636  1     !       THE MSCP PACKET DESIGNATED BY "INDEX" IS RETURNED TO THE POOL BY THIS
;   6637  1     !       ROUTINE.
;   6638  1     !-
;   6639  1
;   6640  1
;   6641  2         begin
;   6642  2
;   6643  2
;   6644  2         local
;   6645  2             RING_ADDR : word,
;   6646  2             OWNER : word;
;   6647  2
;   6648  2         RING_ADDR = .DCT_ADDR [RR_BEG];                         ! ADDRESS IN FIRST RESPONSE RING
;   6649  2
;   6650  2         incr COUNT from 1 to (RRING_LEN + CRING_LEN) do          ! FOR EACH ADDRESS IN THE RINGS
;   6651  3             begin
;   6652  3
;   6653  3             if .MSCP_PKT [.index, PKT_LO] eqla ..RING_ADDR      ! IF ADDRESS MATCHES
;   6654  3
;   6655  3             then
;   6656  4                 begin
;   6657  4                 OWNER = .RING_ADDR + 2;                         ! ADDRESS OF OWNERSHIP WORD
;   6658  4                 .OWNER = ..OWNER and (not (ED_OWN)) and (not (ED_FLAG)) ;   ! GIVE OWNERSHIP TO HOST
;   6659  3                 end;
;   6660  3
;   6661  3
;   6662  3             RING_ADDR = .RING_ADDR + 4;                         ! LOOK AT NEXT PACKET ADDRESS IN RING
;   6663  2             end;
;   6664  2
;   6665  2
;   6666  2         PKT_USE [.index] = -1;
;   6667  2
;   6668  1         end;


                                .SBTTL  PUT.PKT GLOBAL ROUTINES
000000  004137  000000G   PUT.PKT::
                            JSR     R1,$SAVE4                   ;                                   6633
000004  013700  000000G            MOV     DCT.ADDR,R0         ;                                   6648
000010  016001  000004             MOV     4(R0),R1            ; *,RING.ADDR
000014  016602  000014             MOV     14(SP),R2           ; INDEX,*                           6653
000020  010246                     MOV     R2,-(SP)
000022  012746  000106             MOV     #106,-(SP)
000026  004737  000000G            JSR     PC,BL$MUL
000032  012704  000010             MOV     #10,R4              ; *,COUNT                           6650
000036  026011  000000G   1$:      CMP     MSCP.PKT(R0),(R1)   ; *,RING.ADDR                       6653
000042  001005                     BNE     2$
000044  012703  000002             MOV     #2,R3               ; *,OWNER                           6657
```

```
000050  060103                          ADD     R1,R3                   ; RING.ADDR,OWNER
000052  042713  140000                  BIC     #140000,(R3)            ; *,OWNER                       6658
000056  062701  000004          2$:     ADD     #4,R1                   ; *,RING.ADDR                   6662
000062  005304                          DEC     R4                      ; COUNT                         6650
000064  001364                          BNE     1$
000066  112762  000377  000000G         MOVB    #377,PKT.USE(R2)        ;                               6666
000074  022626                          CMP     (SP)+,(SP)+             ;                               6641
000076  000207                          RTS     PC                      ;                               6633

; Routine Size:  32 words,      Routine Base:  $CODE$ + 6074
; Maximum stack depth per invocation:  8 words


;   6669  1
;   6670  1
```

```
;    6671  1      routine PUTA_PKT (CTLR) : novalue =
;    6672  1
;    6673  1      !+
;    6674  1      !       THIS ROUTINE DEALLOCATES ALL MSCP PACKETS WHICH HAVE BEEN ALLOCATED
;    6675  1      !       TO A PARTICULAR CONTROLLER.
;    6676  1      !
;    6677  1      !       INPUTS:
;    6678  1      !               CTLR - CONTROLLER NUMBER
;    6679  1      !-
;    6680  1
;    6681  1          incr COUNT from 0 to (PKT_CNT - 1) do       ! FOR EACH ENTRY IN ALLOCATION TABLE
;    6682  1
;    6683  1              if .PKT_USE [.COUNT] eql .CTLR          ! IF PACKET IS ALLOCATED TO GIVEN CONTROLLER
;    6684  1              then
;    6685  1                  PKT_USE [.COUNT] =  1;              ! DEALLOCATE IT


                                        .SBTTL  PUTA.PKT GLOBAL ROUTINES
000000  010146                  PUTA.PKT:
                                        MOV     R1,-(SP)                ;                                       6671
000002  005000                          CLR     R0                      ; COUNT                                 6681
000004  116001  000000G         1$:     MOVB    PKT.USE(R0),R1          ; *(COUNT),*                            6683
000010  020166  000004                  CMP     R1,4(SP)                ; *,CTLR
000014  001003                          BNE     2$
000016  112760  000377  000000G        MOVB    #377,PKT.USE(R0)        ; *,*(COUNT)                            6685
000024  005200                  2$:     INC     R0                      ; COUNT                                 6681
000026  020027  000013                  CMP     R0,#13                  ; COUNT,*
000032  003764                          BLE     1$
000034  012601                          MOV     (SP)+,R1                ;                                       6671
000036  000207                          RTS     PC

; Routine Size:  16 words,      Routine Base:  $CODE$ + 6174
; Maximum stack depth per invocation:  2 words
```

```
;   6686  1     global routine GET_RETPKT (CTLR) =
;   6687  1
;   6688  1     !+
;   6689  1     !       THIS ROUTINE SEARCHES THE RETURN PACKET POOL ALLOCATION TABLE (RP_USE)
;   6690  1     !       FOR A FREE RETURN PACKET TO ALLOCATE TO THE GIVEN CONTROLLER. IF ONE IS
;   6691  1     !       FOUND, THE PACKET IS ZEROED OUT, AND THE PACKET INDEX IS RETURNED TO
;   6692  1     !       THE CALLER. OTHERWISE, A -1 IS RETURNED INDICATING NONE AVAILABLE.
;   6693  1     !
;   6694  1     !       INPUTS:
;   6695  1     !               CTLR - CONTROLLER NUMBER REQUESTING ALLOCATION
;   6696  1     !-
;   6697  1
;   6698  2         begin
;   6699  2
;   6700  2         local
;   6701  2             index : signed word initial (-1);       ! ASSUME NONE AVAILABLE
;   6702  2
;   6703  2         incr COUNT from 0 to (RP_CNT - 1) do        ! FOR EACH ENTRY IN TABLE
;   6704  2
;   6705  2             if .RP_USE [.COUNT] lss 0               ! IF FREE RETPKT IS FOUND
;   6706  2             then
;   6707  3                 begin
;   6708  3                 RP_USE [.COUNT] = .CTLR;            ! ALLOCATE RETURN PACKET TO CONTROLLER
;   6709  3                 index = .COUNT;
;   6710  3
;   6711  3                 incr J from 0 to (RP_LEN - 1) do    ! ZERO OUT RETPKT
;   6712  3                     RETPKT [.COUNT, .J, 0, 16, 0] = 0;
;   6713  3
;   6714  3                 exitloop;                           ! DONE
;   6715  2                 end;
;   6716  2
;   6717  2         return .index;                              ! RETURN PACKET INDEX (OR  1) TO CALLER
;   6718  1         end;


                                        .SBTTL  GET.RETPKT GLOBAL ROUTINES
000000  004137  000000G          GET.RETPKT::
                                        JSR     R1,$SAVE4                       ;                               6686
000004  012703  177777                  MOV     #-1,R3                          ; *,INDEX                       6698
000010  005001                          CLR     R1                              ; COUNT                         6703
000012  105761  000000G          1$:    TSTB    RP.USE(R1)                      ; *(COUNT)                      6705
000016  002025                          BGE     3$
000020  116661  000014  000000G        MOVB    14(SP),RP.USE(R1)               ; CTLR,*(COUNT)                 6708
000026  010103                          MOV     R1,R3                           ; COUNT,INDEX                   6709
000030  010146                          MOV     R1,-(SP)                        ; COUNT,*                       6712
000032  012746  000026                  MOV     #26,-(SP)
000036  004737  000000G                JSR     PC,BL$MUL
000042  022626                          CMP     (SP)+,(SP)+
000044  005002                          CLR     R2                              ; J                             6711
000046  010004                  2$:     MOV     R0,R4                           ;                               6712
000050  060204                          ADD     R2,R4                           ; J,*
000052  006304                          ASL     R4
000054  005064  000000G                CLR     RETPKT(R4)
```

```
000060  005202                          INC     R2                      ; J                             6711
000062  020227  000025                  CMP     R2,#25                  ; J,*
000066  003767                          BLE     2$
000070  000404                          BR      4$                      ;                               6707
000072  005201                  3$:     INC     R1                      ; COUNT                         6703
000074  020127  000007                  CMP     R1,#7                   ; COUNT,*
000100  003744                          BLE     1$
000102  010300                  4$:     MOV     R3,R0                   ; INDEX,*                       6698
000104  000207                          RTS     PC                      ;                               6686

; Routine Size:  35 words,      Routine Base:  $CODE$ + 6234
; Maximum stack depth per invocation:  8 words
```

```
;   6719  1     global routine PUT_RETPKT (index) : novalue =
;   6720  1
;   6721  1     !+
;   6722  1     !       THE RETURN PACKET DESIGNATED BY "INDEX" IS RETURNED TO THE POOL BY THIS
;   6723  1     !       ROUTINE.
;   6724  1     !-
;   6725  1
;   6726  1         RP_USE [.index] = -1;


                                        .SBTTL  PUT.RETPKT GLOBAL ROUTINES
000000  016600  000002          PUT.RETPKT::
                                MOV     2(SP),R0                        ; INDEX,*                       6726
000004  112760  000377  000000G         MOVB    #377,RP.USE(R0)
000012  000207                          RTS     PC                      ;                               6719

; Routine Size:  6 words,       Routine Base:  $CODE$ + 6342
; Maximum stack depth per invocation:  0 words
```

```
;    6727  1
;    6728  1
;    6729  1     global routine GET_IO_BUFF (ADDR) : novalue =
;    6730  1
;    6731  1
;    6732  1     !+
;    6733  1     !       THIS ROUTINE HANDLES THE ALLOCATION OF AN I/O BUFFER FROM THE BUFFER
;    6734  1     !       POOL.
;    6735  1     !
;    6736  1     !       INPUTS:
;    6737  1     !               ADDR - ADDRESS TO STORE THE 2-WORD BUFFER DESCRIPTOR
;    6738  1     !
;    6739  1     !       IMPLICIT INPUTS:
;    6740  1     !               CCTLR - CURRENT CONTROLLER NUMBER
;    6741  1     !
;    6742  1     !       OUTPUTS:
;    6743  1     !               THE ALLOCATED BUFFER'S DESCRIPTOR IS LOADED INTO THE TWO
;    6744  1     !               WORDS AT "ADDR" AND "ADDR + 2". OTHERWISE, A ZERO IS RETURNED
;    6745  1     !               AT "ADDR" IF NO BUFFERS ARE AVAILABLE.
;    6746  1     !-
;    6747  1
;    6748  1
;    6749  1
;    6750  2         begin
;    6751  2         .ADDR = 0;                                              ! ASSUME FAILURE
;    6752  2
;    6753  2         incr COUNT from 0 to (QIO_PER_CTLR * MAX_CTLR - 1) do   ! FOR EACH ENTRY IN BUFFER TABLE
;    6754  2
;    6755  2             if .BUFF_OWN [.COUNT] lss 0                         ! IF BUFFER IS FREE
;    6756  2
;    6757  2             then
;    6758  2
;    6759  3                 begin
;    6760  3                 BUFF_OWN [.COUNT] = .CCTLR;                     ! ALLOCATE BUFFER TO CONTROLLER
;    6761  3                 .ADDR = .BUFF_ADDR [.COUNT];                    ! RETURN BUFFER DESCRIPTOR
;    6762  3                 exitloop;                                       ! DONE
;    6763  2                 end;
;    6764  2
;    6765  2
;    6766  1         end;                                                    ! ROUTINE GET_IO_BUFF


                                        .SBTTL  GET.IO.BUFF GLOBAL ROUTINES
000000  010146                    GET.IO.BUFF::
                                        MOV     R1,-(SP)                ;                                       6729
000002  005076  000004                  CLR     @4(SP)                  ; ADDR                                  6751
000006  005001                          CLR     R1                      ; COUNT                                 6753
000010  105761  000000G           1$:   TSTB    BUFF.OWN(R1)            ; *(COUNT)                              6755
000014  002011                          BGE     2$
000016  113761  000000G 000000G         MOVB    CCTLR,BUFF.OWN(R1)      ; *,*(COUNT)                            6760
000024  010100                          MOV     R1,R0                   ; COUNT,*                               6761
000026  006300                          ASL     R0
000030  016076  000000G 000004          MOV     BUFF.ADDR(R0),@4(SP)    ; *,ADDR
```

```
000036  000404                          BR      3$                              ;                               6759
000040  005201                  2$:     INC     R1                              ; COUNT                         6753
000042  020127  000007                  CMP     R1,#7                           ; COUNT,#
000046  003760                          BLE     1$
000050  012601                  3$:     MOV     (SP)+,R1                        ;                               6729
000052  000207                          RTS     PC

; Routine Size:  22 words,      Routine Base:  $CODE$ + 6356
; Maximum stack depth per invocation:  2 words


;   6767  1
;   6768  1
```

```
;    6769  1     global routine PUT_IO_BUFF (ADDR) : novalue =
;    6770  1
;    6771  1     !+
;    6772  1     !       THIS ROUTINE HANDLES THE DEALLOCATION OF AN I/O BUFFER, RETURNING IT
;    6773  1     !       TO THE BUFFER POOL.
;    6774  1     !
;    6775  1     !       INPUTS:
;    6776  1     !               ADDR - ADDRESS OF THE 2-WORD BUFFER DESCRIPTOR TO BE
;    6777  1     !                       DEALLOCATED
;    6778  1     !-
;    6779  1
;    6780  1         incr COUNT from 0 to (QIO_PER_CTLR * MAX_CTLR - 1) do       ! FOR EACH ENTRY IN BUFFER TABLE
;    6781  1
;    6782  1             if .BUFF_ADDR [.COUNT] eqla ..ADDR                      ! IF THIS IS THE BUFFER'S ENTRY
;    6783  1             then
;    6784  2                 begin
;    6785  2                 BUFF_OWN [.COUNT] = -1;                             ! DEALLOCATE BUFFER
;    6786  2                 exitloop;                                           ! DONE
;    6787  1                 end;


                                        .SBTTL  PUT.IO.BUFF GLOBAL ROUTINES
000000  010146                 PUT.IO.BUFF::
                                        MOV     R1,-(SP)                        ;                                       6769
000002  005001                          CLR     R1                              ; COUNT                                 6780
000004  010100                 1$:     MOV     R1,R0                           ; COUNT,*                               6782
000006  006300                          ASL     R0
000010  026076  000000G 000004          CMP     BUFF.ADDR(R0),@4(SP)            ; *,ADDR
000016  001004                          BNE     2$
000020  112761  000377  000000G         MOVB    @377,BUFF.OWN(R1)               ; *,*(COUNT)                            6785
000026  000404                          BR      3$                              ;                                       6784
000030  005201                 2$:     INC     R1                              ; COUNT                                 6780
000032  020127  000007                  CMP     R1,@7                           ; COUNT,*
000036  003762                          BLE     1$
000040  012601                 3$:     MOV     (SP)+,R1                        ;                                       6769
000042  000207                          RTS     PC

; Routine Size:  18 words,      Routine Base:  $CODE$ + 6432
; Maximum stack depth per invocation:  2 words
```

```
;    6788  1      global routine PUTA_BUFF : novalue =
;    6789  1
;    6790  1      !+
;    6791  1      !       THIS ROUTINE DEALLOCATES ALL I/O BUFFERS WHICH HAVE BEEN ALLOCATED TO
;    6792  1      !       THE CURRENT CONTROLLER (CCTLR).
;    6793  1      !-
;    6794  1
;    6795  1          incr COUNT from 0 to (QIO_PER_CTLR * MAX_CTLR - 1) do       ! FOR EACH ENTRY IN BUFFER TABLE
;    6796  1
;    6797  1              if .BUFF_OWN [.COUNT] eql .CCTLR                        ! IF THIS BUFFER ALLOCATED TO CURRENT CONTROLLER
;    6798  1              then
;    6799  1                  BUFF_OWN [.COUNT] = -1;                             ! DEALLOCATE IT

                                        .SBTTL  PUTA.BUFF GLOBAL ROUTINES
000000  010146                 PUTA.BUFF::
                                        MOV     R1,-(SP)                        ;                                       6788
000002  005000                          CLR     R0                              ; COUNT                                 6795
000004  116001  C00000G         1$:     MOVB    BUFF.OWN(R0),R1                 ; *(COUNT),*                            6797
000010  020137  000000G                 CMP     R1,CCTLR
000014  001003                          BNE     2$
000016  112760  000377  000000G        MOVB    #377,BUFF.OWN(R0)               ; *,*(COUNT)                            6799
000024  005200                 2$:     INC     R0                              ; COUNT                                 6795
000026  020027  000007                  CMP     R0,#7                           ; COUNT,*
000032  003764                          BLE     1$
000034  012601                          MOV     (SP)+,R1                        ;                                       6788
000036  000207                          RTS     PC

; Routine Size:  16 words,      Routine Base:  $CODE$ + 6476
; Maximum stack depth per invocation:  2 words
```

```
;    6800  1     global routine OUT_IODQ =
;    6801  1
;    6802  1     !+
;    6803  1     !       THIS ROUTINE RETURNS TO THE CALLER THE NEXT RETPKT INDEX TO BE
;    6804  1     !       PROCESSED FROM THE I/O DONE QUEUE (IODQ). THE "OUT" POINTER TO THE
;    6805  1     !       QUEUE IS ALSO UPDATED.
;    6806  1     !
;    6807  1     !       INPUTS:
;    6808  1     !               NONE
;    6809  1     !
;    6810  1     !       OUTPUTS:
;    6811  1     !               THE INDEX OF THE NEXT RETPKT TO BE PROCESSED.
;    6812  1     !-
;    6813  1
;    6814  2         begin
;    6815  2
;    6816  2         local
;    6817  2             index : word;
;    6818  2
;    6819  2         index = .IODQ [.IODQ_OUT];                  ! GET NEXT RETPKT INDEX
;    6820  2         IODQ_OUT = .IODQ_OUT + 1;                   ! ADVANCE "OUT" POINTER
;    6821  2
;    6822  2         if .IODQ_OUT gequ IODQ_LEN                  ! IF BEYOND END OF QUEUE
;    6823  2         then
;    6824  2             IODQ_OUT = 0;                           ! SET POINTER TO BEGINNING OF QUEUE
;    6825  2
;    6826  2         return .index;                              ! RETURN INDEX TO CALLER
;    6827  1         end;


                                        .SBTTL  OUT.IODQ GLOBAL ROUTINES
000000  013700  000000G             OUT.IODQ::
                                        MOV     IODQ.OUT,R0                     ;                               6819
000004  116000  000000G                 MOVB    IODQ(R0),R0                     ; *,INDEX
000010  042700  177400                  BIC     #177400,R0                      ; *,INDEX
000014  005237  000000G                 INC     IODQ.OUT                        ;                               6820
000020  023727  000000G 000010          CMP     IODQ.OUT,#10                    ;                               6822
000026  103402                          BLO     1$
000030  005037  000000G                 CLR     IODQ.OUT                        ;                               6824
000034  000207                  1$:     RTS     PC                              ;                               6800

; Routine Size:  15 words,      Routine Base:  $CODE$ + 6536
; Maximum stack depth per invocation:  0 words
```

```
;    6828  1     global routine IN_IODQ (index) : novalue =
;    6829  1
;    6830  1     !+
;    6831  1     !       THIS ROUTINE INSERTS A RETURN PACKET INDEX INTO THE I/O DONE QUEUE, AND
;    6832  1     !       UPDATES THE IODQ_IN POINTER.
;    6833  1     !-
;    6834  1
;    6835  1         if ((.IODQ_IN + 1) eql .IODQ_OUT) or
;    6836  2            (.IODQ_IN - (IODQ_LEN - 1) eql .IODQ_OUT)
;    6837  1         then
;    6838  1             return
;    6839  1         else
;    6840  2             begin
;    6841  2             IODQ [.IODQ_IN] = .index;              ! LOAD INDEX INTO QUEUE
;    6842  2             IODQ_IN = .IODQ_IN + 1;                ! ADVANCE "IN" POINTER
;    6843  2
;    6844  2             if .IODQ_IN gequ IODQ_LEN              ! IF BEYOND END OF QUEUE
;    6845  2             then
;    6846  2                 IODQ_IN = 0;                       ! CYCLE BACK TO BEGINNING OF QUEUE
;    6847  2
;    6848  1             end;                                   ! IF IODQ IS NOT FULL


                                        .SBTTL  IN.IODQ GLOBAL ROUTINES
000000  010146                    IN.IODQ::
                                        MOV     R1,-(SP)                        ;                               6828
000002  013701  000000G                 MOV     IODQ.IN,R1                      ;                               6835
000006  010100                          MOV     R1,R0
000010  005200                          INC     R0
000012  020037  000000G                 CMP     R0,IODQ.OUT
000016  001421                          BEQ     1$
000020  010100                          MOV     R1,R0                           ;                               6836
000022  162700  000007                  SUB     #7,R0
000026  020037  000000G                 CMP     R0,IODQ.OUT
000032  001413                          BEQ     1$                              ;                               6838
000034  116661  000004  000000G         MOVB    4(SP),IODQ(R1)                  ; INDEX,*                       6841
000042  005237  000000G                 INC     IODQ.IN                         ;                               6842
000046  023727  000000G 000010          CMP     IODQ.IN,#10                     ;                               6844
000054  103402                          BLO     1$
000056  005037  000000G                 CLR     IODQ.IN                         ;                               6846
000062  012601                    1$:   MOV     (SP)+,R1                        ;                               6828
000064  000207                          RTS     PC

; Routine Size:  27 words,      Routine Base:  $CODE$ + 6574
; Maximum stack depth per invocation:  2 words
```

```
;    6849  1
;    6850  1
;    6851  1     global routine DROP_CTLR (CTLR, REASON) : novalue =
;    6852  1
;    6853  1
;    6854  1
;    6855  1     !+
;    6856  1     !       THIS ROUTINE DROPS ALL UNITS ASSOCIATED WITH THE CONTROLLER DESIGNATED
;    6857  1     !       BY "CTLR". THE REASON FOR DROPPING THE DEVICE IS LOADED INTO THE DUR
;    6858  1     !       VECTOR FOR EACH ATTACHED UNIT. THIS DATA IS THEN USED BY THE DROP UNIT
;    6859  1     !       SECTION.
;    6860  1     !-
;    6861  1
;    6862  1
;    6863  2         begin
;    6864  2
;    6865  2         local
;    6866  2             UNIT;
;    6867  2
;    6868  2         incr N from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT SIZE + OF_UN) by UNIT_SIZE do       ! FOR EACH UNIT
;    6869  2
;    6870  2             if  CST [.CTLR, .N + OF DATA, D PRES] eql PRESENT                                       ! IF CON IGURED
;    6871  2             then
;    6872  3                 begin
;    6873  3                 UNIT = .CST [.CTLR, .N + OF_DATA, D UNIT];                                          ! DRS UNIT NUMBER
;    6874  3                 DUR [.UNIT] = .REASON;                                                              ! DROP REASON
;    6875  3                 DODU (.UNIT);                                                                       ! DROP UNIT
;    6876  2                 end;
;    6877  2
;    6878  1         end;


                                        .SBTTL  DROP.CTLR GLOBAL ROUTINES
000000  004137  000000G           DROP.CTLR::
                                    JSR     R1,$SAVE3                       ;                                   6851
000004  016646  000014              MOV     14(SP), (SP)                    ; CTLR,*                            6870
000010  012746  000053              MOV     #53,-(SP)
000014  004737  000000G             JSR     PC,BL$MUL
000020  010003                      MOV     R0,R3
000022  012702  000003              MOV     #3,R2                           ; *,N                               6868
000026  010300              1$:     MOV     R3,R0                           ;                                   6870
000030  060200                      ADD     R2,R0                           ; N,*
000032  006300                      ASL     R0
000034  032760  040000  000000G     BIT     #40000,CST(R0)
000042  001412                      BEQ     2$
000044  016001  000000G             MOV     CST(R0),R1                      ; *,UNIT                            6873
000050  000301                      SWAB    R1                              ; UNIT
000052  042701  177760              BIC     #177760,R1                      ; *,UNIT
000056  116661  000016  000000G     MOVB    16(SP),DUR(R1)                  ; REASON,*(UNIT)                    6874
000064  010100                      MOV     R1,R0                           ; UNIT,*                            6875
000066  104451                      TRAP    51
000070  062702  000012              ADD     #12,R2                          ; *,N                               6868
000074  020227  000041              CMP     R2,#41                          ; N,*
```

```
000100  003752                          BLE     1$
000102  022626                          CMP     (SP)+,(SP)+                     ;                               6863
000104  000207                          RTS     PC                              ;                               6851

; Routine Size:  35 words,      Routine Base:  $CODE$ + 6662
; Maximum stack depth per invocation:  8 words


;   6879  1
;   6880  1
```

```
;    6881  1      global routine DRV_CTLERR (CTLR) : novalue =
;    6882  1
;    6883  1      !+
;    6884  1      !       THIS ROUTINE IS CALLED BY DRV_TIMCHK AND FATAL_ERROR WHENEVER AN
;    6885  1      !       UNRECOVERABLE CONTROLLER ERROR HAS BEEN DETECTED.  ITS PURPOSE IS TO
;    6886  1      !       CLEAN UP ALL CONTROLLER-RELATED DATA IN THE "DRIVER" PORTION OF THE
;    6887  1      !       PROGRAM.  THIS INCLUDES MARKING THE CONTROLLER OFFLINE, CLEARING THE
;    6888  1      !       C-RING COUNT, AND DEALLOCATING MSCP PACKETS DESCRIBED IN THE RESPONSE
;    6889  1      !       RING.
;    6890  1      !
;    6891  1      !       INPUTS:
;    6892  1      !               CTLR - DYING CONTROLLER NUMBER
;    6893  1      !-
;    6894  1
;    6895  2          begin
;    6896  2
;    6897  2          local
;    6898  2              D_ADDR : ref block [DCT_LEN, word] field (DCT_FIELDS);  ! CONTROLLER'S DCT ADDRESS
;    6899  2
;    6900  2          D_ADDR = DCT + (.CTLR * DCT_LEN * 2);                       ! GET CONTROLLER'S DCT ADDR
;    6901  2          D_ADDR [WORD0] = OFFLINE;                                   ! MARK DCT OFFLINE AND CLEAR CRING_CNT
;    6902  2          PUTA_PKT (.CTLR);                                           ! RELEASE ALL PACKETS ALLOCATED TO CONTROLLER
;    6903  2          DROP_CTLR (.CTLR, DU_CFATAL);                               ! DROP ALL UNITS ON THE CONTROLLER
;    6904  1          end;                                                        ! ROUTINE DRV_CTLERR


                                        .SBTTL  DRV.CTLERR GLOBAL ROUTINES
000000  010146                    DRV.CTLERR::
                                        MOV     R1, (SP)                        ;                                       6881
000002  016601  000004                  MOV     4(SP),R1                        ; CTLR,*                                6900
000006  010146                          MOV     R1,-(SP)
000010  012746  000022                  MOV     #22,-(SP)
000014  004737  000000G                 JSR     PC,BL$MUL
000020  062700  000000G                 ADD     #DCT,R0
000024  005010                          CLR     (R0)                            ; D.ADDR                                6901
000026  010116                          MOV     R1,(SP)                         ;                                       6902
000030  004737  006174'                 JSR     PC,PUTA.PKT
000034  010116                          MOV     R1,(SP)                         ;                                       6903
000036  012746  000006                  MOV     #6,-(SP)
000042  004737  006662'                 JSR     PC,DROP.CTLR
000046  062706  000006                  ADD     #6,SP                           ;                                       6895
000052  012601                          MOV     (SP)+,R1                        ;                                       6881
000054  000207                          RTS     PC

; Routine Size:  23 words,      Routine Base:  $CODE$ + 6770
; Maximum stack depth per invocation:  5 words
```

```
;    6905  1     global routine SEND (index) =
;    6906  1
;    6907  1     !+
;    6908  1     !       IF THE CURRENT RDRX IS ONLINE AND ITS CRING IS NOT FULL, THEN THIS
;    6909  1     !       ROUTINE "SENDS" A COMMAND TO THE RDRX BY LOADING THE PACKET
;    6910  1     !       DESCRIPTOR OF AN MSCP PACKET INTO THE COMMAND RING AND READING THE
;    6911  1     !       DEVICE'S IP REGISTER.  IF THE
;    6912  1     !       CURRENT RDRX IN NOT ONLINE, THEN A FAILURE INDICATION IS RETURNED TO
;    6913  1     !       THE CALLER, AND NO ACTION IS TAKEN.
;    6914  1     !
;    6915  1     !       INPUTS:
;    6916  1     !               INDEX - INDEX OF MSCP PACKET CONTAINING THE COMMAND TO
;    6917  1     !                       BE SENT
;    6918  1     !
;    6919  1     !       IMPLICIT INPUTS:
;    6920  1     !               CCTLR - CURRENT CONTROLLER NUMBER
;    6921  1     !               DCT_ADDR - ADDRESS OF CURRENT CONTROLLER'S DCT
;    6922  1     !-
;    6923  1
;    6924  2         begin
;    6925  2
;    6926  2         local
;    6927  2             SLOT_ADDR,
;    6928  2             TEMP : word,
;    6929  2             CUR_PRIORITY : word;
;    6930  2
;    6931  2         if (.DCT_ADDR [CRING_CNT] lssu CRING_LEN) and                       ! IF CRING IS NOT FULL AND
;    6932  3            ((.DCT_ADDR [STAT] eql ONLINE) or                                !   IF DEVICE IS ONLINE OR
;    6933  3             (.MSCP_PKT [.index, OPCODE] eql OP_SCC))                        !   IT IS A SET-CTRL-CHAR COMMAND
;    6934  2         then
;    6935  2
;    6936  4             if (not ((.MSCP_PKT [.index, OPCODE] eql OP_ACC) or ( MSCP_PKT [.index, OPCODE] eql OP_ONL) or
;    6937  4                      (.MSCP_PKT [.index, OPCODE] eql OP_RD) or (.MSCP_PKT [.index, OPCODE] eql OP_SCC) or
;    6938  4             (.MSCP_PKT [.INDEX, OPCODE] EQL OP_SDD) OR                      !ZZZ
;    6939  4             (.MSCP_PKT [.INDEX, OPCODE] EQL OP_RCD) OP                      !ZZZ
;    6940  4             (.MSCP_PKT [.INDEX, OPCODE] EQL OP_GDS) OR                      !ZZZ
;    6941  4             (.MSCP_PKT [.INDEX, OPCODE] EQL OP_ELP) OR                      !ZZZ
;    6942  4             (.MSCP_PKT [.INDEX, OPCODE] EQL OP_ABT) OR                      !ZZZ
;    6943  4             (.MSCP_PKT [.INDEX, OPCODE] EQL OP_ESP) OR                      !ZZZ
;    6944  3                      (.MSCP_PKT [.index, OPCODE] eql OP_WRT)))
;    6945  2             then
;    6946  3                 begin
;    6947  3                 PRINTF (DBM107, .MSCP_PKT [.index, OPCODE]);
;    6948  3                 return FAILURE;
;    6949  3                 end
;    6950  2             else
;    6951  3                 begin
;    6952  3
;    6953  3                 do
;    6954  3                     BREAK                                                   ! LOOP TILL CREDIT BALANCE POSITIVE
;    6955  4                 until ((.MSCP_PKT [.index, CMD_TYPE] eql IMM_CMD) and
;    6956  3                        (.CREDIT_BAL gequ 1)) or
;    6957  3                       (.CREDIT_BAL gtru 1);
```

```
;    6958  3
;    6959  3                    MSCP_PKT [.index, CRN_LO] = (CRN_LOW = .CRN_LOW + 1);       ! ASSIGN CMD REF NUM
;    6960  3
;    6961  3                    if .CRN_LOW eql 0
;    6962  3                    then
;    6963  3                        CRN_HIGH = .CRN_HIGH + 1;                               ! CMD REF NUM (HIGH ORDER)
;    6964  3
;    6965  3                    MSCP_PKT [.index, CRN_HI] = .CRN_HIGH;                      !
;    6966  3                    SLOT_ADDR = .DCT_ADDR [CR_NEXT];                            ! ADDR OF NEXT COMMAND SLOT
;    6967  3
;    6968  3                    do                                                          ! WAIT TILL NEXT SLOT HOST OWNED
;    6969  3                        BREAK                                                   !
;    6970  3                    until ((.(.SLOT_ADDR + 2) and ED_OWN) eql 0);               !
;    6971  3
;    6972  3                    GETPRI (CUR_PRIORITY);                                      ! NO INTERRUPTS WHILE POINTERS UPDATED
;    6973  3    !ZZZ            SETPRI (PRI04);                                             !
;    6974  3                    SETPRI (.BRLEVEL);                                          !          ZZZ
;    6975  3
;    6976  3                    .SLOT_ADDR = .MSCP_PKT [.index, PKT_LO];                    ! LOAD BUFF DESC (LO) INTO COMMAND SLOT
;    6977  3                    SLOT_ADDR = .SLOT_ADDR + 2;                                 ! ADVANCE TO NEXT WORD
;    6978  3                    .SLOT_ADDR = .MSCP_PKT [.index, PKT_HI];                    ! LOAD BUFF DESC (HI) INTO COMMAND SLOT
;    6979  3                    .SLOT_ADDR = ..SLOT_ADDR and (not (ED_FLAG));               ! CLEAR INTERRUPT FLAG IN CASE SET
;    6980  3                    .SLOT_ADDR = ..SLOT_ADDR or ED_OWN;                         ! GIVE OWNERSHIP TO CONTROLLER
;    6981  3                    SLOT_ADDR = .SLOT_ADDR + 2;                                 ! ADVANCE TO NEXT COMMAND SLOT
;    6982  3
;    6983  3                    if .SLOT_ADDR gtra .DCT_ADDR [CR_END]                       ! IF BEYOND END OF CRING
;    6984  3                    then
;    6985  3                        SLOT_ADDR = .DCT_ADDR [CR_BEG];                         ! CYCLE BACK TO BEGINNING
;    6986  3
;    6987  3                    DCT_ADDR [CR_NEXT] = .SLOT_ADDR;                            ! RESTORE CR_NEXT POINTER IN DCT
;    6988  3                    DCT_ADDR [CRING_CNT] = .DCT_ADDR [CRING_CNT] + 1;           ! INCR # OF COMMANDS IN CRING
;    6989  4                    IF (.MSCP_PKT [.INDEX, CONNID] EQL CID_MSCP)                !IF MSCP COMMAND                  ZZZ
;    6990  3                    THEN (CREDIT_BAL = .CREDIT_BAL - 1);                        !DECR CREDIT BALANCE              ZZZ
;    6991  3                    TEMP = .RDRX_ADDR [RCIP, RC_ALL];                           ! READ IP TO FORCE PORT TO POLL
;    6992  3                    SETPRI (.CUR_PRIORITY);                                     ! LOWER PRIORITY
;    6993  3                    return SUCCESS;
;    6994  3                    end
;    6995  3
;    6996  2            else
;    6997  2                return FAILURE;                                                 ! IF DEVICE IS NOT ONLINE
;    6998  2
;    6999  1            end;                                                                ! ROUTINE SEND


                                        .SBTTL  SEND GLOBAL ROUTINES
000000  004137  000000G           SEND:: JSR     R1,$SAVE3                    ;                                          6905
000004  005746                         TST     -(SP)
000006  127727  000000G 000004          CMPB    @DCT.ADDR,#4                 ;                                          6931
000014  103100                         BHIS    2$
000016  005777  000000G                TST     @DCT.ADDR                    ;                                          6932
000022  100413                         BMI     1$
000024  016646  000014                 MOV     14(SP),-(SP)                 ; INDEX,*                                  6933
000030  012746  000106                 MOV     #106,-(SP)
```

```
000034  004737  000000G                    JSR     PC,BL$MUL
000040  022626                              CMP     (SP)+,(SP)+
000042  126027  000022G 000004              CMPB    MSCP.PKT+22(R0),#4
000050  001167                              BNE     10$
000052  016646  000014              1$:     MOV     14(SP), (SP)            ; INDEX,*                       6936
000056  012746  000106                      MOV     #106,-(SP)
000062  004737  000000G                    JSR     PC,BL$MUL
000066  010002                              MOV     R0,R2
000070  022626                              CMP     (SP)+,(SP)+
000072  005000                              CLR     R0
000074  156200  000022G                    BISB    MSCP.PKT+22(R2),R0
000100  020027  000020                      CMP     R0,#20
000104  001445                              BEQ     3$
000106  020027  000011                      CMP     R0,#11
000112  001442                              BEQ     3$
000114  020027  000041                      CMP     R0,#41                  ;                               6937
000120  001437                              BEQ     3$
000122  020027  000004                      CMP     R0,#4
000126  001434                              BEQ     3$
000130  020027  000005                      CMP     R0,#5                   ;                               6939
000134  001431                              BEQ     3$
000136  020027  000001                      CMP     R0,#1                   ;                               6940
000142  001426                              BEQ     3$
000144  020027  000003                      CMP     R0,#3                   ;                               6941
000150  001423                              BEQ     3$
000152  020027  000006                      CMP     R0,#6                   ;                               6942
000156  001420                              BEQ     3$
000160  020027  000002                      CMP     R0,#2                   ;                               6943
000164  001415                              BEQ     3$
000166  020027  000042                      CMP     R0,#42                  ;                               6944
000172  001412                              BEQ     3$
000174  010046                              MOV     R0,-(SP)                ;                               6947
000176  012746  000000G                    MOV     #DBM107,-(SP)
000202  012746  000002                      MOV     #2,-(SP)
000206  010600                              MOV     SP,R0                   ; SP,*
000210  104417                              TRAP    17
000212  062706  000006                      ADD     #6,SP                   ;                               6946
000216  000504                      2$:     BR      10$                     ;                               6936
000220  104422                      3$:     TRAP    22                      ;                               6953
000222  105762  000004G                    TSTB    MSCP.PKT+4(R2)          ;                               6955
000226  001003                              BNE     4$
000230  005737  000000G                    TST     CREDIT.BAL              ;                               6956
000234  001004                              BNE     5$
000236  023727  000000G 000001      4$:     CMP     CREDIT.BAL,#1           ;                               6957
000244  101765                              BLOS    3$
000246  013700  000000G              5$:     MOV     CRN.LOW,R0              ;                               6959
000252  005200                              INC     R0
000254  010037  000000G                    MOV     R0,CRN.LOW
000260  010062  000012G                    MOV     R0,MSCP.PKT+12(R2)
000264  001002                              BNE     6$                      ;                               6961
000266  005237  000000G                    INC     CRN.HIGH                ;                               6963
000272  013762  000000G 000014G      6$:     MOV     CRN.HIGH,MSCP.PKT+14(R2)  ;                             6965
000300  013700  000000G                    MOV     DCT.ADDR,R0             ;                               6966
```

```
000304  016001  000020                          MOV     20(R0),R1               ; *.SLOT.ADDR
000310  104422                          7$:     TRAP    22                      ;                                       6968
000312  032761  100000  000002                BIT     #-100000,2(R1)          ; *,*(SLOT.ADDR)                        6970
000320  001373                                  BNE     7$
000322  104440                                  TRAP    40                      ;                                       6972
000324  010003                                  MOV     R0,R3                   ; *.CUR.PRIORITY
000326  013700  000000G                         MOV     @#RLEVEL,R0             ;                                       6974
000332  104441                                  TRAP    41
000334  016221  000000G                         MOV     MSCP.PKT(R2),(R1)+      ; *.SLOT.ADDR                           6976
000340  016211  000002G                         MOV     MSCP.PKT+2(R2),(R1)     ; *.SLOT.ADDR                           6978
000344  042711  040000                          BIC     #40000,(R1)             ; *.SLOT.ADDR                           6979
000350  052721  100000                          BIS     #100000,(R1)+           ; *.SLOT.ADDR                           6980
000354  013700  000000G                         MOV     DCT.ADDR,R0             ;                                       6985
000360  020160  000012                          CMP     R1,12(R0)               ; SLOT.ADDR,*
000364  101402                                  BLOS    8$
000366  016001  000010                          MOV     10(R0),R1               ; *.SLOT.ADDR                           6985
000372  010160  000020                  8$:     MOV     R1,20(R0)               ; SLOT.ADDR,*                           6987
000376  105210                                  INCB    (R0)                    ;                                       6988
000400  105762  C00011G                         TSTB    MSCP.PKT+11(R2)         ;                                       6989
000404  001002                                  BNE     9$
000406  005337  000000G                         DEC     CREDIT.BAL              ;                                       6990
000412  017716  000000G                  9$:     MOV     @RDRX.ADDR,(SP)         ; *.RC.REG                              6991
000416  010300                                  MOV     R3,R0                   ; CUR.PRIORITY,*                        6992
000420  104441                                  TRAP    41
000422  012700  000001                          MOV     #1,R0                   ;                                       6936
000426  000401                                  BR      11$                     ;                                       6997
000430  005000                          10$:    CLR     R0
000432  005726                          11$:    TST     (SP)+                   ;                                       6905
000434  000207                                  RTS     PC

; Routine Size:  143 words,    Routine Base:  $CODE$ + 7046
; Maximum stack depth per invocation:  10 words
```

```
;    7000  1     global routine WAIT : novalue =
;    7001  1
;    7002  1     !+
;    7003  1     !       THE PURPOSE OF THIS ROUTINE IS TO KILL TIME UNTIL AN RDRX INTERRUPT
;    7004  1     !       RESULTS IN A RETURN PACKET INDEX BEING DEPOSITED INTO THE I/O DONE
;    7005  1     !       QUEUE (IODQ).
;    7006  1     !-
;    7007  1
;    7008  1         do
;    7009  1             BREAK                                   ! BREAK FOR ACT
;    7010  1         until .IODQ_IN neq .IODQ_OUT;

                                        .SBTTL  WAIT GLOBAL ROUTINES
000000  104422                 WAIT::
000000                          1$:     TRAP    22                      ;                       7008
000002  023737  000000G 000000G        CMP     IODQ.IN,IODQ.OUT        ;                       7010
000010  001773                        BEQ     1$
000012  000207                        RTS     PC                      ;                       7000

; Routine Size:  6 words,       Routine Base:  $CODE$ + 7504
; Maximum stack depth per invocation:  2 words


;    7011  1
```

```
;    7012  1
;    7013  1     GLOBAL ROUTINE MODULAS (LO_LIMIT, HI LIMIT) =                                   !ZZZ
;    7014  1
;    7015  1     !+ THE PURPOSE OF THIS ROUTINE IS TO GET A RANDOM NUMBER BETWEEN                !ZZZ
;    7016  1     !  THE LOW AND HIGH LIMITS. THIS SHOULD WORK FOR A 16 BIT WORD.                 !ZZZ
;    7017  1     !- THE "MOD" FUNC ONLY WORKS ON 15 BITS.                                        !ZZZ
;    7018  1
;    7019  2     BEGIN                                                                           !ZZZ
;    7020  2     OWN     X : WORD;                   !VARIABLE FOR RANDOM WD TABLE               !ZZZ
;    7021  2     LOCAL   ANSWER : UNSIGNED WORD,     !FINAL ANSWER                               !ZZZ
;    7022  2             SAVESZ : UNSIGNED WORD,     !SAVES SIZE OF WINDOW                       !ZZZ
;    7023  2             SIZE : UNSIGNED WORD;       !SIZE OF WINDOW                             !ZZZ
;    7024  2                                                                                     !ZZZ
;    7025  2                                                                                     !ZZZ
;    7026  2     X = .X + 1;                                                                     !ZZZ
;    7027  2     IF .X GEQ RDM_LEN                                                               !ZZZ
;    7028  2     THEN X = 0;                 !KEEP ROTATING RANDOM NUMBERS USED                  !ZZZ
;    7029  2
                        !ZZZ
;    7030  2     SIZE = .HI_LIMIT - .LO_LIMIT;                                                   !ZZZ
;    7031  2     SAVESZ = .HI_LIMIT - .LO_LIMIT;                                                 !ZZZ
;    7032  3     IF (.SIZE LEQU %O'077777')      !IF BIT 15 NOT SET                              !ZZZ
;    7033  3     THEN ANSWER = ((.RANDOM [.X] AND %O'077777') MOD (.SIZE + 1))                   !ZZZ
;    7034  3                                     !ONLY 15 BIT WD, SO TAKE RANDOM SAMPLE          !ZZZ
;    7035  2     ELSE                            !16 BIT WD                                      !ZZZ
;    7036  3             BEGIN                                                                   !ZZZ
;    7037  3             SIZE = .SIZE ^ -1;      !MAKES SIZE A 15 BIT LENGTH, OR DIV BY 2        !ZZZ
;    7038  3             ANSWER = (.RANDOM [.X] AND %O'077777') MOD (.SIZE + 1);                 !ZZZ
;    7039  3                                     !GIVES 15 BIT RANDOM NUMBER                     !ZZZ
;    7040  3             ANSWER = .ANSWER ^ 1;   !BUILD UP TO REGULAR SIZE                       !ZZZ
;    7041  3             ANSWER = .ANSWER + (.RANDOM [.X + 1] AND 1);                            !ZZZ
;    7042  3                                     !RANDOMLY FILL BIT 0                            !ZZZ
;    7043  4             IF (.ANSWER GTRU SAVESZ) !ITS POSSIBLE TO BE 1 LARGER THAN SIZE         !ZZZ
;    7044  3             THEN ANSWER =  SAVESZ;  !SO CHECK.                                      !ZZZ
;    7045  2             END;                                                                    !ZZZ
;    7046  2     RETURN .ANSWER;
;    7047  1     END;                            !END MODULAS ROUTINE                            !ZZZ

007520                              X:      .BLKW   1


                                            .SBTTL  MODULAS GLOBAL ROUTINES
000000  004137  000000G             MODULAS::
                                            JSR     R1,$SAVE2                   ;                   7013
000004  005746                              TST     -(SP)
000006  005237  007520'                      INC     X                           ;                   7026
000012  023727  007520' 000020              CMP     X,#20                       ;                   7027
000020  002402                              BLT     1$
000022  005037  007520'                      CLR     X                           ;                   7028
000026  016600  000012              1$:     MOV     12(SP),R0                   ; HI.LIMIT,*        7030
000032  166600  000014                      SUB     14(SP),R0                   ; LO.LIMIT,*
000036  010001                              MOV     R0,R1                       ; *,SIZE
000040  010016                              MOV     R0,(SP)                     ; *,SAVESZ          7031
```

```
000042  013700  007520'                        MOV     X,R0                            ;                                       7033
000046  006300                                  ASL     R0
000050  020127  077777                        CMP     R1,#77777                       ; SIZE,*                                7032
000054  101011                                BHI     2$
000056  016046  000000G                       MOV     RANDOM(R0), (SP)                ;                                       7033
000062  042716  100000                        BIC     #100000,(SP)
000066  010146                                MOV     R1,-(SP)                        ; SIZE,*
000070  005216                                INC     (SP)
000072  004737  000000G                       JSR     PC,BL$MOD
000076  000431                                BR      3$                              ;                                       7032
000100  006201                          2$:   ASR     R1                              ; SIZE                                  7037
000102  016046  000000G                       MOV     RANDOM(R0),-(SP)                ;                                       7038
000106  042716  100000                        BIC     #100000,(SP)
000112  010146                                MOV     R1,-(SP)                        ; SIZE,*
000114  005216                                INC     (SP)
000116  004737  000000G                       JSR     PC,BL$MOD
000122  006300                                ASL     R0                              ; ANSWER                                7040
000124  013701  007520'                        MOV     X,R1                            ;                                       7041
000130  006301                                ASL     R1
000132  116102  000002G                       MOVB    RANDOM+2(R1),R2
000136  042702  177776                        BIC     #177776,R2
000142  060200                                ADD     R2,R0                           ; *,ANSWER
000144  012701  000004                        MOV     #4,R1                           ;                                       7043
000150  060601                                ADD     SP,R1                           ; SAVESZ,*
000152  020001                                CMP     R0,R1                           ; ANSWER,*
000154  101402                                BLOS    3$
000156  016600  000004                        MOV     4(SP),R0                        ; SAVESZ,ANSWER                         7044
000162  062706  000006                  3$:   ADD     #6,SP                           ;                                       7013
000166  000207                                RTS     PC

; Routine Size:  60 words,      Routine Base:  $CODE$ + 7522
; Maximum stack depth per invocation:  7 words
```

```
;    7048  1     %sbttl 'ERROR MESSAGE SUBROUTINES'
;    7049  1
;    7050  1     routine EMS_SA : novalue =
;    7051  1
;    7052  1     !+
;    7053  1     !       THIS ROUTINE PRINTS (EXTENDED) THE GLOBAL DATUM "SA_REG" WHICH CONTAINS
;    7054  1     !       THE CONTENTS OF THE SA REGISTER.
;    7055  1     !-
;    7056  1
;    7057  2         begin
;    7058  2
;    7059  2         if .SA_REG eql %o'177777'                                   ! IF CONTROLLER TIME-OUT
;    7060  2         then
;    7061  3             begin
;    7062  3             PRINTX (CRLF);
;    7063  3             PRINTX (ASTERISK);
;    7064  3             PRINTX (.CNTR_ERR [0]);
;    7065  3             end
;    7066  2         else
;    7067  2
;    7068  2             if (.SA_REG and %o'003777') lequ 22                     ! IF GENERIC CONTROLLER ERROR
;    7069  2             then
;    7070  3                 begin
;    7071  3                 PRINTX (CRLF);
;    7072  3                 PRINTX (ASTERISK);
;    7073  3                 PRINTX (.CNTR_ERR [.SA_REG and %o'003777']);
;    7074  3                 end
;    7075  2             else
;    7076  2
;    7077  2                 if ((.SA_REG and %o'003777') - 400) lequ 6          ! IF RDRX SPECIFIC CONTROLLER ERROR
;    7078  2                 then
;    7079  3                     begin
;    7080  3                     PRINTX (CRLF);
;    7081  3                     PRINTX (ASTERISK);
;    7082  3                     PRINTX (.RDRX_ERR [(.SA_REG and %o'003777') - 400]);
;    7083  3                     end
;    7084  2                 else
;    7085  2                     PRINTX (EX_SA, .SA_REG);                        ! JUST PRINT CONTENTS OF SA
;    7086  2
;    7087  2         EMS_TIM ();                                                 ! TIME
;    7088  1         end;


                                        .SBTTL  EMS.SA ERROR MESSAGE SUBROUTINES
000000  010146                  EMS.SA: MOV     R1,-(SP)                        ;                                   7050
000002  013701  000000G                 MOV     SA.REG,R1                       ;                                   7051
000006  020127  177777                  CMP     R1,#-1
000012  001023                          BNE     1$
000014  012746  000000G                 MOV     #CRLF,-(SP)                     ;                                   7062
000020  012746  000001                  MOV     #1,-(SP)
000024  010600                          MOV     SP,R0                           ; SP,*
000026  104415                          TRAP    15
000030  012716  000000G                 MOV     #ASTERISK,(SP)                  ;                                   7063
```

```
000034  012746  000001                    MOV     #1,-(SP)
000040  010600                            MOV     SP,R0                   ; SP,*
000042  104415                            TRAP    15
000044  013716  000000G                   MOV     CNTR.ERR,(SP)           ;                                       7064
000050  012746  000001                    MOV     #1,-(SP)
000054  010600                            MOV     SP,R0                   ; SP,*
000056  104415                            TRAP    15
000060  000475                            BR      3$                      ;                                       7061
000062  010100                    1$:     MOV     R1,R0                   ;                                       7068
000064  042700  174000                    BIC     #174000,R0
000070  020027  000026                    CMP     R0,#26
000074  101030                            BHI     2$
000076  012746  000000G                   MOV     #CRLF,-(SP)             ;                                       7071
000102  012746  000001                    MOV     #1,-(SP)
000106  010600                            MOV     SP,R0                   ; SP,*
000110  104415                            TRAP    15
000112  012716  000000G                   MOV     #ASTERISK,(SP)          ;                                       7072
000116  012746  000001                    MOV     #1,-(SP)
000122  010600                            MOV     SP,R0                   ; SP,*
000124  104415                            TRAP    15
000126  013700  000000G                   MOV     SA.REG,R0               ;                                       7073
000132  042700  174000                    BIC     #174000,R0
000136  006300                            ASL     R0
000140  016016  000000G                   MOV     CNTR.ERR(R0),(SP)
000144  012746  000001                    MOV     #1,-(SP)
000150  010600                            MOV     SP,R0                   ; SP,*
000152  104415                            TRAP    15
000154  000437                            BR      3$                      ;                                       7070
000156  010100                    2$:     MOV     R1,R0                   ;                                       7077
000160  042700  174000                    BIC     #174000,R0
000164  162700  000620                    SUB     #620,R0
000170  020027  000006                    CMP     R0,#6
000174  101031                            BHI     4$
000176  012746  000000G                   MOV     #CRLF,-(SP)             ;                                       7080
000202  012746  000001                    MOV     #1,-(SP)
000206  010600                            MOV     SP,R0                   ; SP,*
000210  104415                            TRAP    15
000212  012716  000000G                   MOV     #ASTERISK,(SP)          ;                                       7081
000216  012746  000001                    MOV     #1,-(SP)
000222  010600                            MOV     SP,R0                   ; SP,*
000224  104415                            TRAP    15
000226  013700  000000G                   MOV     SA.REG,R0               ;                                       7082
000232  042700  174000                    BIC     #174000,R0
000236  006300                            ASL     R0
000240  016016  176340G                   MOV     RDRX.ERR-1440(R0),(SP)
000244  012746  000001                    MOV     #1,-(SP)
000250  010600                            MOV     SP,R0                   ; SP,*
000252  104415                            TRAP    15
000254  005726                    3$:     TST     (SP)+                   ;                                       7079
000256  000407                            BR      5$                      ;                                       7077
000260  010146                    4$:     MOV     R1,-(SP)                ;                                       7085
000262  012746  000000G                   MOV     #EX.SA,-(SP)
000266  012746  000002                    MOV     #2,-(SP)
```

```
000272  010600                          MOV     SP,R0                   ; SP,*
000274  104415                          TRAP    15
000276  004737  000000V          5$:     JSR     PC,EMS.TIM              ;                       7087
000302  062706  000006                  ADD     #6,SP                   ;                       7057
000306  012601                          MOV     (SP)+,R1                ;                       7058
000310  000207                          RTS     PC

  Routine Size:  101 words,     Routine Base:  $CODE$ + 7712
  Maximum stack depth per invocation:  7 words

    7089  1
```

```
;    7090  1      routine EMS_SBC1 (addr): novalue =                                                  !MMM
;    7091  1
;    7092  1      !+
;    7093  1      !       THIS ROUTINE PRINTS (EXTENDED) THE  "SB_CODE" (SUB CODE) IF
;    7094  1      !       EITHER THE STATUS CODE (ST_CODE) OR THE SUB CODE IS NON-ZERO. (A
;    7095  1      !       NON-ZERO SUB-CODE ALWAYS HAS SIGNIFICANCE, WHEREAS A ZERO SUB-CODE ONLY
;    7096  1      !       HAS MEANING WITH A NON-ZERO STATUS CODE).
;    7097  1      !-
;    7098  1
;    7099  2          begin
;    7100  2
;    7101  2          local
;    7102  2
;    7103  2              ST_CODE : word,                                                             ! MMM
;    7104  2              SB_CODE : word,                                                             ! MMM
;    7105  2              RP_ADDR : ref block [RP_LEN, word] field (RP FIELDS);                       ! RETURN PACKET ADDRESS  MMM
;    7106  2
;    7107  2
;    7108  2          RP_ADDR = .addr;                                        ! MMM
;    7109  2          ST_CODE = .RP_ADDR [STSCOD];                            ! MMM
;    7110  2          SB_CODE = .RP_ADDR [SUBCOD];                            ! MMM
;    7111  2
;    7112  2          if (.ST_CODE or .SB_CODE) neq 0                                             ! PRINT SUB-CODE ONLY ON ERROR
;    7113  2          then
;    7114  3              begin
;    7115  3              PRINTX (EX_SB);                                                         ! SUB-CODE :
;    7116  3
;    7117  3              selectoneu  .ST_CODE of                                                 !MMM  ADDITIONAL SUBCODES
;    7118  3                  set                                                                 !MMM
;    7119  3
;    7120  4                      [ST_SUC]:           begin                                       ! SUCCESS SUB-CODES  MMM
;    7121  4                                          if .SB_CODE lequ 16                         ! SUCCESS SUB CODES MMM
;    7122  4                                          then
;    7123  4                                          PRINTX (.TBL_SUC [.SB_CODE]);
;    7124  4                                          if .SB_CODE eqlu 32
;    7125  4                                          then
;    7126  4                                          PRINTX (.TBL_SUC [17]);
;    7127  4                                          if .SB_CODE eqlu 64
;    7128  4                                          then
;    7129  4                                          PRINTX (.TBL_SUC [18]);                     !MMM
;    7130  3                                          end;                                        !MMM
;    7131  3
;    7132  3                      [ST_CMD]:           PRINTX (EX_SBO, .SB_CODE / 8);              ! INVALID COMMAND
;    7133  3
;    7134  3                      [ST_ABO]:           ;                                           ! COMMAND ABORTED
;    7135  3
;    7136  3                      [ST_OFL]:           if .SB_CODE lequ 8                          ! UNIT OFFLINE
;    7137  3                                          then
;    7138  3                                              PRINTX (.TBL_OFL [.SB_CODE]);
;    7139  3
;    7140  3                      [ST_AVL]:           ;                                           ! UNIT AVAILABLE
;    7141  3
;    7142  3                      [ST_MFE]:           if .SB_CODE lequ 10                         ! MEDIA FORMAT ERROR
```

```
;    7143  3                                  then
;    7144  3                                      PRINTX (.TBL_MFE [.SB_CODE]);
;    7145  3
;    7146  4              [ST_WPT]:             begin                                   !MMM
;    7147  4                                    if .SB_CODE eqlu 8                      !MMM
;    7148  4                                    then
;    7149  4                                        PRINTX (.TBL_WPT [3]);               !MMM
;    7150  4                                    if (.SB_CODE / 128) lequ 2                ! WRITE PROTECTED
;    7151  4                                    then
;    7152  4                                        PRINTX (.TBL_WPT [(.SB_CODE / 128)]); !MMM
;    7153  3                                    end;                                    !MMM
;    7154  3
;    7155  3              [ST_CMP]:             ;                                       ! COMPARE ERROR
;    7156  3
;    7157  3              [ST_DAT]:             if .SB_CODE lequ 15                     ! DATA ERROR
;    7158  3                                    then
;    7159  3                                        PRINTX (.TBL_DAT [.SB_CODE]);
;    7160  3
;    7161  3              [ST_HST]:             if .SB_CODE lequ 4                      ! HOST ACCESS ERROR
;    7162  3                                    then
;    7163  3                                        PRINTX (.TBL_HST [.SB_CODE]);
;    7164  3
;    7165  3              [ST_CNT]:             if .SB_CODE lequ 3                      ! CONTROLLER ERROR
;    7166  3                                    then
;    7167  3                                        PRINTX (.TBL_CNT [.SB_CODE]);
;    7168  3
;    7169  3              [ST_DRV]:             if .SB_CODE lequ 8                      ! DRIVE ERROR
;    7170  3                                    then
;    7171  3                                        PRINTX (.TBL_DRV [.SB_CODE]);
;    7172  3
;    7173  3              [otherwise]:          PRINTX (EX_SBO, .SB_CODE);              ! JUST PRINT SUB CODE IF NO MATCH
;    7174  3              tes;
;    7175  3
;    7176  3
;    7177  3      !MMM    case .ST_CODE from ST_SUC to ST_DRV of
;    7178  3      !MMM        set
;    7179  3
;    7180  3      !MMM        [ST_SUC]:             if .SB_CODE lequ 16                 ! SUCCESS SUB-CODES
;    7181  3      !MMM                              then
;    7182  3      !MMM                                  PRINTX (.TBL_SUC [.SB_CODE]);
;    7183  3
;    7184  3      !MMM        [ST_CMD]:             PRINTX (EX_SBO, .SB_CODE / 8);      ! INVALID COMMAND
;    7185  3
;    7186  3      !MMM        [ST_ABO]:             ;                                   ! COMMAND ABORTED
;    7187  3
;    7188  3      !MMM        [ST_OFL]:             if .SB_CODE lequ 8                  ! UNIT OFFLINE
;    7189  3      !MMM                              then
;    7190  3      !MMM                                  PRINTX (.TBL_OFL [.SB_CODE]);
;    7191  3
;    7192  3      !MMM        [ST_AVL]:             ;                                   ! UNIT AVAILABLE
;    7193  3
;    7194  3      !MMM        [ST_MFE]:             if .SB_CODE lequ 10                 ! MEDIA FORMAT ERROR
;    7195  3      !MMM                              then
```

```
;    7196  3      !****                          PRINTX (.TBL MFE [.SB_CODE]);
;    7197  3
;    7198  3      !****       [ST_WPT]:          if (.SB CODE / 128) lequ 2              ! WRITE PROTECTED
;    7199  3      !****                          then
;    7200  3      !****                              PRINTX (.TBL WPT [(.SB CODE / 128)]);
;    7201  3
;    7202  3      !****       [ST_CMP]:          ;                                       ! COMPARE ERROR
;    7203  3
;    7204  3      !****       [ST_DAT]:          if .SB CODE lequ 15                     ! DATA ERROR
;    7205  3      !****                          then
;    7206  3      !****                              PRINTX (.TBL_DAT [.SB CODE]);
;    7207  3
;    7208  3      !****       [ST_HST]:          if .SB_CODE lequ 4                      ! HOST ACCESS ERROR
;    7209  3      !****                          then
;    7210  3      !****                              PRINTX (.TBL HST [.SB_CODE]);
;    7211  3
;    7212  3      !****       [ST_CNT]:          if .SB_CODE lequ 3                      ! CONTROLLER ERROR
;    7213  3      !****                          then
;    7214  3      !****                              PRINTX (.TBL CNT [.SB_CODE]);
;    7215  3
;    7216  3      !****       [ST_DRV]:          if .SB_CODE lequ 8                      ! DRIVE ERROR
;    7217  3      !****                          then
;    7218  3      !****                              PRINTX (.TBL DRV [.SB_CODE]);
;    7219  3
;    7220  3      !****       [outrange]:        PRINTX (EX_SBO, .SB CODE),              ! JUST PRINT SUB CODE IF NO MATCH
;    7221  3      !****       tes:
;    7222  3
;    7223  2              end;
;    7224  2
;    7225  1          end;


                                                .SBTTL  EMS.SBC1 ERROR MESSAGE SUBROUTINES
000000  004137  000000G          EMS.SBC1:      JSR     R1,$SAVE2                       ;                                       7090
000004  016600  000010                         MOV     10(SP),R0                       ; ADDR.RP.ADDR                          7108
000010  116002  000016                         MOVB    16(R0),R2                       ; *(RP.ADDR),ST.CODE                    7109
000014  042702  177740                         BIC     #177740,R2                      ; *,ST.CODE
000020  016001  000016                         MOV     16(R0),R1                       ; *(RP.ADDR),SB.CODE                    7110
000024  006201                                 ASR     R1                              ; SB.CODE
000026  006201                                 ASR     R1                              ; SB.CODE
000030  006201                                 ASR     R1                              ; SB.CODE
000032  006201                                 ASR     R1                              ; SB.CODE
000034  006201                                 ASR     R1                              ; SB.CODE
000036  042701  174000                         BIC     #174000,R1                      ; *,SB.CODE
000042  010100                                 MOV     R1,R0                           ; SB.CODE,*                             7112
000044  050200                                 BIS     R2,R0                           ; ST.CODE,*
000046  001001                                 BNE     1$
000050  000207                                 RTS     PC
000052  012746  000000G          1$:            MOV     #EX.SB, (SP)                    ;                                       7115
000056  012746  000001                         MOV     #1,-(SP)
000062  010600                                 MOV     SP,R0                           ; SP,*
000064  104415                                 TRAP    15
```

```
000066  005702                          TST     R2                      ; ST.CODE                       7120
000070  001040                          BNE     4$
000072  020127  000020                  CMP     R1,#20                  ; SB.CODE,*                     7121
000076  101011                          BHI     2$
000100  010100                          MOV     R1,R0                   ; SB.CODE,*                     7123
000102  006300                          ASL     R0
000104  016016  000000'                  MOV     TBL.SUC(R0),(SP)
000110  012746  000001                  MOV     #1,-(SP)
000114  010600                          MOV     SP,R0                   ; SP,*
000116  104415                          TRAP    15
000120  005726                          TST     (SP)+
000122  020127  000040          2$:     CMP     R1,#40                  ; SB.CODE,*                     7124
000126  001007                          BNE     3$
000130  013716  000042'                  MOV     TBL.SUC+42,(SP)         ;                               7126
000134  012746  000001                  MOV     #1,-(SP)
000140  010600                          MOV     SP,R0                   ; SP,*
000142  104415                          TRAP    15
000144  005726                          TST     (SP)+
000146  020127  000100          3$:     CMP     R1,#100                 ; SB.CODE,*                     7127
000152  001030                          BNE     5$
000154  013716  000044'                  MOV     TBL.SUC+44,(SP)         ;                               7129
000160  012746  000001                  MOV     #1,-(SP)
000164  010600                          MOV     SP,R0                   ; SP,*
000166  104415                          TRAP    15
000170  000565                          BR      12$
000172  020227  000001          4$:     CMP     R2,#1                   ; ST.CODE,*                     7132
000176  001020                          BNE     6$
000200  010116                          MOV     R1,(SP)                 ; SB.CODE,*
000202  012746  000010                  MOV     #10,-(SP)
000206  004737  000000G                 JSR     %C,BL$DIV
000212  010016                          MOV     R0,(SP)
000214  012746  000000G                 MOV     #E, SBO,-(SP)
000220  012746  000002                  MOV     #2, (SP)
000224  010600                          MOV     SP,R0                   ; SP,*
000226  104415                          TRAP    15
000230  062706  000006                  ADD     #6,SP
000234  000137  011110'          5$:     JMP     17$                     ;                               7117
000240  020227  000002          6$:     CMP     R2,#2                   ; ST.CODE,*                     7134
000244  001773                          BEQ     5$                      ;                               7117
000246  020227  000003                  CMP     R2,#3                   ; ST.CODE,*                     7136
000252  001014                          BNE     7$
000254  020127  000010                  CMP     R1,#10                  ; SB.CODE,*
000260  101365                          BHI     5$
000262  010100                          MOV     R1,R0                   ; SB.CODE,*                     7138
000264  006300                          ASL     R0
000266  016016  000046'                  MOV     TBL.OFL(R0),(SP)
000272  012746  000001                  MOV     #1,-(SP)
000276  010600                          MOV     SP,R0                   ; SP,*
000300  104415                          TRAP    15
000302  000556                          BR      15$
000304  020227  000004          7$:     CMP     R2,#4                   ; ST.CODE,*                     7140
000310  001565                          BEQ     17$                     ;                               7117
000312  020227  000005                  CMP     R2,#5                   ; ST.CODE,*                     7142
```

```
000316  001014                          BNE     8$
000320  020127  000012                  CMP     R1,#12                  ; SB.CODE,*
000324  101157                          BHI     17$
000326  010100                          MOV     R1,R0                   ; SB.CODE,*             7144
000330  006300                          ASL     R0
000332  016016  000070'                  MOV     TBL.MFE(R0),(SP)
000336  012746  000001                  MOV     #1,-(SP)
000342  010600                          MOV     SP,R0                   ; SP,*
000344  104415                          TRAP    15
000346  000534                          BR      15$
000350  020227  000006          8$:     CMP     R2,#6                   ; ST.CODE,*             7146
000354  001033                          BNE     10$
000356  020127  000010                  CMP     R1,#10                  ; SB.CODE,*             7147
000362  001007                          BNE     9$
000364  013716  000124'                  MOV     TBL.WPT+6,(SP)          ;                       7149
000370  012746  000001                  MOV     #1,-(SP)
000374  010600                          MOV     SP,R0                   ; SP,*
000376  104415                          TRAP    15
000400  005726                          TST     (SP)+
000402  010116          9$:             MOV     R1,(SP)                 ; SB.CODE,*             7150
000404  012746  000200                  MOV     #200,-(SP)
000410  004737  000000G                 JSR     PC,BL$DIV
000414  005726                          TST     (SP)+
000416  020027  000002                  CMP     R0,#2
000422  101120                          BHI     17$
000424  006300                          ASL     R0                      ;                       7152
000426  016016  000116'                  MOV     TBL.WPT(R0),(SP)
000432  012746  000001                  MOV     #1,-(SP)
000436  010600                          MOV     SP,R0                   ; SP,*
000440  104415                          TRAP    15
000442  000476                          BR      15$
000444  020227  000007          10$:    CMP     R2,#7                   ; ST.CODE,*             7155
000450  001505                          BEQ     17$                     ;                       7117
000452  020227  000010                  CMP     R2,#10                  ; ST.CODE,*             7157
000456  001014                          BNE     11$
000460  020127  000017                  CMP     R1,#17                  ; SB.CODE,*
000464  101077                          BHI     17$
000466  010100                          MOV     R1,R0                   ; SB.CODE,*             7159
000470  006300                          ASL     R0
000472  016016  000126'                  MOV     TBL.DAT(R0),(SP)
000476  012746  000001                  MOV     #1, (SP)
000502  010600                          MOV     SP,R0                   ; SP,*
000504  104415                          TRAP    15
000506  000454                          BR      15$
000510  020227  000011          11$:    CMP     R2,#11                  ; ST.CODE,*             7161
000514  001014                          BNE     13$
000516  020127  000004                  CMP     R1,#4                   ; SB.CODE,*
000522  101060                          BHI     17$
000524  010100                          MOV     R1,R0                   ; SB.CODE,*             7163
000526  006300                          ASL     R0
000530  016016  000166'                  MOV     TBL.HST(R0),(SP)
000534  012746  000001                  MOV     #1,-(SP)
000540  010600                          MOV     SP,R0                   ; SP,*
```

```
000542  104415                          TRAP    15
000544  000435                  12$:    BR      15$
000546  020227  000012          13$:    CMP     R2,#12                  ; ST.CODE,*                             7165
000552  001014                          BNE     14$
000554  020127  000003                  CMP     R1,#3                   ; SB.CODE,*
000560  101041                          BHI     17$
000562  010100                          MOV     R1,R0                   ; SB.CODE,*                             7167
000564  006300                          ASL     R0
000566  016016  000200'                  MOV     TBL.CNT(R0),(SP)
000572  012746  000001                  MOV     #1,-(SP)
000576  010600                          MOV     SP,R0                   ; SP,*
000600  104415                          TRAP    15
000602  000416                          BR      15$
000604  020227  000013          14$:    CMP     R2,#13                  ; ST.CODE,*                             7169
000610  001015                          BNE     16$
000612  020127  000010                  CMP     R1,#10                  ; SB.CODE,*
000616  101022                          BHI     17$
000620  010100                          MOV     R1,R0                   ; SB.CODE,*                             7171
000622  006300                          ASL     R0
000624  016016  000210'                  MOV     TBL.DRV(R0),(SP)
000630  012746  000001                  MOV     #1,-(SP)
000634  010600                          MOV     SP,R0                   ; SP,*
000636  104415                          TRAP    15
000640  005726                  15$:    TST     (SP)+
000642  000410                          BR      17$                     ;                                       7117
000644  010116                  16$:    MOV     R1,(SP)                 ; SB.CODE,*                             7173
000646  012746  000000G                 MOV     #EX.SBO, (SP)
000652  012746  000002                  MOV     #2,-(SP)
000656  010600                          MOV     SP,R0                   ; SP,*
000660  104415                          TRAP    15
000662  022626                          CMP     (SP)+,(SP)+
000664  022626                  17$:    CMP     (SP)+,(SP)+             ;                                       7114
000666  000207                          RTS     PC                      ;                                       7090

; Routine Size:  220 words,    Routine Base:  $CODE$ + 10224
; Maximum stack depth per invocation:  10 words


;   7226  1
;   7227  1
```

```
;    7228  1
;    7229  1      routine EMS_CMD1 (addr) : novalue =                                    ! MMM
;    7230  1
;    7231  1      !*
;    7232  1      !       THIS ROUTINE PRINTS (EXTENDED) THE OPCODE AND COMMAND MODIFIER (IF
;    7233  1      !       PRESENT) OF THE RETURN PACKET. THESE FIELDS ARE "TRANSLATED"
;    7234  1      !       INTO ENGLISH TEXT RATHER THAN PRINTED AS RAW NUMBERS.
;    7235  1      !
;    7236  1      !-
;    7237  1
;    7238  2          begin
;    7239  2
;    7240  2          local
;    7241  2              RP_ADDR : ref block [RP_LEN, word] field (RP FIELDS);          ! RETURN PACKET ADDRESS  MMM
;    7242  2
;    7243  2          RP_ADDR = .addr;                                                   ! MMM
;    7244  2          PRINTX (EX_CMD);                                                   ! "COMMAND: "
;    7245  2
;    7246  2          selectoneu (.RP_ADDR [ENDCOD] and OP_MSK) of
;    7247  2              set
;    7248  2
;    7249  2              [OP_ONL]:       PRINTX (EX_ONL);                           ! ONLINE
;    7250  2
;    7251  2              [OP_ACC]:       PRINTX (EX_ACC);                           ! ACCESS
;    7252  2
;    7253  3              [OP_RD]:        begin
;    7254  3                              PRINTX (EX_RD);                            ! READ
;    7255  3
;    7256  3      !MMM                    if .RP_ADDR [CMDMOD] neq 0
;    7257  3                              if (.RP_ADDR [CMDMOD] and MD_CMP) neq 0 !MMM
;    7258  3                              then
;    7259  3                                  PRINTX (EX_CMP);                       ! COMPARE
;    7260  3
;    7261  2                              end;
;    7262  2
;    7263  3              [OP_WRT]:       begin
;    7264  3                              PRINTX (EX_WRT);                           ! WRITE
;    7265  3
;    7266  3      !MMM                    if .RP_ADDR [CMDMOD] neq 0
;    7267  3                              if (.RP_ADDR [CMDMOD] and MD_CMP) neq 0    !MMM
;    7268  3                              then
;    7269  3                                  PRINTX (EX_CMP);                       ! COMPARE
;    7270  3
;    7271  2                              end;
;    7272  2
;    7273  2              [otherwise]:    PRINTX (EX_OP, .RP_ADDR [ENDCOD]);         ! ENDCODE VALUE IF NO MATCH
;    7274  2              tes;
;    7275  2
;    7276  1          end;                                                           ! ROUTINE EMS_CMD1


                                        .SBTTL  EMS.CMD1 ERROR MESSAGE SUBROUTINES
000000  004137  000000G                EMS.CMD1:
```

```
                                                JSR     R1,$SAVE2                       ;                                       7229
000004  016601  000010                          MOV     10(SP),R1                       ; ADDR,RP.ADDR                          7243
000010  012746  000000G                         MOV     #EX.CMD,-(SP)                   ;                                       7244
000014  012746  000001                          MOV     #1, (SP)
000020  010600                                  MOV     SP,R0                           ; SP,*
000022  104415                                  TRAP    15
000024  116102  000014                          MOVB    14(R1),R2                       ; *(RP.ADDR),*                          7246
000030  042702  177600                          BIC     #177600,R2
000034  020227  000011                          CMP     R2,#11                          ;                                       7249
000040  001007                                  BNE     1$
000042  012716  000000G                         MOV     #EX.ONL,(SP)
000046  012746  000001                          MOV     #1,-(SP)
000052  010600                                  MOV     SP,R0                           ; SP,*
000054  104415                                  TRAP    15
000056  000462                                  BR      5$
000060  020227  000020                  1$:     CMP     R2,#20                          ;                                       7251
000064  001007                                  BNE     2$
000066  012716  000000G                         MOV     #EX.ACC,(SP)
000072  012746  C00001                          MOV     #1,-(SP)
000076  010600                                  MOV     SP,R0                           ; SP,*
000100  104415                                  TRAP    15
000102  000450                                  BR      5$
000104  020227  000041                  2$:     CMP     R2,#41                          ;                                       7253
000110  001021                                  BNE     3$
000112  012716  000000G                         MOV     #EX.RD,(SP)                     ;                                       7254
000116  012746  000001                          MOV     #1,-(SP)
000122  010600                                  MOV     SP,R0                           ; SP,*
000124  104415                                  TRAP    15
000126  032761  040000  000012                  BIT     #40000,12(R1)                   ; *,*(RP.ADDR)                          7257
000134  001433                                  BEQ     5$
000136  012716  000000G                         MOV     #EX.CMP,(SP)                    ;                                       7259
000142  012746  000001                          MOV     #1,-(SP)
000146  010600                                  MOV     SP,R0                           ; SP,*
000150  104415                                  TRAP    15
000152  000423                                  BR      4$
000154  020227  000042                  3$:     CMP     R2,#42                          ;                                       7263
000160  001023                                  BNE     6$
000162  012716  000000G                         MOV     #EX.WRT,(SP)                    ;                                       7264
000166  012746  000001                          MOV     #1,-(SP)
000172  010600                                  MOV     SP,R0                           ; SP,*
000174  104415                                  TRAP    15
000176  032761  040000  000012                  BIT     #40000,12(R1)                   ; *,*(RP.ADDR)                          7267
000204  001407                                  BEQ     5$
000206  012716  000000G                         MOV     #EX.CMP,(SP)                    ;                                       7269
000212  012746  000001                          MOV     #1,-(SP)
000216  010600                                  MOV     SP,R0                           ; SP,*
000220  104415                                  TRAP    15
000222  005726                          4$:     TST     (SP)+
000224  005726                          5$:     TST     (SP)+                           ;                                       7263
000226  000412                                  BR      7$                              ;                                       7246
000230  005016                          6$:     CLR     (SP)                            ;                                       7273
000232  116116  000014                          MOVB    14(R1),(SP)                     ; *(RP.ADDR),*
000236  012746  000000G                         MOV     #EX.OP,-(SP)
```

```
000242  012746  000002                          MOV     #2,-(SP)
000246  010600                                  MOV     SP,R0                   ; SP,R
000250  104415                                  TRAP    15
000252  022626                                  CMP     (SP)+,(SP)+
000254  022626                          7$:     CMP     (SP)+,(SP)+             ;                                       7238
000256  000207                                  RTS     PC                      ;                                       7229

; Routine Size:  88 words,    Routine Base:  $CODE$ + 11114
; Maximum stack depth per invocation:  9 words


;   7277  1
```

```
;    7278  1      !MMMGLOBAL ROUTINE EMS_DBN : NOVALUE =                                                  !ZZZ
;    7279  1      !*                                                                                      !ZZZ
;    7280  1      !       THIS ROUTINE PRINTS THE PRESENT DBN                                             !ZZZ
;    7281  1      !                                                                                       !ZZZ
;    7282  1      !       IMPLICIT INPUTS:                                                                !ZZZ
;    7283  1      !               CST_ADDR - ADDRESS OF CONTROLLER STATUS TABLE                           !ZZZ
;    7284  1      !-                                                                                      !ZZZ
;    7285  1                                                                                             !ZZZ
;    7286  1      !BEGIN                                                                                  !ZZZ
;    7287  1      !PRINTB (XX13, .CDISK);                         !"DISK XXX'                             !ZZZ
;    7288  1      !PRINTB (XX2?  .CST_ADDR [.CUOFF + OF_DBN, D_DBN], .CST_AD'                              !ZZZ
;    7289  1      !                        [.CUOFF + OF_DBN, D_DBN]);     !"DBN, XXXXXX."                 !ZZZ
;    7290  1      !PRINTB (XX32, .S_DUPPKT - 2);                  !PRINT BYTE COUNT                       !ZZZ
;    7291  1      !PRINTB (XX33, .S_PATTERN);                     !PRINT THE PATTERN                      !ZZZ
;    7292  1      !PRINTB (XX34, .(DUPPKT + .S_DUPPKT), .(DUPPKT + .S_DUPPKT));   !PRINT THE WORD READ    !ZZZ
;    7293  1      !EMS_BLK (DUPPKT +2, 256);                      !PRINT WHOLE BLOCK READ                 !ZZZ
;    7294  1      !END;                                           !IN OCTAL                               !ZZZ
;    7295  1      !MMM
;    7296  1
```

```
;    7297  1
;    7298  1      GLOBAL ROUTINE EMS_BLK (ADDR, LENGTH) : NOVALUE =                                !ZZZ
;    7299  1
;    7300  1      !+                                                                              !ZZZ
;    7301  1      !       THIS ROUTINE WILL PRINTX A BLOCK OF MEMORY, WHICH IS 'LENGTH'           !ZZZ
;    7302  1      !       WORDS LONG STARTING AT ADDRESS 'ADDR'. PRINTING IS DONE IN OCTAL        !ZZZ
;    7303  1      !       8 WDS TO A LINE.                                                        !ZZZ
;    7304  1      !-                                                                              !ZZZ
;    7305  1                                                                                      !ZZZ
;    7306  2      BEGIN                                                                           !ZZZ
;    7307  2      LITERAL                                                                         !ZZZ
;    7308  2              MASK = %o'7';                                                           !ZZZ
;    7309  2                                                                                      !ZZZ
;    7310  2      PRINTX (CRLF);                                                                  !ZZZ
;    7311  2              INCR COUNT FROM 1 TO .LENGTH DO          !FOR EACH WD TO PRINT         !ZZZ
;    7312  3                      BEGIN                                                           !ZZZ
;    7313  3                      IF ((.COUNT - 1) AND MASK) EQL 0 !IF START OF NEW LINE         !ZZZ
;    7314  3                      THEN                                                            !ZZZ
;    7315  3                              PRINTX (SPACE4);         !PRINT 4 BLANKS               !ZZZ
;    7316  3                                                                                      !ZZZ
;    7317  3                      PRINTX (EX_WRD, ..ADDR);         !PRINTX A WORD                !ZZZ
;    7318  3                      ADDR = .ADDR +2;                 !TO NEXT ADDRESS              !ZZZ
;    7319  3                                                                                      !ZZZ
;    7320  4                      IF (((.COUNT AND MASK) EQL 0) OR !END OF LINE OR               !ZZZ
;    7321  4                          (.COUNT EQL .LENGTH))        !WHEN DONE                    !ZZZ
;    7322  3                      THEN                                                            !ZZZ
;    7323  3                              PRINTX (CRLF);           !PRINT CR LF                  !ZZZ
;    7324  2                      END;                                                            !ZZZ
;    7325  1              END;                                                                    !ZZZ


                                        .SBTTL  EMS.BLK ERROR MESSAGE SUBROUTINES
000000  010146                  EMS.BLK::
                                        MOV     R1,-(SP)                ;                       7298
000002  012746  000000G                 MOV     #CRLF,-(SP)             ;                       7310
000006  012746  000001                  MOV     #1,-(SP)
000012  010600                          MOV     SP,R0                   ; SP,*
000014  104415                          TRAP    15
000016  005001                          CLR     R1                      ; COUNT                 7311
000020  000445                          BR      5$
000022  010100                  1$:     MOV     R1,R0                   ; COUNT,*               7313
000024  005300                          DEC     R0
000026  032700  000007                  BIT     #7,R0
000032  001007                          BNE     2$
000034  012716  000000G                 MOV     #SPACE4,(SP)            ;                       7315
000040  012746  000001                  MOV     #1,-(SP)
000044  010600                          MOV     SP,R0                   ; SP,*
000046  104415                          TRAP    15
000050  005726                          TST     (SP)+
000052  017616  000012          2$:     MOV     @12(SP),(SP)            ; ADDR,*                7317
000056  012746  000000G                 MOV     #EX.WRD,-(SP)
000062  012746  000002                  MOV     #2,-(SP)
00006   010600                          MOV     SP,R0                   ; SP,*
```

```
000070  104415                                  TRAP    15
000072  062766  000002  000016                  ADD     #2,16(SP)       ; .,ADDR                7318
000100  032701  000007                          BIT     #7,R1           ; .,COUNT               7320
000104  001403                                  BEQ     3$
000106  020166  000014                          CMP     R1,14(SP)       ; COUNT,LENGTH          7321
000112  001007                                  BNE     4$
000114  012716  000000G                 3$:     MOV     #CRLF,(SP)      ;                       7325
000120  012746  000001                          MOV     #1,-(SP)
000124  010600                                  MOV     SP,R0           ; SP,.
000126  104415                                  TRAP    15
000130  005726                                  TST     (SP)+
000132  022626                          4$:     CMP     (SP)+,(SP)+     ;                       7312
000134  005201                          5$:     INC     R1              ; COUNT                 7311
000136  020166  000010                          CMP     R1,10(SP)       ; COUNT,LENGTH
000142  003727                                  BLE     1$
000144  022626                                  CMP     (SP)+,(SP)+     ;                       7306
000146  012601                                  MOV     (SP)+,R1        ;                       7298
000150  000207                                  RTS     PC

; Routine Size:  53 words,    Routine Base:  $CODE$ + 11374
; Maximum stack depth per invocation:  8 words


;   7326  1
;   7327  1
```

```
;    7328  1
;    7329  1      routine EMS_LBN1 (addr) : novalue =                                     ! MMM
;    7330  1
;    7331  1      !+
;    7332  1      !       THIS ROUTINE PRINTS (EXTENDED) ONE OF TWO BLOCK NUMBERS APPEARING IN
;    7333  1      !       THE RETURN PACKET. NORMALLY, THE LBN FIELD IS PRINTED; THIS
;    7334  1      !       FIELD WAS COPIED INTO THE RETURN PACKET FROM THE ASSOCIATED COMMAND
;    7335  1      !       PACKET. HOWEVER, IF THE "FLAGS" FIELD OF THE RETURN PACKET
;    7336  1      !       INDICATES "BAD BLOCK REPORTED", THEN THE "FIRST BAD BLOCK" FIELD IS
;    7337  1      !       PRINTED.
;    7338  1      !
;    7339  1      !-
;    7340  1
;    7341  2          begin
;    7342  2          local
;    7343  2              RP_ADDR : ref block [RP_LEN, word] field (RP_FIELDS);       ! RETURN PACKET ADDRESS  MMM
;    7344  2
;    7345  2          RP_ADDR = addr;                                                 ! MMM
;    7346  2
;    7347  2          if (not BIT_TST (RP_ADDR [FLAGS], EF_BBR)) and                  ! IF NO BAD BLOCK FOUND
;    7348  3             (not BIT_TST (RP_ADDR [FLAGS], EF_BBU))
;    7349  2          then
;    7350  2              PRINTX (EX_LBN2, .RP_ADDR [LBN_HI], .RP_ADDR [LBN_LO]);                                    !ZZZ
;    7351  2
;    7352  2          if (not BIT_TST (RP_ADDR [FLAGS], EF_BBR)) and                  ! IF BAD BLOCKS FOUND AND REPLACED
;    7353  3             (BIT_TST (RP_ADDR [FLAGS], EF_BBU))
;    7354  2          then
;    7355  2              PRINTX (EX_BBU2, .RP_ADDR [BBLK_HI], .RP_ADDR [BBLK_LO]);                                  !ZZZ
;    7356  2
;    7357  2          if (BIT_TST (RP_ADDR [FLAGS], EF_BBR)) and                      ! IF HOST REPLACEABLE BAD BLOCK FOUND
;    7358  3             (not BIT_TST (RP_ADDR [FLAGS], EF_BBU))
;    7359  2          then
;    7360  2              PRINTX (EX_BB2, .RP_ADDR [BBLK_HI], .RP_ADDR [BBLK_LO]);                                   !ZZZ
;    7361  2
;    7362  2          if (BIT_TST (RP_ADDR [FLAGS], EF_BBR)) and                      ! IF MORE THAN 1 HOST REPLACEABLE BAD BLOCK FOUND
;    7363  3             (BIT_TST (RP_ADDR [FLAGS], EF_BBU))
;    7364  2          then
;    7365  2              PRINTX (EX_BB12, .RP_ADDR [BBLK_HI], .RP_ADDR [BBLK_LO]);                                  !ZZZ
;    7366  1          end;

                                        .SBTTL  EMS.LBN1 ERROR MESSAGE SUBROUTINES
000000  004137  000000G          EMS.LBN1:
                                        JSR     R1,#SAVE3                       ;                                   7329
000004  016601  000012                  MOV     12(SP),R1                       ; ADDR,RP.ADDR                      7345
000010  005002                          CLR     R2                              ;                                   7347
000012  156102  000015                  BISB    15(R1),R2                       ; *(RP.ADDR),*
000016  005003                          CLR     R3
000020  105702                          TSTB    R2
000022  100002                          BPL     1$
000024  005203                          INC     R3
000026  000417                          BR      2$
000030  032702  000100          1$:     BIT     #100,R2                         ;                                   7348
```

```
000034  001014                          BNE     2$
000036  016146  000050                  MOV     50(R1),-(SP)            ; *(RP.ADDR),*                  7350
000042  016146  000052                  MOV     52(R1),-(SP)            ; *(RP.ADDR),*
000046  012746  000000G                 MOV     #EX.LBN2,-(SP)
000052  012746  000003                  MOV     #3,-(SP)
000056  010600                          MOV     SP,R0                   ; SP,*
000060  104415                          TRAP    15
000062  062706  000010                  ADD     #10,SP
000066  032703  000001          2$:     BIT     #1,R3                   ;                               7352
000072  001022                          BNE     4$
000074  032702  000100                  BIT     #100,R2                 ;                               7353
000100  001414                          BEQ     3$
000102  016146  000040                  MOV     40(R1),-(SP)            ; *(RP.ADDR),*                  7355
000106  016146  000042                  MOV     42(R1),-(SP)            ; *(RP.ADDR),*
000112  012746  000000G                 MOV     #EX.BBU2, (SP)
000116  012746  000003                  MOV     #3,-(SP)
000122  010600                          MOV     SP,R0                   ; SP,*
000124  104415                          TRAP    15
000126  062706  000010                  ADD     #10,SP
000132  032703  000001          3$:     BIT     #1,R3                   ;                               7357
000136  001417                          BEQ     5$
000140  032702  000100          4$:     BIT     #100,R2                 ;                               7358
000144  001014                          BNE     5$
000146  016146  000040                  MOV     40(R1), (SP)            ; *(RP.ADDR),*                  7360
000152  016146  000042                  MOV     42(R1),-(SP)            ; *(RP.ADDR),*
000156  012746  000000G                 MOV     #EX.BB2,-(SP)
000162  012746  000003                  MOV     #3, (SP)
000166  010600                          MOV     SP,R0                   ; SP,*
000170  104415                          TRAP    15
000172  062706  000010                  ADD     #10,SP
000176  006003          5$:     ROR     R3                              ;                               7362
000200  103017                          BCC     6$
000202  032702  000100                  BIT     #100,R2                 ;                               7363
000206  001414                          BEQ     6$
000210  016146  000040                  MOV     40(R1), (SP)            ; *(RP.ADDR),*                  7365
000214  016146  000042                  MOV     42(R1), (SP)            ; *(RP.ADDR),*
000220  012746  000000G                 MOV     #EX.BB12,-(SP)
000224  012746  000003                  MOV     #3,-(SP)
000230  010600                          MOV     SP,R0                   ; SP,*
000232  104415                          TRAP    15
000234  062706  000010                  ADD     #10,SP
000240  000207          6$:     RTS     PC                              ;                               7329

; Routine Size:  81 words,      Routine Base:  $CODE$ + 11546
; Maximum stack depth per invocation:  10 words


;    7367  1
;    7368  1
;    7369  1
;    7370  1
```

```
;    7371  1
;    7372  1      routine EMS_BC1 (addr) : novalue =                ! MMM
;    7373  1
;    7374  1      !*
;    7375  1      !       THIS ROUTINE PRINTS (EXTENDED) BOTH BYTE COUNT FIELDS OF THE
;    7376  1      !       RETURN PACKET: THE BYTE COUNT FROM THE COMMAND PACKET AND THE
;    7377  1      !       ACTUAL NUMBER OF BYTES TRANSFERRED (FROM THE RESPONSE PACKET).
;    7378  1      !
;    7379  1      !-
;    7380  1
;    7381  2          begin
;    7382  2          local
;    7383  2              RP_ADDR : ref block [RP_LEN, word] field (RP_FIELDS);          ! RETURN PACKET ADDRESS  MMM
;    7384  2
;    7385  2          RP_ADDR = .addr;                                  ! MMM
;    7386  2          PRINTX (EX_CBC, .RP_ADDR [CBCNT_LO]);        ! "BYTE COUNT IN COMMAND: XXXXX."
;    7387  2          PRINTX (EX_BC, .RP_ADDR [BCNT_LO]);          ! "ACTUAL # OF BYTES TRANSFERRED: XXXXX."
;    7388  1          end;                                          ! ROUTINE EMS_BC1


                                        .SBTTL  EMS.BC1 ERROR MESSAGE SUBROUTINES
000000  010146                    EMS.BC1:MOV     R1,-(SP)                        ;                                       7372
000002  016601  000004                    MOV     4(SP),R1                        ; ADDR,RP.ADDR                          7385
000006  016146  000044                    MOV     44(R1), (SP)                    ; *(RP.ADDR),*                          7386
000012  012746  000000G                   MOV     #EX.CBC, (SP)
000016  012746  000002                    MOV     #2,-(SP)
000022  010600                            MOV     SP,R0                           ; SP,*
000024  104415                            TRAP    15
000026  016116  000020                    MOV     20(R1),(SP)                     ; *(RP.ADDR),*                          7387
000032  012746  000000G                   MOV     #EX.BC,-(SP)
000036  012746  000002                    MOV     #2,-(SP)
000042  010600                            MOV     SP,R0                           ; SP,*
000044  104415                            TRAP    15
000046  062706  000012                    ADD     #12,SP                          ;                                       7381
000052  012601                            MOV     (SP)+,R1                        ;                                       7372
000054  000207                            RTS     PC

; Routine Size:  23 words,      Routine Base:  $CODE$ + 12010
; Maximum stack depth per invocation:  8 words


;    7389  1
```

```
;    7390  1
;    7391  1      routine EMS_BD1 (addr) : novalue =                                          ! MMM
;    7392  1
;    7393  1      !+
;    7394  1      !       THIS ROUTINE PRINTS (EXTENDED) THE TWO WORD I/O BUFFER DESCRIPTOR
;    7395  1      !       APPEARING IN THE RETURN PACKET.
;    7396  1      !
;    7397  1      !
;    7398  2          begin
;    7399  2
;    7400  2          local
;    7401  2              RP_ADDR : ref block [RP_LEN, word] field (RP_FIELDS);          ! RETURN PACKET ADDRESS  MMM
;    7402  2
;    7403  2          RP_ADDR = .addr;                                          ! MMM
;    7404  2          PRINTX (EX_BD, .RP_ADDR [BUFF_1], .RP_ADDR [BUFF 0]);      ! "I/O BUFFER DESCRIPTOR: XXXXXX XXXXXX"
;    7405  2
;    7406  1          end;


                                        .SBTTL  EMS.BD1 ERROR MESSAGE SUBROUTINES
000000  016600  000002          EMS.BD1:MOV     2(SP),R0                        ; ADDR,RP.ADDR                          7403
000004  016046  000024                  MOV     24(R0),-(SP)                    ; *(RP.ADDR),*                          7404
000010  016046  000026                  MOV     26(R0), (SP)                    ; *(RP.ADDR),*
000014  012746  000000G                 MOV     #EX.BD,-(SP)
000020  012746  000003                  MOV     #3,-(SP)
000024  010600                          MOV     SP,R0                           ; SP,*
000026  104415                          TRAP    15
000030  062706  000010                  ADD     #10,SP                          ;                                       7398
000034  000207                          RTS     PC                              ;                                       7391

; Routine Size:  15 words,      Routine Base:  $CODE$ + 12066
; Maximum stack depth per invocation:  6 words


;    7407  1
```

```
;    7408  1
;    7409  1     global routine EMS_R2 (addr) : novalue =                                  ! MMM
;    7410  1
;    7411  1
;    7412  1     !+
;    7413  1     !       THIS ROUTINE IS RESPONSIBLE FOR PRINTING (EXTENDED) THE RELEVANT FIELDS
;    7414  1     !       OF THE RETURN PACKET.
;    7415  1     !-
;    7416  1
;    7417  1
;    7418  2         begin
;    7419  2
;    7420  2         local
;    7421  2             RP_ADDR : ref block [RP_LEN, word] field (RP_FIELDS);          ! RETURN PACKET ADDRESS  MMM
;    7422  2
;    7423  2
;    7424  2         RP_ADDR = .addr;                                          ! MMM
;    7425  2         EMS_SBC1 (.RP_ADDR);                                       ! MMM
;    7426  2         EMS_CMD1 (.RP_ADDR);                                      ! COMMAND (AND MODIFIER) MMM
;    7427  2
;    7428  2         if (.RP_ADDR [ENDCOD] and OP_MSK) neq OP_ONL
;    7429  2
;    7430  2         then
;    7431  2             EMS_LBN1 (.RP_ADDR);                                      ! LBN OR BAD BLOCK NUMBER  MMM
;    7432  2
;    7433  2         if ((.RP_ADDR [ENDCOD] and OP_MSK) eql OP_RD) or
;    7434  3            ((.RP_ADDR [ENDCOD] and OP_MSK) eql OP_WRT)
;    7435  3
;    7436  2         then
;    7437  3             begin
;    7438  3             EMS_BC1 (.RP_ADDR);                                       ! BYTE COUNTS MMM
;    7439  3             EMS_BD1 (.RP_ADDR);                                       ! I/O BUFFER DESCRIPTOR MMM
;    7440  2             end;
;    7441  2
;    7442  2         EMS_TIM ();                                               ! TIME
;    7443  1         end;                                                      ! ROUTINE EMS R2

                                .SBTTL  EMS.R2 ERROR MESSAGE SUBROUTINES
000000  010146                 EMS.R2::MOV     R1,-(SP)                        ;                                       7409
000002  016601  000004                 MOV     4(SP),R1                        ; ADDR,RP.ADDR                          7424
000006  010146                         MOV     R1,-(SP)                        ; RP.ADDR,*                             7425
000010  004737  010224'                JSR     PC,EMS.SBC1
000014  010116                         MOV     R1,(SP)                         ; RP.ADDR,*                             7426
000016  004737  011114'                JSR     PC,EMS.CMD1
000022  116100  000014                 MOVB    14(R1),R0                       ; *(RP.ADDR),*                          7428
000026  042700  177600                 BIC     #177600,R0
000032  020027  000011                 CMP     R0,#11
000036  001403                         BEQ     1$
000040  010116                         MOV     R1,(SP)                         ; RP.ADDR,*                             7431
000042  004737  011546'                JSR     PC,EMS.LBN1
000046  116100  000014         1$:     MOVB    14(R1),R0                       ; *(RP.ADDR),*                          7433
000052  042700  177600                 BIC     #177600,R0
```

```
000056  020027  000041                          CMP     R0,#41
000062  001407                                  BEQ     2$
000064  116100  000014                          MOVB    14(R1),R0               ; *(RP.ADDR),*                  7434
000070  042700  177600                          BIC     #177600,R0
000074  020027  000042                          CMP     R0,#42
000100  001006                                  BNE     3$
000102  010116                          2$:     MOV     R1,(SP)                 ; RP.ADDR,*                     7438
000104  004737  012010'                         JSR     PC,EMS.BC1
000110  010116                                  MOV     R1,(SP)                 ; RP.ADDR,*                     7439
000112  004737  012066'                         JSR     PC,EMS.BD1
000116  004737  000000V                 3$:     JSR     PC,EMS.TIM              ;                               7442
000122  005726                                  TST     (SP)+                   ;                               7418
000124  012601                                  MOV     (SP)+,R1                ;                               7409
000126  000207                                  RTS     PC

; Routine Size:  44 words,    Routine Base:  $CODE$ + 12124
; Maximum stack depth per invocation:  3 words


;   7444  1
```

```
;    7445  1     global routine EMS_R1 (addr) : novalue =
;    7446  1
;    7447  1     !+
;    7448  1     !       THIS  ROUTINE  IS  CALLED  TO  PRINT  THE  ENTIRE CONTENTS OF THE
;    7449  1     !       RETURN PACKET DESIGNATED.  HOWEVER, THE PRINTING WILL ONLY
;    7450  1     !       OCCUR IF EXTENDED ERROR PRINTING IS ENABLED.
;    7451  1     !-
;    7452  1
;    7453  2         begin
;    7454  2         local
;    7455  2             RP_ADDR : ref block [RP_LEN, word] field (RP FIELDS);          ! RETURN PACKET ADDRESS  MMM
;    7456  2
;    7457  2         RP_ADDR = .addr;                                ! MMM
;    7458  2         PRINTX (EX_RP);                                 ! "CONTENTS OF RETURN PACKET:"
;    7459  2         EMS_BLK (.RP_ADDR, RP_LEN);                     ! PRINT BLOCK OF WORDS
;    7460  1         end;


                                        .SBTTL  EMS.R1 ERROR MESSAGE SUBROUTINES
000000  010146                  EMS.R1::MOV     R1,-(SP)                        ;                                       7445
000002  016601  000004                  MOV     4(SP),R1                        ; ADDR,RP.ADDR                          7457
000006  012746  000000G                 MOV     #EX.RP,-(SP)                    ;                                       7458
000012  012746  000001                  MOV     #1,-(SP)
000016  010600                          MOV     SP,R0                           ; SP,*
000020  104415                          TRAP    15
000022  010116                          MOV     R1,(SP)                         ; RP.ADDR,*                             7459
000024  012746  000026                  MOV     #26,-(SP)
000030  004737  011374'                 JSR     PC,EMS.BLK
000034  062706  000006                  ADD     #6,SP                           ;                                       7453
000040  012601                          MOV     (SP)+,R1                        ;                                       7445
000042  000207                          RTS     PC

; Routine Size:  18 words,      Routine Base:  $CODE$ + 12254
; Maximum stack depth per invocation:  5 words
```

```
;    7461  1      global routine EMS_EL (index) : novalue =
;    7462  1
;    7463  1      !+
;    7464  1      !       THIS ROUTINE IS CALLED FROM 'SEQUEN' AND 'DATAGM' AND PRINTS THE CONTENTS OF THE
;    7465  1      !       ERROR-LOG PACKET
;    7466  1      !-
;    7467  1
;    7468  2          begin
;    7469  2
;    7470  2          local
;    7471  2              ELOG_ADDR : ref block [EP_LEN, word] field (EP_FIELDS),
;    7472  2              REASON : word,
;    7473  2              DISK_NUM : byte,
;    7474  2              ELOG_CODE : byte,
;    7475  2              ELOG_SUB : word;
;    7476  2
;    7477  2          ELOG_ADDR = ELOG_PKT + (.index * EP_LEN * 2);                   ! ERROR LOG PACKET'S ADDRESS
;    7478  2          REASON = .ELOG_ADDR [EL_FORMAT];                                ! FORMAT
;    7479  2          DISK_NUM = .ELOG_ADDR [EL_DK_NUM];                              ! DISK NUMBER
;    7480  2          ELOG_CODE = .ELOG_ADDR [EL_CODE];                               ! CODE
;    7481  2          ELOG_SUB = .ELOG_ADDR [EL_SUBCODE];                             ! SUBCODE
;    7482  2          PRINTB (ELG_00);                                                ! ERROR-LOG MESSAGE RECEIVED
;    7483  2
;    7484  2          if (.REASON eql FORMAT_CNTR) or
;    7485  3             (.REASON eql FORMAT_HOST)
;    7486  2          then
;    7487  2              PRINTB (.ELG_FMT [.REASON]);                                ! PRINT BASIC REASON
;    7488  2
;    7489  2          if (.REASON eql FORMAT_XFER) or                                 !MMM
;    7490  2             (.REASON eql FORMAT_SDI) or                                  !MMM
;    7491  3             (.REASON eql FORMAT_SDE)                                     !MMM
;    7492  2          then
;    7493  2              PRINTB (.ELG_FMT [.REASON], .DISK_NUM);                     ! PRINT BASIC REASON WITH DISK NUMBER
;    7494  2
;    7495  3          if (.REASON eql FORMAT_BRA)                                     ! BAD BLOCK REPLACEMENT ATTEMPT MMM
;    7496  2          then
;    7497  2              PRINTB (.ELG_FMT [5], .DISK_NUM);                           ! PRINT BASIC REASON WITH DISK NUMBER MMM
;    7498  2
;    7499  2          if (.ELOG_CODE gtru 0) and
;    7500  3             (.ELOG_CODE lequ 11)
;    7501  2          then
;    7502  3              begin
;    7503  3              PRINTX (ASTERISK);
;    7504  3              PRINTX (.ERR_COD [.ELOG_CODE - 1]);                         ! CODE
;    7505  3              end
;    7506  2          else
;    7507  2
;    7508  2              if .ELOG_CODE eql ST_DIA                                    ! MESSAGE FROM INTERNAL DIAGNOSTICS
;    7509  2              then
;    7510  3                  begin
;    7511  3                  PRINTX (ASTERISK);
;    7512  3                  PRINTX (.ERR_COD [11]);                                 !MMM
;    7513  2                  end;
```

```
;    7514  2
;    7515  2          if .ELOG_CODE eql ST_BRC                                    ! BAD BLOCK REPLACEMENT COMPLETION MMM
;    7516  2          then
;    7517  3              begin
;    7518  3              PRINTX (ASTERISK);
;    7519  3              PRINTX (.ERR_COD [14]);                                 !MMM
;    7520  2              end;
;    7521  2
;    7522  2          if (.ELOG_CODE eql ST_MFE) and
;    7523  3             (.ELOG_SUB lequ 10)
;    7524  2          then
;    7525  3              begin
;    7526  3              PRINTX (CRLF);
;    7527  3              PRINTX (ASTERISK);
;    7528  3              PRINTX (.TBL_MFE [.ELOG_SUB]);                          ! MEDIA FORMAT ERROR
;    7529  2              end;
;    7530  2
;    7531  2          if (.ELOG_CODE eql ST_DAT) and
;    7532  3             (.ELOG_SUB lequ 15)
;    7533  2          then
;    7534  3              begin
;    7535  3              PRINTX (CRLF);
;    7536  3              PRINTX (ASTERISK);
;    7537  3              PRINTX (.TBL_DAT [.ELOG_SUB]);                          ! DATA ERROR
;    7538  2              end;
;    7539  2
;    7540  2          if (.ELOG_CODE eql ST_HST) and
;    7541  3             (.ELOG_SUB lequ 4)
;    7542  2          then
;    7543  3              begin
;    7544  3              PRINTX (CRLF);
;    7545  3              PRINTX (ASTERISK);
;    7546  3              PRINTX (.TBL_HST [.ELOG_SUB]);                          ! HOST ACCESS ERROR
;    7547  2              end;
;    7548  2
;    7549  2          if (.ELOG_CODE eql ST_CNT) and
;    7550  3             (.ELOG_SUB lequ 3)
;    7551  2          then
;    7552  3              begin
;    7553  3              PRINTX (CRLF);
;    7554  3              PRINTX (ASTERISK);
;    7555  3              PRINTX (.TBL_CNT [.ELOG_SUB]);                          ! CONTROLLER ERROR
;    7556  2              end;
;    7557  2
;    7558  2          if (.ELOG_CODE eql ST_DRV) and
;    7559  3             (.ELOG_SUB lequ 8)
;    7560  2          then
;    7561  3              begin
;    7562  3              PRINTX (CRLF);
;    7563  3              PRINTX (ASTERISK);
;    7564  3              PRINTX (.TBL_DRV [.ELOG_SUB]);                          ! DRIVE ERROR
;    7565  2              end;
;    7566  2
```

```
;    7567  2          if (.ELOG_CODE eql ST_BRC) and                                    ! BAD BLOCK REPLACEMENT COMPLETION MMM
;    7568  3             (.ELOG_SUB lequ 4)
;    7569  2          then
;    7570  3              begin
;    7571  3              PRINTX (CRLF);
;    7572  3              PRINTX (ASTERISK);
;    7573  3              PRINTX (.TBL_BRC [.ELOG SUB]);                               ! OUTCOME OF BAD BLOCK REPELACEMENT MMM
;    7574  2              end;
;    7575  2
;    7576  2          if .REASON eql FORMAT_XFER                                       ! IF DISK XFER INVOLVED
;    7577  2          then
;    7578  2
;    7579  2              if .ELOG_ADDR [EL_BLOCK_TYPE] eql TYPE_LBN                   ! PRINT PBN OR RBN
;    7580  2              then
;    7581  3                  PRINTX (EX_PBN2, .ELOG_ADDR [EL_BLOCK_HI], .ELOG_ADDR [EL_BLOCK])                    !ZZZ
;    7582  2              else
;    7583  2                  PRINTX (EX_RBN2, .ELOG_ADDR [EL_BLOCK_HI], .ELOG_ADDR [EL_BLOCK]);                   !ZZZ
;    7584  2
;    7585  2          if .REASON eql FORMAT_BRA                                        ! IF BAD BLOCK REPLACEMENT INVOLVED MMM
;    7586  2          then
;    7587  2              PRINTX (EX_LB, .ELOG_ADDR [EL_BLOCK_HI], .ELOG_ADDR [EL_BLOCK]);                         !MMM
;    7588  2
;    7589  2          EMS_TIM ();                                                      ! TIME
;    7590  2          EMS_BLK ((.ELOG_ADDR + 2), ((.ELOG_ADDR [EL_MSGLEN] + 1) / 2) + 2); ! PRINTX CONTENTS OF PACKET
;    7591  2          ELOG_ADDR [EL_CONTENTS] = EMPTY;                                 ! DECLARE SAVE AREA FREE
;    7592  2
;    7593  1          end;


                                        .SBTTL  EMS.EL ERROR MESSAGE SUBROUTINES
000000  004137  000000G          EMS.EL::JSR     R1,$SAVE5                       ;                                       7461
000004  024646                          CMP     -(SP),-(SP)
000006  016646  000022                  MOV     22(SP),-(SP)                    ; INDEX,*                               7477
000012  012746  000102                  MOV     #102,-(SP)
000016  004737  000C)0G                 JSR     PC,BL$MUL
000022  062700  000000G                 ADD     #ELOG.PKT,R0
000026  010001                          MOV     R0,R1                           ; *,ELOG.ADDR
000030  005002                          CLR     R2                              ; REASON                                7478
000032  156102  000016                  BISB    16(R1),R2                       ; *(ELOG.ADDR),REASON
000036  116105  000012                  MOVB    12(R1),R5                       ; *(ELOG.ADDR),DISK.NUM                 7479
000042  116100  000020                  MOVB    20(R1),R0                       ; *(ELOG.ADDR),*
000046  042700  177740                  BIC     #177740,R0
000052  105004                          CLRB    R4                              ; ELOG.CODE
000054  050004                          BIS     R0,R4                           ; *,ELOG.CODE
000056  016103  000020                  MOV     20(R1),R3                       ; *(ELOG.ADDR),ELOG.SUB
000062  006203                          ASR     R3                              ; ELOG.SUB
000064  006203                          ASR     R3                              ; ELOG.SUB
000066  006203                          ASR     R3                              ; ELOG.SUB
000070  006203                          ASR     R3                              ; ELOG.SUB
000072  006203                          ASR     R3                              ; ELOG.SUB
000074  042703  174000                  BIC     #174000,R3                      ; *,ELOG.SUB
000100  012716  000000G                 MOV     #ELG.00,(SP)                    ;                                       7482
000104  012746  000001                  MOV     #1, (SP)
```

```
000110  010600                          MOV     SP,R0                   ; SP,*
000112  104414                          TRAP    14
000114  005702                          TST     R2                      ; REASON                        7484
000116  001403                          BEQ     1$
000120  020227  000001                  CMP     R2,#1                   ; REASON,*                      7485
000124  001011                          BNE     2$
000126  010200                  1$:     MOV     R2,R0                   ; REASON,*                      7487
000130  006300                          ASL     R0
000132  016016  000000G                 MOV     ELG.FMT(R0),(SP)
000136  012746  000001                  MOV     #1,-(SP)
000142  010600                          MOV     SP,R0                   ; SP,*
000144  104414                          TRAP    14
000146  005726                          TST     (SP)+
000150  005066  000006          2$:     CLR     6(SP)                   ;                               7489
000154  020227  000002                  CMP     R2,#2                   ; REASON,*
000160  001003                          BNE     3$
000162  005266  000006                  INC     6(SP)
000166  000406                          BR      4$
000170  020227  000003          3$:     CMP     R2,#3                   ; REASON,*                      7490
000174  001403                          BEQ     4$
000176  020227  000004                  CMP     R2,#4                   ; REASON,*                      7491
000202  001013                          BNE     5$
000204  005016                  4$:     CLR     (SP)                    ;                               7493
000206  110516                          MOVB    R5,(SP)                 ; DISK.NUM,*
000210  010200                          MOV     R2,R0                   ; REASON,*
000212  006300                          ASL     R0
000214  016046  000000G                 MOV     ELG.FMT(R0),-(SP)
000220  012746  000002                  MOV     #2,-(SP)
000224  010600                          MOV     SP,R0                   ; SP,*
000226  104414                          TRAP    14
000230  022626                          CMP     (SP)+,(SP)+
000232  005066  000010          5$:     CLR     10(SP)                  ;                               7495
000236  020227  000011                  CMP     R2,#11                  ; REASON,*
000242  001013                          BNE     6$
000244  005266  000010                  INC     10(SP)
000250  005016                          CLR     (SP)                    ;                               7497
000252  110516                          MOVB    R5,(SP)                 ; DISK.NUM,*
000254  013746  000012G                 MOV     ELG.FMT+12,-(SP)
000260  012746  000002                  MOV     #2,-(SP)
000264  010600                          MOV     SP,R0                   ; SP,*
000266  104414                          TRAP    14
000270  022626                          CMP     (SP)+,(SP)+
000272  105704                  6$:     TSTB    R4                      ; ELOG.CODE                     7499
000274  001423                          BEQ     7$
000276  120427  000013                  CMPB    R4,#13                  ; ELOG.CODE,*                   7500
000302  101020                          BHI     7$
000304  012716  000000G                 MOV     #ASTERISK,(SP)          ;                               7503
000310  012746  000001                  MOV     #1,-(SP)
000314  010600                          MOV     SP,R0                   ; SP,*
000316  104415                          TRAP    15
000320  005000                          CLR     R0                      ;                               7504
000322  150400                          BISB    R4,R0                   ; ELOG.CODE,*
000324  006300                          ASL     R0
```

```
000326  016016  177776G                        MOV     ERR.COD 2(R0),(SP)
000332  012746  000001                        MOV     #1, (SP)
000336  010600                                MOV     SP,R0                   ; SP,*
000340  104415                                TRAP    15
000342  000417                                BR      8$                      ;                                       7502
000344  120427  000037          7$:           CMPB    R4,#37                  ; ELOG.CODE,*                           7508
000350  001015                                BNE     9$
000352  012716  000000G                       MOV     #ASTERISK,(SP)          ;                                       7511
000356  012746  000001                        MOV     #1,-(SP)
000362  010600                                MOV     SP,R0                   ; SP,*
000364  104415                                TRAP    15
000366  013716  000026G                       MOV     ERR.COD+26,(SP)         ;                                       7512
000372  012746  000001                        MOV     #1, (SP)
000376  010600                                MOV     SP,R0                   ; SP,*
000400  104415                                TRAP    15
000402  022626                        8$:     CMP     (SP)+,(SP)+             ;                                       7510
000404  005002                        9$:     CLR     R2                      ;                                       7515
000406  120427  000024                        CMPB    R4,#24                  ; ELOG.CODE,*
000412  001016                                BNE     10$
000414  005202                                R2
000416  012716  000000G                       #ASTERISK,(SP)          ;                                       7518
000422  012746  000001                        #1,-(SP)
000426  010600                        MOV     SP,R0                   ; SP,*
000430  104415                                TRAP    15
000432  013716  000034G                       MOV     ERR.COD+34,(SP)         ;                                       7519
000436  012746  000001                        MOV     #1,-(SP)
000442  010600                                MOV     SP,R0                   ; SP,*
000444  104415                                TRAP    15
000446  022626                                CMP     (SP)+,(SP)+             ;                                       7517
000450  120427  000005          10$:          CMPB    R4,#5                   ; ELOG.CODE,*                           7522
000454  001031                                BNE     11$
000456  020327  000012                        CMP     R3,#12                  ; ELOG.SUB,*                            7523
000462  101026                                BHI     11$
000464  012716  000000G                       MOV     #CRLF,(SP)              ;                                       7526
000470  012746  000001                        MOV     #1,-(SP)
000474  010600                                MOV     SP,R0                   ; SP,*
000476  104415                                TRAP    15
000500  012716  000000G                       MOV     #ASTERISK,(SP)          ;                                       7527
000504  012746  000001                        MOV     #1,-(SP)
000510  010600                                MOV     SP,R0                   ; SP,*
000512  104415                                TRAP    15
000514  010300                                MOV     R3,R0                   ; ELOG.SUB,*                            7528
000516  006300                                ASL     R0
000520  016016  000070'                       MOV     TBL.MFE(R0),(SP)
000524  012746  000001                        MOV     #1,-(SP)
000530  010600                                MOV     SP,R0                   ; SP,*
000532  104415                                TRAP    15
000534  062706  000006                        ADD     #6,SP                   ;                                       7525
000540  120427  000010          11$:          CMPB    R4,#10                  ; ELOG.CODE,*                           7531
000544  001031                                BNE     12$
000546  020327  000017                        CMP     R3,#17                  ; ELOG.SUB,*                            7532
000552  101026                                BHI     12$
000554  012716  000000G                       MOV     #CRLF,(SP)              ;                                       7535
```

```
000560  012746  000001                        MOV     #1, (SP)
000564  010600                                MOV     SP,R0           ; SP,*
000566  104415                                TRAP    15
000570  012716  000000G                       MOV     #ASTERISK,(SP)  ;                       7536
000574  012746  000001                        MOV     #1, (SP)
000600  010600                                MOV     SP,R0           ; SP,*
000602  104415                                TRAP    15
000604  010300                                MOV     R3,R0           ; ELOG.SUB,*            7537
000606  006300                                ASL     R0
000610  016016  000126'                       MOV     TBL.DAT(R0),(SP)
000614  012746  000001                        MOV     #1,-(SP)
000620  010600                                MOV     SP,R0           ; SP,*
000622  104415                                TRAP    15
000624  062706  000006                        ADD     #6,SP           ;                       7534
000630  120427  000011            12$:        CMPB    R4,#11          ; ELOG.CODE,*           7540
000634  001031                                BNE     13$
000636  020327  000004                        CMP     R3,#4           ; ELOG.SUB,*            7541
000642  101026                                BHI     13$
000644  012716  000000G                       MOV     #CRLF,(SP)      ;                       7544
000650  012746  000001                        MOV     #1,-(SP)
000654  010600                                MOV     SP,R0           ; SP,*
000656  104415                                TRAP    15
000660  012716  000000G                       MOV     #ASTERISK,(SP)  ;                       7545
000664  012746  000001                        MOV     #1,-(SP)
000670  010600                                MOV     SP,R0           ; SP,*
000672  104415                                TRAP    15
000674  010300                                MOV     R3,R0           ; ELOG.SUB,*            7546
000676  006300                                ASL     R0
000700  016016  000166'                       MOV     TBL.HST(R0),(SP)
000704  012746  000001                        MOV     #1,-(SP)
000710  010600                                MOV     SP,R0           ; SP,*
000712  104415                                TRAP    15
000714  062706  000006                        ADD     #6,SP           ;                       7543
000720  120427  000012            13$:        CMPB    R4,#12          ; ELOG.CODE,*           7549
000724  001031                                BNE     14$
000726  020327  000003                        CMP     R3,#3           ; ELOG.SUB,*            7550
000732  101026                                BHI     14$
000734  012716  000000G                       MOV     #CRLF,(SP)      ;                       7553
000740  012746  000001                        MOV     #1,-(SP)
000744  010600                                MOV     SP,R0           ; SP,*
000746  104415                                TRAP    15
000750  012716  000000G                       MOV     #ASTERISK,(SP)  ;                       7554
000754  012746  000001                        MOV     #1,-(SP)
000760  010600                                MOV     SP,R0           ; SP,*
000762  104415                                TRAP    15
000764  010300                                MOV     R3,R0           ; ELOG.SUB,*            7555
000766  006300                                ASL     R0
000770  016016  000200'                       MOV     TBL.CNT(R0),(SP)
000774  012746  000001                        MOV     #1,-(SP)
001000  010600                                MOV     SP,R0           ; SP,*
001002  104415                                TRAP    15
001004  062706  000006                        ADD     #6,SP           ;                       7552
001010  120427  000013            14$:        CMPB    R4,#13          ; ELOG.CODE,*           7558
```

```
001014  001031                                  BNE     15$
001016  020327  000010                          CMP     R3,#10                  ; ELOG SUB.*                    7559
001022  101026                                  BHI     15$
001024  012716  000000G                         MOV     #CRLF,(SP)              ;                               7562
001030  012746  000001                          MOV     #1,-(SP)
001034  010600                                  MOV     SP,R0                   ; SP,*
001036  104415                                  TRAP    15
001040  012716  000000G                         MOV     #ASTERISK,(SP)          ;                               7563
001044  012746  000001                          MOV     #1,-(SP)
001050  010600                                  MOV     SP,R0                   ; SP,*
001052  104415                                  TRAP    15
001054  010300                                  MOV     R3,R0                   ; ELOG.SUB,*                    7564
001056  006300                                  ASL     R0
001060  016016  000210'                         MOV     TBL.DRV(R0),(SP)
001064  012746  000001                          MOV     #1,-(SP)
001070  010600                                  MOV     SP,R0                   ; SP,*
001072  104415                                  TRAP    15
001074  062706  000006                          ADD     #6,SP                   ;                               7561
001100  006002                          15$:    ROR     R2                      ;                               7567
001102  103031                                  BCC     16$
001104  020327  000004                          CMP     R3,#4                   ; ELOG.SUB,*                    7568
001110  101026                                  BHI     16$
001112  012716  000000G                         MOV     #CRLF,(SP)              ;                               7571
001116  012746  000001                          MOV     #1,-(SP)
001122  010600                                  MOV     SP,R0                   ; SP,*
001124  104415                                  TRAP    15
001126  012716  000000G                         MOV     #ASTERISK,(SP)          ;                               7572
001132  012746  000001                          MOV     #1,-(SP)
001136  010600                                  MOV     SP,R0                   ; SP,*
001140  104415                                  TRAP    15
001142  010300                                  MOV     R3,R0                   ; ELOG.SUB,*                    7573
001144  006300                                  ASL     R0
001146  016016  000232'                         MOV     TBL.BRC(R0),(SP)
001152  012746  000001                          MOV     #1,-(SP)
001156  010600                                  MOV     SP,R0                   ; SP,*
001160  104415                                  TRAP    15
001162  062706  000006                          ADD     #6,SP                   ;                               7570
001166  032766  000001  000006          16$:    BIT     #1,6(SP)                ;                               7576
001174  001437                                  BEQ     19$
001176  012700  000060                          MOV     #60,R0                  ;                               7579
001202  060100                                  ADD     R1,R0                   ; ELOG.ADDR,*
001204  032710  170000                          BIT     #170000,(R0)
001210  001014                                  BNE     17$
001212  016116  000056                          MOV     56(R1),(SP)             ; *(ELOG.ADDR),*                7581
001216  011046                                  MOV     (R0),-(SP)
001220  042716  170000                          BIC     #170000,(SP)
001224  012746  000000G                         MOV     #EX.PBN2,-(SP)
001230  012746  000003                          MOV     #3,-(SP)
001234  010600                                  MOV     SP,R0                   ; SP,*
001236  104415                                  TRAP    15
001240  000413                                  BR      18$                     ;                               7579
001242  016116  000056                  17$:    MOV     56(R1),(SP)             ; *(ELOG.ADDR),*                7583
001246  011046                                  MOV     (R0),-(SP)
```

```
001250  042716  170000                          BIC     #170000,(SP)
001254  012746  000000G                         MOV     #EX.RBN2,-(SP)
001260  012746  000003                          MOV     #3,-(SP)
001264  010600                                  MOV     SP,R0                   ; SP,*
001266  104415                                  TRAP    15
001270  062706  000006                  18$:    ADD     #6,SP                   ;                                       7579
001274  032766  000001  000010          19$:    BIT     #1,10(SP)               ;                                       7585
001302  001416                                  BEQ     20$
001304  016116  000056                          MOV     56(R1),(SP)             ; *(ELOG.ADDR),*                        7587
001310  016146  000060                          MOV     60(R1),-(SP)            ; *(ELOG.ADDR),*
001314  042716  170000                          BIC     #170000,(SP)
001320  012746  000000G                         MOV     #EX.LB,-(SP)
001324  012746  000003                          MOV     #3,-(SP)
001330  010600                                  MOV     SP,R0                   ; SP,*
001332  104415                                  TRAP    15
001334  062706  000006                          ADD     #6,SP
001340  004737  000000V                  20$:    JSR     PC,EMS.TIM              ;                                       7589
001344  012716  000002                          MOV     #2,(SP)                 ;                                       7590
001350  060116                                  ADD     R1,(SP)                 ; ELOG.ADDR,*
001352  016146  000002                          MOV     2(R1),-(SP)             ; *(ELOG.ADDR),*
001356  005216                                  INC     (SP)
001360  012746  000002                          MOV     #2,-(SP)
001364  004737  000000G                         JSR     PC,BL$DIV
001370  010066  000002                          MOV     R0,2(SP)
001374  062766  000002  000002                  ADD     #2,2(SP)
001402  005726                                  TST     (SP)+
001404  004737  011374'                         JSR     PC,EMS.BLK
001410  105061  000001                          CLRB    1(R1)                   ; *(ELOG.ADDR)                          7591
001414  062706  000014                          ADD     #14,SP                  ;                                       7461
001420  000207                                  RTS     PC

; Routine Size:  393 words,     Routine Base:  $CODE$ + 12320
; Maximum stack depth per invocation:  16 words
```

```
;    7594  1     global routine EMS_CMP (ADDR) : novalue =
;    7595  1
;    7596  1     !+
;    7597  1     ! THIS ROUTINE IS CALLED FROM 'HOST WPT CHK' AND PRINTS RELEVENT DATA ON A HOST
;    7598  1     ! COMPARE ERROR
;    7599  1     !-
;    7600  1
;    7601  2         begin
;    7602  2
;    7603  2         local
;    7604  2             ORIG_ADDR : ref block [RP_LEN, word] field (RP_FIELDS); ! MMM
;    7605  2
;    7606  2         ORIG_ADDR = .ADDR;                                          ! ADDRESS OF THE WRITE RETPKT
;    7607  2         PRINTB (ERR_00, .CDISK);                                    ! "DISK XXX"
;    7608  2         PRINTB (DASH);                                              !
;    7609  2         PRINTB (.ERR_COD [12]);                                     ! "   HOST COMPARE ERROR"
;    7610  2         PRINTX (EX_LBW2, .ORIG_ADDR [LBN_HI], .ORIG_ADDR [LBN_LO]); ! LBN (WRITTEN)                         ZZZ
;    7611  2         PRINTX (EX_LBR2, .RP_ADDR [LBN_HI], .RP_ADDR [LBN_LO]);     ! LBN (READ)                          ZZZ
;    7612  2         PRINTX (EX_CBW, .ORIG_ADDR [CBCNT_LO]);                     ! BYTE COUNT (WRITE)
;    7613  2         PRINTX (EX_BC, .ORIG_ADDR [BCNT_LO]);                       ! BYTE COUNT XMITTED (WRITE)
;    7614  2         PRINTX (EX_CBR, .RP_ADDR [CBCNT_LO]);                       ! BYTE COUNT (READ);
;    7615  2         PRINTX (EX_BC, .RP_ADDR [BCNT_LO]);                         ! BYTE COUNT XMITTED (READ)
;    7616  2         PRINTX (EX_BDW, .ORIG_ADDR [BUFF_1], .ORIG_ADDR [BUFF_0]);  ! BUFFER ADDRESS (WRITE)
;    7617  2         PRINTX (EX_BDR, .RP_ADDR [BUFF_1], .RP_ADDR [BUFF_0]);      ! BUFFER ADDRESS (READ)
;    7618  2         EMS_TIM ();                                                 ! TIME
;    7619  2         EMS_R2 (.ORIG_ADDR);                                        ! MMM
;    7620  2         EMS_R1 (.ORIG_ADDR);                                          ! MMM
;    7621  2         EMS_R2 (.RP_ADDR);                                        ! MMM
;    7622  2         EMS_R1 (.RP_ADDR);                                          ! MMM
;    7623  1         end;


                                        .SBTTL  EMS.CMP ERROR MESSAGE SUBROUTINES
000000  010146                    EMS.CMP::
                                        MOV     R1, (SP)                        ;                                   7594
000002  016601  000004                  MOV     4(SP),R1                        ; ADDR.ORIG.ADDR                    7606
000006  013746  000000G                 MOV     CDISK,-(SP)                     ;                                   7607
000012  012746  000000G                 MOV     #ERR.00,-(SP)
000016  012746  000002                  MOV     #2,-(SP)
000022  010600                          MOV     SP,R0                           ; SP,*
000024  104414                          TRAP    14
000026  012716  000000G                 MOV     #DASH,(SP)                      ;                                   7608
000032  012746  000001                  MOV     #1,-(SP)
000036  010600                          MOV     SP,R0                           ; SP,*
000040  104414                          TRAP    14
000042  013716  000030G                 MOV     ERR.COD+30,(SP)                 ;                                   7609
000046  012746  000001                  MOV     #1,-(SP)
000052  010600                          MOV     SP,R0                           ; SP,*
000054  104414                          TRAP    14
000056  016116  000050                  MOV     50(R1),(SP)                     ; *(ORIG.ADDR),*                    7610
000062  016146  000052                  MOV     52(R1),-(SP)                    ; *(ORIG.ADDR),*
000066  012746  000000G                 MOV     #EX.LBW2,-(SP)
000072  012746  000003                  MOV     #3,-(SP)
```

```
000076  010600                  MOV     SP,R0                   ; SP,*
000100  104415                  TRAP    15
000102  013700  000000G         MOV     RP.ADDR,R0              ;                                       7611
000106  016016  000050          MOV     50(R0),(SP)
000112  016046  000052          MOV     52(R0),-(SP)
000116  012746  000000G         MOV     #EX.LBR2,-(SP)
000122  012746  000003          MOV     #3,-(SP)
000126  010600                  MOV     SP,R0                   ; SP,*
000130  104415                  TRAP    15
000132  016116  000044          MOV     44(R1),(SP)             ; *(ORIG.ADDR),*                        7612
000136  012746  000000G         MOV     #EX.CBW,-(SP)
000142  012746  000002          MOV     #2, (SP)
000146  010600                  MOV     SP,R0                   ; SP,*
000150  104415                  TRAP    15
000152  016116  000020          MOV     20(R1),(SP)             ; *(ORIG.ADDR),*                        7613
000156  012746  000000G         MOV     #EX.BC,-(SP)
000162  012746  000002          MOV     #2,-(SP)
000166  010600                  MOV     SP,R0                   ; SP,*
000170  104415                  TRAP    15
000172  013700  000000G         MOV     RP.ADDR,R0              ;                                       7614
000176  016016  000044          MOV     44(R0),(SP)
000202  012746  000000G         MOV     #EX.CBR,-(SP)
000206  012746  000002          MOV     #2,-(SP)
000212  010600                  MOV     SP,R0                   ; SP,*
000214  104415                  TRAP    15
000216  013700  000000G         MOV     RP.ADDR,R0              ;                                       7615
000222  016016  000020          MOV     20(R0),(SP)
000226  012746  000000G         MOV     #EX.BC, (SP)
000232  012746  000002          MOV     #2,-(SP)
000236  010600                  MOV     SP,R0                   ; SP,*
000240  104415                  TRAP    15
000242  016116  000024          MOV     24(R1),(SP)             ; *(ORIG.ADDR),*                        7616
000246  016146  000026          MOV     26(R1),-(SP)            ; *(ORIG.ADDR),*
000252  012746  000000G         MOV     #EX.BDW,-(SP)
000256  012746  000003          MOV     #3,-(SP)
000262  010600                  MOV     SP,R0                   ; SP,*
000264  104415                  TRAP    15
000266  013700  000000G         MOV     RP.ADDR,R0              ;                                       7617
000272  016016  000024          MOV     24(R0),(SP)
000276  016046  000026          MOV     26(R0),-(SP)
000302  012746  000000G         MOV     #EX.BDR,-(SP)
000306  012746  000003          MOV     #3,-(SP)
000312  010600                  MOV     SP,R0                   ; SP,*
000314  104415                  TRAP    15
000316  004737  000000V         JSR     PC,EMS.TIM              ;                                       7618
000322  010116                  MOV     R1,(SP)                 ; ORIG.ADDR,*                           7619
000324  004737  012124'         JSR     PC,EMS.R2
000330  010116                  MOV     R1,(SP)                 ; ORIG.ADDR,*                           7620
000332  004737  012254'         JSR     PC,EMS.R1
000336  013716  000000G         MOV     RP.ADDR,(SP)            ;                                       7621
000342  004737  012124'         JSR     PC,EMS.R2
000346  013716  000000G         MOV     RP.ADDR,(SP)            ;                                       7622
000352  004737  012254'         JSR     PC,EMS.R1
```

```
000356  062706  000062                          ADD     #62,SP                  ;                                       7601
000362  012601                                  MOV     (SP)+,R1                ;                                       7594
000364  000207                                  RTS     PC

; Routine Size:  123 words,     Routine Base:  $CODE$ + 13742
; Maximum stack depth per invocation:  28 words
```

```
;    7624  1     global routine EMS_ERR : novalue =
;    7625  1
;    7626  2         begin
;    7627  2
;    7628  2     ! TABLE OF BASIC, HARD ERROR MESSAGE ADDRESSES, INDEXED BY STATUS CODE
;    7629  2     !
;    7630  2         PRINTB (ERR_00, .CDISK);                        ! "DISK XXX"
;    7631  2         PRINTB (DASH);                                  !
;    7632  2
;    7633  2         if (.ST_CODE gtru 0) and                        ! IF STATUS CODE IS WITHIN RANGE
;    7634  3            (.ST_CODE lequ 11)
;    7635  2         then
;    7636  3             PRINTB (.ERR_COD [.ST_CODE - 1])            ! PRINTB APPROPRIATE MESSAGE
;    7637  2         else
;    7638  2
;    7639  2             if .ST_CODE eql ST_DIA
;    7640  2             then
;    7641  3                 PRINTB (.ERR_COD [11])                  ! MESSAGE FROM INTERNAL DIAGNOSTICS
;    7642  2             else
;    7643  2                 PRINTB (EX_SC, .ST_CODE);               ! JUST PRINT STATUS CODE WHEN NO MATCH
;    7644  2
;    7645  2         EMS_R2 (.RP_ADDR);                                      ! PRINTX OTHER RETPKT FIELDS
;    7646  2
;    7647  1         end;


                                        .SBTTL  EMS.ERR ERROR MESSAGE SUBROUTINES
000000  013746  000000G          EMS.ERR::
                                        MOV     CDISK,-(SP)             ;                               7630
000004  012746  000000G                 MOV     #ERR.00,-(SP)
000010  012746  000002                  MOV     #2,-(SP)
000014  010600                          MOV     SP,R0                   ; SP,*
000016  104414                          TRAP    14
000020  012716  000000G                 MOV     #DASH,(SP)              ;                               7631
000024  012746  000001                  MOV     #1,-(SP)
000030  010600                          MOV     SP,R0                   ; SP,*
000032  104414                          TRAP    14
000034  013700  000000G                 MOV     ST.CODE,R0              ;                               7633
000040  001413                          BEQ     1$
000042  020027  000^13                  CMP     R0,#13                  ;                               7634
000046  101010                          BHI     1$
000050  006300                          ASL     R0                      ;                               7636
000052  016016  177776G                 MOV     ERR.COD-2(R0),(SP)
000056  012746  000001                  MOV     #1,-(SP)
000062  010600                          MOV     SP,R0                   ; SP,*
000064  104414                          TRAP    14
000066  000422                          BR      3$                      ;                               7633
000070  020027  000037          1$:     CMP     R0,#37                  ;                               7639
000074  001007                          BNE     2$
000076  013716  000026G                 MOV     ERR.COD+26,(SP)         ;                               7641
000102  012746  000001                  MOV     #1,-(SP)
000106  010600                          MOV     SP,R0                   ; SP,*
000110  104414                          TRAP    14
```

```
000112  000410                          BR      3$                      ;                       7639
000114  010016                  2$:     MOV     R0,(SP)                 ;                       7643
000116  012746  000000G                 MOV     #EX.SC, (SP)
000122  012746  000002                  MOV     #2,-(SP)
000126  010600                          MOV     SP,R0                   ; SP,*
000130  104414                          TRAP    14
000132  005726                          TST     (SP)+
000134  013716  000000G          3$:     MOV     RP.ADDR,(SP)            ;                       7645
000140  004737  012124'                  JSR     PC,EMS.R2
000144  062706  000012                  ADD     #12,SP                  ;                       7626
000150  000207                          RTS     PC                      ;                       7624

; Routine Size:  53 words,      Routine Base:  $CODE$ + 14330
; Maximum stack depth per invocation:  8 words
```

```
;    7648  1     routine EMS_TIM : novalue =
;    7649  1
;    7650  1     !+
;    7651  1     ! THIS ROUTINE PRINTS THE TIME-OF DAY MESSAGE
;    7652  1     !-
;    7653  1
;    7654  1     PRINTX (EX_TIM, .HOURS, .MINUTES);

                                            .SBTTL  EMS.TIM ERROR MESSAGE SUBROUTINES
000000  005046                        EMS.TIM:CLR     -(SP)                           ;                                       7654
000002  113716  000000G                        MOVB    MINUTES,(SP)
000006  005046                                CLR     -(SP)
000010  113716  000000G                        MOVB    HOURS,(SP)
000014  012746  000000G                        MOV     @EX.TIM, (SP)
000020  012746  000003                         MOV     #3, (SP)
000024  010600                                MOV     SP,R0                           ; SP,*
000026  104415                                TRAP    15
000030  062706  C00010                        ADD     #10,SP
000034  000207                                RTS     PC                              ;                                       7648

; Routine Size:  15 words,      Routine Base:  $CODE$ + 14502
; Maximum stack depth per invocation:  6 words
```

```
;   7655  1     BGNMSG (EMS_01);


                                            .SBTTL  EMS.01 ERROR MESSAGE SUBROUTINES
000000  004737  000000V                EMS.01::JSR     PC,M$EMS.01                     ;                                       7655
000004  104423                               TRAP    23
000006  000207                               RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 14540
; Maximum stack depth per invocation:  2 words


;   7656  2     PRINTB (EBS_01, MAX_UNITS);                     ! "MORE THAN XX UNITS SPECIFIED"
;   7657  1     ENDMSG;


                                            .SBTTL  M$EMS.01 ERROR MESSAGE SUBROUTINES
000000  012746  000004                M$EMS.01:
                                               MOV     #4,-(SP)                        ;                                       7656
000004  012746  000000G                        MOV     #EBS.01,-(SP)
000010  012746  000002                         MOV     #2,-(SP)
000014  010600                                 MOV     SP,R0                           ; SP,*
000016  104414                                 TRAP    14
000020  062706  000006                         ADD     #6,SP                           ;                                       7655
000024  000207                                 RTS     PC

; Routine Size:  11 words,      Routine Base:  $CODE$ + 14550
; Maximum stack depth per invocation:  5 words
```

```
;   7658  1     BGNMSG (EMS_10);


                                           .SBTTL  EMS.10 ERROR MESSAGE SUBROUTINES
000000  004737  000000V                EMS.10::JSR     PC,M$EMS.10                     ;                                       7658
000004  104423                               TRAP    23
000006  000207                               RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 14576
; Maximum stack depth per invocation:  2 words


;   7659  2     PRINTB (EBD_10, .RDRX_ADDR + .OF_RC);          ! "NO RESPONSE AT ADDRESS XXXXXX"
;   7660  1     ENDMSG;


                                           .SBTTL  M$EMS.10 ERROR MESSAGE SUBROUTINES
000000  013746  000000G                M$EMS.10:
                                               MOV     RDRX.ADDR,-(SP)                 ;                                       7659
000004  063716  000000G                        ADD     OF.RC,(SP)
000010  012746  000000G                        MOV     #EBD.10,-(SP)
000014  012746  000002                         MOV     #2,-(SP)
000020  010600                                 MOV     SP,R0                           ; SP,*
000022  104414                                 TRAP    14
000024  062706  000006                         ADD     #6,SP                           ;                                       7658
000030  000207                                 RTS     PC

; Routine Size:  13 words,      Routine Base:  $CODE$ + 14606
; Maximum stack depth per invocation:  5 words
```

```
;    7661  1     BGNMSG (EMS_12);


                                            .SBTTL  EMS.12 ERROR MESSAGE SUBROUTINES
000000  004737  000000V                EMS.12::JSR     PC,M$EMS.12                     ;                          7661
000004  104423                               TRAP    23
000006  000207                               RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 14640
; Maximum stack depth per invocation:  2 words


;    7662  2     PRINTB (EBD_12, .RDRX_ADDR);                ! "INCORRECT BR LEVEL GIVEN FOR DEVICE XXXXXX"
;    7663  1     ENDMSG;


                                            .SBTTL  M$EMS.12 ERROR MESSAGE SUBROUTINES
000000  013746  000000G                M$EMS.12:
                                               MOV     RDRX.ADDR,-(SP)                 ;                          7662
000004  012746  000000G                        MOV     @EBD.12,-(SP)
000010  012746  000002                         MOV     #2,-(SP)
000014  010600                                 MOV     SP,R0                           ; SP,*
000016  104414                                 TRAP    14
000020  062706  000006                         ADD     #6,SP                           ;                          7661
000024  000207                                 RTS     PC

; Routine Size:  11 words,      Routine Base:  $CODE$ + 14650
; Maximum stack depth per invocation:  5 words
```

```
;   7664  1     BGNMSG (EMS_13);


                                            .SBTTL  EMS.13 ERROR MESSAGE SUBROUTINES
000000  004737  000000V                EMS.13::JSR     PC,M$EMS.13                     ;                                7664
000004  104423                               TRAP    23
000006  000207                               RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 14676
; Maximum stack depth per invocation:  2 words


;   7665  2     PRINTB (EBD_13, .STEP);                         ! "STEP X READ ERROR"
;   7666  2     EMS_SA ();                                      ! PRINTX SA CONTENTS
;   7667  1     ENDMSG;


                                            .SBTTL  M$EMS.13 ERROR MESSAGE SUBROUTINES
000000  013746  C00000G                M$EMS.13:
                                               MOV     STEP,-(SP)                      ;                                7665
000004  012746  000000G                        MOV     #EBD.13,-(SP)
000010  012746  000002                         MOV     #2,-(SP)
000014  010600                                 MOV     SP,R0                           ; SP,*
000016  104414                                 TRAP    14
000020  004737  007712'                        JSR     PC,EMS.SA                       ;                                7666
000024  062706  000006                         ADD     #6,SP                           ;                                7664
000030  000207                               RTS     PC

; Routine Size:  13 words,      Routine Base:  $CODE$ + 14706
; Maximum stack depth per invocation:  5 words
```

```
;   7668  1     BGNMSG (EMS_14);


                                        .SBTTL  EMS.14 ERROR MESSAGE SUBROUTINES
000000  004737  000000V           EMS.14::JSR     PC,M$EMS.14                     .                                       7668
000004  104423                            TRAP    23
000006  000207                            RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 14740
; Maximum stack depth per invocation:  2 words


;   7669  2     PRINTB (EBD_14, .IRDRX_ADDR);                   ! "BAD SA CODE FROM DEVICE XXXXXX"
;   7670  2     EMS_SA ();                                      ! PRINTX SA REGISTER CONTENTS
;   7671  1     ENDMSG;


                                        .SBTTL  M$EMS.14 ERROR MESSAGE SUBROUTINES
000000  013746  C00000G           M$EMS.14:
                                        MOV     IRDRX.ADDR,-(SP)                ;                                       7669
000004  012746  000000G                 MOV     #EBD.14, (SP)
000010  012746  000002                  MOV     #2,-(SP)
000014  010600                          MOV     SP,R0                           ; SP,*
000016  104414                          TRAP    14
000020  004737  007712'                 JSR     PC,EMS.SA                       ;                                       7670
000024  062706  000006                  ADD     #6,SP                           ;                                       7668
000030  000207                          RTS     PC

; Routine Size:  13 words,      Routine Base:  $CODE$ + 14750
; Maximum stack depth per invocation:  5 words
```

```
;   7672  1     BGNMSG (EMS_18);


                                            .SBTTL  EMS.18 ERROR MESSAGE SUBROUTINES
000000  004737  000000V                EMS.18::JSR     PC,M$EMS.18                     ;                                       7672
000004  104423                               TRAP    23
000006  000207                               RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 15002
; Maximum stack depth per invocation:  2 words


;   7673  2     PRINTB (EBD_18, .CDISK);                        ! "DISK XXX WENT OFFLINE"
;   7674  2     EMS_R2 (.RP_ADDR);                              ! PRINTX RELEVANT RETPKT FIELDS
;   7675  1     ENDMSG;


                                            .SBTTL  M$EMS.18 ERROR MESSAGE SUBROUTINES
000000  013746  C00000G                M$EMS.18:
                                               MOV     CDISK,-(SP)                     ;                                       7675
000004  012746  000000G                        MOV     #EBD.18,-(SP)
000010  012746  000002                         MOV     #2,-(SP)
000014  010600                                 MOV     SP,R0                           ; SP,*
000016  104414                                 TRAP    14
000020  013716  000000G                        MOV     RP.ADDR,(SP)                    ;                                       7674
000024  004737  012124'                        JSR     PC,EMS.R2
000030  062706  000006                         ADD     #6,SP                           ;                                       7672
000034  000207                               RTS     PC

; Routine Size:  15 words,      Routine Base:  $CODE$ + 15012
; Maximum stack depth per invocation:  5 words
```

```
;   7676  1     BGNMSG (EMS_21);


                                          .SBTTL  EMS.21 ERROR MESSAGE SUBROUTINES
000000  004737  000000V                EMS.21::JSR     PC,M$EMS.21                     ;                       7676
000004  104423                                TRAP    23
000006  000207                                RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 15050
; Maximum stack depth per invocation:  2 words


;   7677  2     EMS_R1 (.RP_ADDR);                                  ! CONTENTS OF RETURN PACKET
;   7678  1     ENDMSG;


                                          .SBTTL  M$EMS.21 ERROR MESSAGE SUBROUTINES
000000  013746  000000G                M$EMS.21:
                                          MOV     RP.ADDR,-(SP)                   ;                       7677
000004  004737  012254'                        JSR     PC,EMS.R1
000010  005726                                TST     (SP)+                           ;                       7676
000012  000207                                RTS     PC

; Routine Size:  6 words,       Routine Base:  $CODE$ + 15060
; Maximum stack depth per invocation:  2 words
```

```
;    7679  1      !MMMBGNMSG (EMS_22)                     !CONTENTS OF DUP BUFFER          ZZZ
;    7680  1      !MMMEMS_DBN ();                                                  !ZZZ
;    7681  1      !MMMENDMSG;                                                             !ZZZ
```

```
;   7682  1     BGNMSG (EMS_24);


                                            .SBTTL  EMS.24 ERROR MESSAGE SUBROUTINES
000000  004737  000000V                EMS.24::JSR     PC,M$EMS.24                     ;                                       7682
000004  104423                               TRAP    23
000006  000207                               RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 15074
; Maximum stack depth per invocation:  2 words


;   7683  2     PRINTB (EBD_24, .CDISK);                        ! 'DISK XXX WENT TO THE AVAILABLE STATE"
;   7684  2     EMS_R2 (.RP_ADDR);                              ! PRINTX RELEVANT RETPKT FIELDS
;   7685  1     ENDMSG;


                                            .SBTTL  M$EMS.24 ERROR MESSAGE SUBROUTINES
000000  013746  C00000G              M$EMS.24:
                                            MOV     CDISK,-(SP)                     ;                                       7683
000004  012746  000000G                     MOV     @EBD.24,-(SP)
000010  012746  000002                      MOV     #2, (SP)
000014  010600                              MOV     SP,R0                           ; SP,R0
000016  104414                              TRAP    14
000020  013716  000000G                     MOV     RP.ADDR,(SP)                    ;                                       7684
000024  004737  012124'                     JSR     PC,EMS.R2
000030  062706  000006                      ADD     #6,SP                           ;                                       7682
000034  000207                              RTS     PC

; Routine Size:  15 words,      Routine Base:  $CODE$ + 15104
; Maximum stack depth per invocation:  5 words
```

```
;   7686  1     BGNMSG (EMS_30);


                                        .SBTTL  EMS.30 ERROR MESSAGE SUBROUTINES
000000  004737  000000V           EMS.30::JSR     PC,M$EMS.30                     ;                                       7686
000004  104423                           TRAP    23
000006  000207                           RTS     PC

; Routine Size:  4 words,       Routine Base:  $CODE$ + 15142
; Maximum stack depth per invocation:  2 words


;   7687  2     EMS_ERR ();                                     ! PRINT ALL RELEVANT DATA ON DETECTING AN ERROR
;   7688  1     ENDMSG;


                                        .SBTTL  M$EMS.30 ERROR MESSAGE SUBROUTINES
000000  004737  014330'           M$EMS.30:
                                        JSR     PC,EMS.ERR                      ;                                       7687
000004  000207                           RTS     PC                              ;                                       7686

; Routine Size:  3 words,       Routine Base:  $CODE$ + 15152
; Maximum stack depth per invocation:  1 word


;   7689  1
;   7690  1     end
;   7691  1
;   7692  0     eludom


;                                       OTS external references
                                                .GLOBL  $SAVE5, $SAVE4, $SAVE3, $SAVE2
                                                .GLOBL  BL$DIV, BL$MOD, BL$MUL


;                                       PSECT SUMMARY
;
;       Psect Name                      Words     Attributes
;         $OWN$                           82       RW  ,  D  ,  LCL,  REL,  CON
;         $CODE$                        3384       RO  ,  I  ,  LCL,  REL,  CON


;                                 Library Statistics
;
;                                                 -  ---- Symbols  --          Pages       Processing
;       File                                     Total    Loaded   Percent      Mapped      Time
;
;  DISK$USER2:[MLYNAR.ZRQ]ZRQAM0.L16;10           411       295        71         21          00:00.1
```

```
;                                       COMMAND QUALIFIERS

;       BLISS/PDP11 ZRQAM0.BL1/LIST=ZRQAM0.LS1/OBJECT=ZRQAM0.OB1/SOURCE=PAGE:53

; Size:         3216 code + 6709 data words
; Run Time:       01:53.7
; Elapsed Time:   09:09.1
; Lines/CPU Min:   4060
; Lexemes/CPU-Min: 37129
; Memory Used:  727 pages
; Compilation Complete
```



```
;   0001  0     module ZRQAM3 (
;   0002  0
;   0003  0     %title 'RD/RX EXERCISER'
;   0004  0                 ident = 'V02.3',
;   0005  0                 addressing_mode (absolute),
;   0006  0                 environment (noe's)
;   0007  0                 ) =
;   0008  0
;   0009  1     begin
;   0010  1
;   0011  1     %sbttl 'DECLARATIONS'
;   0012  1
;   0013  1     library 'ZRQAM0.L16';                       ! PDRX EXERCISER GLOBAL LIBRARY
;   0014  1
;   0015  1     !MMM require 'BLSMAC.REQ';                  ! DIAGNOSTIC SUPERVISOR LIBRARY      ZZZ
;   0016  1     require 'HSAXA0.BLB';                       ! DIAGNOSTIC SUPERVISOR LIBRARY      ZZZ
;   1757  1
;   1758  1     EQUALS;
;   1759  1
;   1760  1     forward routine                             ! ROUTINES APPEAR IN THIS ORDER
;   1761  1         INIT_TEST : novalue,                    !    INDENTATION IMPLIES CALLED SUBROUTINE
;   1762  1             DRIVER_INIT : novalue,
;   1763  1                 CTLR_INIT : novalue,
;   1764  1                     INI_CTLR_DAT : novalue,
;   1765  1                     REG_EXIST,
;   1766  1                     VEC_BR_TEST,
;   1767  1                     INT_GEN,
;   1768  1                     HARD_INIT,
;   1769  1                     INI_RRING : novalue,
;   1770  1                     SET_CTLR_CHAR,
;   1771  1                 UNIT_INIT : novalue,
;   1772  1                     DR_ERR : novalue,
;   1773  1             ACCESS : novalue,
;   1774  1         MULTI_DRIVE : novalue,
;   1775  1             MD_INIT : novalue,
;   1776  1                 INIT_IO_BUFF : novalue,
;   1777  1             FATAL_ERROR : novalue,
;   1778  1             QIO_OK,
;   1779  1                 QIO_OUT,
;   1780  1                 QIO_GEN : novalue,
;   1781  1                     GET_RANDOM : novalue,
;   1782  1                     QIO_UNIT : novalue,
;   1783  1                     QIO_FUNC : novalue,
;   1784  1     !MMM                    DUP : NOVALUE,                                  !ZZZ
;   1785  1     !MMM                        DUPWRTDBN : NOVALUE,                        !ZZZ
;   1786  1     !MMM                        DUPREDOBN : NOVALUE,                        !ZZZ
;   1787  1     !MMM                        DUPCOMMAND : NOVALUE,                       !ZZZ
;   1788  1     !MMM                        DUPIDLE : NOVALUE,                          !ZZZ
;   1789  1                     QIO_LBN : novalue,
;   1790  1                     QIO_SIZE : novalue,
```

```
;    1794  1      !MMM                    DUP_COMPARE : NOVALUE,                          !ZZZ
;    1795  1                          IO_RETPKT : novalue,
;    1796  1                              FSET_UPAR : novalue,
;    1797  1                              HARD_ERROR : novalue,
;    1798  1                                  ERR_HRD_RTNE : novalue,
;    1799  1                                  ERR_HRD_RTNE_APT : novalue,
;    1800  1                              UPD_IO_TALLY : novalue,
;    1801  1                                  OVF_CHK : novalue,
;    1802  1                                  ROUND_OUTPUT : novalue,
;    1803  1                              HOST_WRT_CHK,
;    1804  1      !                           ERR_HRD_RTNE : novalue,
;    1805  1      !                           ERR_HRD_RTNE_APT : novalue,
;    1806  1                              SWEEP : novalue,
;    1807  1                                  RPS_REM,
;    1808  1                          DR_RETPKT : novalue,
;    1809  1              AZINTO : L$ISR novalue,
;    1810  1                  AZINT : novalue,
;    1811  1      !               FATAL_ERROR : novalue,
;    1812  1                      POLL_CRING : novalue,
;    1813  1                      POLL_RRING : novalue,
;    1814  1      !MMM                    DUP_RSP  : NOVALUE,
 !ZZZ
;    1815  1                          DISK_RSP : novalue,
;    1816  1                              SEQUEN : novalue,
;    1817  1      !MMM                        SCAN_ERRLOG : novalue,
;    1818  1      !MMM                            ERR_SOFT_RTNE : novalue,
;    1819  1      !MMM                            ERR_SOFT_RTNE_APT : novalue,
;    1820  1      !MMM                            SOFT_ERROR : novalue,
;    1821  1                              DATAGM : novalue,
;    1822  1                                  ERR_SOFT_RTNE : novalue,
;    1823  1                                  ERR_SOFT_RTNE_APT : novalue,
;    1824  1                                  SOFT_ERROR : novalue;
;    1825  1
;    1826  1      external
;    1827  1          CST : blockvector [MAX_CTLR, CST_LEN, word] field (CST_FIELDS),
;    1828  1                              ! RUN-TIME CONTROLLER STATUS TABLES
;    1829  1          CST_ADDR : ref block [CST_LEN, word] field (CST_FIELDS),
;    1830  1                              ! CONTROLLER STATUS TABLE ADDRESS OF "CURRENT" CONTROLLER
;    1831  1          DCT : blockvector [MAX_CTLR, DCT_LEN, word] field (DCT_FIELDS),
;    1832  1                              ! DRIVER CONTROLLER TABLES
;    1833  1          DCT_ADDR : ref block [DCT_LEN, word] field (DCT_FIELDS),
;    1834  1                              ! ADDRESS OF "CURRENT" DRIVER CONTROLLER TABLE
;    1835  1          RDRX_ADDR : ref rdrx field (RC_REG),
;    1836  1                              ! DEVICE ADDRESS OF "CURRENT" CONTROLLER
;    1837  1          IRDRX_ADDR : ref rdrx field (RC_REG),
;    1838  1                              ! DEVICE ADDRESS OF INTERRUPTING CONTROLLER
;    1839  1          BST : BLOCKVECTOR [MAX_UNITS, 2, WORD],                             !ZZZ
;    1840  1                              !BLOCK SEQUENCE TABLE FOR SEQUENTIAL LBN (VS    !ZZZ
;    1841  1                              !RANDOM SEEK) MODE                              !ZZZ
;    1842  1          TALLY : vector [MAX_UNITS * TALLY_LEN, word] field (T_FIELDS),
;    1843  1                              ! STATISTICS TABLES
;    1844  1          T_ADDR : ref block [TALLY_LEN, word] field (T_FIELDS),
;    1845  1                              ! ADDRESS OF STATISTICS TABLE (TALLY) FOR CURRENT UNIT
;    1846  1      !MMM    DUPPKT : BLOCK [257, WORD] FIELD (DP_FIELDS),   !BUFFER FOR DUP  ZZZ
```

```
;    1847  1      !MMM                        !INFO FROM RECEIVE AND SEND COMMANDS                ZZZ
;    1848  1          TRK_SGN : VECTOR [MAX_UNITS, BYTE, SIGNED], !CURRENT TK DIRECTION       ZZZ
;    1849  1          RDM_CNT : WORD,     !NO. OF RANDOM NOS.             KEEP\\            ZZZ
;    1850  1          RANDOM : VECTOR [RDM_LEN, WORD],    !RAND NO TABLE TOGET//HER           ZZZ
;    1851  1          C_ERR_TBL : blockvector [MAX_CTLR, C_ERR_LEN, word] field (C_ERR FIELDS),
;    1852  1                              ! STATISTICS TABLE FOR CONTROLLER ERRORS
;    1853  1          MSCP_PKT : blockvector [PKT_CNT, PKT_LEN, word] field (PKT_FIELDS),
;    1854  1                              ! MSCP PACKET POOL
;    1855  1          IPKT_ADDR : ref block [PKT_LEN, word] field (PKT_FIELDS),
;    1856  1                              ! ADDRESS OF AN MSCP PACKET (INTERRUPT PROCESSING)
;    1857  1          PKT_USE : vector [PKT_CNT, byte, signed],
;    1858  1                              ! MSCP PACKET POOL ALLOCATION TABLE
;    1859  1          RETPKT : blockvector [RP_CNT, RP_LEN, word] field (RP_FIELDS),
;    1860  1                              ! RETURN PACKET POOL
;    1861  1          RP_USE : vector [RP_CNT, byte, signed],
;    1862  1                              ! RETURN PACKET POOL ALLOCATION TABLE
;    1863  1          RP_INDX : word,     ! CURRENT RETURN PACKET INDEX
;    1864  1          RP_ADDR : ref block [RP_LEN, word] field (RP_FIELDS),
;    1865  1                              ! CURRENT RETURN PACKET ADDRESS
;    1866  1          ELOG_PKT : blockvector [EP_CNT + 1, EP_LEN, word] field (EP_FIELDS),
;    1867  1                              ! ERROR-LOG PACKET SAVE AREA
;    1868  1          BUFF_ADDR : vector [MAX_BUF_CNT],                   ! TABLE OF I/O BUFFER DESCRIPTORS
;    1869  1          BUFF_OWN : vector [MAX_BUF_CNT, byte, signed],      ! I/O BUFFER OWNERSHIP (CONTROLLER NUMBER)
;    1870  1          IODQ : vector [IODQ_LEN, byte],                     ! I/O DONE QUEUE - CIRCULAR QUEUE OF RETPKT INDECES
;    1871  1          IODQ_IN : word,                                     ! I/O DONE QUEUE IN POINTER
;    1872  1          IODQ_OUT : word,                                    ! I/O DONE QUEUE OUT POINTER
;    1873  1          ENTRY_REASON : byte,                                ! CURRENT OPERATOR COMMAND
;    1874  1          EOP_FLAG : byte,                                    ! END-OF-PASS FLAG
;    1875  1          DUP_FLAGS : WORD,                                   !DUP FLAGS                                  ZZZ
;    1876  1          CCTLR : word,                                       ! NUMBER OF "CURRENT" CONTROLLER
;    1877  1          CDISK : word,                                       ! CURRENT DISK ADDRESS (RD/RX DISK NUMBER)
;    1878  1          CUOFF : word,                                       ! CURRENT UNIT CST OFFSET
;    1879  1          CTLR_CNT : word,                                    ! TOTAL NUMBER OF CONFIGURED CONTROLLERS
;    1880  1          DUR : vector [MAX_UNITS, byte],                     ! DROP UNIT REASON
;    1881  1          QIO : vector [MAX_CTLR, byte],                      ! NUMBER OF OUTSTANDING QIOs PER CONTROLLER
;    1882  1          FREE_MEM_ADDR,                                      ! START OF FREE MEMORY
;    1883  1          BYTS_PER_QIO : word,                                ! SIZE (BYTES) OF AN I/O BUFFER
;    1884  1          ST_CODE : word,                                     ! CURRENT STATUS CODE
;    1885  1          SB_CODE : word,                                     ! CURRENT SUB-CODE
;    1886  1          STEP : word,                                        ! CURRENT STEP IN HARD_INIT
;    1887  1          OF_RC : signed word,                                ! OFFSET (0 OR 2) TO READ IP OR SA
;    1888  1          SA_REG : word,                                      ! STORAGE FOR SA REGISTER READS AND WRITES
;    1889  1          CMD_TIME : word,                                    ! COMMAND TIMEOUT VALUE (IN SECONDS)
;    1890  1          NEX : word,                                         ! NON-EXISTENT MEMORY TRAP INDICATOR
;    1891  1          CRN_LOW : word,                                     ! COMMAND REF NUMBER OF LAST COMMAND SENT
;    1892  1          CRN_HIGH : word,                                    ! COMMAND REF NUMBER (HI ORDER)
;    1893  1          TEMP1 : WORD,                                       !TEMPORARY STORAGE WD USED IN BGNCLN            !ZZZ
;    1894  1          TEMP2 : WORD,                                       !TEMPORARY STORAGE WD USED IN BGNCLN            !ZZZ
;    1895  1          CREDIT_BAL : word,                                  ! CREDIT BALANCE
;    1896  1          NEXT_PKT_USE : byte,                                ! POINTER TO NEXT ENTRY IN PKT_USE TABLE
;    1897  1          HOURS : byte,                                       ! TIME OF DAY (HOURS)
;    1898  1          MINUTES : byte,                                     ! TIME OF DAY (MINUTES)
;    1899  1          CLK_TICKS : word,                                   ! TIME OF DAY (LINE-CLOCK TICKS)
```

```
;    1900  1          CLK_PRESENT : b,te,                          ! FLAG INDICATES IF LINE-CLOCK PRESENT
;    1901  1          HOE_FLAG : byte,                             ! FLAG INDICATES IF "HALT ON ERROR" FLAG SET
;    1902  1          FORCED_ERROR : byte,                         ! "FORCED ERROR" DETECTED IN LAST READ
;    1903  1          FER0_LBN : word,                             !LO LBN ADR OF THE "FORCED ERROR" BLOCK                  ZZZ
;    1904  1          FER1_LBN : word,                             !HI LBN ADR OF THE "FORCED ERROR" BLOCK                  ZZZ
;    1905  1      !   FER_LBN : word,                              ! LBN OF THE "FORCED ERROR" BLOCK                        ZZZ
;    1906  1          FER_BC : word,                               ! BYTE COUNT OF THE "FORCED ERROR" BLOCK
;    1907  1          INIT_OCCURED : byte,                         ! EXERCISER INITIALIZATION COMPLETE
;    1908  1          ADDR_VECT_OK : byte,                         ! FLAG INDICATES IF ADDRESS/VECTOR TEST PASSED
;    1909  1
;    1910  1          TYPER : VECTOR [MAX_UNITS, WORD],    !READ I/O COUNTER                    ZZZ MMM
;    1911  1          TYPEW : VECTOR [MAX_UNITS, WORD],    !WRITE I/O COUNTER                   ZZZ MMM
;    1912  1          BAL_IN_PROGRESS : VECTOR [MAX_UNITS, WORD], !FLAG SET TO BALANCE I/O TYPES      ZZZ MMM
;    1913  1          FORCE_WR : VECTOR [MAX_UNITS, WORD],          !FLAG TO ISSUE MORE WRITES WHEN BALANCING MMM
;    1914  1          CSR_MEM : WORD,                               !MMM
;    1915  1          CSR_ADD : WORD,                               !MMM
;    1916  1          TST_PAR : WORD,                               !MMM
;    1917  1          MAN_TST : WORD,                               !MMM
;    1918  1      !MMM    S_PATTERN : WORD,                        !PATTERN WRITTEN TO DBNS            ZZZ
;    1919  1      !MMM    S_DUPPKT : WORD,                     !DBN BYTE COUNTER                  ZZZ
;    1920  1          P_INDEX : SIGNED WORD,               !CURRENT MESSAGE PACKET INDEX       ZZZ
;    1921  1          RD_COUNT : WORD,                     ! NUMBER OF WINCHESTER UNITS        ZZZ
;    1922  1          BRLEVEL : word,                      ! CURRENT DEVICE'S BR LEVEL         ZZZ
;    1923  1          D_FAIL : BYTE,                       !SIGNIFIES DUP TYPE ERROR           ZZZ
;    1924  1          DBM12,
;    1925  1          DBM18,
;    1926  1          DBM19,
;    1927  1          DBM20,
;    1928  1          DBM21,
;    1929  1          DBM22,
;    1930  1          DBM23,
;    1931  1          DBM25,
;    1932  1          DBM26,
;    1933  1          DBM27,
;    1934  1          DBM29,
;    1935  1          DBM108,
;    1936  1          DBM109,
;    1937  1          DBM111,
;    1938  1          DBM112,
;    1939  1          DBM120,
;    1940  1          DBM121,
;    1941  1          DBM123,                                                  !MMM
;    1942  1          DBM125,                                                  !MMM
;    1943  1          DBM126,                                                  !MMM
;    1944  1          DBM127,                                                  !MMM
;    1945  1          DBM128,                                                  !MMM
;    1946  1          EH_0,                                                    !ZZZ
;    1947  1          EH_1,                                                    !ZZZ
;    1948  1          EH_2,                                                    !ZZZ
;    1949  1          EH_3,                                                    !ZZZ
;    1950  1          EH_4,                                                    !ZZZ
;    1951  1          EH_5,                                                    !ZZZ
;    1952  1          EH_6,                                                    !ZZZ
```

```
;    1953  1          EH_7,                                                !ZZZ
;    1954  1          EH_8,                                                !ZZZ
;    1955  1          EH_9,                                                !ZZZ
;    1956  1          EH_10,                                               !ZZZ
;    1957  1          EH_12,                                               !ZZZ
;    1958  1          EH_13,                                               !ZZZ
;    1959  1          MSG_02,
;    1960  1          MSG_03,
;    1961  1          EGS_02,
;    1962  1          EGD_10,
;    1963  1          EGD_11,
;    1964  1          EGD_12,
;    1965  1          EGD_13,
;    1966  1          EGD_14,
;    1967  1          EGD_15,
;    1968  1          EGD_16,
;    1969  1          EGD_17,
;    1970  1          EGD_18,
;    1971  1          EGD_19,
;    1972  1          EGD_20,
;    1973  1          EGD_21,
;    1974  1          EGD_22,
;    1975  1          EGD_23,
;    1976  1          EGD_24,
;    1977  1          EGH_30,
;    1978  1          DF_MSG,
;    1979  1          HRD_MSG,
;    1980  1          SFT_MSG,
;    1981  1          HRD_SUB,
;    1982  1          CRLF,
;    1983  1          SWP_ERROR : word,                    ! HARD ERROR LIMIT FOR DROPPING UNIT
;    1984  1          SWP_XFER : word,                     ! TRANSFER LIMIT FOR DROPPING UNIT
;    1985  1          SWP_FLAGS : word,                    ! FLAGS (SEE DOCUMENTATION)
;    1986  1          !MMM DUPROUND  : WORD,                      !DUP TESTING RATIO          ZZZ
;    1987  1          SWP_RAT : word,                      ! RD51/52 OPERATION RATIO
;    1988  1          SWP_DPAT : word,                     ! DATA PATTERN NUMBER
;    1989  1          SWP_UCNT : word,                     ! USER DATA PATTERN COUNT
;    1990  1          SWP_TIME : word,                     ! TIME OF DAY
;    1991  1          SWP_UDPAT : vector [MAX_UDP_CNT, word],  ! USER DATA PATTERN
;    1992  1          L$LUN,
;    1993  1          L$UNIT;
;    1994  1
;    1995  1      psect
;    1996  1          own = $GGG$(read, nowrite, execute, local, concatenate);
;    1997  1
;    1998  1      own
;    1999  1          COMM_AREA : blockvector [MAX_CTLR, COMM_LEN, word] field (COM_FIELDS),
;    2000  1                              ! COMMUNICATIONS AREA BETWEEN HOST AND AZTEC CONTROLLERS
;    2001  1      !!ZZZ    BST : vector [MAX_UNITS, word, signed],
;    2002  1                              ! BLOCK SEQUENCE TABLE FOR SEQUENTIAL LBN (VS. RANDOM SEEK) MODE
;    2003  1          DPST : vector [MAX_UNITS, byte],         ! DATA PATTERN SEQUENCE TABLE
;    2004  1          MAX_LBN : vector [MAX_UNITS, word],      ! LARGEST LBN ALLOWED
;    2005  1          STORAGE : vector [MAX_UNITS, word],      ! DUMMY STORAGE
```

```
;    2006  1          ICOM_ADDR : ref block [COMM_LEN, word] field (COM_FIELDS),
;    2007  1                              ! ADDRESS OF INTERRUPTING CONTROLLER'S COMMUNICATION AREA
;    2008  1          ICST_ADDR : ref block [CST_LEN, word] field (CST_FIELDS),
;    2009  1                              ! ADDRESS OF INTERRUPTING CONTROLLER'S CST
;    2010  1          IDCT_ADDR : ref block [DCT_LEN, word] field (DCT_FIELDS),
;    2011  1                              ! ADDRESS OF INTERRUPTING CONTROLLER'S DCT
;    2012  1          INT_ADDR : vector [MAX_CTLR] initial (AZINTO %(, AZINT1, AZINT2, AZINT3)%),
;    2013  1                              ! INTERRUPT SERVICE ROUTINE ADDRESS TABLE
;    2014  1      !!ZZZ    RDM_CNT : word initial (RDM_LEN),                ! NUMBER OF RANDOM NUMBERS  \ KEEP
;    2015  1      !!ZZZ    RANDOM : vector [RDM_LEN, word],                 ! RANDOM NUMBER TABLE       / TOGETHER
;    2016  1          ICTLR : word,                                  ! INTERRUPTING CONTROLLING NUMBER
;    2017  1          EL_FLUSH : vector [MAX_CTLR, word],            ! STOP QIO TO PROCESS ERROR LOGS    MMM
;    2018  1          MX1 : signed word,                             ! MSCP PKT INDEX FOR FIRST QIO
;    2019  1          MX2 : signed word,                             ! MSCP PKT INDEX FOR SECOND QIO
;    2020  1          MAD1 : ref block [PKT_LEN, word] field (PKT_FIELDS),
;    2021  1                              ! ADDRESS OF MSCP PACKET FOR FIRST QIO
;    2022  1          MAD2 : ref block [PKT_LEN, word] field (PKT_FIELDS),
;    2023  1                              ! ADDRESS OF MSCP PACKET FOR SECOND QIO
;    2024  1          LAST_PKT : blockvector [MAX_CTLR, LAST_PKT_LEN, word] field (LAST_PKT_FIELDS),
;    2025  1                              ! SAVE AREA FOR INFO ABOUT LAST RESPONSE PACKET
;    2026  1
;    2027  1          RNDY0 : WORD,                                          !32-BIT RANDOM PATTERN LO WD            ZZZ
;    2028  1          RNDY1 : WORD,                                          !32-BIT RANDOM PATTERN HI WD            ZZZ
;    2029  1          FRAME_CNT : WORD,                                      !WHICH 7-BIT FRAME OF R_STRING IN USE   ZZZ
;    2030  1          R_STRING: WORD,                                        !BITS USED IN PATTERN SELECTION         ZZZ
;    2031  1          RNDYIN :  vector [9, word] initial (%o'127102',        !NINE SEED WORDS                        ZZZ
;    2032  1                    %o'143662', %o'036750', %o'121624', %o'023267',                                     !ZZZ
;    2033  1                    %o'036561', %o'063714', %o'560255', %o'134230'),                                    !ZZZ
;    2034  1          RNDMS0 :  vector [8, word] initial (%o'17',            !MASK FOR LOW WORD                      ZZZ
;    2035  1                    %o'377', %o'7777', %o'177777', %o'177777',                                          !ZZZ
;    2036  1                    %o'177777', %o'177777', %o'177777'),                                                !ZZZ
;    2037  1          RNDMS1 :  vector [8, word] initial (%o'0000',          !MASK FOR HIGH WORD                     ZZZ
;    2038  1                    %o'0000', %o'0000', %o'0000', %o'17',                                               !ZZZ
;    2039  1                    %o'377', %o'7777', %o'177777'),                                                     !ZZZ
;    2040  1
;    2041  1          PAT02 : vector [2] initial (1,                                 ! PATTERN 2
;    2042  1                  %o'000000'),
;    2043  1          PAT03 : vector [2] initial (1,                                 ! PATTERN 3
;    2044  1                  %o'177777'),
;    2045  1          PAT04 : vector [2] initial (1,                                 ! PATTERN 4
;    2046  1                  %o'105613'),
;    2047  1          PAT05 : vector [2] initial (1,                                 ! PATTERN 5
;    2048  1                  %o'031463'),
;    2049  1          PAT06 : vector [2] initial (1,                                 ! PATTERN 6
;    2050  1                  %o'030221'),
;    2051  1          PAT07 : vector [17] initial (16,                               ! PATTERN 7
;    2052  1                  %o'000001', %o'000003', %o'000007', %o'000017',
;    2053  1                  %o'000037', %o'000077', %o'000177', %o'000377',
;    2054  1                  %o'000777', %o'001777', %o'003777', %o'007777',
;    2055  1                  %o'017777', %o'037777', %o'077777', %o'177777'),
;    2056  1          PAT08 : vector [17] initial (16,                               ! PATTERN 8
;    2057  1                  %o'177776', %o'177774', %o'177770', %o'177760',
;    2058  1                  %o'177740', %o'177700', %o'177600', %o'177400',
```

```
;    2059  1                %o'177000', %o'176000', %o'174000', %o'170000',
;    2060  1                %o'160000', %o'140000', %o'100000', %o'000000'),
;    2061  1          PAT09 : vector [17] initial (16,                                ! PATTERN 9
;    2062  1                rep 3 of (%o'000000'), rep 3 of (%o'177777'),
;    2063  1                rep 2 of (%o'000000'), rep 2 of (%o'177777'),
;    2064  1                %o'000000', %o'177777', %o'000000', %o'177777',
;    2065  1                %o'000000', %o'177777'),
;    2066  1          PAT10 : vector [2] initial (1,                                  ! PATTERN 10
;    2067  1                %o'133331'),
;    2068  1          PAT11 : vector [17] initial (16,                                ! PATTERN 11
;    2069  1                rep 3 of (%o'052525'), rep 3 of (%o'125252'),
;    2070  1                rep 2 of (%o'052525'), rep 2 of (%o'125252'),
;    2071  1                %o'052525', %o'125252', %o'052525', %o'125252',
;    2072  1                %o'052525', %o'125252'),
;    2073  1          PAT12 : vector [21] initial (20,                                ! PATTERN 12
;    2074  1                rep 3 of (%o'026455'), rep 3 of (%o'151322'),
;    2075  1                rep 2 of (%o'026455'), rep 2 of (%o'151322'),
;    2076  1                rep 2 of (%o'026455'),
;    2077  1                %o'151322', %o'026455', %o'151322', %o'026455',
;    2078  1                %o'151322', %o'026455', %o'151322', %o'026455'),
;    2079  1          PAT13 : vector [2] initial (1,                                  ! PATTERN 13
;    2080  1                %o'066666'),
;    2081  1          PAT14 : vector [17] initial (16,                                ! PATTERN 14
;    2082  1                %o'000001', %o'000002', %o'000004', %o'000010',
;    2083  1                %o'000020', %o'000040', %o'000100', %o'000200',
;    2084  1                %o'000400', %o'001000', %o'002000', %o'004000',
;    2085  1                %o'010000', %o'020000', %o'040000', %o'100000'),
;    2086  1          PAT15 : vector [17] initial (16,                                ! PATTERN 15
;    2087  1                %o'177776', %o'177775', %o'177773', %o'177767',
;    2088  1                %o'177757', %o'177737', %o'177677', %o'177577',
;    2089  1                %o'177377', %o'176777', %o'175777', %o'173777',
;    2090  1                %o'167777', %o'157777', %o'137777', %o'077777'),
;    2091  1          PAT16 : vector [17] initial (16,                                ! PATTERN 16
;    2092  1                rep 3 of (%o'133331'), rep 3 of (%o'155554'),
;    2093  1                rep 2 of (%o'133331'), rep 2 of (%o'155554'),
;    2094  1                %o'133331', %o'155554', %o'133331', %o'155554',
;    2095  1                %o'133331', %o'155554'),
;    2096  1          PAT17 : vector [22] initial (21,                                ! PATTERN 17
;    2097  1                %o'000000', rep 2 of (%o'106466'),
;    2098  1                rep 3 of (%o'071311'), rep 4 of (%o'106466'),
;    2099  1                rep 5 of (%o'071311'), rep 6 of (%o'106466')),
;    2100  1          PAT18 : vector [22] initial (21,                                ! PATTERN 18
;    2101  1                %o'106466', %o'000000', %o'071311',
;    2102  1                rep 3 of (%o'106466'), rep 4 of (%o'071311'),
;    2103  1                rep 5 of (%o'106466'), rep 6 of (%o'071311')),
;    2104  1          PAT19 : vector [22] initial (21,                                ! PATTERN 19
;    2105  1                %o'000000', rep 2 of (%o'134631'),
;    2106  1                rep 3 of (%o'043146'), rep 4 of (%o'134631'),
;    2107  1                rep 5 of (%o'043146'), rep 6 of (%o'134631')),
;    2108  1          PAT20 : vector [22] initial (21,                                ! PATTERN 20
;    2109  1                %o'134631', %o'000000', %o'043146',
;    2110  1                rep 3 of (%o'134631'), rep 4 of (%o'043146'),
;    2111  1                rep 5 of (%o'134631'), rep 6 of (%o'043146')),
```

```
;  2112  1          PAT21 : vector [2] initial (1,                          ! PATTERN 21
;  2113  1                  # '000000'),                                    !    (LBN)
;  2114  1          DPA_TBL : vector [DP_CNT] initial                       ! DATA PATTERN ADDRESS TABLE
;  2115  1                    (RDM_CNT, PAT02, PAT03, PAT04, PAT05,
;  2116  1                     PAT06, PAT07, PAT08, PAT09, PAT10, PAT11,
;  2117  1                     PAT12, PAT13, PAT14, PAT15, PAT16, PAT17,
;  2118  1                     PAT18, PAT19, PAT20, PAT21),
;  2119  1          BST_CNT : word initial (0),                 ! CURRENT SEQUENTIAL BLOCK COUNT
;  2120  1          BST_DEV : word initial (0),                 ! CURRENT SEQUENTIAL BLOCK DEVICE
;  2121  1          CURRENT_VECTOR : word,                      ! CURRENT DEVICE'S VECTOR ADDRESS
;  2122  1      !ZZZ    BRLEVEL : word,                         ! CURRENT DEVICE'S BR LEVEL              ZZZ
;  2123  1      !MMM    DUOFF   : WORD,                         !DUP OFFSET INTO CST                     ZZZ
;  2124  1          DRS_START,                                  ! START OF THE SUPERVISOR
;  2125  1          PAR_TSD : word,                             !MMM
;  2126  1          APT_MODE : byte initial (byte (FALSE)),     ! FLAG SET IF EXERCISER RUNNING UNDER APT
;  2127  1          MAIL_BOX_TESTNUM,                           ! ADDRESS OF TEST NUMBER LOCATION IN APT MAIL-BOX
;  2128  1          MAIL_BOX_SUBTST,                            ! ADDRESS OF SUB-TEST NUMBER LOCATION IN APT MAIL BOX
;  2129  1          COMPARE_DATA : byte,                        ! FLAG CLEARED TO BYPASS HOST COMPARES
;  2130  1          DRS_FLAGS: word,                            ! FLAGS USED IN START/RESTART OF THE EXERCISER
;  2131  1          RD_MAX_SEQ_CNT : word,                      ! COUNT USED IN SEQUENTIAL ACCESS OPERATIONS
;  2132  1          RX_MAX_SEQ_CNT : word;                      !
;  2133  1
;  2134  1      external routine
;  2135  1          NEX_TRAP : L$ISR novalue,
;  2136  1          PARITY : novalue,                           !MMM
;  2137  1          TIME : L$ISR novalue,
;  2138  1          SET_CPAR : novalue,
;  2139  1          SET_UPAR : novalue,
;  2140  1          OUT_IODQ,
;  2141  1          IN_IODQ : novalue,
;  2142  1          GET_PKT,
;  2143  1          PUT_PKT : novalue,
;  2144  1          GET_RETPKT,
;  2145  1          PUT_RETPKT : novalue,
;  2146  1          GET_IO_BUFF : novalue,
;  2147  1          PUT_IO_BUFF : novalue,
;  2148  1          PUTA_BUFF : novalue,
;  2149  1          SEND,
;  2150  1          WAIT : novalue,
;  2151  1          MODULAS,                                                !ZZZ
;  2152  1          DROP_CTLR : novalue,
;  2153  1          DRV_CTLERR : novalue,
;  2154  1          EMS_R2 : novalue,                                       !MMM
;  2155  1          EMS_R1 : novalue,                                       !MMM
;  2156  1          EMS_EL : novalue,
;  2157  1          EMS_CMP : novalue,
;  2158  1          EMS_ERR : novalue,
;  2159  1          EMS_10 : novalue,
;  2160  1          EMS_12 : novalue,
;  2161  1          EMS_13 : novalue,
;  2162  1          EMS_14 : novalue,
;  2163  1          EMS_18 : novalue,
;  2164  1          EMS_21 : novalue,
```

```
;   2165  1          !MMMEMS_22 : NOVALUE,                                   !ZZZ
;   2166  1          EMS_24 : novalue,
;   2167  1          EMS_30 : novalue;
```

```
;    2168  1     %sbttl 'TEST SECTION'
;    2169  1
;    2170  1
;    2171  1     !+
;    2172  1     !       THIS SECTION CONTAINS THE TOP LEVEL TEST CODE FOR THE RDRX EXERCISER.
;    2173  1     !       THE EXERCISER CONSISTS OF ONE TEST WHICH IS SUBDIVIDED INTO A NUMBER OF
;    2174  1     !       SUBTESTS. ALL SUBTESTS ARE DECLARED WITHIN THIS BLOCK.
;    2175  1     !-
;    2176  1
;    2177  1
;    2178  3     BGNTST;
;    2179  3
;    2180  3     local
;    2181  3         DUMMY_0 : word,
;    2182  3         DUMMY_1 : word;
;    2183  3
;    2184  3
;    2185  3     EOP_FLAG = TRUE;                                        ! ASSUME NO UNIT AVAILABLE
;    2186  3     COMPARE_DATA = TRUE;                                    ! ALLOW HOST COMAPRES IF ASKED FOR
;    2187  3     DUP_FLAGS = .DUP_FLAGS AND (NOT SWP_DINT);              !CLEAR DUP INIT FLAG     ZZZ
;    2188  3     HOE_FLAG = FALSE;                                       ! ASSUME 'HOE' FLAG NOT SET
;    2189  3     FORCED_ERROR = FALSE;                                   ! INITIALIZE "FORCED ERROR" FLAG
;    2190  3
;    2191  3
;    2192  3     incr I from 0 to PKT_CNT - 1 do                         ! INITIALIZE PACKET AREA
;    2193  4         begin
;    2194  4
;    2195  4         incr J from 0 to PKT_LEN - 1 do
;    2196  4             MSCP_PKT [.I, .J, 0, 16, 0] = 0;
;    2197  4
;    2198  4         MSCP_PKT [.I, RSP_RECEIVED] = FALSE;
;    2199  3         end;
;    2200  3
;    2201  3     incr I from 0 to RP_CNT   1 do                          ! INITIALIZE RESPONSE SAVE AREA
;    2202  3         incr J from 0 to RP_LEN - 1 do
;    2203  3             RETPKT [.I, .J, 0, 16, 0] = 0;
;    2204  3
;    2205  3     incr I from 0 to EP_CNT do                              ! INITIALIZE ERROR LOG SAVE AREA
;    2206  4         begin
;    2207  4
;    2208  4         incr J from 0 to EP_LEN - 1 do
;    2209  4             ELOG_PKT [.I, .J, 0, 16, 0] = 0;
;    2210  4
;    2211  4         ELOG_PKT [.I, EL CONTENTS] = EMPTY;
;    2212  3         end;
;    2213  3
;    2214  4     if BIT_TST (SWP_FLAGS, SWF_CWC)                         ' NO SIMULTANEOUS CNTR/HOST WRIE CHECKS
;    2215  3     then
;    2216  3         SWP_FLAGS = .SWP_FLAGS and (not SWF_HWC);
;    2217  3
;    2218  4     if BIT_TST (SWP_FLAGS, SWF_RDM)                         ! NO SIMULTANEOUS RANDOM/SEQUENTIAL SELECTS
;    2219  3     then
;    2220  3         SWP_FLAGS = .SWP_FLAGS and (not SWF_SEQ);
```

```
;    2221  3
;    2222  3      if not .INIT_OCCURED
;    2223  3      then
;    2224  4          begin
;    2225  4          DRS_START = .FREE_MEM_ADDR + 2 + (..FREE_MEM_ADDR & 2);          ! START OF SUPERVISOR
;    2226  4
;    2227  4
;    2228  4
;    2229  4      !   THE FOLLOWING DETERMINES WHETHER THE TEST IS TO BE RUN IN APT MODE:                              !Z
ZZ
;    2230  4                                                                                                          !Z
ZZ
;    2231  5      IF BIT_TST (SWP_FLAGS, SWF_APT)                                 !IF APT                             !Z
ZZ
;    2232  4          then
;    2233  5              begin
;    2234  5              APT_MODE = TRUE;
;    2235  5              MAIL_BOX_TESTNUM = .DRS_START + %o'62' + %o'6' ;            ! APT MAIL BOX IS OFFSET AT OCTAL 62 FROM
;    2236  5              MAIL_BOX_SUBTST = .DRS_START + %o'62' + %o'4' ;             ! BEGINNING OF SUPERVISOR
;    2237  4              end;
;    2238  4
;    2239  4
;    2240  4          NEX = FALSE;                                                    ! CHECK IF LINE-CLOCK PRESENT
;    2241  4          CLK_PRESENT = FALSE;                                            !
;    2242  4          SETVEC (4, NEX_TRAP, PRIO7);                                    ! SET TRAP CATCHER ADDRESS
;    2243  4          DUMMY_0 = .LINE_CLOCK;                                          ! TRY TO ADDRESS THE CLOCK
;    2244  4          DUMMY_1 = 0;                                                    ! DUMMY INSTRUCTION
;    2245  4          CLRVEC (4);                                                     ! RETURN LOC 4 TO THE SUPERVISOR
;    2246  4
;    2247  4
;    2248  4          if not .NEX
;    2249  4          then
;    2250  5              begin
;    2251  5              CLK_PRESENT = TRUE;                                         ! SET FLAG IF CLOCK PRESENT
;    2252  5              CLK_TICKS = 0;                                              ! INITIALIZE THE LINE CLOCK TICK COUNT
;    2253  5              HOURS = .SWP_TIME / 100;                                    ! TIME OF DAY (HOURS)
;    2254  5              MINUTES = (.SWP_TIME mod 100) + 1;                          ! TIME OF DAY (MINUTES)
;    2255  5
;    2256  5              while .MINUTES gequ 60 do                                   ! NORMALIZE MINUTES
;    2257  6                  begin
;    2258  6                  MINUTES = .MINUTES   60;
;    2259  6                  HOURS = .HOURS + 1;
;    2260  5                  end;
;    2261  5
;    2262  5              HOURS = .HOURS mod 24;                                      ! NORMALIZE HOURS
;    2263  4              end;
;    2264  4
;    2265  4          NEX = FALSE;                                                    ! CHECK IF MEMORY CSR PRESENT MMM
;    2266  4          CSR_MEM = FALSE;                                                ! MMM
;    2267  4          SETVEC (4, NEX_TRAP, PRIO7);                                    ! SET TRAP CATCHER ADDRESS
;    2268  4          DUMMY_0 = ..CSR_ADD;                                            ! TRY TO ADDRESS THE MEMORY CSR MMM
;    2269  4          DUMMY_1 = 0;                                                    ! DUMMY INSTRUCTION MMM
;    2270  4          CLRVEC (4);                                                     ! RETURN LOC 4 TO THE SUPERVISOR MMM
;    2271  4
;    2272  4
;    2273  4          if not .NEX                                                     ! MMM
```

```
;    2274  4          then                                                                    ! MMM
;    2275  5              begin                                                               ! MMM
;    2276  5              CSR_MEM = TRUE;                                                     ! SET FLAG IF CSR PRESENT  MMM
;    2277  4              end;                                                                ! MMM
;    2278  4
;    2279  3          end;
;    2280  3
;    2281  3
;    2282  3      if .CLK_PRESENT
;    2283  3      then
;    2284  4          begin
;    2285  4          SETVEC (%o'100', TIME, PRI06);                                          ! LINE CLOCK VECTOR
;    2286  4          LINE_CLOCK = BIT6;                                                      ! START THE CLOCK
;    2287  3          end;
;    2288  3
;    2289  3      if .CSR_MEM and .TST_PAR                                                    ! MEMORY CSR PRESENT AND MMM
;    2290  3      then                                                                        ! ENABLE MEMORY PARITY REQUESTED MMM
;    2291  4          begin                                                                   ! THEN ENABLE MEMORY PARITY MMM
;    2292  4          SETVEC (%o'114', PARITY, PRI07);                                        ! MEMORY PARITY VECTOR MMM
;    2293  4           CSR_ADD = %o'1';                                                       ! ENABLE MEMORY PARITY MMM
;    2294  3          end;
;    2295  3
;    2296  3      RFLAGS (DRS_FLAGS);                                                         ! READ DRS FLAGS INTO LOC DRS_FLAGS
;    2297  3
;    2298  3      if BIT_TST (DRS_FLAGS, HOE) eql HOE
;    2299  3      then
;    2300  3          HOE_FLAG = TRUE;                                                        ! SET FLAG IF  HOE' SET
;    2301  3
;    2302  3
;    2303  3      INIT_TEST ();                                                               ! INITIALIZE TEST ENVIRONMENT
;    2304  3
;    2305  3      incr CTLR from 0 to (MAX_CTLR - 1) do                                       ! FOR EVERY CONTROLLER
;    2306  3
;    2307  3          if (.CST [.CTLR, STATE] eql ONLINE) and                                 ! IF CONTROLLER ONLINE
;    2308  3             (.DCT [.CTLR, STAT] eql ONLINE) and
;    2309  4             (.CST [.CTLR, U_CNT] gequ 0)
;    2310  3          then
;    2311  3              incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR   1) * UNIT_SIZE + 4) by UNIT_SIZE do
;    2312  3
;    2313  3                  if .CST [.CTLR, .OFFSET + OF_DATA, D_STAT] eql ONLINE           ! IF AT LEAST ONE UNIT ALIVE
;    2314  3                  then
;    2315  4                      begin
;    2316  4                      EOP_FLAG = FALSE;                                           ! NOT END OF PASS
;    2317  4                      exitloop;
;    2318  3                      end;
;    2319  3
;    2320  3      if not .EOP_FLAG
;    2321  3      then
;    2322  3          MULTI_DRIVE ();                                                         ! RUN MULTI DRIVE TEST
;    2323  1      ENDTST;
```

```
                                        .IDENT  /V02.3/
                                        .ENABL  AMA


000000                                  .PSECT  $GGG$,  RO
000000                          COMM.AREA:
                                        .BLKW   24
000050                          DPST:   .BLKW   2
000054                          MAX.LBN:.BLKW   4
000064                          STORAGE:.BLKW   4
000074                          ICOM.ADDR:
                                        .BLKW   1
000076                          ICST.ADDR:
                                        .BLKW   1
000100                          IDCT.ADDR:
                                        .BLKW   1
000102  000000V                 INT.ADDR:
                                        .WORD   AZINTO
000104                          ICTLR:  .BLKW   1
000106                          EL.FLUSH:
                                        .BLKW   1
000110                          MX1:    .BLKW   1
000112                          MX2:    .BLKW   1
000114                          MAD1:   .BLKW   1
000116                          MAD2:   .BLKW   1
000120                          LAST.PKT:
                                        .BLKW   3
000126                          RNDY0:  .BLKW   1
000130                          RNDY1:  .BLKW   1
000132                          FRAME.CNT:
                                        .BLKW   1
000134                          R.STRING:
                                        .BLKW   1
000136  127102                  RNDYIN: .WORD   -50676
000140  143662                          .WORD   -34116
000142  036750                          .WORD   36750
000144  121624                          .WORD   -56154
000146  023267                          .WORD   23267
000150  036561                          .WORD   36561
000152  063714                          .WORD   63714
000154  160255                          .WORD   -17523
000156  134230                          .WORD   -43550
000160  000017                  RNDMS0: .WORD   17
000162  000377                          .WORD   377
000164  007777                          .WORD   7777
000166  177777                          .WORD   -1
000170  177777                          .WORD   -1
000172  177777                          .WORD   -1
000174  177777                          .WORD   -1
000176  177777                          .WORD   -1
000200  000000                  RNDMS1: .WORD   0
000202  000000                          .WORD   0
000204  000000                          .WORD   0
```

```
000206  000000                          .WORD   0
000210  000017                          .WORD   17
000212  000377                          .WORD   377
000214  007777                          .WORD   7777
000216  177777                          .WDRD    1
000220  000001                  PAT02:  .WORD   1
000222  000000                          .WORD   0
000224  000001                  PAT03:  .WORD   1
000226  177777                          .WORD   -1
000230  000001                  PAT04:  .WORD   1
000232  105613                          .WORD   -72165
000234  000001                  PAT05:  .WORD   1
000236  031463                          .WORD   31463
000240  000001                  PAT06:  .WORD   1
000242  030221                          .WORD   30221
000244  000020                  PAT07:  .WORD   20
000246  000001                          .WORD   1
000250  000003                          .WORD   3
000252  000007                          .WORD   7
000254  000017                          .WORD   17
000256  000037                          .WORD   37
000260  000077                          .WORD   77
000262  000177                          .WORD   177
000264  000377                          .WORD   377
000266  000777                          .WORD   777
000270  001777                          .WORD   1777
000272  003777                          .WORD   3777
000274  007777                          .WORD   7777
000276  017777                          .WORD   17777
000300  037777                          .WORD   37777
000302  077777                          .WORD   77777
000304  177777                          .WORD    1
000306  000020                  PAT08:  .WORD   20
000310  177776                          .WORD   -2
000312  177774                          .WORD   -4
000314  177770                          .WORD   -10
000316  177760                          .WORD   -20
000320  177740                          .WORD    40
000322  177700                          .WORD   -100
000324  177600                          .WORD   -200
000326  177400                          .WORD   -400
000330  177000                          .WORD   -1000
000332  176000                          .WORD   -2000
000334  174000                          .WORD   -4000
000336  170000                          .WORD   -10000
000340  160000                          .WORD   -20000
000342  140000                          .WORD   -40000
000344  100000                          .WORD   -100000
000346  000000                          .WORD   0
000350  000020                  PAT09:  .WORD   20
000352  000000                          .WORD   0
000354  000000                          .WORD   0
000356  000000                          .WORD   0
```

```
000360  177777                          .WORD    1
000362  177777                          .WORD   -1
000364  177777                          .WORD   -1
000366  000000                          .WORD   0
000370  000000                          .WORD   0
000372  177777                          .WORD    1
000374  177777                          .WORD    1
000376  000000                          .WORD   0
000400  177777                          .WORD   -1
000402  000000                          .WORD   0
000404  177777                          .WORD   -1
000406  000000                          .WORD   0
000410  177777                          .WORD   -1
000412  000001                  PAT10:  .WORD   1
000414  133331                          .WORD   -44447
000416  000020                  PAT11:  .WORD   20
000420  052525                          .WORD   52525
000422  052525                          .WORD   52525
000424  052525                          .WORD   52525
000426  125252                          .WORD   -52526
000430  125252                          .WORD    52526
000432  125252                          .WORD   -52526
000434  052525                          .WORD   52525
000436  052525                          .WORD   52525
000440  125252                          .WORD   -52526
000442  125252                          .WORD    52526
000444  052525                          .WORD   52525
000446  125252                          .WORD    52526
000450  052525                          .WORD   52525
000452  125252                          .WORD   -52526
000454  052525                          .WORD   52525
000456  125252                          .WORD   -52526
000460  000024                  PAT12:  .WORD   24
000462  026455                          .WORD   26455
000464  026455                          .WORD   26455
000466  026455                          .WORD   26455
000470  151322                          .WORD   -26456
000472  151322                          .WORD   -26456
000474  151322                          .WORD   -26456
000476  026455                          .WORD   26455
000500  026455                          .WORD   26455
000502  151322                          .WORD   -26456
000504  151322                          .WORD   -26456
000506  026455                          .WORD   26455
000510  026455                          .WORD   26455
000512  151322                          .WORD   -26456
000514  026455                          .WORD   26455
000516  151322                          .WORD   -26456
000520  026455                          .WORD   26455
000522  151322                          .WORD   -26456
000524  026455                          .WORD   26455
000526  151322                          .WORD   -26456
000530  026455                          .WORD   26455
```

```
000532  000001                  PAT13:  .WORD   1
000534  066666                          .WORD   66666
000536  000020                  PAT14:  .WORD   20
000540  000001                          .WORD   1
000542  000002                          .WORD   2
000544  000004                          .WORD   4
000546  000010                          .WORD   10
000550  000020                          .WORD   20
000552  000040                          .WORD   40
000554  000100                          .WORD   100
000556  000200                          .WORD   200
000560  000400                          .WORD   400
000562  001000                          .WORD   1000
000564  002000                          .WORD   2000
000566  004000                          .WORD   4000
000570  010000                          .WORD   10000
000572  020000                          .WORD   20000
000574  040000                          .WORD   40000
000576  100000                          .WORD   -100000
000600  000020                  PAT15:  .WORD   20
000602  177776                          .WORD   -2
000604  177775                          .WORD   -3
000606  177773                          .WORD   -5
000610  177767                          .WORD    11
000612  177757                          .WORD   -21
000614  177737                          .WORD   -41
000616  177677                          .WORD    101
000620  177577                          .WORD   -201
000622  177377                          .WORD   -401
000624  176777                          .WORD    1001
000626  175777                          .WORD   -2001
000630  173777                          .WORD   -4001
000632  167777                          .WORD   -10001
000634  157777                          .WORD   -20001
000636  137777                          .WORD   -40001
000640  077777                          .WORD   77777
000642  000020                  PAT16:  .WORD   20
000644  133331                          .WORD   -44447
000646  133331                          .WORD   -44447
000650  133331                          .WORD   -44447
000652  155554                          .WORD   -22224
000654  155554                          .WORD   -22224
000656  155554                          .WORD   -22224
000660  133331                          .WORD   -44447
000662  133331                          .WORD   -44447
000664  155554                          .WORD   -22224
000666  155554                          .WORD   -22224
000670  133331                          .WORD   -44447
000672  155554                          .WORD   -22224
000674  133331                          .WORD   -44447
000676  155554                          .WORD   -22224
000700  133331                          .WORD   -44447
000702  155554                          .WORD   -22224
```

```
000704  000025                  PAT17:  .WORD   25
000706  000000                          .WORD   0
000710  106466                          .WORD   -71312
000712  106466                          .WORD   -71312
000714  071311                          .WORD   71311
000716  071311                          .WORD   71311
000720  071311                          .WORD   71311
000722  106466                          .WORD   -71312
000724  106466                          .WORD   -71312
000726  106466                          .WORD   -71312
000730  106466                          .WORD   -71312
000732  071311                          .WORD   71311
000734  071311                          .WORD   71311
000736  071311                          .WORD   71311
000740  071311                          .WORD   71311
000742  071311                          .WORD   71311
000744  106466                          .WORD    71312
000746  106466                          .WORD   -71312
000750  106466                          .WORD   -71312
000752  106466                          .WORD   -71312
000754  106466                          .WORD   -71312
000756  106466                          .WORD   -71312
000760  000025                  PAT18:  .WORD   25
000762  106466                          .WORD   -71312
000764  000000                          .WORD   0
000766  071311                          .WORD   71311
000770  106466                          .WORD   -71312
000772  106466                          .WORD   -71312
000774  106466                          .WORD   -71312
000776  071311                          .WORD   71311
001000  071311                          .WORD   71311
001002  071311                          .WORD   71311
001004  071311                          .WORD   71311
001006  106466                          .WORD   -71312
001010  106466                          .WORD   -71312
001012  106466                          .WORD   -71312
001014  106466                          .WORD   -71312
001016  106466                          .WORD   -71312
001020  071311                          .WORD   71311
001022  071311                          .WORD   71311
001024  071311                          .WORD   71311
001026  071311                          .WORD   71311
001030  071311                          .WORD   71311
001032  071311                          .WORD   71311
001034  000025                  PAT19:  .WORD   25
001036  000000                          .WORD   0
001040  134631                          .WORD   -43147
001042  134631                          .WORD   -43147
001044  043146                          .WORD   43146
001046  043146                          .WORD   43146
001050  043146                          .WORD   43146
001052  134631                          .WORD   -43147
001054  134631                          .WORD   -43147
```

```
001056  134631                          .WORD    43147
001060  134631                          .WORD   -43147
001062  043146                          .WORD   43146
001064  043146                          .WORD   43146
001066  043146                          .WORD   43146
001070  043146                          .WORD   43146
001072  043146                          .WORD   43146
001074  134631                          .WORD   -43147
001076  134631                          .WORD   -43147
001100  134631                          .WORD   -43147
001102  134631                          .WORD   -43147
001104  134631                          .WORD   -43147
001106  134631                          .WORD   -43147
001110  000025                  PAT20:  .WORD   25
001112  134631                          .WORD   -43147
001114  000000                          .WORD   0
001116  043146                          .WORD   43146
001120  134631                          .WORD   -43147
001122  134631                          .WORD   -43147
001124  134631                          .WORD   -43147
001126  043146                          .WORD   43146
001130  043146                          .WORD   43146
001132  043146                          .WORD   43146
001134  043146                          .WORD   43146
001136  134631                          .WORD   -43147
001140  134631                          .WORD   -43147
001142  134631                          .WORD   -43147
001144  134631                          .WORD   -43147
001146  134631                          .WORD   -43147
001150  043146                          .WORD   43146
001152  043146                          .WORD   43146
001154  043146                          .WORD   43146
001156  043146                          .WORD   43146
001160  043146                          .WORD   43146
001162  043146                          .WORD   43146
001164  000001                  PAT21:  .WORD   1
001166  000000                          .WORD   0
001170  000000G                 DPA TBL:.WORD   RDM.CNT
001172  000220'                         .WORD   PAT02
001174  000224'                         .WORD   PAT03
001176  000230'                         .WORD   PAT04
001200  000234'                         .WORD   PAT05
001202  000240'                         .WORD   PAT06
001204  000244'                         .WORD   PAT07
001206  000306'                         .WORD   PAT08
001210  000350'                         .WORD   PAT09
001212  000412'                         .WORD   PAT10
001214  000416'                         .WORD   PAT11
001216  000460'                         .WORD   PAT12
001220  000532'                         .WORD   PAT13
001222  000536                          .WORD   PAT14
001224  000600'                         .WORD   PAT15
001226  000642'                         .WORD   PAT16
```

```
001230  000704'                         .WORD   PAT17
001232  000760'                         .WORD   PAT18
001234  001034'                         .WORD   PAT19
001236  001110'                         .WORD   PAT20
001240  001164'                         .WORD   PAT21
001242  000000                 BST.CNT: .WORD   0
001244  000000                 BST.DEV: .WORD   0
001246                         CURRENT.VECTOR:
                                        .BLKW   1
001250                         DRS.START:
                                        .BLKW   1
001252                         PAR.TSD: .BLKW   1
001254                         APT.MODE:
001254      000                         .BYTE   0
                                        .EVEN
001256                         MAIL.BOX.TESTNUM:
                                        .BLKW   1
001260                         MAIL.BOX.SUBTST:
                                        .BLKW   1
001262                         COMPARE.DATA:
                                        .BLKB   1
                                        .EVEN
001264                         DRS.FLAGS:
                                        .BLKW   1
001266                         RD.MAX.SEQ.CNT:
                                        .BLKW   1
001270                         RX.MAX.SEQ.CNT:
                                        .BLKW   1


                                .GLOBL  CST, CST.ADDR, DCT, DCT.ADDR, RDRX.ADDR
                                .GLOBL  IRDRX.ADDR, BST, TALLY, T.ADDR
                                .GLOBL  TRK.SGN, RDM.CNT, RANDOM, C.ERR.TBL
                                .GLOBL  MSCP.PKT, IPKT ADDR, PKT.USE, RETPKT
                                .GLOBL  RP.USE, RP.INDX, RP.ADDR, ELOG.PKT
                                .GLOBL  BUFF.ADDR, BUFF.OWN, IODQ, IODQ.IN
                                .GLOBL  IODQ.OUT, ENTRY.REASON, EOP.FLAG
                                .GLOBL  DUP.FLAGS, CCTLR, CDISK, CUOFF
                                .GLOBL  CTLR.CNT, DUR, QIO, FREE.MEM.ADDR
                                .GLOBL  BYTS.PER.QIO, ST.CODE, SB.CODE
                                .GLOBL  STEP, OF.RC, SA.REG, CMD.TIME
                                .GLOBL  NEX, CRN.LOW, CRN.HIGH, TEMP1
                                .GLOBL  TEMP2, CREDIT.BAL, NEXT.PKT.USE
                                .GLOBL  HOURS, MINUTES, CLK.TICKS, CLK.PRESENT
                                .GLOBL  HOE.FLAG, FORCED.ERROR, FER0.LBN
                                .GLOBL  FER1.LBN, FER.BC, INIT.OCCURED
                                .GLOBL  ADDR.VECT.OK, TYPER, TYPEW, BAL.IN.PROGRESS
                                .GLOBL  FORCE.WR, CSR.MEM, CSR.ADD, TST.PAR
                                .GLOBL  MAN.TST, P.INDEX, RD.COUNT, BRLEVEL
                                .GLOBL  D.FAIL, DBM12, DBM18, DBM19, DBM20
                                .GLOBL  DBM21, DBM22, DBM23, DBM25, DBM26
                                .GLOBL  DBM27, DBM29, DBM108, DBM109, DBM111
                                .GLOBL  DBM112, DBM120, DBM121, DBM123
```

```
                        .GLOBL  DBM125, DBM126, DBM127, DBM128
                        .GLOBL  EH.0,  H.1, EH.2, EH.3, EH.4, EH.5
                        .GLOBL  EH.6  EH.7, EH.8, EH.9, EH.10
                        .GLOBL  EH.1   EH.13, MSG.02, MSG.03, EGS.02
                        .GLOBL  EGD.10, EGD.11, EGD.12, EGD.13
                        .GLOBL  EGD.14, EGD.15, EGD.16, EGD.17
                        .GLOBL  EGD.18, EGD.19, EGD.20, EGD.21
                        .GLOBL  EGD.22, EGD.23, EGD.24, EGH.30
                        .GLOBL  DF.MSG, HRD.MSG, SFT.MSG, HRD.SUB
                        .GLOBL  CRLF, SWP.ERROR, SWP.XFER, SWP.FLAGS
                        .GLOBL  SWP.RAT, SWP.DPAT, SWP.UCNT, SWP.TIME
                        .GLOBL  SWP.UDPAT, L$LUN, L$UNIT, NEX.TRAP
                        .GLOBL  PARITY, TIME, SET.CPAR, SET.UPAR
                        .GLOBL  OUT.IODQ, IN.IODQ, GET.PKT, PUT.PKT
                        .GLOBL  GET.RETPKT, PUT.RETPKT, GET.IO.BUFF
                        .GLOBL  PUT.IO.BUFF, PUTA.BUFF, SEND, WAIT
                        .GLOBL  MODULAS, DROP.CTLR, DRV.CTLERR
                        .GLOBL  EMS.R2, EMS.R1, EMS.EL, EMS.CMP
                        .GLOBL  EMS.ERR, EMS.10, EMS.12, EMS.13
                        .GLOBL  EMS.14, EMS.18, EMS.21, EMS.24
                        .GLOBL  EMS.30

000001                  ON==            1
000002                  OFF==           2
100000                  BIT15==         -100000
040000                  BIT14==         40000
020000                  BIT13==         20000
010000                  BIT12==         10000
004000                  BIT11==         4000
002000                  BIT10==         2000
001000                  BIT09==         1000
000400                  BIT08==         400
000200                  BIT07==         200
000100                  BIT06==         100
000040                  BIT05==         40
000020                  BIT04==         20
000010                  BIT03==         10
000004                  BIT02==         4
000002                  BIT01==         2
000001                  BIT00==         1
001000                  BIT9==          1000
000400                  BIT8==          400
000200                  BIT7==          200
000100                  BIT6==          100
000040                  BIT5==          40
000020                  BIT4==          20
000010                  BIT3==          10
000004                  BIT2==          4
000002                  BIT1==          2
000001                  BIT0==          1
000035                  EF.NEW==        35
000034                  EF.PWR==        34
```

```
        000040                          EF.START==          40
        000037                          EF.RESTART==        37
        000036                          EF.CONTINUE==       36
        000340                          PRI07==             340
        000300                          PRI06==             300
        000240                          PRI05==             240
        000200                          PRI04==             200
        000140                          PRI03==             140
        000100                          PRI02==             100
        000040                          PRI01==             40
        000000                          PRI00==             0
        000004                          EVL==               4
        000010                          LOT==               10
        000020                          ADR==               20
        000040                          IDU==               40
        000100                          ISR==               100
        000200                          UAM==               200
        000400                          BOE==               400
        001000                          PNT==               1000
        002000                          PRI==               2000
        004000                          IXE==               4000
        010000                          IBE==               10000
        020000                          IER==               20000
        040000                          LOE==               40000
        100000                          HOE==               -100000


                                                .SBTTL  $T1 TEST SECTION
000000                                          .PSECT  $CODE$,  RO

000000  004137  000000G                $T1:    JSR     R1,$SAVE3               ;                               2167
000004  112737  000001  000000G               MOVB    #1,EOP.FLAG             ;                               2185
000012  112737  000001  001262'               MOVB    #1,COMPARE.DATA         ;                               2186
000020  042737  000002  000000G               BIC     #2,DUP.FLAGS            ;                               2187
000026  105037  000000G                       CLRB    HOE.FLAG                ;                               2188
000032  105037  000000G                       CLRB    FORCED.ERROR            ;                               2189
000036  005002                               CLR     R2                      ; I                             2192
000040  010246                         1$:   MOV     R2,-(SP)                ; I,*                           2196
000042  012746  000043                       MOV     #43,-(SP)
000046  004737  000000G                       JSR     PC,BL$MUL
000052  005001                               CLR     R1                      ; J                             2195
000054  010003                         2$:   MOV     R0,R3                   ;                               2196
000056  060103                               ADD     R1,R3                   ; J,*
000060  006303                               ASL     R3
000062  005063  000000G                       CLR     MSCP.PKT(R3)
000066  005201                               INC     R1                      ; J                             2195
000070  020127  000042                       CMP     R1,#42                  ; J,*
000074  003767                               BLE     2$
000076  010216                               MOV     R2,(SP)                 ; I,*                           2198
000100  012746  000106                       MOV     #106,-(SP)
000104  004737  000000G                       JSR     PC,BL$MUL
000110  105060  000005G                       CLRB    MSCP.PKT+5(R0)
000114  062706  000006                       ADD     #6,SP                   ;                               2193
```

```
000120  005202                          INC     R2                      ; I                     2192
000122  020227  000013                  CMP     R2,#13                  ; I,*
000126  003744                          BLE     1$
000130  005002                          CLR     R2                      ; I                     2201
000132  005001                  3$:     CLR     R1                      ; J                     2202
000134  010200                  4$:     MOV     R2,R0                   ; I,*                   2203
000136  060100                          ADD     R1,R0                   ; J,*
000140  006300                          ASL     R0
000142  005060  000000G                 CLR     RETPKT(R0)
000146  005201                          INC     R1                      ; J                     2202
000150  020127  000025                  CMP     R1,#25                  ; J,*
000154  003767                          BLE     4$
000156  062702  000026                  ADD     #26,R2                  ; *,I                   2201
000162  020227  000232                  CMP     R2,#232                 ; I,*
000166  003761                          BLE     3$
000170  005002                          CLR     R2                      ; I                     2205
000172  010246                  5$:     MOV     R2,-(SP)                ; I,*                   2209
000174  012746  000041                  MOV     #41,-(SP)
000200  004737  C00000G                 JSR     PC,BL$MUL
000204  005001                          CLR     R1                      ; J                     2208
000206  010003                  6$.     MOV     R0,R3                   ;                       2209
000210  060103                          ADD     R1,R3                   ; J,*
000212  006303                          ASL     R3
000214  005063  000000G                 CLR     ELOG.PKT(R3)
000220  005201                          INC     R1                      ; J                     2208
000222  020127  000040                  CMP     R1,#40                  ; J,*
000226  003767                          BLE     6$
000230  010216                          MOV     R2,(SP)                 ; I,*                   2211
000232  012746  000102                  MOV     #102,-(SP)
000236  004737  000000G                 JSR     PC,BL$MUL
000242  105060  000001G                 CLRB    ELOG.PKT+1(R0)
000246  062706  000006                  ADD     #6,SP                   ;                       2206
000252  005202                          INC     R2                      ; I                     2205
000254  020227  000014                  CMP     R2,#14                  ; I,*
000260  003744                          BLE     5$
000262  032737  000020  000000G         BIT     #20,SWP.FLAGS           ;                       2214
000270  001403                          BEQ     7$
000272  042737  000040  000000G         BIC     #40,SWP.FLAGS           ;                       2216
000300  032737  000002  000000G 7$:     BIT     #2,SWP.FLAGS            ;                       2218
000306  001403                          BEQ     8$
000310  042737  001000  000000G         BIC     #1000,SWP.FLAGS         ;                       2220
000316  132737  000001  000000G 8$:     BITB    #1,INIT.OCCURED         ;                       2222
000324  001402                          BEQ     9$
000326  000137  000732'                 JMP     15$
000332  017700  000000G         9$:     MOV     @FREE.MEM.ADDR,R0       ;                       2225
000336  006300                          ASL     R0
000340  063700  000000G                 ADD     FREE.MEM.ADDR,R0
000344  010037  001250                  MOV     R0,DRS.START
000350  062737  000002  001250'         ADD     #2,DRS.START
000356  032737  000001  000000G         BIT     #1,SWP.FLAGS            ;                       2231
000364  001417                          BEQ     10$
000366  112737  000001  001254'         MOVB    #1,APT.MODE             ;                       2234
000374  013737  001250' 001256'         MOV     DRS.START,MAIL.BOX.TESTNUM ;                    2235
```

```
000402  062737  000070  001256'          ADD     #70,MAIL.BOX.TESTNUM
000410  013737  001250' 001260'          MOV     DRS.START,MAIL.BOX.SUBTST       ;                                       2236
000416  062737  000066  001260'          ADD     #66,MAIL.BOX.SUBTST
000424  005037  000000G                  10$:    CLR     NEX                     ;                                       2240
000430  105037  000000G                          CLRB    CLK.PRESENT             ;                                       2241
000434  012746  000340                          MOV     #340,-(SP)              ;                                       2242
000440  012746  000000G                          MOV     #NEX.TRAP, (SP)
000444  012746  000004                          MOV     #4, (SP)
000450  012746  000003                          MOV     #3,-(SP)
000454  104437                               TRAP    37
000456  013701  177546                       MOV     @#177546,R1             ; #,DUMMY.0                             2243
000462  005002                               CLR     R2                      ; DUMMY.1                               2244
000464  012700  000004                       MOV     #4,R0                   ;                                       2245
000470  104436                               TRAP    36
000472  032737  000001  000000G             BIT     #1,NEX                  ;                                       2248
000500  001060                               BNE     13$
000502  112737  000001  000000G             MOVB    #1,CLK.PRESENT          ;                                       2251
000510  005037  000000G                      CLR     CLK.TICKS               ;                                       2252
000514  013716  000000G                      MOV     SWP.TIME,(SP)           ;                                       2253
000520  012746  000144                       MOV     #144,-(SP)
000524  004737  000000G                      JSR     PC,BL$DIV
000530  110037  000000G                      MOVB    R0,HOURS
000534  013716  000000G                      MOV     SWP.TIME,(SP)           ;                                       2254
000540  012746  000144                       MOV     #144, (SP)
000544  004737  000000G                      JSR     PC,BL$MOD
000550  010003                               MOV     R0,R3
000552  005203                               INC     R3
000554  110337  000000G                      MOVB    R3,MINUTES
000560  123727  000000G 000074      11$:    CMPB    MINUTES,#74             ;                                       2256
000566  103412                               BLO     12$
000570  005000                               CLR     R0                      ;                                       2258
000572  153700  000000G                      BISB    MINUTES,R0
000576  162700  000074                       SUB     #74,R0
000602  110037  000000G                      MOVB    R0,MINUTES
000606  105237  000000G                      INCB    HOURS                   ;                                       2259
000612  000762                               BR      11$                     ;                                       2256
000614  005016                       12$:    CLR     (SP)                    ;                                       2262
000616  113716  000000G                      MOVB    HOURS,(SP)
000622  012746  000030                       MOV     #30,-(SP)
000626  004737  000000G                      JSR     PC,BL$MOD
000632  110037  000000G                      MOVB    R0,HOURS
000636  062706  000006                       ADD     #6,SP                   ;                                       2250
000642  005037  000000G                      13$:    CLR     NEX             ;                                       2265
000646  005037  000000G                      CLR     CSR.MEM                 ;                                       2266
000652  012716  000340                       MOV     #340,(SP)               ;                                       2267
000656  012746  000000G                      MOV     #NEX.TRAP, (SP)
000662  012746  000004                       MOV     #4,-(SP)
000666  012746  000003                       MOV     #3, (SP)
000672  104437                               TRAP    37
000674  017701  000000G                      MOV     @CSR.ADD,R1             ; #,DUMMY.0                             2268
000700  005002                               CLR     R2                      ; DUMMY.1                               2269
000702  012700  000004                       MOV     #4,R0                   ;                                       2270
000706  104436                               TRAP    36
```

```
000710  032737  000001  000000G          BIT     #1,NEX                  ;                       2273
000716  001003                           BNE     14$
000720  012737  000001  000000G          MOV     #1,CSR.MEM              ;                       2276
000726  062706  000016          14$:     ADD     #16,SP                  ;                       2224
000732  132737  000001  000000G  15$:     BITB    #1,CLK.PRESENT          ;                       2282
000740  001416                           BEQ     16$
000742  012746  000300                   MOV     #300, (SP)              ;                       2285
000746  012746  000000G                  MOV     #TIME, (SP)
000752  012746  000100                   MOV     #100, (SP)
000756  012746  000003                   MOV     #3, (SP)
000762  104437                           TRAP    37
000764  012737  000100  177546          MOV     #100,@#177546           ;                       2286
000772  062706  000010                   ADD     #10,SP                  ;                       2284
000776  032737  000001  000000G  16$:     BIT     #1,CSR.MEM              ;                       2289
001004  001422                           BEQ     17$
001006  032737  000001  000000G          BIT     #1,TST.PAR
001014  001416                           BEQ     17$
001016  012746  000340                   MOV     #340, (SP)              ;                       2292
001022  012746  C00000G                  MOV     #PARITY,-(SP)
001026  012746  000114                   MOV     #114,-(SP)
001032  012746  000003                   MOV     #3,-(SP)
001036  104437                           TRAP    37
001040  012777  000001  000000G          MOV     #1,@CSR.ADD             ;                       2293
001046  062706  000010                   ADD     #10,SP                  ;                       2291
001052  104421                  17$:     TRAP    21                      ;                       2296
001054  010037  001264'                  MOV     R0,DRS.FLAGS
001060  042700  077777                   BIC     #77777,R0               ;                       2298
001064  020027  100000                   CMP     R0,#-100000
001070  001003                           BNE     18$
001072  012700  000001                   MOV     #1,R0
001076  000401                           BR      19$
001100  005000                  18$:     CLR     R0
001102  020027  100000          19$:     CMP     R0,#-100000
001106  001003                           BNE     20$
001110  112737  000001  000000G          MOVB    #1,HOE.FLAG             ;                       2300
001116  004737  000000V          20$:     JSR     PC,INIT.TEST            ;                       2303
001122  005002                           CLR     R2                      ; CTLR                  2305
001124  010246                  21$:     MOV     R2, (SP)                ; CTLR,*                2307
001126  012746  000126                   MOV     #126,-(SP)
001132  004737  000000G                  JSR     PC,BL$MUL
001136  022626                           CMP     (SP)+,(SP)+
001140  005760  000002G                  TST     CST+2(R0)
001144  100040                           BPL     25$
001146  010246                           MOV     R2,-(SP)                ; CTLR,*                2308
001150  012746  000022                   MOV     #22, (SP)
001154  004737  000000G                  JSR     PC,BL$MUL
001160  022626                           CMP     (SP)+,(SP)+
001162  005760  000000G                  TST     DCT(R0)
001166  100027                           BPL     25$
001170  010246                           MOV     R2,-(SP)                ; CTLR,*                2313
001172  012746  000053                   MOV     #53, (SP)
001176  004737  000000G                  JSR     PC,BL$MUL
001202  012701  000003                   MOV     #3,R1                   ; *,OFFSET              2311
```

```
001206  010003                          22$:    MOV     R0,R3                           ;                               2313
001210  060103                                  ADD     R1,R3                           ; OFFSET,*
001212  006303                                  ASL     R3
001214  032763  020000  000000G                BIT     #20000,CST(R3)
001222  001403                                  BEQ     23$
001224  105037  000000G                        CLRB    EOP.FLAG                        ;                               2316
001230  000405                                  BR      24$                             ;                               2315
001232  062701  000012                  23$:    ADD     #12,R1                          ; *,OFFSET                      2311
001236  020127  000042                          CMP     R1,#42                          ; OFFSET,*
001242  003761                                  BLE     22$
001244  022626                          24$:    CMP     (SP)+,(SP)+
001246  005202                          25$:    INC     R2                              ; CTLR                          2305
001250  000243                                  .WORD CLV!CLC

001252  003724                                  BLE     21$
001254  132737  000001  000000G                BITB    #1,EOP.FLAG                     ;                               2320
001262  001002                                  BNE     26$
001264  004737  000000V                        JSR     PC,MULTI.DRIVE                  ;                               2322
001270  000207                          26$:    RTS     PC                              ;                               2167

; Routine Size:  349 words,     Routine Base:  $CODE$ + 0000
; Maximum stack depth per invocation:  13 words



                                                .SBTTL  T1 TEST SECTION
000000  004737  000000'                  T1::
000000                                  1$:     JSR     PC,$T1                          ;                               2322
000004  104466                                  TRAP    66
000006  006000                                  ROR     R0
000010  103773                                  BLO     1$
000012  000207                                  RTS     PC

; Routine Size:  6 words,       Routine Base:  $CODE$ + 1272
; Maximum stack depth per invocation:  2 words
```

```
;    2324  1      %sbttl 'INITIALIZATION TEST ROUTINES'
;    2325  1
;    2326  1      GLOBAL routine INIT_TEST : novalue =
;    2327  1
;    2328  1      !+
;    2329  1      !       THE INITIALIZATION TEST IS DESIGNED TO VERIFY THE EXISTENCE OF THE
;    2330  1      !       DEVICES AS CONFIGURED BY THE OPERATOR DURING THE HW DIALOG, AND TO
;    2331  1      !       BRING EACH DEVICE ONLINE IN PREPARATION FOR EITHER THE MULTI DRIVE TEST
;    2332  1      !       OR THE DM EXERCISER.
;    2333  1      !
;    2334  1      !       BASICALLY, THE DEVICES ARE BROUGHT ONLINE VIA "DRIVER_INIT", WHICH IS
;    2335  1      !       INVOKED IMMEDIATELY. ANY DEVICES WHICH FAIL DURING THIS PHASE WILL BE
;    2336  1      !       MARKED OFFLINE IN THEIR DCT AND CST. FOR THOSE DEVICES WHICH SURVIVE
;    2337  1      !       THE INITIALIZATION, THIS ROUTINE WILL ATTEMPT 1 OR 2 ACCESS COMMANDS TO
;    2338  1      !       EACH DISK VIA ROUTINE "ACCESS'. THE INITIALIZATION TEST IS DEEMED A
;    2339  1      !       SUCCESS IF A BLOCK OF EACH DISK CAN BE ACCESSED.
;    2340  1      !-
;    2341  1
;    2342  2          begin
;    2343  2          DRIVER_INIT ();                             ! INIT DRIVER DATA AND DEVICES
;    2344  2
;    2345  2          incr CTLR from 0 to (MAX_CTLR   1) do       ! FOR EACH CONTROLLER
;    2346  3              begin
;    2347  3              SET_CPAR (.CTLR);                       ! SET UP COMMONLY-USED CONTROLLER-RELATED DATA ITEMS
;    2348  3
;    2349  3              if .CST_ADDR [STATE] eql ONLINE         ! IF CONTROLLER IS STILL ALIVE
;    2350  3              then                                    ! FOR EACH DISK
;    2351  3
;    2352  3                  incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do
;    2353  3
;    2354  3                      if (.CST_ADDR [.OFFSET + OF_DATA, D_PRES] eql PRESENT) and
;    2355  3                         (.CST_ADDR [.OFFSET + OF_DATA, D_STAT] eql ONLINE) and
;    2356  4                         (not .CST_ADDR [.OFFSET + OF_DATA, D_FATAL])
;    2357  3                      then
;    2358  4                          begin
;    2359  4                          SET_UPAR (.OFFSET);         ! SET UP UNIT-RELATED DATA ITEMS
;    2360  5                          IF SWP_DINT_NEQ (.DUP_FLAGS AND SWP_DINT)          !ZZZ
;    2361  4                             THEN ACCESS ();                                 !ZZZ
;    2362  4                                                  !SKIP IF DUP CAUSED INIT ZZZ
;    2363  4
;    2364  3                          end;                        ! IF UNIT IS PRESENT AND ONLINE
;    2365  3
;    2366  2              end;                                    ! CONTROLLER LOOP
;    2367  2
;    2368  1          end;                                        ! ROUTINE INIT_TEST
```

```
                                .SBTTL  INIT.TEST INITIALIZATION TEST ROUTINES
000000  004137  000000G     INIT.TEST::
                            JSR     R1,$SAVE2                   ;                   2326
000004  004737  000000V             JSR     PC,DRIVER.INIT              ;                   2343
000010  005002                      CLR     R2                          ; CTLR              2345
000012  010246              1$:     MOV     R2,-(SP)                    ; CTLR,*            2347
```

```
000014  004737  000000G                        JSR     PC,SET.CPAR
000020  013700  000000G                        MOV     CST.ADDR,R0             ;                               2349
000024  005760  000002                         TST     2(R0)
000030  100035                                 BPL     4$
000032  012701  000003                         MOV     #3,R1                   ; *,OFFSET                      2352
000036  010100                         2$:     MOV     R1,R0                   ; OFFSET,*                      2354
000040  006300                                 ASL     R0
000042  063700  000000G                        ADD     CST.ADDR,R0
000046  032710  040000                         BIT     #40000,(R0)
000052  001417                                 BEQ     3$
000054  032710  020000                         BIT     #20000,(R0)             ;                               2355
000060  001414                                 BEQ     3$
000062  032710  010000                         BIT     #10000,(R0)             ;                               2356
000066  001011                                 BNE     3$
000070  010116                                 MOV     R1,(SP)                 ; OFFSET,*                      2359
000072  004737  000000G                        JSR     PC,SET.UPAR
000076  032737  000002  000000G                BIT     #2,DUP.FLAGS            ;                               2360
000104  001002                                 BNE     3$
000106  004737  C00000V                        JSR     PC,ACCESS               ;                               2361
000112  062701  000012                 3$:     ADD     #12,R1                  ; *,OFFSET                      2352
000116  020127  000041                         CMP     R1,#41                  ; OFFSET,*
000122  003745                                 BLE     2$
000124  005726                         4$.     TST     (SP)+                   ;                               2346
000126  005202                                 INC     R2                      ; CTLR                          2345
000130  000243                                 .WORD CLV!CLC

000132  003727                                 BLE     1$
000134  000207                                 RTS     PC                      ;                               2326

; Routine Size:  47 words,      Routine Base:  $CODE$ + 1306
; Maximum stack depth per invocation:  5 words
```

```
;    2369  1     GLOBAL routine DRIVER_INIT : novalue =
;    2370  1
;    2371  1     !+
;    2372  1     !       THIS ROUTINE IS EQUIVALENT IN FUNCTION TO THE INITIALIZATION ENTRY
;    2373  1     !       POINT OF A STANDARD DEVICE DRIVER. ITS RESPONSIBILITY IS TO INITIALIZE
;    2374  1     !       DRIVER DATA, AND TO BRING EACH RDRX CONTROLLER AND UNIT (DISK)
;    2375  1     !       ONLINE.
;    2376  1     !-
;    2377  1
;    2378  2         begin
;    2379  2
;    2380  2         local
;    2381  2             PKT_ADDR;
;    2382  2
;    2383  2         PKT_ADDR = MSCP_PKT + 10;                                       ! ADDR (TEXT + 0) OF 1ST MSCP PKT
;    2384  2         NEXT_PKT_USE = 0;                                               ! NEXT PACKET TO ALLOCATE
;    2385  2
;    2386  2         incr COUNT from 0 to (PKT_CNT - 1) do                           ! FOR EACH MSCP PACKET
;    2387  3             begin
;    2388  3             PKT_USE [.COUNT] = -1;                                      ! MARK PACKET FREE
;    2389  3             MSCP_PKT [.COUNT, PKT_LO] = .PKT_ADDR;                      ! LOAD ADDR INTO BUFFER DESCRIPTOR
;    2390  3             MSCP_PKT [.COUNT, PKT_HI] = 0;
;    2391  3             MSCP_PKT [.COUNT, CONNID] = CID_DISK;                       ! SET CONNECTION ID TO MSCP ID
;    2392  3             PKT_ADDR = .PKT_ADDR + (PKT_LEN  *  2);                     ! ADVANCE ADDR TO NEXT PACKET
;    2393  2             end;
;    2394  2
;    2395  2         incr CTLR from 0 to (MAX_CTLR - 1) do                           ! FOR EACH CONTROLLER
;    2396  2
;    2397  2             if .CST [.CTLR, IP_ADDR] neqa 0                             ! IF CONTROLLER IS PRESENT
;    2398  2             then
;    2399  3                 begin
;    2400  3                 SET_CPAR (.CTLR);                                       ! CURRENT CONTROLLER PARAMETERS
;    2401  3                 CURRENT_VECTOR = .CST_ADDR [VEC_ADDR];                  ! CURRENT CONTROLLER'S VECTOR
;    2402  3                 BRLEVEL = .CST_ADDR [BR_LEV] + 5;                       ! SET CURRENT CONTROLLER'S BR LEVEL
;    2403  3                 CTLR_INIT ();                                           ! INIT DEVICE AND CTLR DATA
;    2404  3
;    2405  3                 if .DCT_ADDR [STAT] eql ONLINE                          ! IF CONTROLLER IS STILL ALIVE
;    2406  3                 then                                                    ! FOR EACH DIAK UNIT
;    2407  3
;    2408  3                     incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do
;    2409  3
;    2410  3                         if (.CST_ADDR [.OFFSET + OF_DATA, D_PRES] eql PRESENT) and  ! IF UNIT EXISTS
;    2411  4                            (not .CST_ADDR [.OFFSET + OF_DATA, D_FATAL])
;    2412  3                         then
;    2413  4                             begin
;    2414  4                             CST_ADDR [.OFFSET + OF_NAME_0, D_NAME_0] = %o'40';      ! BLANK DEVICE NAME
;    2415  4                             CST_ADDR [.OFFSET + OF_NAME_0, D_NAME_1] = %o'40';      !
;    2416  4                             CST_ADDR [.OFFSET + OF_NAME_2, D_NAME_2] = %o'40';      !
;    2417  4                             CST_ADDR [.OFFSET + OF_NAME_2, D_NAME_3] = %o'40';      !
;    2418  4                             SET_UPAR (.OFFSET);                                     ! SET UP UNIT RELATED DATA ITEMS
;    2419  4                             UNIT_INIT ();                                           ! BRING UNIT ONLINE
;    2420  3                             end;                                                    ! IF UNIT EXISTS
;    2421  3
```

```
;   2422  2                 end;                                          ! IF CONTROLLER IS PRESENT
;   2423  2
;   2424  1             end;                                            ! ROUTINE DRIVER INIT


                                                .SBTTL  DRIVER.INIT INITIALIZATION TEST ROUTINES
000000  004137  000000G                    DRIVER.INIT::
                                                JSR     R1,$SAVE3                       ;                                       2369
000004  012702  000012G                            MOV     #MSCP.PKT+12,R2             ; *,PKT.ADDR                            2383
000010  105037  000000G                            CLRB    NEXT.PKT.USE                ;                                       2384
000014  005001                                     CLR     R1                          ; COUNT                                 2386
000016  112761  000377  000000G           1$:      MOVB    #377,PKT.USE(R1)            ; *,*(COUNT)                            2388
000024  010146                                     MOV     R1,-(SP)                    ; COUNT,*                               2389
000026  012746  000106                            MOV     #106, (SP)
000032  004737  000000G                            JSR     PC,BL$MUL
000036  010260  000000G                            MOV     R2,MSCP.PKT(R0)             ; PKT.ADDR,*
000042  005060  000002G                            CLR     MSCP.PKT+2(R0)              ;                                       2390
000046  105060  000011G                            CLRB    MSCP.PKT+11(R0)             ;                                       2391
000052  062702  C00106                            ADD     #106,R2                     ; *,PKT.ADDR                            2392
000056  022626                                     CMP     (SP)+,(SP)+                 ;                                       2387
000060  005201                                     INC     R1                          ; COUNT                                 2386
000062  020127  000013                            CMP     R1,#13                      ; COUNT,*
000066  003753                                     BLE     1$
000070  005003                                     CLR     R3                          ; CTLR                                  2395
000072  010346                           2$:      MOV     R3,-(SP)                    ; CTLR,*                                2397
000074  012746  000126                            MOV     #126, (SP)
000100  004737  000000G                            JSR     PC,BL$MUL
000104  022626                                     CMP     (SP)+,(SP)+
000106  005760  000000G                            TST     CST(R0)
000112  001503                                     BEQ     6$
000114  010346                                     MOV     R3,-(SP)                    ; CTLR,*                                2400
000116  004737  000000G                            JSR     PC,SET.CPAR
000122  013700  000000G                            MOV     CST.ADDR,R0                 ;                                       2401
000126  016037  000002  001246'                    MOV     2(R0),CURRENT.VECTOR
000134  042737  177000  001246'                    BIC     #177000,CURRENT.VECTOR
000142  005016                                     CLR     (SP)                        ;                                       2402
000144  116016  000004                            MOVB    4(R0),(SP)
000150  012746  000005                            MOV     #5,-(SP)
000154  004737  000000G                            JSR     PC,BL$SHF
000160  010037  000000G                            MOV     R0,BRLEVEL
000164  004737  000000V                            JSR     PC,CTLR.INIT                ;                                       2403
000170  005777  000000G                            TST     @DCT.ADDR                   ;                                       2405
000174  100051                                     BPL     5$
000176  012701  000003                            MOV     #3,R1                       ; *,OFFSET                              2408
000202  013702  000000G                    3$:     MOV     CST.ADDR,R2                 ;                                       2410
000206  010100                                     MOV     R1,R0                       ; OFFSET,*
000210  006300                                     ASL     R0
000212  060200                                     ADD     R2,R0
000214  032710  040000                            BIT     #40000,(R0)
000220  001432                                     BEQ     4$
000222  032710  010000                            BIT     #10000,(R0)                 ;                                       2411
000226  001027                                     BNE     4$
000230  010100                                     MOV     R1,R0                       ; OFFSET,*                              2414
```

```
000232  006300                          ASL     R0
000234  060200                          ADD     R2,R0
000236  112760  000040  000012          MOVB    #40,12(R0)
000244  112760  000040  000013          MOVB    #40,13(R0)              ;                               2415
000252  010100                          MOV     R1,R0                   ; OFFSET,*                      2416
000254  006300                          ASL     R0
000256  060200                          ADD     R2,R0
000260  112760  000040  000014          MOVB    #40,14(R0)
000266  112760  000040  000015          MOVB    #40,15(R0)              ;                               2417
000274  010116                          MOV     R1,(SP)                 ; OFFSET,*                      2418
000276  004737  000000G                 JSR     PC,SET.UPAR
000302  004737  000000V                 JSR     PC,UNIT.INIT            ;                               2419
000306  062701  000012          4$:     ADD     #12,R1                  ; *,OFFSET                      2408
000312  020127  000041                  CMP     R1,#41                  ; OFFSET,*
000316  003731                          BLE     3$
000320  022626                  5$:     CMP     (SP)+,(SP)+             ;                               2399
000322  005203                  6$:     INC     R3                      ; CTLR                          2395
000324  000243                          .WORD CLV!CLC

000326  003661                          BLE     2$
000330  000207                          RTS     PC                      ;                               2369

; Routine Size:  109 words,     Routine Base:  $CODE$ + 1444
; Maximum stack depth per invocation:  7 words
```

```
;  2425  1     GLOBAL routine CTLR_INIT : novalue =
;  2426  1
;  2427  1     !*
;  2428  1     !       THIS "DRIVER' ROUTINE IS CALLED FROM DRIVER_INIT FOR EACH CONTROLLER
;  2429  1     !       CONFIGURED FOR TESTING. ITS GENERAL PURPOSE IS TO BRING THE RDRX ONLINE
;  2430  1     !       TO THE HOST. SPECIFICALLY, IT IS WRITTEN TO:
;  2431  1     !
;  2432  1     !       1. INITIALIZE DRIVER CONTROLLER DATA, INCLUDING THE DCT,
;  2433  1     !       2. SET UP THE DEVICE'S INTERRUPT VECTOR ADDRESS,
;  2434  1     !       3. PERFORM A REGISTER EXISTENCE TEST TO VERIFY THE DEVICE'S PRESENCE,
;  2435  1     !       4. PERFORM A VECTOR AND BR LEVEL TEST TO VERIFY THE DEVICE'S VECTOR
;  2436  1     !             ADDRESS AND INTERRUPT REQUEST LEVEL,
;  2437  1     !       5. DO A HARD INITIALIZATION (FOUR STEPS) ON THE DEVICE.
;  2438  1     !
;  2439  1     !       IF ANY OF THESE INITIAL TESTS FAIL, THEN ALL UNITS ASSOCIATED WITH THE
;  2440  1     !       DEVICE ARE DROPPED.
;  2441  1     !
;  2442  1
;  2443  2         begin
;  2444  2
;  2445  2         local
;  2446  2             RESULT : byte;
;  2447  2
;  2448  2         INI_CTLR_DAT ();                                        ! INITIALIZE CONTROLLER DATA
;  2449  2     !ZZZ    SETVEC (.CURRENT_VECTOR, .INT_ADDR [.CCTLR], PRIO4);    ! SET DEVICE'S ASSUMED VECTOR ADDRESS
;  2450  2         SETVEC (.CURRENT_VECTOR, .INT_ADDR [.CCTLR], .BRLEVEL);     ! SET DEVICE'S ASSUMED VECTOR ADDRESS    ZZZ
;  2451  2         DCT_ADDR [IG_INT] = TRUE;                               ! SET "IGNORE INTERRUPT" BIT
;  2452  2         L$LUN = .CST_ADDR [OF_UN + OF_DATA, D_UNIT];            ! GET FIRST UNIT NUMBER OF CONTROLLER
;  2453  2                                                                 ! (USED BY DRS FOR DEVICE FATAL CTLR ERRORS)
;  2454  3     IF SWP_DINT NEQ (.DUP_FLAGS AND SWP_DINT)                   !IF DUP  ZZZ
;  2455  2     THEN                                !CAUSED INIT, SKIP THIS CODE   ZZZ
;  2456  2
;  2457  2         if REG_EXIST () eql FAILURE                             ! REGISTER EXISTENCE TEST
;  2458  2         then
;  2459  3             begin
;  2460  3             DROP_CTLR (.CCTLR, DU_INIT);                        ! DROP ALL CONTROLLER'S UNITS
;  2461  3             return;
;  2462  2             end;
;  2463  2
;  2464  3     IF SWP_DINT NEQ (.DUP_FLAGS AND SWP_DINT)                   !IF DUP  ZZZ
;  2465  2     THEN                                !CAUSED INIT, SKIP THIS CODE   ZZZ
;  2466  2
;  2467  2         if VEC_BR_TEST () eql FAILURE                           ! VECTOR ADDR AND BR LEVEL TEST
;  2468  2         then
;  2469  3             begin
;  2470  3             DROP_CTLR (.CCTLR, DU_INIT);                        ! DROP ALL CONTROLLER'S UNITS
;  2471  3             return;
;  2472  2             end;
;  2473  2
;  2474  2         RESULT = HARD_INIT ();                                  ! ATTEMPT HARD DEVICE INIT
;  2475  2         DCT_ADDR [IG_INT] = FALSE;                              ! CLAER "IGNORE INTERRUPT" BIT
;  2476  2
;  2477  2         if .RESULT eql SUCCESS                                  ! IF HARD INIT WAS SUCCESSFUL
```

```
;  2478  2          then
;  2479  3              begin
;  2480  3              ADDR_VECT_OK = TRUE;                    ! ADDRESS/VECTOR TEST PASSED
;  2481  3              INI_RRING ();                           ! INITIALIZE RESPONSE RING
;  2482  3              WRT_RDRX (RCSA, RC_ALL, SA_GO);         ! SET "GO" BIT (START CTLR POLLING)
;  2483  3
;  2484  3              if SET_CTLR_CHAR () eql SUCCESS         ! SET CONTROLLER CHARACTERISTICS
;  2485  3              then
;  2486  4                  begin
;  2487  4                  DCT_ADDR [STAT] = ONLINE;           ! MARK CONTROLLER ONLINE IN "DRIVER"
;  2488  4                  CST_ADDR [STATE] = ONLINE;          ! MARK CONTROLLER ONLINE IN "PROGRAM"
;  2489  3                  end;
;  2490  3              end
;  2491  3
;  2492  2          else                                        ! HARD INIT FAILED
;  2493  3              begin
;  2494  3              DROP_CTLR (.CCTLR, DU_INIT);            ! DROP ALL CONTROLLER'S UNITS
;  2495  2              end;
;  2496  2
;  2497  1          end;                                        ! ROUTINE CTLR_INIT
```

```
                                        .SBTTL  CTLR.INIT INITIALIZATION TEST ROUTINES
000000  010146                  CTLR.INIT::
                                        MOV     R1,-(SP)                ;                       2425
000002  004737  000000V                 JSR     PC,INI.CTLR.DAT         ;                       2448
000006  013746  000000G                 MOV     BRLEVEL,-(SP)           ;                       2450
000012  013700  000000G                 MOV     CCTLR,R0
000016  006300                          ASL     R0
000020  016046  000102'                 MOV     INT.ADDR(R0),-(SP)
000024  013746  001246'                 MOV     CURRENT.VECTOR,-(SP)
000030  012746  000003                  MOV     #3,-(SP)
000034  104437                          TRAP    37
000036  052777  040000  000000G         BIS     #40000,@DCT.ADDR        ;                       2451
000044  013700  000000G                 MOV     CST.ADDR,R0             ;                       2452
000050  016001  000006                  MOV     6(R0),R1
000054  000301                          SWAB    R1
000056  042701  177760                  BIC     #177760,R1
000062  010137  000000G                 MOV     R1,L$LUN
000066  032737  000002  000000G         BIT     #2,DUP.FLAGS            ;                       2454
000074  001025                          BNE     2$
000076  004737  000000V                 JSR     PC,REG.EXIST            ;                       2457
000102  005700                          TST     R0
000104  001410                          BEQ     1$                      ;                       2460
000106  032737  000002  000000G         BIT     #2,DUP.FLAGS            ;                       2464
000114  001015                          BNE     2$
000116  004737  000000V                 JSR     PC,VEC.BR.TEST          ;                       2467
000122  005700                          TST     R0
000124  001011                          BNE     2$
000126  013716  000000G         1$:     MOV     CCTLR,(SP)              ;                       2470
000132  012746  000002                  MOV     #2,-(SP)
000136  004737  000000G                 JSR     PC,DROP.CTLR
000142  062706  000012                  ADD     #12,SP                  ;                       2471
```

```
000146  000453                                  BR      5$                      ;                                       2469
000150  004737  000000V                 2$:     JSR     PC,HARD.INIT            ;                                       2474
000154  110001                                  MOVB    R0,R1                   ; *,RESULT
000156  042777  040000  000000G                BIC     #40000,@DCT.ADDR        ;                                       2475
000164  120127  000001                          CMPB    R1,#1                   ; RESULT,*                              2477
000170  001031                                  BNE     3$
000172  112737  000001  000000G                MOVB    #1,ADDR.VECT.OK         ;                                       2480
000200  004737  000000V                         JSR     PC,INI.RRING            ;                                       2481
000204  012701  000001                          MOV     #1,R1                   ; *,RC.REG                              2482
000210  013700  000000G                         MOV     RDRX.ADDR,R0
000214  010160  000002                          MOV     R1,2(R0)                ; RC.REG,*
000220  004737  000000V                         JSR     PC,SET.CTLR.CHAR        ;                                       2484
000224  020027  000001                          CMP     R0,#1
000230  001020                                  BNE     4$
000232  052777  100000  000000G                BIS     #100000,@DCT.ADDR       ;                                       2487
000240  013700  000000G                         MOV     CST.ADDR,R0             ;                                       2488
000244  052760  100000  000002                  BIS     #100000,2(R0)
000252  000407                                  BR      4$                      ;                                       2477
000254  013716  000000G                 3$:     MOV     CCTLR,(SP)              ;                                       2494
000260  012746  000002                          MOV     #2,-(SP)
000264  004737  000000G                         JSR     PC,DROP.CTLR
000270  005726                                  TST     (SP)+                   ;                                       2493
000272  062706  000010                 4$:     ADD     #10,SP                  ;                                       2443
000276  012601                         5$:     MOV     (SP)+,R1                ;                                       2425
000300  000207                                  RTS     PC

; Routine Size:  97 words,      Routine Base:  $CODE$ + 1776
; Maximum stack depth per invocation:  7 words
```

```
;    2498  1      GLOBAL routine INI_CTLR_DAT : novalue =
;    2499  1
;    2500  1      !+
;    2501  1      !       THIS ROUTINE IS RESPONSIBLE FOR INITIALIZING ALL CONTROLLER RELATED
;    2502  1      !       DATA IN THE "DRIVER" PORTION OF THE EXERCISER. THIS INCLUDES THE
;    2503  1      !       CONTROLLER'S DCT AND OUTSTANDING COMMAND LIST.
;    2504  1      !
;    2505  1      !       IMPLICIT INPUTS:
;    2506  1      !               CCTLR - CURREN. CONTROLLER NUMBER
;    2507  1      !               DCT_ADDR - ADDRESS OF CURENT CONTROLLER'S DCT
;    2508  1      !-
;    2509  1
;    2510  2          begin
;    2511  2          DCT_ADDR [WORD0] = 0;                                          ! CLEAR FIRST DCT WORD
;    2512  2          DCT_ADDR [RR_BEG] = COMM_AREA + 8 + (.CCTLR * COMM_LEN * 2);   ! START OF RESPONSE RING
;    2513  2          DCT_ADDR [RR_END] = .DCT_ADDR [RR_BEG] + ((RRING_LEN - 1) * 4); ! LAST SLOT IN RESPONSE RING
;    2514  2          DCT_ADDR [CR_BEG] = .DCT_ADDR [RR_END] + 4;                    ! START OF COMMAND RING
;    2515  2          DCT_ADDR [CR_END] = .DCT_ADDR [CR_BEG] + ((CRING_LEN - 1) * 4); ! LAST SLOT IN COMMAND RING
;    2516  2          DCT_ADDR [PR_POLL] = .DCT_ADDR [RR_BEG];                       ! FIRST RRING SLOT TO POLL
;    2517  2          DCT_ADDR [CR_POLL] = DCT_ADDR [CR_NEXT] = .DCT_ADDR [CR_BEG];  ! CRING POLL AND NEXT COMMAND POINTERS
;    2518  1          end;


                                        .SBTTL  INI.CTLR.DAT INITIALIZATION TEST ROUTINES
000000  004137  000000G           INI.CTLR.DAT::
                                        JSR     R1,$SAVE2                       ;                                       2498
000004  013701  000000G                 MOV     DCT.ADDR,R1                     ;                                       2511
000010  005011                          CLR     (R1)
000012  012702  000004                  MOV     #4,R2                           ;                                       2512
000016  060102                          ADD     R1,R2
000020  013746  000000G                 MOV     CCTLR,-(SP)
000024  012746  000050                  MOV     #50,-(SP)
000030  004737  000000G                 JSR     PC,@L$MUL
000034  062700  000010'                 ADD     #COMM.AREA+10,R0
000040  010012                          MOV     R0,(R2)
000042  010061  000006                  MOV     R0,6(R1)                        ;                                       2513
000046  062761  000014  000006         ADD     #14,6(R1)
000054  012700  000010                  MOV     #10,R0                          ;                                       2514
000060  060100                          ADD     R1,R0
000062  016110  000006                  MOV     6(R1),(R0)
000066  062710  000004                  ADD     #4,(R0)
000072  011061  000012                  MOV     (R0),12(R1)                     ;                                       2515
000076  062761  000014  000012         ADD     #14,12(R1)
000104  011261  000014                  MOV     (R2),14(R1)                     ;                                       2516
000110  011061  000020                  MOV     (R0),20(R1)                     ;                                       2517
000114  011061  000016                  MOV     (R0),16(R1)
000120  022626                          CMP     (SP)+,(SP)+                     ;                                       2510
000122  000207                          RTS     PC                              ;                                       2498

; Routine Size:  42 words,      Routine Base:  $CODE$ + 2300
; Maximum stack depth per invocation:  6 words
```

```
;    2519  1     GLOBAL routine REG_EXIST =
;    2520  1     !+
;    2521  1     !       THIS IS THE REGISTER EXISTENCE (OR "PROBE") TEST DESIGNED TO VERIFY
;    2522  1     !       THE PRESENCE OF AN RDRX DEVICE. THIS OBJECTIVE IS ACCOMPLISHED BY
;    2523  1     !       SETTING UP THE NON-EXISTENT MEMORY (NEX) TRAP VECTOR (LOCATION 4) AND
;    2524  1     !       ATTEMPTING TO READ WHAT IS ASSUMED TO BE THE DEVICE'S SA AND IP
;    2525  1     !       REGISTERS. IF THE NEX TRAP HANDLER IS INVOKED DUE TO AN ABSENT DEVICE,
;    2526  1     !       THEN THE GLOBAL DATUM "NEX" WILL BE SET TO "TRUE". THIS DATUM
;    2527  1     !       DETERMINES THE SUCCESS / FAILURE VALUE OF THIS ROUTINE.
;    2528  1     !-
;    2529  2         begin
;    2530  2
;    2531  2         local
;    2532  2             DUMMY_0 : word,                         ! TEMP FOR READING SA AND IP
;    2533  2             DUMMY_1 : word;                         !
;    2534  2
;    2535  2         if .ENTRY_REASON eql NEW_PASS
;    2536  2         then
;    2537  2             return SUCCESS;                         ! SKIP TEST FOR NEXT PASS
;    2538  2
;    2539  2         OF_RC = 2;                                  ! SET UP TO READ SA FIRST
;    2540  2
;    2541  2         do
;    2542  3             begin
;    2543  3             NEX = FALSE,                            ! SET TO "TRAP NOT RECEIVED"
;    2544  3             SETVEC (4, NEX_TRAP, PRI07);            ! SET LOCATION 4 TRAP VECTOR ADDRESS
;    2545  3             DUMMY_0 = .(.RDRX_ADDR + .OF_RC);       ! READ REGISTER (THEN TRAP OR CONTINUE)
;    2546  3             DUMMY_1 = 0;                            ! DUMMY INSTRUCTION TO COVER TRAP RETURN BUG
;    2547  3                                                     !       (TRAP RETURNS TO NEXT INSTRUCTION)
;    2548  3             CLRVEC (4);                             ! CLEAR LOCATION 4 TRAP VECTOR ADDRESS
;    2549  3
;    2550  3             if .NEX                                 ! IF NEX TRAP OCCURRED
;    2551  3             then
;    2552  4                 begin
;    2553  4                 C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR_HRD] + 1;
;    2554  4
;    2555  4                 if .APT_MODE
;    2556  4                 then
;    2557  5                     begin
;    2558  5                     .MAIL_BOX_TESTNUM = 1;
;    2559  5                     .MAIL_BOX_SUBTST = 0;
;    2560  4                     end;
;    2561  4
;    2562  4                 ERRDF (10, EGD_10, EMS_10);         ! REGISTER EXISTENCE TEST FAILED
;    2563  4                 SETPRI (PRI00);                     ! LOWER PRIORITY
;    2564  4                 return FAILURE;
;    2565  4                 end
;    2566  3             else
;    2567  3                 OF_RC = .OF_RC - 2;                 ! SET UP FOR IP REG OR QUIT
;    2568  3
;    2569  3             end
;    2570  2         until .OF_RC lss 0;
;    2571  2
```

```
;  2572  2          return SUCCESS;
;  2573  1          end;


                                                .SBTTL  REG.EXIST INITIALIZATION TEST ROUTINES
000000  004137  000000G                  REG.EXIST::
                                                JSR     R1,$SAVE2                       ;                                       2519
000004  123727  000000G 000005                  CMPB    ENTRY.REASON,#5                 ;                                       2535
000012  001472                                  BEQ     4$                              ;                                       2537
000014  012737  000002  000000G                MOV     #2,OF.RC                        ;                                       2539
000022  005037  000000G                  1$:     CLR     NEX                             ;                                       2543
000026  012746  000340                          MOV     #340,-(SP)                      ;                                       2544
000032  012746  000000G                          MOV     #NEX.TRAP,-(SP)
000036  012746  000004                          MOV     #4,-(SP)
000042  012746  000003                          MOV     #3,-(SP)
000046  104437                                  TRAP    37
000050  013700  000000G                          MOV     RDRX.ADDR,R0                    ;                                       2545
000054  063700  000000G                          ADD     OF.RC,R0
000060  011001                                  MOV     (R0),R1                         ; *,DUMMY.0
000062  005002                                  CLR     R2                              ; DUMMY.1                               2546
000064  012700  000004                          MOV     #4,R0                           ;                                       2548
000070  104436                                  TRAP    36
000072  032737  000001  000000G                BIT     #1,NEX                          ;                                       2550
000100  001427                                  BEQ     3$
000102  013700  000000G                          MOV     CCTLR,R0                        ;                                       2553
000106  006300                                  ASL     R0
000110  105260  000000G                          INCB    C.ERR.TBL(R0)
000114  032737  000001  001254'                BIT     #1,APT.MODE                     ;                                       2555
000122  001405                                  BEQ     2$
000124  012777  000001  001256'                MOV     #1,@MAIL.BOX.TESTNUM            ;                                       2558
000132  005077  001260'                        CLR     @MAIL.BOX.SUBTST                ;                                       2559
000136  104455                          2$:     TRAP    55                              ;                                       2562
000140  000012                                  .WORD   12
000142  000000G                                .WORD   EGD.10
000144  000000G                                .WORD   EMS.10
000146  005000                                  CLR     R0                              ;                                       2563
000150  104441                                  TRAP    41
000152  062706  000010                          ADD     #10,SP                          ;                                       2564
000156  000413                                  BR      5$                              ;                                       2552
000160  162737  000002  000000G          3$:     SUB     #2,OF.RC                        ;                                       2567
000166  062706  000010                          ADD     #10,SP                          ;                                       2542
000172  005737  000000G                          TST     OF.RC                           ;                                       2570
000176  002311                                  BGE     1$
000200  012700  000001                  4$:     MOV     #1,R0                           ;                                       2529
000204  000207                                  RTS     PC
000206  005000                          5$:     CLR     R0                              ;                                       2519
000210  000207                                  RTS     PC

; Routine Size:  69 words,      Routine Base:  $CODE$ + 2424
; Maximum stack depth per invocation,  9 words
```

```
;    2574  1      GLOBAL rout ne VEC_BR TEST =
;    2575  1
;    2576  1      !+
;    2577  1      !       THIS ROUTINE ATTEMPTS TO VERIFY (A) THAT THE RDRX VECTOR ADDRESS GIVEN
;    2578  1      !       BY THE USER DURING THE HW DIALOG IS VALID, AND (B) THAT THE
;    2579  1      !       USER SPECIFIED BUS REQUEST LEVEL FOR THE DEVICE IS CORRECT. THE FIRST
;    2580  1      !       OBJECTIVE IS ACCOMPLISHED BY SETTING THE CPU PRIORITY TO 0 AND FORCING
;    2581  1      !       AN RDRX INTERRUPT. IF THE USER SPECIFIED AN INCORRECT VECTOR ADDRESS,
;    2582  1      !       THEN THE RESULT MAY BE UNPREDICTABLE. FOR THIS REASON, THE MESSAGE
;    2583  1      !       "FUNCTIONAL TEST STARTED' IS PRINTED BEFORE THE TEST, AND
;    2584  1      !       "EXERCISER STARTED" IS PRINTED AT ITS SUCCESSFUL CONCLUSION. IF
;    2585  1      !       EITHER "FUNCTIONAL TEST ..." OR "EXERCISER ..." DOES NOT APPEAR, THEN
;    2586  1      !       PROGRAM CONTROL IS ASSUMED LOST AND A FATAL TRAP IS LIKELY TO OCCUR. AT
;    2587  1      !       THIS POINT, THE EXERCISER MUST BE STARTED AGAIN.
;    2588  1      !
;    2589  1      !       IF THIS TEST SUCCEEDS, THEN THE BR LEVEL TEST IS RUN BY SETTING THE
;    2590  1      !       PROCESSOR PRIORITY TO THE ASSUMED INTERRUPT PRIORITY GIVEN BY THE
;    2591  1      !       USER. A FORCED INTERRUPT SHOULD NOT OCCURR. THEN, BY LOWERING THE
;    2592  1      !       PRIORITY BY ONE, THE DELAYED INTERRUPT SHOULD OCCUR.
;    2593  1      !
;    2594  1
;    2595  2          begin
;    2596  2
;    2597  2          if .ENTRY_REASON eql NEW_PASS
;    2598  2          then
;    2599  3              begin
;    2600  3              SETPRI (PRI00);                         ! LOWER PRIORITY
;    2601  3              return SUCCESS;                         ! SKIP TEST IF NEXT PASS
;    2602  2              end;
;    2603  2
;    2604  2          PRINTF (MSG_02);                            ! 'FUNCTIONAL TEST STARTED"
;    2605  2
;    2606  2          if INT_GEN () eql FALSE                     ! FORCE AN INTERRUPT
;    2607  2          then
;    2608  3              begin                                   ! IF INTERRUPT DID NOT OCCUR
;    2609  3              C_ERR_TBL [.CCTLR, C ERR_HRD] = .C_ERR TBL [.CCTLR, C ERR_HRD] + 1;
;    2610  3
;    2611  3              if .APT_MODE
;    2612  3              then
;    2613  4                  begin
;    2614  4                  .MAIL BOX TESTNUM = 1;
;    2615  4                  .MAIL BOX_SUBTST = 0;
;    2616  3                  end;
;    2617  3
;    2618  3              ERRDF (11, EGD_11, 0);                  ! VECTOR TEST FAILED
;    2619  3              return FAILURE;
;    2620  3              end
;    2621  2          else
;    2622  3              begin                                   ! INTERRUPT DID OCCUR
;    2623  3              PRINTF (MSG 03);                        ! "EXERCISER STARTED"
;    2624  3              SETPRI (.BRLEVEL);                      ! SET PRIORITY TO ASSUMED BR LEVEL
;    2625  3
;    2626  3              if INT GEN () eql FALSE                 ! FORCE AN INTERRUPT (SHOULD NOT OCCUR)
```

```
;  2627  3              then
;  2628  4                  begin                                   ! IF INTERRUPT DID NOT OCCUR
;  2629  4                  SETPRI (.BRLEVEL    %o 40');            ! LOWER PRIORITY BY 1
;  2630  4                  DELAY (1);                              ! WAIT
;  2631  4                  BREAK;                                  ! MMM
;  2632  4
;  2633  4                  if .DCT_ADDR [SA SAVE] neq 0            ! IF INTERRUPT DID OCCUR (SA SAVE WOULD BE NON-ZERO)
;  2634  4                  then
;  2635  5                      begin
;  2636  5                      SETPRI (PRI00);                     ! RESTORE PROCESSOR PRIORITY TO 0
;  2637  5                      return SUCCESS;                     ! ONLY SUCCESSFUL EXIT POINT
;  2638  4                      end;
;  2639  4
;  2640  3                  end;
;  2641  3
;  2642  2              end;
;  2643  2
;  2644  2          SETPRI (PRI00);                                 ! COME HERE ONLY FOR BR TEST FAILURE
;  2645  2          C_ERR_TBL [.CCTLR, C ERR HRD] = .C ERR TBL [.CCTLR, C ERR HRD] + 1;
;  2646  2
;  2647  2          if .APT_MODE
;  2648  2          then
;  2649  3              begin
;  2650  3              .MAIL_BOX TESTNUM = 1;
;  2651  3              .MAIL_BOX SUBTST = 0;
;  2652  2              end;
;  2653  2
;  2654  2          ERRDF (12, EGD_12, EMS 12);
;  2655  2          return FAILURE;
;  2656  1          end;

                                        .GLOBL  L$DLY

                                        .SBTTL  VEC.BR.TEST INITIALIZATION TEST ROUTINES
000000  010146                  VEC.BR.TEST::
                                        MOV     R1,-(SP)                ;                       2574
000002  005746                          TST     (SP)
000004  123727  000000G 000005         CMPB    ENTRY.REASON,#5         ;                       2597
000012  001003                          BNE     1$
000014  005000                          CLR     R0                      ;                       2600
000016  104441                          TRAP    41
000020  000505                          BR      8$                      ;                       2599
000022  012746  000000G          1$:    MOV     #MSG.02,-(SP)           ;                       2604
000026  012746  000001                  MOV     #1,-(SP)
000032  010600                          MOV     SP,R0                   ; SP,*
000034  104417                          TRAP    17
000036  004737  000000V                 JSR     PC,INT.GEN              ;                       2606
000042  005700                          TST     R0
000044  001023                          BNE     3$
000046  013700  000000G                 MOV     CCTLR,R0                ;                       2609
000052  006300                          ASL     R0
```

```
000054  105260  000000G                        INCB    C.ERR.TBL(R0)
000060  032737  000001  001254'                BIT     #1,APT.MODE             ;                       2611
000066  001405                                  BEQ     2$
000070  012777  000001  001256'                MOV     #1,@MAIL.BOX.TESTNUM    ;                       2614
000076  005077  001260'                        CLR     @MAIL.BOX.SUBTST        ;                       2615
000102  104455                          2$:   TRAP    55                      ;                       2618
000104  000013                                .WORD   13
000106  000000G                               .WORD   EGD.11
000110  000000                                .WORD   0
000112  000500                                BR      11$                     ;                       2619
000114  012716  000000G                 3$:   MOV     #MSG.03,(SP)            ;                       2623
000120  012746  000001                        MOV     #1, (SP)
000124  010600                                MOV     SP,R0                   ; SP,*
000126  104417                                TRAP    17
000130  013700  000000G                        MOV     BRLEVEL,R0              ;                       2624
000134  104441                                TRAP    41
000136  004737  000000V                        JSR     PC,INT.GEN              ;                       2626
000142  005700                                TST     R0
000144  001036                                BNE     9$
000146  013700  000000G                        MOV     BRLEVEL,R0              ;                       2629
000152  162700  000040                        SUB     #40,R0
000156  104441                                TRAP    41
000160  012701  000001                        MOV     #1,R1                   ; *,$$TMP2              2630
000164  001411                          4$:   BEQ     7$
000166  013700  000000G                        MOV     L$DLY,R0                ; *,$$TMP1
000172  001404                                BEQ     6$
000174  005066  000006                  5$:   CLR     6(SP)                   ; $$TMP
000200  005300                                DEC     R0                      ; $$TMP1
000202  001374                                BNE     5$
000204  005301                          6$:   DEC     R1                      ; $$TMP2
000206  000766                                BR      4$
000210  104422                          7$:   TRAP    22
000212  013700  000000G                        MOV     DCT.ADDR,R0             ;                       2633
000216  005760  000002                        TST     2(R0)
000222  001407                                BEQ     9$
000224  005000                                CLR     R0                      ;                       2636
000226  104441                                TRAP    41
000230  062706  000006                        ADD     #6,SP                   ;                       2637
000234  012700  000001                  8$:   MOV     #1,R0                   ;                       2635
000240  000427                                BR      12$
000242  005726                          9$:   TST     (SP)+                   ;                       2622
000244  005000                                CLR     R0                      ;                       2644
000246  104441                                TRAP    41
000250  013700  000000G                        MOV     CCTLR,R0                ;                       2645
000254  006300                                ASL     R0
000256  105260  000000G                        INCB    C.ERR.TBL(R0)
000262  032737  000001  001254'                BIT     #1,APT.MODE             ;                       2647
000270  001405                                BEQ     10$
000272  012777  000001  001256'                MOV     #1,@MAIL.BOX.TESTNUM    ;                       2650
000300  005077  001260'                        CLR     @MAIL.BOX.SUBTST        ;                       2651
000304  104455                         10$:   TRAP    55                      ;                       2654
000306  000014                                .WORD   14
000310  000000G                               .WORD   EGD.12
```

```
000312  000000G                             .WORD   EMS.12
000314  022626                      11$:    CMP     (SP)+,(SP)+                     ;                       2655
000316  005000                              CLR     R0                              ;                       2574
000320  005726                      12$:    TST     (SP)+
000322  012601                              MOV     (SP)+,R1
000324  000207                              RTS     PC

; Routine Size:  107 words,    Routine Base:  $CODE$ + 2636
; Maximum stack depth per invocation:  7 words
```

```
;    2657  1     GLOBAL routine INT_GEN =
;    2658  1
;    2659  1     !*
;    2660  1     !       THIS ROUTINE BEGINS AN RDRX INITIALIZATION SEQUENCE, BUT ONLY
;    2661  1     !       COMPLETES THROUGH THE STEP 1 WRITE. ITS PURPOSE IS TO CREATE AN RDRX
;    2662  1     !       INTERRUPT (AT THE COMPLETEION OF STEP 1) IN ORDER TO HELP VERIFY THE
;    2663  1     !       THE USER-SPECIFIED VECTOR ADDRESS AND BUS REQUEST INTERRUPT LEVEL.
;    2664  1     !       A VALUE OF "TRUE" IS RETURNED TO THE CALLER IF AN INTERRUPT OCCURS,
;    2665  1     !       AND "FALSE" OTHERWISE. THE INTERRUPT IS VERIFIED BY A NON-ZERO VALUE
;    2666  1     !       IN THE "SA SAVE" WORD IN THE DEVICE'S DCT.
;    2667  1     !
;    2668  1
;    2669  2         begin
;    2670  2
;    2671  2         local
;    2672  2             SA : word;                                          ! STORAGE FOR STEP 1 READ AND WRITE
;    2673  2
;    2674  2         DCT_ADDR [SA_SAVE] = 0;                                 ! ZERO OUT SA SAVE WORD IN DCT
;    2675  2         WRT_RDRX (RCIP, RC_ALL, ALL_ONES);                      ! WRITE IP TO START INIT SEQUENCE
;    2676  2         DELAY (2);                                              ! WAIT
;    2677  2         BREAK;                                                  ! MMM
;    2678  2         INCR COUNT FROM 1 TO 500 DO                             !MAKE SURE WE GET INTO STEP 1  ZZZ
;    2679  3             BEGIN                                               !BEFORE STEP 1 WRITE           ZZZ
;    2680  3             SA = .RDRX_ADDR [RCSA, RC_ALL];                     ! STEP 1 READ
;    2681  3               IF (.SA AND S1_MASK) EQL SA_S1                    !DID WE GET THE S1 BIT?        ZZZ
;    2682  3               THEN                                              !                              ZZZ
;    2683  3               EXITLOOP;                                         !EXIT IF SO                    ZZZ
;    2684  3             DELAY (1);                                          !                              ZZZ
;    2685  3             BREAK;                                              !                              MMM
;    2686  2             END;                                                !                              ZZZ
;    2687  2
;    2688  2        SA = (WR_RING + 8) or (.CURRENT_VECTOR + -2) or SA_INT;  ! STEP 1 WRITE VALUE
;    2689  2         WRT_RDRX (RCSA, RC_ALL, .SA);                           ! STEP 1 WRITE
;    2690  2
;    2691  2         incr COUNT from 1 to 8000 do
;    2692  3             begin
;    2693  3             DELAY (1);                                          ! TOTAL DELAY COUNT OF 8,000
;    2694  3
;    2695  3             if .DCT_ADDR [SA_SAVE] neq 0                        ! IF SA WAS CHANGED
;    2696  3             then
;    2697  3                 return TRUE;                                    ! INTERRUPT OCCURED
;    2698  3
;    2699  3             BREAK;
;    2700  2             end;
;    2701  2
;    2702  2         return FALSE;                                           ! IF INTERRUPT DID NOT OCCUR
;    2703  1         end;


                                        .SBTTL  INT.GEN INITIALIZATION TEST ROUTINES
000000  004137  000000G          INT.GEN::
                                        JSR     R1,$SAVE3                       ;                                   2657
000004  024646                          CMP     -(SP),-(SP)
```

```
000006  013700  000000G                 MOV     DCT.ADDR,R0             ;                               2674
000012  005060  000002                   CLR     2(R0)
000016  012700  177777                   MOV     #-1,R0                  ; *,RC.REG                      2675
000022  010077  000000G                  MOV     R0,@RDRX.ADDR           ; RC.REG,*
000026  012701  000002                   MOV     #2,R1                   ; *,$$TMP2                      2676
000032  001411                   1$:     BEQ     4$
000034  013700  000000G                  MOV     L$DLY,R0                ; *,$$TMP1
000040  001404                           BEQ     3$
000042  005066  000002           2$:     CLR     2(SP)                   ; $$TMP
000046  005300                           DEC     R0                      ; $$TMP1
000050  001374                           BNE     2$
000052  005301                   3$:     DEC     R1                      ; $$TMP2
000054  000766                           BR      1$
000056  104422                   4$:     TRAP    22
000060  012703  000764                   MOV     #764,R3                 ; *,COUNT                       2678
000064  013700  000000G          5$:     MOV     RDRX.ADDR,R0            ;                               2680
000070  016016  000002                   MOV     2(R0),(SP)              ; *,RC.REG
000074  011602                           MOV     (SP),R2                 ; RC.REG,SA
000076  010200                           MOV     R2,R0                   ; SA,*                          2681
000100  042700  001777                   BIC     #1777,R0
000104  020027  004000                   CMP     R0,#4000
000110  001417                           BEQ     10$                     ;                               2683
000112  012701  000001                   MOV     #1,R1                   ; *,$$TMP2                      2684
000116  001411                   6$:     BEQ     9$
000120  013700  000000G                  MOV     L$DLY,R0                ; *,$$TMP1
000124  001404                           BEQ     8$
000126  005066  000002           7$:     CLR     2(SP)                   ; $$TMP
000132  005300                           DEC     R0                      ; $$TMP1
000134  001374                           BNE     7$
000136  005301                   8$:     DEC     R1                      ; $$TMP2
000140  000766                           BR      6$
000142  104422                   9$:     TRAP    22
000144  005303                           DEC     R3                      ; COUNT                         2678
000146  001346                           BNE     5$
000150  013700  001246'          10$:    MOV     CURRENT.VECTOR,R0       ;                               2688
000154  006200                           ASR     R0
000156  006200                           ASR     R0
000160  010002                           MOV     R0,R2                   ; *,SA
000162  052702  111200                   BIS     #111200,R2              ; *,SA
000166  010201                           MOV     R2,R1                   ; SA,RC.REG                     2689
000170  013700  000000G                  MOV     RDRX.ADDR,R0
000174  010160  000002                   MOV     R1,2(R0)                ; RC.REG,*
000200  012702  017500                   MOV     #17500,R2               ; *,COUNT                       2691
000204  012701  000001           11$:    MOV     #1,R1                   ; *,$$TMP2                      2693
000210  001411                   12$:    BEQ     15$
000212  013700  000000G                  MOV     L$DLY,R0                ; *,$$TMP1
000216  001404                           BEQ     14$
000220  005066  000002           13$:    CLR     2(SP)                   ; $$TMP
000224  005300                           DEC     R0                      ; $$TMP1
000226  001374                           BNE     13$
000230  005301                   14$:    DEC     R1                      ; $$TMP2
000232  000766                           BR      12$
000234  013700  000000G          15$:    MOV     DCT.ADDR,R0             ;                               2695
```

```
000240  005760  000002                          TST     2(R0)
000244  001403                                  BEQ     16$
000246  012700  000001                          MOV     #1,R0                   ;                               2697
000252  000404                                  BR      17$
000254  104422                          16$:    TRAP    22
000256  005302                                  DEC     R2                      ; COUNT                         2691
000260  001351                                  BNE     11$
000262  005000                                  CLR     R0                      ;                               2669
000264  022626                          17$:    CMP     (SP)+,(SP)+             ;                               2657
000266  000207                                  RTS     PC

; Routine Size:  92 words,      Routine Base:  $CODE$ + 3164
; Maximum stack depth per invocation:  8 words
```

```
;    2704  1      GLOBAL routine HARD_INIT =
;    2705  1
;    2706  1      !+
;    2707  1      !       THIS ROUTINE PERFORMS THE FOUR READ / WRITE STEPS REQUIRED TO
;    2708  1      !       INITIALIZE AN RDRX DEVICE. IF NO READ ERRORS ARE DETECTED IN ANY OF
;    2709  1      !       THE FOUR STEPS, THEN A SUCCESS VALUE IS RETURNED TO THE CALLER.
;    2710  1      !       OTHERWISE, ADDITIONAL ATTEMPTS MAY BE MADE TO INITIALIZE THE DEVICE.
;    2711  1      !       IF ALL ATTEMPTS FAIL, A FAILURE INDICATION IS RETURNED.
;    2712  1      !-
;    2713  1
;    2714  2          begin
;    2715  2
;    2716  2          local
;    2717  2              IE_VEC : word;                                  ! IE-BIT AND VECTOR-ADDRESS/4 BYTE
;    2718  2                                                              !   (USED IN STEP 1 WRITE AND STEP 3 READ)
;    2719  2
;    2720  2          IE_VEC = .CURRENT_VECTOR + 2;                       ! GET VECTOR ADDR/4 (IE = 0)
;    2721  2
;    2722  2          incr ATTEMPTS from 1 to INI_ATT do
;    2723  3              begin
;    2724  3
;    2725  3              label
;    2726  3                  STEP_1_READ,
;    2727  3                  STEP_2_READ,
;    2728  3                  STEP_3_READ,
;    2729  3                  STEP_4_READ;
;    2730  3
;    2731  3              WRT_RDRX (RCIP, RC_ALL, ALL ONES);              ! WRITE IP TO START INIT SEQUENCE
;    2732  3      !
;    2733  3      !       STEP 1 READ
;    2734  3      !
;    2735  3              STEP = 1;
;    2736  3              STEP_1_READ:
;    2737  4                  begin
;    2738  4
;    2739  4                  incr COUNT from 1 to 500 do
;    2740  5                      begin
;    2741  5                      DELAY (1);                              ! TOTAL DELAY COUNT OF 500 FOR STEP 1
;    2742  5                      SA_REG = .RDRX_ADDR [RCSA, RC_ALL];     ! READ SA
;    2743  5
;    2744  5                      if (.SA_REG and S1_MASK) eql SA_S1      ! IF STEP 1 READ IS O.K.
;    2745  5                      then
;    2746  5                          leave STEP_1_READ;
;    2747  5
;    2748  5                      BREAK;
;    2749  4                      end;
;    2750  4
;    2751  4                  exitloop;
;    2752  3                  end;
;    2753  3
;    2754  3      !
;    2755  3      !       STEP 1 WRITE
;    2756  3      !
```

```
;  2757  3              SA_REG = (WR_RING ^ 8) or .IE_VEC;                      ! STEP 1 WRITE VALUE
;  2758  3              WRT_RDRX (RCSA, RC_ALL, .SA_REG);                       ! STEP 1 WRITE
;  2759  3      !
;  2760  3      !       STEP 2 READ
;  2761  3      !
;  2762  3              STEP = .STEP + 1;
;  2763  3              STEP_2_READ:
;  2764  4                  begin
;  2765  4
;  2766  4                  incr COUNT from 1 to 10000 do
;  2767  5                      begin
;  2768  5                      DELAY (1);                                      ! TOTAL DELAY COUNT OF 10,000 FOR STEP 2
;  2769  5                      SA_REG = .RDRX_ADDR [RCSA, RC_ALL];             ! READ SA
;  2770  5
;  2771  6                      if (.SA_REG and S2_MASK) eql (SA_S2 or WR_RING) ! IF STEP 2 READ IS O.K.
;  2772  5                      then
;  2773  5                          leave STEP_2_RFAD;
;  2774  5
;  2775  5                      BREAK;
;  2776  4                      end;
;  2777  4
;  2778  4                  exitloop;
;  2779  3                  end;
;  2780  3
;  2781  3      !
;  2782  3      !       STEP 2 WRITE
;  2783  3      !
;  2784  3              WRT_RDRX (RCSA, RC_ALL, .DCT_ADDR [RR BEG]);            ! RINGBASE LO, PI = 0
;  2785  3      !
;  2786  3      !       STEP 3 READ
;  2787  3      !
;  2788  3              STEP = .STEP + 1;
;  2789  3              STEP_3_READ:
;  2790  4                  begin
;  2791  4
;  2792  4                  incr COUNT from 1 to 10000 do
;  2793  5                      begin
;  2794  5                      DELAY (1);                                      ! TOTAL DELAY COUNT OF 10,000 FOR STEP 3 READ
;  2795  5                      SA_REG = .RDRX_ADDR [RCSA, RC_ALL];             ! READ SA
;  2796  5
;  2797  6                      if (.SA_REG and S3_MASK) eql (SA_S3 or .IE_VEC) ! IF STEP 3 READ IS O.K.
;  2798  5                      then
;  2799  5                          leave STEP 3_READ;
;  2800  5
;  2801  5                      BREAK;
;  2802  4                      end;
;  2803  4
;  2804  4                  exitloop;
;  2805  3                  end;
;  2806  3
;  2807  3      !
;  2808  3      !       STEP 3 WRITE
;  2809  3      !
```

```
;    2810  3              WRT_RDRX (RCSA, RC_ALL, 0);                                 ! PP, RINGBASE-HI = 0
;    2811  3      !
;    2812  3      !       STEP 4 READ
;    2813  3      !
;    2814  3              STEP = .STEP + 1;
;    2815  3              STEP_4_READ:
;    2816  4                  begin
;    2817  4
;    2818  4                  incr COUNT from 1 to 10000 do
;    2819  5                      begin
;    2820  5                      DELAY (1);                                          ! TOTAL DELAY COUNT OF 10,000 FOR STEP 4 READ
;    2821  5                      SA_REG = .RDRX_ADDR [RCSA, RC_ALL];                 ! READ SA
;    2822  5
;    2823  5                      if (.SA_REG and S4 MASK) eql SA_S4                  ! IF STEP 4 READ IS O.K.
;    2824  5                      then
;    2825  5                          leave STEP_4_READ;
;    2826  5
;    2827  5                      BREAK;
;    2828  4                      end;
;    2829  4
;    2830  4                  exitloop;
;    2831  3                  end;
;    2832  3      !
;    2833  3      !       STEP 4 WRITE
;    2834  3      !
;    2835  3              CREDIT_BAL = 1;                                             ! START WITH A CREDIT BALANCE = 1
;    2836  3              WRT_RDRX (RCSA, RC_ALL, 0);                                 ! BURST, LF, GO = 0
;    2837  3              return SUCCESS;                                             ! SUCCESS EXIT POINT
;    2838  3
;    2839  2              end;                                                        ! TRY AGAIN OR GIVE UP
;    2840  2
;    2841  2          CREDIT_BAL = 0;                                                 ! NO CREDIT BALANCE
;    2842  2          C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR_HRD] + 1;
;    2843  2
;    2844  2          if .APT_MODE
;    2845  2          then
;    2846  3              begin
;    2847  3              .MAIL_BOX_TESTNUM = 1;
;    2848  3              .MAIL_BOX_SUBTST = 0;
;    2849  2              end;
;    2850  2
;    2851  2          ERRDF (13, EGD_13, EMS_13);                                     ! INIT SEQUENCE FAILED
;    2852  2          return FAILURE;
;    2853  1          end;                                                            ! ROUTINE HARD_INIT


                                        .SBTTL  HARD.INIT INITIALIZATION TEST ROUTINES
000000  004137  000000G           HARD.INIT::
                                        JSR     R1,$SAVE5                           ;                                       2704
000004  162706  000012                  SUB     #12,SP
000010  013704  001246'                 MOV     CURRENT.VECTOR,R4                   ; #,IE.VEC                              2720
000014  006204                          ASR     R4                                  ; IE.VEC
000016  006204                          ASR     R4                                  ; IE.VEC
```

```
000020  012705  000002                          MOV     #2,R5                           ; *,ATTEMPTS                    2722
000024  012700  177777                          MOV     #-1,R0                          ; *,RC.REG                      2731
000030  010077  000000G                         MOV     R0,@RDRX.ADDR                   ; RC.REG,*
000034  012737  000001  000000G                 MOV     #1,STEP                         ;                               2735
000042  012702  000764                          MOV     #764,R2                         ; *,COUNT                       2739
000046  012701  000001                  1$:     MOV     #1,R1                           ; *,$$TMP2                      2741
000052  001411                          2$:     BEQ     5$
000054  013700  000000G                         MOV     L$DLY,R0                        ; *,$$TMP1
000060  001404                                  BEQ     4$
000062  005066  000010                  3$:     CLR     10(SP)                          ; $$TMP
000066  005300                                  DEC     R0                              ; $$TMP1
000070  001374                                  BNE     3$
000072  005301                          4$:     DEC     R1                              ; $$TMP2
000074  000766                                  BR      2$
000076  013700  000000G                  5$:     MOV     RDRX.ADDR,R0                    ;                               2742
000102  016016  000002                          MOV     2(R0),(SP)                      ; *,RC.REG
000106  011637  000000G                         MOV     (SP),SA.REG                     ; RC.REG,*
000112  011600                                  MOV     (SP),R0                         ; SA.REG,*                      2744
000114  042700  001777                          BIC     #1777,R0
000120  020027  004000                          CMP     R0,#4000
000124  001404                                  BEQ     6$                              ;                               2746
000126  104422                                  TRAP    22
000130  005302                                  DEC     R2                              ; COUNT                         2739
000132  001345                                  BNE     1$                              ;                               2723
000134  000532                                  BR      18$
000136  010437  000000G                  6$:     MOV     R4,SA.REG                       ; IE.VEC,*                      2757
000142  052737  111000  000000G                 BIS     #111000,SA.REG
000150  013701  000000G                         MOV     SA.REG,R1                       ; *,RC.REG                      2758
000154  013700  000000G                         MOV     RDRX.ADDR,R0
000160  010160  000002                          MOV     R1,2(R0)                        ; RC.REG,*
000164  005237  000000G                         INC     STEP                            ;                               2762
000170  012702  023420                          MOV     #23420,R2                       ; *,COUNT                       2766
000174  012701  000001                  7$:     MOV     #1,R1                           ; *,$$TMP2                      2768
000200  001411                          8$:     BEQ     11$
000202  013700  000000G                         MOV     L$DLY,R0                        ; *,$$TMP1
000206  001404                                  BEQ     10$
000210  005066  000010                  9$:     CLR     10(SP)                          ; $$TMP
000214  005300                                  DEC     R0                              ; $$TMP1
000216  001374                                  BNE     9$
000220  005301                          10$:    DEC     R1                              ; $$TMP2
000222  000766                                  BR      8$
000224  013700  000000G                  11$:    MOV     RDRX.ADDR,R0                    ;                               2769
000230  016066  000002  000002                  MOV     2(R0),2(SP)                     ; *,RC.REG
000236  016637  000002  000C00G                 MOV     2(SP),SA.REG                    ; RC.REG,*
000244  016600  000002                          MOV     2(SP),R0                        ; SA.REG,*                      2771
000250  042700  003400                          BIC     #3400,R0
000254  020027  010222                          CMP     R0,#10222
000260  001404                                  BEQ     12$                             ;                               2773
000262  104422                                  TRAP    22
000264  005302                                  DEC     R2                              ; COUNT                         2766
000266  001342                                  BNE     7$
000270  000537                                  BR      26$                             ;                               2723
000272  013700  000000G                  12$:    MOV     DCT.ADDR,R0                     ;                               2784
```

```
000276  016001  000004                          MOV     4(R0),R1                ; *,RC.REG
000302  013700  000000G                         MOV     RDRX.ADDR,R0
000306  010160  000002                          MOV     R1,2(R0)                ; RC.REG,*
000312  005237  000000G                         INC     STEP                    ;                                       2788
000316  010403                                  MOV     R4,R3                   ; IE.VEC,*                              2797
000320  052703  020000                          BIS     #20000,R3
000324  012702  023420                          MOV     #23420,R2               ; *,COUNT                               2792
000330  012701  000001                  13$:    MOV     #1,R1                   ; *,$$TMP2                              2794
000334  001411                          14$:    BEQ     17$
000336  013700  000000G                         MOV     L$DLY,R0                ; *,$$TMP1
000342  001404                                  BEQ     16$
000344  005066  000010                  15$:    CLR     10(SP)                  ; $$TMP
000350  005300                                  DEC     R0                      ; $$TMP1
000352  001374                                  BNE     15$
000354  005301                          16$:    DEC     R1                      ; $$TMP2
000356  000766                                  BR      14$
000360  013700  000000G                 17$:    MOV     RDRX.ADDR,R0            ;                                       2795
000364  016066  000002  000004                 MOV     2(R0),4(SP)             ; *,RC.REG
000372  016637  C00004  000000G                 MOV     4(SP),SA.REG            ; RC.REG,*
000400  016600  000004                          MOV     4(SP),R0                ; SA.REG,*                              2797
000404  042700  003400                          BIC     #3400,R0
000410  020003                                  CMP     R0,R3
000412  001404                                  BEQ     19$                     ;                                       2799
000414  104422                                  TRAP    22
000416  005302                                  DEC     R2                      ; COUNT                                 2792
000420  001343                                  BNE     13$
000422  000462                          18$:    BR      26$                     ;                                       2723
000424  013700  000000G                 19$:    MOV     RDRX.ADDR,R0            ;                                       2810
000430  005060  000002                          CLR     2(R0)
000434  005237  000000G                         INC     STEP                    ;                                       2814
000440  012703  023420                          MOV     #23420,R3               ; *,COUNT                               2818
000444  012701  000001                  20$:    MOV     #1,R1                   ; *,$$TMP2                              2820
000450  001411                          21$:    BEQ     24$
000452  013700  000000G                         MOV     L$DLY,R0                ; *,$$TMP1
000456  001404                                  BEQ     23$
000460  005066  000010                  22$:    CLR     10(SP)                  ; $$TMP
000464  005300                                  DEC     R0                      ; $$TMP1
000466  001374                                  BNE     22$
000470  005301                          23$:    DEC     R1                      ; $$TMP2
000472  000766                                  BR      21$
000474  013700  000000G                 24$:    MOV     RDRX.ADDR,R0            ;                                       2821
000500  016066  000002  000006                 MOV     2(R0),6(SP)             ; *,RC.REG
000506  016637  000006  000000G                 MOV     6(SP),SA.REG            ; RC.REG,*
000514  016600  000006                          MOV     6(SP),R0                ; SA.REG,*                              2823
000520  042700  003777                          BIC     #3777,R0
000524  020027  040000                          CMP     R0,#40000
000530  001404                                  BEQ     25$                     .                                       2825
000532  104422                                  TRAP    22
000534  005303                                  DEC     R3                      ; COUNT                                 2818
000536  001342                                  BNE     20$
000540  000413                                  BR      26$                     ;                                       2723
000542  012737  000001  000000G         25$:    MOV     #1,CREDIT.BAL           ;                                       2835
000550  005001                                  CLR     R1                      ; RC.REG                                2836
```

```
000552  013700  000000G                        MOV     RDRX.ADDR,R0
000556  005060  000002                         CLR     2(R0)
000562  012700  000001                         MOV     #1,R0                   ;                       2723
000566  000425                                 BR      28$
000570  005037  000000G             26$:        CLR     CREDIT.BAL              ;                       2841
000574  013700  000000G                        MOV     CCTLR,R0                ;                       2842
000600  006300                                 ASL     R0
000602  105260  000000G                        INCB    C.ERR.TBL(R0)
000606  032737  000001  001254'               BIT     #1,APT.MODE             ;                       2844
000614  001405                                 BEQ     27$
000616  012777  000001  001256                 MOV     #1,@MAIL.BOX.TESTNUM    ;                       2847
000624  005077  001260'                        CLR     @MAIL.BOX.SUBTST        ;                       2848
000630  104455                     27$:        TRAP    55                      ;                       2851
000632  000015                                 .WORD   15
000634  000000G                                .WORD   EGD.13
000636  000000G                                .WORD   EMS.13
000640  005000                                 CLR     R0                      ;                       2714
000642  062706  000012             28$:        ADD     #12,SP                  ;                       2704
000646  000207                                 RTS     PC

; Routine Size:  212 words,     Routine Base:  $CODE$ + 3454
; Maximum stack depth per invocation:  13 words
```

```
;    2854  1      GLOBAL rout ne INI RRING . novalue =
;    2855  1
;    2856  1      !*
;    2857  1      !       THIS ROUTINE IS RESPONSIBLE FOR ALLOCATING ENOUGH MSCP PACKETS TO
;    2858  1      !       FILL AN RDRX RESPONSE RING. THE BUFFER DESCRIPTOR OF EACH PACKET
;    2859  1      !       (LOCATED IN FRONT OF THE PACKET ITSELF) IS LOADED INTO SUCCESSIVE
;    2860  1      !       RRING SLOTS. NOTE THAT THE BUFFER DESCRIPTORS HAVE BEEN INITIALIZED
;    2861  1      !       WITH THE FLAG AND OWNERSHIP BITS SET TO "1", MAKING EACH SLOT
;    2862  1      !       CONTROLLER OWNED.
;    2863  1      !
;    2864  1      !       IMPLICIT INPUTS:
;    2865  1      !               CCTLR   CURRENT CONTROLLER NUMBER
;    2866  1      !               DCT_ADDR   ADDRESS OF CURRENT CONTROLLER S DCT
;    2867  1      !
;    2868  1
;    2869  2          begin
;    2870  2
;    2871  2          local
;    2872  2              index : word,
;    2873  2              RRING_ADDR;
;    2874  2
;    2875  2          RRING_ADDR = .DCT ADDR [RR BEG];                    ! FIRST RESPONSE RING SLOT
;    2876  2
;    2877  2          incr COUNT from 1 to RRING_LEN do
;    2878  3              begin
;    2879  3              index = GET PKT (.CCTLR);                       ! GET AN MSCP PACKET
;    2880  3              .RRING_ADDR = .MSCP_PKT [.index, PKT LO];       ! LOAD LO ORDER BUFF DESC INTO SLOT
;    2881  3              RRING_ADDR = .RRING_ADDR + 2;                   ! ADVANCE TO SECOND WORD
;    2882  3              .RRING_ADDR = .MSCP_PKT [.index, PKT_HI];       ! LOAD HI ORDER BUFF DESC INTO SLOT
;    2883  3              PKT_USE [.index] = .CCTLR;                      ! PACKET IN USE
;    2884  3              .RRING_ADDR = ..RRING_ADDR or ED OWN or ED FLAG;! GIVE OWNERSHIP TO CONTRLLER
;    2885  3              RRING_ADDR = .RRING_ADDR + 2;                   ! ADVANCE TO NEXT SLOT
;    2886  2              end;
;    2887  2
;    2888  1          end;
```

```
                                        .SBTT   INI.RRING INITIALIZATION TEST ROUTINES
000000  004137  000000G          INI.RRING::
                                        JSR     R1,$SAVE4                       ;                                       2854
000004  013700  000000G                 MOV     DCT.ADDR,R0                     ;                                       2875
000010  016001  000004                  MOV     4(R0),R1                        ; *,RRING.ADDR
000014  013703  000000G                 MOV     CCTLR,R3                        ;                                       2879
000020  012704  000004                  MOV     #4,R4                           ; *,COUNT                               2877
000024  010346                  1$:     MOV     R3,-(SP)                        ;                                       2879
000026  004737  000000G                 JSR     PC,GET.PKT
000032  010002                          MOV     R0,R2                           ; *,INDEX
000034  010216                          MOV     R2,(SP)                         ; INDEX,*                               2880
000036  012746  000106                  MOV     #106,-(SP)
000042  004737  000000G                 JSR     PC,BL$MUL
000046  016021  000000G                 MOV     MSCP.PKT(R0),(R1)+              ; *,RRING.ADDR
000052  016011  000002G                 MOV     MSCP.PKT+2(R0),(R1)             ; *,RRING.ADDR                          2882
000056  013703  000000G                 MOV     CCTLR,R3                        ;                                       2883
```

```
000062  110362  000000G                 MOVB    R3,PKT.USE(R2)          ; *,*(INDEX)
000066  052721  140000                  BIS     #140000,(R1)+           ; *,RRING.ADDR                  2894
000072  022626                          CMP     (SP)+,(SP)+             ;                               2878
000074  005304                          DEC     R4                      ; COUNT                         2877
000076  001352                          BNE     1$
000100  000207                          RTS     PC                      ;                               2854

; Routine Size:  33 words,      Routine Base:  $CODE$ + 4324
; Maximum stack depth per invocation:  8 words
```

```
;    2889  1     GLOBAL routine SET_CTLR_CHAR =
;    2890  1
;    2891  1     !+
;    2892  1     !       THIS ROUTINE IS CALLED BY CTLR INIT AFTER THE RDRX HAS BEEN HARD-
;    2893  1     !       INITIALIZED. ITS PURPOSE IS TO FORMAT AND SEND THE "SET CONTROLLER
;    2894  1     !       CHARACTERISTICS" COMMAND, AND TO VALIDATE THE RESPONSE (END MESSAGE).
;    2895  1     !
;    2896  1     !       IMPLICIT INPUTS:
;    2897  1     !               CCTLR - CURRENT CONTROLLER NUMBER
;    2898  1     !-
;    2899  1
;    2900  2         begin
;    2901  2
;    2902  2         local
;    2903  2             P_INDEX : word;
;    2904  2
;    2905  2
;    2906  2     ! MISCELLANEOUS INITIALIZATION                                           !ZZZ
;    2907  2                                                                             !ZZZ
;    2908  2     QIO [.CCTLR] = 0;               !INIT NO OF OUTSTANDING QIOS            !ZZZ
;    2909  2     CST [.CCTLR, U_CNT] = 0;        !CLEAR UNITS IN CST TABLE               !ZZZ
;    2910  2     INCR COUNT FROM 0 TO (RP_CNT   1) DO    !INIT RETURN PACKET POOL        !ZZZ
;    2911  2          RP_USE [.COUNT] = -1;                                              !ZZZ
;    2912  2                                                                             !ZZZ
;    2913  2     IODQ_IN = IODQ_OUT = 0;         !INIT I/O DONE QUEUE POINTERS           !ZZZ
;    2914  2
;    2915  2
;    2916  2         P_INDEX = GET_PKT (.CCTLR);                                 ! GET AN MSCP PACKET
;    2917  2         MSCP_PKT [.P_INDEX, MSGLEN] = SZ_SCC;                       ! PACKET SIZE
;    2918  2         MSCP_PKT [.P_INDEX, OPCODE] = OP_SCC;                       ! OPCODE = SET CTLR CHAR
;    2919  2         MSCP_PKT [.P_INDEX, C_FLAGS] = CF_MASK;                     ! CONTROLLER FLAGS
;    2920  2         MSCP_PKT [.P_INDEX, CMD_TYPE] = IMM_CMD;                    ! IMMEDIATE COMMAND
;    2921  2
;    2922  2         if SEND (.P_INDEX) eql FAILURE                              ! ATTEMPT SEND
;    2923  2         then
;    2924  3             begin                                                   ! IF SEND WAS UNSUCCESSFUL
;    2925  3             C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR_HRD] + 1;
;    2926  3
;    2927  3             if .APT_MODE
;    2928  3             then
;    2929  4                 begin
;    2930  4                 .MAIL_BOX_TESTNUM = 1;
;    2931  4                 .MAIL_BOX_SUBTST = 0;
;    2932  3                 end;
;    2933  3
;    2934  3             ERRDF (20, EGD_20, 0);                                  ! FATAL ERROR
;    2935  3             PUT_PKT (.P_INDEX);                                     ! RETURN PACKET TO POOL
;    2936  3             DROP_CTLR (.CCTLR, DU_CFATAL);                          ! DROP CONTROLLER
;    2937  3             return FAILURE;
;    2938  3             end
;    2939  2         else
;    2940  3             begin                                                   ! IF SEND WAS SUCCESSFUL
;    2941  3
```

```
;    2942  3              do
;    2943  4                  begin
;    2944  4                  WAIT ();                                          ! WAIT FOR RETPKT RESPONSE
;    2945  4                  RP_INDX = OUT_IODQ ();                            ! GET INDEX OF RETPKT
;    2946  4                  RP_ADDR = RETPKT + (.RP_INDX * RP_LEN * 2);       ! CALCULATE RETPKT ADDRESS
;    2947  4
;    2948  4                  if .RP_ADDR [MF_STYP] neq MT_SEQ                  ! RETURN ALL RETPKTS NOT SENT BY CONTROLLER
;    2949  4                  then
;    2950  4                      PUT_RETPKT (.RP_INDX);
;    2951  4
;    2952  4                  end
;    2953  3              until (.RP_ADDR [CONID] eql CID_DRIVER) or
;    2954  4                    ((.RP_ADDR [MESTYP] eql MT_SEQ) and
;    2955  3                     ((.RP_ADDR [ENDCOD] and OP_END) eql OP_END));
;    2956  3
;    2957  3              if .RP_ADDR [CONID] eql CID_DRIVER                    ! IF RETPKT IS FROM "DRIVER"
;    2958  3              then
;    2959  4                  begin
;    2960  4                  PRINTF (DBM23);                                   ! "ERROR IN SET_CTLR_CHAR"
;    2961  4                  PUT_RETPKT (.RP_INDX);                            ! RELEASE RETURN PACKET
;    2962  4                  DR_ERR ();                                        ! DROP CONTROLLER
;    2963  4                  return FAILURE;
;    2964  4                  end
;    2965  3              else
;    2966  4                  begin                                             ! ELSE - RETPKT IS FROM DISK MSCP
;    2967  4
;    2968  4                  if (.RP_ADDR [ENDCOD] neq (OP_SCC or OP_END)) or  ! IF WRONG ENDCODE
;    2969  5                     ((.RP_ADDR [C_FLGS] and CF_MASK) neq CF_MASK)  ! OR FLAGS IN ERROR
;    2970  4                  then
;    2971  5                      begin
;    2972  5                      C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR_HRD] + 1;
;    2973  5
;    2974  5                      if .APT_MODE
;    2975  5                      then
;    2976  6                          begin
;    2977  6                          .MAIL_BOX_TESTNUM = 1;
;    2978  6                          .MAIL_BOX_SUBTST = 0;
;    2979  5                          end;
;    2980  5
;    2981  5                      ERRDF (21, EGD_21, EMS_21);                   ! FATAL ERROR
;    2982  5                      DROP_CTLR (.CCTLR, DU_CFATAL);                ! DROP CONTROLLER
;    2983  5                      PUT_RETPKT (.RP_INDX);                        ! RELEASE RETURN PACKET
;    2984  5                      return FAILURE;
;    2985  5                      end
;    2986  4                  else
;    2987  5                      begin                                         ! RETPKT HAS CORRECT ENDCODE
;    2988  5                      CMD_TIME = .RP_ADDR [C_TIME] * 2;
;    2989  5
;    2990  5     !ZZZ             if BIT_TST (SWP_FLAGS, SWF_TRC)
;    2991  5     !ZZZ             then
;    2992  5     !ZZZ                 PRINTF (DBM25, .RP_ADDR [C_TIME]);
;    2993  5
;    2994  4                      end;                                          ! RETPKT HAS CORRECT ENDCODE
```

```
;    2995  4
;    2996  3                end;                                          ! IF RETPKT WAS SENT BY DISK MSCP
;    2997  3
;    2998  3            PUT_RETPKT (.RP_INDX);
;    2999  3            return SUCCESS;                                   ! IF SEND WAS SUCCESSFUL
;    3000  2            end;
;    3001  2
;    3002  1        end;                                                  ! ROUTINE SET_CTLR_CHAR


                                        .SBTTL  SET.CTLR.CHAR INITIALIZATION TEST ROUTINES
000000  010146                    SET.CTLR.CHAR::
                                        MOV     R1, (SP)                ;                                       2889
000002  013701  000000G                 MOV     CCTLR,R1                ;                                       2908
000006  105061  000000G                 CLRB    QIO(R1)
000012  010146                          MOV     R1,-(SP)                ;                                       2909
000014  012746  000126                  MOV     #126,-(SP)
000020  004737  000000G                 JSR     PC,BL$MUL
000024  105060  C00005G                 CLRB    CST+5(R0)
000030  005000                          CLR     R0                      ; COUNT                                 2910
000032  112760  000377  000000G  1$:    MOVB    #377,RP.USE(R0)         ; *,*(COUNT)                            2911
000040  005200                          INC     R0                      ; COUNT                                 2910
000042  020027  000007                  CMP     R0,#7                   ; COUNT,*
000046  003771                          BLE     1$
000050  005037  000000G                 CLR     IODQ.OUT                ;                                       2913
000054  005037  000000G                 CLR     IODQ.IN
000060  010116                          MOV     R1,(SP)                 ;                                       2916
000062  004737  000000G                 JSR     PC,GET.PKT
000066  010001                          MOV     R0,R1                   ; *,P.INDEX
000070  010116                          MOV     R1,(SP)                 ; P.INDEX,*                             2917
000072  012746  000106                  MOV     #106,-(SP)
000076  004737  000000G                 JSR     PC,BL$MUL
000102  012760  000040  000006G         MOV     #40,MSCP.PKT+6(R0)
000110  112760  000004  000022G         MOVB    #4,MSCP.PKT+22(R0)      ;                                       2918
000116  012760  000120  000030G         MOV     #120,MSCP.PKT+30(R0)    ;                                       2919
000124  105060  000004G                 CLRB    MSCP.PKT+4(R0)          ;                                       2920
000130  010116                          MOV     R1,(SP)                 ; P.INDEX,*                             2922
000132  004737  000000G                 JSR     PC,SEND
000136  005700                          TST     R0
000140  001036                          BNE     3$
000142  013700  000000G                 MOV     CCTLR,R0                ;                                       2925
000146  006300                          ASL     R0
000150  105260  000000G                 INCB    C.ERR.TBL(R0)
000154  032737  000001  001254'         BIT     #1,APT.MODE             ;                                       2927
000162  001405                          BEQ     2$
000164  012777  000001  001256'         MOV     #1,@MAIL.BOX.TESTNUM    ;                                       2930
000172  005077  001260'                 CLR     @MAIL.BOX.SUBTST        ;                                       2931
000176  104455                  2$:     TRAP    55                      ;                                       2934
000200  000024                          .WORD   24
000202  000000G                         .WORD   EGD.20
000204  000000                          .WORD   0
000206  010116                          MOV     R1,(SP)                 ; P.INDEX,*                             2935
000210  004737  000000G                 JSR     PC,PUT.PKT
```

```
000214  013716  000000G                        MOV     CCTLR,(SP)              ;                               2936
000220  012746  000006                         MOV     #6, (SP)
000224  004737  000000G                        JSR     PC,DROP.CTLR
000230  005726                                 TST     (SP)+                   ;                               2924
000232  005000                                 CLR     R0                      ;                               2940
000234  000554                                 BR      12$
000236  004737  000000G               3$:     JSR     PC,WAIT                 ;                               2944
000242  004737  000000G                        JSR     PC,OUT.IODQ             ;                               2945
000246  010037  000000G                        MOV     R0,RP.INDX
000252  010016                                 MOV     R0,(SP)                 ; RP.INDX,*                     2946
000254  012746  000054                         MOV     #54,-(SP)
000260  004737  000000G                        JSR     PC,BL$MUL
000264  062700  000000G                        ADD     #RETPKT,R0
000270  010037  000000G                        MOV     R0,RP.ADDR
000274  132760  000360  000002                 BITB    #360,2(R0)              ;                               2948
000302  001404                                 BEQ     4$
000304  013716  000000G                        MOV     RP.INDX,(SP)            ;                               2950
000310  004737  000000G                        JSR     PC,PUT.RETPKT
000314  005726                         4$:     TST     (SP)+                   ;                               2943
000316  013701  000000G                        MOV     RP.ADDR,R1              ;                               2953
000322  005000                                 CLR     R0
000324  126127  000003  000003                 CMPB    3(R1),#3
000332  001002                                 BNE     5$
000334  005200                                 INC     R0
000336  000407                                 BR      6$
000340  132761  000360  000002         5$:     BITB    #360,2(R1)              ;                               2954
000346  001333                                 BNE     3$
000350  105761  000014                         TSTB    14(R1)                  ;                               2955
000354  100330                                 BPL     3$
000356  006000                         6$:     ROR     R0                      ;                               2957
000360  103015                                 BCC     7$
000362  012716  000000G                        MOV     #DBM23,(SP)             ;                               2960
000366  012746  000001                         MOV     #1,-(SP)
000372  010600                                 MOV     SP,R0                   ; SP,*
000374  104417                                 TRAP    17
000376  013716  000000G                        MOV     RP.INDX,(SP)            ;                               2961
000402  004737  000000G                        JSR     PC,PUT.RETPKT
000406  004737  000000V                        JSR     PC,DR.ERR               ;                               2962
000412  000447                                 BR      10$                     ;                               2963
000414  126127  000014  000204         7$:     CMPB    14(R1),#204             ;                               2968
000422  001007                                 BNE     8$
000424  016100  000022                         MOV     22(R1),R0               ;                               2969
000430  042700  177657                         BIC     #177657,R0
000434  020027  000120                         CMP     R0,#120
000440  001437                                 BEQ     11$
000442  013700  000000G               8$:     MOV     CCTLR,R0                ;                               2972
000446  006300                                 ASL     R0
000450  105260  000000G                        INCB    C.ERR.TBL(R0)
000454  032737  000001  001254'               BIT     #1,APT.MODE             ;                               2974
000462  001405                                 BEQ     9$
000464  012777  000001  001256'               MOV     #1,@MAIL.BOX.TESTNUM    ;                               2977
000472  005077  001260'                        CLR     @MAIL.BOX.SUBTST        ;                               2978
000476  104455                         9$:     TRAP    55                      ;                               2981
```

```
000500  000025                                  .WORD   25
000502  000000G                                 .WORD   EGD.21
000504  000000G                                 .WORD   EMS.21
000506  013716  000000G                         MOV     CCTLR,(SP)              ;                               2982
000512  012746  000006                          MOV     #6,-(SP)
000516  004737  000000G                         JSR     PC,DROP.CTLR
000522  013716  000000G                         MOV     RP.INDX,(SP)            ;                               2983
000526  004737  000000G                         JSR     PC,PUT.RETPKT
000532  062706  000010              10$:        ADD     #10,SP                  ;                               2984
000536  000416                                  BR      13$                     ;                               2971
000540  016137  000024  000000G     11$:        MOV     24(R1),CMD.TIME         ;                               2988
000546  006337  000000G                         ASL     CMD.TIME
000552  013716  000000G                         MOV     RP.INDX,(SP)            ;                               2998
000556  004737  000000G                         JSR     PC,PUT.RETPKT
000562  012700  000001                          MOV     #1,R0                   ;                               2940
000566  062706  000006              12$:        ADD     #6,SP                   ;                               2922
000572  000401                                  BR      14$                     ;                               2900
000574  005000                      13$:        CLR     R0                      ;                               2889
000576  012601                      14$:        MOV     (SP)+,R1
000600  000207                                  RTS     PC

; Routine Size:  193 words,     Routine Base:  $CODE$ + 4426
; Maximum stack depth per invocation:  7 words
```

```
;    3003  1      routine UNIT_INIT : novalue =
;    3004  1
;    3005  1      !+
;    3006  1      !       THIS ROUTINE IS CALLED FROM DRIVER_INIT FOR EACH CONFIGURED UNIT
;    3007  1      !       (DISK) WHICH IS ATTACHED TO A CONTROLLER THAT SURVIVED
;    3008  1      !       INITIALIZATION. ITS PURPOSE IS TO FORMAT AND SEND AN "ONLINE"
;    3009  1      !       MESSAGE, AND TO VERIFY THE RESPONSE.
;    3010  1      !
;    3011  1      !       IMPLICIT INPUTS:
;    3012  1      !               CCTLR - CURRENT CONTROLLER NUMBER
;    3013  1      !               CDISK - CURRENT DISK ADDRESS (RD/RX DISK NUMBER)
;    3014  1      !               L$LUN - CURRENT (DRS) UNIT NUMBER
;    3015  1      !               CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
;    3016  1      !-
;    3017  1
;    3018  2          begin
;    3019  2          local
;    3020  2              MAX0_LBNS : WORD UNSIGNED,              ! UNIT'S MAXIMUM LO WORD LBN
;    3021  2              MAX1_LBNS : WORD UNSIGNED;              ! UNIT'S MAXIMUM HI WORD LBN
;    3022  2
;    3023  2
;    3024  2          P_INDEX = GET_PKT (.CCTLR);                 ! GET AN MSCP PACKET
;    3025  2          MSCP_PKT [.P_INDEX, MSGLEN] = SZ_ONL;       ! PACKET SIZE
;    3026  2          MSCP_PKT [.P_INDEX, DK_NUM] = .CDISK;       ! SET DISK ADDRESS (RD/RX DISK NUMBER)
;    3027  2          MSCP_PKT [.P_INDEX, OPCODE] = OP_ONL;       ! OPCODE FOR "ONLINE"
;    3028  2      !ZZZ MSCP_PKT [.P_INDEX, DDPAR] = BIT00;        ! SHOW ALL ECC ERRORS IN ERROR LOG MESSAGES
;    3029  2          MSCP_PKT [.P_INDEX, CMD_TYPE] = SEQ_CMD;    ! SEQUENTIAL COMMAND
;    3030  2
;    3031  2          if SEND (.P_INDEX) eql FAILURE              ! ATTEMPT TO SEND; IF CTLR IS OFFLINE
;    3032  2          then
;    3033  3              begin
;    3034  3              T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
;    3035  3
;    3036  3              if .APT_MODE                            !ZZZ
;    3037  3              then
;    3038  4                  begin
;    3039  4                  .MAIL_BOX_TESTNUM = 1;
;    3040  4                  .MAIL_BOX_SUBTST = .CST_ADDR [.CUOFF + OF_DATA, D_DISK_NUM];
;    3041  3                  end;
;    3042  3
;    3043  3              CST_ADDR [.CUOFF, D_FATAL] = TRUE;      ! FATAL ERROR
;    3044  3              ERRDF (22, EGD_22, 0);                  !
;    3045  3              DUR [.L$LUN] = DU_ONLINE;               ! SETUP REASON TO DROP UNIT
;    3046  3              DODU (.L$LUN);                          ! DROP UNIT
;    3047  3              PUT_PKT (.P_INDEX);                     ! RETURN PACKET TO POOL
;    3048  3              end
;    3049  2          else
;    3050  3              begin                                   ! OTHERWISE (SEND WAS SUCCESSFUL)
;    3051  3
;    3052  3              do
;    3053  4                  begin
;    3054  4                  WAIT ();                            ! WAIT FOR RETPKT RESPONSE
;    3055  4                  RP_INDX = OUT_IODQ ();              ! GET INDEX OF RETPKT
```

```
;    3056  4                  RP_ADDR = RETPKT + (.RP_INDX * RP_LEN * 2); ! CALCULATE RETPKT ADDRESS
;    3057  4
;    3058  4                  if .RP_ADDR [MESTYP] neq MT_SEQ     ! RETURN ALL RETPKTS NOT SENT BY CONTROLLER
;    3059  4                  then
;    3060  4                      PUT_RETPKT (.RP_INDX);
;    3061  4
;    3062  4                  end
;    3063  3              until (.RP_ADDR [CONID] eql CID_DRIVER) or
;    3064  4                    ((.RP_ADDR [MESTYP] eql MT_SEQ) and
;    3065  3                    ((.RP_ADDR [ENDCOD] and OP_END) eql OP_END));
;    3066  3
;    3067  3              if .RP_ADDR [CONID] eql CID_DRIVER      ! IF RETPKT IS FROM "DRIVER"
;    3068  3              then
;    3069  4                  begin
;    3070  4                  PRINTF (DBM26);                     ! "ERROR IN UNIT_INIT"
;    3071  4                  DR_ERR ();                          ! DROP CONTROLLER
;    3072  4                  end
;    3073  3              else
;    3074  3
;    3075  4                  if .RP_ADDR [ENDCOD] neq (OP_ONL or OP_END) ! IF RETPKT IS FROM DISK MSCP
;    3076  3                  then
;    3077  4                      begin
;    3078  4                      T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;    3079  4
;    3080  4                      if .APT_MODE                    !ZZZ
;    3081  4                      then
;    3082  5                          begin
;    3083  5                          .MAIL_BOX_TESTNUM = 1;
;    3084  5                          .MAIL_BOX_SUBTST = .CST_ADDR [.CUOFF + OF_DATA, D_DISK_NUM];
;    3085  4                          end;
;    3086  4
;    3087  4                      CST_ADDR [.CUOFF, D_FATAL] = TRUE;
;    3088  4                      ERRDF (23, EGD_23, EMS_21);     ! FATAL ERROR
;    3089  4                      DUR [.L$LUN] = DU_ONLINE;       ! SETUP REASON TO DROP UNIT
;    3090  4                      DODU (.L$LUN);                  ! DROP UNIT
;    3091  4                      end
;    3092  3                  else
;    3093  4                      begin                           ! RETPKT HAS GOOD ENDCODE
;    3094  4                      ST_CODE = .RP_ADDR [STSCOD];    ! GET STATUS CODE
;    3095  4                      SB_CODE = .RP_ADDR [SUBCOD];    ! GET SUB-CODE
;    3096  4
;    3097  4                      CST_ADDR [.CUOFF + OF_NAME_0, D_NAME_0] = .RP_ADDR [NAME_0] + %o'100';                  ! UNIT NAME
ZZZ
;    3098  4                      CST_ADDR [.CUOFF + OF_NAME_0, D_NAME_1] = .RP_ADDR [NAME_1_HI] * 16;                    !ZZZ
;    3099  4                      CST_ADDR [.CUOFF + OF_NAME_0, D_NAME_1] = .CST_ADDR [.CUOFF + OF_NAME_0, D_NAME_1] +    !ZZZ
;    3100  4                                                                .RP_ADDR [NAME_1_LO] + %o'100';               !ZZZ
;    3101  4                      CST_ADDR [.CUOFF + OF_NAME_2, D_NAME_2] = .RP_ADDR [NAME_NUM] / 10 + %o'60';            !ZZZ
;    3102  4                      CST_ADDR [.CUOFF + OF_NAME_2, D_NAME_3] = (.RP_ADDR [NAME_NUM] mod 10) + %o'60';        !ZZZ
;    3103  4
;    3104  4
;    3105  4
;    3106  4                      IF .CST_ADDR [.CUOFF + OF_NAME_0, D_NAME_1] EQL %O'104'         !IF NAME IS _D          !ZZZ
;    3107  4                      THEN                                                                                    !ZZZ
;    3108  4                      CST_ADDR [.CUOFF, D_TYPE] = FIXED                               !ITS FIXED.             !ZZZ
```

```
;    3109  4                    ELSE                                                                    !ZZZ
;    3110  4                    CST_ADDR [.CUOFF, D_TYPE] = REMOVABLE;                  !OTHERWISE REMOVABLE    !ZZZ
;    3111  4
;    3112  4
;    3113  4
;    3114  4                    if .ST_CODE neq ST_SUC          ! IF STATUS CODE IS NOT SUCCESSFUL
;    3115  4                    then
;    3116  5                        begin
;    3117  5                        T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;    3118  5
;    3119  5                        if .APT_MODE                !ZZZ
;    3120  5                        then
;    3121  6                            begin
;    3122  6                            .MAIL_BOX_TESTNUM = 1;
;    3123  6                            .MAIL_BOX_SUBTST = .CST_ADDR [.CUOFF + OF_DATA, D_DISK_NUM];
;    3124  5                            end;
;    3125  5
;    3126  5                        CST_ADDR [.CUOFF, D_FATAL] = TRUE;
;    3127  5                        ERRDF (15, EGD_15, EMS_30); ! ONLINE FAILED
;    3128  5                        DUR [.L$LUN] = DU_ONLINE;   ! SET UP REASON FOR DROPPING UNIT
;    3129  5                        DODU (.L$LUN);              ! DROP UNIT
;    3130  5                        end
;    3131  4                    else
;    3132  5                        begin                       ! SUCCESFUL OPERATION
;    3133  5
;    3134  5                        MAX0_LBNS = .RP_ADDR [SIZE0];                       ! LOAD LOWER WORD OF UNIT SIZE
;    3135  5                        MAX1_LBNS = .RP_ADDR [SIZE1];                       ! LOAD UPPER WORD OF UNIT SIZE
;    3136  5
;    3137  6                        if (.MAX0_LBNS eql 0)                               ! THIS SUBTRACTS ONE FROM THE TOTAL
;    3138  5                        then                                                ! BECAUSE EVERYTHING STARTS AT 0
;    3139  6                            begin                                           ! THROUGH (MAXIMUM   1)
;    3140  6                            MAX0_LBNS = %O'177777';
;    3141  6                            MAX1_LBNS = .MAX1_LBNS - 1;
;    3142  6                            end
;    3143  5                        else
;    3144  5                            MAX0_LBNS = .MAX0_LBNS - 1;
;    3145  5
;    3146  5                        if  (.CST_ADDR [.CUOFF + 2, D_BEG1] gtru .MAX1_LBNS) or         ! THIS SECTION CHECKS TO SEE
 IF LBNs LISTED
;    3147  5
;    3148  6                            ((.CST_ADDR [.CUOFF + 2, D_BEG1] eqlu .MAX1_LBNS) and       ! IN SOFTWARE QUESTIONS WERE
 TO LARGE FOR
;    3149  6                            (.CST_ADDR [.CUOFF + 1, D_BEG0] gtru (.MAX0_LBNS - 1)))     ! DEVICE SPECIFIED
;    3150  6                                                                                 ! note 1 less then max. or diagnosti
c   will error
;    3151  5                        then                                                    ! operator error
;    3152  6                            begin
;    3153  6                            CST_ADDR [.CUOFF + 2, D_BEG1] = 0;
;    3154  6                            CST_ADDR [.CUOFF + 1, D_BEG0] = 0;                  ! change beginning lbn to 0
;    3155  5                            end;
;    3156  5
;    3157  5                         if
;    3158  5                            (.CST_ADDR [.CUOFF + 4, D_END1] gtru .MAX1_LBNS) or
;    3159  5
;    3160  6                            ((.CST_ADDR [.CUOFF + 4, D_END1] eqlu .MAX1_LBNS) and
;    3161  6                            (.CST_ADDR [.CUOFF + 3, D_END0] gtru .MAX0_LBNS))
```

```
;    3162  5                          then
;    3163  6                              begin
;    3164  6                              CST_ADDR [.CUOFF + 4, D_END1] = .MAX1_LBNS;
;    3165  6                              CST_ADDR [.CUOFF + 3, D_END0] = .MAX0_LBNS;          ! end ending lbn to max_lbn
;    3166  5                              end;
;    3167  5
;    3168  6                          if  (.CST_ADDR [.CUOFF + OF_BEG1, D_BEG1] gtru           !MAKE SURE START ADDRESS
      !ZZZ
;    3169  5                               .CST_ADDR [.CUOFF + OF_END1, D_END1]) or            !IS NO LARGER THAN END ADDRESS
      !ZZZ
;    3170  5                                                                                   !
      !ZZZ
;    3171  7                              ((.CST_ADDR [.CUOFF + OF_BEG1, D_BEG1] eqlu          !
      !ZZZ
;    3172  6                                .CST_ADDR [.CUOFF + OF_END1, D_END1]) and          !
      !ZZZ
;    3173  7                              (.CST_ADDR [.CUOFF + OF_BEG, D_BEG0] gtru            !
      !ZZZ
;    3174  6                               .CST_ADDR [.CUOFF + OF_END, D_END0] ))              !
      !ZZZ
;    3175  6                                                                                   !
      !ZZZ
;    3176  5                          then                                                     !
      !ZZZ
;    3177  6                              begin                                                !
       ZZZ
;    3178  6                              CST_ADDR [.CUOFF + OF_BEG1, D_BEG1] = 0;             !IF IT IS, THEN
       ZZZ
;    3179  6                              CST_ADDR [.CUOFF + OF_BEG, D_BEG0] = 0;              ! change beginning lbn to 0
       ZZZ
;    3180  5                              end;                                                 !
       ZZZ
;    3181  5
      !ZZZ
;    3182  5
;    3183  7                              if (((.ENTRY_REASON eql RESTART) or                  ! if restart or
;    3184  6                                  (.ENTRY_REASON eql START)) and                   ! if continue
;    3185  6
;    3186  6                                  (.CRN_LOW leq 8) and                             ! and
;    3187  6                                  (.CRN_HIGH eql 0))                               ! first initialization
;    3188  6
;    3189  5                              THEN                                                 ! intialize block numbers
;    3190  6                                  begin
;    3191  6                                  BST [.L$LUN, LO_WRD] = .CST_ADDR [.CUOFF + 1, D_BEG0];     ! LOAD sequential LBN table
;    3192  6                                  BST [.L$LUN, HI_WRD] = .CST_ADDR [.CUOFF + 2, D_BEG1];     !
;    3193  6                                  TRK_SGN [.L$LUN] = 1;                                      ! POSITIVE TRACKING DIRECTIO
N
;    3194  5                                  end;
;    3195  5
;    3196  5
;    3197  5                                                                                   ! THIS SECTION LOADS TYPE INTO  CST TABLE
;    3198  5      !ZZZ                            selectoneu .RP_ADDR [R_MODEL] of                  ! MODEL BYTE TELLS WHAT TYPE OF UNIT
 IN
;    3199  5      !ZZZ                                                                              ! INDENTIFICATION BLOCK
;    3200  5      !ZZZ                                set
;    3201  5      !ZZZ
;    3202  5      !ZZZ                                [%O'6'] :   CST_ADDR [.CUOFF, D_TYPE] = RD_51;     ! RD 51
;    3203  5      !ZZZ                                [%O'7'] :   CST_ADDR [.CUOFF, D_TYPE] = RX_50;     ! RX 50
;    3204  5      !ZZZ                                [%O'10'] :  CST_ADDR [.CUOFF, D_TYPE] = RD_52;     ! RD 52
;    3205  5      !ZZZ
;    3206  5      !ZZZ                                [otherwise] : BEGIN
;    3207  5      !ZZZ                                              ERRDF (25 ,EGD_24 ,EMS_30);          ! ERROR UNKNOWN DEVICE
;    3208  5      !ZZZ                                              END;
;    3209  5      !ZZZ                                tes;
;    3210  5
;    3211  5
;    3212  5
;    3213  5                          if ((.RP_ADDR [U_FLGS] and UF_WPH) eql UF_WPH) and       ! STATUS CODE IS O.K.
;    3214  6                             (.CST_ADDR [.CUOFF, D_PROT] eql UNPROTECTED)
```

```
;    3215  5                          then
;    3216  6                              begin
;    3217  6                              T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;    3218  6
;    3219  6                              if .APT_MODE                        !ZZZ
;    3220  6                              then
;    3221  7                                  begin
;    3222  7                                  .MAIL_BOX_TESTNUM = 1;
;    3223  7                                  .MAIL_BOX_SUBTST = .CST_ADDR [.CUOFF + OF_DATA, D_DISK_NUM];
;    3224  6                                  end;
;    3225  6
;    3226  6                              CST_ADDR [.CUOFF, D_FATAL] = TRUE;
;    3227  6                              ERROF (16, EGD_16, EMS_30);                     ! WRITE-PROTECT CONFLICT
;    3228  6                              DUR [.L$LUN] = DU_PROTECT;                      ! SET REASON TO DROP UNIT
;    3229  6                              DODU (.L$LUN);                                  ! DROP UNIT
;    3230  6                              end
;    3231  5                          else
;    3232  6                              begin                                       ! WRITE PROTECT SWITCH IS O.K.
;    3233  6                              CST_ADDR [.CUOFF, D_STAT] = ONLINE;             ! SET ONLINE FLAG
;    3234  6                              CST [.CCTLR, U_CNT] = .CST [.CCTLR, U_CNT] + 1; ! ADD UNIT TO CTRL TABLE
;    3235  5                              end;
;    3236  4                          end;
;    3237  3                      end;                                ! IF RETPKT HAS CORRECT ENDCODE
;    3238  3
;    3239  3                  PUT_RETPKT (.RP_INDX);
;    3240  2                  end;                                    ! IF SEND WAS SUCCESSFUL
;    3241  2
;    3242  1              end;                                        ! ROUTINE UNIT-INIT


                                        .SBTTL  UNIT.INIT INITIALIZATION TEST ROUTINES
000000  004137  000000G                UNIT.INIT:
                                        JSR     R1,$SAVE5                       ;                       3003
000004  005746                         TST     -(SP)
000006  013746  000000G                MOV     CCTLR,-(SP)                     ;                       3024
000012  004737  000000G                JSR     PC,GET.PKT
000016  010037  000000G                MOV     R0,P.INDEX
000022  010016                         MOV     R0,(SP)                         ; P.INDEX,*             3025
000024  012746  000106                 MOV     #106,-(SP)
000030  004737  000000G                JSR     PC,BL$MUL
000034  012760  000044  000006G        MOV     #44,MSCP.PKT+6(R0)
000042  013760  000000G  000016G        MOV     CDISK,MSCP.PKT+16(R0)           ;                       3026
000050  112760  000011  000022G        MOVB    #11,MSCP.PKT+22(R0)             ;                       3027
000056  112760  000001  000004G        MOVB    #1,MSCP.PKT+4(R0)               ;                       3029
000064  013716  000000G                MOV     P.INDEX,(SP)                    ;                       3031
000070  004737  0000C0G                JSR     PC,SEND
000074  005700                         TST     R0
000076  001054                         BNE     2$
000100  013700  000000G                MOV     T.ADDR,R0                       ;                       3034
000104  105260  000051                 INCB    51(R0)
000110  032737  000001  001254         BIT     #1,APT.MODE                     ;                       3036
000116  001415                         BEQ     1$
000120  012777  000001  001256'        MOV     #1,@MAIL BOX TESTNUM            ;                       3039
```

```
000126  013700  000000G                        MOV     CUOFF,R0                ;                               3040
000132  006300                                  ASL     R0
000134  063700  000000G                        ADD     CST.ADDR,R0
000140  111077  001260'                        MOVB    (R0),@MAIL.BOX.SUBTST
000144  042777  177760  001260'                BIC     #177760,@MAIL.BOX.SUBTST
000152  013700  000000G              1$:       MOV     CUOFF,R0                ;                               3043
000156  006300                                  ASL     R0
000160  063700  000000G                        ADD     CST.ADDR,R0
000164  052710  010000                        BIS     #10000,(R0)
000170  104455                                TRAP    55                      ;                               3044
000172  000026                                .WORD   26
000174  000000G                               .WORD   EGD.22
000176  000000                                .WORD   0
000200  013700  000000G                        MOV     L$LUN,R0                ;                               3045
000204  112760  000007  000000G                MOVB    #7,DUR(R0)
000212  104451                                TRAP    51                      ;                               3046
000214  013716  000000G                        MOV     P.INDEX,(SP)            ;                               3047
000220  004737  000000G                        JSR     PC,PUT.PKT
000224  000137  C07164'                        JMP     28$                     ;                               3031
000230  004737  000000G              2$:       JSR     PC,WAIT                 ;                               3054
000234  004737  000000G                        JSR     PC,OUT.IODQ             ;                               3055
000240  010037  000000G                        MOV     R0,RP.INDX
000244  010016                                MOV     R0,(SP)                 ; RP.INDX,*                     3056
000246  012746  000054                        MOV     #54,-(SP)
000252  004737  000000G                        JSR     PC,BL$MUL
000256  062700  000000G                        ADD     #RETPKT,R0
000262  010037  000000G                        MOV     R0,RP.ADDR
000266  132760  000360  000002                BITB    #360,2(R0)              ;                               3058
000274  001404                                BEQ     3$
000276  013716  000000G                        MOV     RP.INDX,(SP)            ;                               3060
000302  004737  000000G                        JSR     PC,PUT.RETPKT
000306  005726                        3$:     TST     (SP)+                   ;                               3053
000310  013702  000000G                        MOV     RP.ADDR,R2              ;                               3063
000314  005000                                CLR     R0
000316  126227  000003  000003                CMPB    3(R2),#3
000324  001002                                BNE     4$
000326  005200                                INC     R0
000330  000407                                BR      5$
000332  132762  000360  000002        4$:     BITB    #360,2(R2)              ;                               3064
000340  001333                                BNE     2$
000342  105762  000014                        TSTB    14(R2)                  ;                               3065
000346  100330                                BPL     2$
000350  006000                        5$:     ROR     R0                      ;                               3067
000352  103012                                BCC     6$
000354  012716  000000G                        MOV     #DBM26,(SP)             ;                               3070
000360  012746  000001                        MOV     #1,-(SP)
000364  010600                                MOV     SP,R0                   ; SP,*
000366  104417                                TRAP    17
000370  004737  000000V                        JSR     PC,DR.ERR               ;                               3071
000374  005726                                TST     (SP)+                   ;                               3069
000376  000456                                BR      8$                      ;                               3067
000400  013766  000000G 000004        6$:     MOV     CUOFF,4(SP)             ;                               3087
000406  006366  000004                        ASL     4(SP)
```

```
000412  063766  000000G 000004          ADD     CST.ADDR,4(SP)
000420  126227  000014  000211          CMPB    14(R2),#211             ;3075
000426  001444                          BEQ     9$
000430  013700  000000G                 MOV     T.ADDR,R0               ;3078
000434  105260  000050                  INCB    50(R0)
000440  032737  000001  001254'        BIT     #1,APT.MODE             ;3080
000446  001415                          BEQ     7$
000450  012777  000001  001256          MOV     #1,@MAIL.BOX.TESTNUM    ;3083
000456  013700  000000G                 MOV     CUOFF,R0                ;3084
000462  006300                          ASL     R0
000464  063700  000000G                 ADD     CST.ADDR,R0
000470  111077  001260'                 MOVB    (R0),@MAIL.BOX.SUBTST
000474  042777  177760  001260'        BIC     #177760,@MAIL.BOX.SUBTST
000502  052776  010000  000004  7$:     BIS     #10000,@4(SP)           ;3087
000510  104455                          TRAP    55                      ;3088
000512  000027                          .WORD   27
000514  000000G                         .WORD   EGD.23
000516  000000G                         .WORD   EMS.21
000520  013700  000000G                 MOV     L$LUN,R0                ;3089
000524  112760  000007  000000G         MOVB    #7,DUR(R0)
000532  104451                          TRAP    51                      ;3090
000534  000137  007154'          8$:     JMP     27$                     ;3075
000540  116237  000016  000000G  9$:     MOVB    16(R2),ST.CODE          ;3094
000546  042737  177740  000000G         BIC     #177740,ST.CODE
000554  016200  000016                  MOV     16(R2),R0               ;3095
000560  006200                          ASR     R0
000562  006200                          ASR     R0
000564  006200                          ASR     R0
000566  006200                          ASR     R0
000570  006200                          ASR     R0
000572  042700  174000                  BIC     #174000,R0
000576  010037  000000G                 MOV     R0,SB.CODE
000602  013701  000000G                 MOV     CUOFF,R1                ;3097
000606  006301                          ASL     R1
000610  063701  000000G                 ADD     CST.ADDR,R1
000614  012703  000012                  MOV     #12,R3
000620  060103                          ADD     R1,R3
000622  116200  000036                  MOVB    36(R2),R0
000626  006200                          ASR     R0
000630  042700  177740                  BIC     #177740,R0
000634  062700  000100                  ADD     #100,R0
000640  110013                          MOVB    R0,(R3)
000642  116200  000036                  MOVB    36(R2),R0               ;3098
000646  042700  177776                  BIC     #177776,R0
000652  006300                          ASL     R0
000654  006300                          ASL     R0
000656  006300                          ASL     R0
000660  006300                          ASL     R0
000662  110063  000001                  MOVB    R0,1(R3)
000666  005000                          CLR     R0                      ;3099
000670  156300  000001                  BISB    1(R3),R0
000674  016201  000034                  MOV     34(R2),R1
000700  006201                          ASR     R1
```

```
000070?  006201                          ASR     R1
000704   006201                          ASR     R1
000706   006201                          ASR     R1
000710   000301                          SWAB    R1
000712   042701  177760                  BIC     #177760,R1
000716   060100                          ADD     R1,R0
000720   010001                          MOV     R0,R1                   ;                       3100
000722   062701  000100                  ADD     #100,R1
000726   110163  000001                  MOVB    R1,1(R3)
000732   013701  GOOOOOG                 MOV     CUOFF,R1                ;                       3101
000736   006301                          ASL     R1
000740   063701  000000G                 ADD     CST.ADDR,R1
000744   116216  000034                  MOVB    34(R2),(SP)
000750   042716  177700                  BIC     #177700,(SP)
000754   012746  000012                  MOV     #12, (SP)
000760   004737  000000G                 JSR     PC,BL$DIV
000764   010004                          MOV     R0,R4
000766   062704  000060                  ADD     #60,R4
000772   110461  C00014                  MOVB    R4,14(R1)
000776   116216  000034                  MOVB    34(R2),(SP)             ;                       3102
001002   042716  177700                  BIC     #177700,(SP)
001006   012746  000012                  MOV     #12,-(SP)
001012   004737  000000G                 JSR     PC,BL$MOD
001016   010004                          MOV     R0,R4
001020   062704  000060                  ADD     #60,R4
001024   110461  000015                  MOVB    R4,15(R1)
001030   126327  000001  000104          CMPB    1(R3),#104              ;                       3106
001036   001004                          BNE     10$
001040   152776  000020  000010          BISB    #20,@10(SP)             ;                       3108
001046   000403                          BR      11$                     ;                       3106
001050   142776  000020  000010  10$:    BICB    #20,@10(SP)             ;                       3110
001056   005737  000000G          11$:    TST     ST.CODE                 ;                       3114
001062   001440                          BEQ     13$
001064   013700  000000G                 MOV     T.ADDR,R0               ;                       3117
001070   105260  000050                  INCB    50(R0)
001074   032737  000001  001254'         BIT     #1,APT.MODE             ;                       3119
001102   001411                          BEQ     12$
001104   012777  000001  001256'         MOV     #1,@MAIL.BOX.TESTNUM    ;                       3122
001112   117677  000010  001260'         MOVB    @10(SP),@MAIL.BOX.SUBTST ;                      3123
001120   042777  177760  001260'         BIC     #177760,@MAIL.BOX.SUBTST
001126   052776  010000  000010  12$:    BIS     #10000,@10(SP)          ;                       3126
001134   104455                          TRAP    55                      ;                       3127
001136   000017                          .WORD   17
001140   000000G                         .WORD   EGD.15
001142   000000G                         .WORD   EMS.30
001144   013700  000000G                 MOV     L$LUN,R0                ;                       3128
001150   112760  000007  000000G         MOVB    #7,DUR(R0)
001156   104451                          TRAP    51                      ;                       3129
001160   000137  007152'                 JMP     26$                     ;                       3114
001164   016203  000044          13$:    MOV     44(R2),R3               ; *,MAX0.LBNS           3134
001170   016204  000046                  MOV     46(R2),R4               ; *,MAX1.LBNS           3135
001174   005703                          TST     R3                      ; MAX0.LBNS             3137
001176   001004                          BNE     14$
```

```
001200  012703  177777                        MOV     #-1,R3                  ; *,MAX0.LBNS                   3140
001204  005304                                 DEC     R4                      ; MAX1.LBNS                     3141
001206  000401                                 BR      15$                     ;                               3137
001210  005303                          14$:   DEC     R3                      ; MAX0.LBNS                     3144
001212  013701  000000G                 15$:   MOV     CUOFF,R1                ;                               3146
001216  006301                                 ASL     R1
001220  063701  000000G                         ADD     CST.ADDR,R1
001224  012705  000004                         MOV     #4,R5
001230  060105                                 ADD     R1,R5
001232  021504                                 CMP     (R5),R4                 ; *,MAX1.LBNS
001234  101013                                 BHI     16$
001236  001022                                 BNE     17$                     ;                               3148
001240  013701  000000G                         MOV     CUOFF,R1                ;                               3149
001244  006301                                 ASL     R1
001246  063701  000000G                         ADD     CST.ADDR,R1
001252  010300                                 MOV     R3,R0                   ; MAX0.LBNS,*
001254  005300                                 DEC     R0
001256  026100  000002                         CMP     2(R1),R0
001262  101410                                 BLOS    17$
001264  005015                          16$:   CLR     (R5)                    ;                               3153
001266  013701  000000G                         MOV     CUOFF,R1                ;                               3154
001272  006301                                 ASL     R1
001274  063701  000000G                         ADD     CST.ADDR,R1
001300  005061  000002                         CLR     2(R1)
001304  013701  000000G                 17$:   MOV     CUOFF,R1                ;                               3158
001310  006301                                 ASL     R1
001312  063701  000000G                         ADD     CST.ADDR,R1
001316  012700  000010                         MOV     #10,R0
001322  060100                                 ADD     R1,R0
001324  021004                                 CMP     (R0),R4                 ; *,MAX1.LBNS
001326  101011                                 BHI     18$
001330  001020                                 BNE     19$                     ;                               3160
001332  013701  000000G                         MOV     CUOFF,R1                ;                               3161
001336  006301                                 ASL     R1
001340  063701  000000G                         ADD     CST.ADDR,R1
001344  026103  000006                         CMP     6(R1),R3                ; *,MAX0.LBNS
001350  101410                                 BLOS    19$
001352  010410                          18$:   MOV     R4,(R0)                 ; MAX1.LBNS,*                   3164
001354  013701  000000G                         MOV     CUOFF,R1                ;                               3165
001360  006301                                 ASL     R1
001362  063701  000000G                         ADD     CST.ADDR,R1
001366  010361  000006                         MOV     R3,6(R1)                ; MAX0.LBNS,*
001372  021510                          19$:   CMP     (R5),(R0)               ;                               3168
001374  101017                                 BHI     20$
001376  001026                                 BNE     21$                     ;                               3171
001400  013700  000000G                         MOV     CUOFF,R0                ;                               3173
001404  006300                                 ASL     R0
001406  063700  000000G                         ADD     CST.ADDR,R0
001412  013701  000000G                         MOV     CUOFF,R1                ;                               3174
001416  006301                                 ASL     R1
001420  063701  000000G                         ADD     CST.ADDR,R1
001424  026061  000002  000006                 CMP     2(R0),6(R1)             ;                               3173
001432  101410                                 BLOS    21$
```

```
001434  005015                          20$:    CLR     (R5)                            ;                       3178
001436  013701  000000G                        MOV     CUOFF,R1                        ;                       3179
001442  006301                                ASL     R1
001444  063701  000000G                        ADD     CST.ADDR,R1
001450  005061  000002                        CLR     2(R1)
001454  123727  000000G 000002          21$:    CMPB    ENTRY.REASON,#2                 ;                       3183
001462  001404                                BEQ     22$
001464  123727  000000G 000001                CMPB    ENTRY.REASON,#1                 ;                       3184
001472  001031                                BNE     23$
001474  023727  000000G 000010          22$:    CMP     CRN.LOW,#10                     ;                       3186
001502  003025                                BGT     23$
001504  005737  000000G                        TST     CRN.HIGH                        ;                       3187
001510  001022                                BNE     23$
001512  013700  000000G                        MOV     L$LUN,R0                        ;                       3191
001516  010004                                MOV     R0,R4
001520  006304                                ASL     R4
001522  006304                                ASL     R4
001524  013701  000000G                        MOV     CUOFF,R1
001530  006301                                ASL     R1
001532  063701  000000G                        ADD     CST.ADDR,R1
001536  016164  000002  000000G               MOV     2(R1),BST(R4)
001544  011564  000002G                       MOV     (R5),BST+2(R4)                  ;                       3192
001550  112760  000001  000000G               MOVB    #1,TRK.SGN(R0)                  ;                       3193
001556  032762  020000  000022          23$:    BIT     #20000,22(R2)                   ;                       3213
001564  001442                                BEQ     25$
001566  005776  000010                        TST     @10(SP)                         ;                       3214
001572  100037                                BPL     25$
001574  013700  000000G                        MOV     T.ADDR,R0                       ;                       3217
001600  105260  000050                        INCB    50(R0)
001604  032737  000001  001254'               BIT     #1,APT.MODE                     ;                       3219
001612  001411                                BEQ     24$
001614  012777  000001  001256'               MOV     #1,@MAIL.BOX.TESTNUM            ;                       3222
001622  117677  000010  001260'               MOVB    @10(SP),@MAIL.BOX.SUBTST        ;                       3223
001630  042777  177760  001260'               BIC     #177760,@MAIL.BOX.SUBTST
001636  052776  010000  000010          24$:    BIS     #10000,@10(SP)                  ;                       3226
001644  104455                                TRAP    55                              ;                       3227
001646  000020                                .WORD   20
001650  000000G                               .WORD   EGD.16
001652  000000G                               .WORD   EMS.30
001654  013700  000000G                        MOV     L$LUN,R0                        ;                       3228
001660  112760  000011  000000G               MOVB    #11,DUR(R0)
001666  104451                                TRAP    51                              ;                       3229
001670  000414                                BR      26$                             ;                       3213
001672  052776  020000  000010          25$:    BIS     #20000,@10(SP)                  ;                       3233
001700  013716  000000G                        MOV     CCTLR,(SP)                      ;                       3234
001704  012746  000126                        MOV     #126.,-(SP)
001710  004737  000000G                        JSR     PC,BL$MUL
001714  105260  000005G                        INCB    CST+5(R0)
001720  005726                                TST     (SP)+                           ;                       3232
001722  022626                          26$:    CMP     (SP)+,(SP)+                     ;                       3093
001724  013716  000000G                 27$:    MOV     RP.INDX,(SP)                    ;                       3239
001730  004737  000000G                        JSR     PC,PUT.RETPKT
001734  062706  000006                  28$:    ADD     #6,SP                           ;                       3003
```

```
001740  000207                                  RTS     PC

; Routine Size:  497 words,     Routine Base:  $CODE$ + 5230
; Maximum stack depth per invocation:  13 words
```

```
;    3243  1      GLOBAL routine DR_ERR : novalue =
;    3244  1
;    3245  1      !+
;    3246  1      !       THIS ROUTINE IS DESIGNED TO PROCESS RETURN PACKETS THAT ORIGINATE AT
;    3247  1      !       THE "DRIVER" RATHER THAN THE DEVICE.  DRIVER-ORIGINATED PACKETS INDICATE
;    3248  1      !       EITHER A FATAL DEVICE ERROR OR A COMMAND TIMEOUT.  SINCE THIS ROUTINE IS
;    3249  1      !       ONLY CALLED DURING THE INITIALIZATION TEST, IT TREATS A COMMAND TIMEOUT
;    3250  1      !       AS AN INITIALIZATION ERROR.
;    3251  1      !
;    3252  1      !       IMPLICIT INPUTS:
;    3253  1      !               RP_ADDR - ADDRESS OF A RETPKT THAT ORIGINATED AT THE "DRIVER"
;    3254  1      !                       (I.E., CONNECTION ID = CID_DRIVER)
;    3255  1      !-
;    3256  1
;    3257  2          begin
;    3258  2
;    3259  2          local
;    3260  2              REASON : word initial (DU_TIME);        ! ASSUME COMMAND TIMEOUT
;    3261  2
;    3262  2          if .RP_ADDR [MESTYP] eql MT_FATAL           ! IF FATAL DEVICE ERROR
;    3263  2          then
;    3264  2
;    3265  2          DROP_CTLR (.CCTLR, .REASON);                ! DROP ALL UNITS ON CONTROLLER
;    3266  1          end;


                                        .SBTTL  DR.ERR INITIALIZATION TEST ROUTINES
000000  010146                         DR.ERR::MOV     R1,-(SP)                        ;                               3243
000002  012701  000012                          MOV     #12,R1                          ; #,REASON                      3257
000006  013700  000000G                         MOV     RP.ADDR,R0                      ;                               3262
000012  116000  000002                          MOVB    2(R0),R0
000016  042700  177417                          BIC     #177417,R0
000022  020027  000060                          CMP     R0,#60
000026  001006                                 BNE     1$
000030  013746  000000G                         MOV     CCTLR,-(SP)                     ;                               3265
000034  010146                                 MOV     R1,-(SP)                        ; REASON,#
000036  004737  000000G                         JSR     PC,DROP.CTLR
000042  022626                                 CMP     (SP)+,(SP)+
000044  012601                         1$:     MOV     (SP)+,R1                        ;                               3243
000046  000207                                 RTS     PC

; Routine Size:  20 words,      Routine Base:  $CODE$ + 7172
; Maximum stack depth per invocation:  4 words
```

```
;    3267  1      routine ACCESS : novalue =
;    3268  1
;    3269  1      !+
;    3270  1      !       THIS ROUTINE IS CALLED BY INIT_TEST TO VERIFY THAT THE CURRENT DISK
;    3271  1      !       CAN BE ACCESSED. THIS OBJECTIVE IS ACCOMPLISHED BY FORMATTING AND
;    3272  1      !       SENDING ONE OR TWO MSCP ACCESS COMMANDS TO THE DISK, AND CHECKING
;    3273  1      !       THE STATUS FIELD OF THE RESPONSE MESSAGE(S).
;    3274  1      !
;    3275  1      !       IMPLICIT INPUTS:
;    3276  1      !               CCTLR - CURRENT CONTROLLER NUMBER
;    3277  1      !               CDISK - CURRENT DISK ADDRESS (RD/RX DISK NUMBER)
;    3278  1      !               L$LUN - CURRENT (DRS) UNIT NUMBER
;    3279  1      !-
;    3280  1
;    3281  2          begin
;    3282  2
;    3283  2      local:
;    3284  2              RESULT : word initial (FAILURE),        ! GUILTY UNTIL PROVEN INNOCENT
;    3285  2              LBN : word,
;    3286  2              PASS : word initial (1);                ! LOOP PASS COUNT
;    3287  2
;    3288  2          ST_CODE = SB_CODE = 0;                      ! STATUS CODE AND SUB-CODE
;    3289  2      !ZZZ    LBN = (((.MAX_LBN [.L$LUN] + 1) +  1) and %o'77777') - 1;
;    3290  2              LBN = 0;                                !TRY LBN 0 FIRST                                    !ZZZ
;    3291  2
;    3292  2          do
;    3293  3              begin                                   ! LOOP STARTS HERE
;    3294  3              P_INDEX = GET_PKT (.CCTLR);             ! GET AN MSCP PACKET
;    3295  3              MSCP_PKT [.P_INDEX, DK_NUM] = .CDISK;   ! SET DISK ADDR (RD/RX DISK NUMBER)
;    3296  3              MSCP_PKT [.P_INDEX, OPCODE] = OP_ACC;   ! ACCESS OPCODE
;    3297  3              MSCP_PKT [.P_INDEX, BC_LO] = 512;       ! BYTE COUNT (1 BLOCK)
;    3298  3              MSCP_PKT [.P_INDEX, LBN_L] = .LBN;      ! LOGICAL BLOCK NUMBER
;    3299  3              MSCP_PKT [.P_INDEX, CMD_TYPE] = NON_SEQ_CMD;    ! NON-SEQUENTIAL COMMAND
;    3300  3
;    3301  3              if SEND (.P_INDEX) eql FAILURE          ! ATTEMPT TO SEND; IF CTLR NOT ONLINE
;    3302  3              then
;    3303  4                  begin
;    3304  4                  PUT_PKT (.P_INDEX);                 ! RETURN PACKET TO POOL
;    3305  4                  PASS = 2;                           ! NO MORE TRIES
;    3306  4                  end
;    3307  3              else
;    3308  4                  begin                               ! IF SEND WAS SUCCESSFUL
;    3309  4
;    3310  4                  do
;    3311  5                      begin
;    3312  5                      WAIT ();                        ! WAIT FOR RESPONSE
;    3313  5                      RP_INDX = OUT_IODQ ();          ! GET RETPKT (RESPONSE) INDEX
;    3314  5                      RP_ADDR = RETPKT + (.RP_INDX * RP_LEN * 2);     ! CALCULATE RETPKT ADDRESS
;    3315  5
;    3316  5                      if .RP_ADDR [MESTYP] neq MT_SEQ ! RETURN ALL RETPKTS NOT SENT BY CONTROLLER
;    3317  5                      then
;    3318  5                          PUT_RETPKT (.RP_INDX);
;    3319  5
```

```
;    3320  5                    end
;    3321  4                until (.RP_ADDR [CONID] eql CID_DRIVER) or
;    3322  5                      ((.RP_ADDR [MESTYP] eql MT_SEQ) and
;    3323  4                       ((.RP_ADDR [ENDCOD] and OP_END) eql OP_END));
;    3324  4
;    3325  4                if .RP_ADDR [CONID] eql CID_DRIVER  ! IF RETPKT CAME FROM "DRIVER"
;    3326  4                then
;    3327  4                    PASS = 2                        ! NO MORE TRIES
;    3328  4                else
;    3329  4
;    3330  5                    if .RP_ADDR [ENDCOD] neq (OP_ACC or OP_END)
;    3331  4                    then
;    3332  5                        begin
;    3333  5                        PRINTF (DBM29);             ! "RETPKT HAS BAD ENDCODE"
;    3334  5    !ZZZ                EMSCMD ();
;    3335  5                        end
;    3336  4                    else
;    3337  5                        begin                       ! RETPKT HAS CORRECT ENDCODE
;    3338  5                        ST_CODE = .RP_ADDR [STSCOD];! GET STATUS CODE FROM PACKET
;    3339  5                        SB_CODE = .RP_ADDR [SUBCOD];! GET SUB-CODE FROM PACKET
;    3340  5
;    3341  5                        if .ST_CODE eql ST_SUC      ! IF STATUS CODE INDICATES SUCCESS
;    3342  5                        then
;    3343  6                            begin
;    3344  6                            RESULT = SUCCESS;
;    3345  6                            PASS = 2;               ! NO NEED TO TRY AGAIN
;    3346  5                            end;
;    3347  5
;    3348  4                        end;                        ! IF RETPKT HAS CORRECT ENDCODE
;    3349  4
;    3350  4                PUT_RETPKT (.RP_INDX);
;    3351  3                end;                                ! IF SEND WAS SUCCESSFUL
;    3352  3
;    3353  3            LBN = .LBN + 100;                       !TRY ANOTHER ONE                    !ZZZ
;    3354  3            PASS = .PASS + 1;                       ! SECOND PASS
;    3355  3            end                                     ! END OF PASS LOOP
;    3356  2        until .PASS gequ 3;
;    3357  2
;    3358  2        if .RESULT eql FAILURE
;    3359  2        then
;    3360  3            begin
;    3361  3            T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;    3362  3            CST_ADDR [.CUOFF, D_FATAL] = TRUE,      ! FATAL ERROR
;    3363  3            ERRDF (17, EGD_17, EMS_30);                 ! ACCESS FAILED
;    3364  3            DUR [.L$LUN] = DU_ACCESS;               ! SET REASON TO DROP UNIT
;    3365  3            DODU (.L$LUN);                          ! DROP UNIT
;    3366  2            end;                                    ! IF ACCESS FAILED
;    3367  2
;    3368  1        end;                                        ! ROUTINE ACCESS

                                .SBTTL  ACCESS INITIALIZATION TEST ROUTINES
000000  004137  000000G    ACCESS: JSR     R1,$SAVE4                       ;                                   3267
```

```
000004  005003                          CLR     R3                      ; RESULT                        3281
000006  012702  000001                  MOV     #1,R2                   ; #,PASS
000012  005037  000000G                 CLR     SB.CODE                 ;                               3288
000016  005037  000000G                 CLR     ST.CODE
000022  005004                          CLR     R4                      ; LBN                           3290
000024  013746  000000G          1$:    MOV     CCTLR,-(SP)             ;                               3294
000030  004737  000000G                 JSR     PC,GET.PKT
000034  010037  000000G                 MOV     R0,P.INDEX
000040  010016                          MOV     R0,(SP)                 ; P.INDEX,#                     3295
000042  012746  000106                  MOV     #106,-(SP)
000046  004737  000000G                 JSR     PC,BL$MUL
000052  013760  000000G  000016G        MOV     CDISK,MSCP.PKT+16(R0)
000060  112760  000020  000022G        MOVB    #20,MSCP.PKT+22(R0)     ;                               3296
000066  012760  001000  000026G        MOV     #1000,MSCP.PKT+26(R0)   ;                               3297
000074  010460  000046G                 MOV     R4,MSCP.PKT+46(R0)      ; LBN,#                         3298
000100  112760  000002  000004G        MOVB    #2,MSCP.PKT+4(R0)       ;                               3299
000106  013716  000000G                 MOV     P.INDEX,(SP)            ;                               3301
000112  004737  000000G                 JSR     PC,SEND
000116  005700                          TST     R0
000120  001007                          BNE     2$
000122  013716  000000G                 MOV     P.INDEX,(SP)            ;                               3304
000126  004737  000000G                 JSR     PC,PUT.PKT
000132  012702  000002                  MOV     #2,R2                   ; #,PASS                        3305
000136  000522                          BR      9$                      ;                               3301
000140  004737  000000G          2$:    JSR     PC,WAIT                 ;                               3312
000144  004737  000000G                 JSR     PC,OUT.IODQ             ;                               3313
000150  010037  000000G                 MOV     R0,RP.INDX
000154  010016                          MOV     R0,(SP)                 ; RP.INDX,#                     3314
000156  012746  000054                  MOV     #54,-(SP)
000162  004737  000000G                 JSR     PC,BL$MUL
000166  062700  000000G                 ADD     #RETPKT,R0
000172  010037  000000G                 MOV     R0,RP.ADDR
000176  132760  000360  000002         BITB    #360,2(R0)              ;                               3316
000204  001404                          BEQ     3$
000206  013716  000000G                 MOV     RP.INDX,(SP)            ;                               3318
000212  004737  000000G                 JSR     PC,PUT.RETPKT
000216  005726                  3$:     TST     (SP)+                   ;                               3311
000220  013701  000000G                 MOV     RP.ADDR,R1              ;                               3321
000224  005000                          CLR     R0
000226  126127  000003  000003         CMPB    3(R1),#3
000234  001002                          BNE     4$
000236  005200                          INC     R0
000240  000407                          BR      5$
000242  132761  000360  000002  4$:     BITB    #360,2(R1)              ;                               3322
000250  001333                          BNE     2$
000252  105761  000014                  TSTB    14(R1)                  ;                               3323
000256  100330                          BPL     2$
000260  006000                  5$:     ROR     R0                      ;                               3325
000262  103442                          BLO     7$                      ;                               3327
000264  126127  000014  000220         CMPB    14(R1),#220             ;                               3330
000272  001410                          BEQ     6$
000274  012716  000000G                 MOV     #DBM29,(SP)             ;                               3333
000300  012746  000001                  MOV     #1,-(SP)
```

```
000304  010600                                  MOV     SP,R0                   ; SP,*
000306  104417                                  TRAP    17
000310  005726                                  TST     (SP)+                   ;                               3332
000312  000430                                  BR      8$                      ;                               3330
000314  116137  000016  000000G          6$:    MOVB    16(R1),ST.CODE          ;                               3338
000322  042737  177740  000000G                BIC     #177740,ST.CODE
000330  016100  000016                          MOV     16(R1),R0               ;                               3339
000334  006200                                  ASR     R0
000336  006200                                  ASR     R0
000340  006200                                  ASR     R0
000342  006200                                  ASR     R0
000344  006200                                  ASR     R0
000346  042700  174000                          BIC     #174000,R0
000352  010037  000000G                        MOV     R0,SB.CODE
000356  005737  000000G                        TST     ST.CODE                 ;                               3341
000362  001004                                  BNE     8$
000364  012703  000001                          MOV     #1,R3                   ; *,RESULT                      3344
000370  012702  000002                  7$:     MOV     #2,R2                   ; *,PASS                        3345
000374  013716  C00000G                  8$:     MOV     RP.INDX,(SP)            ;                               3350
000400  004737  000000G                        JSR     PC,PUT.RETPKT
000404  062704  000144                  9$:     ADD     #144,R4                 ; *,LBN                         3353
000410  005202                                  INC     R2                      ; PASS                          3354
000412  022626                                  CMP     (SP)+,(SP)+             ;                               3293
000414  020227  000003                          CMP     R2,#3                   ; PASS,*                        3356
000420  103601                                  BLO     1$
000422  005703                                  TST     R3                      ; RESULT                        3358
000424  001025                                  BNE     10$
000426  013700  000000G                        MOV     T.ADDR,R0               ;                               3361
000432  105260  000050                          INCB    50(R0)
000436  013700  000000G                        MOV     CUOFF,R0                ;                               3362
000442  006300                                  ASL     R0
000444  063700  000000G                        ADD     CST.ADDR,R0
000450  052710  010000                          BIS     #10000,(R0)
000454  104455                                  TRAP    55                      ;                               3363
000456  000021                                  .WORD   21
000460  000000G                                 .WORD   EGD.17
000462  000000G                                 .WORD   EMS.30
000464  013700  000000G                        MOV     L$LUN,R0                ;                               3364
000470  112760  000010  000000G                MOVB    #10,DUR(R0)
000476  104451                                  TRAP    51                      ;                               3365
000500  000207                          10$:    RTS     PC                      ;                               3267

; Routine Size:  161 words,     Routine Base:  $CODE$ + 7242
; Maximum stack depth per invocation:  10 words
```

```
;    3369  1      %sbttl 'MULTI-DRIVE TEST ROUTINES'
;    3370  1
;    3371  1
;    3372  1      GLOBAL routine MULTI_DRIVE : novalue =
;    3373  1
;    3374  1
;    3375  1      !+
;    3376  1      !       THIS SUBTEST IS THE MOST SIGNIFICANT PART OF THE ENTIRE PROGRAM. THE
;    3377  1      !       MULTI-DRIVE TEST IS A HOST-CONTROLLED EXERCISER DESIGNED TO GIVE THE
;    3378  1      !       USER AN INDICATION OF HOW ONE OR SEVERAL RDRX DRIVES WOULD PERFORM IN
;    3379  1      !       AN OPERATING SYSTEM ENVIRONMENT.
;    3380  1      !
;    3381  1      !       THIS ROUTINE ACTS AS AN "EXECUTIVE" TO THE WHOLE  ‹OCESS. AFTER
;    3382  1      !       INVOKIN" MD_INIT TO INITIALIZE MULTI DRIVE TEST DATA, THIS ROUTINE
;    3383  1      !       ENTERS   LOOP WHICH ISSUES QIOs TO ALL ACTIVE CONTROLLERS AND PROCESSES
;    3384  1      !       ANY RESPONSES. IN ADDITION, ALL OUTSTANDING COMMANDS ARE TIMED IN
;    3385  1      !       DRV_TIMCHK WHICH IS INVOKED EVERY SECOND. NORMAL TERMINATION OF THIS
;    3386  1      !       LOOP OCCURS WHEN QIOs ARE NO LONGER BEING ISSUED, AND ALL OUTSTANDING
;    3387  1      !       QIOS HAVE COMPLETED.
;    3388  1      !-
;    3389  1
;    3390  1
;    3391  2          begin
;    3392  2
;    3393  2          local
;    3394  2              CUR_PRIORITY : word;
;    3395  2
;    3396  2          label
;    3397  2              SEND_COMMANDS;
;    3398  2
;    3399  2          MD_INIT ();                                                 ! INIT MULTI-DRIVE TEST DATA
;    3400  2          INIT_OCCURED = TRUE;                                        !
;    3401  2
;    3402  2
;    3403  3          do  begin                                                   ! START OF EXECUTIVE LOOP
;    3404  3
;    3405  3              incr CTLR from 0 to (MAX_CTLR - 1) do                   ! FOR EACH CONTROLLER
;    3406  4                  begin
;    3407  4                  SET_CPAR (.CTLR);                                   ! SET UP CURRENT CONTROLLER PARAMETERS
;    3408  4                  GETPRI (CUR_PRIORITY);                              !
;    3409  4      !ZZZ        SETPRI (PRI04);                                     ! NO INTERRUPTS WHEN EXAMINING SA
;    3410  4                  SETPRI (.BRLEVEL);                                  ! NO INTERRUPTS WHEN EXAMINING SA          ZZ
Z
;    3411  4                  ICTLR = .CCTLR;                                     ! FAKE INTERRUPTING CONTROLLER'S NUMBER
;    3412  4                  ICST_ADDR = .CST_ADDR;                              ! FAKE INTERRUPTING CONTROLLER'S CST ADDR
;    3413  4                  IDCT_ADDR = .DCT_ADDR;                              ! FAKE INTERRUPTING CONTROLLER'S DCT ADDR
;    3414  4                  IRDRX_ADDR = .ICST_ADDR [IP_ADDR];                  ! FAKE INTERRUPTING CONTROLLER'S ADDRESS
;    3415  4                  IDCT_ADDR [SA_SAVE] = .IRDRX_ADDR [RCSA, RC_ALL];   ! CONTENTS OF THE SA REGISTER
;    3416  4
;    3417  5                  if BIT_TST (IDCT_ADDR [SA_SAVE], SA_ERR)            ! IF SA SHOWS AN ERROR
;    3418  4                  then
;    3419  5                      begin
;    3420  5                      FATAL_ERROR ();                                 ! DECLARE FATAL ERROR
;    3421  5                      SETPRI (.CUR_PRIORITY);                         ! LOWER PRIORITY
```

```
;    3422  5                    exitloop;                                          ! QUIT
;    3423  5                    end
;    3424  5
;    3425  4                else
;    3426  4                    SETPRI (.CUR_PRIORITY);                            ! IF NO ERROR, CONTINUE
;    3427  4
;    3428  4                if QIO_OK ()                                           ! IF O.K. TO ISSUE QIO(S) TO CONTROLLER
;    3429  4                then
;    3430  4                    SEND_COMMANDS:
;    3431  5                        begin
;    3432  5                        QIO_GEN ();                                    ! GENERATE 1 OR 2 QIOs
;    3433  5
;    3434  5                        if (.MX1 geq 0) and                            ! IF SUCCESS ON FIRST QIO
;    3435  6                           (not .EOP_FLAG)
;    3436  5                        then
;    3437  5
;    3438  5                            if SEND (.MX1) eql SUCCESS                 ! ATTEMPT TO SEND IT. IF SUCCESS
;    3439  5                            then
;    3440  6                            BEGIN                                      !ZZZ
;    3441  6                                QIO [.CTLR] = .QIO [.CTLR] + 1;        ! INCR OUTSTANDING QIO COUNT ZZZ
;    3442  6                            END                                        !ZZZ
;    3443  6
;    3444  5                            else
;    3445  6                                begin
;    3446  6                                PUT_PKT (.MX1);                        ! RETURN PACKET TO POOL
;    3447  6                                leave SEND_COMMANDS;
;    3448  5                                end;
;    3449  5
;    3450  5
;    3451  5                        if (.MX2 geq 0) and                            ! IF SUCCESS ON SECOND QIO
;    3452  6                           (not .EOP_FLAG)
;    3453  5                        then
;    3454  6                            begin
;    3455  6
;    3456  6                            do
;    3457  6                                BREAK                                  ! WAIT TILL 1 MORE SLOT AVAILABLE IN CRING
;    3458  6                            until (.DCT_ADDR [CRING_CNT] lssu CRING_LEN);  !
;    3459  6
;    3460  6                            if SEND (.MX2) eql SUCCESS                 ! ATTEMPT TO SEND IT.
;    3461  6                            then
;    3462  7                            BEGIN                                      !ZZZ
;    3463  7                                QIO [.CTLR] = .QIO [.CTLR] + 1;        ! IF SUCCESS, INCR OUTSTANDING QIO COUNT
;    3464  7                            END                                        !ZZZ
;    3465  7
;    3466  6                            else
;    3467  7                                begin
;    3468  7                                PRINTF (D8M121, .CRN_HIGH, .CRN_LOW
;    3469  7                                COMPARE_DATA = FALSE;                  ! NO SENSE IN COMPARING WRITE DATA
;    3470  7                                PUT_PKT (.MX2);                        ! RETURN PACKET TO POOL
;    3471  6                                end;
;    3472  6
;    3473  5                            end;
;    3474  5
```

```
;    3475  4                        end;                                    ! O.K. TO ISSUE QIO(S)
;    3476  3                    end;                                        ! CONTROLLER LOOP
;    3477  3
;    3478  3
;    3479  3                BREAK;                                          ! LET SUPERVISOR CATCH USER REQUESTS
;    3480  3                PROC_RETPKT ();                                 ! PROCESS ANY RETURN PACKETS
;    3481  3
;    3482  3                end                                             ! EXECUTIVE PROCESSING LOOP
;    3483  3            until ((not QIO_OUT ()) or
;    3484  4                   ((.DCT_ADDR [CRING_CNT] eql 0) and
;    3485  2                    (.EOP_FLAG)));
;    3486  2
;    3487  2
;    3488  2            DCT_ADDR [IG_INT] = TRUE;                           ! NO FURTHER INTERRUPTS ON THIS CONTROLLER
;    3489  2
;    3490  2
;    3491  1            end;                                                ! EXERCISER


                                        .SBTTL  MULTI.DRIVE MULTI-DRIVE TEST ROUTINES
000000  004137  000000G           MULTI.DRIVE::
                                        JSR     R1,$SAVE3                   ;                                   3372
000004  005746                         TST     -(SP)
000006  004737  000000V                 JSR     PC,MD.INIT                  ;                                   3399
000012  112737  000001  000000G         MOVB    #1,INIT.OCCURED             ;                                   3400
000020  005001                  1$:     CLR     R1                          ; CTLR                              3405
000022  010146                  2$:     MOV     R1,-(SP)                    ; CTLR,*                            3407
000024  004737  000000G                 JSR     PC,SET.CPAR
000030  104440                         TRAP    40                          ;                                   3408
000032  010003                         MOV     R0,R3                       ; *,CUR.PRIORITY
000034  013700  000000G                 MOV     BRLEVEL,R0                  ;                                   3410
000040  104441                         TRAP    41
000042  013737  000000G 000104'         MOV     CCTLR,ICTLP                 ;                                   3411
000050  013737  000000G 000076'         MOV     CST.ADDR,ICST.ADDR          ;                                   3412
000056  013737  000000G 000100'         MOV     DCT.ADDR,IDCT.ADDR          ;                                   3413
000064  013737  000076' 000000G         MOV     @ICST.ADDR,IRDRX.ADDR       ;                                   3414
000072  013700  000100                 MOV     @DCT.ADDR,R0                ;                                   3415
000076  013702  000000G                 MOV     IRDRX.ADDR,R2
000102  016266  000002  000002         MOV     2(R2),2(SP)                 ; *,RC.REG
000110  016660  000002  000002         MOV     2(SP),2(R0)                 ; RC.REG,*
000116  016600  000002                 MOV     2(SP),R0                    ;                                   3417
000122  042700  077777                 BIC     #77777,R0
000126  020027  100000                 CMP     R0,# 100000
000132  001006                         BNE     3$
000134  004737  000000V                 JSR     PC,FATAL.ERROR              ;                                   3420
000140  010300                         MOV     R3,R0                       ; CUR.PRIORITY,*                    3421
000142  104441                         TRAP    41
000144  005726                         TST     (SP)+                       ;                                   3419
000146  000511                         BR      9$
000150  010300                  3$:     MOV     R3,R0                       ; CUR.PRIORITY,*                    3426
000152  104441                         TRAP    41
000154  004737  000000V                 JSR     PC,QIO.OK                   ;                                   3428
000160  006000                         ROR     R0
```

```
000162  103077                          BCC     8$
000164  004737  000000V                 JSR     PC,QIO.GEN              ;                       3432
000170  013700  000110'                 MOV     MX1,R0                  ;                       3434
000174  002422                          BLT     5$
000176  132737  000001  000000G         BITB    #1,EOP.FLAG             ;                       3435
000204  001016                          BNE     5$
000206  010016                          MOV     R0,(SP)                 ;                       3438
000210  004737  000000G                 JSR     PC,SEND
000214  020027  000001                  CMP     R0,#1
000220  001003                          BNE     4$
000222  105261  000000G                 INCB    QIO(R1)                 ; *(CTLR)               3441
000226  000405                          BR      5$                      ;                       3438
000230  013716  000110'         4$:     MOV     MX1,(SP)                ;                       3446
000234  004737  000000G                 JSR     PC,PUT.PKT
000240  000450                          BR      8$                      ;                       3445
000242  005737  000112'         5$:     TST     MX2                     ;                       3451
000246  002445                          BLT     8$
000250  132737  000001  000000G         BITB    #1,EOP.FLAG             ;                       3452
000256  001041                          BNE     8$
000260  104422                  6$.     TRAP    22                      ;                       3456
000262  127727  000000G 000004          CMPB    @DCT.ADDR,#4            ;                       3458
000270  103373                          BHIS    6$
000272  013716  000112'                 MOV     MX2,(SP)                ;                       3460
000276  004737  000000G                 JSR     PC,SEND
000302  020027  000001                  CMP     R0,#1
000306  001003                          BNE     7$
000310  105261  000000G                 INCB    QIO(R1)                 ; *(CTLR)               3463
000314  000422                          BR      8$                      ;                       3460
000316  013716  000000G         7$:     MOV     CRN.LOW,(SP)            ;                       3468
000322  013746  000000G                 MOV     CRN.HIGH, (SP)
000326  012746  000000G                 MOV     #DBM121,-(SP)
000332  012746  000003                  MOV     #3, (SP)
000336  010600                          MOV     SP,R0                   ; SP,*
000340  104417                          TRAP    17
000342  105037  001262'                 CLRB    COMPARE.DATA            ;                       3469
000346  013716  000112'                 MOV     MX2,(SP)                ;                       3470
000352  004737  000000G                 JSR     PC,PUT.PKT
000356  062706  000006                  ADD     #6,SP                   ;                       3467
000362  005726                  8$.     TST     (SP)+                   ;                       3406
000364  005201                          INC     R1                      ; CTLR                  3405
000366  000243                          .WORD CLV!CLC

000370  003614                          BLE     2$
000372  104422                  9$:     TRAP    22                      ;                       3476
000374  004737  000000V                 JSR     PC,PROC.RETPKT          ;                       3480
000400  004737  000000V                 JSR     PC,QIO.OUT              ;                       3483
000404  006000                          ROR     R0
000406  103011                          BCC     10$
000410  105777  000000G                 TSTB    @DCT.ADDR               ;                       3484
000414  001201                          BNE     1$
000416  132737  000001  000000G         BITB    #1,EOP.FLAG             ;                       3485
000424  001002                          BNE     10$
000426  000137  007764'                 JMP     1$
```

```
000432  052777  040000  000000G          10$:    BIS     #40000,@DCT.ADDR                ;                       3488
000440  005726                                   TST     (SP)+                           ;                       3372
000442  000207                                   RTS     PC

; Routine Size:  146 words,     Routine Base:  $CODE$ + 7744
; Maximum stack depth per invocation:  11 words


;   3492  1
```

```
;    3493  1     GLOBAL routine MD_INIT : novalue =
;    3494  1
;    3495  1     !+
;    3496  1     !       THIS ROUTINE IS CALLED BY ROUTINE MULTI DRIVE TO INITIALIZE DATA ITEMS
;    3497  1     !       USED BY THE MULTI DRIVE TEST.
;    3498  1     !-
;    3499  1
;    3500  2         begin
;    3501  2
;    3502  2     !!ZZZ     local
;    3503  2     !!ZZZ     AVG_XFER_SIZE : word,                                   ! SIZE (BYTES) OF AN AVERAGE I/O XFER
;    3504  2     !!ZZZ     QUICK_PASS_CNT : word;                                  ! AVG NO. OF I/O OPERATIONS IN A QUICK PASS
;    3505  2
;    3506  2         if not .INIT_OCCURED                                          ! IF THIS IS A START
;    3507  2         then
;    3508  2             INIT_IO_BUFF ();                                          ! PARTITION FREE MEMORY INTO I/O BUFFERS
;    3509  2
;    3510  2         if (.ENTRY_REASON neq CONT) and                               ! IF START, RESTART, OR PWR FAIL
;    3511  3            (.ENTRY_REASON neq NEW_PASS)
;    3512  2         then
;    3513  2
;    3514  2             incr CTLR from 0 to (MAX_CTLR   1) do
;    3515  3                 begin
;    3516  3                 SET_CPAR (.CTLR);
;    3517  3
;    3518  4                 INCR DISK FROM (0 + OF_UN) TO (3 * UNIT_SIZE                    !ZZZ
;    3519  3                       + OF_UN) BY UNIT_SIZE DO                          !ZZZ
;    3520  4                       BEGIN                                             !ZZZ
;    3521  4                       SET_UPAR (.DISK);                                 !ZZZ
;    3522  4                       DPST [.L$LUN] = DP_CNT;        !INIT DATA PTRN SEQ TABLEZZZ
;    3523  3                       END;                                              !ZZZ
;    3524  3
;    3525  2                 END;                                                    !ZZZ
;    3526  2             INCR COUNT FROM 0 TO (QIO_PER_CTLR * MAX_CTLR - 1) DO   !INIT   !ZZZ
;    3527  2                  BUFF_OWN [.COUNT] =  1;             !I/O BUFF ALLOC TABLE   !ZZZ
;    3528  1             END;                                     !END MD INIT            !ZZZ


                                        .SBTTL  MD.INIT MULTI DRIVE TEST ROUTINES
 000000  004137  000000G           MD.INIT::
                                    JSR     R1,$SAVE2                       ;                                       3493
 000004  132737  000001  000000G           BITB    #1,INIT.OCCURED         ;                                       3506
 000012  001002                     BNE     1$
 000014  004737  000000V           JSR     PC,INIT.IO.BUFF                 ;                                       3508
 000020  123727  000000G 000003    1$:     CMPB    ENTRY.REASON,#3         ;                                       3510
 000026  001433                     BEQ     4$
 000030  123727  000000G 000005           CMPB    ENTRY.REASON,#5         ;                                       3511
 000036  001427                     BEQ     4$
 000040  005002                     CLR     R2                              ; CTLR                                  3514
 000042  010246                    2$:     MOV     R2,-(SP)                ; CTLR,*                                3516
 000044  004737  000000G           JSR     PC,SET.CPAR
 000050  012701  000003            MOV     #3,R1                           ; *,DISK                                3518
 000054  010116                    3$:     MOV     R1,(SP)                 ; DISK,*                                3521
```

```
000056  004737  000000G                         JSR     PC,SET.UPAR
000062  013700  000000G                         MOV     L$LUN,R0                ;                                       3522
000066  112760  000025  000050'                 MOVB    #25,DPST(R0)
000074  062701  000012                          ADD     #12,R1                  ; *,DISK                                3518
000100  020127  000041                          CMP     R1,#41                  ; DISK,*
000104  003763                                  BLE     3$
000106  005726                                  TST     (SP)+                   ;                                       3515
000110  005202                                  INC     R2                      ; CTLR                                  3514
000112  000243                                  .WORD CLV!CLC

000114  003752                                  BLE     2$
000116  005000                          4$:     CLR     R0                      ; COUNT                                 3526
000120  112760  000377  000000G         5$:     MOVB    #377,BUFF.OWN(R0)       ; *,*(COUNT)                            3527
000126  005200                                  INC     R0                      ; COUNT                                 3526
000130  020027  000007                          CMP     R0,#7                   ; COUNT,*
000134  003771                                  BLE     5$
000136  000207                                  RTS     PC                      ;                                       3493

; Routine Size:  48 words,      Routine Base:  $CODE$ + 10410
; Maximum stack depth per invocation:  5 words


;   3529  1
```

```
;    3530  1     GLOBAL routine INIT_IO_BUFF : novalue =
;    3531  1
;    3532  1     !+
;    3533  1     !       THIS ROUTINE IS CALLED BY MD_INIT WHEN THE MULTI DRIVE TEST IS FIRST
;    3534  1     !       STARTED. IT IS RESPONSIBLE FOR PARTITIONING FREE MEMORY INTO A
;    3535  1     !       COLLECTION OF I/O BUFFERS. THE SIZE OF EACH I/O BUFFER IS DETERMINED
;    3536  1     !       BY A NUMBER OF FACTORS, INCLUDING THE NUMBER OF UNITS, THE NUMBER OF
;    3537  1     !       CONTROLLERS, AND THE SIZE OF FREE MEMORY.
;    3538  1     !
;    3539  1     !       ONCE THE BUFFER SIZE IS DETERMINED, THE NUMBER OF I/O BUFFERS IS
;    3540  1     !       CALCULATED. FINALLY, THE BUFFER ADDRESS (BUFF_ADDR) TABLE IS LOADED
;    3541  1     !       WITH FIXED BUFFER DESCRIPTORS THAT ARE USED IN THE ALLOCATION AND
;    3542  1     !       DEALLOCATION PROCESS.
;    3543  1     !
;    3544  1     !       IMPLICIT INPUTS:
;    3545  1     !               CTLR_CNT - THE NUMBER OF CONTROLLERS CONFIGURED
;    3546  1     !               L$UNIT - THE NUMBER OF UNITS AVAILABLE FOR TESTING
;    3547  1     !               FREE MEM_ADDR - START OF FREE MEMORY
;    3548  1     !-
;    3549  1
;    3550  2         begin
;    3551  2         BUFF_ADDR [0] = (.FREE_MEM_ADDR + 2 + 1) and %o'177776';                ! START OF READ/WRITE BUFFERS
;    3552  2
;    3553  2         while (.BUFF_ADDR [0] and %o'37') neq 0 do                              ! FORCE FIRST I/O BUFFER TO START
;    3554  2             BUFF_ADDR [0] = .BUFF_ADDR [0] + 2;                                 ! ON EVEN BOUNDARY
;    3555  2
;    3556  2         BYTS_PER_QIO = ((.DRS_START - .BUFF_ADDR [0]) / (QIO_PER_CTLR * MAX_CTLR)) and %o'177740';
;    3557  2                                                                                 ! MAX TRANSFER SIZE
;    3558  2
;    3559  2         if .BYTS_PER_QIO gtru MAX_XFER_SIZE
;    3560  2         then
;    3561  2             BYTS_PER_QIO = MAX_XFER_SIZE;                                       ! ADJUST TRANSFER SIZE LOWER
;    3562  2
;    3563  2         if .BYTS_PER_QIO lssu 32
;    3564  2         then
;    3565  3             begin
;    3566  3             ERRSF (2, EGS_02, 0);                                               ! ERROR IF NOT ENOUGH MEMORY
;    3567  3             DOCLN;
;    3568  2             end;
;    3569  2
;    3570  2         if (QIO_PER_CTLR * MAX_CTLR) gtru 1
;    3571  2         then
;    3572  2
;    3573  2             incr index from 1 to (QIO_PER_CTLR * MAX_CTLR - 1) do               ! INIT REMAINING TABLE ENTRIES
;    3574  2                 BUFF_ADDR [.index] = .BUFF_ADDR [.index - 1] + .BYTS_PER_QIO;   ! FIXED BUFFER ADDRESS
;    3575  2
;    3576  1         end;                                                                    ! ROUTINE INIT IO BUFF


                                        .SBTTL  INIT.IO.BUFF MULTI-DRIVE TEST ROUTINES
000000  004137  000000G           INIT.IO.BUFF::
                                        JSR     R1,$SAVE3                       ;                                       3530
000004  013700  000000G                 MOV     FREE.MEM.ADDR,R0                ;                                       3551
```

```
000010  062700  000003                          ADD     #3,R0
000014  010037  000000G                         MOV     R0,BUFF.ADDR
000020  042737  000001  000000G                 BIC     #1,BUFF.ADDR
000026  032737  000037  000000G         1$:     BIT     #37,BUFF.ADDR                   ;                       3553
000034  001404                                  BEQ     2$
000036  062737  000002  000000G                 ADD     #2,BUFF.ADDR                    ;                       3554
000044  000770                                  BR      1$                              ;                       3553
000046  013746  C01250'                 2$:     MOV     DRS.START, (SP)                 ;                       3556
000052  163716  000000G                         SUB     BUFF.ADDR,(SP)
000056  012746  000010                          MOV     #10, (SP)
000062  004737  000000G                         JSR     PC,BL$DIV
000066  010037  000000G                         MOV     R0,BYTS.PER.QIO
000072  042737  000037  000000G                 BIC     #37,BYTS.PER.QIO
000100  023727  000000G 001400                  CMP     BYTS.PER.QIO,#1400              ;                       3559
000106  101403                                  BLOS    3$
000110  012737  001400  000000G                 MOV     #1400,BYTS.PER.QIO              ;                       3561
000116  023727  000000G 000040         3$:     CMP     BYTS.PER.QIO,#40                ;                       3563
000124  103005                                  BHIS    4$
000126  104454                                  TRAP    54                              ;                       3566
000130  000002                                  .WORD   2
000132  000000G                                 .WORD   EGS.02
000134  000000                                  .WORD   0
000136  104444                                  TRAP    44
000140  012702  000001                 4$:     MOV     #1,R2                           ; *,INDEX               3570
000144  010200                         5$:     MOV     R2,R0                           ; INDEX,*               3574
000146  006300                                 ASL     R0
000150  010201                                 MOV     R2,R1                           ; INDEX,*
000152  006301                                 ASL     R1
000154  016103  177776G                         MOV     BUFF.ADDR-2(R1),R3
000160  063703  000000G                         ADD     BYTS.PER.QIO,R3
000164  010360  000000G                         MOV     R3,BUFF.ADDR(R0)
000170  005202                                 INC     R2                              ; INDEX                 3570
000172  020227  000007                         CMP     R2,#7                           ; INDEX,*
000176  003762                                 BLE     5$
000200  022626                                 CMP     (SP)+,(SP)+                     ;                       3550
000202  000207                                 RTS     PC                              ;                       3530

; Routine Size:  66 words,      Routine Base:  $CODE$ + 10550
; Maximum stack depth per invocation:  8 words
```

```
;    3577  1      GLOBAL routine QIO_OK =
;    3578  1
;    3579  1
;    3580  1      !+
;    3581  1      !       THIS ROUTINE IS CALLED BY THE MULTI_DRIVE "EXECUTIVE" IN ORDER TO
;    3582  1      !       DETERMINE WHETHER OR NOT A QIO REQUEST (OR QIO PAIR) SHOULD BE
;    3583  1      !       GENERATED TO THE CURRENT CONTROLLER. A VALUE OF "TRUE" IS RETURNED IF
;    3584  1      !       THE CONTROLLER MEETS 3 REQUIREMENTS:
;    3585  1      !
;    3586  1      !               A. THE CONTROLLER IS ONLINE;
;    3587  1      !               B. THE NUMBER OF OUTSTANDING QIOs IS AT LEAST 2 LESS THAN THE
;    3588  1      !                       MAXIMUM ALLOWED FOR ANY ONE CONTROLLER;
;    3589  1      !               C. THERE IS AT LEAST ONE DISK ONLINE TO THE CONTROLLER.
;    3590  1      !
;    3591  1      !       IF ANY OF THESE TEST FAIL, THEN A VALUE OF "FALSE' IS RETURNED.
;    3592  1      !
;    3593  1      !       IMPLICIT INPUTS:
;    3594  1      !               CCTLR - CURRENT CONTROLLER NUMBER
;    3595  1      !               CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
;    3596  1      !-
;    3597  1
;    3598  1
;    3599  2          begin
;    3600  2
;    3601  2          local                                                   !MMM
;    3602  2
;    3603  2              MILLISECOND : WORD,                                 !MMM
;    3604  2              DUTY_CYCLE : WORD;                                  !MMM
;    3605  2
;    3606  2
;    3607  2          MILLISECOND = .CLK_TICKS mod 60;                       !MMM
;    3608  2
;    3609  2          if (.CST_ADDR [STATE] eql ONLINE) and                   ! IF CONTROLLER IS ONLINE
;    3610  2             (not .EOP_FLAG) and
;    3611  2      !MMM   ((.QIO [.CCTLR] + 2) lequ QIO_PER_CTLR) and          ! IF OUTSTANDING QIO COUNT IS O.K.
;    3612  2             (.QIO [.CCTLR] lequ (CRING_LEN-2)) and              ! IF OUTSTANDING QIO COUNT IS O.K.     MMM
;    3613  2             (.CST_ADDR [U_CNT] neq 0) and                       ! IF THERE IS VALID UNIT
;    3614  3             ((not .EL_FLUSH [.CCTLR]) or (.QIO [.CCTLR] eqlu 0))    ! MMM
;    3615  3
;    3616  2          then
;    3617  3              begin                                               ! MMM
;    3618  3      !        if .CSR_MEM and .TST_PAR                           ! MMM
;    3619  3      !        then                                               ! MMM
;    3620  3      !           if not .PAR_TSD                                 ! MMM
;    3621  3      !           then
;    3622  3      !              if .QIO [.CCTLR] geq 1                       ! MMM PROCESS ONE COMMAND AT A TIME UNTIL
;    3623  3      !              then                                         ! PARITY TEST IS COMPLETE
;    3624  3      !                 return FALSE;
;    3625  3              EL_FLUSH [.CCTLR] = 0;                              ! MMM
;    3626  3      !        if (((not .TST_PAR) or (.TST_PAR and .PAR_TSD)) and (.SWP XFER NEQ 0))          ! MMM
;    3627  3      !        then
;    3628  3              if .MAN_TST                                 ! MMM
;    3629  3              then                                        ! MMM
```

```
;  3630  3              if (DUTY_CYCLE = .MILLISECOND mod 60) gtru 15     !LOOK AT 'CURRENT SECOND' MMM
;  3631  3              then
;  3632  3                  return FALSE;                                 !FIRST 15 OF 60 TICKS (=1 SECOND) IS 25% DUTY CYCLE MMM
;  3633  3          return TRUE;                                            ! "TRUE" EXIT POINT
;  3634  3          end
;  3635  2      else
;  3636  2          return FALSE;                                           ! "FALSE" EXIT POINT
;  3637  2
;  3638  1      end;                                                        !MMM


                                        .SBTTL  QIO.OK MULTI-DRIVE TEST ROUTINES
000000  004137  000000G          QIO.OK::JSR     R1,$SAVE2                       ;                                3577
000004  013746  000000G                  MOV     CLK.TICKS,-(SP)                 ;                                3607
000010  012746  000074                   MOV     #74,-(SP)
000014  004737  000000G                  JSR     PC,BL$MOD
000020  013701  000000G                  MOV     CST.ADDR,R1                     ;                                3609
000024  005761  000002                   TST     2(R1)
000030  100061                          BPL     3$
000032  132737  000001  000000G         BITB    #1,EOP.FLAG                     ;                                3610
000040  001055                          BNE     3$
000042  013701  000000G                  MOV     CCTLR,R1                        ;                                3612
000046  126127  000000G 000002          CMPB    QIO(R1),#2
000054  101047                          BHI     3$
000056  013701  000000G                  MOV     CST.ADDR,R1                     ;                                3613
000062  105761  000005                   TSTB    5(R1)
000066  001442                          BEQ     3$
000070  013701  000000G                  MOV     CCTLR,R1                        ;                                3614
000074  010102                          MOV     R1,R2
000076  006302                          ASL     R2
000100  032762  000001  000106'         BIT     #1,EL.FLUSH(R2)
000106  001403                          BEQ     1$
000110  105761  000000G                  TSTB    QIO(R1)
000114  001027                          BNE     3$
000116  013701  000000G          1$:     MOV     CCTLR,R1                        ;                                3625
000122  006301                          ASL     R1
000124  005061  000106'                  CLR     EL.FLUSH(R1)
000130  032737  000001  000000G         BIT     #1,MAN.TST                      ;                                3628
000136  001413                          BEQ     2$
000140  010016                          MOV     R0,(SP)                         ; MILLISECOND,*                  3630
000142  012746  000074                   MOV     #74, (SP)
000146  004737  000000G                  JSR     PC,BL$MOD
000152  005726                          TST     (SP)+
000154  020027  000017                   CMP     R0,#17                          ; DUTY.CYCLE,*
000160  101402                          BLOS    2$
000162  022626                          CMP     (SP)+,(SP)+                     ;                                3632
000164  000406                          BR      5$
000166  012700  000001          2$:     MOV     #1,R0                           ;                                3636
000172  000401                          BR      4$
000174  005000                  3$:     CLR     R0
000176  022626                  4$:     CMP     (SP)+,(SP)+                     ;                                3609
000200  000207                          RTS     PC                              ;                                3599
000202  005000                  5$:     CLR     R0                              ;                                3577
```

```
000204  000207                                  RTS     PC

; Routine Size:  67 words,      Routine Base:  $CODE$ + 10754
; Maximum stack depth per invocation:  7 words


;   3639  1
```

```
;    3640  1      GLOBAL routine QIO_OUT =
;    3641  1
;    3642  1      !+
;    3643  1      !       THIS ROUTINE IS CALLED BY THE MULTI_DRIVE EXECUTIVE FOR DETERMINING THE
;    3644  1      !       END OF THE MULTI DRIVE TEST. ITS PURPOSE IS TO EXAMINE THE QIO VECTOR
;    3645  1      !       FOR ANY OUTSTANDING QIOs ON ANY CONTROLLER. A VALUE OF "TRUE" IS
;    3646  1      !       RETURNED IF THERE IS AT LEAST ONE QIO OUTSTANDING ON ANY CONTROLLER.
;    3647  1      !       OTHERWISE, "FALSE" IS RETURNED INDICATING NO OUTSTANDING QIOs.
;    3648  1      !-
;    3649  1
;    3650  2          begin
;    3651  2
;    3652  2          incr CTLR from 0 to (MAX_CTLR - 1) do
;    3653  3              begin
;    3654  3              SET_CPAR (.CTLR);                       ! SET UP CURRENT CONTROLLER PARAMETERS
;    3655  3
;    3656  3              if .CST_ADDR [STATE] eql ONLINE         ! IF CONTROLLER IS ONLINE
;    3657  3              then
;    3658  3                  return TRUE;
;    3659  3
;    3660  2              end;
;    3661  2
;    3662  2          return FALSE;                               ! EXIT - NO CONTROLLERS ONLINE
;    3663  1          end;


                                        .SBTTL  QIO.OUT MULTI-DRIVE TEST ROUTINES
000000  010146                  QIO.OUT::
                                        MOV     R1,-(SP)                        ;                       3640
000002  005001                          CLR     R1                              ; CTLR                  3652
000004  010146                  1$:     MOV     R1,-(SP)                        ; CTLR,*                3654
000006  004737  000000G                 JSR     PC,SET.CPAR
000012  013700  000000G                 MOV     CST.ADDR,R0                     ;                       3656
000016  005760  000002                  TST     2(R0)
000022  100004                          BPL     2$
000024  005726                          TST     (SP)+                           ;                       3658
000026  012700  000001                  MOV     #1,R0
000032  000405                          BR      3$
000034  005726                  2$:     TST     (SP)+                           ;                       3653
000036  005201                          INC     R1                              ; CTLR                  3652
000040  000243                          .WORD CLV!CLC

000042  003760                          BLE     1$
000044  005000                          CLR     R0                              ;                       3650
000046  012601                  3$:     MOV     (SP)+,R1                        ;                       3640
000050  000207                          RTS     PC

; Routine Size:  21 words,      Routine Base:  $CODE$ + 11162
; Maximum stack depth per invocation:  3 words
```

```
;    3664  1      GLOBAL routine QIO_GEN : novalue =
;    3665  1
;    3666  1      !+
;    3667  1      !       THIS ROUTINE IS CALLED BY THE MULTI_DRIVE EXECUTIVE FOR AN ONLINE
;    3668  1      !       CONTROLLER ELIGIBLE TO RECEIVE I/O TRANSFER REQUESTS. IT IS
;    3669  1      !       RESPONSIBLE FOR SECURING ONE OR TWO MSCP PACKETS AND LOADING THEM
;    3670  1      !       WITH VARIOUS PARAMETERS COMPRISING THE I/O REQUEST. THE I/O REQUEST
;    3671  1      !       GENERATED HERE IS DESTINED TO A PARTICULAR UNIT SELECTED AT RANDOM FROM
;    3672  1      !       THOSE CONFIGURED UNDER THE CURRENT CONTROLLER.
;    3673  1      !
;    3674  1      !       EACH FIELD OF THE PACKET(S) IS LOADED WITHIN INDIVIDUAL ROUTINES
;    3675  1      !       (QIO_FUNC, QIO_LBN, QIO_SIZE, ETC.). MOST OF THE VALUES SELECTED FOR
;    3676  1      !       EACH FIELD ARE BASED ON A SET OF RANDOM NUMBER GENERATED AT THE START.
;    3677  1      !
;    3678  1      !       UNDER NORMAL CIRCUMSTANCES, ONLY ONE I/O REQUEST IS GENERATED. HOWEVER,
;    3679  1      !       IF THIS I/O REQUEST IS A "WRITE", AND IF THE OPERATOR SELECTED THE
;    3680  1      !       OPTION FOR HOST WRITE-COMPARES, THEN A SECOND "READ" REQUEST WILL BE
;    3681  1      !       GENERATED WITH THE SAME LBN AND BYTE COUNT.
;    3682  1      !
;    3683  1      !       AFTER THE PACKET(S) HAVE BEEN LOADED, THIS ROUTINE REGAINS CONTROL
;    3684  1      !       AND ATTEMPTS TO GET ONE OR TWO I/O BUFFERS FOR THE ACTUAL DATA
;    3685  1      !       TRANSFERS. THE SUCCESS / FAIL STATUS OF THIS ENTIRE OPERATION IS
;    3686  1      !       PASSED BACK TO THE CALLER THROUGH THE GLOBALS "MX1" AND "MX2"; THEY
;    3687  1      !       CONTAIN VALID MSCP PACKET INDECES, OR -1.
;    3688  1      !
;    3689  1      !       IMPLICIT INPUTS:
;    3690  1      !               CCTLR - CURRENT CONTROLLER NUMBER
;    3691  1      !-
;    3692  1
;    3693  2          begin
;    3694  2          MX2 = -1;                                   ! ASSUME FAILURE IN SECURING 2ND PACKET
;    3695  2
;    3696  2          if (MX1 = GET_PKT (.CCTLR)) lss 0           ! TRY TO GET 1ST PACKET. IF FAILURE
;    3697  2          then
;    3698  2              return;                                 ! NO POINT IN CONTINUING
;    3699  2
;    3700  2          if (MX2 = GET_PKT (.CCTLR)) lss 0           ! TRY TO GET 2ND PACKET. IF FAILURE
;    3701  2          then
;    3702  3              begin
;    3703  3              PUT_PKT (.MX1);                         ! RETURN 1ST PACKET TO POOL
;    3704  3              MX1 = -1;                               ! INDICATE FAILURE
;    3705  3              return;                                 ! DONE
;    3706  2              end;
;    3707  2
;    3708  2          MAD1 = MSCP_PKT + (.MX1 * PKT_LEN * 2);     ! CALCULATE STARTING ADDRESSES
;    3709  2          MAD2 = MSCP_PKT + (.MX2 * PKT_LEN * 2);     !     OF BOTH PACKETS
;    3710  2          GET_RANDOM ();                              ! GENERATE A SET OF RANDOM NUMBERS
;    3711  2          QIO_UNIT ();                                ! LOAD RANDOM UNIT NUMBER INTO PACKETS
;    3712  2
;    3713  2          if .EOP_FLAG                                ! RETURN IF NO UNIT ONLINE
;    3714  2          then
;    3715  2              return;
;    3716  2
```

```
;  3717  2          QIO_FUNC ();                            ! LOAD RANDOM FUNCTION CODE (OPCODE)
;  3718  2          QIO_LBN ();                             ! LOAD LBN (RANDOM OR SEQUENTIAL)
;  3719  2          QIO_SIZE ();                            ! LOAD RANDOM BYTE COUNT
;  3720  2          GET_IO_BUFF (MAD1 [BUF_0]);             ! TRY TO GET AN I/O BUFFER
;  3721  2
;  3722  2          if .MX2 geq 0                           ! IF TWO QIOs ARE TO BE ISSUED
;  3723  2          then
;  3724  3              begin
;  3725  3              GET_IO_BUFF (MAD2 [BUF_0]);         ! TRY TO GET 2ND I/O BUFFER
;  3726  3
;  3727  3              if .MAD2 [BUF_0] eqla 0             ! IF 2ND BUFFER ALLOCATION FAILED
;  3728  3              then
;  3729  4                  begin
;  3730  4
;  3731  4                  if .MAD1 [BUF_0] neqa 0         ! IF 1ST I/O BUFFER WAS ALLOCATED
;  3732  4                  then
;  3733  5                      begin
;  3734  5                      PUT_IO_BUFF (MAD1 [BUF_0]); ! RETURN 1ST I/O BUFFER TO POOL
;  3735  5                      MAD1 [BUF_0] = 0;           ! MARK IT AS FAILED
;  3736  4                      end;
;  3737  4
;  3738  4                  PUT_PKT (.MX2);                 ! RETURN 2ND PACKET TO POOL
;  3739  4                  MX2 = -1;                       ! INDICATE FAILURE
;  3740  3                  end;                            ! IF 2ND I/O BUFFER ALLOCATION FAILED
;  3741  3
;  3742  2              end;                                ! IF TWO QIOs ARE TO BE ISSUED
;  3743  2
;  3744  2          if .MAD1 [BUF_0] eqla 0                 ! IF 1ST I/O BUFFER ALLOCATION FAILED
;  3745  2          then
;  3746  3              begin
;  3747  3              PUT_PKT (.MX1);                     ! RETURN 1ST PACKET TO POOL
;  3748  3              MX1 = -1;                           ! INDICATE FAILURE
;  3749  3              end
;  3750  2          else
;  3751  2
;  3752  2              if .MAD1 [OPCODE] eql OP_WRT        ! OTHERWISE, IF 1ST OPCODE IS A WRITE  (ALL IS O.K.)
;  3753  2              then
;  3754  2                  FILL_BUFF ();                   ! FILL 1ST I/O BUFFER WITH APPROPRIATE DATA PATTERN
;  3755  2
;  3756  1          end;                                    ! ROUTINE QIO_GEN

                                        .SBTTL  QIO.GEN MULTI-DRIVE TEST ROUTINES
000000  012737  177777  000112'  QIO.GEN::
                                        MOV     #-1,MX2                 ;                       3694
000006  013746  000000G                 MOV     CCTLR,-(SP)             ;                       3696
000012  004737  000000G                 JSR     PC,GET.PKT
000016  010037  000110'                 MOV     R0,MX1
000022  005726                          TST     (SP)+
000024  005700                          TST     R0                      ; MX1
000026  002563                          BLT     6$                      ;                       3698
000030  013746  000000G                 MOV     CCTLR,-(SP)             ;                       3700
000034  004737  000000G                 JSR     PC,GET.PKT
```

```
000040  010037  000112'                        MOV     R0,MX2
000044  005726                                 TST     (SP)+
000046  005700                                 TST     R0              ; MX2
000050  002011                                 BGE     1$
000052  013746  000110'                        MOV     MX1,-(SP)       ;                       3703
000056  004737  000000G                        JSR     PC,PUT.PKT
000062  012737  177777  000110'                MOV     #-1,MX1         ;                       3704
000070  005726                                 TST     (SP)+           ;                       3705
000072  000207                                 RTS     PC              ;                       3702
000074  013746  000110'             1$:        MOV     MX1, (SP)       ;                       3708
000100  012746  000106                         MOV     #106,-(SP)
000104  004737  000000G                        JSR     PC,BL$MUL
000110  062700  000000G                        ADD     #MSCP.PKT,R0
000114  010037  000114'                        MOV     R0,MAD1
000120  013716  000112'                        MOV     MX2,(SP)        ;                       3709
000124  012746  000106                         MOV     #106,-(SP)
000130  004737  000000G                        JSR     PC,BL$MUL
000134  062700  000000G                        ADD     #MSCP.PKT,R0
000140  010037  000116'                        MOV     R0,MAD2
000144  004737  000000V                        JSR     PC,GET.RANDOM   ;                       3710
000150  004737  000000V                        JSR     PC,QIO.UNIT     ;                       3711
000154  132737  000001  000000G                BITB    #1,EOP.FLAG     ;                       3713
000162  001103                                 BNE     5$              ;                       3664
000164  004737  000000V                        JSR     PC,QIO.FUNC     ;                       3717
000170  004737  000000V                        JSR     PC,QIO.LBN      ;                       3718
000174  004737  000000V                        JSR     PC,QIO.SIZE     ;                       3719
000200  013716  000114                         MOV     MAD1,(SP)       ;                       3720
000204  062716  000032                         ADD     #32,(SP)
000210  004737  000000G                        JSR     PC,GET.IO.BUFF
000214  005737  000112'                        TST     MX2             ;                       3722
000220  002437                                 BLT     3$
000222  013716  000116'                        MOV     MAD2,(SP)       ;                       3725
000226  062716  000032                         ADD     #32,(SP)
000232  004737  000000G                        JSR     PC,GET.IO.BUFF
000236  013700  000116'                        MOV     MAD2,R0         ;                       3727
000242  005760  000032                         TST     32(R0)
000246  001024                                 BNE     3$
000250  013700  000114                         MOV     MAD1,R0         ;                       3731
000254  062700  000032                         ADD     #32,R0
000260  005710                                 TST     (R0)
000262  001407                                 BEQ     2$
000264  010016                                 MOV     R0,(SP)         ;                       3734
000270  004737  000000G                        JSR     PC,PUT.IO.BUFF
000274  013700  000114'                        MOV     MAD1,R0         ;                       3735
000300  005060  000032                         CLR     32(R0)
000302  013716  000112             2$:        MOV     MX2,(SP)        ;                       3738
000306  004737  000000G                        JSR     PC,PUT.PKT
000312  012737  177777  000112                MOV     #-1,MX2         ;                       3739
000320  013700  000114'             3$:        MOV     MAD1,R0         ;                       3744
000324  005760  000032                         TST     32(R0)
000330  001010                                 BNE     4$
000332  013716  000110                         MOV     MX1,(SP)        ;                       3747
000336  004737  000000G                        JSR     PC,PUT.PKT
```

```
000342  012737  177777  000110'                MOV     #-1,MX1                         ;                       3748
000350  000410                                 BR      5$                              ;                       3744
000352  013700  000114'                4$:     MOV     MAD1,R0                         ;                       3752
000356  126027  000022  000042                CMPB    22(R0),#42
000364  001002                                 BNE     5$
000366  004737  000000V                        JSR     PC,FILL.BUFF                    ;                       3754
000372  062706  000006                5$:     ADD     #6,SP                           ;                       3693
000376  000207                        6$:     RTS     PC                              ;                       3664

; Routine Size:  128 words,     Routine Base:  $CODE$ + 11234
; Maximum stack depth per invocation:  4 words
```

```
;    3757  1      GLOBAL rout ne GET RANDOM : novalue =
;    3758  1
;    3759  1      !+
;    3760  1      !       THIS ROUTINE IS CALLED BY QIO_GEN TO GENERATE A SET OF RANDOM NUMBERS,
;    3761  1      !       AND TO STORE THEM INTO THE RANDOM NUMBER TABLE (RANDOM). THE RANDOM
;    3762  1      !       NUMBERS ARE USED TO SELECT I/O REQUEST PARAMETERS FOR THE CURRENT QIO
;    3763  1      !       OR QIO PAIR. IN ADDITION, IF DATA PATTERN #1 IS BEING USED, THESE
;    3764  1      !       RANDOM NUMBERS WILL BE USED IN THE WRITE OPERATION.
;    3765  1      !-
;    3766  1
;    3767  2          begin
;    3768  2
;    3769  2          own
;    3770  2              SEED : word initial (173),
;    3771  2              NEXT_RANDNUM : word initial (245);
;    3772  2
;    3773  2          incr COUNT from 0 to (RDM_LEN - 1) do
;    3774  3              begin
;    3775  3              SEED = (.SEED * .NEXT_RANDNUM + 1) & 4;
;    3776  3              NEXT_RANDNUM = (.NEXT_RANDNUM / 4) + .SEED;
;    3777  3              RANDOM [.COUNT] = .NEXT_RANDNUM;
;    3778  2              end;
;    3779  2
;    3780  1          end;


001272                                  .PSECT  $GGG$,  RO
001272  000255                SEED:     .WORD   255
001274  000365                NEXT.RANDNUM:
                                        .WORD   365


                                        .SBTTL  GET.RANDOM MULTI DRIVE TEST ROUTINES
011634                                  .PSECT  $CODE$,  PO

000000  004137  000000G       GET.RANDOM::
                                        JSR     R1,$SAVE3                       ;                       3757
000004  013703  001272'                 MOV     SEED,R3                         ;                       3775
000010  013702  001274'                 MOV     NEXT.RANDNUM,R2
000014  005001                          CLR     R1                              ; COUNT                 3773
000016  010200                1$:       MOV     R2,R0                           ;                       3775
000020  060300                          ADD     R3,R0
000022  006300                          ASL     R0
000024  006300                          ASL     R0
000026  010037  001272'               MOV     R0,SEED
000032  062737  000004  001272'        ADD     #4,SEED
000040  010246                          MOV     R2,-(SP)                        ;                       3776
000042  012746  000004                 MOV     #4, (SP)
000046  004737  000000G               JSR     PC,BL$DIV
000052  013703  001272'               MOV     SEED,R3
000056  060300                          ADD     R3,R0
000060  010037  001274'               MOV     R0,NEXT.RANDNUM
```

```
000064  010002                          MOV     R0,R2                   ; NEXT.RANDNUM,*                        3777
000066  010261  000000G                 MOV     R2,RANDOM(R1)           ; *,*(COUNT)
000072  022626                          CMP     (SP)+,(SP)+             ;                                       3774
000074  062701  000002                  ADD     #2,R1                   ; *,COUNT                               3773
000100  020127  000036                  CMP     R1,#36                  ; COUNT,*
000104  003744                          BLE     1$
000106  000207                          RTS     PC                      ;                                       3757

; Routine Size:  36 words,      Routine Base:  $CODE$ + 11634
; Maximum stack depth per invocation:  7 words
```

```
;    3781  1
;    3782  1      GLOBAL routine RANDY : novalue =
;    3783  1
;    3784  1      !+
;    3785  1      !       THIS ROUTINE GENERATES A 32-BIT RANDOM NUMBER. THE LOW 16 BITS
;    3786  1      !       ARE OUTPUT IN "RNDY0". THE HIGH 16 BITS ARE OUTPUT IN "RNDY1".
;    3787  1      !
;    3788  1      !       THE LOW 3 BITS OF CLK_TICKS SELECTS A WORD FROM 'RNDYIN'. THIS
;    3789  1      !       IS 'R_STRING'. FRAME_CNT (0-9) SELECTS A 7-BIT FRAME OF THIS
;    3790  1      !       WORD. BITS OF THIS FRAME ARE USED AS FOLLOWS:
;    3791  1      !
;    3792  1      !            BITS 0-2 ... SELECT A PATTERN FOR LOW WORD.
;    3793  1      !            BITS 1-3 ... SELECT A PATTERN FOR HIGH WORD.
;    3794  1      !            BIT   4  ... IF 1, SHIFT PATTERN LEFT.
;    3795  1      !            BITS 4-6 ... SELECTS MASKS FOR FINAL OUTPUT.
;    3796  1      !
;    3797  1      !-
;    3798  1
;    3799  2          begin
;    3800  2
;    3801  2          local
;    3802  2            PAT_LO: WORD,                                   !LO WORD OF PATTERN
;    3803  2            PAT_HI: WORD,                                   !HI WORD OF PATTERN
;    3804  2            SHIFT : WORD,                                   !LEFT-SHIFT BIT
;    3805  2            MSKNO : WORD;                                   !WHICH MASK TO USE
;    3806  2
;    3807  2
;    3808  2         IF .FRAME_CNT EQLU 0                               !IF IT'S TIME TO SAMPLE CLOCK AGAIN
;    3809  2         THEN
;    3810  3            BEGIN
;    3811  3            R_STRING = .RNDYIN [.CLK_TICKS AND 7]           !CLOCK BITS SELECT 16 BIT STRING
;    3812  2            END;
;    3813  2
;    3814  2
;    3815  2         PAT_LO = .RNDYIN [(.R_STRING + .FRAME_CNT) AND 7];     !BITS 0-2 OF FRAME SELECT LO WD OF PATTERN
;    3816  2         PAT_HI = .RNDYIN [(.R_STRING +( 1 -.FRAME_CNT)) AND 7];!BITS 1-3 OF FRAME SELECT HI WD OF PATTERN
;    3817  2
;    3818  2
;    3819  2         SHIFT =  (.R_STRING + (-4 -.FRAME_CNT)) AND 1;         !BIT 4 OF FRAME IS SHIFTER.
;    3820  2         PAT_LO =  .PAT_LO + .SHIFT;                            !SHIFT PATTERN IF SHIFTER = 1
;    3821  2         PAT_HI = (.PAT_HI + .SHIFT) + .SHIFT;                  !SHIFT PATTERN AND ADD 1 IF SHIFTER = 1
;    3822  2
;    3823  2
;    3824  2         MSKNO = (.R_STRING + (-4 -.FRAME_CNT)) AND 7;          !GET MASK INDEX
;    3825  2         RNDY0 = .PAT_LO AND (.RNDMS0 [.MSKNO]);                !MASK LO WORD
;    3826  2         RNDY1 = .PAT_HI AND (.RNDMS1 [.MSKNO]);                !MASK HI WORD
;    3827  2
;    3828  2
;    3829  2         FRAME_CNT = .FRAME_CNT + 1;                            !SHIFT FRAME LEFT ONE BIT
;    3830  2         IF .FRAME_CNT GTRU 9                                   !IF DONE TEN RANDOM 32-BIT NUMBERS
;    3831  2         THEN
;    3832  2            FRAME_CNT = 0;                                      !ZERO IT, SO WE'LL READ CLOCK NEXT TIME
;    3833  2
```

```
;   3834  1     END;


                                        .SBTTL  RANDY MULTI DRIVE TEST ROUTINES
000000  004137  000000G                RANDY:: JSR     R1,$SAVE4                       ;                       3782
000004  013702  000132'                        MOV     FRAME.CNT,R2                    ;                       3808
000010  001010                                BNE     1$
000012  013700  000000G                        MOV     CLK.TICKS,R0                    ;                       3811
000016  042700  177770                        BIC     #177770,R0
000022  006300                                ASL     R0
000024  016037  000136' 000134'              MOV     RNDYIN(R0),R.STRING             ;                       3810
000032  013701  000134'              1$:     MOV     R.STRING,R1                     ;                       3815
000036  010146                              MOV     R1,-(SP)
000040  010246                              MOV     R2,-(SP)
000042  005416                              NEG     (SP)
000044  004737  0000C0G                     JSR     PC,BL$SHF
000050  042700  177770                      BIC     #177770,R0
000054  006300                              ASL     R0
000056  016004  C00136'                      MOV     RNDYIN(R0),R4                   ; *,PAT.LO
000062  010116                              MOV     R1,(SP)                         ;                       3816
000064  012746  177777                      MOV     #-1,-(SP)
000070  160216                              SUB     R2,(SP)
000072  004737  000000G                     JSR     PC,BL$SHF
000076  042700  177770                      BIC     #177770,R0
000102  006300                              ASL     R0
000104  016003  000136'                      MOV     RNDYIN(R0),R3                   ; *,PAT.HI
000110  010116                              MOV     R1,(SP)                         ;                       3819
000112  012746  177774                      MOV     #-4,-(SP)
000116  160216                              SUB     R2,(SP)
000120  004737  000000G                     JSR     PC,BL$SHF
000124  010001                              MOV     R0,R1
000126  010102                              MOV     R1,R2                           ; *,SHIFT
000130  042702  177776                      BIC     #177776,R2                      ; *,SHIFT
000134  010416                              MOV     R4,(SP)                         ; PAT.LO,*              3820
000136  010246                              MOV     R2,-(SP)                        ; SHIFT,*
000140  004737  000000G                     JSR     PC,BL$SHF
000144  010004                              MOV     R0,R4                           ; *,PAT.LO
000146  010316                              MOV     R3,(SP)                         ; PAT.HI,*              3821
000150  010246                              MOV     R2,-(SP)                        ; SHIFT,*
000152  004737  000000G                     JSR     PC,BL$SHF
000156  060200                              ADD     R2,R0                           ; SHIFT,*
000160  010003                              MOV     R0,R3                           ; *,PAT.HI
000162  010102                              MOV     R1,R2                           ; *,MSKNO               3824
000164  042702  177770                      BIC     #177770,R2                      ; *,MSKNO
000170  010200                              MOV     R2,R0                           ; MSKNO,*               3825
000172  006300                              ASL     R0
000174  016037  000160' 000126'              MOV     RNDMS0(R0),RNDY0
000202  005104                              COM     R4
000204  040437  000126'                      BIC     R4,RNDY0
000210  010200                              MOV     R2,R0                           ; MSKNO,*               3826
000212  006300                              ASL     R0
000214  016037  000200' 000130'              MOV     RNDMS1(R0),RNDY1
000222  005103                              COM     R3
```

```
000224  040337  000130'                        BIC     R3,RNDY1
000230  005237  000132'                        INC     FRAME.CNT                       ;                       3829
000234  023727  000132' 000011                 CMP     FRAME.CNT,#11                   ;                       3830
000242  101402                                 BLOS    2$
000244  005037  000132'                        CLR     FRAME.CNT                       ;                       3832
000250  062706  000014                2$:     ADD     #14,SP                          ;                       3799
000254  000207                                 RTS     PC                              ;                       3782

; Routine Size:  87 words,      Routine Base:  $CODE$ + 11744
; Maximum stack depth per invocation:  12 words
```

```
;    3835  1      GLOBAL routine QIO_UNIT : novalue =
;    3836  1
;    3837  1      !+
;    3838  1      !       THIS ROUTINE IS CALLED BY QIO_GEN TO RANDOMLY SELECT ONE UNIT
;    3839  1      !       CONFIGURED UNDER THE CURRENT CONTROLLER (CCTLR) TO BE USED FOR THE
;    3840  1      !       CURRENT QIO OR QIO PAIR. THE UNIT SELECTED IS BASED ON THE NUMBER OF
;    3841  1      !       UNITS ELIGIBLE TO RECEIVE AN I/O REQUEST (FROM 1 TO 4) AND THE FIRST
;    3842  1      !       RANDOM NUMBER IN THE RANDOM NUMBER TABLE (RANDOM).
;    3843  1      !
;    3844  1      !       IMPLICIT INPUTS:
;    3845  1      !               CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
;    3846  1      !
;    3847  1      !       IMPLICIT OUTPUTS:
;    3848  1      !               THE RD/RX DISK NUMBER (DISK ADDRESS) IS LOADED INTO THE
;    3849  1      !                       APPROPRIATE FIELD OF BOTH MSCP PACKETS.
;    3850  1      !-
;    3851  1
;    3852  2          begin
;    3853  2
;    3854  2          local
;    3855  2              MOD_COUNT : byte,
;    3856  2              TBL_COUNT : byte,
;    3857  2              SELECT_RD : byte initial (byte (TRUE)),
;    3858  2      !ZZZ    RD_COUNT : word initial (0),
;    3859  2              RX_COUNT : word initial (0);
;    3860  2
;    3861  2      !
;    3862  2      ! THE UNITS WILL BE SELECTED ON AN ADJUSTABLE RATIO, RD51/52 TO RX50,
;    3863  2      ! SELECTED VIA THE SOFTWARE PARAMETERS
;    3864  2      !
;    3865  2      ! THIS MODE IS FOR SELECTING DEVICES ON THE FOLLOWING SCHEME:
;    3866  2      ! CHOOSE A DEVICE AND KEEP IT SELECTED FOR A CONSTANT TIME, THEN
;    3867  2      ! MOVE TO THE NEXT. THIS IS NON-RANDOM, FIXED SEQUENTIAL OPERATIONAL
;    3868  2      ! MODE
;    3869  2      !
;    3870  2
;    3871  2                  RD_COUNT = 0;                                                   !ZZZ
;    3872  2                  RX_COUNT = 0;                                                   !ZZZ
;    3873  2
;    3874  2                  incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do
;    3875  2
;    3876  2                      if (.CST_ADDR [.OFFSET + OF_DATA, D_PRES] eql PRESENT) and
;    3877  2                         (.CST_ADDR [.OFFSET + OF_DATA, D_STAT] eql ONLINE) and
;    3878  3                         (not .CST_ADDR [.OFFSET + OF_DATA, D_FATAL])
;    3879  2                      then
;    3880  2
;    3881  3                          if (.CST_ADDR [.OFFSET + OF_DATA, D_TYPE] eql FIXED)
;    3882  2                          then
;    3883  2                              RD_COUNT = .RD_COUNT + 1        ! NUMBER OF RD51/52s UNDER TEST
;    3884  2                          else
;    3885  2                              RX_COUNT = .RX_COUNT + 1;       ! NUMBER OF RX50s UNDER TEST
;    3886  2
;    3887  2
```

```
;    3888  2
;    3889  2          if (not BIT_TST (SWP_FLAGS, SWF_RDM)) and           ! NOT RANDOM MODE
;    3890  3             (not BIT_TST (SWP_FLAGS, SWF_SEQ))               ! NOT RANDOM SEQUENTIAL MODE
;    3891  2          then
;    3892  2
;    3893  2              if (.BST_CNT r_q 0) and
;    3894  2                 (.CST_ADDR [.BST_DEV + OF_DATA, D_PRES] eql PRESENT) and
;    3895  2                 (.CST_ADDR [.BST_DEV + OF_DATA, D_STAT] eql ONLINE) and
;    3896  3                 (not .CST_ADDR [.BST_DEV + OF_DATA, D_FATAL])
;    3897  2              then
;    3898  3                  begin                                       ! ALREADY WITHIN DEVICE
;    3899  3                  BST_CNT = .BST_CNT   1;
;    3900  3                  SET_UPAR (.BST_DEV);
;    3901  3                  MAD1 [DK_NUM] = .CDISK;
;    3902  3                  MAD2 [DK_NUM] = .CDISK;
;    3903  3                  return;
;    3904  3                  end
;    3905  2              else
;    3906  3                  begin                                       ! GET NEW DEVICE
;    3907  3
;    3908  3      !ZZZ        incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do
;    3909  3      !ZZZ
;    3910  3      !ZZZ            if (.CST_ADDR [.OFFSET + OF_DATA, D_PRES] eql PRESENT) and
;    3911  3      !ZZZ               (.CST_ADDR [.OFFSET + OF_DATA, D_STAT] eql ONLINE) and
;    3912  3      !ZZZ               (not .CST_ADDR [.OFFSET + OF_DATA, D_FATAL])
;    3913  3      !ZZZ            then
;    3914  3      !ZZZ
;    3915  3      !ZZZ                if (.CST_ADDR [.OFFSET + OF_DATA, D_TYPE] eql FIXED)
;    3916  3      !ZZZ                then
;    3917  3      !ZZZ                    RD_COUNT = .RD_COUNT + 1        ! NUMBER OF RD51/52s UNDER TEST
;    3918  3      !ZZZ                else
;    3919  3      !ZZZ                    RX COUNT = .RX_COUNT + 1;       ! NUMBER OF RX50s UNDER TEST
;    3920  3
;    3921  3                  incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF UN) by UNIT SIZE do
;    3922  4                      begin
;    3923  4
;    3924  4                      if (.BST_DEV eql 0) or
;    3925  5                         (.BST_DEV eql ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN))
;    3926  4                      then
;    3927  4                          BST_DEV = OF_UN
;    3928  4                      else
;    3929  4                          BST_DEV = .BST_DEV + UNIT_SIZE;
;    3930  4
;    3931  4                      if (.CST_ADDR [.BST_DEV + OF_DATA, D_PRES] eql PRESENT) and
;    3932  4                         (.CST_ADDR [.BST_DEV + OF_DATA, D_STAT] eql ONLINE) and
;    3933  5                         (not .CST_ADDR [.BST_DEV + OF_DATA, D_FATAL])
;    3934  4                      then
;    3935  5                          begin
;    3936  5
;    3937  5                          if .CST ADDR [.BST_DEV + OF_DATA, D_TYPE] eql REMOVABLE
;    3938  5                          then
;    3939  5                              BST_CNT = .RX_MAX_SEQ_CNT / .RX_COUNT
;    3940  5                          else
```

```
;    3941  5                          BST_CNT = .RD_MAX_SEQ_CNT / .RD_COUNT;
;    3942  5
;    3943  5                      if .BST_CNT eql 0
;    3944  5                      then
;    3945  5                          BST_CNT = 1;
;    3946  5
;    3947  5                      SET_UPAR (.BST_DEV);
;    3948  5                      MAD1 [DK_NUM] = .CDISK;
;    3949  5                      MAD2 [DK_NUM] = .CDISK;
;    3950  5                      return;
;    3951  4                      end;
;    3952  4
;    3953  3                  end;
;    3954  3
;    3955  2              end;
;    3956  2
;    3957  2      !
;    3958  2      ! RANDOM SELECTION OF DRIVES
;    3959  2      !
;    3960  2      !
;    3961  2      ! DETERMINE IF RD51/52s ARE TO BE SELECTED
;    3962  2      !
;    3963  2
;    3964  2          if ((.RANDOM [RDM_LEN - 1] and %o'077777') mod 100) gequ .SWP_RAT
;    3965  2          then
;    3966  2              SELECT_RD = FALSE;
;    3967  2
;    3968  2      !
;    3969  2      ! IF RD51/52s SELECTED
;    3970  2      !
;    3971  2      ! COUNT NUMBER OF RD51/52s AVAILABLE
;    3972  2      !
;    3973  2
;    3974  2          if .SELECT_RD
;    3975  2          then
;    3976  3              begin
;    3977  3              MOD_COUNT = 0;                                  ! COUNT THE NUMBER OF RDs UNDER TEST
;    3978  3
;    3979  3              incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do
;    3980  3
;    3981  3                  if (.CST_ADDR [.OFFSET + OF_DATA, D_PRES] eql PRESENT) and
;    3982  3                     (.CST_ADDR [.OFFSET + OF_DATA, D_STAT] eql ONLINE) and
;    3983  3                     (.CST_ADDR [.OFFSET + OF_DATA, D_TYPE] eql FIXED) and
;    3984  4                     (not .CST_ADDR [.OFFSET + OF_DATA, D_FATAL])
;    3985  3                  then
;    3986  4                      begin
;    3987  4                      STORAGE [.MOD_COUNT] = .OFFSET;
;    3988  4                      MOD_COUNT = .MOD_COUNT + 1;
;    3989  3                      end;
;    3990  3
;    3991  3      !
;    3992  3      ! SELECT ON OF THE RD51/52s
;    3993  3      !
```

```
;    3994  3
;    3995  3              if  MOD_COUNT neq 0                             ! IF AT LEAST ONE RD51/52 PRESENT
;    3996  3              then
;    3997  4                  begin
;    3998  4                  TBL_COUNT = 0;
;    3999  4
;    4000  4                  do
;    4001  5                      begin
;    4002  5                      SET_UPAR (.STORAGE [(.RANDOM [.TBL_COUNT] and %o'077777') mod .MOD_COUNT]);
;    4003  5                      TBL_COUNT = .TBL_COUNT + 1;
;    4004  5                      end
;    4005  5                  until ((.CST_ADDR [.CUOFF + OF_DATA, D_PRES] eql PRESENT) and
;    4006  5                         (.CST_ADDR [.CUOFF + OF_DATA, D_STAT] eql ONLINE) and
;    4007  4                         (not .CST_ADDR [.CUOFF + OF_DATA, D_FATAL])) or
;    4008  4                        (.TBL_COUNT eql RDM_LEN);
;    4009  4
;    4010  4                  MAD1 [DK_NUM] = .CDISK;
;    4011  4                  MAD2 [DK_NUM] = .CDISK;
;    4012  4                  return;
;    4013  3                  end;
;    4014  3
;    4015  2              end;
;    4016  2
;    4017  2          !
;    4018  2          ! IF NO RD51/52 SELECTED, SELECT AN RX50
;    4019  2          !
;    4020  2          ! COUNT THE NUMBER OF RX50s
;    4021  2          !
;    4022  2
;    4023  2              MOD_COUNT = 0;
;    4024  2
;    4025  2              incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do
;    4026  2
;    4027  2                  if ( CST_ADDR [.OFFSET + OF_DATA, D_PRES] eql PRESENT) and
;    4028  2                     (.CST_ADDR [.OFFSET + OF_DATA, D_STAT] eql ONLINE) and
;    4029  2                     (.CST_ADDR [.OFFSET + OF_DATA, D_TYPE] eql REMOVABLE) and
;    4030  3                     (not .CST_ADDR [.OFFSET + OF_DATA, D_FATAL])
;    4031  2                  then
;    4032  3                      begin
;    4033  3                      STORAGE [.MOD_COUNT] = .OFFSET;
;    4034  3                      MOD_COUNT = .MOD_COUNT + 1;
;    4035  2                      end;
;    4036  2
;    4037  2          !
;    4038  2          ! AND CHOOSE ONE!
;    4039  2          !
;    4040  2
;    4041  2              if .MOD_COUNT neq 0
;    4042  2              then
;    4043  3                  begin
;    4044  3                  TBL_COUNT = 0;
;    4045  3
;    4046  3                  do
```

```
;  4047  4                begin
;  4048  4                SET_UPAR (.STORAGE [(.RANDOM [.TBL_COUNT] and %o'077777') mod .MOD_COUNT]);
;  4049  4                TBL_COUNT = .TBL_COUNT + 1;
;  4050  4                end
;  4051  4            until ((.CST_ADDR [.CUOFF + OF_DATA, D_PRES] eql PRESENT) and
;  4052  4                   (.CST_ADDR [.CUOFF + OF_DATA, D_STAT] eql ONLINE) and
;  4053  3                   (not .CST_ADDR [.CUOFF + OF_DATA, D_FATAL])) or
;  4054  3                  (.TBL_COUNT eql RDM_LEN);
;  4055  3
;  4056  3            MAD1 [DK_NUM] = .CDISK;
;  4057  3            MAD2 [DK_NUM] = .CDISK;
;  4058  3            return;
;  4059  2            end;
;  4060  2
;  4061  2        !
;  4062  2        ! IF NO UNIT SELECTED SO FAR BY ABOVE METHOD, SELECT ANY ONE AT RANDOM
;  4063  2        !
;  4064  2        ! COUNT ALL UNITS AVAILABLE
;  4065  2        !
;  4066  2
;  4067  2            MOD_COUNT = 0;
;  4068  2
;  4069  2            incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do
;  4070  2
;  4071  2                if (.CST_ADDR [.OFFSET + OF_DATA, D_PRES] eql PRESENT) and
;  4072  2                   (.CST_ADDR [.OFFSET + OF_DATA, D_STAT] eql ONLINE) and
;  4073  3                   (not .CST_ADDR [.OFFSET + OF_DATA, D_FATAL])
;  4074  2                then
;  4075  3                    begin
;  4076  3                    STORAGE [.MOD_COUNT] = .OFFSET;
;  4077  3                    MOD_COUNT = .MOD_COUNT + 1;
;  4078  2                    end;
;  4079  2
;  4080  2        !
;  4081  2        ! SELECT ANY ONE ONE UNIT AT RANDOM
;  4082  2        !
;  4083  2            if .MOD_COUNT neq 0
;  4084  2            then
;  4085  3                begin
;  4086  3                TBL_COUNT = 0;
;  4087  3
;  4088  3                do
;  4089  4                    begin
;  4090  4                    SET_UPAR (.STORAGE [(.RANDOM [.TBL_COUNT] and %o'077777') mod .MOD_COUNT]);
;  4091  4                    TBL_COUNT = .TBL_COUNT + 1;
;  4092  4                    end
;  4093  4                until ((.CST_ADDR [.CUOFF + OF_DATA, D_PRES] eql PRESENT) and
;  4094  4                       (.CST_ADDR [.CUOFF + OF_DATA, D_STAT] eql ONLINE) and
;  4095  3                       (not .CST_ADDR [.CUOFF + OF_DATA, D_FATAL])) or
;  4096  3                      (.TBL_COUNT eql RDM_LEN);
;  4097  3
;  4098  3                MAD1 [DK_NUM] = .CDISK;
;  4099  3                MAD2 [DK_NUM] = .CDISK;
```

```
;    4100  3              return
;    4101  3              end
;    4102  3
;    4103  3          !
;    4104  3          ! DECLARE END-OF-PASS IF NO UNIT ONLINE
;    4105  3          !
;    4106  3
;    4107  2          else
;    4108  2              EOP_FLAG = TRUE;
;    4109  2
;    4110  1          end;                                        ! ROUTINE QIO_UNIT

                                        .SBTTL  QIO.UNIT MULTI-DRIVE TEST ROUTINES
000000  004137  000000G          QIO.UNIT::
                                        JSR     R1,$SAVE4                       ;                                       3835
000004  112704  000001                  MOVB    #1,R4                           ; *,SELECT.RD                           3852
000010  005003                          CLR     R3                              ; RX.COUNT
000012  005037  C00000G                 CLR     RD.COUNT                        ;                                       3871
000016  013702  000000G                 MOV     CST.ADDR,R2                     ;                                       3876
000022  012701  000006                  MOV     #6,R1                           ; *,OFFSET                              3874
000026  010100                  1$:     MOV     R1,R0                           ; OFFSET,*                              3876
000030  060200                          ADD     R2,R0
000032  032710  040000                  BIT     #40000,(R0)
000036  001415                          BEQ     3$
000040  032710  020000                  BIT     #20000,(R0)                     .                                       3877
000044  001412                          BEQ     3$
000046  032710  010000                  BIT     #10000,(R0)                     :                                       3878
000052  001007                          BNE     3$
000054  132710  000020                  BITB    #20,(R0)                        ;                                       3881
000060  001403                          BEQ     2$
000062  005237  000000G                 INC     RD.COUNT                        ;                                       3883
000066  000401                          BR      3$                              ;                                       3881
000070  005203                  2$:     INC     R3                              ; RX.COUNT                              3885
000072  062701  000024          3$:     ADD     #24,R1                          ; *,OFFSET                              3874
000076  020127  000102                  CMP     R1,#102                         ; OFFSET,*
000102  003751                          BLE     1$
000104  032737  000002  000000G         BIT     #2,SWP.FLAGS                    ;                                       3889
000112  001163                          BNE     13$
000114  032737  001000  000000G         BIT     #1000,SWP.FLAGS                 ;                                       3890
000122  001157                          BNE     13$
000124  005737  001242'                 TST     BST.CNT                         ;                                       3893
000130  001447                          BEQ     4$
000132  013700  001244                  MOV     BST.DEV,R0                      ;                                       3894
000136  006300                          ASL     R0
000140  060200                          ADD     R2,R0
000142  032710  040000                  BIT     #40000,(R0)
000146  001440                          BEQ     4$
000150  013700  001244                  MOV     BST.DEV,R0                      ;                                       3895
000154  006300                          ASL     R0
000156  060200                          ADD     R2,R0
000160  032710  020000                  BIT     #20000,(R0)
000164  001431                          BEQ     4$
```

```
000166  013700  001244'                        MOV     BST.DEV,R0              ;                               3896
000172  006300                                  ASL     R0
000174  060200                                  ADD     R2,R0
000176  032710  010000                          BIT     #10000,(R0)
000202  001022                                  BNE     4$
000204  005337  001242                          DEC     BST.CNT                 ;                               3899
000210  013746  001244'                        MOV     BST.DEV,-(SP)           ;                               3900
000214  004737  000000G                        JSR     PC,SET.UPAR
000220  013700  000114'                        MOV     MAD1,R0                 ;                               3901
000224  013760  000000G 000016                MOV     CDISK,16(R0)
000232  013700  000116'                        MOV     MAD2,R0                 ;                               3902
000236  013760  000000G 000016                MOV     CDISK,16(R0)
000244  005726                                  TST     (SP)+                   ;                               3903
000246  000207                                  RTS     PC                      ;                               3898
000250  012702  000003              4$:         MOV     #3,R2                   ; *,OFFSET                      3921
000254  013700  001244'              5$:         MOV     BST.DEV,R0              ;                               3924
000260  001403                                  BEQ     6$
000262  020027  000041                          CMP     R0,#41                  ;                               3925
000266  001004                                  BNE     7$
000270  012737  000003  001244'      6$:         MOV     #3,BST.DEV              ;                               3927
000276  000403                                  BR      8$                      ;                               3924
000300  062737  000012  001244'      7$:         ADD     #12,BST.DEV             ;                               3929
000306  013700  001244'              8$:         MOV     BST.DEV,R0              ;                               3931
000312  006300                                  ASL     R0
000314  063700  000000G                        ADD     CST.ADDR,R0
000320  032710  040000                          BIT     #40000,(R0)
000324  001451                                  BEQ     12$
000326  032710  020000                          BIT     #20000,(R0)             ;                               3932
000332  001446                                  BEQ     12$
000334  032710  010000                          BIT     #10000,(R0)             ;                               3933
000340  001043                                  BNE     12$
000342  132710  000020                          BITB    #20,(R0)                ;                               3937
000346  001004                                  BNE     9$
000350  013746  001270'                        MOV     RX.MAX.SEQ.CNT,-(SP)    ;                               3939
000354  010346                                  MOV     R3,-(SP)                ; RX.COUNT,*
000356  000404                                  BR      10$
000360  013746  001266              9$:         MOV     RD.MAX.SEQ.CNT,-(SP)    ;                               3941
000364  013746  000000G                        MOV     RD.COUNT,-(SP)
000370  004737  000000G              10$:        JSR     PC,BL$DIV
000374  010037  001242'                        MOV     R0,BST.CNT
000400  001003                                  BNE     11$                     ;                               3943
000402  012737  000001  001242                MOV     #1,BST.CNT              ;                               3945
000410  013716  001244'              11$:        MOV     BST.DEV,(SP)            ;                               3947
000414  004737  000000G                        JSR     PC,SET.UPAR
000420  013700  000114'                        MOV     MAD1,R0                 ;                               3948
000424  013760  000000G 000016                MOV     CDISK,16(R0)
000432  013700  000116'                        MOV     MAD2,R0                 ;                               3949
000436  013760  000000G 000016                MOV     CDISK,16(R0)
000444  022626                                  CMP     (SP)+,(SP)+             ;                               3950
000446  000207                                  RTS     PC                      ;                               3935
000450  062702  000012              12$:        ADD     #12,R2                  ; *,OFFSET                      3921
000454  020227  000041                          CMP     R2,#41                  ; OFFSET,*
000460  003675                                  BLE     5$
```

```
000462  013746  000036G          13$:    MOV     RANDOM+36, (SP)         ;                               3964
000466  042716  100000                    BIC     #100000,(SP)
000472  012746  000144                    MOV     #144, (SP)
000476  004737  000000G                   JSR     PC,BL$MOD
000502  022626                            CMP     (SP)+,(SP)+
000504  020037  000000G                   CMP     R0,SWP.RAT
000510  103401                            BLO     14$
000512  105004                            CLRB    R4                      ; SELECT.RD                     3966
000514  006004          14$:              ROR     R4                      ; SELECT.RD                     3974
000516  103105                            BCC     19$
000520  105003                            CLRB    R3                      ; MOD.COUNT                     3977
000522  012701  000003                    MOV     #3,R1                   ; *,OFFSET                      3979
000526  010100          15$:              MOV     R1,R0                   ; OFFSET,*                      3981
000530  006300                            ASL     R0
000532  063700  000000G                   ADD     CST.ADDR,R0
000536  032710  040000                    BIT     #40000,(R0)
000542  001417                            BEQ     16$
000544  032710  020000                    BIT     #20000,(R0)             ;                               3982
000550  001414                            BEQ     16$
000552  132710  000020                    BITB    #20,(R0)                ;                               3983
000556  001411                            BEQ     16$
000560  032710  010000                    BIT     #10000,(R0)             ;                               3984
000564  001006                            BNE     16$
000566  005000                            CLR     R0                      ;                               3987
000570  150300                            BISB    R3,R0                   ; MOD.COUNT,*
000572  006300                            ASL     R0
000574  010160  000064                    MOV     R1,STORAGE(R0)          ; OFFSET,*
000600  105203                            INCB    R3                      ; MOD.COUNT                     3988
000602  062701  000012          16$:      ADD     #12,R1                  ; *,OFFSET                      3979
000606  020127  000041                    CMP     R1,#41                  ; OFFSET,*
000612  003745                            BLE     15$
000614  105703                            TSTB    R3                      ; MOD.COUNT                     3995
000616  001445                            BEQ     19$
000620  105002                            CLRB    R2                      ; TBL.COUNT                     3998
000622  005000          17$:              CLR     R0                      ;                               4002
000624  150200                            BISB    R2,R0                   ; TBL.COUNT,*
000626  006300                            ASL     R0
000630  016046  000000G                   MOV     RANDOM(R0), (SP)
000634  042716  100000                    BIC     #100000,(SP)
000640  005046                            CLR     -(SP)
000642  110316                            MOVB    R3,(SP)                 ; MOD.COUNT,*
000644  004737  000000G                   JSR     PC,BL$MOD
000650  006300                            ASL     R0
000652  016016  000064'                   MOV     STORAGE(R0),(SP)
000656  004737  000000G                   JSR     PC,SET.UPAR
000662  105202                            INCB    R2                      ; TBL.COUNT                     4003
000664  022626                            CMP     (SP)+,(SP)+             ;                               4001
000666  013700  000000G                   MOV     CUOFF,R0                ;                               4005
000672  006300                            ASL     R0
000674  063700  000000G                   ADD     CST.ADDR,R0
000700  032710  040000                    BIT     #40000,(R0)
000704  001406                            BEQ     18$
000706  032710  020000                    BIT     #20000,(R0)             ;                               4006
```

```
000712  001403                          BEQ     18$
000714  032710  010000                  BIT     #10000,(R0)             ;                               4007
000720  001510                          BEQ     24$
000722  120227  000020          18$:    CMPB    R2,#20                  ; TBL.COUNT,*                   4008
000726  001335                          BNE     17$
000730  000504                          BR      24$                     ;                               4010
000732  105003                  19$:    CLRB    R3                      ; MOD.COUNT                     4023
000734  012701  000003                  MOV     #3,R1                   ; *,OFFSET                      4025
000740  010100                  20$:    MOV     R1,R0                   ; OFFSET,*                      4027
000742  006300                          ASL     R0
000744  063700  000000G                 ADD     CST ADDR,R0
000750  032710  040000                  BIT     #40000,(R0)
000754  001417                          BEQ     21$
000756  032710  020000                  BIT     #20000,(R0)             ;                               4028
000762  001414                          BEQ     21$
000764  132710  000020                  BITB    #20,(R0)                ;                               4029
000770  001011                          BNE     21$
000772  032710  010000                  BIT     #10000,(R0)             ;                               4030
000776  001006                          BNE     21$
001000  005000                          CLR     R0                      ;                               4033
001002  150300                          BISB    R3,R0                   ; MOD.COUNT,*
001004  006300                          ASL     R0
001006  010160  000064'                 MOV     R1,STORAGE(R0)          ; OFFSET,*
001012  105203                          INCB    R3                      ; MOD.COUNT                     4034
001014  062701  000012          21$:    ADD     #12,R1                  ; *,OFFSET                      4025
001020  020127  000041                  CMP     R1,#41                  ; OFFSET,*
001024  003745                          BLE     20$
001026  105703                          TSTB    R3                      ; MOD.COUNT                     4041
001030  001445                          BEQ     25$
001032  105002                          CLRB    R2                      ; TBL.COUNT                     4044
001034  005000                  22$:    CLR     R0                      ;                               4048
001036  150200                          BISB    R2,R0                   ; TBL.COUNT,*
001040  006300                          ASL     R0
001042  016046  000000G                 MOV     RANDOM(R0), (SP)
001046  042716  100000                  BIC     #100000,(SP)
001052  005046                          CLR     -(SP)
001054  110316                          MOVB    R3,(SP)                 ; MOD.COUNT,*
001056  004737  000000G                 JSR     PC,BL$MOD
001062  006300                          ASL     R0
001064  016016  000064'                 MOV     STORAGE(R0),(SP)
001070  004737  000000G                 JSR     PC,SET.UPAR
001074  105202                          INCB    R2                      ; TBL.COUNT                     4049
001076  022626                          CMP     (SP)+,(SP)+             ;                               4047
001100  013700  000000G                 MOV     CUOFF,R0                ;                               4051
001104  006300                          ASL     R0
001106  063700  000000G                 ADD     CST.ADDR,R0
001112  032710  040000                  BIT     #40000,(R0)
001116  001406                          BEQ     23$
001120  032710  020000                  BIT     #20000,(R0)             ;                               4052
001124  001403                          BEQ     23$
001126  032710  010000                  BIT     #10000,(R0)             ;                               4053
001132  001505                          BEQ     30$
001134  120227  000020          23$:    CMPB    R2,#20                  ; TBL.COUNT,*                   4054
```

```
001140  001335                          BNE     22$
001142  000501                  24$:    BR      30$                     ;                               4056
001144  105003                  25$:    CLRB    R3                      ; MOD.COUNT                     4067
001146  012701  000003                  MOV     #3,R1                   ; *,OFFSET                      4069
001152  010100                  26$:    MOV     R1,R0                   ; OFFSET,*                      4071
001154  006300                          ASL     R0
001156  063700  000000G                 ADD     CST.ADDR,R0
001162  032710  040000                  BIT     #40000,(R0)
001166  001414                          BEQ     27$
001170  032710  020000                  BIT     #20000,(R0)             ;                               4072
001174  001411                          BEQ     27$
001176  032710  010000                  BIT     #10000,(R0)             ;                               4073
001202  001006                          BNE     27$
001204  005000                          CLR     R0                      ;                               4076
001206  150300                          BISB    R3,R0                   ; MOD.COUNT,*
001210  006300                          ASL     R0
001212  010160  000064'                 MOV     R1,STORAGE(R0)          ; OFFSET,*
001216  105203                          INCB    R3                      ; MOD.COUNT                     4077
001220  062701  C00012          27$:    ADD     #12,R1                  ; *,OFFSET                      4069
001224  020127  000041                  CMP     R1,#41                  ; OFFSET,*
001230  003750                          BLE     26$
001232  105703                          TSTB    R3                      ; MOD.COUNT                     4083
001234  001457                          BEQ     31$
001236  105002                          CLRB    R2                      ; TBL.COUNT                     4086
001240  005000                  28$:    CLR     R0                      ;                               4090
001242  150200                          BISB    R2,R0                   ; TBL.COUNT *
001244  006300                          ASL     R0
001246  016046  000000G                 MOV     RANDOM(R0),-(SP)
001252  042716  100000                  BIC     #100000,(SP)
001256  005046                          CLR     -(SP)
001260  110316                          MOVB    R3,(SP)                 ; MOD.COUNT,*
001262  004737  000000G                 JSR     PC,BL$MOD
001266  006300                          ASL     R0
001270  016016  000064'                 MOV     STORAGE(R0),(SP)
001274  004737  000000G                 JSR     PC,SET.UPAR
001300  105202                          INCB    R2                      ; TBL.COUNT                     4091
001302  022626                          CMP     (SP)+,(SP)+             ;                               4089
001304  013700  000000G                 MOV     CUOFF,R0                ;                               4093
001310  006300                          ASL     R0
001312  063700  000000G                 ADD     CST.ADDR,R0
001316  032710  040000                  BIT     #40000,(R0)
001322  001406                          BEQ     29$
001324  032710  020000                  BIT     #20000,(R0)             ;                               4094
001330  001403                          BEQ     29$
001332  032710  010000                  BIT     #10000,(R0)             ;                               4095
001336  001403                          BEQ     30$
001340  120227  000020          29$:    CMPB    R2,#20                  ; TBL.COUNT,*                   4096
001344  001335                          BNE     28$
001346  013700  000114'          30$:    MOV     MAD1,R0                 ;                               4098
001352  013760  000000G 000016          MOV     CDISK,16(R0)
001360  013700  000116'                 MOV     MAD2,R0                 ;                               4099
001364  013760  000000G 000016          MOV     CDISK,16(R0)
001372  000207                          RTS     PC                      ;                               4085
```

```
001374  112737  000001  000000G         31$:    MOVB    #1,EOP.FLAG                     ;                                       4108
001402  000207                                  RTS     PC                              ;                                       3835

; Routine Size:  386 words,     Routine Base:  $CODE$ + 12222
; Maximum stack depth per invocation:  8 words
```

```
;    4111  1     GLOBAL routine QIO_FUNC : novalue =
;    4112  1
;    4113  1     !+
;    4114  1     !       THIS ROUTINE IS CALLED BY QIO_GEN TO SELECT THE I/O FUNCTION (OPCODE)
;    4115  1     !       TO BE USED FOR THE CURRENT QIO OR QIO PAIR. THE FUNCTION IS DETERMINED
;    4116  1     !       BY THE FOLLWING ALGORITHM:
;    4117  1     !
;    4118  1     !               IF THE CHOSEN UNIT IS PROTECTED
;    4119  1     !               THEN
;    4120  1     !                       FUNCTION = READ
;    4121  1     !               ELSE (UNPROTECTED)
;    4122  1     !                       FUNCTION (WRITE OR READ) IS BASED ON A RANDOM
;    4123  1     !                       NUMBER
;    4124  1     !
;    4125  1     !       IN ADDITION, IF THE OPERATOR SELECTED THE OPTION OF PERFORMING WRITE-
;    4126  1     !       COMPARES AT THE HOST, AND IF A "WRITE" FUNCTION WAS CHOSEN ABOVE FOR
;    4127  1     !       THE FIRST QIO, THEN A "READ" OPCODE IS LOADED INTO THE SECOND MSCP
;    4128  1     !       PACKET. OTHERWISE, THE SECOND MSCP PACKET IS RETURNED TO THE POOL.
;    4129  1     !
;    4130  1     !
;    4131  1     !MMM!       PERIODIACLLY, THIS ROUTINE WILL CALL THE DUP ROUTINE BEFORE IT       ZZZ
;    4132  1     !MMM!   BEGINS ITS OWN TASK. IF THE OPERATOR HAS SELECTED, "ALSO RUN     ZZZ
;    4133  1     !MMM!   DUP EXERCISER," THEN DUP TESTING OF DBNS WILL BE INTERLEAVED     ZZZ
;    4134  1     !MMM!   WITH THE REGULAR MSCP TESTING OF THE LBNS.                        ZZZ
;    4135  1     !MMM!
;    4136  1     !MMM!   TO AVOID LONG, CUMULATIVE INIT TIMES, THE DUP CODE IS ONLY       ZZZ
;    4137  1     !MMM!   EXECUTED AFTER (25 TIMES 'DUPROUND') MSCP I/O's HAVE BEEN DONE.  ZZZ
;    4138  1     !MMM!   THE DUMBER OF DUP I/O's IS 'DUPROUND'. THIS GIVES US A 25 TO 1   ZZZ
;    4139  1     !MMM!   INTERLEAVE.                                                      ZZZ
;    4140  1     !MMM!
;    4141  1     !MMM!   THE DUP TESTING IS DONE BY EXECUTING CONTROLLER LOCAL PROGRAMS   ZZZ
;    4142  1     !MMM!   TO READ OR WRITE/READ DBNS. AFTER THE DUP TESTING, THE CON-     ZZZ
;    4143  1     !MMM!   TROLLER IS REINITIALIZED, AND QIO_FUNC ROUTINE CONTINUES FROM    ZZZ
;    4144  1     !MMM!   WHERE IT LEFT OFF.                                               ZZZ
;    4145  1     !MMM!
;    4146  1     !
;    4147  1     !       IMPLICIT INPUTS:
;    4148  1     !               CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
;    4149  1     !               CUOFF - CURRENT UNIT CST OFFSET
;    4150  1     !
;    4151  1     !       IMPLICIT OUTPUTS:
;    4152  1     !               THE OPCODE FIELD OF ONE OR BOTH MSCP PACKETS IS LOADED.
;    4153  1     !-
;    4154  1
;    4155  2         begin
;    4156  2
;    4157  2         local
;    4158  2             FUNC : word,                                        ! OPCODE (READ OR WRITE)
;    4159  2             INDEX : word;                                       ! UNIT NO.              ZZZ
;    4160  2
;    4161  2     !MMM DUOFF = .CUOFF;                                    !SAVE IN CASE OTHER CMDS ZZZ
;    4162  2     !MMM                                                !LEFT IN QUEUE           ZZZ
;    4163  2     !MMM IF ((.CST_ADDR [.DUOFF + OF COUNT, D_COUNT) LEQ 0) AND !MSCP CNT=0       ZZZ
```

```
;    4164  2      !MMM    (.CST_ADDR [.DUOFF, D_TYPE] NEQ RX_50) AND          !FIXED DISK        ZZZ
;    4165  2      !MMM    (.CST_ADDR [.DUOFF + OF DUPFLAGS, NODUPMEDIA] NEQ 1)) !MEDIA IN       ZZZ
;    4166  2      !MMM                                                                          !ZZZ
;    4167  2      !MMM THEN                                                                      !ZZZ
;    4168  2      !MMM     BEGIN                                                                 !ZZZ
;    4169  2      !MMM     PUT_PKT (.MX2);                              !RETURN 2ND ENVLOPE      !ZZZ
;    4170  2      !MMM     MX2 = -1;                                    !INDICATE FAILURE         ZZZ
;    4171  2      !MMM     DUP ();                                      !DO DUP TEST              ZZZ
;    4172  2      !MMM     CST_ADDR [.DUOFF + OF_COUNT, D_COUNT] =     !REINIT MSCP FUN-         ZZZ
;    4173  2      !MMM             (25 * .DUPROUND);                    !CTION COUNTER            ZZZ
;    4174  2      !MMM                                                                          !ZZZ
;    4175  2      !MMM !  THE FOLLOWING REINITS 2 ENVELOPES, SO THAT THE MSCP EXERCISER         ZZZ
;    4176  2      !MMM !  CAN PROCEED AS BEFORE THE DUP EXERCISER WAS CALLED.                   ZZZ
;    4177  2      !MMM !                                                                        ZZZ
;    4178  2      !MMM    DUP_FLAGS = .DUP_FLAGS OR SWP_DINT;          !SET DUP INIT FLAG        ZZZ
;    4179  2      !MMM    INIT_TEST ();                       !REINIT CONTROLLER                ZZZ
;    4180  2      !MMM    DUP_FLAGS = .DUP_FLAGS AND (NOT SWP_DINT);   !CLR DUP INIT DLAG        ZZZ
;    4181  2      !MMM                                                                          !ZZZ
;    4182  2      !MMM    MX2 = -1;                                    !ASSUME NO 2ND ENVELOPE   ZZZ
;    4183  2      !MMM    IF (MX1 = GET_PKT (.CCTLR)) LSS 0            !TRY FOR 1ST ENVELOPE     ZZZ
;    4184  2      !MMM            OR (.EOP_FLAG)                       !IF FAILURE               ZZZ
;    4185  2      !MMM    THEN    RETURN;                              !NO POINT TO GO ON        ZZZ
;    4186  2      !MMM    IF (MX2 = GET_PKT (.CCTLR)) LSS 0            !TRY FOR 2ND ENVELOPE     ZZZ
;    4187  2      !MMM            OR (.EOP_FLAG)                       !IF FAILURE               ZZZ
;    4188  2      !MMM    THEN    BEGIN                                                         !ZZZ
;    4189  2      !MMM         PUT_PKT (.MX1);                         !PUT 1ST BACK IN POOL     ZZZ
;    4190  2      !MMM             MX1 = -1;                           !INDICATE FAILURE         ZZZ
;    4191  2      !MMM             RETURN;                             !DONE                     ZZZ
;    4192  2      !MMM             END;                                                         !ZZZ
;    4193  2      !MMM                                                                          !ZZZ
;    4194  2      !MMM             MAD1 = MSCP_PKT + (.MX1 * PKT_LEN * 2); !CALC START ADDR   ZZZ
;    4195  2      !MMM             MAD2 = MSCP_PKT + (.MX2 * PKT_LEN * 2); !OF BOTH ENVELOPES ZZZ
;    4196  2      !MMM             GET_RANDOM ();                      !GET SET OF RANDOM NOS    ZZZ
;    4197  2      !MMM             QIO_UNIT ();                        !PUT RAND UNIT NO IN      ZZZ
;    4198  2      !MMM             END;                                !ENVELOPES                ZZZ
;    4199  2      !MMM                                                                          !ZZZ
;    4200  2
;    4201  2      !MMM!   MSCP CODE STARTS HERE                                                 ZZZ
;    4202  2      !MMM!                                                                         ZZZ
;    4203  2
;    4204  2      INDEX = .CST_ADDR [.CUOFF + OF_DATA, D_DISK_NUM];                             !POINT TO TYPER + TYPEW FOR THIS UNIT   ZZZ
;    4205  2
;    4206  2      CST_ADDR [.CUOFF + OF_COUNT, D_COUNT] =          !                            ZZZ
;    4207  2          .CST_ADDR [.CUOFF + OF_COUNT,
;    4208  2      D_COUNT] -1;    !DECR MSCP FUNCTION CNTR ZZZ
;    4209  2
;    4210  2          MAD2 [OPCODE] = 0;                                                        ! ASSUME 2ND PACKET NOT NEEDED
;    4211  2
;    4212  2          if (.CST_ADDR [.CUOFF + OF_DATA, D_PROT] eql UNPROTECTED) and             ! IF "FORCED ERROR" SET IN LAST READ.
;    4213  2             (.CST_ADDR [.CUOFF + OF_DATA, D_TYPE] eql FIXED) and                   !       REWRITE SAME BLOCK
;    4214  3             (.FORCED_ERROR)                                                       !
;    4215  2          then
;    4216  2              FUNC = OP_WRT
```

```
;  4217  2          else
;  4218  2
;  4219  2              if .CST_ADDR [.CUOFF + OF DATA, D_PROT] eql PROTECTED          ! IF UNIT IS PROTECTED
;  4220  2              then
;  4221  2                  FUNC = OP_RD                                           ! SET FUNCTION TO READ
;  4222  2              else
;  4223  2
;  4224  2      !MMM        if (.RANDOM [1] and 1)                                 ! USE 2ND RANDOM NUMBER TO SELECT
;  4225  2      !MMM        then
;  4226  2      !MMM            FUNC = OP_RD                                       !     READ
;  4227  2      !MMM        else
;  4228  2      !MMM            FUNC = OP_WRT;                                     !     WRITE
;  4229  2
;  4230  2                  IF NOT .BAL_IN_PROGRESS [.INDEX]                       ! MMM
;  4231  2                  THEN                                                   ! MMM
;  4232  3                     IF (.RANDOM [1] AND 1)                              ! MMM
;  4233  2                     THEN                                                ! MMM
;  4234  2                        FUNC = OP_RD                                     ! MMM
;  4235  2                     ELSE                                                ! MMM
;  4236  2                        FUNC = OP_WRT                                    ! MMM
;  4237  2                   ELSE                                                 ! MMM
;  4238  2                     IF .FORCE_WR [.INDEX]                              ! MMM
;  4239  2                     THEN                                               ! MMM
;  4240  2                        FUNC = OP_WRT                                   ! MMM
;  4241  2                     ELSE                                               ! MMM
;  4242  2                        FUNC = OP_RD;                                   ! MMM
;  4243  2
;  4244  2
;  4245  2          if (MAD1 [OPCODE] = .FUNC) eql OP_WRT                          ! LOAD CHOSEN OPCODE. IF WRITE
;  4246  2          then
;  4247  3              begin
;  4248  3              MAD1 [CMD_TYPE] = NON_SEQ_CMD;                             ! NON-SEQUENTIAL COMMAND
;  4249  3
;  4250  4              if BIT_TST (SWP_FLAGS, SWF_CWC)                            ! IF CONTROLLER DOES WRITE COMPARES
;  4251  3              then
;  4252  3                  MAD1 [MODIFY] = MD_CMP                                 ! ADD COMPARE MODIFIER
;  4253  3              else
;  4254  3
;  4255  4                  if BIT_TST (SWP_FLAGS, SWF_HWC)                        ! IF HOST DOES WRITE COMPARES
;  4256  3                  then
;  4257  4                      begin
;  4258  4                      MAD1 [MODIFY] = MD_EXP;                            ! SET WRITE AS AN EXPRESS REQUEST
;  4259  4                      MAD2 [OPCODE] = OP_RD;                             ! SET READ OPCODE INTO 2ND MSCP PACKET
;  4260  4                      MAD2 [MODIFY] = MD_EXP;                            ! SET READ AS AN EXPRESS REQUEST TOO
;  4261  4                      MAD2 [CMD TYPE] = NON_SEQ_CMD;                     ! NON-SEQUENTIAL COMMAND
;  4262  3                      end;
;  4263  3              end
;  4264  2          else
;  4265  3              begin
;  4266  3              MAD1 [CMD_TYPE] = NON_SEQ_CMD;                             ! NON-SEQUENTIAL COMMAND
;  4267  3
;  4268  4              if BIT_TST (SWP_FLAGS, SWF_CRC)                            ! IF READ COMPARES   FUNCTION IS READ
;  4269  3              then
```

```
;    4270  3                MAD1 [MODIFY] = MD_CMP;                          ! ADD COMPARE MODIFIER
;    4271  3
;    4272  2            end;
;    4273  2
;    4274  2        ;if .MAD2 [OPCODE] eql 0                                 ! IF NO OPCODE IN 2ND PACKET
;    4275  2        then
;    4276  3            begin
;    4277  3            PUT_PKT (.MX2);                                      ! RETURN 2ND PACKET TO POOL
;    4278  3            MX2 = -1;                                            ! MARK IT UNUSED
;    4279  2            end;
;    4280  2
;    4281  1        end;                                                     ! ROUTINE QIO FUNC


                                        .SBTTL  QIO.FUNC MULTI-DRIVE TEST ROUTINES
000000  004137  000000G          QIO.FUNC::
                                        JSR     R1,$SAVE4                       ;                               4111
000004  013702  000000G                 MOV     CUOFF,R2                        ;                               4204
000010  006302                          ASL     R2
000012  063702  000000G                 ADD     CST.ADDR,R2
000016  111200                          MOVB    (R2),R0                         ; *,INDEX
000020  042700  177760                  BIC     #177760,R0                      ; *,INDEX
000024  013701  000000G                 MOV     CUOFF,R1                        ;                               4206
000030  006301                          ASL     R1
000032  063701  000000G                 ADD     CST.ADDR,R1
000036  005361  000022                  DEC     22(R1)                          ;                               4208
000042  013701  000116'                 MOV     MAD2,R1                         ;                               4210
000046  012704  000022                  MOV     #22,R4
000052  060104                          ADD     R1,R4
000054  105014                          CLRB    (R4)
000056  005712                          TST     (R2)                            ;                               4212
000060  100007                          BPL     1$
000062  132712  000020                  BITB    #20,(R2)                        ;                               4213
000066  001404                          BEQ     1$
000070  132737  000001  000000G         BITB    #1,FORCED.ERROR                 ;                               4214
000076  001021                          BNE     3$                              ;                               4216
000100  032712  100000          1$:     BIT     #100000,(R2)                    ;                               4219
000104  001421                          BEQ     4$                              ;                               4221
000106  006300                          ASL     R0                              ;                               4230
000110  032760  000001  000000G         BIT     #1,BAL.IN.PROGRESS(R0)
000116  001005                          BNE     2$
000120  032737  000001  000002G         BIT     #1,RANDOM+2                     ;                               4232
000126  001405                          BEQ     3$
000130  000407                          BR      4$                              ;                               4234
000132  032760  000001  000000G 2$:     BIT     #1,FORCE.WR(R0)                 ;                               4238
000140  001403                          BEQ     4$
000142  012702  000042          3$:     MOV     #42,R2                          ; *,FUNC                        4240
000146  000402                          BR      5$                              ;                               4238
000150  012702  000041          4$:     MOV     #41,R2                          ; *,FUNC                        4242
000154  013700  000114'         5$:     MOV     MAD1,R0                         ;                               4245
000160  013703  000000G                 MOV     SWP.FLAGS,R3                    ;                               4250
000164  110260  000022                  MOVB    R2,22(R0)                       ; FUNC,*                        4245
000170  020227  000042                  CMP     R2,#42                          ; FUNC,*
```

```
000174  001025                                  BNE     6$
000176  112760  000002  000004                  MOVB    #2,4(R0)        ;                       4248
000204  032703  000020                          BIT     #20,R3          ;                       4250
000210  001025                                  BNE     7$              ;                       4252
000212  032703  000040                          BIT     #40,R3          ;                       4255
000216  001425                                  BEQ     8$
000220  012760  100000  000024                  MOV     #-100000,24(R0) ;                       4258
000226  112714  000041                          MOVB    #'!,(R4)        ;                       4259
000232  012761  100000  000024                  MOV     #-100000,24(R1) ;                       4260
000240  112761  000002  000004                  MOVB    #2,4(R1)        ;                       4261
000246  000411                                  BR      8$              ;                       4245
000250  112760  000002  000004          6$:     MOVB    #2,4(R0)        ;                       4266
000256  032703  000004                          BIT     #4,R3           ;                       4268
000262  001403                                  BEQ     8$
000264  012760  040000  000024          7$:     MOV     #40000,24(R0)   ;                       4270
000272  105714                          8$:     TSTB    (R4)            ;                       4274
000274  001010                                  BNE     9$
000276  013746  000112'                          MOV     MX2,-(SP)       ;                       4277
000302  004737  C00000G                          JSR     PC,PUT.PKT
000306  012737  177777  000112'                  MOV     #-1,MX2         ;                       4278
000314  005726                                  TST     (SP)+           ;                       4276
000316  000207                          9$:     RTS     PC              ;                       4111

; Routine Size:  104 words,    Routine Base:  $CODE$ + 13626
; Maximum stack depth per invocation:  7 words
```

```
;    4282  1
;    4283  1      !MMMGLOBAL ROUTINE DUP : NOVALUE =                                                    !ZZZ
;    4284  1      !MMM!*                                                                              !ZZZ
;    4285  1      !MMM!   THIS ROUTINE IS CALLED BY QIO_FUNC AFTER 25 * 'DUPROUND' RD/WTS.            ZZZ
;    4286  1      !MMM!   THIS EXERCISER WAS PLACED IN THE MIDDLE OF THE MSCP EXERCISER,             ZZZ
;    4287  1      !MMM!   SO COMMON INIT AND OTHER ROUTINES COULD BE USED.                           ZZZ
;    4288  1      !MMM!                                                                             ZZZ
;    4289  1      !MMM!   THE DUP EXERCISER WILL PERFORM EITHER READ-ONLY, OR WRITE-READ-          ZZZ
;    4290  1      !MMM!   COMPARE OPERATIONS ON THE DIAGNOSTIC BLOCKS (DBNS). IT WILL             ZZZ
;    4291  1      !MMM!   RECORD THE STATISTICS IN THE TALLY TABLES.                                ZZZ
;    4292  1      !MMM!                                                                             ZZZ
;    4293  1      !MMM!   THE PROGRAM USES CONTROLLER LOCAL PROGRAMS TO WRITE AND READ            ZZZ
;    4294  1      !MMM!   DBNS. WHEN WRITING TO THE DBNS, A ONE WORD PATTERN WILL BE             ZZZ
;    4295  1      !MMM!   SELECTED, AND REPLICATED THROUGH A 256 WORD BLOCK FOR DATA.             ZZZ
;    4296  1      !MMM!   THE ROUTINE WILL WRITE 'DUPROUND' NUMBER OF SEQUENTIAL DBN               ZZZ
;    4297  1      !MMM!   BLOCKS. IF THE CONTROLLER LOCAL PROGRAMS EXIST, AND THE OPERATOR        ZZZ
;    4298  1      !MMM!   SELECTS 'WRITE TO DIAGNOSTIC AREA', WRITE-READ-COMPARES WILL BE        ZZZ
;    4299  1      !MMM!   PERFORMED ON THE DBNS. OTHERWISE, READS WITH NO COMPARES WILL BE       ZZZ
;    4300  1      !MMM!   DONE. BAD BLOCKS FOUND IN THE COMPARISON TESTS WILL NOT BE LIST-       ZZZ
;    4301  1      !MMM!   ED IN THE RCT TABLES.                                                   ZZZ
;    4302  1      !MMM!                                                                             ZZZ
;    4303  1      !MMM!   AFTER 'DUPROUND' NUMBER OF DBNS HAVE BEEN TESTED, THE ENVELOPES        ZZZ
;    4304  1      !MMM!   WILL BE REINITIATED, SO THAT THE MSCP EXERCISER CAN CONTINUE            ZZZ
;    4305  1      !MMM!   AS BEFORE.                                                              ZZZ
;    4306  1      !MMM!                                                                             ZZZ
;    4307  1      !MMM!   IMPLICIT INPUTS:                                                        ZZZ
;    4308  1      !MMM!                   CCTLR - CURRENT CONTROLLER NUMBER                         ZZZ
;    4309  1      !MMM!                   CST_ADDRS   CONTAINS THE CURRENT CONTROLLER               ZZZ
;    4310  1      !MMM!                               STATUS TABLE                                  ZZZ
;    4311  1      !MMM!                   CUOFF - CURRENT OFFSET IN CST TABLE FOR                   ZZZ
;    4312  1      !MMM!                           PARTICULAR DRIVE                                  ZZZ
;    4313  1      !MMM!                                                                             ZZZ
;    4314  1      !MMM!   IMPLICIT OUTPUTS:                                                         ZZZ
;    4315  1      !MMM!                   S_PATTERN - PATTERN BEING WRITTEN TO DBNS                  ZZZ
;    4316  1      !MMM!                                                                             ZZZ
;    4317  1      !MMM!                                                                            !ZZZ
;    4318  1      !MMM!                                                                            !ZZZ
;    4319  1
```

```
;    4320  1      !MMM
.    4321  1
;    4322  1
;    4323  1      !MMM BEGIN
;    4324  1      !MMM OWN
;    4325  1      !MMM    TEMP : WORD;
;    4326  1
;    4327  1      !PRINTX (DBM110);
;    4328  1      !PRINTX (DER10);
;    4329  1
;    4330  1      !until (.CRN_LOW eqlu .RP_ADDR [CRF_LO]) or      ! TO ENSURE THAT ALL RETURN MESSAGES HAVE BEEN PROCESSED
;    4331  1      !      (.EOP_FLAG eql true) do                   ! Make sure all MSCP commands are completed
;    4332  1      !     begin
;    4333  1      !     BREAK;                                     ! BREAK FOR ACT
;    4334  1      !     PROC_RETPKT();                             ! PROCESS RETURN PACKET TO SEE IF OK FOR DUP
.    4335  1      !     RP_INDX = .RP_INDX + 1;                    ! INCREMENT RP_INDX
;    4336  1      !     if .RP_INDX geq RP_CNT then (RP_INDX = 0;); ! MAKE SURE THE COUNTER DOES NOT GET TO BIG
;    4337  1      !     RP_ADDR = RETPKT + (.RP_INDX * RP_LEN * 2);        ! CALCULATE RETPKT ADDRESS
;    4338  1      !     end;
.    4339  1
;    4340  1
;    4341  1      !S_PATTERN = .RANDOM [1];                                 !OTHER UNIT VARIABLES
;    4342  1
;    4343  1      !IF (.CST_ADDR [.DUOFF + OF_DBN, D_DBN] + .duproun) GEQ 144    ! TEST TO SEE IF NEXT DBN'S TO LARGE
;    4344  1      !THEN (CST_ADDR [.DUOFF + OF_DBN, D_DBN] = 0);           ! CIRCLE ARROUND IF DBN TO LARGE
;    4345  1
;    4346  1      !DUPIDLE ();                                             ! DO A GET DUST STATUS TO FIND IF LOCAL DUP MEDIA
;    4347  1      !IF .CST_ADDR [.DUOFF + OF_DBN, NODUPMEDIA] EQL 1 THEN RETURN; ! IF DUP LOCAL MEDIA NOT THERE THEN RETURN
;    4348  1
;    4349  1      !TEMP = .CST_ADDR [.DUOFF + OF_DBN, D_DBN];
;    4350  1      !INCR DBNCNT FROM (.TEMP + 1) TO (.TEMP + .duproun) DO                    ! INCREMENT FROM RELATIVF DBN TO DBN
  + duproun
;    4351  1      !       BEGIN
;    4352  1      !       IF .CST_ADDR [.DUOFF + OF DBN, DUPWRITE]                          ! IF WRITE FLAG SET IN CST TABLE THE
N WRITE DBN'S
;    4353  1      !       THEN
;    4354  1      !               BEGIN
;    4355  1      !               DUPIDLE ();                                       ! MAKE SURE THE CONTROLLER IS IN AN IDLE STA
TE
;    4356  1      !               DUPWRTDBN ();                                     ! CALL ROUTINE TO HANDLE WRITTING ROUTINES
;    4357  1      !               END;
;    4358  1
;    4359  1      !       DUPIDLE ();                                               ! MAKE SURE CONTROLLER IN IDLE STATE
;    4360  1      !       DUPREDDBN ();                                             ! CALL ROUTINE TO HANDLE READING DBN'S
;    4361  1
;    4362  1      !       CST_ADDR [.DUOFF + OF_DBN, D_DBN] = .CST_ADDR [.DUOFF + OF_DBN, D_DBN] + 1; ! INCREMENT RELATIVE DBN COUNTER
;    4363  1      !        IF .CST_ADDR [.DUOFF + OF_DBN, D_DBN]  GTRU  MAX_DBN                    !BUT NOT MORE THAN MAX NUMBER
     ZZZ
;    4364  1      !        THEN                                                                   !IF BIGGER THAN MAX
     ZZZ
;    4365  1      !          CST_ADDR [.DUOFF + OF_DBN, D_DBN]  =  0                              !MAKE IT ZERO
     ZZZ
;    4366  1
;    4367  1
;    4368  1
;    4369  1      !       IF .CST_ADDR [.DUOFF + OF_DBN, DUPERROR] EQL 1                    ! ERROR IN DUP REINITIALIZE
;    4370  1      !       THEN RETURN;                                                      ! AND RETURN
;    4371  1      !       END;
;    4372  1      !END;
```

. 4373 1

```
;  1   !MMMGLOBAL ROUTINE DUPWRTDBN : NOVALUE =
;  1   !MMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMMM
;  1   !+
;  1   ! THIS ROUTINE IS CALLED BY DUP ROUTINE TO USE THE CONTROLLER LOCAL PROGRAM
;  1   ! "WRTDBN".  TO USE THE PROGRAM THE OPTIONAL DUP SUB-PROTOCAL IS USED TO
;  1   ! COMMUNICATE WITH THE CONTROLLER.  THE PROGRAM WRITES TO A DIAGONOSTIC BLOCK (DBN)
;  1   ! THE WORD IN "S_PATTERN" IS WRITTEN TO THE 256 WORDS IN THE DBN.  IF AN ERROR OCCURS
;  1   ! WHILE RUNNING THE CONTROLLER LOCAL PROGRAM THE ERROR IS USSUALLY REPORTED IN THE
;  1   ! DUP BUFFER. (EX. ILLEGAL UNIT NUMBER, ILLEGAL BLK #, DEVICE ERROR, ZERO LENGHT MSG)
;  1   !
;  1   !        IMPLICIT INPUTS:
;  1   !                CST_ADDRS     CONTAINS THE CURRENT CONTROLLER STATUS TABLE
;  1   !                DUOFF       - CURRENT OFFSET IN CST TABLE FOR PARTICULAR DRIVE
;  1   !                S_PATTERN     CONTAINS PATTERN WORD!-
;  1   !BEGIN
;  1   !LOCAL                                            !                                 ZZZ
;  1   !       TRYNUM : WORD,                            !                                 ZZZ
;  1   !       MAX_TRY_COUNT : word initial (9);         ! MAXIMUM NUMBER OF RETRIES BEFORE ERROR ZZZ
;  1   !                                                 !                                 ZZZ
;  1   !LABEL                                            !                                 ZZZ
;  1   !      DUP_WLOOP;                                 !START OF DUP WRITE RETRY LOOP    ZZZ
;  1
;  1   !PRINTX (DER11);
;  1   !T_ADDR [T_DBN_WT] = .T ADDR [T DBN WT] + 1;     ! INCREMENT # OF WRITES GIVEN
;  1
;  1   !TRYNUM = 0;                                      !ZERO TRY COUNTER                 ZZZ
;  1   !DUP_WLOOP:                                       !LABEL FOR LOOP EXCAPE ON GOOD WRITE ZZZ
;  1   !BEGIN                                            !BEGIN DUP_WLOOP                  ZZZ
;  1   !INCR TRIES FROM 1 TO 10 DO                       !START TRYING DUP WRITES          ZZZ
;  1   !BEGIN                                            !BEGIN LARGE DO LOOP              ZZZ
;  1                                                     !                                ZZZ
;  1
;  1   !MSCP_PKT [.MX1, MSGLEN] = SZ_ELP;               ! PACKET SIZE          EXECUTE LOCAL PROGRAM WRT DB
N
;  1   !MSCP_PKT [.MX1, OPCODE] = OP_ELP;               ! OPCODE = EXECUTE LOCAL PROGRAM
;  1   !MSCP_PKT [.MX1, L1] = %ascii'W';                ! FILL IN PROGRAM NAME WITH ASCII LETTERS
;  1   !MSCP_PKT [.MX1, L2] = %ascii'R';
;  1   !MSCP_PKT [.MX1, L3] = %ascii'T';
;  1   !MSCP_PKT [.MX1, L4] = %ascii'D';
;  1   !MSCP_PKT [.MX1, L5] = %ascii'B';
;  1   !MSCP_PKT [.MX1, L6] = %ascii'N ;
;  1   !MSCP_PKT [.MX1, MODIFY] = 1;                    ! STANDALONE MODIFIER
;  1   !Z.Z MSCP_PKT [.MX1, MSGTYP] = IMM_CMD;          ! CALL IT IMMEDIATE
;  1   !MSCP_PKT [.MX1, MSGTYP] = MT_SEQ;               ! CALL ALL DUP CMDS SEQUENTIAL.          ZZZ
;  1   !DUPCOMMAND ();                                  ! SENDS AND RECEIVES THE COMMAND
;  1
;  1   !IF .CST_ADDR [ DUOFF + OF_DBN, DUPERROR] EQL 1        !status error
;  1   !THEN RETURN;                                    ! AND RETURN
;  1
;  1   !DO (MX1 = GET_PKT (.CCTLR))
;  1   !UNTIL (.MX1 GEQ 0);                   ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRG ERROR
;  1
;  1   !        MSCP_PKT [.MX1, MSGLEN] = SZ_REC;                ! PACKET SIZE          RECIEVE DATA
;  1   !        MSCP PKT [.MX1, OPCODE] = OP RCD;                ! OPCODE = RECEIVE DATA
```

```
;    4427  1      !       MSCP_PKT [.MX1, BC_LO] = 80;                    ! BYTE COUNT TO BE TRANSFERED EQUALS 2 ***see pg 26 of DUP s
pec
;    4428  1      !       MSCP_PKT [.MX1, BUF_O] = DUPPKT;                ! LOAD DESCRIBTOR BUFFER
;    4429  1      !       MSCP_PKT [.MX1, MODIFY] = 0;                    !
;    4430  1      !ZZZ    MSCP_PKT [.MX1, MSGTYP] = SEQ_CMD;              ! CALL IT sequential
;    4431  1      !       MSCP_PKT [.MX1, MSGTYP] = MT_SEQ;               ! CALL ALL DUP CMDS SEQUENTIAL.                         ZZZ
;    4432  1      !       DUPCOMMAND ();                                  ! SENDS AND RECEIVES THE COMMAND
;    4433  1
;    4434  1      !       IF (.CST_ADDR [.DUOFF + OF_DBN, DUPERROR] EQL 1) OR     !status error
;    4435  1      !          (.DUPPKT [DUPTYPE] NEQU 1) OR                !dup type error
;    4436  1      !          (.DUPPKT [DUPMESG] NEQU 6)
;    4437  1      !       THEN
;    4438  1      !               (D_FAIL = 1;                            !TELL HARD_ERROR IT WAS A DUP PROBLEM           ZZZ
;    4439  1      !                HARD_ERROR ();                         !
;    4440  1      !                D_FAIL = 0;                            !                                               ZZZ
;    4441  1      !               CST_ADDR [.DUOFF + OF_DBN, DUPERROR] = 1;       ! SET FLAG
;    4442  1      !               RETURN;);                               ! NO POINT IN CONTINUING
;    4443  1
;    4444  1      !       DO (MX1 = GET_PKT (.CCTLR))
;    4445  1      !       UNTIL (.MX1 GEQ 0);                             ! TRY TO GET AN ENVELOPE  IF FAILURE LOOP PRG ERROR
;    4446  1
;    4447  1      !       MSCP_PKT [.MX1, MSGLEN] = SZ_SEN;               ! PACKET SIZE                                 SEND DATA
;    4448  1      !       MSCP_PKT [.MX1, OPCODE] = OP_SDD;               ! OPCODE = SEND DATA
;    4449  1      !       MSCP_PKT [.MX1, BC_LO] = 6;                     ! BYTE COUNT TO BE TRANSFERED EQUALS 6
;    4450  1      !       MSCP_PKT [.MX1, BUF_O] = DUPPKT;                ! LOAD DESCRIBTOR BUFFER
;    4451  1      !       DUPPKT [DUPBF0] = .CST_ADDR [.DUOFF, D_DISK_NUM]; !LOAD UNIT NUMBER (RDRX)
;    4452  1      !       DUPPKT [DUPBF1] = .CST_ADDR [.DUOFF + OF_DBN, D_DBN];  ! LOAD DBN NUMBER
;    4453  1      !       DUPPKT [DUPBF2] = .S_PATTERN;                   ! LOAD PATTERN
;    4454  1      !       MSCP_PKT [.MX1, MODIFY] = 0;                    !
;    4455  1      !ZZZ    MSCP_PKT [.MX1, MSGTYP] = SEQ_CMD;              ! CALL IT sequential
;    4456  1      !       MSCP_PKT [.MX1, MSGTYP] = MT_SEQ;               ! CALL ALL DUP CMDS SEQUENTIAL.                         ZZZ
;    4457  1      !       DUPCOMMAND ();                                  ! SENDS AND RECEIVES THE COMMAND
;    4458  1
;    4459  1      !        IF .CST_ADDR [.DUOFF + OF_DBN, DUPERROR] EQL 1         ! status error
;    4460  1      !        THEN RETURN;
;    4461  1      !
;    4462  1      !       DO (MX1 = GET_PKT (.CCTLR))
;    4463  1      !       UNTIL (.MX1 GEQ 0);                     ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRG ERROR
;    4464  1
;    4465  1      !       MSCP_PKT [.MX1, MSGLEN] = SZ_REC;               ! PACKET SIZE                                 RECEIVE DATA
;    4466  1      !       MSCP_PKT [.MX1, OPCODE] = OP_RCD;               ! OPCODE = RECEIVE DATA
;    4467  1      !       MSCP_PKT [.MX1, BC_LO] = 4;                     ! BYTE COUNT TO BE TRANSFERED EQUALS 4
;    4468  1      !       MSCP_PKT [.MX1, BUF_O] = DUPPKT;                ! LOAD DESCRIBTOR BUFFER
;    4469  1      !       MSCP_PKT [.MX1, MODIFY] = 0;                    !
;    4470  1      !ZZZ    MSCP_PKT [.MX1, MSGTYP] = SEQ_CMD;              ! CALL IT sequential
;    4471  1      !       MSCP_PKT [.MX1, MSGTYP] = MT_SEQ;               ! CALL ALL DUP CMDS SEQUENTIAL.                         ZZZ
;    4472  1      !       DUPCOMMAND ();                                  ! SENDS AND RECEIVES THE COMMAND
;    4473  1
;    4474  1
;    4475  1      !       IF (.CST_ADDR [.DUOFF + OF_DBN, DUPERROR] EQL 0) AND    !IF status OK AND                   ZZZ
;    4476  1      !          (.DUPPKT [DUPTYPE] EQL 3) AND                !NO dup type error                      ZZZ
;    4477  1      !          (.DUPPKT [DUPMESG] EQL 3) AND                !                                       ZZZ
;    4478  1      !          (.DUPPKT [DUPBF1]  EQL 0)                    !AND A successful write code            ZZZ
;    4479  1                                                              !                                       ZZZ
```

```
;    4480  1      !        THEN                                          !THEN                                          ZZZ
;    4481  1      !            LEAVE DUP_WLOOP                           !I/O OK. EXIT RETRY LOOP.                       ZZZ
;    4482  1
;    4483  1      !ZZZ ;;;;;;;;;;;;;;;;;;;;;;;;;;
;    4484  1      !        ELSE                                                                                        !ZZZ
;    4485  1      !        IF (.DUPPKT [DUPBF0] EQL 50003) AND           !IF DBN  IS OUT OF RANGE                       ZZZ
;    4486  1      !           (.DUPPKT [DUPBF1]  EQL  2)                 !WD 0 = 2 FOR OUT OF RANGE STATUS.              ZZZ
;    4487  1      !        THEN                                          !THEN                                          ZZZ
;    4488  1      !            LEAVE DUP_WLOOP                           !EXIT RETRY LOOP.                               ZZZ
;    4489  1      !ZZZ ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
;    4490  1
;    4491  1      !        ELSE                                          !                                                  ZZZ
;    4492  1      !            BEGIN                                     !                                                  ZZZ
;    4493  1      !            TRYNUM = .TRYNUM + 1;                     !INCR ATTEMPT COUNT                                ZZZ
;    4494  1      !            IF .TRYNUM  EQL .MAX_TRY_COUNT            !IF IT FAILED ALL RETRIES, THEN                    ZZZ
;    4495  1      !            THEN                                      !REPORT THE ERROR.                                 ZZZ
;    4496  1      !                    (D_FAIL = 1;                      !TELL HARD_ERROR IT WAS A DUP PROBLEM             ZZZ
;    4497  1      !                      HARD_ERROR ();                  !                                                  ZZZ
;    4498  1      !                      D_FAIL = 0;                     !                                                  ZZZ
;    4499  1      !                     CST ADDR [.DUOFF + OF_DBN, DUPERROR] = 1;    ! SET FLAG                          ZZZ
;    4500  1      !                     RETURN;);                       ! NO POINT IN CONTINUING                        ZZZ
;    4501  1      !            END;                                      !                                                  ZZZ
;    4502  1      ! END;                                                 !END LARGE DO LOOP                                 ZZZ
;    4503  1      !                                                      !                                                  ZZZ
;    4504  1      !END;                                                  !END DUP WLOOP                                     ZZZ
;    4505  1
;    4506  1
;    4507  1      !DO (MX1 = GET_PKT (.CCTLR))
;    4508  1      !UNTIL (.MX1 GEQ 0);                                   ! TRY TO GET AN ENVELOPE.
;    4509  1      !
;    4510  1      !T_ADDR [T_BLK_WT] = .T_ADDR [T_BLK_WT] + 1;           !INCREMENT COUNTER IF A SUCCESS
;    4511  1      !
;    4512  1      !END;
```

```
;  4513  1      !GLOBAL ROUTINE DUPREDDBN : NOVALUE =
;  4514  1
;  4515  1      !+
;  4516  1      ! THIS ROUTINE IS CALLED BY DUP ROUTINE TO USE THE CONTROLLER LOCAL PROGRAM
;  4517  1      ! "REDDBN".  TO USE THE PROGRAM THE OPTIONAL DUP SUB PROTOCAL IS USED TO
;  4518  1      ! COMMUNICATE WITH THE CONTROLLER.  THE PROGRAM READS A DIAGONOSTIC BLOCK (DBN)
;  4519  1      ! AND PLACES IT IN THE DUP BUFFER CALLED "DUPPKT".  IF AN ERROR OCCURS WHILE
;  4520  1      ! RUNNING THE CONTROLLER LOCAL PROGRAM THE ERROR IS USSUALLY REPORTED IN THE
;  4521  1      ! DUP BUFFER. (EX. ILLEGAL UNIT NUMBER, ILLEGAL BLK #, DEVICE ERROR, ZERO LENGHT MSG)
;  4522  1      !
;  4523  1      !
;  4524  1      !       IMPLICIT INPUTS:
;  4525  1      !               CST_ADDR      CONTAINS THE CURRENT CONTROLLER STATUS TABLE
;  4526  1      !               DUOFF         CURRENT OFFSET IN CST TABLE FOR PARTICULAR DRIVE
;  4527  1      !
;  4528  1      !BEGIN
;  4529  1      !LOCAL                                                !                                                ZZZ
;  4530  1      !      TRYNUM : WORD,                                 !                                                ZZZ
;  4531  1      !      MAX_TRY_COUNT : word initial (9);              ! MAXIMUM NUMBER OF RETRIES BEFORE ERROR ZZZ
;  4532  1                                                           !                                              ZZZ
;  4533  1      !LABEL                                                !                                                ZZZ
;  4534  1      !     DUP_RLOOP;                                      !START OR DUP READ RETRY LOOP                    ZZZ
;  4535  1
;  4536  1
;  4537  1      !PRINTX (DER12);
;  4538  1      !T_ADOR [T_DBN RD] = .T_ADDR [T_DBN_RD] + 1;     ! INCREMENT # OF READS GIVEN
;  4539  1
;  4540  1      !TRYNUM = 0;                                          !ZERO TRY COUNTER                                ZZZ
;  4541  1      !DUP_RLOOP:                                           !LABEL FOR LOOP EXCAPE ON GOOD READ              ZZZ
;  4542  1      !BEGIN                                                !BEGIN DUP_RLOOP                                 ZZZ
;  4543  1      !INCR TRIES FROM 1 TO 10 DO                           !START TRYING DUP READS                          ZZZ
;  4544  1      !BEGIN                                                !BEGIN LARGE DO LOOP                             ZZZ
;  4545  1                                                           !                                               ZZZ
;  4546  1
;  4547  1      ! MSCP_PKT [.MX1, MSGLEN] = SZ_ELP;                   ! PACKET SIZE                          EXECUTE REDDBN PROGRAM
;  4548  1      ! MSCP_PKT [.MX1, OPCODE] = OP_ELP;                   ! OPCODE = EXECUTE LOCAL PROGRAM
;  4549  1      ! MSCP_PKT [.MX1, L1] = %ascii'R';                    ! FILL IN PROGRAM NAME WITH ASCII LETTERS
;  4550  1      ! MSCP_PKT [.MX1, L2] = %ascii'E';
;  4551  1      ! MSCP_PKT [.MX1, L3] = %ascii'D';
;  4552  1      ! MSCP_PKT [.MX1, L4] = %ascii'D';
;  4553  1      ! MSCP_PKT [.MX1, L5] = %ascii'B';
;  4554  1      ! MSCP_PKT [.MX1, L6] = %ascii'N';
;  4555  1      ! MSCP_PKT [.MX1, MODIFY] = 1;                        ! STANDALONE MODIFIER
;  4556  1      !ZZZ  MSCP_PKT [.MX1, MSGTYP] = IMM_CMD;                    ! CALL IT IMMEDIATE
;  4557  1      ! MSCP_PKT [.MX1, MSGTYP] = MT_SEQ;                   ! CALL ALL DUP CMDS SEQUENTIAL.                  ZZZ
;  4558  1      ! DUPCOMMAND ();                                             ! SENDS AND RECEIVES THE COMMANO
;  4559  1      !
;  4560  1      ! IF .CST_ADDR [.DUOFF + OF_DBN, DUPERROR] EQL 1        !status error
;  4561  1      ! THEN RETURN;
;  4562  1
;  4563  1      ! DO (MX1 = GET_PKT (.CCTLR))
;  4564  1      ! UNTIL (.MX1 GEQ 0);                    ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRG ERROR
;  4565  1
```

```
;    4566  1       !       MSCP_PKT [.MX1, MSGLEN] = SZ_REC;               ! PACKET SIZE                                   RECIEVE DATA
;    4567  1       !       MSCP_PKT [.MX1, OPCODE] = OP_RCD;               ! OPCODE = RECEIVE DATA
;    4568  1       !       MSCP_PKT [.MX1, BC_LO] = 80;                    ! BYTE COUNT TO BE TRANSFERED EQUALS 2 ******see pg 26 DUP sp
ec
;    4569  1       !       MSCP_PKT [.MX1, BUF_0] = DUPPKT;                ! LOAD DESCRIBTOR BUFFER
;    4570  1       !       MSCP_PKT [.MX1, MODIFY] = 0;                    !
;    4571  1       !ZZZ    MSCP_PKT [.MX1, MSGTYP] = SEQ_CMD;              ! CALL IT sequential
;    4572  1       !       MSCP_PKT [.MX1, MSGTYP] = MT_SEQ;               ! CALL ALL DUP CMDS SEQUENTIAL.                         ZZZ
;    4573  1       !       DUPCOMMAND ();                                  ! SENDS AND RECEIVES THE COMMAND
;    4574  1
;    4575  1       !       IF (.CST_ADDR [.DUOFF + OF_DBN, DUPERROR] EQL 1) OR     !status error
;    4576  1       !          (.DUPPKT [DUPTYPE] NEQU 1) OR                !dup type error
;    4577  1       !          (.DUPPKT [DUPMESG] NEQU 5)
;    4578  1       !       THEN
;    4579  1       !               (D_FAIL = 1;                            !TELL HARD ERROR IT WAS A DUP PROBLEM           ZZZ
;    4580  1       !                 HARD_ERROR ();
;    4581  1       !                 D_FAIL = 0;                            !                                               ZZZ
;    4582  1       !                CST_ADDR [.DUOFF + OF_DBN, DUPERROR] = 1;      ! SET FLAG
;    4583  1       !                RETURN;);                               ! NO POINT IN CONTINUING
;    4584  1
;    4585  1       !       DO (MX1 = GET_PKT (.CCTLR))
;    4586  1       !       UNTIL (.MX1 GEQ 0);                             ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRG ERROR
;    4587  1       !
;    4588  1       !       MSCP_PKT [.MX1, MSGLEN] = SZ_SEN;               ! PACKET SIZE                                   SEND DATA
;    4589  1       !       MSCP_PKT [.MX1, OPCODE] = OP_SDD;               ! OPCODE = SEND DATA
;    4590  1       !       MSCP_PKT [.MX1, BC_LO] = 4;                     ! BYTE COUNT TO BE TRANSFERED EQUALS 4
;    4591  1       !       MSCP_PKT [.MX1, BUF_0] = DUPPKT;                ! LOAD DESCRIBTOR BUFFER
;    4592  1       !       DUPPKT [DUPBF0] = .CST_ADDR [.DUOFF, D_DISK_NUM]; ! LOAD UNIT NUMBER (RDRX)
;    4593  1       !       DUPPKT [DUPBF1] = .CST_ADDR [.DUOFF + OF DBN, D_DBN];  ! LOAD DBN NUMBER
;    4594  1       !       MSCP PKT [.MX1, MODIFY] = 0;                    !
;    4595  1       !!ZZZ   MSCP_PKT [.MX1, MSGTYP] = SEQ_CMD;              ! CALL IT sequential
;    4596  1       !       MSCP_PKT [.MX1, MSGTYP] = MT_SEQ;               ! CALL ALL DUP CMDS SEQUENTIAL.                         ZZZ
;    4597  1       !       DUPCOMMAND ();                                  ! SENDS AND RECEIVES THE COMMAND
;    4598  1
;    4599  1       !         IF .CST_ADDR [.DUOFF + OF_DBN, DUPERROR] EQL 1        !status error
;    4600  1       !         THEN RETURN;
;    4601  1
;    4602  1       !       DO (MX1 = GET_PKT (.CCTLR))
;    4603  1       !       UNTIL (.MX1 GEQ 0);                     ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRG ERROR
;    4604  1
;    4605  1       !       MSCP_PKT [.MX1, MSGLEN] = SZ_REC;               ! PACKET SIZE                                   RECEIVE DATA
;    4606  1       !       MSCP_PKT [.MX1, OPCODE] = OP_RCD;               ! OPCODE = GET DUST STATUS
;    4607  1       !       MSCP_PKT [.MX1, BC_LO] = 514;                   ! BYTE COUNT TO BE TRANSFERED EQUALS 512
;    4608  1       !       MSCP_PKT [.MX1, BUF_0] = DUPPKT;                ! LOAD DESCRIBTOR BUFFER
;    4609  1       !       MSCP_PKT [.MX1, MODIFY] = 0;                    !
;    4610  1       !ZZZ    MSCP_PKT [.MX1, MSGTYP] = SEQ_CMD;              ! CALL IT sequential
;    4611  1       !       MSCP_PKT [.MX1, MSGTYP] = MT_SEQ;               ! CALL ALL DUP CMDS SEQUENTIAL.                         ZZZ
;    4612  1       !       DUPCOMMAND ();                                  ! SENDS AND RECEIVES THE COMMAND
;    4613  1
;    4614  1       !       IF (.CST_ADDR [.DUOFF + OF_DBN, DUPERROR] EQL 0) AND    !IF status OK AND                       ZZZ
;    4615  1       !          (.DUPPKT [DUPTYPE] EQL 6) AND                !NO dup type error                      ZZZ
;    4616  1       !          (.DUPPKT [DUPMESG] EQL 2)                    !                                       ZZZ
;    4617  1       !       THEN                                            !THEN                                   ZZZ
;    4618  1       !           LEAVE DUP RLOOP                             !I/O OK. EXIT RETRY LOOP.               ZZZ
```

```
!ZZZ ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
!         ELSE                                                          !ZZZ
!         IF (.DUPPKT [DUPBF0] EQL 50003) AND          !IF DBN  IS OUT OF RANGE          ZZZ
!!            (.DUPPKT [DUPBF1]  EQL  2)                 !WD 0 = 2 FOR OUT OF RANGE STATUS.    ZZZ
!        THEN                                          !THEN                             ZZZ
!            LEAVE DUP_RLOOP                            !EXIT RETRY LOOP.                 ZZZ
!ZZZ ;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;

!         ELSE                                          !                                 ZZZ
!             BEGIN                                     !                                 ZZZ
!             TRYNUM = .TRYNUM + 1;                     !INCR ATTEMPT COUNT               ZZZ
!             IF .TRYNUM  EQL .MAX_TRY COUNT            !IF IT FAILED ALL RETRIES, THEN   ZZZ
!             THEN                                      !REPORT THE ERROR.                ZZZ
!                     (D_FAIL = 1;                     !TELL HARD_ERROR IT WAS A DUP PROBLEM ZZZ
!                       HARD_ERROR ();                  !                                 ZZZ
!                       D_FAIL = 0;                     !                                 ZZZ
!                      CST_ADDR [.DUOFF + OF_DBN, DUPERROR] = 1;    ! SET FLAG              ZZZ
!                      RETURN;);                       ! NO POINT IN CONTINUING          ZZZ
!             END;                                      !                                 ZZZ
! END;                                                  !END LARGE DO LOOP                ZZZ
                                                       !                                 ZZZ
!END;                                                   !END DUP RLOOP                    ZZZ

!DO (MX1 = GET_PKT (.CCTLR))
!UNTIL (.MX1 GEQ 0);                  ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRG ERROR

!T_ADDR [T_BLK_RD] = .T_ADDR [T BLK_RD] + 1;            !IF DUP NO ERROR THEN INCREMENT COUNTER

!END;
```

```
;  4650  1     !
;  4651  1     !GLOBAL ROUTINE DUPCOMMAND : NOVALUE =
;  4652  1
;  4653  1     !!+
;  4654  1     ! THIS ROUTINE IS CALLED BY DUP TO PROCESS COMMANDS.
;  4655  1     ! THE COMMAND ENVOLOPES ARE FILLED IN DUP ROUTINES IN THE "MX1" INDEX.
;  4656  1     ! WITH THE INDEX THIS ROUTINE SENDS THE COMMAND, WAITS FOR A
;  4657  1     ! RESPONSES AND THEN PROCESSES THE RETURN PACKET.
;  4658  1     !-
;  4659  1     !BEGIN
;  4660  1     !PRINTX (DER13);
;  4661  1
;  4662  1     !MSCP_PKT [.MX1, CREDITS] = 0;                  ! DUP DOES NOT USE THE CREDIT SYSTEM
;  4663  1     !MSCP_PKT [.MX1, CONNID] = CID_DUP;             ! MAKE PACKAGE EQUAL A DUP COMMAND
;  4664  1     !MSCP_PKT [.MX1, DK_NUM] = 0;                  ! DISK NUMBER (NOT APPLICABLE)
;  4665  1     !
;  4666  1     !IF SEND (.MX1) EQLU FAILURE                   ! ATTEMPT SEND; IF CTLR IS OFFLINE
;  4667  1     !THEN
;  4668  1     !       BEGIN
;  4669  1     !       PUT_PKT (.MX1);
;  4670  1     !       MX1 = -1;                              ! RETURN ENVELOPE TO POOL
;  4671  1     !       CST_ADDR [.DUOFF + OF DBN, DUPERROR] = 1;
;  4672  1     !!      PRINTF (DBM112);                       ! "DUP: PKT NOT AVAILABLE"  ZZZ
;  4673  1     !       END
;  4674  1
;  4675  1     !ELSE
;  4676  1     !       do
;  4677  1     !               begin
;  4678  1     !               BREAK;                                  ! BREAK FOR ACT
;  4679  1     !               PROC_RETPKT ();                                 ! PROCESS RETURN PACKET TO SEE IF OK FOR DUP
;  4680  1     !               end
;  4681  1     !       until (.CRN_LOW eqlu .RP_ADDR [CRF_LO]) or      ! TO ENSURE THAT ALL RETURN MESSAGES HAVE BEEN PROCESSED
;  4682  1     !       (.EOP_FLAG eql true);                           ! or end of pass caused by error
;  4683  1     !END;
```

```
;    4684  1
;    4685  1      !GLOBAL ROUTINE DUPIDLE : NOVALUE =
;    4686  1      !*
;    4687  1      ! THIS ROUTINE IS CALLED BY DUP ROUTINE TO INSURE THAT THE CONTROLLER
;    4688  1      ! IS NOT IN A ACTIVE STATE. IF CALLED AND THE CONTROLLER IS IN AN ACTIVE
;    4689  1      ! STATE THE CONTROLLER WILL GIVE AN ABORT COMMAND WHICH SHOULD KILL THE
;    4690  1      ! CURRENT JOB OR LOCAL PROGRAM.
;    4691  1      !-
;    4692  1      !BEGIN
;    4693  1      !CST_ADDR [.DUOFF + OF_DBN, DUPERROR] = 0;              !CLEAR DUP ERROR FLAG;
;    4694  1      !
;    4695  1      !MSCP_PKT [.MX1, MSGLEN] = SZ_GDS;              ! PACKET SIZE                              GET DUST STATUS
;    4696  1      !MSCP_PKT [.MX1, OPCODE] = OP_GDS;              ! OPCODE = GET DUST STATUS
;    4697  1      !MSCP_PKT [.MX1, MODIFY] = 0;                   !
;    4698  1      !!ZZZ MSCP_PKT [.MX1, MSGTYP] = IMM_CMD;                ! CALL IT IMMEDIATE
;    4699  1      !MSCP_PKT [.MX1, MSGTYP] = MT_SEQ;              ! CALL ALL DUP CMDS SEQUENTIAL.                    ZZZ
;    4700  1      !DUPCOMMAND ();                                 ! SENDS AND RECEIVES THE COMMAND
;    4701  1      !                                               ! GDS ONLY RETURNS SUCCESS or it don't return
;    4702  1
;    4703  1      !DO (MX1 = GET_PKT (.CCTLR))
;    4704  1      !UNTIL (.MX1 GEQ 0);                            ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRGRAM ERROR
;    4705  1      !
;    4706  1      !if .CST_ADDR [.DUOFF + OF_DBN, D_ACTIVE] neq IDLE      ! if not in idle state then abort the program
;    4707  1      !then
;    4708  1      !    begin
;    4709  1      !    MSCP_PKT [.MX1, MSGLEN] = SZ_ABT;               ! PACKET SIZE                                  ABORT CMD
;    4710  1      !    MSCP_PKT [.MX1, OPCODE] = OP_ABT;               ! OPCODE = ABORT PROGRAM
;    4711  1      !    MSCP_PKT [.MX1, MODIFY] = 0;                    !
;    4712  1      !!ZZZ MSCP_PKT [.MX1, MSGTYP] = IMM_CMD;                     ! CALL IT IMMEDIATE
;    4713  1      !    MSCP_PKT [.MX1, MSGTYP] = MT_SEQ;               ! CALL ALL DUP CMDS SEQUENTIAL.                ZZZ
;    4714  1      !    DUPCOMMAND ();                                  ! SENDS AND RECEIVES THE COMMAND
;    4715  1      !                                                    !ONLY ERROR IS already in idle state
;    4716  1      !    DO (MX1 = GET_PKT (.CCTLR))
;    4717  1      !    UNTIL (.MX1 GEQ 0);                             ! TRY TO GET AN ENVELOPE. IF FAILURE LOOP PRGRAM ERRCR
;    4718  1      !    end;
;    4719  1      !end;
```

```
;    4720  1     GLOBAL routine QIO_LBN : novalue =
;    4721  1
;    4722  1     !+
;    4723  1     !       THIS ROUTINE IS CALLED BY QIO_GEN TO SELECT THE LOGICAL BLOCK NUMBER TO
;    4724  1     !       BE USED FOR THE CURRENT QIO OR QIO PAIR.
;    4725  1     !
;    4726  1     !       IF THE OPERATOR CHOSE THE RANDOM SEEK MODE OPTION, THEN THE LBN IS
;    4727  1     !       RANDOMLY CHOSEN WITHIN THE SPECIFIED LIMITS FOR THE LBN.
;    4728  1     !       OTHERWISE, THE NEXT SEQUENTIAL LBN IS DERIVED FROM THE BLOCK SEQUENCE
;    4729  1     !       TABLE (BST).
;    4730  1     !
;    4731  1     !       IMPLICIT INPUTS:
;    4732  1     !               L$LUN   CURRENT (DIAGNOSTIC SUPERVIOR) UNIT NUMBER
;    4733  1     !
;    4734  1     !       IMPLICIT OUTPUTS:
;    4735  1     !               THE LBN IS LOADED INTO ONE OR BOTH MSCP PACKETS.
;    4736  1     !-
;    4737  1
;    4738  2         begin
;    4739  2
;    4740  2         own
;    4741  2             LBN0_SAVE : word initial (0),                       !LO LBN SELECTED IN PREVIOUS PASS
   ZZZ
;    4742  2             LBN1_SAVE : word initial (0);                       !HI LBN SELECTED IN PREVIOUS PASS
   ZZZ
;    4743  2
;    4744  2         local
;    4745  2             S0_TEMP : word,                                     ! TEMPORARY STORAGE FOR START LBN LO
   ZZZ
;    4746  2             S1_TEMP : word,                                     ! TEMPORARY STORAGE FOR START LBN HI
   ZZZ
;    4747  2             E0_TEMP : word,                                     ! TEMPORARY STORAGE FOR END LBN LO
   ZZZ
;    4748  2             E1_TEMP : word,                                     ! TEMPORARY STORAGE FOR END LBN HI
   ZZZ
;    4749  2             ADD0_LBN : word,                                    ! TEMPORARY STORAGE USED FOR COMPUTING DESIRED LBN L
0  ZZZ
;    4750  2             ADD1_LBN : word,                                    ! TEMPORARY STORAGE USED FOR COMPUTING DESIRED LBN H
I  ZZZ
;    4751  2             LBN0 : word,                                        ! LOGICAL BLOCK NUMBER LO
   ZZZ
;    4752  2             LBN1 : word,                                        ! LOGICAL BLOCK NUMBER HI
   ZZZ
;    4753  2             WINCHESTER : byte initial (byte (TRUE));            ! FLAG TO INDICATE WINCHESTER DISK SELECTED
;    4754  2
;    4755  2         label
;    4756  2             FIND_LBN;
;    4757  2
;    4758  2         S0_TEMP = .CST_ADDR [.CUOFF + OF_BEG, D_BEG0];          ! STARTING LBN LO
  ZZZ
;    4759  2         S1_TEMP = .CST_ADDR [.CUOFF + OF_BEG1, D_BEG1];         ! STARTING LBN HI
 ZZZ
;    4760  2         E0_TEMP = .CST_ADDR [.CUOFF + OF_END, D_END0];          ! ENDING LBN LO
  ZZZ
;    4761  2         E1_TEMP = .CST_ADDR [.CUOFF + OF_END1, D_END1];         ! ENDING LBN HI
 ZZZ
;    4762  2
;    4763  2         FIND_LBN:
;    4764  3             begin                                               !BEGIN A.
  ZZZ
;    4765  3
;    4766  3             if (.CST_ADDR [.CUOFF + OF_DATA, D_TYPE] eql FIXED) and
;    4767  3                (BIT_TST (SWP_FLAGS, SWF_FER)) and
;    4768  3                (.MAD1 [OPCODE] eql OP_WRT) and
;    4769  4                (.FORCED_ERROR)
;    4770  3             then
.    4771  4                 begin
;    4772  4                 LBN0= .FER0_LBN;                                ! IF "FORCED ERROR" DETECTED, REWRITE ERROR LBN LO
 ZZZ
```

```
;  4                    LBN1= .FER1_LBN;                              ! IF "FORCED ERROR" DETECTED, REWRITE ERROR LBN HI
 ZZZ
;  4                    leave FIND_LBN;
;  3                    end;
;  3
;  3                 if .CST ADDR [.CUOFF + OF_DATA, D_TYPE] eql REMOVABLE
;  3                 then
;  3                    WINCHESTER = FALSE;
;  3
;  4                 if BIT_TST (SWP_FLAGS, SWF_RDM)                  ! IF RANDOM SEEK MODE
;  3                 then
;  3
;  3        !!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
;  3        !                                                                              !
;  3        !    NOTE:  UNOMMENT THE 2 LINES AT "IF WINCHESTER", AND DELETE "IF 1 EQLU 0" TO !
;  3        !           REDUCE SEEKS ON THE WINCHESTERS BY HALF.                           !
;  3        !!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
;  3
;  4                    begin
;  4                    IF 1 EQLU 0                                           !COMMENT OUT FOR REDUCED SEEKS
   ZZZ
;  4
;  4
;  4        !ZZZ        if (.WINCHESTER) and
;  4        !ZZZ           (((.RANDOM [0] and %o'077777') mod (100)) lequ 49)
;  4                    then
;  5                       BEGIN                                              !
   ZZZ
;  5                       LBNO = .LBNO SAVE;                                 ! REDUCE SEEKS ON RDs by 50%
   ZZZ
;  5                       LBN1 = .LBN1_SAVE;                                 ! REDUCE SEEKS ON RDs by 50%
   ZZZ
;  5                       END                                                !
   ZZZ
;  4                    else
;  4
;  4
;  5                       begin
;  5                       RANDY ();                                          !GET A 32 BIT RANDOM NUMBER
   ZZZ
;  5                       IF ( RNDY1 GTRU .E1_TEMP) OR                       !IF NUMBER GREATER THAN MAX
   ZZZ
;  6                          ((.RNDY1 EQLU .E1_TEMP) AND                     !
   ZZZ
;  6                          (.RNDYO GTRU .EO_TEMP))                         !
   ZZZ
;  5                       THEN                                               !
   ZZZ
;  6                          BEGIN                                           !THEN MASK IT WITH HI LIMIT
   ZZZ
;  6                          RNDY1 = .RNDY1 AND .E1_TEMP;                    !
   ZZZ
;  6                          R     = .RNDYO AND .EO_TEMP;                    !
   ZZZ
;  5                          END;                                            !
   ZZZ
;  5                                                                          !
   ZZZ
;  5                       IF (.RNDY1 LSSU .S1_TEMP) OR                       !IF NUMBER LESS THAN MIN
   ZZZ
;  6                          ((.RNDY1 EQLU .S1_TEMP) AND                     !
   ZZZ
;  6                          (.RNDYO LSSU .SO_TEMP))                         !
   ZZZ
;  5                       THEN                                               !
   ZZZ
;  6                          BEGIN                                           !THEN MASK IT WITH LO LIMIT
   ZZZ
;  6                          RNDY1 = .RNDY1 AND .S1_TEMP;                    !
   ZZZ
;  6                          RNDYO = .RNDYO AND .SO_TEMP;                    !
```

```
;    4824  5                    LBN0 = .RNDY0;                          !LO HALF
     ZZZ
;    4825  5                    LBN1 = .RNDY1;                          !HI HALF
     ZZZ
```

```
.   4867  6                   END
ZZZ
;   4826  4                   end;
;   4827  4               end
;   4828  4
;   4829  3           ELSE                                                  !
ZZZ
;   4830  4           begin                                                 ! ELSE - SEQUENTIAL LBN MODE  (BEGIN A)
ZZZ
;   4831  4               LBN0 = .BST [.L$LUN, LO_WRD];                     ! GET LBN FROM BST (LO WORD)
ZZZ
;   4832  4               LBN1 = .BST [.L$LUN, HI_WRD];                     ! GET LBN FROM BST (HI WORD)
ZZZ
;   4833  4
;   4834  4               IF .TRK_SGN [.L$LUN] EQLU 1                       !IF WE WANT SERIAL INCREMENT
ZZZ
;   4835  4               THEN                                              !
ZZZ
;   4836  5               BEGIN                                             !(BEGIN B)
ZZZ
;   4837  5                   IF .BST [.L$LUN, LO_WRD] EQLU %o'177777'      !IF OVERFLOW FROM LO WD TO HI WD
ZZZ
;   4838  5                   THEN                                          !
ZZZ
;   4839  6                   BEGIN                                         !
ZZZ
;   4840  6                       BST [.L$LUN, LO_WRD] = 0;                 'ZERO LO WORD
ZZZ
;   4841  6                       BST [.L$LUN, HI_WRD] = .BST [.L$LUN, HI_WRD] + 1,       !INCREMENT HI WORD
ZZZ
;   4842  6                   END                                           !
ZZZ
;   4843  5                   ELSE                                                    !OTHERWISE JUST INCR LO WORD
ZZZ
;   4844  5                       BST [.L$LUN, LO_WRD] = .BST [.L$LUN, LO_WRD] + 1;   !
ZZZ
;   4845  5
;   4846  5                                                                 !NOW TAKE CARE OF OVERFLOW WHILE INCREMENTIN
G.  ZZZ
;   4847  6                   IF (.BST [.L$LUN, HI_WRD] GTRU .E1_TEMP)      !IF LBN1 OVER HI LIMIT
ZZZ
;   4848  7                     OR ((.BST [.L$LUN, HI_WRD] EQLU .E1_TEMP)   !OR LBN1 EQUALS HI LIMIT AND LBN0 IS OVER LI
MIT ZZZ
;   4849  6                     AND (.BST [.L$LUN, LO_WRD] GTRU .E0_TEMP))  !
ZZZ
;   4850  5                   THEN                                          !
ZZZ
;   4851  6                      BEGIN                                      !
ZZZ
;   4852  6                      BST [.L$LUN, LO_WRD] = .E0_TEMP;           !THEN SET HI LIMITS
ZZZ
;   4853  6                      BST [.L$LUN, HI_WRD] = .E1_TEMP;           !INTO BST FOR NEXT TIME
ZZZ
;   4854  6                      TRK_SGN [.L$LUN] = - 1;                    !AND REVERSE D^\ECTION
ZZZ
;   4855  5                      END;                                       !
ZZZ
;   4856  5               END                                               !(END B)
ZZZ
;   4857  5
;   4858  5
;   4859  5
;   4860  4               ELSE                                              !IF WE WANT SERIAL DECREMENT
ZZZ
;   4861  5               BEGIN                                             !(BEGIN C)
ZZZ
;   4862  5                   IF .BST [.L$LUN, LO_WRD] EQLU 0               !IF NEED TO BORROW FROM HI WD
ZZZ
;   4863  5                   THEN                                          !
ZZZ
;   4864  6                   BEGIN                                         !
ZZZ
;   4865  6                       BST [.L$LUN, LO_WRD] = %o'177777';        !LO WORD
ZZZ
```

```
;    4868  5                ELSE                                                    !OTHERWISE JUST DECR LO WORD
     ZZZ
;    4869  5                    BST [.L$LUN, LO_WRD] = .BST [ L$LUN, LO WRD]   1;   !
     ZZZ
;    4870  5
;    4871  5                                                                       !NOW TAKE CARE OF UNDERFLOW WHILE INCREMENTI
NG.  ZZZ
;    4872  6                IF (.BST [.L$LUN, HI_WRD] LSS  .S1_TEMP)              !IF LBN1 IS BELOW LIMIT
     ZZZ
;    4873  7                  OR ((.BST [.L$LUN, HI WRD] EQLU .S1_TEMP)           !OR LBN1 EQUALS LO LIMIT AND LBNO IS BELOW
     ZZZ
;    4874  6                  AND (.BST [.L$LUN, LO_WRD] LSSU .SO_TEMP))          !
     ZZZ
;    4875  5                THEN                                                  !
     ZZZ
;    4876  6                   BEGIN                                              !
     ZZZ
;    4877  6                   BST [.L$LUN, LO_WRD] = .SO_TEMP;                   !THEN SET LO LIMITS
     ZZZ
;    4878  6                   BST [.L$LUN, HI_WRD] = .S1_TEMP;                   !INTO BST FOR NEXT TIME
     ZZZ
```

```
;  4879  6                        TRK_SGN [.L$LUN] = + 1;                                    !AND REVERSE DIRECTION
ZZZ
;  4880  5                        END;                                                       !
ZZZ
;  4881  4                    END;                                                           !
ZZZ
;  4882  3                END;                                                               !END C.
ZZZ
;  4883  3                                                                                   !
ZZZ
;  4884  2             END;                                                                  !END A.
ZZZ
;  4885  2
;  4886  2
;  4887  3            IF ((.S1_TEMP EQLU .E1_TEMP) AND (.S0_TEMP EQLU .E0_TEMP))            !IF START ADDR SAME AS END ADDR
ZZZ
;  4888  2            THEN                                                                  !JUST USE THE START ADDRESS.
ZZZ
;  4889  3               BEGIN                                                              !
ZZZ
;  4890  3               LBN0 = .S0 TEMP;                                                   !
ZZZ
;  4891  3               LBN1 = .S1_TEMP;                                                   !
ZZZ
;  4892  2               END;                                                               !
ZZZ
;  4893  2
;  4894  2            MAD1 [LBN L] = .LBN0;                                 ! LOAD LBN INTO 1ST PACKET
ZZZ
;  4895  2            MAD1 [LBN H] = .LBN1;                                 ! LOAD LBN INTO 1ST PACKET
ZZZ
;  4896  2
;  4897  2            if .MX2 geq 0                                         ! IF 2 QIOs
ZZZ
;  4898  2            then
;  4899  2                MAD2 [LBN_L] = .LBN0;                             ! LOAD LBN INTO 2ND PACKET
ZZZ
;  4900  2                MAD2 [LBN H] = .LBN1;                             ! LOAD LBN INTO 2ND PACKET
ZZZ
;  4901  2
;  4902  2            LBN0_SAVE = .LBN0;                                    ! SAVE FOR USE NEXT CYCLE IF NEEDED
ZZZ
;  4903  2            LBN1_SAVE = .LBN1;                                    ! SAVE FOR USE NEXT CYCLE IF NEEDED
ZZZ
;  4904  2
;  4905  1            end;                                                  ! ROUTINE QIO LBN
```

```
001276                                  .PSECT  $GGG$,  RO
001276  000000                 LBN0.SAVE:
                                        .WORD   0
001300  000000                 LBN1.SAVE:
                                        WORD    0


                                        .SBTTL  QIO.LBN MULTI DRIVE TEST ROUTINES
014146                                  .PSECT  $CODE$,  RO

000000  004137  000000G         QIO.LBN::
                                        JSR     R1,$SAVE5                 ;                                  4720
000004  024646                          CMP     (SP), (SP)
000006  112746  000001                  MOVB    #1,-(SP)                  ; *.WINCHESTER                     4738
000012  013701  000000G                 MOV     CST.ADDR,R1               ;                                  4758
000016  013702  000000G                 MOV     CUOFF,R2
000022  010200                          MOV     R2,R0
000024  006300                          ASL     R0
000026  060100                          ADD     R1,R0
000030  016005  000002                  MOV     2(R0),R5                  ; *.S0.TEMP
000034  010200                          MOV     R2,R0                     ;                                  4759
```

```
000042  016003  000004                          MOV     4(R0),R3                ; *,S1.TEMP
000046  010200                                  MOV     R2,R0                   ;                                       4760
000050  006300                                  ASL     R0
000052  060100                                  ADD     R1,R0
000054  016046  000006                          MOV     6(R0),-(SP)             ; *,E0.TEMP
000060  010200                                  MOV     R2,R0                   ;                                       4761
000062  006300                                  ASL     R0
000064  060100                                  ADD     R1,R0
000066  016004  000010                          MOV     10(R0),R4               ; *,E1.TEMP
000072  006302                                  ASL     R2                      ;                                       4766
000074  060102                                  ADD     R1,R2
000076  132712  000020                          BITB    #20,(R2)
000102  001430                                  BEQ     2$
000104  032737  004000  000000G                 BIT     #4000,SWP.FLAGS         ;                                       4767
000112  001421                                  BEQ     1$
000114  013700  000114'                         MOV     MAD1,R0                 ;                                       4768
000120  126027  000022  000042                  CMPB    22(R0),#42
000126  001013                                  BNE     1$
000130  132737  C00001  000000G                 BITB    #1,FORCED.ERROR         ;                                       4769
000136  001407                                  BEQ     1$
000140  013766  000000G 000004                  MOV     FER0.LBN,4(SP)          ; *,LBN0                                4772
000146  013766  000000G 000006                  MOV     FER1.LBN,6(SP)          ; *,LBN1                                4773
000154  000544                                  BR      16$                     ;                                       4771
000156  132712  000020                  1$:     BITB    #20,(R2)                ;                                       4777
000162  001002                                  BNE     3$
000164  105066  000002                  2$:     CLRB    2(SP)                   ; WINCHESTER                            4779
000170  032737  000002  000000G         3$:     BIT     #2,SWP.FLAGS            ;                                       4781
000176  001447                                  BEQ     8$
000200  004737  011744                          JSR     PC,RANDY                ;                                       4805
000204  023704  000130'                         CMP     RNDY1,R4                ; *,E1.TEMP                             4806
000210  101004                                  BHI     4$
000212  001013                                  BNE     5$                      ;                                       4807
000214  023716  000126'                         CMP     RNDY0,(SP)              ; *,E0.TEMP                             4808
000220  101410                                  BLOS    5$
000222  010400                  4$:     MOV     R4,R0                   ; E1.TEMP,*                             4811
000224  005100                                  COM     R0
000226  040037  000130                          BIC     R0,RNDY1
000232  011600                                  MOV     (SP),R0                 ; E0.TEMP,*                             4812
000234  005100                                  COM     R0
000236  040037  000126'                         BIC     R0,RNDY0
000242  023703  000130'                 5$.     CMP     RNDY1,R3                ; *,S1.TEMP                             4815
000246  103404                                  BLO     6$
000250  001013                                  BNE     7$                      ;                                       4816
000252  023705  000126'                         CMP     RNDY0,R5                ; *,S0.TEMP                             4817
000256  103010                                  BHIS    7$
000260  010300                  6$:     MOV     R3,R0                   ; S1.TEMP,*                             4820
000262  005100                                  COM     R0
000264  040037  000130'                         BIC     R0,RNDY1
000270  010500                                  MOV     R5,R0                   ; S0.TEMP,*                             4821
000272  005100                                  COM     R0
000274  040037  000126                          BIC     R0,RNDY0
000300  013766  000126' 000004          7$:     MOV     RNDY0,4(SP)             ; *,LBN0                                4824
000306  013766  000130  000006                  MOV     RNDY1,6(SP)             ; *,LBN1                                4825
```

```
000314  000464                          BR      16$                     ;                                       4781
000316  013702  000000G                 8$:     MOV     L$LUN,R2        ;                                       4831
000322  010201                          MOV     R2,R1
000324  006301                          ASL     R1
000326  006301                          ASL     R1
000330  012700  000000G                 MOV     #BST,R0
000334  060100                          ADD     R1,R0
000336  011066  000004                  MOV     (R0),4(SP)              ; *,LBN0
000342  062701  000002G                 ADD     #BST+2,R1               ;                                       4832
000346  011166  000006                  MOV     (R1),6(SP)              ; *,LBN1
000352  062702  000000G                 ADD     #TRK.SGN,R2             ;                                       4834
000356  121227  000001                  CMPB    (R2),#1
000362  001021                          BNE     12$
000364  021027  177777                  CMP     (R0),#-1                ;                                       4837
000370  001003                          BNE     9$
000372  005010                          CLR     (R0)                    ;                                       4840
000374  005211                          INC     (R1)                    ;                                       4841
000376  000401                          BR      10$                     ;                                       4837
000400  005210                  9$:     INC     (R0)                    ;                                       4844
000402  021104                  10$:    CMP     (R1),R4                 ; *,E1.TEMP                             4847
000404  101003                          BHI     11$
000406  001027                          BNE     16$                     ;                                       4848
000410  021016                          CMP     (R0),(SP)               ; *,E0.TEMP                             4849
000412  101425                          BLOS    16$
000414  011610                  11$:    MOV     (SP),(R0)               ; E0.TEMP,*                             4852
000416  010411                          MOV     R4,(R1)                 ; E1.TEMP,*                             4853
000420  112712  000377                  MOVB    #377,(R2)               ;                                       4854
000424  000420                          BR      16$                     ;                                       4834
000426  005710                  12$:    TST     (R0)                    ;                                       4862
000430  001004                          BNE     13$
000432  012710  177777                  MOV     #-1,(R0)                ;                                       4865
000436  005311                          DEC     (R1)                    ;                                       4866
000440  000401                          BR      14$                     ;                                       4862
000442  005310                  13$:    DEC     (R0)                    ;                                       4869
000444  021103                  14$:    CMP     (R1),R3                 ; *,S1.TEMP                             4872
000446  002403                          BLT     15$
000450  001006                          BNE     16$                     ;                                       4873
000452  021005                          CMP     (R0),R5                 ; *,S0.TEMP                             4874
000454  103004                          BHIS    16$
000456  010510                  15$:    MOV     R5,(R0)                 ; S0.TEMP,*                             4877
000460  010311                          MOV     R3,(R1)                 ; S1.TEMP,*                             4878
000462  112712  000001                  MOVB    #1,(R2)                 ;                                       4879
000466  020304                  16$:    CMP     R3,R4                   ; S1.TEMP,E1.TEMP                       4887
000470  001006                          BNE     17$
000472  020516                          CMP     R5,(SP)                 ; S0.TEMP,E0.TEMP
000474  001004                          BNE     17$
000476  010566  000004                  MOV     R5,4(SP)                ; S0.TEMP,LBN0                          4890
000502  010366  000006                  MOV     R3,6(SP)                ; S1.TEMP,LBN1                          4891
000506  013700  000114'          17$:    MOV     MAD1,R0                 ;                                       4894
000512  016660  000004  000046          MOV     4(SP),46(R0)            ; LBN0,*
000520  016660  000006  000050          MOV     6(SP),50(R0)            ; LBN1,*                                4895
000526  005737  000112'                  TST     MX2                     ;                                       4897
000532  002405                          BLT     18$
```

```
000534  013700  000116'                        MOV     MAD2,R0                         ;                               4899
000540  016660  000004  000046                 MOV     4(SP),46(R0)                    ; LBN0,*
000546  013700  000116'                 18$:    MOV     MAD2,R0                         ;                               4900
000552  016660  000006  000050                 MOV     6(SP),50(R0)                    ; LBN1,*
000560  016637  000004  001276'                 MOV     4(SP),LBN0.SAVE                 ; LBN0,*                        4902
000566  016637  000006  001300'                 MOV     6(SP),LBN1.SAVE                 ; LBN1,*                        4903
000574  062706  000010                         ADD     #10,SP                          ;                               4720
000600  000207                                 RTS     PC

; Routine Size:  193 words,     Routine Base:  $CODE$ + 14146
; Maximum stack depth per invocation:  11 words


;   4906  1
```

```
;    4907  1      !!ZZZ routine QIO_SIZE : novalue =
;    4908  1      GLOBAL ROUTINE QIO_SIZE : NOVALUE =
;    4909  1
;    4910  1      !+
;    4911  1      !       THIS ROUTINE IS CALLED BY QIO_GEN TO SELECT THE I/O TRANSFER BYTE COUNT
;    4912  1      !       TO BE USED FOR THE CURRENT QIO OR QIO PAIR.  THE BYTE COUNT IS
;    4913  1      !       DETERMINED BY A RANDOM NUMBER, AND WILL ALWAYS FALL BETWEEN 1 AND THE
;    4914  1      !       I/O BUFFER SIZE (BYTS_PER_QIO).  It is assumed that BYTS_PER_QIO will
;    4915  1      !       never be larger than one binary word or  65000 bytes.
;    4916  1      !
;    4917  1      !       IMPLICIT OUTPUTS:
;    4918  1      !               THE BYTE COUNT IS LOADED INTO ONE OR BOTH MSCP PACKETS.
;    4919  1      !-
;    4920  1
;    4921  2          begin
;    4922  2
;    4923  2          local
;    4924  2              SIZE : word,                                                    ! BYTE COUNT
;    4925  2              BLOCKS_LEFT : word;                                             ! REMAINING BLOCKS LEFT
;    4926  2
;    4927  2          SIZE = ((.RANDOM [4] and %o'077777') mod (.BYTS_PER_QIO + 1)) and %o'177760';!GET BYTE COUNT FROM RANDOM NUMBER
;    4928  2
;    4929  2          if .SIZE eql 0
;    4930  2          then
;    4931  2              SIZE = 16;
;    4932  2
;    4933  2          if .CST_ADDR [.CUOFF + 4, D_END1] gtru .MAD1 [LBN_H]
;    4934  2          then BLOCKS_LEFT = %o'177777'                                           ! find
;    4935  2          else BLOCKS_LEFT = .CST_ADDR [.CUOFF + 3, D_END0] - .MAD1 [LBN_L] + 1;  ! REMAINING BLOCK COUNT
;    4936  2
;    4937  2          if ((.SIZE + BYTES_PER_SECT - 1) / BYTES_PER_SECT) gtru .BLOCKS_LEFT    ! IF BLOCK COUNT NOT ENOUGH
;    4938  2          then
;    4939  2              SIZE = .BLOCKS_LEFT * BYTES_PER_SECT;                               ! ADJUST BYTE COUNT DOWN
;    4940  2
;    4941  2          MAD1 [BC_LO] = .SIZE;                                                   ! LOAD SIZE INTO 1ST MSCP PACKET
;    4942  2
;    4943  2          if .MX2 geq 0                                                           ! IF 2 QIOS
;    4944  2          then
;    4945  2              MAD2 [BC_LO] = .SIZE;                                               ! LOAD SIZE INTO 2ND MSCP PACKET
;    4946  2
;    4947  1          end;                                                                    ! ROUTINE QIO_SIZE


                                        .SBTTL  QIO.SIZE MULTI-DRIVE TEST ROUTINES
000000  004137  000000G          QIO.SIZE::
                                        JSR     R1,$SAVE3                       ;                                       4908
000004  013746  000010G                 MOV     RANDOM+10,-(SP)                 ;                                       4927
000010  042716  100000                  BIC     #100000,(SP)
000014  013746  000000G                 MOV     BYTS.PER.QIO,-(SP)
000020  005216                          INC     (SP)
000022  004737  000000G                 JSR     PC,BL$MOD
000026  010003                          MOV     R0,R3                           ; *,SIZE
000030  042703  000017                  BIC     #17,R3                          ; *,SIZE
```

```
000034  001002                          BNE     1$                      ;                               4929
000036  012703  000020                  MOV     #20,R3                  ; *,SIZE                        4931
000042  013700  000000G           1$:    MOV     CUOFF,R0                ;                               4933
000046  006300                          ASL     R0
000050  063700  000000G                  ADD     CST.ADDR,R0
000054  013701  000114'                  MOV     MAD1,R1
000060  026061  000010  000050          CMP     10(R0),50(R1)
000066  101403                          BLOS    2$
000070  012702  177777                  MOV     #-1,R2                  ; *,BLOCKS.LEFT                 4934
000074  000413                          BR      3$                      ;                               4933
000076  013700  000000G           2$:    MOV     CUOFF,R0                ;                               4935
000102  006300                          ASL     R0
000104  063700  000000G                  ADD     CST.ADDR,R0
000110  016000  000006                  MOV     6(R0),R0
000114  166100  000046                  SUB     46(R1),R0
000120  010002                          MOV     R0,R2                   ; *,BLOCKS.LEFT
000122  005202                          INC     R2                      ; BLOCKS.LEFT
000124  010316                  3$:     MOV     R3,(SP)                 ; SIZE,*                        4937
000126  062716  C00777                  ADD     #777,(SP)
000132  012746  001000                  MOV     #1000,-(SP)
000136  004737  000000G                  JSR     PC,BL$DIV
000142  005726                          TST     (SP)+
000144  020002                          CMP     R0,R2                   ; *,BLOCKS.LEFT
000146  101405                          BLOS    4$
000150  010200                          MOV     R2,R0                   ; BLOCKS.LEFT,*                 4939
000152  000300                          SWAB    R0
000154  105000                          CLRB    R0
000156  006300                          ASL     R0
000160  010003                          MOV     R0,R3                   ; *,SIZE
000162  010361  000026           4$:    MOV     R3,26(R1)               ; SIZE,*                        4941
000166  005737  000112'                  TST     MX2                     ;                               4943
000172  002404                          BLT     5$
000174  013700  000116'                  MOV     MAD2,R0                 ;                               4945
000200  010360  000026                  MOV     R3,26(R0)               ; SIZE,*
000204  022626                  5$:     CMP     (SP)+,(SP)+             ;                               4921
000206  000207                          RTS     PC                      ;                               4908

; Routine Size:  68 words,      Routine Base:  $CODE$ + 14750
; Maximum stack depth per invocation:  8 words
```

```
;  4948  1     GLOBAL routine FILL_BUFF : novalue =
;  4949  1
;  4950  1     !+
;  4951  1     !       THIS ROUTINE IS CALLED BY QIO_GEN TO LOAD THE I/O BUFFER DESCRIBED IN
;  4952  1     !       THE FIRST MSCP PACKET WITH THE APPROPRIATE DATA PATTERN.
;  4953  1     !
;  4954  1     !       THE DATA PATTERN TO BE SELECTED IS BASED ON THE FOLLOWING ALGORITHM:
;  4955  1     !
;  4956  1     !               IF THE OPERATOR DEFINED A DATA PATTERN
;  4957  1     !               THEN
;  4958  1     !                       SELECT IT
;  4959  1     !               ELSE
;  4960  1     !                       GET DATA PATTERN NUMBER FROM SW P-TABLE
;  4961  1     !                       IF DATA PATTERN NUMBER = 0
;  4962  1     !                       THEN
;  4963  1     !                               GET DATA PATTERN NUMBER FROM THE UNIT'S ENTRY
;  4964  1     !                               IN THE DATA PATTERN SEQUENCE TABLE (DPST)
;  4965  1     !
;  4966  1     !       NOTE THAT PATTERN # 1 CONSISTS OF RANDOM NUMBERS, AND PATTERNS # 17 -
;  4967  1     !       21 USE THE ACTUAL LBN OF THE WRITE REQUEST
;  4968  1     !
;  4969  1     !       IMPLICIT INPUTS:
;  4970  1     !               L$LUN - CURRENT (DRS) UNIT NUMBER
;  4971  1     !-
;  4972  1
;  4973  2         begin
;  4974  2
;  4975  2         local
;  4976  2             DP_NUM : word,                              ! DATA PATTERN NUMBER SELECTED
;  4977  2             DP_ADDR,                                    ! ADDR OF DATA PATTERN (LENGTH)
;  4978  2             IOB_ADDR,                                   ! I/O BUFFER ADDRESS (DESTINATION)
;  4979  2             SRC_ADDR,                                   ! WORKING SOURCE ADDRESS
;  4980  2             COUNT : word,                               ! NO. OF WORDS IN DATA PATTERN
;  4981  2             CUR_PRIORITY : word;                        ! MMM
;  4982  2
;  4983  3         if BIT_TST (SWP_FLAGS, SWF_UDP)                 ! IF USER DEFINED A DATA PATTERN
;  4984  2         then
;  4985  2             DP_ADDR = SWP_UCNT                          ! SELECT IT
;  4986  2         else
;  4987  3             begin
;  4988  3
;  4989  3             if .SWP_DPAT neq 0                          ! IF USER SELECTED A PRE-DEFINED DATA PATTERN
;  4990  3             then
;  4991  3                 DP_NUM = .SWP_DPAT                      ! SELECT IT
;  4992  3             else
;  4993  4                 begin
;  4994  4                 DP_NUM = .DPST [.L$LUN];                ! GET PATTERN NUMBER FROM SEQUENCE TABLE
;  4995  4                 DPST [.L$LUN] = .DPST [.L$LUN] + 1;     ! ADVANCE TO NEXT PATTERN NUMBER
;  4996  4
;  4997  4                 if .DPST [.L$LUN] gtru DP_CNT           ! CHECK FOR HIGH LIMIT
;  4998  4                 then
;  4999  4                     DPST [.L$LUN] = 1;
;  5000  4
```

```
;    5001  3                end;
;    5002  3
;    5003  3            DP_ADDR = .DPA_TBL [.DP_NUM - 1];              ! ADDRESS OF DATA PATTERN (COUNT)
;    5004  3
;    5005  3            if .DP NUM gequ 17
;    5006  3            then
;    5007  3
;    5008  3                if .DP_NUM                                 ! CHECK MACRO (IF PATTERN 17, 19, OR 21)
;    5009  3                then
;    5010  3                    (.DP ADDR + 2) = .MAD1 [LBN_L]         ! LOAD LBN INTO FIRST WORD OF PATTERN
;    5011  3                else
;    5012  3                    (.DP_ADDR + 4) = .MAD1 [LBN_L];        ! LOAD LBN INTO SECOND WORD OF PATTERN
;    5013  3
;    5014  2            end;
;    5015  2
;    5016  2        IOB_ADDR = .MAD1 [BUF_0];                          ! I/O BUFFER ADDRESS
;    5017  2        COUNT = ..DP_ADDR;                                 ! NO. OF WORDS IN DATA PATTERN
;    5018  2        SRC_ADDR = .DP_ADDR + 2;                           ! START OF THE ACTUAL DATA PATTERN
;    5019  2
;    5020  2        incr N from 1 to ((.MAD1 [BC_LO] + 1) / 2) do      ! FOR EACH WORD IN THIS WRITE REQUEST
;    5021  3            begin
;    5022  3            .IOB_ADDR = ..SRC_ADDR;                        ! MOVE 1 WORD
;    5023  3            IOB_ADDR = .IOB_ADDR + 2;                      ! ADVANCE DESTINATION ADDRESS
;    5024  3            SRC_ADDR = .SRC_ADDR + 2;                      ! ADVANCE SOURCE ADDRESS
;    5025  3            COUNT = .COUNT - 1;                            ! DECREMENT COUNT
;    5026  3
;    5027  3            if .COUNT eql 0                                ! IF END OF DATA PATTERN
;    5028  3            then
;    5029  4                begin
;    5030  4                COUNT = ..DP_ADDR;                         ! REPEAT DATA PATTERN
;    5031  4                SRC_ADDR = .DP_ADDR + 2;
;    5032  3                end;
;    5033  3
;    5034  2            end;                                           ! WORD TRANSFER LOOP
;    5035  2
;    5036  2    !     if (.CSR_MEM and .TST_PAR)                                          ! MMM
;    5037  2    !     then                                                                ! MMM
;    5038  2    !        if not .PAR_TSD                                                  ! MMM
;    5039  2    !        then                                                             ! MMM
;    5040  2    !           begin
;    5041  2    !           GETPRI(CUR_PRIORITY);                                        ! MMM
;    5042  2    !           SETPRI(PRIO7);                                               ! MMM
;    5043  2    !           IOB_ADDR = .MAD1 [BUF_0];                                    ! I/O BUFFER ADDRESS MMM
;    5044  2    !           incr COUNT from 1 to 2 do                                    ! MMM
;    5045  2    !              begin                                                     ! MMM
;    5046  2    !              %o'172100' = %o'5';                                       ! MMM
;    5047  2    !              end;                                                      ! MMM
;    5048  2    !           .IOB_ADDR = %o'2';                                           ! MOVE 1 WORD MMM
;    5049  2    !           %o'172100' = %o'1';                                          ! MMM
;    5050  2    !           SETPRI(.CUR_PRIORITY);                                       ! MMM
;    5051  2    !           end;                                                         ! MMM
;    5052  2
;    5053  1        end;                                               ! ROUTINE FILL_BUFF
```

```
                                        .SBTTL  FILL.BUFF MULTI-DRIVE TEST ROUTINES
000000  004137  000000G               FILL.BUFF::
                                        JSR     R1,$SAVE5                       ;                                       4948
000004  005746                            TST     -(SP)
000006  032737  000100  000000G           BIT     #100,SWP.FLAGS                  ;                                       4983
000014  001403                            BEQ     1$
000016  012701  000000G                   MOV     #SWP.UCNT,R1                    ; *,DP.ADDR                             4985
000022  000443                            BR      5$                              ;                                       4983
000024  013700  000000G           1$:     MOV     SWP.DPAT,R0                     ;                                       4989
000030  001402                            BEQ     2$
000032  010002                            MOV     R0,R2                           ; *,DP.NUM                              4991
000034  000414                            BR      3$                              ;                                       4989
000036  013700  000000G           2$:     MOV     L$LUN,R0                        ;                                       4994
000042  062700  000050'                   ADD     #DPST,R0
000046  005002                            CLR     R2                              ; DP.NUM
000050  151002                            BISB    (R0),R2                         ; *,DP.NUM
000052  105210                            INCB    (R0)                            ;                                       4995
000054  121027  000025                    CMPB    (R0),#25                        ;                                       4997
000060  101402                            BLOS    3$
000062  112710  000001                    MOVB    #1,(R0)                         ;                                       4999
000066  010200                    3$:     MOV     R2,R0                           ; DP.NUM,*                              5003
000070  006300                            ASL     R0
000072  016001  001166'                   MOV     DPA.TBL-2(R0),R1                ; *,DP.ADDR
000076  020227  000021                    CMP     R2,#21                          ; DP.NUM,*                              5005
000102  103413                            BLO     5$
000104  013700  000114'                   MOV     MAD1,R0                         ;                                       5010
000110  006002                            ROR     R2                              ; DP.NUM                                5008
000112  103004                            BCC     4$
000114  016061  000046  000002            MOV     46(R0),2(R1)                    ; *,*(DP.ADDR)                          5010
000122  000403                            BR      5$                              ;                                       5008
000124  016061  000046  000004    4$:     MOV     46(R0),4(R1)                    ; *,*(DP.ADDR)                          5012
000132  013700  000114'            5$:     MOV     MAD1,R0                         ;                                       5016
000136  016004  000032                    MOV     32(R0),R4                       ; *,IOB.ADDR
000142  011103                            MOV     (R1),R3                         ; DP.ADDR,COUNT                         5017
000144  012705  000002                    MOV     #2,R5                           ;                                       5018
000150  060105                            ADD     R1,R5                           ; DP.ADDR,*
000152  010502                            MOV     R5,R2                           ; *,SRC.ADDR
000154  016046  000026                    MOV     26(R0),-(SP)                    ;                                       5020
000160  005216                            INC     (SP)
000162  012746  000002                    MOV     #2,-(SP)
000166  004737  000000G                   JSR     PC,BL$DIV
000172  010066  000004                    MOV     R0,4(SP)
000176  005000                            CLR     R0                              ; N
000200  000405                            BR      7$
000202  012224                    6$:     MOV     (R2)+,(R4)+                     ; SRC.ADDR,IOB.ADDR                     5022
000204  005303                            DEC     R3                              ; COUNT                                 5025
000206  001002                            BNE     7$                              ;                                       5027
000210  011103                            MOV     (R1),R3                         ; DP.ADDR,COUNT                         5030
000212  010502                            MOV     R5,R2                           ; *,SRC.ADDR                            5031
000214  005200                    7$:     INC     R0                              ; N                                     5020
000216  020066  000004                    CMP     R0,4(SP)                        ; N,*
```

```
000222  003767                          BLE     6$
000224  062706  000006                  ADD     #6,SP                   ;                               4948
000230  000207                          RTS     PC

; Routine Size:  77 words,      Routine Base:  $CODE$ + 15160
; Maximum stack depth per invocation:  10 words


;   5054  1
;   5055  1
```

```
;    5056  1      GLOBAL ROUTINE PROC_RETPKT : NOVALUE =
;    5057  1
;    5058  1      !+
;    5059  1      !       THIS ROUTINE IS CALLED FROM THE MULTI_DRIVE "EXECUTIVE" AND DUP_COMMAND TO CHECK FOR
;    5060  1      !       AND PROCESS ANY RETURN PACKETS THAT HAVE BEEN "SENT" BY THE "DRIVER"
;    5061  1      !       PORTION OF THE PROGRAM. THE I/O DONE QUEUE (IODQ) ACTS AS THE LINK
;    5062  1      !       BETWEEN THE TWO PROGRAM PARTS; IT HOLDS INDECES OF RETURN PACKETS WHICH
;    5063  1      !       REQUIRE PROCESSING.
;    5064  1      !
;    5065  1      !       UNDER THE MULTI-DRIVE TEST, RETURN PACKETS ORIGINATE FROM THREE SOURCES:
;    5066  1      !               1. MSCP           THE MORE COMMON, DESCRIBING A COMPLETED I/O
;    5067  1      !                                 OPERATION.
;    5068  1      !MMM!           2. DUP            - THE LESS COMMON, DESCRIBING A PORTION OF I/O
;    5069  1      !                                 COMMUNICATIONS WITH THE CONTROLLER PROGRAM.
;    5070  1      !               3. THE PROGRAM "DRIVER" - DESCRIBING A CONTROLLER ERROR OR
;    5071  1      !                                 COMMAND TIMEOUT.
;    5072  1      !-
;    5073  1
;    5074  1          while .IODQ_IN neq .IODQ_OUT do                          ! DO UNTIL I/O DONE QUEUE IS EMPTY
;    5075  2          begin
;    5076  2          RP_INDX = OUT_IODQ ();                                   ! GET INDEX OF NEXT RETPKT AND ADVANCE OUT POINTER
;    5077  2          RP_ADDR = RETPKT + (.RP_INDX * RP_LEN * 2);              ! CALCULATE RETPKT ADDRESS
;    5078  3          if NOT (.RP_ADDR [CONID] eql CID_DUP)                    ! if not DUP then
;    5079  2          then (SET_CPAR (.RP_ADDR [CTLR]););                      ! SET UP CURRENT CONTROLLER PARAMETERS
;    5080  2
;    5081  2          selectoneu .RP_ADDR [CONID] of                           ! CONNECTION ID INDICATES PACKET SOURCE
;    5082  2              set
;    5083  2
;    5084  2              [CID_MSCP] :        IO_RETPKT ();                    ! DISK MSCP (I/O TRANSFER DONE)
;    5085  2      !MMM                [CID_DUP] :         DIO_RETPKT ();               ! DUP (I/O TRANSFER DONE)
;    5086  2              [CID_DRIVER] :      DR_RETPKT ();                    ! MESSAGE FROM "DRIVER"
;    5087  2
;    5088  2              [otherwise] :       PRINTF (DBM12, .RP_ADDR [CONID]);!"CONN ID = XXXXX RECEIVED"
;    5089  2              tes;
;    5090  2
;    5091  1          end;                                                     ! UNITL I/O DONE QUEUE IS EMPTY


                                        .SBTTL  PROC.RETPKT MULTI-DRIVE TEST ROUTINES
000000  010146                    PROC.RETPKT::
                                        MOV     R1,-(SP)                         ;                                       5056
000002  023737  000000G 000000G  1$:     CMP     IODQ.IN,IODQ.OUT                 ;                                       5074
000010  001461                          BEQ     6$
000012  004737  000000G                 JSR     PC,OUT.IODQ                      ;                                       5076
000016  010037  000000G                 MOV     R0,RP.INDX
000022  010046                          MOV     R0,-(SP)                         ; RP.INDX,*                             5077
000024  012746  000054                  MOV     #54,-(SP)
000030  004737  000000G                 JSR     PC,$$MUL
000034  062700  000000G                 ADD     #RETPKT,R0
000040  010037  000000G                 MOV     R0,RP.ADDR
000044  126027  000003  000002         CMPB    3(R0),#2                         ;                                       5078
000052  001406                          BEQ     2$
000054  116016  000002                  MOVB    2(R0),(SP)                       ;                                       5079
```

```
000060  042716  177760                          BIC     #177760,(SP)
000064  004737  000000G                         JSR     PC,SET.CPAR
000070  013700  000000G             2$:         MOV     RP.ADDR,R0              ;                       5081
000074  005001                                  CLR     R1
000076  156001  000003                          BISB    3(R0),R1
000102  005701                                  TST     R1                      ;                       5084
000104  001003                                  BNE     3$
000106  004737  000000V                         JSR     PC,IO.RETPKT
000112  000416                                  BR      5$                      ;                       5081
000114  020127  000003              3$:         CMP     R1,#3                   ;                       5086
000120  001003                                  BNE     4$
000122  004737  000000V                         JSR     PC,DR.RETPKT
000126  000410                                  BR      5$                      ;                       5081
000130  010116              4$:         MOV     R1,(SP)                 ;                       5088
000132  012746  000000G                         MOV     #DBM12,-(SP)
000136  012746  000002                          MOV     #2,-(SP)
000142  010600                                  MOV     SP,R0                   ; SP,R
000144  104417                                  TRAP    17
000146  022626                                  CMP     (SP)+,(SP)+
000150  022626              5$:         CMP     (SP)+,(SP)+             ;                       5075
000152  000713                                  BR      1$                      ;                       5074
000154  012601              6$:         MOV     (SP)+,R1                ;                       5056
000156  000207                                  RTS     PC

; Routine Size:  56 words,      Routine Base:  $CODE$ + 15412
; Maximum stack depth per invocation:  7 words
```

```
;    5092  1        .MMM
;    5093  1        !GLOBAL ROUTINE DIO_RETPKT : NOVALUE =
;    5094  1
;    5095  1        !+
;    5096  1        !       THIS ROUTINE IS CALLED BY PROC_RETPKT TO HANDLE ALL DUP I/O TRANSFER
;    5097  1        !       RETURN PACKETS. PROCESSING OF THESE PACKETS INCLUDES DECLARING ANY
;    5098  1        !       HARD ERRORS THAT MAY HAVE OCCURRED, UPDATING THE STATISTICS.
;    5099  1        !
;    5100  1        !       IMPLICIT INPUTS:
;    5101  1        !               RP_ADDR - ADDRESS OF THE CURRENT RETURN PACKET
;    5102  1        !               T_ADDR - ADDRESS OF THE CURRENT UNIT'S STATISTICS BLOCK (TALLY)
;    5103  1        !               CST_ADDR - ADDRESS OF THE CURRENT CONTROLLER'S CST
;    5104  1        !               DUOFF - CST OFFSET FOR THE CURRENT UNIT
;    5105  1        !               L$LUN - CURRENT UNIT NUMBER
;    5106  1        !               CCTLR - CURRENT CONTROLLER NUMBER
;    5107  1        !
;    5108  1        !       IMPLICIT OUTPUTS
;    5109  1        !               CST_ADDR [.DUOFF + OF_DBN, NODUPMEDIA] - IF THIS BIT SET NO DUP EXERCISER
;    5110  1        !
;    5111  1        !-
;    5112  1        !BEGIN
;    5113  1
;    5114  1        !LOCAL  FLAG : BYTE INITIAL(BYTE(TRUE)),
;    5115  1        !        SUM2 : WORD,
;    5116  1        !        SUM : WORD;                                    ! TOTAL NUMBER OF BYTES TRANSFERRED TO/FROM A UNIT
;    5117  1        !PRINTX (DER18);
;    5118  1
;    5119  1        !IF .RP_ADDR [STATUS] NEQU ST_SUC                              ! IF STATUS CODE INDICATES ERROR
;    5120  1        !THEN
;    5121  1        !       BEGIN
;    5122  1        !       CST_ADDR [.DUOFF + OF_DBN, DUPERROR] = 1;              ! SET DUP ERROR FLAG
;    5123  1        !       HARD_ERROR ();
;    5124  1        !       IF .RP_ADDR [ENDCOD] EQLU (OP_ELP + OP_END) OR  ! IF ENDCODE IS EXECUTE LOCAL PROGRAM
;    5125  1        !          .RP_ADDR [ENDCOD] EQLU (OP_GDS + OP_END)     !             OR GET DUST STATUS
;    5126  1        !       THEN    BEGIN
;    5127  1        !               CST_ADDR [.DUOFF + OF_DBN, NODUPMEDIA] = 1;                    ! TURN OFF DUP EXERCISR
;    5128  1        !               END;
;    5129  1        !       END
;    5130  1        !ELSE                                          ! ELSE - I/O WAS SUCCESSFUL
;    5131  1        !    BEGIN
;    5132  1        !
;    5133  1        !    IF .RP_ADDR [ENDCOD] EQLU (OP_GDS + OP_END)       ! IF ENDCODE IS GET DUST STATUS
;    5134  1        !    THEN
;    5135  1        !       BEGIN
;    5136  1        !       IF .RP_ADDR [9,11,1,0] EQL 1
;    5137  1        !               THEN CST_ADDR [.DUOFF + OF_DBN, D_ACTIVE] = ACTIVE             ! CONTROLLER IN AN ACTIVE STAE
;    5138  1        !               ELSE CST_ADDR [.DUOFF + OF_DBN, D_ACTIVE] = IDLE;              ! CONTROLLER IN AN IDLE STATE
;    5139  1        !       IF .RP_ADDR [9,9,1,0] NEQ 1 THEN       ! TEST TO SEE IF CONTROLLER LOCAL PROGRAMS(PG 18 OF DUP DOC)
;    5140  1        !               BEGIN
;    5141  1        !               HARD_ERROR ();
;    5142  1        !               CST_ADDR [.DUOFF + OF_DBN, NODUPMEDIA] = 1;                    ! TURN OFF DUP EXERCISR
;    5143  1        !               END;
;    5144  1        !       END;
```

```
;    5145  1      !
;    5146  1      !
;    5147  1      !IF (.RP_ADDR [ENDCOD] EQL (OP_RCD + OP_END)) AND
;    5148  1      !   (.DUPPKT [DUPTYPE] EQL 6) AND
;    5149  1      !   (.DUPPKT [DUPMESG] EQL 2) AND                 !IF IT IS A RECEIVE DBN COMMAND WITH TYPE 6 AND MESSAGE 2 THEN
;    5150  1      !   (.CST_ADDR [.DUOFF + OF_DBN, DUPWRITE] EQLU 1)      ! IF WRITE FLAG SET IN CST TABLE THEN COMPARE BLOCKS
;    5151  1      !       THEN DUP_COMPARE ();
;    5152  1      !
;    5153  1      !END;                                               ! COMPARE THE FOLLOWING 512 BYTES
;    5154  1      !
;    5155  1      !PUT_RETPKT (.RP_INDX);
;    5156  1      !END;                                               ! ROUTINE DIO_RETPKT
;    5157  1
```

```
;    5158  1      !MMMGLOBAL ROUTINE DUP COMPARE : NOVALUE =
;    5159  1
;    5160  1
;    5161  1      !+
;    5162  1      !       THIS ROUTINE IS CALLED BY DIO_RETPKT WHEN THE RECEIVE DATA COMMAND
;    5163  1      !       IS BEING PROCESSED. THIS COMMAND COMPARES THE WRITTEN BUFFER WITH
;    5164  1      !       THE PATERN WORD GIVEN IN SEND DATA COMMAND.  FOR EVERY WORD COMPARED
;    5165  1      !       THE ROUTINE INCREMENTS THE TALLY TABLE.  IF THE COMPARE SHOWS AN
;    5166  1      !       ERROR, THE DBN HARD ERROR COUNTER WILL BE INCREMENTED AND THE
;    5167  1      !       THE DBN NUMBER AND BYTE COUNT WILL BE PRINTED.
;    5168  1      !
;    5169  1      !       IMPLICIT INPUTS:
;    5170  1      !               S_PATTERN       ! THE SAVED PATTERN WRITTEN TO THE DBN'S
;    5171  1      !               S_DUPPKT        ! THE POINTER FOR DUP BUFFER
;    5172  1      !               T_ADDR          ! THE ADDRESS OF THE TALLY TABLE FOR THIS UNIT
;    5173  1      !               CST_ADDR        ! THE ADDRESS OF PRESENT CONTROLLER STATUS TABLE
;    5174  1      !-
;    5175  1      !BEGIN
;    5176  1      !
;    5177  1      !OWN
;    5178  1      !       COUNT : WORD;
;    5179  1      !
;    5180  1      !!PRINTX (DER19);
;    5181  1      !S_DUPPKT = 0;
;    5182  1      !INCR COUNT FROM 1 TO 256 DO    !INDEX PIONTER FOR DATA STORED IN MSCP ENV PACKET
;    5183  1      !       BEGIN
;    5184  1      !       S_DUPPKT = .S_DUPPKT + 2;                               ! INITIALLY THIS SKIPS THE FIRST WORD OF DUPPKT
;    5185  1      !       IF .(DUPPKT + .S_DUPPKT) NEQ .S_PATTERN THEN            !IF THE CONTENTS OF DBN DOESN T EQUAL PATTERN
;    5186  1      !               BEGIN
;    5187  1      !               CST_ADDR [.DUOFF + OF_DBN, DUPERROR] = 1;               ! SET DUP ERROR FLAG
;    5188  1      !               ERRHRD (46, EH_10, EMS 22);                     !LIST ERROR
;    5189  1      !               EXITLOOP;
;    5190  1      !               END;
;    5191  1      !       END;                                            !GO THROUGH ALL DBN WORDS
;    5192  1      !END;                                                   !END ROUTINE DUP-COMPARE
;    5193  1
;    5194  1
;    5195  1
```

```
;    5196  1     GLOBAL routine IG_RETPKT : novalue =
;    5197  1
;    5198  1     !+
;    5199  1     !       THIS ROUTINE IS CALLED BY PROC_RETPKT TO HANDLE ALL I/O TRANSFER
;    5200  1     !       RETURN PACKETS. PROCESSING OF THESE PACKETS INCLUDES DECLARING ANY
;    5201  1     !       HARD ERRORS THAT MAY HAVE OCCURRED, UPDATING THE STATISTICS, AND
;    5202  1     !       PERFORMING HOST WRITE-COMPARES IF REQUIRED.
;    5203  1     !
;    5204  1     !       IMPLICIT INPUTS:
;    5205  1     !               CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
;    5206  1     !               RP_ADDR - ADDRESS OF THE CURRENT RETURN PACKET
;    5207  1     !               T_ADDR - ADDRESS OF CURRENT UNIT'S STATISTICS BLOCK (TALLY)
;    5208  1     !               CCTLR - CURRENT CONTROLLER NUMBER
;    5209  1     !               L$LUN   CURRENT UNIT NUMBER
;    5210  1     !-
;    5211  1
;    5212  2         begin
;    5213  2
;    5214  2         local
;    5215  2             FLAG : byte initial (byte (TRUE));
;    5216  2
;    5217  2         FSET_UPAR ();                               ! FIND UNIT'S ENTRY IS CST AND SET UP UNIT RELATED DATA
;    5218  2         ST_CODE =  RP_ADDR [STSCOD];                ! GET STATUS CODE FROM RETPKT
;    5219  2         SB_CODE = .RP_ADDR [SUBCOD];                ! GET SUB-CODE, IF ANY
;    5220  2
;    5221  3         if (.ST_CODE neq ST_SUC)                    ! IF STATUS CODE INDICATES ERROR
;    5222  2         then
;    5223  3             begin
;    5224  3             HARD_ERROR ();                          ! UPDATE ERROR COUNT
;    5225  3             COMPARE_DATA = FALSE;                   ! NO POINT IN DOING HOST COMPARES ON ERRORS
;    5226  3
;    5227  3             if (.ST_CODE neq ST_OFL) and            ! DROP UNIT IF ERROR COUNTS EXCEEDS LIMIT
;    5228  3                (.ST_CODE neq ST_AVL) and
;    5229  4                (.T_ADDR [ERR_HARD] gequ .SWP_ERROR)
;    5230  3             then
;    5231  4                 begin
;    5232  4                 DUR [.L$LUN] = DU_HERR;             ! LOAD REASON FOR DROPPING UNIT
;    5233  4                 DODU (.L$LUN);                      ! DROP UNIT
;    5234  3                 end;
;    5235  3
;    5236  3             end
;    5237  2         else                                        ! IF I/O WAS SUCCESSFUL
;    5238  3             begin
;    5239  3             UPD_IO_TALLY ();                        ! UPDATE I/O TALLY (STATISTICS)
;    5240  3
;    5241  4             if .RP_ADDR [ENDCOD] eql (OP_WRT or OP_END)
;    5242  3             then
;    5243  3                 COMPARE_DATA = TRUE;                ! HOST COMPARES MAY BE ALLOWED IF NO FURTHER ERRORS
;    5244  3
;    5245  3             if (BIT_TST (SWP_FLAGS, SWF_HWC)) and   ! IF HOST IS DOING WRITE-COMPARES
;    5246  4                (.COMPARE_DATA)
;    5247  3             then
;    5248  3                 FLAG = HOST_WRT_CHK ();             ! SAVE I/O PACKET OR DO WRITE CHECK
```

```
;    5249  3
;    5250  2              end;
;    5251  2
;    5252  2          if .FLAG                                ! IF FLAG IS STILL TRUE
;    5253  2          then
;    5254  2              SWEEP ();                           ! DEALLOCATE BUFFER(S) AND RETPKT(S)
;    5255  2
;    5256  2          QIO [.CCTLR] = .QIO [.CCTLR] - 1;       ! DECREMENT NO. OF OUTSTANDING QIOs
;    5257  1          end;                                    ! ROUTINE IO.RETPKT


                                        .SBTTL  IO.RETPKT MULTI-DRIVE TEST ROUTINES
000000  004137  000000G          IO.RETPKT::
                                        JSR     R1,$SAVE2                       ;                       5196
000004  112701  000001                  MOVB    #1,R1                           ; *,FLAG                5212
000010  004737  000000V                  JSR     PC,FSET.UPAR                    ;                       5217
000014  013700  000000G                  MOV     RP.ADDR,R0                      ;                       5218
000020  116037  000016  000000G          MOVB    16(R0),ST.CODE
000026  042737  177740  000000G          BIC     #177740,ST.CODE
000034  016002  000016                  MOV     16(R0),R2                       ;                       5219
000040  006202                          ASR     R2
000042  006202                          ASR     R2
000044  006202                          ASR     R2
000046  006202                          ASR     R2
000050  006202                          ASR     R2
000052  042702  174000                  BIC     #174000,R2
000056  010237  000000G                  MOV     R2,SB.CODE
000062  005737  000000G                  TST     ST.CODE                         ;                       5221
000066  001431                          BEQ     1$
000070  004737  000000V                  JSR     PC,HARD.ERROR                   ;                       5224
000074  105037  001262'                  CLRB    COMPARE.DATA                    ;                       5225
000100  023727  000000G 000003          CMP     ST.CODE,#3                      ;                       5227
000106  001447                          BEQ     3$
000110  023727  000000G 000004          CMP     ST.CODE,#4                      ;                       5228
000116  001443                          BEQ     3$
000120  013700  000000G                  MOV     T.ADDR,R0                       ;                       5229
000124  026037  000014  000000G          CMP     14(R0),SWP.ERROR
000132  103435                          BLO     3$
000134  013700  000000G                  MOV     L$LUN,R0                        ;                       5232
000140  112760  000004  000000G          MOVB    #4,DVR(R0)
000146  104451                          TRAP    51                              ;                       5233
000150  000426                          BR      3$                              ;                       5221
000152  004737  000000V          1$:     JSR     PC,UPD.IO.TALLY                 ;                       5239
000156  013700  000000G                  MOV     RP.ADDR,R0                      ;                       5241
000162  126027  000014  000242          CMPB    14(R0),#242
000170  001003                          BNE     2$
000172  112737  000001  001262'          MOVB    #1,COMPARE.DATA                 ;                       5243
000200  032737  000040  000000G  2$:     BIT     #40,SWP.FLAGS                   ;                       5245
000206  001407                          BEQ     3$
000210  032737  000001  001262'          BIT     #1,COMPARE.DATA                 ;                       5246
000216  001403                          BEQ     3$
000220  004737  000000V                  JSR     PC,HOST.WRT.CHK                 ;                       5248
000224  110001                          MOVB    R0,R1                           ; *,FLAG
```

```
000226  006001                          3$:     ROR     R1                      ; FLAG                          5252
000230  103002                                  BCC     4$
000232  004737  000000V                         JSR     PC,SWEEP                ;                               5254
000236  013700  000000G                 4$:     MOV     CCTLR,R0                ;                               5256
000242  105360  000000G                         DECB    QIO(R0)
000246  000207                                  RTS     PC                      ;                               5196

; Routine Size:  84 words,      Routine Base:  $CODE$ + 15572
; Maximum stack depth per invocation:  5 words
```

```
;    5258  1     GLOBAL routine FSET_UPAR : novalue =
;    5259  1
;    5260  1     !+
;    5261  1     !       THIS ROUTINE IS CALLED BY IO_RETPKT AND OTHERS TO SEARCH THE CURRENT
;    5262  1     !       CONTROLLER STATUS TABLE (CST) FOR THE DISK ADDRESS WHICH IS
;    5263  1     !       CONTAINED IN THE CURRENT RETURN PACKET. WHEN FOUND, THE OFFSET INTO THE
;    5264  1     !       CST IS USED AS INPUT TO SET_UPAR, WHICH SETS UP CURRENT UNIT-RELATED
;    5265  1     !       DATA PARAMETERS.
;    5266  1     !
;    5267  1     !       IMPLICIT INPUTS:
;    5268  1     !               RP_ADDR - ADDRESS OF CURRENT RETURN PACKET
;    5269  1     !               CST_ADDR   ADDRESS OF CURRENT CONTROLLER'S CST
;    5270  1     !-
;    5271  1
;    5272  2         begin
;    5273  2
;    5274  2         incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR   1) * UNIT_SIZE + OF UN) by UNIT_SIZE do  ! FOR EACH UNIT
;    5275  2
;    5276  2             if .CST_ADDR [.OFFSET + OF_DATA, D_DISK_NUM] eql .RP_ADDR [DISK]        ! IF RETPKT UNIT MATCHES CST ENTRY
;    5277  2             then
;    5278  3                 begin
;    5279  3                 SET_UPAR (.OFFSET);                                             ! SET UP UNIT RELATED DATA
;    5280  3                 return;                                                         ! DONE
;    5281  2                 end;
;    5282  2
;    5283  2         PRINTF (DBM19, .RP_ADDR [DISK], .CCTLR);                                ! "CAN'T FIND DISK XXX IN CST X"
;    5284  1         end;                                                                    ! ROUTINE FSET_UPAR


                                        .SBTTL  FSET.UPAR MULTI-DRIVE TEST ROUTINES
000000  004137  000000G          FSET.UPAR::
                                        JSR     R1,$SAVE4                       ;                               5258
000004  012702  000003                  MOV     #3,R2                           ; *,OFFSET                      5274
000010  010201                  1$:     MOV     R2,R1                           ; OFFSET,*                      5276
000012  006301                          ASL     R1
000014  063701  000000G                 ADD     CST.ADDR,R1
000020  013700  000000G                 MOV     RP.ADDR,R0
000024  016004  000010                  MOV     10(R0),R4
000030  111103                          MOVB    (R1),R3
000032  042703  177760                  BIC     #177760,R3
000036  020304                          CMP     R3,R4
000040  001005                          BNE     2$
000042  010246                          MOV     R2,-(SP)                        ; OFFSET,*                      5279
000044  004737  000000G                 JSR     PC,SET.UPAR
000050  005726                          TST     (SP)+                           ;                               5280
000052  000207                          RTS     PC                              ;                               5278
000054  062702  000012          2$:     ADD     #12,R2                          ; *,OFFSET                      5274
000060  020227  000041                  CMP     R2,#41                          ; OFFSET,*
000064  003751                          BLE     1$
000066  013746  000000G                 MOV     CCTLR,-(SP)                     ;                               5283
000072  013700  000000G                 MOV     RP.ADDR,R0
000076  016046  000010                  MOV     10(R0),-(SP)
000102  012746  000000G                 MOV     #DBM19,-(SP)
```

```
000106  012746  000003                        MOV     #3,-(SP)
000112  010600                                MOV     SP,R0                   ; SP,R
000114  104417                                TRAP    17
000116  062706  000010                        ADD     #10,SP                  ;                                       5272
000122  000207                                RTS     PC                      ;                                       5258

; Routine Size:  42 words,      Routine Base:  $CODE$ + 16042
; Maximum stack depth per invocation:  11 words
```

```
;    5285  1      GLOBAL routine HARD_ERROR : novalue =
;    5286  1
;    5287  1      !+
;    5288  1      !       THIS ROUTINE IS CALLED BY IO_RETPKT AND OTHERS TO INCREMENT THE HARD
;    5289  1      !       ERROR STATISTIC FIELD FOR THE CURRENT UNIT. IF THE HARD ERROR COUNT
;    5290  1      !       HAS EXCEEDED THE OPERATOR-SPECIFIED LIMIT, THEN THE UNIT IS DROPPED
;    5291  1      !       FROM TESTING.
;    5292  1      !
;    5293  1      !       IMPLICIT INPUTS:
;    5294  1      !               L$LUN - CURRENT UNIT NUMBER
;    5295  1      !               CST_ADDR - ADDRESS OF CURRENT CONTROLLER'S CST
;    5296  1      !               CUOFF - CST OFFSET FOR CURRENT UNIT
;    5297  1      !               T_ADDR - ADDRESS OF CURRENT UNIT'S STATISTICS BLOCK (TALLY)
;    5298  1      !
;    5299  1
;    5300  2          begin
;    5301  2          T_ADDR [ERR_HARD] = .T_ADDR [ERR_HARD] + 1;                         ! INCREMENT UNIT'S HARD ERROR COUNT
;    5302  2      if .RP_ADDR [CONID] EQL CID_MSCP                                        !FOR MSCP ERRORS    ZZZ
;    5303  2      THEN                                                                    !                   ZZZ
;    5304  2
;    5305  2          selectoneu .ST_CODE of
;    5306  2              set
;    5307  2
;    5308  2              [ST_SUC]:       if .SB_CODE neq 0                           ! SUCCESS WITH NON-ZERO SUB CODE
;    5309  2                              then
;    5310  3                                  begin
;    5311  3
;    5312  3                                  if .SB_CODE eql 4
;    5313  3                                  then
;    5314  3                                      T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1
;    5315  3                                  else
;    5316  3                                      T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
;    5317  3
;    5318  3                                  if .APT_MODE
;    5319  3                                  then
;    5320  3                                      ERR_HRD_RTNE_APT (44)
;    5321  3                                  else
;    5322  3                                      ERR_HRD_RTNE (44);
;    5323  3
;    5324  2                                  end;
;    5325  2
;    5326  3              [ST_CMD]:       begin                                       ! INVALID COMMAND
;    5327  3                              T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
;    5328  3
;    5329  3                              if .APT_MODE
;    5330  3                              then
;    5331  3                                  ERR_HRD_RTNE_APT (31)
;    5332  3                              else
;    5333  3                                  ERR_HRD_RTNE (31);
;    5334  3
;    5335  2                              end;
;    5336  2
;    5337  3              [ST_ABO]:       begin                                       ! COMMAND ABORTED
```

```
;    5338  3                          T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;    5339  3
;    5340  3                          if .APT_MODE
;    5341  3                          then
;    5342  3                              ERR_HRD_RTNE_APT (32)
;    5343  3                          else
;    5344  3                              ERR_HRD_RTNE (32);
;    5345  3
;    5346  2                          end;
;    5347  2
;    5348  3                [ST_OFL] :    begin                                          ! OFFLINE
;    5349  3                          T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;    5350  3
;    5351  3                          if .APT_MODE
;    5352  3                          then
;    5353  4                              begin
;    5354  4                              .MAIL_BOX_TESTNUM = 1;
;    5355  4                              .MAIL_BOX_SUBTST = .CST_ADDR [.CUOFF + OF_DATA, D_DISK_NUM];
;    5356  3                              end;
;    5357  3
;    5358  3                          ERRDF (18, EGD_18, EMS_18);                        !
;    5359  3                          DUR [.L$LUN] = DU_DFATAL;                          ! DEVICE FATAL ERROR
;    5360  3                          DODU (.L$LUN);                                     ! DROP UNIT
;    5361  2                          end;
;    5362  2
;    5363  3                [ ' AVL]:     begin                                          ! WENT TO AVAILABLE STATE
;    5364  3                          T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;    5365  3
;    5366  3                          if .APT_MODE
;    5367  3                          then
;    5368  4                              begin
;    5369  4                              .MAIL_BOX_TESTNUM = 1;
;    5370  4                              .MAIL_BOX_SUBTST = .CST_ADDR [.CUOFF + OF_DATA, D_DISK_NUM];
;    5371  3                              end;
;    5372  3
;    5373  3                          ERRDF (24, EGD_18, EMS_24);                        !
;    5374  3                          DUR [.L$LUN] = DU_DFATAL;                          ! DEVICE FATAL ERROR
;    5375  3                          DODU (.L$LUN);                                     ! DROP UNIT
;    5376  2                          end;
;    5377  2
;    5378  3                [ST_MFE]:     begin                                          ! MEDIA FORMAT ERROR
;    5379  3                          T_ADDR [ERR_HRD_SEK] = .T_ADDR [ERR_HRD_SEK] + 1;
;    5380  3
;    5381  3                          if .APT_MODE
;    5382  3                          then
;    5383  3                              ERR_HRD_RTNE_APT (35)
;    5384  3                          else
;    5385  3                              ERR_HRD_RTNE (35);
;    5386  3
;    5387  2                          end;
;    5388  2
;    5389  3                [ST_WPT]:     begin                                          ! DEVICE WRITE PROTECTED
;    5390  3
```

```
;    5391  3                          if .SB_CODE eql 128
;    5392  3                          then
;    5393  3                              T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1
;    5394  3                          else
;    5395  3                              T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;    5396  3
;    5397  3                          if .APT_MODE
;    5398  3                          then
;    5399  3                              ERR_HRD_RTNE_APT (36)
;    5400  3                          else
;    5401  3                              ERR_HRD_RTNE (36);
;    5402  3
;    5403  2                          end;
;    5404  2
;    5405  3                  [ST_CMP]:       begin                                           ! COMPARE ERROR
;    5406  3                          T_ADDR [ERR_HRD_DAT] = .T_ADDR [ERR_HRD_DAT] + 1;
;    5407  3
;    5408  3                          if .APT_MODE
;    5409  3                          then
;    5410  3                              ERR_HRD_RTNE_APT (37)
;    5411  3                          else
;    5412  3                              ERR_HRD_RTNE (37);
;    5413  3
;    5414  2                          end;
;    5415  2
;    5416  3                  [ST_DAT]:       begin                                           ! DATA ERROR
;    5417  3
;    5418  3                          if .SB_CODE eql 2
;    5419  3                          then
;    5420  3                              T_ADDR [ERR_HRD_SEK] = .T_ADDR [ERR_HRD_SEK] + 1
;    5421  3                          else
;    5422  3                              T_ADDR [ERR_HRD_DAT] = .T_ADDR [ERR_HRD_DAT] + 1;
;    5423  3
;    5424  3                          if (.SB_CODE eql 0) and
;    5425  3                             (not .FORCED_ERROR) and
;    5426  4                             (BIT_TST (SWP_FLAGS, SWF_FER))
;    5427  3                          then
;    5428  4                              begin
;    5429  4                              FORCED_ERROR = TRUE;                                ! BLOCK WITH "FORCED ERROR" FOUND
;    5430  4                              FER0_LBN = .RP_ADDR [LBN_LO];                       !
 ZZZ
;    5431  4                              FER1_LBN = .RP_ADDR [LBN_HI];                       !
 ZZZ
;    5432  4                              FER_BC = .RP_ADDR [CBCNT_LO];                       !
;    5433  3                              end;
;    5434  3
;    5435  3
;    5436  3                          if .APT_MODE
;    5437  3                          then
;    5438  3                              ERR_HRD_RTNE_APT (38)
;    5439  3                          else
;    5440  3                              ERR_HRD_RTNE (38);
;    5441  3
;    5442  2                          end;
;    5443  2
```

```
;  5444  3              [ST_HST]:       begin                                                   ! HOST ACCESS ERROR
;  5445  3                              T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
;  5446  3
;  5447  3                              if .APT_MODE
;  5448  3                              then
;  5449  3                                  ERR_HRD_RTNE_APT (39)
;  5450  3                              else
;  5451  3                                  ERR_HRD_RTNE (39);
;  5452  3
;  5453  2                              end;
;  5454  2
;  5455  3              [ST_CNT]:       begin                                                   ! CONTROLLER ERROR
;  5456  3                              T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;  5457  3
;  5458  3                              if .APT_MODE
;  5459  3                              then
;  5460  3                                  ERR_HRD_RTNE_APT (40)
;  5461  3                              else
;  5462  3                                  ERR_HRD_RTNE (40);
;  5463  3
;  5464  2                              end;
;  5465  2
;  5466  3              [ST_DRV]:       begin                                                   ! DRIVE ERROR
;  5467  3
;  5468  3                              if .SB_CODE eql 3
;  5469  3                              then
;  5470  3                                  T_ADDR [ERR_HRD_SEK] = .T_ADDR [ERR_HRD_SEK] + 1
;  5471  3                              else
;  5472  3                                  T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;  5473  3
;  5474  3                              if .APT_MODE
;  5475  3                              then
;  5476  3                                  ERR_HRD_RTNE_APT (41)
;  5477  3                              else
;  5478  3                                  ERR_HRD_RTNE (41);
;  5479  3
;  5480  2                              end;
;  5481  2
;  5482  3              [ST_DIA]:       begin                                                   ! MESSAGE FROM INTERNAL DIAGNOSTICS
;  5483  3                              T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;  5484  3
;  5485  3                              if .APT_MODE
;  5486  3                              then
;  5487  3                                  ERR_HRD_RTNE_APT (43)
;  5488  3                              else
;  5489  3                                  ERR_HRD_RTNE (43);
;  5490  3
;  5491  2                              end;
;  5492  2
;  5493  3              [otherwise]:    begin                                                   ! PRINT STATUS CODE IF NO MATCH
;  5494  3                              C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR_HRD] + 1;
;  5495  3
;  5496  3                              if .APT_MODE
```

```
;    5497  3                              then
;    5498  3                                  ERR_HRD RTNE_APT (45)
;    5499  3                              else
;    5500  3                                  ERR_HRD_RTNE (45);
;    5501  3
;    5502  2                              end;
;    5503  2
;    5504  2          tes;
;    5505  2
;    5506  2     !MMM;f .RP_ADDR [CONID] EQL CID_DUP                                  !FOR DUP ERRORS                          ZZZ
;    5507  2     !MMMOR .D FAIL EQL 1                                                 !EVEN IF UNRECOGNIZABLE AS SUCH          ZZZ
;    5508  2     !MMMTHEN                                                             !                                        ZZZ
;    5509  2
;    5510  2     !    selectoneu .RP_ADDR [STSCOD] of
;    5511  2     !          SET
;    5512  2     !          [%o'0']            : begin                                ! if status code succesful
;    5513  2     !                               if .RP_ADDR [ENDCOD] EQLU (OP_GDS + OP_END) and ! IF ENDCODE IS GET DUST STATUS
;    5514  2     !                                  .RP_ADDR [9,9,1,0] NEQ 1                    ! TEST TO SEE IF CONTROLLER LOCAL PR
OGRAMS
;    5515  2     !                               then                                           ! (PG 18 OF DUP DOC)
;    5516  2     !                                       BEGIN
;    5517  2     !                                        ERR_HRD_RTNE (60);                    !UNABLE TO LOAD LOCAL CONTROLLER DUP
 MEDIA !ZZZ
;    5518  2     !                                       T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;    5519  2     !                                       END
;    5520  2     !                               else
;    5521  2     !                                       begin
;    5522  2     !                                       if (.DUPPKT [DUPTYPE] eql 5)          ! if fatal error
;    5523  2     !                                       then
;    5524  2     !!ZZZ                                          begin                          !DON'T DROP DEVICE ON DUP ERROR
       ZZZ
;    5525  2     !!ZZZ                                          DUR [.L$LUN] = DU_DFATAL;      !GIVE F.E. A CHANCE TO SEE ERRORS
       ZZZ
;    5526  2     !!ZZZ                                          DODU (.L$LUN);                 ! FATAL DEVICE ERROR DROP UNIT);
       ZZZ
;    5527  2     !!ZZZ                                          end;                           ! SET REASON FOR DROPPING UNIT
       ZZZ
;    5528  2     !                                       selectoneu .DUPPKT [DUPMESG] of
;    5529  2     !                                       SET
;    5530  2     !                                       [%o'1'] : begin
;    5531  2     !                                                 ERR_HRD_RTNE (62);          ! illegal unit number    !ZZZ
;    5532  2     !                                                 T_ADDR                      ADDR [ERR_HRD_HST] + 1;
;    5533  2     !                                                 end;
;    5534  2     !                                       [%o'2'] : begin
;    5535  2     !                                                 ERR_HRD_RTNE (63);          ! illegal relative or pnysical b
lock # !ZZZ
;    5536  2     !                                                 T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
;    5537  2     !                                                 end;
;    5538  2     !                                       [%o'3'] : begin
;    5539  2     !                                                 ERR_HRD_RTNE (64);          ! device error    !ZZZ
;    5540  2     !                                                 T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;    5541  2     !                                                 end;
;    5542  2     !                                       [%o'4'] : begin
;    5543  2     !                                                 ERR_HRD_RTNE (65);          ! zero lenght message    !ZZZ
;    5544  2     !                                                 T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
;    5545  2     !                                                 end;
;    5546  2     !                                       [%o'5'] : begin                                                    !MMM
;    5547  2     !                                                 ERR_HRD_RTNE (64);          ! device error               !MMM
;    5548  2     !                                                 T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;  !MMM
;    5549  2     !                                                 end;                                               !MMM
```

```
;   5550  2     !                                                   [OTHERWISE] : begin
;   5551  2     !                                                           ERR_HRD_RTNE (66);      ! DUP UNKNOWN STATUS CODE   !ZZZ
;   5552  2     !                                                           C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR HR
D] + 1;
;   5553  2     !                                                           end;
;   5554  2     !                                                   tes;
;   5555  2     !                                           end;
;   5556  2     !
;   5557  2     !                                   end;
;   5558  2     !                       [%o'1']         : begin
;   5559  2     !                                   ERR_HRD_RTNE (67);      ! INVALID COMMAND           !ZZZ
;   5560  2     !                                   T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;   5561  2     !                                   end;
;   5562  2     !                       [%o'2']         : begin
;   5563  2     !                                   ERR_HRD_RTNE (68);      ! NO REGION AVAILABLE       !ZZZ
;   5564  2     !                                   T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;   5565  2     !                                   end;
;   5566  2     !                       [%o'3']         : begin
;   5567  2     !                                   ERR_HRD_RTNE (69);          ! NO REGION SUITABLE        !ZZZ
;   5568  2     !                                   T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
;   5569  2     !                                   end;
;   5570  2     !                       [%o'4']         : begin
;   5571  2     !                                   ERR_HRD_RTNE (70);      ! PROGRAM NOT KNOWN         !ZZZ
;   5572  2     !                                   T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
;   5573  2     !                                   end;
;   5574  2     !                       [%o'5']         : begin
;   5575  2     !                                   ERR_HRD_RTNE (71);          ! LOAD FAILURE              !ZZZ
;   5576  2     !                                   T_ADDR [ERR_HRD_DRV] = .T_ADDR [ERR_HRD_DRV] + 1;
;   5577  2     !                                   end;
;   5578  2     !                       [%o'6']         : begin
;   5579  2     !                                   ERR_HRD_RTNE (72);          ! STANDALONE                !ZZZ
;   5580  2     !                                   T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
;   5581  2     !                                   end;
;   5582  2     !                       [OTHERWISE] : begin
;   5583  2     !                                   ERR_HRD_RTNE (73);          ! DUP UNKNOWN STATUS CODE   !ZZZ
;   5584  2     !                                   C_ERR_TBL [.CCTLR, C_ERR_HRD] = .C_ERR_TBL [.CCTLR, C_ERR_HRD] + 1;
;   5585  2     !                                   end;
;   5586  2     !MMM                TES;
;   5587  2
;   5588  1         end;                                                                    ! ROUTINE HARD_ERROR


                                            .SBTTL  HARD.ERROR MULTI-DRIVE TEST ROUTINES
000000  004137  000000G                 HARD.ERROR::
                                            JSR     R1,$SAVE4                       ;                                       5285
000004  013701  000000G                             MOV     T.ADDR,R1               ;                                       5301
000010  005261  000014                              INC     14(R1)
000014  013703  000000G                             MOV     RP.ADDR,R3              ;                                       5302
000020  105763  000003                              TSTB    3(R3)
000024  001401                                      BEQ     2$
000026  000207                        1$:         RTS     PC
000030  013702  000000G                 2$:         MOV     ST.CODE,R2              ;                                       5305
000034  001027                                      BNE     6$                      ;                                       5308
000036  013704  000000G                             MOV     SB.CODE,R4
```

```
000042  001771                          BEQ     1$
000044  012700  000050                  MOV     #50,R0                  ;                       5314
000050  060100                          ADD     R1,R0
000052  020427  000004                  CMP     R4,#4                   ;                       5312
000056  001002                          BNE     3$
000060  105210                          INCB    (R0)                    ;                       5314
000062  000402                          BR      4$                      ;                       5312
000064  105260  000001          3$:     INCB    1(R0)                   ;                       5316
000070  032737  000001  001254'  4$:     BIT     #1,APT.MODE             ;                       5318
000076  001403                          BEQ     5$
000100  012746  000054                  MOV     #54,-(SP)               ;                       5320
000104  000556                          BR      15$
000106  012746  000054          5$:     MOV     #54,-(SP)               ;                       5322
000112  000556                          BR      17$
000114  020227  000001          6$:     CMP     R2,#1                   ;                       5326
000120  001014                          BNE     8$
000122  105261  000051                  INCB    51(R1)                  ;                       5327
000126  032737  000001  001254'        BIT     #1,APT.MODE             ;                       5329
000134  001403                          BEQ     7$
000136  012746  000037                  MOV     #37,-(SP)               ;                       5331
000142  000567                          BR      21$
000144  012746  000037          7$:     MOV     #37,-(SP)               ;                       5333
000150  000567                          BR      23$
000152  020227  000002          8$:     CMP     R2,#2                   ;                       5337
000156  001014                          BNE     10$
000160  105261  000050                  INCB    50(R1)                  ;                       5338
000164  032737  000001  001254'        BIT     #1,APT.MODE             ;                       5340
000172  001403                          BEQ     9$
000174  012746  000040                  MOV     #40,-(SP)               ;                       5342
000200  000567                          BR      25$
000202  012746  000040          9$:     MOV     #40,-(SP)               ;                       5344
000206  000567                          BR      27$
000210  020227  000003          10$:    CMP     R2,#3                   ;                       5348
000214  001036                          BNE     12$
000216  105261  000050                  INCB    50(R1)                  ;                       5349
000222  032737  000001  001254'        BIT     #1,APT.MODE             ;                       5351
000230  001415                          BEQ     11$
000232  012777  000001  001256'        MOV     #1,@MAIL.BOX.TESTNUM    ;                       5354
000240  013700  000000G                 MOV     CUOFF,R0                ;                       5355
000244  006300                          ASL     R0
000246  063700  000000G                 ADD     CST.ADDR,R0
000252  111077  001260'                 MOVB    (R0),@MAIL.BOX.SUBTST
000256  042777  177760  001260'        BIC     #177760,@MAIL.BOX.SUBTST
000264  104455                  11$:    TRAP    55                      ;                       5358
000266  000022                          .WORD   22
000270  000000G                         .WORD   EGD.18
000272  000000G                         .WORD   EMS.18
000274  013700  000000G                 MOV     L$LUN,R0                ;                       5359
000300  112760  000005  000000G         MOVB    #5,DUR(R0)
000306  104451                          TRAP    51                      ;                       5360
000310  000207                          RTS     PC                      ;                       5305
000312  020227  000004          12$:    CMP     R2,#4                   ;                       5363
000316  001036                          BNE     14$
```

```
000320  105261  000050                          INCB    50(R1)                  ;                               5364
000324  032737  000001  001254'                 BIT     #1,APT.MOD              ;                               5366
000332  001415                                  BEQ     13$
000334  012777  000001  001256'                 MOV     #1,@MAIL.BOX.TESTNUM    ;                               5369
000342  013700  000000G                         MOV     CUOFF,R0                ;                               5370
000346  006300                                  ASL     R0
000350  063700  000000G                         ADD     CST.ADDR,R0
000354  111077  001260'                         MOVB    (R0),@MAIL.BOX.SUBTST
000360  042777  177760  001260'                 BIC     #177760,@MAIL.BOX.SUBTST
000366  104455                          13$:    TRAP    55                      ;                               5373
000370  000030                                  .WORD   30
000372  000000G                                 .WORD   EGD.18
000374  000000G                                 .WORD   EMS.24
000376  013700  000000G                         MOV     L$LUN,R0                ;                               5374
000402  112760  000005  000000G                 MOVB    #5,DUR(R0)
000410  104451                                  TRAP    51                      ;                               5375
000412  000207                                  RTS     PC                      ;                               5305
000414  020227  000005                  14$:    CMP     R2,#5                   ;                               5378
000420  001014                                  BNE     18$
000422  105261  000046                          INCB    46(R1)                  ;                               5379
000426  032737  000001  001254'                 BIT     #1,APT.MODE             ;                               5381
000434  001403                                  BEQ     16$
000436  012746  000043                          MOV     #43,-(SP)               ;                               5383
000442  000563                          15$:    BR      36$
000444  012746  000043                  16$:    MOV     #43,-(SP)               ;                               5385
000450  000563                          17$:    BR      38$
000452  020227  000006                  18$:    CMP     R2,#6                   ;                               5389
000456  001025                                  BNE     24$
000460  012700  000050                          MOV     #50,R0                  ;                               5393
000464  060100                                  ADD     R1,R0
000466  023727  000000G 000200                  CMP     SB.CODE,#200            ;                               5391
000474  001003                                  BNE     19$
000476  105260  000001                          INCB    1(R0)                   ;                               5393
000502  000401                                  BR      20$                     ;                               5391
000504  105210                          19$:    INCB    (R0)                    ;                               5395
000506  032737  000001  001254'          20$:    BIT     #1,APT.MODE             ;                               5397
000514  001403                                  BEQ     22$
000516  012746  000044                          MOV     #44,-(SP)               ;                               5399
000522  000561                          21$:    BR      42$
000524  012746  000044                  22$:    MOV     #44,-(SP)               ;                               5401
000530  000561                          23$:    BR      44$
000532  020227  000007                  24$:    CMP     R2,#7                   ;                               5405
000536  001014                                  BNE     28$
000540  105261  000047                          INCB    47(R1)                  ;                               5406
000544  032737  000001  001254'                 BIT     #1,APT.MODE             ;                               5408
000552  001403                                  BEQ     26$
000554  012746  000045                          MOV     #45,-(SP)               ;                               5410
000560  000561                          25$:    BR      46$
000562  012746  000045                  26$:    MOV     #45,-(SP)               ;                               5412
000566  000561                          27$:    BR      48$
000570  020227  000010                  28$:    CMP     R2,#10                  ;                               5416
000574  001054                                  BNE     33$
000576  012700  000046                          MOV     #46,R0                  ;                               5420
```

```
000602  060100                                  ADD     R1,R0
000604  023727  000000G 000002                  CMP     SB.CODE,#2              ;                       5418
000612  001002                                  BNE     29$
000614  105210                                  INCB    (R0)                    ;                       5420
000616  000402                                  BR      30$                     ;                       5418
000620  105260  000001                  29$:    INCB    1(R0)                   ;                       5422
000624  005737  000000G                 30$:    TST     SB.CODE                 ;                       5424
000630  001024                                  BNE     31$
000632  132737  000001  000000G                BITB    #1,FORCED.ERROR         ;                       5425
000640  001020                                  BNE     31$
000642  032737  004000  000000G                BIT     #4000,SWP.FLAGS         ;                       5426
000650  001414                                  BEQ     31$
000652  112737  000001  000000G                MOVB    #1,FORCED.ERROR         ;                       5429
000660  016337  000050  000000G                MOV     50(R3),FER0.LBN         ;                       5430
000666  016337  000052  000000G                MOV     52(R3),FER1.LBN         ;                       5431
000674  016337  000044  000000G                MOV     44(R3),FER.BC           ;                       5432
000702  032737  000001  001254'        31$:    BIT     #1,APT.MODE             ;                       5436
000710  001403                                  BEQ     32$
000712  012746  000046                          MOV     #46,-(SP)               ;                       5438
000716  000521                                  BR      50$
000720  012746  000046                  32$:    MOV     #46,-(SP)               ;                       5440
000724  000523                                  BR      52$
000726  020227  000011                  33$:    CMP     R2,#11                  ;                       5444
000732  001014                                  BNE     35$
000734  105261  000051                          INCB    51(R1)                  ;                       5445
000740  032737  000001  001254'                BIT     #1,APT.MODE             ;                       5447
000746  001403                                  BEQ     34$
000750  012746  000047                          MOV     #47,-(SP)               ;                       5449
000754  000502                                  BR      50$
000756  012746  000047                  34$:    MOV     #47,-(SP)               ;                       5451
000762  000504                                  BR      52$
000764  020227  000012                  35$:    CMP     R2,#12                  ;                       5455
000770  001014                                  BNE     39$
000772  105261  000050                          INCB    50(R1)                  ;                       5456
000776  032737  000001  001254'                BIT     #1,APT.MODE             ;                       5458
001004  001403                                  BEQ     37$
001006  012746  000050                          MOV     #50,-(SP)               ;                       5460
001012  000453                          36$:    BR      50$
001014  012746  000050                  37$:    MOV     #50,-(SP)               ;                       5462
001020  000465                          38$:    BR      52$
001022  020227  000013                  39$:    CMP     R2,#13                  ;                       5466
001026  001023                                  BNE     45$
001030  023727  000000G 000003                  CMP     SB.CODE,#3              ;                       5468
001036  001003                                  BNE     40$
001040  105261  000046                          INCB    46(R1)                  ;                       5470
001044  000402                                  BR      41$                     ;                       5468
001046  105261  000050                  40$:    INCB    50(R1)                  ;                       5472
001052  032737  000001  001254'        41$:    BIT     #1,APT.MODE             ;                       5474
001060  001403                                  BEQ     43$
001062  012746  000051                          MOV     #51,-(SP)               ;                       5476
001066  000435                          42$:    BR      50$
001070  012746  000051                  43$:    MOV     #51,-(SP)               ;                       5478
001074  000437                          44$:    BR      52$
```

```
001076  020227  000037                    45$:    CMP     R2,#37                          ;                       5482
001102  001014                                    BNE     49$
001104  105261  000050                            INCB    50(R1)                          ;                       5483
001110  032737  000001  001254'                   BIT     #1,APT.MODE                     ;                       5485
001116  001403                                    BEQ     47$
001120  012746  000053                            MOV     #53,-(SP)                       ;                       5487
001124  000416                              46$:  BR      50$
001126  012746  000053                      47$:  MOV     #53, (SP)                       ;                       5489
001132  000420                              48$:  BR      52$
001134  013700  000000G                     49$:  MOV     CCTLR,R0                        ;                       5494
001140  006300                                    ASL     R0
001142  105260  000000G                           INCB    C.ERR.TBL(R0)
001146  032737  000001  001254'                   BIT     #1,APT.MODE                     ;                       5496
001154  001405                                    BEQ     51$
001156  012746  000055                            MOV     #55,-(SP)                       ;                       5498
001162  004737  000000V                     50$:  JSR     PC,ERR.HRD.RTNE.APT
001166  000404                                    BR      53$                             ;                       5496
001170  012746  000055                      51$:  MOV     #55,-(SP)                       ;                       5500
001174  004737  000000V                     52$:  JSR     PC,ERR.HRD.RTNE
001200  005726                              53$:  TST     (SP)+                           ;                       5493
001202  000207                                    RTS     PC                              ;                       5285

; Routine Size:  322 words,    Routine Base:  $CODE$ + 16166
; Maximum stack depth per invocation:  7 words


;   5589  1
```

```
;    5590  1     GLOBAL routine UPD_IO_TALLY : novalue =
;    5591  1
;    5592  1     !+
;    5593  1     !       THIS ROUTINE IS CALLED FROM IO_RETPKT FOR ALL I/O TRANSFER RETURN
;    5594  1     !       PACKETS WITH "SUCCESS" STATUS CODES. ITS PURPOSE IS TO UPDATE ALL THE
;    5595  1     !       APPROPRIATE STATISTICAL FIELDS FOR THE CURRENT UNIT. A CHECK IS ALSO
;    5596  1     !       MADE ON THE TOTAL NUMBER OF BYTES TRANSFERRED THUS FAR; IF THE
;    5597  1     !       OPERATOR-SPECIFIED LIMIT HAS BEEN REACHED, THEN THE UNIT IS DROPPED.
;    5598  1     !
;    5599  1     !       IMPLICIT INPUTS:
;    5600  1     !               RP_ADDR - ADDRESS OF THE CURRENT RETURN PACKET
;    5601  1     !               T_ADDR - ADDRESS OF THE CURRENT UNIT'S STATISTICS BLOCK (TALLY)
;    5602  1     !               CST_ADDR - ADDRESS OF THE CURRENT CONTROLLER'S CST
;    5603  1     !               CUOFF - CST OFFSET FOR THE CURRENT UNIT
;    5604  1     !               L$LUN - CURRENT UNIT NUMBER
;    5605  1     !-
;    5606  1
;    5607  2         begin
;    5608  2
;    5609  2         local
;    5610  2             THOUSANDS : word,
;    5611  2             MILLIONS : word,                                    ! TOTAL NO. OF BYTES XFERRED TO/FROM A UNIT
;    5612  2             FILL_CNT : word,                                    ! PARTIAL SECTOR FILL COUNT                 MMM
;    5613  2             PARTIAL_CNT : word,                                 ! PARTIAL SECTOR TRANSFER COUNT             MMM
;    5614  2             BYTES_PER_SECTOR : word initial (512),              ! RD AND RX BYTES PER SECTOR                MMM
;    5615  2             INDEX : word;                                       ! UNIT NO.                                  MMM
;    5616  2
;    5617  2         INDEX = .CST_ADDR [.CUOFF + OF_DATA, D_DISK_NUM];       !POINT TO TYPER + TYPEW FOR THIS UNIT       MMM
;    5618  2
;    5619  2         PARTIAL_CNT = .RP_ADDR [BCNT_LO] MOD .BYTES_PER_SECTOR; ! PARTIAL SECTOR COUNT TRANSFERED           MMM
;    5620  2
;    5621  2         if .PARTIAL_CNT eql 0                                   ! CALCULATE ZERO FILL LENGHT ON             MMM
;    5622  2         then FILL_CNT = 0                                       ! PARTIAL SECTOR TRANSFER AND
;    5623  2         else FILL_CNT = .BYTES_PER_SECTOR - .PARTIAL_CNT;       ! ADD TO TALLY COUNT
;    5624  2
;    5625  3         if .RP_ADDR [ENDCOD] eql (OP_RD or OP_END)              ! IF ENDCODE IS READ
;    5626  2         then
;    5627  3             begin
;    5628  3             TYPER [.INDEX] = .TYPER [.INDEX] + 1;               !INCREMENT READ COUNT                       ZZZ
MMM
;    5629  3             T_ADDR [TOT_READS_LO] = .T_ADDR [TOT_READS_LO] + 1; ! INCREMENT NO. OF READS AND ADD BYTE COUNT
;    5630  3             T_ADDR [BYTES_READ_LO] = .T_ADDR [BYTES_READ_LO] + .RP_ADDR [BCNT_LO] + .FILL_CNT ;                 ! MMM

;    5631  3             T_ADDR [TOT_BYT_RED_LO] = .T_ADDR [TOT_BYT_RED_LO] + .RP_ADDR [BCNT_LO] + .FILL_CNT ;               ! MMM
;    5632  3             OVF_CHK (T_ADDR [TOT_READS_LO]);                    ! CHECK FOR FIELD OVERFLOW
;    5633  3             OVF_CHK (T_ADDR [BYTES_READ_LO]);                   !
;    5634  3             OVF_CHK (T_ADDR [TOT_BYT_RED_LO]);                  !
;    5635  3             end
;    5636  2         else
;    5637  2
;    5638  3             if .RP_ADDR [ENDCOD] eql (OP_WRT or OP_END)         ! IF ENDCODE IS WRITE
;    5639  2             then
;    5640  3                 begin
;    5641  3                 TYPEW [.INDEX] = .TYPEW [.INDEX] + 1;           !INCREMENT WRITE COUNT                      ZZZ
MMM
;    5642  3                 T_ADDR [TOT_WRITES_LO] = .T_ADDR [TOT_WRITES_LO] + 1;   ! INCREMENT NO. OF WRITES, ADD BYTE COUNT
```

```
;    5643  3                T_ADDR [BYTES_WRIT_LO] = .T_ADDR [BYTES_WRIT_LO] + .RP_ADDR [BCNT_LO] + .FILL_CNT ;                ! MMM
;    5644  3                T_ADDR [TOT_BYT_WRT_LO] = .T_ADDR [TOT_BYT_WRT_LO] + .RP_ADDR [BCNT_LO] + .FILL_CNT ;            ! MMM
;    5645  3                OVF_CHK (T_ADDR [TOT_WRITES_LO]);                                 ! CHECK FOR FIELD OVERFLOW
;    5646  3                OVF_CHK (T_ADDR [BYTES_WRIT_LO]);                                 !
;    5647  3                OVF_CHK (T_ADDR [TOT_BYT_WRT_LO]);                                !
;    5648  2                end;
;    5649  2
;    5650  2            if (.RP_ADDR [ENDCOD] eql (OP_RD or OP_END)) or
;    5651  3               (.RP_ADDR [ENDCOD] eql (OP_WRT or OP_END))
;    5652  2            then
;    5653  3                begin
;    5654  3                MILLIONS = .T_ADDR [MBYTES_READ] + .T_ADDR [MBYTES_WRIT];         ! TOTAL BYTES TRANSFERRED
;    5655  3                THOUSANDS = .T_ADDR [BYTES_READ_HI] + .T_ADDR [BYTES_WRIT_HI];
;    5656  3
;    5657  3                if .THOUSANDS gequ 1000
;    5658  3                then
;    5659  4                    begin
;    5660  4                    MILLIONS = .MILLIONS + 1;                                     ! COUNT THE LOWER OVERFLOW TOO!
;    5661  4                    THOUSANDS = .THOUSANDS - 1000;
;    5662  3                    end;
;    5663  3
;    5664  3
;    5665  4        IF  (.TYPER [.INDEX] GEQU %o'100000' ) OR (.TYPEW [.INDEX] GEQU %O'100000')   ! RESET COUNTERS AT SOME      MMM
;    5666  3        THEN                                                                          ! CONVENIENT POINT TO AVOID   MMM
;    5667  4           BEGIN                                                                      ! OVERFLOWING                 MMM
;    5668  4           TYPER [.INDEX] = 0;                                                        !                             MMM
;    5669  4           TYPEW [.INDEX] = 0;                                                        !                             MMM
;    5670  4           BAL_IN_PROGRESS [.INDEX] = 0;                                              !                             MMM
;    5671  4           FORCE_WR [.INDEX] = 0;                                                     !                             MMM
;    5672  3           END;                                                                       !                             MMM
;    5673  3
;    5674  4        IF .TYPER [.INDEX] GTRU ((2 * .TYPEW [.INDEX]) + 20)                          ! TOO MANY READS ?            MMM
;    5675  3        THEN                                                                          !                             MMM
;    5676  4           BEGIN                                                                      ! FORCE WRITE OPERATIONS      MMM
;    5677  4           BAL_IN_PROGRESS [.INDEX] = TRUE;                                           !                             MMM
;    5678  4           FORCE_WR [.INDEX] = TRUE;                                                  !                             MMM
;    5679  3           END;                                                                       !                             MMM
;    5680  3
;    5681  3        IF ((2 * .TYPEW [.INDEX]) + 20)  GTRU .TYPER [.INDEX]                         ! TOO MANY WRITES ?           MMM
;    5682  3        THEN                                                                          !                             MMM
;    5683  4           BEGIN                                                                      ! FORCE READ OPERATIONS       MMM
;    5684  4           BAL_IN_PROGRESS [.INDEX] = TRUE;                                           !                             MMM
;    5685  4           FORCE_WR [.INDEX] = FALSE;                                                 !                             MMM
;    5686  3           END;                                                                       !                             MMM
;    5687  3
;    5688  3        IF .TYPER [.INDEX] GTRU ((2 * .TYPEW [.INDEX]) + 5)  AND                      ! ENOUGH WRITES TO STOP       MMM
;    5689  3           BAL_IN_PROGRESS [.INDEX]                                                   ! BALANCE PROCESS ?           MMM
;    5690  3        THEN                                                                          !                             MMM
;    5691  4           BEGIN                                                                      !                             MMM
;    5692  4           BAL_IN_PROGRESS [.INDEX] = FALSE;                                          !                             MMM
;    5693  4           FORCE_WR [.INDEX] = FALSE;                                                 !                             MMM
;    5694  3           END;                                                                       !                             MMM
;    5695  3
```

```
;    5696  3     IF (  ((2 * .TYPEW [.INDEX]) + 5) GTRU .TYPER [.INDEX]  )  AND                ! ENOUGH READS TO STOP          MMM
;    5697  3        BAL_IN_PROGRESS [.INDEX]                                                  ! BALANCE PROCESS ?             MMM
;    5698  3     THEN                                                                         !                               MMM
;    5699  4        BEGIN                                                                     !                               MMM
;    5700  4        BAL_IN_PROGRESS [.INDEX] = FALSE;                                         !                               MMM
;    5701  4        FORCE_WR [.INDEX] = FALSE;                                                !                               MMM
;    5702  3        END;                                                                      !                               MMM
;    5703  3
;    5704  3
;    5705  3
;    5706  3
;    5707  3
;    5708  3     !
;    5709  3     ! THIS ADDED BECAUSE IT WILL TAKE FOREVER TO TRANSFER ON THE ORDER OF A MEGABYTE TO A FLOPPY
;    5710  3     ! BUT IT IS A MUCH MORE REASONABLE MEASURE FOR THE RD51/52 WINCHESTER.  THE QUESTION NOW REFERS TO
;    5711  3     ! THE TOTAL DATA TRANSFER TO THE CONTROLLER AND THIS IS PRETTY CLOSE SINCE THE FLOPPIES GET
;    5712  3     ! ABOUT 1/1000 THE DATA THE HARD DISK(S) GET.
;    5713  3     !
;    5714  3
;    5715  3           if .SWP_XFER eql 0                                                     ! IF THERE IS A TRANSFER LIMIT
;    5716  3           then
;    5717  4               begin
;    5718  4
;    5719  4               if .THOUSANDS gtru 50                                          !ZZZ
;    5720  4               then
;    5721  4                   EOP_FLAG = TRUE;                                           ! SET END-OF-PASS FLAG
;    5722  4
;    5723  4               end
;    5724  3           else
;    5725  3
;    5726  3               if .MILLIONS gequ .SWP_XFER                                    ! IF TRANSFER LIMIT IS REACHED
;    5727  3               then
;    5728  3                   EOP_FLAG = TRUE;                                           ! SET END-OF-PASS FLAG
;    5729  3
;    5730  2           end;                                                               ! IF UNIT IS STILL ALIVE
;    5731  2
;    5732  2        !.....................................................................
;    5733  2        !                                                                    .
;    5734  2        ! THE FOLLOWING IS ADDED TO MAKE THE RUN TIME ABOUT 1.5 MINUTES FOR A  .
;    5735  2        ! QUICK PASS IF ALL UNITS UNDER TEST ARE FLOPPIES.                     .
;    5736  2        !.....................................................................
;    5737  2
;    5738  2     !!ZZZ   IF .RD_COUNT EQL 0                                                !IF THERE ARE NO WINCHESTERS   ZZZ
;    5739  2     !!ZZZ      THEN                                                           !                              ZZZ
;    5740  2     !!ZZZ        BEGIN                                                        !                              ZZZ
;    5741  2     !!ZZZ        IF .THOUSANDS GTRU 44                                        !IF ABOUT 1.5 MINUTES GONE BY  ZZZ
;    5742  2     !!ZZZ        THEN                                                         !                              ZZZ
;    5743  2     !!ZZZ           EOP_FLAG = TRUE;                                          !SET THE END OF PASS FLAG      ZZZ
;    5744  2     !!ZZZ        END;                                                         !                              ZZZ
;    5745  2
;    5746  2
;    5747  2        ROUND_OUTPUT ();                                                       ! ROUND TOTALS TO FIT PRINT POSITIONS
;    5748  1        end;                                                                   ! ROUTINE UPD_IO_TALLY
```

```
                                        .SBTTL  UPD.IO.TALLY MULTI-DRIVE TEST ROUTINES
000000  004137  000000G           UPD.IO.TALLY::
                                        JSR     R1,$SAVE5                       ;                                       5590
000004  012701  001000                  MOV     #1000,R1                        ; *,BYTES.PER.SECTO                     5607
000010  013700  000000G                 MOV     CUOFF,R0                        ;                                       5617
000014  006300                          ASL     R0
000016  063700  000000G                 ADD     CST.ADDR,R0
000022  111003                          MOVB    (R0),R3                         ; *,INDEX
000024  042703  177760                  BIC     #177760,R3                      ; *,INDEX
000030  013700  000000G                 MOV     RP.ADDR,R0                      ;                                       5619
000034  016004  000020                  MOV     20(R0),R4
000040  010446                          MOV     R4,-(SP)
000042  010146                          MOV     R1,-(SP)                        ; BYTES.PER.SECTO,*
000044  004737  000000G                 JSR     PC,BL$MOD
000050  005700                          TST     R0                              ; PARTIAL.CNT                           5621
000052  001002                          BNE     1$
000054  005002                          CLR     R2                              ; FILL.CNT                              5622
000056  000402                          BR      2$                              ;                                       5621
000060  010102                1$:       MOV     R1,R2                           ; BYTES.PER.SECTO,FILL.CNT              5623
000062  160002                          SUB     R0,R2                           ; PARTIAL.CNT,FILL.CNT
000064  013700  000000G           2$:   MOV     RP.ADDR,R0                      ;                                       5625
000070  126027  000014  000241         CMPB    14(R0),#241
000076  001040                          BNE     3$
000100  010300                          MOV     R3,R0                           ; INDEX,*                               5628
000102  006300                          ASL     R0
000104  005260  000000G                 INC     TYPER(R0)
000110  013700  000000G                 MOV     T.ADDR,R0                       ;                                       5629
000114  005260  000016                  INC     16(R0)
000120  010401                          MOV     R4,R1                           ;                                       5630
000122  061001                          ADD     (R0),R1
000124  060201                          ADD     R2,R1                           ; FILL.CNT,*
000126  010110                          MOV     R1,(R0)
000130  010401                          MOV     R4,R1                           ;                                       5631
000132  066001  000032                  ADD     32(R0),R1
000136  060201                          ADD     R2,R1                           ; FILL.CNT,*
000140  010160  000032                  MOV     R1,32(R0)
000144  012716  000016                  MOV     #16,(SP)                        ;                                       5632
000150  060016                          ADD     R0,(SP)
000152  004737  000000V                 JSR     PC,OVF.CHK
000156  013716  000000G                 MOV     T.ADDR,(SP)                     ;                                       5633
000162  004737  000000V                 JSR     PC,OVF.CHK
000166  013716  000000G                 MOV     T.ADDR,(SP)                     ;                                       5634
000172  062716  000032                  ADD     #32,(SP)
000176  000447                          BR      4$
000200  126027  000014  000242   3$:    CMPB    14(R0),#242                     ;                                       5638
000206  001045                          BNE     5$
000210  010300                          MOV     R3,R0                           ; INDEX,*                               5641
000212  006300                          ASL     R0
000214  005260  000000G                 INC     TYPEW(R0)
000220  013700  000000G                 MOV     T.ADDR,R0                       ;                                       5642
000224  005260  000024                  INC     24(R0)
```

```
000230  010401                          MOV     R4,R1                   ;                                       5643
000232  066001  000006                  ADD     6(R0),R1
000236  060201                          ADD     R2,R1                   ; FILL.CNT,*
000240  010160  000006                  MOV     R1,6(R0)
000244  010401                          MOV     R4,R1                   ;                                       5644
000246  066001  000040                  ADD     40(R0),R1
000252  060201                          ADD     R2,R1                   ; FILL.CNT,*
000254  010160  000040                  MOV     R1,40(R0)
000260  012716  000024                  MOV     #24,(SP)                ;                                       5645
000264  060016                          ADD     R0,(SP)
000266  004737  000000V                 JSR     PC,OVF.CHK
000272  013716  000000G                 MOV     T.ADDR,(SP)             ;                                       5646
000276  062716  000006                  ADD     #6,(SP)
000302  004737  000000V                 JSR     PC,OVF.CHK
000306  013716  000000G                 MOV     T.ADDR,(SP)             ;                                       5647
000312  062716  000040                  ADD     #40,(SP)
000316  004737  000000V         4$:     JSR     PC,OVF.CHK
000322  013700  000000G         5$:     MOV     RP.ADDR,R0              ;                                       5650
000326  126027  000014  000241          CMPB    14(R0),#241
000334  001404                          BEQ     6$
000336  126027  000014  000242          CMPB    14(R0),#242             ;                                       5651
000344  001134                          BNE     16$
000346  013700  000000G         6$:     MOV     T.ADDR,R0               ;                                       5654
000352  016005  000004                  MOV     4(R0),R5                ; *,MILLIONS
000356  066005  000012                  ADD     12(R0),R5               ; *,MILLIONS
000362  016004  000002                  MOV     2(R0),R4                ; *,THOUSANDS                           5655
000366  066004  000010                  ADD     10(R0),R4               ; *,THOUSANDS
000372  020427  001750                  CMP     R4,#  50                ; THOUSANDS,*                           5657
000376  103403                          BLO     7$
000400  005205                          INC     R5                      ; MILLIONS                              5660
000402  162704  001750                  SUB     #1750,R4                ; *,THOUSANDS                           5661
000406  010300                  7$:     MOV     R3,R0                   ; INDEX,*                               5665
000410  006300                          ASL     R0
000412  012702  000000G                 MOV     #TYPER,R2
000416  060002                          ADD     R0,R2
000420  021227  100000                  CMP     (R2),#100000
000424  103004                          BHIS    8$
000426  026027  000000G 100000          CMP     TYPEW(R0),#100000
000434  103407                          BLO     9$
000436  005012                  8$:     CLR     (R2)                    ;                                       5668
000440  005060  000000G                 CLR     TYPEW(R0)               ;                                       5669
000444  005060  000000G                 CLR     BAL.IN.PROGRESS(R0)     ;                                       5670
000450  005060  000000G                 CLR     FORCE.WR(R0)            ;                                       5671
000454  016003  000000G         9$:     MOV     TYPEW(R0),R3            ;                                       5674
000460  006303                          ASL     R3
000462  010301                          MOV     R3,R1
000464  062701  000024                  ADD     #24,R1
000470  021201                          CMP     (R2),R1
000472  101406                          BLOS    10$
000474  012760  000001  000000G         MOV     #1,BAL.IN.PROGRESS(R0)  ;                                       5677
000502  012760  000001  000000G         MOV     #1,FORCE.WR(R0)         ;                                       5678
000510  020112                  10$:    CMP     R1,(R2)                 ;                                       5681
000512  101405                          BLOS    11$
```

```
000514  012760  000001  000000G                 MOV     #1,BAL.IN.PROGRESS(R0)          ;                               5684
000522  005060  000000G                         CLR     FORCE.WR(R0)                    ;                               5685
000526  062703  000005                 11$:    ADD     #5,R3                           ;                               5686
000532  021203                                 CMP     (R2),R3
000534  101411                                 BLOS    12$
000536  010001                                 MOV     R0,R1                           ;                               5689
000540  062701  000000G                         ADD     #8AL.IN.PROGRESS,R1
000544  006001                                 ROR     R1
000546  103004                                 BCC     12$
000550  005060  000000G                         CLR     BAL.IN.PROGRESS(R0)             ;                               5692
000554  005060  000000G                         CLR     FORCE.WR(R0)                    ;                               5693
000560  020312                 12$:    CMP     R3,(R2)                         ;                               5696
000562  101411                                 BLOS    13$
000564  010001                                 MOV     R0,R1                           ;                               5697
000566  062701  000000G                         ADD     #8AL.IN.PROGRESS,R1
000572  006001                                 ROR     R1
000574  103004                                 BCC     13$
000576  005060  000000G                         CLR     BAL.IN.PROGRESS(R0)             ;                               5700
000602  005060  C00000G                         CLR     FORCE.WR(R0)                    ;                               5701
000606  013700  000000G                 13$:    MOV     SWP.XFER,R0                     ;                               5715
000612  001004                                 BNE     14$
000614  020427  000062                         CMP     R4,#62                          ; THOUSANDS,*                   5719
000620  101406                                 BLOS    16$
000622  000402                                 BR      15$                             ;                               5721
000624  020500                 14$:    CMP     R5,R0                           ; MILLIONS,*                    5726
000626  103403                                 BLO     16$
000630  112737  000001  000000G         15$:    MOVB    #1,EOP.FLAG                     ;                               5728
000636  004737  000000V                 16$:    JSR     PC,ROUND.OUTPUT                 ;                               5747
000642  022626                                 CMP     (SP)+,(SP)+                     ;                               5607
000644  000207                                 RTS     PC                              ;                               5590

; Routine Size:  211 words,     Routine Base:  $CODE$ + 17372
; Maximum stack depth per invocation:  9 words
```

```
;    5749  1     GLOBAL routine OVF_CHK (ADDR) : novalue =
;    5750  1     !*
;    5751  1     !       THIS ROUTINE IS CALLED FROM UPD_IO_TALLY TO CHECK FOR OVERFLOW IN
;    5752  1     !       CERTAIN STATISTICAL FIELDS OF THE CURRENT UNIT. SPECIFICALLY, THE
;    5753  1     !       LOW-ORDER FIELD OF THE NUMBER OF BYTES READ OR WRITTEN IS CHECKED FOR
;    5754  1     !       EXCEEDING 1000. IF TRUE, THEN THE HIGH-ORDER COUNT IS INCREMENTED. IF
;    5755  1     !       THAT EXCEEDS 1000, THEN THE MEGABYTE COUNT IN INCREMENTED.
;    5756  1     !
;    5757  1     !       INPUTS:
;    5758  1     !               ADDR - ADDRESS OF THE BYTES_READ_LO OR BYTES_WRIT_LO FIELD FOR
;    5759  1     !                      THE CURRENT UNIT (SEE STATISTIC TABLE (TALLY) LAYOUT)
;    5760  1     !-
;    5761  2         begin
;    5762  2
;    5763  2         while ..ADDR gequ 1000 do                   ! IF LO-ORDER OVERFLOW
;    5764  3             begin
;    5765  3             .ADDR = ..ADDR - 1000;                  ! SUBTRACT 1000
;    5766  3             (.ADDR + 2) = .(.ADDR + 2) + 1;         ! INCR HI-ORDER
;    5767  2             end;
;    5768  2
;    5769  2         if .(.ADDR + 2) gequ 1000                   ! IF HI-ORDER OVERFLOW
;    5770  2         then
;    5771  3             begin
;    5772  3             (.ADDR + 2) = .(.ADDR + 2) - 1000;      ! SUBTRACT 1000
;    5773  3             (.ADDR + 4) = .(.ADDR + 4) + 1;         ! INCREMENT MBYTES
;    5774  2             end;
;    5775  2
;    5776  1         end;                                        ! ROUTINE OVF_CHK


                                        .SBTTL  OVF.CHK MULTI-DRIVE TEST ROUTINES
000000  010146                 OVF.CHK::
                                        MOV     R1,-(SP)                        ;                                       5749
000002  016600  000004                  MOV     4(SP),R0                        ; ADDR,*                                5763
000006  012701  000002                  MOV     #2,R1                           ;                                       5766
000012  060001                          ADD     R0,R1
000014  021027  001750          1$:     CMP     (R0),#1750                      ;                                       5763
000020  103404                          BLO     2$
000022  162710  001750                  SUB     #1750,(R0)                      ;                                       5765
000026  005211                          INC     (R1)                            ;                                       5766
000030  000771                          BR      1$                              ;                                       5763
000032  021127  001750          2$:     CMP     (R1),#1750                      ;                                       5769
000036  103404                          BLO     3$
000040  162711  001750                  SUB     #1750,(R1)                      ;                                       5772
000044  005260  000004                  INC     4(R0)                           ;                                       5773
000050  012601                  3$:     MOV     (SP)+,R1                        ;                                       5749
000052  000207                          RTS     PC

; Routine Size:  22 words,      Routine Base:  $CODE$ + 20240
; Maximum stack depth per invocation:  2 words
```

```
;    5777  1     GLOBAL routine ROUND_OUTPUT : novalue =
;    5778  1
;    5779  1     !+
;    5780  1     !       THIS ROUTINE ROUNDS THE TOTALS TO FIT PRINT POSITIONS.
;    5781  1     !-
;    5782  1
;    5783  2         begin
;    5784  2
;    5785  2         if .T_ADDR [TOT_READS_HI] gtru 9999
;    5786  2         then
;    5787  3             begin
;    5788  3
;    5789  3             if .T_ADDR [TOT_READS_LO] lssu 999
;    5790  3             then
;    5791  4                 begin
;    5792  4                 T_ADDR [TOT_READS_HI] = .T_ADDR [TOT_READS_HI] - 1;
;    5793  4                 T_ADDR [TOT_READS_LO] = .T_ADDR [TOT_READS_LO] + 1000;
;    5794  3                 end;
;    5795  3
;    5796  3             T_ADDR [TOT_READS_LO] = .T_ADDR [TOT_READS_LO] - 999;
;    5797  3             T_ADDR [TOT_READS_HI] = .T_ADDR [TOT_READS_HI] - 9999;
;    5798  2             end;
;    5799  2
;    5800  2         if .T_ADDR [TOT_WRITES_HI] gtru 9999
;    5801  2         then
;    5802  3             begin
;    5803  3
;    5804  3             if .T_ADDR [TOT_WRITES_LO] lssu 999
;    5805  3             then
;    5806  4                 begin
;    5807  4                 T_ADDR [TOT_WRITES_HI] = .T_ADDR [TOT_WRITES_HI] - 1;
;    5808  4                 T_ADDR [TOT_WRITES_LO] = .T_ADDR [TOT_WRITES_LO] + 1000;
;    5809  3                 end;
;    5810  3
;    5811  3             T_ADDR [TOT_WRITES_LO] = .T_ADDR [TOT_WRITES_LO] - 999;
;    5812  3             T_ADDR [TOT_WRITES_HI] = .T_ADDR [TOT_WRITES_HI] - 9999;
;    5813  2             end;
;    5814  2
;    5815  2         if .T_ADDR [MTOT_BYT_RED] gtru 999
;    5816  2         then
;    5817  3             begin
;    5818  3
;    5819  3             if .T_ADDR [TOT_BYT_RED_HI] lssu 999
;    5820  3             then
;    5821  4                 begin
;    5822  4                 T_ADDR [MTOT_BYT_RED] = .T_ADDR [MTOT_BYT_RED] - 1;
;    5823  4                 T_ADDR [TOT_BYT_RED_HI] = .T_ADDR [TOT_BYT_RED_HI] + 1000;
;    5824  3                 end;
;    5825  3
;    5826  3             if .T_ADDR [TOT_BYT_RED_LO] lssu 999
;    5827  3             then
;    5828  4                 begin
;    5829  4                 T_ADDR [TOT_BYT_RED_HI] = .T_ADDR [TOT_BYT_RED_HI] - 1;
```

```
;    5830  4                  T_ADDR [TOT_BYT_RED_LO] = .T_ADDR [TOT_BYT_RED_LO] + 1000;
;    5831  4
;    5832  4                  if .T_ADDR [TOT_BYT_RED_HI] lssu 999
;    5833  4                  then
;    5834  5                      begin
;    5835  5                      T_ADDR [MTOT_BYT_RED] = .T_ADDR [MTOT_BYT_RED] - 1;
;    5836  5                      T_ADDR [TOT_BYT_RED_HI] = .T_ADDR [TOT_BYT_RED_HI] + 1000;
;    5837  4                      end;
;    5838  3                  end;
;    5839  3
;    5840  3              T_ADDR [TOT_BYT_RED_LO] = .T_ADDR [TOT_BYT_RED_LO] - 999;
;    5841  3              T_ADDR [TOT_BYT_RED_HI] = .T_ADDR [TOT_BYT_RED_HI] - 999;
;    5842  3              T_ADDR [MTOT_BYT_RED] = .T_ADDR [MTOT_BYT_RED] - 999;
;    5843  2              end;
;    5844  2
;    5845  2          if .T_ADDR [MTOT_BYT_WRT] gtru 999
;    5846  2          then
;    5847  3              begin
;    5848  3
;    5849  3              if .T_ADDR [TOT_BYT_WRT_HI] lssu 999
;    5850  3              then
;    5851  4                  begin
;    5852  4                  T_ADDR [MTOT_BYT_WRT] = .T_ADDR [MTOT_BYT_WRT] - 1;
;    5853  4                  T_ADDR [TOT_BYT_WRT_HI] = .T_ADDR [TOT_BYT_WRT_HI] + 1000;
;    5854  3                  end;
;    5855  3
;    5856  3              if .T_ADDR [TOT_BYT_WRT_LO] lssu 999
;    5857  3              then
;    5858  4                  begin
;    5859  4                  T_ADDR [TOT_BYT_WRT_HI] = .T_ADDR [TOT_BYT_WRT_HI] - 1;
;    5860  4                  T_ADDR [TOT_BYT_WRT_LO] = .T_ADDR [TOT_BYT_WRT_LO] + 1000;
;    5861  4
;    5862  4                  if .T_ADDR [TOT_BYT_WRT_HI] lssu 999
;    5863  4                  then
;    5864  5                      begin
;    5865  5                      T_ADDR [MTOT_BYT_WRT] = .T_ADDR [MTOT_BYT_WRT] - 1;
;    5866  5                      T_ADDR [TOT_BYT_WRT_HI] = .T_ADDR [TOT_BYT_WRT_HI] + 1000;
;    5867  4                      end;
;    5868  3                  end;
;    5869  3
;    5870  3              T_ADDR [TOT_BYT_WRT_LO] = .T_ADDR [TOT_BYT_WRT_LO] - 999;
;    5871  3              T_ADDR [TOT_BYT_WRT_HI] = .T_ADDR [TOT_BYT_WRT_HI] - 999;
;    5872  3              T_ADDR [MTOT_BYT_WRT] = .T_ADDR [MTOT_BYT_WRT] - 999;
;    5873  2              end;
;    5874  2
;    5875  1          end;


                                        .SBTTL  ROUND.OUTPUT MULTI-DRIVE TEST ROUTINES
000000  004137  000000G          ROUND.OUTPUT::
                                        JSR     R1,$SAVE3                       ;                                       5777
000004  013700  000000G                 MOV     T.ADDR,R0                       ;                                       5785
000010  012702  000020                  MOV     #20,R2
```

```
000014  060002                          ADD     R0,R2
000016  021227  023417                  CMP     (R2),#23417
000022  101415                          BLOS    2$
000024  012701  000016                  MOV     #16,R1                  ;                       5789
000030  060001                          ADD     R0,R1
000032  021127  001747                  CMP     (R1),#1747
000036  103003                          BHIS    1$
000040  005312                          DEC     (R2)                    ;                       5792
000042  062711  001750                  ADD     #1750,(R1)              ;                       5793
000046  162711  001747          1$:     SUB     #1747,(R1)              ;                       5796
000052  162712  023417                  SUB     #23417,(R2)             ;                       5797
000056  012702  000026          2$:     MOV     #26,R2                  ;                       5800
000062  060002                          ADD     R0,R2
000064  021227  023417                  CMP     (R2),#23417
000070  101415                          BLOS    4$
000072  012701  000024                  MOV     #24,R1                  ;                       5804
000076  060001                          ADD     R0,R1
000100  021127  001747                  CMP     (R1),#1747
000104  103003                          BHIS    3$
000106  005312                          DEC     (R2)                    ;                       5807
000110  062711  001750                  ADD     #1750,(R1)              ;                       5808
000114  162711  001747          3$:     SUB     #1747,(R1)              ;                       5811
000120  162712  023417                  SUB     #23417,(R2)             ;                       5812
000124  012703  000036          4$:     MOV     #36,R3                  ;                       5815
000130  060003                          ADD     R0,R3
000132  021327  001747                  CMP     (R3),#1747
000136  101436                          BLOS    7$
000140  012701  000034                  MOV     #34,R1                  ;                       5819
000144  060001                          ADD     R0,R1
000146  021127  001747                  CMP     (R1),#1747
000152  103003                          BHIS    5$
000154  005313                          DEC     (R3)                    ;                       5822
000156  062711  001750                  ADD     #1750,(R1)              ;                       5823
000162  012702  000032          5$:     MOV     #32,R2                  ;                       5826
000166  060002                          ADD     R0,R2
000170  021227  001747                  CMP     (R2),#1747
000174  103011                          BHIS    6$
000176  005311                          DEC     (R1)                    ;                       5829
000200  062712  001750                  ADD     #1750,(R2)              ;                       5830
000204  021127  001747                  CMP     (R1),#1747              ;                       5832
000210  103003                          BHIS    6$
000212  005313                          DEC     (R3)                    ;                       5835
000214  062711  001750                  ADD     #1750,(R1)              ;                       5836
000220  162712  001747          6$:     SUB     #1747,(R2)              ;                       5840
000224  162711  001747                  SUB     #1747,(R1)              ;                       5841
000230  162713  001747                  SUB     #1747,(R3)              ;                       5842
000234  012702  000044          7$:     MOV     #44,R2                  ;                       5845
000240  060002                          ADD     R0,R2
000242  021227  001747                  CMP     (R2),#1747
000246  101435                          BLOS    10$
000250  012701  000042                  MOV     #42,R1                  ;                       5849
000254  060001                          ADD     R0,R1
000256  021127  001747                  CMP     (R1),#1747
```

```
000262  103003                                  BHIS    8$
000264  005312                                  DEC     (R2)                    ;                                       5852
000266  062711  001750                          ADD     #1750,(R1)              ;                                       5853
000272  062700  000040              8$:         ADD     #40,R0                  ;                                       5856
000276  021027  001747                          CMP     (R0),#1747
000302  103011                                  BHIS    9$
000304  005311                                  DEC     (R1)                    ;                                       5859
000306  062710  001750                          ADD     #1750,(R0)              ;                                       5860
000312  021127  001747                          CMP     (R1),#1747              ;                                       5862
000316  103003                                  BHIS    9$
000320  005312                                  DEC     (R2)                    ;                                       5865
000322  062711  001750                          ADD     #1750,(R1)              ;                                       5866
000326  162710  001747              9$:         SUB     #1747,(R0)              ;                                       5870
000332  162711  001747                          SUB     #1747,(R1)              ;                                       5871
000336  162712  001747                          SUB     #1747,(R2)              ;                                       5872
000342  000207                      10$:        RTS     PC                      ;                                       5777

; Routine Size:  114 words,     Routine Base:  $CODE$ + 20314
; Maximum stack depth per invocation:  5 words
```

```
;  5876  1     GLOBAL routine HOST_WRT_CHK =
;  5877  1
;  5878  1     !+
;  5879  1     !       THIS ROUTINE IS CALLED FROM IO_RETPKT FOR ALL I/O TRANSFER RETURN
;  5880  1     !       PACKETS WITH "SUCCESS" STATUS CODES, BUT ONLY IF THE HOST WRITE-COMPARE
;  5881  1     !       OPTION WAS SELECTED BY THE OPERATOR.
;  5882  1     !
;  5883  1     !       IF THE CURRENT RETPKT BEING PROCESSED IS A WRITE FUNCTION, THEN THE
;  5884  1     !       PACKET INDEX (RP_INDX) IS SAVED IN THE CONTROLLER'S RETURN PACKET SAVE
;  5885  1     !       AREA (RP_SAVE). OTHERWISE, THE PACKET IS A READ, SO ITS ASSOCIATED
;  5886  1     !       WRITE PACKET IS REMOVED FROM THE SAVE AREA, AND A BYTE-BY-BYTE
;  5887  1     !       COMPARISON IS PERFORMED ON THE TWO I/O BUFFERS. ANY DIFFERENCES
;  5888  1     !       ENCOUNTERED RESULTS IN THE DECLARATION OF A HARD ERROR.
;  5889  1     !
;  5890  1     !       IMPLICIT INPUTS:
;  5891  1     !               RP_ADDR - ADDRESS OF THE CURRENT RETURN PACKET
;  5892  1     !               RP_INDX - INDEX OF THE CURRENT RETURN PACKET
;  5893  1     !-
;  5894  1
;  5895  2         begin
;  5896  2
;  5897  2         local
;  5898  2             BUFF1 : ref block [MAX_XFER_SIZE, byte],            ! I/O BUFFER ADDRESS
;  5899  2             BUFF2 : ref block [MAX_XFER_SIZE, byte],            ! I/O BUFFER ADDRESS
;  5900  2             BUFFW,                                              ! I/O BUFFER ADDRESS
;  5901  2             COUNT : word,                                       ! BYTE COUNT
;  5902  2             FLAG : byte initial (byte (TRUE)),
;  5903  2             index : signed word;
;  5904  2
;  5905  3         if .RP_ADDR [ENDCOD] eql (OP_WRT or OP_END)             ! IF WRITE OPERATION
;  5906  2         then
;  5907  2             FLAG = FALSE                                        ! DON'T CALL SWEEP FROM IO_RETPKT
;  5908  2         else
;  5909  2
;  5910  2             if (.RP_ADDR [ENDCOD] eql (OP_RD or OP_END)) and
;  5911  3                ((index = RPS_REM ()) geq 0)                     ! IF ASSOCIATED WRITE PACKET IS FOUND
;  5912  2             then
;  5913  3                 begin
;  5914  3                 BUFFW = RETPKT [.index, BUFF_0];                ! ADDR OF ADDR OF WRITE I/O BUFFER
;  5915  3                 BUFF1 = ..BUFFW;                                ! ADDR OF WRITE I/O BUFFER
;  5916  3                 BUFF2 = .RP_ADDR [BUFF_0];                      ! ADDR OF READ I/O BUFFER
;  5917  3                 COUNT = .RP_ADDR [BCNT_LO];                     ! BYTE COUNT
;  5918  3
;  5919  3                 incr I from 1 to .COUNT do                      ! FOR EACH BYTE IN BUFFERS
;  5920  3
;  5921  3                     if .(.BUFF1)<0, 8, 0> eql .(.BUFF2)<0, 8, 0>    ! IF BYTES COMPARE O.K.
;  5922  3                     then
;  5923  4                         begin
;  5924  4                         BUFF1 = .BUFF1 + 1;                     ! ADVANCE WRITE BUFFER ADDR
;  5925  4                         BUFF2 = .BUFF2 + 1;                     ! ADVANCE READ BUFFER ADDR
;  5926  4                         end
;  5927  3                     else
;  5928  4                         begin                                   ! ELSE - COMPARE ERROR
```

```
;    5929  4                          T_ADDR [ERR_HARD] = .T_ADDR [ERR_HARD] + 1;
;    5930  4                          T_ADDR [ERR_HRD_HST] = .T_ADDR [ERR_HRD_HST] + 1;
;    5931  4
;    5932  4                          EMS_CMP (RETPKT + (.index * RP_LEN * 2));    !MMM PRINT ERROR INFORMATION BEFORE
;    5933  4                                                                       ! HARD ERROR CALL
;    5934  4                                                                       ! IF FLAG:HOE IS SET, THEN ERROR INFORMATION
;    5935  4                                                                       ! IS PRINTED BEFORE HALT !
;    5936  4                          if .APT_MODE
;    5937  4                          then
;    5938  4                              ERR_HRD_RTNE_APT (42)                    ! I/O REQUEST FAILED
;    5939  4                          else
;    5940  4                              ERR_HRD_RTNE (42);
;    5941  4
;    5942  4     !MMM                 EMS_CMP (RETPKT + (.index * RP_LEN * 2));
;    5943  4
;    5944  4                          if .T_ADDR [ERR_HARD] gequ .SWP_ERROR
;    5945  4                          then
;    5946  5                              begin
;    5947  5                              DUR [.L$LUN] = DU_HERR;                  ! IF ERROR COUNT EXCEEDED
;    5948  5                              DODU (.L$LUN);                           ! DROP UNIT
;    5949  4                              end;
;    5950  4
;    5951  4                          exitloop;                                    ! NO NEED TO CONTINUE
;    5952  3                          end;                                         ! IF COMPARE ERROR
;    5953  3
;    5954  2                  end;                                                 ! IF ASSOCIATED WRITE RETPKT WAS FOUND
;    5955  2
;    5956  2          return (.FLAG);
;    5957  1          end;                                                         ! ROUTINE HOST_WRT_CHK


                                        .SBTTL  HOST.WRT.CHK MULTI-DRIVE TEST ROUTINES
000000  004137  000000G          HOST.WRT.CHK::
                                        JSR     R1,$SAVE5                        ;                                       5876
000004  005746                          TST     -(SP)
000006  112705  000001                  MOVB    #1,R5                            ; *,FLAG                                5895
000012  013700  000000G                 MOV     RP.ADDR,R0                       ;                                       5905
000016  126027  000014  000242          CMPB    14(R0),#242
000024  001002                          BNE     1$
000026  105005                          CLRB    R5                               ; FLAG                                  5907
000030  000511                          BR      8$                               ;                                       5905
000032  126027  000014  000241  1$:     CMPB    14(R0),#241                      ;                                       5910
000040  001105                          BNE     8$
000042  004737  000000V                 JSR     PC,RPS.REM                       ;                                       5911
000046  005700                          TST     R0                               ; INDEX
000050  002501                          BLT     8$
000052  010046                          MOV     R0,-(SP)                         ; INDEX,*                               5914
000054  012746  000054                  MOV     #54,-(SP)
000060  004737  000000G                 JSR     PC,BL$MUL
000064  010066  000004                  MOV     R0,4(SP)
000070  062700  000024G                 ADD     #RETPKT+24,R0                    ; *,BUFFW
000074  011001                          MOV     (R0),R1                          ; BUFFW,BUFF1                           5915
000076  013700  000000G                 MOV     RP.ADDR,R0                       ;                                       5916
```

```
000102  016002  000024                          MOV     24(R0),R2                       ; *,BUFF2
000106  016004  000020                          MOV     20(R0),R4                       ; *,COUNT                       5917
000112  005003                                  CLR     R3                              ; I                             5919
000114  000453                                  BR      6$
000116  121112                          2$:     CMPB    (R1),(R2)                       ; BUFF1,BUFF2                   5921
000120  001003                                  BNE     3$
000122  005201                                  INC     R1                              ; BUFF1                         5924
000124  005202                                  INC     R2                              ; BUFF2                         5925
000126  000446                                  BR      6$                              ;                               5921
000130  013700  000000G                  3$:     MOV     T.ADDR,R0                       ;                               5929
000134  005260  000014                          INC     14(R0)
000140  105260  000051                          INCB    51(R0)                          ;                               5930
000144  016616  000004                          MOV     4(SP),(SP)                      ;                               5932
000150  062716  000000G                          ADD     #RETPKT,(SP)
000154  004737  000000G                          JSR     PC,EMS.CMP
000160  032737  000001  001254'                  BIT     #1,APT.MODE                     ;                               5936
000166  001405                                  BEQ     4$
000170  012716  000052                          MOV     #52,(SP)                        ;                               5938
000174  004737  C00000V                          JSR     PC,ERR.HRD.RTNE.APT
000200  000404                                  BR      5$                              ;                               5936
000202  012716  000052                  4$:     MOV     #52,(SP)                        ;                               5940
000206  004737  000000V                          JSR     PC,ERR.HRD.RTNE
000212  013700  000000G                  5$:     MOV     T.ADDR,R0                       ;                               5944
000216  026037  000014  000000G                  CMP     14(R0),SWP.ERROR
000224  103412                                  BLO     7$
000226  013700  000000G                          MOV     L$LUN,R0                        ;                               5947
000232  112760  000004  000000G                  MOVB    #4,DUR(R0)
000240  104451                                  TRAP    51                              ;                               5948
000242  000403                                  BR      7$                              ;                               5928
000244  005203                          6$:     INC     R3                              ; I                             5919
000246  020304                                  CMP     R3,R4                           ; I,COUNT
000250  003722                                  BLE     2$
000252  022626                          7$:     CMP     (SP)+,(SP)+                     ;                               5913
000254  005000                          8$:     CLR     R0                              ;                               5956
000256  150500                                  BISB    R5,R0                           ; FLAG,*
000260  005726                                  TST     (SP)+                           ;                               5876
000262  000207                                  RTS     PC

; Routine Size:  90 words,      Routine Base:  $CODE$ + 20660
; Maximum stack depth per invocation:  11 words
```

```
;    5958  1     GLOBAL routine SWEEP : novalue =
;    5959  1
;    5960  1     !+
;    5961  1     !       THIS ROUTINE IS CALLED FROM IO_RETPKT AND OTHERS TO DEALLOCATE THE
;    5962  1     !       RESOURCES ASSOCIATED WITH THE CURRENT RETURN PACKET. THIS INCLUDES THE
;    5963  1     !       PACKET ITSELF AND THE I/O BUFFER. IN ADDITION, IF THE HOST IS
;    5964  1     !       PERFORMING WRITE-COMPARES, AND IF THE CURRENT RETURN PACKET IS A READ
;    5965  1     !       FUNCTION, THEN THE CURRENT CONTROLLER'S RP_SAVE AREA IS SEARCHED FOR
;    5966  1     !       THE ASSOCIATED WRITE RETPKT SO THAT ITS RESOURCES CAN ALSO BE
;    5967  1     !       DEALLOCATED.
;    5968  1     !
;    5969  1     !       IMPLICIT INPUTS:
;    5970  1     !               RP_ADDR - ADDRESS OF CURRENT RETURN PACKET
;    5971  1     !               RP_INDX - INDEX OF CURRENT RETURN PACKET
;    5972  1     !-
;    5973  1
;    5974  2         begin
;    5975  2
;    5976  2         local
;    5977  2             index : signed word;
;    5978  2
;    5979  2         if (.RP_ADDR [ENDCOD] and OP_MSK) eql OP_RD          ! IF READ OPCODE OR ENDCODE
;    5980  2         then
;    5981  2
;    5982  3             if BIT_TST (SWP_FLAGS, SWF_HWC)                  ! IF HOST IS DOING WRITE-COMPARES
;    5983  2             then
;    5984  2
;    5985  2                 if (index = RPS_REM ()) geq 0                ! IF ASSOCIATED WRITE RETPKT IS FOUND
;    5986  2                 then
;    5987  3                     begin
;    5988  3                     PUT_IO_BUFF (RETPKT [.index, BUFF_O]);   ! RETURN WRITE I/O BUFFER TO POOL
;    5989  3                     PUT_RETPKT (.index);                     ! RETURN WRITE PACKET TO POOL
;    5990  2                     end;
;    5991  2
;    5992  2         PUT_IO_BUFF (RP_ADDR [BUFF_O]);                      ! RETURN CURRENT I/O BUFFER TO POOL
;    5993  2         PUT_RETPKT (.RP_INDX);                               ! RETURN CURRENT RETPKT TO POOL
;    5994  1         end;                                                 ! ROUTINE SWEEP

                                        .SBTTL  SWEEP MULTI-DRIVE TEST ROUTINES
000000  010146                  SWEEP:: MOV     R1,-(SP)                ;                                5958
000002  013700  000000G                MOV     RP.ADDR,R0              ;                                5979
000006  116000  000014                 MOVB    14(R0),R0
000012  042700  177600                 BIC     #177600,R0
000016  020027  000041                 CMP     R0,#41
000022  001026                        BNE     1$
000024  032737  000040  000000G        BIT     #40,SWP.FLAGS           ;                                5982
000032  001422                        BEQ     1$
000034  004737  000000V                JSR     PC,RPS.REM              ;                                5985
000040  010001                        MOV     R0,R1                   ; *,INDEX
000042  002416                        BLT     1$
000044  010146                        MOV     R1,-(SP)                ; INDEX,*                        5988
000046  012746  000054                MOV     #54,-(SP)
```

```
000052  004737  000000G                        JSR     PC,BL$MUL
000056  062700  000024G                        ADD     @RETPKT+24,R0
000062  010016                                 MOV     R0,(SP)
000064  004737  000000G                        JSR     PC,PUT.IO.BUFF
000070  010116                                 MOV     R1,(SP)          ; INDEX,*                    5989
000072  004737  000000G                        JSR     PC,PUT.RETPKT
000076  022626                                 CMP     (SP)+,(SP)+      ;                            5987
000100  013746  000000G                1$:     MOV     RP.ADDR,-(SP)    ;                            5992
000104  062716  000024                         ADD     #24,(SP)
000110  004737  000000G                        JSR     PC,PUT.IO.BUFF
000114  013716  000000G                        MOV     RP.INDX,(SP)     ;                            5993
000120  004737  000000G                        JSR     PC,PUT.RETPKT
000124  005726                                 TST     (SP)+            ;                            5974
000126  012601                                 MOV     (SP)+,R1         ;                            5958
000130  000207                                 RTS     PC

; Routine Size:  45 words,      Routine Base:  $CODE$ + 21144
; Maximum stack depth per invocation:  4 words
```

```
;    5995  1     GLOBAL routine RPS_REM =
;    5996  1
;    5997  1     !+
;    5998  1     !       THIS ROUTINE SEARCHES THE CURRENT CONTROLLER'S RP_SAVE AREA FOR A
;    5999  1     !       RETURN PACKET WHOSE COMMAND REFERENCE NUMBER (CRN) IS ONE LESS THAN THE
;    6000  1     !       CRN OF THE CURRENT RETURN PACKET (I.E., SEARCHING FOR THE SAVED WRITE
;    6001  1     !       OPERATION ASSOCIATED WITH THE CURRENT READ OPERATION). IF FOUND, THE
;    6002  1     !       RP_SAVE ENTRY IS CLEARED (TO -1) AND THE RETPKT INDEX OF THE WRITE
;    6003  1     !       OPERATION IS RETURNED TO THE CALLER.
;    6004  1     !
;    6005  1     !       IMPLICIT INPUTS:
;    6006  1     !               RP_ADDR - ADDRESS OF THE CURRENT RETURN PACKET
;    6007  1     !
;    6008  1     !       OUTPUTS:
;    6009  1     !               INDEX (VALUE OF THIS ROUTINE) - INDEX OF THE RETPKT CONTAINING
;    6010  1     !                       A CRN WHICH IS ONE LESS THAN THE CURRENT
;    6011  1     !-
;    6012  1
;    6013  2         begin
;    6014  2
;    6015  2         local
;    6016  2             index : signed word initial (-1);                       ! ASSUME NOT FOUND
;    6017  2
;    6018  2         incr COUNT from 0 to RP_CNT - 1 do                          ! FOR EACH ENTRY IN RP_SAVE
;    6019  2
;    6020  2             if (.RP_USE [.COUNT] eql .CCTLR) and                    ! IF THIS IS A VALID RETPKT INDEX
;    6021  3               (.RETPKT [.COUNT, ENDCOD] eql (OP_WRT or OP_END))
;    6022  2             then
;    6023  2
;    6024  3                 if ((.RETPKT [.COUNT, CRF_LO] eql (.RP_ADDR [CRF_LO] - 1)) and      ! IF CORRECT CRN
;    6025  2                     (.RETPKT [.COUNT, CRF_HI] eql .RP_ADDR [CRF_HI])) or
;    6026  3                    ((.RETPKT [.COUNT, CRF_HI] eql (.RP_ADDR [CRF_HI] - 1)) and
;    6027  3                     (.RETPKT [.COUNT, CRF_LO] eql %o'177777') and
;    6028  3                     (.RP_ADDR [CRF_LO] eql 0))
;    6029  2                 then
;    6030  3                     begin
;    6031  3                     index = .COUNT;                                 ! INDEX TO BE RETURNED
;    6032  3                     exitloop;                                       ! DONE
;    6033  2                     end;
;    6034  2
;    6035  2         return .index;
;    6036  1         end;                                                        ! ROUTINE RPS REM


                                        .SBTTL  RPS.REM MULTI-DRIVE TEST ROUTINES
000000  004137  000000G          RPS.REM::
                                        JSR     R1,$SAVE4                       ;                                   5995
000004  012704  177777                  MOV     #-1,R4                          ; *,INDEX                           6013
000010  005003                          CLR     R3                              ; COUNT                             6018
000012  116300  000000G          1$:    MOVB    RP.USE(R3),R0                   ; *(COUNT),*                        6020
000016  020037  000000G                  CMP     R0,CCTLR
000022  001053                          BNE     4$
000024  010346                          MOV     R3,-(SP)                        ; COUNT,*                           6021
```

```
000026  012746  000054                        MOV     #54,-(SP)
000032  004737  000000G                       JSR     PC,BL$MUL
000036  022626                                CMP     (SP)+,(SP)+
000040  126027  000014G 000242                CMPB    RETPKT+14(R0),#242
000046  001041                                BNE     4$
000050  010346                                MOV     R3,-(SP)                ; COUNT,*                       6024
000052  012746  000054                        MOV     #54,-(SP)
000056  004737  000000G                       JSR     PC,BL$MUL
000062  022626                                CMP     (SP)+,(SP)+
000064  013701  000000G                       MOV     RP.ADDR,R1
000070  016102  000004                        MOV     4(R1),R2
000074  005302                                DEC     R2
000076  026002  000004G                       CMP     RETPKT+4(R0),R2
000102  001004                                BNE     2$
000104  026061  000006G 000006                CMP     RETPKT+6(R0),6(R1)      ;                               6025
000112  001415                                BEQ     3$
000114  016102  000006                2$:     MOV     6(R1),R2                ;                               6026
000120  005302                                DEC     R2
000122  026002  000006G                       CMP     RETPKT+6(R0),R2
000126  001011                                BNE     4$
000130  026027  000004G 177777                CMP     RETPKT+4(R0),#-1        ;                               6027
000136  001005                                BNE     4$
000140  005761  000004                        TST     4(R1)                   ;                               6028
000144  001002                                BNE     4$
000146  010304                        3$:     MOV     R3,R4                   ; COUNT,INDEX                   6031
000150  000404                                BR      5$                      ;                               6030
000152  005203                        4$:     INC     R3                      ; COUNT                         6018
000154  020327  000007                        CMP     R3,#7                   ; COUNT,*
000160  003714                                BLE     1$
000162  010400                        5$:     MOV     R4,R0                   ; INDEX,*                       6013
000164  000207                                RTS     PC                      ;                               5995

; Routine Size:  59 words,      Routine Base:  $CODE$ + 21276
; Maximum stack depth per invocation:  8 words
```

```
;    6037  1     GLOBAL routine DR_RETPKT : novalue =
;    6038  1
;    6039  1     !+
;    6040  1     !       THIS ROUTINE IS CALLED BY PROC_RETPKT FOR ALL PACKETS ORIGINATING AT
;    6041  1     !       THE "DRIVER" PORTION OF THE PROGRAM. THIS INCLUDES PACKETS DESCRIBING
;    6042  1     !       FATAL DEVICE ERRORS.
;    6043  1     !
;    6044  1     !       FOR FATAL DEVICE ERRORS, THIS ROUTINE RELEASES ALL RESOURCES HELD BY
;    6045  1     !       THE CONTROLLER. THE CONTROLLER IS MARKED OFFLINE IN ITS CST, AND ALL
;    6046  1     !       UNITS ATTACHED TO THE CONTROLLER ARE DROPPED.
;    6047  1     !
;    6048  1     !       IMPLICIT INPUTS:
;    6049  1     !               RP_INDX - INDEX OF THE CURRENT RETURN PACKET
;    6050  1     !               RP_ADDR - ADDRESS OF THE CURRENT RETURN PACKET
;    6051  1     !               CST_ADDR - ADDRESS OF THE CURRENT CONTROLLER'S CST
;    6052  1     !               CCTLR - CURRENT CONTROLLER NUMBER
;    6053  1     !-
;    6054  1
;    6055  2         begin
;    6056  2
;    6057  2
;    6058  2         PUTA_BUFF ();                           ! RELEASE ALL I/O BUFFERS HELD BY CONTROLLER
;    6059  2
;    6060  2         incr index from 0 to RP_CNT - 1 do      ! FOR EACH ENTRY IN CONTROLLER'S RP_SAVE
;    6061  2
;    6062  2             if .RP_USE [.index] eql .CCTLR      ! IF VALID RETPKT INDEX
;    6063  2             then
;    6064  2                 PUT_RETPKT (.index);            ! RETURN RETPKT TO POOL
;    6065  2
;    6066  2         QIO [.CCTLR] = 0;                       ! CLEAR NO. OF OUTSTANDING QIOs
;    6067  2         CST_ADDR [STATE] = OFFLINE;             ! MARK CST OFFLINE
;    6068  2         DROP_CTLR (.CCTLR, DU_CFATAL);          ! DROP CONTROLLER'S UNITS
;    6069  2         PUT_RETPKT (.RP_INDX);                  ! PUT BACK RETPKT
;    6070  1         end;                                    ! ROUTINE DR_RETPKT


                                        .SBTTL  DR.RETPKT MULTI-DRIVE TEST ROUTINES
000000  010146                    DR.RETPKT::
                                        MOV     R1,-(SP)                ;                                       6037
000002  004737  000000G                 JSR     PC,PUTA.BUFF            ;                                       6058
000006  005001                          CLR     R1                      ; INDEX                                 6060
000010  116100  000000G           1$:   MOVB    RP.USE(R1),R0           ; *(INDEX),*                            6062
000014  020037  000000G                 CMP     R0,CCTLR
000020  001004                          BNE     2$
000022  010146                          MOV     R1,-(SP)                ; INDEX,*                               6064
000024  004737  000000G                 JSR     PC,PUT.RETPKT
000030  005726                          TST     (SP)+
000032  005201                  2$:     INC     R1                      ; INDEX                                 6060
000034  020127  000007                  CMP     R1,#7                   ; INDEX,*
000040  003763                          BLE     1$
000042  013701  000000G                 MOV     CCTLR,R1                ;                                       6066
000046  105061  000000G                 CLRB    QIO(R1)
000052  013700  000000G                 MOV     CST.ADDR,R0             ;                                       6067
```

```
000056  042760  100000  000002                  BIC     #100000,2(R0)
000064  010146                                  MOV     R1,-(SP)                ;                                       6068
000066  012746  000006                          MOV     #6,-(SP)
000072  004737  000000G                         JSR     PC,DROP.CTLR
000076  013716  000000G                         MOV     RP.INDX,(SP)            ;                                       6069
000102  004737  000000G                         JSR     PC,PUT.RETPKT
000106  022626                                  CMP     (SP)+,(SP)+             ;                                       6055
000110  012601                                  MOV     (SP)+,R1                ;                                       6037
000112  000207                                  RTS     PC

; Routine Size:  38 words,      Routine Base:  $CODE$ + 21464
; Maximum stack depth per invocation:  4 words
```

```
;    6071  1     %sbttl 'RDRX INTERRUPT SERVICE ROUTINES'
;    6072  1
;    6073  1     !+
;    6074  1     !       THERE EXISTS AN RDRX INTERRUPT SERVICE ROUTINE FOR EACH DEVICE
;    6075  1     !       CONTROLLER. EACH SERVICE ROUTINE BEGINS BY SIMPLY SETTING THE
;    6076  1     !       APPROPRIATE CONTROLLER NUMBER INTO "ICTLR"  ALL SERVICE ROUTINES THEN
;    6077  1     !       BRANCH TO A COMMON INTERRUPT PROCESSING ROUTINE.
;    6078  1     !-
;    6079  1
;    6080  2     BGNSRV (AZINT0);
;    6081  2     ICTLR = 0;
;    6082  2     AZINT ();
;    6083  1     ENDSRV;


                                                .SBTTL  AZINT0 RDRX INTERRUPT SERVICE ROUTINES
000000  010046                             AZINT0::MOV     R0,-(SP)                        ;                               6080
000002  005037  000104'                             CLR     ICTLR                           ;                               6081
000006  004737  C00000V                             JSR     PC,AZINT                        ;                               6082
000012  012600                                      MOV     (SP)+,R0                        ;                               6080
000014  000002                                      RTI

; Routine Size:  7 words,       Routine Base:  $CODE$ + 21600
; Maximum stack depth per invocation:  2 words
```

```
;   6084  1     GLOBAL routine AZINT : novalue =
;   6085  1
;   6086  1     !+
;   6087  1     !       THIS IS THE COMMON INTERRUPT SERVICE ROUTINE FOR ALL RDRX CONTROLLERS.
;   6088  1     !       AFTER CALCULATING THE DCT ADDRESS FOR THE INTERRUPTING DEVICE, THIS
;   6089  1     !       ROUTINE WILL SAVE THE CURRENT CONTENTS OF THE SA REGISTER IN THE DCT.
;   6090  1     !       THEN, IF THE "IGNORE INTERRUPT" BIT IS SET, NO FURTHER ACTION IS TAKEN.
;   6091  1     !       OTHERWISE, THE SA VALUE IS CHECKED FOR A FATAL ERROR, AND THE COMMAND
;   6092  1     !       AND RESPONSE RINGS ARE POLLED.
;   6093  1     !-
;   6094  1
;   6095  2         begin
;   6096  2         IDCT_ADDR = DCT + (.ICTLR * DCT_LEN * 2);           ! GET DCT ADDRESS
;   6097  2         ICST_ADDR = CST + (.ICTLR * CST_LEN * 2);           ! GET CST ADDRESS
;   6098  2         IRDRX_ADDR = .ICST_ADDR [IP_ADDR];                  ! GET RDRX ADDRESS
;   6099  2         ICOM_ADDR = COMM_AREA + (.ICTLR * COMM_LEN * 2);    ! GET COMM_AREA ADDR
;   6100  2         IDCT_ADDR [SA_SAVE] = .IRDRX_ADDR [RCSA, RC_ALL];   ! SAVE SA REGISTER
;   6101  2
;   6102  2         if .IDCT_ADDR [IG_INT]                              ! IGNORE INTERRUPT?
;   6103  2         then
;   6104  2             return;                                         ! RETURN IF INTERRUPTS IGNORED
;   6105  2
;   6106  3         if BIT_TST (IDCT_ADDR [SA_SAVE], SA_ERR)            ! IF FATAL ERROR
;   6107  2         then
;   6108  2             FATAL_ERROR ()
;   6109  2         else
;   6110  3             begin
;   6111  3             POLL_CRING ();                                  ! POLL COMMAND RING
;   6112  3             POLL_RRING ();                                  ! POLL RESPONSE RING
;   6113  2             end;
;   6114  2
;   6115  1         end;


                                    .SBTTL  AZINT RDRX INTERRUPT SERVICE ROUTINES
000000  010146                 AZINT:: MOV     R1,-(SP)                        ;                                   6084
000002  005746                         TST     -(SP)
000004  013701  000104'                MOV     ICTLR,R1                        ;                                   6096
000010  010146                         MOV     R1,-(SP)
000012  012746  000022                 MOV     #22,-(SP)
000016  004737  000000G                JSR     PC,BL$MUL
000022  062700  000000G                ADD     #DCT,R0
000026  010037  000100'                MOV     R0,IDCT.ADDR
000032  010116                         MOV     R1,(SP)                         ;                                   6097
000034  012746  000126                 MOV     #126,-(SP)
000040  004737  000000G                JSR     PC,BL$MUL
000044  062700  000000G                ADD     #CST,R0
000050  010037  000076'                MOV     R0,ICST.ADDR
000054  011037  000000G                MOV     (R0),IRDRX.ADDR                 ; ICST.ADDR,*                       6098
000060  010116                         MOV     R1,(SP)                         ;                                   6099
000062  012746  000050                 MOV     #50,-(SP)
000066  004737  000000G                JSR     PC,BL$MUL
000072  062700  000000'                ADD     #COMM.AREA,R0
```

```
000076  010037  000074'                        MOV     R0,ICOM.ADDR
000102  013701  000100'                        MOV     IDCT.ADDR,R1            ;                               6100
000106  013700  000000G                        MOV     IRDRX.ADDR,R0
000112  016066  000002  000010                 MOV     2(R0),10(SP)            ; *,RC.REG
000120  016661  000010  000002                 MOV     10(SP),2(R1)            ; RC.REG,*
000126  032711  040000                         BIT     #4000 ,(R1)             ; *,IDCT.ADDR                   6102
000132  001016                                 BNE     2$                      ;                               6084
000134  016601  000010                         MOV     10(SP),R1               ;                               6106
000140  042701  077777                         BIC     #77777,R1
000144  020127  100000                         CMP     R1,#-100000
000150  001003                                 BNE     1$
000152  004737  000000V                        JSR     PC,FATAL.ERROR          ;                               6108
000156  000404                                 BR      2$                      ;                               6106
000160  004737  000000V             1$:        JSR     PC,POLL.CRING           ;                               6111
000164  004737  000000V                        JSR     PC,POLL.RRING           ;                               6112
000170  062706  000012              2$:        ADD     #12,SP                  ;                               6084
000174  012601                                 MOV     (SP)+,R1
000176  000207                                 RTS     PC

; Routine Size:  64 words,      Routine Base:  $CODE$ + 21316
; Maximum stack depth per invocation:  7 words


;   6116  1
```

```
;    6117  1
;    6118  1      !MMMGLOBAL ROUTINE DUP_RSP : NOVALUE =                                          !ZZZ
;    6119  1      !MMM
;    6120  1      !+
;    6121  1      !       THIS ROUTINE IS CALLED BY POLL_RRING FOR EACH DUP RESPONSE
;    6122  1      !       ITS GENERAL PURPOSE IS TO ACT ON A DATAGRAM OR SEQUENTIAL MESSAGE.
;    6123  1      !       IF THE MESSAGE TYPE IS SEQUENTIAL, THE ROUTINE COPIES THE
;    6124  1      !       CONTENTS OF THE MESSAGE ENVELOPE INTO A RETURN PACKET SO THAT THE
;    6125  1      !       ENVELOPE CAN BE RETURNED TO THE CONTROLLER.
;    6126  1      !
;    6127  1      !       IMPLICIT INPUTS:
;    6128  1      !               ICTLR - INTERRUPTING CONTROLLER NUMBER
;    6129  1      !               IPKT_ADDR - ADDRESS OF MSCP ENVELOPE CONTAINING RESPONSE
;    6130  1      !-
;    6131  1      !    begin
;    6132  1      !
;    6133  1      !    local
;    6134  1      !       R_INDEX : signed word,
;    6135  1      !        DEBUG,                                                 !ZZZ
;    6136  1      !       SRC_ADDR,
;    6137  1      !       DST_ADDR,
;    6138  1      !       R_ADDR : ref block [RP_LEN, word] field (RP_FIELDS);
;    6139  1      !    !PRINTX (DER34);
;    6140  1      !
;    6141  1      !    incr COUNT from 0 to PKT_CNT - 1 do
;    6142  1      !
;    6143  1      !       if (.MSCP_PKT [.COUNT, CRN_LO] eql .IPKT_ADDR [CRN_LO]) and     ! IF THIS IS THE ASSOC CMD
;    6144  1      !          (.MSCP_PKT [.COUNT, CRN_HI] eql .IPKT_ADDR [CRN_HI]) and
;    6145  1      !          (.MSCP_PKT [.COUNT, PKT_LO] neqa .IPKT_ADDR [PKT_LO]) and
;    6146  1      !          ((.MSCP_PKT [.COUNT, OPCODE] and OP_END) neq OP_END) and
;    6147  1      !          (.MSCP_PKT [.COUNT, CONNID] eql CID_DUP) and
;    6148  1      !          ((.IPKT_ADDR [OPCODE] and OP_END) eql OP_END)
;    6149  1      !       then
;    6150  1      !           begin
;    6151  1      !           P_INDEX = .COUNT;                   ! SET PKT NUMBER
;    6152  1      !           exitloop;
;    6153  1      !           end;
;    6154  1      !
;    6155  1      !    if .P_INDEX lss 0                          ! IF COMMAND NOT FOUND
;    6156  1      !    then
;    6157  1      !       begin
;    6158  1      !       PRINTF (DBM108, .IPKT_ADDR [CRN_LO]);   ! UNKNOWN COMMAND REF. NUMBER
;    6159  1      !       return;
;    6160  1      !       end;
;    6161  1      !
;    6162  1      !    if (R_INDEX = GET_RETPKT (.ICTLR)) lss 0   ! IF RETPKT IS NOT AVAILABLE
;    6163  1      !    then
;    6164  1      !        DEBUG = TRUE                           !TO SEE IF THIS PATH TAKEN          ZZZ
;    6165  1      !!      PRINTF (DBM112)                        ! "DUP-RSP: RETPKT NOT AVAILABLE"   ZZZ
;    6166  1      !    else
;    6167  1      !       begin
;    6168  1      !       SRC_ADDR = .IPKT_ADDR + 6;             ! SET UP COPY (SKIP OVER PKT DESC)
;    6169  1      !       R_ADDR = DST_ADDR = RETPKT + (.R_INDEX * RP_LEN * 2);   ! START OF ALLOCATED RETPKT
```

```
;    6170  1      !
;    6171  1      !       incr COUNT from 1 to RP_LEN do
;    6172  1      !           begin
;    6173  1      !           .DST_ADDR = ..SRC_ADDR;          ! COPY 1 WORD
;    6174  1      !           DST_ADDR = .DST_ADDR + 2;        ! ADVANCE DESTINATION ADDR
;    6175  1      !           SRC_ADDR = .SRC_ADDR + 2;        ! ADVANCE SOURCE ADDR
;    6176  1      !           end;                             ! COPY LOOP
;    6177  1      !
;    6178  1      !       IN_IODQ (.R_INDEX);                  ! PUT RETPKT INDEX INTO IODQ
;    6179  1      !       end;                                 ! IF RETPKT WAS ALLOCATED
;    6180  1      !
;    6181  1      !
;    6182  1      !   if .P_INDEX geq 0                        ! IF ASSOC CMD PKT WAS FOUND
;    6183  1      !   then
;    6184  1      !       PUT_PKT (.P_INDEX);                  ! RETURN COMMAND PACKET TO POOL
;    6185  1      !
;    6186  1      !   end;                                     ! ROUTINE DUP RSP
;    6187  1
```

```
;    6188  1     GLOBAL routine FATAL_ERROR : novalue =
;    6189  1
;    6190  1     !+
;    6191  1     !       THIS ROUTINE IS CALLED BY THE INTERRUPT SERVICE ROUTINE (AZINT) UPON
;    6192  1     !       DETECTING AN UNRECOVERABLE ERROR THROUGH THE DEVICE'S SA REGISTER.
;    6193  1     !       ITS PURPOSE IS TO CLEAN UP DEVICE DATA IN THE "DRIVER" PORTION OF
;    6194  1     !       THE EXERCISER, AND TO INFORM THE "PROGRAM" PORTION OF THE EVENT VIA
;    6195  1     !       RETURN PACKET.
;    6196  1     !
;    6197  1     !       IMPLICIT INPUTS:
;    6198  1     !               ICTLR - INTERRUPTING CONTROLLER NUMBER
;    6199  1     !               IDCT_ADDR - ADDRESS OF INTERRUPTING CONTROLLER'S DCT
;    6200  1     !               ICST_ADDR - ADDRESS OF INTERRUPTING CONTROLLER S CST
;    6201  1     !               IRDRX_ADDR - ADDRESS OF INTERRUPTING CONTROLLER'S IP REGISTER
;    6202  1     !-
;    6203  1
;    6204  2         begin
;    6205  2
;    6206  2         local
;    6207  2             index : signed word,
;    6208  2             U_SAVE : word;
;    6209  2
;    6210  2         SA_REG = .IDCT_ADDR [SA_SAVE];
;    6211  2         U_SAVE = .L$LUN;                                    ! SAVE PRE-INTERRUPT CURRENT UNIT NUMBER
;    6212  2         C_ERR_TBL [.ICTLR, C_ERR_HRD] = .C_ERR_TBL [.ICTLR, C ERR_HRD] + 1;
;    6213  2
;    6214  2         if .APT_MODE
;    6215  2         then
;    6216  3             begin
;    6217  3             .MAIL_BOX_TESTNUM = 1;
;    6218  3             .MAIL_BOX_SUBTST = 0;
;    6219  2             end;
;    6220  2
;    6221  2         L$LUN = .ICST_ADDR [OF_UN + OF_DATA, D_UNIT];       ! SET CURRENT UNIT TO FIRST IN CONTROLLER
;    6222  2         ERRDF (14, EGD_14, EMS_14);                         ! FATAL CONTROLLER ERROR
;    6223  2         L$LUN = .U_SAVE;                                    ! RESTORE PRE-INTERRUPT CURRENT UNIT
;    6224  2         DRV_CTLERR (.ICTLR);                                ! CLEAN UP DRIVER DATA FOR CONTROLLER
;    6225  2
;    6226  2         if (index = GET_RETPKT (.ICTLR)) lss 0              ! TRY TO GET A RETPKT; IF FAILURE
;    6227  2         then
;    6228  3             PRINTF (DBM18)                                  ! "FATAL_ERROR: RETPKT NOT AVAILABLE"
;    6229  2         else
;    6230  3             begin                                           ! IF RETPKT WAS ALLOCATED
;    6231  3             RETPKT [.index, CONID] = CID_DRIVER;            ! SET CONNECTION ID TO "DRIVER"
;    6232  3             RETPKT [.index, MESTYP] = MT_FATAL;             ! FATAL ERROR
;    6233  3             RETPKT [.index, CTLR] = .ICTLR;                 ! CONTROLLER NUMBER
;    6234  3             IN_IODQ (.index);                               ! LOAD RETPKT INDEX INTO IODQ
;    6235  2             end;                                            ! IF RETPKT WAS ALLOCATED
;    6236  2
;    6237  1         end;                                                ! ROUTINE FATAL_ERR

                                        .SBTTL  FATAL.ERROR RDRX INTERRUPT SERVICE ROUTINES
```

```
000000  004137  000000G                FATAL.ERROR::
                                        JSR     R1,$SAVE2                       ;                                       6188
000004  013700  000100'                MOV     IDCT.ADDR,R0                    ;                                       6210
000010  016037  000002  000000G        MOV     2(R0),SA.REG
000016  013701  000000G                MOV     L$LUN,R1                        ; *,U.SAVE                              6211
000022  013700  000104'                MOV     ICTLR,R0                        ;                                       6212
000026  006300                        ASL     R0
000030  105260  000000G                INCB    C.ERR.TBL(R0)
000034  032737  000001  001254'        BIT     #1,APT.MODE                     ;                                       6214
000042  001405                        BEQ     1$
000044  012777  000001  001256'        MOV     #1,@MAIL.BOX.TESTNUM            ;                                       6217
000052  005077  001260'                CLR     @MAIL.BOX.SUBTST                ;                                       6218
000056  013700  000076'        1$:     MOV     ICST.ADDR,R0                    ;                                       6221
000062  016002  000006                MOV     6(R0),R2
000066  000302                        SWAB    R2
000070  042702  177760                BIC     #177760,R2
000074  010237  000000G                MOV     R2,L$LUN
000100  104455                        TRAP    55                              ;                                       6222
000102  000016                        .WORD   16
000104  000000G                       .WORD   EGD.14
000106  000000G                       .WORD   EMS.14
000110  010137  000000G                MOV     R1,L$LUN                        ; U.SAVE,*                              6223
000114  013746  000104'                MOV     ICTLR,-(SP)                     ;                                       6224
000120  004737  000000G                JSR     PC,DRV.CTLERR
000124  013716  000104'                MOV     ICTLR,(SP)                      ;                                       6226
000130  004737  000000G                JSR     PC,GET.RETPKT
000134  010001                        MOV     R0,R1                           ; *,INDEX
000136  002007                        BGE     2$
000140  012716  000000G                MOV     @DBM18,(SP)                     ;                                       6228
000144  012746  000001                MOV     #1,-(SP)
000150  010600                        MOV     SP,R0                           ; SP,*
000152  104417                        TRAP    17
000154  000424                        BR      3$                              ;                                       6226
000156  010116                2$:     MOV     R1,(SP)                         ; INDEX,*                               6231
000160  012746  000054                MOV     #54,-(SP)
000164  004737  000000G                JSR     PC,BL$MUL
000170  062700  000002G                ADD     #RETPKT+2,R0
000174  112760  000003  000001        MOVB    #3,1(R0)
000202  013702  000104'                MOV     ICTLR,R2                        ;                                       6233
000206  042702  177760                BIC     #177760,R2
000212  112710  000060                MOVB    #60,(R0)
000216  150210                        BISB    R2,(R0)
000220  010116                        MOV     R1,(SP)                         ; INDEX,*                               6234
000222  004737  000000G                JSR     PC,IN.IODQ
000226  022626                3$:     CMP     (SP)+,(SP)+                     ;                                       6204
000230  000207                        RTS     PC                              ;                                       6188

; Routine Size:  77 words,      Routine Base:  $CODE$ + 22016
; Maximum stack depth per invocation:  7 words
```

```
;    6238  1     GLOBAL routine POLL_CRING : novalue =
;    6239  1
;    6240  1     !+
;    6241  1     !       THIS ROUTINE IS CALLED BY THE RDRX INTERRUPT SERVICE ROUTINE (AZINT)
;    6242  1     !       FOR EACH DEVICE INTERRUPT EXCEPT DURING INITIALIZATION OR FATAL ERROR.
;    6243  1     !       ITS PURPOSE IS TO SCAN THE DEVICE'S COMMAND RING AND CHECK FOR ANY
;    6244  1     !       COMMAND SLOTS THAT HAVE BEEN "TAKEN" BY THE CONTROLLER. SUCH SLOTS
;    6245  1     !       HAVE BEEN RETURNED TO THE HOST, INDICATED BY A ZERO OWNERSHIP BIT. FOR
;    6246  1     !       EACH SLOT THAT HAS BEEN RETURNED TO THE HOST, THE CRING COUNT IS
;    6247  1     !       DECREMENTED, AND THE CR_POLL ADDRESS IS ADVANCED TO THE NEXT SLOT IN
;    6248  1     !       THE COMMAND RING.
;    6249  1     !
;    6250  1     !       IMPLICIT INPUTS:
;    6251  1     !               ICTLR - INTERRUPTING CONTROLLER NUMBER
;    6252  1     !               IDCT_ADDR - ADDRESS OF INTERRUPTING CONTROLLER'S DCT
;    6253  1     !               ICOM_ADDR - ADDRESS OF INTERRUPTING CONTROLLER'S COMM_AREA
;    6254  1     !-
;    6255  1
;    6256  2         begin
;    6257  2         ICOM_ADDR [CMD_INT] = 0;                                    ! CLEAR COMMAND INTERRUPT WORD IN RING HEADER    ZZZ
;    6258  2
;    6259  3         while ((.IDCT_ADDR [CRING_CNT] gtru 0) and                  ! WHILE # OF COMMANDS IN CRING > 0 AND
;    6260  2             not (BIT_TST ((.IDCT_ADDR [CR_POLL] + 2), ED_OWN))) do  ! CURRENT SLOT IS HOST-OWNED
;    6261  3             begin
;    6262  3             IDCT_ADDR [CRING_CNT] = .IDCT_ADDR [CRING_CNT] - 1;     ! DECREMENT # CMDs IN CRING
;    6263  3             IDCT_ADDR [CR_POLL] = .IDCT_ADDR [CR_POLL] + 4;         ! ADVANCE TO NEXT SLOT TO POLL
;    6264  3
;    6265  3             if .IDCT_ADDR [CR_POLL] gtra .IDCT_ADDR [CR_END]        ! IF BEYOND END OF RING
;    6266  3             then
;    6267  3                 IDCT_ADDR [CR_POLL] = .IDCT_ADDR [CR_BEG];          ! SET POINTER TO TOP OF CRING
;    6268  3
;    6269  2             end;
;    6270  2
;    6271  2     !ZZZ    ICOM_ADDR [CMD_INT] = 0;                                    ! CLEAR COMMAND INTERRUPT WORD IN RING HEADE
R
;    6272  1         end;


                                        .SBTTL  POLL.CRING RDRX INTERRUPT SERVICE ROUTINES
000000  004137  000000G        POLL.CRING::
                                JSR     R1,$SAVE2                       ;                                       6238
000004  013700  000074'                 MOV     ICOM.ADDR,R0            ;                                       6257
000010  005060  000004                  CLR     4(R0)
000014  013701  000100'                 MOV     IDCT.ADDR,R1            ;                                       6259
000020  012702  000016                  MOV     #16,R2                  ;                                       6263
000024  060102                          ADD     R1,R2
000026  105711                 1$:     TSTB    (R1)                    ;                                       6259
000030  001422                          BEQ     2$
000032  016100  000016                  MOV     16(R1),R0               ;                                       6260
000036  016000  000002                  MOV     2(R0),R0
000042  042700  077777                  BIC     #77777,R0
000046  020027  100000                  CMP     R0,#-100000
000052  001411                          BEQ     2$
000054  105311                          DECB    (R1)                    ;                                       6262
```

```
000056  062712  000004                          ADD     #4,(R2)                 ;                       6263
000062  021261  000012                          CMP     (R2),12(R1)             ;                       6265
000066  101757                                  BLOS    1$
000070  016112  000010                          MOV     10(R1),(R2)             ;                       6267
000074  000754                                  BR      1$                      ;                       6259
000076  000207                          2$:     RTS     PC                      ;                       6238

; Routine Size:  32 words,      Routine Base:  $CODE$ + 22250
; Maximum stack depth per invocation:  4 words
```

```
;   6273  1     GLOBAL routine POLL_RRING : novalue =
;   6274  1
;   6275  1
;   6276  1     !+
;   6277  1     !       THIS ROUTINE IS CALLED BY THE RDRX INTERRUPT SERVICE ROUTINE (AZINT)
;   6278  1     !       FOR EACH DEVICE INTERRUPT EXCEPT DURING INITIALIZATION OR FATAL ERROR.
;   6279  1     !       ITS PURPOSE IS TO SCAN THE DEVICE'S RESPONSE RING AND CHECK FOR ANY
;   6280  1     !       SLOTS WHICH HAVE BEEN RETURNED TO THE HOST (OWNERSHIP BIT = 0). FOR
;   6281  1     !       EACH SUCH SLOT, THE ASSOCIATED MESSAGE IS PROCESSED BASED ON ITS
;   6282  1     !       CONNECTION ID (DISK OR DUP). AFTER PROCESSING, THE MESSAGE PACKET
;   6283  1     !       IS RE-INITIALIZED AND RETURNED TO THE CONTROLLER (OWNERSHIP BIT SET
;   6284  1     !       TO 1).
;   6285  1     !
;   6286  1     !       IMPLICIT INPUTS:
;   6287  1     !               ICTLR - NUMBER OF INTERRUPTING CONTROLLER
;   6288  1     !               IDCT_ADDR - ADDRESS OF INTERRUPTING CONTROLLER'S DCT
;   6289  1     !-
;   6290  1
;   6291  2         begin
;   6292  2
;   6293  2         local
;   6294  2             TEMP : word;                                          ! MMM
;   6295  2
;   6296  2         ICOM_ADDR [RSP_INT] = 0;                                  ! CLR RESPONSE INTERRUPT WRD IN RING HEADER
    ZZZ
;   6297  2         TEMP = .PAR_TSD;                                          ! MMM
;   6298  2
;   6299  2         while not (BIT_TST ((.IDCT_ADDR [RR_POLL] + 2), ED_OWN)) do   ! WHILE 0 = 0
;   6300  3             begin
;   6301  3             IPKT_ADDR = ..IDCT_ADDR [RR_POLL] - 10;               ! ADDRESS OF RESPONSE PACKET
;   6302  3
;   6303  3
;   6304  4     IF NOT (.IPKT_ADDR [CONNID] EQL CID_DUP)                !       ZZZ
;   6305  3             THEN                                            !       ZZZ
;   6306  3             (CREDIT_BAL = .CREDIT_BAL + .IPKT_ADDR [CREDITS]);      !ZZZ
;   6307  3     !IT WAS NOTICE THAT DUP WAS SENDIND BACK CREDITS WHICH IT SHOULD NOT.    !ZZZ
;   6308  3             selectoneu .IPKT_ADDR [CONNID] of
;   6309  3                 set
;   6310  3
;   6311  3                 [CID_DISK] :        DISK_RSP ();
;   6312  3
;   6313  3     !MMM            [CID_DUP]  :        DUP_RSP  ();                        !ZZZ
;   6314  3
;   6315  3                 [otherwise] :       PRINTF (DBM20, .IPKT_ADDR [CONNID], .IRDRX_ADDR);
;   6316  3                                                                 ! "BAD CONN ID = XXXXX FROM XXXXXX"
;   6317  3                 tes;
;   6318  3
;   6319  3
;   6320  3     !           if .PAR_TSD                                       ! MMM
;   6321  3     !           then
;   6322  3     !               if  not .TEMP
;   6323  3     !               then
;   6324  3     !                   return;                                   ! MMM
;   6325  3
```

```
;    6326  3              IPKT_ADDR [MSGLEN] = MSG_LEN * 2;                          ! RE-INIT PKT FIELDS; MESSAGE LENGTH
;    6327  3              IDCT_ADDR [RR_POLL] = .IDCT_ADDR [RR_POLL] + 2;            ! ADVANCE TO HI ORDER WORD OF RING SLOT
;    6328  3              .IDCT_ADDR [RR_POLL] = .IPKT_ADDR [PKT_HI];                ! RETURN SLOT TO CONTROLLER
;    6329  3              .IDCT_ADDR [RR_POLL] = ..IDCT_ADDR [RR_POLL] or ED_OWN or ED_FLAG; ! OWNERSHIP TOO
;    6330  3              IDCT_ADDR [RR_POLL] = .IDCT_ADDR [RR_POLL] + 2;            ! ADVANCE TO NEXT RRING SLOT
;    6331  3
;    6332  3
;    6333  3              if .IDCT_ADDR [RR_POLL] gtra .IDCT_ADDR [RR_END]           ! IF BEYOND END OF RING
;    6334  3
;    6335  3              then
;    6336  3                  IDCT_ADDR [RR_POLL] = .IDCT_ADDR [RR_BEG];             ! CYCLE TO TOP OF RING
;    6337  3
;    6338  2              end;                                                       ! WHILE LOOP
;    6339  2
;    6340  2      !ZZZ    ICOM_ADDR [RSP_INT] = 0;                                          ! CLR RESPONSE INTERRUPT WRD IN RING
 HEADER
;    6341  1          end;


                                        .SBTTL  POLL.RRING RDRX INTERRUPT SERVICE ROUTINES
000000  004137  000000G          POLL.RRING::
                                        JSR     R1,$SAVE3                          ;                                    6273
000004  013700  000074'                 MOV     ICOM.ADDR,R0                       ;                                    6296
000010  005060  000006                  CLR     6(R0)
000014  013701  000100'                 MOV     IDCT.ADDR,R1                       ;                                    6299
000020  062701  000014                  ADD     #14,R1
000024  011100                   1$:    MOV     (R1),R0
000026  016000  000002                  MOV     2(R0),R0
000032  042700  077777                  BIC     #77777,R0
000036  020027  100000                  CMP     R0,#-100000
000042  001476                         BEQ     5$
000044  017137  000000  000000G        MOV     @0(R1),IPKT.ADDR                   ;                                    6301
000052  162737  000012  000000G        SUB     #12,IPKT.ADDR
000060  013700  000000G                MOV     IPKT.ADDR,R0                       ;                                    6304
000064  005002                         CLR     R2
000066  156002  000011                  BISB    11(R0),R2
000072  020227  000002                  CMP     R2,#2
000076  001406                         BEQ     2$
000100  116003  000010                  MOVB    10(R0),R3                          ;                                    6306
000104  042703  177760                  BIC     #177760,R3
000110  060337  000000G                ADD     R3,CREDIT.BAL
000114  005702                   2$:    TST     R2                                 ;                                    6311
000116  001003                         BNE     3$
000120  004737  000000V                JSR     PC,DISK.RSP
000124  000413                         BR      4$                                 ;                                    6308
000126  013746  000000G          3$:    MOV     IRDRX.ADDR,-(SP)                   ;                                    6315
000132  010246                         MOV     R2,-(SP)
000134  012746  000000G                MOV     #DBM20,-(SP)
000140  012746  000003                  MOV     #3,-(SP)
000144  010600                         MOV     SP,R0                              ; SP,*
000146  104417                         TRAP    17
000150  062706  000010                  ADD     #10,SP
000154  013700  000000G          4$:    MOV     IPKT.ADDR,R0                       ;                                    6326
000160  012760  000074  000006        MOV     #74,6(R0)
```

```
000166  013702  000100'                        MOV     IDCT,ADDR,R2                    ;                       6327
000172  010201                                  MOV     R2,R1
000174  062701  000014                        ADD     #14,R1
000200  062711  000002                        ADD     #2,(R1)
000204  016071  000002  000000                MOV     2(R0),B0(R1)                    ;                       6328
000212  052771  140000  000000                BIS     #-40000,B0(R1)                  ;                       6329
000220  062711  000002                        ADD     #2,(R1)                         ;                       6330
000224  021162  000006                        CMP     (R1),6(R2)                      ;                       6333
000230  101675                                BLOS    1$
000232  016211  000004                        MOV     4(R2),(R1)                      ;                       6336
000236  000672                                BR      1$                              ;                       6299
000240  000207                          5$:   RTS     PC                              ;                       6273

; Routine Size:  81 words,      Routine Base:  $CODE$ + 22350
; Maximum stack depth per invocation:  10 words

;   6342  1
```

```
;    6343  1
;    6344  1
;    6345  1     GLOBAL routine DISK_RSP : novalue =
;    6346  1
;    6347  1
;    6348  1     !+
;    6349  1     !       THIS ROUTINE IS CALLED BY POLL_RRING FOR EACH RESPONSE MESSAGE
;    6350  1     !       WHICH HAS A CONNECTION ID INDICATING A DISK MSCP ORIGINATOR
;    6351  1     !       (I.E., ALL EXCEPT DUP RESPONSES). ITS PURPOSE IS TO PASS
;    6352  1     !       CONTROL TO THE APPROPRIATE ROUTINE BASED ON THE MESSAGE TYPE
;    6353  1     !       FIELD (SEQUENTIAL, DATAGRAM, OR CREDIT NOTIFICATION).
;    6354  1     !
;    6355  1     !       IMPLICIT INPUTS:
;    6356  1     !               IPKT_ADDR - ADDRESS OF MSCP PACKET CONTAINING RESPONSE
;    6357  1     !                           MESSAGE
;    6358  1     !-
;    6359  1
;    6360  1
;    6361  1
;    6362  1         selectoneu .IPKT_ADDR [MSGTYP] of
;    6363  1
;    6364  1
;    6365  1             set
;    6366  1
;    6367  1             [MT_SEQ] :      SEQUEN ();
;    6368  1
;    6369  1             [MT_DG] :       DATAGM ();
;    6370  1
;    6371  1             [otherwise] :   PRINTF (DBM21, .IPKT_ADDR [MSGTYP]);    ! "MESSAGE TYPE XX RECEIVED"
;    6372  1             tes;


                                        .SBTTL  DISK.RSP RDRX INTERRUPT SERVICE ROUTINES
000000  010146                  DISK.RSP::
                                        MOV     R1,-(SP)                        ;                       6345
000002  013700  000000G                 MOV     IPKT.ADDR,R0                    ;                       6362
000006  116001  000010                  MOVB    10(R0),R1
000012  006201                          ASR     R1
000014  006201                          ASR     R1
000016  006201                          ASR     R1
000020  006201                          ASR     R1
000022  042701  177760                  BIC     #177760,R1
000026  001003                          BNE     1$                              ;                       6367
000030  004737  000000V                 JSR     PC,SEQUEN
000034  000417                          BR      3$                              ;                       6362
000036  020127  000001          1$:     CMP     R1,#1                           ;                       6369
000042  001003                          BNE     2$
000044  004737  000000V                 JSR     PC,DATAGM
000050  000411                          BR      3$                              ;                       6362
000052  010146                  2$:     MOV     R1,-(SP)                        ;                       6371
000054  012746  000000G                 MOV     #DBM21,-(SP)
000060  012746  000002                  MOV     #2,-(SP)
000064  010600                          MOV     SP,R0                           ; SP,*
```

```
000066  104417                          TRAP    17
000070  062706  000006                  ADD     #6,SP
000074  012601                  3$:     MOV     (SP)+,R1        ;                       6345
000076  000207                          RTS     PC

; Routine Size:  32 words,      Routine Base:  $CODE$ + 22612
; Maximum stack depth per invocation:  6 words


;   6373  1
;   6374  1
;   6375  1
```

```
;    6376  1     GLOBAL routine SEQUEN : novalue =
;    6377  1
;    6378  1     !+
;    6379  1     !       THIS ROUTINE IS CALLED BY DISK_RSP FOR EACH DISK MSCP RESPONSE MESSAGE
;    6380  1     !       WITH THE "SEQUENTIAL" MESSAGE TYPE. ITS GENERAL PURPOSE IS TO COPY THE
;    6381  1     !       CONTENTS OF THE MESSAGE PACKET INTO A RETURN PACKET SO THAT THE
;    6382  1     !       PACKET CAN BE RETURNED TO THE CONTROLLER.   IN ADDITION,
;    6383  1     !       IF THE COMMAND WAS AN I/O TRANSFER (READ, WRITE, OR ACCESS), THEN SOME
;    6384  1     !       FIELDS OF THE COMMAND PACKET ARE COPIED INTO THE RETURN PACKET.
;    6385  1     !
;    6386  1     !       IMPLICIT INPUTS:
;    6387  1     !               ICTLR - INTERRUPTING CONTROLLER NUMBER
;    6388  1     !               IPKT_ADDR - ADDRESS OF MSCP PACKET CONTAINING RESPONSE
;    6389  1     !-
;    6390  1
;    6391  2         begin
;    6392  2
;    6393  2         local
;    6394  2             P_INDEX : signed word initial (-1),                          ! ASSUME NO ASSOCIATED COMMAND PKT
;    6395  2             R_INDEX : signed word,
;    6396  2             SRC_ADDR,
;    6397  2             DST_ADDR,
;    6398  2             SAV_ADDR,
;    6399  2             R_ADDR : ref block [RP_LEN, word] field (RP_FIELDS);
;    6400  2
;    6401  2         builtin                                                          !MMM
;    6402  2
;    6403  2             HALT;                                                        !MMM
;    6404  2
;    6405  2         incr COUNT from 0 to PKT_CNT - 1 do
;    6406  2
;    6407  2             if (.MSCP_PKT [.COUNT, CRN_LO] eql .IPKT_ADDR [CRN_LO]) and  ! IF THIS IS THE ASSOC CMD
;    6408  2                (.MSCP_PKT [.COUNT, CRN_HI] eql .IPKT_ADDR [CRN_HI]) and
;    6409  2                (.MSCP_PKT [.COUNT, PKT_LO] neqa .IPKT_ADDR [PKT_LO]) and
;    6410  2                ((.MSCP_PKT [.COUNT, OPCODE] and OP_END) neq OP_END) and
;    6411  2                (.MSCP_PKT [.COUNT, MSGTYP] eql MT_SEQ) and
;    6412  2                ((.IPKT_ADDR [OPCODE] and OP_END) eql OP_END) and
;    6413  3                (.PKT_USE [.COUNT] eql .ICTLR)
;    6414  2             then
;    6415  3                 begin
;    6416  3                 P_INDEX = .COUNT;                                       ! SET PKT NUMBER
;    6417  3                 exitloop;
;    6418  2                 end;
;    6419  2
;    6420  2         if .P_INDEX lss 0                                                ! IF COMMAND NOT FOUND
;    6421  2         then
;    6422  3             begin
;    6423  3             PRINTF (DBM108, .IPKT_ADDR [CRN_HI], .IPKT_ADDR [CRN_LO]);  ! UNKNOWN COMMAND REF. NUMBER
;    6424  3             return;
;    6425  2             end;
;    6426  2
;    6427  3         if .MSCP_PKT [.P_INDEX, OPCODE] neq (.IPKT_ADDR [OPCODE] and (not OP_END))  ! IF OPCODE MISMATCH
;    6428  2         then
```

```
;   6429  2               PRINTF (DBM111, .MSCP_PKT [.P_INDEX, OPCODE], .IPKT_ADDR [OPCODE], .IPKT_ADDR [CRN_HI], .IPKT_ADDR [CRN_LO])
;
;   6430  2
;   6431  3           if ((.IPKT_ADDR [OPCODE] eql (OP_RD or OP_END)) or
;   6432  2               (.IPKT_ADDR [OPCODE] eql (OP_WRT or OP_END))) and
;   6433  3              ((.IPKT_ADDR [STATUS_CODE] eql ST_SUC) and
;   6434  2               (.IPKT_ADDR [STATUS_SUBCODE] eql 0)) and
;   6435  3              ((.MSCP_PKT [.P_INDEX, BC_LO] neq .IPKT_ADDR [BC_LO]) or
;   6436  3               (.MSCP_PKT [.P_INDEX, BC_HI] neq .IPKT_ADDR [BC_HI]))
;   6437  2           then
; P 6438  2               PRINTF (DBM112,
; P 6439  2                       .MSCP_PKT [.P_INDEX, BC_HI], .MSCP_PKT [.P_INDEX, BC_LO], .IPKT_ADDR [BC_HI], .IPKT_ADDR [BC_LO],
;   6440  2                       .IPKT_ADDR [CRN_HI], .IPKT_ADDR [CRN_LO]);
;   6441  2
;   6442  2           if .MSCP_PKT [.P_INDEX, RSP_RECEIVED]
;   6443  2           then
;   6444  3               begin
;   6445  3               PRINTF (DBM120, .MSCP_PKT [.P_INDEX, CRN_HI], .MSCP_PKT [.P_INDEX, CRN_LO]);
;   6446  3               PUT_PKT (.P_INDEX);
;   6447  3               return;
;   6448  3               end
;   6449  2           else
;   6450  2               MSCP_PKT [.P_INDEX, RSP_RECEIVED] = TRUE;                       ! MARK RESPONSE RECEIVED
;   6451  2
;   6452  2           if (R_INDEX = GET_RETPKT (.ICTLR)) lss 0                            ! IF RETPKT IS NOT AVAILABLE
;   6453  2           then
;   6454  3               begin
;   6455  3               PRINTF (DBM22);                                                 ! "SEQUEN: RETPKT NOT AVAILABLE"
;   6456  3               PUT_PKT (.P_INDEX);
;   6457  3               return;
;   6458  3               end
;   6459  2           else
;   6460  3               begin
;   6461  3               SRC_ADDR = .IPKT_ADDR + 6;                                  ! SET UP COPY (SKIP OVER PKT DESC)
;   6462  3               R_ADDR = DST_ADDR = RETPKT + (.R_INDEX * RP_LEN * 2);       ! START OF ALLOCATED RETPKT
;   6463  3
;   6464  3               incr COUNT from 1 to RP_LEN do
;   6465  4                   begin
;   6466  4                   .DST_ADDR = ..SRC_ADDR;                                 ! COPY 1 WORD
;   6467  4                   DST_ADDR = .DST_ADDR + 2;                               ! ADVANCE DESTINATION ADDR
;   6468  4                   SRC_ADDR = .SRC_ADDR + 2;                               ! ADVANCE SOURCE ADDR
;   6469  4
;   6470  5                   if .IPKT_ADDR [OPCODE] eql (OP_ONL or OP_END)           ! IF THIS IS THE ONLINE END MESSAGE
;   6471  4                   then
;   6472  4                       if .COUNT eql 10                                    ! SKIP OVER RESERVED WORDS
;   6473  4                       then
;   6474  4                           SRC_ADDR = .SRC_ADDR + 4;                       !       IN ONLINE END   MESSAGE
;   6475  3                   end;                                                    ! COPY LOOP
;   6476  3
;   6477  3               R_ADDR [CTLR] = .ICTLR;                                     ! LOAD CONTROLLER NUMBER INTO PKT
;   6478  3
;   6479  3               if .P_INDEX geq 0                                           ! IF ASSOC. CMD PKT WAS FOUND
;   6480  3               then
;   6481  3
```

```
;    6482  3                  if (.IPKT_ADDR [OPCODE] eql (OP_RD or OP_END)) or                   ! IF END MESSAGE IS
;    6483  3                     (.IPKT_ADDR [OPCODE] eql (OP_WRT or OP_END)) or                  !      READ, WRITE, OR
;    6484  4                     (.IPKT_ADDR [OPCODE] eql (OP_ACC or OP_END))                     !      ACCESS
;    6485  3                  then
;    6486  4                      begin
;    6487  4                      R_ADDR [CMDMOD] = .MSCP_PKT [.P_INDEX, MODIFY];                 ! COPY
;    6488  4                      R_ADDR [CBCNT_LO] = .MSCP_PKT [.P_INDEX, BC_LO];                ! RELEVANT
;    6489  4                      R_ADDR [CBCNT_HI] = .MSCP_PKT [.P_INDEX, BC_HI];                ! FIELDS
;    6490  4                      R_ADDR [LBN_LO] = .MSCP_PKT [.P_INDEX, LBN_L];                  ! FROM
;    6491  4                      R_ADDR [LBN_HI] = .MSCP_PKT [.P_INDEX, LBN_H];                  ! COMMAND
;    6492  4                      R_ADDR [BUFF_0] = .MSCP_PKT [.P_INDEX, BUF_0];                  ! PACKET
;    6493  4                      R_ADDR [BUFF_1] = .MSCP_PKT [.P_INDEX, BUF_1];                  ! TO RETPKT
;    6494  3                      end;                                                            ! IF ENDCODE WAS READ/WRITE/ACCESS
;    6495  3
;    6496  3                  IN_IODQ (.R_INDEX);                                                 ! PUT RETPKT INDEX INTO IODQ
;    6497  2                  end;                                                                ! IF RETPKT WAS ALLOCATED
;    6498  2
;    6499  2              if (.IPKT_ADDR [STATUS_CODE] neq  ST_SUC) or
;    6500  3                 (.IPKT_ADDR [STATUS_SUBCODE] neq 0)
;    6501  2              then
;    6502  2                  LAST_PKT [.ICTLR, LAST_HRD_ERR] = HRD_OCCURED                       ! SAVE ERROR CONDITION
;    6503  2              else
;    6504  2                  LAST_PKT [.ICTLR, LAST_HRD_ERR] = HRD_NOT_OCCURED;                  !
;    6505  2
;    6506  2             LAST_PKT [.ICTLR, LAST_CRN_LO] = .IPKT_ADDR [CRN_LO];                    ! SAVE COMMAND REFERENCE NUMBER
;    6507  2             LAST_PKT [.ICTLR, LAST_CRN_HI] = .IPKT_ADDR [CRN_HI];                    !
;    6508  2     !MMM    SCAN_ERRLOG ();                                                          ! PRINT ANY ASSOCIATED ERROR-LOGS
;    6509  2
;    6510  2              if (.R_ADDR [FLAGS] and %o'40') eql %o'40'                              ! MMM IF ERROR LOG(S) GENERATED
;    6511  2              then                                                                    ! MMM PRINT RESPONSE PACKET
;    6512  3                 begin
;    6513  3                 PRINTB (DBM123);
;    6514  3                 EMS_R2 (.R_ADDR);
;    6515  3                 EMS_R1 (.R_ADDR);
;    6516  2                 end;
;    6517  2
;    6518  2     !MMM    SCAN_ERRLOG ( );                                                             ! PRINT ANY ASSOCIATED ERROR LOG
S MMM
;    6519  2
;    6520  2
;    6521  2              if .CSR_MEM and .TST_PAR                                    !MMM
;    6522  2              then
;    6523  3                  if ((..CSR_ADD and %o'100000') eqlu %o'100000')         !MMM
;    6524  2                  then
;    6525  3                      begin
;    6526  3                      PRINTF (DBM125, ..CSR_ADD);
;    6527  3                      .CSR_ADD = %o'40000';                                           !MMM PRINT EXTENDED CSR
;    6528  3                      PRINTF (DBM126, ..CSR_ADD);
;    6529  3                      HALT ();                                                        ! MMM HALT ON HOST MEMORY PARI
TY ERROR
;    6530  2                      end;
;    6531  2
;    6532  2              if .P_INDEX geq 0                                                   ! IF ASSOC CMD PKT WAS FOUND
;    6533  2              then
;    6534  2                  PUT_PKT (.P_INDEX);                                             ! RETURN COMMAND PACKET TO POOL
```

```
;   6535  2
;   6536  1        end;                                                                    ! ROUTINE DISK_RSP


                                                .SBTTL  SEQUEN RDRX INTERRUPT SERVICE ROUTINES
000000  004137  000000G                  SEQUEN::JSR     R1,$SAVE5                       ;                                       6376
000004  005746                                  TST     -(SP)
000006  012746  177777                          MOV     #-1, (SP)                       ; *,P.INDEX                             6391
000012  013701  000000G                          MOV     IPKT.ADDR,R1                    ;                                       6407
000016  005002                                  CLR     R2                              ; COUNT                                 6405
000020  010246                          1$:     MOV     R2,-(SP)                        ; COUNT,*                               6407
000022  012746  000106                          MOV     #106,-(SP)
000026  004737  000000G                          JSR     PC,BL$MUL
000032  022626                                  CMP     (SP)+,(SP)+
000034  026061  000012G 000012                  CMP     MSCP.PKT+12(R0),12(R1)
000042  001030                                  BNE     2$
000044  026061  000014G 000014                  CMP     MSCP.PKT+14(R0),14(R1)          ;                                       6408
000052  001024                                  BNE     2$
000054  026011  000000G                          CMP     MSCP.PKT(R0),(R1)               ;                                       6409
000060  001421                                  BEQ     2$
000062  105760  000022G                          TSTB    MSCP.PKT+22(R0)                 ;                                       6410
000066  100416                                  BMI     2$
000070  132760  000360  000010G                 BITB    #360,MSCP.PKT+10(R0)            ;                                       6411
000076  001012                                  BNE     2$
000100  105761  000022                          TSTB    22(R1)                          ;                                       6412
000104  100007                                  BPL     2$
000106  116200  000000G                          MOVB    PKT.USE(R2),R0                  ; *(COUNT),*                            6413
000112  020037  000104'                          CMP     R0,ICTLR
000116  001002                                  BNE     2$
000120  010216                                  MOV     R2,(SP)                         ; COUNT,P.INDEX                         6416
000122  000405                                  BR      3$                              ;                                       6415
000124  005202                          2$:     INC     R2                              ; COUNT                                 6405
000126  020227  000013                          CMP     R2,#13                          ; COUNT,*
000132  003732                                  BLE     1$
000134  005716                                  TST     (SP)                            ; P.INDEX                               6420
000136  002013                          3$:     BGE     4$
000140  016146  000012                          MOV     12(R1), (SP)                    ;                                       6423
000144  016146  000014                          MOV     14(R1),-(SP)
000150  012746  000000G                          MOV     #DBM108,-(SP)
000154  012746  000003                          MOV     #3,-(SP)
000160  010600                                  MOV     SP,R0                           ; SP,*
000162  104417                                  TRAP    17
000164  000545                                  BR      9$                              ;                                       6424
000166  011646                          4$:     MOV     (SP),-(SP)                      ; P.INDEX,*                             6427
000170  012746  000106                          MOV     #106,-(SP)
000174  004737  000000G                          JSR     PC,BL$MUL
000200  010001                                  MOV     R0,R1
000202  022626                                  CMP     (SP)+,(SP)+
000204  013700  000000G                          MOV     IPKT.ADDR,R0
000210  116003  000022                          MOVB    22(R0),R3
000214  042703  177600                          BIC     #177600,R3
000220  005002                                  CLR     R2
000222  156102  000022G                          BISB    MSCP.PKT+22(R1),R2
```

```
000226  020203                                  CMP     R2,R3
000230  001422                                  BEQ     5$
000232  016046  000012                          MOV     12(R0),-(SP)            ;                               6429
000236  016046  000014                          MOV     14(R0),-(SP)
000242  005046                                  CLR     -(SP)
000244  116016  000022                          MOVB    22(R0),(SP)
000250  005046                                  CLR     -(SP)
000252  116116  000022G                         MOVB    MSCP.PKT+22(R1),(SP)
000256  012746  000000G                         MOV     #DBM111,-(SP)
000262  012746  000005                          MOV     #5,-(SP)
000266  010600                                  MOV     SP,R0                   ; SP,*
000270  104417                                  TRAP    17
000272  062706  000014                          ADD     #14,SP
000276  013700  000000G                 5$:     MOV     IPKT.ADDR,R0            ;                               6431
000302  126027  000022  000241                 CMPB    22(R0),#241
000310  001404                                  BEQ     6$
000312  126027  000022  000242                 CMPB    22(R0),#242             ;                               6432
000320  001045                                  BNE     8$
000322  012702  C00024                  6$:     MOV     #24,R2                  ;                               6433
000326  060002                                  ADD     R0,R2
000330  132712  000037                          BITB    #37,(R2)
000334  001037                                  BNE     8$
000336  032712  177740                          BIT     #177740,(R2)            ;                               6434
000342  001034                                  BNE     8$
000344  026160  000026G 000026                 CMP     MSCP.PKT+26(R1),26(R0)  ;                               6435
000352  001004                                  BNE     7$
000354  026160  000030G 000030                 CMP     MSCP.PKT+30(R1),30(R0)  ;                               6436
000362  001424                                  BEQ     8$
000364  016046  000012                  7$:     MOV     12(R0),-(SP)            ;                               6440
000370  016046  000014                          MOV     14(R0),-(SP)
000374  016046  000026                          MOV     26(R0),-(SP)
000400  016046  000030                          MOV     30(R0),-(SP)
000404  016146  000026G                         MOV     MSCP.PKT+26(R1),-(SP)
000410  016146  000030G                         MOV     MSCP.PKT+30(R1),-(SP)
000414  012746  000000G                         MOV     #DBM112,-(SP)
000420  012746  000007                          MOV     #7,-(SP)
000424  010600                                  MOV     SP,R0                   ; SP,*
000426  104417                                  TRAP    17
000430  062706  000020                          ADD     #20,SP
000434  132761  000001  000005G         8$:     BITB    #1,MSCP.PKT+5(R1)       ;                               6442
000442  001422                                  BEQ     10$
000444  016146  000012G                         MOV     MSCP.PKT+12(R1),-(SP)   ;                               6445
000450  016146  000014G                         MOV     MSCP.PKT+14(R1),-(SP)
000454  012746  000000G                         MOV     #DBM120,-(SP)
000460  012746  000003                          MOV     #3,-(SP)
000464  010600                                  MOV     SP,R0                   ; SP,*
000466  104417                                  TRAP    17
000470  016616  000010                          MOV     10(SP),(SP)             ; P.INDEX,*                     6446
000474  004737  000000G                         JSR     PC,PUT.PKT
000500  062706  000010                  9$:     ADD     #10,SP                  ;                               6447
000504  000137  024230'                         JMP     23$                     ;                               6444
000510  112761  000001  000005G         10$:    MOVB    #1,MSCP.PKT+5(R1)       ;                               6450
000516  013746  000104'                         MOV     ICTLR,-(SP)             ;                               6452
```

```
000522  004737  000000G                        JSR     PC,GET.RETPKT
000526  010066  000004                         MOV     R0,4(SP)        ; *,R.INDEX
000532  005726                                 TST     (SP)+
000534  005766  000002                         TST     2(SP)           ; R.INDEX
000540  002010                                 BGE     11$
000542  012746  000000G                        MOV     #DBM22,-(SP)    ;                                       6455
000546  012746  000001                         MOV     #1,-(SP)
000552  010600                                 MOV     SP,R0           ; SP,*
000554  104417                                 TRAP    17
000556  000137  024216'                       JMP     21$             ;                                       6456
000562  013704  000000G             11$:       MOV     IPKT.ADDR,R4    ; *,SRC.ADDR                            6461
000566  062704  000006                         ADD     #6,R4           ; *,SRC.ADDR
000572  016646  000002                         MOV     2(SP),-(SP)     ; R.INDEX,*                             6462
000576  012746  000054                         MOV     #54,-(SP)
000602  004737  000000G                        JSR     PC,BL$MUL
000606  062700  000000G                        ADD     #RETPKT,R0
000612  010005                                 MOV     R0,R5           ; *,DST.ADDR
000614  010002                                 MOV     R0,R2           ; *,R.ADDR
000616  013700  000000G                        MOV     IPKT.ADDR,R0    ;                                       6470
000622  012703  000001                         MOV     #1,R3           ; *,COUNT                               6464
000626  012425                     12$:        MOV     (R4)+,(R5)+     ; SRC.ADDR,DST.ADDR                     6466
000630  126027  000022  000211                CMPB    22(R0),#211     ;                                       6470
000636  001005                                 BNE     13$
000640  020327  000012                         CMP     R3,#12          ; COUNT,*                               6472
000644  001002                                 BNE     13$
000646  062704  000004                         ADD     #4,R4           ; *,SRC.ADDR                            6474
000652  005203                     13$:        INC     R3              ; COUNT                                 6464
000654  020327  000026                         CMP     R3,#26          ; COUNT,*
000660  003762                                 BLE     12$
000662  013703  000104'                       MOV     ICTLR,R3        ;                                       6477
000666  042703  177760                         BIC     #177760,R3
000672  142762  000017  000002                BICB    #17,2(R2)       ; *,*(R.ADDR)
000700  150362  000002                         BISB    R3,2(R2)        ; *,*(R.ADDR)
000704  005766  000004                         TST     4(SP)           ; P.INDEX                               6479
000710  002442                                 BLT     15$
000712  116000  000022                         MOVB    22(R0),R0       ;                                       6482
000716  042700  177400                         BIC     #177400,R0
000722  020027  000241                         CMP     R0,#241
000726  001406                                 BEQ     14$
000730  020027  000242                         CMP     R0,#242         ;                                       6483
000734  001403                                 BEQ     14$
000736  020027  000220                         CMP     R0,#220         ;                                       6484
000742  001025                                 BNE     15$
000744  016162  000024G 000012     14$:        MOV     MSCP.PKT+24(R1),12(R2)  ; *,*(R.ADDR)                   6487
000752  016162  000026G 000044                 MOV     MSCP.PKT+26(R1),44(R2)  ; *,*(R.ADDR)                   6488
000760  016162  000030G 000046                 MOV     MSCP.PKT+30(R1),46(R2)  ; *,*(R.ADDR)                   6489
000766  016162  000046G 000050                 MOV     MSCP.PKT+46(R1),50(R2)  ; *,*(R.ADDR)                   6490
000774  016162  000050G 000052                 MOV     MSCP.PKT+50(R1),52(R2)  ; *,*(R.ADDR)                   6491
001002  016162  000032G 000024                 MOV     MSCP.PKT+32(R1),24(R2)  ; *,*(R.ADDR)                   6492
001010  016162  000034G 000026                 MOV     MSCP.PKT+34(R1),26(R2)  ; *,*(R.ADDR)                   6493
001016  016616  000006             15$:        MOV     6(SP),(SP)      ; R.INDEX,*                             6496
001022  004737  000000G                        JSR     PC,IN.IODQ
001026  005726                                 TST     (SP)+           ;                                       6460
```

```
001030  013716  000104'                          MOV     ICTLR,(SP)                      ;                                       6502
001034  012746  000006                            MOV     #6,-(SP)
001040  004737  000000G                           JSR     PC,BL$MUL
001044  013701  000000G                           MOV     IPKT.ADDR,R1                    ;                                       6499
001050  012703  000024                            MOV     #24,R3
001054  060103                                    ADD     R1,R3
001056  132713  000037                            BITB    #37,(R3)
001062  001003                                    BNE     16$
001064  032713  177740                            BIT     #177740,(R3)                    ;                                       6500
001070  001404                                    BEQ     17$
001072  012760  000001  000120'          16$:     MOV     #1,LAST.PKT(R0)                 ;                                       6502
001100  000402                                    BR      18$                             ;                                       6499
001102  005060  000120'          17$:     CLR     LAST.PKT(R0)                    ;                                       6504
001106  016160  000012  000122'          18$:     MOV     12(R1),LAST.PKT+2(R0)           ;                                       6506
001114  016160  000014  000124'                   MOV     14(R1),LAST.PKT+4(R0)           ;                                       6507
001122  132762  000040  000015                    BITB    #40,15(R2)                      ; #,#(R.ADDR)                           6510
001130  001415                                    BEQ     19$
001132  012716  000000G                           MOV     #DBM123,(SP)                    ;                                       6513
001136  012746  C00001                            MOV     #1,-(SP)
001142  010600                                    MOV     SP,R0                           ; SP,#
001144  104414                                    TRAP    14
001146  010216                                    MOV     R2,(SP)                         ; R.ADDR,#                              6514
001150  004737  000000G                           JSR     PC,EMS.R2
001154  010216                                    MOV     R2,(SP)                         ; R.ADDR,#                              6515
001156  004737  000000G                           JSR     PC,EMS.R1
001162  005726                                    TST     (SP)+                           ;                                       6512
001164  032737  000001  000000G          19$:     BIT     #1,CSR.MEM                      ;                                       6521
001172  001441                                    BEQ     20$
001174  032737  000001  000000G                   BIT     #1,TST.PAR
001202  001435                                    BEQ     20$
001204  017700  000000G                           MOV     @CSR.ADD,R0                     ;                                       6523
001210  042700  077777                            BIC     #77777,R0
001214  020027  100000                            CMP     R0,#-100000
001220  001026                                    BNE     20$
001222  017716  000000G                           MOV     @CSR.ADD,(SP)                   ;                                       6526
001226  012746  000000G                           MOV     #DBM125,-(SP)
001232  012746  000002                            MOV     #2,-(SP)
001236  010600                                    MOV     SP,R0                           ; SP,#
001240  104417                                    TRAP    17
001242  012777  040000  000000G                   MOV     #40000,@CSR.ADD                 ;                                       6527
001250  012716  040000                            MOV     #40000,(SP)                     ;                                       6528
001254  012746  000000G                           MOV     #DBM126,-(SP)
001260  012746  000002                            MOV     #2,-(SP)
001264  010600                                    MOV     SP,R0                           ; SP,#
001266  104417                                    TRAP    17
001270  000000                                    HALT                                    ;                                       6529
001272  062706  000010                            ADD     #10,SP                          ;                                       6525
001276  005766  000004                  20$:     TST     4(SP)                           ; P.INDEX                               6532
001302  002404                                    BLT     22$
001304  016616  000004                  21$:     MOV     4(SP),(SP)                      ; P.INDEX,#                             6534
001310  004737  000000G                           JSR     PC,PUT.PKT
001314  022626                          22$:     CMP     (SP)+,(SP)+                     ;                                       6391
001316  022626                          23$:     CMP     (SP)+,(SP)+                     ;                                       6376
```

```
001320  000207                                  RTS     PC

; Routine Size:  361 words,     Routine Base:  $CODE$ + 22712
; Maximum stack depth per invocation:  18 words
```

```
;    6537  1      !MMMGLOBAL routine SCAN_ERRLOG : novalue =
;    6538  1
;    6539  1      !MMM!+
;    6540  1      !MMM! THIS ROUTINE SCANS THE ERROR-LOG SAVE AREA AND PRINTS ANY ERROR-LOGS RECEIVED FOR THE ASSOCIATED RESPONSE
;    6541  1      !MMM!-
;    6542  1
;    6543  1      !MMM    begin
;    6544  1
;    6545  1      !MMM    local
;    6546  1      !MMM    TEMP_UNIT,
;    6547  1      !MMM    SFT_ERR_PRINTED : byte initial (byte (FALSE));
;    6548  1
;    6549  1      !MMM    incr index from 0 to EP_CNT do                                          ! SCAN ERROR-LOG PACKET SAVE AREA
;    6550  1      !MMM    begin
;    6551  1
;    6552  1      !MMM    if (.ELOG_PKT [.index, EL_CNTR] eql .ICTLR) and
;    6553  1      !MMM       (.ELOG_PKT [.index, EL_CRN_LO] eql .IPKT_ADDR [CRN_LO]) and          ! MMM
;    6554  1      !MMM       (.ELOG_PKT [.index, EL_CRN_HI] eql .IPKT_ADDR [CRN_HI]) and
;    6555  1      !MMM       (.ELOG_PKT [.index, EL_CONTENTS] eql FULL)
;    6556  1      !MMM    then
;    6557  1      !MMM        begin                                                               ! ERROR-LOG PENDING THIS RESPONSE
;    6558  1
;    6559  1      !MMM        if .LAST_PKT [.ICTLR, LAST_HRD_ERR] eql HRD_NOT_OCCURED             ! IF SOFT ERROR OCCURED
;    6560  1      !MMM        then
;    6561  1
;    6562  1      !MMM            if .ELOG_PKT [.index, EL_FORMAT] lequ 4
;    6563  1      !MMM            then
;    6564  1      !MMM                begin
;    6565  1      !MMM                SOFT_ERROR (.index);                                        ! UPATE SOFT ERROR COUNT
;    6566  1      !MMM                TEMP_UNIT = .L$LUN;                                         ! SAVE UNIT NUMBER AS KNOWN TO DRS
;    6567  1
;    6568  1      !MMM                incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do
;    6569  1
;    6570  1      !MMM                    if (.ICST_ADDR [.OFFSET + OF_DATA, D_DISK_NUM] eql .ELOG_PKT [.index, EL_DK_NUM]) and
;    6571  1      !MMM                       (.ICST_ADDR [.OFFSET + OF_DATA, D_PRES] eql PRESENT)
;    6572  1      !MMM                    then
;    6573  1      !MMM                        begin
;    6574  1      !MMM                        L$LUN = .ICST_ADDR [.OFFSET + OF_DATA, D_UNIT];     ! CORECT UNIT NO. FOR ERROR MESSAGE
;    6575  1      !MMM                        exitloop;
;    6576  1      !MMM                        end;
;    6577  1
;    6578  1      !MMM                case .ELOG_PKT [.index, EL_FORMAT] from 0 to 4 of
;    6579  1      !MMM                    set
;    6580  1
;    6581  1      !MMM                    [0]:    if .APT_MODE                                    ! CONTROLLER ERROR
;    6582  1      !MMM                            then
;    6583  1      !MMM                                ERR_SOFT_RTNE_APT (50, .index)
;    6584  1      !MMM                            else
;    6585  1      !MMM                                ERR_SOFT_RTNE (50);
;    6586  1
;    6587  1      !MMM                    [1]:    if .APT_MODE                                    ! HOST MEMORY ACCESS ERROR
;    6588  1      !MMM                            then
;    6589  1      !MMM                                ERR_SOFT_RTNE_APT (51, .index)
```

```
;    6590  1      !MMM                                else
;    6591  1      !MMM                                    ERR_SOFT_RTNE (51);
;    6592  1
;    6593  1      !MMM                        [2]:    if .APT_MODE                                    ! DISK TRANSFER ERROR
;    6594  1      !MMM                                then
;    6595  1      !MMM                                    ERR_SOFT_RTNE_APT (52, .index)
;    6596  1      !MMM                                else
;    6597  1      !MMM                                    ERR_SOFT_RTNE (52);
;    6598  1
;    6599  1      !MMM                        [3]:    if .APT_MODE                                    ! SDI ERROR
;    6600  1      !MMM                                then
;    6601  1      !MMM                                    ERR_SOFT_RTNE_APT (53, .index)
;    6602  1      !MMM                                else
;    6603  1      !MMM                                    ERR_SOFT_RTNE (53);
;    6604  1
;    6605  1      !MMM                        [4]:    if .APT_MODE                                    ! SMALL DISK ERROR
;    6606  1      !MMM                                then
;    6607  1      !MMM                                    ERR_SOFT_RTNE_APT (54, .index)
;    6608  1      !MMM                                else
;    6609  1      !MMM                                    ERR_SOFT_RTNE (54);
;    6610  1      !MMM                        tes;
;    6611  1
;    6612  1      !MMM                    L$LUN = .TEMP_UNIT;                                         ! RESTORE UNIT NUMBER
;    6613  1      !MMM                    SFT_ERR_PRINTED = TRUE;                                     ! SOFT ERROR PRINTOUT OCCURED
;    6614  1      !MMM                    end
;    6615  1      !MMM                else
;    6616  1      !MM                     PRINTF (DBM109, .ELOG_PKT [.index, EL_FORMAT]);             ! UNKNOWN ERROR LOG FORMAT
;    6617  1
;    6618  1      !MMM            if not (.SFT_ERR_PRINTED)
;    6619  1      !MMM            then
;    6620  1      !MMM                PRINTB (CRLF);                                                  ! EXTRA CARRIAGE-RETURN/LINE-FEED
;    6621  1
;    6622  1      !MMM                if ((.ELOG_PKT [.index, EL_CRN_LO] neq .IPKT_ADDR [CRN_LO]) or      ! MMM
;    6623  1      !MMM            (.ELOG_PKT [.index, EL_CRN_HI] neq .IPKT_ADDR [CRN_HI])) and
;    6624  1      !MMM                (.QIO [.ICTLR] eql 1)
;    6625  1      !MMM                then
;    6626  1      !MMM                   PRINTB (DBM122);                                                 ! 'Late or Unexpected Error Log:
MMM
;    6627  1      !MMM            EMS_EL (.index);                                                    ! PRINT ERROR-LOG CONTENTS
;    6628  1      !MMM            end
;    6629  1      !MMM        else
;    6630  1
;    6631  1      !MMM            if (.ELOG_PKT [.index, EL_CNTR] eql .ICTLR) and
;    6632  1      !MMM               ((.ELOG_PKT [.index, EL_CRN_HI] lssu .IPKT_ADDR [CRN_HI]) or
;    6633  1      !MMM                ((.ELOG_PKT [.index, EL_CRN_HI] eql .IPKT_ADDR [CRN_HI]) and
;    6634  1      !MMM                 (.ELOG_PKT [.index, EL_CRN_LO] lssu .IPKT_ADDR [CRN_LO]))) and
;    6635  1      !MMM               (.ELOG_PKT [.index, EL_CONTENTS] eql FULL)
;    6636  1
;    6637  1
;    6638  1      !MMM            if (.ELOG_PKT [.index, EL_CNTR] eql .ICTLR) and                     ! MMM
;    6639  1      !MMM               (.ELOG_PKT [.index, EL_CONTENTS] eql FULL) and
;    6640  1      !MMM                   (.QIO [.ICTLR] eqlu 1)
;    6641  1
;    6642  1      !MMM            then
```

```
;    6643  1      !MMM              begin
;    6644  1      !MMM              PRINTB (CRLF);                          ! CARRIAGE-RETURN/LINE-FEED
;    6645  1      !MMM              EMS_EL (.index);                        ! PRINT ERROR-LOG CONTENTS
;    6646  1      !MMM              end;
;    6647  1
;    6648  1      !MMM    end;                                              ! ERROR-LOG SAVE AREA SCAN
;    6649  1
;    6650  1      !MMM    end;
```

```
;    6651  1     GLOBAL routine DATAGM : novalue =
;    6652  1
;    6653  1     !+
;    6654  1     !       THIS ROUTINE HANDLES ALL DATAGRAM (ERROR LOG) MESSAGES RECEIVED FROM
;    6655  1     !       THE RDRX
;    6656  1     !
;    6657  1     !       IMPLICIT INPUTS:
;    6658  1     !               IPKT_ADDR - ADDRESS OF MSCP PACKET CONTAINING ERROR LOG
;    6659  1     !                           MESSAGE
;    6660  1     !               ICST_ADDR - ADDRESS OF THE INTERRUPTING CONTROLLER'S CST
;    6661  1     !-
;    6662  1
;    6663  2         begin
;    6664  2
;    6665  2         local
;    6666  2             index : signed word initial (-1),
;    6667  2             SAVE_ADDR : ref block [EP_LEN, word] field (EP_FIELDS),
;    6668  2             SRC_ADDR,
;    6669  2             DST_ADDR,
;    6670  2             TEMP_UNIT,
;    6671  2     !MMM    SFT_ERR_PRINTED : byte initial (byte (FALSE)),
;    6672  2             PACKET_LEN : word;
;    6673  2
;    6674  2     !
;    6675  2     ! FIND AN EMPTY SLOT IN THE ERROR-LOG PACKET SAVE AREA
;    6676  2     !
;    6677  2
;    6678  2         EL_FLUSH [.ICTLR] = TRUE;                                   ! MMM
;    6679  2
;    6680  2         incr COUNT from 0 to EP_CNT - 1 do
;    6681  2
;    6682  2             if .ELOG_PKT [.COUNT, EL_CONTENTS] eql EMPTY            ! IF EMPTY SLOT FOUND
;    6683  2             then
;    6684  3                 begin
;    6685  3                 index = .COUNT;                                     ! SAVE INDEX INTO THE SAVE AREA
;    6686  3                 exitloop;
;    6687  2                 end;
;    6688  2
;    6689  2         if .index lss 0
;    6690  2         then
;    6691  2             index = EP_CNT;                                         ! IF NO SLOT FOUND, USE LAST SPARE SLOT
;    6692  2
;    6693  2     !
;    6694  2     ! SAVE THE PACKET CONTENTS
;    6695  2     !
;    6696  2
;    6697  2         SAVE_ADDR = ELOG_PKT + (.index * EP_LEN * 2);               ! ADDRESS OF THE SAVE AREA
;    6698  2         SAVE_ADDR [EL_CONTENTS ] = FULL;                            ! MARK IT FULL
;    6699  2         SAVE_ADDR [EL_CNTR] = .ICTLR;                               ! OWNERSHIP
;    6700  2         SRC_ADDR = .IPKT_ADDR + 6;                                  ! SETUP COPY ADDRESSES
;    6701  2         DST_ADDR = .SAVE_ADDR + 2;                                  !
;    6702  2         PACKET_LEN = ((.IPKT_ADDR [MSGLEN] + 1) / 2) + 2;           ! LENGTH OF ERROR-LOG INCLUDING ENVELOPE
;    6703  2
```

```
;    6704  2          if .PACKET_LEN gtru EP_LEN - 1
;    6705  2          then
;    6706  2              PACKET_LEN = EP_LEN - 1;                                    ! ADJUST LENGTH, IF TOO LONG
;    6707  2
;    6708  2          incr COUNT from 1 to .PACKET_LEN do
;    6709  3              begin
;    6710  3              .DST_ADDR = ..SRC_ADDR;                                     ! COPY A WORD
;    6711  3              SRC_ADDR = .SRC_ADDR + 2;                                   ! UPDATE ADDRESS POINTERS
;    6712  3              DST_ADDR = .DST_ADDR + 2;                                   !
;    6713  2              end;
;    6714  2
;    6715  2     !     if (.CSR_MEM and .TST_PAR) and (not .PAR_TSD) and (.SAVE_ADDR [EL_FORMAT] eql 1)   ! MMM
;    6716  2     !     then                                                                              ! MMM
;    6717  2     !         begin                                                                         ! MMM
;    6718  2     !         WRT_RDRX (RCIP, RC_ALL, ALL_ONES);                                            ! MMM
;    6719  2     !         PAR_TSD = TRUE;                                                               ! MMM
;    6720  2     !         INIT_TEST ();                                                                 ! MMM
;    6721  2     !         return;                                                                       ! MMM
;    6722  2     !         end;                                                                          ! MMM
;    6723  2
;    6724  2
;    6725  2          if .SAVE_ADDR [EL_BRR] eql TRUE                                ! TEST ERROR LOG MESSAGE FLAGS MMM
;    6726  2          then
;    6727  2             PRINTF (D8M127);                                             ! BAD BLOCK REPLACEMENT REQUEST FLAG SET MMM
;    6728  2
;    6729  2          if .SAVE_ADDR [EL_EDR] eql TRUE                                !ERROR DURING REPLACEMENT (BAD BLOCK) FLAG SET M
MM
;    6730  2          then
;    6731  2             PRINTF (D8M128);                                            !MMM
;    6732  2
;    6733  2          if .SAVE_ADDR [EL_SUCCESS] eql TRUE                               !MMM
;    6734  2          then
;    6735  2             if .SAVE_ADDR [EL_FORMAT] lequ 4
;    6736  2             then
;    6737  3                 begin
;    6738  3                 SOFT_ERROR (.index);                                    ! UPDATE SOFT ERROR COUNT
;    6739  3                 TEMP_UNIT = .L$LUN;                                     ! SAVE UNIT NUMBER AS KNOWN TO DRS
;    6740  3
;    6741  3                 incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do
;    6742  3
;    6743  3                    if (.ICST_ADDR [.OFFSET + OF_DATA, D_DISK_NUM] eql .SAVE_ADDR [EL_DK_NUM]) and
;    6744  4                       (.ICST_ADDR [.OFFSET + OF_DATA, D_PRES] eql PRESENT)
;    6745  3                    then
;    6746  4                       begin
;    6747  4                       L$LUN = .ICST_ADDR [.OFFSET + OF_DATA, D_UNIT];       ! CORRECT UNIT NUMBER FOR ERROR MESSAGE
;    6748  4                       exitloop;
;    6749  3                       end;
;    6750  3
;    6751  3                    case .SAVE_ADDR [EL_FORMAT] from 0 to 4 of
;    6752  3                       set
;    6753  3
;    6754  3                       [0] :  if .APT_MODE                               ! CONTROLLER ERROR
;    6755  3                              then
;    6756  3                                 ERR_SOFT_RTNE_APT (50, .index)
```

```
;    6757  3                          else
;    6758  3                             ERR_SOFT_RTNE (50);
;    6759  3
;    6760  3                    [1] :  if .APT MODE                              ! HOST MEMORY ACCESS ERROR
;    6761  3                          then
;    6762  3                             ERR_SOFT_RTNE_APT (51, .index)
;    6763  3                          else
;    6764  3                             ERR_SOFT_RTNE (51);
;    6765  3
;    6766  3                    [2] :  if .APT_MODE                              ! DISK TRANSFER ERROR
;    6767  3                          then
;    6768  3                             ERR_SOFT_RTNE_APT (52, .index)
;    6769  3                          else
;    6770  3                             ERR_SOFT_RTNE (52);
;    6771  3
;    6772  3                    [3] :  if .APT_MODE                              ! SDI ERROR
;    6773  3                          then
;    6774  3                             ERR_SOFT_RTNE_APT (53, .index)
;    6775  3                          else
;    6776  3                             ERR_SOFT_RTNE (53);
;    6777  3
;    6778  3                    [4] :  if .APT_MODE                              ! SMALL DISK ERROR
;    6779  3                          then
;    6780  3                             ERR_SOFT_RTNE_APT (54, .index)
;    6781  3                          else
;    6782  3                             ERR_SOFT_RTNE (54);
;    6783  3                    tes;
;    6784  3
;    6785  3
;    6786  3              L$LUN = .TEMP_UNIT;                                    ! RESTORE UNIT NUMBER
;    6787  2              end;
;    6788  2
;    6789  2    !MMM      else
;    6790  2    !MMM         PRINTF (DBM109, .SAVE_ADDR [EL_FORMAT]);            ! ERROR LOG FORMAT UNKNOWN
;    6791  2
;    6792  2        PRINTB (CRLF);                                               ! EXTRA CARRIEGE-RETURN/LINE-FEED
;    6793  2        EMS_EL (.index);                                             ! PRINT PACKET CONTENTS
;    6794  1        end;                                                         !

                                        .SBTTL  DATAGM RDRX INTERRUPT SERVICE ROUTINES
000000  004137  000000G          DATAGM::JSR     R1,$SAVE5                       ;                                    6651
000004  012704  177777                  MOV     #-1,R4                          ; *,INDEX                            6663
000010  013700  000104'                 MOV     ICTLR,R0                        ;                                    6678
000014  006300                          ASL     R0
000016  012760  000001  000106'         MOV     #1,EL.FLUSH(R0)
000024  005001                          CLR     R1                              ; COUNT                              6680
000026  010146                  1$:     MOV     R1,-(SP)                        ; COUNT,*                            6682
000030  012746  000102                  MOV     #102,-(SP)
000034  004737  000000G                 JSR     PC,BL$MUL
000040  022626                          CMP     (SP)+,(SP)+
000042  105760  000001G                 TSTB    ELOG.PKT+1(R0)
000046  001002                          BNE     2$
```

```
000050  010104                          MOV     R1,R4           ; COUNT,INDEX                   6685
000052  000405                          BR      3$              ;                               6684
000054  005201                  2$:     INC     R1              ; COUNT                         6680
000056  020127  000013                  CMP     R1,#13          ; COUNT,*
000062  003761                          BLE     1$
000064  005704                          TST     R4              ; INDEX                         6689
000066  002002                  3$:     BGE     4$
000070  012704  000014                  MOV     #14,R4          ; *,INDEX                       6691
000074  010446                  4$:     MOV     R4,-(SP)        ; INDEX,*                       6697
000076  012746  000102                  MOV     #102,-(SP)
000102  004737  000000G                 JSR     PC,BL$MUL
000106  062700  000000G                 ADD     #ELOG.PKT,R0
000112  010001                          MOV     R0,R1           ; *,SAVE.ADDR
000114  111761  000001                  MOVB    (PC),1(R1)      ; *,*(SAVE.ADDR)                6698
000120  113711  000104'                 MOVB    ICTLR,(R1)      ; *,SAVE.ADDR                   6699
000124  013700  000000G                 MOV     IPKT.ADDR,R0    ;                               6700
000130  012705  000006                  MOV     #6,R5           ; *,SRC.ADDR
000134  060005                          ADD     R0,R5           ; *,SRC.ADDR
000136  012703  C00002                  MOV     #2,R3           ; *,DST.ADDR                    6701
000142  060103                          ADD     R1,R3           ; SAVE.ADDR,DST.ADDR
000144  016016  000006                  MOV     6(R0),(SP)      ;                               6702
000150  005216                          INC     (SP)
000152  012746  000002                  MOV     #2,-(SP)
000156  004737  000000G                 JSR     PC,BL$DIV
000162  062700  000002                  ADD     #2,R0
000166  020027  000040                  CMP     R0,#40          ; PACKET.LEN,*                  6704
000172  101402                          BLOS    5$
000174  012700  000040                  MOV     #40,R0          ; *,PACKET.LEN                  6706
000200  005002                  5$:     CLR     R2              ; COUNT                         6708
000202  000401                          BR      7$
000204  012523                  6$:     MOV     (R5)+,(R3)+     ; SRC.ADDR,DST.ADDR             6710
000206  005202                  7$:     INC     R2              ; COUNT                         6708
000210  020200                          CMP     R2,R0           ; COUNT,PACKET.LEN
000212  003774                          BLE     6$
000214  012702  000016                  MOV     #16,R2          ;                               6725
000220  060102                          ADD     R1,R2           ; SAVE.ADDR,*
000222  032712  020000                  BIT     #20000,(R2)
000226  001407                          BEQ     8$
000230  012716  000000G                 MOV     #DBM127,(SP)    ;                               6727
000234  012746  000001                  MOV     #1,-(SP)
000240  010600                          MOV     SP,R0           ; SP,*
000242  104417                          TRAP    17
000244  005726                          TST     (SP)+
000246  032712  010000          8$:     BIT     #10000,(R2)     ;                               6729
000252  001407                          BEQ     9$
000254  012716  000000G                 MOV     #DBM128,(SP)    ;                               6731
000260  012746  000001                  MOV     #1,-(SP)
000264  010600                          MOV     SP,R0           ; SP,*
000266  104417                          TRAP    17
000270  005726                          TST     (SP)+
000272  005712                  9$:     TST     (R2)            ;                               6733
000274  100136                          BPL     27$
000276  121227  000004                  CMPB    (R2),#4         ;                               6735
```

```
000302  101133                          BHI     27$
000304  010416                          MOV     R4,(SP)                 ; INDEX,*                       6738
000306  004737  000000V                 JSR     PC,SOFT.ERROR
000312  013705  000000G                 MOV     L$LUN,R5                ; *,TEMP.UNIT                   6739
000316  012703  000006                  MOV     #6,R3                   ; *,OFFSET                      6741
000322  010300                  10$:     MOV     R3,R0                   ; OFFSET,*                      6743
000324  063700  000076'                 ADD     ICST.ADDR,R0
000330  016146  000012                  MOV     12(R1),-(SP)            ; *(SAVE.ADDR),*
000334  111046                          MOVB    (R0),-(SP)
000336  042716  177760                  BIC     #177760,(SP)
000342  022626                          CMP     (SP)+,(SP)+
000344  001012                          BNE     11$
000346  032710  040000                  BIT     #40000,(R0)             ;                               6744
000352  001407                          BEQ     11$
000354  011046                          MOV     (R0),-(SP)              ;                               6747
000356  000316                          SWAB    (SP)
000360  042716  177760                  BIC     #177760,(SP)
000364  012637  000000G                 MOV     (SP)+,L$LUN
000370  000405                          BR      12$                     ;                               6746
000372  062703  000024          11$:    ADD     #24,R3                  ; *,OFFSET                      6741
000376  020327  000102                  CMP     R3,#102                 ; OFFSET,*
000402  003747                          BLE     10$
000404  005000                  12$:    CLR     R0                      ;                               6754
000406  153700  001254'                 BISB    APT.MODE,R0
000412  005001                          CLR     R1                      ;                               6751
000414  151201                          BISB    (R2),R1
000416  006301                          ASL     R1
000420  066107  000000'                 ADD     P.AAA(R1),PC            ; Case dispatch
000424  032700  000001          14$:    BIT     #1,R0                   ;                               6754
000430  001403                          BEQ     15$
000432  012716  000062                  MOV     #62,(SP)                ;                               6756
000436  000442                          BR      23$
000440  012716  000062          15$:    MOV     #62,(SP)                ;                               6758
000444  000446                          BR      25$
000446  032700  000001          16$:    BIT     #1,R0                   ;                               6760
000452  001403                          BEQ     17$
000454  012716  000063                  MOV     #63,(SP)                ;                               6762
000460  000431                          BR      23$
000462  012716  000063          17$:    MOV     #63,(SP)                ;                               6764
000466  000435                          BR      25$
000470  032700  000001          18$:    BIT     #1,R0                   ;                               6766
000474  001403                          BEQ     19$
000476  012716  000064                  MOV     #64,(SP)                ;                               6768
000502  000420                          BR      23$
000504  012716  000064          19$:    MOV     #64,(SP)                ;                               6770
000510  000424                          BR      25$
000512  032700  000001          20$:    BIT     #1,R0                   ;                               6772
000516  001403                          BEQ     21$
000520  012716  000065                  MOV     #65,(SP)                ;                               6774
000524  000407                          BR      23$
000526  012716  000065          21$:    MOV     #65,(SP)                ;                               6776
000532  000413                          BR      25$
000534  006000                  22$:    ROR     R0                      ;                               6778
```

```
000536  103007                                  BCC     24$
000540  012716  000066                          MOV     #66.,(SP)                       ;                               6780
000544  010446                          23$:    MOV     R4,-(SP)                        ; INDEX,*
000546  004737  000000V                         JSR     PC,ERR.SOFT.RTNE.APT
000552  005726                                  TST     (SP)+
000554  000404                                  BR      26$                             ;                               6778
000556  012716  000066                  24$:    MOV     #66,(SP)                        ;                               6782
000562  004737  000000V                 25$:    JSR     PC,ERR.SOFT.RTNE
000566  010537  000000G                 26$:    MOV     R5,L$LUN                        ; TEMP.UNIT,*                   6786
000572  012716  000000G                 27$:    MOV     #CRLF,(SP)                      ;                               6792
000576  012746  000001                          MOV     #1,-(SP)
000602  010600                                  MOV     SP,R0                           ; SP,*
000604  104414                                  TRAP    14
000606  010416                                  MOV     R4,(SP)                         ; INDEX,*                       6793
000610  004737  000000G                         JSR     PC,EMS.EL
000614  062706  000010                          ADD     #10,SP                          ;                               6663
000620  000207                                  RTS     PC                              ;                               6651

; Routine Size:  201 words,     Routine Base:  $CODE$ + 24234
; Maximum stack depth per invocation:  12 words


000000                                          .PSECT  $PLIT$,  RO ,  D

                                        P.AAA:                                          ; CASE Table for DATAGM+0420    6751
000000  000000                          13$:    .WORD   0                               ; [14$]
000002  000022                                  .WORD   22                              ; [16$]
000004  000044                                  .WORD   44                              ; [18$]
000006  000066                                  .WORD   66                              ; [20$]
000010  000110                                  .WORD   110                             ; [22$]



;    6795  1
;    6796  1
;    6797  1      !MMM    if (.SAVE_ADDR [EL_CRN_LO] eql .LAST_PKT [.ICTLR, LAST_CRN_LO]) and
;    6798  1      !MMM       (.SAVE_ADDR [EL_CRN_HI] eql .LAST_PKT [.ICTLR, LAST_CRN_HI])
;    6799  1      !MMM    then
;    6800  1      !MMM       begin                                                    ! LOG REFERS TO THE LAST RESPONSE RE
CEIVED
;    6801  1
;    6802  1      !MMM       if .LAST_PKT [.ICTLR, LAST_HRD_ERR] eql HRD_NOT_OCCURED  ! IF SOFT ERROR HAD OCCURED
;    6803  1      !MMM       then
;    6804  1
;    6805  1      !MMM          if .SAVE_ADDR [EL_FORMAT] lequ 4
;    6806  1      !MMM          then
;    6807  1      !MMM             begin
;    6808  1      !MMM             SOFT_ERROR (.index);                             ! UPDATE SOFT ERROR COUNT
;    6809  1      !MMM             TEMP_UNIT = .L$LUN;                              ! SAVE UNIT NUMBER AS KNOWN TO DRS
;    6810  1
;    6811  1      !MMM             incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do
;    6812  1
;    6813  1      !MMM                 if (.ICST_ADDR [.OFFSET + OF_DATA, D_DISK_NUM] eql .SAVE_ADDR [EL_DK_NUM]) and
;    6814  1      !MMM                    (.ICST_ADDR [.OFFSET + OF_DATA, D_PRES] eql PRESENT)
```

```
;    6815  1      !MMM                then
;    6816  1      !MMM                    begin
;    6817  1      !MMM                    L$LUN = .ICST_ADDR [.OFFSET + OF_DATA, D_UNIT]; ! CORRECT UNIT NUMBER FOR ERROR MESSAGE
;    6818  1      !MMM                    exitloop;
;    6819  1      !MMM                    end;
;    6820  1
;    6821  1      !MMM            case .SAVE_ADDR [EL_FORMAT] from 0 to 4 of
;    6822  1      !MMM                set
;    6823  1
;    6824  1
;    6825  1      !MMM                [0] :       if .APT_MODE                            ! CONTROLLER ERROR
;    6826  1      !MMM                            then
;    6827  1      !MMM                                ERR_SOFT_RTNE_APT (50, .index)
;    6828  1      !MMM                            else
;    6829  1      !MMM                                ERR_SOFT_RTNE (50);
;    6830  1
;    6831  1      !MMM                [1] :       if .APT_MODE                            ! HOST MEMORY ACCESS ERROR
;    6832  1      !MMM                            then
;    6833  1      !MMM                                ERR_SOFT_RTNE_APT (51, .index)
;    6834  1      !MMM                            else
;    6835  1      !MMM                                ERR_SOFT_RTNE (51);
;    6836  1
;    6837  1      !MMM                [2] :       if .APT_MODE                            ! DISK TRANSFER ERROR
;    6838  1      !MMM                            then
;    6839  1      !MMM                                ERR_SOFT_RTNE_APT (52, .index)
;    6840  1      !MMM                            else
;    6841  1      !MMM                                ERR_SOFT_RTNE (52);
;    6842  1
;    6843  1      !MMM                [3] :       if .APT_MODE                            ! SDI ERROR
;    6844  1      !MMM                            then
;    6845  1      !MMM                                ERR_SOFT_RTNE_APT (53, .index)
;    6846  1      !MMM                            else
;    6847  1      !MMM                                ERR_SOFT_RTNE (53);
;    6848  1
;    6849  1      !MMM                [4] :       if .APT_MODE                            ! SMALL DISK ERROR
;    6850  1      !MMM                            then
;    6851  1      !MMM                                ERR_SOFT_RTNE_APT (54, .index)
;    6852  1      !MMM                            else
;    6853  1      !MMM                                ERR_SOFT_RTNE (54);
;    6854  1      !MMM                tes;
;    6855  1
;    6856  1
;    6857  1      !MMM            L$LUN = .TEMP_UNIT;                                     ! RESTORE UNIT NUMBER
;    6858  1      !MMM            SFT_ERR_PRINTED = TRUE;                                 ! SOFT ERROR PRINTOUT OCCURED
;    6859  1      !MMM            end
;    6860  1
;    6861  1      !MMM        else
;    6862  1      !MMM            PRINTF (DBM109, .SAVE_ADDR [EL_FORMAT]);                ! ERROR LOG FORMAT UNKNOWN
;    6863  1
;    6864  1      !MMM    if not (.SFT_ERR_PRINTED)
;    6865  1
;    6866  1      !MMM    then
;    6867  1      !MMM        PRINTB (CRLF);                                              ! EXTRA CARRIEGE-RETURN/LINE-FEED
```

```
;    6868  1
;    6869  1      !MMM    EMS_EL (.index);                                        ! PRINT PACKET CONTENTS
;    6870  1      !MMM    end                                                     ! CORRESPONDING RESPONSE RECEIVED
;    6871  1
;    6872  1      !MMM    else
;    6873  1
;    6874  1      !MMM    if (.SAVE_ADDR [EL_CRN_HI] lssu .LAST_PKT [.ICTLR, LAST_CRN_HI]) or
;    6875  1      !MMM       ((.SAVE_ADDR [EL_CRN_HI] eql .LAST_PKT [.ICTLR, LAST_CRN_HI]) and
;    6876  1      !MMM        (.SAVE_ADDR [EL_CRN_LO] lssu .LAST_PKT [.ICTLR, LAST_CRN_LO]))
;    6877  1
;    6878  1      !MMM    if  (.QIO [.ICTLR] eqlu 0)                              ! MMM
;    6879  1
;    6880  1      !MMM    then
;    6881  1      !MMM        begin                                               ! LOG REFERS TO SOME PREVIOUS RESPONSE
;    6882  1      !MMM        PRINTB (CRLF);                                      ! CARRIAGE-RETURN/LINE-FEED
;    6883  1      !MMM        EMS_EL (.index);                                    ! PRINT PACKET CONTENTS
;    6884  1      !MMM        end;
;    6885  1
;    6886  1      !MMM    end;
;    6887  1
;    6888  1
;    6889  1
```

```
;    6890  1     GLOBAL routine SOFT_ERROR (index) : novalue =
;    6891  1
;    6892  1     !+
;    6893  1     !       THIS ROUTINE UPDATES THE SOFT ERROR COUNT IN THE TALLY TABLE FOR EACH
;    6894  1     !       ERROR LOG MESSAGE RECEIVED
;    6895  1     !
;    6896  1     !       IMPLICIT INPUTS:
;    6897  1     !               ICST_ADDR - ADDRESS OF THE INTERRUPTING CONTROLLER'S CST
;    6898  1     !-
;    6899  1
;    6900  2         begin
;    6901  2
;    6902  2         local
;    6903  2             FOUND: byte initial (byte (FALSE)),
;    6904  2             SOFT_OCCURED : byte initial (byte (FALSE)),
;    6905  2             UNIT: word,
;    6906  2             ERROR_CODE : byte,
;    6907  2             ERROR_SUB : word,
;    6908  2             RETRIES : word,
;    6909  2             TALLY_ADDR : ref block [TALLY_LEN, word] field (T_FIELDS),
;    6910  2             ELOG_ADDR : ref block [EP_LEN, word] field (EP_FIELDS);
;    6911  2
;    6912  2         ELOG_ADDR = ELOG_PKT + (.index * EP_LEN * 2);                          ! ADDR OF ERROR PKT
;    6913  2         ERROR_CODE = .ELOG_ADDR [EL_CODE];                                     ! ERROR CODE
;    6914  2         ERROR_SUB = .ELOG_ADDR [EL_SUBCODE];                                   ! ERROR SUBCODE
;    6915  2
;    6916  2         if (BIT_TST (SWP_FLAGS, SWF_TRY)) and
;    6917  3            (.ELOG_ADDR [EL_FORMAT] eql 2)
;    6918  2         then
;    6919  2             RETRIES = .ELOG_ADDR [EL_RETRY]                                    ! COUNT EACH RETRY
;    6920  2         else
;    6921  2             RETRIES = 1;                                                       ! IGNORE RETRIES
;    6922  2
;    6923  2         if .RETRIES eql 0                                                      ! IN CASE OF A BUG
;    6924  2         then
;    6925  2             RETRIES = 1;
;    6926  2
;    6927  2         incr OFFSET from (0 + OF_UN) to ((UNITS_PER_CNTR - 1) * UNIT_SIZE + OF_UN) by UNIT_SIZE do
;    6928  2
;    6929  2             if (.ICST_ADDR [.OFFSET + OF_DATA, D_PRES] eql PRESENT) and        ! DISK TO UNIT NO.
;    6930  3                (.ICST_ADDR [.OFFSET + OF_DATA, D_DISK_NUM] eql .ELOG_ADDR [EL_DK_NUM])
;    6931  2             then
;    6932  3                 begin
;    6933  3                 FOUND = TRUE;
;    6934  3                 UNIT = .ICST_ADDR [.OFFSET + OF_DATA, D_UNIT];                 ! DISK'S UNIT NO.
;    6935  3                 exitloop;
;    6936  2                 end;
;    6937  2
;    6938  2     !   if (.ELOG_ADDR [EL_SUCCESS]) or
;    6939  2     !      (.ELOG_ADDR [EL_CONTINUE])
;    6940  2     !   then
;    6941  2             SOFT_OCCURED = TRUE;                                           ! SOFT ERROR FLAG
;    6942  2
```

```
;  6943  2          if .FOUND                                                                   ! IF UNIT FOUND
;  6944  2          then
;  6945  3              begin
;  6946  3              TALLY_ADDR = TALLY + (.UNIT * TALLY_LEN * 2);                           ! ADDR OF TALLY TBL
;  6947  3
;  6948  3              if .SOFT_OCCURED                                                        ! FOR SOFT ERRORRS
;  6949  3              then
;  6950  3                  selectoneu .ERROR_CODE of
;  6951  3                      set
;  6952  3
;  6953  3                      [ST_MFE]:       TALLY_ADDR [ERR_SFT_SEK] = .TALLY_ADDR [ERR_SFT_SEK] + .RETRIES;! SOFT-MEDIA FORMAT
;  6954  3
;  6955  3                      [ST_DAT]:       if .ERROR_SUB eql 2                             ! SOFT-DATA
;  6956  3                                      then
;  6957  3                                          TALLY_ADDR [ERR_SFT_SEK] = .TALLY_ADDR [ERR_SFT_SEK] + .RETRIES
;  6958  3                                      else
;  6959  3                                          TALLY_ADDR [ERR_SFT_DAT] = .TALLY_ADDR [ERR_SFT_DAT] + .RETRIES;
;  6960  3
;  6961  3                      [ST_HST]:       TALLY_ADDR [ERR_SFT_HST] = .TALLY_ADDR [ERR_SFT_HST] + .RETRIES;! SOFT-HOST ACCESS
;  6962  3
;  6963  3                      [ST_CNT]:       C_ERR_TBL [.ICTLR, C_ERR_SFT] = .C_ERR_TBL [.ICTLR, C_ERR_SFT] + .RETRIES;
;  6964  3                                                                                      ! SOFT-CONTROLLER
;  6965  3
;  6966  3                      [ST_DRV]:       if .ERROR_SUB eql 3                             ! SOFT_DRIVE
;  6967  3                                      then
;  6968  3                                          TALLY_ADDR [ERR_SFT_SEK] = .TALLY_ADDR [ERR_SFT_SEK] + .RETRIES
;  6969  3                                      else
;  6970  3                                          TALLY_ADDR [ERR_SFT_DRV] = .TALLY_ADDR [ERR_SFT_DRV] + .RETRIES;
;  6971  3                      tes
;  6972  3              else
;  6973  3
;  6974  3                  if (.ELCu_ADDR [EL_CRN_LO] eql 0) and
;  6975  4                     (.ELOG_ADDR [EL_CRN_HI] eql 0)
;  6976  3                  then
;  6977  3                      selectoneu .ERROR_CODE of
;  6978  3                          set
;  6979  3
;  6980  3                          [ST_MFE]:   TALLY_ADDR [ERR_HRD_SEK] = .TALLY_ADDR [ERR_HRD_SEK] + 1;       ! HARD-MEDIA FORMAT
;  6981  3
;  6982  3                          [ST_DAT]:   if .ERROR_SUB eql 2                             ! HARD-DATA
;  6983  3                                      then
;  6984  3                                          TALLY_ADDR [ERR_HRD_SEK] = .TALLY_ADDR [ERR_HRD_SEK] + 1
;  6985  3                                      else
;  6986  3                                          TALLY_ADDR [ERR_HRD_DAT] = .TALLY_ADDR [ERR_HRD_DAT] + 1;
;  6987  3
;  6988  3                          [ST_HST]:   TALLY_ADDR [ERR_HRD_HST] = .TALLY_ADDR [ERR_HRD_HST] + 1;       ! HARD-HOST ACCESS
;  6989  3
;  6990  3                          [ST_CNT]:   C_ERR_TBL [.ICTLR, C_ERR_HRD] = .C_ERR_TBL [.ICTLR, C_ERR_HRD] + 1;
;  6991  3                                                                                      ! HARD-CONTROLLER
;  6992  3
;  6993  3                          [ST_DRV]:   if .ERROR_SUB eql 3                             ! HARD-DRIVE
;  6994  3                                      then
;  6995  3                                          TALLY_ADDR [ERR_HRD_SEK] = .TALLY_ADDR [ERR_HRD_SEK] + 1
```

```
;    6996  3                                    else
;    6997  3                                        TALLY_ADDR [ERR_HRD_DRV] = .TALLY_ADDR [ERR_HRD_DRV] + 1;
;    6998  3                            tes;
;    6999  3
;    7000  3                        end
;    7001  2                    else                                                          ! UNIT NOT FOUND
;    7002  2
;    7003  2                        if .SOFT_OCCURED
;    7004  2                        then
;    7005  2                            C_ERR_TBL [.ICTLR, C_ERR_SFT] = .C_ERR_TBL [.ICTLR, C_ERR_SFT] + 1
;    7006  2                        else
;    7007  2                            C_ERR_TBL [.ICTLP, C_ERR_HRD] = .C_ERR_TBL [.ICTLR, C_ERR_HRD] + 1;
;    7008  2
;    7009  1                    end;                                                          ! RTNE SOFT_ERROR


                                                .SBTTL  SOFT.ERROR RDRX INTERRUPT SERVICE ROUTINES
025056                                          .PSECT  $CODE$,  RO

000000  004137  000000G                 SOFT.ERROR::
                                                JSR     R1,$SAVE5                       ;                                       6890
000004  005746                                  TST     -(SP)
000006  105046                                  CLRB    -(SP)                           ; FOUND                                 6900
000010  105046                                  CLRB    -(SP)                           ; SOFT.OCCURED
000012  016646  000024                          MOV     24(SP),-(SP)                    ; INDEX,*                               6912
000016  012746  000102                          MOV     #102,-(SP)
000022  004737  000000G                         JSR     PC,BL$MUL
000026  062700  000000G                         ADD     #ELOG.PKT,R0
000032  010001                                  MOV     R0,R1                           ; *,ELOG.ADDR
000034  116100  000020                          MOVB    20(R1),R0                       ; *(ELOG.ADDR),*                        6913
000040  042700  177740                          BIC     #177740,R0
000044  105003                                  CLRB    R3                              ; ERROR.CODE
000046  050003                                  BIS     R0,R3                           ; *,ERROR.CODE
000050  016105  000020                          MOV     20(R1),R5                       ; *(ELOG.ADDR),ERROR.SUB                6914
000054  006205                                  ASR     R5                              ; ERROR.SUB
000056  006205                                  ASR     R5                              ; ERROR.SUB
000060  006205                                  ASR     R5                              ; ERROR.SUB
000062  006205                                  ASR     R5                              ; ERROR.SUB
000064  006205                                  ASR     R5                              ; ERROR.SUB
000066  042705  174000                          BIC     #174000,R5                      ; *,ERROR.SUB
000072  013700  000000G                         MOV     SWP.FLAGS,R0                    ;                                       6916
000076  042700  077777                          BIC     #77777,R0
000102  020027  100000                          CMP     R0,#-100000
000106  001010                                  BNE     1$
000110  126127  000016  000002                  CMPB    16(R1),#2                       ; *(ELOG.ADDR),*                        6917
000116  001004                                  BNE     1$
000120  005004                                  CLR     R4                              ; RETRIES                               6919
000122  156104  000051                          BISB    51(R1),R4                       ; *(ELOG.ADDR),RETRIES
000126  000402                                  BR      2$                              ;                                       6916
000130  012704  000001                  1$:     MOV     #1,R4                           ; *,RETRIES                             6921
000134  005704                          2$:     TST     R4                              ; RETRIES                               6923
000136  001002                                  BNE     3$
000140  012704  000001                          MOV     #1,R4                           ; *,RETRIES                             6925
```

```
000144  012702  000006              3$:     MOV     #6,R2                           ; *,OFFSET                      6927
000150  010200                      4$:     MOV     R2,R0                           ; OFFSET,*                      6929
000152  063700  000076'                      ADD     ICST.ADDR,R0
000156  032710  040000                      BIT     #40000,(R0)
000162  001421                              BEQ     5$
000164  016146  000012                      MOV     12(R1),-(SP)                    ; -(ELOG.ADDR),*                6930
000170  111046                              MOVB    (R0),-(SP)
000172  042716  177760                      BIC     #177760,(SP)
000176  022626                              CMP     (SP)+,(SP)+
000200  001012                              BNE     5$
000202  112766  000001  000006              MOVB    #1,6(SP)                        ; *,FOUND                       6933
000210  011046                              MOV     (R0),-(SP)                      ;                               6934
000212  000316                              SWAB    (SP)
000214  042716  177760                      BIC     #177760,(SP)
000220  012666  000010                      MOV     (SP)+,10(SP)                    ; *,UNIT
000224  000405                              BR      6$                              ;                               6932
000226  062702  000024              5$:     ADD     #24,R2                          ; *,OFFSET                      6927
000232  020227  000102                      CMP     R2,#102                         ; OFFSET,*
000236  003744                              BLE     4$
000240  112766  000001  000004      6$:     MOVB    #1,4(SP)                        ; *,SOFT.OCCURED                6941
000246  032766  000001  000006              BIT     #1,6(SP)                        ; *,FOUND                       6943
000254  001002                              BNE     7$
000256  000137  025744'                      JMP     22$
000262  016616  000010              7$:     MOV     10(SP),(SP)                     ; UNIT,*                        6946
000266  012746  000066                      MOV     #66,-(SP)
000272  004737  000000G                      JSR     PC,BL$MUL
000276  062700  000000G                      ADD     #TALLY,R0
000302  032766  000001  000006              BIT     #1,6(SP)                        ; *,SOFT.OCCURED                6948
000310  001503                              BEQ     14$
000312  120327  000005                      CMPB    R3,#5                           ; ERROR.CODE,*                  6953
000316  001462                              BEQ     12$
000320  120327  000010                      CMPB    R3,#10                          ; ERROR.CODE,*                  6955
000324  001022                              BNE     9$
000326  012702  000052                      MOV     #52,R2                          ;                               6957
000332  060002                              ADD     R0,R2                           ; TALLY.ADDR,*
000334  020527  000002                      CMP     R5,#2                           ; ERROR.SUB,*                   6955
000340  001005                              BNE     8$
000342  005001                              CLR     R1                              ;                               6957
000344  151201                              BISB    (R2),R1
000346  060401                              ADD     R4,R1                           ; RETRIES,*
000350  110112                              MOVB    R1,(R2)
000352  000543                              BR      21$                             ;                               6955
000354  005001              8$:     CLR     R1                              ;                               6959
000356  156201  000001                      BISB    1(R2),R1
000362  060401                              ADD     R4,R1                           ; RETRIES,*
000364  110162  000001                      MOVB    R1,1(R2)
000370  000534                              BR      21$                             ;                               6950
000372  120327  000011              9$:     CMPB    R3,#11                          ; ERROR.CODE,*                  6961
000376  001007                              BNE     10$
000400  005001                              CLR     R1
000402  156001  000055                      BISB    55(R0),R1                       ; *(TALLY.ADDR),*
000406  060401                              ADD     R4,R1                           ; RETRIES,*
000410  110160  000055                      MOVB    R1,55(R0)                       ; *,*(TALLY.ADDR)
```

```
000414  000522                          BR      21$                     ;                               6950
000416  120327  000012        10$:      CMPB    R3,#12                  ; ERROR.CODE,*                  6963
000422  001012                          BNE     11$
000424  013702  000104'                 MOV     ICTLR,R2
000430  006302                          ASL     R2
000432  005001                          CLR     R1
000434  156201  000001G                 BISB    C.ERR.TBL+1(R2),R1
000440  060401                          ADD     R4,R1                   ; RETRIES,*
000442  110162  000001G                 MOVB    R1,C.ERR.TBL+1(R2)
000446  000505                          BR      21$                     ;                               6950
000450  120327  000013        11$:      CMPB    R3,#13                  ; ERROR.CODE,*                  6966
000454  001102                          BNE     21$
000456  020527  000003                  CMP     R5,#3                   ; ERROR.SUB,*
000462  001007                          BNE     13$
000464  005001                12$:      CLR     R1                      ;                               6968
000466  156001  000052                  BISB    52(R0),R1               ; *(TALLY.ADDR),*
000472  060401                          ADD     R4,R1                   ; RETRIES,*
000474  110160  000052                  MOVB    R1,52(R0)               ; *,*(TALLY.ADDR)
000500  000470                          BR      21$                     ;                               6966
000502  005001                13$:      CLR     R1                      ;                               6970
000504  156001  000054                  BISB    54(R0),R1               ; *(TALLY.ADDR),*
000510  060401                          ADD     R4,R1                   ; RETRIES,*
000512  110160  000054                  MOVB    R1,54(R0)               ; *,*(TALLY.ADDR)
000516  000461                          BR      21$                     ;                               6950
000520  005761  000006        14$:      TST     6(R1)                   ; *(ELOG.ADDR)                  6974
000524  001056                          BNE     21$
000526  005761  000010                  TST     10(R1)                  ; *(ELOG.ADDR)                  6975
000532  001053                          BNE     21$
000534  120327  000005                  CMPB    R3,#5                   ; ERROR.CODE,*                  6980
000540  001443                          BEQ     19$
000542  120327  000010                  CMPB    R3,#10                  ; ERROR.CODE,*                  6982
000546  001013                          BNE     16$
000550  012704  000046                  MOV     #46,R4                  ;                               6984
000554  060004                          ADD     R0,R4                   ; TALLY.ADDR,*
000556  020527  000002                  CMP     R5,#2                   ; ERROR.SUB,*                   6982
000562  001002                          BNE     15$
000564  105214                          INCB    (R4)                    ;                               6984
000566  000435                          BR      21$                     ;                               6982
000570  105264  000001        15$:      INCB    1(R4)                   ;                               6986
000574  000432                          BR      21$                     ;                               6977
000576  120327  000011        16$:      CMPB    R3,#11                  ; ERROR.CODE,*                  6988
000602  001003                          BNE     17$
000604  105260  000051                  INCB    51(R0)                  ; *(TALLY.ADDR)
000610  000424                          BR      21$                     ;                               6977
000612  120327  000012        17$:      CMPB    R3,#12                  ; ERROR.CODE,*                  6990
000616  001006                          BNE     18$
000620  013702  000104'                 MOV     ICTLR,R2
000624  006302                          ASL     R2
000626  105262  000000G                 INCB    C.ERR.TBL(R2)
000632  000413                          BR      21$                     ;                               6977
000634  120327  000013        18$:      CMPB    R3,#13                  ; ERROR.CODE,*                  6993
000640  001010                          BNE     21$
000642  020527  000003                  CMP     R5,#3                   ; ERROR.SUB,*
```

```
000646  001003                          BNE     20$
000650  105260  000046         19$:     INCB    46(R0)          ; *(TALLY.ADDR)                 6995
000654  000402                          BR      21$             ;                               6993
000656  105260  000050         20$:     INCB    50(R0)          ; *(TALLY.ADDR)                 6997
000662  005726                 21$:     TST     (SP)+           ;                               6945
000664  000415                          BR      24$             ;                               6943
000666  013700  000104'         22$:     MOV     ICTLR,R0        ;                               7005
000672  006300                          ASL     R0
000674  062700  000000G                 ADD     #C.ERR.TBL,R0
000700  032766  000001  000004          BIT     #1,4(SP)        ; *,SOFT.OCCURED                7003
000706  001403                          BEQ     23$
000710  105260  000001                  INCB    1(R0)           ;                               7005
000714  000401                          BR      24$             ;                               7003
000716  105210                 23$:     INCB    (R0)            ;                               7007
000720  062706  000012         24$:     ADD     #12,SP          ;                               6890
000724  000207                          RTS     PC

; Routine Size:  235 words,    Routine Base:  $CODE$ + 25056
; Maximum stack depth per invocation:  13 words
```

```
;    7010  1      routine ERR_HRD_RTNE (ERRNUM) : novalue =
;    7011  1
;    7012  1      !+
;    7013  1      ! THIS ROUTINE DECIDES WHETHER TO ISSUE AN 'ERRHRD' MACRO CALL TO DRS OR TO FAKE
;    7014  1      ! THE SAME EFFECT WITHOUT ISSUING THE CALL
;    7015  1      !-
;    7016  1
;    7017  2          begin
;    7018  2
;    7019  2          local
;    7020  2              CUR_PRIORITY : word;
;    7021  2
;    7022  2          builtin
;    7023  2              PC;
;    7024  2
;    7025  2          GETPRI (CUR_PRIORITY);
;    7026  2      !ZZZ    SETPRI (PRI04);                          ! DON'T ALLOW SOFT_ERROR MESSAGES TO COME IN NOW
;    7027  2          SETPRI (.BRLEVEL);                           ! DON'T ALLOW SOFT_ERROR MESSAGES TO COME IN NOW    ZZZ
;    7028  2
;    7029  2          if (.ERRNUM lequ 34) or                      ! FOR NON-BAD BLOCK TYPE ERRORS
;    7030  2             (.ERRNUM gtru 38) or
;    7031  2             (.ERRNUM eql 36) or
;    7032  3             (.ERRNUM eql 37)
;    7033  2          then
;    7034  2
;    7035  3              if BIT_TST (SWP_FLAGS, SWF_HRD)          ! IF ERRORS TO BE TREATED NORMALLY
;    7036  2              then
;    7037  2
;    7038  2      !ZZZ        case .ERRNUM from 31 to 45 of
;    7039  2                  case .ERRNUM from 31 to 73 of        !INCLUDE DUP NUMBERS (60-73)          ZZZ
;    7040  2              set
;    7041  2
;    7042  2                      [31]:   ERRHRD (31, EGH_30, EMS_30);    ! INVALID COMMAND
;    7043  2
;    7044  2                      [32]:   ERRHRD (32, EGH_30, EMS_30);    ! COMMAND ABORTED
;    7045  2
;    7046  2                      [33]:   ;                               !
;    7047  2
;    7048  2                      [34]:   ;                               !
;    7049  2
;    7050  2                      [35]:   ;                               ! MEDIA FORMAT ERROR
;    7051  2
;    7052  2                      [36]:   ERRHRD (36, EGH_30, EMS_30);    ! WRITE PROTECTED
;    7053  2
;    7054  2                      [37]:   ERRHRD (37, EGH_30, EMS_30);    ! COMPARE ERROR
;    7055  2
;    7056  2                      [38]:   ;                               ! DATA ERROR
;    7057  2
;    7058  2                      [39]:   ERRHRD (39, EGH_30, EMS_30);    ! HOST BUFFER ACCESS ERROR
;    7059  2
;    7060  2                      [40]:   ERRHRD (40, EGH_30, EMS_30);    ! CONTROLLER ERROR
;    7061  2
;    7062  2                      [41]:   ERRHRD (41, EGH_30, EMS_30);    ! DRIVE ERROR
```

```
;  7063  2
;  7064  2                    [42]:   ERRHRD (42, EGH_30, 0);          ! HOST WRITE COMPARE ERROR
;  7065  2
;  7066  2                    [43]:   ERRHRD (43, EGH_30, EMS_30);     ! MESSAGE FROM INTERNAL DIAGNOSTICS
;  7067  2
;  7068  2                    [44]:   ERRHRD (44, EGH_30, EMS_30);     ! DUPLICATE UNIT NUMBER
;  7069  2
;  7070  2                    [45]:   ERRHRD (45, EGH_30, EMS_30);     ! INVALID END CODE
;  7071  2
;  7072  2                    [46]:   ;                                !LEAVE ROOM FOR SOFT ERROR NUMBERS AND SOME PADDING  ZZZ
;  7073  2                    [47]:   ;                                !
;  7074  2                    [48]:   ;                                !
;  7075  2                    [49]:   ;                                !
;  7076  2                    [50]:   ;                                !
;  7077  2                    [51]:   ;                                !
;  7078  2                    [52]:   ;                                !
;  7079  2                    [53]:   ;                                !
;  7080  2                    [54]:   ;                                !
;  7081  2                    [55]:   ;                                !
;  7082  2                    [56]:   ;                                !
;  7083  2                    [57]:   ;                                !
;  7084  2                    [58]:   ;                                !
;  7085  2                    [59]:   ;                                !
;  7086  2
;  7087  2                    [60]:   ERRHRD (60, EH_12, EMS_30);      !NOT USED                                          ZZZ
;  7088  2                    [61]:   ERRHRD (61, EH_13, EMS_30);      !SUCCESSFUL MESSAGE                                ZZZ
;  7089  2                    [62]:   ERRHRD (62, EH_13, EMS_30);      !ILLEGAL UNIT NUMBER                               ZZZ
;  7090  2                    [63]:   ERRHRD (63, EH_13, EMS_30);      !ILLEGAL RELATIVE OR PHYSICAL BLOCK                ZZZ
;  7091  2                    [64]:   ERRHRD (64, EH_13, EMS_30);      !DEVICE ERROR                                      ZZZ
;  7092  2                    [65]:   ERRHRD (65, EH_13, EMS_30);      !ZERO LENGTH MESSAGE                               ZZZ
;  7093  2                    [66]:   ERRHRD (66, EH_8,  EMS_30);      !DUP UNKNOWN STATUS CODE                           ZZZ
;  7094  2                    [67]:   ERRHRD (67, EH_7,  EMS_30);      !INVALID COMMAND                                   ZZZ
;  7095  2                    [68]:   ERRHRD (68, EH_7,  EMS_30);      !NO REGION AVAILABLE                               ZZZ
;  7096  2                    [69]:   ERRHRD (69, EH_7,  EMS_30);      !NO REGION SUITABLE                                ZZZ
;  7097  2                    [70]:   ERRHRD (70, EH_7,  EMS_30);      !PROGRAM NOT KNOWN                                 ZZZ
;  7098  2                    [71]:   ERRHRD (71, EH_7,  EMS_30);      !LOAD FAILURE                                      ZZZ
;  7099  2                    [72]:   ERRHRD (72, EH_7,  EMS_30);      !STANDALONE                                        ZZZ
;  7100  2                    [73]:   ERRHRD (73, EH_8,  EMS_30);      !DUP UNKNOWN STATUS CODE                           ZZZ
;  7101  2
;  7102  2                    tes
;  7103  2                else
;  7104  3                    begin
;  7105  3                    !****increment error count               ! INCREMENT TOTAL ERROR COUNT
;  7106  3                    PRINTB (HRD_MSG, .ERRNUM, .L$LUN, .PC);  ! PRINT ERROR MESSAGE JUST LIKE DRS
;  7107  3
;  7108  3                    if .ERRNUM neq 42
;  7109  3                    then
;  7110  4                        begin
;  7111  4                        PRINTB (HRD_SUB);                    ! NEXT LINE FOR NON-HOST COMPARE ERRORS
;  7112  4                        EMS_ERR ();                          ! PRINT REST OF THE INFORMATION
;  7113  3                        end;
;  7114  2                    end;
;  7115  2
```

```
;    7116  2          if (.ERRNUM eql 35) or                          ! FOR BAD-BLOCK TYPE ERRORS
;    7117  3             (.ERRNUM eql 38)
;    7118  2          then
;    7119  2
;    7120  3              if BIT_TST (SWP_FLAGS, SWF_BLK)             ! IF ERRORS TO BE TREATED NORMALLY
;    7121  2              then
;    7122  2
;    7123  2                  selectoneu .ERRNUM of
;    7124  2                      set
;    7125  2
;    7126  2                      [35]:   ERRHRD (35, EGH_30, EMS_30);    ! MEDIA FORMAT ERROR
;    7127  2
;    7128  2                      [38]:   ERRHRD (38, EGH_30, EMS_30);    ! DATA ERROR
;    7129  2                      tes
;    7130  2              else
;    7131  3                  begin
;    7132  3                  !****increment error count              ! INCREMENT TOTAL ERROR COUNT
;    7133  3                  PRINTB (HRD_MSG, .ERRNUM, .L$LUN, .PC);     ! PRINT ERROR LINE JUST LIKE DRS
;    7134  3                  PRINTB (HRD_SUB);                       ! PRINT NEXT LINE TOO
;    7135  3                  EMS_ERR ();                             ! PRINT REST OF THE INFORMATION
;    7136  2                  end;
;    7137  2
;    7138  2          SETPRI (.CUR_PRIORITY);                         ! PRIORITY BACK TO NORMAL
;    7139  2
;    7140  1          end;


                                        .SBTTL  ERR.HRD.RTNE RDRX INTERRUPT SERVICE ROUTINES
000000  004137  000000G          ERR.HRD.RTNE:
                                        JSR     R1,$SAVE2                       ;                               7010
000004  104440                          TRAP    40                              ;                               7025
000006  010002                          MOV     R0,R2                           ; *,CUR.PRIORITY
000010  013700  000000G                 MOV     BRLEVEL,R0                      ;                               7027
000014  104441                          TRAP    41
000016  016601  000010                  MOV     10(SP),R1                       ; ERRNUM,*                      7029
000022  020127  000042                  CMP     R1,#42
000026  101411                          BLOS    1$
000030  020127  000046                  CMP     R1,#46                          ;                               7030
000034  101006                          BHI     1$
000036  020127  000044                  CMP     R1,#44                          ;                               7031
000042  001403                          BEQ     1$
000044  020127  000045                  CMP     R1,#45                          ;                               7032
000050  001176                          BNE     27$
000052  032737  010000  000000G  1$:     BIT     #10000,SWP.FLAGS                ;                               7035
000060  001002                          BNE     2$
000062  000137  026500'                 JMP     31$
000066  010100                  2$:     MOV     R1,R0                           ;                               7039
000070  162700  000037                  SUB     #37,R0
000074  006300                          ASL     R0
000076  066007  000012'                 ADD     P.AAB(R0),PC                    ; Case dispatch
000102  104456                  4$:     TRAP    56                              ;                               7042
000104  000037                          .WORD   37
000106  000000G                         .WORD   EGH.30
```

```
000110  000000G                         .WORD   EMS.30
000112  000567                         BR      30$                     ;                       7039
000114  104456                 5$:     TRAP    56                      ;                       7044
000116  000040                         .WORD   40
000120  000000G                         .WORD   EGH.30
000122  000000G                         .WORD   EMS.30
000124  000562                         BR      30$                     ;                       7039
000126  104456                 6$:     TRAP    56                      ;                       7052
000130  000044                         .WORD   44
000132  000000G                         .WORD   EGH.30
000134  000000G                         .WORD   EMS.30
000136  000555                         BR      30$                     ;                       7039
000140  104456                 7$:     TRAP    56                      ;                       7054
000142  000045                         .WORD   45
000144  000000G                         .WORD   EGH.30
000146  000000G                         .WORD   EMS.30
000150  000550                         BR      30$                     ;                       7039
000152  104456                 8$:     TRAP    56                      ;                       7058
000154  000047                         .WORD   47
000156  000000G                         .WORD   EGH.30
000160  000000G                         .WORD   EMS.30
000162  000574                         BR      33$                     ;                       7039
000164  104456                 9$:     TRAP    56                      ;                       7060
000166  000050                         .WORD   50
000170  000000G                         .WORD   EGH.30
000172  000000G                         .WORD   EMS.30
000174  000567                         BR      33$                     ;                       7039
000176  104456                 10$:    TRAP    56                      ;                       7062
000200  000051                         .WORD   51
000202  000000G                         .WORD   EGH.30
000204  000000G                         .WORD   EMS.30
000206  000562                         BR      33$                     ;                       7039
000210  104456                 11$:    TRAP    56                      ;                       7064
000212  000052                         .WORD   52
000214  000000G                         .WORD   EGH.30
000216  000000                         .WORD   0
000220  000555                         BR      33$                     ;                       7039
000222  104456                 12$:    TRAP    56                      ;                       7066
000224  000053                         .WORD   53
000226  000000G                         .WORD   EGH.30
000230  000000G                         .WORD   EMS.30
000232  000550                         BR      33$                     ;                       7039
000234  104456                 13$:    TRAP    56                      ;                       7068
000236  000054                         .WORD   54
000240  000000G                         .WORD   EGH.30
000242  000000G                         .WORD   EMS.30
000244  000543                         BR      33$                     ;                       7039
000246  104456                 14$:    TRAP    56                      ;                       7070
000250  000055                         .WORD   55
000252  000000G                         .WORD   EGH.30
000254  000000G                         .WORD   EMS.30
000256  000536                         BR      33$                     ;                       7039
000260  104456                 15$:    TRAP    56                      ;                       7087
```

```
000262  000074                          .WORD   74
000264  000000G                         .WORD   EH.12
000266  000000G                         .WORD   EMS.30
000270  000531                          BR      33$                     ;                       7039
000272  104456                  16$:    TRAP    56                      ;                       7088
000274  000075                          .WORD   75
000276  000000G                         .WORD   EH.13
000300  000000G                         .WORD   EMS.30
000302  000524                          BR      33$                     ;                       7039
000304  104456                  17$:    TRAP    56                      ;                       7089
000306  000076                          .WORD   76
000310  000000G                         .WORD   EH.13
000312  000000G                         .WORD   EMS.30
000314  000517                          BR      33$                     ;                       7039
000316  104456                  18$:    TRAP    56                      ;                       7090
000320  000077                          .WORD   77
000322  000000G                         .WORD   EH.13
000324  000000G                         .WORD   EMS.30
000326  000512                          BR      33$                     ;                       7039
000330  104456                  19$:    TRAP    56                      ;                       7091
000332  000100                          .WORD   100
000334  000000G                         .WORD   EH.13
000336  000000G                         .WORD   EMS.30
000340  000505                          BR      33$                     ;                       7039
000342  104456                  20$:    TRAP    56                      ;                       7092
000344  000101                          .WORD   101
000346  000000G                         .WORD   EH.13
000350  000000G                         .WORD   EMS.30
000352  000500                          BR      33$                     ;                       7039
000354  104456                  21$:    TRAP    56                      ;                       7093
000356  000102                          .WORD   102
000360  000000G                         .WORD   EH.8
000362  000000G                         .WORD   EMS.30
000364  000473                          BR      33$                     ;                       7039
000366  104456                  22$:    TRAP    56                      ;                       7094
000370  000103                          .WORD   103
000372  000000G                         .WORD   EH.7
000374  000000G                         .WORD   EMS.30
000376  000466                          BR      33$                     ;                       7039
000400  104456                  23$:    TRAP    56                      ;                       7095
000402  000104                          .WORD   104
000404  000000G                         .WORD   EH.7
000406  000000G                         .WORD   EMS.30
000410  000461                          BR      33$                     ;                       7039
000412  104456                  24$:    TRAP    56                      ;                       7096
000414  000105                          .WORD   105
000416  000000G                         .WORD   EH.7
000420  000000G                         .WORD   EMS.30
000422  000454                          BR      33$                     ;                       7039
000424  104456                  25$:    TRAP    56                      ;                       7097
000426  000106                          .WORD   106
000430  000000G                         .WORD   EH.7
000432  000000G                         .WORD   EMS.30
```

```
000434  000447                          BR      33$                             ;                               7039
000436  104456                  26$.    TRAP    56                              ;                               7098
000440  000107                          .WORD   107
000442  000000G                         .WORD   EH.7
000444  000000G                         .WORD   EMS.30
000446  000442                  27$:    BR      33$                             ;                               7039
000450  104456                  28$:    TRAP    56                              ;                               7099
000452  000110                          .WORD   110
000454  000000G                         .WORD   EH.7
000456  000000G                         .WORD   EMS.30
000460  000435                          BR      33$                             ;                               7039
000462  104456                  29$:    TRAP    56                              ;                               7100
000464  000111                          .WORD   111
000466  000000G                         .WORD   EH.8
000470  000000G                         .WORD   EMS.30
000472  000430                  30$:    BR      33$                             ;                               7035
000474  010746                  31$:    MOV     PC,-(SP)                        ; PC,*                          7106
000476  013746  000000G                 MOV     L$LUN,-(SP)
000502  010146                          MOV     R1,-(SP)
000504  012746  000000G                 MOV     #HRD.MSG,-(SP)
000510  012746  000004                  MOV     #4,-(SP)
000514  010600                          MOV     SP,R0                           ; SP,*
000516  104414                          TRAP    14
000520  020127  000052                  CMP     R1,#52                          ;                               7108
000524  001411                          BEQ     32$
000526  012716  000000G                 MOV     #HRD.SUB,(SP)                   ;                               7111
000532  012746  000001                  MOV     #1,-(SP)
000536  010600                          MOV     SP,R0                           ; SP,*
000540  104414                          TRAP    14
000542  004737  000000G                 JSR     PC,EMS.ERR                      ;                               7112
000546  005726                          TST     (SP)+                           ;                               7110
000550  062706  000012          32$:    ADD     #12,SP                          ;                               7104
000554  020127  000043          33$:    CMP     R1,#43                          ;                               7116
000560  001403                          BEQ     34$
000562  020127  000046                  CMP     R1,#46                          ;                               7117
000566  001050                          BNE     37$
000570  032737  040000  000000G  34$:    BIT     #40000,SWP.FLAGS                ;                               7120
000576  001420                          BEQ     36$
000600  020127  000043                  CMP     R1,#43                          ;                               7126
000604  001005                          BNE     35$
000606  104456                          TRAP    56
000610  000043                          .WORD   43
000612  000000G                         .WORD   EGH.30
000614  000000G                         .WORD   EMS.30
000616  000434                          BR      37$                             ;                               7123
000620  020127  000046          35$:    CMP     R1,#46                          ;                               7128
000624  001031                          BNE     37$
000626  104456                          TRAP    56
000630  000046                          .WORD   46
000632  000000G                         .WORD   EGH.30
000634  000000G                         .WORD   EMS.30
000636  000424                          BR      37$                             ;                               7123
000640  010746                  36$:    MOV     PC,-(SP)                        ; PC,*                          7133
```

```
000642  013746  000000G                        MOV     L$LUN,-(SP)
000646  010146                                  MOV     R1,-(SP)
000650  012746  000000G                        MOV     #HRD.MSG,-(SP)
000654  012746  000004                        MOV     #4,-(SP)
000660  010600                                  MOV     SP,R0                   ; SP,*
000662  104414                                  TRAP    14
000664  012716  000000G                        MOV     #HRD.SUB,(SP)           ;                                       7134
000670  012746  000001                        MOV     #1,-(SP)
000674  010600                                  MOV     SP,R0                   ; SP,*
000676  104414                                  TRAP    14
000700  004737  000000G                        JSR     PC,EMS.ERR              ;                                       7135
000704  062706  000014                        ADD     #14,SP                  ;                                       7131
000710  010200                        37$:     MOV     R2,R0                   ; CUR.PRIORITY,*                        7138
000712  104441                                  TRAP    41
000714  000207                                  RTS     PC                      ;                                       7010

; Routine Size:  231 words,     Routine Base:  $CODE$ + 26004
; Maximum stack depth per invocation:  11 words


000012                                          .PSECT  $PLIT$,  RO ,  D

                                        P.AAB:                                  ; CASE Table for ERR.HRD.RTNE+0076      7039
000012  000000                          3$:     .WORD   0                       ; [4$]
000014  000012                                  .WORD   12                      ; [5$]
000016  000452                                  .WORD   452                     ; [33$]
000020  000452                                  .WORD   452                     ; [33$]
000022  000452                                  .WORD   452                     ; [33$]
000024  000024                                  .WORD   24                      ; [6$]
000026  000036                                  .WORD   36                      ; [7$]
000030  000452                                  .WORD   452                     ; [33$]
000032  000050                                  .WORD   50                      ; [8$]
000034  000062                                  .WORD   62                      ; [9$]
000036  000074                                  .WORD   74                      ; [10$]
000040  000106                                  .WORD   106                     ; [11$]
000042  000120                                  .WORD   120                     ; [12$]
000044  000132                                  .WORD   132                     ; [13$]
000046  000144                                  .WORD   144                     ; [14$]
000050  000452                                  .WORD   452                     ; [33$]
000052  000452                                  .WORD   452                     ; [33$]
000054  000452                                  .WORD   452                     ; [33$]
000056  000452                                  .WORD   452                     ; [33$]
000060  000452                                  .WORD   452                     ; [33$]
000062  000452                                  .WORD   452                     ; [33$]
000064  000452                                  .WORD   452                     ; [33$]
000066  000452                                  .WORD   452                     ; [33$]
000070  000452                                  .WORD   452                     ; [33$]
000072  000452                                  .WORD   452                     ; [33$]
000074  000452                                  .WORD   452                     ; [33$]
000076  000452                                  .WORD   452                     ; [33$]
000100  000452                                  .WORD   452                     ; [33$]
000102  000452                                  .WORD   452                     ; [33$]
000104  000156                                  .WORD   156                     ; [15$]
```

```
000106  000170                          .WORD   170                     ; [16$]
000110  000202                          .WORD   202                     ; [17$]
000112  000214                          .WORD   214                     ; [18$]
000114  000226                          .WORD   226                     ; [19$]
000116  000240                          .WORD   240                     ; [20$]
000120  000252                          .WORD   252                     ; [21$]
000122  000264                          .WORD   264                     ; [22$]
000124  000276                          .WORD   276                     ; [23$]
000126  000310                          .WORD   310                     ; [24$]
000130  000322                          .WORD   322                     ; [25$]
000132  000334                          .WORD   334                     ; [26$]
000134  000346                          .WORD   346                     ; [28$]
000136  000360                          .WORD   360                     ; [29$]
```

```
;    7141  1      routine ERR_SOFT_RTNE (ERRNUM) : novalue =
;    7142  1
;    7143  1      !+
;    7144  1      ! THIS ROUTINE DECIDES WHETHER TO ISSUE AN 'ERRSOFT' MACRO CALL TO DRS OR TO FAKE
;    7145  1      ! THE SAME EFFECT WITHOUT ISSUING THE CALL
;    7146  1      !-
;    7147  1
;    7148  2          begin
;    7149  2
;    7150  2          builtin
;    7151  2              PC;
;    7152  2
;    7153  3          if BIT_TST (SWP_FLAGS, SWF SFT)                    ! IF SOFT ERRORS TO BE TREATED LIKE OTHER ERRORS
;    7154  2          then
;    7155  2
;    7156  2              case .ERRNUM from 50 to 54 of
;    7157  2                  set
;    7158  2
;    7159  2                  [50]:       ERRSOFT (50, 0, 0);            ! CONTROLLER ERROR
;    7160  2
;    7161  2                  [51]:       ERRSOFT (51, 0, 0);            ! HOST MEMORY ACCESS ERROR
;    7162  2
;    7163  2                  [52]:       ERRSOFT (52, 0, 0);            ! DISK TRANSFER ERROR
;    7164  2
;    7165  2                  [53]:       ERRSOFT (53, 0, 0);            ! SDI ERROR
;    7166  2
;    7167  2                  [54]:       ERRSOFT (54, 0, 0);            ! SMALL DISK ERROR
;    7168  2                  tes
;    7169  2          else
;    7170  3              begin
;    7171  3              !****increment error count                     ! INCREMENT TOTAL ERROR COUNT
;    7172  3              PRINTB (SFT_MSG, .ERRNUM, .L$LUN, .PC);        ! PRINT ERROR LINE JUST LIKE DRS
;    7173  2              end;
;    7174  2
;    7175  1          end;


                                        .SBTTL  ERR.SOFT.RTNE RDRX INTERRUPT SERVICE ROUTINES
                                        .PSECT  $CODE$,  RO

000000  032737  020000  000000G  ERR.SOFT.RTNE:
                                        BIT     #20000,SWP.FLAGS            ;                       7153
000006  001440                          BEQ     7$
000010  016600  000002                  MOV     2(SP),RO                    ; ERRNUM,*              7156
000014  162700  000062                  SUB     #62,RO
000020  006300                          ASL     RO
000022  066007  000140'                 ADD     P.AAC(RO),PC                ; Case dispatch
000026  104457                  2$:     TRAP    57                          ;                       7159
000030  000062                          .WORD   62
000032  000000                          .WORD   0
000034  000000                          .WORD   0
000036  000207                          RTS     PC                          ;                       7156
000040  104457                  3$:     TRAP    57                          ;                       7161
```

```
000042  000063                          .WORD   63
000044  000000                          .WORD   0
000046  000000                          .WORD   0
000050  000207                          RTS     PC                              ;                               7156
000052  104457                  4$:     TRAP    57                              ;                               7163
000054  000064                          .WORD   64
000056  000000                          .WORD   0
000060  000000                          .WORD   0
000062  000207                          RTS     PC                              ;                               7156
000064  104457                  5$:     TRAP    57                              ;                               7165
000066  000065                          .WORD   65
000070  000000                          .WORD   0
000072  000000                          .WORD   0
000074  000207                          RTS     PC                              ;                               7156
000076  104457                  6$:     TRAP    57                              ;                               7167
000100  000066                          .WORD   66
000102  000000                          .WORD   0
000104  000000                          .WORD   0
000106  000207                          RTS     PC                              ;                               7153
000110  010746                  7$:     MOV     PC,-(SP)                        ; PC,*                          7172
000112  013746  000000G                 MOV     L$LUN,-(SP)
000116  016646  000006                  MOV     6(SP),-(SP)                     ; ERRNUM,*
000122  012746  000000G                 MOV     #SFT.MSG,-(SP)
000126  012746  000004                  MOV     #4,-(SP)
000132  010600                          MOV     SP,R0                           ; SP,*
000134  104414                          TRAP    14
000136  062706  000012                  ADD     #12,SP                          ;                               7170
000142  000207                          RTS     PC                              ;                               7141

; Routine Size:  50 words,      Routine Base:  $CODE$ + 26722
; Maximum stack depth per invocation:  7 words


000140                                  .PSECT  $PLIT$,  RO ,  D

                                P.AAC:                                          ; CASE Table for ERR.SOFT.RTNE+0022     7156
000140  000000                 1$:     .WORD   0                               ; [2$]
000142  000012                          .WORD   12                              ; [3$]
000144  000024                          .WORD   24                              ; [4$]
000146  000036                          .WORD   36                              ; [5$]
000150  000050                          .WORD   50                              ; [6$]
```

```
;    7176  1      routine ERR_HRD_RTNE_APT (ERRNUM) : novalue =
;    7177  1
;    7178  1
;    7179  1      !+
;    7180  1      ! THIS ROUTINE DECIDES WHETHER TO ISSUE AN 'ERRHRD' MACRO CALL TO DRS OR TO FAKE
;    7181  1      ! THE SAME EFFECT WITHOUT ISSUING THE CALL
;    7182  1      !-
;    7183  1
;    7184  1
;    7185  2          begin
;    7186  2
;    7187  2
;    7188  2          local
;    7189  2              CUR_PRIORITY;
;    7190  2
;    7191  2
;    7192  2          builtin
;    7193  2              PC;
;    7194  2
;    7195  2          GETPRI (CUR_PRIORITY);
;    7196  2      !ZZZ    SETPRI (PRI04);                         ! DON'T ALLOW SOFT_ERROR MESSAGES TO COME IN NOW
;    7197  2          SETPRI (.BRLEVEL);                          ! DON'T ALLOW SOFT_ERROR MESSAGES TO COME IN NOW     ZZZ
;    7198  2
;    7199  2
;    7200  2          if .APT_MODE
;    7201  2          then
;    7202  2
;    7203  3              begin
;    7204  3              .MAIL_BOX_ ESTNUM = .RP_ADDR [LBN_LO];  ! CHANGE TEST NUMBER TO SHOW LBN UNDER APT ONLY
;    7205  3              .MAIL_BOX_SUBTST = .RP_ADDR [DISK];     ! CHANGE SUB-TEST NUMBER TO SHOW DISK NUMBER UNDER APT ONLY
;    7206  2              end;
;    7207  2
;    7208  2
;    7209  2          if (.ERRNUM lequ 34) or                     ! FOR NON BAD BLOCK TYPE ERRORS
;    7210  2             (.ERRNUM gtru 38) or
;    7211  2             (.ERRNUM eql 36) or
;    7212  3             (.ERRNUM eql 37)
;    7213  3
;    7214  2          then
;    7215  2
;    7216  3              if BIT_TST (SWP_FLAGS, SWF_HRD)         ! IF ERRORS TO BE TREATED NORMALLY
;    7217  2              then
;    7218  2
;    7219  2                  case .ERRNUM from 31 to 45 of
;    7220  2                      set
;    7221  2
;    7222  2                      [31]:   ERRDF (31, EGH_30, EMS_30);     ! INVALID COMMAND
;    7223  2
;    7224  2                      [32]:   ERRDF (32, EGH_30, EMS_30);     ! COMMAND ABORTED
;    7225  2
;    7226  2                      [33]:   ;                               !
;    7227  2
;    7228  2                      [34]:   ;                               !
```

```
;    7229  2
;    7230  2                    [35]:   ;                                   ! MEDIA FORMAT ERROR
;    7231  2
;    7232  2                    [36]:   ERRDF (36, EGH_30, EMS_30);         ! WRITE PROTECTED
;    7233  2
;    7234  2                    [37]:   ERRDF (37, EGH_30, EMS_30);         ! COMPARE ERROR
;    7235  2
;    7236  2                    [38]:   ;                                   ! DATA ERROR
;    7237  2
;    7238  2                    [39]:   ERRDF (39, EGH_30, EMS_30);         ! HOST BUFFER ACCESS ERROR
;    7239  2
;    7240  2                    [40]:   ERRDF (40, EGH_30, EMS_30);         ! CONTROLLER ERROR
;    7241  2
;    7242  2                    [41]:   ERRDF (41, EGH_30, EMS_30);         ! DRIVE ERROR
;    7243  2
;    7244  2                    [42]:   ERRDF (42, EGH_30, 0);              ! HOST WRITE COMPARE ERROR
;    7245  2
;    7246  2                    [43]:   ERRDF (43, EGH_30, EMS_30);         ! MESSAGE FROM INTERNAL DIAGNOSTICS
;    7247  2
;    7248  2                    [44]:   ERRDF (44, EGH_30, EMS_30);         ! DUPLICATE UNIT NUMBER
;    7249  2
;    7250  2                    [45]:   ERRDF (45, EGH_30, EMS_30);         ! INVALID END CODE
;    7251  2                    tes
;    7252  2
;    7253  2                else
;    7254  2
;    7255  3                    begin
;    7256  3                    !****increment error count                  ! INCREMENT TOTAL ERROR COUNT
;    7257  3                    PRINTB (DF_MSG, .ERRNUM, .L$LUN, .PC);      ! PRINT ERROR MESSAGE JUST LIKE DRS
;    7258  3
;    7259  3
;    7260  3                    if .ERRNUM neq 42
;    7261  3
;    7262  3                    then
;    7263  4                        begin
;    7264  4                        PRINTB (HRD_SUB);                       ! NEXT LINE FOR NON-HOST COMPARE ERRORS
;    7265  4                        EMS_ERR ();                             ! PRINT REST OF THE INFORMATION
;    7266  3                        end;
;    7267  2                    end;
;    7268  2
;    7269  2                if (.ERRNUM eql 35) or                          ! FOR BAD-BLOCK TYPE ERRORS
;    7270  3                   (.ERRNUM eql 38)
;    7271  3
;    7272  2                then
;    7273  2
;    7274  3                    if BIT_TST (SWP_FLAGS, SWF_BLK)             ! IF ERRORS TO BE TREATED NORMALLY
;    7275  2                    then
;    7276  2
;    7277  2                    selectoneu .ERRNUM of
;    7278  2                        set
;    7279  2
;    7280  2                        [35]:   ERRDF (35, EGH_30, EMS_30);     ! MEDIA FORMAT ERROR
;    7281  2
```

```
;    7282  2                    [38]:   ERRDF (38, EGH_30, EMS_30);     ! DATA ERROR
;    7283  2                    tes
;    7284  2
;    7285  2              else
;    7286  2
;    7287  3                  begin
;    7288  3                  !****increment error count                 ! INCREMENT TOTAL ERROR COUNT
;    7289  3                  PRINTB (DF_MSG, .ERRNUM, .L$LUN, .PC);     ! PRINT ERROR LINE JUST LIKE DRS
;    7290  3                  PRINTB (HRD_SUB);                          ! PRINT NEXT LINE TOO
;    7291  3                  EMS_ERR ();                                ! PRINT REST OF THE INFORMATION
;    7292  2                  end;
;    7293  2
;    7294  2
;    7295  2          SETPRI (.CUR_PRIORITY);                            ! PRIORITY BACK TO NORMAL
;    7296  2
;    7297  2
;    7298  1          end;


                                        .SBTTL  ERR.HRD.RTNE.APT RDRX INTERRUPT SERVICE ROUTINES
027066                                  .PSECT  $CODE$,  RO

000000  004137  000000G          ERR.HRD.RTNE.APT:
                                        JSR     R1,$SAVE2                       ;                                       7176
000004  104440                          TRAP    40                              ;                                       7195
000006  010002                          MOV     R0,R2                           ; *,CUR.PRIORITY
000010  013700  000000G                 MOV     BRLEVEL,R0                      ;                                       7197
000014  104441                          TRAP    41
000016  032737  000001  001254'         BIT     #1,APT.MODE                     ;                                       7200
000024  001412                          BEQ     1$
000026  013700  000000G                 MOV     RP.ADDR,R0                      ;                                       7204
000032  016077  000050  001256'         MOV     50(R0),@MAIL.BOX.TESTNUM
000040  013700  000000G                 MOV     RP.ADDR,R0                      ;                                       7205
000044  016077  000010  001260'         MOV     10(R0),@MAIL.BOX.SUBTST
000052  016601  000010          1$:     MOV     10(SP),R1                       ; ERRNUM,*                              7209
000056  020127  000042                  CMP     R1,#42
000062  101411                          BLOS    2$
000064  020127  000046                  CMP     R1,#46                          ;                                       7210
000070  101006                          BHI     2$
000072  020127  000044                  CMP     R1,#44                          ;                                       7211
000076  001403                          BEQ     2$
000100  020127  000045                  CMP     R1,#45                          ;                                       7212
000104  001131                          BNE     17$
000106  032737  010000  000000G  2$:     BIT     #10000,SWP.FLAGS                ;                                       7216
000114  001475                          BEQ     15$
000116  010100                          MOV     R1,R0                           ;                                       7219
000120  162700  000037                  SUB     #37,R0
000124  006300                          ASL     R0
000126  066007  000152'                 ADD     P.AAD(R0),PC                    ; Case dispatch
000132  104455          4$:             TRAP    55                              ;                                       7222
000134  000037                          .WORD   37
000136  000000G                         .WORD   EGH.30
000140  000000G                         .WORD   EMS.30
```

```
000142  000512                          BR      17$                             ;                               7219
000144  104455                  5$:     TRAP    55                              ;                               7224
000146  000040                          .WORD   40
000150  000000G                         .WORD   EGH.30
000152  000000G                         .WORD   EMS.30
000154  000505                          BR      17$                             ;                               7219
000156  104455                  6$:     TRAP    55                              ;                               7232
000160  000044                          .WORD   44
000162  000000G                         .WORD   EGH.30
000164  000000G                         .WORD   EMS.30
000166  000500                          BR      17$                             ;                               7219
000170  104455                  7$:     TRAP    55                              ;                               7234
000172  000045                          .WORD   45
000174  000000G                         .WORD   EGH.30
000176  000000G                         .WORD   EMS.30
000200  000473                          BR      17$                             ;                               7219
000202  104455                  8$:     TRAP    55                              ;                               7238
000204  000047                          .WORD   47
000206  000000G                         .WORD   EGH.30
000210  000000G                         .WORD   EMS.30
000212  000466                          BR      17$                             ;                               7219
000214  104455                  9$:     TRAP    55                              ;                               7240
000216  000050                          .WORD   50
000220  000000G                         .WORD   EGH.30
000222  000000G                         .WORD   EMS.30
000224  000461                          BR      17$                             ;                               7219
000226  104455                  10$:    TRAP    55                              ;                               7242
000230  000051                          .WORD   51
000232  000000G                         .WORD   EGH.30
000234  000000G                         .WORD   EMS.30
000236  000454                          BR      17$                             ;                               7219
000240  104455                  11$:    TRAP    55                              ;                               7244
000242  000052                          .WORD   52
000244  000000G                         .WORD   EGH.30
000246  000000                          .WORD   0
000250  000447                          BR      17$                             ;                               7219
000252  104455                  12$:    TRAP    55                              ;                               7246
000254  000053                          .WORD   53
000256  000000G                         .WORD   EGH.30
000260  000000G                         .WORD   EMS.30
000262  000442                          BR      17$                             ;                               7219
000264  104455                  13$:    TRAP    55                              ;                               7248
000266  000054                          .WORD   54
000270  000000G                         .WORD   EGH.30
000272  000000G                         .WORD   EMS.30
000274  000435                          BR      17$                             ;                               7219
000276  104455                  14$:    TRAP    55                              ;                               7250
000300  000055                          .WORD   55
000302  000000G                         .WORD   EGH.30
000304  000000G                         .WORD   EMS.30
000306  000430                          BR      17$                             ;                               7216
000310  010746                  15$:    MOV     PC,-(SP)                        ; PC,*                          7257
000312  013746  000000G                 MOV     L$LUN,-(SP)
```

```
000316  010146                          MOV     R1,-(SP)
000320  012746  000000G                 MOV     #DF.MSG,-(SP)
000324  012746  000004                  MOV     #4,-(SP)
000330  010600                          MOV     SP,R0                   ; SP,*
000332  104414                          TRAP    14
000334  020127  000052                  CMP     R1,#52                  ;                       7260
000340  001411                          BEQ     16$
000342  012716  000000G                 MOV     #HRD.SUB,(SP)           ;                       7264
000346  012746  000001                  MOV     #1,-(SP)
000352  010600                          MOV     SP,R0                   ; SP,*
000354  104414                          TRAP    14
000356  004737  000000G                 JSR     PC,EMS.ERR              ;                       7265
000362  005726                          TST     (SP)+                   ;                       7263
000364  062706  000012          16$:    ADD     #12,SP                  ;                       7255
000370  020127  000043          17$:    CMP     R1,#43                  ;                       7269
000374  001403                          BEQ     18$
000376  020127  000046                  CMP     R1,#46                  ;                       7270
000402  001050                          BNE     21$
000404  032737  C40000  000000G 18$:    BIT     #40000,SWP.FLAGS        ;                       7274
000412  001420                          BEQ     20$
000414  020127  000043                  CMP     R1,#43                  ;                       7280
000420  001005                          BNE     19$
000422  104455                          TRAP    55
000424  000043                          .WORD   43
000426  000000G                         .WORD   EGH.30
000430  000000G                         .WORD   EMS.30
000432  000434                          BR      21$                     ;                       7277
000434  020127  000046          19$:    CMP     R1,#46                  ;                       7282
000440  001031                          BNE     21$
000442  104455                          TRAP    55
000444  000046                          .WORD   46
000446  000000G                         .WORD   EGH.30
000450  000000G                         .WORD   EMS.30
000452  000424                          BR      21$                     ;                       7277
000454  010746          20$:            MOV     PC,-(SP)                ; PC,*                  7289
000456  013746  000000G                 MOV     L$LUN,-(SP)
000462  010146                          MOV     R1,-(SP)
000464  012746  000000G                 MOV     #DF.MSG,-(SP)
000470  012746  000004                  MOV     #4,-(SP)
000474  010600                          MOV     SP,R0                   ; SP,*
000476  104414                          TRAP    14
000500  012716  000000G                 MOV     #HRD.SUB,(SP)           ;                       7290
000504  012746  000001                  MOV     #1,-(SP)
000510  010600                          MOV     SP,R0                   ; SP,*
000512  104414                          TRAP    14
000514  004737  000000G                 JSR     PC,EMS.ERR              ;                       7291
000520  062706  000014                  ADD     #14,SP                  ;                       7287
000524  010200          21$:            MOV     R2,R0                   ; CUR.PRIORITY,*        7295
000526  104441                          TRAP    41
000530  000207                          RTS     PC                      ;                       7176

; Routine Size:  173 words,     Routine Base:  $CODE$ + 27066
; Maximum stack depth per invocation:  11 words
```

```
000152                                  .PSECT  $PLIT$,  RO ,  D

                                P.AAD:                                  ; CASE Table for ERR.HRD.RTNE AP-0126   7219
000152  000000                  3$:     .WORD   0                       ; [4$]
000154  000012                          .WORD   12                      ; [5$]
000156  000236                          .WORD   236                     ; [17$]
000160  000236                          .WORD   236                     ; [17$]
000162  000236                          .WORD   236                     ; [17$]
000164  000024                          .WORD   24                      ; [6$]
000166  000036                          .WORD   36                      ; [7$]
000170  000236                          .WORD   236                     ; [17$]
000172  000050                          .WORD   50                      ; [8$]
000174  000062                          .WORD   62                      ; [9$]
000176  000074                          .WORD   74                      ; [10$]
000200  000106                          .WORD   106                     ; [11$]
000202  000120                          .WORD   120                     ; [12$]
000204  000132                          .WORD   132                     ; [13$]
000206  000144                          .WORD   144                     ; [14$]


;    7299  1
;    7300  1
```

```
;    7301  1      routine ERR_SOFT_RTNE APT (ERRNUM, index) : novalue =
;    7302  1
;    7303  1      !+
;    7304  1      ! THIS ROUTINE DECIDES WHETHER TO ISSUE AN 'ERRSOFT' MACRO CALL TO DRS OR TO FAKE
;    7305  1      ! THE SAME EFFECT WITHOUT ISSUING THE CALL
;    7306  1      !-
;    7307  1
;    7308  2          begin
;    7309  2
;    7310  2          local
;    7311  2              ELOG_ADDR : ref block [EP_LEN, word] field (EP_FIELDS);
;    7312  2
;    7313  2          builtin
;    7314  2              PC;
;    7315  2
;    7316  2          ELOG_ADDR = ELOG_PKT + (.index * EP_LEN * 2);       ! ADDRESS OF THE SAVED ERROR LOG INFORMATION
;    7317  2
;    7318  2          if .APT_MODE
;    7319  2          then
;    7320  3              begin
;    7321  3              .MAIL_BOX_TESTNUM = .ELOG_ADDR [EL_BLOCK];      ! CHANGE TEST NUMBER TO SHOW LBN UNDER APT ONLY
;    7322  3              .MAIL_BOX_SUBTST = .ELOG_ADDR [EL_DK_NUM];      ! CHANGE SUB-TEST NUMBER TO SHOW DISK NUMBER IN APT ONLY
;    7323  2              end;
;    7324  2
;    7325  3          if BIT_TST (SWP_FLAGS, SWF_SFT)                     ! IF SOFT ERRORS TO BE TREATED LIKE OTHER ERRORS
;    7326  2          then
;    7327  2
;    7328  2              case .ERRNUM from 50 to 54 of
;    7329  2                  set
;    7330  2
;    7331  2                  [50]:       ERRDF (50, 0, 0);               ! CONTROLLER ERROR
;    7332  2
;    7333  2                  [51]:       ERRDF (51, 0, 0);               ! HOST MEMORY ACCESS ERROR
;    7334  2
;    7335  2                  [52]:       ERRDF (52, 0, 0);               ! DISK TRANSFER ERROR
;    7336  2
;    7337  2                  [53]:       ERRDF (53, 0, 0);               ! SDI ERROR
;    7338  2
;    7339  2                  [54]:       ERRDF (54, 0, 0);               ! SMALL DISK ERROR
;    7340  2                  tes
;    7341  2          else
;    7342  3              begin
;    7343  3              !****increment error count                      ! INCREMENT TOTAL ERROR COUNT
;    7344  3              PRINTB (DF_MSG, .ERRNUM, .L$LUN, .PC);          ! PRINT ERROR LINE JUST LIKE DRS
;    7345  2              end;
;    7346  2
;    7347  1          end;


                                        .SBTTL  ERR.SOFT.RTNE.APT RDRX INTERRUPT SERVICE ROUTINES
027620                                  .PSECT  $CODE$,  RO

000000  016646  000002          ERR.SOFT.RTNE.APT:
```

```
                                                MOV     2(SP),-(SP)             ; INDEX,*                               7316
000004  012746  000102                          MOV     #102,-(SP)
000010  004737  000000G                         JSR     PC,BL$MUL
000014  062700  000000G                         ADD     #ELOG.PKT,R0
000020  032737  000001  001254'                 BIT     #1,APT.MODE             ;                                       7318
000026  001406                                  BEQ     1$
000030  016077  000056  001256'                 MOV     56(R0),@MAIL.BOX.TESTNUM ; *(ELOG.ADDR),*                       7321
000036  016077  000012  001260'                 MOV     12(R0),@MAIL.BOX.SUBTST ; *(ELOG.ADDR),*                        7322
000044  032737  020000  000000G       1$:       BIT     #20000,SWP.FLAGS        ;                                       7325
000052  001440                                  BEQ     8$
000054  016600  000010                          MOV     10(SP),R0               ; ERRNUM,*                              7328
000060  162700  000062                          SUB     #62,R0
000064  006300                                  ASL     R0
000066  066007  000210'                         ADD     P.AAE(R0),PC            ; Case dispatch
000072  104455                          3$:     TRAP    55                      ;                                       7331
000074  000062                                  .WORD   62
000076  000000                                  .WORD   0
000100  000000                                  .WORD   0
000102  000441                                  BR      9$                      ;                                       7328
000104  104455                          4$:     TRAP    55                      ;                                       7333
000106  000063                                  .WORD   63
000110  000000                                  .WORD   0
000112  000000                                  .WORD   0
000114  000434                                  BR      9$                      ;                                       7328
000116  104455                          5$:     TRAP    55                      ;                                       7335
000120  000064                                  .WORD   64
000122  000000                                  .WORD   0
000124  000000                                  .WORD   0
000126  000427                                  BR      9$                      ;                                       7328
000130  104455                          6$:     TRAP    55                      ;                                       7337
000132  000065                                  .WORD   65
000134  000000                                  .WORD   0
000136  000000                                  .WORD   0
000140  000422                                  BR      9$                      ;                                       7328
000142  104455                          7$:     TRAP    55                      ;                                       7339
000144  000066                                  .WORD   66
000146  000000                                  .WORD   0
000150  000000                                  .WORD   0
000152  000415                                  BR      9$                      ;                                       7325
000154  010716                          8$:     MOV     PC,(SP)                 ; PC,*                                  7344
000156  013746  000000G                         MOV     L$LUN,-(SP)
000162  016646  000012                          MOV     12(SP),-(SP)            ; ERRNUM,*
000166  012746  000000G                         MOV     #DF.MSG,-(SP)
000172  012746  000004                          MOV     #4,-(SP)
000176  010600                                  MOV     SP,R0                   ; SP,*
000200  104414                                  TRAP    14
000202  062706  000010                          ADD     #10,SP                  ;                                       7342
000206  022626                          9$:     CMP     (SP)+,(SP)+             ;                                       7308
000210  000207                                  RTS     PC                      ;                                       7301

; Routine Size:  69 words,      Routine Base:  $CODE$ + 27620
; Maximum stack depth per invocation:  8 words
```

```
000210                                  .PSECT  $PLIT$,  RO ,  D

                                P.AAE:                                  ; CASE Table for ERR.SOFT.RTNE.A+0066   7328
000210  000000                  2$:     .WORD   0                       ; [3$]
000212  000012                          .WORD   12                      ; [4$]
000214  000024                          .WORD   24                      ; [5$]
000216  000036                          .WORD   36                      ; [6$]
000220  000050                          .WORD   50                      ; [7$]


;    7348  1
;    7349  1
;    7350  1     end
;    7351  1
;    7352  0     eludom


;                               OTS external references
                                        .GLOBL  $SAVE5, $SAVE4, $SAVE3, $SAVE2
                                        .GLOBL  BL$SHF, BL$DIV, BL$MOD, BL$MUL


;                               PSECT SUMMARY
;
;       Psect Name              Words     Attributes
;         $GGG$                   353       RO ,  I  ,  LCL,  REL,  CON
;         $CODE$                 6157       RO ,  I  ,  LCL,  REL,  CON
;         $PLIT$                   73       RO ,  D  ,  LCL,  REL,  CON


;                           Library Statistics
;
;                                       -------- Symbols --------      Pages       Processing
;       File                            Total    Loaded   Percent      Mapped      Time
;
;  DISK$USER2:[MLYNAR.ZRQ]ZRQAH0.L16;10   411       312        75        21        00:00.1




;                               COMMAND QUALIFIERS

;       BLISS/PDP11 ZRQAH0.BL2/LIST=ZRQAH0.LS2/OBJECT=ZRQAH0.OB2/SOURCE=PAGE:53
```

```
;    7353  0      module ZRQAM4 (
;    7354  0
;    7355  0      %title 'RD/RX EXERCISER'
;    7356  0                     ident = 'V01.9',
;    7357  0                     addressing_mode (absolute),
;    7358  0                     environment (noeis)
;    7359  0                     ) =
;    7360  0
;    7361  1      begin
;    7362  1
;    7363  1      %sbttl 'LASTAD AND SETUP'
;    7364  1
;    7365  1      library 'ZRQAM0.L16';
;    7366  1
;    7367  1      !MMM require 'BLSMAC.REQ';                    ! DIAGNOSTIC SUPERVISOR LIBRARY      ZZZ
;    7368  1      require 'HSAXA0.BLB';                         ! DIAGNOSTIC SUPERVISOR LIBRARY      ZZZ
;    9109  1
;    9110  2      LASTAD
;    9111  2
;    9112  2      BGNSETUP (4)                                                                       !ZZZ
;    9113  2
; P  9114  2              BGNPTAB
; P  9115  2                      INIT_IP_ADDR, INIT_INTR_VECT, INIT_BR_LEVEL, %o'000020', 0, 0, RD52_MAX_LBN, 0  !ZZZ
; P  9116  2                              ! IP, VECTOR, BR, DISK ADDR, START BLOCK, END BLOCK
; P  9117  2
;    9118  2              ENDPTAB
;    9119  2
; P  9120  2              BGNPTAB
; P  9121  2                      INIT_IP_ADDR, INIT_INTR_VECT, INIT_BR_LEVEL, %o'000001', 0, 0, RX50_MAX_LBN, 0  !ZZZ
; P  9122  2                              ! IP, VECTOR, BR, DISK ADDR, START BLOCK, END BLOCK
;    9123  2              ENDPTAB
;    9124  2
; P  9125  2              BGNPTAB
; P  9126  2                      INIT_IP_ADDR, INIT_INTR_VECT, INIT_BR_LEVEL, %o'000002', 0, 0, RX50_MAX_LBN, 0  !ZZZ
; P  9127  2                              ! IP, VECTOR, BR, DISK ADDR, START BLOCK, END BLOCK
;    9128  2              ENDPTAB
; P  9129  2              BGNPTAB
; P  9130  2                      INIT_IP_ADDR, INIT_INTR_VECT, INIT_BR_LEVEL, %o'000003', 0, 0, RX50_MAX_LBN, 0  !ZZZ
; P  9131  2                              !HERE'S ONE FOR THE 4TH DRIVE                                              !ZZZ
;    9132  2              ENDPTAB                                                                                    !ZZZ
;    9133  2
;    9134  1      ENDSETUP

                                        .TITLE  ZRQAM4 RD/RX EXERCISER
                                        .IDENT  /V01.9/
                                        .ENABL  AMA

000000                                  .PSECT  $XYZ$,  RO
000000  000124'                BL$LAS::.WORD   T$FREE
000002  000000C                        .WORD   <<T$FREE-<BL$LAS+4>>/2>
000004  000034'                P.AAA:  .WORD   L$LAST+30
```

```
000006  000010                          .WORD   10                      ; Plit count word
000010  172150          P.AAB:         .WORD   -5630
000012  000154                          .WORD   154
000014  000004                          .WORD   4
000016  000020                          .WORD   20
000020  000000                          .WORD   0
000022  000000                          .WORD   0
000024  150477                          .WORD   -27301
000026  000000                          .WORD   0
000030  000060'          P.AAC:         .WORD   L$LAST+54
000032  000010                          .WORD   10                      ; Plit count word
000034  172150          P.AAD:         .WORD   -5630
000036  000154                          .WORD   154
000040  000004                          .WORD   4
000042  000001                          .WORD   1
000044  000000                          .WORD   0
000046  000000                          .WORD   0
000050  001437                          .WORD   1437
000052  000000                          .WORD   0
000054  000104'          P.AAE:         .WORD   L$LAST+100
000056  000010                          .WORD   10                      ; Plit count word
000060  172150          P.AAF:         .WORD   -5630
000062  000154                          .WORD   154
000064  000004                          .WORD   4
000066  000002                          .WORD   2
000070  000000                          .WORD   0
000072  000000                          .WORD   0
000074  001437                          .WORD   1437
000076  000000                          .WORD   0
000100  000000          P.AAG:         .WORD   0
000102  000010                          .WORD   10                      ; Plit count word
000104  172150          P.AAH:         .WORD   -5630
000106  000154                          .WORD   154
000110  000004                          .WORD   4
000112  000003                          .WORD   3
000114  000000                          .WORD   0
000116  000000                          .WORD   0
000120  001437                          .WORD   1437
000122  000000                          .WORD   0
000124  000000          T$FREE::       .WORD   0

        000004'         L$LAST==                BL$LAS+4
        000004          T$PTHV==                4
        000004'         $LAS5=                  P.AAA
        000010'         $REM5=                  P.AAB
        000030'         $LAS4=                  P.AAC
        000034'         $REM4=                  P.AAD
        000054'         $LAS3=                  P.AAE
        000060'         $REM3=                  P.AAF
        000100'         $$LAS1=                 P.AAG
        000104'         $REM2=                  P.AAH
```

```
                                        .SBTTL  $END.LINK LASTAD AND SETUP
000000  000207                          $END.LINK::
                                            RTS     PC                                  ;                                       9108

; Routine Size:  1 word,        Routine Base:  $XYZ$ + 0126
; Maximum stack depth per invocation:  0 words


;   9135  1     end
;   9136  1
;   9137  0     eludom


;                                       PSECT SUMMARY
;
;       Psect Name                      Words     Attributes
;        $XYZ$                             44       RO ,  I  ,  LCL,  REL,  CON


;                                  Library Statistics
;
;                                           -------- Symbols --------      Pages       Processing
;       File                                Total    Loaded   Percent      Mapped      Time
;
;  DISK$USER2:[MLYNAR.ZRQ]ZRQAH0.L16;10       411         7         1        21         00:00.1




;                                       COMMAND QUALIFIERS

;       BLISS/PDP11 ZRQAH0.BL2/LIST=ZRQAH0.LS2/OBJECT=ZRQAH0.OB2/SOURCE=PAGE:53

; Size:         6158 code + 469 data words
; Run Time:        02:19.8
; Elapsed Time:    09:52.7
; Lines/CPU Min:    3922
; Lexemes/CPU-Min: 29675
; Memory Used:  501 pages
; Compilation Complete
```

```
Partition name : DUMMY
Identification : V02.3
Task  UIC      : [202,12]
Task attributes: -HD
Total address windows: 1.
Task  image  size  : 16704. words
Task address limits: 002000 103143
R-W disk blk limits: 000002 000103 000102 00066.

*** Root segment: ZRQAH0


R/W mem  limits: 002000 103143 101144 33380.
Disk blk limits: 000002 000103 000102 00066.


Memory allocation synopsis:

Section                                          Title  Ident  File
-------                                          -----  -----  ----
. BLK.:(RW,I,LCL,REL,CON)      002000 000000 00000.
$CODE$:(RO,I,LCL,REL,CON)      002000 071746 29670.
                               002000 024110 10312.  ZRQAM1 V02.3  ZRQAH0.OB1;3
                               026110 015160 06768.  ZRQAM2 V02.3  ZRQAH0.OB1;3
                               043270 030032 12314.  ZRQAM3 V02.3  ZRQAH0.OB2;3
                               073322 000316 00206.  B16MUL 2.8    NOEIS.OLB;1
                               073640 000106 00070.  B16SAV 2.4    NOEIS.OLB;1
$FFF$ :(RW,D,GBL,REL,CON)      073746 005056 02606.
                               073746 005056 02606.  ZRQAM1 V02.3  ZRQAH0.OB1;3
$GGG$ :(RO,I,LCL,REL,CON)      101024 001302 00706.
                               101024 001302 00706.  ZRQAM3 V02.3  ZRQAH0.OB2;3
$OWN$ :(RW,D,LCL,REL,CON)      102326 000244 00164.
                               102326 000244 00164.  ZRQAM2 V02.3  ZRQAH0.OB1;3
$PLIT$:(RO,D,LCL,REL,CON)      102572 000222 00146.
                               102572 000222 00146.  ZRQAM3 V02.3  ZRQAH0.OB2;3
$XYZ$ :(RO,I,LCL,REL,CON)      103014 000130 00088.
                               103014 000130 00088.  ZRQAM4 V01.9  ZRQAH0.OB2;3


Global symbols:

ADDR.V 101023-R  BIT06  000100    BIT4   000020    BST    074126-R  CRLF   025742-R  DBM101 006226-R  DBM126 007260-R
ADR    000020    BIT07  000200    BIT5   000040    BUFF.A 100604-R  CRN.HI 100716-R  DBM104 006254-R  DBM127 007340-R
ASTERI 025754-R  BIT08  000400    BIT6   000100    BUFF.O 100624-R  CRN.LO 100714-R  DBM105 006316-R  DBM128 007416-R
AZINT  065106-R  BIT09  001000    BIT7   000200    BYTS.P 100674-R  CSR.AD 101004-R  DBM107 006354-R  DBM15  005204-R
AZINTO 065070-R  BIT1   000002    BIT8   000400    CCTLR  100654-R  CSR.ME 101002-R  DBM108 006412-R  DBM18  005234-R
BAL.IN 100762-R  BIT10  002000    BIT9   001000    CDISK  100656-R  CST    073746-R  DBM109 006502-R  DBM19  005306-R
BIT0   000001    BIT11  004000    BL$DIV 073546-R  CER.01 017342-R  CST.AD 074074-R  DBM111 006562-R  DBM20  005372-R
BIT00  000001    BIT12  010000    BL$LAS 103014-R  CER.02 017406-R  CTLR.C 100662-R  DBM112 006662-R  DBM21  005446-R
BIT01  000002    BIT13  020000    BL$MOD 073560-R  CLK.PR 100740-R  CTLR.I 045266-R  DBM12  005130-R  DBM22  005530-R
BIT02  000004    BIT14  040000    BL$MUL 073322-R  CLK.TI 100732-R  CUOFF  100660-R  DBM120 006764-R  DBM23  005574-R
BIT03  000010    BIT15  100000    BL$SHF 073572-R  CMD.TI 100710-R  C.ERR. 074546-R  DBM121 007056-R  DBM25  005632-R
BIT04  000020    BIT2   000004    BOE    000400    CNTR.E 024652-R  DASH   025746-R  DBM123 007146-R  DBM26  005700-R
BIT05  000040    BIT3   000010    BRLEVE 101012-R  CREDIT 100724-R  DATAGM 067524-R  DBM125 007210-R  DBM27  005732-R
```

DBM28A	006004-R	EH.10	013770-R	EX.ONL	015520-R	GP$5	026220-R	L$AUT	002070-R	L$SWLE	026012-R	QIO.SI	060240-R
DBM28B	006044-R	EH.12	014020-R	EX.OP	015544-R	GP$6	026230-R	L$AUTO	032242-R	L$TEST	002114-R	QIO.UN	055512-R
DBM29	006104-R	EH.13	014054-R	EX.PBN	016010-R	GP$7	026242-R	L$CCP	002106-R	L$TIML	002014-R	RANDOM	074506-R
DBM32	006152-R	EH.2	013452-R	EX.RBN	016166-R	GP$8	026254-R	L$CLEA	032542-R	L$UNIT	002012-R	RANDY	055234-R
DBM5	005102-R	EH.3	013512-R	EX.RD	015464-R	GP$9	026270-R	L$CO	002032-R	MAN.TS	026074-R	RDM.CN	074504-R
DCT	074076-R	EH.4	013550-R	EX.RP	016730-R	HARD.E	061456-R	L$DEPO	002011-R	MD.INI	053700-R	RDRX.A	074122-R
DCT.AD	074120-R	EH.5	013574-R	EX.SA	015350-R	HARD.I	046744-R	L$DESC	026130-R	MINUTE	100730-R	RDRX.E	025372-R
DFPTBL	025764-R	EH.6	013624-R	EX.SB	015422-R	HOE	100000	L$DESP	002076-R	MODULA	035632-R	RD.COU	101010-R
DF.MSG	025410-R	EH.7	013654-R	EX.SBO	015416-R	HOE.FL	100741-R	L$DEVP	002060-R	MSCP.P	074550-R	REG.EX	045714-R
DISK.R	066102-R	EH.8	013704-R	EX.SC	015366-R	HOST.W	064150-R	L$DISP	002124-R	MSG.01	010252-R	RETPKT	076276-R
DRIVER	044734-R	EH.9	013740-R	EX.TIM	017026-R	HOURS	100727-R	L$DLY	002116-R	MSG.02	010304-R	ROUND.	063604-R
DROP.C	034772-R	ELG.FM	015334-R	EX.WRD	017016-R	HRD.MS	025506-R	L$DTP	002040-R	MSG.03	010340-R	RPS.RE	064566-R
DRV.CT	035100-R	ELG.OO	014720-R	EX.WRT	015474-R	HRD.SU	025704-R	L$DTYP	002034-R	MULTI.	053234-R	RPT1	010372-R
DR.ERR	052462-R	ELOG.P	077052-R	FATAL.	065306-R	HWPTE0	026000-R	L$DU	033146-R	NAME.H	026006-R	RPT10	011102-R
DR.RET	064754-R	EMS.BL	037504-R	FER.BC	101020-R	HWPTE1	026002-R	L$DUT	002072-R	NAME.L	026004-R	RPT11	011170-R
DUPROU	026072-R	EMS.CM	042052-R	FER.LB	101016-R	HWPTS0	025774-R	L$DVTY	026110-R	NEX	100712-R	RPT12	011236-R
DUP.FL	100652-R	EMS.EL	040430-R	FERO.L	100734-R	HWPTS1	025776-R	L$EF	002052-R	NEXT.P	100726-R	RPT13	011304-R
DUR	100664-R	EMS.ER	042440-R	FER1.L	100736-R	HWPT.B	025770-R	L$ENVI	002044-R	NEX.TR	033250-R	RPT14	011404-R
DU.MSG	007504-R	EMS.R1	040364-R	FILL.B	060450-R	HWPT.D	025772-R	L$ERRT	002126-R	NULL	005100-R	RPT15	011502-R
DU.RSN	010224-R	EMS.R2	040234-R	FORCED	101015-R	HWPT.I	025764-R	L$ETP	002102-R	OFF	000002	RPT16	011602-R
D$PCNT	002122-R	EMS.01	042650-R	FORCE.	100772-R	HWPT.V	025766-R	L$EXP1	002046-R	OF.RC	100704-R	RPT2	010456-R
D.FAIL	101014-R	EMS.10	042706-R	FREE.M	100672-R	HWQ1	002460-R	L$EXP4	002064-R	ON	000001	RPT3	010522-R
EBD.10	012766-R	EMS.12	042750-R	FSET.U	061332-R	HWQ2	002474-R	L$EXP5	002066-R	OUT.IO	034646-R	RPT4	010606-R
EBD.12	013026-R	EMS.13	043006-R	GET.IO	034466-R	HWQ3	002504-R	L$HARD	026154-R	OVF.CH	063530-R	RPT5	010652-R
EBD.13	013074-R	EMS.14	043050-R	GET.PK	033620-R	HWQ4	002546-R	L$HIME	002120-R	PARITY	033260-R	RPT6	010740-R
EBD.14	013126-R	EMS.18	043112-R	GET.RA	055124-R	HWQ5	002564-R	L$HPCP	002016-R	PKT.US	076262-R	RPT7	011004-R
EBD.18	013166-R	EMS.21	043160-R	GET.RE	034344-R	HWQ6A	002634-R	L$HPTP	002022-R	PNT	001000	RPT8	011022-R
EBD.19	013222-R	EMS.24	043204-R	GP$DIS	026476-R	HWQ6B	002706-R	L$HRDL	026152-R	POLL.C	065540-R	RPT9	011050-R
EBD.24	013302-R	EMS.30	043252-R	GP$1	026154-R	HWQ7A	002762-R	L$HW	025764-R	POLL.R	065640-R	RP.ADD	077050-R
EBS.01	012724-R	ENTRY.	100650-R	GP$10	026304-R	HWQ7B	003032-R	L$HWLE	025762-R	PRI	002000	RP.IND	077046-R
EF.CON	000036	EOP.FL	100651-R	GP$11	026314-R	HWQ8	003102-R	L$ICP	002104-R	PRIO0	000000	RP.USE	077036-R
EF.NEW	000035	ERRBLK	002134-R	GP$12	026330-R	HWQ9	003160-R	L$INIT	032230-R	PRIO1	000040	SA.REG	100706-R
EF.PWR	000034	ERRMSG	002132-R	GP$13	026342-R	IBE	010000	L$LADP	002026-R	PRIO2	000100	SB.COD	100700-R
EF.RES	000037	ERRNBR	002130-R	GP$14	026354-R	IDU	000040	L$LAST	103020-R	PRIO3	000140	SC.CLK	022610-R
EF.STA	000040	ERRTYP	002126-R	GP$15	026366-R	IER	020000	L$LOAD	002100-R	PRIO4	000200	SC.CON	017506-R
EGD.10	011776-R	ERR.CO	014662-R	GP$16	026400-R	INIT.I	054040-R	L$LUN	002074-R	PRIO5	000240	SC.CTO	022052-R
EGD.11	012036-R	ERR.OO	014126-R	GP$17	026406-R	INIT.O	101022-R	L$MREV	002050-R	PRIO6	000300	SC.DIS	020104-R
EGD.12	012062-R	EVL	000004	GP$18	026414-R	INIT.T	044576-R	L$NAME	002000-R	PRIO7	000340	SC.DST	020514-R
EGD.13	012110-R	EX.ACC	015532-R	GP$19	026422-R	INI.CT	045570-R	L$NDHR	026324-R	PROC.R	060702-R	SC.DS2	020570-R
EGD.14	012136-R	EX.BBU	015670-R	GP$2	026164-R	INI.RR	047614-R	L$NDHW	026010-R	PTCH1	002136-R	SC.DUP	017530-R
EGD.15	012166-R	EX.BB1	015616-R	GP$20	026430-R	INT.GE	046454-R	L$NDSF	026624-R	PTCH2	002210-R	SC.ECC	020642-R
EGD.16	012204-R	EX.BB2	015550-R	GP$21	026436-R	IN.IOD	034704-R	L$NDSW	026100-R	PTCH3	002262-R	SC.ECD	020724-R
EGD.17	012234-R	EX.BC	016416-R	GP$22	026452-R	IODQ	100634-R	L$PRIO	002042-R	PTCH4	002334-R	SC.EC1	021174-R
EGD.18	012252-R	EX.BD	016472-R	GP$23	026462-R	IODQ.I	100644-R	L$PROT	026102-R	PTCH5	002406-R	SC.EC2	021224-R
EGD.19	012272-R	EX.BDR	016550-R	GP$24	026470-R	IODQ.O	100646-R	L$PRT	002112-R	PUTA.B	034606-R	SC.EC3	021254-R
EGD.20	012332-R	EX.BDW	016640-R	GP$25	026502-R	IO.RET	061062-R	L$REPP	002062-R	PUT.IO	034542-R	SC.EC4	021306-R
EGD.21	012420-R	EX.CBC	016226-R	GP$26	026516-R	IPKT.A	076260-R	L$REV	002010-R	PUT.PK	034204-R	SC.EC5	021336-R
EGD.22	012532-R	EX.CBR	016272-R	GP$27	026526-R	IRDRX.	074124-R	L$RPT	027462-R	PUT.RE	034452-R	SC.EC6	021366-R
EGD.23	012572-R	EX.CBW	016344-R	GP$28	026542-R	ISR	000100	L$SFTL	026326-R	P.INDE	101006-R	SC.EC7	021416-R
EGD.24	012634-R	EX.CMD	015444-R	GP$29	026560-R	IXE	004000	L$SOFT	026330-R	QIO	100670-R	SC.EC8	021450-R
EGH.30	012700-R	EX.CMP	015504-R	GP$3	026174-R	LOE	040000	L$SPC	002056-R	QIO.FU	057116-R	SC.EC9	021502-R
EGS.01	011664-R	EX.LB	017064-R	GP$30	026572-R	LOT	000010	L$SPCP	002020-R	QIO.GE	054524-R	SC.EDC	022202-R
EGS.02	011704-R	EX.LBN	015750-R	GP$31	026610-R	L$ACP	002110-R	L$SPTP	002024-R	QIO.LB	057436-R	SC.FCT	021126-R
EH.0	013356-R	EX.LBR	016050-R	GP$32	026616-R	L$APT	002036-R	L$STA	002030-R	QIO.OK	054244-R	SC.FER	020176-R
EH.1	013414-R	EX.LBW	016116-R	GP$4	026206-R	L$AU	033240-R	L$SW	026014-R	QIO.OU	054452-R	SC.FE2	020264 R

```
SC.FUL 020776-R  SC.PSP 022734-R  SC.VOL 017752-R  SWP.DP 026022-R  SWQ17  004126-R  TEMP1  100720-R  XX13   017130-R
SC.HWP 021604-R  SC.RCT 020756-R  SC.576 021052-R  SWP.ER 026014-R  SWQ19  004224-R  TEMP2  100722-R  XX23   017152-R
SC.IDS 022242-R  SC.RDY 022526-R  SEND   035156-R  SWP.FL 026020-R  SWQ2   003302-R  TIME   033342-R  XX32   017206-R
SC.INR 017622-R  SC.REF 023130-R  SEQUEN 066202-R  SWP.RA 026024-R  SWQ20  004314-R  TRK.SG 074500-R  XX33   017234-R
SC.INV 017654-R  SC.REP 023016-R  SET.CP 033424-R  SWP.TI 026026-R  SWQ21  004402-R  TST.PA 026076-R  XX34   017272-R
SC.IOP 020032-R  SC.RSP 022636-R  SET.CT 047716-R  SWP.UC 026030-R  SWQ22  004466-R  TYPER  100742-R  $END.L 103142-R
SC.ISH 020354-R  SC.SAF 021644-R  SET.UP 033520-R  SWP.UD 026032-R  SWQ23  004526-R  TYPEW  100752-R  $SAVE2 073640-R
SC.IS2 020434-R  SC.SDI 017462-R  SFPTBL 026014-R  SWP.XF 026016-R  SWQ24  004600-R  T$FREE 103140-R  $SAVE3 073654-R
SC.NBB 023060-R  SC.SDS 022124-R  SFT.MS 025604-R  SWQ1   003260-R  SWQ26  004644-R  T$PTHV 000004    $SAVE4 073672-R
SC.NXM 021762-R  SC.SDN 017602-R  SOFT.E 070346-R  SWQ10  003532-R  SWQ27  005004-R  T.ADDR 074476-R  $SAVE5 073712-R
SC.ODA 021710-R  SC.SRI 022404-R  SPACE4 025736-R  SWQ11  003576-R  SWQ28  005030-R  T1     044562-R
SC.ODB 021740-R  SC.SRT 022312-R  STEP   100702-R  SWQ12  003630-R  SWQ4   003362-R  UAM    000200
SC.ONL 017560-R  SC.SUR 022704-R  ST.COD 100676-R  SWQ13  003726-R  SWQ7   003404-R  UPD.IO 062662-R
SC.PAR 022016-R  SC.SWP 021544-R  SWEEP  064434-R  SWQ14  004004-R  SWQ9   003456-R  VEC.BR 046126-R
SC.POE 022472-R  SC.UNK 017672-R  SWM1   004706-R  SWQ15  004056-R  TALLY  074146-R  WAIT   035614-R


*** Task builder statistics:

    Total work file references: 146628.
    Work  file  reads: 0.
    Work  file writes: 0.
    Size of core pool: 23454. words (91. pages)
    Size of work file: 5120. words (20. pages)

    Elapsed time:00:00:46
```

ZRQAHO CREATED BY TKB ON 10-OCT-85 AT 09:56 PAGE 1

GLOBAL CROSS REFERENCE CREF V02

SYMBOL	VALUE	REFERENCES...		
ADDR.V	101023-R	# ZRQAM1	ZRQAM2	ZRQAM3
ADR	000020	# ZRQAM1	# ZRQAM2	# ZRQAM3
ASTERI	025754-R	# ZRQAM1	ZRQAM2	
AZINT	065106-R	# ZRQAM3		
AZINTO	065070-R	# ZRQAM3		
BAL.IN	100762-R	# ZRQAM1	ZRQAM2	ZRQAM3
BIT0	000001	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT00	000001	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT01	000002	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT02	000004	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT03	000010	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT04	000020	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT05	000040	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT06	000100	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT07	000200	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT08	000400	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT09	001000	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT1	000002	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT10	002000	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT11	004000	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT12	010000	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT13	020000	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT14	040000	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT15	100000	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT2	000004	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT3	000010	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT4	000020	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT5	000040	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT6	000100	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT7	000200	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT8	000400	# ZRQAM1	# ZRQAM2	# ZRQAM3
BIT9	001000	# ZRQAM1	# ZRQAM2	# ZRQAM3
BL$DIV	073546-R	# B16MUL	ZRQAM2	ZRQAM3
BL$LAS	103014-R	# ZRQAM4		
BL$MOD	073560-R	# B16MUL	ZRQAM2	ZRQAM3
BL$MUL	073322-R	# B16MUL	ZRQAM2	ZRQAM3
BL$SHF	073572-R	# B16MUL	ZRQAM3	
BOE	000400	# ZRQAM1	# ZRQAM2	# ZRQAM3
BRLEVE	101012-R	# ZRQAM1	ZRQAM2	ZRQAM3
BST	074126-R	# ZRQAM1	ZRQAM2	ZRQAM3
BUFF.A	100604-R	# ZRQAM1	ZRQAM2	ZRQAM3
BUFF.O	100624-R	# ZRQAM1	ZRQAM2	ZRQAM3
BYTS.P	100674-R	# ZRQAM1	ZRQAM2	ZRQAM3
CCTLR	100654-R	# ZRQAM1	ZRQAM2	ZRQAM3
CDISK	100656-R	# ZRQAM1	ZRQAM2	ZRQAM3
CER.01	017342-R	# ZRQAM1	ZRQAM2	
CER.02	017406-R	# ZRQAM1	ZRQAM2	
CLK.PR	100740-R	# ZRQAM1	ZRQAM2	ZRQAM3
CLK.TI	100732-R	# ZRQAM1	ZRQAM2	ZRQAM3
CMD.TI	100710-R	# ZRQAM1	ZRQAM2	ZRQAM3
CNTR.E	024652-R	# ZRQAM1	ZRQAM2	
CREDIT	100724-R	# ZRQAM1	ZRQAM2	ZRQAM3

GLOBAL CROSS REFERENCE CREF V02

SYMBOL	VALUE	REFERENCES...		
CRLF	025742-R	# ZRQAM1	ZRQAM2	ZRQAM3
CRN.HI	100716-R	# ZRQAM1	ZRQAM2	ZRQAM3
CRN.LO	100714-R	# ZRQAM1	ZRQAM2	ZRQAM3
CSR.AD	101004-R	# ZRQAM1	ZRQAM2	ZRQAM3
CSR.ME	101002-R	# ZRQAM1	ZRQAM2	ZRQAM3
CST	073746-R	# ZRQAM1	ZRQAM2	ZRQAM3
CST.AD	074074-R	# ZRQAM1	ZRQAM2	ZRQAM3
CTLR.C	100662-R	# ZRQAM1	ZRQAM2	ZRQAM3
CTLR.I	045266-R	# ZRQAM3		
CUOFF	100660-R	# ZRQAM1	ZRQAM2	ZRQAM3
C.ERR.	074546-R	# ZRQAM1	ZRQAM2	ZRQAM3
DASH	025746-R	# ZRQAM1	ZRQAM2	
DATAGM	067524-R	# ZRQAM3		
DBM101	006226-R	# ZRQAM1		
DBM104	006254-R	# ZRQAM1		
DBM105	006316-R	# ZRQAM1		
DBM107	006354-R	# ZRQAM1	ZRQAM2	
DBM108	006412-R	# ZRQAM1	ZRQAM3	
DBM109	006502-R	# ZRQAM1	ZRQAM3	
DBM111	006562-R	# ZRQAM1	ZRQAM3	
DBM112	006662-R	# ZRQAM1	ZRQAM3	
DBM12	005130-R	# ZRQAM1	ZRQAM3	
DBM120	006764-R	# ZRQAM1	ZRQAM3	
DBM121	007056-R	# ZRQAM1	ZRQAM3	
DBM123	007146-R	# ZRQAM1	ZRQAM3	
DBM125	007210-R	# ZRQAM1	ZRQAM2	ZRQAM3
DBM126	007260-R	# ZRQAM1	ZRQAM2	ZRQAM3
DBM127	007340-R	# ZRQAM1	ZRQAM3	
DBM128	007416-R	# ZRQAM1	ZRQAM3	
DBM15	005204-R	# ZRQAM1		
DBM18	005234-R	# ZRQAM1	ZRQAM3	
DBM19	005306-R	# ZRQAM1	ZRQAM3	
DBM20	005372-R	# ZRQAM1	ZRQAM3	
DBM21	005446-R	# ZRQAM1	ZRQAM3	
DBM22	005530-R	# ZRQAM1	ZRQAM3	
DBM23	005574-R	# ZRQAM1	ZRQAM3	
DBM25	005632-R	# ZRQAM1	ZRQAM3	
DBM26	005700-R	# ZRQAM1	ZRQAM3	
DBM27	005732-R	# ZRQAM1	ZRQAM3	
DBM28A	006004-R	# ZRQAM1		
DBM28B	006044-R	# ZRQAM1		
DBM29	006104-R	# ZRQAM1	ZRQAM3	
DBM32	006152-R	# ZRQAM1		
DBM5	005102-R	# ZRQAM1	ZRQAM2	
DCT	074076-R	# ZRQAM1	ZRQAM2	ZRQAM3
DCT.AD	074120-R	# ZRQAM1	ZRQAM2	ZRQAM3
DFPTBL	025764-R	# ZRQAM1		
DF.MSG	043410-R	# ZRQAM1	ZRQAM3	
DISK.R	066102-R	# ZRQAM3		
DRIVER	044734-R	# ZRQAM3		
DROP.C	034772-R	# ZRQAM2	ZRQAM3	
DRV.CT	035100-R	# ZRQAM2	ZRQAM3	

SYMBOL	VALUE	REFERENCES...		
DR.ERR	052462-R	# ZRQAM3		
DR.RET	064754-R	# ZRQAM3		
DUPROU	026072-R	# ZRQAM1		
DUP.FL	100652-R	# ZRQAM1	ZRQAM2	ZRQAM3
DUR	100664-R	# ZRQAM1	ZRQAM2	ZRQAM3
DU.MSG	007504-R	# ZRQAM1	ZRQAM2	
DU.RSN	010224-R	# ZRQAM1	ZRQAM2	
D#PCNT	002122-R	# ZRQAM1		
D.FAIL	101014-R	# ZRQAM1	ZRQAM2	ZRQAM3
EBD.10	012766-R	# ZRQAM1	ZRQAM2	
EBD.12	013026-R	# ZRQAM1	ZRQAM2	
EBD.13	013074-R	# ZRQAM1	ZRQAM2	
EBD.14	013126-R	# ZRQAM1	ZRQAM2	
EBD.18	013166-R	# ZRQAM1	ZRQAM2	
EBD.19	013222-R	# ZRQAM1	ZRQAM2	
EBD.24	013302-R	# ZRQAM1	ZRQAM2	
EBS.01	012724-R	# ZRQAM1	ZRQAM2	
EF.CON	000036	# ZRQAM1	# ZRQAM2	# ZRQAM3
EF.NEW	000035	# ZRQAM1	# ZRQAM2	# ZRQAM3
EF.PWR	000034	# ZRQAM1	# ZRQAM2	# ZRQAM3
EF.RES	000037	# ZRQAM1	# ZRQAM2	# ZRQAM3
EF.STA	000040	# ZRQAM1	# ZRQAM2	# ZRQAM3
EGD.10	011776-R	# ZRQAM1	ZRQAM3	
EGD.11	012036-R	# ZRQAM1	ZRQAM3	
EGD.12	012062-R	# ZRQAM1	ZRQAM3	
EGD.13	012110-R	# ZRQAM1	ZRQAM3	
EGD.14	012136-R	# ZRQAM1	ZRQAM3	
EGD.15	012166-R	# ZRQAM1	ZRQAM3	
EGD.16	012204-R	# ZRQAM1	ZRQAM3	
EGD.17	012234-R	# ZRQAM1	ZRQAM3	
EGD.18	012252-R	# ZRQAM1	ZRQAM3	
EGD.19	012272-R	# ZRQAM1	ZRQAM3	
EGD.20	012332-R	# ZRQAM1	ZRQAM3	
EGD.21	012420-R	# ZRQAM1	ZRQAM3	
EGD.22	012532-R	# ZRQAM1	ZRQAM3	
EGD.23	012572-R	# ZRQAM1	ZRQAM3	
EGD.24	012634-R	# ZRQAM1	ZRQAM3	
EGH.30	012700-R	# ZRQAM1	ZRQAM3	
EGS.01	011664-R	# ZRQAM1	ZRQAM2	
EGS.02	011704-R	# ZRQAM1	ZRQAM3	
EH.0	013356-R	# ZRQAM1	ZRQAM2	ZRQAM3
EH.1	013414-R	# ZRQAM1	ZRQAM2	ZRQAM3
EH.10	013770-R	# ZRQAM1	ZRQAM2	ZRQAM3
EH.12	014020-R	# ZRQAM1	ZRQAM2	ZRQAM3
EH.13	014054-R	# ZRQAM1	ZRQAM2	ZRQAM3
EH.2	013452-R	# ZRQAM1	ZRQAM2	ZRQAM3
EH.3	013512-R	# ZRQAM1	ZRQAM2	ZRQAM3
EH.4	013550-R	# ZRQAM1	ZRQAM2	ZRQAM3
EH.5	013574-R	# ZRQAM1	ZRQAM2	ZRQAM3
EH.6	013624-R	# ZRQAM1	ZRQAM2	ZRQAM3
EH.7	013654-R	# ZRQAM1	ZRQAM2	ZRQAM3
EH.8	013704-R	# ZRQAM1	ZRQAM2	ZRQAM3

GLOBAL CROSS REFERENCE CREF V02

SYMBOL	VALUE	REFERENCES...		
EM.9	013740 R	# ZRQAM1	ZRQAM2	ZRQAM3
ELG.FM	015374-R	# ZRQAM1	ZRQAM2	
ELG.OO	014720 R	# ZRQAM1	ZRQAM2	
ELOG.P	077052 R	# ZRQAM1	ZRQAM2	ZRQAM3
EMS.BL	037504 R	# ZRQAM2		
EMS.CM	042052 R	# ZRQAM2	ZRQAM3	
EMS.EL	040430-R	# ZRQAM2	ZRQAM3	
EMS.ER	042440 R	# ZRQAM2	ZRQAM3	
EMS.R1	040364-R	# ZRQAM2	ZRQAM3	
EMS.R2	040234 R	# ZRQAM2	ZRQAM3	
EMS.01	042650-R	# ZRQAM2		
EMS.10	042706-R	# ZRQAM2	ZRQAM3	
EMS.12	042750 R	# ZRQAM2	ZRQAM3	
EMS.13	043006-R	# ZRQAM2	ZRQAM3	
EMS.14	043050-R	# ZRQAM2	ZRQAM3	
EMS.18	043112-R	# ZRQAM2	ZRQAM3	
EMS.21	043160-R	# ZRQAM2	ZRQAM3	
EMS.24	043204-R	# ZRQAM2	ZRQAM3	
EMS.30	043252-R	# ZRQAM2	ZRQAM3	
ENTRY.	100650-R	# ZRQAM1	ZRQAM2	ZRQAM3
EOP.FL	100651-R	# ZRQAM1	ZRQAM2	ZRQAM3
ERRBLK	002134-R	# ZRQAM1		
ERRMSG	002132-R	# ZRQAM1		
ERRNBR	002130-R	# ZRQAM1		
ERRTYP	002126-R	# ZRQAM1		
ERR.CO	014662-R	# ZRQAM1	ZRQAM2	
ERR.OO	014126-R	# ZRQAM1	ZRQAM2	
EVL	000004	# ZRQAM1	# ZRQAM2	# ZRQAM3
EX.ACC	015532-R	# ZRQAM1	ZRQAM2	
EX.BBU	015670-R	# ZRQAM1	ZRQAM2	
EX.BB1	015616-R	# ZRQAM1	ZRQAM2	
EX.BB2	015550-R	# ZRQAM1	ZRQAM2	
EX.BC	016416-R	# ZRQAM1	ZRQAM2	
EX.BD	016472-R	# ZRQAM1	ZRQAM2	
EX.BDR	016550-R	# ZRQAM1	ZRQAM2	
EX.BDW	016640-R	# ZRQAM1	ZRQAM2	
EX.CBC	016226-R	# ZRQAM1	ZRQAM2	
EX.CBR	016272-R	# ZRQAM1	ZRQAM2	
EX.CBW	016344-R	# ZRQAM1	ZRQAM2	
EX.CMD	015444-R	# ZRQAM1	ZRQAM2	
EX.CMP	015504-R	# ZRQAM1	ZRQAM2	
EX.LB	017064-R	# ZRQAM1	ZRQAM2	
EX.LBN	015750-R	# ZRQAM1	ZRQAM2	
EX.LBR	016050-R	# ZRQAM1	ZRQAM2	
EX.LBW	016116-R	# ZRQAM1	ZRQAM2	
EX.ONL	015520-R	# ZRQAM1	ZRQAM2	
EX.OP	015544-R	# ZRQAM1	ZRQAM2	
EX.PBN	016010-R	# ZRQAM1	ZRQAM2	
EX.RBN	016166-R	# ZRQAM1	ZRQAM2	
EX.RD	015464-R	# ZRQAM1	ZRQAM2	
EX.RP	016730-R	# ZRQAM1	ZRQAM2	
EX.SA	015350-R	# ZRQAM1	ZRQAM2	

GLOBAL CROSS REFERENCE CREF V02

SYMBOL	VALUE	REFERENCES...		
EX.SB	015422-R	# ZRQAM1	ZRQAM2	
EX.SBO	015416 R	# ZRQAM1	ZRQAM2	
EX.SC	015366-R	# ZRQAM1	ZRQAM2	
EX.TIM	017026 R	# ZRQAM1	ZRQAM2	
EX.WRD	017016-R	# ZRQAM1	ZRQAM2	
EX.WRT	015474-R	# ZRQAM1	ZRQAM2	
FATAL.	065306-R	# ZRQAM3		
FER.BC	101020-R	# ZRQAM1	ZRQAM2	ZRQAM3
FER.LB	101016-R	# ZRQAM1	ZRQAM2	
FER0.L	100734-R	# ZRQAM1	ZRQAM2	ZRQAM3
FER1.L	100736-R	# ZRQAM1	ZRQAM2	ZRQAM3
FILL.B	060450-R	# ZRQAM3		
FORCED	101015-R	# ZRQAM1	ZRQAM2	ZRQAM3
FORCE.	100772-R	# ZRQAM1	ZRQAM2	ZRQAM3
FREE.M	100672-R	# ZRQAM1	ZRQAM2	ZRQAM3
FSET.U	061332-R	# ZRQAM3		
GET.IO	034466-R	# ZRQAM2	ZRQAM3	
GET.PK	033620-R	# ZRQAM2	ZRQAM3	
GET.RA	055124-R	# ZRQAM3		
GET.RE	034344-R	# ZRQAM2	ZRQAM3	
GP$DIS	026476-R	# ZRQAM2		
GP$1	026154-R	# ZRQAM2		
GP$10	026304-R	# ZRQAM2		
GP$11	026314-R	# ZRQAM2		
GP$12	026330-R	# ZRQAM2		
GP$13	026342-R	# ZRQAM2		
GP$14	026354-R	# ZRQAM2		
GP$15	026366-R	# ZRQAM2		
GP$16	026400-R	# ZRQAM2		
GP$17	026406-R	# ZRQAM2		
GP$18	026414-R	# ZRQAM2		
GP$19	026422-R	# ZRQAM2		
GP$2	026164-R	# ZRQAM2		
GP$20	026430-R	# ZRQAM2		
GP$21	026436-R	# ZRQAM2		
GP$22	026452-R	# ZRQAM2		
GP$23	026462-R	# ZRQAM2		
GP$24	026470-R	# ZRQAM2		
GP$25	026502-R	# ZRQAM2		
GP$26	026516-R	# ZRQAM2		
GP$27	026526-R	# ZRQAM2		
GP$28	026542-R	# ZRQAM2		
GP$29	026560-R	# ZRQAM2		
GP$3	026174-R	# ZRQAM2		
GP$30	026572-R	# ZRQAM2		
GP$31	026610-R	# ZRQAM2		
GP$32	026616-R	# ZRQAM2		
GP$4	026206-R	# ZRQAM2		
GP$5	026220-R	# ZRQAM2		
GP$6	026230-R	# ZRQAM2		
GP$7	026242-R	# ZRQAM2		
GP$8	026254-R	# ZRQAM2		

```
SYMBOL  VALUE      REFERENCES...

GP$9    026270 R  # ZRQAM2
HARD.E  061456-R  # ZRQAM3
HARD.I  046744-R  # ZRQAM3
HOE     100000    # ZRQAM1  # ZRQAM2  # ZRQAM3
HOE.FL  100741-R  # ZRQAM1    ZRQAM2    ZRQAM3
HOST.W  064150-R  # ZRQAM3
HOURS   100727-R  # ZRQAM1    ZRQAM2    ZRQAM3
HRD.MS  025506-R  # ZRQAM1    ZRQAM3
HRD.SU  025704-R  # ZRQAM1    ZRQAM3
HWPTE0  026000-R  # ZRQAM1
HWPTE1  026002-R  # ZRQAM1
HWPTS0  025774-R  # ZRQAM1
HWPTS1  025776-R  # ZRQAM1
HWPT.B  025770-R  # ZRQAM1
HWPT.D  025772-R  # ZRQAM1
HWPT.I  025764-R  # ZRQAM1
HWPT.V  025766-R  # ZRQAM1
HWQ1    002460-R  # ZRQAM1    ZRQAM2
HWQ2    002474 R  # ZRQAM1    ZRQAM2
HWQ3    002504-R  # ZRQAM1    ZRQAM2
HWQ4    002546-R  # ZRQAM1    ZRQAM2
HWQ5    002564-R  # ZRQAM1    ZRQAM2
HWQ6A   002634-R  # ZRQAM1    ZRQAM2
HWQ6B   002706-R  # ZRQAM1    ZRQAM2
HWQ7A   002762-R  # ZRQAM1    ZRQAM2
HWQ7B   003032-R  # ZRQAM1    ZRQAM2
HWQ8    003102-R  # ZRQAM1    ZRQAM2
HWQ9    003160-R  # ZRQAM1    ZRQAM2
IBE     010000    # ZRQAM1  # ZRQAM2  # ZRQAM3
IDU     000040    # ZRQAM1  # ZRQAM2  # ZRQAM3
IER     020000    # ZRQAM1  # ZRQAM2  # ZRQAM3
INIT.I  054040-R  # ZRQAM3
INIT.O  101022-R  # ZRQAM1    ZRQAM2    ZRQAM3
INIT.T  044576-R  # ZRQAM3
INI.CT  045570-R  # ZRQAM3
INI.RR  047614-R  # ZRQAM3
INT.GE  046454-R  # ZRQAM3
IN.IOD  034704-R  # ZRQAM2    ZRQAM3
IODQ    100634-R  # ZRQAM1    ZRQAM2    ZRQAM3
IODQ.I  100644-R  # ZRQAM1    ZRQAM2    ZRQAM3
IODQ.O  100646-R  # ZRQAM1    ZRQAM2    ZRQAM3
IO.RET  061062-R  # ZRQAM3
IPKT.A  076260-R  # ZRQAM1    ZRQAM2    ZRQAM3
IRDRX.  074124-R  # ZRQAM1    ZRQAM2    ZRQAM3
ISR     000100    # ZRQAM1  # ZRQAM2  # ZRQAM3
IXE     004000    # ZRQAM1  # ZRQAM2  # ZRQAM3
LOE     040000    # ZRQAM1  # ZRQAM2  # ZRQAM3
LOT     000010    # ZRQAM1  # ZRQAM2  # ZRQAM3
L$ACP   002110-R  # ZRQAM1
L$APT   002036-R  # ZRQAM1
L$AU    033240-R    ZRQAM1  # ZRQAM2
L$AUT   002070-R  # ZRQAM1
```

GLOBAL CROSS REFERENCE CREF V02

SYMBOL	VALUE	REFERENCES...
L$AUTO	032242-R	ZRQAM1 # ZRQAM2
L$CCP	002106 R	# ZRQAM1
L$CLEA	032542-R	ZRQAM1 # ZRQAM2
L$CO	002032-R	# ZRQAM1
L$DEPO	002011-R	# ZRQAM1
L$DESC	026130-R	ZRQAM1 # ZRQAM2
L$DESP	002076-R	# ZRQAM1
L$DEVP	002060-R	# ZRQAM1
L$DISP	002124-R	# ZRQAM1
L$DLY	002116-R	# ZRQAM1 ZRQAM2 ZRQAM3
L$DTP	002040-R	# ZRQAM1
L$DTYP	002034-R	# ZRQAM1
L$DU	033146-R	ZRQAM1 # ZRQAM2
L$DUT	002072-R	# ZRQAM1
L$DVTY	026110-R	ZRQAM1 # ZRQAM2
L$EF	002052-R	# ZRQAM1
L$ENVI	002044-R	# ZRQAM1
L$ERRT	002126-R	# ZRQAM1
L$ETP	002102-R	# ZRQAM1
L$EXP1	002046-R	# ZRQAM1
L$EXP4	002064-R	# ZRQAM1
L$EXP5	002066-R	# ZRQAM1
L$HARD	026154-R	ZRQAM1 # ZRQAM2
L$HIME	002120-R	# ZRQAM1 ZRQAM2
L$HPCP	002016-R	# ZRQAM1
L$HPTP	002022-R	# ZRQAM1
L$HRDL	026152-R	# ZRQAM2
L$HW	025764-R	# ZRQAM1
L$HWLE	025762-R	# ZRQAM1
L$ICP	002104-R	# ZRQAM1
L$INIT	032230-R	ZRQAM1 # ZRQAM2
L$LADP	002026-R	# ZRQAM1
L$LAST	103020-R	ZRQAM1 # ZRQAM4
L$LOAD	002100-R	# ZRQAM1
L$LUN	002074-R	# ZRQAM1 ZRQAM2 ZRQAM3
L$MREV	002050-R	# ZRQAM1
L$NAME	002000-R	# ZRQAM1
L$NDHR	026324-R	# ZRQAM2
L$NDHW	026010-R	# ZRQAM1
L$NDSF	026624-R	# ZRQAM2
L$NDSW	026100-R	# ZRQAM1
L$PRIO	002042-R	# ZRQAM1
L$PROT	026102-R	# ZRQAM1
L$PRT	002112-R	# ZRQAM1
L$REPP	002062-R	# ZRQAM1
L$REV	G02010-R	# ZRQAM1
L$RPT	027462-R	ZRQAM1 # ZRQAM2
L$SFTL	026326-R	# ZRQAM2
L$SOFT	026330-R	ZRQAM1 # ZRQAM2
L$SPC	002056-R	# ZRQAM1
L$SPCP	002020-R	# ZRQAM1
L$SPTP	002024-R	# ZRQAM1

SYMBOL	VALUE	REFERENCES...		
L$STA	002030-R	# ZRQAM1		
L$SW	026014-R	# ZRQAM1		
L$SWLE	026012-R	# ZRQAM1		
L$TEST	002114-R	# ZRQAM1		
L$TIML	002014-R	# ZRQAM1		
L$UNIT	002012-R	# ZRQAM1	ZRQAM2	ZRQAM3
MAN.TS	026074-R	# ZRQAM1	ZRQAM3	
MD.INI	053700-R	# ZRQAM3		
MINUTE	100730-R	# ZRQAM1	ZRQAM2	ZRQAM3
MODULA	035632-R	# ZRQAM2	ZRQAM3	
MSCP.P	074550-R	# ZRQAM1	ZRQAM2	ZRQAM3
MSG.01	010252-R	# ZRQAM1	ZRQAM2	
MSG.02	010304-R	# ZRQAM1	ZRQAM3	
MSG.03	010340-R	# ZRQAM1	ZRQAM3	
MULTI.	053234-R	# ZRQAM3		
NAME.H	026006-R	# ZRQAM1		
NAME.L	026004-R	# ZRQAM1		
NEX	100712-R	# ZRQAM1	ZRQAM2	ZRQAM3
NEXT.P	100726-R	# ZRQAM1	ZRQAM2	ZRQAM3
NEX.TR	033250-R	# ZRQAM2	ZRQAM3	
NULL	005100-R	# ZRQAM1	ZRQAM2	
OFF	000002	# ZRQAM1	# ZRQAM2	# ZRQAM3
OF.RC	100704-R	# ZRQAM1	ZRQAM2	ZRQAM3
ON	000001	# ZRQAM1	# ZRQAM2	# ZRQAM3
OUT.IO	034646-R	# ZRQAM2	ZRQAM3	
OVF.CH	063530-R	# ZRQAM3		
PARITY	033260-R	# ZRQAM2	ZRQAM3	
PKT.US	076262-R	# ZRQAM1	ZRQAM2	ZRQAM3
PNT	001000	# ZRQAM1	# ZRQAM2	# ZRQAM3
POLL.C	065540-R	# ZRQAM3		
POLL.R	065640-R	# ZRQAM3		
PRI	002000	# ZRQAM1	# ZRQAM2	# ZRQAM3
PRI00	000000	# ZRQAM1	# ZRQAM2	# ZRQAM3
PRI01	000040	# ZRQAM1	# ZRQAM2	# ZRQAM3
PRI02	000100	# ZRQAM1	# ZRQAM2	# ZRQAM3
PRI03	000140	# ZRQAM1	# ZRQAM2	# ZRQAM3
PRI04	000200	# ZRQAM1	# ZRQAM2	# ZRQAM3
PRI05	000240	# ZRQAM1	# ZRQAM2	# ZRQAM3
PRI06	000300	# ZRQAM1	# ZRQAM2	# ZRQAM3
PRI07	000340	# ZRQAM1	# ZRQAM2	# ZRQAM3
PROC.R	060702-R	# ZRQAM3		
PTCH1	002136-R	# ZRQAM1		
PTCH2	002210-R	# ZRQAM1		
PTCH3	002262-R	# ZRQAM1		
PTCH4	002334-R	# ZRQAM1		
PTCH5	002406-R	# ZRQAM1		
PUTA.B	034606-R	# ZRQAM2	ZRQAM3	
PUT.IO	034542-R	# ZRQAM2	ZRQAM3	
PUT.PK	034204-R	# ZRQAM2	ZRQAM3	
PUT.RE	034452-R	# ZRQAM2	ZRQAM3	
P.INDE	101006-R	# ZRQAM1	ZRQAM2	ZRQAM3
QIO	100670-R	# ZRQAM1	ZRQAM2	ZRQAM3

GLOBAL CROSS REFERENCE CREF V02

SYMBOL	VALUE	REFERENCES...		
QIO.FU	057116-R	# ZRQAM3		
QIO.GE	054524-R	# ZRQAM3		
QIO.LB	057436-R	# ZRQAM3		
QIO.OK	054244-R	# ZRQAM3		
QIO.OU	054452-R	# ZRQAM3		
QIO.SI	060240-R	# ZRQAM3		
QIO.UN	055512-R	# ZRQAM3		
RANDOM	074506-R	# ZRQAM1	ZRQAM2	ZRQAM3
RANDY	055234-R	# ZRQAM3		
RDM.CN	074504-R	# ZRQAM1	ZRQAM2	ZRQAM3
RDRX.A	074122-R	# ZRQAM1	ZRQAM2	ZRQAM3
RDRX.E	025372-R	# ZRQAM1	ZRQAM2	
RD.COU	101010-R	# ZRQAM1	ZRQAM2	ZRQAM3
REG.EX	045714-R	# ZRQAM3		
RETPKT	076276-R	# ZRQAM1	ZRQAM2	ZRQAM3
ROUND.	063604-R	# ZRQAM3		
RPS.RE	064566-R	# ZRQAM3		
RPT1	010372-R	# ZRQAM1	ZRQAM2	
RPT10	011102-R	# ZRQAM1	ZRQAM2	
RPT11	011170-R	# ZRQAM1	ZRQAM2	
RPT12	011236-R	# ZRQAM1	ZRQAM2	
RPT13	011304-R	# ZRQAM1	ZRQAM2	
RPT14	011404-R	# ZRQAM1	ZRQAM2	
RPT15	011502-R	# ZRQAM1	ZRQAM2	
RPT16	011602-R	# ZRQAM1	ZRQAM2	
RPT2	010456-R	# ZRQAM1	ZRQAM2	
RPT3	010522-R	# ZRQAM1	ZRQAM2	
RPT4	010606-R	# ZRQAM1	ZRQAM2	
RPT5	010652-R	# ZRQAM1	ZRQAM2	
RPT6	010740-R	# ZRQAM1	ZRQAM2	
RPT7	011004-R	# ZRQAM1	ZRQAM2	
RPT8	011022-R	# ZRQAM1	ZRQAM2	
RPT9	011050-R	# ZRQAM1	ZRQAM2	
RP.ADD	077050-R	# ZRQAM1	ZRQAM2	ZRQAM3
RP.IND	077046-R	# ZRQAM1	ZRQAM2	ZRQAM3
RP.USE	077036-R	# ZRQAM1	ZRQAM2	ZRQAM3
SA.REG	100706-R	# ZRQAM1	ZRQAM2	ZRQAM3
SB.COD	100700-R	# ZRQAM1	ZRQAM2	ZRQAM3
SC.CLK	022610-R	# ZRQAM1	ZRQAM2	
SC.CON	017506-R	# ZRQAM1	ZRQAM2	
SC.CTO	022052-R	# ZRQAM1	ZRQAM2	
SC.DIS	020104-R	# ZRQAM1	ZRQAM2	
SC.DST	020514-R	# ZRQAM1	ZRQAM2	
SC.DS2	020570-R	# ZRQAM1	ZRQAM2	
SC.DUP	017530-R	# ZRQAM1	ZRQAM2	
SC.ECC	020642-R	# ZRQAM1	ZRQAM2	
SC.ECD	020724-R	# ZRQAM1	ZRQAM2	
SC.EC1	021174-R	# ZRQAM1	ZRQAM2	
SC.EC2	021224-R	# ZRQAM1	ZRQAM2	
SC.EC3	021254-R	# ZRQAM1	ZRQAM2	
SC.EC4	021306-R	# ZRQAM1	ZRQAM2	
SC.EC5	021336-R	# ZRQAM1	ZRQAM2	

GLOBAL CROSS REFERENCE CREF V02

SYMBOL	VALUE	REFERENCES...		
SC.EC6	021366-R	# ZRQAM1	ZRQAM2	
SC.EC7	021416-R	# ZRQAM1	ZRQAM2	
SC.EC8	021450 R	# ZRQAM1	ZRQAM2	
SC.EC9	021502-R	# ZRQAM1	ZRQAM2	
SC.EDC	022202-R	# ZRQAM1	ZRQAM2	
SC.FCT	021126-R	# ZRQAM1	ZRQAM2	
SC.FER	020176-R	# ZRQAM1	ZRQAM2	
SC.FE2	020264-R	# ZRQAM1	ZRQAM2	
SC.FUL	020776-R	# ZRQAM1	ZRQAM2	
SC.HWP	021604-R	# ZRQAM1	ZRQAM2	
SC.IDS	022242-R	# ZRQAM1	ZRQAM2	
SC.INR	017622-R	# ZRQAM1	ZRQAM2	
SC.INV	017654-R	# ZRQAM1	ZRQAM2	
SC.IOP	020032-R	# ZRQAM1	ZRQAM2	
SC.ISH	020354-R	# ZRQAM1	ZRQAM2	
SC.IS2	020434-R	# ZRQAM1	ZRQAM2	
SC.NBB	023060-R	# ZRQAM1	ZRQAM2	
SC.NXM	021762-R	# ZRQAM1	ZRQAM2	
SC.ODA	021710-R	# ZRQAM1	ZRQAM2	
SC.ODB	021740-R	# ZRQAM1	ZRQAM2	
SC.ONL	017560-R	# ZRQAM1	ZRQAM2	
SC.PAR	022016-R	# ZRQAM1	ZRQAM2	
SC.POE	022472-R	# ZRQAM1	ZRQAM2	
SC.PSP	022734-R	# ZRQAM1	ZRQAM2	
SC.RCT	020756-R	# ZRQAM1	ZRQAM2	
SC.RDY	022526-R	# ZRQAM1	ZRQAM2	
SC.REF	023130-R	# ZRQAM1	ZRQAM2	
SC.REP	023016-R	# ZRQAM1	ZRQAM2	
SC.RSP	022636-R	# ZRQAM1	ZRQAM2	
SC.SAF	021644-R	# ZRQAM1	ZRQAM2	
SC.SDI	017462-R	# ZRQAM1	ZRQAM2	
SC.SDS	022124-R	# ZRQAM1	ZRQAM2	
SC.SON	017602-R	# ZRQAM1	ZRQAM2	
SC.SRI	022404-R	# ZRQAM1	ZRQAM2	
SC.SRT	022312-R	# ZRQAM1	ZRQAM2	
SC.SUR	022704-R	# ZRQAM1	ZRQAM2	
SC.SWP	021544-R	# ZRQAM1	ZRQAM2	
SC.UNK	017672-R	# ZRQAM1	ZRQAM2	
SC.VOL	017752-R	# ZRQAM1	ZRQAM2	
SC.576	021052-R	# ZRQAM1	ZRQAM2	
SEND	035156-R	# ZRQAM2	ZRQAM3	
SEQUEN	066202-R	# ZRQAM3		
SET.CP	033424-R	# ZRQAM2	ZRQAM3	
SET.CT	047716-R	# ZRQAM3		
SET.UP	033520-R	# ZRQAM2	ZRQAM3	
SFPTBL	026014-R	# ZRQAM1		
SFT.MS	025604-R	# ZRQAM1	ZRQAM3	
SOFT.E	070346-R	# ZRQAM3		
SPACE4	025736-R	# ZRQAM1	ZRQAM2	
STEP	100702-R	# ZRQAM1	ZRQAM2	ZRQAM3
ST.COD	100676-R	# ZRQAM1	ZRQAM2	ZRQAM3
SWEEP	064434-R	# ZRQAM3		

GLOBAL CROSS REFERENCE CREF V02

SYMBOL	VALUE	REFERENCES...			
SWM1	004706 R	# ZRQAM1	ZRQAM2		
SWP.DP	026022-R	# ZRQAM1	ZRQAM3		
SWP.ER	026014-R	# ZRQAM1	ZRQAM3		
SWP.FL	026020-R	# ZRQAM1	ZRQAM2	ZRQAM3	
SWP.RA	026024-R	# ZRQAM1	ZRQAM3		
SWP.TI	026026-R	# ZRQAM1	ZRQAM3		
SWP.UC	026030 R	# ZRQAM1	ZRQAM3		
SWP.UD	026032-R	# ZRQAM1	ZRQAM3		
SWP.XF	026016-R	# ZRQAM1	ZRQAM3		
SWQ1	003260-R	# ZRQAM1	ZRQAM2		
SWQ10	003532-R	# ZRQAM1	ZRQAM2		
SWQ11	003576-R	# ZRQAM1	ZRQAM2		
SWQ12	003630-R	# ZRQAM1	ZRQAM2		
SWQ13	003726-R	# ZRQAM1	ZRQAM2		
SWQ14	004004-R	# ZRQAM1	ZRQAM2		
SWQ15	004056-R	# ZRQAM1	ZRQAM2		
SWQ17	004126-R	# ZRQAM1	ZRQAM2		
SWQ19	004224-R	# ZRQAM1	ZRQAM2		
SWQ2	003302-R	# ZRQAM1	ZRQAM2		
SWQ20	004314-R	# ZRQAM1	ZRQAM2		
SWQ21	004402-R	# ZRQAM1	ZRQAM2		
SWQ22	004466-R	# ZRQAM1	ZRQAM2		
SWQ23	004526-R	# ZRQAM1	ZRQAM2		
SWQ24	004600-R	# ZRQAM1	ZRQAM2		
SWQ26	004644-R	# ZRQAM1	ZRQAM2		
SWQ27	005004-R	# ZRQAM1	ZRQAM2		
SWQ28	005030-R	# ZRQAM1	ZRQAM2		
SWQ4	003362-R	# ZRQAM1	ZRQAM2		
SWQ7	003404-R	# ZRQAM1	ZRQAM2		
SWQ9	003456-R	# ZRQAM1	ZRQAM2		
TALLY	074146-R	# ZRQAM1	ZRQAM2	ZRQAM3	
TEMP1	100720-R	# ZRQAM1	ZRQAM2	ZRQAM3	
TEMP2	100722-R	# ZRQAM1	ZRQAM2	ZRQAM3	
TIME	033342-R	# ZRQAM2	ZRQAM3		
TRK.SG	074500-R	# ZRQAM1	ZRQAM2	ZRQAM3	
TST.PA	026076-R	# ZRQAM1	ZRQAM3		
TYPER	100742-R	# ZRQAM1	ZRQAM2	ZRQAM3	
TYPEW	100752-R	# ZRQAM1	ZRQAM2	ZRQAM3	
T$FREE	103140-R	# ZRQAM4			
T$PTMV	000004	ZRQAM1	# ZRQAM4		
T.ADDR	074476-R	# ZRQAM1	ZRQAM2	ZRQAM3	
T1	044562-R	ZRQAM1	# ZRQAM3		
UAM	000200	# ZRQAM1	# ZRQAM2	# ZRQAM3	
UPD.IO	062662-R	# ZRQAM3			
VEC.BR	046126-R	# ZRQAM3			
WAIT	035614-R	# ZRQAM2	ZRQAM3		
XX13	017130-R	# ZRQAM1	ZRQAM2		
XX23	017152-R	# ZRQAM1	ZRQAM2		
XX32	017206-R	# ZRQAM1	ZRQAM2		
XX33	017234-R	# ZRQAM1	ZRQAM2		
XX34	017272-R	# ZRQAM1	ZRQAM2		
$END.L	103142-R	# ZRQAM4			

GLOBAL CROSS REFERENCE CREF V02

SYMBOL	VALUE	REFERENCES...				
$SAVE2	073640-R	B16MUL	# B16SAV	ZRQAM2	ZRQAM3	
$SAVE3	073654-R	# B16SAV	ZRQAM2	ZRQAM3		
$SAVE4	073672 R	# B16SAV	ZRQAM2	ZRQAM3		
$SAVE5	073712-R	B16MUL	# B16SAV	ZRQAM2	ZRQAM3	