



**DATA GENERAL
CORPORATION**

Southboro,
Massachusetts 01772
(617) 485-9100

PROGRAM

NOVA 800 Instruction Timer

TAPES

Binary 095-000046

ABSTRACT

NOVA 800 Instruction Timer is a maintenance program designed to test the CPU clock circuits by timing the instruction set. The 100 MS teletype clock is used for calibration and is assumed accurate.

```

01
02      )
03
04      )1.  ABSTRACT
05      )
06      )
07      )
08      )
09      )
10
11      )2.  MACHINE REQUIREMENTS
12      )
13      )
14
15      )3.  SWITCH SETTINGS
16      )
17      )
18
19      )4.  OPERATING PROCEEDURE
20      )4.1  LOAD THE PROGRAM VIA THE BINARY LOADER
21      )4.2  SET SWITCHES TO 3
22      )4.3  PRESS START
23      )4.4  THE PROGRAM WILL PRINT RUB-OUT CHARACTERS
24      )
25
26      )5.  PROGRAM OUTPUT
27      )5.1  WHEN THE PROGRAM IS STARTED AT LOCATION
28      )
29      )
30      )
31      )
32      )
33      )5.2  FOR EXAMPLE:
34      )
35      )
36      )
37      )
38      )
39      )
40      )
41      )
42      )
43      )
44      )
45      )
46      )
47      )
48      )
49      )
50      )
51      )
52      )
53      )
54      )
55      )
56      )
57      )

```

NOVA 800 INSTRUCTION TIMER

NOVA 800 INSTRUCTION TIMER IS A MAINTENANCE PROGRAM DESIGNED TO TEST THE CPU CLOCK CIRCUITS BY TIMING THE INSTRUCTION SET. THE 100 MS TELETYPE CLOCK IS USED FOR CALIBRATION AND IS ASSUMED ACCURATE.

NOVA-800 PROCESSOR
A TYPE 33 OR 35 TELETYPE

STARTING ADDRESS=2 PRINT TIMES
STARTING ADDRESS=3 PRINT TIMES IF IN ERROR

LOAD THE PROGRAM VIA THE BINARY LOADER
SET SWITCHES TO 3
PRESS START
THE PROGRAM WILL PRINT RUB-OUT CHARACTERS AND ANY INSTRUCTION TIME IN ERROR.

WHEN THE PROGRAM IS STARTED AT LOCATION THREE, ONLY THOSE INSTRUCTIONS WITH TIMING MALFUNCTIONS WILL BE PRINTED. WHEN THE PROGRAM IS STARTED AT LOCATION TWO EACH INSTRUCTION TESTED ALONG WITH ITS EXECUTION TIME WILL BE PRINTED.

FOR EXAMPLE:

INSTRUCTION	EXECUTION TIMES
MOV 0,0	803
ADD 0,0	803
AND 0,0	803
COM 0,0,SKP	1003
LDA 0,0	1603
STA 0,0	1603
ISZ 0	1802
DSZ 0	1802
JMP .+1	804
JSR .+1	804
LDA 0,0,2	1603
LDA 0,00	2402
LDA 0,#21	2602
LDA 0,#31	2601
LDA 0,#(00)	3201
DIA 0,0	2202
DOA 0,0	2202
NIOS 0	2801
INTA 0	2202
SKPBN 0	1403
SKPBZ 0	1599
DIVIDE	8794
MULTIPLY	8794

A 0002 .MAIN

```
01
02      )6.      PROGRAM DESCRIPTION
03      )6.1
04      )
05      )
06      )
07      )
08      )
09      )
10      )
11      )
12      )
13      )
14      )
15      )
16      )
17      )
18      )
19      )
20      )
21      )
22      )6.2
23      )
24      )
25      )
26      )
27      )
28
29      )7.      LIMITATIONS/MISC
30      )
31      )
32      )
33      )
34      )
```

THE FOLLOWING PROCEDURE IS USED TO CALCULATE THE INSTRUCTION TIMES. THE TELETYPE IS COM- MANED TO PRINT A CHARACTER. A "INC" INSTRUCTION THEN RECORDS THE NUMBER OF TIMES A SMALL LOOP IS ITERATED BEFORE THE TELETYPE BUSY FLAG IS ZERO. THIS COUNT REPRESENTS 100 MILLISECONDS, AND IS USED FOR CALIBRATION. A 1000 WORD BUFFER IS FILLED WITH THE INST- RUCTION TO BE TIMED. A CHAR. IS AGAIN SENT TO THE TELETYPE AND PROGRAM CONTROL IS TRANS- FERED TO THE BUFFER. THE BUFFER IS EXE. 10 TIMES. WHEN THE INSTRUCTION IN QUESTION HAS BEEN EXECUTED 10000 TIMES (1000*10) THE PRO- GRAM THEN TIMES THE REMAINDER OF THE TTY BUSY FLAG. THIS VALUE IS SUBTRACTED FROM THE 100MS CALIB. TIME. THE DIFFERENCE REPRESENTS THE TIME FOR 10000 INSTRUCTIONS. THIS TIME IS CONVERTED TO NANO SECONDS FOR PRINTING.

THE NUMBER +1 IS MULTIPLIED BY +2. IF THE RESULT IS +2 THE MUL/DIV OPTION IS ASSUMED TO EXIST. IF THE RESULT IS NOT +2 THE MUL/DIV TIMES ARE NOT TESTED. TIMES REPRESENT THE NUMBER (125252) MULTIPLIED AND DIVIDED BY THE NUMBER +1.

THIS PROGRAM WILL NOT FUNCTION PROPERLY WITH A TYPE 37 TELETYPE. PROGRAM MEASUREMENTS FALL WITHIN + OR - 6NS. A MEASUREMENT OUTSIDE THE RANGE + OR - 20NS IS CONSIDERED IN ERROR.

A 0003 .MAIN

01

02 000002 .LOC 2

03 00002 002050 JMP #B1

04 00003 002051 JMP #B2

05

06 000050 .LOC 50

07

08 00050 000400 B1: BEGIN

09 00051 000401 B2: BEGIN+1

10 00052 000000 PSWIT: 0

11 00053 000000 CALIBR: 0

12 00054 003210 ICRLF: CRLF

13 00055 003065 IMESS: MESS

14 00056 000570 CITAB: ITABL-1

15 00057 001110 Ibuff: BBUF

16 00060 003060 Fbuff: FBUF

17 00061 023420 C23420: 23420

18 00062 000000 TIMEX: 0

19 00063 000012 C12: 12

20 00064 003107 IPDEC: PDEC

21 00065 000000 MSAV: 0

22 00066 177760 M20: -20

23 00067 100000 ZPOINT: #0

24 00070 000060 C60: 60

25 00071 000024 C24: 24

26 00072 100001 CSKP1: COM 0,0,SKP

27 00073 063500 CSKP2: SKPBZ 0

28 00074 073101 CDIV: DOCS 2,1

29 00075 073301 CMUL: DOCP 2,1

30 00076 000000 MDOPT: 0

31 00077 000000 TEN0: 0

32 00100 125252 C5252: 125252

33

34 000400 .LOC 400

35

36 00400 102401 BEGIN: SUB 0,0,SKP

!PRINT

37 00401 102000 ADC 0,0

!DON'T PRINT

38 00402 040052 STA 0,PSWIT

39 00403 102400 SUB 0,0

40 00404 126520 SUBZL 1,1

!LOOK FOR M/D OPTION

41 00405 131120 MOVZL 1,2

42 00406 073301 DOCP 2,1

!MULTIPLY

43 00407 146400 SUB 2,1

44 00410 044076 STA 1,MDOPT

!C(1)=0 IF PRESENT.

45 00411 004524 JSR TIMER

46 00412 152000 ADC 2,2

47 00413 071111 DOAS 2,TTO

48 00414 004521 JSR TIMER

49 00415 071111 DOAS 2,TTO

50 00416 004517 JSR TIMER

!CALIBRATE ON

51 00417 040053 STA 0,CALIBR

!100 MS CLOCK.

52

53

A 0004 .MAIN

```
01
02 00420 020052 BEG2: LDA 0,PSWIT
03 00421 101004 MOV 0,0,SZR
04 00422 000405 JMP BEG1 ;DON'T PRINT
05 00423 006054 JSR 0,ICRLF ;HEADER
06 00424 006054 JSR 0,ICRLF
07 00425 006055 JSR 0,IMESS
08 00426 000677 HEADER
09
10 00427 020056 BEG1: LDA 0,CITAB ;INITIALIZE INST
11 00430 040020 STA 0,20 ;TO BE TIMED.
12 00431 034076 BEG1: LDA 3,MDOPT
13 00432 030075 LDA 2,CMUL
14 00433 024074 LDA 1,CDIV
15 00434 022020 LDA 0,020
16 00435 106404 SUB 0,1,SZR
17 00436 112405 SUB 0,2,SNR
18 00437 175005 MOV 3,3,SNR ;A M/D INSTRUCTION
19 00440 101005 MOV 0,0,SNR
20 00441 000757 JMP BEG2 ;END OF TABLE
21 00442 024063 LDA 1,C12
22 00443 030072 LDA 2,CSKP1
23 00444 034073 LDA 3,CSKP2 ;IF SKP TYPE INST EXE
24 00445 142414 SUB# 2,0,SZR ;THE BUFFER 20 TIMES
25 00446 162415 SUB# 3,0,SNR
26 00447 024071 LDA 1,C24
27 00450 044077 STA 1,TEN0
28 00451 030057 LDA 2,IBUFF ;FILL A 1K BUFFER
29 00452 034060 LDA 3,FBUFF ;WITH INSTRUCTIONS.
30 00453 041000 STA 0,0,2
31 00454 151400 INC 2,2
32 00455 156404 SUB 2,3,SZR
33 00456 000774 JMP .-4
34
35 00457 054000 INIT: STA 3,0 ;INIT FOR 0 TEST.
36 00460 054021 STA 3,21
37 00461 152220 ADCZR 2,2
38 00462 151220 MOVZR 2,2
39 00463 050031 STA 2,31
40 00464 004451 JSR TIMER ;WAIT IF TTO BUSY.
41 00465 071111 DOAS 2,TTO
42 00466 004447 JSR TIMER
43 00467 102400 SUB 0,0
44 00470 024100 LDA 1,C5252
45 00471 034057 LDA 3,IBUFF
46 00472 030077 LDA 2,TEN0
47 00473 151200 MOVR 2,2
48 00474 151203 MOVR 2,2,SNC
49 00475 000404 JMP .+4
50 00476 152520 SUBZL 2,2 ;NO-SKIP INST
51 00477 071111 DOAS 2,TTO ;START THE TTO
52 00500 001410 JMP 10,3 ;EXIT TO BUFFER
53
54 00501 152520 SUBZL 2,2 ;SKIP INSTRUCTION
55 00502 071111 DOAS 2,TTO ;START TTO
56 00503 001550 JMP 150,3 ;EXIT TO BUFFER
```

```

A 0005 ,MAIN
01
02 00504 004431 TINSR: JSR TIMER           )TIME TTO
03 00505 024053         LDA 1,CALIBR
04 00506 106400         SUB 0,1           )C(1)=10K INST TIME
05 00507 030061         LDA 2,C23420
06 00510 004432         JSR MULT
07 00511 030053         LDA 2,CALIBR           )C(1)=TIME PER INST
08 00512 004442         JSR .DIV             )IN NANO SECONDS,
09
10 00513 044062 TLOOK: STA 1,TIMEX           )C(1)=ACTUAL TIME
11 00514 034020         LDA 3,20             )C(2)=CORRECT TIME
12 00515 031430         LDA 2,ITABE=ITABL,3
13 00516 132423         SUBZ 1,2,SNC           )THEORY=ACTUAL
14 00517 150400         NEG 2,2             )C(2)=+DIFFERENCE
15 00520 020071         LDA 0,C24             )C(0)=20 NANO SECONDS
16 00521 112440         SUBO 0,2
17 00522 030052         LDA 2,PSWIT
18 00523 151006         MOV 2,2,SEZ
19 00524 000705         JMP BEG
20
21 00525 035457         LDA 3,IMEST=ITABL,3
22 00526 054403         STA 3,.,+3
23 00527 006054         JSR @ICRLF
24 00530 006055         JSR @IMESS           )MESSAGE ABOUT
25 00531 000000         0                               )INSTRUCTION TIMED.
26 00532 024062         LDA 1,TIMEX
27 00533 006064         JSR @IPDEC           )PRINT THE TIME.
28 00534 000675         JMP BEG
29
30 00535 102000 TIMER: ADC 0,0           )RECORD THE TIME
31 00536 101400         INC 0,0           )FOR TTO TO FINISH.
32 00537 063511         SKPBZ TTO
33 00540 000776         JMP .-2
34 00541 001400         JMP 0,3

```

A 0006 .MAIN

```
01
02 00542 102400 MULTI:  SUBC 0,0          /C(1)*C(2)
03 00543 054065          STA 3,MSAV        /RESULT TO C(0),C(1)
04 00544 034066          LDA 3,M20
05 00545 125203 MLOOP:   MOVR 1,1,SNC
06 00546 101201          MOVR 0,0,SKP
07 00547 143220          ADDZR 2,0
08 00550 175404          INC 3,3,SZR
09 00551 000774          JMP MLOOP
10 00552 125260          MOVCR 1,1
11 00553 002065          JMP @MSAV
12
13 00554 054065 .DIV:    STA 3,MSAV        /C(0),C(1)/C(2)
14 00555 034066          LDA 3,M20        /C(0)=REMAINDER
15 00556 125120          MOVZL 1,1        /C(1)=QUOIENT
16 00557 101100 DLOOP:   MOVL 0,0
17 00560 142412          SUB# 2,0,SZC
18 00561 142400          SUB 2,0
19 00562 125100          MOVL 1,1
20 00563 175404          INC 3,3,SZR
21 00564 000773          JMP DLOOP
22 00565 151220          MOVZR 2,2        /ROUND UP
23 00566 142432          SUBZ# 2,0,SZC
24 00567 125400          INC 1,1
25 00570 002065          JMP @MSAV
26
27 00571 101000 ITABL:   MOV 0,0          /INST TO BE TIMED
28 00572 103000          ADD 0,0
29 00573 103400          AND 0,0
30 00574 100001          COM 0,0,SKP
31 00575 020000          LDA 0,0
32 00576 040000          STA 0,0
33 00577 010000          ISZ 0
34 00600 014000          DSZ 0
35 00601 000401          JMP .+1
36 00602 004401          JSR .+1
37 00603 021000          LDA 0,0,2
38 00604 022000          LDA 0,00
39 00605 022021          LDA 0,021
40 00606 022031          LDA 0,031
41 00607 022067          LDA 0,0ZPOINT
42 00610 060400          DIA 0,0
43 00611 061000          DOA 0,0
44 00612 060100          NIOS 0
45 00613 061477          INTA 0
46 00614 063400          SKPBN 0
47 00615 063500          SKPBZ 0
48 00616 073101          DOCS 2,1
49 00617 073301          DOCP 2,1
50 00620 000000          0
```

A 0007 .MAIN

01

02 000012 .RDX 10

03

04	00021	001440	ITABE:	800
05	00022	001440		800
06	00023	001440		800
07	00024	001750		1000
08	00025	003100		1600
09	00026	003100		1600
10	00027	003410		1800
11	00030	003410		1800
12	00031	001440		800
13	00032	001440		800
14	00033	003100		1600
15	00034	004540		2400
16	00035	005050		2600
17	00036	005050		2600
18	00037	006200		3200
19	00040	004230		2200
20	00041	004230		2200
21	00042	005360		2800
22	00043	004230		2200
23	00044	002570		1400
24	00045	003100		1600
25	00046	021140		8800
26	00047	021140		8800

!CORRECT TIMES.

27

28 000010 .RDX 8

29

30	00050	000715	IMEST:	I1
31	00051	000722		I2
32	00052	000727		I3
33	00053	001061		I3.1
34	00054	000734		I4
35	00055	000741		I5
36	00056	000746		I6
37	00057	000752		I7
38	00060	000756		I8
39	00061	000763		I9
40	00062	001070		I9.1
41	00063	000770		I10
42	00064	000776		I11
43	00065	001004		I12
44	00066	001012		I13
45	00067	001021		I14
46	00070	001026		I15
47	00071	001076		I15.1
48	00072	001033		I16
49	00073	001040		I17
50	00074	001103		I17.1
51	00075	001045		I18
52	00076	001052		I19

A 0000 .MAIN

01

02

HEADER: .TXTE |INSTRUCTION EXECUTION TIMES|

00677 047311
00700 152123
00701 052722
00702 152303
00703 147711
00704 120116
00705 154305
00706 141705
00707 152125
00710 147711
00711 120116
00712 144724
00713 142515
00714 000123

03

04

I1: .TXTE |MOV 0,0 |

00715 147515
00716 120126
00717 126060
00720 004460
00721 000011

05

I2: .TXTE |ADD 0,0 |

00722 042101
00723 120104
00724 126060
00725 004460
00726 000011

06

I3: .TXTE |AND 0,0 |

00727 047101
00730 120104
00731 126060
00732 004460
00733 000011

07

I4: .TXTE |LDA 0,0 |

00734 042314
00735 120101
00736 126060
00737 004460
00740 000011

08

I5: .TXTE |STA 0,0 |

00741 152123
00742 120101
00743 126060
00744 004460
00745 000011

09

I6: .TXTE |ISZ 0 |

00746 051711
00747 120132
00750 004460
00751 000011

10

I7: .TXTE |DSZ 0 |

00752 051504
00753 120132
00754 004460
00755 000011

11

I8: .TXTE |JMP .+1 |

00756 046712

	0000	.MAIN		
	00757	120120		
	00760	025456		
	00761	004661		
	00762	000011		
01			I01	.TXTE IJSR ,+1
	00763	051712		
	00764	120322		
	00765	025456		
	00766	004661		
	00767	000011		
02			I101	.TXTE ILDA 0,00
	00770	042314		
	00771	120101		
	00772	126060		
	00773	030300		
	00774	120240		
	00775	000011		
03			I111	.TXTE ILDA 0,021
	00776	042314		
	00777	120101		
	01000	126060		
	01001	131300		
	01002	004661		
	01003	000000		
04			I121	.TXTE ILDA 0,031
	01004	042314		
	01005	120101		
	01006	126060		
	01007	031700		
	01010	004661		
	01011	000000		
05			I131	.TXTE ILDA 0,0(00)
	01012	042314		
	01013	120101		
	01014	126060		
	01015	024300		
	01016	030300		
	01017	004661		
	01020	000000		
06			I141	.TXTE IDIA 0,0
	01021	144504		
	01022	120101		
	01023	126060		
	01024	004460		
	01025	000011		
07			I151	.TXTE IDOA 0,0
	01026	147504		
	01027	120101		
	01030	126060		
	01031	004460		
	01032	000011		
08			I161	.TXTE IINTA 0
	01033	047311		
	01034	040724		
	01035	030240		
	01036	004411		
	01037	000000		
09			I171	.TXTE ISKPBN 0
	01040	045523		

```

0010 .MAIN
01041 041120
01042 120110
01043 004400
01044 000011

01
02
03          I18:  .TXTE !DIVIDE          |
01045 144504
01046 144526
01047 142504
01050 004411
01051 000000

04          I19:  .TXTE !MULTIPLY        |
01052 052515
01053 152314
01054 050311
01055 054714
01056 120240
01057 004640
01060 000000

05          I3.1: .TXTE !COM 0,0,SKP    |
01061 147703
01062 120115
01063 120060
01064 120060
01065 045523
01066 004520
01067 000000

06          I9.1:  .TXTE !LDA 0,0,2     |
01070 042314
01071 120101
01072 120060
01073 120060
01074 004662
01075 000000

07          I15.1: .TXTE !NIOS 0        |
01076 144516
01077 051717
01100 030240
01101 004411
01102 000000

08          I17.1: .TXTE !SKPBZ 0      |
01103 045523
01104 041120
01105 120132
01106 120060
01107 000011

09
10
11 01110 000000 BBUF:  0
12          000012 ,RDX 10
13          003060 ,LOC .+999
14          000010 ,RDX 8
15
16 03060 014077 FBUF:  DSZ TEN0
17 03061 002402          JMP 0,+2
18 03062 002402          JMP 0,+2
19 03063 001110          BBUF
20 03064 000504          TINSR

```

0011 .MAIN

A 0012 .MAIN

```
01
02      ;TTO NON INTERRUPT PACKAGE
03      ;"MESS" PRINTS ASCII MESSAGES AS SPECIFIED BY ASSEMBLR
04      ;"CHAR" PRINTS ASCII CHARACTER, C(0)R,C(0)L MUST BE 0
05      ;WILL RETURN +2 IF C(0)R=0,CORRECTS THE PARITY,33 SIMULATE
06      ;"TYPE" PRINTS C(0)R. MUST HAVE PROPER PARITY. RETURN IS
07      ;TO CALL+1.REPLACE THIS ROUTINE WITH INTERRUPT TYPE IF DESIRED.
08      ;"CRLF" PRINTS A CARRIAGE RETURN
09      ;"POCT" PRINTS C(1) IN OCTAL FOLLOWED BY A TAB
10      ;"PDEC" PRINTS C(1) IN DECIMAL,LEADING ZEROS SUPPRESSED,
11      ;FOLLOWED BY A TAB.
12
13 03066 054545 MESS:   STA 3,MESSR      ;PRINT A TEXT MESSAGE
14 03066 010544      ISZ MESSR
15 03067 031400      LDA 2,0,3      ;C(2) POINTS TO MESSAGE
16 03070 024541      LDA 1,C377     ;A 8 BIT MASK
17 03071 021000      LDA 0,0,2      ;C(2)=DATA WORD
18 03072 125112      MOVL# 1,1,SZC
19 03073 123701      ANDS 1,0,SKP
20 03074 123401      AND 1,0,SKP      ;C(0)=DATA CHARACTER RIGHT
21 03075 151400      INC 2,2      ;INC TO NEXT WORD
22 03076 124000      COM 1,1      ;FLIP MASK
23 03077 004462      JSR CHAR      ;PRINT
24 03100 000771      JMP MESS+4     ;ANOTHER
25 03101 002531      JMP @MESSR    ;LAST
26
27 03102 020525 ZOCT:  LDA 0,CH240
28 03103 101001      MOV 0,0,SKP
29
30 03104 020070 POCT:  LDA 0,C60
31 03105 030433      LDA 2,OCTAB   ;PRINT C(1) IN OCTAL
32 03106 000403      JMP ,+3
33 03107 030441 PDEC:  LDA 2,DECTB   ;PRINT C(1) IN DECIMAL
34 03110 020517      LDA 0,CH240   ;SUPPRESS LEADING ZEROS
35 03111 054447      STA 3,RADRET  ;BOTH ENTRYS PRINT NUMBER
36 03112 040445      STA 0,ZSUPP  ;THEN TAB TO NEXT POSITION
37 03113 050401      STA 2,.,+1
38 03114 000000 DECOCT: 0      ;A"LDA 2,TABLE" INSTRUCTION
39 03115 010777      ISZ ,=1
40 03116 034442      LDA 3,RADRET  ;SETUP "TAB" AT END
41 03117 020503      LDA 0,CHTAB
42 03120 151005      MOV 2,2,SNR  ;IF TABLE ENTRY=0
43 03121 000440      JMP CHAR     ;EXIT WITH TAB
44 03122 034435      LDA 3,ZSUPP  ;ZEROS SUPPRESS STUF
45 03123 102400      SUB 0,0
46 03124 146512 DECOT:  SUBL# 2,1,SZC
47 03125 000405      JMP DECP
48 03126 146400      SUB 2,1      ;FORM THE DIGIT
49 03127 034070      LDA 3,C60
50 03130 101400      INC 0,0
51 03131 000773      JMP DECOT
52 03132 151235 DECP:  MOVZR# 2,2,SNR
53 03133 034070      LDA 3,C60
54 03134 054423      STA 3,ZSUPP  ;C(0)=DIGIT
55 03135 163000      ADD 3,0      ;MAKE ASCII
56 03136 004423      JSR CHAR     ;PRINT
57 03137 000755      JMP DECOCT   ;GET NEXT DIGIT
58
```

```

A 0013 .MAIN
01
02
03 03140 030425 OCTAB: LDA 2,.,+1+,-DECOCT
04 03141 100000      100000
05 03142 010000      10000
06 03143 001000      1000
07 03144 000100      100
08 03145 000010      10
09 03146 000001      1
10 03147 000000      0
11
12 03150 030435 DECTB: LDA 2,.,+1+,-DECOCT
13          000012 .RDX 10
14 03151 023420      10000
15 03152 001750      1000
16 03153 000144      100
17 03154 000012      10
18 03155 000001      1
19 03156 000000      0
20          000010 .RDX 8
21
22 03157 000000 ZSUPP: 0
23 03160 000000 RADRET: 0
24
25 03161 054442 CHAR:  STA 3,CHRET      )PRINT C(0) RIGHT
26 03162 101325      MOVZS 0,0,SNR      )RETURN +2 IF NULL
27 03163 001401      JMP 1,3
28 03164 040440      STA 0,CHSAV
29 03165 176000      ADC 3,3          )COMPUTE THE PARITY
30 03166 117000      ADD 0,3
31 03167 163404      AND 3,0,SZR
32 03170 000775      JMP .-3
33 03171 176660      SUBCR 3,3       )COMBIND PARITY WITH CHAR
34 03172 020432      LDA 0,CHSAV
35 03173 163300      ADDS 3,0
36
37 03174 034426 CHAR1: LDA 3,CHTAB      )IS THIS A TAB
38 03175 116405      SUB 0,3,SNR
39 03176 000407      JMP .+7         )YES
40 03177 004434      JSR TYPE        )NO PRINT IT
41 03200 002423      JMP 0,CHRET     )EXIT
42
43 03201 020424      LDA 0,CHORZ     )SIMULATE A TAB
44 03202 034424      LDA 3,CHAR7     )VIA 1 TO 8 SPACES
45 03203 117405      AND 0,3,SNR
46 03204 002417      JMP 0,CHRET
47 03205 020422      LDA 0,CH240
48 03206 004425      JSR TYPE
49 03207 000772      JMP .-6
50

```

A 0014 .MAIN

```
01
02
03
04 03210 054420 CRLF:   STA 3,CRLF      )SAVE RETURN
05 03211 020410        LDA 0,C215
06 03212 004747        JSR CHAR        )PRINT CARRIAGE AND LF
07 03213 020405        LDA 0,C212
08 03214 004745        JSR CHAR
09 03215 102400        SUB 0,0
10 03216 040407        STA 0,CHORZ     )CLEAR HORZ POSISTION
11 03217 002411        JMP 0CRLF      )EXIT
12
13 03220 000212 C212:   212
14 03221 000215 C215:   215
15 03222 000011 CHTAB:  11
16 03223 000000 CHRET:  0
17 03224 000000 CHSAV:  0
18 03225 000000 CHORZ:  0
19 03226 000007 CHAR7:  7
20 03227 000240 CH240:  240
21 03230 000000 CRLF:   0
22
23 03231 000377 C377:   377
24 03232 000000 MESSR:  0
25 03233 054400 TYPE:   STA 3,TYPRET    )TYPE THE C(0)R IF
26 03234 010771        ISZ CHORZ
27 03235 063511        SKPBZ TTO
28 03236 000777        JMP .-1
29 03237 061111        DOAS 0,TTO
30 03240 002401        JMP 0TYPRET
31 03241 000000 TYPRET: 0
32
33 03242 000000 LAST:   0
34
35                      .END
```